



INDEX

A

alert central, accessing [10-1](#)

alert notification

- configuring parameters for counter (table) [6-6](#)
- e-mail for counter [6-5](#)
- message [6-5](#)
- schedule [6-5](#)
- thresholds [6-5](#)

alert notification, configuring [10-5](#)

alerts

- accessing alert central [10-1](#)
- action configuration (table) [9-7](#)
- configuring actions [10-6](#)
- configuring e-mail for [10-5](#)
- configuring with Default alert action [10-6](#)
- customization (table) [9-5](#)
- emailing notification [3-5](#)
- logs, described [9-8](#)
- notification for a counter [3-5](#)
- preconfigured [9-2](#)
- scheduling notification [3-5](#)
- setting properties [10-2](#)
- suspending [10-5](#)
- thresholds [3-5](#)

C

category

- adding [6-1](#)
- deleting [6-2](#)
- renaming [6-2](#)

category tabs

described [3-2](#)

sample rates [3-3](#)

Cisco Analog Access

- perfmon object and counters [B-2](#)

Cisco Annunciator Device

- perfmon object and counters [B-2](#)

Cisco CallManager

- perfmon object and counters [B-3](#)

Cisco CallManager Attendant Console

- perfmon object and counters [B-11](#)

Cisco CallManager System Performance

- perfmon object and counters [B-12](#)

Cisco CTIManager

- perfmon object and counters [B-15](#)

Cisco Dual-Mode Mobility

- perfmon object and counters [B-15](#)

Cisco Extension Mobility

- perfmon object and counters [B-17](#)

Cisco Gatekeeper

- perfmon object and counters [B-17](#)

Cisco H.323

- perfmon object and counters [B-18](#)

Cisco Hunt Lists

- perfmon object and counters [B-19](#)

Cisco HW Conference Bridge Device

- perfmon object and counters [B-19](#)

Cisco IP Manager Assistant

- perfmon object and counters [B-20](#)

Cisco Lines

- perfmon object and counters [B-21](#)

Cisco Locations

- perfmon object and counters [B-21](#)

Cisco Media Streaming Application

- perfmon object and counters [B-22](#)
- Cisco Messaging Interface
 - perfmon object and counters [B-25](#)
- Cisco MGCP BRI Device
 - perfmon object and counters [B-25](#)
- Cisco MGCP FXO Device
 - perfmon object and counters [B-26](#)
- Cisco MGCP FXS Device
 - perfmon object and counters [B-27](#)
- Cisco MGCP Gateways
 - perfmon object and counters [B-27](#)
 - Cisco MGCP Gateways [B-28](#)
- Cisco MGCP PRI Device
 - perfmon object and counters [B-28](#)
- Cisco MGCP T1CAS Device
 - perfmon object and counters [B-28](#)
- Cisco MOH Device
 - perfmon object and counters [B-29, B-30](#)
- Cisco MTP Device
 - perfmon object and counters [B-31](#)
- Cisco Phones
 - perfmon object and counters [B-31](#)
- Cisco Presence Feature
 - perfmon object and counters [B-32](#)
- Cisco QSIG Feature
 - perfmon object and counters [B-32](#)
- Cisco Signaling Performance
 - perfmon object and counters [B-33](#)
- Cisco SIP
 - perfmon object and counters [B-32, B-33](#)
- Cisco SIP Stack
 - perfmon object and counters [B-33](#)
- Cisco SW Conf Bridge Device
 - perfmon object and counters [B-43](#)
- Cisco TFTP Server
 - perfmon object and counters [B-44](#)
- Cisco Tomcat Connector
 - perfmon object and counters [A-2](#)
- Cisco Transcode Device
 - perfmon object and counters [B-48](#)
- Cisco Unity Connection
 - using port monitor [8-2](#)
- Cisco Video Conference Bridge
 - perfmon object and counters [B-48](#)
- Cisco WebDialer
 - perfmon object and counters [B-49](#)
- Cisco WSM Connector
 - perfmon object and counters [B-49](#)
- configuration profile
 - adding [2-8](#)
 - deleting [2-9](#)
 - restoring [2-9](#)
 - using default [2-8](#)
- conventions [1-xvi](#)
- counters
 - adding [6-3](#)
 - alert notification [3-5](#)
 - alert notification parameters (table) [6-6](#)
 - configuring alert notification for [6-5](#)
 - data sample, configuring [6-9](#)
 - data sample parameters (table) [6-9](#)
 - properties [3-4](#)
 - viewing data [6-10](#)
 - zooming [3-3, 3-4](#)
- CTI
 - Cisco CTIManager
 - perfmon object and counters [B-15](#)
 - finding CTI devices [5-11](#)
 - monitoring CTI applications [5-15](#)
 - monitoring CTI devices [5-15](#)
 - monitoring CTI lines [5-16](#)
 - viewing CTIManager information [5-15](#)
- CUC Data Store, perfmon object and counters [C-2](#)
- CUC Data Store: Databases, perfmon object and counters [C-2](#)
- CUC Message Store, perfmon object and counters [C-2](#)
- CUC Message Store: Databases, perfmon object and counters [C-3](#)

CUC Personal Call Transfer Rules, perfmon object and counters [C-3](#)

CUC Phone System, perfmon object and counters [C-4](#)

CUC Phone System: Ports, perfmon object and counters [C-6](#)

CUC Replication, perfmon object and counters [C-6](#)

CUC Sessions: Calendar Access, perfmon object and counters [C-7](#)

CUC Sessions: E-mail Access, perfmon object and counters [C-7](#)

CUC Sessions: IMAP Server, perfmon object and counters [C-8](#)

CUC Sessions: RSS, perfmon object and counters [C-9](#)

CUC Sessions: SMTP Server, perfmon object and counters [C-10](#)

CUC Sessions: TRaP, perfmon object and counters [C-10](#)

CUC Sessions: TTS, perfmon object and counters [C-10](#)

CUC Sessions: Voice, perfmon object and counters [C-11](#)

CUC Sessions: VUI, perfmon object and counters [C-13](#)

CUC Sessions: Web, perfmon object and counters [C-13](#)

CUC Sessions: Web Calendar Access, perfmon object and counters [C-14](#)

CUC Sessions: Web E-mail Access, perfmon object and counters [C-15](#)

D

Database Change Notification Client

- perfmon object and counters [A-5](#)

Database Change Notification Server

- perfmon object and counters [A-6](#)

Database Change Notification Subscription

- perfmon object and counters [A-6](#)

Database Local DSN

- perfmon object and counters [A-7](#)

data sample

- configuring parameters (table) [6-9](#)

DB User Host Information Counters

- perfmon object and counters [A-7](#)

document

- audience [1-xiv](#)

- conventions [1-xvi](#)
- organization [1-xiv](#)
- purpose [1-xiii](#)

documentation

- related [1-xvi](#)

E

e-mail configuration

- alerts [10-5](#)

Enterprise Replication DBSpace Monitors

- perfmon object and counters [A-7](#)

Enterprise Replication Perfmon Counters

- perfmon object and counters [A-7](#)

I

installation logs

- collecting [11-7](#)

IP

- perfmon object and counters [A-8](#)

L

Log Partition Monitoring

- configuring [13-1](#)

logs

- alerts [9-8](#)

M

Memory

- perfmon object and counters [A-9](#)

monitoring

- CTI applications [5-15](#)
- CTI devices [5-11, 5-15](#)
- CTI lines [5-16](#)
- gateways [5-11](#)

H.323 devices [5-11](#)
 hunt list [5-11](#)
 media resources [5-11](#)
 phones [5-11](#)
 SIP trunk [5-11](#)
 voice-mail devices [5-11](#)

N

Network Interface
 perfmon object and counters [A-10](#)
 Number of Replicates
 perfmon object and counters [A-11](#)

O

object and counters
 Database Change Notification Client [A-5](#)
 organization [1-xiv](#)

P

Partition
 perfmon object and counters [A-12](#)
 perfmon
 counters
 adding [6-3](#)
 category tabs, described [3-2](#)
 properties [3-4](#)
 sample rates [3-3](#)
 object and counters
 Cisco Analog Access [B-2](#)
 Cisco Annunciator Device [B-2](#)
 Cisco CallManager [B-3](#)
 Cisco CallManager Attendant Console [B-11](#)
 Cisco CallManager System Performance [B-12](#)
 Cisco CTIManager [B-15](#)
 Cisco Dual-Mode Mobility [B-15](#)

Cisco Extension Mobility [B-17](#)
 Cisco Gatekeeper [B-17](#)
 Cisco H.323 [B-18](#)
 Cisco Hunt Lists [B-19](#)
 Cisco HW Conference Bridge Device [B-19](#)
 Cisco IP Manager Assistant [B-20](#)
 Cisco Lines [B-21](#)
 Cisco Locations [B-21](#)
 Cisco Media Streaming Application [B-22](#)
 Cisco Messaging Interface [B-25](#)
 Cisco MGCP FXO Device [B-26](#)
 Cisco MGCP FXS Device [B-27](#)
 Cisco MGCP Gateways [B-27](#)
 Cisco MGCP PRI Device [B-28](#)
 Cisco MGCP T1CAS Device [B-28](#)
 Cisco MobilityManager [B-29](#)
 Cisco MOH Device [B-30](#)
 Cisco MTP Device [B-31](#)
 Cisco Phones [B-31](#)
 Cisco Presence Feature [B-32](#)
 Cisco QSIG Feature [B-32](#)
 Cisco Signaling Performance [B-33](#)
 Cisco SIP [B-32](#), [B-33](#)
 Cisco SIP Stack [B-33](#)
 Cisco SIP Station [B-42](#)
 Cisco SW Conf Bridge Device [B-43](#)
 Cisco TFTP Server [B-44](#)
 Cisco Tomcat Connector [A-2](#)
 Cisco Transcode Device [B-48](#)
 Cisco Video Conference Bridge [B-48](#)
 Cisco WebDialer [B-49](#)
 Cisco WSM Connector [B-49](#)
 CUC Data Store [C-2](#)
 CUC Data Store: Databases [C-2](#)
 CUC Message Store [C-2](#)
 CUC Message Store: Databases [C-3](#)
 CUC Personal Call Transfer Rules [C-3](#)
 CUC Phone System [C-4](#)
 CUC Phone System: Ports [C-6](#)

- CUC Replication [C-6](#)
- CUC Sessions: E-mail Access [C-7](#)
- CUC Sessions: IMAP Server [C-8](#)
- CUC Sessions: RSS [C-9](#)
- CUC Sessions: SMTP Server [C-10](#)
- CUC Sessions: TRaP [C-10](#)
- CUC Sessions: TTS [C-10](#)
- CUC Sessions: Voice [C-11](#)
- CUC Sessions: VUI [C-13](#)
- CUC Sessions: Web [C-13](#)
- CUC Sessions: Web Calendar Access [C-14](#)
- CUC Sessions: Web E-mail Access [C-15](#)
- Database Change Notification Server [A-6](#)
- Database Change Notification Subscription [A-6](#)
- Database Local DSN [A-7](#)
- DB User Host Information [A-7](#)
- Enterprise Replication [A-7](#)
- Enterprise Replication DBSpace Monitors [A-7](#)
- IP [A-8](#)
- Memory [A-9](#)
- Network Interface [A-10](#)
- Partition [A-12](#)
- Process [A-13](#)
- Processor [A-14](#)
- System [A-15](#)
- TCP [A-16](#)
- Thread [A-16](#)
- Tomcat JVM [A-3](#)
- Tomcat Web Application [A-4](#)
- Perfmon data logging [7-4](#)
- perfmon data logging
 - troubleshooting [3-5](#)
 - understanding [3-5](#)
- perfmon logs
 - understanding [3-5](#)
- performance counter
 - adding a counter instance [6-4](#)
 - removing [6-4](#)
- performance counters
 - displaying in chart format [6-3](#)
 - displaying in table format [6-3](#)
- performance monitoring
 - category tabs,described [3-2](#)
 - configuring alert notification for counters [6-5](#)
 - counters
 - adding [6-3](#)
 - properties [3-4](#)
 - Number of Replicates [A-11](#)
 - object and counters
 - Cisco Analog Access [B-2](#)
 - Cisco Annunciator Device [B-2](#)
 - Cisco CallManager [B-3](#)
 - Cisco CallManager Attendant Console [B-11](#)
 - Cisco CallManager System Performance [B-12](#)
 - Cisco CTIManager [B-15](#)
 - Cisco Dual-Mode Mobility [B-15](#)
 - Cisco Extension Mobility [B-17](#)
 - Cisco Gatekeeper [B-17](#)
 - Cisco H.323 [B-18](#)
 - Cisco Hunt Lists [B-19](#)
 - Cisco HW Conference Bridge Device [B-19](#)
 - Cisco IP Manager Assistant [B-20](#)
 - Cisco Lines [B-21](#)
 - Cisco Locations [B-21](#)
 - Cisco Media Streaming Application [B-22](#)
 - Cisco Messaging Interface [B-25](#)
 - Cisco MGCP BRI Device [B-25](#)
 - Cisco MGCP FXO Device [B-26](#)
 - Cisco MGCP FXS Device [B-27](#)
 - Cisco MGCP Gateways [B-27](#)
 - Cisco MGCP PRI Device [B-28](#)
 - Cisco MGCP T1CAS Device [B-28](#)
 - Cisco Mobility Manager [B-29](#)
 - Cisco MOH Device [B-30](#)
 - Cisco MTP Device [B-31](#)
 - Cisco Phones [B-31](#)
 - Cisco Presence Feature [B-32](#)
 - Cisco QSIG Feature [B-32](#)

- Cisco Signaling Performance [B-33](#)
- Cisco SIP [B-32](#), [B-33](#)
- Cisco SIP Stack [B-33](#)
- Cisco SIP Station [B-42](#)
- Cisco SW Conf Bridge Device [B-43](#)
- Cisco TFTP Server [B-44](#)
- Cisco Tomcat Connector [A-2](#)
- Cisco Transcode Device [B-48](#)
- Cisco Video Conference Bridge [B-48](#)
- Cisco WebDialer [B-49](#)
- Cisco WSM Connector [B-49](#)
- CUC Data Store [C-2](#)
- CUC Data Store: Databases [C-2](#)
- CUC Message Store [C-2](#)
- CUC Message Store: Databases [C-3](#)
- CUC Personal Call Transfer Rules [C-3](#)
- CUC Phone System [C-4](#)
- CUC Phone System: Ports [C-6](#)
- CUC Replication [C-6](#)
- CUC Sessions: Calendar Access [C-7](#)
- CUC Sessions: E-mail Access [C-7](#)
- CUC Sessions: IMAP Server [C-8](#)
- CUC Sessions: RSS [C-9](#)
- CUC Sessions: SMTP Server [C-10](#)
- CUC Sessions: TRaP [C-10](#)
- CUC Sessions: TTS [C-10](#)
- CUC Sessions: Voice [C-11](#)
- CUC Sessions: VUI [C-13](#)
- CUC Sessions: Web [C-13](#)
- CUC Sessions: Web Calendar Access [C-14](#)
- CUC Sessions: Web E-mail Access [C-15](#)
- Database Change Notification Server [A-6](#)
- Database Change Notification Subscription [A-6](#)
- Database Local DSN [A-7](#)
- DB User Host Information [A-7](#)
- Enterprise Replication [A-7](#)
- Enterprise Replication DBSpace Monitors [A-7](#)
- IP [A-8](#)
- Memory [A-9](#)

- Network Interface [A-10](#)
- Number of Replicates [A-11](#)
- Partition [A-12](#)
- Process [A-13](#)
- Processor [A-14](#)
- System [A-15](#)
- Thread [A-16](#)
- Tomcat JVM [A-3](#)
- Tomcat Web Application [A-4](#)

- sample rates [3-3](#)
- viewing counter data [6-10](#)
- performance queries [6-3](#)
- plug-ins
 - accessing [13-1](#)
 - downloading [13-1](#)
- polling intervals
 - sample rate [3-3](#)
- polling rate [5-13](#)
- port monitor
 - overview [8-1](#)
 - using [8-2](#)
- Process
 - perfmon object and counters [A-13](#)
- Processor
 - perfmon object and counters [A-14](#)

Q

- Q931 Translator, using [11-22](#)

R

- Real-Time Monitoring Tool
 - alert notification
 - configuring for a counter [6-5](#)
 - alerts
 - accessing alert central [10-1](#)
 - action configuration (table) [9-7](#)

- configuring alert actions [10-6](#)
- configuring e-mail for [10-5](#)
- configuring with Default alert action [10-6](#)
- customization (table) [9-5](#)
- logs, described [9-8](#)
- notification for a counter [3-5](#)
- preconfigured [9-2](#)
- setting properties [10-2](#)
- suspending [10-5](#)
- category
 - adding [6-1](#)
 - deleting [6-2](#)
 - renaming [6-2](#)
- category tabs,described [3-2](#)
- collecting a crash dump [11-16](#)
- collecting traces [11-3](#)
- collecting traces using the query wizard [11-7](#)
- collecting traces using the schedule collection option [11-12](#)
- configuration profile
 - adding [2-8](#)
 - deleting [2-9](#)
 - restoring [2-9](#)
 - using default [2-8](#)
- counters
 - alert notification [3-5](#)
 - data sample [6-9](#)
 - displaying property description [6-8](#)
 - viewing data [6-10](#)
 - zooming [3-3, 3-4](#)
- data samples [6-9](#)
- deleting scheduled collections [11-15](#)
- finding
 - CTI applications [5-15](#)
 - CTI devices [5-15](#)
 - CTI lines [5-16](#)
 - devices [5-11](#)
- highlighting a chart [3-4](#)
- installing multiple copies [2-4](#)

- logging and report generation
 - call log [5-5](#)
 - device log [5-10](#)
 - server log [4-4](#)
 - service log [5-7](#)
- polling interval [3-3](#)
- polling rate, configuring [5-13](#)
- related topics for trace collection [11-29](#)
- sample rate [3-3](#)
- SysLog Viewer [12-1](#)
- updating trace configuration settings [11-28](#)
- using the real time trace option [11-25](#)
- using the real time trace option, monitor user event [11-26](#)
- using the real time trace option, view real time data [11-25](#)
- viewing
 - CTIManager information [5-15](#)
 - device properties [5-13](#)
 - phone information [5-12](#)
- viewing trace collection status [11-15](#)
- viewing trace files using the local browse option [11-18](#)
- viewing trace files using the remote browse option [11-19](#)
- zooming a counter [3-3](#)
- related documentation [1-xvi](#)

S

- sample rate [3-3](#)
- server authentication certificates
 - importing using the trace collection option [11-2](#)
- SysLog Viewer [12-1](#)
- System
 - perfmon object and counters [A-15](#)

T

- TCP [A-16](#)

perfmon object and counters [A-16](#)

Thread

perfmon object and counters [A-16](#)

Tomcat JVM

perfmon object and counters [A-3](#)

Tomcat Web Application

perfmon object and counters [A-4](#)

Trace

collection

collecting crash dump option [11-16](#)

collecting files option [11-3](#)

configuration, described [11-1](#)

deleting scheduled collections [11-15](#)

list of topics [11-1](#)

related topics [11-29](#)

schedule collection option [11-12](#)

using the local browse option [11-18](#)

using the query wizard option [11-7](#)

using the real time trace option [11-25](#)

using the real time trace option, monitor user event [11-26](#)

using the real time trace option, view real time data [11-25](#)

using the remote browse option [11-19](#)

viewing status [11-15](#)

trace and log central

collecting installation and upgrade logs [11-7](#)

troubleshooting

Perfmon data logging

configuring [7-4](#)

parameters [7-5](#)

viewing log files [7-3](#)

Z

zooming a counter [3-3, 3-4](#)

U

upgrade logs

collecting [11-7](#)