



CHAPTER 34

Setup Mode Settings

Impacted GUI: Cisco Unified Communications Manager Business Edition 3000 First Time Setup Wizard

On the Setup Mode page, you select whether you want to manually configure the system through the graphical user interfaces or whether you want to upload the Cisco-provided .xls data configuration file that contains system configuration data, including values for the Cisco Unified Communications Manager Business Edition 3000 First Time Setup Wizard. If you upload a Cisco-provided .xls data configuration file, you do not need to perform additional configuration tasks in the Cisco Unified Communications Manager Business Edition 3000 First Time Setup Wizard; the wizard automatically takes you to the wizard Summary page where you can review the values for your settings.

[Table 34-1](#) describes the settings on the Setup Mode page.

Table 34-1 **Settings on the Setup Mode Page**

Setting	Description
Manual Setup	To use the default settings for the system or if you want to manually configure the settings in the graphical user interfaces, click Manual Setup .

Table 34-1 Settings on the Setup Mode Page (continued)

Setting	Description
Automatic Setup	Click Automatic Setup to set the system settings from the Cisco-provided .xls data configuration file. You can either upload the Cisco-provided .xls data configuration file from your desktop or from a USB key. Values in the subsequent pages are loaded with the information that you provide in the Cisco-provided .xls data configuration file. If a value is not in the file, the system uses the default value. The Cisco-provided .xls data configuration file must be a Microsoft Excel file (.xls), which you can obtain from www.cisco.com. The system reads data from the .xls file, and you can confirm the data on the wizard Summary page.  Caution The system cannot read the data if you have changed the order of the settings in the file or changed the file extension. The data does not get added to Cisco Unified Communications Manager Business Edition 3000 until after the server restarts at the end of the wizard. Cisco recommends that after you restart the server, access the Cisco Unified Communications Manager Business Edition 3000 Administrative Interface to determine whether configuration data got added to the system; for example, if you add user and phone data to the Cisco-provided .xls data configuration file, the Cisco Unified Communications Manager Business Edition 3000 Administrative Interface immediately displays important information about phone and user insertion after you log into the interface.