



CHAPTER 15

Cisco Extension Mobility Report

Impacted GUI: Cisco Unified Communications Manager Business Edition 3000 Administrative Interface

With Cisco Extension Mobility, a phone user can log in to a phone where Cisco Extension Mobility is enabled and use the phone features that are assigned to him; that is, if Cisco Extension Mobility-enabled phone features support the same features as the desk phone. For a user to use Cisco Extension Mobility, you must enable Cisco Extension Mobility in the usage profile (**Users/Phones > Usage Profile**) and then assign the usage profile to the user (**Users/Phones > Users**).

[Table 15-1](#) describes the categories that display on the Cisco Extension Mobility Report page (**Monitoring > Extension Mobility Report**). The report, which obtains its information from the database, provides status of Cisco Extension Mobility usage.



Tip

To create another report, click the Extension Mobility Report menu option again.

Table 15-1 Categories on the Cisco Extension Mobility Reports Page

Category	Description
Summary	This section lists the number of phones where Cisco Extension Mobility is enabled and the number of users that are currently logged into Cisco Extension Mobility-enabled phones. The summary table lists the users that are currently logged into Cisco Extension Mobility-enabled phones and the phone that is being used. You can also view the date and time when the user logged into the phone. Tip For the table to display data, the number of users that are currently logged into Cisco Extension Mobility-enabled phones must be greater than zero, as indicated for the Active Cisco Extension Mobility sessions.

