



Numerics

7931 [258](#)
911 services [1071](#)

A

abbreviated dialing [1384](#)
accept command [733](#)
access-digit command [1212](#)
account code entry [1337](#)
Acct soft key [1336](#)
addon command [232](#)
addons command [307](#)
address command [1085](#)
ad hoc conferencing [951](#)
Ad-Hoc Hardware Conferencing [1004](#)
after-hour exempt (voice register pool) command [693](#)
after-hour exempt command [692](#)
after-hours block pattern command [687](#)
afterhours block patterns command [699](#)
after hours call blocking
 configuring exception for dial peer [689](#)
 configuring exception for SIP phone [691, 692](#)
after-hours date command [688](#)
after-hours day command [688](#)
Afterhours Pattern Blocking Support for Regular Expressions [684](#)
after-hours toll bar [683](#)
agent availability, ephone hunt groups [860](#)
agent status control, hunt groups [862](#)
alerting (call state) [1336](#)
allow connections command [808](#)
allow-connections command [90, 806](#)
allow-connections sip-to-sip command [1542, 1565](#)
allow subscribe command [1293](#)
allow watch command [1286, 1544, 1548](#)
analog phones [212](#)
announcements
 blocked precedence [1209](#)
 busy station [1209](#)
 isolated code [1209](#)
 loss of C2 features [1210](#)
 MLPP [1209](#)
 unauthorized precedence [1210](#)
 vacant code [1210](#)
Answer soft key [1336](#)
API, XML [1615](#)
application (voice register global) command [170](#)
application command [336](#)
archives, downloading for Cisco Unified CME [62](#)
associate application command [460](#)
associate application sccp command [967](#)
associate ccm command [459, 493, 967](#)
associate profile command [459, 494](#)
ATA (Cisco Analog Telephone Adapters) [212](#)
attendant-console command [1222](#)
audio fallback, for video calls [1401](#)
audio file for MOH [64](#)
audio paging [1255](#)
authenticate command [161](#)
authenticate credential command [113, 1294](#)
authenticate ood-refer command [112](#)
authenticate presence command [1294](#)
authentication, *See* phone authentication
authentication credential command [1119](#)

authentication for HTTP server [521](#)
 authentication string, entering on phone [626](#)
 auth-mode command [614, 619](#)
 auth-string command [615](#)
 auto-answer, headset [1169](#)
 auto-answer command [1186](#)
 auto assign command [341](#)
 autoconfiguration of VG2xx [214](#)
 auto-cut-through command [1237](#)
 auto-line command [663](#)
 auto logout command [863](#)
 automatic agent status not-ready, ephone hunt groups [863](#)
 automatic line selection [661](#)
 automatic registration blocking [151](#)
 auto-reg-ephone command [151](#)

B

b2bua command [564](#)
 bandwidth, for video [1415](#)
 barge [667](#)
 Barge soft key [1336](#)
 billing records [31](#)
 bind interface command [965](#)
 bit-rate, setting maximum value [1414](#)
 blast hunt group [857](#)
 BLF for a phone [209, 1281](#)
 BLF for a phone line [208, 1278](#)
 blf-speed-dial command [1288, 1290](#)
 BLF status [1278](#)
 blind transfer [767](#)
 blocked precedence announcement [1209](#)
 blocking

- automatic registration [151](#)
- caller ID [683](#)
- call park [708](#)
- calls [683](#)
- call transfer [767](#)
- features [1338](#)

local directory [1039](#)
 bnea command [1212](#)
 bpa command [1212](#)
 bulk command [143](#)
 bulk-loading speed-dial numbers [1386](#)
 bulk registration

- configuring [142](#)
- disabling SIP proxy registration [252](#)

 bulk-speed-dial list command [1387](#)
 bulk-speed-dial-prefix command [1387](#)
 busy call forwarding [764](#)
 busy station announcement [1209](#)
 busy-trigger-per-button command [236, 241](#)
 button command [271](#)

- assigning dns to phones [235](#)
- overlaid ephone-dns [912](#)

 button-layout [1479](#)
 button-layout command [1476](#)
 button optimization [210](#)
 button-layout [1480, 1481](#)
[1480, 1481](#)

C

CA (certification authority) [586](#)
 cadence command [963](#)
 Callback and Calling Number Display [388](#)
 Callback soft key [1336](#)
 call blast [857](#)
 call blocking

- based on date and time [683](#)
- override [685](#)

 call-coverage features [845](#)
 call detail records [31](#)
 caller-id block command [944](#)
 caller ID blocking [942](#)
 caller-id command [1196](#)
 caller ID name [1043](#)
 call-forward all command [794](#)

- call-forward b2bua all command [821](#)
- call-forward b2bua busy command [557, 822](#)
- call-forward b2bua mailbox command [557, 822](#)
- call-forward b2bua noan command [558, 822](#)
- call-forward b2bua unreachable command [822](#)
- call-forward busy command [794](#)
- call-forward busy command, overlaid ephone-dns [911](#)
- call forwarding
 - blocking local extension forwards [795](#)
 - H.450.3 standard [772](#)
 - selective [764](#)
 - transcoding between G.726 and G.711 [450](#)
- call-forward max-length command [795](#)
- call-forward night-service command [795](#)
- call-forward noan command [794](#)
- call-forward noan command, overlaid ephone-dns [911](#)
- call-forward pattern command [794, 808](#)
- call-forward system command [391](#)
- call history [31](#)
- call hunt [847](#)
- calling-number local command [808](#)
- callmon command [1541](#)
- callmonitor command [1566](#)
- Call Park
 - Recall Enhancement [708](#)
- call park
 - alternate target [706](#)
 - blocking [708](#)
 - call-park slots [704](#)
 - dedicated slots [707](#)
 - directed [706](#)
 - examples [717](#)
 - monitoring call-park slots [705](#)
 - redirect [708](#)
 - reminder ring [705](#)
 - reservation groups [706](#)
 - timeout interval [705](#)
- call-park system command [711](#)
- call pickup
 - examples [916](#)
 - group numbers [848](#)
- call routing, loopback [1193](#)
- call setup, video [1402](#)
- call start slow command [1413](#)
- call transfer [828](#)
 - blocking [767](#)
 - consult transfer for direct station select [771](#)
 - direct station select [771](#)
 - H.450.2 standard [772](#)
 - H.450 standards [767](#)
 - recall [210, 770](#)
 - transcoding between G.726 and G.711 [450](#)
- call type [1401](#)
- call waiting
 - beep [850](#)
 - cancel [851](#)
 - overlaid ephone-dns [868](#)
 - ring [851](#)
- call-waiting [885](#)
- call-waiting beep command [881](#)
- call-waiting ring command [851, 881](#)
- cancel call waiting [851](#)
- CAPF (certificate authority proxy function) [587](#)
- capf-auth-str command [618](#)
- capf-server command [614](#)
- cBarge [667](#)
- CBarge soft key [1336](#)
- CDRs [31](#)
- cert-enroll-trustpoint command [614](#)
- certificate [586](#)
- certificate authority proxy function, *See* CAPF
- certificate revocation list, *See* CRL
- certificate trust list, *See* CTL
- certification authority, *See* CA
- cert-oper (CAPF-server) command [616](#)
- cert-oper (ephone) command [619](#)
- CFwdALL soft key [1336](#)
- channel huntstop [848](#)

CIF (common intermediate format) [1398](#)
 Cisco BTS Softswitch (Cisco BTS) [772, 774, 777, 779](#)
 Cisco IOS software [47](#)
 Cisco Jabber for Microsoft Windows [1464](#)
 Cisco phone firmware
 troubleshooting upgrade [81](#)
 upgrading SIP [69](#)
 verifying firmware version on an IP phone [80](#)
 Cisco PSTN Gateway (Cisco PGW) [772, 777, 779](#)
 Cisco QoS [49](#)
 Cisco Unified 8941 and 8945 SCCP IP Phones [219](#)
 Cisco Unified CME
 CTI CSTA [1562](#)
 Localization Enhancements [410](#)
 Cisco Unified CME for SIP phones
 applying translation rules [399](#)
 configuring bulk registration [142](#)
 configuring call forwarding [820](#)
 configuring call transfer [828](#)
 configuring dial-plan patterns [390](#)
 configuring hunt stop [875](#)
 configuring voice hunt groups [894](#)
 configuring voice mailbox [556](#)
 creating and applying templates [1530](#)
 creating DNs [237](#)
 disabling SIP proxy registration [252](#)
 generating configuration profiles [363](#)
 RFC 2833 dual tone DTMF MTP passthrough [541](#)
 SIP MWI - QSIG translation [542](#)
 Cisco Unified Communications Manager
 interworking with Cisco Unified CME [814, 818](#)
 network scenario [785, 786](#)
 no support for H.450 standards [772](#)
 Cisco Unified IP Phone 7931G [258](#)
 Cisco Unified IP Phones
 HTTPS Provisioning [597](#)
 Cisco Unified SCCP IP Phones
 MIB Support for Extension Mobility [1115](#)
 Virtual SNR DN [1319](#)

Cisco Unified SIP IP Phones
 Localization Support [411](#)
 My Phone Apps [1466](#)
 Single Number Reach [1318](#)
 Support for Paging Group [1258](#)
 Trunk-to-Trunk Transfer Blocking for Toll Fraud Prevention [768](#)
 Cisco Unified Video Advantage [1397](#)
 Cisco Unity
 configuring SIP dial peer for [560](#)
 integration [540](#)
 Cisco Unity Connection integration [539](#)
 Cisco Unity Express
 AXL enhancement [544](#)
 configuring SIP dial peer for [563](#)
 integration with Cisco Unified CME [539](#)
 transcoding between G.726 and G.711 [450](#)
 Cisco Unity Express AXL enhancement [544](#)
 Cisco VG 224 [212](#)
 class of restriction (COR) [686](#)
 clear cti session command [1573](#)
 clear telephony-service xml-event-log command [1660](#)
 clear voice moh-group statistics command [1253](#)
 clid strip command [943](#)
 clid strip name command [943](#)
 client identifier command [95](#)
 cli write command [345](#)
 clock summer-time command [98](#)
 clock timezone command [98](#)
 cnf-file command [153](#)
 cnf-file location command [153](#)
 cnf-file perphone command [606](#)
 codec (dspfarm-profile) command [460](#)
 codec command [254, 257, 288, 338, 565, 966, 1549](#)
 codec g729r8 dspfarm-assist command [218, 453](#)
 codec preference command [633](#)
 common intermediate format, see CIF [1398](#)
 conference add-mode command [973](#)
 conference ad-hoc command [971](#)

- conference admin command [973](#)
 - conference drop-mode command [973](#)
 - conference hardware command [969](#)
 - conference-join custom-cptone command [966](#)
 - conference-leave custom-cptone command [966](#)
 - conference meetme command [971](#)
 - conferencing [949](#)
 - end-of-conference options [951](#)
 - examples [983](#)
 - gain control [951](#)
 - guaranteed audio video conferences [1022](#)
 - heterogeneous video conferences [1021](#)
 - initiator dropoff control [951](#)
 - transcoding between G.729 and G.711 for ad hoc calls [450](#)
 - video [1015](#)
 - video examples [1026](#)
 - configuration files
 - externally stored [127, 360](#)
 - GUI [526](#)
 - per phone [127, 360](#)
 - per phone type [127, 360](#)
 - configuring Cisco QoS [49](#)
 - Configuring Toll Fraud Prevention [503](#)
 - configuring VLANs [49](#)
 - ConfList soft key [1336](#)
 - Confrn soft key [1336](#)
 - connected (call state) [1336](#)
 - connection plar opx command [261](#)
 - consultative transfer [767, 771](#)
 - COR (class of restriction) [686](#)
 - cor command [696](#)
 - corlist command [695](#)
 - CPU consumption, for video calls [1399](#)
 - create cnf-files command [69, 79, 282](#)
 - create profile command [71, 75, 251, 364](#)
 - credentials command [621](#)
 - CRL (certificate revocation list) [587](#)
 - crypto pki authenticate command [479, 480, 604, 628, 636](#)
 - crypto pki enroll command [479, 604](#)
 - crypto pki server command [474, 599, 601, 625](#)
 - crypto pki trustpoint command [475, 477, 480, 601, 603, 624, 628, 636](#)
 - CSTA client application [1561](#)
 - csv accounting [31](#)
 - cti-aware command [1569](#)
 - cti csta mode basic command [1566](#)
 - CTI CSTA protocol suite [1561](#)
 - cti message device-id suppress-conversion command [1566](#)
 - cti notify command [1571](#)
 - cti shutdown command [1566](#)
 - cti watch command [1571](#)
 - CTL (certificate trust list) [587](#)
 - ctl-client command [609, 611](#)
 - ctl-service admin command [622](#)
 - customer administrator GUI access setup
 - using the CLI [528](#)
 - using the GUI [527](#)
 - customer administrator GUI file [526](#)
-
- ## D
- database level command [474, 600](#)
 - database url command [475, 600](#)
 - date-format command [163](#)
 - debug cch323 video command [1417](#)
 - debug cme-hfs command [167](#)
 - debug dspfarm command [472](#)
 - debug ephone detail command [1417](#)
 - debug ephone message command [1418](#)
 - debug ephone mlpp command [1224](#)
 - debug ephone mtp command [472](#)
 - debug ephone register command [1418](#)
 - debug ephone video command [1418](#)
 - debug h225asn1 command [1417](#)
 - debug h245 asn1 command [1417](#)
 - debug sccp command [472](#)

- debug tftp event command [81](#)
- debug voice mlpp command [1224](#)
- debug voip ccapi inout command [1417](#)
- dedicated call-park slots [707](#)
- default-router command [94, 96](#)
- demote [385](#)
- description (ephone-hunt) command [890](#)
- description(moh-group) command [1242](#)
- description command [308, 562, 564, 921, 1493, 1494](#)
- destination-pattern command [338, 562, 564](#)
- device-id command [231](#)
- device-name command [231](#)
- device-security-mode command [606, 617](#)
- device-type command [231](#)
- DHCP server
 - changing TFTP address [110](#)
 - option 150 and configuration files [110](#)
- DHCP service
 - description [85](#)
 - setting up [92](#)
- dialing plans [381](#)
- dial-peer hunt command [866](#)
- dial-peer hunt for ephone-dn dial peers
- dial-peer preference [847](#)
- dial peers
 - ephone-dns [198](#)
 - for call transfer and forwarding [781](#)
- dial-peer voice command [561, 564](#)
- dialplan command [245](#)
- dialplan-pattern command [390, 391](#)
- dial plans for SIP phones [220](#)
- dial tone, secondary [384](#)
- DID (Direct Inward Dialing) [383](#)
- digital certificate [586](#)
- digital certificates [585](#)
- digital signature [586](#)
- digit collect kpml command [248](#)
- directed call park [706](#)
- directed call pickup, *See* call pickup
- directories [1039](#)
- directory command [1042](#)
- directory entry command [1044](#)
- directory numbers for SIP phones [237](#)
- direct station select [1379](#)
- direct station select call transfer [771](#)
- display-logout command [890](#)
- distinctive ringing [1305](#)
- DND (do not disturb) [1065](#)
- dnd command [1067](#)
- dnd feature-ring command [1064](#)
- DND soft key [863, 1068, 1336](#)
- dn-webedit command [524](#)
- do not disturb (DND) [1065](#)
- downloading files for Cisco Unified CME [62](#)
- DSCP (Differentiated Services Code Point) [126](#)
- DSP calculator [491, 1024](#)
- dspfarm connection interval command [469](#)
- dspfarm profile command [460](#)
- dspfarm rtp timeout command [469](#)
- DSP farms, modifying configuration after upgrading Cisco IOS software [466](#)
- DSP farms, usage considerations [453](#)
- dspfarm transcoder maximum sessions command [462, 468](#)
- DSPs (digital signal processors) [451](#)
- dsp services dspfarm command [457, 461, 962](#)
- DSS (direct station select) service [1379](#)
- dst auto-adjust command [163](#)
- dst command [163](#)
- DTMF integration [540](#)
- DTMF integration patterns for voice mail [558](#)
- dtmf-interworking rtp-nte command [563](#)
- DTMF relay
 - for H.323 networks [86](#)
 - SIP NOTIFY [563](#)
 - SIP trunks [107](#)
- dtmf-relay (voice register pool) command [241, 1549](#)
- dtmf-relay h245-alphanumeric command [107, 338](#)
- dtmf-relay rtp-nte command [108, 562](#)

dtmf-relay sip-notify command [108, 565](#)
 dual-line ephone-dn [200](#)
 dual-number ephone-dns [203](#)
 dualtone conference command [963](#)
 dynamic membership, hunt groups [862](#)

E

E.164 Enhancements [385](#)
 E.164 number registration
 ephone-hunt group pilot number [889](#)
 SIP [87](#)
 E911 services [1071](#)
 elin command [1085](#)
 emadmin login command [1571](#)
 emadmin logout command [1571](#)
 emergency response callback command [1090](#)
 emergency response location command [1093, 1094, 1095](#)
 emergency response zone command [1088, 1089](#)
 emergency services [1071](#)
 em external command [1572](#)
 em keep-history command [1119, 1127](#)
 em logout command [1119, 1127](#)
 emptycapability command [632](#)
 EndCall soft key [1336](#)
 endpoint capability match [1401](#)
 enhanced 911 services [1071](#)
 enrollment terminal command [628](#)
 enrollment url command [477, 601, 603, 624](#)
 ephone command [234](#)
 ephone-dn command [78, 228, 554](#)
 ephone-dn dial-peer hunt
 ephone-dns
 assigning to phone (button command) [235](#)
 definition [27](#)
 dual-line [200](#)
 dual-number [203](#)
 hunt groups [852](#)
 overlaid [205, 207, 866](#)

secondary number [203](#)
 shared [204](#)
 single-line [199](#)
 two ephone-dns with one number [202](#)
 types [199](#)
 ephone-hunt command [887](#)
 ephone Hunt Group
 Agent Statistics [859](#)
 ephone hunt groups
 agent availability options [860](#)
 agent status control [862](#)
 automatic agent status not-ready [863](#)
 dynamic membership [862](#)
 examples [917](#)
 hops [852](#)
 longest-idle groups [856](#)
 peer groups [855](#)
 sequential groups [854](#)
 ephone-hunt login command [891](#)
 ephones
 basic configuration [233](#)
 definition [27](#)
 enabling video [1415](#)
 setting video bandwidth [1415](#)
 ephone-type command [231](#)
 Ephone-type templates [230](#)
 extending overlaid ephone-dn calls [870](#)
 extension assigner feature [327](#)
 automatic synchronization [333](#)
 extension-assigner tag-type command [340](#)
 extension mobility [1111](#)
 extension-range command [1243](#)
 external-ring command [1312](#)

F

FAC [1147](#)
 fac [1154](#)
 FAC (feature access code) [1139](#)

fac command [552, 712, 878, 883, 1142](#)
 far-end camera control, see FECC [1398](#)
 fastdial command [1383, 1392](#)
 Fast-Track Configuration Approach [225](#)
 fax relay [1161](#)
 fax support [213](#)
 feature access code (FAC) [1139](#)
 feature blocking [1338](#)
 feature-button command [1364, 1366](#)
 feature buttons
 fixed [1461](#)
 URL provisioning for [1465](#)
 [1487](#)
 features blocked command [1357](#)
 FECC (far-end camera control) [1398](#)
 filename command [244](#)
 files, downloading for Cisco Unified CME [62](#)
 file text command [71, 75, 364](#)
 final command [888, 897](#)
 firmware files
 phone [62](#)
 video [1398](#)
 fixed line/feature button layout [1461](#)
 Flash soft key [1336, 1338](#)
 flow-around mode, video stream [1404](#)
 flow control messages [1402](#)
 flow-through mode, video stream [1404](#)
 forwarding, *See* call forwarding
 forwarding calls using local hairpin routing [807](#)
 forward local-calls command [795](#)
 frequency command [963](#)
 from-ring command [890](#)
 fwd-final command [889](#)
 fxo hook-flash command [1355](#)
 FXO port monitoring [210](#)
 FXO trunk lines [209](#)
 FXS ports [212](#)

G

G.711 conference calls [951](#)
 G.729r8 codec
 remote phones [218, 453](#)
 transcoding [449](#)
 gain control for conferences [951](#)
 gatekeeper, H.323
 not registering ephone hunt-group pilot number [889](#)
 number format restrictions [382](#)
 gcid command [1542, 1566](#)
 generating SIP profiles [363](#)
 GPickUp soft key [1336](#)
 grant auto command [474, 601, 625](#)
 group call pickup [848](#)
 group command [732, 1605](#)
 group phone command [1608](#)
 group pickup, *See* call pickup
 gsm-support command [308](#)
 guaranteed audio video conferences [1022](#)
 GUI (graphical user interface)
 customer administrator setup [527](#)
 how to access [525](#)
 phone user setup [529](#)
 prerequisites [519](#)
 restrictions [520](#)
 setting up [521](#)
 system administrator setup [523](#)

H

H.225 debug messages [1417](#)
 H.245 debug messages [1417](#)
 H.261 video codec [1398](#)
 H.263 video codec [489, 1017, 1398](#)
 H.264 video codec [1400](#)
 H.323-to-H.323 connections, enabling [805](#)
 H.323 video endpoints [1400](#)
 H.450.12 supplementary services

- description [776](#)
- H.450.2 supplementary services [772](#)
 - description [772](#)
 - enabling [787](#)
 - handling non-H.450.2 calls [776](#)
 - network requirements [774](#)
- H.450.3 supplementary services [772](#)
 - description [772](#)
 - enabling [787](#)
 - handling non-H.450.3 calls [776](#)
 - network requirements [774](#)
- H.450 standards
 - call forwarding [764](#)
 - call transfer [767](#)
- H.450 tandem gateways
 - description [779](#)
 - enabling H.323-to-H.323 connections [805](#)
 - licensing [779](#)
- h225 h245-address on-connect (h323 voice-service) command [817](#)
- h225 h245-address on-connect (voice-class) command [818](#)
- h323 command [632](#)
- hairpin call routing
 - description [776](#)
 - enabling H.323-to-H.323 connections [805](#)
 - network requirements [778](#)
 - restrictions [805](#)
- headset auto-answer [1169](#)
- headset auto-answer command [1172](#)
- heterogeneous video conferences [1021](#)
- hfs enable command [166](#)
- hfs home-path command [168](#)
- HLog soft key [863, 1336](#)
- hold (call state) [1336](#)
- hold-alert command [885, 1310](#)
- Hold soft key [1336](#)
- homogeneous conferences [1020](#)
- hookflash functionality [1338](#)

- hops command [888, 897](#)
- host command [95](#)
- host-id-check command [1441](#)
- HTTP path, setting [521](#)
- HTTP server, enabling [521](#)
- HTTPS Provisioning [597](#)
- hunt, *See* call hunt
- hunt-group logout command [863, 891](#)
- hunt groups [852](#)
- huntstop [847, 875](#)
- huntstop, channel [848](#)
- huntstop channel command [228, 239, 873, 910](#)
- huntstop command [260, 267, 847, 876, 910](#)
- huntstop command, overlaid ephone-dns [866](#)

- ica command [1222](#)
- id command [240, 1186, 1188](#)
- id device-id-name command [1514](#)
- iDivert [1336](#)
- iDivert softkey [1359](#)
- idle (call state) [1336](#)
- import certificate command [642](#)
- incoming alerting command (redundant router) [157](#)
- feature-button [1487](#)
- index command [739, 746](#)
- url-button [1483](#)
- in key systems [271](#)
- input gain command [1237](#)
- installing Cisco IOS software [47](#)
- installing hardware [45](#)
- intercom command [1182, 1188](#)
- intercom lines
 - configuring for SCCP phones [1181](#)
 - configuring for SIP phones [1185](#)
 - description [1177](#)
- interface command [97](#)
- internal-call command [1248](#)

international languages and tones
 alternative locales [412](#)
 user-defined locales [411](#)

interoperability with other systems [783](#)

intersite calling plan [382](#)

ip dhcp pool command [93, 95, 111](#)

ip helper-address command [97](#)

ip http authentication command [523](#)

ip http path flash command [522, 1381](#)

ip http server command [522, 1118, 1381](#)

IP phone
 configuring phone options [1467](#)
 programmable vendor parameters [1462](#)

ip qos dscp command [148, 161](#)

ip source-address (credentials) command [496, 621](#)

ip source-address command [140, 465](#)

ip source-address command (redundant router) [148, 156](#)

isolated code announcement [1209](#)

issuer-name command [600](#)

ixi application cme command [1656](#)

ixi transport http command [1655](#)

J

Join soft key [1336](#)

K

keepalive command [155, 1546, 1569](#)

keepalive retries command [459](#)

keep-conference (voice register pool) command [960](#)

keep-conference command [958](#)

keygen-retry command [615](#)

keygen-timeout command [615](#)

keypad-normalize command [236](#)

keyswitch [29, 258](#)

key system [29, 258](#)

KPML [220](#)

kron occurrence command [346](#)

kron policy-list command [345](#)

L

label command [1497, 1498](#)

language support [409](#)

license requirements [27](#)

lifetime certificate command [600, 625](#)

line buttons
 fixed [1461](#)
 phone labels [1462](#)

line selection, automatic [661](#)

list command [888, 896](#)

live-feed music on hold [1229](#)

LiveRcd soft key [1337](#)

live record [544](#)

live record command [554](#)

load (telephony service) command [69, 79](#)

load-cfg-file command [607](#)

load command [71, 147, 160](#)

loc2 command [1223](#)

local directory [1039](#)

locale installer [413](#)

locales
 multiple [412](#)
 system-defined [410](#)
 user-defined [411](#)

locally significant certificate, *See* LSC

local speed dial [1380](#)

location command [1086](#)

logical partitioning class of restriction [723](#)

login (telephony-service) command [689](#)

Login soft key [1337](#)

logout-profile command [1124, 1129](#)

log table max-size command [1659](#)

log table retain-timer command [1659](#)

longest-idle ephone hunt groups [856](#)

loopback call routing [1193](#)

loopback-dn command [1197](#)
 loss of C2 features announcement [1210](#)
 LPCOR [723](#)
 lpcor incoming (ephone) command [741](#)
 lpcor incoming (trunk group) command [735](#)
 lpcor incoming (voice port) command [736](#)
 lpcor incoming (voice service) command [739](#)
 lpcor outgoing (dial peer) command [739](#)
 lpcor outgoing (ephone) command [742](#)
 lpcor outgoing (trunk group) command [735](#)
 lpcor outgoing (voice port) command [736](#)
 lpcor type command [741](#)
 lpcor type mobile command [745](#)
 LSC (locally significant certificate) [588](#)

M

mac-address command [235, 270, 282, 344](#)
 MAC addresses for analog phones [285](#)
 mailbox-selection (dial-peer) command [548](#)
 mailbox-selection (ephone-dn) command [549](#)
 mailbox selection policy [547, 548](#)
 manufacture-installed certificate, *See* MIC
 max-calls-per-button command [235](#)
 max-conferences command [957](#)
 max-dn command [148, 161](#)
 max-ephones command [126, 148](#)
 max-idle-time command [1131](#)
 maximum bit-rate command [1414](#)
 maximum conference-party command [966](#)
 maximum sessions command [460, 966](#)
 max-pool command [161](#)
 max-presentation command [231](#)
 max-redirect command [891](#)
 max-subscription command [1284](#)
 max-timeout command [889](#)
 media command [171](#)
 media encryption [581](#)
 media messages [1401](#)
 media path setup [1402](#)
 media termination point, *See* MTP
 meet-me conferencing [952](#)
 Cisco CME 3.2 to Cisco Unified CME 4.0 [953](#)
 Meet-Me Hardware Conferencing [1003](#)
 MeetMe soft key [1337](#)
 messages
 debug [1417](#)
 flow control [1402](#)
 media [1401](#)
 MIBs [34](#)
 MIC (manufacture-installed certificate) [588](#)
 configuring [627](#)
 Mixed Shared Lines [205](#)
 MLPP
 access digit [1202](#)
 announcements [1209](#)
 explained [1201](#)
 precedence [1202](#)
 preemption [1203](#)
 service domains [1207](#)
 mlpp indication command [1215, 1218](#)
 mlpp max-precedence command [1213](#)
 mlpp preemption command [1215, 1218](#)
 mlpp service-domain command [1215, 1218](#)
 mobility command [1321, 1325](#)
 Mobility soft key [1322, 1337](#)
 MOC client [1561](#)
 mode command [71, 160](#)
 mode ra command [625](#)
 MOH (music on hold)
 audio file to download [64](#)
 from a live feed [1229](#)
 from an audio file [1232](#)
 transcoding between G.726 and G.711 [450](#)
 moh (telephony-service) command [1233, 1242](#)
 moh command [1239](#)
 moh-file-buffer command [1249](#)
 moh-group command [1246](#)

monitoring call-park slots [705](#)
 monitor-line button [1378](#)
 monitor mode for shared lines [208](#)
 MTP (media termination point)
 remote phones [217](#)
 transcoding for video [1399](#)
 mtp command [288](#)
 multicast moh command [1234, 1243](#)
 multicast-moh command [1235, 1240](#)
 multi-party ad hoc conferencing [951](#)
 Multiple Calls Per Line [219](#)

MWI

 configuring Subscribe notify [569](#)
 configuring unsolicited notify [569](#)
 defining MWI outcall [568](#)
 prefix specification for SIP [571](#)
 mwi command [566, 569, 571](#)
 mwi-line command [271, 566](#)
 mwi prefix command [572](#)
 mwi reg-e164 command [568](#)
 mwi-server command [570, 574](#)
 mwi stutter command [568](#)
 mwi-type command [260, 567](#)

N

url-button index type | url [1485](#)
 name command [228, 900, 1043, 1050, 1085](#)
 network command [93](#)
 network-locale (ephone-template) command [426, 437](#)
 network-locale command [282, 425, 436](#)
 network locales
 alternative [412](#)
 system-defined [410](#)
 user-defined [411](#)
 network parameters [83](#)
 NewCall soft key [1337](#)
 night service [864](#)
 examples [926](#)

 notification [864](#)
 night-service bell (ephone) command [906](#)
 night-service bell (ephone-dn) command [906](#)
 night-service call forwarding [764](#)
 night-service code command [905](#)
 night-service date command [904](#)
 night-service day command [904](#)
 night-service everyday command [905](#)
 night-service weekday command [905](#)
 night-service weekend command [905](#)
 no-answer call forwarding [764](#)
 no ephone command [74](#)
 no-reg (ephone-hunt) command [889](#)
 no-reg command [253](#)
 no supplementary-service sip moved-temporary command [1542, 1566](#)
 no supplementary-service sip refer command [1566](#)
 notification, night-service [864](#)
 notification, on-hold [1306](#)
 notify telephone-event command [91, 108](#)
 not-ready, automatic, ephone hunt groups [863](#)
 no upgrade command [72](#)
 no vad command [565](#)
 no voice register pool command [77](#)
 nte-end-digit-delay command [236](#)
 NTP (Network Time Protocol) [85, 127](#)
 ntp server command [99](#)
 ntp-server command [164](#)
 number (voice logout-profile) command [1122](#)
 number (voice register dn) command [238, 875, 1186](#)
 number (voice register pool) command [241, 1186, 1188](#)
 number (voice user-profile) command [1131](#)
 number command [228, 259, 554](#)
 number plan [382](#)
 num-buttons command [231](#)
 num-lines command [308](#)

O

octo-lines

- autoprovisioning in SRST fallback mode [1588](#)
- barge [667](#)
- conferencing [950](#)
- description [200](#)
- privacy [667](#)

Olson Timezones [85](#)

one-quarter common intermediate format, see QCIF [1398](#)

on-hold notification [1306](#)

OOD-R (out-of-dialog refer) [87](#)

open logical channel (OLC) [1402](#)

operation command [1237](#)

option 150 and configuration files, changing TFTP address [110](#)

option 150 ip command [93, 95, 111](#)

overlaid ephone-dns [207, 866](#)

- call waiting [868](#)
- definition [205](#)
- examples [927](#)
- huntstop [866](#)
- huntstop channel [910](#)
- preference [866](#)
- restrictions [909](#)
- rollover to another button [870](#)

overlap-signal command [158](#)

override for after-hours toll bar [683](#)

P

packet voice/data modules (PVDM) [451](#)

paging [1255](#)

paging command [1260](#)

paging-dn command [1263](#)

paging group command [1262](#)

parallel hunt groups [857](#)

param ea-password command [336](#)

param max-entries [1156, 1157](#)

param passwd-prompt filename [1157](#)

paramspace callsetup after-hours-exempt command [690](#)

paramspace command [337](#)

param term-digit [1156, 1157](#)

param user-prompt filename [1157](#)

parking calls [703, 704](#)

Park Monitor [709](#)

park reservation-group command [714](#)

park reservation groups [706](#)

park-slot command [713](#)

Park soft key [1337](#)

pattern command [244](#)

pattern direct command [559](#)

pattern ext-to-ext busy command [560](#)

pattern ext-to-ext no-answer command [560](#)

pattern trunk-to-ext busy command [560](#)

pattern trunk-to-ext no-answer command [560](#)

PBX model [383](#)

PBX system [29, 226](#)

peer ephone hunt groups [855](#)

per-phone configuration files [127, 360](#)

personal speed dial [1383](#)

phone authentication [581](#)

authentication string entering on phone [626](#)

CA configuration [598](#)

CAPF server configuration [613](#)

certificates [585](#)

configuration tasks [598](#)

CTL client and CTL provider configuration [608](#)

examples [643](#)

MIC importing [627](#)

PKI [585](#)

RA configuration [623](#)

telephony-service security configuration [605](#)

telephony-service security parameters [605](#)

phone-key-size command [615](#)

phone labels [1462](#)

phoneload command [232](#)

Phoneload-support command [308](#)

- phone number plan [382](#)
- phone-redirect-limit command [828](#)
- phones
 - analog [212](#)
 - basic configuration [189](#)
 - configuration files [359](#)
 - remote teleworker [217](#)
- phone screen
 - custom background images [1458](#)
 - header bar display [1461](#)
 - system message display [1465](#)
- Phones in Cisco Unified CME [191](#)
- phone-specific parameters for individual SIP phones [240](#)
- phone user GUI access setup [529](#)
 - using CLI [530](#)
 - using GUI [529](#)
- Phone User Interface for BLF-Speed-Dial [1282](#)
- pickup, *See* call pickup
- pickup-call any-group command [878](#)
- pickup-group command [878](#)
- PickUp soft key [1337](#)
- pilot command [887, 896](#)
- PIN (personal identification number) [685](#)
- pin (voice logout-profile) command [1122](#)
- pin (voice user-profile) command [1131](#)
- pin command [692](#)
- PKI (Public Key Infrastructure) [585](#)
- PLK [1340](#)
- policy-list command [346](#)
- port (CAPF-server) command [615](#)
- precedence
 - blocked announcement [1209](#)
 - busy station announcement [1209](#)
 - explained [1202](#)
 - isolated code announcement [1209](#)
 - unauthorized announcement [1210](#)
 - vacant code announcement [1210](#)
- preemption
 - explained [1203](#)
 - preemption reserve timer command [1222](#)
 - preemption tone timer command [1221](#)
 - preemption trunkgroup command [1221](#)
 - preemption user command [1221](#)
 - preference (ephone-dn) command [847, 873](#)
 - preference (ephone-hunt) command [889](#)
 - preference (voice hunt group) command [897](#)
 - preference, dial-peer [847](#)
 - preference command [259, 875](#)
 - preference command, overlaid ephone-dns [866, 910](#)
 - preference command for prebuilt dns [1593](#)
 - presence call-list command [1284, 1288, 1291](#)
 - presence command [1284, 1293](#)
 - presence enable command [1284](#)
 - presence service [1277](#)
 - present-call command [890](#)
 - Preventing Local Call Forwarding [859](#)
 - privacy [667](#)
 - privacy-button command [676, 679, 1122, 1132](#)
 - privacy command [675, 676, 678](#)
 - privacy initial-state command [679](#)
 - privacy-on-hold command [675, 678](#)
 - private lines to Public Switched Telephone Network (PSTN) [209](#)
 - profile-identifier register command [968](#)
 - Programmable Line Keys [1340](#)
 - protocol mode command [138](#)
 - provision-tag command [344](#)
 - PTT [1462](#)
 - push-to-talk [1462](#)

Q

- QCIF (one-quarter common intermediate format) [1398](#)
- qsig decode command [810](#)

R

- RA (registration authority) [586](#)

RADIUS accounting [31](#)
 ready/not-ready status, hunt groups [862](#)
 Real-Time Transport Protocol, *See* RTP
 rebooting phones [369](#)
 Redial soft key [1337](#)
 redirect-called translation rule [394](#)
 redirect-target translation rule [394](#)
 reference-pooltype command [307](#)
 refer-ood enable command [112](#)
 refer target dial-peer command [1548](#)
 regenerate command [610, 612](#)
 register id command [1546, 1569](#)
 register support, SIP [87](#)
 registrar command [91, 108, 143](#)
 registrar server command [91, 1542, 1567](#)
 registration, blocking automatic [151](#)
 registration, video-enabled endpoints [1398](#)
 registration authority, *See* RA
 relay, DTMF [86](#)
 reminder, call-park [705](#)
 reminder, on-hold [1306](#)
 remote-in-use (call state) [1336](#)
 remote phones [217](#)
 Remove Last Conference Participant [1005](#)
 request outstanding command [1655](#)
 request timeout command [1656](#)
 reset (voice register global) command [376, 377](#)
 reset (voice register pool) command [72](#)
 reset tapi command [374](#)
 resetting all SIP phones [375](#)
 resetting a TAPI session [374](#)
 resetting phones
 description [369](#)
 reset (ephone) command [371, 375](#)
 resolution, for video [1398](#)
 response size command [1655](#)
 response timeout command [1657](#)
 restarting phones
 description [369](#)

 restart (ephone) command [372](#)
 Resume soft key [1337](#)
 retry register command [92, 108](#)
 revocation-check command [476, 478, 603, 624, 628, 636](#)
 RFC 2833 DTMF MTP passthrough [541](#)
 ring command [1308](#)
 ringing, distinctive [1305](#)
 ringing call state [1336](#)
 ring number command (redundant router) [157](#)
 RmLstC soft key [1337](#)
 rollover button for overlaid ephone-dns [870](#)
 route code [1206](#)
 route-code command [1222](#)
 routing, loopback [1193](#)
 RSA key pair [586](#)
 rsakeypair command [476, 478, 603, 624](#)
 RTP (Real-Time Transport Protocol) [1404](#)
 RTP packets [1404](#)
 rule command [394](#)

S

SAST (system administrator security token)
 sast1 trustpoint command [609, 611](#)
 sast2 trustpoint command [609, 612](#)
 SCCP (Skinny Client Control Protocol)
 analog phones [212](#)
 firmware [62](#)
 security [581](#)
 sccp blf-speed-dial retry-interval command [1293](#)
 sccp ccm command [462, 964](#)
 sccp ccm group command [458, 493, 964, 967](#)
 sccp command [965](#)
 SCCP Controlled Analog (FXS) Ports [284](#)
 sccp ip precedence command [469](#)
 sccp local command [462, 964](#)
 SCCP video endpoints [1400](#)
 sdsfarm conference mute-on command [969](#)
 sdsfarm tag command [465, 467, 496, 969](#)

- sdspfarm transcode sessions [501, 1037](#)
- sdspfarm transcode sessions command [465, 495](#)
- sdspfarm units [501, 1037](#)
- sdspfarm units command [969](#)
- sdspfarm unregister force [501, 1037](#)
- secondary dial tone [384](#)
- secondary-dialtone command [402](#)
- secondary numbers [203](#)
- secondary start command [890](#)
- secure real-time transport protocol [581](#)
- secure-signaling trustpoint command [606](#)
- Secure SIP Trunk Support on Cisco Unified CME [593](#)
- secure transcoding [454, 596](#)
- security, *See* phone authentication
- security command [232](#)
- seized (call state) [1336](#)
- selective call forwarding [764](#)
- Select soft key [1337](#)
- sequential ephone hunt groups [854](#)
- serial-number command [624](#)
- server (CTL-client) command [609](#)
- server cme command [610, 612](#)
- server command [1293](#)
- server-security-mode command [607](#)
- service command [336, 338](#)
- service dhcp command [97](#)
- service digit [1205](#)
- service-digit command [1222](#)
- service directed-pickup command [877](#)
- service-domain command [1213, 1220](#)
- service-domain midcall-mismatch command [1222](#)
- service domains [1207](#)
- service dss command [1382](#)
- service fac [1154](#)
- service local-directory command [1042](#)
- service phone 722CodecSupport command [255](#)
- service phone command [1507, 1509](#)
- service phone thumbButton1 command [1511](#)
- service phone videoCapability command [1414](#)
- Session Initiation Protocol, *See* SIP
- session protocol command [564](#)
- session-server command [1544, 1548, 1549](#)
- session target command [338, 562, 564](#)
- session transport protocol [221](#)
- shared ephone-dns [204](#)
- shared-line command [238](#)
- shared-line overlays [867](#)
- shared lines [202, 382](#)
- show call active video command [1418](#)
- show call prompt-mem-usage command [820](#)
- show dspfarm sessions active command [472](#)
- show dspfarm sessions command [471](#)
- show dspfarm sessions summary command [471](#)
- show ephone-dn park command [717](#)
- show ephone-dn whisper-intercom command [1184](#)
- show ephone offhook command [1418](#)
- show ephone phone-load command [80](#)
- show ephone registered command [1415, 1418](#)
- show ephone rtp connections command [221](#)
- show ephone socket command [141](#)
- show fb-its-log command [1660](#)
- show rtp connections command [1418](#)
- show running-config command [1417](#)
- show sccp command [470](#)
- show sccp connections command [470](#)
- show sccp connections details command [472](#)
- show sdspfarm command [470](#)
- show shared-line command [507, 509](#)
- show sip-ua register status command [109, 110](#)
- show sip-ua statistics command [109, 110](#)
- show sip-ua status command [109](#)
- show sip-ua timers command [109, 110](#)
- show telephony-service bulk-speed-dial command [1387](#)
- show telephony-service security-info command [607](#)
- show telephony-service tftp-bindings command [363](#)
- show voice emergency callers command [1098](#)
- show voice moh-group command [1251](#)
- show voice moh-group statistics command [1252](#)

- show voice register hfs command [181](#)
- show voice register profile text command [365](#)
- show voice register tftp-bind command [365](#)
- show voip rtp connections command [819](#), [1404](#)
- signal immediate command [1237](#)
- signal loop-start live-feed command [1237](#)
- signature [586](#)
- single in-line memory module (SIMM) sockets [451](#)
- single-line ephone-dn [199](#)
- SIP (Session Initiation Protocol)
 - dial plans [220](#)
 - endpoints [1398](#)
 - register support [87](#)
 - shared lines [202](#)
- sip command [91](#), [1542](#), [1566](#)
- SIP MWI - QSIG translation [542](#)
- SIP phone firmware, upgrading [69](#)
- SIP-to-SIP call forwarding [820](#)
- sip-ua command [112](#), [143](#), [570](#), [573](#), [1283](#)
- slots, call-park [704](#)
- snr answer too soon time [1325](#)
- snr calling-number local command [1322](#)
- snr command [1322](#)
- snr ring-stop [1325](#)
- soft key
 - display [1335](#)
 - DND [863](#)
 - feature blocking [1335](#)
 - HLog [863](#)
- softkeys alerting command [1349](#)
- softkeys commands [1335](#)
- softkeys connected (voice register template) command [1352](#)
- softkeys connected command [551](#), [555](#), [973](#), [1322](#), [1349](#)
- softkeys hold command [974](#), [1349](#), [1352](#)
- softkeys idle (voice register template) command [1352](#)
- softkeys idle command [974](#), [1066](#), [1322](#), [1349](#)
- softkeys remote-in-use command [671](#), [673](#), [1349](#)
- softkeys ringIn command [1066](#)
- softkeys ringing command [1350](#)
- softkeys seized (voice register template) command [1352](#)
- softkeys seized command [883](#), [974](#), [1350](#)
- software, downloading for Cisco Unified CME [62](#)
- source-addr command [614](#)
- source-address command [160](#)
- speed dial
 - bulk loading [1386](#)
 - buttons on phones [1384](#)
 - local [1380](#)
 - monitor-line button [1378](#)
 - personal [1383](#)
- speed-dial (voice logout-profile) command [1122](#)
- speed-dial (voice user-profile) command [1131](#)
- speeddial.xml file [1376](#)
- speed dial buttons [1389](#)
- speed-dial command [1385](#), [1390](#)
- speed-dial options in GUI [1113](#)
- speed-dial options in phone user interface [1113](#)
- speed-dial user interface [1379](#)
- spfarm profile command [966](#)
- squeeze command [152](#), [361](#)
- srst dn line-mode command [1590](#)
- srst dn template command [1590](#)
- srst ephone description command [1591](#)
- srst ephone template command [1590](#)
- SRST fallback
 - preference command for prebuilt dns [1593](#)
- SRST fallback mode [1583](#)
- srst mode auto-provision command [1590](#)
- S RTP [581](#)
- srtp fallback command [632](#), [634](#)
- subnet command [1092](#)
- supplementary-service h225-notify cid-update (dial-peer) command [818](#)
- supplementary-service h225-notify cid-update (voice-service) command [817](#)
- supplementary-service h450.12 (dial-peer) command [805](#)
- supplementary-service h450.12 (voice-service) command [804](#)

supplementary-service h450.2 (dial-peer) command [792](#)
 supplementary-service h450.2 (voice-service) command [791](#)
 supplementary-service h450.3 (dial-peer) command [792](#)
 supplementary-service h450.3 (voice-service) command [791, 808](#)
 supplementary-service h450.7 command [810, 812](#)
 supplementary-service media-renegotiate command [631](#)
 supplementary-service qsig call-forward command [810, 812](#)
 supplementary-service sip moved-temporarily command [813](#)
 supplementary-service sip refer command [814](#)
 switchback interval command [460](#)
 switchback method command [459](#)
 switchover method command [459](#)
 system administrator GUI access setup [523](#)
 system administrator security token, *See* SAST
 system-defined locales [410](#)
 system message command [1500](#)

T

TACACS authentication for HTTP server [521](#)
 TAPI (Telephony Application Programming Interface) software [65](#)
 telephony-service ccm-compatible (h323 voice-service) command [816](#)
 telephony-service ccm-compatible (voice-class) command [817](#)
 telephony service command [68, 78](#)
 telephony-service security parameters [605](#)
 teleworker remote phones [217](#)
 telnet-support command [308](#)
 template command [829, 1531](#)
 templates, creating and applying [1530](#)
 tftp-path command [161](#)
 TFTP server
 changing address [110](#)
 storing configuration files [127, 359](#)
 tftp-server command [68, 78, 147](#)
 tftp-server-credentials trustpoint command [606](#)
 three-party ad hoc conferencing [951](#)
 three-party conferencing, *See* conferencing
 time-format command [150, 163](#)
 timeout command [888, 897](#)
 timeouts busy command [154](#)
 timeouts interdigit (telephony-service) command [154](#)
 timeouts night-service bell command [905](#)
 timeout transfer-recall command [790, 796](#)
 timers register command [92, 109](#)
 time-webedit command [525](#)
 time-zone command [150](#)
 timezone command [162](#)
 TLS (transport layer security) [588](#)
 toll bar, after-hours [683](#)
 toll bar override [683](#)
 toll fraud prevention [38](#)
 transcoding support [449](#)
 transfer, *See* call transfer
 transfer-digit-collect command [791](#)
 transfer max-length command [798](#)
 transfer-mode command [796](#)
 transfer-pattern blocked command [797, 803](#)
 transfer-pattern command [790, 801](#)
 transfer recall [210, 770](#)
 transfer-system command [789](#)
 transfer-system full-consult command [969](#)
 transfer to voice mail [544](#)
 translate [404](#)
 translate command [394, 397](#)
 translate-outgoing command [400](#)
 translation-profile command [396](#)
 translation-profile incoming command [398](#)
 transport command [308](#)
 transport layer security, *See* TLS
 Trnsfer soft key [1337](#)
 TrnsfVM soft key [1337](#)
 troubleshooting Cisco phone firmware upgrade [81](#)

troubleshooting tips for upgrading, downgrading,
converting phone firmware [81](#)

troubleshooting video conferences [1031](#)

trunk command [263, 267](#)

trunk lines [209](#)

trunk monitoring [210](#)

trunk optimization [210](#)

Trunk-to-Trunk Transfer Blocking for Toll Fraud
Prevention [768](#)

trustpoint [586](#)

trustpoint (credentials) command [621](#)

trustpoint-label command [614](#)

TSP (TAPI Service Provider) software [65](#)

type command [235, 241, 244, 271, 282, 1186, 1188](#)

type ip-ste command [293](#)

type Jabber-Win command [1513](#)

U

unauthorized precedence announcement [1210](#)

upa command [1213](#)

upgrade command [71, 75](#)

upgrading SIP firmware [69](#)

url authentication command [1118, 1126](#)

url-button command [1361, 1362](#)

url command [1503, 1505](#)

url directories command [1046](#)

url directory command [1051](#)

url idle command [1500](#)
[1483](#)

url services root command [1572](#)

user (voice logout-profile) command [1121](#)

user (voice user-profile) command [1131](#)

user-defined locales [411](#)

user GUI access setup [529](#)

user-locale (ephone-template) command [426, 437](#)

user-locale command [423, 425, 432, 434, 436](#)

user locales
 alternative [412](#)

 system-defined [410](#)

 user-defined [411](#)

username command [530](#)

utf8 command [232](#)

V

vacant code announcement [1210](#)

vad command [339](#)

vca command [1223](#)

vendorConfig parameters [1462](#)

verifying firmware version on an IP phone [80](#)

verifying SIP profiles [365](#)

VG2xx autoconfiguration [214](#)

video
 call setup [1402](#)

 codec selection process [1401](#)

 codecs supported [1398](#)

 conferences [1015](#)

 firmware version [1398](#)

 formats supported [1398](#)

 icon [1399](#)

 prerequisites [1405](#)

 restrictions [1405](#)

 setting parameters [1414](#)

 transcoding [487, 490](#)

 transrating [490](#)

 troubleshooting [1417](#)

video (config-ephone) command [1416](#)

video (config-telephony) command [1414](#)

video capability class [1019](#)

video conferences
 configuring DSP farm [1024](#)

 troubleshooting [1031](#)

video conferencing [1015](#)

video format [490](#)

video transcoding [487](#)
 configuring DSP farm [492](#)

virtual voice port [198](#)

- VLAN [49](#)
 - vm-integration command [559](#)
 - vmwi dc-voltage command [573](#)
 - voice [1153](#)
 - Voice and Video Hardware Conferencing [1002](#)
 - voice call send-alert command [1541](#)
 - voice-card command [962](#)
 - voice class codec command [633](#)
 - voice-class codec command [634](#)
 - voice class custom-cptone command [963](#)
 - voice class media command [172](#)
 - voice class mlpp command [1220](#)
 - voice-class mlpp command [1220](#)
 - voice emergency response location command [1085, 1092](#)
 - voice emergency response zone command [1086](#)
 - voice-gateway system command [282](#)
 - Voice Hunt Group
 - Displaying Support for the Name of a Called Voice Hunt Group [857](#)
 - voice hunt-group command [896](#)
 - Voice Hunt Group Descriptions [859](#)
 - Voice Hunt Groups
 - Preventing Local Call Forwarding to the Final Agent [859](#)
 - voice hunt groups [894](#)
 - voice logout-profile command [1121](#)
 - voice lpcor call-block cause command [732](#)
 - voice lpcor custom [1153](#)
 - voice lpcor custom command [732](#)
 - voice lpcor enable [1153](#)
 - voice lpcor enable command [732](#)
 - voice lpcor ip-phone mobility command [746](#)
 - voice lpcor ip-phone subnet command [745](#)
 - voice lpcor ip-trunk subnet incoming command [738](#)
 - voice lpcor policy command [732](#)
 - voice mail
 - mailbox selection policy [547, 548](#)
 - MWI prefix specification for SIP [571](#)
 - voicemail (voice register global) command [546, 551, 557](#)
 - voicemail command [554](#)
 - voice mlpp command [1212, 1221](#)
 - voice moh-group command [1242](#)
 - voice port, virtual [198](#)
 - voice-port command [282](#)
 - voice register dialplan command [243](#)
 - voice register dn command [238, 557, 1050, 1185](#)
 - voice register global command [71, 75, 160, 162, 170, 828, 1051](#)
 - voice register pool command [72, 240, 696, 1186, 1188](#)
 - voice-register session-server command [1546, 1568](#)
 - voice register template command [829, 1531](#)
 - voice services hardware [45](#)
 - voice service voip command [1541](#)
 - voice translation-profile command [394](#)
 - voice translation-rule command [393](#)
 - voice user-profile command [1130](#)
 - VoIP-to-VoIP connections
 - configuring [805](#)
 - H.450 tandem gateways [779](#)
 - hairpin call routing [776, 783](#)
 - vpn-gateway command [1440](#)
 - vpn-group command [1440](#)
 - vpn-hash-algorithm command [1440](#)
 - vpn-profile command [1440](#)
 - vpn-trustpoint command [1440](#)
-
- ## W
- watcher all command [1293](#)
 - watch mode for a phone [209](#)
 - web admin customer command [529](#)
 - web admin system command [524](#)
 - web customize load command [527](#)
 - whisper intercom [1179](#)
 - whisper intercom command [1184](#)

X

XML application programming interface [1615](#)

Xml-config command [308](#)

XML files

 downloading xml.template [64](#)

 GUI configuration file [526](#)

 speeddial.xml for system speed dial [1376](#)

xml user command [1658](#)

