



INDEX

Symbols

? command [16](#)

A

atrace_save.log [177](#)

autoregistration [127](#), [1104](#), [1126](#), [1131](#), [1159](#)

B

backup category command [110](#)

backup command [112](#), [114](#)

C

Cisco IOS configuration changes, saving [16](#)

command

 backup [112](#), [114](#)

 backup category [110](#)

 copy ftp [129](#)

 copy log [131](#)

 copy running-config [133](#)

 copy startup-config [135](#)

 copy tftp [137](#)

 ip domain-name [162](#), [163](#)

 list number delete [168](#), [170](#)

 log console [172](#)

 log console monitor [173](#)

 log trace boot [176](#)

 log trace buffer save [177](#)

 name [186](#)

 ntp server [195](#)

offline [198](#)

reload [1106](#)

restore [1108](#)

service-module [15](#)

session [15](#)

show backup [1114](#)

show backup history [1116](#)

show backup server [1119](#)

show clock detail [1123](#)

show crypto key [1125](#)

show hosts [1132](#)

show ip route [1133](#)

show log [1140](#)

show logging [1143](#)

show logs [1145](#)

show memory [1146](#)

show ntp source [1152](#)

show process [1155](#)

show running-config [1160](#)

show software [1162](#)

show software directory [1164](#)

show startup-config [1166](#)

show trace buffer [1170](#)

show trace store [1172](#)

show trace store-prev [1174](#)

shutdown [1179](#)

software download abort [1180](#)

software download clean [1181](#)

software download server [1183](#)

software download status [1184](#)

software download upgrade [1186](#)

software install clean [1188](#)

software install downgrade [1190](#)

software install upgrade [1192](#)
software remove [1193](#)
telnet [15](#)
username [1204](#)
command environment [14](#)
command modes, understanding [13 to 14](#)
commands
 context-sensitive help for abbreviating [16](#)
 default form, using [16](#)
 no form, using [16](#)
configurations, saving [16](#)
copy ftp command [129](#)
copy log command [131](#)
copy running-config command [133](#)
copy startup-config command [135](#)
copy tftp command [137](#)

D

DRAM [129](#)

F

Feature Navigator
 See platforms, supported

H

hardware platforms
 See platforms, supported
help command [16](#)

I

ip domain-name command [162, 163](#)

L

list number delete command [168, 170](#)
log console command [172](#)
log console monitor command [173](#)
log trace boot command [176](#)
log trace buffer save command [177](#)

M

modes
 See command modes

N

name command [186](#)
ntp server command [195](#)

O

offline command [198](#)

P

platforms, supported
 Feature Navigator, identify using [17](#)
prompts, system [14](#)

Q

question mark (?) command [16](#)

R

reload command [1106](#)
restore command [1108](#)

S

service-module command [15](#)
session command [15](#)
show backup command [1114](#)
show backup history command [1116](#)
show backup server command [1119](#)
show clock detail command [1123](#)
show crypto key command [1125](#)
show hosts command [1132](#)
show ip route command [1133](#)
show log command [1140](#)
show logging command [1143](#)
show logs command [1145](#)
show memory command [1146](#)
show ntp source command [1152](#)
show process command [1155](#)
show running-config command [1160](#)
show software command [1162](#)
show software directory command [1164](#)
show startup-config command [1166](#)
show trace buffer command [1170](#)
show trace store command [1172](#)
show trace store-prev command [1174](#)
shutdown command [1179](#)
software download abort command [1180](#)
software download clean command [1181](#)
software download server command [1183](#)
software download status command [1184](#)
software download upgrade command [1186](#)
software install clean command [1188](#)
software install downgrade command [1190](#)
software install upgrade command [1192](#)
software remove command [1193](#)

T

Tab key, command completion [16](#)
telnet command [15](#)

Telnet session [15](#)

U

user EXEC mode, summary of [14](#)
username command [1204](#)

