



M

Last Updated: November 17, 2010

member

member

To assign a member to an SDL, use the **member** command in Cisco UMG list manager edit mode.

member *number* **type** { **sub** | **list** }

Syntax Description

<i>number</i>	Either a subscriber's mailbox number (sub) or the list number of another SDL (list).
sub	Member type: a subscriber.
list	Member type: another SDL.

Command Modes

Cisco UMG list manager edit (listmgr-edit)

Command History

Cisco UMG Version	Modification
1.0	This command was introduced.

Usage Guidelines

Use this command to create members for an SDL. Members can be of two types, either **sub**, which is a subscriber, or **list**, which is another SDL.

Messages sent to an SDL cannot be received unless that SDL has members.

Members of an SDL cannot receive any messages unless that SDL has at least one authorized sender configured.

The system accepts any subscriber as a member, even one whose number it does not find in the subscriber directory. However, it will not accept as members lists that do not exist.



Note

If you change any detail of any member's information, you must republish to all peer messaging gateways all the SDLs to which the member belongs.

Examples

The following example illustrates the use of the member command where the new member is another SDL:

```
umg-1# config t
umg-1(config)# list-manager
umg-1(listmgr)# list number 2345
umg-1(listmgr-edit)# member 4085550100 type list
umg-1(listmgr-edit)# end
umg-1(listmanager)# list publish id 1000
umg-1(listmanager)# end
umg-1(config)# end
umg-1#
```

Related Commands	Command	Description
	list-manager	Locks down list management on all peer Cisco UMGs and enters list manager edit mode.
	list number	Creates or edits an SDL.
	list publish	Publishes one or more lists to one or more peer messaging gateways.
	privilege	Configures an authorized sender to an SDL.
	show list	Displays a list of the SDLs that are configured.
	show list privilege	Displays the authorized sender to a specific SDL.
	show list tracking version	Displays an SDL tracking version.

