



# X

---

**Last Updated: April 14, 2008**

[xml credentials hidden \(site\)](#)

[xml username password \(site\)](#)

# xml credentials hidden (site)

To configure the hidden XML credentials for the site, use the **xml credentials hidden** command in Cisco Unity Express site-configuration mode.

**xml credentials hidden** *username-password-hash*

<b>Syntax Description</b>	<i>username-password-hash</i> Encrypted XML credentials for the username and password for the site.
---------------------------	---

<b>Defaults</b>	No hidden XML credentials are configured for the site.
-----------------	--

<b>Command Modes</b>	Cisco Unity Express site-configuration
----------------------	--

<b>Command History</b>	<b>Cisco Unity Express Release</b>	<b>Modification</b>
	3.2	This command was introduced.

<b>Examples</b>	<p>The following example configures the XML hidden credentials for site4:</p> <pre> se-10-0-0-0# config t se-10-0-0-0(config)# site name site1 se-10-0-0-0 (site)# xml credentials hidden "GlxGRq8cUmFqrOHVxftjAknfGWTYHfmPSd8ZZNgd+ Y9J3x1k2B35j0nfGWTYHfmPSd8ZZNgd+Y9J3x1k2B35j0nfGWTYHfmPSd8ZZNgd+Y9J3x1k2B35j0nfGWTYHfmP" se-10-0-0-0 (site)# exit </pre>
-----------------	---

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">description (site)</a>	Configures a description for a specific site.
	<a href="#">site name</a>	Creates a site.
	<a href="#">web username password (site)</a>	Configures the Web username and Web password for a site.
	<a href="#">web credentials hidden (site)</a>	Configures the Web hidden credentials for a site
	<a href="#">xml username password (site)</a>	Configures the XML username and password for a site.

# xml username password (site)

To configure the XML username and password for the site, use the **xml username password** command in Cisco Unity Express site-configuration mode.

**xml username** *username* **password** *password*

## Syntax Description

<i>username</i>	XML username for the site
<i>password</i>	XML password for the site

## Defaults

No XML username and password are configured for the site.

## Command Modes

Cisco Unity Express site-configuration

## Command History

Cisco Unity Express Release	Modification
3.2	This command was introduced.

## Examples

The following example sets the XML username and password for site1 to user1 and password1:

```
se-10-0-0-0# config t
se-10-0-0-0(config)# site name site1
se-10-0-0-0 (site)# xml username user1 password password1
se-10-0-0-0 (site)# exit
```

## Related Commands

Command	Description
<a href="#">description (site)</a>	Configures a description for a specific site.
<a href="#">site name</a>	Creates a site.
<a href="#">web username password (site)</a>	Configures the Web username and Web password for a site.
<a href="#">web credentials hidden (site)</a>	Configures the Web hidden credentials for a site
<a href="#">xml credentials hidden (site)</a>	Configures the XML hidden credentials for a site

