



## INDEX

---

### A

accounting command **1**  
antenna receive command **3**  
audience **11**  
authentication client command **6**  
authentication command **4**  
authentication key-management command **7**  
authentication network-eap command **9**  
authentication open command **11**  
authentication shared command **13**

---

### B

beacon command **15**  
boot buffersize command **16**  
boot ios-break command **17**  
boot upgrade command **18**  
bridge aging-time command **19**  
bridge forward-time command **20**  
bridge-group block-unknown-source command **25**  
bridge-group command **27**  
bridge-group path-cost command **26**  
bridge-group priority command **28**  
bridge-group spanning-disabled command **29**  
bridge-group subscriber-loop-control command **30**  
bridge-group unicast-flooding command **31**  
bridge hello-time command **21**  
bridge max-age command **22**  
bridge priority command **23**  
bridge protocol ieee command **24**  
broadcast-key command **32**

---

---

### C

caution, description **12**  
cca command **34**  
channel command **35**  
channel-match command **38**  
channels, supported by regulatory domains **36**  
class map  
    command **39**  
    creating **39**  
    defining the match criteria **125**  
clear dot11 aaa authentication mac-authen filter-cache command **41**  
clear dot11 aaa client command **43**  
clear dot11 cckm-statistics command **42**  
clear dot11 hold-list command **44**  
clear dot11 statistics command **45**  
clear iapp rogue-ap-list command **46**  
clear iapp statistics command **47**  
clear wlccp wds command **48**  
command modes defined **1**  
concatenation command **49**  
conventions  
    command **12**  
    publication **12**  
    text **12**  
countermeasure tkip hold-time command **50**  
country codes **84**

---

### D

debug dot11 aaa command **52**  
debug dot11 command **51**

debug dot11 dot11radio command **54**  
debug dot11 ids eap command **56**  
debug iapp command **57**  
debug radius local-server command **58**  
debug wlccp ap command **59**  
debug wlccp packet command **60**  
debug wlccp rmlib command **61**  
debug wlccp wds command **62**  
dfs band command **64**  
distance command **66**  
documentation related **12**  
document conventions **12**  
dot11 aaa authentication attributes service-type login-only command **68**  
dot11 aaa authentication mac-authen filter-cache command **69**  
dot11 aaa csid **70**  
dot11 activity-timeout command **71**  
dot11 adjacent-ap command **73**  
dot11 antenna-alignment command **74**  
dot11 extension aironet command **77**  
dot11 ids eap attempts command **79**  
dot11 igmp snooping-helper command **80**  
dot11 lbs command **81**  
dot11 linktest command **82**  
dot11 location isocc **84**  
dot11 mbssid command **85**  
dot11 meter command **86**  
dot11 network-map command **87**  
dot11 phone command **88**  
dot11 priority\_map avvid command **89**  
dot11 ssid command **90**  
dot11 vlan-name command **92**  
dot1x reauth-period command **93**  
duplex command **94**

---

**E**

encryption command **99, 103**

exception crashinfo buffersize command **105**  
exception crashinfo file command **106**

---

**F**

fragment-threshold command **107**  
frequencies **35, 36**

---

**G**

global configuration mode **2, 3**  
group command **108**  
guest-mode command **109**

---

**H**

holdoff-time command **78**

---

**I**

iapp standby mac-address command **110**  
iapp standby poll-frequency command **111**  
iapp standby primary-shutdown command **112**  
iapp standby timeout command **113**  
information-element ssidl command **114**  
infrastructure-client command **115**  
infrastructure-ssid command **116**  
interface configuration mode **2, 3**  
interface dot11 command **117**  
interface dot11radio command **118**  
ip redirection command **119**  
ISO country codes **84**  
ITU country and area codes **84**

---

**L**

led flash command **122**  
logging buffered command **123**

logging snmp-trap command **124**

---

## M

manual

- audience **11**
- organization of **11**
- purpose of **11**

match (class-map configuration) command **125**

match command **125**

max-associations command **127**

mbssid (SSID configuration mode) command **129**

mbssid command **128**

method command **131**

mobile station command **132**

mobility network-id command **133**

modes, commands **1**

multicast address command **134**

---

## N

nas command **135**

note, description **12**

---

## P

packet retries command **136**

packet-type command **137**

parent command **138, 139**

payload-encapsulation command **140**

power client command **141**

power local command **144**

preamble-short command **147**

privileged EXEC mode **2**

publications, related **12**

---

## Q

QoS class map

- creating **39**

- defining the match criteria **125**

---

## R

radius local-server pac-generate command **148**

radius-server local command **149**

regulatory domains **35**

rts command **150**

---

## S

server-address command **151**

short-slot-time command **152**

show controllers dot11radio command **153**

show dot11 aaa mac-authen filter-cache command **154**

show dot11 adjacent-ap command **155**

show dot11 bssid command **159**

show dot11 carrier busy command **160**

show dot11 network-map command **162**

show dot11radio associations command **157**

show dot11 statistics client-traffic command **163**

show dot11 vlan-name command **164**

show environment command **165**

show iapp rogue-ap-list command **166**

show iapp standby-parms command **168**

show iapp statistics command **169**

show int dot11radio command **171**

show interfaces dot11radio command **170**

show interfaces dot11radio statistics command **172**

show led flash **173**

show power-injector command **174**

show radius local-server statistics command **175**

show running-config ssid command **177**

show spanning-tree command **178**

show wlccp command **179**

snmp-server enable traps envmon temperature command **182**  
wpa-psk command **218**  
snmp-server group command **183**  
snmp-server location command **186**  
snmp-server user command **187**  
snmp-server view command **189**  
speed (Ethernet interface) command **191**  
speed (radio interface) command **193**  
speed ofdm command **196**  
ssid command **198**  
station-role command **200**  
station-role install command **203**  
STP **24**

---

## T

traffic-class command **204**

---

## U

user command **206**  
user EXEC mode **2**

---

## V

vlan command **208**

---

## W

warnings **12**  
WISPr **186**  
wlccp ap command **209**  
wlccp authentication-server command **210**  
wlccp wds aaa authentication mac-authen filter-cache command **212**  
wlccp wds priority command **213**  
wlccp wnm ip address command **214**  
workgroup-bridge client-vlan command **215**  
world-mode command **216**