



A

aaa pod server command **22**
accounting command **24**
admin-traffic command **27**
admission-control command **25**
admit-traffic command **28**
anonymous-id command **30**
antenna receive command **31**
audience **v**
authentication client command **34**
authentication command **32**
authentication key-management command **35**
authentication network-eap command **37**
authentication open command **39**
authentication shared command **41**

B

beacon command **43**
boot buffersize command **44**
boot ios-break command **45**
boot mode-button command **46**
boot upgrade command **47**
bridge aging-time command **48**
bridge forward-time command **49**
bridge-group block-unknown-source command **54**
bridge-group command **56**
bridge-group path-cost command **55**
bridge-group priority command **57**
bridge-group spanning-disabled command **58**
bridge-group subscriber-loop-control command **59**
bridge-group unicast-flooding command **60**

bridge hello-time command **50**
bridge max-age command **51**
bridge priority command **52**
bridge protocol ieee command **53**
broadcast-key command **61**

C

cache authentication profile **63, 64**
cache expiry command **65**
caution, description **vi**
cca command **66**
channel command **67**
channel-match command **70**
class map
 command **71**
 creating **71**
 defining the match criteria **182**
clear dot11 aaa authentication mac-authen filter-cache
 command **73**
clear dot11 aaa client command **75**
clear dot11 cckm-statistics command **74**
clear dot11 hold-list command **76**
clear dot11 statistics command **77**
clear eap sessions command **78**
clear iapp rogue-ap-list command **79**
clear iapp statistics command **80**
clear ip igmp snooping membership command **81**
clear wlccp wds command **82**
clear wlccp wds recovery statistics command **83**
command modes defined **13**
concatenation command **84**
conventions

command [vi](#)
publication [vi](#)
text [vi](#)
countermeasure tkip hold-time command [85](#)
country codes [129](#)
cw-max command [86](#)
cw-min command [88](#)

D

debug dot11 aaa command [91](#)
debug dot11 cac command [93](#)
debug dot11 command [90](#)
debug dot11 dot11radio command [95](#)
debug dot11 ids eap command [97](#)
debug dot11 ids mfp command [98](#)
debug eap command [99](#)
debug iapp command [100](#)
debug radius local-server command [101](#)
debug wlccp ap command [102](#)
debug wlccp ap rm enhanced-neighbor-list command [103](#)
debug wlccp packet command [104](#)
debug wlccp rmlib command [105](#)
debug wlccp wds command [106](#)
description dot1x credentials command [108](#)
dfs band command [109](#)
distance command [110](#)
documentation related [vi](#)
document conventions [vi](#)
dot11 aaa authentication attributes service-type login-only
 command [111](#)
dot11 aaa authentication mac-authen filter-cache
 command [112](#)
dot11 aaa csid [113](#)
dot11 activity-timeout command [115](#)
dot11 adjacent-ap command [117](#)
dot11 extension aironet command [120](#)
dot11 extension power native command [121](#)
dot11 ids eap attempts command [123](#)

dot11 ids mfp command [124](#)
dot11 igmp snooping-helper command [125](#)
dot11 lbs command [126](#)
dot11 linktest command [127](#)
dot11 location isocc [129](#)
dot11 mbssid command [130](#)
dot11 meter command [131](#)
dot11 network-map command [132](#)
dot11 phone command [133](#)
dot11 priority_map avvid command [134](#)
dot11qos class command [135](#)
dot11 ssid command [137](#)
dot11 vlan-name command [139](#)
dot11 wpa handshake timeout [140](#)
dot1x credentials command [141](#)
dot1x eap profile (configuration interface mode)
 command [143](#)
dot1x eap profile (SSID configuration mode)
 command [144](#)
dot1x reauth-period command [146](#)
dot1x timeout supp-response command [145](#)
duplex command [146](#)

E

eap profile command [148](#)
encryption command [152, 156](#)
exception crashinfo buffersize command [158](#)
exception crashinfo file command [159](#)

F

fixed-slot command [160](#)
fragment-threshold command [162](#)
frequencies [67, 68](#)

G

global configuration mode [14, 15](#)

group command **163**
 guest-mode command **164**

H

holdoff-time command **122**

I

iapp standby mac-address command **165**
 iapp standby poll-frequency command **166**
 iapp standby primary-shutdown command **167**
 iapp standby timeout command **168**
 information-element ssidl command **169**
 infrastructure-client command **170**
 infrastructure-ssid command **171**
 interface configuration mode **14, 15**
 interface dot11 command **172**
 interface dot11radio command **173**
 ip igmp snooping vlan command **174**
 ip redirection command **175**
 ISO country codes **129**
 ITU country and area codes **129**

L

led display command **178**
 led flash command **178**
 logging buffered command **180**
 logging snmp-trap command **181**

M

manual
 audience **v**
 organization of **v**
 purpose of **v**
 match (class-map configuration) command **182**

match command **182**
 max-associations command **184**
 mbssid (SSID configuration mode) command **186**
 mbssid command **185**
 method command **188, 189**
 mobile station command **190**
 mobility network-id command **191**
 modes, commands **13**
 multicast address command **192**

N

nas command **193**
 note, description **vi**

P

packet max-retries command **194**
 packet retries command **196**
 packet timeout command **198**
 packet-type command **199**
 parent command **200, 201**
 password command **202**
 payload-encapsulation command **203**
 pki-trustpoint command **204**
 power client command **205**
 power inline negotiation command **207**
 power local command **209**
 preamble-short command **212**
 privileged EXEC mode **14**
 publications, related **vi**

Q

QoS class map
 creating **71**
 defining the match criteria **182**

R

radius local-server pac-generate command **215**
radius-server local command **216**
regulatory domains **67**
rts command **217**

S

server-address command **218**
short-slot-time command **219**
show boot mode-button command **220**
show controllers dot11radio command **221**
show dot11 aaa mac-authen filter-cache command **222**
show dot11 adjacent-ap command **223**
show dot11 bssid command **227**
show dot11 carrier busy command **230**
show dot11 directed-roam command **231**
show dot11 ids eap command **232**
show dot11 network-map command **234**
show dot11radio associations command **225**
show dot11 statistics client-traffic command **235**
show dot11 vlan-name command **236, 237**
show dot1x command **238**
show dot1x credentials command **240**
show eap registrations command **241**
show eap sessions command **243**
show environment command **244**
show iapp rogue-ap-list command **245**
show iapp standby-parms command **247**
show iapp statistics command **248**
show int dot11radio command **250**
show interfaces dot11radio command **249**
show interfaces dot11radio statistics command **251**
show ip igmp snooping groups command **252**
show led flash **253**
show radius local-server statistics command **256**
show running-config ssid command **257**
show spanning-tree command **258**

show wlccp ap enhanced-neighbor-list command **263**
show wlccp ap mn command **262**
show wlccp command **259**
snmp-server enable traps envmon temperature command **264**
snmp-server group command **265**
snmp-server location command **268**
snmp-server user command **269**
snmp-server view command **271**
speed (Ethernet interface) command **273**
speed (radio interface) command **275**
speed ofdm command **278**
ssid command **279**
station-role command **281**
station-role install command **285**
STP **53**

T

traffic-class command **288**
traffic-stream command **290**
transmit-op command **286**

U

user command **293**
user EXEC mode **14**
username command **292**

V

vlan command **295**

W

warnings **vi**
WISPr **268**
wlccp ap eap profile command **296**
wlccp ap username command **297**

wlccp authentication-server command **298**
wlccp wds aaa authentication mac-authen filter-cache
 command **300**
wlccp wds priority command **301**
wlecp wnm ip address command **303**
workgroup-bridge client-vlan command **304**
world-mode command **305**
wpa-psk command **307**
write memory command **308**
write terminal command **309**

