

Preface

The Preface describes the audience, organization, and conventions of this document. It also provides information on how to obtain other documentation. It includes the following sections:

- Audience, page v
- Document Organization, page v
- Conventions, page vi
- Related Documentation, page vi

Audience

This document is for experienced network administrators who configure and maintain Cisco wireless LAN controllers and Cisco lightweight access points. It also contains information useful to users who connect to a network via a Cisco Aironet 600 Series OfficeExtend Access Point.

Document Organization

The following table describes the contents of each chapter in this document:

Table 1 Document Organization	
Chapter and Title	Description
Chapter 1, "Unpacking and Installing the Access Point"	This chapter provides information on unpacking and installing the access point. It also gives you instructions on placement, and a description of the parts of the access point.
Chapter 2, "Access Point GUI"	This chapter describes the various pages in the access point's GUI.
Chapter 3, "Configuring the Features of the Access Point"	This chapter provides information on how to configure the features provided by the access point.
Chapter 4, "Declarations of Conformity and Regulatory Information"	This chapter contains declarations of conformity and regulatory information for the Cisco Aironet 600 Series OfficeExtend Access Point.
Appendix A, "Open Source Software Licenses and Notices"	This appendix contains the licenses and notices for open source software used in the Cisco Aironet 600 Series OfficeExtend Access Point

Conventions

The following table describes conventions used in this document:

 Table 2
 Command Syntax Guide

Convention	Description
boldface	Commands and keywords.
italic	Command input that is supplied by you.
[]	Keywords or arguments that appear within square brackets are optional.
{ x x x }	A choice of keywords (represented by x) appears in braces separated by vertical bars. You must select one.
^ or Ctrl	Represent the key labeled <i>Control</i> . For example, when you read ^ <i>D</i> or <i>Ctrl-D</i> , you should hold down the Control key while you press the D key.
screen font	Examples of information displayed on the screen.
boldface screen font	Examples of information that you must enter.
< >	Nonprinting characters, such as passwords, appear in angled brackets.
[]	Default responses to system prompts appear in square brackets.



Means reader needs to take note. Notes contain helpful suggestions or references to material not covered in the manual.



Means the following information will help you solve a problem.



Means reader needs to be careful. In this situation, you might perform an action that could result in equipment damage or loss of data.

Related Documentation

In addition to the information provided in this publication, you might need to refer to the the following documents:

• Cisco Wireless LAN Controller configuration guides.

http://www.cisco.com/en/US/products/ps10315/products_installation_and_configuration_guides_l ist.html

- Cisco Wireless LAN Controller command references. http://www.cisco.com/en/US/products/ps10315/prod_command_reference_list.html
- Cisco Wireless LAN Controller System Message Guide.

http://www.cisco.com/en/US/products/ps10315/products_system_message_guides_list.html

• Release Notes for Cisco Wireless LAN Controllers and Lightweight Access Points. http://www.cisco.com/en/US/products/ps10315/prod_release_notes_list.html