

# **About This Guide**

#### Revised: January 28, 2014, OL-31200-01

This section describes the objectives, audience, organization, and conventions of this software command reference. It contains the following sections:

- Document Revision History, page vii
- Objectives, page vii
- Audience, page vii
- Conventions, page viii
- Related Documentation, page ix
- Obtaining Documentation and Submitting a Service Request, page ix

### **Document Revision History**

The Document Revision History table below records technical changes to this document.

Document Number	Date	Change Summary
	January 28, 2014	Updated the auto-negotiation feature information for <b>duplex</b> and <b>speed</b> commands.
OL-31200-01	December 4, 2013	Initial release of the document.

### **Objectives**

This guide explains how to use the Command Line Interface on the Cisco ASR 901S Series Aggregation Services Router.

# Audience

This publication is for the person responsible for configuring the router. This guide is intended for the following audiences:

- Customers with technical networking background and experience
- System administrators who are familiar with the fundamentals of router-based internetworking, but who may not be familiar with Cisco IOS software
- System administrators who are responsible for installing and configuring internetworking equipment, and who are familiar with Cisco IOS software

## **Conventions**

This document uses the following conventions:

Convention	Indication	
<b>bold</b> font	Commands and keywords and user-entered text appear in <b>bold</b> font.	
<i>italic</i> font	Document titles, new or emphasized terms, and arguments for which you supply values are in <i>italic</i> font.	
[ ]	Elements in square brackets are optional.	
$\{x \mid y \mid z \}$	Required alternative keywords are grouped in braces and separated by vertical bars.	
[ x   y   z ]	Optional alternative keywords are grouped in brackets and separated by vertical bars.	
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.	
courier font	Terminal sessions and information the system displays appear in courier font.	
< >	Nonprinting characters such as passwords are in angle brackets.	
[]	Default responses to system prompts are in square brackets.	
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.	



Means reader take note.



Means the following information will help you solve a problem.



Means *reader be careful*. In this situation, you might perform an action that could result in equipment damage or loss of data.



Means *the described action saves time*. You can save time by performing the action described in the paragraph.

L



Means *reader be warned*. In this situation, you might perform an action that could result in bodily injury.

## **Related Documentation**

The following list includes documentation related to the product by implementation.

- Cisco ASR 901S Series Aggregation Services Router Software Configuration Guide
- Cisco ASR 901S Series Aggregation Services Router Hardware Installation Guide
- Regulatory Compliance and Safety Information for the Cisco ASR 901S Series Aggregation Services Router
- Release Notes for Cisco ASR 901S Series Aggregation Services Router for Cisco IOS Release



To obtain the latest information, access the online documentation.

# **Obtaining Documentation and Submitting a Service Request**

For information on obtaining documentation, using the Cisco Bug Search Tool (BST), submitting a service request, and gathering additional information, see *What's New in Cisco Product Documentation* at: http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html.

Subscribe to *What's New in Cisco Product Documentation*, which lists all new and revised Cisco technical documentation, as an RSS feed and deliver content directly to your desktop using a reader application. The RSS feeds are a free service.