



Connecting the Explorer® 2000™/3000™ to a Stereo TV and Stereo VCR and DVD Player

Explorer 2000/3000



Cable Input


Back of DVD Player



Optional Connection

Note: This connection is optional and if used without the other audio/video connections, it will provide monaural audio.

Back of Stereo TV



Back of Stereo VCR

