

Cisco Application eXtension Platform 1.0 Command Reference

Revised: 8/19/08, OL-15872-01

This guide contains the following sections:

- Entering and Exiting the Command Environment, page 1
- Cisco AXP 1.0 Commands, page 3
- Notices, page 128

Entering and Exiting the Command Environment

This section describes the procedures for entering and exiting the command environment where Cisco AXP configuration commands are executed, and consists of the following sections:

- EXEC and Configuration Modes, page 1
- Entering the Command Environment, page 2
- Exiting the Command Environment, page 3

EXEC and Configuration Modes

The Cisco AXP EXEC and Cisco AXP configuration command modes are similar to the EXEC and configuration modes for Cisco IOS CLI commands.

- Cisco AXP EXEC mode. This mode is similar to Cisco IOS Privileged EXEC mode.
 se-Module>
- Cisco AXP application service EXEC mode.

se-Module> app-service application-name

Example:

```
se-Module> app-service helloworld
se-Module(exec-helloworld)>
```

Cisco AXP configuration mode.

```
se-Module> configure terminal
se-Module(config)>
```

Cisco AXP application service configuration mode.

Example:

```
se-Module(config)> app-service helloworld
se-Module(config-helloworld)>
```

Cisco AXP syslog application service configuration mode.

Example:

```
se-100-0-5-2(config)> app SYSLOG_APP1
se-100-0-5-2(config-SYSLOG_APP1)>
```

• Cisco AXP interface configuration mode.

Example:

```
se-Module (config-interface)> ip route table 10
```

Entering the Command Environment

After the Cisco AXP is installed and active, use this procedure to enter the command environment.

Prerequisites

The following information is required to enter the command environment:

- IP address of the ISR router that contains the Cisco AXP service module
- Username and password to log in to the router
- Slot number of the module

SUMMARY STEPS

- 1. Open a Telnet session.
- 2. telnet ip-address
- 3. Enter the user ID and password of the router.
- 4. service-module service-engine slot/port session
- **5. enable** (Optional)

DETAILED STEPS

	Command or Action	Purpose
Step 1	Open a Telnet session.	Use a Microsoft DOS window, a secure shell, or a software emulation tool such as Reflection.
Step 2	telnet ip-address	Specifies the IP address of the router.
	Example: C:\> telnet 172.16.231.195	

	Command or Action	Purpose	
Step 3	Username: Password:	Enter your user ID and password for the router.	
Step 4	<pre>service-module integrated-service-engine slot/port session</pre>	Enters the Cisco AXP command environment using the module located in <i>slot</i> and <i>port</i> . The prompt changes to "se" with the IP address of the service module.	
	Example: Router# service-module integrated-service-engine 1/0 session	If the message "Trying <i>ip-address slot/port</i> Connection refused by remote host" appears, enter the command: service-module integrated-service-engine <i>slot/port</i> session clear and retry Step 4.	
Step 5	enable (Optional)		

Exiting the Command Environment

To leave the Cisco AXP command environment and return to the Cisco ISR 2800 command environment, use the **exit** command.

Example:

se-Module> **exit** Router#

Cisco AXP 1.0 Commands

- app-service
- bind interface
- bind serial
- clear cores
- clear core
- clear logs
- clear log
- clear syslog-server logs
- clear syslog-server log-name
- clock timezone
- connect console
- copy syslog-server logs bundle
- copy syslog-server log name
- copy core
- copy log
- copy logs bundle

- hostname
- interface
- ip address
- ip route table
- ip ssh server
- ip ssh server interface
- ip ssh username
- ip local policy route-map
- ip access-list standard
- ip domain-name
- ip name-server
- limit log-file size
- limit cpu utilization
- limit disk utilization
- log console
- log console monitor
- log trace boot
- log trace buffer save
- log trace local enable
- log trace server
- log server address
- log level
- ntp server
- status-monitor
- show app-service state
- show app-service statistics
- show app-service status-monitor
- show clock detail
- show device serial
- show interfaces
- show logs
- show log name
- show ntp associations
- show ntp servers
- show ntp source
- show ntp status
- show process
- show processes

Cisco Application eXtension Platform 1.0 Command Reference

- show resource limits
- show running-config
- show ssh-server
- show state
- show statistics
- show statistics app
- show status-monitor
- show syslog-server logs
- show syslog-server log name
- show tech-support
- show software
- show software directory
- show startup-config
- show system language
- show trace buffer
- show trace store
- show trace store-prev
- show version
- software download abort
- software download clean
- software download server
- software download status
- software download upgrade
- software install add
- software install clean
- software install downgrade
- software install upgrade
- software remove
- syslog-server
- syslog-server limit file-rotation
- syslog-server limit file-size
- write

app-service

To configure the Cisco AXP application hosting environment for a specific application, use the **app-service** command in Cisco AXP configuration mode.

app-service app-name

Syntax Description	app-name	Application name	
Defaults	No default behavior or	values.	
Command Default	None.		
Command Modes	Cisco AXP Configurat	ion Mode.	
Command History	Cisco AXP Version	Modification This command was introduced.	
Examples	In the following example, the configuration mode for application "helloworld" is entered. se-Module(config)> app-service helloworld se-Module(config-helloworld)>		
Related Commands	Command	Description	
	show state	Displays the state and health of the specified application.	

bind interface

To attach a networking device to the application environment, use the **bind interface** command in Cisco AXP application service configuration mode. To detach a networking device from the application environment, use the **no** form of this command.

bind interface network-interface-name

no bind interface network-interface-name

Syntax Description	network-interface-name Interface name defined in the host.			
Defaults	No default behavior or values.			
Command Default	None.			
Command Modes Cisco AXP application service configuration.				
Command History	Cisco AXP Version Modification			
	1.0 This command was introduced.			
Usage Guidelines	 This command attaches or detaches a networking device to or from the application environment. The network-interface-name is the interface name defined in the host, for example, the Ethernet device-name defined in the interface command. The interface is immediately available to the virtual instance with the execution of a new bind command Removing an interface binding with the no prefix displays the following warning messages: WARNING!!! Reset the hosting environment WARNING!!! For binding to be removed 			
	Note This command modifies configuration entries in the /etc/hosts file for ipaddr and hostname mapping. ipaddr in the /etc/hosts file is modified when you enter the bind interface command (eth0 is the default).			
Examples	In the following example, the Cisco AXP application service EXEC mode for application "helloworld" is entered, then the bind command attaches pre-defined interface eth0 to the application. se-Module(config)> app-service helloworld se-Module (config-helloworld)> bind interface eth0			

Related Commands	Command	Description
	interface	Configures the network interfaces.

bind serial

To attach or bind the serial device to the application environment, use the **bind serial** command in Cisco AXP application service configuration mode. To unattach the serial device to the application environment, use the **no** form of the command.

bind serial device-id [device-id on hosting environment]

no bind serial *device-id* [*device-id on hosting environment*]

Syntax Description	device-id	Device ID of the serial device connected to the IOS side.
	device-id on hosting environment	(Optional) Device name in hosting environment, which is different from the device ID (<i>device-id</i>) on the Cisco IOS side.
Defaults	No default behavior or	values.
Command Default	None.	
Command Modes	Cisco AXP application service configuration.	
Command History	Cisco AXP Version	Modification
	1.0	This command was introduced.
Usage Guidelines	This command typically serial application.	y follows the app-service <application name=""> command.The application being a</application>
	serial application. In the following examp	y follows the app-service <application name=""> command. The application being a le, the Cisco AXP application service configuration mode for the serial device Then the serial device is bound to a Cisco IOS side device id of "vtty000".</application>
	serial application. In the following examp "serialapp" is entered. se-Module(config)> a	le, the Cisco AXP application service configuration mode for the serial device Then the serial device is bound to a Cisco IOS side device id of "vtty000".
Examples	serial application. In the following examp "serialapp" is entered. se-Module(config)> a	Then the serial device is bound to a Cisco IOS side device id of "vtty000".
Usage Guidelines Examples Related Commands	serial application. In the following examp "serialapp" is entered. se-Module(config)> ap se-Module(config-ser	le, the Cisco AXP application service configuration mode for the serial device Then the serial device is bound to a Cisco IOS side device id of "vtty000". pp-service serialapp ialapp)> bind serial vtty000 modem

clear cores

To clear all of an application's core files, use the **clear cores** command in Cisco AXP application service EXEC mode.

clear cores

- **Syntax Description** This command has no arguments or keywords.
- **Defaults** No default behavior or values.

Command Default None.

Command Modes Cisco AXP application service EXEC.

Command History	Cisco AXP Version	Modification
	1.0	This command was introduced.

Examples In the following example, clear the core files of a Cisco AXP application in Cisco AXP application service EXEC mode:

se-Module(exec-helloworld)> clear cores

Related Commands	Command	Description
	show cores	Displays all core files.

clear core

To clear one specific core file of an application, use the **clear core** command in Cisco AXP application service EXEC mode.

clear core name core-name

Syntax Description	core-name	Name of the core file.
Defaults	No default behavior or	values.
Command Default	None.	
Command Modes	Cisco AXP application	n service EXEC.
Command History	Cisco AXP Version	Modification This command was introduced.
Examples		ple, the helloworld-test-core-file is cleared from the application:
	se-Module(exec-hello	<pre>world)> clear core name helloworld-test-core-file</pre>
Related Commands	Command	Description
	show cores	Displays all core files.

clear logs

In Cisco AXP application service EXEC mode, use the **clear logs** command to clear the content of all log files of the application.

In Cisco AXP EXEC mode, use the clear logs command to clear the content of all host log files.

clear logs

Syntax Description This command has no arguments or keywor
--

- **Defaults** No default behavior or values.
- Command Default None.
- Command ModesCisco AXP application service EXEC.Cisco AXP EXEC.

 Command History
 Cisco AXP Version
 Modification

 1.0
 This command was introduced.

Usage Guidelines Depending on the mode, the command either clears the contents of all host log files (Cisco AXP EXEC mode) or clears the contents of the application log files (Cisco AXP application service EXEC mode).



In Cisco AXP EXEC mode, the command does not clear syslog server log files.

 Examples
 In the following example, the log files are cleared in Cisco AXP application service EXEC mode:

 se-Module(exec-helloworld)> clear logs

 In the following example, the log files are cleared in Cisco AXP EXEC mode:

se-Module> clear logs

Related Commands	Command	Description
	show logs	Displays all log files.

clear log

In Cisco AXP application service EXEC mode, use the **clear log** command to clear the content of a specific log file of the application.

In Cisco AXP EXEC mode, use the clear log command to clear the content of a specific host log file.

clear log name log-name

Syntax Description	log-name	Name of the specific log file.
Syntax Description		Name of the specific log me.
Defaults	No default behavior of	r values.
Command Default	None.	
Command Modes	Cisco AXP application	
Command Woues		ii service EAEC.
	Cisco AXP EXEC.	
Command History	Cisco AXP Version	Modification
Command history		This command was introduced.
Usage Guidelines		de, use this command to either clear the contents of a specific host log file ode) or clear the contents of a specific application log file (Cisco AXP application
Note	In Cisco AXP EXEC	mode, the command does not clear a syslog server log file.
Examples	In the following exam mode:	ple, the log file messages.log is cleared in Cisco AXP application service EXEC
	se-Module(exec-hell	oworld) > clear log name messages.log
	In the following exam	ple, the log file sshd.log is cleared in Cisco AXP EXEC mode:
	se-Module> clear lo	g name sshd.log
Related Commands	Command	Description
	show logs	Displays all log files.

clear syslog-server logs

To clear the content of all syslog files in the /var/remote directory, use the **clear syslog-server logs** command in Cisco AXP EXEC mode.

clear syslog-server logs

Syntax Description	This command has no a	arguments or keywords.
Defaults	No default behavior or	values.
Command Default	None.	
Command Modes	Cisco AXP EXEC.	
Command History	Cisco AXP Version 1.0	Modification This command was introduced.
Examples	In the following examp se-Module> clear sys	le, the content of all syslog files in the /var/remote directory is cleared: log-server logs
Related Commands	Command	Description
	show syslog-server logs	Displays all syslog files.

clear syslog-server log-name

To clear the contents of a specific syslog server file, use the **clear syslog-server log-name** command in Cisco AXP EXEC mode.

clear syslog-server log name log-name

Syntax Description	log-name	Name of the specific syslog server log file.
Defaults	No default behavior or value	es.
Command Default	None.	
Command Modes	Cisco AXP EXEC.	
Command History	Cisco AXP Version	Modification
Freemales		This command was introduced.
Examples		ne contents of a specific syslog server file are cleared: server log name remote_messages.log
Related Commands	Command	Description
	show syslog-server logs	Displays all syslog server log files.

clock timezone

To set the time zone for the Cisco AXP service module, use the **clock timezone** command in Cisco AXP configuration mode.

clock timezone [time-zone]

Syntax Description	time-zone	(Optional) Time zone of the local branch.		
Command Modes	Cisco AXP configura	ation.		
Command History	Cisco AXP Version	Modification		
	1.0	This command was introduced.		
Usage Guidelines	-	server provides the date-stamp system and application functions. The clock specifies the local time zone where Cisco AXP is installed.		
		se for the time-zone, enter it for the <i>time-zone</i> value. If you do not know the time e <i>time-zone</i> value blank and a series of menus appear to guide you through the time ss.		
Examples	In the following example the second	nple, the United States Pacific Time is selected from the timezone menu:		
	<pre>se-10-0-0-0>config se-10-0-0-0(config Please identify a Please select a co 1) Africa 2) Americas</pre>)> clock timezone location so that time zone rules can be set correctly.		
	3) Antarctica	6) Atlantic Ocean 9) Indian Ocean		
	>? 2 Please select a country.			
	1) Anguilla	18) Ecuador 35) Paraguay		
	2) Antigua & Barb			
	3) Argentina	20) French Guiana 37) Puerto Rico		
	4) Aruba 5) Bahamas	21) Greenland38) St Kitts & Nevis22) Grenada39) St Lucia		
	6) Barbados	23) Guadeloupe 40) St Pierre & Miquelon		
	7) Belize	24) Guatemala 41) St Vincent		
	8) Bolivia	25) Guyana 42) Suriname		
	9) Brazil	26) Haiti 43) Trinidad & Tobago		
	10) Canada	27) Honduras 44) Turks & Caicos Is		
	11) Cayman Islands	28) Jamaica 45) United States		
	12) Chile	29) Martinique 46) Uruguay		
	13) Colombia	30) Mexico 47) Venezuela		
	14) Costa Rica	31) Montserrat 48) Virgin Islands (UK)		
	15) Cuba 16) Dominica	32) Netherlands Antilles 49) Virgin Islands (US) 33) Nicaragua		
	17) Dominican Repu			
	>? 45	· · · , · · ·		

```
Please select one of the following time zone regions.
1) Eastern Time
 2) Eastern Time - Michigan - most locations
3) Eastern Time - Kentucky - Louisville area
 4) Eastern Standard Time - Indiana - most locations
 5) Central Time
 6) Central Time - Michigan - Wisconsin border
7) Mountain Time
 8) Mountain Time - south Idaho & east Oregon
9) Mountain Time - Navajo
10) Mountain Standard Time - Arizona
11) Pacific Time
12) Alaska Time
13) Alaska Time - Alaska panhandle
14) Alaska Time - Alaska panhandle neck
15) Alaska Time - west Alaska
16) Aleutian Islands
17) Hawaii
>? 11
The following information has been given:
        United States
        Pacific Time
Therefore TZ='America/Los_Angeles' will be used.
Local time is now: Fri Dec 24 10:41:28 PST 2004.
Universal Time is now: Fri Dec 24 18:41:28 UTC 2004.
Is the above information OK?
1) Yes
2) No
>? 1
se-10-0-0(config)>
```

To select United States Pacific Time using the timezone using the timezone name:

```
se-10-0-0-> config t
se-10-0-0-0(config)> clock timezone Americas/Los_Angeles
```

Related Commands	Command	Description
	ntp server	Specifies the NTP server.
	show clock detail	Displays the clock details.

connect console

To allow third-party applications to integrate their commands to the console shell, use the **connect console** command in Cisco AXP application service EXEC mode.

connect console

Syntax Description	This command has no ar	guments or keywords.
Defaults	No default behavior or v	ralues.
Command Default	None.	
Command Modes	Cisco AXP application s	service EXEC.
Command History	Cisco AXP Version	Modification
	1.0	This command was introduced.
Usage Guidelines	initiating the command,	third party to integrate their own application commands to the console shell. On /bin/console is executed. The third party application must provide its own a script (telnet to their CLI), to cross connect to its CLI shell.
	If the application does n	ot provide a console file, the following message appears:
	Unable to start con	sole
Examples	se-Module(exec-tcptra	e, the shell of an application's virtual instance is entered: ce)> connect console <enter></enter>
	bash-2.05b#	
Related Commands	Command	Description
	show tech-support	Displays system details.

copy syslog-server logs bundle

To bundle all the syslog server log files into a gzip file and copy them to a remote URL, use the **copy syslog-server logs bundle** command in Cisco AXP EXEC mode.

copy syslog-server logs bundle destination-filename.gz url ftp/http url

Syntax Description	destination-filename	gzip filename
,	ftp/http url	Destination URL
Defaults	No default behavior or	values.
Command Default	None.	
Command Modes	Cisco AXP EXEC.	
Command History	Cisco AXP Version	Modification This command was introduced.
Examples		le, the syslog server log files are bundled into a gzip file and copied to a remote
		og-server logs bundle myappslogs.gz url http://testfiles.company.com
Related Commands	Command	Description
	show syslog-server logs	Displays all syslog server log files.

copy syslog-server log name

To copy a specific syslog server log file, use the **copy syslog-server log name** command in Cisco AXP EXEC mode.

copy syslog-server log name log-name url ftp/http url

Syntax Description	log-name	Syslog server log filename.
	ftp/http url	Destination URL.
Defaults	No default behavior or	values.
Command Default	None.	
Command Modes	Cisco AXP EXEC.	
Command History	Cisco AXP Version	Modification
	1.0	This command was introduced.
Usage Guidelines	The standard FTP URL	format is supported:
		assword@]ftp-server-address[/directory] sed to copy more than one log file at a time.
Related Commands	Command	Description
	show syslog-server logs	Displays all syslog server log files.

copy core

To copy a core file to a remote URL, use the **copy core** command in Cisco AXP application service EXEC mode.

copy core core-name url ftp/http url

	-	
Syntax Description	core-name	Core filename
	ftp/http url	FTP/HTTP address
Defaults	No default behavior or	values.
Command Default	None.	
Command Modes	Cisco AXP application	service EXEC.
Command History	Cisco AXP Version	Modification
	1.0	This command was introduced.
Usage Guidelines	The standard FTP URL	o format is supported: assword@]ftp-server-address[/directory]
Examples	0 1	le, the file mping-test-file2 is copied to remote URL http://example.net. world)> copy core mping-test-file2 http://example.net
Related Commands	Command	Description
	show cores	Displays all core files.

copy log

To copy an application log file to a remote URL, use the **copy log** command in Cisco AXP application service EXEC mode.

To copy a Cisco AXP host operating system log file to a remote URL, use the **copy log** command in Cisco AXP EXEC mode.

copy log log-name url ftp/http url

ftp/http url FTP/HTTP address Defaults No default behavior or values. Command Default None. Command Modes Cisco AXP application service EXEC. Cisco AXP EXEC. Command History Cisco AXP Version Modification 1.0 This command was introduced. Usage Guidelines Use this command, in Cisco AXP application service EXEC mode, to copy syslog, trace and custom application log files for a specific application to a remote URL. The standard ftp URL format is supported:	Syntax Description	log-name Log filename	
Command Default None. Command Modes Cisco AXP application service EXEC. Cisco AXP EXEC. Command History Cisco AXP Version Modification 1.0 This command was introduced. Use this command, in Cisco AXP application service EXEC mode, to copy syslog, trace and custom application log files for a specific application to a remote URL. The standard ftp URL format is supported: ftp://[user-id:ftp-password0]ftp-server-address[/directory] The log filename (in both command modes) may contain wildcards * allowing the copying of more than one log file at a time. Examples In the following example, the copy log command copies log file install.log from application "mping" to a remote server: se-Module(exec-mping)> copy log install.log url ftp://admin:mpg010.10.67.163/Installinfo Related Commands Command Description		<i>ftp/http url</i> FTP/HTTP address	
Command Modes Cisco AXP application service EXEC. Cisco AXP EXEC. Command History Cisco AXP Version Modification 1.0 This command was introduced. Usage Guidelines Use this command, in Cisco AXP application service EXEC mode, to copy syslog, trace and custom application log files for a specific application to a remote URL. The standard ftp URL format is supported: ftp://[user-id:ftp-password@]ftp-server-address[/directory] The log filename (in both command modes) may contain wildcards * allowing the copying of more than one log file at a time. Examples In the following example, the copy log command copies log file install.log from application "mping" to a remote server: se-Module(exec-mping)> copy log install.log url ftp://admin:mpg@10.10.67.163/Installinfo Related Commands Command Description	Defaults	No default behavior or values.	
Cisco AXP EXEC. Command History Cisco AXP Version Modification 1.0 This command was introduced. Usage Guidelines Use this command, in Cisco AXP application service EXEC mode, to copy syslog, trace and custom application log files for a specific application to a remote URL. The standard ftp URL format is supported: ftp://(user-id:ftp-password@]ftp-server-address[/directory] The log filename (in both command modes) may contain wildcards * allowing the copying of more than one log file at a time. Examples In the following example, the copy log command copies log file install.log from application "mping" to a remote server: se-Module(exec-mping)> copy log install.log url ftp://admin:mpg@10.10.67.163/Installinfo Related Commands Command Description	Command Default	None.	
I.0 This command was introduced. Usage Guidelines Use this command, in Cisco AXP application service EXEC mode, to copy syslog, trace and custom application log files for a specific application to a remote URL. The standard ftp URL format is supported: ftp://[user-id:ftp-password@]ftp-server-address[/directory] The log filename (in both command modes) may contain wildcards * allowing the copying of more than one log file at a time. Examples In the following example, the copy log command copies log file install.log from application "mping" to a remote server: se-Module(exec-mping)> copy log install.log url ftp://admin:mpg@10.10.67.163/lnstallinfo Related Commands Command Description	Command Modes		
Usage Guidelines Use this command, in Cisco AXP application service EXEC mode, to copy syslog, trace and custom application log files for a specific application to a remote URL. The standard ftp URL format is supported: ftp://[user-id:ftp-password@]ftp-server-address[/directory] The log filename (in both command modes) may contain wildcards * allowing the copying of more than one log file at a time. Examples In the following example, the copy log command copies log file install.log from application "mping" to a remote server: se-Module(exec-mping)> copy log install.log url ftp://admin:mpg@10.10.67.163/lnstallinfo Related Commands Command	Command History		
ftp://[user-id:ftp-password@]ftp-server-address[/directory] The log filename (in both command modes) may contain wildcards * allowing the copying of more than one log file at a time. Examples In the following example, the copy log command copies log file install.log from application "mping" to a remote server: se-Module(exec-mping)> copy log install.log url ftp://admin:mpg@10.10.67.163/lnstallinfo Related Commands Command	Usage Guidelines	Use this command, in Cisco AXP application service EXEC mode, to copy syslog, trace and cust application log files for a specific application to a remote URL. The standard ftp URL format is	om
examples In the following example, the copy log command copies log file install.log from application "mping" to a remote server: se-Module(exec-mping)> copy log install.log url ftp://admin:mpg@10.10.67.163/lnstallinfo Related Commands Command			
a remote server: se-Module(exec-mping)> copy log install.log url ftp://admin:mpg@10.10.67.163/lnstallinfo Related Commands Command		The log filename (in both command modes) may contain wildcards * allowing the copying of more	than
Related Commands Command Description	Examples	a remote server:	-
	Related Commands		-
		show logs Displays all log files.	

copy logs bundle

To copy a tar file containing syslog files and custom application log files on the guest operating system to a remote URL, use the **copy logs bundle** command in Cisco AXP application service EXEC mode.

To copy a tar file containing syslog files and custom application log files on the guest and host operating systems to a remote URL, use the **copy logs bundle** command in Cisco AXP EXEC mode.

copy logs bundle destfilename.tar url url

Syntax Description	destfilename	Tar filename
	url	Destination URL.
Defaults	No default behavio	or or values.
Command Default	None.	
Command Modes	Cisco AXP applica Cisco AXP EXEC	ation service EXEC.
Command History	Cisco AXP Version 1.0	n Modification This command was introduced.
Usage Guidelines	If you are in In Cis	sco AXP EXEC mode, this command does not copy remote syslog server log files.
Examples	•	xample, a tar file is copied to a remote server: mping)> copy logs bundle mpg.tar url http://lab:mpg@10.10.67.163/appinfo
Related Commands	Command	Description
	show logs	Displays all log files.

hostname

To configure a hostname for the application that is different from the name used for the host, use the **hostname** command in Cisco AXP application service configuration mode.

To disable the hostname for the application, use the **no** form of this command.

hostname name

no hostname name

Syntax Description	name	Hostname for the application.	
Defaults	Hostname configured of	on the host side.	
Command Default	None.		
Command Modes	Cisco AXP application	service configuration.	
Command History	Cisco AXP Version	Modification	
	1.0	This command was introduced.	
Usage Guidelines	This command configures the hostname for the application, if it is different from the hostname configured for the Cisco AXP host. The hostname is limited to 32 characters. If more than 32 characters are entered, the following error message appears:		
	hostname size greater than 32		
	This command modifie of the hostname: IP ma	es configuration directives in file <i>/etc/hosts</i> . The command updates the hostname apping entry.	
	If the file does not exis	t, the command creates the /etc/hosts file, and adds an entry to the file.	
		cample, if an application package has already bundled its own <i>/etc/hosts</i> file), the ded to the existing entries and the original entries remain intact.	
Examples	In the following examp	ple, the initial contents of file etc/hosts are:	
		localdomain localhost ## added by cli in hostname ## added by cli	
	-	ving commands set the hostname to "myhostname". The original hostname is the after installing the application, the hostname for the vserver is the same as for the	

configure terminal app-service myapp hostname myhostname

The hostname in the second line of the /etc/hosts file above, (ipaddr hostname.domain hostname) is changed to myhostname.

The /etc/hosts file is created by Cisco AXP if it is not packaged by the user. An /etc/hosts file that is created by the user must contain the first line shown above (starting with "127.0.0.1"). Lines following the first line of the file are created by Cisco AXP.

The IP address, ipaddr in the /etc/hosts file is modified using the bind interface command.

The first binding of the interface provides *ipaddr*, which is normally eth0. The interface eth0 is bound to each virtual instance by default. Use the **bind interface** command for multiple bindings.

Related Commands	Command	Description
	bind interface	Attaches a device to the application environment.

interface

To configure external network interfaces and enter interface configuration mode, use the **interface** command in Cisco AXP configuration mode.

interface device-name

Syntax Description	device-name	Ethernet device name.
Syntax Description		
Defaults	None.	
Command Default	None.	
Command Modes	Cisco AXP configurat	ion.
Command History	Cisco AXP Version	Modification
	1.0	This command was introduced.
Usage Guidelines		be eth0 or eth1 for a built-in physical interface, eth0:1 for a virtual interface, or
	eth0.1 for a VLAN int	
		interfaces can be configured only if these interfaces are not bound to the virtual f the interfaces are bound, an error message with the specific device name appears.
	For example, for eth0 .	1 the error message will display:
	Frror Message eth0 1	still bound to hosting environment(s), unbind first.
	-	in physical interface. On removal, an error message appears:
		in physical interface. On removal, an error message appears.
	Error Message Can no	t remove the built-in interface eth0/1.
Examples	In the following examply by entering interface c	ple, the command interface eth0 configures the external network interface eth0, configuration mode.
	se-Module (config)>	interface eth0
	se-Module(config-int	cerface)>

Related Commands

Command	Description
bind interface	Attaches or detaches a networking device to or from the application environment.

ip address

To configure the IP address for a network interface, use the **ip address** command in Cisco AXP interface configuration mode.

ip address ip-address network-mask

Syntax Description	ip-address	Defines the IP address.
	network mask	Defines the network mask.
Defaults	None.	
Command Default	None.	
Command Modes	Cisco AXP interface c	onfiguration.
Command History	Cisco AXP Version	Modification
	1.0	This command was introduced.
Usage Guidelines	Changing the IP addres	configure the IP address and network mask for the specified network interface. ss for a bound interface results in a message warning the user that the application ce. To remove the old IP configuration, reset the virtual instance.
Examples	In the following examp specified:	ple, the IP address of an interface in Cisco AXP interface configuration mode is
	se-Module (config-ir	nterface)> ip address 209.165.201.1 255.255.255.224
Related Commands	Command	Description
	interface	Configures the interface device.

ip route table

To configure the route table for a connected route, use the **ip route table** command in Cisco AXP interface configuration mode.

ip route table table-num

Syntax Description	table-num	Route table number from 1 to 100.
Defaults	None.	
Command Default	None.	
Command Modes	Cisco AXP interface co	onfiguration.
Command History	Cisco AXP Version	Modification
	1.0	This command was introduced.
Usage Guidelines	Use this command to c	onfigure the route table for a connected route for source-based routing.
Usage Guidelines Examples		onfigure the route table for a connected route for source-based routing. ble, the route table number 10 is configured:
	In the following examp	
	In the following examp	ble, the route table number 10 is configured:
	In the following examp	ble, the route table number 10 is configured:
Examples	In the following examp se-Module (config-in	ole, the route table number 10 is configured: terface)> ip route table 10

ip ssh server

To enable the IP SSH service, use the **ip ssh server** command in Cisco AXP syslog application configuration mode. To disable the service, use the **no** form of this command.

ip ssh server [port-num]

no ip ssh server

Syntax Description	<i>port-num</i> Port number with a range	ge of 1–65535.
Defaults	Port number 22.	
Command Default	Enabled.	
Command Modes	Cisco AXP syslog application service configuration	on.
Command History	Cisco AXP Version Modification	
	1.0 This command was intr	oduced.
Usage Guidelines	Use this command to start or stop the SSH server the of port numbers that may be used is 1–65535 and Error messages: Table	hat is located on the specified port number. The range the default is 22.
	Error Message	Description
	Port is in use, please use another port.	System cannot start the SSH server because the port designated with number <i>port-num</i> is currently being used. After seeing this message,
		you can re-enter the command, using a different value for <i>port-num</i> .

Examples

In the following example, the IP SSH server is enabled on port 5000 for application SYSLOG_APP1. se-100-0-5-2(config)> **app SYSLOG_APP1** se-100-0-5-2(config-SYSLOG_APP1)> **ip ssh server port 5000**

Related Commands	Command	Description
	ip ssh interface	Interface on which the sshd daemon listens for an incoming connection.

ip ssh server interface

To enable the interface on which the sshd daemon listens for an incoming connection, use the **ip ssh server interface** command in Cisco AXP configuration mode.

ip ssh server interface interface

Syntax Description	interface	Interface name.
Defaults	None.	
Command Default	None.	
Command Modes	Cisco AXP configurat	tion.
Command History	Cisco AXP Version	Modification
	1.0	This command was introduced.
Usage Guidelines		ies the interface on which the sshd process listens for an incoming connection. this command, the sshd process listens on all interfaces.
Related Commands	Command	Description

ip ssh username

To specify an unencrypted or hidden password for SSH tunneling, use the **ip ssh username** command in Cisco AXP syslog application configuration mode.

To disable tunneling, use the **no** form of the command.

ip ssh username [tunnel_root | tunnel_user] password clear-password-string

no ip ssh username [tunnel_root | tunnel_user] password clear-password-string

Syntax Description	tunnel_root	Allows an SSH user with shell access to the application environment.
	tunnel_user	Allows an SSH user shell access to the application environment through a startup script that is implemented by the third party developer.
	clear-password-string	UNIX password for the user with a minimum of five characters.
Defaults	None.	
Command Default	None.	
Command Modes	Cisco AXP syslog appli	cation service configuration.
Command History	Cisco AXP Version	Modification
	1.0	This command was introduced.
Usage Guidelines	For a tunnel user, the sta operations.	artup script decides on the level of access a user can have to perform specific
Related Commands	Command	Description

ip local policy route-map

To configure a route map for policy routing, use the **ip local policy route-map** command in Cisco AXP configuration mode.

ip local policy route-map *map-tag*

Syntax Description	map-tag	Route map name.
Defaults	None.	
Command Default	None.	
Command Modes	Cisco AXP configurati	ion.
Command History	Cisco AXP Version	Modification
	1.0	This command was introduced.
Usage Guidelines	The route map name n	nust match the <i>map-tag</i> in the route-map command.
Examples	In the following examp	ple, the route map is configured for policy routing with <i>map-tag</i> =10:
	se-100-0-5-2(config)	> ip local policy route-map 10
Related Commands	Command	Description
	route map	Specifies the route map.

ip access-list standard

To configure a standard access list for the application, use the **ip access-list standard** command in Cisco AXP configuration mode.

ip access-list standard {acl-name | acl-num}

Syntax Description	acl-name	Name identifier for an access list to which all commands entered in access list configuration mode apply. Format: 30 alphanumeric characters, beginning with a letter.	
	acl-num	Numeric identifier for an access list to which all commands entered in access list configuration mode apply. Format (for standard access lists): number in the range 1–99.	
Defaults	None.		
Command Default	None.		
Command Modes	Cisco AXP configurati	ion.	
Command History	Cisco AXP Version	Modification	
	1.0	This command was introduced.	
Usage Guidelines	Use this command to c	create an access list for source-based route configurations.	
	•	specifies the type of packets that you want for further processing, use the permit ACL subcommand mode (config-std-nacl) to specify the type of packets that must processing.	
	Include at least one permit entry to create a valid access list.		
	Cisco AXP 1.0 allows	only a single IP address in the access list to be specified.	
Examples	In the following examp	ple, an access list is created for source-based route configuration.	
	se-Module (config)>	ip access-list standard test	
Related Commands	Command	Description	
	permit	Adds a line to a standard access list specifying the type of packets to be accepted for further processing.	

ip domain-name

To configure the domain name for the application, use the **ip domain-name** command in Cisco AXP application configuration mode. To disable the domain name, use the **no** form of this command.

ip domain-name dns-server-domain-name

no ip domain-name dns-server-domain-name

Syntax Description	<i>dns-server-domain-name</i> Domain name for the DNS server.		
Defaults	No domain name is configured.		
Command Default	None.		
Command Modes	Cisco AXP application service configuration.		
Command History	Cisco AXP Version Modification		
	1.0This command was introduced.		
Usage Guidelines	The domain-name is limited to 64 characters. If you enter more than 64 characters, the following error message appears:		
	Error Message domain size greater than 64		
	This command modifies configuration directives in <i>/etc/hosts</i> and <i>/etc/resolv.conf</i> files where the domain name is relevant, and also modifies the search list for hostname lookup and domain directives for local domain name in the <i>/etc/resolv.conf</i> file.		
	For the /etc/hosts file, this command updates the domain name of the hostname-ip mapping entry.		
	Example:		
	/etc/resolv.conf: search cisco.com ## added by cli domain cisco.com ## added by cli nameserver x.x.x.x ## added by cli		
	/etc/hosts: 10.100.50.10 appre.cisco.com appre		
	Use this command with the ip name-server command to configure the DNS server. The host commands ip domain-name and ip name-server populate the <i>/etc/resolv.conf</i> file in each installed virtual instance. Changing the configuration results in the updating of host results in the <i>/etc/resolv.conf</i> file.		
When these commands are used to configure a new name-server and domain-name for a virtual instance (in app-service mode), the */etc/resolv.conf* file in that virtual instance is overridden with the new server name and domain name.

The */etc/resolv.conf* file in that virtual instance reverts to the host configuration whenever the virtual instance does not have a name-server or domain-name configured.

Configuring the name-server and domain-server in a virtual instance always takes precedence over configuration in the host.

Examples

In the following example, the domain name of the application is changed from **mping** to **mycompany.com**:

```
SE-Module> config t
```

```
se-10-0-0-0(config-mping)> ip domain-name mycompany.com
se-10-0-0-0(config-mping)> ip name-server 10.0.61.1
```

Related Commands

Command	Description	
hostname	Specifies the server that stores the Cisco AXP applications.	
ip name-server	Specifies the DNS server name of the application.	
ntp server	Specifies the NTP clocking server.	
show hosts	Displays all configured hosts.	
show ip route	Displays IP route destinations, gates, and masks.	

ip name-server

To configure the IP address of the domain name server (DNS) of the application, use the **ip name-server** command in Cisco AXP application service configuration mode.

To disable the name server, use the **no** form of this command.

ip name-server ip-address

no ip name-server ip-address

Syntax Description	ip-address	IP address of the DNS server.
Defaults	No name server is	configured.
Command Default	None.	
Command Modes	Cisco AXP applica	ation service configuration.
Command History	Cisco AXP Version	Modification
	1.0	This command was introduced.
Usage Guidelines	DNS servers can b addresses of name node available on	with the ip domain-name command to configure the DNS server. A maximum of two be defined. In a Linux environment, the <i>/etc/resolv.conf</i> file typically contains the IP servers (DNS name resolvers) that attempt to translate names into addresses for any the network.
		al instance. Using this command to change the configuration in the host results in the
		ands are used to configure a new name-server and domain-name for a virtual instance ode), the <i>/etc/resolv.conf</i> file in that virtual instance is overridden with the new server name.
	virtual instance do	If file in that virtual instance reverts back to the host configuration whenever the es not have a name-server or domain-name configured. Configuring the name-server in a virtual instance always takes precedence over configuration in the host.
		ackage has already bundled its own <i>/etc/resolv.conf</i> file, the new entries will be sisting ones and will leave the original ones intact.
	Example:	
	domain localdoma	in## added by cli in## added by cli .x## added by cli

Examples

In the following example, the IP name server of the application is changed from mping to 10.10.61.16:

```
se-Module> config t
se-Module(config-mping)> ip name-server 10.10.61.16
se-Module(config-mping)> ip domain-name mycompany.com
```

Related Commands

Command	Description	
hostname	Specifies the server that stores the Cisco AXP applications.	
ip domain-name	Specifies the DNS domain name of the application.	
ntp server	Specifies the NTP clocking server.	
show hosts	Displays all configured hosts.	
show ip route	Displays IP route destinations, gates, and masks.	

limit log-file size

To configure the log file size, use the **limit log-file size** command in Cisco AXP application service configuration mode.

To disable log file size configuration, use the **no** form of this command.

limit log-file size size

no limit log-file size size

Syntax Description	size	Maximum log file size in MB. Range is 0 to 40 MB.
Defaults	Default value is 5 MB.	
Command Default	None.	
Command Modes	Cisco AXP application	service configuration.
Command History	Cisco AXP Version	Modification
	1.0	This command was introduced.
Usage Guidelines	a syslog to its own file / its contents are moved t	maximum size of the log file /var/log/messages.log. Each virtual instance writes var/log/messages.log. When this file reaches the limit specified by this command, o a backup log file messages.log.prev and a new messages.log file is started. The a default size of 5 MB for two files.
	megabytes: The range of	of the log file size from 0–40 MB.
	When the value is out o	of range, the following message appears:
	%Invalid input de	etected at `^' marker
	If the log file size confi reverts to the default va	guration is disabled (no limit log-file size), the maximum size of the log file lue of 5 MB.
	If the maximum size of	the log file is set to 0 MB, the minimum file size is 10 KB.
Examples	• •	le, the size of the log file is changed to 10 MB. loworld)> limit log-file size 10

Related Commands

Command	Description
show logs	Lists logs in the application environment that reside in the /var/log directory.

limit cpu utilization

To configure the CPU resource usage limits, use the **limit cpu utilization** command in Cisco AXP application service configuration mode.

To disable setting CPU utilization limits, use the **no** form of this command.

limit cpu utilization *index*

no limit cpu utilization index

Syntax Description	index	CPU index number.
Defaults	No default behavior or	values.
Command Default	None.	
Command Modes	Cisco AXP applicatior	service configuration.
Command History	Cisco AXP Version	Modification
	1.0	This command was introduced.
Usage Guidelines	when the application in	
		nge varies between the minimum and maximum limits specified by the package. lization maximum for a Cisco AXP service module is based on a platform CPU
	1.0 GHz Celeron M Cl	ex is specified relative to a value of 10000 assigned to the following configuration: PU on the application runtime engine of an NME_APPRE_302-K9 network the CPU utilization limit for the AIM_APPRE 102 blade is 3000.
Examples	In the following examp blade):	ple, the CPU utilization limit is set to 3000, (typical for an AIM_APPRE 102
	se-Module(config-hel	loworld)> limit cpu utilization 3000
Related Commands	Command	Description
	show resource limits	Displays the resource limits configured for the application.

limit disk utilization

To modify the disk utilization setup during installation, use the **limit disk utilization** command in Cisco AXP application service configuration mode.

To disable setting of disk utilization limits, use the **no** form of the command.

limit disk utilization amount

no limit disk utilization amount

Syntax Description	amount	Range is 1 to 100,000 MB
Defaults	No default behavior or v	values.
Command Default	None.	
Command Modes	Cisco AXP application s	service configuration.
Command History	Cisco AXP Version	Modification This command was introduced.
Usage Guidelines		e disk space utilization in a virtual instance. The disk utilization range varies mit specified by the package to the maximum limit available to the system.
Examples		e, the disk utilization is set to 100 MB during installation: p1)> limit disk utilization 100
Related Commands	Command	Description
	show resource limits	Displays the resource limits configured for the application.

log console

To configure the types of messages to be displayed on the console, use the **log console** command in Cisco AXP configuration mode. To stop messages from displaying, use the **no** form of this command.

log console {errors | info | notice | warning}

no log console {errors | info | notice | warning}

$\underline{\mathbb{N}}$			
Caution	This command generates many screen messages that scroll down the screen until you turn off the display. Seeing the prompt to turn off the display may be difficult. Pressing CTRL-c does not work for this command.		
Syntax Description	errors	Error messages.	
	info	Information messages.	
	notice	Notice messages	
	warning	Warning messages.	
Defaults	Only fatal error me	ssages are displayed.	
Command Modes	CiscoAXP configu	ration	
Command History	Cisco AXP Release	Modification	
	1.0	This command was introduced .	
Usage Guidelines	The messages on th for debugging purp	e console display are also saved in the messages.log file. These messages can be used oses.	
Examples	-	nple configures error messages to be displayed on the console:	
	se-10-0-0-0> conf se-10-0-0-0(confi se-10-0-0-0(confi	g)> log console errors	
Related Commands	Command	Description	
	show logging	Displays the types of messages that are displayed on the console.	

log console monitor

To display system messages on the console, use the **log console monitor** command in Cisco AXP EXEC mode. To stop messages from displaying, use the **no** form of this command.

log console monitor {*module* | *entity* | *activity*}

no log console monitor {*module* | *entity* | *activity*}

<u> </u>		tes many screen messages that scroll down the screen until you turn off the display. turn off the display may be difficult. Pressing CTRL-c does not work for this
Syntax Description	module entity	Cisco AXP modules. Cisco AXP module entities.
	activity	Cisco AXP entity actions.
Defaults	Only fatal error messa	nges are displayed.
Command Modes	Cisco AXP EXEC	
Command History	Cisco AXP Release	Modification
	1.0	This command was introduced .
Usage Guidelines	The messages on the output of the used for debugging put	console monitor are also saved in the messages.log file. These messages can be irposes.
Examples	- 1	e displays messages for results of the database entity in the networking module: nsole monitor networking database results
Related Commands	Command	Description
	show logging	Displays the types of messages that are displayed on the console.

log trace boot

To save the trace configuration upon rebooting, use the **log trace boot** command in Cisco AXP EXEC mode.

log trace boot

Syntax Description This command has no arguments or keywords.

Command Modes Cisco AXP EXEC

 Command History
 Cisco AXP Release
 Modification

 1.0
 This command was introduced.

 Usage Guidelines
 To ensure that the current trace configuration is saved when the Cisco AXP service module is rebooted, use the log trace boot command.

 Examples
 The following example illustrates the log trace boot command: se-10-0-0-log trace boot

Related Commands	Command	Description
	show trace	Displays the modules and entities being traced.

log trace buffer save

To save the current trace information, use the **log trace buffer save** command in Cisco AXP EXEC mode. To turnoff the log trace, use the **no** form of this command.

log trace buffer save

no log trace buffer

Syntax Description	This command has no arguments or keywords.
--------------------	--

Command Modes Cisco AXP EXEC

Command History	Cisco AXP Release	Modification
	1.0	This command was introduced.

Usage Guidelines Current trace information stored in the memory buffer can be saved to a file.

ExamplesThe following example illustrates the log trace buffer save command:
se-10-0-0->log trace buffer save

Related Commands	ted Commands Command Description	
	show logs	Displays a list of the trace logs.
	show trace buffer	Displays the modules and entities being traced.

log trace local enable

To configure tracing messages to a local disk, use the **log trace local enable** command in Cisco AXP configuration mode.

log trace local enable

Syntax Description	There is no syntax description for this command.		
Defaults	None		
Command Modes	Cisco AXP configur	ration	
Command History	Cisco AXP Release	Modification	
	1.0	This command was introduced .	
Usage Guidelines	Enable local tracing	to a disk.	
Examples	The following exam	ple configures tracing toto a local disk:	
	<pre>se-10-0-0-0> config t se-10-0-0-0(config)> log trace local enable se-10-0-0-0(config)> exit</pre>		
Related Commands	Command	Description	
	show logging	Displays the types of messages that are displayed on the console.	

log trace server

To configure tracing messages for remote storage , use the **log trace server** command in Cisco AXP configuration mode.

log trace server {enable | url url}

Syntax Description	enable	Enables tracing to the FTP server.
	url	Designates remote storage directory.
	url	FTP URL address.
Defaults	None	
Command Modes	Cisco AXP configur	ration
Command History	Cisco AXP Release	Modification
	1.0	This command was introduced .
Usage Guidelines	Configures tracing r	messages for remote storage.
Examples	The following exam	ple configures tracing remotely:
	se-10-0-0-0> conf se-10-0-0-0(config se-10-0-0-0(config	g)> log trace server url ftp url
Related Commands	Command	Description
noracea commanus	show logging	Displays the types of messages that are displayed on the console.
	Show logging	Displays the types of messages that are displayed on the console.

log server address

To configure the remote logging server, use the **log server address** command in Cisco AXP application service configuration mode.

To disable the remote logging server, use the **no** form of this command.

log server address {*ip-address* | *hostname*}

no log server address {*ip-address* | *hostname*}

Syntax Description	ip-address	IP address of the external log server.		
	hostname	Hostname of the external log server.		
Defaults	No external log server i	No external log server is configured.		
Command Modes	Cisco AXP application	service configuration.		
Command History	Cisco AXP Version	Modification		
	1.0	This command was introduced		
Usage Guidelines	This command enables and disables remote logging, and configures the remote logging server. Application syslog messages are sent to the specified log server. The hostname can be an IP address or a name. When an invalid IP address format such as 0.0.0.0 is entered, the following error message appears:			
	Error Message 0.0.0.0 is an invalid Host IP address This is used to stream out the application logs to the remote syslog server.			
Examples	In the following example, IP address 10.1.61.16 is assigned as the external log server: se-10-0-0-0(config-mping)> log server address 10.1.61.16 se-10-0-0-0(config-mping)> exit			
Related Commands	Command	Description		
	show hosts	Displays all configured hosts.		
	show log	Displays a specific log.		
	show logs	Displays all logs.		
	show running-config	Displays the log server as part of the configuration.		

log level

To configure the different system log levels, use the **log level** command in Cisco AXP application service configuration mode.

To disable log levels, use the **no** form of this command.

log level levels

no log level levels

Syntax Description	levels	info: Events with LOG_INFO and higher severity are logged, including all messages described in notice .
		warn (Default): Events with LOG_WARNING and higher severity are logged, including all error messages described in err .
		err : Events with LOG_ERR and higher severity are logged, including LOG_EMERG, LOG_ALERT, and LOG_CRIT.
		notice : Events with LOG_NOTICE and higher severity are logged, including all messages described in warn .
		debug – Events with LOG_DEBUG and higher severity are logged, including all messages described in info .
Defaults	warn is the default val	
Delauns	warn is the default var	uc.
Command Default	None.	
Command Modes	Cisco AXP application	n service configuration.
Command History	Cisco AXP Version	Modification
	1.0	This command was introduced.
Examples	The following example are logged:	e shows the log level being set so that events with LOG_INFO or higher severity
	se-Module(config-mya	app)> log level info
Usage Guidelines	log level info logs even	nts with LOG_INFO or higher severity.
		ple, events within the stdout of a CLI plug-in and the output from s made by the application MyAppMain, are redirected to syslog if they have a log r above.

java -cp

./app_bin/myApp.jar:/cli_comm/:/usr/lib/java/localsocket.jar:/usr/lib/java/cli_distributio n_vm.jar com.myApp.MyAppMain | /bin/logger -p info

Related Comm

nmands	Command	Description
	show log	Displays a specific log.
	show logs	Displays all logs.

ntp server

To synchronize the Cisco AXP application system clock with a remote Network Time Protocol (NTP) server, use the **ntp server** command in Cisco AXP configuration mode.

To disable the Cisco AXP application system clock from being synchronized with an NTP server, use the **no** form of this command.

ntp server {hostname | ip-address} [prefer]

no ntp server {*hostname* | *ip-address*}

Syntax Description	hostname	Hostname of the NTP server.	
	ip-address	IP address of the NTP server.	
	prefer	(Optional) Marks the server as preferred.	
Defaults	The default is the IP address of th	e server.	
Command Default	None.		
Command Modes	Cisco AXP configuration.		
Command History	Cisco AXP Version	Modification	
	1.0	This command was introduced.	
Usage Guidelines	Cisco AXP systems and applicati	with the clock time command to set the timing functions for ons. he specified server is chosen for synchronization from among a set of	
<u>Caution</u>	The no ntp server command dele caution.	etes the NTP server hostname or IP address. Use this command with	
Examples	The following example assigns th se-10-0-0(config)> ntp serv	e server with address 192.168.1.100 as the preferred NTP server: er 192.168.1.100 prefer	
	The following example assigns the server with hostname main_ntp as the NTP server: se-10-0-0(config)> ntp server main_ntp		

Related Commands	Command Description	
	clock timezone	Configures the local time zone.
	show clock detail	Displays current clock statistics.
	show ntp source	Displays current NTP server statistics.

status-monitor

To configure the status monitor and recovery threshold, use the status-monitor command in Cisco AXP application service configuration mode.

status-monitor monitor_interval Interval-Num recovery_threshold Threshold-Num

Syntax Description	monitor_interval	Threshold value for monitoring interval				
Syntax Description		Threshold value for monitoring interval.				
	Interval-Num	Range is 1 to 99. Default is 12. Measured at 5 seconds per interval.				
	recovery_threshold					
	Threshold-Num	Recovery threshold range is 1 to 99. Default is 5.				
Defaults	Default value for monit	tor interval is 12 and recovery threshold is 5.				
Command Default	None.					
Command Modes	Cisco AXP application	service configuration.				
Command History	Cisco AXP Version	Modification				
	1.0	This command was introduced.				
Usage Guidelines	Cisco AXP allows third party applications to plug in their status monitoring and allows recovery from a malfunctioned state.					
	An application must provide one or more watchdog scripts or executable files bundled in their package to use the Cisco AXP application monitoring feature. The number of scripts or executables is dependent on the application, resulting in a unique way of determining the status of the application. For example, it can be based on Process Identifier (PID), or a response to an application ping. Cisco AXP supports Shell scripts and C language executables for application status monitoring.					
	For more information on watchdog scripts and executables, see the Cisco AXP Developer Guide.					
	The application status monitor has a heartbeat of 5 seconds, which is the minimum interval used for monitoring. For example, if the monitor interval is set at 12, monitoring of each virtual instance takes place every 12 heartbeat intervals, which is every one minute. You can configure the monitoring interval for a virtual instance through the status-monitor monitor interval command.					
	The scripts or executables return a status code where zero indicates that the application is healthy and alive. A non zero status code indicates that the application is not functional. When a watchdog script or executable returns a non zero status code, relevant information such as the name of the watchdog script, return status, and time of failure is logged.					

	A recovery counter counts the number of times the failure takes place, and acts as a delay mechanism for further action. A recovery count of three means that the application monitor has run for three iterations and is receiving either a non zero return status, or the watchdog script has been running for over 3 monitoring intervals and is not returning a value.
	You can use the status-monitor monitor interval command for configuring the recovery threshold that decides on the number of recovery counters before taking the next action. When the recovery threshold is reached, the virtual instance restarts and the application monitor continues to run, repeating the monitoring cycle. A virtual instance can restart any number of times.
	If you are developing a third party application, you can provide default configuration parameters using a configuration file that is packaged together with the application.
Examples	The following example sets the threshold value for the monitor interval to 10 (monitoring occurs every 50 seconds) and the threshold value for recovery attempts to 10.
	<pre>se-Module(config-mping)> status-monitor monitor_interval 10 recovery_threshold 10</pre>
Related Commands	Command Description

Displays data for the application status monitor.

show status-monitor

show app-service state

To display the state and health of all installed virtual instances and applications, use the **show app-service state** command in Cisco AXP EXEC mode.

show app-service state

Syntax Description	This command has no arguments or keywords.			
Defaults	No default behavior or	values.		
Command Default	None.			
Command Modes	Cisco AXP EXEC.			
Command History	Cisco AXP Version	Modification		
	1.0	This command wa	s introduced.	
Usage Guidelines	Use this command freq are up and running.	uently on the applicati	on service module to d	letermine whether your application
Examples	In the following examp are displayed on the sc		nning applications, the	application's name, state, and healtl
	se-100.0.4.2> show a	pp-service state		
		PPLICATION	STATE	HEALTH
		helloworld	online	ALIVE
	simpleF	C4CPlusApp x11_app	online online	
Related Commands	Command	Description		
	show state	Displays the status application service	_	ic application in Cisco AXP

show app-service statistics

To display the memory and processing time information of an installed virtual instance, use the **show app-service statistics** command in Cisco AXP EXEC mode.

show app-service statistics

Syntax Description	This command has no arguments or keywords.
--------------------	--

Defaults No default behavior or values.

Command Default None.

Command Modes Cisco AXP EXEC.

Command History	Cisco AXP Version	Modification
	1.0	This command was introduced.

Examples

In the following example, the statistics for all installed virtual instances are displayed on the screen.

se-100	0.0.4.2:	> shov	<i>app-se</i>	ervice stati	stics		
CTX	PROC	VSZ	RSS	userTIME	SYSTIME	UPTIME	NAME
0	122	2.7G	626.9M	1h23m20	1h39m08	6d18h56	root server
2	4	8.6M	2.9M	1m46s57	2m07s88	6d18h54	helloworld
CTX =	context	= numb	per for	the virtual	instance		
PROC =	= quant:	ity of	proces	sses in the d	context		
VSZ =	number	of pa	ages of	virtual memo	ory		
RSS =	Resider	nt set	size 1	limits for me	emory		
userT	ime = u	time t	Jser-mod	le CPU time a	accumulate	d	
sysTir	me = ct:	ime Ke	ernel-mo	de CPU time	accumulat	ed	
upTime	e = upt:	ime					

Related Commands	Command	Description
	show statistics app	Allows third party applications to integrate their own application statistics for display.
		ior any main and the second se

show app-service status-monitor

To display status monitor information for all installed applications, use the **show app-service status-monitor** command in Cisco AXP EXEC mode.

show app-service status-monitor

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values.

Command Default None.

Command Modes Cisco AXP EXEC.

Command History	Cisco AXP Version	Modification
	1.0	This command was introduced.

Examples

In the following example, the monitoring information for helloworld is displayed on the screen. (helloworld is the only installed application.)

```
se-100.0.4.2> show app-service status-monitor
Application: helloworld
Monitor status: PASSED
Monitor in progress: Yes
Last executed watchdog: W00template.sh
Last executed date: Wed Sep 5 14:09:58 PDT 2007
Last failed watchdog: ---
Last failed return code: -
Last failed date: ---
Last restarted date: ---
Recovery threshold: 4
Monitor interval: 3
```

Related Commands	Command	Description
	show running-config	Displays the current running configuration.

show clock detail

To display clock statistics, use the show clock detail command in Cisco AXP EXEC mode.

show clock detail

Syntax Description	This command has no arguments or keywords.						
Defaults	No default behavior or values.						
Command Default	None.						
Command Modes	Cisco AXP EXEC.						
Command History	Cisco AXP VersionModific1.0This co						
Command History		ion mand was introduced.					
Command History Examples	1.0 This co						
	1.0 This co	mand was introduced.					
	1.0This controlIn the following example, the clockse-100.0.4.2>show clock detainse-10-1-1-20>show clock detain15:22:08.375PST Thu Nov 29 20	mand was introduced. statistics are displayed on the screen.					
	1.0This controlIn the following example, the closese-100.0.4.2>show clock detase-10-1-1-20>show clock deta15:22:08.375PST Thu Nov 29 20time zone:	mand was introduced. statistics are displayed on the screen. 7 America/Los_Angeles					
	1.0This controlIn the following example, the closese-100.0.4.2>show clock detase-10-1-1-20>show clock deta15:22:08.375PST Thu Nov 29 20time zone:clock state:	mand was introduced. statistics are displayed on the screen. 7 America/Los_Angeles unsync					
	1.0This controlIn the following example, the closese-100.0.4.2>show clock detase-10-1-1-20>show clock deta15:22:08.375PST Thu Nov 29 20time zone:	mand was introduced. statistics are displayed on the screen. 7 America/Los_Angeles unsync					
	1.0This controlIn the following example, the clockse-100.0.4.2> show clock detase-10-1-1-20> show clock deta15:22:08.375 PST Thu Nov 29 20time zone:clock state:delta from reference (microsed)	mand was introduced. statistics are displayed on the screen. America/Los_Angeles unsync : 0					
	1.0This controlIn the following example, the clockse-100.0.4.2> show clock detase-10-1-1-20> show clock deta15:22:08.375 PST Thu Nov 29 20time zone:clock state:delta from reference (microsec):	mand was introduced. statistics are displayed on the screen. America/Los_Angeles unsync Unsy					
	1.0 This constraints of the clock detains the following example, the clock se-100.0.4.2> show clock detains se-10-1-1-20> show clock detains the clock detains the clock detains of the clock detains the clock de	mand was introduced. statistics are displayed on the screen. America/Los_Angeles unsync Unsy					

Related Commands	Command	Description				
	clock timezone	Configures the local timezone.				
	ntp server	Configures the NTP server for time synchronization				

show device serial

To display the serial device ID, use the show device serial command in Cisco AXP EXEC mode.

Syntax Description This command has no arguments or keywords. Defaults No default behavior or values. Command Default None Command Modes Cisco AXP EXEC. Command History Cisco AXP Version Modification 1.0 This command was introduced. In the following example, all the serial devices are displayed on the screen. se-Module> show device serial Device Name TTY No. Line No. Line Type Intf Name Assigned To Vuxi1 TYY No. Line No. Line Type Intf Name Assigned To Vuxi2 O 0/0/0 2 TTY Se0/0/0 serialapp Related Commands Command Description bind serial Description		show devic	e serial				
Command Default None Command Modes Cisco AXP EXEC. Command History Cisco AXP Version Modification 1.0 This command was introduced. Examples In the following example, all the serial devices are displayed on the screen. se-Module> show device serial Device Name Device Name TTY No. Line No. Line Type Intf Name Assigned To vaux1 1 1 AUX - vtty000 0/0/0 2 TTY vtty001 0/0/1 3 TTY Related Commands Command Description	Syntax Description	This command	has no arguments or ke	eywords.			
Command Modes Cisco AXP EXEC. Command History Cisco AXP Version Modification 1.0 This command was introduced. Examples In the following example, all the serial devices are displayed on the screen. se-Module> show device serial Device Name Device Name TTY No. Line No. Line Type Intf Name Assigned To vaux1 1 1 AUX - vtty000 0/0/0 2 TTY Se0/0/0 serialapp vtty001 0/0/1 3 TTY Se0/0/1 - Related Commands Command Description	Defaults	No default beha	avior or values.				
Command History Cisco AXP Version Modification 1.0 This command was introduced. Examples In the following example, all the serial devices are displayed on the screen. se-Module> show device serial Device Name Device Name TTY No. Line No. Line Type Intf Name Assigned To vaux1 1 AUX - vtty000 0/0/0 2 TTY Se0/0/0 serialapp vtty001 0/0/1 3 TTY Se0/0/1 -	Command Default	None					
In the following example, all the serial devices are displayed on the screen. se-Module> show device serial Device Name TTY No. Line No. Line Type Intf Name Assigned To vaux1 1 AUX - vtty000 0/0/0 2 TTY Se0/0/0 serialapp Related Commands Command Description	Command Modes	Cisco AXP EX	EC.				
se-Module> show device serial Device Name TTY No. Line No. Line Type Intf Name Assigned To vaux1 1 1 AUX - - vtty000 0/0/0 2 TTY Se0/0/0 serialapp vtty001 0/0/1 3 TTY Se0/0/1 -	Command History				uced.		
Device Name TTY No. Line No. Line Type Intf Name Assigned To vaux1 1 1 AUX - - vtty000 0/0/0 2 TTY Se0/0/0 serialapp vtty001 0/0/1 3 TTY Se0/0/1 - Related Commands Command Description	Examples	In the following	g example, all the seria	l devices are d	lisplayed on the s	creen.	
Device Name TTY No. Line No. Line Type Intf Name Assigned To vaux1 1 1 AUX - - vtty000 0/0/0 2 TTY Se0/0/0 serialapp vtty001 0/0/1 3 TTY Se0/0/1 -	-	an Madulas ab	- 				
vaux1 1 1 AUX - - vtty000 0/0/0 2 TTY Se0/0/0 serialapp vtty001 0/0/1 3 TTY Se0/0/1 - Related Commands Command Description - -				Line Type	Intf Name N	ssigned To	
vtty000 0/0/0 2 TTY Se0/0/0 serialapp vtty001 0/0/1 3 TTY Se0/0/1 -						-	
vtty001 0/0/1 3 TTY Se0/0/1 - Related Commands Command Description					Se0/0/0	serialapp	
· · · · · · · · · · · · · · · · · · ·		vtty001	0/0/1 3	ТТҮ	Se0/0/1	-	
bind serial Binds the serial device.	Related Commands	Command	Description				
		bind serial	Binds the se	rial device.			

OL-15872-01

show interfaces

To display all the configured interfaces, including virtual and VLAN interfaces, use the **show interfaces** command in Cisco AXP EXEC mode.

show interfaces [| |GigabitEthernetlide]

Syntax Description	I	Pipes output to another command.							
	GigabitEthernet	Gigabit Ethernet device.							
	ide Integrated Drive Electronics (hard disk)								
Defaults	No default behavior o	r values.							
Command Default	None.								
Command Modes	Cisco AXP EXEC.								
Command History	Cisco AXP Version	Modification							
	1.0	This command was introduced.							
	1.0 In the following examp	This command was introduced.							
	1.0 In the following examp a GigabitEthernet inte se-100.0.4.2> show	This command was introduced. ple, the show interfaces command displays all configured interfaces on the screen: rface and an IDE (hard disk) interface. interfaces							
	1.0 In the following examp a GigabitEthernet inte se-100.0.4.2> show GigabitEthernet 0 i	This command was introduced. ple, the show interfaces command displays all configured interfaces on the screen: rface and an IDE (hard disk) interface.							
	1.0 In the following examp a GigabitEthernet inter se-100.0.4.2> show GigabitEthernet 0 i Internet address 25629 packets	This command was introduced. ple, the show interfaces command displays all configured interfaces on the screen: interfaces s up, line protocol is up is 10.10.1.20 mask 255.255.0 (configured on router) input, 1688582 bytes							
	1.0 In the following examp a GigabitEthernet inter se-100.0.4.2> show GigabitEthernet 0 i Internet address 25629 packets 0 input errors 25634 packets	This command was introduced. ple, the show interfaces command displays all configured interfaces on the screen: interface and an IDE (hard disk) interface. interfaces s up, line protocol is up is 10.10.1.20 mask 255.255.255.0 (configured on router) input, 1688582 bytes , 0 dropped, 0 overrun, 0 frame errors output, 1785015 bytes							
	1.0 In the following examp a GigabitEthernet inter se-100.0.4.2> show GigabitEthernet 0 i Internet address 25629 packets 0 input errors 25634 packets 0 output error	This command was introduced. ple, the show interfaces command displays all configured interfaces on the screen interface and an IDE (hard disk) interface. interfaces s up, line protocol is up is 10.10.1.20 mask 255.255.255.0 (configured on router) input, 1688582 bytes , 0 dropped, 0 overrun, 0 frame errors							
	<pre>1.0 In the following examp a GigabitEthernet inter se-100.0.4.2> show GigabitEthernet 0 i Internet address 25629 packets 0 input errors 25634 packets 0 output error 0 output carri IDE hd0 is up, line 2060 reads, 32 0 read errors</pre>	This command was introduced. ple, the show interfaces command displays all configured interfaces on the screen wrface and an IDE (hard disk) interface. interfaces s up, line protocol is up is 10.10.1.20 mask 255.255.255.0 (configured on router) input, 1688582 bytes , 0 dropped, 0 overrun, 0 frame errors output, 1785015 bytes s, 0 dropped, 0 overrun, 0 collision errors er detect errors protocol is up							
Examples Related Commands	<pre>1.0 In the following examp a GigabitEthernet inter se-100.0.4.2> show GigabitEthernet 0 i Internet address 25629 packets 0 input errors 25634 packets 0 output error 0 output carri IDE hd0 is up, line 2060 reads, 32 0 read errors 489797 write,</pre>	This command was introduced. ple, the show interfaces command displays all configured interfaces on the screen: interfaces s up, line protocol is up is 10.10.1.20 mask 255.255.255.0 (configured on router) input, 1688582 bytes , 0 dropped, 0 overrun, 0 frame errors output, 1785015 bytes s, 0 dropped, 0 overrun, 0 collision errors er detect errors protocol is up 704512 bytes							

show logs

L

The show logs command can be used in either of the following two modes:

- Cisco AXP application service EXEC mode: the command displays log files in the application environment.
- Cisco AXP EXEC mode: the command displays log files on the Cisco AXP service module.

show logs

Syntax Description	This command	has no arguments	or keywords.
--------------------	--------------	------------------	--------------

Defaults No default behavior or values.

- Command Default None.
- Command ModesCisco AXP application service EXEC.Cisco AXP EXEC.

Command History	Cisco AXP Version	Modification
	1.0	This command was introduced.

Usage Guidelines In Cisco AXP application service EXEC mode, this command displays all the log files under the /var/log directory of the virtual instance.

Examples

In the following example, the **show logs** command, executed in Cisco AXP application service EXEC mode, shows the log files under the /var/log directory of the virtual instance.

se-Module(exec-mping)> **show logs** SIZE LAST_MODIFIED_TIME NAME 108 Mon Nov 05 19:50:33 PST 2007 messages.log

In the following example, the **show logs** command, executed in Cisco AXP EXEC mode, shows the log files on the Cisco AXP service module.

se-Module>	show	logs	3				
SIZE		LAS	ST_1	MODIFIED_	CIME		NAME
43452	Tue	Nov	06	10:46:44	PST	2007	linux_session.log
7630	Thu	Nov	15	16:18:22	PST	2007	install.log
8508	Thu	Nov	15	16:18:00	PST	2007	dmesg
0	Thu	Nov	01	18:12:34	PDT	2007	eem.log
4614755	Thu	Nov	15	16:16:50	PST	2007	messages.log.prev

Related Commands	Command	Description
	log level	Configures the severity of messages to be logged.
	log trace	Configures trace logging options.

show log name

To display a specific log file in the application environment, use the **show log name** command in Cisco AXP application service EXEC mode.

To display system level logging data for a specific log file, use the **show log name** command in Cisco AXP EXEC mode.

show log name log-name {containing expression | paged | interactive | {|begin | lexclude | |
 include | lpage} | tail}

Syntax Description		
	log-name	Log name. See the show logs command for log names.
	containing expression	Only display events matching a regular expression (regex) pattern, where <i>expression</i> is a regex.
	paged	Displays in page mode.
	interactive	Displays logs in interactive mode.
	1	Pipes output to another command.
	begin	Pipes output to another command and begins with the matching line.
	exclude	Pipes output to another command and excludes lines that match.
	include	Pipes output to another command and includes lines that match.
	page	Pipes output to another command and paginates the output.
	tail	Waits for events and prints them as they occur.
Command Modes	Cisco AXP application s	ervice EXEC.
Command Modes	Cisco AXP application s Cisco AXP EXEC.	service EXEC.
	••	Modification
Command Modes Command History	Cisco AXP EXEC.	

Related Commands	Command	Description
	show logs	Displays all the log files.

show ntp associations

To display the association identifier and status for all Network Time Protocol (NTP) servers, use the **show ntp associations** command in Cisco AXP EXEC mode.

show ntp associations [assocID association-id]

Syntax Description	assoc-ID association-id	association-id: Specified association ID.
Command Modes	Cisco AXP EXEC.	
Command History	Cisco AXP Version	Modification
	1.0	This command was introduced.
Usage Guidelines	servers configured for Cisc	command displays the association identifier and status for all the NTP o AXP and does not provide details about the servers. The show ntp <i>ciation-id</i> command provides details on the status of a specified NTP server.
	Use the status field to determine the configuration and status of all the NTP servers. This field consists of 4 hexadecimal digits:	
	• The first two digits spe	cify the server configuration and how far it progressed through the clock

- The first two digits specify the server configuration and how far it progressed through the clock selection process. See Table 1.
- The second two digits indicate the number of events and the type of the last event. See Table 2.

Table 1 shows common status codes and their descriptions. The first digit specifies the configuration, reachability, and authentication status for the specified server. The second digit records how well the specified server passed through the clock selection algorithm.

Status Field Codes	Description
1xxx	Server has sent a peer synchronization request to the local machine, and the server is not configured locally.
7xxx	Server is a peer that is not configured locally, is reachable, and uses proper authentication.
8xxx	Server is configured and not authenticated or reachable.
9xxx	Server is configured and reachable.
Cxxx	Server is configured to use authentication but is not reachable.
Dxxx	Server is configured to use authentication and is reachable but is not using a trusted key.
Fxxx	Server is authenticated as a trusted server and is reachable.

Table 1Status Field Code Descriptions

Status Field Codes	Description
x0xx	Server did not pass any sanity checks and is rejected by the client. Possible causes for this condition include the server failing to authenticate, the server having a huge error bound (over 16 seconds), or the server existing on a higher stratum number than the client.
x1xx	Server passed the sanity checks and was not close enough to other servers to survive the intersection algorithm. This indicates that the server's clock was outside the largest possible error bounds of the other clocks, a condition that usually indicates that the server is set to the wrong time.
x2xx	Server passed the correctness checks (intersection algorithm). This value indicates that the server is probably configured correctly.
x3xx	Server passed the candidate checks. The server was not discarded because there were too many good servers (over 10).
x4xx	Server passed through the clustering algorithms without being discarded as an outlier having too much dispersion.
x5xx	Server would be the synchronization source and is too far away. This means that all the other clocks did not pass the sanity check or are too far away also.
хбхх	Server is the current synchronization source. This is the preferred server status.
x7xx to xFxx	Reserved values. These should not occur in normal usage.

Table 1	Status Field Code Descriptions (continued)
---------	--

Table 2 lists the event codes. The third digit indicates the number of events that have occurred since the last time an error was returned to the console by NTP or by one of the **show ntp** commands. This value does not wrap and stops incrementing at 15 (or hex F).

For a properly running server, the value should be xx1x, unless one of the **show ntp** commands has queried the server since startup. In that case, the value should be xx0x. If the third digit is any other value, check for the event causing errors.

The fourth digit in the field indicates the last event that occurred. For properly running servers, the event should be the server becoming reachable.

Event Field Codes	Description
xxx0	Unspecified event. Either no events have occurred or some sort of special error has occurred.
xxx1	IP error occurred reaching the server.
xxx2	Unable to authenticate a server that used to be reachable. This indicates that the keys changed or someone is spoofing the server.
xxx3	Formerly reachable server is now unreachable.
xxx4	Formerly unreachable server is now reachable.
xxx5	Server's clock had an error.
xxx6 to xxxF	Reserved values. These should not occur in normal usage.

Table 2Event Field Code Values

The flash field indicates the status of the packets while a series of 12 diagnostic tests are performed on them. The tests are performed in a specified sequence to gain maximum information while protecting against accidental or malicious errors.

The flash variable is set to zero as each packet is received. If any bits are set as a result of the tests, the packet is discarded.

The tests look for the following information:

- TEST1 to TEST3 check the packet time stamps from which the offset and delay are calculated. If no bits are set, the packet header variables are saved.
- TEST4 and TEST5 check access control and cryptographic authentication. If no bits are set, no values are saved.
- TEST6 to TEST8 check the health of the server. If no bits are set, the offset and delay relative to the server are calculated and saved.
- TEST9 checks the health of the association. If no bits are set, the saved variables are passed to the clock filter and mitigation algorithm.
- TEST10 to TEST12 check the authentication state using Autokey public-key cryptography. If any bits are set and the association was previously marked as reachable, the packet is discarded. Otherwise, the originate and receive time stamps are saved with a continuation of the process.

Table 3 lists the flash bits for each test.

Flash Bit Values	Description
0x001	TEST1. Duplicate packet. The packet is at best a casual retransmission and at worst a malicious replay.
0x002	TEST2. Bogus packet. The packet is not a reply to a message previously sent. This can happen when the NTP daemon is restarted.
0x004	TEST3. Unsynchronized. One or more time-stamp fields are invalid. This normally happens when the first packet from a peer is received.
0x008	TEST4. Access is denied.
0x010	TEST5. Cryptographic authentication fails.
0x020	TEST6. Server is unsynchronized. Wind up its clock first.
0x040	TEST7. Server stratum is at the maximum of 15. The server is probably unsynchronized, and its clock needs to be wound up.
0x080	TEST8. Either the root delay or the dispersion is greater than 1 second.
0x100	TEST9. Either the peer delay or the dispersion is greater than 1 second.
0x200	TEST10. Autokey protocol has detected an authentication failure.
0x400	TEST11. Autokey protocol has not verified the server, or the peer is proventic and has valid key credentials.
0x800	TEST12. Protocol or configuration error occurred in the public key algorithm, or a possible intrusion event is detected.

Table 3 Flash Field Diagnostic Bit Values

Examples

The following example show the output that appears after using the basic **show ntp associations** command:

```
se-10-0-0-0> show ntp associations
```

Table 4 describes the significant fields shown in the display.

Table 4show ntp associations Field Descriptions

Field	Description
ind	Index number of the association.
assID	Peer identifier returned by the server.
status	Hexadecimal value of the server status. See Table 1 and Table 2 for a description of these field codes.
conf	Indicates whether the server is configured or not. Valid values are yes and no.
reach	Indicates whether the peer is reachable or not. Valid values are yes and no.
auth	Status of the server authentication. Valid values are:
	• ok
	• bad
	• none
	• ""
condition	Type of association in the clock selection process. Valid values are:
	• space: Reject. Peer is discarded as unreachable.
	• falsetick: Peer is discarded as a false tick.
	• excess: Peer is discarded as not among the 10 closest peers.
	• outlier: Peer is discarded as an outlier.
	• candidate: Peer selected for possible synchronization.
	• selected: Almost synchronized to this peer.
	• sys.peer: Synchronized to this peer.
	• pps.peer: Synchronized to this peer on the basis of a pulse-per-second signal.

Field	Description
last_event	Last event that occurred in the system. Valid values are:
	• (empty)
	• IP error
	• Auth fail
	• lost reach
	• reachable
	• clock expt
	See Table 2 for descriptions of these values.
cnt	Number of events that occurred since the last time an error was returned to the console by the NTP. This value does not wrap and stops incrementing at 15 (or hex F). For a properly functioning server, this value should be 1 or 0.

Table 4 show ntp associations Field Descriptions (continued)

The following example shows the ntp associations for a particular assocID, using the **show ntp associations assocID** command:

```
se-10-0-0-0> show ntp associations assocID 50101
```

```
status=8000 unreach, conf, no events,
srcadr=10.1.10.2, srcport=123, dstadr=10.1.1.20, dstport=123, leap=11,
stratum=16, precision=-17, rootdelay=0.000, rootdispersion=0.000,
refid=0.0.0.0, reach=000, unreach=16, hmode=3, pmode=0, hpoll=10,
ppoll=10, flash=00 ok, keyid=0, offset=0.000, delay=0.000,
dispersion=0.000, jitter=4000.000,
reftime=00000000.00000000 Wed, Feb 6 2036 22:28:16.000,
org=00000000.0000000 Wed, Feb 6 2036 22:28:16.000,
rec=00000000.00000000 Wed, Feb 6 2036 22:28:16.000,
xmt=cafae952.b5de7a74 Fri, Nov 30 2007 11:56:02.710,
filtdelay=
              0.00
                      0.00
                              0.00
                                      0.00
                                              0.00
                                                      0.00
                                                              0.00
                                                                      0.00,
              0.00
                      0.00
                                                                      0.00,
filtoffset=
                              0.00
                                      0.00
                                              0.00
                                                      0.00
                                                              0.00
filtdisp= 16000.0 16000.0 16000.0 16000.0 16000.0 16000.0 16000.0
```

Table 5 describes the significant fields shown in the display.

Field	Description
status	Status of the peer. See Table 1, Table 2, and Table 4 for descriptions of the values in this line.
srcadr	IP address of the host server.
srcport	Port address of the host server.
dstadr	IP address of the destination server.
dstport	Port address of the destination server.

Table 5 show ntp associations assoc-id Field Descriptions

Field	Description
leap	Two-bit coded warning of an impending leap second to be inserted in the NTP timescale. Valid values are:
	• 00: No warning
	• 01: Last minute has 61 seconds
	• 10: Last minute has 59 seconds
	• 11: Alarm condition (clock not synchronized)
stratum	Server hop count to the primary clock source. Valid values are:
	• 0: Unspecified
	• 1: Primary clock reference
	• 2–255: Secondary reference via NTP
	If the stratum value is 15, the server is probably unsynchronized and its clock needs to be reset.
precision	Precision of the clock, in seconds to the power of two.
rootdelay	Total round-trip delay, in seconds, to the primary reference source at the root of the synchronization subnet.
rootdispersion	Maximum error, in seconds, relative to the primary reference source at the root of the synchronization subnet.
refid	IP address of the peer selected for synchronization.
reach	Peer reachability status history, in octal. Each bit is set to 1 if the server is reached during a polling period and is set to 0 otherwise. The value 377 indicates that the last 8 attempts were good.
unreach	Number of poll intervals since the last valid packet was received.
hmode	Association mode of the host server. Valid values are:
	• 0: Unspecified
	• 1: Symmetric active
	• 2: Symmetric passive
	• 3: Client
	• 4: Server
	• 5: Broadcast
	• 6: Reserved for NTP control messages
	• 7: Reserved for private use

Table 5 show ntp associations assoc-id Field Descriptions (continued)
Field	Description			
pmode	Association mode of the peer server. Valid values are:			
	• 0: Unspecified			
	• 1: Symmetric active			
	• 2: Symmetric passive			
	• 3: Client			
	• 4: Server			
	• 5: Broadcast			
	• 6: Reserved for NTP control messages			
	• 7: Reserved for private use			
hpoll	Minimum interval, in seconds as a power of two, between transmitted messages from the host.			
ppoll	Minimum interval, in seconds as a power of two, between transmitted messages to the peer.			
flash	Status of the packet after a series of diagnostic tests are performed on the packet. See the description of the flash field values in Table 3.			
keyid	ID of the cryptographic key used to generate the message-authentication code.			
offset	Time difference between the client and the server, in milliseconds.			
delay	Round-trip delay of the packet, in milliseconds.			
dispersion	Measure, in milliseconds, of how scattered the time offsets have been from a specific time server.			
jitter	Estimated time error, in milliseconds, of the Cisco AXP clock measured as an exponential average of RMS time differences.			
reftime	Local time, in time-stamp format, when the local clock was last updated. If the local clock has never been synchronized, the value is zero.			
org	Local time, in time-stamp format, at the peer when its latest NTP message was sent. If the peer becomes unreachable, the value is zero.			
rec	Local time, in time-stamp format, when the latest NTP message from the peer arrived. If the peer becomes unreachable, the value is zero.			
xmt	Local time, in time-stamp format, at which the NTP message departed the sender.			
filtdelay	Round-trip delay, in seconds, between the peer clock and the local clock over the network between them.			

Table 5	show ntp associations assoc-id Field Descriptions (continued)
---------	---

Field	Description
filtoffset	Offset, in seconds, of the peer clock relative to the local clock.
filtdisp	Maximum error, in seconds, of the peer clock relative to the local clock over the network between them. Only values greater than zero are possible.

Table 5 show ntp associations assoc-id Field Descriptions (continued)

Related Commands	Command	Description		
	show ntp servers	Displays a list of NTP servers and their current states.		
	show ntp source	Displays the primary time source for an NTP server.		

show ntp servers

To display a list of Network Time Protocol (NTP) servers, their current states, and a summary of the remote peers associated with each server, use the **show ntp servers** command in Cisco AXP EXEC mode.

show ntp servers

Syntax Description This command has no keywords or arguments.

Command Modes Cisco AXP EXEC.

 Command History
 Cisco AXP Version
 Modification

 1.0
 This command was introduced.

Usage Guidelines Use the **show ntp servers** command after changing the ntp server configuration.

Examples The following example shows sample output for the **show ntp servers** command:

se-10-1-1-20> remote	show ntp servers refid	st t	when poll re	ach	delay	offset jitter
10.1.10.2	0.0.0.0	16 u	- 1024	0	0.000	0.000 4000.00
space reject,	x falsetick,		. excess,		- out	lyer
+ candidate,	<pre># selected,</pre>		* sys.peer,		o pps	.peer

Table 6 describes the significant fields shown in the display.

Table 6show ntp servers Field Descriptions

Field	Description
remote	IP address of the remote server.
refid	Server's current time source.
st	Hop count (stratum) to the remote server.
t	Type of peer. Valid values are:
	• 1: Local
	• u: Unicast
	• m: Multicast
	• b: Broadcast
when	Time when the last packet was received.
poll	Polling interval, in seconds.

Field	Description		
reach	Peer reachability status history, in octal. Each bit is set to 1 if the server is reached during a polling period and is set to 0 otherwise. The value 377 indicates that the last 8 attempts were good.		
delay	Round-trip delay of the packet, in milliseconds.		
offset	Time difference between the client and the server, in milliseconds		
jitter	Estimated time error, in milliseconds, of the Cisco AXP clock measured as an exponential average of RMS time differences.		
(tally code)	The character preceding the remote IP address indicates the status of the association in the clock selection process. Valid values are:		
	• space Reject: Peer is discarded as unreachable.		
	• x Falsetick: Peer is discarded as a false tick.		
	• . Excess: Peer is discarded as not among the ten closest peers		
	• – Outlier: Peer is discarded as an outlier.		
	• + Candidate: Peer selected for possible synchronization.		
	• # Selected: Almost synchronized to this peer.		
	• * Sys.peer: Synchronized to this peer.		
	• o PPS.peer: Synchronized to this peer on the basis of a pulse-per-second signal.		

Table 6	show ntp servers Field Descriptions (continued)
10.510 0	

Related Commands	Command	Description
	ntp server	Configures the NTP server.
	show ntp associations	Displays a list of association identifiers and peer statuses for an NTP server.
	show ntp source	Displays the time source for an NTP server.

show ntp source

To display the time source for a Network Time Protocol (NTP) server, use the **show ntp source** command in Cisco AXP EXEC mode. The display extends back to the primary time source, starting from the localhost.

show ntp source [detail]

Syntax Description	detail	(Optional) Additional NTP server details including: precision, leap, refid, delay, dispersion, rootdelay, rootdispersion, reference time, originate timestamp, and transmit timestamp.
Command Modes	Cisco AXP EXEC.	
Command History	Cisco AXP Version	Modification
	1.0	This command was introduced.
Examples	The following example	e shows the sample output for the show ntp source command:

se-10-0-0-0> show ntp source

127.0.0.1: stratum 9, offset 0.000015, synch distance 0.03047 10.100.10.65: stratum 8, offset -0.001124, synch distance 0.00003

Table 7 describes the significant fields shown in the display.

Table 7show ntp source Field Descriptions

Field	Description		
(first field)	IP address of the host.		
stratum	Server hop count to the primary clock source. Valid values are:		
	• 0: Unspecified		
	• 1: Primary clock reference		
	• 2–255: Secondary reference by NTP		
offset	Time offset between the host and the local host, in seconds.		
synch distance	Host synchronization distance, which is the estimated error from the primary source.		

The following example shows the sample output for the **show ntp source detail** command:

se-1-100-5-2> show ntp source detail

server 10.0.0.1, port 123
stratum 9, precision -17, leap 00
refid [10.10.10.65] delay 0.00012, dispersion 0.00000 offset 0.000011
rootdelay 0.00058, rootdispersion 0.03111, synch dist 0.03140
reference time: af4a3ff7.926698bb Thu, Feb 30 2007 14:47:19.571
originate timestamp: af4a4041.bf991bc5 Thu, Nov 30 2007 14:48:33.748
transmit timestamp: af4a4041.bf90a782 Thu, Nov 30 2007 14:48:33.748
server 10.10.10.65, port 123

stratum 8, precision -18, leap 00
refid [172.16.7.1] delay 0.00024, dispersion 0.00000 offset -0.001130
rootdelay 0.00000, rootdispersion 0.00003, synch dist 0.00003
reference time: af4a402e.f46eaea6 Thu, Nov 30 2007 14:48:14.954
originate timestamp: af4a4041.bf6fb4d4 Thu, Nov 30 2007 14:48:33.747
transmit timestamp: af4a4041.bfb0d51f Thu, Nov 30 2007 14:48:33.748

Table 8 describes the significant fields shown in the display.

Table 8show ntp source detail Field Descriptions

Field	Description	
server	IP address of the host server.	
port	Port number of the host server.	
stratum	Server hop count to the primary clock source. Valid values are:	
	• 0: Unspecified	
	• 1: Primary clock reference	
	• 2–255: Secondary reference by the NTP	
precision	Precision of the clock, in seconds to the power of two.	
leap	Two-bit code warning of an impending leap second to be inserted in the NTP time scale. Valid values are:	
	• 00: No warning	
	• 01: Last minute was 61 seconds	
	• 10: Last minute was 59 seconds	
	• 11: Alarm condition (clock not synchronized)	
refid	IP address of the peer selected for synchronization.	
delay	Round-trip delay of the packet, in milliseconds.	
dispersion	Measure, in milliseconds, of how scattered the time offsets have been from a specific time server.	
offset	Time offset between the host and the local host, in seconds.	
rootdelay	Total round-trip delay, in seconds, to the primary reference source at the root of the synchronization subnet.	
rootdispersion	Maximum error, in seconds, relative to the primary reference source at the root of the synchronization subnet.	
synch dist	Host synchronization distance, which is the estimated error from the primary source.	

Field	Description Local time, in time-stamp format, when the local clock was last updated. If the local clock has never been synchronized, the value is zero.				
reference time					
originate timestamp	Local time, in time-stamp format, at the peer when its latest NTP message was sent. If the peer becomes unreachable, the value is zero.				
transmit timestamp	Local time, in time-stamp format, when the latest NTP message from the peer arrived. If the peer becomes unreachable, the value is zero.				

Table 8	show ntp source detail Field Descriptions (continued)

Related Commands	Command	Description				
	show ntp associations	Displays a list of association identifiers and peer status for an NTP server.				
	show ntp servers	Displays a list of NTP servers and their current states.				

show ntp status

To display statistics for the Network Time Protocol (NTP) server, use the **show ntp status** command in Cisco AXP EXEC mode.

show ntp status

Syntax Description This command has no arguments or keywords.

Command Modes Cisco AXP EXEC.

 Command History
 Cisco AXP Version
 Modification

 1.0
 This command was introduced.

Examples

The following shows sample output for the **show ntp status** command:

se-10-0-0-0> show ntp status

NTP reference server 1:	10.100.6.9
Status:	sys.peer
Time difference (secs):	3.268110005008586E8
Time jitter (secs):	0.17168384790420532

Table 9 describes the significant fields shown in the display.

Table 9show ntp status Field Descriptions

Field	Description				
NTP reference server 1	IP address of the NTP server.				
Status	Status of the peer association in the clock selection process. Valid values are:				
	• Reject: Peer is discarded as unreachable.				
	• Falsetick: Peer is discarded as a false tick.				
	• Excess: Peer is discarded as not among the ten closest peers.				
	• Outlier: Peer is discarded as an outlier.				
	• Candidate: Peer selected for possible synchronization.				
	• Selected: Almost synchronized to this peer.				
	• Sys.peer: Synchronized to this peer.				
	• PPS.peer: Synchronized to this peer on the basis of a pulse-per-second signal.				

Field	Description
Time difference (secs)	Difference in seconds between the system clock and the NTP server.
Time jitter (secs)	Estimated time error, in seconds, of the Cisco AXP clock measured as an exponential average of root mean square (RMS) time differences.

Table 9 show ntp status Field Descriptions (continued)

Related Commands

Command	Description
clock timezone	Sets the local time zone.
ntp server	Specifies the NTP server for Cisco AXP.
show clock detail	Displays clock statistics.

show process

To display all processes in the application environment, use the **show process** command in Cisco AXP application service EXEC mode.

show process [all | memory | pid id | running}

Syntax Description	all	Displays a snapshot of all processes and summary information.
	memory	Displays random access memory utilization.
	pid id	Displays a snapshot of the process, where <i>id</i> is the process identifier.
	running	Displays a snapshot of the current running processes.
Defaults	No default behavior of	r values.
Command Default	None.	
Command Modes	Cisco AXP application	n service EXEC.
Command History	Cisco AXP Version	Modification
Command History	Cisco AXP Version 1.0	Modification This command was introduced.
	1.0	
Usage Guidelines	1.0 This command display ascending order.	This command was introduced.
Usage Guidelines	1.0 This command display ascending order.	This command was introduced. ys all processes in the virtual application environment and sorted by process ID in ple, show process displays summary and process information on the screen.
Usage Guidelines	1.0 This command display ascending order. In the following examt se-Module(exec-mping USER PID %CPU %MEM	This command was introduced. ys all processes in the virtual application environment and sorted by process ID in ple, show process displays summary and process information on the screen. g)> show process VSZ RSS TTY STAT START TIME COMMAND
Usage Guidelines	1.0 This command display ascending order. In the following examt se-Module(exec-mping)	This command was introduced. ys all processes in the virtual application environment and sorted by process ID in ple, show process displays summary and process information on the screen. g)> show process VSZ RSS TTY STAT START TIME COMMAND 1972 612 ? S Nov05 0:00 init [4]
Command History Usage Guidelines Examples	1.0 This command display ascending order. In the following examt se-Module(exec-mping USER PID %CPU %MEMt root 1 0.0 0.1	This command was introduced. ys all processes in the virtual application environment and sorted by process ID in ple, show process displays summary and process information on the screen. g)> show process VSZ RSS TTY STAT START TIME COMMAND 1972 612 ? S Nov05 0:00 init [4]
Usage Guidelines	1.0 This command display ascending order. In the following exam se-Module(exec-mping USER PID %CPU %MEM root 1 0.0 root 8522 0.0 root 8523 0.0	This command was introduced. ys all processes in the virtual application environment and sorted by process ID in ple, show process displays summary and process information on the screen. g)> show process VSZ RSS TTY STAT START TIME COMMAND 1972 612 ? S Nov05 0:00 init [4] 2244 800 ? Ss Nov05 0:00 /cisco/bin/syslog_ng

show processes

To display processes running on the Cisco AXP service module, use the **show processes** command in Cisco AXP EXEC mode.

show processes [cpu | memory]

Syntax Description	сри			Cent	tral proc	cessir	ng uni	t utiliza	tion.			
	memor	у		Rand	dom acc	cess n	nemoi	ry utiliz	ation.			
Defaults	No defa	ult beh	avior o	r values.								
Command Default	None.											
Command Modes	Cisco A	XP EX	EC.									
Command History	Cisco A	XP Ver	sion	Mod	ificatio	n						
	1.0			This	comma	and w	vas int	roduced	1.			
Examples	In the fo	ollowin	g exam	ple. show	v proces	sses d	lisplay	vs all the	e runni	ng pro	cesses. For each process th	e name
Examples		rocess (-	-	-						be state of the process are dis	
Examples	of the pr on the s	rocess (creen.	(in the (-	umn), tl	he hea					-	
Examples	of the pr on the s se-Modu se-10-0	rocess (creen. le(exe	(in the (g)> show	umn), tl 7 proce	he hea sses					-	
Examples	of the pr on the s se-Modu se-10-0 STATE	rocess (creen. le(exe	(in the (g)> show rocesses	umn), tl 7 proce 5 EALTH	he hea sses CMD	alth of	f the pro			-	
Examples	of the pr on the s se-Modu se-10-0	rocess (creen. le(exe	(in the (g)> show rocesses HE al	umn), tl 7 proce S EALTH .ive	he hea sses CMD sysl	alth of	f the pro	ocess, a		-	
Examples	of the pr on the s se-Modu se-10-0 STATE online	rocess (creen. le(exe	(in the (g)> show rocesses HE al al	umn), tl 7 proce 5 EALTH	he hea sses CMD sysl	og-ng	f the pro	ocess, a		-	
Examples	of the pr on the s se-Modu se-10-0 STATE online online	rocess (creen. le(exe	(in the (CMD cold g)> show rocesses HE al al al	a proces A proces CALTH .ive .ive	he he: sses CMD sysl plat	og-ng form_	f the pro	ocess, a		-	
Examples	of the pr on the s se-Modu se-10-0 STATE online online online online online	rocess (creen. le(exe	(in the (g)> show rocesses HE al al al al al	a process SALTH ive ive ive ive ive	he hea sses CMD sysl plat trac rbcp ntp	.og-nc form_	f the pro	ocess, a		-	
Examples	of the pr on the s se-Modu se-10-0 STATE online online online online online online	rocess (creen. le(exe	(in the (g)> show rocesses HE al al al al al al al	a process SALTH .ive .ive .ive .ive .ive .ive .ive .ive	CMD Sysl plat trac rbcp ntp down	og-ng form_ e	f the pro g _config	ocess, a		-	
Examples	of the pr on the s se-Modu se-10-0 STATE online online online online online online online	rocess (creen. le(exe	(in the (g)> show rocesses HE al al al al al al al al al	a proce EALTH ive ive ive ive ive ive ive ive ive ive	he hea sses CMD sysl plat trac rbcp ntp down supe	.og-nc form_	f the pro g _config	ocess, a		-	
Examples	of the pr on the s se-Modu se-10-0 STATE online online online online online online online online	rocess (creen. le(exe	(in the (g)> show rocesses HE al al al al al al al al al al al al	A proce BALTH ive ive ive ive ive ive ive ive ive ive	he hea sses CMD sysl plat trac rbcp ntp down supe dns	alth of	f the pro config er ead	ocess, a		-	
Examples	of the pr on the s se-Modu se-10-0 STATE online online online online online online online online online online	rocess (creen. le(exe	(in the (g)> show rocesses HE al al al al al al al al al al al al al	A proce CALTH ive ive ive ive ive ive ive ive ive ive	he hea sses CMD sysl plat trac rbcp ntp down supe dns back	og-ng form_ e	f the pro config er ead	ocess, a		-	
Examples	of the pr on the s se-Modu se-10-0 STATE online online online online online online online online	rocess (creen. le(exe -0-0>	(in the (g)> show rocesses HE al al al al al al al al al al al al al	A proce BALTH ive ive ive ive ive ive ive ive ive ive	he hea sses CMD sysl plat trac rbcp ntp down supe dns	alth of	f the pro config er ead	ocess, a		-	
Examples	of the pr on the s se-Modu se-10-0 STATE online onl	creen. le(exe -0-0>	g exam	g)> show rocesses HE al al al al al al al al al al al al al	wmn), the second	CMD Sysl plat trac rbcp ntp down supe dns back cli sshd	alth of .og-ng form_ ee alloade erthre supres	f the pro f the pro config er ead store ory disp	ocess, a	and the	-	playec
Examples	of the pr on the s se-Modu se-10-0 STATE online	creen. le(exe -0-0>	g exam ne ten r	g)> show rocesses HE al al al al al al al al al al al al al	umn), the process of	CMD Sysl plat trac rbcp ntp down supe dns back cli ssho	alth of .og-ng form_ ee alloade erthre supres	f the pro f the pro config er ead store ory disp	ocess, a	and the	e state of the process are dis	playeo
Examples	of the pr on the s se-Modu se-10-0 STATE online online online online online online online online service In the fo utilization se-10-0 VSZ	creen. le (exe -0-0> bllowin on of th -0-0> RSS	g exam ne ten r Show p	CMD colu g)> show rocesses HE al al al al al al al al al al al pple, show running pr rocesses PVT	umn), the process of	CMD Sysl plat trac rbcp ntp down supe dns back cli ssho	alth of og-ng form e aloade arthre aupres a memo the sci EXE	f the pro	ocess, a	nd the ne Ran %PVT	dom Access Memory (RAM	playeo
Examples	of the pr on the s se-Modu se-10-0 STATE online online online online online online online service In the for utilization se-10-0 VSZ 12680	creen. le (exe -0-0> bllowin on of th -0-0> RSS 1360	g exam ne ten r show p	CMD colu g)> show rocesses HE al al al al al al al al al al al pple, show running pr rocesses PVT 392	umn), the second	he hea sses CMD sysl plat trac rbcp ntp down supe dns back cli sshd sshd sshd sshd sson t y RW 0	alth of og-ng form e alloade erthre tupres the sci EXE 96	f the pro	ocess, a blays th STK 0	nd the ne Ran %PVT 0.1	dom Access Memory (RAM	playeo
Examples	of the pr on the s se-Modu se-10-0 STATE online online online online online online online online service In the for utilization se-10-0 VSZ 12680 22704	creen. le (exe -0-0> bllowin on of th -0-0> RSS 1360 1336	g exam ne ten r show p show p show p show p show p show p show p show p	g)> show rocesses HE al al al al al al al al al al pple, show running pr rocesses PVT 392 260	umn), the second	he head sses CMD sysl plat trac rbcp ntp down supe dns back cli sshd sshd sshd sshd sshd sshd sshd son t y RW 0 0	alth of og-ng form e aloade arthre tupres the sci EXE 96 64	f the pro	ocess, a plays th STK 0 0	the Ran %PVT 0.1 0.1	dom Access Memory (RAM Syslog-ng platform_config	playec
Examples	of the pr on the s se-Modu se-10-0 STATE online online online online online online online service In the for utilization se-10-0 VSZ 12680	creen. le (exe -0-0> blowin on of tl -0-0> RSS 1360 1336 1072	g exam be the formula g exam be formula g exam be the formula g exam be formula g exam formula g exam fo	CMD cold g)> show rocesses HE al al al al al al al al al al	umn), the second	he hea sses CMD sysl plat trac rbcp ntp down supe dns back cli sshd sshd sshd sshd sson t y RW 0	alth of og-ng form e alloade erthre aupres d memo the sci exe 96 64 28	f the pro	ocess, a blays th STK 0	the Ran %PVT 0.1 0.1 0.0	dom Access Memory (RAM	playec

2560	772	568	204	0	0	572	464	0	0.0	monitor	
23504	3808	1456	2352	0	0	20	13848	0	0.5	downloader	
18832	1364	1120	244	0	0	212	10812	0	0.0	ntp	
63660	17780	2324	15456	0	0	40	53424	0	3.0	superthread	l
63660	17780	2324	15456	0	0	40	53424	0	3.0	cli	
1972	616	524	92	0	0	28	496	0	0.0	sshd	
Proces	s Memor	y Info	ormatior	n for h	nellow	orld					
VSZ	RSS	SHI	R PV	/Τ	RD	RW	EXE		DAT	STK	CMD
1972	616	524	4 92	2	0	0	28		496	0	init
2244	872	704	1 16	58	0	0	92		572	0	syslog_ng
2500	1096	948	3 14	18	0	0	572		404	0	hello_world.sh
1948	532	450	5 76	5	0	0	8		492	0	logmgr
0	0	0	0		0	0	0		0	0	

In the following example, **show processes cpu** displays the CPU utilization of the the combined running processes on the screen.

 se-10-0-0-> show processes cpu

 Uptime (secs):
 1122639.02

 User time (secs):
 9834.87

 Kernel time (secs):
 11647.49

 Idle time (secs):
 1100952.01

 se-10-0-0-0>

Related Commands	Command	Description
	show tech-support	Displays a summary of the diagnostic information for the application.

```
Cisco Application eXtension Platform 1.0 Command Reference
```

show resource limits

To display a summary of the resource limits configuration, use the **show resource limits** command in Cisco AXP application service EXEC mode.

show resource limits

Syntax Description	This command has no ar	guments or keywords.
Defaults	No default behavior or v	alues.
Command Default	None.	
Command Modes	Cisco AXP application s	ervice EXEC.
Command History	Cisco AXP Version 1.0	Modification This command was introduced.
Examples	• •	e, show resource limits shows that for application mping, the CPU index value imit is 10 MB, disk limit is 10 MB, and log size limit is 5 MB.
	se-Module(exec-mping); APPLICATION CPU(INDEX) mping 1000	<pre>> show resource limits) MEMORY(MB) DISK(MB) LOG(MB) 10 10 5</pre>
Related Commands	Command	Description
	show tech-support	Displays diagnostic information for the application.

show running-config

To display the running configuration of the application environment, use the **show running-config** command in Cisco AXP application service EXEC mode.

show running-config

Syntax Description	This command has no arguments or keywords.	
Defaults	No default behavior or va	alues.
Command Default	None.	
Command Modes	Cisco AXP application se	ervice EXEC.
Command History	Cisco AXP Version 1.0	Modification This command was introduced.
Examples	<pre>In the following example mping on the screen. se-Module(exec-mping)> app-service mping bind interface eth0 hostname se-10-0-0-0 exit</pre>	s, show running-config displays the running configuration for the application show running-config
Related Commands	Command	Description
	show tech-support	Displays a summary of the diagnostic information for the application.

show ssh-server

To display the current status of the SSH server for a virtual instance, use the **show ssh-server** command in Cisco AXP application service EXEC mode.

show ssh-server

Syntax Description	This command has no arguments or keywords.		
Defaults	No default behavior or values.		
Command Default	None.		
Command Modes	Cisco AXP application service EXEC.		
Command History	Cisco AXP VersionModification1.0This command was introduced.		
Usage Guidelines	Use this command to display the status of the SSH server—either RUNNING or NOT RUNNING.		
Examples	In the following example, the status of the SSH server for the virtual instance of the application SYSLOG_APP1 is displayed on the screen. In this case the SSH server is RUNNING.		
	<pre>se-100-0-5-2> app-service SYSLOG_APP1 se-100-0-5-2(exec-SYSLOG_APP1)> show ssh-server Application SSH Server Status: RUNNING se-100-0-5-2(exec-SYSLOG_APP1)></pre>		

Related Commands	Command	Description
	ip ssh-server	Configures the SSH server.
	ip ssh username	Configures SSH tunneling.

show state

To display the status and health of a specific application, use the **show state** command in Cisco AXP application service EXEC mode.

show state

	There are no arguments or keywords for this command.		
Defaults No default behavior or values.			
Command Default None.			
Command Modes Cisco AXP application service EXEC.			
Command History Cisco AXP Version Modification			
1.0This command was introduced.			
Usage GuidelinesThe show state command displays the state and health as:• State: Online, Offline, Pending-online, Pending-offline.• Health: Alive, or Down.			
Examples In the following example, show state displays the state and health store on the screen. se-Module(exec-helloworld)> show state APPLICATION STATE HEALTH helloworld online ALIVE	se-Module(exec-helloworld)> show state APPLICATION STATE HEALTH		
Related Command Description			
show app-service state Displays a list of all the installed virtual in	nstances and applications.		
show tech-support Displays a summary of the diagnostic info	ormation for the application.		

show statistics

To display statistics for a virtual instance in the application environment, use the **show statistics** command in Cisco AXP application service EXEC mode.

show statistics

Command Default	None.		
Command Modes	Cisco AXP application service EXEC.		
Command History	Cisco AXP Version Modification		
	1.0This command was introduced.		
Usage Guidelines	The show statistics command displays statistics such as CPU utilization and memory for a virtual instance in the application environment.		
	The show statistics app command displays statistics of third party applications integrated into the application environment.		
	When this command is initiated, <i>/bin/appstats</i> is executed. The third party application must provide th <i>appstats</i> file, in binary or script format, to plug in for its statistics.		
Examples	In the following example, show statistics displays statistics for the environment of application "mping" on the screen.		
	se-Module(exec-mping)> show statistics CTX PROC VSZ RSS userTIME sysTIME UPTIME NAME 2 3 6.6M 2.5M 0m00s12 0m00s40 3h04m08 mping		
	CTX = context number for the virtual instance PROC = quantity of processes in the context VSZ = number of pages of virtual memory RSS = Resident set size limits for memory userTime = utime User-mode CPU time accumulated sysTIME = ctime Kernel-mode CPU time accumulated UPTIME = uptime NAME = application name		
Related Commands	Command Description		

show statistics app

To allow third party applications to integrate their own application statistics for display, use the **show statistics app** command in Cisco AXP application service EXEC mode.

show statistics app

Syntax Description	This command has no arguments or keywords.		
Defaults	No default behavior or	values.	
Command Default	None.		
Command Modes	Cisco AXP application	service EXEC.	
Command History	Cisco AXP Version	Modification This command was introduced.	
Usage Guidelines	When this command is initiated, <i>/bin/appstats</i> is executed which plugs in statistics that must be provided by the third party application using file <i>appstats</i> (in binary or script format).		
Related Commands	Command	Description	
	show statistics	Displays statistics for a virtual instance in the application environment.	

show status-monitor

To display parameters of the status monitor, use the **show status-monitor** command in Cisco AXP application service EXEC mode.

show status-monitor

Syntax Description	This command has no	arguments or keywords.
Command Default	None.	
Command Modes	Cisco AXP application	service EXEC.
Command History	Cisco AXP Version	Modification
	1.0	This command was introduced.

Examples

In the following example, the **show status-monitor** command displays the status of the status-monitor for the helloworld application.

```
se-Module(exec-helloworld)> show status-monitor
Application: helloworld
Monitor status: PASSED
Monitor in progress: Yes
Last executed watchdog: W00template.sh
Last executed date: Wed Sep 5 14:09:58 PDT 2007
Last failed watchdog: ---
Last failed return code: -
Last failed date: ---
Last restarted date: ---
Recovery threshold: 4
Monitor interval: 3
```

Table 10	show status-monitor Field Descriptions
----------	--

Field	Description
Monitor status	IP address of the NTP server.
	: Monitor has not been turned ON.
	Passed : Monitoring reports successful execution of watchdog scripts.
	Recover : Monitoring reports a watchdog failure, or the watchdog is taking longer than the monitor interval to return a value. The virtual instance restarts if the recovery threshold period is exceeded.

Related Commands	Command	Description
	show app-service state	Displays a list of all the installed virtual instances and applications.
	show tech-support	Displays a summary of the diagnostic information for the application.

show syslog-server logs

To display syslog server log files in the /var/remote log directory, use the **show syslog-server logs** command in Cisco AXP EXEC mode.

show syslog-server logs

Syntax Description	This command has no arguments or keywords.			
Defaults	No default behavior or values.			
Command Default	None.	None.		
Command Modes	Cisco AXP EXEC.			
Command History	Cisco AXP Version	Modification		
	1.0	This command was introduced.		
Usage Guidelines	This command displays	all the syslog files under /var/remote log directory.		
Examples	The following example illustrates the show syslog-server logs command that displays the size last modified date and time for each of the syslog files under the /var/remote log directory. In this case, there is only one syslog file: remote_messages.log.			
	se-Module> show syslc SIZE LAST_MODIFIED_ 62 Thu Oct 18 16:			
Related Commands	Command	Description		
	log level	Configures the severity of messages to be logged.		
	log trace	Configures trace logging options.		

show syslog-server log name

To display system level logging data for a specific log file, use the **show log name** command in Cisco AXP EXEC mode.

show syslog-server log name log-name { paged |||}

Syntax Description	log-name	Log name. See the show logs command for log names.		
		Displays in page mode.		
	I Pipes output to another command.			
Defaults	No default behavior or values.			
Command Default	None.			
Command Modes	Cisco AXP EXEC.			
Command History	Cisco AXP Version	Modification		
	1.0	This command was introduced.		
Examples	In the following example, show syslog-server log name displays system level logging data for log file remote_messages.log.			
	<pre>se-10-0-0-0> show Press <ctrl-c> to #!/bin/cat 16:37:22 logmgr: B 16:37:22 logmgr: S</ctrl-c></pre>	EGIN FILE		
Related Commands	Command	Description		
	show logs	Displays log files in the application environment or on the		

Cisco AXP service module.

Displays all the syslog files.

show syslog-server logs

show tech-support

To display diagnostic information about the application environment, use the **show tech-support** command in Cisco AXP application service EXEC mode.

show tech-support

Syntax Description	This command has no arguments or keywords.
Command Default	None.
Command Modes	Cisco AXP application service EXEC.
Command History	Cisco AXP VersionModification1.0This command was introduced.
Usage Guidelines	This command:
j.	• Dumps information to the screen provided by the third party application
	 Displays the running-config, state, resource limits, and statistics about the application environment
Examples	provided by the third-party application. In the following example, show tech-support displays diagnostic information for the application environment on the screen. This information includes: state, statistics, processes, resource limits, and running configuration.
	<pre>se-10-0-0(exec-helloworld)> show tech-support</pre>
	show app-service state APPLICATION STATE HEALTH helloworld online ALIVE
	show app-service statisticsCTXPROCVSZRSSuserTIMEUPTIME NAME01222.7G624.3M59m23s941h10m584d20h45root server248.6M2.9M1m16s661m31s314d20h43helloworld
	JSER PID %CPU %MEM VSZ RSS TTY STAT START TIME COMMAND root 1 0.0 0.1 1972 616 ? S Nov15 0:00 init [4] root 3758 0.0 0.1 2244 872 ? Ss Nov15 0:00 /usr/bin/syslog_ng root 3763 0.0 0.2 2500 1096 ? S Nov15 0:00 /bin/bash /opt/helloworld/hello_world.sh root 29302 0.0 0.1 1948 532 ? Ss 12:55 0:00 /bin/logmgr /var/log/messages.log 5000000 5000000 5000000 5000000 5000000 5000000

31016 0.0 0.1 2216 532 ? S 13:02 0:00 sleep 5 root ----- show resource limits -----APPLICATION CPU(INDEX) MEMORY(MB) DISK(MB) LOG(MB) 800 helloworld 10 20 5 ----- show running-config ------Generating running configuration: app-service helloworld bind interface eth0 hostname se-10-0-0-0 log level info exit

Related Commands

Command	Description
show resource limits	Displays a summary of the resource limits configuration.
show running-config	Displays the running configuration of the application environment.
show state	Displays the status and health of a specific application.
show statistics	Displays statistics for a virtual instance in the application environment.

show software

To display characteristics of the installed software, use the **show software** command in Cisco AXP EXEC mode.

show software {directory | download server | licenses | packages | versions}

Syntax Description	directory	Displays the software directory.
	download server	Displays the IP address of the FTP server.
	licenses	Displays the terms and limits of the purchased license for the system.
	packages	Displays the configured Cisco AXP application packages.
	versions	Displays the current versions of the configured software and applications.
Command Modes	Cisco AXP EXEC.	
	cisco mai LALC.	
0	<u> </u>	
Command History	Cisco AXP Version	Modification
	1.0	This command was introduced.
Examples	The following is samp	le output of the show software command:
	se-10-0-0-0> show s	oftware download server
	Download server URL	is: ftp://172.16.0.1/ftp
	se-10-0-0-0> show so	oftware licenses
	Core:	
	- application mode:	: AXP

```
se-10-0-0-> show software packages
Installed Packages:
 - Core (Integrated Voice Services - Core)
- Boot Loader (Service Engine Bootloader)
se-10-50-10-125> show software versions
Installed Packages:
Software Version: 3.0.1
 - Installer 3.0.1.0
 - Thirdparty 2.3.1.0
 - Bootloader (Primary) 2.1.14
 - Infrastructure 2.3.2.0
```

Related Commands	Command	Description
	show app-service	Displays statistics for installed applications.

```
Cisco Application eXtension Platform 1.0 Command Reference
```

show software directory

To display directory information for software download and downgrade files, use the **show software directory** command in Cisco AXP EXEC mode.

show software directory {download | downgrade}

Syntax Description	downgrade	lowngrade Displays downgrade directory information.				
	download	Displays dow	nload directory information.			
Command Modes	Cisco AXP EXEC.					
Command History	Cisco AXP Version	Modification				
-	1.0	This comman	nd was introduced.			
Examples	In the following example, the show software directory download command shows download directory information to the screen.					
	se-10-10-0-0> sho	w software dire	ctory download			
	KBytes Directory 27347 /dwnld/pk					
	Directory listings					
	Directory: /dwnld/pkgdata					
	total 27347					
	drwxrwxr-x 2 r drwxrwxr-x 4 r	oot daemon oot daemon	136 Oct 18 19:30 . 136 Oct 18 19:30			
		oot root	27857860 Oct 18 19:31 axp-upgrade.2.1			
	-rw-rw-r 1 r se-10-0-0-0>	oot root	113161 Oct 18 19:30 axp.2.1.pkg			
	In the following example, the show software directory downgrade command displays downgrade directory information to the screen.					
	se-172-16-0-0> sh	ow software dir	ectory downgrade			
	KBytes Directory 6154 /dwnld/dw					
	Directory listings					
	Directory: /dwnld	/dwngrade				
	total 6154					
		oot daemon oot daemon	184 Nov 3 17:22 . 360 Nov 3 17:22			
	-rw-rw-r 1 r		227 Oct 28 18:42 .uninstall_work_order			
	-rw-rw-r 1 r		6286628 Oct 28 18:42 add_files.fhdr			

drwxrwxr-x se-10-0-0-0>	2 root	daemon	48 Nov	3 17:22	tmp
Command		Description			
show app-serv	vice	Displays statis	tics for instal	led applie	cations.
show tech-sup	oport	Displays a sum	mary of the	diagnosti	c information for the application.
	command show app-ser	se-10-0-0>	se-10-0-0-0>CommandDescriptionshow app-serviceDisplays statistic	se-10-0-0-0>CommandDescriptionshow app-serviceDisplays statistics for instal	se-10-0-0>CommandDescriptionshow app-serviceDisplays statistics for installed applied

show startup-config

To display the current startup configuration, use the **show startup-config** command in Cisco AXP EXEC mode.

show startup-config [paged]

Syntax Description	paged	Displays enough output to fill the current viewing screen.		
Command Modes	Cisco AXP EXEC.			
Command History	Cisco AXP Version	Modification		
	1.0	This command was introduced.		
Usage Guidelines	This command displa	ays the startup configuration stored in flash memory.		
Examples	The following example example output from the show startup-config command shows the stored configuration on the screen.			
	se-10-0-0-0> show a	startup-config		
	! This adds all the !	e platform CLI commands		
	! hostname hostname se-10-0-0-	-0		
	! Domain Name ip domain-name loca	aldomain		
	! DNS Servers ip name-server 10.1	100.10.130		
	! Timezone Settings clock timezone Amer end			

Related	Commands
---------	----------

Command	Description
copy ftp	Copies network FTP server data to another location.
copy running-config	Copies the running configuration to another location.
copy startup-config	Copies the startup configuration to another location.
copy tftp	Copies network TFTP server data to another location.
erase startup-config	Deletes configuration data.
show running-config	Displays the running configuration.
write	Copies the running configuration to the startup configuration.

show system language

To display which language the system is configured to use and/or a list of the languages available, use the **show system language** command in Cisco AXP EXEC mode.

show system language {preferred | installed}

Syntax Description	installed	The languages that are available for use.
	preferred	The language the system is using.
Command Modes	Cisco AXP EXEC.	
Command History	Cisco AXP Version	Modification
	1.0	This command was introduced.
Examples	used by the system.	e shows that English is the system language preferred.
Examples		ystem language preferred
Related Commands	Command	Description
nonatou ooninanus	system language preferred	Configures the system language.

show trace buffer

To display a list of events in memory, use the show trace buffer command in Cisco AXP EXEC mode.

show trace buffer [containing string [long | short] | long [paged] | short [paged] | tail [number
 [long | short]]]

yntax Description	containing string	(Optional) Displays only events that match a search expression.
	long	(Optional) Displays expanded text for many error and return codes.
	short	(Optional) Displays hexadecimal codes.
	paged	(Optional) Displays the output a page at a time.
	tail	(Optional) Display the latest events as they occur.
	number	(Optional) Displays the most recent number of events.
ommand Modes	Cisco AXP EXEC.	
command History	Cisco AXP Version	Modification
	1.0	This command was introduced.
		monitor trace events set for debugging. Stop the output by pressing Ctrl-C e shows partial output from the show trace buffer command:
lsage Guidelines xamples		e shows partial output from the show trace buffer command:
-	The following exampl se-10-0-0- show t :	e shows partial output from the show trace buffer command: race buffer
-	The following exampl se-10-0-0-0> show t : Press <ctrl-c> to e:</ctrl-c>	e shows partial output from the show trace buffer command: race buffer
-	The following exampl se-10-0-0-0> show t : Press <ctrl-c> to e: 238 09/19 23:23:11.0 238 09/19 23:23:11.0</ctrl-c>	e shows partial output from the show trace buffer command: race buffer kit 041 TRAC TIMZ 0 UTC UTC 0 043 TRAC TIMZ 0 UTC UTC 0
-	The following exampl se-10-0-0-0> show t : Press <ctrl-c> to e: 238 09/19 23:23:11.0 238 09/19 23:23:11.0 800 09/19 23:28:04.1</ctrl-c>	e shows partial output from the show trace buffer command: race buffer kit 041 TRAC TIMZ 0 UTC UTC 0 043 TRAC TIMZ 0 UTC UTC 0 152 WFSP MISC 0 WFSysdbLimits::WFSysdbLimits hwModuleType=NM
-	The following exampl se-10-0-0-0> show t : Press <ctrl-c> to e: 238 09/19 23:23:11.0 238 09/19 23:23:11.0 800 09/19 23:28:04.1 800 09/19 23:28:04.1</ctrl-c>	e shows partial output from the show trace buffer command: race buffer kit 041 TRAC TIMZ 0 UTC UTC 0 043 TRAC TIMZ 0 UTC UTC 0
-	The following exampl se-10-0-0-> show t : Press <ctrl-c> to e: 238 09/19 23:23:11.0 238 09/19 23:23:11.0 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1 str = /sw/apps/wf/co</ctrl-c>	e shows partial output from the show trace buffer command: race buffer kit 041 TRAC TIMZ 0 UTC UTC 0 043 TRAC TIMZ 0 UTC UTC 0 152 WFSP MISC 0 WFSysdbLimits::WFSysdbLimits hwModuleType=NM 171 WFSP MISC 0 WFSysdbProp::getProp 171 WFSP MISC 0 keyName = limitsDir cnapps/limits
-	The following exampl se-10-0-0-> show t: Press <ctrl-c> to e: 238 09/19 23:23:11.0 238 09/19 23:23:11.0 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1 str = /sw/apps/wf/ca 800 09/19 23:28:04.1</ctrl-c>	e shows partial output from the show trace buffer command: race buffer kit 041 TRAC TIMZ 0 UTC UTC 0 043 TRAC TIMZ 0 UTC UTC 0 152 WFSP MISC 0 WFSysdbLimits::WFSysdbLimits hwModuleType=NM 171 WFSP MISC 0 WFSysdbProp::getProp 171 WFSP MISC 0 keyName = limitsDir cnapps/limits 197 WFSP MISC 0 WFSysdbProp::getNodeXml
-	The following exampl se-10-0-0-> show t: Press <ctrl-c> to e: 238 09/19 23:23:11.0 238 09/19 23:23:11.0 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1 str = /sw/apps/wf/ca 800 09/19 23:28:04.1</ctrl-c>	e shows partial output from the show trace buffer command: race buffer kit 041 TRAC TIMZ 0 UTC UTC 0 043 TRAC TIMZ 0 UTC UTC 0 152 WFSP MISC 0 WFSysdbLimits::WFSysdbLimits hwModuleType=NM 171 WFSP MISC 0 WFSysdbProp::getProp 171 WFSP MISC 0 keyName = limitsDir cnapps/limits 197 WFSP MISC 0 WFSysdbProp::getNodeXml 197 WFSP MISC 0 WFSysdbProp::getProp
-	The following exampl se-10-0-0-> show t: Press <ctrl-c> to e: 238 09/19 23:23:11.0 238 09/19 23:23:11.0 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1 str = /sw/apps/wf/cd 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1</ctrl-c>	e shows partial output from the show trace buffer command: race buffer kit 041 TRAC TIMZ 0 UTC UTC 0 043 TRAC TIMZ 0 UTC UTC 0 152 WFSP MISC 0 WFSysdbLimits::WFSysdbLimits hwModuleType=NM 171 WFSP MISC 0 WFSysdbProp::getProp 171 WFSP MISC 0 keyName = limitsDir cnapps/limits 197 WFSP MISC 0 WFSysdbProp::getNodeXml 197 WFSP MISC 0 WFSysdbProp::getProp 198 WFSP MISC 0 keyName = limits ="1.0" encoding="ISO-8859-1" standalone="yes"?> <attrlist> <a< td=""></a<></attrlist>
-	The following exampl se-10-0-0-> show t: Press <ctrl-c> to e: 238 09/19 23:23:11.0 238 09/19 23:23:11.0 800 09/19 23:28:04.1 800 09/19</ctrl-c>	e shows partial output from the show trace buffer command: race buffer kit 041 TRAC TIMZ 0 UTC UTC 0 043 TRAC TIMZ 0 UTC UTC 0 152 WFSP MISC 0 WFSysdbLimits::WFSysdbLimits hwModuleType=NM 171 WFSP MISC 0 WFSysdbProp::getProp 171 WFSP MISC 0 keyName = limitsDir cnapps/limits 197 WFSP MISC 0 WFSysdbProp::getNodeXml 197 WFSP MISC 0 WFSysdbProp::getProp 198 WFSP MISC 0 keyName = limits
-	The following exampl se-10-0-0-> show t: Press <ctrl-c> to e: 238 09/19 23:23:11.0 238 09/19 23:23:11.0 800 09/19 23:28:04.1 800 09/19</ctrl-c>	e shows partial output from the show trace buffer command: race buffer kit 041 TRAC TIMZ 0 UTC UTC 0 043 TRAC TIMZ 0 UTC UTC 0 152 WFSP MISC 0 WFSysdbLimits::WFSysdbLimits hwModuleType=NM 171 WFSP MISC 0 WFSysdbProp::getProp 171 WFSP MISC 0 keyName = limitsDir cnapps/limits 197 WFSP MISC 0 WFSysdbProp::getNodeXml 197 WFSP MISC 0 WFSysdbProp::getProp 198 WFSP MISC 0 keyName = limits ="1.0" encoding="ISO-8859-1" standalone="yes"?> <attrlist> <a NFIG" type="INT32" maxsize="4"> <node>limits</node></a </attrlist>
-	The following exampl se-10-0-0-> show t: 238 09/19 23:23:11.4 238 09/19 23:23:11.4 800 09/19 23:23:04.3 800 09/19 23:28:04.3 800 09/19 23:28:04.3 str = /sw/apps/wf/cd 800 09/19 23:28:04.3 800 09/19 23:28:04.3 800 09/19 23:28:04.3 800 09/19 23:28:04.3 str = xml version:<br ttrDecl purpose="COI _scripts <de: cl> <attrdecl 1.0"="" ?="" encoding="ISO-8859-1" purpose="COI
_scripts</attr></td><td><pre>e shows partial output from the show trace buffer command:
race buffer
kit
041 TRAC TIMZ 0 UTC UTC 0
043 TRAC TIMZ 0 UTC UTC 0
152 WFSP MISC 0 WFSysdbLimits::WFSysdbLimits hwModuleType=NM
171 WFSP MISC 0 WFSysdbProp::getProp
171 WFSP MISC 0 keyName = limitsDir
cnapps/limits
197 WFSP MISC 0 WFSysdbProp::getProp
198 WFSP MISC 0 WFSysdbProp::getProp
198 WFSP MISC 0 keyName = limits
=" standalone="yes"> <attrlist> <a NFIG" type="INT32" maxsize="4"> <node>limits NFIG" type="INT32" maxsize="4"> <node>limits </node></node></a </attrlist></attrdecl></de: 	
-	The following exampl se-10-0-0-0> show t: 238 09/19 23:23:11.4 238 09/19 23:23:11.4 238 09/19 23:23:11.4 800 09/19 23:28:04.3 800 09/19 23:28:04.3 str = /sw/apps/wf/cc 800 09/19 23:28:04.3 800 09/19 23:28:04.3 800 09/19 23:28:04.3 800 09/19 23:28:04.3 800 09/19 23:28:04.3 str = xml versions<br ttrDecl purpose="COI _scripts <dex cl> <attrdecl 1.0"="" ?="" encoding="ISO-8859-1" purpose="COI
tr>max_prompts</attr
attrDecl> </attrList</td><td><pre>e shows partial output from the show trace buffer command:
race buffer
kit
041 TRAC TIMZ 0 UTC UTC 0
043 TRAC TIMZ 0 UTC UTC 0
152 WFSP MISC 0 WFSysdbLimits::WFSysdbLimits hwModuleType=NM
171 WFSP MISC 0 WFSysdbProp::getProp
171 WFSP MISC 0 keyName = limitsDir
cnapps/limits
197 WFSP MISC 0 WFSysdbProp::getProp
198 WFSP MISC 0 WFSysdbProp::getProp
198 WFSP MISC 0 keyName = limits
=" standalone="yes"> <attrlist> <a NFIG" type="INT32" maxsize="4"> <node>limits NFIG" type="INT32" maxsize="4"> <node>limits </node></node></a </attrlist></attrdecl></dex 	
-	The following exampl se-10-0-0-0> show t: 238 09/19 23:23:11.4 238 09/19 23:23:11.4 800 09/19 23:23:04.3 800 09/19 23:28:04.3 800 09/19 23:28:04.3 str = /sw/apps/wf/cc 800 09/19 23:28:04.3 800 09/19 23:28:04.3 800 09/19 23:28:04.3 str = xml version:<br ttrDecl purpose="COI _scripts <de: cl> <attrdecl 1.0"="" ?="" encoding="ISO-8859-1" purpose="COI
tr>max_prompts</attr
attrDecl> </attrList
800 09/19 23:28:04.3</td><td><pre>e shows partial output from the show trace buffer command:
race buffer
kit
041 TRAC TIMZ 0 UTC UTC 0
043 TRAC TIMZ 0 UTC UTC 0
152 WFSP MISC 0 WFSysdbLimits::WFSysdbLimits hwModuleType=NM
171 WFSP MISC 0 WFSysdbProp::getProp
171 WFSP MISC 0 keyName = limitsDir
cnapps/limits
197 WFSP MISC 0 WFSysdbProp::getProp
198 WFSP MISC 0 WFSysdbProp::getProp
198 WFSP MISC 0 keyName = limits
=" standalone="yes"> <attrlist> <a NFIG" type="INT32" maxsize="4"> <node>limits NFIG" type="INT32" maxsize="4"> <node>limits </node></node></a </attrlist></attrdecl></de: 	

Related Commands

Command	Description
show logs	Displays a list of the log files.

show trace store

To display a list of events from the atrace.log file, use the **show trace store** command in Cisco AXP EXEC mode.

show trace store [containing string [long | short] | long [paged] | short [paged] | tail [number
 [long | short]]]

untax Description		
Syntax Description	containing string	(Optional) Displays only events that match a search expression.
	long	(Optional) Displays expanded text for many error and return codes
	short	(Optional) Displays hexadecimal codes.
	paged	(Optional) Displays the output a page at a time.
	tail	(Optional) Display events as they occur.
	number	(Optional) Displays the most recent <i>number</i> of events.
command Modes	Cisco AXP EXEC.	
Command History	Cisco AXP Version	Modification
-	1.0	This command was introduced.
Examples	The following example	e shows partial output from the show trace store command:
Examples	The following example se-10-0-0-0> show t	
Examples	se-10-0-0-0> show tu Press <ctrl-c> to ex</ctrl-c>	race store xit
Examples	se-10-0-0-0> show tr Press <ctrl-c> to er 238 09/19 23:23:11.(</ctrl-c>	race store xit 043 TRAC TIMZ 0 UTC UTC 0
Examples	se-10-0-0-0> show tr Press <ctrl-c> to es 238 09/19 23:23:11.0 800 09/19 23:28:04.1</ctrl-c>	race store xit
Examples	se-10-0-0-0> show tr Press <ctrl-c> to ex 238 09/19 23:23:11.0 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1</ctrl-c>	race store kit 043 TRAC TIMZ 0 UTC UTC 0 152 WFSP MISC 0 WFSysdbLimits::WFSysdbLimits hwModuleType=NM 171 WFSP MISC 0 WFSysdbProp::getProp 171 WFSP MISC 0 keyName = limitsDir
ixamples	se-10-0-0-0> show tr Press <ctrl-c> to ex 238 09/19 23:23:11.0 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1 str = /sw/apps/wf/cc</ctrl-c>	race store kit 043 TRAC TIMZ 0 UTC UTC 0 152 WFSP MISC 0 WFSysdbLimits::WFSysdbLimits hwModuleType=NM 171 WFSP MISC 0 WFSysdbProp::getProp 171 WFSP MISC 0 keyName = limitsDir cnapps/limits
xamples	se-10-0-0-0> show tr Press <ctrl-c> to ex 238 09/19 23:23:11.0 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1 str = /sw/apps/wf/cc 800 09/19 23:28:04.1</ctrl-c>	race store kit 043 TRAC TIMZ 0 UTC UTC 0 152 WFSP MISC 0 WFSysdbLimits::WFSysdbLimits hwModuleType=NM 171 WFSP MISC 0 WFSysdbProp::getProp 171 WFSP MISC 0 keyName = limitsDir
xamples	se-10-0-0-> show tr Press <ctrl-c> to ex 238 09/19 23:23:11.0 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1 str = /sw/apps/wf/cc 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1</ctrl-c>	<pre>race store kit 043 TRAC TIMZ 0 UTC UTC 0 152 WFSP MISC 0 WFSysdbLimits::WFSysdbLimits hwModuleType=NM 171 WFSP MISC 0 WFSysdbProp::getProp 171 WFSP MISC 0 keyName = limitsDir cnapps/limits 197 WFSP MISC 0 WFSysdbProp::getNodeXml 197 WFSP MISC 0 WFSysdbProp::getProp 198 WFSP MISC 0 keyName = limits</pre>
ixamples	<pre>se-10-0-0-0> show tr Press <ctrl-c> to ex 238 09/19 23:23:11.0 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1 str = /sw/apps/wf/cc 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1 str = <?xml version=</pre></ctrl-c></pre>	<pre>race store kit 043 TRAC TIMZ 0 UTC UTC 0 152 WFSP MISC 0 WFSysdbLimits::WFSysdbLimits hwModuleType=NM 171 WFSP MISC 0 WFSysdbProp::getProp 171 WFSP MISC 0 keyName = limitsDir cnapps/limits 197 WFSP MISC 0 WFSysdbProp::getNodeXml 197 WFSP MISC 0 WFSysdbProp::getProp 198 WFSP MISC 0 keyName = limits ="1.0" encoding="ISO-8859-1" standalone="yes"?> <attrlist> <a< pre=""></a<></attrlist></pre>
xamples	<pre>se-10-0-0-> show tr Press <ctrl-c> to ex 238 09/19 23:23:11.0 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1 str = /sw/apps/wf/cc 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1 str = <?xml version= ttrDecl purpose="CON"</ctrl-c></pre>	<pre>race store kit 043 TRAC TIMZ 0 UTC UTC 0 152 WFSP MISC 0 WFSysdbLimits::WFSysdbLimits hwModuleType=NM 171 WFSP MISC 0 WFSysdbProp::getProp 171 WFSP MISC 0 keyName = limitsDir cnapps/limits 197 WFSP MISC 0 WFSysdbProp::getNodeXml 197 WFSP MISC 0 WFSysdbProp::getProp 198 WFSP MISC 0 keyName = limits</pre>
Examples	<pre>se-10-0-0-> show tr Press <ctrl-c> to ex 238 09/19 23:23:11.0 800 09/19 23:28:04.1 800 09/19 23:28:04.1 str = <?xml version= ttrDecl purpose="COM _scripts <des cl> <attrdecl pre="" purpose<=""></attrdecl></des </ctrl-c></pre>	<pre>race store kit 043 TRAC TIMZ 0 UTC UTC 0 152 WFSP MISC 0 WFSysdbLimits::WFSysdbLimits hwModuleType=NM 171 WFSP MISC 0 WFSysdbProp::getProp 171 WFSP MISC 0 keyName = limitsDir cnapps/limits 197 WFSP MISC 0 WFSysdbProp::getNodeXml 197 WFSP MISC 0 WFSysdbProp::getProp 198 WFSP MISC 0 keyName = limits ="1.0" encoding="ISO-8859-1" standalone="yes"?> <attrlist> <node>limits</node> NFIG" type="INT32" maxsize="4"> <node>limits </node></attrlist></pre>
Examples	<pre>se-10-0-0-> show tr Press <ctrl-c> to ex 238 09/19 23:23:11.0 800 09/19 23:28:04.1 800 09/19 23:28:04.1 str = <?xml version= ttrDecl purpose="COM _scripts <des cl> <attrdecl pre="" purpose<=""></attrdecl></des </ctrl-c></pre>	<pre>race store kit 043 TRAC TIMZ 0 UTC UTC 0 152 WFSP MISC 0 WFSysdbLimits::WFSysdbLimits hwModuleType=NM 171 WFSP MISC 0 WFSysdbProp::getProp 171 WFSP MISC 0 keyName = limitsDir cnapps/limits 197 WFSP MISC 0 WFSysdbProp::getNodeXml 197 WFSP MISC 0 WFSysdbProp::getProp 198 WFSP MISC 0 keyName = limits ="1.0" encoding="ISO-8859-1" standalone="yes"?> <attrlist> <node>limits</node> NFIG" type="INT32" maxsize="4"> <node>limits </node></attrlist></pre>
Examples	<pre>se-10-0-0> show tr Press <ctrl-c> to ex 238 09/19 23:23:11.0 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1 str = /sw/apps/wf/cc 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1 str = <?xml version= ttrDecl purpose="CON _scripts <des cl> <attrdecl purpos<br="">tr>max_promptsattrDecl> 800 09/19 23:28:04.1</attrdecl></des </ctrl-c></pre>	<pre>race store kit 043 TRAC TIMZ 0 UTC UTC 0 152 WFSP MISC 0 WFSysdbLimits::WFSysdbLimits hwModuleType=NM 171 WFSP MISC 0 WFSysdbProp::getProp 171 WFSP MISC 0 keyName = limitsDir cnapps/limits 197 WFSP MISC 0 WFSysdbProp::getNodeXml 197 WFSP MISC 0 WFSysdbProp::getProp 198 WFSP MISC 0 keyName = limits ="1.0" encoding="ISO-8859-1" standalone="yes"?> <attrlist> <node>limits</node> NFIG" type="INT32" maxsize="4"> <node>limits </node></attrlist></pre>
Examples	<pre>se-10-0-0-> show tr Press <ctrl-c> to ex 238 09/19 23:23:11.0 800 09/19 23:28:04.1 800 09/19 23:28:04.1 str = <?xml version= ttrDecl purpose="CON _scripts <des cl> <attrdecl purpose<br="">tr>max_promptsattrDecl> </attrdecl></des </ctrl-c></pre>	<pre>race store kit 243 TRAC TIMZ 0 UTC UTC 0 152 WFSP MISC 0 WFSysdbLimits::WFSysdbLimits hwModuleType=N 171 WFSP MISC 0 WFSysdbProp::getProp 171 WFSP MISC 0 keyName = limitsDir cnapps/limits 197 WFSP MISC 0 WFSysdbProp::getNodeXml 197 WFSP MISC 0 WFSysdbProp::getProp 198 WFSP MISC 0 keyName = limits ="1.0" encoding="ISO-8859-1" standalone="yes"?> <attrlist> NFIG" type="INT32" maxsize="4"> <node>limits sc>maximum number of scripts <value>0</value> <node>limits </node></node></attrlist></pre>

Related Commands

Command	Description
show logs	Displays a list of the log files.

show trace store-prev

To display a list of events from the atrace.log.prev file, use the **show trace store-prev** command in Cisco AXP EXEC mode.

show trace store-prev [containing string [long | short] | long [paged] | short [paged] | tail
 [number [long | short]]]

ax Description	containing string	(Optional) Display only events that match a search expression.
	long	(Optional) Displays expanded text for many error and return codes.
	short	(Optional) Displays hexadecimal codes.
	paged	(Optional) Displays the output a page at a time.
	tail	(Optional) Display the latest events as they occur.
	number	(Optional) Displays the most recent <i>number</i> of events.
mand Modes	Cisco AXP EXEC.	
Command History	Cisco AXP Version	Modification
	1.0	This command was introduced.
je Guidelines nples		monitor trace events set for debugging. e shows partial output from the show trace store-prev command:
		e shows partial output from the show trace store-prev command:
	The following exampl se-10-0-0-> show t	e shows partial output from the show trace store-prev command: race store-prev
	The following exampl se-10-0-0-0> show t Press <ctrl-c> to ex</ctrl-c>	e shows partial output from the show trace store-prev command: race store-prev
	The following exampl se-10-0-0-0> show t Press <ctrl-c> to ex 238 09/19 23:23:11.0 238 09/19 23:23:11.0</ctrl-c>	e shows partial output from the show trace store-prev command: race store-prev xit 041 TRAC TIMZ 0 UTC UTC 0 043 TRAC TIMZ 0 UTC UTC 0
	The following example se-10-0-0-0> show t Press <ctrl-c> to ex 238 09/19 23:23:11.0 238 09/19 23:23:11.0 800 09/19 23:28:04.2</ctrl-c>	e shows partial output from the show trace store-prev command: race store-prev xit 041 TRAC TIMZ 0 UTC UTC 0 043 TRAC TIMZ 0 UTC UTC 0 152 WFSP MISC 0 WFSysdbLimits::WFSysdbLimits hwModuleType=NM
	The following example se-10-0-0-0> show tr Press <ctrl-c> to er 238 09/19 23:23:11.0 238 09/19 23:23:11.0 800 09/19 23:28:04.1 800 09/19 23:28:04.1</ctrl-c>	e shows partial output from the show trace store-prev command: race store-prev xit 041 TRAC TIMZ 0 UTC UTC 0 043 TRAC TIMZ 0 UTC UTC 0 152 WFSP MISC 0 WFSysdbLimits::WFSysdbLimits hwModuleType=NM 171 WFSP MISC 0 WFSysdbProp::getProp 171 WFSP MISC 0 keyName = limitsDir
	The following example se-10-0-0-0> show tr Press <ctrl-c> to er 238 09/19 23:23:11.0 238 09/19 23:23:11.0 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1 str = /sw/apps/wf/co</ctrl-c>	e shows partial output from the show trace store-prev command: race store-prev xit 041 TRAC TIMZ 0 UTC UTC 0 043 TRAC TIMZ 0 UTC UTC 0 152 WFSP MISC 0 WFSysdbLimits::WFSysdbLimits hwModuleType=NM 171 WFSP MISC 0 WFSysdbProp::getProp 171 WFSP MISC 0 keyName = limitsDir cnapps/limits
	The following example se-10-0-0-> show tr Press <ctrl-c> to er 238 09/19 23:23:11.0 238 09/19 23:23:11.0 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1 str = /sw/apps/wf/co 800 09/19 23:28:04.1</ctrl-c>	e shows partial output from the show trace store-prev command: race store-prev xit 041 TRAC TIMZ 0 UTC UTC 0 043 TRAC TIMZ 0 UTC UTC 0 152 WFSP MISC 0 WFSysdbLimits::WFSysdbLimits hwModuleType=NM 171 WFSP MISC 0 WFSysdbProp::getProp 171 WFSP MISC 0 keyName = limitsDir
	The following example se-10-0-0-> show tr Press <ctrl-c> to er 238 09/19 23:23:11.0 238 09/19 23:23:11.0 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1 str = /sw/apps/wf/co 800 09/19 23:28:04.1 800 09/19 23:28:04.1</ctrl-c>	e shows partial output from the show trace store-prev command: race store-prev xit 041 TRAC TIMZ 0 UTC UTC 0 043 TRAC TIMZ 0 UTC UTC 0 152 WFSP MISC 0 WFSysdbLimits::WFSysdbLimits hwModuleType=NM 171 WFSP MISC 0 WFSysdbProp::getProp 171 WFSP MISC 0 keyName = limitsDir cnapps/limits 197 WFSP MISC 0 WFSysdbProp::getNodeXml 197 WFSP MISC 0 WFSysdbProp::getProp 198 WFSP MISC 0 keyName = limits
	The following example se-10-0-0-0> show tr Press <ctrl-c> to er 238 09/19 23:23:11.0 238 09/19 23:23:11.0 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1 str = /sw/apps/wf/cc 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1</ctrl-c>	e shows partial output from the show trace store-prev command: race store-prev xit 041 TRAC TIMZ 0 UTC UTC 0 043 TRAC TIMZ 0 UTC UTC 0 152 WFSP MISC 0 WFSysdbLimits::WFSysdbLimits hwModuleType=NM 171 WFSP MISC 0 WFSysdbProp::getProp 171 WFSP MISC 0 keyName = limitsDir cnapps/limits 197 WFSP MISC 0 WFSysdbProp::getNodeXml 197 WFSP MISC 0 WFSysdbProp::getProp 198 WFSP MISC 0 keyName = limits ="1.0" encoding="ISO-8859-1" standalone="yes"?> <attrlist> <a< td=""></a<></attrlist>
	The following example se-10-0-0-0> show tr Press <ctrl-c> to er 238 09/19 23:23:11.0 238 09/19 23:23:11.0 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1 str = /sw/apps/wf/cc 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1 str = <?xml versions ttrDecl purpose="COM_scripts</ctrl-c>	e shows partial output from the show trace store-prev command: race store-prev xit 041 TRAC TIMZ 0 UTC UTC 0 043 TRAC TIMZ 0 UTC UTC 0 152 WFSP MISC 0 WFSysdbLimits::WFSysdbLimits hwModuleType=NM 171 WFSP MISC 0 WFSysdbProp::getProp 171 WFSP MISC 0 keyName = limitsDir cnapps/limits 197 WFSP MISC 0 WFSysdbProp::getNodeXml 197 WFSP MISC 0 WFSysdbProp::getProp 198 WFSP MISC 0 keyName = limits ="1.0" encoding="ISO-8859-1" standalone="yes"?> <attrlist> <a NFIG" type="INT32" maxsize="4"> <node>limits//value> </node></a </attrlist>
	The following example se-10-0-0-> show tr Press <ctrl-c> to er 238 09/19 23:23:11.0 238 09/19 23:23:11.0 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1 str = /sw/apps/wf/cc 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1 str = <?xml versioner ttrDecl purpose="COM_scripts <der< td=""><td>e shows partial output from the show trace store-prev command: race store-prev xit 041 TRAC TIMZ 0 UTC UTC 0 043 TRAC TIMZ 0 UTC UTC 0 152 WFSP MISC 0 WFSysdbLimits::WFSysdbLimits hwModuleType=NM 171 WFSP MISC 0 WFSysdbProp::getProp 171 WFSP MISC 0 keyName = limitsDir cnapps/limits 197 WFSP MISC 0 WFSysdbProp::getNodeXml 197 WFSP MISC 0 WFSysdbProp::getProp 198 WFSP MISC 0 keyName = limits ="1.0" encoding="ISO-8859-1" standalone="yes"?> <attrlist> <a NFIG" type="INT32" maxsize="4"> <node>limits sc>maximum number of scripts <value>0</value> se="CONFIG" type="INT32" maxsize="4"> <node>limits</node></node></a </attrlist></td></der<></ctrl-c>	e shows partial output from the show trace store-prev command: race store-prev xit 041 TRAC TIMZ 0 UTC UTC 0 043 TRAC TIMZ 0 UTC UTC 0 152 WFSP MISC 0 WFSysdbLimits::WFSysdbLimits hwModuleType=NM 171 WFSP MISC 0 WFSysdbProp::getProp 171 WFSP MISC 0 keyName = limitsDir cnapps/limits 197 WFSP MISC 0 WFSysdbProp::getNodeXml 197 WFSP MISC 0 WFSysdbProp::getProp 198 WFSP MISC 0 keyName = limits ="1.0" encoding="ISO-8859-1" standalone="yes"?> <attrlist> <a NFIG" type="INT32" maxsize="4"> <node>limits sc>maximum number of scripts <value>0</value> se="CONFIG" type="INT32" maxsize="4"> <node>limits</node></node></a </attrlist>
	The following example se-10-0-0-> show tr Press <ctrl-c> to er 238 09/19 23:23:11.0 238 09/19 23:23:11.0 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1 str = /sw/apps/wf/cc 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1 str = <?xml versioner ttrDecl purpose="COM_scripts <der< td=""><td>e shows partial output from the show trace store-prev command: race store-prev kit 041 TRAC TIMZ 0 UTC UTC 0 043 TRAC TIMZ 0 UTC UTC 0 152 WFSP MISC 0 WFSysdbLimits::WFSysdbLimits hwModuleType=NM 171 WFSP MISC 0 WFSysdbProp::getProp 171 WFSP MISC 0 keyName = limitsDir cnapps/limits 197 WFSP MISC 0 WFSysdbProp::getNodeXml 197 WFSP MISC 0 WFSysdbProp::getProp 198 WFSP MISC 0 keyName = limits ="1.0" encoding="ISO-8859-1" standalone="yes"?> <attrlist> <a NFIG" type="INT32" maxsize="4"> <node>limits NFIG" type="INT32" maxsize="4"> <node>limits</node></node></a </attrlist></td></der<></ctrl-c>	e shows partial output from the show trace store-prev command: race store-prev kit 041 TRAC TIMZ 0 UTC UTC 0 043 TRAC TIMZ 0 UTC UTC 0 152 WFSP MISC 0 WFSysdbLimits::WFSysdbLimits hwModuleType=NM 171 WFSP MISC 0 WFSysdbProp::getProp 171 WFSP MISC 0 keyName = limitsDir cnapps/limits 197 WFSP MISC 0 WFSysdbProp::getNodeXml 197 WFSP MISC 0 WFSysdbProp::getProp 198 WFSP MISC 0 keyName = limits ="1.0" encoding="ISO-8859-1" standalone="yes"?> <attrlist> <a NFIG" type="INT32" maxsize="4"> <node>limits NFIG" type="INT32" maxsize="4"> <node>limits</node></node></a </attrlist>
	The following example se-10-0-0-0> show tr Press <ctrl-c> to er 238 09/19 23:23:11.0 238 09/19 23:23:11.0 800 09/19 23:28:04.1 800 09/19 23:28:04.1 str = /sw/apps/wf/cc 800 09/19 23:28:04.1 800 09/19 23:28:04.1 800 09/19 23:28:04.1 str = <?xml version: ttrDecl purpose="COI _scripts <des cl> <attrdecl coi<br="" purpose="COI
_scripts</attr> <des
cl> <attrDecl purpose=">_scripts </attrdecl>_scripts </des </attrdecl>_scripts </des </attrdecl>attrDecl purpose="COI _scripts </des </attrdecl>attrDecl purpose="coil">attrDecl purpose="coil"</des </attrdecl></des </attrdecl></des </attrdecl></des </attrdecl></des </ctrl-c>	e shows partial output from the show trace store-prev command: race store-prev kit 041 TRAC TIMZ 0 UTC UTC 0 043 TRAC TIMZ 0 UTC UTC 0 152 WFSP MISC 0 WFSysdbLimits::WFSysdbLimits hwModuleType=NM 171 WFSP MISC 0 WFSysdbProp::getProp 171 WFSP MISC 0 keyName = limitsDir cnapps/limits 197 WFSP MISC 0 WFSysdbProp::getNodeXml 197 WFSP MISC 0 WFSysdbProp::getProp 198 WFSP MISC 0 keyName = limits ="1.0" encoding="ISO-8859-1" standalone="yes"?> <attrlist> <a NFIG" type="INT32" maxsize="4"> <node>limits NFIG" type="INT32" maxsize="4"> <node>limits</node></node></a </attrlist>
Related Commands	Command	Description
-------------------------	------------------	---
	show logs	Displays a list of the log files.
	show trace store	Displays a list of events from the atrace.log file.

show version

To display versions of Cisco AXP components, use the **show version** command in Cisco AXP EXEC mode.

show version

Syntax Description This command has no arguments or keywords.

Command Modes Cisco AXP EXEC.

 Command History
 Cisco AXP Version
 Modification

 1.0
 This command was introduced.

Usage Guidelines This command displays a list of the installed Cisco AXP hardware components with their versions and serial numbers.

Examples

The following example shows the displayed details from the **show version** command, containing Cisco AXP network module details.

```
se-10-1-1-20> show version
se-10-1-1-20 uptime is 0 weeks, 0 days, 20 hours, 0 minutes
CPU Model:
                              Intel(R) Celeron(R) M processor
                                                                        1.00GHz
                              1000.192
CPU Speed (MHz):
CPU Cache (KByte):
                              512
BogoMIPS:
                              2002.02
SKU:
                              NME-APPRE-302-K9
Chassis Type:
                              C2821
Chassis Serial:
                              FHK0945F1TA
Module Type:
                              NME
Module Serial:
                              FOC10480BFM
UDI Name:
                              Not Available
                              Not Available
UDI Description:
                               64MB
IDE Drive:
SATA Drive:
                               80.0GB
SDRAM (MByte):
                               512
```

Table 11 describes the significant fields shown in the display.

Table 11	show version Field Descriptions
----------	---------------------------------

Field	Description
CPU Model	Model of the Cisco AXP service module CPU.
CPU Speed (MHz)	CPU speed, in MHz.
CPU Cache (KByte)	Size of the CPU cache, in KB.
Chassis Type	Type of chassis of the Cisco AXP service module.

	Field	Description
	Chassis Serial	Serial number of the chassis.
	Module Type	A Cisco Network Module (NM), or a Cisco Advanced Integration Module (AIM).
	Module Serial	Serial number of the Cisco AXP service module.
	SATA Drive	Hard Drive on the Cisco AXP service module.
	SKU	Unique ordering identifier for a Cisco AXP module.
Related Commands	Command	Description
	show software	Displays the version numbers of the installed Cisco AXP software components.

Table 11 show version Field Descriptions (continued)

software download abort

To abort a download that is in progress, use the **software download abort** command in Cisco AXP EXEC mode.

software download abort

Syntax Description This command has no arguments or keywords. **Command Modes** Cisco AXP EXEC. **Command History Cisco AXP Version** Modification This command was introduced. 1.0 **Examples** The following is an example of downloading a software package to install later where the FTP server information is included on the command line. se-10-0-0-0> software download abort Download request aborted. **Related Commands** Command Description software download clean Downloads a complete package to install later. software download status Reports the status of a download in progress. software download upgrade Downloads an upgrade package to install later.

software download clean

To download software packages for installing later, use the **software download clean** command in Cisco AXP EXEC mode.

software download clean {*package-file-name* | **url ftp:**//*ftp-server-ip-address*/*package-file-name*}

Syntax Description	package-file-name	Name of the package file for the new software.	
	url ftp://ftp-server-ip-address	URL of the FTP server.	
Command Modes	Cisco AXP EXEC.		
Command History	Cisco AXP Version	Modification	
	1.0	This command was introduced.	
Examples	The following is an example of downloading a software package to install later where the FTP server information has been set in the configuration.		
	se-172-16-0-0> software download clean axp-abc.2.0.1.pkg		
	The following is an example of downloading a software package to install later where the FTP server information is included on the command line.		
	se-10-16-0-0> software download clean url ftp://10.16.0.2/axp-abc.2.0.1.pkg		
	WARNING:: This command will download the necessary software to WARNING:: complete a clean install. It is recommended that a backup be done WARNING:: before installing software.		
	Would you like to continue? [:	n] y	
	Downloading axp-abc.2.0.1.pk Bytes downloaded : 63648	g	
	Validating package signature	done	
	> x [17488 refs] se-10-0-0-0>		
	The following is an example of usi progress.	ing the software download status command to check on the download	
	se-172-16-0-0> software downl	oad status	
	Download request in progress. downloading file : axp-abc.2. bytes downloaded : 5536224	0.prt1	

Related Commands	Command	Description
	software download abort	Aborts a download that is in progress.
	software download status	Reports the status of a download in progress.
	software download upgrade	Downloads an upgrade package to install later.

software download server

To configure the FTP server address on the Cisco AXP service module, use the **software download server** command in Cisco AXP configuration mode.

software download server url ftp://server-ip-address[/dir] [**username** username **password** password | **credentials** hidden credentials]

Syntax Description	url ftp://server-ip-address	IP address of the FTP server.	
	<i>Idir</i>	(Optional) The FTP directory on the server.	
	username username	(Optional) Specifies the FTP username. If this option is not used, the default is "anonymous".	
	password password	(Optional) Specifies the FTP password.	
	credentials hidden credentials	(Optional) Specifies the encrypted username and password value.	
Command Modes	Cisco AXP configuration.		
Command History	Cisco AXP Version	Modification	
	1.0	This command was introduced.	
Examples	se-10-16-0-0(config)> software	tting the server information with just a root directory. a download server url ftp://10.19.0.0/ tting the server information with a directory different than the root	
	se-10-16-0-0(config)> software	a download server url ftp://10.19.0.0/ftp_dir	
	The following is an example of setting the server information with a username and password.		
	se-10-16-0-0(config)> software ftpuser password ftppassword	e download server url ftp://10.19.0.0/ftp_dir username	
	ftpuser password ftppassword		
Related Commands		a download server url ftp://10.19.0.0/ftp_dir username Description Displays the FTP server information.	

software download status

To display the progress of a software download, use the **software download status** command in Cisco AXP EXEC mode.

software download status

Syntax Description This command has no arguments or keywords.

Command Modes Cisco AXP EXEC.

 Command History
 Cisco AXP Version
 Modification

 1.0
 This command was introduced.

Examples The following is an example of a download in progress:

se-10-0-0-0> software download status

Download request in progress. downloading file : axp-abc.2.0.1.prt1 bytes downloaded : 5536224

The following is an example of a download that has completed:

se-10-0-0-0> software download status

Download request completed successfully.

Related Commands	Command	Description
	software download abort	Aborts a download that is in progress.
	software download clean	Downloads a complete package to install later.
	software download upgrade	Downloads an upgrade package to install later.

software download upgrade

To download software for a later upgrade, use the **software download upgrade** command in Cisco AXP EXEC mode.

software download upgrade {package-filename |

url ftp://*ftp-server-ip-address*[/*dir*]/*package-filename*} [**username** *username* **password** *password*]

Syntax Description	package-filename	Name of the package file for the new software.
	url ftp://ftp-server-ip-address	URL of the FTP server.
	ldir	(Optional) Directory other than the default.
	username username	(Optional) Username for the FTP server.
	password password	(Optional) Password for the FTP server.
Command Modes	Cisco AXP EXEC.	
Command History	Cisco AXP Version	Modification
	1.0	This command was introduced.
	se-10-0-0-0> software downloa	d upgrade axp-abc.2.1.pkg
	information is included on the con	ownloading a software package to upgrade later where the FTP server nmand line. The username and password could also be included in this
	information is included on the cor command.	nmand line. The username and password could also be included in this
	information is included on the cor command.	
	information is included on the con- command. se-10-0-0-> software download WARNING:: This command will do	nmand line. The username and password could also be included in thi d upgrade url ftp://10.16.0.1/axp-abc.2.1.pkg ownload the necessary software to . It is recommended that a backup be done
	<pre>information is included on the cor command. se-10-0-0-0> software download WARNING:: This command will d WARNING:: complete an upgrade WARNING:: before installing so Would you like to continue? [: url_host :10.16.0.1</pre>	nmand line. The username and password could also be included in thi d upgrade url ftp://10.16.0.1/axp-abc.2.1.pkg ownload the necessary software to . It is recommended that a backup be done oftware.
	<pre>information is included on the cor command. se-10-0-0-0> software download WARNING:: This command will de WARNING:: complete an upgrade WARNING:: before installing se Would you like to continue? [: url_host :10.16.0.1 url_user :null url_uname :anonymous url_psword :anonymous</pre>	nmand line. The username and password could also be included in thi d upgrade url ftp://10.16.0.1/axp-abc.2.1.pkg ownload the necessary software to . It is recommended that a backup be done oftware.
	<pre>information is included on the corr command. se-10-0-0-0> software download WARNING:: This command will de WARNING:: complete an upgrade WARNING:: before installing se Would you like to continue? [: url_host :10.16.0.1 url_user :null url_uname :anonymous</pre>	nmand line. The username and password could also be included in thi d upgrade url ftp://10.16.0.1/axp-abc.2.1.pkg ownload the necessary software to . It is recommended that a backup be done oftware. n] y

```
Bytes downloaded : 63648
Validating package signature ... done
Validating installed manifests .....complete.
[17497 refs]
```

<u>Note</u>

When you download the software, there are no other prompts for subscriber input. The software package is downloaded to the service module.

The following is an example of using the **software download status** command to check on the download progress.

se-10-0-0-0> software download status

Download request in progress. downloading file : axp-abc.2.1.prt1 bytes downloaded : 5536224

se-10-0-0-0> software download status

Download request completed successfully.

The following is an example of using the **show software directory download** to determine if a download has been successful:

```
se-10-10-0-0> show software directory download
```

KBytes Directory 0 /dwnld/pkgdata Directory listings Directory: /dwnld/pkgdata total 0 drwxrwxr-x 2 root daemon 48 Sep 15 2007 . drwxrwxr-x 4 root daemon 200 Sep 15 2007 .

Related Commands

;	Command	Description	
software download abort Aborts a downl		Aborts a download that is in progress.	
	software download status	Reports the status of a download in progress.	
show software directory Displays directory downgrades.		Displays directory information for software downloads and downgrades.	

software install add

To install add-on packageson the Cisco AXP service module, use the **software install add** command in Cisco AXP EXEC mode.

software install add {*package-filename* | **url ftp:**//*ftp-server-ip-address*/*package-filename*}

Syntax Description	package-filename	Name of the add-on package file.
	url ftp://ftp-server-ip-address	URL address of the FTP server where the package is located.
Command Modes	Cisco AXP EXEC.	
Command History	Cisco AXP Version	Modification
	1.0	This command was introduced.
Usage Guidelines	Use this command to install ad	d-on packages.
	1	ackages, see the latest Cisco AXP release notes by clicking General a of the Cisco AXP documentation page.
Examples	The following is an example of FTP server information was server	the command to install a new version of Cisco AXP software where the t in the configuration.
	se-10-16-0-0> software inst	all add axp-eemapi.aim.1.0.5.pkg
	The following is an example of information is included in the context.	f installing a new version of Cisco AXP software where the FTP server command line.
	The system enters interactive mode, prompting you for information.	
	se-10-16-0-0> software inst	all add url ftp://10.16.0.1/ axp-eemapi.aim.1.0.5.pkg
Delated Operations	<u>.</u>	Description
Related Commands	Command	Description
	software download abort	Aborts a download that is in progress.
	software download status	Reports the status of a download in progress.

software download upgrade Downloads an upgrade package to install later.

software install upgrade

Upgrades the current Cisco AXP software to a newer version.

software install clean

To install a new version of Cisco AXP software, use the **software install clean** command in Cisco AXP EXEC mode.

software install clean {*package-filename* | **url ftp:**//*ftp-server-ip-address*/*package-filename* }

Syntax Description	package-filename	Name of the package file for the new software.
	url ftp: // <i>ftp-server-ip-address</i> /	URL of the FTP server.
Command Modes	Cisco AXP EXEC.	
Command History	Cisco AXP Version	Modification
	1.0	This command was introduced.
Usage Guidelines	Use this command to download files for a new installation.	
	This command cleans the disk. All configuration and voice messages are lost after this step. F upgrades and installations, verify that a backup has been done. If it has not, abort and do a bac	
Examples	The following is an example of th FTP server information was set in	the command to install a new version of Cisco AXP software where the n the configuration.
	se-10-16-0-0> software install clean axp-abc.2.0.pkg	
The following is an example of installing a new version of Cisco AXP software we information is included in the command line.		
	e 1	6
	information is included in the con	6

Related Commands	Command	Description
	software download abort	Aborts a download that is in progress.
	software download status	Reports the status of a download in progress.
	software download upgrade	Downloads an upgrade package to install later.
	software install upgrade	Upgrades the current Cisco AXP software to a newer version.

software install downgrade

The **software install downgrade** command is not supported, although it is visible upto maintenance release 1.0.6.

To downgrade Cisco AXP software to a lower release, use the same command for upgrading:

software install upgrade

software install upgrade

To upgrade to a newer version of Cisco AXP software, use the **software install upgrade** command in Cisco AXP EXEC mode.

software install upgrade {pkg axp-package.pkg |
 url ftp://ftp-server-ip-address/axp-package.pkg}

Syntax Description	pkg axp-package.pkg		Specifies a package name.
	url ftp://ftp-server-ip-address	laxp-package .pkg	Specifies the FTP server information.
Command Modes	Cisco AXP EXEC.		
Command History	Cisco AXP Version	Modification	
	1.0	This command	was introduced.
Usage Guidelines	Use this command to upgrade	to a newer version o	f Cisco AXP software.
	Copy the installer payload file <i>axp-installer-k9</i> .< <i>platform></i> .< <i>version></i> . <i>prt1</i> to the same FTP directory as the Cisco AXP package.		
	÷		ing one, the old installer from the previous release is <i>latform</i> >.< <i>version</i> >. <i>prt1</i> , and then the new image is
Examples	• •	-	pgrade to a newer version of Cisco AXP software.
	se-10-16-0-0> software install upgrade url ftp://10.16.0.1/axp-abc.2.0.2.pkg		
	• •	r the software files v	ograde to a newer version of Cisco AXP software if were downloaded previously with the software
	se-10-16-0-0> software inst	all upgrade pkg a	xp-abc.2.0.2.pkg
Related Commands	Command	Description	
	software download server	Configures the FTI	P server information.
	software download upgrade	Downloads the file	s for a future upgrade.
	software install clean	Installs a new version	ion of the Cisco AXP software.
	software install downgrade	Downgrades the cu	rrent Cisco AXP software to an older version.

show software directory

software remove

To remove software installed during a download or upgrade, use the **software remove** command in Cisco AXP EXEC mode.

software remove {all | downgradefiles | downloadfiles}

Syntax Description	all	Removes both the downgrade and the download files.	
	downgradefiles	Removes the downgrade files.	
	downloadfiles	Removes the download files.	
Command Modes	Cisco AXP EXEC.		
Command History	Cisco AXP Version	Modification	
	1.0	This command was introduced.	
Examples	The following is an example of the software remove all command: se-172-19-0-0> software remove all Download files removed		
	Downgrade files removed Downgrade files removed The following is an example of the software remove downgradefiles command:		
	se-172-19-0-0> software remove downgradefiles		
	Downgrade files removed		
	The following is an example of the software remove downloadfiles command: se-172-19-0-0> software remove downloadfiles		
	Download files removed		
Related Commands	Command	Description	

Displays the disk usage for the download and downgrade directories.

syslog-server

To enable the syslog server, use the syslog-server command in Cisco AXP configuration mode.

syslog-server **Syntax Description** This command has no arguments or keywords. **Command Default** Disabled. **Command Modes** Cisco AXP configuration. **Cisco AXP Version** Modification **Command History** This command was introduced. 1.0 **Usage Guidelines** This command enables or disables syslog server. The syslog server is disabled by default. If the server is enabled, the Cisco AXP service module is used as a syslog server to receive all the log files from external devices. The error message below arises if the system has less than 80G disk storage, or available disk space does not satisfy the current limits set by file size, and the number of files. ERROR - system does not have enough disk space This error is resolved by either unloading applications to free disk space, or by changing limits. If this error occurs, the syslog server is disabled. **Related Commands** Command Description

Sets syslog server limits.

syslog-server limit

syslog-server limit file-rotation

To set the syslog server file rotation limits, use the **syslog-server limit file-rotation** command in Cisco AXP configuration mode.

syslog-server limit file-rotation size [file-size num]

Syntax Description	num	Defines the number of log files to be rotated. The range is 1–40 and the default is 10.	
	size	Defines the maximum size (in MB) of each log file. The range is 1-1000 MB and the default is 20 MB.	
Command Default	None.		
Command Modes	Cisco AXP configura	tion.	
Command History	Cisco AXP Version	Modification	
	1.0	This command was introduced.	
Examples	In the following example, the original current file rotation size is 5 (number of files). The syslog-server limit file-rotation command sets the new file rotation size to 2. This has the effect of deleting log files 3, 4, and 5.		
	syslog-server limit	: file-rotation 10 file-size 2	
	The message below in	ndicates that the new file rotation value is lower than the current file rotation value.	
	WARNING - setti: extra log files	ng the new file-rotation value to 2 from the old value of 5 caused to be removed	
	In the following exam	pple, the syslog-server limit file-rotation command sets the file size to 100 MB.	
	syslog-server limit	: file-rotation 100 file-size 2	
	The message below re limits.	esults from the available system disk space being insufficient for newly configured	
	System does not	have enough disk space.	
	•	pple, the syslog-server limit file-rotation command exceeds the limits for both file s causes the new configuration to be rejected and the original file size limit and the same.	
	syslog-server limit	: file-rotation 1001 file-size 1001	

syslog-server limit file-size 1001 ~ Invalid input detected at '^' marker syslog-server limit file-rotation 20 file-size 1001 \sim Invalid input detected at '^' marker.

Related Commands	Command	Description
	syslog-server	Enables the syslog server.

syslog-server limit file-size

To set the syslog server file size limits, use the **syslog-server limit file-size** command in Cisco AXP configuration mode.

syslog-server limit file-size size [file-rotation num]

Syntax Description	num	Defines the number of log files to be rotated The range is 1–40 and the
		default is 10.
	size	Defines the maximum size (in MB) of each log file. The range is 1-1000 MB and the default is 20 MB.
Command Default	None.	
ooninunu Donun	Tone.	
Command Modes	Cisco AXP configurat	ion.
Command History	Cisco AXP Version	Modification
	1.0	This command was introduced.
Usage Guidelines	syslog-server limit fil	e-size size [file-rotation num] works in a similar way to
	syslog-server limit fil	e-rotation num [file-size size].
	See the "syslog-server	limit file-rotation" section on page 125 for usage.
Examples	See the "syslog-server	limit file-rotation" section on page 125 for examples.
Related Commands	Command	Description
	syslog-server	Enables the syslog server.

write

To erase, copy, or display the running configuration, use the write command in Cisco AXP EXEC mode.

write [erase | memory | terminal]

Syntax Description	erase	Erases the running configuration.
, ,	memory	Writes the running configuration to the startup configuration. This is the
	e e e e e e e e e e e e e e e e e e e	default.
	terminal	Displays the running configuration.
Defaults	No default behavior or	values.
ommand Default	None.	
ommand Modes	Cisco AXP EXEC.	
Command History	Cisco AXP Version	Modification
	1.0	This command was introduced.
Jsage Guidelines	Use the write or write command.	memory command as a shortcut for the copy running-config startup-config
Usage Guidelines Related Commands		memory command as a shortcut for the copy running-config startup-config Description
	command.	

Notices

The following notices pertain to this software license.

OpenSSL/Open SSL Project

This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit (http://www.openssl.org/).

This product includes cryptographic software written by Eric Young (eay@cryptsoft.com).

This product includes software written by Tim Hudson (tjh@cryptsoft.com).

License Issues

The OpenSSL toolkit stays under a dual license, i.e. both the conditions of the OpenSSL License and the original SSLeay license apply to the toolkit. See below for the actual license texts. Actually both licenses are BSD-style Open Source licenses. In case of any license issues related to OpenSSL please contact openssl-core@openssl.org.

OpenSSL License:

Copyright © 1998-2007 The OpenSSL Project. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- **1.** Redistributions of source code must retain the copyright notice, this list of conditions and the following disclaimer.
- 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions, and the following disclaimer in the documentation and/or other materials provided with the distribution.
- **3.** All advertising materials mentioning features or use of this software must display the following acknowledgment: "This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit (http://www.openssl.org/)".
- 4. The names "OpenSSL Toolkit" and "OpenSSL Project" must not be used to endorse or promote products derived from this software without prior written permission. For written permission, please contact openssl-core@openssl.org.
- **5.** Products derived from this software may not be called "OpenSSL" nor may "OpenSSL" appear in their names without prior written permission of the OpenSSL Project.
- 6. Redistributions of any form whatsoever must retain the following acknowledgment:

"This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit (http://www.openssl.org/)".

THIS SOFTWARE IS PROVIDED BY THE OpenSSL PROJECT "AS IS" AND ANY EXPRESSED OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE OpenSSL PROJECT OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

This product includes cryptographic software written by Eric Young (eay@cryptsoft.com). This product includes software written by Tim Hudson (tjh@cryptsoft.com).

Original SSLeay License:

Copyright © 1995-1998 Eric Young (eay@cryptsoft.com). All rights reserved.

This package is an SSL implementation written by Eric Young (eay@cryptsoft.com).

The implementation was written so as to conform with Netscapes SSL.

This library is free for commercial and non-commercial use as long as the following conditions are adhered to. The following conditions apply to all code found in this distribution, be it the RC4, RSA, lhash, DES, etc., code; not just the SSL code. The SSL documentation included with this distribution is covered by the same copyright terms except that the holder is Tim Hudson (tjh@cryptsoft.com).

Copyright remains Eric Young's, and as such any Copyright notices in the code are not to be removed. If this package is used in a product, Eric Young should be given attribution as the author of the parts of the library used. This can be in the form of a textual message at program startup or in documentation (online or textual) provided with the package.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- 1. Redistributions of source code must retain the copyright notice, this list of conditions and the following disclaimer.
- 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- **3.** All advertising materials mentioning features or use of this software must display the following acknowledgement:

"This product includes cryptographic software written by Eric Young (eay@cryptsoft.com)".

The word 'cryptographic' can be left out if the routines from the library being used are not cryptography-related.

4. If you include any Windows specific code (or a derivative thereof) from the apps directory (application code) you must include an acknowledgement: "This product includes software written by Tim Hudson (tjh@cryptsoft.com)".

THIS SOFTWARE IS PROVIDED BY ERIC YOUNG "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

The license and distribution terms for any publicly available version or derivative of this code cannot be changed. i.e. this code cannot simply be copied and put under another distribution license [including the GNU Public License].

All other trademarks mentioned in this document or website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0812R)

CCDE, CCENT, Cisco Eos, Cisco HealthPresence, the Cisco logo, Cisco Lumin, Cisco Nexus, Cisco StadiumVision, Cisco TelePresence, Cisco WebEx, DCE, and Welcome to the Human Network are trademarks; Changing the Way We Work, Live, Play, and Learn and Cisco Store are service marks; and Access Registrar, Aironet, AsyncOS, Bringing the Meeting To You, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, CCSP, CCVP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Collaboration Without Limitation, EtherFast, EtherSwitch, Event Center, Fast Step, Follow Me Browsing, FormShare, GigaDrive, HomeLink, Internet Quotient, IOS, iPhone, iQuick Study, IronPort, the IronPort logo, LightStream, Linksys, MediaTone, MeetingPlace, SenderBase, SMARTnet, Spectrum Expert, StackWise, The Fastest Way to Increase Your Internet Quotient, TransPath, WebEx, and the WebEx logo are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

Any Internet Protocol (IP) addresses used in this document are not intended to be actual addresses. Any examples, command display output, and figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses in illustrative content is unintentional and coincidental.

© 2008 Cisco Systems, Inc. All rights reserved.

Cisco Application eXtension Platform 1.0 Command Reference