



CHAPTER 8

Command Reference

This chapter documents new and modified commands. All other commands used with this feature are documented in the Cisco IOS Release 12.2 command reference and master index publications.

Commands in this document that have been replaced by new commands continue to perform their normal function in this release but are no longer documented. Support for these commands will cease in a future release.



Note

Some of the commands in this chapter apply to multiple Cisco products and are supported on different platforms. The documentation for these commands describes differences in syntax and usage for certain platform or product variations. Therefore, when you see multiple forms of syntax, examples, or usage guidelines for a command in this guide, be sure to locate the heading within the command reference page that corresponds to the related SPA (or MSC) for your platform.

New Commands

- [flowcontrol \(Gigabit Ethernet\)](#)
- [debug hw-module subslot](#)
- [debug platform ge-autoneg register](#)
- [debug platform ge-autoneg state](#)
- [show hw-module subslot](#)
- [show hw-module subslot fpd](#)
- [show upgrade fpd file](#)
- [show upgrade fpd package default](#)
- [show upgrade fpd progress](#)
- [show upgrade fpd table](#)
- [test hw-module subslot c2w](#)
- [test hw-module subslot failed](#)
- [test hw-module subslot mac](#)
- [test hw-module subslot mdio](#)
- [test hw-module subslot pause](#)
- [test hw-module subslot phy](#)
- [test hw-module subslot policyram](#)

- test hw-module subslot tcam
- test hw-module subslot temperature
- upgrade fpd auto
- upgrade fpd path
- upgrade hw-module subslot

Modified Commands

- bert errors
- bert pattern
- card type (T1/E1)
- card type (T3/E3)
- framing (T1/E1 controller)
- framing (T3 controller)
- framing (T3/E3 interface)
- hw-module subslot reload
- interface
- mac-address
- mdl
- negotiation
- show c7300
- show controllers fastethernet
- show controllers gigabitethernet
- show controllers pos
- show controllers serial
- show diag
- show environment
- show hw-module subslot
- show hw-module subslot fpd
- show hw-module subslot oir
- show interface sdcc
- show interfaces fastethernet
- show interfaces gigabitethernet
- show interfaces pos
- show interfaces serial
- show tcam-mgr subslot
- t1 framing
- test tcam-mgr subslot
- ttb

Other Supported Commands

- [debug tcam_mgr](#)
- [duplex](#)
- [loopback driver](#)
- [loopback mac](#)
- [media-type \(Gigabit Ethernet\)](#)
- [show environment](#)
- [show interfaces fastethernet](#)
- [show interfaces gigabitethernet](#)
- [speed](#)

Replaced Commands

Command Until Cisco IOS Release 12.2(20)S6	Replacement Command in Cisco IOS Release 12.2(20)S6
show upgrade file	show upgrade fpd file
show upgrade package default	show upgrade fpd package default
show upgrade progress	show uprade fpd progress
show upgrade table	show upgrade fpd table

flowcontrol (Gigabit Ethernet)

To control whether the pause frames are received on a Gigabit Ethernet interface (NSE100/NSE150 native GIGE ports) or not, use the **[no]flowcontrol receive** command in interface configuration mode.

flowcontrol {receive}

no flowcontrol {receive}

Syntax Description

receive	
receive	Configure flowcontrol receive operation

Defaults

receive

Command Modes

Interface configuration

Command History

Release	Modification
12.2(31)SB14	This command was integrated into Cisco IOS Release 12.2(31)SB14.
12.2(33)SB2	This command was integrated into Cisco IOS Release 12.2(33)SB2.

Usage Guidelines

Use the **flowcontrol receive** command to enable or disable the receiving of pause frames on the Native Gigabit Ethernet Ports on the 7304-NSE100/NSE150 processors.

Examples

The following example configures the first GIGE port on a NSE100.

```
Router(config)#interface gigabitEthernet 0/0
Router(config-if)#flowcontrol receive
Router(config-if)#
// to deactivate
Router(config-if)#no flowcontrol receive
```

Command	Description
show interfaces giga-bitethernet	Displays information about the Gigabit Ethernet interfaces. (including flowcontrol information)

bert errors

To transmit bert errors while running any bert pattern, use the **bert error** command in interface configuration mode.

bert errors [*number*]

Syntax Description	<i>number</i> (Optional) Range of 1-255 bert errors that may be introduced in a bert pattern.
--------------------	--

Defaults	Default is 1
----------	--------------

Command Modes	Interface configuration
---------------	-------------------------

Command History	Release	Modification
	12.1(12c)EX1	This command was introduced for Cisco 7304 routers.
	12.2(18)S	This command was introduced on Cisco 7304 routers running Cisco IOS Release 12.2 S.
	12.2(18)SXE	This command was integrated into Cisco IOS Release 12.2(18)SXE to support SPAs on the Cisco 7304 router.
	12.0(31)S	This command was integrated into Cisco IOS Release 12.0(31)S.
	12.2(25)S3	This command was integrated into Cisco IOS Release 12.2(18)SXE.

Usage Guidelines	Use this command to test link availability by injecting a fixed number of bert errors when a pattern is running and check that the same number of errors were received on the remote end.
------------------	---

Examples	This example injects 200 bit errors in a running bit pattern on slot 5, bay 2.
----------	--

```
Router# configure terminal
Router(config)#int serial 5/0/0
Router(config-if)#bert errors 200
```

Related Commands	Command	Description
	bert pattern	Start a BERT pattern on a port.
	show controller serial	Displays serial line statistics.

bert pattern

To start a BERT pattern on a port, use the **bert pattern** command in interface configuration mode. Use the **no bert pattern** command to stop the sequence.

bert pattern {0s | 1s | 2^15 | 2^20 | 2^23 | alt-0-1 | qrss} interval *minutes*}

no bert pattern {0s | 1s | 2^15 | 2^20 | 2^23 | alt-0-1 | qrss} interval *minutes*}

Syntax Description		
0s	Repeating pattern of zeros (...000...).	
1s	Repeating pattern of ones (...111...).	
2^15	Pseudorandom 0.151 test pattern that is 32,768 bits in length.	
2^20	Pseudo-random 0.153 test pattern that is 1,048,575 bits in length.	
2^23	Pseudorandom 0.151 test pattern that is 8,388,607 bits in length.	
alt-0-1	Repeating pattern of alternating zeros and ones (...01010...).	
qrss	Pseudorandom quasi-random signal sequence (QRSS) 0.151 test pattern that is 1,048,575 bits in length.	
interval <i>minutes</i>	Specifies the length of the BERT test in minutes.	

Defaults Bert is disabled by default.

Command Modes Interface configuration

Command History	Release	Modification
	11.1CC	The command was introduced.
	12.0(5)XE	The command was enhanced as an ATM interface configuration command
	12.0(7)XE1	Support for Cisco 7100 series routers was added.
	12.1(5)T	This command was integrated into Cisco IOS Release 12.1(5)T.
	12.1(12c)EX1	Support for Cisco 7304 routers was added.
	12.2(18)S	Support for Cisco 7304 routers was added.
	12.2(18)SXE	This command was integrated into Cisco IOS Release 12.2(18)SXE to support SPAs on the Cisco 7304 router.
	12.0(31)S	This command was integrated into Cisco IOS Release 12.0(31)S.
	12.2(25)S3	This command was integrated into Cisco IOS Release 12.2(25)S3.

Usage Guidelines Use the **bert pattern** command to start or stop a specific bit pattern. To test link availability, start a pattern on one end and put the remote end in network loopback and verify that there are no bert errors.

Examples This example starts a bert pattern on slot 5, bay 0.

```
Router# configure terminal  
Router(config)#int serial 5/0/0  
Router(config-if)#bert pattern 0s
```

Related Commands

Command	Description
bert errors	Transmit bert errors while running any bert pattern.
show controller serial	Displays serial line statistics.
loopback	Loopback at various points in the transmit and receive path.

card type (T1/E1)

To configure the ports on SPA in T1 or E1 mode, use the **card type** command in global configuration mode. To deselect the card type, use the **no** form of this command.

card type {**t1** | **e1**} *slot subslot*

no card type {**t1** | **e1**} *slot subslot*

Syntax Description	<i>slot</i>	Chassis slot number. Refer to the appropriate hardware manual for slot information. For MSCs, refer to the platform-specific SPA hardware installation guide or the corresponding “Identifying Slots and Subslots for MSCs and SPAs” topic in the platform-specific SPA software configuration guide.
	<i>subslot</i>	Secondary slot number on a SPA interface processor (MSC) where a SPA is installed. Refer to the platform-specific SPA hardware installation guide and the corresponding “Specifying the Interface Address on a SPA” topic in the platform-specific SPA software configuration guide for subslot information.
	t1	Clear-channel T1 with integrated data service units (DSUs).
	e1	Clear-channel E1 with integrated data service units (DSUs).

Defaults No default behavior or values. There is no card type when the SPA is inserted for first time. The user must configure this command before they can configure individual ports.

Command Modes Global configuration

Command History	Release	Modification
	12.0(5)XE	This command was introduced.
	12.0(7)T	This command was integrated into Cisco IOS Release 12.0(7)T.
	12.2S	This command was integrated into Cisco IOS Release 12.2S.
	12.2(18)SXE	This command was integrated into Cisco IOS Release 12.2(18)SXE to support SPAs on the Cisco 7304 router.
	12.0(31)S	This command was integrated into Cisco IOS Release 12.0(31)S.
	12.2(25)S3	This command was integrated into Cisco IOS Release 12.2(25)S3.

Usage Guidelines To change all the SPA ports from T1 or T3 to E1 or E3 (or E3 to T3), you must deselect the card type and then configure the card with the new type of interface.

Examples The following example configures all ports of a T3/E3 SPA, seated in slot 5, bay 2, in T3 mode:


```
Router# configure terminal  
Router(config)# card type t3 5 2
```

Command	Description
show interface serial	Displays the serial interface type and other information.

card type (T3/E3)

To configure the ports on SPA in T3 or E3 mode, use the **card type** command in global configuration mode. To deselect the card type, use the **no** form of this command.

card type {**t3** | **e3**} *slot subslot*

no card type {**t3** | **e3**} *slot subslot*

Syntax Description	<i>slot</i>	Chassis slot number. Refer to the appropriate hardware manual for slot information. For MSCs, refer to the platform-specific SPA hardware installation guide or the corresponding “Identifying Slots and Subslots for MSCs and SPAs” topic in the platform-specific SPA software configuration guide.
	<i>subslot</i>	Secondary slot number on a MSC where a SPA is installed. Refer to the platform-specific SPA hardware installation guide and the corresponding “Specifying the Interface Address on a SPA” topic in the platform-specific SPA software configuration guide for subslot information.
	t3	Clear-channel T3 with integrated data service units (DSUs).
	e3	Clear-channel E3 with integrated data service units (DSUs).

Defaults No default behavior or values. There is no card type when the SPA is inserted for first time. The user must configure this command before they can configure individual ports.

Command Modes Global configuration

Command History	Release	Modification
	12.0(5)XE	This command was introduced.
	12.0(7)T	This command was integrated into Cisco IOS Release 12.0(7)T.
	12.1(1)T	This command was introduced.
	12.2(11)YT	This command was integrated into Cisco IOS Release 12.2(11)YT and implemented on the following platforms: Cisco 2650XM, Cisco 2651XM, Cisco 2691, Cisco 3660 series, Cisco 3725, and Cisco 3745 routers.
	12.2(15)T	This command was integrated into Cisco IOS Release 12.2(15)T.
	12.3(1)	This command was integrated into Cisco IOS Release 12.3(1) and support was added for Cisco 2610XM, Cisco 2611XM, Cisco 2620XM, Cisco 2621XM, Cisco 2650XM, Cisco 2651XM, Cisco 2691, Cisco 3631, Cisco 3660, Cisco 3725, and Cisco 3745 platforms.
	12.2S	This command was integrated into Cisco IOS Release 12.2S.
	12.2(25)S3	This command was integrated into Cisco IOS Release 12.2(25)S3.

Release	Modification
12.2(18)SXE	This command was integrated into Cisco IOS Release 12.2(18)SXE to support SPAs on the Cisco 7304 router.
12.0(31)S	This command was integrated into Cisco IOS Release 12.0(31)S.

Usage Guidelines

To change all the SPA ports from T3 to E3, you must deselect the **card type** and then configure the card with the new type of interface.

Once a card type is issued, the user can enter the **no card type** command and then another card type command to configure a new card type. The user must save the configuration to NVRAM and reboot the router in order for the new configuration to take effect.

When the router comes up, the software comes up with the new card type. Note that the software will reject the configuration associated with the old controller and old interface. The user will now have to configure the new controller and serial interface and save it.

Examples

The following example configures all ports of a T3/E3 SPA, seated in slot 5, bay 2, in T3 mode:

```
Router# configure terminal
Router(config)# card type t3 5 2
```

Command	Description
show interface serial	Displays the serial interface type and other information.

debug platform ge-autoneg register

To dump the register information during the auto-negotiation use the debug platform ge-autoneg register command in the Privileged Exec mode.

debug platform ge-autoneg register

no debug platform ge-autoneg register

Syntax Description	<i>register</i>	To enable debugs for auto-negotiation.
---------------------------	-----------------	--

Command Modes	Privileged EXEC (#)
----------------------	---------------------

Command History	Release	Modification
	12.2.(33)SB7	This command was introduced on the 7304 series routers.

Usage Guidelines	The debug platform ge-autoneg register command is used to dump the register information during auto-negotiation.
-------------------------	---

Examples	The following example shows the register information during auto-negotiation:
-----------------	---

```

PE2#debug platform ge-autoneg register
WS Gigabit Ethernet auto-negotiation registers debugging is on

PE2#sh debugging
WS debug subsystem:
  WS Gigabit Ethernet auto-negotiation registers debugging is on

PE2#
*Jan  1 00:03:46.343:   Port-1: pinn_an_no_ack_detect: sync_status:[0x11]
*Jan  1 00:03:46.343:   Port-1: rx_cfg:[0x1E0]
*Jan  1 00:03:46.343:   Port-1: First Read: sync_status:[0x11] rx_cfg:[0x1E0]
*Jan  1 00:03:46.343:   Port-1: Second Read: sync_status:[0x11] rx_cfg:[0x1E0]
*Jan  1 00:03:46.343:   Port-1: gmac_ack_match_word:[0x1E0]
*Jan  1 00:03:46.343:   Port-1: gmac_tx_config:[0x1A0]
*Jan  1 00:03:46.343:   Port-1: AN_STATE_ABILITY_DETECT
*Jan  1 00:03:46.343:   Port-1: First Read: mac_status:[0x11]rx_cfg:[0x41E0]
rx_cfg_read:[0x41E0]
*Jan  1 00:03:46.343:   Port-1: Second Read: mac_status:[0x11]rx_cfg_read:[0x41E0]
*Jan  1 00:03:46.343:   Port-1: gmac_ability_detect_word:[0x41E0]
*Jan  1 00:03:46.343:   Port-1: pinn_an_ack_detect: macstatus:[0x11]
*Jan  1 00:03:46.343:   Port-1: rxCfg:[0x41E0]
*Jan  1 00:03:46.343:   Port-1: First Read: macstatus:[0x11] rx_cfg_read:[0x41E0]
*Jan  1 00:03:46.343:   Port-1: Second Read: macstatus:[0x11] rx_cfg_read:[0x41E0]
*Jan  1 00:03:46.343:   Port-1: gmac_ack_match_word:[0x41E0]
*Jan  1 00:03:46.363:   Port-1: AN_STATE_COMPLETE_ACK
*Jan  1 00:03:46.363:   Port-1: AN_STATE_IDLE_DETECT
*Jan  1 00:03:46.383:   Port-1: AN_STATE_IDLE_DETECT
*Jan  1 00:03:46.383:   Port-1: AN_STATE_LINK_OK
*Jan  1 00:03:46.383:   Port-1: pinn_gmac_is_sync: sync_status:[0x10]

```

```
*Jan  1 00:03:46.383:  Port-1: AN_STATE_AN_DONE  
  
PE2#no debug platform ge-autoneg register  
WS Gigabit Ethernet auto-negotiation registers debugging is off
```

debug platform ge-autoneg state

To dump the state information during the auto-negotiation use the debug platform ge-autoneg state command in the Privileged Exec mode.

- debug platform ge-autoneg state
- no debug platform ge-autoneg state

Syntax Description	state	To enable debugs for auto-negotiation.
--------------------	-------	--

Command Modes	Privileged EXEC (#)
---------------	---------------------

Command History	Release	Modification
	12.2.(33)SB7	This command was introduced on the 7304 series routers.

Usage Guidelines	The debug platform ge-autoneg state command is used to dump the state information during auto-negotiation.
------------------	---

Examples	The following example shows the state information during auto-negotiation:
----------	--

```

PE2#debug platform ge-autoneg state
WS Gigabit Ethernet auto-negotiation states debugging is on

PE2#sh debugging
WS debug subsystem:
  WS Gigabit Ethernet auto-negotiation states debugging is on

*Jan  1 00:04:17.971:  Port-1: AN_STATE_AN_ENABLE_RESTART
*Jan  1 00:04:18.003:  Port-1: AN_STATE_TX_CAPABILITY
*Jan  1 00:04:18.003:  Port-1: AN_STATE_ABILITY_DETECT
*Jan  1 00:04:18.003:  Port-1: AN_STATE_ACK_DETECT
*Jan  1 00:04:18.023:  Port-1: AN_STATE_COMPLETE_ACK
*Jan  1 00:04:18.023:  Port-1: AN_STATE_IDLE_DETECT
*Jan  1 00:04:18.043:  Port-1: AN_STATE_IDLE_DETECT
*Jan  1 00:04:18.043:  Port-1: AN_STATE_LINK_OK
*Jan  1 00:04:18.043:  Port-1: AN_STATE_AN_DONE

PE2#no debug platform ge-autoneg state
WS Gigabit Ethernet auto-negotiation states debugging is off

```

debug tcam_mgr

To debug the ternary content addressable memory (TCAM) manager, use the **debug tcam_mgr** command in privileged EXEC configuration mode.

debug tcam_mgr {error | event | profile}

no debug tcam_mgr {error | event | profile}

Syntax Description	error	Enables debug messages related to TCAM manager errors.
	event	Enables debug messages for TCAM manager events.
	profile	Enables debug messages about the amount of time it takes to add and remove entries from the TCAM regions.

Defaults No default behavior or values

Command Modes Privileged EXEC

Command History	Release	Modification
	12.0 S	This command was introduced.
	12.2(20)S2	This command was integrated into Cisco IOS Release 12.2(20)S2.

Usage Guidelines The **debug tcam_mgr** command is intended for use by Cisco Systems technical support personnel.



Caution

Because debugging output is assigned high priority in the CPU process, it can render the system unusable. For this reason, use **debug** commands only to troubleshoot specific problems or during troubleshooting sessions with Cisco Systems technical support personnel. Moreover, it is best to use **debug** commands during periods of lower network traffic and fewer users. Debugging during these periods decreases the likelihood that increased **debug** command processing overhead will affect system use.

Examples The following example enables TCAM manager event debug messages. It shows the messages associated with shutting down and restarting an interface on the the 4-Port 10/100 Fast Ethernet SPA located in the top subslot (0) of the MSC that is installed in slot 4 of the Cisco 7304 router:

```
Router# debug tcam_mgr event
TCAM Manager Events debugging is on
Router# conf t
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# int fast 4/0/0
Router(config-if)# shut
Router(config-if)#
```

```

4d01h: %LINK-5-CHANGED: Interface FastEthernet4/0/0, changed state to administratively
down
4d01h: %LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet4/0/0, changed state to
down
Router(config-if)#
Router(config-if)# no shut
Router(config-if)#
4d01h: Freeing VC at 0 from mask at 0
4d01h: Freeing VC at 1 from mask at 0
4d01h: Freeing VC at 0 from mask at 8
4d01h: Found Mbu at offset 0 index 0
4d01h: Allocated mbu at offset 0 index 0, vc_index 0 region 0
4d01h: Found Mbu at offset 0 index 0
4d01h: Allocated mbu at offset 0 index 0, vc_index 1 region 0
4d01h: Found Mbu at offset 0 index 1
4d01h: Allocated mbu at offset 0 index 1, vc_index 0 region 0
4d01h: %LINK-3-UPDOWN: Interface FastEthernet4/0/0, changed state to up
4d01h: %LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet4/0/0, changed state to
up

```

Related Commands

Command	Description
show controllers fastethernet	Displays Fast Ethernet interface information, transmission statistics and errors, and applicable MAC destination address and VLAN filtering tables.
show controllers gigabitethernet	Displays Gigabit Ethernet interface information, transmission statistics and errors, and applicable MAC destination address and VLAN filtering tables.
show tcam-mgr subslot	Displays TCAM manager information for SPAs.
test hw-module subslot policyram	Tests the policy table used by the FPGA device for TCAM lookup on a SPA.
test hw-module subslot tcam	Tests the TCAM device on a SPA.

duplex

To configure duplex operation on an interface, use the **duplex** command in interface configuration mode. To return to the default value, use the **no** form of this command.

duplex {full | half | auto}

no duplex

Syntax Description

full	Specifies full-duplex operation.
half	Specifies half-duplex operation.
auto	Enables autonegotiation. The interface automatically operates at half or full duplex depending on environmental factors, such as the type of media and the transmission speeds for the peer routers, hubs, and switches used in the network configuration.

Defaults

Half-duplex mode

For the 4-Port 10/100 Fast Ethernet SPA and the 2-Port 10/100/1000 Gigabit Ethernet SPA on the Cisco 7304 router, the default is **auto**.

Command Modes

Interface configuration

Command History

Release	Modification
11.2(10)P	This command was introduced.
12.2 S	This command was integrated into Cisco IOS Release 12.2 S.
12.2(20)S2	This command was implemented on the 4-Port 10/100 Fast Ethernet SPA and the 2-Port 10/100/1000 Gigabit Ethernet SPA on the Cisco 7304 router.

Usage Guidelines

General Usage Guidelines

To use the autonegotiation capability (that is, detect speed and duplex modes automatically), you must set both speed and duplex to auto.

[Table 8-2](#) describes the access server's performance for different combinations of the duplex and speed modes. The specified **duplex** command configured with the specified **speed** command produces the resulting system action.

Table 8-1 Relationship Between duplex and speed Commands

duplex Command	speed Command	Resulting System Action
duplex auto	speed auto	Autonegotiates both speed and duplex modes.
duplex auto	speed 100 or speed 10	Autonegotiates both speed and duplex modes.

Table 8-1 Relationship Between *duplex* and *speed* Commands (continued)

duplex Command	speed Command	Resulting System Action
duplex half or duplex full	speed auto	Autonegotiates both speed and duplex modes.
duplex half	speed 10	Forces 10 Mbps and half duplex.
duplex full	speed 10	Forces 10 Mbps and full duplex.
duplex half	speed 100	Forces 100 Mbps and half duplex.
duplex full	speed 100	Forces 100 Mbps and full duplex.

For the Cisco AS5300, the **duplex {full | half | auto}** command syntax replaces the following two earlier duplex commands:

- **half-duplex**
- **full-duplex**

You will get the following error messages if you try to use these commands on a Cisco AS5300:

```
Router(config)# interface fastethernet 0
Router(config-if)# full-duplex
Please use duplex command to configure duplex mode
Router(config-if)#
Router(config-if)# half-duplex
Please use duplex command to configure duplex mode
```

Usage Guidelines for the 4-Port 10/100 Fast Ethernet SPA and the 2-Port 10/100/1000 Gigabit Ethernet SPA on the Cisco 7304 router.

The **duplex** command applies to SPA interfaces that are using RJ-45 media. Gigabit Ethernet interfaces using fiber media support full-duplex mode only, and use the **negotiation** command to enable and disable autonegotiation.

To enable the autonegotiation capability on an RJ-45 interface, you must set either the **speed** command or the **duplex** command to **auto**. The default configuration is that both commands are set to **auto**.

Table 8-2 describes the interface behavior for different combinations of the **duplex** and **speed** command settings. The specified **duplex** command configured with the specified **speed** command produces the resulting system action.

If you specify both a **duplex** and **speed** setting other than **auto** on an RJ-45 interface, then autonegotiation is disabled for the interface.



Note

If you need to force an interface port to operate with certain settings and therefore disable autonegotiation, you must be sure that the remote link is configured with compatible link settings for proper transmission. This includes support of flow control on the link.



Note

Every interface on a 4-Port 10/100 Fast Ethernet SPA and 2-Port 10/100/1000 Gigabit Ethernet SPA automatically supports transmission of pause frames to stop packet flow when the MSC is full. You cannot disable flow control for an interface on the 4-Port 10/100 Fast Ethernet SPA or 2-Port 10/100/1000 Gigabit Ethernet SPA. Therefore, flow control support is not configurable, but it is advertised during autonegotiation.

If you disable autonegotiation, then you must be sure that the remote device is configured to support flow control because flow control is automatically enabled for all interfaces on the 4-Port 10/100 Fast Ethernet SPA and the 2-Port 10/100/1000 Gigabit Ethernet SPA.

Table 8-2 Relationship Between duplex and speed Commands

duplex Command	speed Command	Resulting System Action
duplex auto	speed auto	Autonegotiates both speed and duplex mode. The interface advertises capability for the following link settings: <ul style="list-style-type: none"> • 10 Mbps and half duplex • 10 Mbps and full duplex • 100 Mbps and half duplex • 100 Mbps and full duplex • 1000 Mbps and half duplex • 1000 Mbps and full duplex
duplex auto	speed 10 or speed 100 or speed 1000	Autonegotiates the duplex mode. The interface advertises capability for the configured speed with capability for both half-duplex or full-duplex mode. For example, if the speed 100 command is configured with duplex auto , then the interface advertises the following capability: <ul style="list-style-type: none"> • 100 Mbps and half duplex • 100 Mbps and full duplex
duplex half or duplex full	speed auto	Autonegotiates the speed. The interface advertises capability for the configured duplex mode with capability for both 10-Mbps and 100-Mbps operation for Fast Ethernet interfaces, and 10-Mbps, 100-Mbps, and 1000-Mbps for Gigabit Ethernet interfaces. For example, if the duplex full command is configured with the speed auto command, then the interface advertises the following capability: <ul style="list-style-type: none"> • 10 Mbps and full duplex • 100 Mbps and full duplex • 1000 Mbps and full duplex (Gigabit Ethernet interfaces only)
duplex half	speed 10	Forces 10-Mbps and half-duplex operation, and disables autonegotiation on the interface.
duplex full	speed 10	Forces 10-Mbps and full-duplex operation, and disables autonegotiation on the interface.
duplex half	speed 100	Forces 100-Mbps and half-duplex operation, and disables autonegotiation on the interface.

Table 8-2 Relationship Between duplex and speed Commands (continued)

duplex Command	speed Command	Resulting System Action
duplex full	speed 100	Forces 100-Mbps and full-duplex operation, and disables autonegotiation on the interface.
duplex half	speed 1000	Forces 1000-Mbps and half-duplex operation, and disables autonegotiation on the interface (Gigabit Ethernet only).
duplex full	speed 1000	Forces 1000-Mbps and full-duplex operation, and disables autonegotiation on the interface (Gigabit Ethernet only).

Examples

The following example shows how to configure full- duplex operation on a Cisco AS5300:

```
Router(config)# interface fastethernet 0
Router(config-if)# duplex full
```

The following example specifies advertisement of half-duplex support only, and either 10-Mbps or 100-Mbps capability during autonegotiation for the second interface (port 1) on the SPA located in the bottom subslot (1) of the MSC that is installed in slot 2 of the Cisco 7304 router:

```
Router# configure terminal
Router(config)# interface fastethernet 2/1/1
Router(config-if)# duplex half
Router(config-if)# speed auto
```

With this configuration, the interface advertises the following capabilities during autonegotiation:

- 10 Mbps and half duplex
- 100 Mbps and half duplex

**Note**

Recall that flow control support is always advertised when autonegotiation is enabled.

Related Commands

Command	Description
speed	Configures the speed for a Fast Ethernet interface.
interface fastethernet	Selects a particular Fast Ethernet interface for configuration.
interface gigabitethernet	Selects a particular Gigabit Ethernet interface for configuration.
show controllers fastether- net	Displays Fast Ethernet interface information, transmission statistics and errors, and applicable MAC destination address and VLAN filtering tables.
show controllers gigabiteth- ernet	Displays Gigabit Ethernet interface information, transmission statistics and errors, and applicable MAC destination address and VLAN filtering tables.
show interfaces fastethernet	Displays information about the Fast Ethernet interfaces.
show interfaces gigabiteth- ernet	Displays information about the Gigabit Ethernet interfaces.

framing (T1/E1 controller)

To select the frame type for the T1 or E1 data line, use the **framing** command in controller configuration mode.

T1 Lines

```
framing {sf | esf}
```

E1 Lines

```
framing {crc4 | no-crc4} [australia]
```

T1 Shared Port Adapter

```
framing {sf | esf}
```

```
no framing {sf | esf}
```

E1 Shared Port Adapter

```
framing {crc4 | no-crc4 | unframed}
```

```
no framing {crc4 | no-crc4 | unframed}
```

Syntax Description

sf	Specifies super frame as the T1 frame type. This is the default for T1.
esf	Specifies extended super frame as the T1 frame type.
crc4	Specifies CRC4 frame as the E1 frame type. This is the default for E1.
no-crc4	Specifies no CRC4 frame as the E1 frame type.
australia	(Optional) Specifies the E1 frame type used in Australia.

Defaults

sf (for a T1 line)
crc4 (for an E1 line)

Command Modes

Controller configuration

Command History

Release	Modification
12.2S	This command was integrated into Cisco IOS Release 12.2S.
12.2(18)SXE	This command was integrated into Cisco IOS Release 12.2(18)SXE to support SPAs on the Cisco 7304 router.
12.0(31)S	This command was integrated into Cisco IOS Release 12.0(31)S.
12.2(25)S3	This command was integrated into Cisco IOS Release 12.2(25)S3.

Usage Guidelines

Use this command in configurations in which the router or access server is intended to communicate with T1 or E1 fractional data lines. The service provider determines the framing type required for your T1/E1 circuit.

To return to the default mode on a T1/E1 SPA, use the **no** form of this command. This command does not have a **no** form for other T1/E1 lines.

Examples

The following example selects extended super frame as the T1 frame type:

```
Router(config-controller)# framing esf
```

Related Commands

Command	Description
cablelength	Specifies the distance of the cable from the routers to the network equipment.
linecode	Selects the linecode type for T1 or E1 line.

framing (T3 controller)

To choose framing mode on a T3 port, use the **framing** command in controller configuration mode. To return to the default mode, use the **no** form of this command.

T3 Controllers

framing { c-bit | m23 }

no framing

T3/E3 Shared Port Adapters and the Cisco 7500 Series Routers with CT3IP Port Adapter

framing { c-bit | m23 | auto-detect }

no framing

Syntax Description

auto-detect	Specifies detection of the framing type that it receives from the far-end equipment.
c-bit	Specifies that C-bit framing is used as the T3 framing type.
m23	Specifies that M23 framing is used as the T3 framing type.

Defaults

c-bit (for T3 and most T3 controllers)

auto-detect (for the CT3IP in a Cisco 7500 series router)

Command Modes

Controller configuration

Command History

Release	Modification
11.1CA	This command was introduced.
12.2(11)YT	This command was integrated into Cisco IOS Release 12.2(11)YT and implemented on the following platforms for T3: Cisco 2650XM, Cisco 2651XM, Cisco 2691, Cisco 3660 series, Cisco 3725, and Cisco 3745 routers.
12.2(15)T	This command was integrated into Cisco IOS Release 12.2(15)T.
12.2S	This command was integrated into Cisco IOS Release 12.2S.
12.2(18)SXE	This command was integrated into Cisco IOS Release 12.2(18)SXE to support SPAs on the Cisco 7304 router.
12.0(31)S	This command was integrated into Cisco IOS Release 12.0(31)S.
12.2(25)S3	This command was integrated into Cisco IOS Release 12.2(25)S3.

Usage Guidelines

Use the **framing** command to set the framing mode on the T3/E3 port.

Examples

The following example sets the framing mode on a T3 interface.

```
Router# configure terminal  
Router(config)# controller t1 6/0/0  
Router(config-controller)# framing m23
```

The following example sets the framing for the CT3IP to C-bit:

```
Router(config)# controller t3 9/0/0  
Router(config-controller)# framing c-bit
```

Related Commands

Command	Description
controller	Configures a T1, E1, or T3 controller and enters controller configuration mode.
show controller	Displays controller configuration.

framing (T3/E3 interface)

To choose framing mode on a T3 port, use the **framing** command in interface configuration mode. To return to the default mode, use the **no** form of this command.

```
framing {bypass | c-bit | m13}
```

```
no framing {bypass | c-bit | m13}
```

To choose framing mode on an E3 port, use the **framing** command in interface configuration mode. To return to the default mode, use the **no** form of this command.

```
framing {bypass | g751 | g832}
```

```
no framing {bypass | g751 | g832}
```

Syntax Description

<i>bypass</i>	Bypasses DS3 framing mode.
<i>c-bit</i>	Enables DS3 C-bit framing mode.
<i>m13</i>	Enables DS3 M13 framing mode.
<i>g751</i>	Enables E3 G.751 framing mode.
<i>g832</i>	Enables E3 G.832 framing mode.

Defaults

T3: C-bit framing

E3: g751 framing

Command Modes

Interface configuration

Command History

Release	Modification
11.1	This command was introduced.
12.2S	This command was integrated into Cisco IOS Release 12.2S.
12.2(18)SXE	This command was integrated into Cisco IOS Release 12.2(18)SXE to support SPAs on the Cisco 7304 router. The g832 keyword option was added to the command.
12.0(31)S	This command was integrated into Cisco IOS Release 12.0(31)S.
12.2(25)S3	This command was integrated into Cisco IOS Release 12.2(25)S3.

Usage Guidelines

Use the **framing** command to set the framing mode on the T3 port.

Examples

The following example sets the framing mode on the first port on slot 5.

```
Router# configure terminal  
Router(config)# interface serial 5/0/0
```

```
Router(config-if)# framing bypass
```

Related Commands

Command	Description
show controller serial	Displays serial line statistics.

hw-module subslot reload

To restart a shared port adapter (SPA) and its interfaces, use the **hw-module subslot reload** command in privileged EXEC configuration mode. The command does not have a **no** form.

hw-module subslot *slot/subslot* **reload**

Syntax Description	<i>slot</i>	Chassis slot number. Refer to the appropriate hardware manual for slot information. For MSCs, refer to the platform-specific SPA hardware installation guide or the corresponding “Identifying Slots and Subslots for MSCs and SPAs” topic in the platform-specific SPA software configuration guide.
	<i>/subslot</i>	Secondary slot number on a MSC where a SPA is installed. Refer to the platform-specific SPA hardware installation guide and the corresponding “Specifying the Interface Address on a SPA” topic in the platform-specific SPA software configuration guide for subslot information.

Defaults	No default behavior or values
-----------------	-------------------------------

Command Modes	Privileged EXEC
----------------------	-----------------

Command History	Release	Modification
	12.2(25)S3	This command was introduced.

Usage Guidelines The **hw-module subslot reload** command stops and starts power to the SPA. This command is useful when you want to restart all interfaces on a SPA.

The command is recommended to restart a SPA under some of the following conditions:

- To restart a SPA after it has been powered off because of a failure.
- To recover from corrupted messaging between the route processor (RP) and the MSC.

Examples The following command power cycles the SPA in subslot 2 of the MSC installed in chassis slot 13:

```
Router# hw-module subslot 13/2 reload
```

```
SLOT 13/0: 00:27:08: %SCC-2-PROTO_HW: Module (13/2/-1) is a registered proto-type for  
Cisco Lab use only, and not certified for live network operation.
```

Command	Description
show hw-module subslot oir	Displays the operational status of a SPA.

interface

To configure an interface type and enter interface configuration mode, use the **interface** command in global configuration mode.

Standard Syntax

```
interface type number [name-tag]
```

Analysis Module Network Module

```
interface analysis-module slot/unit
```

Content Engine Network Module

```
interface content-engine slot/unit
```

Cisco 7200 Series and Cisco 7500 Series with a Packet over SONET Interface Processor

```
interface type slot/port
```

Cisco 7200 VXR Router used as a Router Shelf in a Cisco AS5800 Universal Access Server

```
interface type router-shelf/slot/port
```

Cisco 7500 Series with Channelized T1 or E1

```
interface serial slot/port:channel-group
```

Cisco 7500 Series with Ports on VIP Cards

```
interface type slot/port-adapter/port
```

To configure a subinterface, use this form of the **interface** global configuration command.

Cisco 7200 Series

```
interface type slot/port.subinterface-number [multipoint | point-to-point]
```

Cisco 7500 Series

```
interface type slot/port-adapter.subinterface-number [multipoint | point-to-point]
```

Cisco 7500 Series with Ports on VIP Cards

```
interface type slot/port-adapter/port.subinterface-number [multipoint | point-to-point]
```

Shared Port Adapters

```
interface type slot/subslot/port[.subinterface-number]
```

Syntax Description		
<i>type</i>		Type of interface to be configured. See Table 8-3 .
<i>number</i>		Port, connector, or interface card number. On Cisco 4700 series routers, specifies the network interface module (NIM) or network processor module (NPM) number. The numbers are assigned at the factory at the time of installation or when added to a system, and can be displayed with the show interfaces command.
<i>name-tag</i>		(Optional) Specifies the logic name to identify the server configuration so that multiple server configurations can be entered. This optional argument is for use with the Redundant Link Manager (RLM) feature.
<i>slot</i>		Chassis slot number. Refer to the appropriate hardware manual for slot information. For MSCs, refer to the platform-specific SPA hardware installation guide or the corresponding “Identifying Slots and Subslots for MSCs and SPAs” topic in the platform-specific SPA software configuration guide.
<i>/subslot</i>		Secondary slot number on a MSC where a SPA is installed. Refer to the platform-specific SPA hardware installation guide and the corresponding “Specifying the Interface Address on a SPA” topic in the platform-specific SPA software configuration guide for subslot information.
<i>/unit</i>		Number of the daughter card on the network module. For analysis module and content engine (CE) network modules, always use 0.
<i>/port</i>		Port or interface number. Refer to the appropriate hardware manual for port information. For SPAs, refer to the corresponding “Specifying the Interface Address on a SPA” topics in the platform-specific SPA software configuration guide.
<i>router-shelf</i>		Router shelf number in a Cisco AS5800 universal access server. Refer to the appropriate hardware manual for router shelf information.
<i>:channel-group</i>		Channel group number. Cisco 7500 series routers specify the channel group number in the range of 0 to 4 defined with the channel-group controller configuration command.
<i>/port-adapter</i>		Port adapter number. Refer to the appropriate hardware manual for information about port adapter compatibility.
<i>.subinterface-number</i>		Subinterface number in the range 1 to 4294967293. The number that precedes the period (.) must match the number to which this subinterface belongs.
multipoint point-to-point		(Optional) Specifies a multipoint or point-to-point subinterface. There is no default.

Defaults No interface types are configured.

Command Modes Global configuration

**Note**

To use this command with the RLM feature, you must be in interface configuration mode.

Command History

Release	Modification
10.0	This command was introduced for the Cisco 7000 series routers.
11.0	This command was implemented on the Cisco 4000 series routers.
12.0(3)T	The optional <i>name-tag</i> argument was added for the RLM feature.
12.2(13)T	The content-engine keyword was added.
12.2(15)T	The lex keyword was removed because the LAN Extension feature is no longer available in Cisco IOS software.
12.3(7)T	The analysis-module keyword was added.
12.2(20)S2	This command was implemented for SPAs on the Cisco 7304 router.

Usage Guidelines

This command does not have a **no** form.

Subinterfaces can be configured to support partially meshed Frame Relay networks. Refer to the “Configuring Serial Interfaces” chapter in the *Cisco IOS Interface and Hardware Component Configuration Guide*.

[Table 8-3](#) displays the keywords that represent the types of interfaces that can be configured with the **interface** command. Replace the *type* argument with the appropriate keyword from the table.

Table 8-3 Interface Type Keywords

Keyword	Interface Type
analysis-module	Analysis module interface. The analysis module interface is a Fast Ethernet interface on the router that connects to the internal interface on the Network Analysis Module (NAM). This interface cannot be configured for subinterfaces or for speed, duplex mode, and similar parameters. See the command-line interface (CLI) help for a list of valid parameters.
async	Port line used as an asynchronous interface.
atm	ATM interface.
bri	ISDN BRI. This interface configuration is propagated to each of the B channels. B channels cannot be individually configured. The interface must be configured with dial-on-demand commands in order for calls to be placed on that interface.
content-engine	Content engine (CE) network module interface. The CE network module interface cannot be configured for subinterfaces or for speed, duplex mode, and similar parameters. See the command-line interface (CLI) help for a list of valid parameters. The content-engine keyword was formerly documented as the interface content-engine command.
dialer	Dialer interface.
ethernet	Ethernet IEEE 802.3 interface.

Table 8-3 **Interface Type Keywords (continued)**

Keyword	Interface Type
fastethernet	100-Mbps Ethernet interface. The fastethernet keyword was formerly documented as the interface fastethernet command.
fddi	FDDI interface.
gigabitethernet	1000-Mbps Ethernet interface. The gigabitethernet keyword was formerly documented as the interface gigabitethernet command.
group-async	Master asynchronous interface. The group-async keyword was formerly documented as the interface group-async command.
hssi	High-Speed Serial Interface (HSSI).
loopback	Software-only loopback interface that emulates an interface that is always up. It is a virtual interface supported on all platforms. The <i>number</i> argument is the number of the loopback interface that you want to create or configure. There is no limit on the number of loopback interfaces that you can create.
null	Null interface.
port-channel	Port channel interface. The port-channel keyword was formerly documented as the interface port-channel command.
pos	Packet OC-3 interface on the Packet-over-SONET (POS) interface processor. The pos keyword was formerly documented as the interface pos command.
sdcc	Section data communications channel interface.
serial	Serial interface.
switch	Switch interface.
tokenring	Token Ring interface.
tunnel	Tunnel interface; a virtual interface. The <i>number</i> argument is the number of the tunnel interface that you want to create or configure. There is no limit on the number of tunnel interfaces that you can create.
vg-anylan	100VG-AnyLAN port adapter. The vg-anylan keyword was formerly documented as the interface vg-anylan command.

Using the analysis-module Keyword

The analysis module interface is used to access the NAM console for the initial configuration. After the NAM IP parameters are configured, the analysis module interface is typically used only during NAM software upgrades and while troubleshooting if the NAM Traffic Analyzer is inaccessible.

Visible only to the Cisco IOS software on the router, the analysis module interface is an internal Fast Ethernet interface on the router that connects to the internal NAM interface. The analysis module interface is connected to the router's Peripheral Component Interconnect (PCI) backplane, and all configuration and management of the analysis module interface must be performed from the Cisco IOS CLI.

Using the group-async Keyword

Using the **group-async** keyword, you create a single asynchronous interface with which other interfaces are associated as members using the **group-range** command. This one-to-many configuration allows you to configure all associated member interfaces by entering one command on the group master interface, rather than entering this command on each individual interface. You can create multiple group masters on a device; however, each member interface can be associated only with one group.

Using the port-channel Keyword

The Fast EtherChannel feature allows multiple Fast Ethernet point-to-point links to be bundled into one logical link to provide bidirectional bandwidth of up to 800 Mbps. You can configure the port-channel interface as you would any Fast Ethernet interface.

After you create a port-channel interface, you assign Fast Ethernet interfaces (up to four) to it. For information on how to assign a Fast Ethernet interface to a port-channel interface, refer to the **channel-group** interface configuration command.



Caution

The port-channel interface is the routed interface. Do not enable Layer 3 addresses on the physical Fast Ethernet interfaces. Do not assign bridge groups on the physical Fast Ethernet interfaces because it creates loops. Also, you must disable spanning tree.



Caution

With Release 11.1(20)CC, the Fast EtherChannel supports Cisco Express Forwarding (CEF) and distributed Cisco Express Forwarding (dCEF). We recommend that you clear all explicit **ip route-cache distributed** commands from the Fast Ethernet interfaces before enabling dCEF on the port-channel interface. Clearing the route cache gives the port-channel interface proper control of its physical Fast Ethernet links. When you enable CEF/dCEF globally, all interfaces that support CEF/dCEF are enabled. When CEF/dCEF is enabled on the port-channel interface, it is automatically enabled on each of the Fast Ethernet interfaces in the channel group. However, if you have previously disabled CEF/dCEF on the Fast Ethernet interface, CEF/dCEF is not automatically enabled. In this case, you must enable CEF/dCEF on the Fast Ethernet interface.

As you work with the **port-channel** keyword, consider the following points:

- Currently, if you want to use the Cisco Discovery Protocol (CDP), you must configure it only on the port-channel interface and not on the physical Fast Ethernet interface.
- If you do not assign a static MAC address on the port-channel interface, the Cisco IOS software automatically assigns a MAC address. If you assign a static MAC address and then later remove it, Cisco IOS software automatically assigns a MAC address.

Using the vg-anylan Keyword

The 100VG-AnyLAN port adapter provides a single interface port that is compatible with and specified by IEEE 802.12. The 100VG-AnyLAN port adapter provides 100 Mbps over Category 3 or Category 5 unshielded twisted-pair (UTP) cable with RJ-45 terminators, and supports IEEE 802.3 Ethernet packets.

You configure the 100VG-AnyLAN port adapter as you would any Ethernet or Fast Ethernet interface. The 100VG-AnyLAN port adapter can be monitored with the IEEE 802.12 Interface MIB.

Examples

Serial Interface Example

The following example shows how to configure serial interface 0 with PPP encapsulation:

```
Router(config)# interface serial 0
```



```
Router(config-if)# encapsulation ppp
```

Loopback Interface Example

The following example shows how to enable loopback mode and assigns an IP network address and network mask to the interface. The loopback interface established here will always appear to be up.

```
Router(config)# interface loopback 0
Router(config-if)# ip address 10.108.1.1 255.255.255.0
```

Cisco 7500 Series Router Ethernet Interface Processor Example

The following example shows how to configure Ethernet port 4 on the Ethernet Interface Processor (EIP) in slot 2 on the Cisco 7500 series router:

```
Router(config)# interface ethernet 2/4
```

Cisco 7500 Series Router Token Ring Interface Example

The following example shows how to configure the Token Ring interface processor in slot 1 on port 0 of a Cisco 7500 series router:

```
Router(config)# interface tokenring 1/0
```

Network Analysis Module Interface Example

The following example configures an analysis module interface when the NAM router is in router slot 1:

```
Router(config)# interface analysis-module 1/0
```

Content Engine Network Module Interface Example

The following example configures an interface for a content engine network module in slot 1:

```
Router(config)# interface content-engine 1/0
```

Cisco 4700 Series Router Fast Ethernet Interface Example

The following example shows how to configure Fast Ethernet interface 0 for standard ARPA encapsulation (the default setting) on a Cisco 4700 series router:

```
Router(config)# interface fastethernet 0
```

Gigabit Ethernet Interface Example

The following example shows how to configure the Gigabit Ethernet interface for slot 0, port 0:

```
Router(config)# interface gigabitethernet 0/0
```

Asynchronous Group Master Interface Example

The following example shows how to define asynchronous group master interface 0:

```
Router(config)# interface group-async 0
```

Port Channel Interface Example

The following example shows how to create a port-channel interface with a channel group number of 1 and adds two Fast Ethernet interfaces to port-channel 1:

```
Router(config)# interface port-channel 1
Router(config-if)# ip address 10.1.1.10 255.255.255.0
Router(config-if)# exit
Router(config)# interface fastethernet 1/0/0
Router(config-if)# channel-group 1
Router(config-if)# exit
Router(config)# interface fastethernet 4/0/0
Router(config-if)# channel-group 1
```

Packet over SONET Interface Example

The following example shows how to specify the single Packet OC-3 interface on port 0 of the POS OC-3 port adapter in slot 2:

```
Router(config)# interface pos 2/0
```

100VG-AnyLAN Interface Example

The following example shows how to specify the 100VG-AnyLAN port adapter in the first port adapter in slot 1:

```
Router(config)# interface vg-anylan 1/0/0
```

Frame Relay Subinterface Example

The following example shows how to configure a partially meshed Frame Relay network. In this example, subinterface serial 0.1 is configured as a multipoint subinterface with two associated Frame Relay permanent virtual connections (PVCs), and subinterface serial 0.2 is configured as a point-to-point subinterface.

```
Router(config)# interface serial 0
Router(config-if)# encapsulation frame-relay
Router(config-if)# exit
Router(config)# interface serial 0/0.1 multipoint
Router(config-if)# ip address 10.108.10.1 255.255.255.0
Router(config-if)# frame-relay interface-dlci 42 broadcast
Router(config-if)# frame-relay interface-dlci 53 broadcast
Router(config-if)# exit
Router(config)# interface serial 0/0.2 point-to-point
Router(config-if)# ip address 10.108.11.1 255.255.255.0
Router(config-if)# frame-relay interface-dlci 59 broadcast
```

T1 Serial Interface Example

The following example shows how to configure circuit 0 of a T1 link for PPP encapsulation:

```
Router(config)# controller t1 4/1
Router(config-controller)# circuit 0 1
Router(config-controller)# exit
Router(config)# interface serial 4/1:0
Router(config-if)# ip address 10.108.13.1 255.255.255.0
Router(config-if)# encapsulation ppp
```

SDCC Interface on a POS Shared Port Adapter Example

The following example configures the first interface (port 0) as a section data communications channel (SDCC) interface on a POS SPA, where the SPA is installed in the top subslot (0) of the MSC, and the MSC is installed in slot 4 of the Cisco 7304 router:

```
Router(config)# interface sdcc 4/3/0
Router(config-if)# ip address 10.1.9.2 255.255.255.0
Router(config-if)# logging event link-status
Router(config-if)# load-interval 30
Router(config-if)# no keepalive
Router(config-if)# no fair-queue
Router(config-if)# no cdp enable
```

Shared Port Adapter Interface Example

The following example configures the second interface (port 1) on a 4-Port 10/100 Fast Ethernet SPA for standard ARPA encapsulation (the default setting), where the SPA is installed in the bottom subslot (1) of the MSC, and the MSC is installed in slot 2 of the Cisco 7304 router:

```
Router(config)# interface fastethernet 2/1/1
```

Related Commands	Command	Description
	channel-group	Defines the timeslots that belong to each T1 or E1 circuit.
	channel-group (Fast EtherChannel)	Assigns a Fast Ethernet interface to a Fast EtherChannel group.
	clear interface	Resets the hardware logic on an interface.
	controller	Configures an E1, J1, T1, or T3 controller and enters controller configuration mode.
	group-range	Creates a list of asynchronous interfaces that are associated with a group interface on the same device.
	mac-address	Sets the MAC layer address.
	ppp	Starts an asynchronous connection using PPP.
	show controllers content-engine	Displays controller information for CE network modules.
	show interfaces	Displays information about interfaces.
	show interfaces content-engine	Displays basic interface configuration information for a CE network module.
	shutdown (RLM)	Shuts down all of the links under the RLM group.
	slip	Starts a serial connection to a remote host using SLIP.

loopback (T3/E3 interface)

To loopback at various points in the transmit and receive path, use the **loopback** command in interface configuration mode. To stop the loopback, use the **no** form of this command.

PA-T3 Port Adapter

```
loopback { dte | local | network {line | payload} | remote}

no loopback
```

PA-E3 Port Adapter

```
loopback { dte | local | network {line | payload} }

no loopback
```

T3/E3 Shared Port Adapters

```
loopback { dte | local | dual | network {line | payload} | remote}

no loopback { dte | local | dual | network {line | payload} | remote}
```

Syntax Description	<i>dte</i>	Loopback after the line interface unit (LIU) towards the terminal.
	<i>local</i>	Loopback after going through the framer toward the terminal.
	<i>dual</i>	Sets both local loopback and network line loopback.
	network {line payload}	Sets the loopback toward the network before going through the framer (line) or after going through the framer (payload).
	<i>remote</i>	Sends FEAC to set remote in loopback.

Defaults	No loopback by default.
----------	-------------------------

Command Modes	Interface configuration
---------------	-------------------------

Command History	Release	Modification
	11.1	This command was introduced.
	11.3	This command was introduced.
	12.2(11)YT	This command was integrated into Cisco IOS Release 12.2(11)YT and implemented on the following platforms for E3: Cisco 2650XM, Cisco 2651XM, Cisco 2691, Cisco 3660 series, Cisco 3725, and Cisco 3745 routers.
	12.2(15)T	This command was integrated into Cisco IOS Release 12.2(15)T.
	12.2S	This command was integrated into Cisco IOS Release 12.2S.

Release	Modification
12.2(18)SXE	This command was integrated into Cisco IOS Release 12.2(18)SXE to support SPAs on the Cisco 7304 router. The dual keyword was added.
12.0(31)S	This command was integrated into Cisco IOS Release 12.0(31)S.
12.2(25)S3	This command was integrated into Cisco IOS Release 12.2(25)S3.

Usage Guidelines

Use the **loopback** command to diagnose problems on the local port, between the framer and the line interface unit (LIU) level.

Examples

The following example creates a loopback on slot 5, bay 0 after the LIU towards the terminal.

```
Router# configure terminal
Router(config)# interface serial 5/0/0
Router(config-if)# loopback dte
```

loopback driver

To enable internal loopback at the PHY device or transceiver level on a Gigabit Ethernet interface, use the **loopback driver** command in interface configuration mode. To disable loopback, use the **no** form of this command.

loopback driver

no loopback driver

Syntax Description	driver Enables internal loopback at the PHY device on the interface.	
Defaults	No default behavior or values	
Command Modes	Interface configuration	
Command History	Release	Modification
	11.2	This command was introduced.
	12.2 S	This command was integrated into Cisco IOS Release 12.2 S.
	12.2(20)S2	This command was implemented on the 2-Port 10/100/1000 Gigabit Ethernet SPA on the Cisco 7304 router.
Usage Guidelines	<p>You can use the loopback driver and loopback mac interface configuration commands with the 2-Port 10/100/1000 Gigabit Ethernet SPA. These commands do not apply to the 4-Port 10/100 Fast Ethernet SPA.</p> <p>To properly enable internal loopback, you must disable autonegotiation.</p>	
Examples	<p>The following example configures the second interface (port 1) on a 2-Port 10/100/1000 Gigabit Ethernet SPA to loop data back at the PHY device, where the SPA is installed in the bottom subslot (1) of the MSC, and the MSC is installed in slot 2 of the Cisco 7304 router. The no negotiation auto interface configuration command disables autonegotiation for a fiber interface:</p> <pre>Router(config)# interface gigabitethernet 2/1/1 Router(config-if)# no negotiation auto Router(config-if) loopback driver</pre>	
Related Commands	Command	Description
	loopback mac	Enables internal loopback at the MAC device on an interface.
	show interfaces gigabitethernet	Displays information about the Gigabit Ethernet interfaces.

loopback mac

To enable internal loopback at the MAC device on a Gigabit Ethernet interface, use the **loopback mac** command in interface configuration mode. To disable loopback, use the **no** form of this command.

loopback mac

no loopback mac

Syntax Description

mac	Enables internal loopback at the MAC device on the interface.
------------	---

Defaults

No default behavior or values

Command Modes

Interface configuration

Command History

Release	Modification
11.2	This command was introduced.
12.2 S	This command was integrated into Cisco IOS Release 12.2 S.
12.2(20)S2	This command was implemented on the 2-Port 10/100/1000 Gigabit Ethernet SPA on the Cisco 7304 router.

Usage Guidelines

You can use the **loopback mac** and **loopback driver** interface configuration commands with the 2-Port 10/100/1000 Gigabit Ethernet SPA. These commands do not apply to the 4-Port 10/100 Fast Ethernet SPA.

To properly enable internal loopback, you must disable autonegotiation.

Examples

The following example configures the second interface (port 1) on a 2-Port 10/100/1000 Gigabit Ethernet SPA to loop data back at the MAC device, where the SPA is installed in the bottom subslot (1) of the MSC, and the MSC is installed in slot 2 of the Cisco 7304 router. The **no negotiation auto** interface configuration command disables autonegotiation for a fiber interface:

```
Router(config)# interface gigabitethernet 2/1/1
Router(config-if)# no negotiation auto
Router(config-if) loopback mac
```

Related Commands

Command	Description
loopback driver	Enables internal loopback at the PHY device or transceiver level on an interface.
show interfaces gigabitethernet	Displays information about the Gigabit Ethernet interfaces.

mac-address

To modify the default MAC address of an interface to some user-defined address, use the **mac-address** command in interface configuration mode. To return to the default MAC address on the interface, use the **no** form of this command.

mac-address *ieee-address*

no mac-address *ieee-address*

Syntax Description

<i>ieee-address</i>	48-bit IEEE MAC address written as a dotted triple of four-digit hexadecimal numbers.
---------------------	---

Defaults

The interface uses a default MAC address that is derived from the base address stored in the electrically erasable programmable read-only memory (EEPROM) on the backplane of the Cisco 7304 router.

Command Modes

Interface configuration

Command History

Release	Modification
10.0	This command was introduced.
12.2 S	This command was integrated into Cisco IOS Release 12.2 S.
12.2(20)S2	This command was implemented on the 4-Port 10/100 Fast Ethernet SPA and the 2-Port 10/100/1000 Gigabit Ethernet SPA on the Cisco 7304 router.

Usage Guidelines

Be sure that no other interface on the network is using the MAC address that you assign.

Examples

The following example changes the default MAC address on the interface to 1111.2222.3333:

```
Router# configure terminal
Router(config)# interface fastethernet 2/1/1
Router(config-if)# mac-address 1111.2222.3333
```

Related Commands

Command	Description
show interfaces fastethernet	Displays information about the Fast Ethernet interfaces.
show interfaces gigabitethernet	Displays information about the Gigabit Ethernet interfaces.

mdl

To configure the Maintenance Data Link (MDL) message defined in the ANSI T1.107a-1990 specification, use the **mdl** command in controller configuration mode.

```
mdl [string {eic | fic | generator | lic | pfi | port | unit}string] [transmit {idle-signal | path | test-signal}]
```

```
no mdl [string {eic | fic | generator | lic | pfi | port | unit}string] [transmit {idle-signal | path | test-signal}]
```

Syntax Description

string eic <i>string</i>	Specifies the Equipment Identification Code; can be up to 10 characters.
string fic <i>string</i>	Specifies the Frame Identification Code; can be up to 10 characters.
string generator <i>string</i>	Specifies the Generator number string sent in the MDL Test Signal message; can be up to 38 characters.
string lic <i>string</i>	Specifies the Location Identification Code; can be up to 11 characters.
string pfi <i>string</i>	Specifies the Path Facility Identification Code sent in the MDL Path message; can be up to 38 characters.
string port <i>string</i>	Specifies the Port number string sent in the MDL Idle Signal message; can be up to 38 characters.
string unit <i>string</i>	Specifies the Unit Identification Code; can be up to 6 characters.
transmit idle-signal	Enables MDL Idle-Signal message transmission.
transmit path	Enables MDL Path message transmission.
transmit test-signal	Enables MDL Test-Signal message transmission.

Defaults

No default behavior or values

Command Modes

Controller configuration

Command History

Release	Modification
11.3	This command was introduced.
12.1(13)EX	This command was introduced on the Cisco 7304 router.
12.2(11)YT	This command was integrated into Cisco IOS Release 12.2(11)YT and implemented on the following platforms: Cisco 2650XM, Cisco 2651XM, Cisco 2691, Cisco 3660 series, Cisco 3725, and Cisco 3745 routers.
12.2(15)T	This command was integrated into Cisco IOS Release 12.2(15)T.
12.2(18)S	This command was introduced on Cisco 7304 routers running Cisco IOS Release 12.2 S.
12.2(18)SXE	This command was integrated into Cisco IOS Release 12.2(18)SXE to support SPAs on the Cisco 7304 router.
12.0(31)S	This command was integrated into Cisco IOS Release 12.0(31)S.
12.2(25)S3	This command was integrated into Cisco IOS Release 12.2(25)S3.

Usage Guidelines Use the **mdl** command to send msgs in maintainance data link in T3 c-bit framing mode.

Examples The following example sends a test signal on the maintenance data link.

```
Router# configure terminal  
Router(config)#controller t3 5/0/0  
Router(config-controller)#mdl transmit test-signal
```

Related Commands

Command	Description
controller	Configures a T1, E1, or T3 controller and enters controller configuration mode.
show controllers serial	Displays serial line statistics.

media-type (Gigabit Ethernet)

To specify the physical connection on a Gigabit Ethernet interface, use the **media-type** command in interface configuration mode. To restore the default value, use the **no** form of this command.

media-type { **rj45** | **gbic** }

no media-type { **rj45** | **gbic** }

Syntax Description	rj45	Specifies an RJ-45 physical connection. This is the default.
	gbic	Specifies a Gigabit Interface Converter (GBIC) or small-form factor pluggable (SFP) physical connection for fiber media.

Defaults	rj45
-----------------	-------------

Command Modes	Interface configuration
----------------------	-------------------------

Command History	Release	Modification
	12.1 E	This command was introduced.
	12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.
	12.2(20)S2	This command was implemented on the 2-Port 10/100/1000 Gigabit Ethernet SPA on the Cisco 7304 router.

Usage Guidelines	Use the media-type interface configuration command to modify the default physical media connection type from rj45 to gbic , to configure a Gigabit Ethernet interface to support fiber media using a GBIC or small form-factor pluggable (SFP) optical transceiver.
	RJ-45 is the only media type supported by the 4-Port 10/100 Fast Ethernet SPA on the Cisco 7304 router is RJ-45, so the media-type command does not apply.

Examples	The following example configures the second interface (port 1) on a 2-Port 10/100/1000 Gigabit Ethernet SPA for a fiber SFP, where the SPA is installed in the bottom subslot (1) of the MSC, and the MSC is installed in slot 2 of the Cisco 7304 router:
	<pre>Router(config)# interface gigabitethernet 2/1/1 Router(config-if) media-type gbic</pre>

Related Commands	Command	Description
	show interfaces gigabitethernet	Displays information about the Gigabit Ethernet interfaces.

negotiation

To enable advertisement of speed and duplex mode, and flow control on a Gigabit Ethernet interface, use the **negotiation** command in interface configuration mode. To disable automatic negotiation, use the **no negotiation auto** command.

negotiation { forced | auto }

no negotiation auto

Syntax Description	forced	Disables flow control and configures the Gigabit Ethernet interface in 1000/full-duplex mode.
	Note	This keyword is not supported on the 2-Port 10/100/1000 Gigabit Ethernet SPA on the Cisco 7304 router.
	auto	Enables the autonegotiation protocol to configure the speed, duplex, and automatic flow control of the Gigabit Ethernet interface.

Defaults negotiation auto

Command Modes Interface configuration

Command History	Release	Modification
	11.1 CC	This command was introduced.
	12.0(7)S, 12.0(6)T	The forced keyword was added.
	12.1(3a)E	The command was integrated into Cisco IOS Release 12.1 E and implemented on the Cisco 7200-I/O-GE+E controller.
	12.1(5)T	This command was integrated into Cisco IOS Release 12.1(5)T.
	12.2(20)S2	This command was implemented on the 2-Port 10/100/1000 Gigabit Ethernet SPA on the Cisco 7304 router. The forced keyword is not supported.

Usage Guidelines The **negotiation** command is applicable to the Gigabit Ethernet interface of the Cisco 7200-I/O-GE+E and interfaces on the 2-Port 10/100/1000 Gigabit Ethernet SPA that are using fiber media. The **negotiation auto** command is used instead of the **duplex** and **speed** commands (which are used on Ethernet and Fast Ethernet interfaces, and interfaces on the 2-Port 10/100/1000 Gigabit Ethernet SPA that are using RJ-45 media) to automatically configure the duplex and speed settings of the interfaces.

The **negotiation forced** command is used to configure the Gigabit Ethernet interface of the Cisco 7200-I/O-GE+E to be 1000/full-duplex only and to disable flow control. The **negotiation forced** command is not supported by the 2-Port 10/100/1000 Gigabit Ethernet SPA.

The Gigabit Ethernet interface of the Cisco 7200-I/O-GE+E and the interfaces on the 2-Port 10/100/1000 Gigabit Ethernet SPA that are using fiber media are restricted to 1000 Mbps/full duplex only. Autonegotiation advertises and negotiates only to these values.

Examples

The following example enables the second interface (port 1) on a 2-Port 10/100/1000 Gigabit Ethernet SPA for autonegotiation, where the SPA is installed in the bottom subslot (1) of the MSC, and the MSC is installed in slot 2 of the Cisco 7304 router:

```
Router(config)# interface gigabitethernet 2/1/1  
Router(config-if) media-type gbic  
Router(config-if) negotiation auto
```

The following example disables the second interface (port 1) on a 2-Port 10/100/1000 Gigabit Ethernet SPA for autonegotiation, where the SPA is installed in the bottom subslot (1) of the MSC, and the MSC is installed in slot 2 of the Cisco 7304 router:

```
Router(config)# interface gigabitethernet 2/1/1  
Router(config-if) no negotiation auto
```

Related Commands

Command	Description
show interfaces gigabitethernet	Displays information about the Gigabit Ethernet interfaces.

show c7300

To display the types and status of cards (NSEs, line cards, MSCs, and SPAs) installed in a Cisco 7300 series router, use the **show c7300** command in privileged EXEC configuration mode.

show c7300

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values

Command Modes Privileged EXEC

Command History	Release	Modification
	12.1(9)EX	This command was introduced.
	12.2(18)S	This command was integrated into Cisco IOS Release 12.2 S on the Cisco 7300 series routers.
	12.2(20)S2	The command output was modified to provide status on MSCs and SPAs on the Cisco 7304 router.

Usage Guidelines This command displays the types and status of cards (NSEs and line cards) installed in a Cisco 7300 series router. This command also displays whether your system is in compliance with line card configuration guidelines.

On the Cisco 7304 router, the command provides information about any modular services cards (MSCs) or shared port adapters (SPAs) that are installed.

For NSEs and line cards, empty slots are not displayed in the output. However, for SPAs, several status values are reported, including an empty subslot, which is reported as “missing.”

Examples The following example displays information about a Cisco 7304 router with an NSE-100, MSC-100s, and 4-Port 10/100 Fast Ethernet SPAs:

```
Router# show c7300
Slot      Card Type      Status      Insertion time
----      -
0,1       NSE100          Active      00:45:29 ago
2         7304-MSC-100    Active      00:44:36 ago
3         7304-MSC-100    Active      00:44:36 ago
4         7304-MSC-100    Active      00:44:36 ago
5         7304-MSC-100    Active      00:14:39 ago
```

The FPGA versions for the cards listed above are current

```
Shared Port Adapter information:
Slot/Subslot SPA Type      Status      Insertion time
-----
```

```

2/0      SPA-4FE-7304      ok      00:44:36 ago
2/1      SPA-4FE-7304      ok      00:44:36 ago
3/0      SPA-4FE-7304      ok      00:44:35 ago
3/1      not present      missing never
4/0      SPA-4FE-7304      ok      00:44:35 ago
4/1      SPA-4FE-7304      ok      00:44:35 ago
5/0      SPA-4FE-7304      ok      00:14:36 ago
5/1      SPA-4FE-7304      ok      00:14:36 ago

```

```

Network IO Interrupt Throttling:
  throttle count=1, timer count=1
  active=0, configured=1
  netint usec=3999, netint mask usec=200

```

Table 8-4 provides a description for each of the possible status fields for SPAs.

Table 8-4 SPA Status Field Descriptions

Status Field for SPAs	Description
booting	SPA is initializing.
failed	SPA is powered off due to five automatic recovery failures.
FW mismatch	An FPGA version mismatch with the Cisco IOS software has been detected for the SPA.
missing	SPA is not present in the MSC subslot.
not allowed online	SPA is not supported.
ok	SPA is operational.
stopped	SPA is deactivated by the hw-module subslot stop command.
unknown	SPA is in unrecognizable state.

Related Commands

Command	Description
show diag	Displays hardware information for any slot or the chassis.
show version ¹	Displays the configuration of the system hardware, the number of each interface type installed, the Cisco IOS software version, the names and sources of configuration files, and the boot images. Displays the configuration of the ROM monitor.

1. Refer to the Cisco IOS Release 12.2 command reference and master index publications.

show controllers fastethernet

To display Fast Ethernet interface information, transmission statistics and errors, and applicable MAC destination address and VLAN filtering tables, use the **show controllers fastethernet** command in privileged EXEC configuration mode.

show controllers fastethernet *slot/subslot/port* [**detail**]

Syntax Description	
<i>slot</i>	(Optional) Chassis slot number. Refer to the appropriate hardware manual for slot information. For MSCs, refer to the platform-specific SPA hardware installation guide or the corresponding “Identifying Slots and Subslots for MSCs and SPAs” topic in the platform-specific SPA software configuration guide.
<i>/subslot</i>	(Optional) Secondary slot number on a MSC where a SPA is installed. Refer to the platform-specific SPA hardware installation guide and the corresponding “Specifying the Interface Address on a SPA” topic in the platform-specific SPA software configuration guide for subslot information.
<i>/port</i>	(Optional) Port or interface number. Refer to the appropriate hardware manual for port information. For SPAs, refer to the corresponding “Specifying the Interface Address on a SPA” topics in the platform-specific SPA software configuration guide.
detail	Specifies display of additional low-level diagnostic information.

Defaults No default behavior or values

Command Modes Privileged EXEC

Command History	Release	Modification
	11.2	This command was introduced.
	12.2 S	This command was integrated into Cisco IOS Release 12.2 S.
	12.2(20)S2	This command was implemented on the 4-Port 10/100 Fast Ethernet SPA on the Cisco 7304 router and introduced a new address format and output.

Usage Guidelines The output from the **show controllers fastethernet** command for the 4-Port 10/100 Fast Ethernet SPA provides several different sections of information and statistics that are organized according to the internal hardware devices and the various paths in the flow of data on the SPA. The following sections are provided:

- Interface configuration information—[Table 8-5 on page 8-50](#)
- Media Access Control (MAC) device counters—[Table 8-6 on page 8-51](#)
- Field programmable gate array (FPGA) device counters—[Table 8-7 on page 8-52](#)

- SPA carrier card counters—[Table 8-8 on page 8-53](#)
- SPA error counters—[Table 8-9 on page 8-54](#)
- MAC destination address filtering table—[Table 8-10 on page 8-55](#)
- Virtual LAN (VLAN) filtering table—[Table 8-11 on page 8-56](#)
- Platform details (including Parallel Express Forwarding [PXF] information)—[Table 8-12 on page 8-57](#)

Several areas of the output are generally useful for diagnostic tasks performed by Cisco Systems technical support personnel only.

Examples

The following is sample output from the **show controllers fastethernet** command for the first interface (port 0) on a 4-Port 10/100 Fast Ethernet SPA that is located in the top subslot (0), of the MSC that is installed in slot 4 on a Cisco 7304 router:

```
Router# show controllers fastethernet 4/0/0
Interface FastEthernet4/0/0
  Hardware is SPA-4FE-7304
  Connection mode is auto-negotiation
  Interface state is up, link is up
  Configuration is Auto Speed, Auto Duplex
  Selected media-type is RJ45
  Promiscuous mode is off, VLAN filtering is enabled
  MDI crossover status: MDI
  Auto-negotiation configuration and status:
    Auto-negotiation is enabled and is completed
    Speed/duplex is resolved to 100 Mbps, full duplex
    Advertised capabilities: 10M/HD 10M/FD 100M/HD 100M/FD Pause capable (Asymmetric)
    Partner capabilities: 10M/HD 10M/FD 100M/HD 100M/FD Pause capable
MAC counters:
  Input: packets = 15, bytes = 1776
        FIFO full/reset removed = 0, error drop = 0
  Output: packets = 18, bytes = 2622
         FIFO full/reset removed = 0, error drop = 0
  Total pause frames: transmitted = 0, received = 0
FPGA counters:
  Input: Total (good & bad) packets: 15, TCAM drops: 4
        Satisfy (host-backpressure) drops: 0, CRC drops: 0
        PL3 RERRs: 0
  Output: EOP (SPI4) errors: 0
SPA carrier card counters:
  Input: packets = 11, bytes = 1476, drops = 0
  Output: packets = 18, bytes = 2550, drops = 0
  Egress flow control status: XON
  Per bay counters:
    General errors: input = 0, output = 0
    SPI4 errors: ingress dip4 = 0, egress dip2 = 0
SPA Error counters:
  SPI4 TX out of frame error = 2 (00:02:31 ago)
  SPI4 TX Train valid error = 1 (00:02:11 ago)
  SPI4 TX DIP4 error = 1 (00:01:30 ago)
  SPI4 RX out of frame error = 1 (00:00:36 ago)
  SPI4 RX DIP2 error = 1 (00:00:13 ago)
MAC destination address filtering table:
  Table entries: Total = 512, Used = 4, Available = 508
  Index MAC destination address      Mask
  ----
  1      0007.0ed3.ba80              ffff.ffff.ffff
  2      ffff.ffff.ffff              ffff.ffff.ffff
```

```

3      0100.0000.0000      0100.0000.0000
4      0100.0ccc.cccc      ffff.ffff.ffff
VLAN filtering table:
  Number of VLANs configured on this interface = 0
  Table entries: Total = 1024, Used = 2, Available = 1022
  Index  VLAN identifier  Enabled  Tunnel
  -----
  1          0             No        No
  2          0             Yes       No
Platform details:
  PXF tif number: 0x10

```

Table 8-5 describes the fields shown in the interface configuration section of the display. This section is useful for verifying the status of autonegotiation and configured parameters on the link, and the amount of traffic being handled by the interface.

Table 8-5 *show controllers Command Field Descriptions—Interface Section*

Field	Description
Interface	Name of the interface.
Hardware	Type of hardware.
Connection mode	Indicator of autonegotiation used to establish the connection.
Link	State of the link.
Configuration	Configuration of the speed and duplex operation on the interface.
Selected media-type	Interface port media type. RJ-45 is the only type supported on the 4-Port 10/100 Fast Ethernet SPA.
Promiscuous mode	State of promiscuous mode (on or off). When promiscuous mode is on, the SPA disables MAC destination address and VLAN filtering. When promiscuous mode is off, the SPA enables MAC destination address and VLAN filtering.
VLAN filtering	<p>Status of ternary content addressable memory (TCAM) filtering of VLANs (enabled or disabled). By default, the SPA always enables VLAN filtering.</p> <p>The SPA disables VLAN filtering if the TCAM table is full, or if the SPA is operating in promiscuous mode.</p> <p>Note VLAN filtering is not enabled or disabled using any command-line interface (CLI) command.</p>
MDI crossover status	State of the media dependent interface (MDI) for the PHY device on the specified interface. The possible values are MDI for straight-through cables or media dependent interface crossover (MDI-X) for crossover cables.
Auto-negotiation	State of autonegotiation (enabled or disabled) on the interface and its current status.
Speed/duplex is resolved to	Results of autonegotiated parameter values (speed and duplex) currently being used on the link.

Table 8-5 *show controllers Command Field Descriptions—Interface Section (continued)*

Field	Description
Advertised capabilities	<p>List of the possible combinations of speed and duplex modes (in <i>speed/duplex</i> format) and flow control that the local interface has advertised it supports to the remote device:</p> <ul style="list-style-type: none"> • For speed—10M is 10 Mbps, and 100M is 100 Mbps. • For duplex—HD is half duplex, and FD is full duplex. • For flow control—“Pause capable (Asymmetric)” means that the SPA advertises support of the PAUSE flow control bit and the ASM_DIR (asymmetric) flow control bit.
Partner capabilities	<p>List of the possible combinations of speed and duplex modes (in <i>speed/duplex</i> format) and flow control that the remote device has advertised it supports to the local interface:</p> <ul style="list-style-type: none"> • For speed—10M is 10 Mbps, and 100M is 100 Mbps. • For duplex—HD is half duplex, and FD is full duplex. • For flow control—“Pause capable” means that the remote device supports implementation of the PAUSE flow control bit; “Pause capable (Asymmetric)” means that the remote device supports implementation of the PAUSE flow control bit and the ASM_DIR (asymmetric) flow control bit.

[Table 8-6](#) describes the fields shown in the MAC counters section of the display. This section is useful for verifying the status of packets processed by the MAC device for the interface. This information is useful for Cisco Systems technical support personnel.

Table 8-6 *show controllers Command Field Descriptions—MAC Counters Section*

Field	Description
Input: packets, bytes	<p>Total number of packets and bytes received by the MAC device for the interface since it was activated or cleared.</p> <p>You can clear these counters using the clear counters privileged EXEC command.</p>
Input: FIFO full/reset removed	<p>Total number of packets removed by the MAC device due to a first-in, first-out (FIFO) overflow condition in the input buffer for the interface.</p>
Input: error drop	<p>Total number of input packets with errors that are dropped by the MAC device for the interface.</p>
Output: packets, bytes	<p>Total number of packets and bytes transmitted by the MAC device for the interface since it was activated or cleared.</p> <p>You can clear these counters using the clear counters privileged EXEC command.</p>

Table 8-6 *show controllers Command Field Descriptions—MAC Counters Section (continued)*

Field	Description
Output: FIFO full/reset removed	Total number of packets removed by the MAC device due to a first-in, first-out (FIFO) overflow condition in the output buffer for the interface.
Output: error drop	Total number of output packets with errors that are dropped by the MAC device for the interface.
Total pause frames	Total number of Ethernet 802.3x pause frames transmitted and received by the MAC device for flow control on the interface.

Table 8-7 describes the fields shown in the FPGA counters section of the display. This section is useful for verifying the status of packets processed by the FPGA device for the interface. This information is useful for Cisco Systems technical support personnel.

Table 8-7 *show controllers Command Field Descriptions—FPGA Counters Section*

Field	Description
Input: Total (good & bad) packets	Total number of packets received by the FPGA device in the ingress direction for the interface.
Input: TCAM drops	Total number of packets dropped by the FPGA device in the ingress direction for the interface due to a ternary content addressable memory (TCAM) lookup failure. This counter increments when the interface receives a frame with a destination MAC address or VLAN identifier that is not present in the TCAM table.
Input: Satisfy (host-backpressure) drops	Total number of packets dropped by the FPGA device in the ingress direction for the interface due to back-pressure from the MSC.
Input: CRC drops	Total number of packets dropped by the FPGA device in the ingress direction for the interface due to cyclic redundancy check (CRC) errors.
Input: PL3 RERRs	Total number of packets with errors received for the interface by the FPGA device in the ingress direction over the System Packet Interface Level 3 (SPI3) (also called PL3) path from the MAC device to the FPGA device.
Output: EOP (SPI4) errors	Total number of packets with end-of-packet (EOP) errors received by the FPGA device in the egress direction for the interface over the System Packet Interface Level 4 (SPI4) path from the MSC to the FPGA device.

Table 8-8 describes the fields shown in the SPA carrier card counters section of the display. This section is useful for verifying the status of packets processed by the MSC for the interface. This information is useful for Cisco Systems technical support personnel.

Table 8-8 *show controllers Command Field Descriptions—SPA Carrier Card Counters Section*

Field	Description
Input: packets, bytes, drops	Total number of packets, bytes, and packet drops that have occurred on the SPI4 path from the FPGA device to the MSC.
Output: packets, bytes, drops	Total number of packets, bytes, and packet drops that have occurred on the SPI4 path from the MSC to the FPGA device.
Egress flow control status	Status of flow control between the MSC and the Route Processor (RP). The possible values are: <ul style="list-style-type: none"> • XON—A control frame has been sent by the MSC to the RP to indicate that the MSC is ready to accept data. • XOFF—A control frame has been sent by the MSC to the RP to indicate congestion on the MSC. The MSC cannot accept any more data from the RP during this condition.
General errors	Total number of errors (such as parity) on the MSC in the ingress and egress direction.
SPI4 errors: ingress dip4	Total number of 4-bit Diagonal Interleaved Parity (DIP4) errors in the ingress direction on the SPI4 path from the FPGA device to the MSC. DIP4 is a parity algorithm where a 4-bit odd parity is computed diagonally over control and data words.
SPI4 errors: egress dip2	Total number of 2-bit Diagonal Interleaved Parity (DIP2) errors in the egress direction on the SPI4 path from the FPGA device to the MSC. DIP2 is a parity algorithm where a 2-bit odd parity is computed diagonally over status words.

[Table 8-9](#) describes the fields shown in the SPA error counters section of the display. This section appears only when one of the SPI4 transmit or receive errors occurs on the interface. This information is useful for Cisco Systems technical support personnel.

**Note**

None of the SPA SPI4 error counters appear in **show controllers fastethernet** command output until at least one of those types of SPI4 errors occurs.

All of the errors in the SPA error counters section are subject to the SPA automatic recovery process when certain thresholds are reached.

Table 8-9 *show controllers Command Field Descriptions—SPA Error Counters Section*

Field	Description
SPI4 TX out of frame error = (hh:mm:ss ago)	<p>Number of SPI4 out-of-frame errors (events) detected in the transmit direction (toward the network), from the MSC to the SPA FPGA device. The time stamp indicates how long ago (in hours:minutes:seconds) from the current system time, that the last error was detected.</p> <p>This error indicates a loss of synchronization between the synchronization block and the data received on the SPI4 path. When synchronization is reacquired, the error no longer occurs.</p>
SPI4 TX Train valid error = (hh:mm:ss ago)	<p>Number of times that a low-level synchronization problem was detected in the transmit direction (toward the network), from the MSC to the SPA FPGA device. The time stamp indicates how long ago (in hours:minutes:seconds) from the current system time, that the last error was detected.</p>
SPI4 TX DIP4 error = (hh:mm:ss ago)	<p>Number of 4-bit Diagonal Interleaved Parity (DIP4) errors in the transmit direction (toward the network), from the MSC to the SPA FPGA device. The time stamp indicates how long ago (in hours:minutes:seconds) from the current system time, that the last error was detected.</p> <p>DIP4 is a parity algorithm where a 4-bit odd parity is computed diagonally over control and data words.</p>
SPI4 RX out of frame error = (hh:mm:ss ago)	<p>Number of SPI4 out-of-frame errors (events) detected in the receive direction (from the network), from the SPA FPGA device to the MSC. The time stamp indicates how long ago (in hours:minutes:seconds) from the current system time, that the last error was detected.</p> <p>This error indicates a loss of synchronization between the synchronization block and the data received on the SPI4 path. When synchronization is reacquired, the error no longer occurs.</p>
SPI4 RX DIP2 error = (hh:mm:ss ago)	<p>Number of 2-bit Diagonal Interleaved Parity (DIP2) errors in the receive direction (from the network), from the SPA FPGA device to the MSC. The time stamp indicates how long ago (in hours:minutes:seconds) from the current system time, that the last error was detected.</p> <p>DIP2 is a parity algorithm where a 2-bit odd parity is computed diagonally over status words.</p>

[Table 8-10](#) describes the fields shown in the MAC destination address filtering table section of the display. This section is useful for verifying the multicast destination addresses that are in the TCAM table and permitted by the interface. This information is useful for Cisco Systems technical support personnel.

Table 8-10 *show controllers Command Field Descriptions—MAC Destination Address Filtering Table Section*

Field	Description
Table entries: Total, Used, Available	<p>Total number of MAC destination address entries possible in the TCAM table for the interface, the number of table entries currently used by the interface, and the number of table entries that remain available.</p> <p>The 4-Port 10/100 Fast Ethernet SPA supports a 512-entry MAC filtering table for each supported interface (2048 entries total on the card).</p>
Index	Table entry identifier.
MAC destination address	<p>MAC destination address (multicast) permitted by the interface and used in the TCAM lookup table for packet filtering.</p> <p>The multicast MAC entries typically come from routing protocols [such as Open Shortest Path First (OSPF) and Enhanced IGRP (EIGRP)], and other protocols including the Hot Standby Router Protocol (HSRP).</p> <p>When the router reloads, three addresses appear by default in the MAC filtering table: the unicast address of the local interface, the Ethernet broadcast address, and the Ethernet multicast address.</p>
Mask	Mask for the corresponding destination address. The SPA uses the bits that are set in the mask to look up the address in the TCAM table.

[Table 8-11](#) describes the fields shown in the VLAN filtering table section of the display. This section is useful for verifying the VLANs that are in the TCAM table and are permitted by the interface. This information is useful for Cisco Systems technical support personnel.

Table 8-11 *show controllers Command Field Descriptions—VLAN Filtering Table Section*

Field	Description
Number of VLANs configured on this interface	<p>Number of VLANs that are configured on the interface.</p> <p>If the number of VLANs configured on the interface is 1022 or less, then the VLAN filtering table also shows an index entry for every VLAN ID. The number of VLANs configured on the interface can be 0, while the number of used table entries reports 2, because the SPA always uses two entries to provide valid matching criteria for promiscuous mode and non-VLAN packets.</p>
Table entries: Total, Used, Available	<p>Total number of VLAN entries possible in the TCAM filtering table for the interface, the number of table entries currently used by the interface (two are always in use by default), and the number of table entries that remain available.</p> <p>The 4-Port 10/100 Fast Ethernet SPA supports a 1024-entry VLAN filtering table for each supported interface (4096 entries total on the card).</p>
Index	Table entry identifier.
VLAN identifier	<p>Number of the VLAN. Two VLAN ID 0 entries always appear in the table and represent the local interface port for handling of promiscuous mode and non-VLAN packets.</p> <p>Other VLAN entries appear in this table when VLANs are configured on the interface.</p>

Table 8-11 *show controllers Command Field Descriptions—VLAN Filtering Table Section*

Field	Description
Enabled	<p>Status of the VLAN ID for TCAM filtering, with the following possible values:</p> <ul style="list-style-type: none"> • No—The entry is disabled for filtering. • Yes—The entry is enabled for filtering. <p>The TCAM filter uses the “first-match” rule to filter packets that the SPA receives against entries in the table. The matching assessment begins at the top of the table with the VLAN ID 0 entries.</p> <p>Note The SPA always supports two VLAN ID 0 entries. The first VLAN ID 0 entry of the TCAM table is used for promiscuous mode. It has a value of “No,” meaning it is disabled, whenever promiscuous mode is disabled for the interface. The second VLAN ID 0 entry is used for filtering of non-VLAN packets.</p>
Tunnel	<p>Status of tunneling for the interface, with the following possible values:</p> <ul style="list-style-type: none"> • No—Tunneling is disabled and the SPA performs MAC destination address filtering. • Yes—Tunneling is enabled and the SPA does not perform MAC destination address filtering. <p>Note If promiscuous mode is enabled, then the first VLAN ID 0 entry shows tunnel = Yes. All other VLAN ID entries show tunnel = No.</p>

[Table 8-12](#) describes the fields shown in the Platform details section of the display.

Table 8-12 *show controllers Command Field Descriptions—Platform Details Section*

Field	Description
PXF tif number	Number of the interface (in hexadecimal format) used for PXF on the network services engine (NSE) or by the Hyper Transport (HT) FPGA device on the network processing engine (NPE).

Related Commands

Command	Description
show interfaces fastethernet	Displays information about the Fast Ethernet interfaces.

show controllers gigabitethernet

To display Gigabit Ethernet interface information, transmission statistics and errors, and applicable MAC destination address and VLAN filtering tables, use the **show controllers gigabitethernet** command in privileged EXEC configuration mode.

show controllers gigabitethernet *slot/subslot/port* [**detail**]

Syntax Description	
<i>slot</i>	(Optional) Chassis slot number. Refer to the appropriate hardware manual for slot information. For MSCs, refer to the platform-specific SPA hardware installation guide or the corresponding “Identifying Slots and Subslots for MSCs and SPAs” topic in the platform-specific SPA software configuration guide.
<i>/subslot</i>	(Optional) Secondary slot number on a MSC where a SPA is installed. Refer to the platform-specific SPA hardware installation guide and the corresponding “Specifying the Interface Address on a SPA” topic in the platform-specific SPA software configuration guide for subslot information.
<i>/port</i>	(Optional) Port or interface number. Refer to the appropriate hardware manual for port information. For SPAs, refer to the corresponding “Specifying the Interface Address on a SPA” topics in the platform-specific SPA software configuration guide.
detail	Specifies display of additional low-level diagnostic information.

Defaults No default behavior or values

Command Modes Privileged EXEC

Command History	Release	Modification
	11.2	This command was introduced.
	12.2 S	This command was integrated into Cisco IOS Release 12.2 S.
	12.2(20)S2	This command was implemented on the 2-Port 10/100/1000 Gigabit Ethernet SPA on the Cisco 7304 router with a new address format and output.

Usage Guidelines The output from the **show controllers gigabitethernet** command for the 2-Port 10/100/1000 Gigabit Ethernet SPA provides several different sections of information and statistics that are organized according to the internal hardware devices and the various paths in the flow of data on the SPA. The following sections are provided:

- Interface configuration information—[Table 8-13 on page 8-61](#)
- Media Access Control (MAC) device counters—[Table 8-14 on page 8-62](#)
- Field Programmable Gate Array (FPGA) device counters—[Table 8-15 on page 8-63](#)

- SPA carrier card counters—[Table 8-16 on page 8-64](#)
- SPA error counters—[Table 8-17 on page 8-65](#)
- MAC destination address filtering table—[Table 8-18 on page 8-66](#)
- Virtual LAN (VLAN) filtering table—[Table 8-19 on page 8-67](#)
- Platform details, including Parallel Express Forwarding (PXF) information—[Table 8-20 on page 8-68](#)

Several areas of the output are generally useful for diagnostic tasks performed by technical support only.

Examples

The following is sample output from the **show controllers gigabitethernet** command for the first RJ-45 interface (port 0) in a 2-Port 10/100/1000 Gigabit Ethernet SPA located in the top subslot (0) of the MSC that is installed in slot 5 on a Cisco 7304 router. This output also shows the SPA Error counters section that appears only if one of the types of SPI4 errors occurs on the interface:

```
Router# show controllers gigabitethernet 5/0/0
Interface GigabitEthernet5/0/0
  Hardware is SPA-2GE-7304
  Connection mode is auto-negotiation
  Interface state is up, link is up
  Configuration is Auto Speed, Auto Duplex
  Selected media-type is RJ45
  Promiscuous mode is off, VLAN filtering is enabled
  MDI crossover status: MDIX
  Auto-negotiation configuration and status:
    Auto-negotiation is enabled and is completed
    Speed/duplex is resolved to 1000 Mbps, full duplex
    Advertised capabilities: 10M/HD 10M/FD 100M/HD 100M/FD 1000M/HD 1000M/FD
                           Pause capable (Asymmetric)
    Partner capabilities: 10M/HD 10M/FD 100M/HD 100M/FD 1000M/FD Pause capable
MAC counters:
  Input: packets = 0, bytes = 0
        FIFO full/reset removed = 0, error drop = 0
  Output: packets = 1, bytes = 64
         FIFO full/reset removed = 0, error drop = 0
  Total pause frames: transmitted = 0, received = 0
FPGA counters:
  Input: Total (good & bad) packets: 0, TCAM drops: 0
        Satisfy (host-backpressure) drops: 0, CRC drops: 0
        PL3 RERRs: 0
  Output: EOP (SPI4) errors: 0
SPA carrier card counters:
  Input: packets = 0, bytes = 0, drops = 0
  Output: packets = 1, bytes = 60, drops = 0
  Egress flow control status: XON
  Per bay counters:
    General errors: input = 0, output = 0
    SPI4 errors: ingress dip4 = 0, egress dip2 = 0
SPA Error counters:
  SPI4 TX out of frame error = 2 (00:02:31 ago)
  SPI4 TX Train valid error = 1 (00:02:11 ago)
  SPI4 TX DIP4 error = 1 (00:01:30 ago)
  SPI4 RX out of frame error = 1 (00:00:36 ago)
  SPI4 RX DIP2 error = 1 (00:00:13 ago)
MAC destination address filtering table:
  Table entries: Total = 1024, Used = 3, Available = 1021
  Index MAC destination address      Mask
  ----
  1      00b0.64ff.5aa0              ffff.ffff.ffff
```

show controllers gigabitethernet

```

2      ffff.ffff.ffff      ffff.ffff.ffff
3      0100.0000.0000      0100.0000.0000
VLAN filtering table:
Number of VLANs configured on this interface = 0
Table entries: Total = 2048, Used = 2, Available = 2046
Index  VLAN identifier  Enabled  Tunnel
-----
1      0                No       No
2      0                Yes      No
Platform details:
  PXF tif number: 0x10

```

The following is sample output from the **show controllers gigabitethernet** command for the first fiber interface (port 0) in a 2-Port 10/100/1000 Gigabit Ethernet SPA located in the bottom subslot (1) of the MSC that is installed in slot 4 on a Cisco 7304 router:

```

Router# show controllers gigabitethernet 4/1/0
Interface GigabitEthernet4/1/0
  Hardware is SPA-2GE-7304
  Connection mode is auto-negotiation
  Interface state is up, link is up
  Configuration is Auto Speed, Auto Duplex
  Selected media-type is GBIC, GBIC type is 1000BaseSX
  SFP is present, LOS: no, Tx fault: no, Security check status: Pass
  Promiscuous mode is off, VLAN filtering is enabled
  MDI configuration is automatic crossover, status is MDI
  Auto-negotiation configuration and status:
    Auto-negotiation is enabled and is completed
    Speed/duplex is resolved to 1000 Mbps, full duplex
    Advertised capabilities: 1000BaseX/FD Pause capable (Asymmetric)
    Partner capabilities: 1000BaseX/FD Pause capable(Asymmetric)
  MAC counters:
    Input: packets = 213, bytes = 21972
           FIFO full/reset removed = 0, error drop = 0
    Output: packets = 216, bytes = 22932
           FIFO full/reset removed = 0, error drop = 0
    Total pause frames: transmitted = 0, received = 0
  FPGA counters:
    Input: Total (good & bad) packets: 213, TCAM drops: 183
           Satisfy (host-backpressure) drops: 0, CRC drops: 0
           PL3 RERRs: 0
    Output: EOP (SPI4) errors: 0
  SPA carrier card counters:
    Input: packets = 30, bytes = 10140, drops = 0
    Output: packets = 216, bytes = 22068, drops = 0
    Egress flow control status: XON
    Per bay counters:
      General errors: input = 0, output = 0
      SPI4 errors: ingress dip4 = 0, egress dip2 = 0
  MAC destination address filtering table:
    Table entries: Total = 1024, Used = 4, Available = 1020
    Index MAC destination address      Mask
    -----
    1      0007.0ed3.ba88              ffff.ffff.ffff
    2      ffff.ffff.ffff              ffff.ffff.ffff
    3      0100.0000.0000              0100.0000.0000
    4      0100.0ccc.cccc              ffff.ffff.ffff
  VLAN filtering table:
    Number of VLANs configured on this interface = 0
    Table entries: Total = 2048, Used = 2, Available = 2046
    Index  VLAN identifier  Enabled  Tunnel
    -----
    1      0                No       No

```

```

2          0          Yes    No
Platform details:
  PXF tif number: 0x14

```

Table 8-13 describes the fields shown in the interface configuration section of the display. This section is useful for verifying the status of autonegotiation and configured parameters on the link, and the amount of traffic being handled by the interface.

Table 8-13 *show controllers Command Field Descriptions—Interface Section*

Field	Description
Interface	Name of the interface.
Hardware	Type of hardware.
Connection mode	Indicator of autonegotiation used to establish the connection.
Link	State of the link.
Configuration	Configuration of the speed and duplex operation on the interface.
Selected media-type	Interface port media type: RJ45 or Gigabit Interface Converter (GBIC).
GBIC type is	GBIC interface type: 1000BaseSX, 1000BaseLX, or 1000BaseZX
SFP is	Indicates presence of an SFP optical transceiver.
LOS	Indicates whether or not the SFP detects a loss of signal (LOS).
Tx fault	Indicates whether or not the SFP detects a transmission fault.
Security check status	Indicates whether or not the SFP passes the security check. The SPA enables a security check by default to verify whether a Cisco-approved SFP is inserted. If the SFP is not a Cisco-approved device, the link is brought down.
Promiscuous mode	State of promiscuous mode (on or off). When promiscuous mode is on, the SPA disables MAC destination address and VLAN filtering. When promiscuous mode is off, the SPA enables MAC destination address and VLAN filtering.
VLAN filtering	<p>Status of ternary content addressable memory (TCAM) filtering of VLANs (enabled or disabled). By default, the SPA always enables VLAN filtering.</p> <p>The SPA disables VLAN filtering if the TCAM table is full, or if the SPA is operating in promiscuous mode.</p> <p>Note VLAN filtering is not enabled or disabled using any command-line interface (CLI) command.</p>
MDI crossover status	State of the media dependent interface (MDI) for the PHY device on the specified interface. The possible values are MDI for straight-through cables or media dependent interface crossover (MDI-X) for crossover cables.
Auto-negotiation	State of autonegotiation (enabled or disabled) on the interface and its current status.

Table 8-13 *show controllers Command Field Descriptions—Interface Section (continued)*

Field	Description
Speed/duplex is resolved to	Results of autonegotiated parameter values (speed and duplex) currently being used on the link.
Advertised capabilities	<p>List of the possible combinations of speed and duplex modes (in <i>speed/duplex</i> format) and flow control that the local interface has advertised it supports to the remote device:</p> <ul style="list-style-type: none"> For speed—10M is 10 Mbps, 100M is 100 Mbps, and 1000M is 1000 Mbps. For duplex—HD is half duplex, and FD is full duplex. For flow control—“Pause capable (Asymmetric)” means that the SPA advertises support of the PAUSE flow control bit and the ASM_DIR (asymmetric) flow control bit.
Partner capabilities	<p>List of the possible combinations of speed and duplex modes (in <i>speed/duplex</i> format) and flow control that the remote device has advertised it supports to the local interface:</p> <ul style="list-style-type: none"> For speed—10M is 10 Mbps, 100M is 100 Mbps, and 1000M is 1000 Mbps. For duplex—HD is half duplex, and FD is full duplex. For flow control—“Pause capable” means that the remote device supports implementation of the PAUSE flow control bit; “Pause capable (Asymmetric)” means that the remote device supports implementation of the PAUSE flow control bit and the ASM_DIR (asymmetric) flow control bit.

Table 8-14 describes the fields shown in the MAC counters section of the display. This section is useful for verifying the status of packets processed by the MAC device for the interface. This information is useful for Cisco Systems technical support personnel.

Table 8-14 *show controllers Command Field Descriptions—MAC Counters Section*

Field	Description
Input: packets, bytes	<p>Total number of packets and bytes received by the MAC device for the interface since it was activated or cleared.</p> <p>You can clear these counters using the clear counters privileged EXEC command.</p>
Input: FIFO full/reset removed	Total number of packets removed by the MAC device due to a first-in, first-out (FIFO) overflow condition in the input buffer for the interface.
Input: error drop	Total number of input packets with errors that are dropped by the MAC device for the interface.

Table 8-14 *show controllers Command Field Descriptions—MAC Counters Section (continued)*

Field	Description
Output: packets, bytes	Total number of packets and bytes transmitted by the MAC device for the interface since it was activated or cleared. You can clear these counters using the clear counters privileged EXEC command.
Output: FIFO full/reset removed	Total number of packets removed by the MAC device due to a first-in, first-out (FIFO) overflow condition in the output buffer for the interface.
Output: error drop	Total number of output packets with errors that are dropped by the MAC device for the interface.
SPI3: disabled port drop	Total number of packets dropped by the MAC device at the System Packet Interface Level 3 (SPI3) path between the MAC device and FPGA device due to a disabled port condition.
SPI3: sync error drop	Total number of packets dropped by the MAC device at the SPI3 path between the MAC device and FPGA device due to a sync error (synchronization bits altered) condition.
SPI3: short packet drop	Total number of packets dropped by the MAC device at the SPI3 path between the MAC device and FPGA device due to a short packet (packet length is less than 64 bytes) condition.
SPI3: parity error drop	Total number of packets dropped by the MAC device at the path between the MAC device and FPGA device due to a parity error (parity bit is altered during data transmission) condition.
Total pause frames	Total number of Ethernet 802.3x pause frames transmitted and received by the MAC device for flow control on the interface.

Table 8-15 describes the fields shown in the FPGA counters section of the display. This section is useful for verifying the status of packets processed by the FPGA device for the interface. This information is useful for Cisco Systems technical support personnel.

Table 8-15 *show controllers Command Field Descriptions—FPGA Counters Section*

Field	Description
Input: Total (good & bad) packets	Total number of packets received by the FPGA device in the ingress direction for the interface.
Input: TCAM drops	Total number of packets dropped by the FPGA device in the ingress direction for the interface due to a ternary content addressable memory (TCAM) lookup failure. This counter increments when the interface receives a frame with a destination MAC address or VLAN identifier that is not present in the TCAM table.
Input: Satisfy (host-backpressure) drops	Total number of packets dropped by the FPGA device in the ingress direction for the interface due to back-pressure from the MSC.

Table 8-15 *show controllers Command Field Descriptions—FPGA Counters Section (continued)*

Field	Description
Input: CRC drops	Total number of packets dropped by the FPGA device in the ingress direction for the interface due to cyclic redundancy check (CRC) errors.
Input: PL3 RERRs	Total number of packets with errors received for the interface by the FPGA device in the ingress direction over the SPI3 (PL3) path from the MAC device to the FPGA device.
Output: EOP (SPI4) errors	Total number of packets with end-of-packet (EOP) errors received by the FPGA device in the egress direction for the interface over the System Packet Interface Level 4 (SPI4) path from the MSC to the FPGA device.

Table 8-16 describes the fields shown in the SPA carrier card counters section of the display. This section is useful for verifying the status of packets processed by the MSC for the interface. This information is useful for Cisco Systems technical support personnel.

Table 8-16 *show controllers Command Field Descriptions—SPA Carrier Card Counters Section*

Field	Description
Input: packets, bytes, drops	Total number of packets, bytes, and packet drops that have occurred on the SPI4 path from the FPGA device to the MSC.
Output: packets, bytes, drops	Total number of packets, bytes, and packet drops that have occurred on the SPI4 path from the MSC to the FPGA device.
Egress flow control status	Status of flow control between the MSC and the Route Processor (RP). The possible values are: <ul style="list-style-type: none"> XON—A control frame has been sent by the MSC to the RP to indicate that the MSC is ready to accept data. XOFF—A control frame has been sent by the MSC to the RP to indicate congestion on the MSC. The MSC cannot accept any more data from the RP during this condition.
General errors	Total number of errors (such as parity) on the MSC in the ingress and egress direction.
SPI4 errors: ingress dip4	Total number of 4-bit Diagonal Interleaved Parity (DIP4) errors in the ingress direction on the SPI4 path from the FPGA device to the MSC. DIP4 is a parity algorithm where a 4-bit odd parity is computed diagonally over control and data words.
SPI4 errors: egress dip2	Total number of 2-bit Diagonal Interleaved Parity (DIP2) errors in the egress direction on the SPI4 path from the FPGA device to the MSC. DIP2 is a parity algorithm where a 2-bit odd parity is computed diagonally over status words.

Table 8-17 describes the fields shown in the SPA error counters section of the display. This section appears only when one of the SPI4 transmit or receive errors occurs on the interface. This information is useful for Cisco Systems technical support personnel.

**Note**

None of the SPA SPI4 error counters appear in **show controllers fastethernet** command output until at least one of those types of SPI4 errors occurs.

All of the errors in the SPA error counters section are subject to the SPA automatic recovery process when certain thresholds are reached.

Table 8-17 *show controllers Command Field Descriptions—SPA Error Counters Section*

Field	Description
SPI4 TX out of frame error = (hh:mm:ss ago)	<p>Number of SPI4 out of frame errors (events) detected in the transmit direction (toward the network), from the MSC to the SPA FPGA device. The time stamp indicates how long ago (in hours:minutes:seconds) from the current system time, that the last error was detected.</p> <p>This error indicates a loss of synchronization between the synchronization block and the data received on the SPI4 path. When synchronization is reacquired, the error no longer occurs.</p>
SPI4 TX Train valid error = (hh:mm:ss ago)	<p>Number of times that a low-level synchronization problem was detected in the transmit direction (toward the network), from the MSC to the SPA FPGA device. The time stamp indicates how long ago (in hours:minutes:seconds) from the current system time, that the last error was detected.</p>
SPI4 TX DIP4 error = (hh:mm:ss ago)	<p>Number of 4-bit Diagonal Interleaved Parity (DIP4) errors in the transmit direction (toward the network), from the MSC to the SPA FPGA device. The time stamp indicates how long ago (in hours:minutes:seconds) from the current system time, that the last error was detected.</p> <p>DIP4 is a parity algorithm where a 4-bit odd parity is computed diagonally over control and data words.</p>

Table 8-17 *show controllers Command Field Descriptions—SPA Error Counters Section*

Field	Description
SPI4 RX out of frame error = (hh:mm:ss ago)	<p>Number of SPI4 out of frame errors (events) detected in the receive direction (from the network), from the SPA FPGA device to the MSC. The time stamp indicates how long ago (in hours:minutes:seconds) from the current system time, that the last error was detected.</p> <p>This error indicates a loss of synchronization between the synchronization block and the data received on the SPI4 path. When synchronization is reacquired, the error no longer occurs.</p>
SPI4 RX DIP2 error = (hh:mm:ss ago)	<p>Number of 2-bit Diagonal Interleaved Parity (DIP2) errors in the receive direction (from the network), from the SPA FPGA device to the MSC. The time stamp indicates how long ago (in hours:minutes:seconds) from the current system time, that the last error was detected.</p> <p>DIP2 is a parity algorithm where a 2-bit odd parity is computed diagonally over status words.</p>

Table 8-18 describes the fields shown in the MAC destination address filtering table section of the display. This section is useful for verifying the multicast destination addresses that are in the TCAM table and permitted by the interface. This information is useful for Cisco Systems technical support personnel.

Table 8-18 *show controllers Command Field Descriptions—MAC Destination Address Filtering Table Section*

Field	Description
Table entries: Total, Used	<p>Total number of MAC destination address entries possible in the TCAM table for the interface, and the number of table entries currently used by the interface.</p> <p>The 2-Port 10/100/1000 Gigabit Ethernet SPA supports a 512-entry MAC filtering table for each supported interface (1024 entries total on the card).</p>
Index	Table entry identifier.

Table 8-18 *show controllers Command Field Descriptions—MAC Destination Address Filtering Table Section (continued)*

Field	Description
MAC destination address	<p>MAC destination address (multicast) permitted by the interface and used in the TCAM lookup table for packet filtering.</p> <p>The multicast MAC entries typically come from routing protocols [such as Open Shortest Path First (OSPF) and Enhanced IGRP (EIGRP)], and other protocols including the Hot Standby Router Protocol (HSRP).</p> <p>When the router reloads, three addresses appear by default in the MAC filtering table: the unicast address of the local interface, the Ethernet broadcast address, and the Ethernet multicast address.</p>
Mask	Mask for the corresponding destination address. The SPA uses the bits that are set in the mask to look up the address in the TCAM table.

Table 8-19 describes the fields shown in the VLAN filtering table section of the display. This section is useful for verifying the VLANs that are in the TCAM table and are permitted by the interface. This information is useful for Cisco Systems technical support personnel.

Table 8-19 *show controllers Command Field Descriptions—VLAN Filtering Table Section*

Field	Description
Number of VLANs configured on this interface	<p>Number of VLANs that are configured on the interface.</p> <p>If the number of VLANs configured on the interface is 1022 or less, then the VLAN filtering table also shows an index entry for every VLAN ID. The number of VLANs configured on the interface can be 0, while the number of used table entries reports 2, because the SPA always uses two entries to provide valid matching criteria for promiscuous mode and non-VLAN packets.</p>
Table entries: Total, Used, Available	<p>Total number of VLAN entries possible in the TCAM filtering table for the interface, the number of table entries currently used by the interface (two are always in use by default), and the number of table entries that remain available.</p> <p>The 2-Port 10/100/1000 Gigabit Ethernet SPA supports a 1024-entry VLAN filtering table for each supported interface (2048 entries total on the card).</p>
Index	Table entry identifier.
VLAN identifier	<p>Number of the VLAN. Two VLAN ID 0 entries always appear in the table and represent the local interface port for handling of promiscuous mode and non-VLAN packets.</p> <p>Other VLAN entries appear in this table when VLANs are configured on the interface.</p>

Table 8-19 *show controllers Command Field Descriptions—VLAN Filtering Table Section*

Field	Description
Enabled	<p>Status of the VLAN ID for TCAM filtering, with the following possible values:</p> <ul style="list-style-type: none"> No—The entry is disabled for filtering. Yes—The entry is enabled for filtering. <p>The TCAM filter uses the “first-match” rule to filter packets that the SPA receives against entries in the table. The matching assessment begins at the top of the table with the VLAN ID 0 entries.</p> <p>Note The SPA always supports two VLAN ID 0 entries. The first VLAN ID 0 entry of the TCAM table is used for promiscuous mode. It has a value of “No,” meaning it is disabled, whenever promiscuous mode is disabled for the interface. The second VLAN ID 0 entry is used for filtering of non-VLAN packets.</p>
Tunnel	<p>Status of tunneling for the interface, with the following possible values:</p> <ul style="list-style-type: none"> No—Tunneling is disabled and the SPA performs MAC destination address filtering. Yes—Tunneling is enabled and the SPA does not perform MAC destination address filtering. <p>Note If promiscuous mode is enabled, then the first VLAN ID 0 entry shows tunnel = Yes. All other VLAN ID entries show tunnel = No.</p>

Table 8-20 describes the fields shown in the platform details section of the display.

Table 8-20 *show controllers Command Field Descriptions—Platform Details Section*

Field	Description
PXF tif number	Number of the interface (in hexadecimal format) used for PXF on the network services engine (NSE) or by the Hyper Transport (HT) FPGA device on the network processing engine (NPE).

Related Commands

Command	Description
show interfaces gigabitethernet	Displays information about the Gigabit Ethernet interfaces.

show controllers pos

To display information about a Packet over SONET (POS) interface, use the **show controllers pos** command in privileged EXEC mode. The command does not have a **no** form.

Cisco 7500 Series Routers

```
show controllers pos [slot/port-adapter/port] [details | pm [time-interval]]
```

Cisco 12000 Series Routers

```
show controllers pos [slot/port] [details | pm [time-interval]]
```

POS Shared Port Adapters

```
show controllers pos [slot/subslot/port[/sub_int]] [details | pm [time-interval]]
```

Syntax Description	
<i>slot</i>	(Optional) Chassis slot number. Refer to the appropriate hardware manual for slot information. For MSCs, refer to the platform-specific SPA hardware installation guide or the corresponding “Identifying Slots and Subslots for MSCs and SPAs” topic in the platform-specific SPA software configuration guide.
<i>/port-adapter</i>	(Optional) Port adapter number. Refer to the appropriate hardware manual for information about port adapter compatibility.
<i>/subslot</i>	(Optional) Secondary slot number on a MSC where a SPA is installed. Refer to the platform-specific SPA hardware installation guide and the corresponding “Specifying the Interface Address on a SPA” topic in the platform-specific SPA software configuration guide for subslot information.
<i>/port</i>	(Optional) Port or interface number. Refer to the appropriate hardware manual for port information. For SPAs, refer to the corresponding “Specifying the Interface Address on a SPA” topics in the platform-specific SPA software configuration guide.
<i>/sub_int</i>	(Optional) Subinterface number.
details	(Optional) In addition to the normal information displayed by the show controllers pos command, the details keyword provides a hexadecimal and ASCII “dump” of the path trace buffer.
pm	(Optional) Displays SONET performance monitoring statistics accumulated for a 24-hour period in 15-minute intervals.
<i>time-interval</i>	(Optional) Number of the SONET MIB 15-minute time interval in the range from 1 to 96. If the <i>time-interval</i> argument is not specified, the performance monitoring statistics for the current time interval are displayed.

Defaults

If you do not specify any slot addressing, information for all installed POS interfaces is displayed.

The **show controllers pos** command with the **pm** keyword displays SONET performance monitoring statistics accumulated at 15-minute intervals, and these statistics can be queried using Simple Network Management Protocol (SNMP) tools. The performance monitoring statistics are collected according to the RFC 1595 specification.

The information that this command displays is generally useful only for diagnostic tasks performed by technical support personnel.

If no interface is specified, the command displays information for all POS interfaces.

Command Modes

Privileged EXEC

Command History

Release	Modification
11.1CC	This command was introduced.
12.2S	This command was integrated into Cisco IOS release 12.2S.
12.2(25)S3	The command was modified to support a new addressing format for SPAs on the Cisco 7304 router.

Examples

Example of the show controllers pos Command on the Cisco 7500 Series Router

The following is sample output from the **show controllers pos** command on a Cisco 7500 series router:

```
Router# show controllers pos
```

```
POS2/0/0
SECTION
  LOF = 0          LOS = 2335          BIP(B1) = 77937133
LINE
  AIS = 2335      RDI = 20          FEBE = 3387950089 BIP(B2) = 1622825387
PATH
  AIS = 2340      RDI = 66090      FEBE = 248886263 BIP(B3) = 103862953
  LOP = 246806    NEWPTR = 11428072 PSE = 5067357    NSE = 4645
```

```
Active Defects: B2-TCA B3-TCA
Active Alarms: None
Alarm reporting enabled for: B1-TCA
```

```
APS
  COAPS = 12612784 PSBF = 8339
  State: PSBF_state = False
  Rx(K1/K2): 00/CC Tx(K1/K2): 00/00
  S1S0 = 03, C2 = 96
CLOCK RECOVERY
  RDOOL = 64322060
  State: RDOOL_state = True
PATH TRACE BUFFER: UNSTABLE
  Remote hostname :
  Remote interface:
  Remote IP addr  :
  Remote Rx(K1/K2): ../.. Tx(K1/K2): ../..
BER thresholds: SF = 10e-3 SD = 10e-8
TCA thresholds: B1 = 10e-7 B2 = 10e-3 B3 = 10e-6
```

Table 8-21 describes the fields shown in this display.

Table 8-21 *show controllers pos* Field Descriptions

Field	Description
POSx/y/z	Slot number of the POS interface.
LOF	Section loss of frame is detected when a severely error framing (SEF) defect on the incoming SONET signal persist for 3 milliseconds.
LOS	Section loss of signal is detected when an all-zeros pattern on the incoming SONET signal lasts 19 plus or minus 3 microseconds or longer. This defect might also be reported if the received signal level drops below the specified threshold.
BIP(B1)/BIP(B2)/BIP(B3)	<p>Bit interleaved parity (BIP).</p> <p>For B1, the BIP error report is calculated by comparing the BIP-8 code with the BIP-8 code extracted from the B1 byte of the following frame. Differences indicate that section-level bit errors have occurred.</p> <p>For B2, the BIP error report is calculated by comparing the BIP-8/24 code with the BIP-8 code extracted from the B2 byte of the following frame. Differences indicate that line-level bit errors have occurred.</p> <p>For B3, the BIP error report is calculated by comparing the BIP-8 code with the BIP-8 code extracted from the B3 byte of the following frame. Differences indicate that path-level bit errors have occurred.</p>
AIS	<p>Alarm indication signal.</p> <p>A line alarm indication signal is sent by the section terminating equipment (STE) to alert the downstream line terminating equipment (LTE) that a loss of signal (LOS) or loss of frame (LOF) defect has been detected on the incoming SONET section.</p> <p>A path alarm indication signal is sent by the LTE to alert the downstream path terminating equipment (PTE) that it has detected a defect on its incoming line signal.</p>
RDI	<p>Remote defect indication.</p> <p>A line remote defect indication is reported by the downstream LTE when it detects LOF, LOS, or AIS.</p> <p>A path remote defect indication is reported by the downstream PTE when it detects a defect on the incoming signal.</p>
FEBE	<p>Far end block errors.</p> <p>Line FEBE (accumulated from the M0 or M1 byte) is reported when the downstream LTE detects BIP(B2) errors.</p> <p>Path FEBE (accumulated from the G1 byte) is reported when the downstream PTE detects BIP(B3) errors.</p>
LOP	Path loss of pointer is reported as a result of an invalid pointer (H1, H2) or an excess number of new data flag (NDF) enabled indications.
NEWPTR	Inexact count of the number of times that the SONET framer has validated a new SONET pointer value (H1, H2).

Table 8-21 *show controllers pos Field Descriptions (continued)*

Field	Description
PSE	Inexact count of the number of times that the SONET framer has detected a positive stuff event in the received pointer (H1, H2).
NSE	Inexact count of the number of times that the SONET framer has detected a negative stuff event in the received pointer (H1, H2).
Active Defects	List of all currently active SONET defects.
Active Alarms	List of current alarms as enforced by Sonet Alarm Hierarchy.
Alarm reporting enabled for	List of alarms for which you enabled reporting with the pos report interface command.
APS	Automatic protection switching.
COAPS	An inexact count of the number of times that a new APS value has been detected in the K1, K2 bytes.
PSBF	An inexact count of the number of times that a protection switching byte failure has been detected (no three consecutive SONET frames contain identical K1 bytes).
PSBF_state	Protection switching byte failure state.
Rx(K1/K2)/Tx(K1/K2)	Contents of the received and transmitted K1 and K2 bytes.
S1S0	The two S bits received in the last H1 byte.
C2	The value extracted from the SONET path signal label byte (C2).
CLOCK RECOVERY	The SONET clock is recovered using information in the SONET overhead. RDOOL is an inexact count of the number of times that Receive Data Out Of Lock has been detected, which indicates that the clock recovery phased lock loop is unable to lock to the receive stream.
PATH TRACE BUFFER	SONET path trace buffer is used to communicate information regarding the remote host name, interface name/number, and IP address. This is a Cisco-proprietary use of the J1 (path trace) byte.
BER thresholds	List of the bit error rate (BER) thresholds that you configured with the pos threshold interface command.
TCA thresholds	List of threshold crossing alarms (TCAs) that you configured with the pos threshold interface command.

Example of the show controllers pos Command on a POS Shared Port Adapter

The following is sample output from the **show controllers pos** command on a Cisco 7600 series router for POS interface 4/3/0 (which is the interface for port 0 of the SPA in subslot 3 of the MSC in chassis slot 4):

```

Router# show controllers pos 4/3/0
POS4/3/0
SECTION
  LOF = 0          LOS    = 0          BIP(B1) = 60
LINE
  AIS = 0          RDI    = 0          FEBE = 261      BIP(B2) = 553
PATH
  AIS = 0          RDI    = 0          FEBE = 85       BIP(B3) = 75
  LOP = 0          NEWPTR = 0          PSE   = 0       NSE    = 0

Active Defects:None

```



```

Active Alarms: None
Alarm reporting enabled for:SF SLOS SLOF B1-TCA B2-TCA PLOP B3-TCA

Framing:SONET
APS
  working (active)
    COAPS = 3          PSBF = 0
    State:PSBF_state = False
    ais_shut = TRUE
    Rx(K1/K2):00/00   S1S0 = 00, C2 = CF
    Remote aps status (none); Reflected local aps status (none)
CLOCK RECOVERY
  RDOOL = 0
  State:RDOOL_state = False
PATH TRACE BUFFER :STABLE
  Remote hostname :r-c7600
  Remote interface:POS4/0
  Remote IP addr  :50.0.0.2
  Remote Rx(K1/K2):00/00 Tx(K1/K2):00/00

BER thresholds: SF = 10e-3  SD = 10e-6
TCA thresholds: B1 = 10e-6  B2 = 10e-6  B3 = 10e-6

```

Table 8-21 describes the fields shown in this display.

Example of the show controllers pos pm Command on the Cisco 12000 Series Router

The following is sample output from the **show controllers pos pm** command that displays performance monitoring statistics on a Cisco 12000 series router:

```

Router# show controllers pos 1/0 pm

POS1/0
Medium is SONET
Line coding is RZ, Line type is LONG SM
Data in current interval (516 seconds elapsed)
SECTION ( NO DEFECT )
  515 Errored Secs, 515 Severely Err Secs
  0 Coding Violations, 515 Sev Err Framing Secs
LINE ( NO DEFECT )
  0 Errored Secs, 0 Severely Err Secs
  0 Coding Violations, 0 Unavailable Secs
FAR END LINE
  0 Errored Secs, 0 Severely Err Secs
  0 Coding Violations, 0 Unavailable Secs
PATH ( NO DEFECT )
  0 Errored Secs, 0 Severely Err Secs
  0 Coding Violations, 0 Unavailable Secs
FAR END PATH
  0 Errored Secs, 0 Severely Err Secs
  0 Coding Violations, 0 Unavailable Secs

```

Table 8-22 describes the fields shown in the display.

Table 8-22 *show controllers pos pm Field Descriptions*

Field	Description
POSx/y	Slot number of the POS interface.
Line coding	Shows the current line encoding type, either return to zero (RZ) or nonreturn to zero (NRZ).

Table 8-22 *show controllers pos pm Field Descriptions (continued)*

Field	Description
Line type	Line type for this interface. Optical line types can be either long range (LONG) or short range (SHORT), and either single mode (SM) or multimode (MM).
Data in current interval	Shows the current accumulation period, which rolls into the 24-hour accumulation every 15 minutes. Accumulation period is from 1 to 900 seconds. The oldest 15-minute period falls off the back of the 24-hour accumulation buffer.
Errored Secs	An errored second is a second in which one of the following is detected: <ul style="list-style-type: none"> One or more coding violations. One or more incoming defects (for example, a severely errored frame (SEF) defect, an LOS defect, an AIS defect, or an LOP defect).
Severely Err Secs	A severely errored second (SES) is a second with one of the following errors: <ul style="list-style-type: none"> A certain number of coding violations. The number is dependent on the line rate and the BER. A certain number of incoming defects.
Coding Violations	Number of coding violations for the current interval. Coding violations are defined as BIP errors that are detected in the incoming signal. The coding violations counter is incremented for each BIP error detected.
Sev Err Framing Secs	Severely errored framing seconds (SEFS) are seconds with one or more SEF defects.
Unavailable Secs	Total number of seconds for which the interface is unavailable. The interface is considered to be unavailable after a series of ten consecutive SESs.

POS Shared Port Adapter Example

The following is sample output from the **show controllers pos** command on a Cisco 7304 router for POS interface 2/0/0 (which is the interface for port 0 of the SPA in subslot 0 of the MSC in chassis slot 2):

```
Router# show controllers pos 2/0/0 details
POS2/0/0
SECTION
LOF = 0 LOS = 1 BIP(B1) = 5
LINE
AIS = 0 RDI = 1 FEBE = 5790 BIP(B2) = 945
PATH
AIS = 0 RDI = 0 FEBE = 0 BIP(B3) = 5
PLM = 0 UNEQ = 0 TIM = 0 TIU = 0
LOP = 1 NEWPTR = 0 PSE = 0 NSE = 0

Active Defects: None
Active Alarms: None
Alarm reporting enabled for: SF SLOS SLOF B1-TCA B2-TCA PLOP B3-TCA

Line alarm trigger delay = 100 ms
Path alarm trigger delay = 100 ms
.
.
.
```

Related Commands	Command	Description
	pos report	Permits selected SONET alarms to be logged to the console for a POS interface.
	pos threshold	Sets the BER threshold values of specified alarms for a POS interface.

show controllers serial

To display serial controller statistics, use the **show controllers serial** command in privileged EXEC mode.

Standard Syntax

```
show controllers serial [slot/port]
```

Cisco 7000 Series Routers with the RSP7000 and RSP7000CI and Cisco 7500 Series Routers

```
show controllers serial [slot/port-adapter/port]
```

T3/E3 Shared Port Adapters and 2-Port and 4-Port Channelized T3 SPA in Unchannelized Mode

```
show controllers serial [slot/subslot/port]
```

Channelized T3 Shared Port Adapters

```
show controllers serial [slot/subslot/port/t1-number]
```

Syntax Description	
<i>slot</i>	(Optional) Chassis slot number. Refer to the appropriate hardware manual for slot information. For MSCs, refer to the platform-specific SPA hardware installation guide or the corresponding “Identifying Slots and Subslots for MSCs and SPAs” topic in the platform-specific SPA software configuration guide.
<i>port-adapter</i>	(Optional) On Cisco 7500 series routers and Cisco 7000 series routers with the RSP7000 and RSP7000CI, the location of the port adapter on a Versatile Interface Processor (VIP). The value can be 0 or 1.
<i>/subslot</i>	(Optional) Secondary slot number on a MSC where a SPA is installed. Refer to the platform-specific SPA hardware installation guide and the corresponding “Specifying the Interface Address on a SPA” topic in the platform-specific SPA software configuration guide for subslot information.
<i>/port</i>	(Optional) Port or interface number. Refer to the appropriate hardware manual for port information. For SPAs, refer to the corresponding “Specifying the Interface Address on a SPA” topics in the platform-specific SPA software configuration guide.
<i>t1-number</i>	(Optional) Logical T1 number in channelized mode. For SPAs, refer to the corresponding “Specifying the Interface Address on a SPA” topics in the platform-specific SPA software configuration guide.

Defaults

No default behavior or values

Command Modes

Privileged EXEC

Command History

Release	Modification
10.0	This command was introduced.
11.1CA	This command was modified to include support for the PA-E3 and PA-T3 port adapters.
12.2S	This command was integrated into Cisco IOS Release 12.2S.
12.2(18)SXE	This command was integrated into Cisco IOS Release 12.2(18)SXE and introduced a new output for interfaces on the serial SPAs on the Cisco 7304 router.
12.0(31)S	This command was integrated into Cisco IOS Release 12.0(31)S.
12.2(25)S3	This command was integrated into Cisco IOS Release 12.2(25)S3.

Usage Guidelines

The output from the **show controllers serial** command provides error and alarm information that is useful in troubleshooting line problems.

The information displayed is generally useful for diagnostic tasks performed by Cisco Systems technical support personnel only. For the PA-E3 or PA-T3 port adapters, the **show controllers serial** command also displays configuration information such as the framing, clock source, bandwidth limit, whether scrambling is enabled, the national bit, the international bits, and DSU mode configured on the interface. Also displayed are the performance statistics for the current interval and last 15-minute interval and whether any alarms exist.

Examples**Example of the show controllers serial Command on the Cisco 4000 Series Router**

The following is sample output from the **show controllers serial** command on the Cisco 4000:

```
Router# show controllers serial
```

```

MK5 unit 0, NIM slot 1, NIM type code 7, NIM version 1
idb = 0x6150, driver structure at 0x34A878, regaddr = 0x8100300
IB at 0x6045500: mode=0x0108, local_addr=0, remote_addr=0
N1=1524, N2=1, scaler=100, T1=1000, T3=2000, TP=1
buffer size 1524
DTE V.35 serial cable attached

RX ring with 32 entries at 0x45560 : RLEN=5, Rxhead 0
00 pak=0x6044D78 ds=0x6044ED4 status=80 max_size=1524 pak_size=0
01 pak=0x60445F0 ds=0x604474C status=80 max_size=1524 pak_size=0
02 pak=0x6043E68 ds=0x6043FC4 status=80 max_size=1524 pak_size=0
03 pak=0x60436E0 ds=0x604383C status=80 max_size=1524 pak_size=0
04 pak=0x6042F58 ds=0x60430B4 status=80 max_size=1524 pak_size=0
05 pak=0x60427D0 ds=0x604292C status=80 max_size=1524 pak_size=0
06 pak=0x6042048 ds=0x60421A4 status=80 max_size=1524 pak_size=0
07 pak=0x60418C0 ds=0x6041A1C status=80 max_size=1524 pak_size=0
08 pak=0x6041138 ds=0x6041294 status=80 max_size=1524 pak_size=0
09 pak=0x60409B0 ds=0x6040B0C status=80 max_size=1524 pak_size=0
10 pak=0x6040228 ds=0x6040384 status=80 max_size=1524 pak_size=0
11 pak=0x603FAA0 ds=0x603FBFC status=80 max_size=1524 pak_size=0
12 pak=0x603F318 ds=0x603F474 status=80 max_size=1524 pak_size=0
13 pak=0x603EB90 ds=0x603ECEC status=80 max_size=1524 pak_size=0
14 pak=0x603E408 ds=0x603E564 status=80 max_size=1524 pak_size=0
15 pak=0x603DC80 ds=0x603DDDC status=80 max_size=1524 pak_size=0
16 pak=0x603D4F8 ds=0x603D654 status=80 max_size=1524 pak_size=0
17 pak=0x603CD70 ds=0x603CECC status=80 max_size=1524 pak_size=0
18 pak=0x603C5E8 ds=0x603C744 status=80 max_size=1524 pak_size=0

```

show controllers serial

```

19 pak=0x603BE60 ds=0x603BFBC status=80 max_size=1524 pak_size=0
20 pak=0x603B6D8 ds=0x603B834 status=80 max_size=1524 pak_size=0
21 pak=0x603AF50 ds=0x603B0AC status=80 max_size=1524 pak_size=0
22 pak=0x603A7C8 ds=0x603A924 status=80 max_size=1524 pak_size=0
23 pak=0x603A040 ds=0x603A19C status=80 max_size=1524 pak_size=0
24 pak=0x60398B8 ds=0x6039A14 status=80 max_size=1524 pak_size=0
25 pak=0x6039130 ds=0x603928C status=80 max_size=1524 pak_size=0
26 pak=0x60389A8 ds=0x6038B04 status=80 max_size=1524 pak_size=0
27 pak=0x6038220 ds=0x603837C status=80 max_size=1524 pak_size=0
28 pak=0x6037A98 ds=0x6037BF4 status=80 max_size=1524 pak_size=0
29 pak=0x6037310 ds=0x603746C status=80 max_size=1524 pak_size=0
30 pak=0x6036B88 ds=0x6036CE4 status=80 max_size=1524 pak_size=0
31 pak=0x6036400 ds=0x603655C status=80 max_size=1524 pak_size=0
TX ring with 8 entries at 0x45790 : TLEN=3, TWD=7
tx_count = 0, tx_head = 7, tx_tail = 7
00 pak=0x000000 ds=0x600D70C status=0x38 max_size=1524 pak_size=22
01 pak=0x000000 ds=0x600D70E status=0x38 max_size=1524 pak_size=2
02 pak=0x000000 ds=0x600D70E status=0x38 max_size=1524 pak_size=2
03 pak=0x000000 ds=0x600D70E status=0x38 max_size=1524 pak_size=2
04 pak=0x000000 ds=0x600D70E status=0x38 max_size=1524 pak_size=2
05 pak=0x000000 ds=0x600D70E status=0x38 max_size=1524 pak_size=2
06 pak=0x000000 ds=0x600D70E status=0x38 max_size=1524 pak_size=2
07 pak=0x000000 ds=0x6000000 status=0x38 max_size=1524 pak_size=0
XID/Test TX desc at 0xFFFFF, status=0x30, max_buffer_size=0, packet_size=0
XID/Test RX desc at 0xFFFFF, status=0x0, max_buffer_size=0, packet_size=0
Status Buffer at 0x60459C8: rcv=0, tcv=0, local_state=0, remote_state=0
phase=0, tac=0, currd=0x00000, curxd=0x00000
bad_frames=0, frmrs=0, Tl_timeouts=0, rej_rxs=0, runts=0
0 missed datagrams, 0 overruns, 0 bad frame addresses
0 bad datagram encapsulations, 0 user primitive errors
0 provider primitives lost, 0 unexpected provider primitives
0 spurious primitive interrupts, 0 memory errors, 0 tr
%LINEPROTO-5-UPDOWN: Line protocol on Serial0 is down
mk5025 registers: csr0 = 0x0E00, csr1 = 0x0302, csr2 = 0x0704
                  csr3 = 0x5500, csr4 = 0x0214, csr5 = 0x0008

```

Example of the show controllers serial Command for a PA-E3 Serial Port Adapter

The following is sample output from the **show controllers serial** command for a PA-E3 serial port adapter installed in slot 2:

```
Router# show controllers serial 2/0
```

```

M1T-E3 pa: show controller:
PAS unit 0, subunit 0, f/w version 2-55, rev ID 0x2800001, version 2
idb = 0x6080D54C, ds = 0x6080F304, ssb=0x6080F4F4
Clock mux=0x30, ucmd_ctrl=0x0, port_status=0x1
Serial config=0x8, line config=0x1B0202
maxdgram=4474, bufpool=128Kb, 256 particles

rxLOS inactive, rxLOF inactive, rxAIS inactive
txAIS inactive, rxRAI inactive, txRAI inactive

line state: up
E3 DTE cable, received clockrate 50071882

base0 registers=0x3D000000, base1 registers=0x3D002000
mxt_ds=0x608BA654, rx ring entries=128, tx ring entries=256
rxring=0x4B01F480, rxr shadow=0x6081081C, rx_head=26
txring=0x4B01F960, txr shadow=0x60810E48, tx_head=192, tx_tail=192, tx_count=0
throttled=0, enabled=0, disabled=0
rx_no_eop_err=0, rx_no_stp_err=0, rx_no_eop_stp_err=0
rx_no_buf=0, rx_soft_overrun_err=0, dump_err= 1
tx_underrun_err=0, tx_soft_underrun_err=0, tx_limited=0

```

```

tx_fullring=0, tx_started=11504
Framing is g751, Clock Source is Line, Bandwidth limit is 34010.
Scrambling is enabled
National Bit is 0, International Bits are: 0 0
DSU mode 1
Data in current interval (213 seconds elapsed):
  0 Line Code Violations, 0 P-bit Coding Violation
  0 C-bit Coding Violation
  0 P-bit Err Secs, 0 P-bit Severely Err Secs
  0 Severely Err Framing Secs, 0 Unavailable Secs
  0 Line Errored Secs, 0 C-bit Errored Secs, 0 C-bit Severely Errored Secs
Total Data (last 24 hours)
  0 Line Code Violations, 0 P-bit Coding Violation,
  0 C-bit Coding Violation,
  0 P-bit Err Secs, 0 P-bit Severely Err Secs,
  0 Severely Err Framing Secs, 0 Unavailable Secs,
  0 Line Errored Secs, 0 C-bit Errored Secs, 0 C-bit Severely Errored Secs

No alarms detected.

```

Example of the show controllers serial Command for a PA-T3 Serial Port Adapter

The following is sample output from the **show controllers serial** command that shows serial port 1/0/0 on a 1-port PA-T3 serial port adapter installed on a VIP2 in chassis slot 1:

```
Router# show controllers serial 2/0/1
```

```

Serial1/0/0 -
Mx T3(1) HW Revision 0x3, FW Revision 2.55
Framing is c-bit, Clock Source is Line
Bandwidth limit is 35000, DSU mode 1, Cable length is 50

Data in current interval (325 seconds elapsed):
  0 Line Code Violations, 0 P-bit Coding Violation
  0 C-bit Coding Violation
  0 P-bit Err Secs, 0 P-bit Sev Err Secs
  0 Sev Err Framing Secs, 0 Unavailable Secs
  0 Line Errored Secs, 0 C-bit Errored Secs, 0 C-bit Sev Err Secs
Total Data (last 24 hours)
  0 Line Code Violations, 0 P-bit Coding Violation,
  0 C-bit Coding Violation,
  0 P-bit Err Secs, 0 P-bit Sev Err Secs,
  0 Sev Err Framing Secs, 0 Unavailable Secs,
  0 Line Errored Secs, 0 C-bit Errored Secs, 0 C-bit Sev Err Secs

No alarms detected.

```

Example of the show controllers serial Command for a Channelized T3 SPA

The following is sample output from the **show controllers serial** command for a 2-port or 4-Port CT3 SPA located in slot 3 of a Cisco 7304 router:

```

Router# show controllers serial
Serial3/1/0 -
Framing is c-bit, Clock Source is Internal
Bandwidth limit is 44210, DSU mode 0, Cable length is 10
rx FEBE since last clear counter 0, since reset 0
Data in current interval (0 seconds elapsed):
  0 Line Code Violations, 0 P-bit Coding Violation
  0 C-bit Coding Violation
  0 P-bit Err Secs, 0 P-bit Sev Err Secs
  0 Sev Err Framing Secs, 0 Unavailable Secs
  0 Line Errored Secs, 0 C-bit Errored Secs, 0 C-bit Sev Err Secs
  0 Severely Errored Line Secs
  0 Far-End Errored Secs, 0 Far-End Severely Errored Secs

```

```

0 CP-bit Far-end Unavailable Secs
0 Near-end path failures, 0 Far-end path failures
0 Far-end code violations, 0 FERF Defect Secs
0 AIS Defect Secs, 0 LOS Defect Secs

Transmitter is sending AIS.

Receiver has loss of signal.
Serial3/1/3 -
Framing is c-bit, Clock Source is Line
Bandwidth limit is 44210, DSU mode 0, Cable length is 10
rx FEBE since last clear counter 0, since reset 0
Data in current interval (757 seconds elapsed):
  0 Line Code Violations, 0 P-bit Coding Violation
  0 C-bit Coding Violation
  0 P-bit Err Secs, 0 P-bit Sev Err Secs
  0 Sev Err Framing Secs, 0 Unavailable Secs
  0 Line Errored Secs, 0 C-bit Errored Secs, 0 C-bit Sev Err Secs
  0 Severely Errored Line Secs
  0 Far-End Errored Secs, 0 Far-End Severely Errored Secs
  0 CP-bit Far-end Unavailable Secs
  0 Near-end path failures, 0 Far-end path failures
  0 Far-end code violations, 0 FERF Defect Secs
  0 AIS Defect Secs, 0 LOS Defect Secs

No alarms detected.
```

Table 8-5 describes the fields shown in the **show controllers serial** output.



Note The fields appearing in the output will vary depending on card type, controller configuration, and the status of the controller line.

Table 8-23 *show controllers serial Field Descriptions*

Field	Description
Serial	Name of the serial controller.
Framing	Framing type.
Clock source	Source of the synchronization signal (clock).
Bandwidth limit	The allowable bandwidth for the controller.
DSU mode	The Data Service Unit (DSU) interoperability mode.
Cable length	The distance to the first repeater.
rx FEBE since last clear counter	Number of received far-end block errors. Note Line far-end block error (accumulated from the M0 or M1 byte) is reported when the downstream LTE detects BIP(B2) errors. Path far-end block error (accumulated from the G1 byte) is reported when the downstream PTE detects BIP(B3) errors.
rx FEBE since last reset	Number of received far-end block errors.
Line Code Violations	Number of Bipolar Violation (BPV) errors or Excessive Zeros (EXZ) errors.

Table 8-23 *show controllers serial Field Descriptions (continued)*

Field	Description
P-bit Coding Violations	Number of P-bit errors encountered between source and destination.
C-bit coding violations	Number of C-bit errors encountered between source and destination.
P-bit Err Secs (PES)	<p>Number of seconds with P-bit errors.</p> <p>Note A PES is a second with one or more PCVs or one or more Out of Frame defects or a detected incoming AIS. This gauge is not incremented when UASs are counted.</p>
P-bit Sev Err Secs (PSES)	<p>Number of seconds with P-bit severe errors.</p> <p>Note A PSES is a second with 44 or more PCVs or one or more Out of Frame defects or a detected incoming AIS. This gauge is not incremented when UASs are counted.</p>
Sev Err Framing Secs	The number of 1-second intervals in which either a Remote Alarm Indication was received or a Loss Of Frame condition occurred.
Unavailable Secs	The number of 1-second intervals in which the controller was down.
Line Errored Secs	The number of 1-second intervals in which a Line Code Violation occurred.
C-bit Errored Secs (CES)	<p>Number of seconds with C-bit errors.</p> <p>Note A CES is a second with one or more CCVs or one or more Out of Frame defects or a detected incoming AIS. This count is only for the SYNTRAN and C-bit Parity DS3 applications. This gauge is not incremented when UASs are counted.</p>
C-bit Sev Err Secs (CSES)	<p>Number of seconds with severe C-bit errors.</p> <p>Note A CSES is a second with 44 or more CCVs or one or more Out of Frame defects or a detected incoming AIS. This count is only for the SYNTRAN and C-bit Parity DS3 applications. This gauge is not incremented when UASs are counted.</p>

Table 8-23 *show controllers serial Field Descriptions (continued)*

Field	Description
Severely Errored Line Secs	<p>For ESF signals, this is a second in which one of the following defects is detected:</p> <ul style="list-style-type: none"> • 320 or more Path Code Violation errors. • One or more Out of Frame defects. • An AIS defect. <p>For E1-CRC signals, this is a second with one of the following errors:</p> <ul style="list-style-type: none"> • 832 or more Path Code Violation errors. • One or more Out of Frame defects. <p>For E1-nonCRC signals, this is a second with 2048 or more Line Code Violations.</p>
Far-End Errored Secs	Number of seconds of far-end failures.
Far-End Severely Errored Secs	The number of 1-second intervals in which either a Remote Alarm Indication was received or a Loss Of Frame condition occurred.
P-bit Unavailable Secs	Number of seconds the interface is unavailable because of P-bit errors.
CP-bit Unavailable Secs	Number of seconds the interface is unavailable because of CP-bit errors.
CP-bit Far-end Unavailable Secs	Number of seconds the interface is unavailable because of CP-bit errors from the far-end device.
Near-end path failures	
Far-end path failures	
Far-end code violations	
FERF Defect Secs	Number of far-end receive failures detected per second.
AIS Defect Secs	Number of alarm indication signals per second.
LOS Defect Secs	Number of loss of signal alarms per second.
Path Code Violations	Indicates a frame synchronization bit error in the D4 and E1-no CRC formats, or a CRC error in the Extended Superframe (ESF) and E1-CRC formats.
Slip Secs	Indicates the replication or deletion of the payload bits of a domestic trunk interface (DS1) frame. A slip might happen when there is a difference between the timing of a synchronous receiving terminal and the received signal.
Fr Loss Secs	Indicates the number of seconds an Out of Frame (OOF) error is detected.
Line Err Secs	Line Errored Seconds (LES) is a second in which one or more Line Code Violation errors are detected.
Degraded Mins	A degraded minute is one in which the estimated error rate exceeds 1E-6 but does not exceed 1E-3.

Table 8-23 *show controllers serial Field Descriptions (continued)*

Field	Description
Errored Secs	<p>In ESF and E1-CRC links, an errored second is a second in which one of the following defects is detected:</p> <ul style="list-style-type: none">• One or more Path Code Violations.• One or more Controlled Slip events. <p>Note For SF and E1 no-CRC links, the presence of Bipolar Violations also triggers an errored second.</p>
Bursty Err Secs	<p>A second with more than one but fewer than 320 Path Coding Violation errors, no Severely Errored Frame defects, and no detected incoming AIS defects. Controlled slips are not included in this parameter.</p>

show diag

To display hardware and diagnostic information for a networking device, a line card, a processor, a jacket card, or a chassis, use the **show diag** command in privileged EXEC configuration mode.

```
show diag [slot-number] [details | summary]
```

Cisco 7304 Router

```
show diag [slot-number | chassis | subslot slot/subslot] [details | summary]
```

Shared Port Adapters

```
show diag [subslot slot/subslot] [details | summary]
```

Syntax Description	<i>slot-number</i>	(Optional) Slot number of the interface. If a slot number is not specified, diagnostic information for all slots is displayed.
	chassis	(Optional) Cisco 7304 Router Specifies the display of diagnostic information about the backplane, power supplies, and fan modules.
	subslot <i>slot/subslot</i>	(Optional) Shared Port Adapters Specifies the display of diagnostic information about the shared port adapter (SPA), where: <ul style="list-style-type: none"> <i>slot</i>—Chassis slot number. Refer to the appropriate hardware manual for slot information. For SIPs, refer to the platform-specific SPA hardware installation guide or the corresponding “Identifying Slots and Subslots for SIPs and SPAs” topic in the platform-specific SPA software configuration guide.
		<ul style="list-style-type: none"> <i>subslot</i>—Secondary slot number on a SIP where a SPA is installed. Refer to the platform-specific SPA hardware installation guide and the corresponding “Specifying the Interface Address on a SPA” topic in the platform-specific SPA software configuration guide for subslot information.
	details	(Optional) Displays more details than the normal show diag output.
	summary	(Optional) Displays a summary (one line per slot) of the chassis.

Defaults	No default behavior or values
----------	-------------------------------

Command Modes	Privileged EXEC
---------------	-----------------

Command History	Release	Modification
	11.1CA	This command was introduced.
	11.2	This command was integrated into Cisco IOS Release 11.2.

Release	Modification
11.2P	This command output was modified for the PA-12E/2FE port adapter, PA-E3 port adapter, and PA-T3 port adapter.
11.2GS	This command was implemented on the Cisco 12000 series Gigabit Switch Routers (GSRs).
11.3 XA	This command was integrated in Cisco IOS Release 11.3 XA.
12.0	This command was implemented on the Cisco AS5300.
12.0(5)XQ	This command was implemented on the Cisco 1750 router.
12.0(7)T	This command was integrated into Cisco IOS Release 12.0(7)T.
12.1(9)EX	This command was introduced on the Cisco 7300 series routers, and the <i>slot-number</i> argument and chassis keyword were added.
12.1(10)EX	This command was enhanced to display information about Field-Programmable Gate Array (FPGA) image versions on installed NSEs and line cards on Cisco 7304 routers.
12.2(11)YZ	Support was added for the 7300-CC-PA.
12.2(8)T	This command was implemented for AIC and WIC cards on the Cisco 2600 series routers and the Cisco 3600 series routers.
12.2(13)T	This command was implemented for the AIM-VPN/EPII and AIM-VPN/HPII cards on the Cisco 2691, Cisco 3660, Cisco 3725, and Cisco 3745.
12.2(15)ZJ	This command was implemented for the AIM-VPN/BPII card on the Cisco 2610XM, Cisco 2611XM, Cisco 2620XM, Cisco 2621XM, Cisco 2650XM, and Cisco 2651XM.
12.2(18)S	This command was integrated into Cisco IOS Release 12.2(18)S and implemented on the Cisco 7304 router.
12.3(4)T	Support for the AIM-VPN/BPII card on the Cisco 2600XM series was integrated into Cisco IOS Release 12.3(4)T.
12.2(20)S2	This command was integrated into Cisco IOS Release 12.2(20)S2 and the subslot <i>slot/subslot</i> keyword and arguments were added to support SPAs on the Cisco 7304 router.
12.0(31)S	This command was integrated into Cisco IOS Release 12.0(31)S and the subslot <i>slot/subslot</i> keyword and arguments were added to support SIPs and SPAs on the Cisco 12000 series router.
12.4(4)T	This command was implemented for the HWIC-1ADSL and HWIC-1ADSLI interface cards on the following platforms: Cisco 1800 (modular) series, Cisco 2800 series, and Cisco 3800 series.

Usage Guidelines

Use this command to determine the type of hardware installed in your router, and to show detailed hardware information and EEPROM version information.

This command displays information for the motherboard, WAN interface cards (WICs), voice interface cards (VICs), high-speed WICs (HWICs), ATM interface cards (AICs), advanced integration modules (AIMs), port adapters, shared port adapters (SPAs), modular services cards (MSCs), and SPA interface processors (SIPs).

Cisco 7304 Router Usage Guidelines

For the Cisco 7304 router, this command applies to NSEs, line cards, MSCs, and SPAs.

- To display hardware information for an NSE, line card, or MSC in the specified slot, use the *slot-number* argument. For MSCs, information about the MSC and each of its installed SPAs is displayed.
- To display hardware information about the backplane, power supplies, and fan modules, use the **chassis** keyword.

Shared Port Adapter Usage Guidelines

- To display hardware information for an MSC or SIP only in a specified slot, use the *slot-number* argument.
- To display hardware information for a SPA only, use the **show diag subslot slot/subslot** version of this command.

Examples

1-Port T3 Serial Port Adapter: Example

The following is sample output from the **show diag** command for a 1-port T3 serial port adapter in chassis slot 1 on a Cisco 7200 series router:

```
Router# show diag 1

Slot 1:
  Physical slot 1, ~physical slot 0xE, logical slot 1, CBus 0
  Microcode Status 0x4
  Master Enable, LED, WCS Loaded
  Board is analyzed
  Pending I/O Status: None
  EEPROM format version 1
  VIP2 controller, HW rev 2.4, board revision D0
  Serial number: 04372053 Part number: 73-1684-03
  Test history: 0x00 RMA number: 00-00-00
  Flags: cisco 7000 board; 7500 compatible

  EEPROM contents (hex):
    0x20: 01 15 02 04 00 42 B6 55 49 06 94 03 00 00 00 00
    0x30: 68 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00

  Slot database information:
  Flags: 0x4 Insertion time: 0x14A8 (5d02h ago)

  Controller Memory Size: 16 MBytes DRAM, 1024 KBytes SRAM

  PA Bay 0 Information:
    T3 Serial PA, 1 ports
    EEPROM format version 1
    HW rev FF.FF, Board revision UNKNOWN
    Serial number: 4294967295 Part number: 255-65535-255
```

Cisco 12000 Series Internet Router: Example

The following is sample output from the **show diag** command on a Cisco 12000 series Internet router:

```
Router# show diag 3

SLOT 3 (RP/LC 3 ): 4 Port Packet Over SONET OC-3c/STM-1 Multi Mode
  MAIN: type 33, 00-0000-00 rev 70 dev 0
  HW config: 0x01 SW key: 00-00-00
  PCA: 73-2147-02 rev 94 ver 2
```

```

HW version 1.0 S/N 04499695
MBUS: MBUS Agent (1) 73-2146-05 rev 73 dev 0
HW version 1.1 S/N 04494882
Test hist: 0x00 RMA#: 00-00-00 RMA hist: 0x00
DIAG: Test count: 0x05000001 Test results: 0x00000000
MBUS Agent Software version 01.27 (RAM) using CAN Bus A
ROM Monitor version 00.0D
Fabric Downloader version used 00.0D (ROM version is 00.0D)
Board is analyzed
Board State is Line Card Enabled (IOS RUN)
Insertion time: 00:00:10 (00:04:51 ago)
DRAM size: 33554432 bytes
FrFab SDRAM size: 67108864 bytes
ToFab SDRAM size: 16777216 bytes

```

The following is sample output from the **show diag** command with the **summary** keyword:

Router# **show diag summary**

```

SLOT 0 (RP/LC 0 ): Route Processor
SLOT 2 (RP/LC 2 ): 4 Port Packet Over SONET OC-3c/STM-1 Single Mode
SLOT 4 (RP/LC 4 ): 4 Port Packet Over SONET OC-3c/STM-1 Single Mode
SLOT 7 (RP/LC 7 ): 4 Port Packet Over SONET OC-3c/STM-1 Single Mode
SLOT 9 (RP/LC 9 ): 4 Port Packet Over SONET OC-3c/STM-1 Single Mode
SLOT 11 (RP/LC 11): 4 Port Packet Over SONET OC-3c/STM-1 Single Mode
SLOT 16 (CSC 0 ): Clock Scheduler Card
SLOT 17 (CSC 1 ): Clock Scheduler Card
SLOT 18 (SFC 0 ): Switch Fabric Card
SLOT 19 (SFC 1 ): Switch Fabric Card
SLOT 20 (SFC 2 ): Switch Fabric Card
SLOT 24 (PS A1 ): AC Power Supply
SLOT 26 (PS B1 ): AC Power Supply
SLOT 28 (TOP FAN ): Blower Module
SLOT 29 (BOT FAN ): Blower Module

```

The following is sample output from the **show diag** command with the **details** keyword:

Router# **show diag 4 details**

```

SLOT 4 (RP/LC 4): 4 Port Packet Over SONET OC-3c/STM-1 Single Mode
MAIN: type 33, 800-2389-01 rev 71 dev 16777215
HW config: 0x00 SW key: FF-FF-FF
PCA: 73-2275-03 rev 75 ver 3
HW version 1.1 S/N 04529465
MBUS: MBUS Agent (1) 73-2146-06 rev 73 dev 0
HW version 1.1 S/N 04541395
Test hist: 0xFF RMA#: FF-FF-FF RMA hist: 0xFF
DIAG: Test count: 0x05000001 Test results: 0x00000000
EEPROM contents (hex):
00: 01 00 01 00 49 00 08 62 06 03 00 00 00 FF FF FF
10: 30 34 35 34 31 33 39 35 FF FF FF FF FF FF FF FF
20: 01 01 00 00 00 00 00 FF FF FF FF FF FF FF FF
30: A5 FF A5 A5 A5 A5 FF A5 A5 A5 A5 A5 A5 A5 A5
40: 00 21 01 01 00 49 00 08 E3 03 05 03 00 01 FF FF
50: 03 20 00 09 55 01 01 FF FF FF 00 FF FF FF FF FF
60: 30 34 35 32 39 34 36 35 FF FF FF FF FF FF FF FF
70: FF FF FF FF FF FF FF FF 05 00 00 01 00 00 00 00
MBUS Agent Software version 01.24 (RAM)
Fabric Downloader version 00.0D
Board is analyzed
Flags: 0x4
Board State is Line Card Enabled (IOS RUN)
Insertion time: 00:00:10 (00:04:51 ago)
DRAM size: 33554432 bytes

```

```
FrFab SDRAM size: 67108864 bytes
ToFab SDRAM size: 16777216 bytes
```

ATM SAR AIM in a Cisco 3660: Example

The following is sample output from the **show diag** command for one ATM Segmentation and Reassembly (SAR) AIM in a Cisco 3660 router:

```
Router# show diag 0

3660 Chassis type: ENTERPRISE

c3600 Backplane EEPROM:
  Hardware Revision      : 1.0
  Top Assy. Part Number  : 800-04740-02
.
.
.
ATM AIM: 1
  ATM AIM module with SAR only (no DSPs)
  Hardware Revision      : 1.0
  Top Assy. Part Number  : 800-03700-01
  Board Revision         : A0
  Deviation Number       : 0-0
  Fab Version            : 02
  PCB Serial Number      : JAB9801ABCD
```

NM-AIC-64 Installed in a Cisco 2611: Example

The following is sample output from the **show diag** command for a Cisco 2611 router with the NM-AIC-64 installed.

```
Router# show diag

Slot 0:
C2611 2E Mainboard Port adapter, 2 ports
Port adapter is analyzed
Port adapter insertion time unknown
EEPROM contents at hardware discovery:
Hardware Revision : 2.3
PCB Serial Number : JAD044808SG (1090473337)
Part Number : 73-2840-13
RMA History : 00
RMA Number : 0-0-0-0
Board Revision : C0
Deviation Number : 0-0
EEPROM format version 4
EEPROM contents (hex):
0x00: 04 FF 40 00 92 41 02 03 C1 18 4A 41 44 30 34 34
0x10: 38 30 38 53 47 20 28 31 30 39 30 34 37 33 33 33
0x20: 37 29 82 49 0B 18 0D 04 00 81 00 00 00 00 42 43
0x30: 30 80 00 00 00 00 FF FF FF FF FF FF FF FF FF
0x40: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x50: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x60: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x70: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF

Slot 1:
NM_AIC_64 Port adapter, 3 ports
Port adapter is analyzed
Port adapter insertion time unknown
EEPROM contents at hardware discovery:
Hardware Revision : 1.0
Part Number : 74-1923-01
```



```

Board Revision : 02
PCB Serial Number : DAN05060012
EEPROM format version 4
EEPROM contents (hex):
0x00: 04 FF 40 02 55 41 01 00 82 4A 07 83 01 42 30 32
0x10: C1 8B 44 41 4E 30 35 30 36 30 30 31 32 FF FF FF
0x20: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x30: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x40: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x50: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x60: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x70: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF

```

Table 8-24 describes significant fields shown in the display.

Table 8-24 *show diag (AIC) Field Descriptions*

Field	Description
C2611 2E Mainboard Port adapter, 2 ports	Line card type; number of ports available.
Port adapter is analyzed	The system has identified the port adapter.
Port adapter insertion time	Elapsed time since insertion.
Hardware Revision	Version number of the port adapter.
PCB Serial Number	Serial number of the printed circuit board.
Part Number	Part number of the port adapter.
RMA History	Counter that indicates how many times the port adapter has been returned and repaired.
RMA Number	Return material authorization number, which is an administrative number assigned if the port adapter needs to be returned for repair.
Board Revision	Revision number (signifying a minor revision) of the port adapter.
Deviation Number	Revision number (signifying a minor deviation) of the port adapter.
EEPROM format version	Version number of the EEPROM format.
EEPROM contents (hex)	Dumps of EEPROM programmed data.

AIM-VPN in a Cisco 2611XM: Example

The following example shows how to obtain hardware information about an installed AIM-VPN on the Cisco 2611XM router.

```
Router# show diag 0
```

```

Encryption AIM 1:
  Hardware Revision      :1.0
  Top Assy. Part Number  :800-03700-01
  Board Revision         :A0
  Deviation Number       :0-0
  Fab Version            :02
  PCB Serial Number      :JAB9801ABCD
  RMA Test History       :00
  RMA Number             :0-0-0-0
  RMA History            :00
  EEPROM format version 4
  EEPROM contents (hex):

```

```

0x00:04 FF 40 03 0B 41 01 00 C0 46 03 20 00 0E 74 01
0x10:42 41 30 80 00 00 00 02 02 C1 8B 4A 41 42 39
0x20:38 30 31 41 42 43 44 03 00 81 00 00 00 04 00
0x30:FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x40:FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x50:FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x60:FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x70:FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF

```

Table 8-25 describes significant fields shown in the display.

Table 8-25 *show diag (AIM-VPN) Field Descriptions*

Field	Description
Hardware Revision	Version number of the port adapter.
Top Assy. Part Number	Part number of the port adapter.
Board Revision	Revision number (signifying a minor revision) of the port adapter.
Deviation Number	Revision number (signifying a minor deviation) of the port adapter.
PCB Serial Number	Serial number of the printed circuit board.
RMA Number	Return material authorization number, which is an administrative number assigned if the port adapter needs to be returned for repair.
RMA History	Counter that indicates how many times the port adapter has been returned and repaired.
EEPROM format version	Version number of the EEPROM format.
EEPROM contents (hex)	Dumps of EEPROM programmed data.

MSC-100 on the Cisco 7304 Router: Example

The following is sample output from the **show diag slot-number** version of the command for an MSC-100 located in slot number 4 on a Cisco 7304 router. Information about the MSC is followed by information for its associated SPAs:

Router# **show diag 4**

Slot 4:

```

7304-MSC-100 SPA Carrier Card Line Card
Line Card state: Active
Insertion time: 00:08:49 ago
Bandwidth points: 4000000
EEPROM contents at hardware discovery:
Hardware Revision      : 0.18
Boot Time out          : 0000
PCB Serial Number      : CSJ07288905
Part Number            : 73-8789-01
Board Revision         : A0
Fab Version            : 02
RMA Test History       : 00
RMA Number             : 0-0-0-0
RMA History            : 00
Deviation Number       : 0-0
Product Number         : 7304-MSC-100
Top Assy. Part Number  : 68-1163-04
Manufacturing Test Data : 00 00 00 00 00 00 00 00
Field Diagnostics Data : 00 00 00 00 00 00 00 00
Calibration Data       : Minimum: 0 dBmV, Maximum: 0 dBmV
    Calibration values :
EEPROM format version 4

```

```

EEPROM contents (hex):
0x00: 04 FF 40 04 50 41 00 12 46 00 00 C1 8B 43 53 4A
0x10: 30 37 32 38 38 39 30 35 82 49 22 55 01 42 41 30
0x20: 02 02 03 00 81 00 00 00 00 04 00 80 00 00 00 00
0x30: CB 94 37 33 30 34 2D 4D 53 43 2D 31 30 30 20 20
0x40: 20 20 20 20 20 20 87 44 04 8B 04 C4 08 00 00 00
0x50: 00 00 00 00 00 C5 08 00 00 00 00 00 00 00 00 C8
0x60: 09 00 00 00 00 00 00 00 00 00 00 C7 7C F6 44 3F 30
0x70: 00 00 00 00 00 00 00 00 00 00 00 00 02 EE FF C8
0x80: C8 37 26 05 DC 64 28 1E 37 26 09 C4 64 32 28 32
0x90: DD 0C E4 64 32 28 43 24 2E E0 AA 82 64 F4 24 00
0xA0: 00 00 00 00 00 00 F0 2E FF FF FF FF FF FF FF
0xB0: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0xC0: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0xD0: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0xE0: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0xF0: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x100: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x110: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x120: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x130: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x140: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x150: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x160: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x170: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x180: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x190: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x1A0: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x1B0: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x1C0: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x1D0: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x1E0: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x1F0: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF

FPGA information:
Current FPGA version      : 00.23
IOS bundled FPGA version  : 00.23
CPLD version              : 01.02

```

```

Subslot 4/1:
Shared port adapter: SPA-4FE-7304, 4 ports
State: ok
Insertion time: 00:15:13 ago
Bandwidth: 400000 kbps
EEPROM contents:
.
.
.

```

NSE-100 on the Cisco 7304 Router: Example

The following example displays diagnostic information about the NSE-100 in slot 0 of a Cisco 7304 router:

```

Router# show diag 0
Slot 0/1:
NSE Card state:Primary
Insertion time:00:03:47 ago
C7300 NSE Mainboard EEPROM:
Hardware Revision      :2.3
PCB Serial Number      :CAB0532JYYT
Part Number            :73-5198-02
Board Revision         :A0
Fab Version            :02
RMA Test History       :00

```

show diag

```

RMA Number           :0-0-0-0
RMA History           :00
Deviation Number      :0-0
Product Number        :7300-NSE-100
Top Assy. Part Number :68-1002-02
Manufacturing Test Data :00 00 00 00 00 00 00 00
Field Diagnostics Data :00 00 00 00 00 00 00 00
Calibration Data      :Minimum:0 dBmV, Maximum:0 dBmV
    Calibration values :
EEPROM format version 4
EEPROM contents (hex):
    0x00:04 FF 40 02 8B 41 02 03 C1 8B 43 41 42 30 35 33
    0x10:32 4A 59 59 54 82 49 14 4E 02 42 41 30 02 02 03
    0x20:00 81 00 00 00 00 04 00 80 00 00 00 00 CB 94 37
    0x30:33 30 30 2D 4E 53 45 2D 31 30 30 20 20 20 20 20
    0x40:20 20 20 87 44 03 EA 02 C4 08 00 00 00 00 00 00
    0x50:00 00 C5 08 00 00 00 00 00 00 00 00 00 C8 09 00 00
    0x60:00 00 00 00 00 00 00 00 C7 7C F6 44 3F 30 F6 44 3F
    0x70:30 F6 44 3F 30 00 00 00 00 07 08 64 32 28 37 26
    0x80:09 C4 5A 32 28 32 DD 0C E4 5A 2D 23 43 24 13 88
    0x90:64 32 28 65 BA 2E E0 AA 82 64 F4 24 00 00 00 00
    0xA0:00 00 00 EF 1C FF FF FF FF FF FF FF FF FF FF FF
    0xB0:FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
    0xC0:FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
    0xD0:FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
    0xE0:FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
    0xF0:FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF

```

C7300 NSE Daughterboard EEPROM:

```

Hardware Revision     :2.0
PCB Serial Number     :CAB0533K3PP
Part Number           :73-5673-03
Board Revision        :A0
Fab Version           :03
RMA Test History      :00
RMA Number            :0-0-0-0
RMA History           :00
Deviation Number      :0-0
Product Number        :7300-NSE-100
Top Assy. Part Number :68-1002-02
Manufacturing Test Data :00 00 00 00 00 00 00 00
Field Diagnostics Data :00 00 00 00 00 00 00 00
Calibration Data      :Minimum:0 dBmV, Maximum:0 dBmV
    Calibration values :
EEPROM format version 4
EEPROM contents (hex):
    0x00:04 FF 40 02 8C 41 02 00 C1 8B 43 41 42 30 35 33
    0x10:33 4B 33 50 50 82 49 16 29 03 42 41 30 02 03 03
    0x20:00 81 00 00 00 00 04 00 80 00 00 00 00 CB 94 37
    0x30:33 30 30 2D 4E 53 45 2D 31 30 30 20 20 20 20 20
    0x40:20 20 20 87 44 03 EA 02 C4 08 00 00 00 00 00 00
    0x50:00 00 C5 08 00 00 00 00 00 00 00 00 00 C8 09 00 00
    0x60:00 00 00 00 00 00 00 00 C7 7C F6 44 3F 30 00 00 00
    0x70:00 00 00 00 00 00 00 00 00 06 72 64 1E 1C 37 26
    0x80:07 08 64 32 28 37 26 00 00 00 00 00 00 00 00 00
    0x90:00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
    0xA0:00 00 00 FB BA FF FF FF FF FF FF FF FF FF FF FF
    0xB0:FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
    0xC0:FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
    0xD0:FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
    0xE0:FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
    0xF0:FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF

```

FPGA information:

```

Current NSE MB FPGA version      :0.3
IOS bundled NSE MB FPGA version :0.12
Current NSE DB FPGA version      :0.3
IOS bundled NSE DB FPGA version :0.10
Fault History Buffer:
7300 Software (C7300-IS-M), Experimental Version 12.1(20011206:191841) [user-ws1 179]
Compiled Tue 29-Jan-02 08:10 by
Signal = 22, Code = 0x0, Uptime 00:00:48
$0 :FFFFFFFF, AT :47001098, v0 :10020028, v1 :0000006F
a0 :A0000000, a1 :00000005, a2 :00000001, a3 :10020028
t0 :00000028, t1 :3401E101, t2 :34018100, t3 :FFFF00FF
t4 :40332E68, t5 :43204650, t6 :70646174, t7 :69707065
s0 :FFFFFFFF, s1 :FFFFFFFF, s2 :FFFFFFFF, s3 :FFFFFFFF
s4 :FFFFFFFF, s5 :FFFFFFFF, s6 :FFFFFFFF, s7 :FFFFFFFF
t8 :00000000, t9 :00000000, k0 :3041D001, k1 :30410000
gp :FFFFFFFF, sp :41AA8F20, s8 :FFFFFFFF, ra :4036B6A4
EPC :4036B69C, SREG :3401E103, Cause :FFFFFFFF
Error EPC :FFFFFFFF, BadVaddr :FFFFFFFF

ROMMON Last Error Info:
count:19, reason:reset
pc:0x4020BFBC, error address:0x00000000
Stack Trace:
FP:0x00000000, PC:0x00000000
FP:0x00000000, PC:0x00000000
.
.
.

```

Shared Port Adapters on the Cisco 7304 Router: Example

The following is sample output from the **show diag subslot** command for a 4-Port 10/100 Fast Ethernet SPA located in the bottom subslot (1) of the MSC that is installed in slot 4 on a Cisco 7304 router:

```

Router# show diag subslot 4/1
Subslot 4/1:
Shared port adapter: SPA-4FE-7304, 4 ports
Info: hw-ver=0x100, sw-ver=0x0 fpga-ver=0x0
State: ok
Insertion time: 23:20:42 ago
Bandwidth: 400000 kbps
EEPROM contents:
Hardware Revision      : 1.0
Boot Time out         : 0190
PCB Serial Number     : JAB073204G5
Part Number           : 73-8717-03
73/68 Level Revision  : 01
Fab Version           : 02
RMA Test History      : 00
RMA Number            : 0-0-0-0
RMA History           : 00
Deviation Number      : 0
Product Number        : SPA-4FE-7304
Product Version Id    : V01
Top Assy. Part Number : 68-2181-01
73/68 Level Revision  : A0
CLEI Code             : CNS9420AAA
Base MAC Address      : 0000.0000.0000
MAC Address block size : 1024
Manufacturing Test Data : 00 00 00 00 00 00 00 00
Field Diagnostics Data : 00 00 00 00 00 00 00 00
Field Diagnostics Data : 00 00 00 00 00 00 00 00
                        00 00 00 00 00 00 00 00

```

■ show diag

```

00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00
Calibration Data      : Minimum: 0 dBmV, Maximum: 0 dBmV
  Calibration values  :
Power Consumption     : 160000mW max
  Mode 1 : 0mW
  Mode 2 : 0mW
  Mode 3 : 0mW
EEPROM format version 4
EEPROM contents (hex):
0x00: 04 FF 40 04 35 41 01 00 46 01 90 C1 8B 4A 41 42
0x10: 30 37 33 32 30 34 47 35 82 49 22 0D 03 8A 30 31
0x20: 20 20 02 02 03 00 81 00 00 00 00 04 00 88 00 00
0x30: 00 00 CB 94 53 50 41 2D 34 46 45 2D 37 33 30 34
0x40: 20 20 20 20 20 20 20 20 89 56 30 31 20 87 44 08
0x50: 85 01 8A 41 30 20 20 C6 8A 43 4E 53 39 34 32 30
0x60: 41 41 41 CF 06 00 00 00 00 00 00 00 43 04 00 C4 08
0x70: 00 00 00 00 00 00 00 00 C5 08 00 00 00 00 00 00
0x80: 00 00 F4 00 64 00 00 00 00 00 00 00 00 00 00 00
0x90: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0xA0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0xB0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0xC0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0xD0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0xE0: 00 00 00 00 00 00 00 00 C8 09 00 00 00 00 00 00
0xF0: 00 00 00 00 D7 08 3E 80 00 00 00 00 00 00 F3 00
0x100: 41 01 08 F6 48 43 34 F6 49 44 35 02 31 04 B0 B4
0x110: A0 8C 00 00 05 DC 64 46 32 00 00 07 08 64 46 32
0x120: 00 00 09 C4 64 46 32 00 00 0C E4 64 46 32 00 00
0x130: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 FE 02
0x140: F2 A6 FF FF FF FF FF FF FF FF FF FF FF FF FF
0x150: CC A0 00 00 00 00 00 00 00 00 00 00 00 00 00
0x160: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x170: 00 00 D4 A0 00 00 00 00 00 00 00 00 00 00 00
0x180: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x190: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x1A0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x1B0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x1C0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x1D0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x1E0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x1F0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
FPGA version:
  Software version : 04.17
  Hardware version : 04.17

```

The following is sample output from the **show diag subslot** command for a 2-Port 10/100/1000 Gigabit Ethernet SPA located in the top subslot (0) of the MSC that is installed in slot 4 on a Cisco 7304 router:

```

Router# show diag subslot 4/0
Subslot 4/0:
  Shared port adapter: SPA-2GE-7304, 2 ports
  Info: hw-ver=0x17, sw-ver=0x0 fpga-ver=0x0
  State: ok
  Insertion time: 00:08:47 ago

```

```

Bandwidth: 2000000 kbps
EEPROM contents:
Hardware Revision      : 0.23
Boot Time out         : 0190
PCB Serial Number     : JAB073406YH
Part Number           : 73-8792-02
73/68 Level Revision  : 01
Fab Version           : 02
RMA Test History      : 00
RMA Number            : 0-0-0-0
RMA History           : 00
Deviation Number      : 0
Product Number        : SPA-2GE-7304
Product Version Id    : V01
Top Assy. Part Number : 68-2181-01
73/68 Level Revision  : A0
CLEI Code             : CNS9420AAA
Base MAC Address      : 0000.0000.0000
MAC Address block size : 1024
Manufacturing Test Data : 00 00 00 00 00 00 00 00
Field Diagnostics Data : 00 00 00 00 00 00 00 00
Field Diagnostics Data : 00 00 00 00 00 00 00 00
                        00 00 00 00 00 00 00 00
                        00 00 00 00 00 00 00 00
                        00 00 00 00 00 00 00 00
                        00 00 00 00 00 00 00 00
                        00 00 00 00 00 00 00 00
                        00 00 00 00 00 00 00 00
                        00 00 00 00 00 00 00 00
                        00 00 00 00 00 00 00 00
                        00 00 00 00 00 00 00 00
                        00 00 00 00
Calibration Data      : Minimum: 0 dBmV, Maximum: 0 dBmV
  Calibration values :
Power Consumption     : 160000mW max
  Mode 1 : 0mW
  Mode 2 : 0mW
  Mode 3 : 0mW
EEPROM format version 4
EEPROM contents (hex):
0x00: 04 FF 40 04 36 41 00 17 46 01 90 C1 8B 4A 41 42
0x10: 30 37 33 34 30 36 59 48 82 49 22 58 02 8A 30 31
0x20: 20 20 02 02 03 00 81 00 00 00 00 04 00 88 00 00
0x30: 00 00 CB 94 53 50 41 2D 32 47 45 2D 37 33 30 34
0x40: 20 20 20 20 20 20 20 20 89 56 30 31 20 87 44 08
0x50: 85 01 8A 41 30 20 20 C6 8A 43 4E 53 39 34 32 30
0x60: 41 41 41 CF 06 00 00 00 00 00 00 43 04 00 C4 08
0x70: 00 00 00 00 00 00 00 00 C5 08 00 00 00 00 00 00
0x80: 00 00 F4 00 64 00 00 00 00 00 00 00 00 00 00 00
0x90: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0xA0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0xB0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0xC0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0xD0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0xE0: 00 00 00 00 00 00 00 00 C8 09 00 00 00 00 00 00
0xF0: 00 00 00 00 D7 08 3E 80 00 00 00 00 00 00 F3 00
0x100: 41 01 08 F6 48 43 34 F6 49 44 35 02 31 03 E8 B4
0x110: A0 8C 37 26 05 DC 64 46 32 37 26 07 08 64 46 32
0x120: 37 26 09 C4 64 46 32 32 DD 0C E4 64 46 32 43 24
0x130: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 FE 02
0x140: EF E2 FF FF FF FF FF FF FF FF FF FF FF FF FF
0x150: CC A0 00 00 00 00 00 00 00 00 00 00 00 00 00

```

```

0x160: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x170: 00 00 D4 A0 00 00 00 00 00 00 00 00 00 00 00 00
0x180: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x190: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x1A0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x1B0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x1C0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x1D0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x1E0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x1F0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
FPGA version:
Software version : 04.17
Hardware version : 04.17

```

Shared Port Adapter on a Cisco 12000 Series Router: Example

The following is sample output from the **show diag subslot** command for the 1-Port OC-192c/STM-64c POS/RPR XFP SPA in subslot 1 of the SIP located in chassis slot 1 on a Cisco 12000 series router:

```

Router# show diag subslot 1/1
SUBSLOT 1/1 (SPA-OC192POS-XFP): 1-port OC192/STM64 POS/RPR XFP Optics Shared Port Adapter
  Product Identifier (PID) : SPA-OC192POS-XFP
  Version Identifier (VID) : V01
  PCB Serial Number       : PRTA1304061
  Top Assy. Part Number   : 68-2190-01
  Top Assy. Revision      : A0
  Hardware Revision       : 2.0
  CLEI Code               : UNASSIGNED
  Insertion Time          : 00:00:10 (13:14:17 ago)
  Operational Status      : ok

```

Table 8-26 describes the significant fields shown in the display.

Table 8-26 *show diag subslot Field Descriptions*

Field	Description
Product Identifier (PID)	Product number of the SPA.
Version Identifier (VID)	Version number of the SPA.
PCB Serial Number	Serial number of the printed circuit board.
Top Assy. Part Number	Part number of the SPA.
Top Assy. Revision	Revision number (signifying a minor revision) of the SPA.
Hardware Revision	Revision number (signifying a minor revision) of the SPA hardware.
CLEI Code	Common Language Equipment Identification number.
Insertion Time	Time when the SPA was installed, and elapsed time between that insertion time and the current time.
Operational Status	Current status of the SPA. For more information about the status field descriptions, refer to the show hw-module subslot oir command.

The following is sample output from the **show diag subslot details** command for the 1-Port OC-192c/STM-64c POS/RPR XFP SPA in subslot 1 of the SIP located in chassis slot 1 on a Cisco 12000 series router:

```

Router# show diag subslot 1/1 details
SUBSLOT 1/1 (SPA-OC192POS-XFP): 1-port OC192/STM64 POS/RPR XFP Optics Shared Port Adapter
  EEPROM version          : 4

```



```

Compatible Type           : 0xFF
Controller Type          : 1100
Hardware Revision        : 2.0
Boot Timeout             : 400 msecs
PCB Serial Number       : PRTA1304061
PCB Part Number         : 73-8546-01
PCB Revision            : A0          Fab Version           : 01
RMA Test History         : 00
RMA Number              : 0-0-0-0
RMA History             : 00
Deviation Number        : 0
Product Identifier (PID) : SPA-OC192POS-XFP
Version Identifier (VID) : V01
Top Assy. Part Number    : 68-2190-01
Top Assy. Revision      : A0          IDPROM Format Revision : 36
System Clock Frequency   : 00 00 00 00 00 00 00 00
                        : 00 00 00 00 00 00 00 00
                        : 00 00 00 00 00 00
CLEI Code               : UNASSIGNED
Base MAC Address        : 00 00 00 00 00 00
MAC Address block size  : 0
Manufacturing Test Data : 00 00 00 00 00 00 00 00
Field Diagnostics Data  : 00 00 00 00 00 00 00 00
Calibration Data        : Minimum: 0 dBmV, Maximum: 0 dBmV
    Calibration values :
Power Consumption       : 11000 mWatts (Maximum)
Environment Monitor Data : 03 30 04 B0 46 32 07 08
                        : 46 32 09 C4 46 32 0C E4
                        : 46 32 13 88 46 32 07 08
                        : 46 32 EB B0 50 3C 00 00
                        : 00 00 00 00 00 00 00 00
                        : 00 00 00 00 00 00 00 00
                        : 00 00 FE 02 F6 AC
Processor Label         : 00 00 00 00 00 00 00 00
Platform features       : 00 00 00 00 00 00 00 00
                        : 00 00 00 00 00 00 00 00
                        : 00 00 00 00 00 00 00 00
                        : 00 00 00 00 00 00 00 00
Asset ID               :
Asset Alias            :
Insertion Time         : 00:00:10 (13:14:24 ago)
Operational Status     : ok

```

SPA Interface Processor on a Cisco 12000 Series Router: Example

The following is sample output from the **show diag** command for a MSC located in chassis slot 2 on a Cisco 12000 series router:

Router# **show diag 2**

```

SLOT 2 (RP/LC 2 ): Modular 10G SPA Interface Card
  MAIN: type 149, 800-26270-01 rev 84
        Deviation: 0
        HW config: 0x00 SW key: 00-00-00
  PCA: 73-9607-01 rev 91 ver 1
        Design Release 1.0 S/N SAD08460678
  MBUS: Embedded Agent
        Test hist: 0x00 RMA#: 00-00-00 RMA hist: 0x00
  DIAG: Test count: 0x00000000 Test results: 0x00000000
  FRU: Linecard/Module: 12000-SIP-650
  FRU: Linecard/Module: 12000-SIP-650
        Processor Memory: MEM-LC5-1024=(Non-Replaceable)
        Packet Memory: MEM-LC5-PKT-256=(Non-Replaceable)
  L3 Engine: 5 - ISE OC192 (10 Gbps)

```

```

MBUS Agent Software version 1.114 (RAM) (ROM version is 3.4)
ROM Monitor version 255.255
Fabric Downloader version used 3.7 (ROM version is 255.255)
Primary clock is CSC 1
Board is analyzed
Board State is Line Card Enabled (IOS RUN )
Insertion time: 1d00h (2d08h ago)
Processor Memory size: 1073741824 bytes
TX Packet Memory size: 268435456 bytes, Packet Memory pagesize: 32768 bytes
RX Packet Memory size: 268435456 bytes, Packet Memory pagesize: 32768 bytes
0 crashes since restart

```

```

SPA Information:
  subslot 2/0: SPA-OC192POS-XFP (0x44C), status is ok
  subslot 2/1: Empty
  subslot 2/2: Empty
  subslot 2/3: Empty

```

ADSL HWICs: Example

The following is sample output from the **show diag** command for a Cisco 2811 router with HWIC-1ADSL installed in slot 1 and HWIC-1ADSLI installed in slot 2. Each HWIC has a daughtercard as part of its assembly. The command results below give the output from the HWIC followed by the output from its daughtercard.

Router# **show diag 0**

```

Slot 0:
C2811 Motherboard with 2FE and integrated VPN Port adapter, 2 ports
  Port adapter is analyzed
  Port adapter insertion time unknown
  Onboard VPN          : v2.2.0
  EEPROM contents at hardware discovery:
  PCB Serial Number    : FOC09052HHA
  Hardware Revision    : 2.0
  Top Assy. Part Number : 800-21849-02
  Board Revision       : B0
  Deviation Number     : 0
  Fab Version          : 06
  RMA Test History     : 00
  RMA Number           : 0-0-0-0
  RMA History          : 00
  Processor type       : 87
  Hardware date code   : 20050205
  Chassis Serial Number : FTX0908A0B0
  Chassis MAC Address   : 0013.1ac2.2848
  MAC Address block size : 24
  CLEI Code            : CNMJ7N0BRA
  Product (FRU) Number : CISCO2811
  Part Number          : 73-7214-09
  Version Identifier    : NA
  EEPROM format version 4
  EEPROM contents (hex):
    0x00: 04 FF C1 8B 46 4F 43 30 39 30 35 32 48 48 41 40
    0x10: 03 E7 41 02 00 C0 46 03 20 00 55 59 02 42 42 30
    0x20: 88 00 00 00 00 02 06 03 00 81 00 00 00 00 04 00
    0x30: 09 87 83 01 31 F1 1D C2 8B 46 54 58 30 39 30 38
    0x40: 41 30 42 30 C3 06 00 13 1A C2 28 48 43 00 18 C6
    0x50: 8A 43 4E 4D 4A 37 4E 30 42 52 41 CB 8F 43 49 53
    0x60: 43 4F 32 38 31 31 20 20 20 20 20 20 82 49 1C 2E
    0x70: 09 89 20 20 4E 41 D9 02 40 C1 FF FF FF FF FF FF

```

WIC Slot 1:

```

ADSL over POTS
Hardware Revision       : 7.0
Top Assy. Part Number   : 800-26247-01
Board Revision          : 01
Deviation Number        : 0
Fab Version             : 07
PCB Serial Number       : FHH093600D4
RMA Test History        : 00
RMA Number              : 0-0-0-0
RMA History             : 00
Product (FRU) Number    : HWIC-1ADSL
Version Identifier      : V01
CLEI Code               :
EEPROM format version 4
EEPROM contents (hex):
0x00: 04 FF 40 04 C8 41 07 00 C0 46 03 20 00 66 87 01
0x10: 42 30 31 88 00 00 00 00 02 07 C1 8B 46 48 48 30
0x20: 39 33 36 30 30 44 34 03 00 81 00 00 00 00 04 00
0x30: CB 94 48 57 49 43 2D 31 41 44 53 4C 20 20 20 20
0x40: 20 20 20 20 20 20 89 56 30 31 20 D9 02 40 C1 C6
0x50: 8A FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x60: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x70: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF

```

EM Slot 0:

```

ADSL over POTS non-removable daughtercard
Hardware Revision       : 5.0
Part Number            : 73-9307-05
Board Revision          : 03
Deviation Number        : 0
Fab Version            : 05
PCB Serial Number       : FHH0936006E
RMA Test History        : 00
RMA Number              : 0-0-0-0
RMA History             : 00
Fab Part Number         : 28-6607-05
Manufacturing Test Data : 00 00 00 00 00 00 00 00 00
Field Diagnostics Data  : 00 00 00 00 00 00 00 00 00
Connector Type          : 01
Version Identifier      : V01
Product (FRU) Number    :
EEPROM format version 4
EEPROM contents (hex):
0x00: 04 FF 40 04 7A 41 05 00 82 49 24 5B 05 42 30 33
0x10: 88 00 00 00 00 02 05 C1 8B 46 48 48 30 39 33 36
0x20: 30 30 36 45 03 00 81 00 00 00 00 00 04 00 85 1C 19
0x30: CF 05 C4 08 00 00 00 00 00 00 00 00 C5 08 00 00
0x40: 00 00 00 00 00 00 05 01 89 56 30 31 20 FF FF FF
0x50: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x60: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x70: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF

```

WIC Slot 2:

```

ADSL over ISDN
Hardware Revision       : 7.0
Top Assy. Part Number   : 800-26248-01
Board Revision          : 01
Deviation Number        : 0
Fab Version             : 07
PCB Serial Number       : FHH093600DA
RMA Test History        : 00
RMA Number              : 0-0-0-0
RMA History             : 00
Product (FRU) Number    : HWIC-1ADSLI

```

■ show diag

```

Version Identifier      : V01
CLEI Code              :
EEPROM format version 4
EEPROM contents (hex):
  0x00: 04 FF 40 04 C9 41 07 00 C0 46 03 20 00 66 88 01
  0x10: 42 30 31 88 00 00 00 02 07 C1 8B 46 48 48 30
  0x20: 39 33 36 30 30 44 41 03 00 81 00 00 00 04 00
  0x30: CB 94 48 57 49 43 2D 31 41 44 53 4C 49 20 20 20
  0x40: 20 20 20 20 20 20 89 56 30 31 20 D9 02 40 C1 C6
  0x50: 8A FF FF FF FF FF FF FF FF FF FF FF FF FF FF
  0x60: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
  0x70: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF

EM Slot 0:
ADSL over ISDN non-removable daughtercard
Hardware Revision      : 5.0
Part Number            : 73-9308-05
Board Revision         : 03
Deviation Number       : 0
Fab Version            : 05
PCB Serial Number      : FHH0936008M
RMA Test History       : 00
RMA Number             : 0-0-0-0
RMA History            : 00
Fab Part Number        : 28-6607-05
Manufacturing Test Data : 00 00 00 00 00 00 00 00
Field Diagnostics Data : 00 00 00 00 00 00 00 00
Connector Type         : 01
Version Identifier      : V01
Product (FRU) Number   :
EEPROM format version 4
EEPROM contents (hex):
  0x00: 04 FF 40 04 7B 41 05 00 82 49 24 5C 05 42 30 33
  0x10: 88 00 00 00 00 02 05 C1 8B 46 48 48 30 39 33 36
  0x20: 30 30 38 4D 03 00 81 00 00 00 00 04 00 85 1C 19
  0x30: CF 05 C4 08 00 00 00 00 00 00 00 00 C5 08 00 00
  0x40: 00 00 00 00 00 00 05 01 89 56 30 31 20 FF FF FF
  0x50: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
  0x60: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
  0x70: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF

```

Related Commands	Command	Description
	dsl operating-mode (ADSL)	Modifies the operating mode of the digital subscriber line for an ATM interface.
	show c7300	Displays the types of hardware (processors, line cards, jacket cards, and so on) installed in the Cisco 7304 router slots, including the bundled, Flash, and current FPGA versions.
	show c7300 errorlog	Displays error information on a Cisco 7304 router.
	show dsl interface atm	Shows all of the ADSL-specific information for a specified ATM interface.
	show controllers fastethernet	Displays Fast Ethernet interface information, transmission statistics and errors, and applicable MAC destination address and VLAN filtering tables.
	show controllers gigabitethernet	Displays Gigabit Ethernet interface information, transmission statistics and errors, and applicable MAC destination address and VLAN filtering tables.

show environment

To display power supply, fan, voltage, and temperature information for the router, use the **show environment** command in privileged EXEC configuration mode.

show environment [**all** | **last** | **table**]

Syntax Description	all	(Optional) Displays a detailed listing of all environmental monitor parameters (for example, the power supplies, temperature readings, voltage readings, and blower speeds). This is the default.
	last	(Optional) Displays information from the last measurement made before a reload of the system.
	table	(Optional) Displays low and high values for warning, critical, and shutdown threshold settings for various voltages and temperature.

Defaults	all
----------	------------

Command Modes	Privileged EXEC
---------------	-----------------

Command History	Release	Modification
	10.0	This command was introduced.
	11.2 GS	The alarms , fans , hardware , leds , power-supply , table , temperature , and voltages keywords were added for Cisco 12000 series GSRs.
	11.3(6)AA	This command was expanded to monitor the RPs and board temperature for the Cisco AS5300 platform, Cisco 3600 series routers, Cisco 7200 series routers, and the Cisco 12000 series GSRs.
	12.2 S	This command was integrated into Cisco IOS Release 12.2 S.
	12.2(20)S2	This command was integrated into Cisco IOS Release 12.2(20)S2 to support MSCs and SPAs on the Cisco 7304 router using the all , last , and table keywords.

Usage Guidelines	For the chassis, NPEs, NSEs, line cards, and MSCs, a routine runs once a minute that reads environmental measurements from sensors and stores the output into a buffer. For SPAs, the temperature and voltage sensors are read every few seconds to get environmental data. The environmental buffer is displayed on the console when you use the show environment command.
------------------	--

If a measurement exceeds desired margins, but has not exceeded fatal margins, a warning message is written to the system console. The system software queries the sensors for measurements once a minute, but warnings for a given test point are written at most once every hour for sensor readings in the warning range and once every five minutes for sensor readings in the critical range. If a measurement is out of line within these time segments, an automatic warning message appears on the console. You can query the environmental status using the **show environment** command at any time to determine whether a measurement is at the warning or critical tolerance.

A SPA is shut down when any of the SPA environment readings exceed the shutdown threshold.

If a shutdown occurs because of detection of fatal environmental margins, the last measured value from each sensor is stored in internal nonvolatile memory.

For environmental specifications, refer to the hardware installation and configuration publication for your individual chassis.

For NPEs, NSEs, line cards, and MSCs, environmental information is recorded in the CISCO-ENVMON-MIB. SPAs are not supported by the CISCO-ENVMON-MIB. In Cisco IOS Release 12.2(20)S2 and later, the CISCO-ENTITY-SENSOR-MIB supports environmental information for SPAs, as well as NPEs, NSEs, line cards, and MSCs.

Examples

Cisco 7304 Router Example Using the all Keyword

The following is sample output from the **show environment all** command on a Cisco 7304 router with modular services cards (MSCs) and shared port adapters (SPAs) installed:

```
Router# show environment all
Power Supplies:
    Power supply 1 is AC power supply. Unit is on.
    Power supply 2 is empty.
Fans:
    Fan 1 is on.
    Fan 2 is on.
Temperature readings:
    Active RP (NPEG100, slot 0):
        npeg100 outlet      measured at 29C/84F
        npeg100 inlet       measured at 34C/93F
        npeg100 hotspot     measured at 35C/95F
    Line card (7304-MSC-100, slot 4):
        7304-MSC-100       measured at 32C/89F
    Card in subslot 4/0:
        SPA-4FE-7304 inlet  measured at 31C/87F
        SPA-4FE-7304 outlet measured at 32C/89F
Voltage readings:
    Active RP (NPEG100, slot 0):
        npe outlet 2.5 V measured at 2.496 V
        npe outlet 3.3 V measured at 3.302 V
        npe outlet 5.0 V measured at 4.992 V
        npe outlet 12.0 V measured at 11.812 V
        npe outlet 3.3c V measured at 3.199 V
        npe inlet 1.5 V measured at 1.494 V
        npe outlet 1.8 V measured at 1.790 V
        npe outlet 1.2 V measured at 1.198 V
        npe outlet 1.2c V measured at 1.198 V
    Line card (7304-MSC-100, slot 4):
        7304-MSC-100 0.75 V measured at 0.733 V
        7304-MSC-100 1.5 V measured at 1.494 V
        7304-MSC-100 2.5 V measured at 2.483 V
        7304-MSC-100 3.3 V measured at 3.250 V
        7304-MSC-100 12 V measured at 11.937 V
    Card in subslot 4/0:
        SPA-4FE-7304 1.8V measured at 1.802 V
        SPA-4FE-7304 1.5V measured at 1.503 V
        SPA-4FE-7304 2.5V measured at 2.474 V
        SPA-4FE-7304 3.3V measured at 3.252 V
        SPA-4FE-7304 1.0V measured at 1.015 V
Envn stats saved 13 time(s) since reload
```

Cisco 7304 Router Example Using the last Keyword

The following is sample output from the **show environment last** command on a Cisco 7304 router with MSCs and SPAs installed and an NSE-100:

```
Router# show environment last
Temperature information:
  NSE board:
    nse outlet          is unmeasured
    nse inlet           is unmeasured
    nse hotspot         is unmeasured
    nse db              is unmeasured
  Line card slot 4:
    7304-MSC-100        is unmeasured
  Card in subslot 4/1:
    SPA-4FE-7304 inlet  previously measured at 30C/86F
    SPA-4FE-7304 outlet previously measured at 32C/89F
Voltage information:
  NSE board:
    nse outlet 1.8 V    is unmeasured
    nse outlet 2.5 V    is unmeasured
    nse outlet 3.3 V    is unmeasured
    nse outlet 5 V      is unmeasured
    nse outlet 12 V     is unmeasured
    nse inlet 1.8 V     is unmeasured
    nse inlet 3.3 V     is unmeasured
    nse inlet 1.5 V     is unmeasured
    nse hotspot 1.8 V   is unmeasured
    nse db 1.65 V      is unmeasured
    nse db 1.8 V       is unmeasured
  Line card slot 4:
    7304-MSC-100 0.75 V is unmeasured
    7304-MSC-100 1.5 V  is unmeasured
    7304-MSC-100 2.5 V  is unmeasured
    7304-MSC-100 3.3 V  is unmeasured
    7304-MSC-100 12 V   is unmeasured
  Card in subslot 4/1:
    SPA-4FE-7304 1.8V   previously measured at 1.823 V
    SPA-4FE-7304 1.5V   previously measured at 1.512 V
    SPA-4FE-7304 2.5V   previously measured at 2.504 V
    SPA-4FE-7304 3.3V   previously measured at 3.258 V
    SPA-4FE-7304 1.0V   previously measured at 1.014 V
Last shutdown reason: shutdown undefined
```

Cisco 7304 Router Example Using the table Keyword

The following is sample output from the **show environment table** command on a Cisco 7304 router with MSCs and SPAs installed:

```
Router# show environment table
Temperature tables:
  Active RP (NPEG100, slot 0):
    Sample Point    HighWarning    HighCritical    HighShutdown
    npeg100 outlet  53C/127F       68C/154F        73C/163F
    npeg100 inlet   53C/127F       68C/154F        73C/163F
    npeg100 hotspot 53C/127F       68C/154F        73C/163F
  Line card (7304-MSC-100, slot 4):
    Sample Point    HighWarning    HighCritical    HighShutdown
    7304-MSC-100    48C/118F       63C/145F        68C/154F
  Card in subslot 4/0:
    Sample Point    HighWarning    HighCritical    HighShutdown
    SPA-4FE-7304 inlet 52C/125F       67C/152F        72C/161F
    SPA-4FE-7304 outlet 52C/125F       67C/152F        72C/161F
Voltage tables:
  Active RP (NPEG100, slot 0):
```

```

Sample Point      LowShut  LowCrit  LowWarn  HighWarn  HighCrit  HighShut
npe outlet 2.5 V 2.275 V 2.375 V 2.400 V 2.600 V 2.625 V 2.725 V
npe outlet 3.3 V 3.003 V 3.135 V 3.185 V 3.415 V 3.465 V 3.597 V
npe outlet 5.0 V 4.500 V 4.750 V 4.800 V 5.200 V 5.250 V 5.500 V
npe outlet 12.0 V 9.960 V 10.440 V 10.800 V 13.200 V 13.560 V 14.040 V
npe outlet 3.3c V 3.003 V 3.135 V 3.185 V 3.415 V 3.465 V 3.597 V
npe inlet 1.5 V 1.350 V 1.425 V 1.455 V 1.545 V 1.575 V 1.650 V
npe outlet 1.8 V 1.620 V 1.710 V 1.728 V 1.872 V 1.890 V 1.980 V
npe outlet 1.2 V 1.128 V 1.164 V 1.167 V 1.233 V 1.236 V 1.272 V
npe outlet 1.2c V 1.128 V 1.164 V 1.167 V 1.233 V 1.236 V 1.272 V
Line card (7304-MSC-100, slot 4):
Sample Point      LowShut  LowCrit  LowWarn  HighWarn  HighCrit  HighShut
7304-MSC-100 0.75 V 0.559 V 0.600 V 0.600 V 0.900 V 0.900 V 0.941 V
7304-MSC-100 1.5 V 1.350 V 1.440 V 1.455 V 1.545 V 1.560 V 1.650 V
7304-MSC-100 2.5 V 2.250 V 2.375 V 2.400 V 2.600 V 2.625 V 2.750 V
7304-MSC-100 3.3 V 2.970 V 3.135 V 3.168 V 3.432 V 3.465 V 3.630 V
7304-MSC-100 12 V 9.960 V 10.440 V 10.800 V 13.200 V 13.560 V 14.040 V
Card in subslot 4/0:
Sample Point      LowShut  LowCrit  LowWarn  HighWarn  HighCrit  HighShut
SPA-4FE-7304 1.8V 1.620 V 1.710 V 1.728 V 1.872 V 1.890 V 1.980 V
SPA-4FE-7304 1.5V 1.350 V 1.425 V 1.440 V 1.560 V 1.575 V 1.650 V
SPA-4FE-7304 2.5V 2.250 V 2.375 V 2.400 V 2.600 V 2.625 V 2.750 V
SPA-4FE-7304 3.3V 2.970 V 3.135 V 3.168 V 3.432 V 3.465 V 3.630 V
SPA-4FE-7304 1.0V 0.900 V 0.950 V 0.960 V 1.040 V 1.050 V 1.100 V

```

Table 8-27 describes the significant fields show in the display.

Table 8-27 *show environment table Field Descriptions for the Cisco 7304 Router*

Field	Description
Sample Point	Area for which measurements are taken.
LowShut	Lowest level for an out-of-tolerance condition at which the system shuts itself down. For out-of-tolerance conditions with SPA environment variables, only the SPA is shut down.
LowCrit/LowCritical	Level at which a critical message is issued for an out-of-tolerance voltage condition. The system continues to operate; however, the system is approaching shutdown.
LowWarn/LowWarning	Level at which a warning message is issued for an out-of-tolerance voltage condition. The system continues to operate, but operator action is recommended to bring the system back to a normal state.
HighWarn/HighWarning	Level at which a warning message is issued for an out-of-tolerance voltage condition. The system continues to operate, but operator action is recommended to bring the system back to a normal state.
HighCrit/HighCritical	Level at which a critical message is issued for an out-of-tolerance voltage condition. The system continues to operate; however, the system is approaching shutdown.
HighShut/HighShutdown	Highest level for an out-of-tolerance condition at which the system shuts itself down. For out-of-tolerance conditions with SPA environment variables, only the SPA is shut down.

Related Commands	Command	Description
	test hw-module subslot temperature	Tests a temperature sensor on a SPA.

show hw-module subslot

To display diagnostic information about internal hardware devices for a SPA, use the **show hw-module subslot** command in privileged EXEC configuration mode.

```
show hw-module subslot slot/subslot {brief | config | counters | errors | registers | status} {fpga
| mac | optics | phy | spi4} port
```

Syntax Description

<i>slot</i>	(Optional) Chassis slot number. Refer to the appropriate hardware manual for slot information. For MSCs, refer to the platform-specific SPA hardware installation guide or the corresponding “Identifying Slots and Subslots for MSCs and SPAs” topic in the platform-specific SPA software configuration guide.
<i>/subslot</i>	(Optional) Secondary slot number on a MSC where a SPA is installed. Refer to the platform-specific SPA hardware installation guide and the corresponding “Specifying the Interface Address on a SPA” topic in the platform-specific SPA software configuration guide for subslot information.
{ brief config counters errors registers status }	Specifies the display of diagnostic and register information related to the following areas: <ul style="list-style-type: none"> • brief—Reserved for future. • config—Displays information related to configuration of the specified internal hardware device. • counters—Displays statistics related to the processing by the specified internal hardware device. • errors—Reserved for future. • registers—Displays register information for the specified internal hardware device. • status—Displays status information for the specified internal hardware device.
{ fpga mac optics phy spi4 }	Specifies the internal hardware device or path on the SPA for which you want to display diagnostic information, including the field programmable gate array (FPGA) device, MAC device, small form-factor pluggable (SFP) optical transceiver, PHY device, or System Packet Interface Level 4 (SPI4) path from the MSC to the FPGA device.
<i>port</i>	(Optional) Port or interface number. Refer to the appropriate hardware manual for port information. For SPAs, refer to the corresponding “Specifying the Interface Address on a SPA” topics in the platform-specific SPA software configuration guide.

Defaults

No default behavior or values

Command Modes

Privileged EXEC

Command History

Release	Modification
12.2(20)S2	This command was introduced.

Usage Guidelines

Use the **show hw-module subslot** command to obtain diagnostic information about an interface on the SPA.

The **counters** keyword displays a subset of the statistics that are also provided by the **show controllers fastethernet** command and **show controllers gigabitethernet** command for the specified SPA device.

Examples

The following examples provide sample output for several versions of the **show hw-module subslot** command for a 4-Port 10/100 Fast Ethernet SPA located in the top subslot (0) of the MSC that is installed in slot 4 on a Cisco 7304 router:

- [show hw-module subslot config fpga Example, page 8-107](#)
- [show hw-module subslot config phy Example, page 8-107](#)
- [show hw-module subslot config phy on Gigabit Ethernet SPA Example, page 8-108](#)
- [show hw-module subslot counters fpga Example, page 8-108](#)
- [show hw-module subslot status mac Example, page 8-109](#)
- [show hw-module subslot status mac on Gigabit Ethernet SPA Example, page 8-109](#)
- [show hw-module subslot status phy Example, page 8-109](#)
- [show hw-module subslot status phy on Gigabit Ethernet SPA Example, page 8-110](#)

show hw-module subslot config fpga Example

The following shows sample output from the **show hw-module subslot config** command for the FPGA device on the first interface (port 0):

```
Router# show hw-module subslot 4/0 config fpga 0
FPGA RX Config
  RX FIFO parity select is even
  RX CRC check is enabled
  RX SHIM header insertion is disabled
  RX Flow control is enabled
  RX CRC strip is enabled
  RX TCAM LKUP is enabled
FPGA TX Config
  TX FIFO parity select is even
  TX CRC generation is enabled
  TX Padding is enabled
```

show hw-module subslot config phy Example

The following shows sample output from the **show hw-module subslot config** command for the PHY device on the first interface (port 0):

```
Router# show hw-module subslot 4/0 config phy 0
PHY version: identifier1 = 0x141, identifier2 = 0xCD2
PHY Configuration:
control (reg 0) = 0x3100
  PHY state: not in reset, not powered down, not isolated
  speed: 100 Mbps, duplex: full
  auto-negotiation enabled, loopback disabled, collision test disabled
phy specific control (reg 16) = 0x78
```

```

force link good: no
MDI cross-over mode: automatic crossover
Tx FIFO depth: +/- 16 bits, Rx FIFO depth: +/- 16 bits
never assert CRS on transmit, energy detect: off
enable extended distance: no, 125 clock: low
MAC interface power: always up, SQE test: disabled
polarity reversal: enabled, jabber function: enabled
extended phy specific control (reg 20) = 0xCE2
  line loopback: disabled, detect lost lock: no, enabled RCLK
  master downshift counter: 4, slave downshift counter: 0
  default MAC interface speed: 1000 Mbps
  fiber auto-negotiation disabled
  add delay to RX_CLK for RXD outputs: yes
  add delay to GTX_CLK for TXD latching: yes
auto-negotiation advertisement for 10/100 (reg 4) = 0xDE1
  10Base-Tx half-duplex: yes, full-duplex: yes
  100Base-Tx half-duplex: yes, full-duplex: yes
  pause frame support: yes, asymmetric pause: yes
  set remote fault bit: no, advertise next page: no

```

show hw-module subslot config phy on Gigabit Ethernet SPA Example

The following shows sample output from the **show hw-module subslot config** command for the PHY device on the first interface (port 0) on a 2-Port 10/100/1000 Gigabit Ethernet SPA:

```

Router# show hw-module subslot 4/1 config phy 0
PHY version: identifier1 = 0x141, identifier2 = 0xCD2
PHY Configuration:
control (reg 0) = 0x1140
  PHY state: not in reset, not powered down, not isolated
  speed: 1000 Mbps, duplex: full
  auto-negotiation enabled, loopback disabled, collision test disable
phy specific control (reg 16) = 0x78
  force link good: no
  MDI cross-over mode: automatic crossover
  Tx FIFO depth: +/- 16 bits, Rx FIFO depth: +/- 16 bits
  never assert CRS on transmit, energy detect: off
  enable extended distance: no, 125 clock: low
  MAC interface power: always up, SQE test: disabled
  polarity reversal: enabled, jabber function: enabled
extended phy specific control (reg 20) = 0xCE2
  line loopback: disabled, detect lost lock: no, enabled RCLK
  master downshift counter: 4, slave downshift counter: 0
  default MAC interface speed: 1000 Mbps
  fiber auto-negotiation disabled
  add delay to RX_CLK for RXD outputs: yes
  add delay to GTX_CLK for TXD latching: yes
auto-negotiation advertisement for 10/100 (reg 4) = 0x1A0
  1000BaseX half-duplex: no, full-duplex: yes
  pause frame support: yes, asymmetric pause: yes
Extended PHY specific control 2 register(reg 26) = 0x6A
  Fiber signal detect input: forced to be good
  Fiber input impedance: 75 ohm, Fiber input impedance: 75 ohm
  Fiber mode clock disabled, Fiber output boost: 1000Base-X
  Fiber output amplitude: 0.7V

```

show hw-module subslot counters fpga Example

The following shows sample output from the **show hw-module subslot counters** command for the FPGA device on the first interface (port 0):

**Note**

This information is also available using the **show controllers fastethernet** command and **show controllers gigabitethernet** command.

```
Router# show hw-module subslot 4/0 counters fpga 0
Input: Total (good & bad) packets: 5734
        TCAM drops: 4908
        Satisfy (host-backpressure) drops: 0
        CRC drops: 0
        PL3 RERRs: 0
Output: EOP (SPI4) errors: 0
```

show hw-module subslot status mac Example

The following shows sample output from the **show hw-module subslot** command for MAC device status on the first interface (port 0):

```
Router# show hw-module subslot 4/0 status mac 0
Status registers:
  speed = 100 Mbps, duplex = full, interface mode = copper
  spi3 side loopback is disabled, line side loopback is disabled
  padding is disabled, crc add is disabled
  force duplex is enabled
Rx FIFO status:
  Read pointer = 0xCDE, Write pointer = 0xCDE
  Occupancy of FIFO in 8 byte locations = 0
  Reset is not set
  Overflow event did not occur
Tx FIFO status:
  Read pointer = 0x498, Write pointer = 0x498
  Occupancy of FIFO in 8 byte locations = 0
  Overflow event did not occur
  Underflow event did not occur
  Out of sequence event did not occur
```

show hw-module subslot status mac on Gigabit Ethernet SPA Example

The following shows sample output from the **show hw-module subslot** command for MAC device status on the first interface (port 0) on a 2-Port 10/100/1000 Gigabit Ethernet SPA:

```
Router# show hw-module subslot 4/1 status mac 0
Status registers:
  speed = 1000 Mbps, RGMII, duplex = full, interface mode = copper
  spi3 side loopback is disabled, line side loopback is disabled
  padding is disabled, crc add is disabled
  force duplex is enabled
Rx FIFO status:
  Read pointer = 0x0, Write pointer = 0x0
  Occupancy of FIFO in 8 byte locations = 0
  Reset is not set
  Overflow event did not occur
Tx FIFO status:
  Read pointer = 0x328, Write pointer = 0x328
  Occupancy of FIFO in 8 byte locations = 0
  Overflow event did not occur
  Underflow event did not occur
  Out of sequence event did not occur
```

show hw-module subslot status phy Example

The following shows sample output from the **show hw-module subslot** command for PHY device status on the first interface (port 0):

```

Router# show hw-module subslot 4/0 status phy 0
PHY Status:
status (reg 1) = 0x7949
  link is down, auto-negotiation is not complete
  remote fault not detected, jabber not detected
phy specific status (reg 17) = 0x4100
  link is down (real-time), speed/duplex not resolved
  speed: 100 Mbps, duplex: half
  page not received, cable length is 80 - 110m
  MDI cross-over status: MDI, downshift status: no
  energy detect status: active
  transmit pause: disabled, receive pause: disabled
  polarity: normal, jabber: no
phy specific extended status (reg 27) = 0x848B
  Fiber/ copper auto selection disabled, copper link
  Serial interface auto-negotiation bypass disabled
  Serial interface auto-negotiation bypass status:
    Link came up because regular fiber autoneg completed
  Interrupt polarity is active low
  receive error count: 0x0

```

show hw-module subslot status phy on Gigabit Ethernet SPA Example

The following shows sample output from the **show hw-module subslot** command for PHY device status on the first interface (port 0) on a 2-Port 10/100/1000 Gigabit Ethernet SPA:

```

Router# show hw-module subslot 4/1 status phy 0
PHY Status:
status (reg 1) = 0x149
  link is down, auto-negotiation is not complete
  remote fault not detected, jabber not detected
Extended status register (reg 15) = 0xC000
  1000BaseX full duplex capable    1000BaseX half duplex capable
  1000BaseT full duplex NOT capable  1000BaseT half duplex NOT capable
phy specific status (reg 17) = 0x8010
  link is down (real-time), speed/duplex not resolved
  speed: 1000 Mbps, duplex: half
  page not received, cable length is < 50m
  MDI cross-over status: MDI, downshift status: no
  energy detect status: sleep
  transmit pause: disabled, receive pause: disabled
  polarity: normal, jabber: no
phy specific extended status (reg 27) = 0xA483
  Fiber/ copper auto selection disabled, fiber link
  Serial interface auto-negotiation bypass disabled
  Serial interface auto-negotiation bypass status:
    Link came up because regular fiber autoneg completed
  Interrupt polarity is active low
  receive error count: 0x0

```

Related Commands

Command	Description
show controllers fastethernet	Displays Fast Ethernet interface information, transmission statistics and errors, and applicable MAC destination address and VLAN filtering tables.
show controllers gigabitethernet	Displays Gigabit Ethernet interface information, transmission statistics and errors, and applicable MAC destination address and VLAN filtering tables.

show hw-module subslot fpd

To display all current versions of FPD image files for all of the active SPAs on a router, enter the **show hw-module subslot fpd** command in privileged EXEC configuration mode.

show hw-module subslot [*slot/subslot*] **fpd**

Syntax Description	<i>slot</i>	(Optional) Chassis slot number. Refer to the appropriate hardware manual for slot information. For MSCs, refer to the platform-specific SPA hardware installation guide or the corresponding “Identifying Slots and Subslots for MSCs and SPAs” topic in the platform-specific SPA software configuration guide.
	<i>/subslot</i>	(Optional) Secondary slot number on a MSC where a SPA is installed. Refer to the platform-specific SPA hardware installation guide and the corresponding “Specifying the Interface Address on a SPA” topic in the platform-specific SPA software configuration guide for subslot information.

Defaults	No default behavior or values. If no location is specified, the output for this command will show information for all SPAs in the router.
-----------------	---

Command Modes	Privileged EXEC
----------------------	-----------------

Command History	Release	Modification
	12.2(20)S2	This command was introduced.

Usage Guidelines	Entering the show hw-module subslot fpd command will show the FPD image information for all of the SPAs on the router.
	Other than the FPD version information, the output for this command may also contain useful FPD-related notes.

Examples	The output display in this example shows that FPD image file versions on the SPAs in the system do not meet the minimum FPD requirements:
-----------------	---

Router# **show hw-module subslot fpd**

```

=====
Slot Card Description      H/W   Field Programmable   Current   Min. Required
Ver.   Device: "ID-Name"   Version   Version
=====
 2/0 SPA-2GE-7304          0.15   1-Data & I/O FPGA    4.12      4.17      *
-----
 2/1 SPA-4FE-7304          0.32   1-Data & I/O FPGA    4.13      4.17      *
=====

```

NOTES:

- FPD images that are required to be upgraded are indicated with a '*' character in the "Minimal Required Version" field.
- The following FPD image package file is required for the upgrade:
"spa-fpd.122-20.S2.pkg"

This example shows the output when using the *slot#/subslot#* argument to identify a particular SPA card and that slot meets the minimum FPD requirements for that SPA on that particular Cisco IOS Release:

Router# **show hw-module subslot 2/0 fpd**

```

=====
Slot Card Description      H/W   Field Programmable   Current   Min. Required
Ver.   Device: "ID-Name"   Version   Version
=====
 2/0 SPA-2GE-7304          0.15  1-Data & I/O FPGA    4.17      4.17
=====

```

The output display in this example shows that the SPA in slot 2/0 is disabled because one of the programmable devices on the card does not meet the minimum version requirements. The output also contains a "NOTES" section that provides the name of the FPD image package file needed to upgrade the FPD image for that particular SPA.

Router# **show hw-module subslot fpd**

```

=====
Slot Card Description      H/W   Field Programmable   Current   Min. Required
Ver.   Device: "ID-Name"   Version   Version
=====
 2/0 SPA-4FE-... <DISABLED> 0.32  1-Data & I/O FPGA    4.12      4.13   *
-----
 2/1 SPA-2GE-7304          0.15  1-Data & I/O FPGA    4.13      4.13
=====

```

NOTES:

- FPD images that are required to be upgraded are indicated with a '*' character in the "Minimal Required Version" field.
- The following FPD image package files is required for the upgrade:
"spa_fpd.122-20.S2.pkg"

Related Commands

Command	Description
upgrade hw-module subslot	Manually upgrades the current FPD image on the specified SPA.
upgrade fpd auto	Configures the router to automatically upgrade the FPD image when an FPD version incompatibility is detected.
upgrade fpd path	Specifies the location from where the FPD image package should be loaded when an automatic FPD upgrade is initiated by the router.
show upgrade fpd file	Displays the contents of an FPD image package file.
show upgrade fpd package default	Displays which FPD image package is needed for the router to properly support the SPAs.
show upgrade fpd progress	Displays the progress of the FPD upgrade while an FPD upgrade is taking place.
show upgrade fpd table	Displays various information used by the Cisco IOS software to manage the FPD image package file.

show hw-module subslot oir

To display the operational status of a shared port adapter (SPA), use the **show hw-module subslot oir** command in privileged EXEC configuration mode. The command does not have a **no** form.

show hw-module subslot [*slot/subslot*] **oir** [**internal**]

Syntax Description	<i>slot</i>	(Optional) Chassis slot number. Refer to the appropriate hardware manual for slot information. For MSCs, refer to the platform-specific SPA hardware installation guide or the corresponding “Identifying Slots and Subslots for MSCs and SPAs” topic in the platform-specific SPA software configuration guide.
	<i>/subslot</i>	(Optional) Secondary slot number on a MSC where a SPA is installed. Refer to the platform-specific SPA hardware installation guide and the corresponding “Specifying the Interface Address on a SPA” topic in the platform-specific SPA software configuration guide for subslot information.
	internal	(Optional) Displays detailed diagnostic information. This option is intended for internal diagnostic use with Cisco Systems technical support personnel.

Defaults	No default behavior or values. If no location is specified, the output for this command will show information for all SPAs in the router.
----------	---

Command Modes	Privileged EXEC
---------------	-----------------

Command History	Release	Modification
	12.2(25)S3	This command was introduced.

Usage Guidelines	Use the show hw-module subslot oir command to obtain operational status information about one or more SPAs. To display information for a specific SPA, specify the <i>slot</i> number of the SIP and the <i>subslot</i> number of the SPA that you want information about. To display information for all SPAs in the router, do not specify the <i>slot/subslot</i> arguments.
------------------	--

The optional **internal** keyword displays detailed diagnostic information that is recommended only for use with Cisco technical support personnel.



Note	The following status descriptions are not applicable to every SPA and can be platform-specific.
------	---

[Table 8-28](#) describes the possible values for the Operational Status field in the output.

Table 8-28 **Operational Status Field Descriptions**

Operational Status	Description
admin down	SPA is administratively disabled by the hw-module subslot shutdown global configuration command.
booting	SPA is initializing.
missing	SPA is not present in the MSC subslot.
ok	SPA is operational.
out of service (<i>reason</i>)	<p>The SPA is out of service for one of the following reasons:</p> <p>Note The following reasons are not applicable to every SPA and can be platform-specific.</p> <ul style="list-style-type: none"> Analyze failed—Failed to create a SPA data structure, most likely due to a memory allocation problem. Authentication failed—SPA has failed hardware validation. Data structure create error—Failed to create a SPA data structure, most likely due to a memory allocation problem. Event corrupt—A SPA online insertion and removal (OIR) event has been corrupted. This could be caused by a corrupted message between the MSC and the route processor (RP) or some other software or hardware problem. Event sequence error—A SPA OIR event was received out of sequence. This could be caused by a corrupted message between the MSC and the route processor (RP) or some other software or hardware problem. Fail code not set—Failure code could not be read from a SPA OIR event message. This could be caused by a corrupted message between the MSC and the RP or some other software or hardware problem. Failed too many times—SPA is disabled because it has failed more than the allowable limit on the platform. FPD upgrade failed—A field-programmable device, such as the Field-Programmable Gate Array (FPGA), failed to automatically upgrade. H/W signal deasserted—The SPA_OK or PWR_OK hardware signal indicating that the SPA is accessible are no longer asserted. Heartbeat failed—Occurs when intelligent SPAs encounter heartbeat failures. Incompatible FPD—An FPGA version mismatch with the Cisco IOS software has been detected for the SPA.

Table 8-28 **Operational Status Field Descriptions**

Operational Status	Description
out of service (reason)—CONTINUED	<ul style="list-style-type: none"> Init timeout—Time limit has been reached during initialization of a SPA. Read SPA type failed—A read from the hardware for the SPA type failed. Reload request—SPA reload is in progress from the hw-module subslot reload command. SPA h/w error—The SPA software driver has detected a hardware error. SPA ready timeout—A timeout occurred on the RP while waiting for the SPA to become operational. SPA type mismatch—Occurs when you have pre-configured a SPA of one type, but have inserted a SPA of a different type. <p>Note This reason code only applies to those platforms that support pre-configuration. This is not applicable to a Cisco 7304 router.</p> <ul style="list-style-type: none"> SPA unrecognized—SPA is not supported by the Cisco IOS software release. Start failed—Failed to start interfaces on SPA. Unexpected inserted event—The SPA OIR software has received a SPA insertion event when the OIR software considered the SPA already present. Wait h/w ok timeout—A timeout occurred while waiting for the SPA_OK and PWR_OK hardware signals to be asserted. Wait start timeout—A timeout occurred on the MSC while waiting for permission from the RP to bring up the SPA.
stopped	SPA has been gracefully deactivated using the hw-module subslot stop privileged EXEC command on the Cisco 7304 router.

Examples

The following example shows the operational status of all of the SPAs installed in the router:

```
Router# show hw-module subslot oir
Module           Model           Operational Status
-----
subslot 4/0      SPA-4XOC3-POS    booting
subslot 4/1      SPA-4XOC3-ATM    out of service(FPD upgrade failed)
subslot 4/2      SPA-4XOC3-POS    ok
subslot 4/3      SPA-1XTENGE-XFP  out of service(SPA unrecognized)
```

The following example shows sample output when using the optional **internal** keyword:

```
Router# show hw-module subslot 4/0 oir internal
WARNING: This command is not intended for production use
and should only be used under the supervision of
Cisco Systems technical support personnel.
```

```

sm(spa_oir_tsm subslot 4/0 TSM), running yes, state ready
Admin Status: admin enabled, Operational Status: ok(1)
Last reset Reason: manual
TSM Context:
  configured_spa_type 0x483
  soft remove fail code 0x0(none)
  last_fail_code 0x110E(SPA unrecognized)
  fail_count 0
  timed_fail_count 0, failed_spa_type 0x483
  recovery_action 6
  associated_fail_code 0x110E(SPA unrecognized)
  sequence numbers: next from tsm 4, last to tsm 2
  flags 0x0
Subslot:
  spa type 0x483, active spa type 0x483
  subslot flags 0x0, plugin flags 0x0
TSM Parameters:
  wait_psm_ready_timeout 360000 ms, init_timeout 240000 ms
  short_recovery_delay 5000 ms, long_recovery_delay 120000 ms
  ok_up_time 1200000 ms, bad_fail_count 10
  fail_time_period 600000 ms, max_fail_count 5
  does not support pre-configuration
SPA OIR state machine audit statistics
      In-sync poll-count  gry-fail resp-fail  restarts fail-count
subslot 4/0              yes      1          0          0          0

```

Related Commands

Command	Description
hw-module subslot reload	Restarts a SPA and its interfaces.
hw-module subslot shutdown	Shuts down a SPA with or without power.

show interface sdcc

To display configuration information and statistics for a sections data communications channel (SDCC) interface, use the **show interface sdcc** command in privileged EXEC mode. The command does not have a **no** form.

show interface sdcc *slot/subslot/port[/sub_int]*

Syntax Description		
<i>slot</i>	Chassis slot number.	Refer to the appropriate hardware manual for slot information. For MSCs, refer to the platform-specific SPA hardware installation guide or the corresponding “Identifying Slots and Subslots for MSCs and SPAs” topic in the platform-specific SPA software configuration guide.
<i>/subslot</i>	Secondary slot number on a MSC where a SPA is installed.	Refer to the platform-specific SPA hardware installation guide and the corresponding “Specifying the Interface Address on a SPA” topic in the platform-specific SPA software configuration guide for subslot information.
<i>/port</i>	(Optional) Port or interface number.	Refer to the appropriate hardware manual for port information. For SPAs, refer to the corresponding “Specifying the Interface Address on a SPA” topics in the platform-specific SPA software configuration guide.
<i>/sub_int</i>	(Optional) Subinterface number.	

Defaults No default behavior or values

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(11)BC3	This command was introduced.
	12.2(25)S3	This command was integrated into Cisco IOS release 12.2(25)S3 to support POS SPAs on the Cisco 7304 router.

Examples The following command displays configuration information and statistics for SDCC interface 4/0/0:

```
Router# show interface sdcc 4/0/0
SDCC4/0/0 is up, line protocol is up
  Hardware is SDCC
  Internet address is 10.10.10.1/24
  MTU 1500 bytes, BW 192 Kbit, DLY 20000 usec,
    reliability 255/255, txload 1/255, rxload 1/255
  Encapsulation HDLC, crc 16, loopback not set
  Keepalive set (10 sec)
  Last input never, output 00:00:07, output hang never
  Last clearing of "show interface" counters 00:01:52
```

```
Input queue: 0/75/0/0 (size/max/drops/flushes); Total output drops: 0
Queueing strategy: fifo
Output queue: 0/40 (size/max)
5 minute input rate 0 bits/sec, 0 packets/sec
5 minute output rate 0 bits/sec, 0 packets/sec
  5 packets input, 520 bytes, 0 no buffer
  Received 0 broadcasts (0 IP multicast)
  0 runts, 0 giants, 0 throttles
  0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
  5 packets output, 520 bytes, 0 underruns
  0 output errors, 0 collisions, 1 interface resets
  0 output buffer failures, 0 output buffers swapped out
  0 carrier transitions
```

show interfaces fastethernet

To display information about the Fast Ethernet interfaces, use the **show interfaces fastethernet** command in privileged EXEC configuration mode.

show interfaces fastethernet *slot/subslot/port*

Syntax Description	<i>slot</i>	Chassis slot number. Refer to the appropriate hardware manual for slot information. For MSCs, refer to the platform-specific SPA hardware installation guide or the corresponding “Identifying Slots and Subslots for MSCs and SPAs” topic in the platform-specific SPA software configuration guide.
	<i>/subslot</i>	Secondary slot number on a MSC where a SPA is installed. Refer to the platform-specific SPA hardware installation guide and the corresponding “Specifying the Interface Address on a SPA” topic in the platform-specific SPA software configuration guide for subslot information.
	<i>/port</i>	(Optional) Port or interface number. Refer to the appropriate hardware manual for port information. For SPAs, refer to the corresponding “Specifying the Interface Address on a SPA” topics in the platform-specific SPA software configuration guide.

Defaults No default behavior or values

Command Modes Privileged EXEC

Command History	Release	Modification
	11.2	This command was introduced.
	12.2 S	This command was integrated into Cisco IOS Release 12.2 S.
	12.2(20)S2	This command was implemented on the 4-Port 10/100 Fast Ethernet SPA on the Cisco 7304 router.

Examples The following is sample output from the **show interfaces fastethernet** command for the second interface (port 1) in a 4-Port 10/100 Fast Ethernet SPA located in the bottom subslot (1) of the MSC that is installed in slot 2 on a Cisco 7304 router:

```
Router# show interfaces fastethernet 2/1/1
FastEthernet2/1/1 is up, line protocol is up
  Hardware is SPA-4FE-7304, address is 00b0.64ff.5d80 (bia 00b0.64ff.5d80)
  Internet address is 192.168.50.1/24
  MTU 9216 bytes, BW 100000 Kbit, DLY 100 usec,
    reliability 255/255, txload 1/255, rxload 1/255
  Encapsulation ARPA, loopback not set
  Keepalive set (10 sec)
  Full-duplex, 100Mb/s, 100BaseTX/FX
```

```

ARP type: ARPA, ARP Timeout 04:00:00
Last input 00:00:22, output 00:00:02, output hang never
Last clearing of "show interface" counters never
Input queue: 0/75/0/0 (size/max/drops/flushes); Total output drops: 0
Queueing strategy: fifo
Output queue: 0/40 (size/max)
5 minute input rate 0 bits/sec, 0 packets/sec
5 minute output rate 0 bits/sec, 0 packets/sec
  5 packets input, 320 bytes
    Received 1 broadcasts (0 IP multicast)
    0 runs, 0 giants, 0 throttles
    0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored
    0 watchdog
    0 input packets with dribble condition detected
  8 packets output, 529 bytes, 0 underruns
    0 output errors, 0 collisions, 2 interface resets
    0 babbles, 0 late collision, 0 deferred
    2 lost carrier, 0 no carrier
    0 output buffer failures, 0 output buffers swapped out

```

**Note**

There are variations in the output for the **show interfaces** commands on Cisco Systems routers depending on the platform, type of interface, and also other features that you might have configured, such as Quality of Service (QoS). Therefore, some additional output fields might appear in your **show** command output. For more information about these fields, see the **show interfaces** command description in the *Cisco IOS Interface Command Reference*, Release 12.2.

Table 8-29 describes the fields shown in the display.

Table 8-29 *show interfaces fastethernet Field Descriptions—Fast Ethernet SPA*

Field	Description
Fast Ethernet...is up ...is administratively down	Indicates whether the interface hardware is currently active and if it has been taken down by an administrator.
line protocol is	Indicates whether the software processes that handle the line protocol consider the line usable or if it has been taken down by an administrator.
Hardware	Hardware type (for example, SPA-4FE-7304) and MAC address.
Description	Alphanumeric string identifying the interface. This only appears if the description interface configuration command has been configured on the interface.
Internet address	Internet address followed by subnet mask.
MTU	Maximum transmission unit of the interface. The default is 1500 bytes for the 4-Port 10/100 Fast Ethernet SPA.
BW	Bandwidth of the interface in kilobits per second.
DLY	Delay of the interface in microseconds.
reliability	Reliability of the interface as a fraction of 255 (255/255 is 100 percent reliability), calculated as an exponential average over 5 minutes.
txload, rxload	Load on the interface (in the transmit “tx” and receive “rx” directions) as a fraction of 255 (255/255 is completely saturated), calculated as an exponential average over 5 minutes.

Table 8-29 *show interfaces fastethernet Field Descriptions—Fast Ethernet SPA (continued)*

Field	Description
Encapsulation	Encapsulation method assigned to the interface.
loopback	Indicates whether or not loopback is set.
Keepalive	Indicates whether or not keepalives are set, and the time interval.
Half-duplex, Full-duplex	Indicates the duplex mode for the interface.
100Mb/s, 10Mb/s	Speed of the interface in megabits per second.
100BaseTX/FX	Media protocol standard.
ARP type:	Type of Address Resolution Protocol (ARP) assigned and the timeout period.
Last input	Number of hours, minutes, and seconds since the last packet was successfully received by an interface and processed locally on the router. Useful for knowing when a dead interface failed. This field is not updated by fast-switched traffic.
output	Number of hours, minutes, and seconds since the last packet was successfully transmitted by the interface. Useful for knowing when a dead interface failed.
output hang	Number of hours, minutes, and seconds (or never) since the interface was last reset because of a transmission that took too long. When the number of hours in any of the “last” fields exceeds 24 hours, the number of days and hours is displayed. If that field overflows, asterisks are printed. Note This field does not apply to SPA interfaces.
Last clearing	Time at which the counters that measure cumulative statistics (such as number of bytes transmitted and received) shown in this report were last reset to zero. Note that variables that might affect routing (for example, load and reliability) are not cleared when the counters are cleared. A series of asterisks (***) indicates the elapsed time is too large to be displayed. 0:00:00 indicates the counters were cleared more than 2^{31} ms (and less than 2^{32} ms) ago.
Input queue (size/max/drops/flushes)	Packet statistics on the input queue reported as: <ul style="list-style-type: none"> • Size—Number of packets in the input queue. • Max—Maximum size of the queue. • Drops—Number of packets dropped because of a full input queue. • Flushes—Number of packets dropped as part of selective packet discard (SPD). SPD implements a selective packet drop policy on the router’s IP process queue. Therefore, it only applies to process-switched traffic.
Total output drops	Total number of packets dropped because of a full output queue.
Queueing strategy	Type of Layer 3 queueing active on this interface. The default is first-in, first-out (FIFO).

Table 8-29 *show interfaces fastethernet Field Descriptions—Fast Ethernet SPA (continued)*

Field	Description
Output queue (size/max)	Number of packets in the output queue (size), and the maximum size of the queue (max).
5 minute input rate, 5 minute output rate	<p>Average number of bits and packets transmitted per second in the last 5 minutes. If the interface is not in promiscuous mode, it senses network traffic it sends and receives (rather than all network traffic).</p> <p>The 5-minute input and output rates should be used only as an approximation of traffic per second during a given 5-minute period. These rates are exponentially weighted averages with a time constant of 5 minutes. A period of four time constants must pass before the average will be within two percent of the instantaneous rate of a uniform stream of traffic over that period.</p>
packets input	Total number of error-free packets received by the system.
bytes	Total number of bytes, including data and MAC encapsulation, in the error-free packets received by the system.
Received...broadcasts	Total number of broadcast or multicast packets received by the interface.
runts	Number of packets that are discarded because they are smaller than the minimum packet size of the medium. For instance, any Ethernet packet that is smaller than 64 bytes is considered a runt.
giants	<p>Number of packets that are discarded because they exceed the maximum packet size of the medium. For example, any Ethernet packet that is larger than 1536 bytes is considered a giant.</p> <p>Note For the 4-Port 10/100 Fast Ethernet SPA, the default is that a giant is any packet greater than 1536 bytes. However, if you modify the maximum transmission unit (MTU) for the interface, this counter increments when you exceed the specified MTU for the interface.</p>
throttles	Number of times the receiver on the port was disabled, possibly because of buffer or processor overload.
input errors	Includes runts, giants, no buffer, CRC, frame, overrun, and ignored counts. Other input-related errors can also cause the input errors count to be increased, and some datagrams may have more than one error; therefore, this sum may not balance with the sum of enumerated input error counts.
CRC	Cyclic redundancy check generated by the originating LAN station or far-end device does not match the checksum calculated from the data received. On a LAN, this usually indicates noise or transmission problems on the LAN interface or the LAN bus itself. A high number of CRCs is usually the result of collisions or a station transmitting bad data.
frame	Number of packets received incorrectly having a CRC error and a noninteger number of octets. On a LAN, this is usually the result of collisions or a malfunctioning Ethernet device.

Table 8-29 *show interfaces fastethernet Field Descriptions—Fast Ethernet SPA (continued)*

Field	Description
overrun	Number of times the receiver hardware was unable to hand received data to a hardware buffer because the input rate exceeded the receiver's ability to handle the data.
ignored	Number of received packets ignored by the interface because the interface hardware ran low on internal buffers. These buffers are different than the system buffers. Broadcast storms and bursts of noise can cause the ignored count to be increased.
watchdog	Number of times the watchdog receive timer expired. Expiration happens when receiving a packet with a length greater than 2048 bytes.
input packets with dribble condition detected	Dribble bit error indicates that a frame is slightly too long. This frame error counter is incremented for informational purposes only; the router accepts the frame.
packets output	Total number of messages transmitted by the system.
bytes	Total number of bytes, including data and MAC encapsulation, transmitted by the system.
underruns	Number of times that the transmitter has been running faster than the router can handle.
output errors	Sum of all errors that prevented the final transmission of datagrams out of the interface being examined. Note that this may not balance with the sum of the enumerated output errors, as some datagrams may have more than one error and others may have errors that do not fall into any of the specifically tabulated categories.
collisions	Number of messages retransmitted because of an Ethernet collision. This is usually the result of an overextended LAN (Ethernet or transceiver cable too long, more than two repeaters between stations, or too many cascaded multiport transceivers). A packet that collides is counted only once in output packets.
interface resets	Number of times an interface has been completely reset. This can happen if packets queued for transmission were not sent within several seconds. Interface resets can occur when an interface is looped back or shut down.
babbles	Transmit jabber timer expired.
late collision	Number of late collisions. Late collision happens when a collision occurs after transmitting the preamble.
deferred	Number of times that the interface had to defer while ready to transmit a frame because the carrier was asserted.
lost carrier	Number of times the carrier was lost during transmission.
no carrier	Number of times the carrier was not present during the transmission. Note This field does not apply to SPA interfaces.
output buffer failures, output buffers swapped out	These counters are not used by the 4-Port 10/100 Fast Ethernet SPA on the Cisco 7304 router.

Related Commands

Command	Description
show interfaces ¹	Displays statistics for the interfaces configured on a router or access server.
show controllers fastethernet	Displays Fast Ethernet interface information, transmission statistics and errors, and applicable MAC destination address and VLAN filtering tables.

1. Refer to the Cisco IOS Release 12.2 command reference and master index publications.

show interfaces gigabitethernet

To display information about the Gigabit Ethernet interfaces, use the **show interfaces gigabitethernet** command in privileged EXEC configuration mode.

show interfaces gigabitethernet *slot/subslot/port*

Syntax Description	<i>slot</i>	Chassis slot number. Refer to the appropriate hardware manual for slot information. For MSCs, refer to the platform-specific SPA hardware installation guide or the corresponding “Identifying Slots and Subslots for MSCs and SPAs” topic in the platform-specific SPA software configuration guide.
	<i>/subslot</i>	Secondary slot number on a MSC where a SPA is installed. Refer to the platform-specific SPA hardware installation guide and the corresponding “Specifying the Interface Address on a SPA” topic in the platform-specific SPA software configuration guide for subslot information.
	<i>/port</i>	(Optional) Port or interface number. Refer to the appropriate hardware manual for port information. For SPAs, refer to the corresponding “Specifying the Interface Address on a SPA” topics in the platform-specific SPA software configuration guide.

Defaults No default behavior or values

Command Modes Privileged EXEC

Command History	Release	Modification
	11.1 CC	This command was introduced.
	12.1(3a)E	Support for the Cisco 7200-I/O-GE+E controller was introduced.
	12.1(5)T	This command was integrated into Cisco IOS Release 12.1(5)T.
	12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.
	12.2(20)S2	This command was integrated into Cisco IOS Release 12.2(20)S2 and introduced a new address format and output for interfaces on the 2-Port 10/100/1000 Gigabit Ethernet SPA on the Cisco 7304 router.

Examples The following is sample output from the **show interfaces gigabitethernet** command for the first interface (port 0) in a 2-Port 10/100/1000 Gigabit Ethernet SPA located in the top subslot (0) of the MSC that is installed in slot 4 on a Cisco 7304 router:

```
Router# show interfaces gigabitethernet 4/0/0
GigabitEthernet4/0/0 is up, line protocol is down
  Hardware is SPA-2GE-7304, address is 00b0.64ff.5a80 (bia 00b0.64ff.5a80)
  MTU 1500 bytes, BW 1000000 Kbit, DLY 10 usec,
    reliability 255/255, txload 1/255, rxload 1/255
```

```

Encapsulation ARPA, loopback not set
Keepalive set (10 sec)
Half-duplex, 1000Mb/s, link type is auto, media type is RJ45
output flow-control is unsupported, input flow-control is unsupported
ARP type: ARPA, ARP Timeout 04:00:00
Last input never, output 00:00:09, output hang never
Last clearing of "show interface" counters never
Input queue: 0/75/0/0 (size/max/drops/flushes); Total output drops: 0
Queueing strategy: fifo
Output queue: 0/40 (size/max)
5 minute input rate 0 bits/sec, 0 packets/sec
5 minute output rate 0 bits/sec, 0 packets/sec
  0 packets input, 0 bytes, 0 no buffer
  Received 0 broadcasts (0 IP multicast)
  0 runs, 0 giants, 0 throttles
  0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored
  0 watchdog, 0 multicast, 0 pause input
  109 packets output, 6540 bytes, 0 underruns
  0 output errors, 0 collisions, 2 interface resets
  0 babbles, 0 late collision, 0 deferred
  1 lost carrier, 0 no carrier, 0 PAUSE output
  0 output buffer failures, 0 output buffers swapped out

```

**Note**

There are variations in the output for the **show interfaces** commands on Cisco Systems routers depending on the platform, type of interface, and also other features that you might have configured, such as Quality of Service (QoS). Therefore, some additional output fields might appear in your **show** command output. For more information about these fields, see the **show interfaces** command description in the *Cisco IOS Interface Command Reference*, Release 12.2.

Table 8-30 describes the fields shown in the display.

Table 8-30 *show interfaces gigabitethernet Field Descriptions—Gigabit Ethernet SPA*

Field	Description
GigabitEthernet...is up ...is administratively down	Indicates whether the interface hardware is currently active and if it has been taken down by an administrator.
line protocol is	Indicates whether the software processes that handle the line protocol consider the line usable or if it has been taken down by an administrator.
Hardware	Hardware type (for example, SPA-2GE-7304) and MAC address.
Description	Alphanumeric string identifying the interface. This only appears if the description interface configuration command has been configured on the interface.
Internet address	Internet address followed by subnet mask.
MTU	Maximum transmission unit of the interface. The default is 1500 bytes for the 2-Port 10/100/1000 Gigabit Ethernet SPA.
BW	Bandwidth of the interface in kilobits per second.
DLY	Delay of the interface in microseconds.
reliability	Reliability of the interface as a fraction of 255 (255/255 is 100 percent reliability), calculated as an exponential average over 5 minutes.

Table 8-30 *show interfaces gigabitethernet Field Descriptions—Gigabit Ethernet SPA (continued)*

Field	Description
txload, rxload	Load on the interface (in the transmit “tx” and receive “rx” directions) as a fraction of 255 (255/255 is completely saturated), calculated as an exponential average over 5 minutes.
Encapsulation	Encapsulation method assigned to the interface.
loopback	Indicates whether or not loopback is set.
Keepalive	Indicates whether or not keepalives are set, and the time interval.
Half-duplex, Full-duplex	Indicates the duplex mode for the interface.
1000Mb/s, 100Mb/s, 10Mb/s	Speed of the interface in megabits per second.
link type	Specifies whether or not autonegotiation is being used on the link.
media type	Interface port media type: RJ45, SX, LX, or ZX.
100BaseTX/FX	Media protocol standard.
ARP type:	Type of Address Resolution Protocol (ARP) assigned and the timeout period.
Last input	Number of hours, minutes, and seconds since the last packet was successfully received by an interface and processed locally on the router. Useful for knowing when a dead interface failed. This field is not updated by fast-switched traffic.
output	Number of hours, minutes, and seconds since the last packet was successfully transmitted by the interface. Useful for knowing when a dead interface failed.
output hang	Number of hours, minutes, and seconds (or never) since the interface was last reset because of a transmission that took too long. When the number of hours in any of the “last” fields exceeds 24 hours, the number of days and hours is displayed. If that field overflows, asterisks are printed. Note This field does not apply to SPA interfaces.
Last clearing	Time at which the counters that measure cumulative statistics (such as number of bytes transmitted and received) shown in this report were last reset to zero. Note that variables that might affect routing (for example, load and reliability) are not cleared when the counters are cleared. A series of asterisks (***) indicates the elapsed time is too large to be displayed. 0:00:00 indicates the counters were cleared more than 2 ³¹ ms (and less than 2 ³² ms) ago.

Table 8-30 *show interfaces gigabitethernet Field Descriptions—Gigabit Ethernet SPA (continued)*

Field	Description
Input queue (size/max/drops/flushes)	Packet statistics on the input queue reported as: <ul style="list-style-type: none"> Size—Number of packets in the input queue. Max—Maximum size of the queue. Drops—Number of packets dropped because of a full input queue. Flushes—Number of packets dropped as part of selective packet discard (SPD). SPD implements a selective packet drop policy on the router's IP process queue. Therefore, it only applies to process-switched traffic.
Total output drops	Total number of packets dropped because of a full output queue.
Queueing strategy	Type of Layer 3 queueing active on this interface. The default is first-in, first-out (FIFO).
Output queue (size/max)	Number of packets in the output queue (size), and the maximum size of the queue (max).
5 minute input rate, 5 minute output rate	Average number of bits and packets transmitted per second in the last 5 minutes. If the interface is not in promiscuous mode, it senses network traffic it sends and receives (rather than all network traffic). The 5-minute input and output rates should be used only as an approximation of traffic per second during a given 5-minute period. These rates are exponentially weighted averages with a time constant of 5 minutes. A period of four time constants must pass before the average will be within two percent of the instantaneous rate of a uniform stream of traffic over that period.
packets input	Total number of error-free packets received by the system.
bytes	Total number of bytes, including data and MAC encapsulation, in the error-free packets received by the system.
Received...broadcasts	Total number of broadcast or multicast packets received by the interface.
runts	Number of packets that are discarded because they are smaller than the minimum packet size of the medium. For instance, any Ethernet packet that is smaller than 64 bytes is considered a runt.
giants	Number of packets that are discarded because they exceed the maximum packet size of the medium. For example, any Ethernet packet that is larger than 1536 bytes is considered a giant. Note For the 2-Port 10/100/1000 Gigabit Ethernet SPA, the default is that a giant is any packet greater than 1536 bytes. However, if you modify the maximum transmission unit (MTU) for the interface, this counter increments when you exceed the specified MTU for the interface.
throttles	Number of times the receiver on the port was disabled, possibly because of buffer or processor overload.

Table 8-30 *show interfaces gigabitethernet Field Descriptions—Gigabit Ethernet SPA (continued)*

Field	Description
input errors	Includes runs, giants, no buffer, CRC, frame, overrun, and ignored counts. Other input-related errors can also cause the input errors count to be increased, and some datagrams may have more than one error; therefore, this sum may not balance with the sum of enumerated input error counts.
CRC	Cyclic redundancy check generated by the originating LAN station or far-end device does not match the checksum calculated from the data received. On a LAN, this usually indicates noise or transmission problems on the LAN interface or the LAN bus itself. A high number of CRCs is usually the result of collisions or a station transmitting bad data.
frame	Number of packets received incorrectly having a CRC error and a noninteger number of octets. On a LAN, this is usually the result of collisions or a malfunctioning Ethernet device.
overrun	Number of times the receiver hardware was unable to hand received data to a hardware buffer because the input rate exceeded the receiver's ability to handle the data.
ignored	Number of received packets ignored by the interface because the interface hardware ran low on internal buffers. These buffers are different than the system buffers. Broadcast storms and bursts of noise can cause the ignored count to be increased.
watchdog	Number of times the watchdog receive timer expired. Expiration happens when receiving a packet with a length greater than 2048 bytes.
input packets with dribble condition detected	Dribble bit error indicates that a frame is slightly too long. This frame error counter is incremented for informational purposes only; the router accepts the frame.
packets output	Total number of messages transmitted by the system.
bytes	Total number of bytes, including data and MAC encapsulation, transmitted by the system.
underruns	Number of times that the transmitter has been running faster than the router can handle.
output errors	Sum of all errors that prevented the final transmission of datagrams out of the interface being examined. Note that this may not balance with the sum of the enumerated output errors, as some datagrams may have more than one error and others may have errors that do not fall into any of the specifically tabulated categories.
collisions	Number of messages retransmitted because of an Ethernet collision. This is usually the result of an overextended LAN (Ethernet or transceiver cable too long, more than two repeaters between stations, or too many cascaded multiport transceivers). A packet that collides is counted only once in output packets.
interface resets	Number of times an interface has been completely reset. This can happen if packets queued for transmission were not sent within several seconds. Interface resets can occur when an interface is looped back or shut down.

Table 8-30 *show interfaces gigabitethernet Field Descriptions—Gigabit Ethernet SPA (continued)*

Field	Description
babbles	Transmit jabber timer expired.
late collision	Number of late collisions. Late collision happens when a collision occurs after transmitting the preamble.
deferred	Number of times that the interface had to defer while ready to transmit a frame because the carrier was asserted.
lost carrier	Number of times the carrier was lost during transmission.
no carrier	Number of times the carrier was not present during the transmission. Note This field does not apply to SPA interfaces.
output buffer failures, output buffers swapped out	These counters are not used by the 2-Port 10/100/1000 Gigabit Ethernet SPA on the Cisco 7304 router.

Related Commands

Command	Description
show interfaces ¹	Displays statistics for the interfaces configured on a router or access server.
show controllers gigabitethernet	Displays Gigabit Ethernet interface information, transmission statistics and errors, and applicable MAC destination address and VLAN filtering tables.

1. Refer to the Cisco IOS Release 12.2 command reference and master index publications.

show interfaces pos

To display configuration information and statistics for a Packet over SONET (POS) interface, use the **show interfaces pos** command in user EXEC or privileged EXEC mode.

Cisco 7000 and Cisco 7500 Series with VIPs

```
show interfaces pos [slot/port-adapter/port]
```

POS Shared Port Adapters

```
show interfaces pos [slot/subslot/port[/sub_int]]
```

Syntax Description		
<i>slot</i>	Chassis slot number.	
	Refer to the appropriate hardware manual for slot information. For MSCs, refer to the platform-specific SPA hardware installation guide or the corresponding “Identifying Slots and Subslots for MSCs and SPAs” topic in the platform-specific SPA software configuration guide.	
<i>/port-adapter</i>	(Optional) Port adapter number. Refer to the appropriate hardware manual for information about port adapter compatibility.	
<i>/subslot</i>	Secondary slot number on a MSC where a SPA is installed.	
	Refer to the platform-specific SPA hardware installation guide and the corresponding “Specifying the Interface Address on a SPA” topic in the platform-specific SPA software configuration guide for subslot information.	
<i>/port</i>	(Optional) Port or interface number.	
	Refer to the appropriate hardware manual for port information. For SPAs, refer to the corresponding “Specifying the Interface Address on a SPA” topics in the platform-specific SPA software configuration guide.	
<i>/sub_int</i>	(Optional) Subinterface number.	

Command Modes	User EXEC Privileged EXEC
---------------	------------------------------

Command History	Release	Modification
	11.2	The show interface posi command was introduced.
	11.3	The name of the command was modified from show interface posi to show interfaces pos , and the sample output was updated.
	12.2S	This command was integrated into Cisco IOS release 12.2S.
	12.2(18)SXE	This command was integrated into Cisco IOS Release 12.2(18)SXE to support SPAs on the Cisco 7304 router. The command was modified to support a new addressing format for SPAs.

Examples

Cisco 7513 Example

The following is sample output from the **show interfaces pos** command on a Cisco 7513 router with one Packet OC-3 Interface Processor (POSIP):

```
Router# show interfaces pos 2/0/0

POS2/0/0 is up, line protocol is up
  Hardware is cyBus Packet over Sonet
  Description: PRI-T1 net to zippy (4K) to Pac-Bell
  Internet address is 10.1.1.1/27
  MTU 4470 bytes, BW 1000 Kbit, DLY 40000 usec, rely 255/255, load 1/255
  Encapsulation HDLC, loopback not set, keepalive set (3 sec)
  Last input 00:00:00, output 00:00:00, output hang never
  Last clearing of "show interface" counters 00:23:09
  Queueing strategy: fifo
  Output queue 0/40, 0 drops; input queue 0/75, 0 drops
  5 minute input rate 0 bits/sec, 1 packets/sec
  5 minute output rate 1000 bits/sec, 1 packets/sec
    1046 packets input, 54437 bytes, 0 no buffer
    Received 485 broadcasts, 0 runts, 0 giants, 0 parity
    0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
    4013 packets output, 1357412 bytes, 0 underruns
    0 output errors, 0 applique, 0 interface resets
    0 output buffer failures, 0 output buffers swapped out
    0 carrier transitions
```

POS Shared Port Adapter Example

The following is sample output from the **show interfaces pos** command on a Cisco 7304 router for POS interface 2/1/1 (which is the interface for port 1 of the SPA in subslot 1 of the MSC in chassis slot 2):

```
Router# show interfaces pos 2/1/1

POS3/0/0 is up, line protocol is up
  Hardware is Packet over Sonet
  MTU 4470 bytes, BW 622000 Kbit, DLY 100 usec,
    reliability 194/255, txload 1/255, rxload 1/255
  Encapsulation FRAME-RELAY, crc 16, loopback not set
  Keepalive set (10 sec)
  Scramble disabled
  LMI enq sent 18, LMI stat recvd 0, LMI upd recvd 0
  LMI enq recvd 1473, LMI stat sent 1473, LMI upd sent 0, DCE LMI up
  LMI DLCI 1023 LMI type is CISCO frame relay DCE
  FR SVC disabled, LAPF state down
  Broadcast queue 0/256, broadcasts sent/dropped 2223/1, interface
  broadcasts 1977
  Last input 00:00:05, output 00:00:05, output hang never
  Last clearing of "show interface" counters 04:46:02
  Input queue: 0/75/0/0 (size/max/drops/flushes); Total output drops: 0
  Queueing strategy: fifo
  Output queue: 0/40 (size/max)
  5 minute input rate 0 bits/sec, 0 packets/sec
  5 minute output rate 0 bits/sec, 0 packets/sec
    47019 packets input, 163195100 bytes, 0 no buffer
    Received 0 broadcasts (0 IP multicast)
    14332 runts, 925 giants, 0 throttles
    0 parity
    17820 input errors, 1268 CRC, 0 frame, 0 overrun, 0 ignored, 10
  abort
    49252 packets output, 170900767 bytes, 0 underruns
    0 output errors, 0 applique, 2 interface resets
    0 output buffer failures, 0 output buffers swapped out
    3 carrier transitions.
```

Table 8-31 describes the significant fields shown in these displays.

Table 8-31 *show interfaces pos Field Descriptions*

Field	Description
POSx/y/z is up, line protocol is up	Indicates whether the interface hardware is currently active and can transmit and receive or whether it has been taken down by an administrator.
Hardware is. . .	Hardware type: <ul style="list-style-type: none"> • For POSIP— cyBus Packet over Sonet • For POS SPAs—Packet over SONET
Internet address is	Internet address and subnet mask.
MTU	Maximum transmission unit of the interface.
BW	Bandwidth of the interface, in kilobits per second.
DLY	Delay of the interface, in microseconds.
Rely	Reliability of the interface as a fraction of 255 (255/255 is 100 percent reliability), calculated as an exponential average over 5 minutes.
Load	Load on the interface as a fraction of 255 (255/255 is completely saturated), calculated as an exponential average over 5 minutes. The calculation uses the value from the bandwidth interface configuration command.
Encapsulation	Encapsulation method assigned to interface.
Loopback	Indicates whether loopbacks are set.
Keepalive	Indicates whether keepalives are set.
Scramble	Indicates whether or not SONET payload scrambling is enabled. SONET scrambling is disabled by default.
Last input	Number of hours, minutes, and seconds since the last packet was successfully received by an interface and processed locally on the router. Useful for knowing when a dead interface failed. This counter is updated only when packets are process-switched, not when packets are fast-switched.
(Last) output	Number of hours, minutes, and seconds since the last packet was successfully transmitted by an interface. This counter is updated only when packets are process-switched, not when packets are fast-switched.
(Last) output hang	Number of hours, minutes, and seconds (or never) since the interface was last reset because of a transmission that took too long. When the number of hours in any of the “last” fields exceeds 24 hours, the number of days and hours is printed. If that field overflows, asterisks are printed.

Table 8-31 *show interfaces pos Field Descriptions (continued)*

Field	Description
Last clearing	Time at which the counters that measure cumulative statistics (such as number of bytes transmitted and received) shown in this report were last reset to zero. Note that variables that might affect routing (for example, load and reliability) are not cleared when the counters are cleared. *** indicates the elapsed time is too large to be displayed. 0:00:00 indicates the counters were cleared more than 22 ³¹ ms (and less than 2 ³² ms) ago.
Queueing strategy	First-in, first-out queueing strategy (other queueing strategies you might see are priority-list, custom-list, and weighted fair).
Output queue, drops input queue, drops	Number of packets in output and input queues. Each number is followed by a slash, the maximum size of the queue, and the number of packets dropped because a queue was full.
5 minute input rate 5 minute output rate	Average number of bits and packets received or transmitted per second in the last 5 minutes.
Packets input	Total number of error-free packets received by the system.
Bytes (input)	Total number of bytes, including data and MAC encapsulation, in the error-free packets received by the system.
No buffer	Number of received packets discarded because there was no buffer space in the main system. Compare with ignored count. Broadcast storms on Ethernets and bursts of noise on serial lines are often responsible for no input buffer events.
Broadcasts	Total number of broadcast or multicast packets received by the interface.
Runts	Number of packets that are discarded because they are smaller than the minimum packet size of the medium.
Giants	Number of packets that are discarded because they exceed the maximum packet size of the medium.
Parity	Report of the parity errors on the interface.
Input errors	Total number of no buffer, runts, giants, CRCs, frame, overrun, ignored, and abort counts. Other input-related errors can also increment the count, so that this sum might not balance with the other counts.
CRC	Cyclic redundancy checksum generated by the originating LAN station or far-end device does not match the checksum calculated from the data received. On a LAN, this usually indicates noise or transmission problems on the LAN interface or the LAN bus itself. A high number of CRCs is usually the result of collisions or a station transmitting bad data. On a serial link, CRCs usually indicate noise, gain hits or other transmission problems on the data link.
Frame	Number of packets received incorrectly having a CRC error and a noninteger number of octets. On a serial line, this is usually the result of noise or other transmission problems.

Table 8-31 *show interfaces pos Field Descriptions (continued)*

Field	Description
Overrun	Number of times the serial receiver hardware was unable to hand received data to a hardware buffer because the input rate exceeded the receiver's ability to handle the data.
Ignored	Number of received packets ignored by the interface because the interface hardware ran low on internal buffers. These buffers are different than the system buffers mentioned previously in the buffer description. Broadcast storms and bursts of noise can cause the ignored count to be incremented.
Abort	Illegal sequence of one bits on the interface.
Packets output	Total number of messages transmitted by the system.
Bytes (output)	Total number of bytes, including data and MAC encapsulation, transmitted by the system.
Underruns	Number of times that the far-end transmitter has been running faster than the near-end router's receiver can handle.
Output errors	Sum of all errors that prevented the final transmission of datagrams out of the interface being examined. Note that this might not balance with the sum of the enumerated output errors, as some datagrams can have more than one error, and others can have errors that do not fall into any of the specifically tabulated categories.
Applique	Indicates an unrecoverable error has occurred on the POSIP applique. The system then invokes an interface reset.
Interface resets	Number of times an interface has been completely reset. This can happen if packets queued for transmission were not sent within a certain interval. If the system notices that the carrier detect line of an interface is up, but the line protocol is down, it periodically resets the interface in an effort to restart it. Interface resets can also occur when an unrecoverable interface processor error occurred, or when an interface is looped back or shut down.
Carrier transitions	Number of times the carrier detect signal of the interface has changed state.

Related Commands

Command	Description
interface	Configures an interface type and enters interface configuration mode.

show interfaces serial

To display information about a serial interface, use the **show interfaces serial** command in privileged EXEC mode. When using Frame Relay encapsulation, use the **show interfaces serial** command in user EXEC or privileged EXEC mode to display information about the multicast data-link connection identifier (DLCI), the DLCIs used on the interface, and the DLCI used for the Local Management Interface (LMI).

Cisco 4000 Series

```
show interfaces serial [number[:channel-group]] [accounting]
```

Cisco 7000 and Cisco 7500 Series with the RSP7000, RSP7000CI, or Ports on VIPs

```
show interfaces serial [slot/port-adapter/port]
```

Cisco 7500 Series

```
show interfaces serial [slot/port[:channel-group]] [accounting]
```

Cisco 7500 Series with a CT3IP

```
show interfaces serial [slot/port-adapter/port][:t1-channel] [accounting | crb]
```

Cisco AS5350 and Cisco AS5400 Universal Gateways

```
show interfaces serial slot/port
```

Cisco AS5800 Access Servers

```
show interfaces serial dial-shelf/slot/t3-port:t1-num:chan-group
```

T3/E3 Shared Port Adapters and 2-Port and 4-Port Channelized T3 SPA in Unchannelized Mode

```
show interfaces serial [slot/subslot/port]
```

Channelized T3 Shared Port Adapters

```
show interfaces serial [slot/subslot/port/t1-num:channel-group]
```

Syntax Description	
<i>number</i>	(Optional) Number of the port being displayed.
<i>:channel-group</i>	(Optional) On the Cisco 4000 series with a Network Management Processor (NPM) or the Cisco 7500 series routers with a MultiChannel Interface Processor (MIP), specifies the T1 channel-group number in the range of 0 to 23 defined with the channel-group controller configuration command. For channelized T3 SPAs, number 0–23 of the DS0 link on the T1 channel.
accounting	(Optional) Displays the number of packets of each protocol type that have been sent through the interface.

<i>slot</i>	(Optional) Chassis slot number. Refer to the appropriate hardware manual for slot information. For MSCs, refer to the platform-specific SPA hardware installation guide or the corresponding “Identifying Slots and Subslots for MSCs and SPAs” topic in the platform-specific SPA software configuration guide.
<i>port</i>	(Optional) Number of the port being displayed. Refer to the appropriate hardware manual for slot and port information.
<i>port-adapter</i>	(Optional) Number of the port adapter being displayed. Refer to the appropriate hardware manual for information about port adapter compatibility.
<i>subslot</i>	Secondary slot number on a MSC where a SPA is installed. Refer to the platform-specific SPA hardware installation guide and the corresponding “Specifying the Interface Address on a SPA” topic in the platform-specific SPA software configuration guide for subslot information.
<i>:t1-channel</i>	(Optional) T1 channel number. For the CT3IP, the T1 channel is a number between 1 and 28. T1 channels on the CT3IP are numbered 1 to 28 rather than the more traditional zero-based scheme (0 to 27) used with other Cisco products. This scheme ensures consistency with telco numbering schemes for T1 channels within channelized T3 equipment.
crb	(Optional) Displays interface routing and bridging information.
<i>dial-shelf</i>	Dial-shelf chassis in the Cisco AS5800 access server that contains the CT3 interface card.
<i>slot</i>	Location of the CT3 interface card in the dial shelf chassis.
<i>t3-port</i>	T3 port number. The only valid value is 0.
<i>:t1-num</i>	T1 time slot in the T3 line. The value can be from 1 to 28.
<i>:chan-group</i>	Channel group identifier.

Defaults

No default behavior or values

Command ModesUser EXEC when Frame Relay encapsulation is used
Privileged EXEC**Command History**

Release	Modification
10.0	This command was introduced on the Cisco 4000 series routers.
11.0	This command was implemented on the Cisco 7000 series routers.
11.1CA	This command was modified to include sample output for the PA-2JT2, PA-E3, and PA-T3 serial port adapters.
11.3	This command was modified to include the CT3IP.
12.0(3)T	This command was implemented on the Cisco AS5800 access servers. This command was modified to include support for flow-based WRED.
12.0(4)T	This command was modified to include enhanced display information for dialer bound interfaces.

Release	Modification
12.0(7)T	This command was modified to include dialer as an interface type, and to reflect the default behavior.
12.2(11)T	This command was implemented on the Cisco AS5350 and Cisco AS5400.
12.2(13)T	This command was modified to display information about Frame Relay interface queueing and fragmentation.
12.2S	This command was integrated into Cisco IOS Release 12.2S.
12.2(18)SXE	This command was integrated into Cisco IOS Release 12.2(18)SXE to support SPAs on the Cisco 7304 router.
12.0(31)S	This command was integrated into Cisco IOS Release 12.0(31)S.
12.2(25)S3	This command was integrated into Cisco IOS Release 12.2(25)S3.

Usage Guidelines

Frame Relay

Use this command to determine the status of the Frame Relay link. This display also indicates Layer 2 status if switched virtual circuits (SVCs) are configured.

Channel Groups as Virtual Serial Interfaces

To find out about channel groups configured as virtual serial interfaces, to verify that the router has High-Level Data Link Control (HDLC) encapsulation on the interface, and to verify that the interface sees the loopback, use the **show interfaces serial** command in privileged EXEC mode.

Examples

Example of Synchronous Serial Interface

The following is sample output from the **show interfaces serial** command for a synchronous serial interface:

```
Router# show interfaces serial

Serial 0 is up, line protocol is up
  Hardware is MCI Serial
  Internet address is 192.168.10.203, subnet mask is 255.255.255.0
  MTU 1500 bytes, BW 1544 Kbit, DLY 20000 usec, rely 255/255, load 1/255
  Encapsulation HDLC, loopback not set, keepalive set (10 sec)
  Last input 0:00:07, output 0:00:00, output hang never
  Output queue 0/40, 0 drops; input queue 0/75, 0 drops
  Five minute input rate 0 bits/sec, 0 packets/sec
  Five minute output rate 0 bits/sec, 0 packets/sec
    16263 packets input, 1347238 bytes, 0 no buffer
    Received 13983 broadcasts, 0 runts, 0 giants
    2 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 2 abort
  1 carrier transitions

    22146 packets output, 2383680 bytes, 0 underruns
    0 output errors, 0 collisions, 2 interface resets, 0 restarts
```

[Table 8-32](#) describes significant fields shown in the display.

Table 8-32 *show interfaces serial Field Descriptions—Synchronous Serial Interface*

Field	Description
Serial ... is {up down} ... is administratively down	Indicates whether the interface hardware is currently active (whether carrier detect is present), is currently inactive, or has been taken down by an administrator.
line protocol is {up down}	Indicates whether the software processes that handle the line protocol consider the line usable (that is, whether keepalives are successful) or whether the line has been taken down by an administrator.
Hardware is	Specifies the hardware type.
Internet address is	Specifies the Internet address and subnet mask.
MTU	Maximum transmission unit of the interface.
BW	Indicates the value of the bandwidth parameter that has been configured for the interface (in kbps). If the interface is attached to a serial line with a line speed that does not match the default (1536 or 1544 kbps for T1 and 56 kbps for a standard synchronous serial line), use the bandwidth command to specify the correct line speed for this serial line.
DLY	Delay of the interface, in microseconds.
rely	Reliability of the interface as a fraction of 255 (255/255 is 100 percent reliability), calculated as an exponential average over 5 minutes.
load	Load on the interface as a fraction of 255 (255/255 is completely saturated), calculated as an exponential average over 5 minutes.
Encapsulation	Encapsulation method assigned to interface.
loopback	Indicates whether or not loopback is set.
keepalive	Indicates whether or not keepalives are set.
Last input	Number of hours, minutes, and seconds since the last packet was successfully received by an interface and processed locally on the router. Useful for knowing when a dead interface failed. This counter is updated only when packets are process-switched, not when packets are fast-switched.
Last output	Number of hours, minutes, and seconds since the last packet was successfully transmitted by an interface. This counter is updated only when packets are process-switched, not when packets are fast-switched.
output hang	Number of hours, minutes, and seconds (or never) since the interface was last reset because of a transmission that took too long. When the number of hours in any of the “last” fields exceeds 24 hours, the number of days and hours is printed. If that field overflows, asterisks are printed.
Output queue, drops input queue, drops	Number of packets in output and input queues. Each number is followed by a slash, the maximum size of the queue, and the number of packets dropped because of a full queue.

Table 8-32 *show interfaces serial Field Descriptions—Synchronous Serial Interface (continued)*

Field	Description
5 minute input rate 5 minute output rate	Average number of bits and packets transmitted per second in the last 5 minutes. The 5-minute input and output rates should be used only as an approximation of traffic per second during a given 5-minute period. These rates are exponentially weighted averages with a time constant of 5 minutes. A period of four time constants must pass before the average will be within two percent of the instantaneous rate of a uniform stream of traffic over that period.
packets input	Total number of error-free packets received by the system.
bytes	Total number of bytes, including data and MAC encapsulation, in the error-free packets received by the system.
no buffer	Number of received packets discarded because there was no buffer space in the main system. Compare with ignored count. Broadcast storms on Ethernet networks and bursts of noise on serial lines are often responsible for no input buffer events.
Received... broadcasts	Total number of broadcast or multicast packets received by the interface.
runts	Number of packets that are discarded because they are smaller than the minimum packet size of the medium.
giants	Number of packets that are discarded because they exceed the maximum packet size of the medium.
input errors	Total number of no buffer, runts, giants, CRCs, frame, overrun, ignored, and abort counts. Other input-related errors can also increment the count, so that this sum might not balance with the other counts.
CRC	Cyclic redundancy checksum generated by the originating station or far-end device does not match the checksum calculated from the data received. On a serial link, CRCs usually indicate noise, gain hits, or other transmission problems on the data link.
frame	Number of packets received incorrectly having a CRC error and a noninteger number of octets. On a serial line, this is usually the result of noise or other transmission problems.
overrun	Number of times the serial receiver hardware was unable to hand received data to a hardware buffer because the input rate exceeded the receiver's ability to handle the data.
ignored	Number of received packets ignored by the interface because the interface hardware ran low on internal buffers. Broadcast storms and bursts of noise can cause the ignored count to be increased.
abort	Illegal sequence of one bits on a serial interface. This usually indicates a clocking problem between the serial interface and the data link equipment.
carrier transitions	Number of times the carrier detect signal of a serial interface has changed state. For example, if data carrier detect (DCD) goes down and comes up, the carrier transition counter will increment two times. Indicates modem or line problems if the carrier detect line is changing state often.
packets output	Total number of messages transmitted by the system.

Table 8-32 *show interfaces serial Field Descriptions—Synchronous Serial Interface (continued)*

Field	Description
bytes output	Total number of bytes, including data and MAC encapsulation, transmitted by the system.
underruns	Number of times that the transmitter has been running faster than the router can handle. This might never be reported on some interfaces.
output errors	Sum of all errors that prevented the final transmission of datagrams out of the interface from being examined. Note that this might not balance with the sum of the enumerated output errors because some datagrams can have more than one error, and others can have errors that do not fall into any of the specifically tabulated categories.
collisions	Number of messages retransmitted because of an Ethernet collision. Some collisions are normal. However, if your collision rate climbs to around 4 or 5 percent, you should consider verifying that there is no faulty equipment on the segment and/or moving some existing stations to a new segment. A packet that collides is counted only once in output packets.
interface resets	Number of times an interface has been completely reset. This can happen if packets queued for transmission were not sent within several seconds' time. On a serial line, this can be caused by a malfunctioning modem that is not supplying the transmit clock signal or by a cable problem. If the system notices that the carrier detect line of a serial interface is up, but the line protocol is down, it periodically resets the interface in an effort to restart it. Interface resets can also occur when an interface is looped back or shut down.
restarts	Number of times the controller was restarted because of errors.
alarm indications, remote alarms, rx LOF, rx LOS	Number of CSU/DSU alarms and number of occurrences of receive loss of frame and receive loss of signal.
BER inactive, NELR inactive, FELR inactive	Status of G.703-E1 counters for bit-error rate (BER) alarm, near-end loop remote (NELR), and far-end loop remote (FELR). Note that you cannot set the NELR or FELR.

Example of PA-2JT2 Serial Interface

The following is sample output from the **show interfaces serial** command for a PA-2JT2 serial interface:

```
Router# show interfaces serial 3/0/0

Serial3/0/0 is up, line protocol is up
  Hardware is cyBus Serial
  Internet address is 10.0.0.1/8
  MTU 1500 bytes, BW 6312 Kbit, DLY 20000 usec, rely 255/255, load 26/255
  Encapsulation HDLC, loopback not set, keepalive not set
  Last input 00:04:31, output 00:04:31, output hang never
  Last clearing of "show interface" counters 00:06:07
  Queueing strategy: fifo
  Output queue 0/40, 0 drops; input queue 0/75, 0 drops
  5 minute input rate 162000 bits/sec, 8 packets/sec
  5 minute output rate 162000 bits/sec, 8 packets/sec
    20005 packets input, 20080520 bytes, 0 no buffer
    Received 0 broadcasts, 0 runts, 0 giants
    0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
    20005 packets output, 20080520 bytes, 0 underruns
    0 output errors, 0 collisions, 0 interface resets
```

```

0 output buffer failures, 0 output buffers swapped out
0 carrier transitions
0 cv errors, 0 crc5 errors, 0 frame errors
rxLOS inactive, rxLOF inactive, rxPAIS inactive
rxAIS inactive, rxRAI inactive, rxHBER inactive

```

Table 8-33 describes significant fields shown in the display that are different from the fields described in Table 8-32.

Table 8-33 *show interfaces serial Field Descriptions—PA-2JT2 Serial Interface*

Field	Description
Last clearing of “show interface” counters	Time the counters were last cleared.
Queueing strategy	First-in, first-out queueing strategy (other queueing strategies that you might see are priority-list, custom-list, and weighted fair).
output buffer failures	Number of “no resource” errors received on the output.
output buffers swapped out	Number of packets swapped to DRAM.
carrier transitions	Number of times the carrier detect signal of a serial interface has changed state. For example, if data carrier detect (DCD) goes down and comes up, the carrier transition counter will increment two times. Indicates modem or line problems if the carrier detect line is changing state often.
cv errors	B8ZS/B6ZS (zero suppression) coding violation counter.
crc5 errors	CRC-5 error counter.
frame errors	Framing error counter.
rxLOS	Receive loss of signal alarm. Values are active or inactive.
rxLOF	Receive loss of frame alarm. Values are active or inactive.
rxPAIS	Receive loss of payload alarm indication signal (AIS). Values are active or inactive.
rxAIS	Receive loss of physical AIS. Values are active or inactive.
rxRAI	Receive remote AIS. Values are active or inactive.
rxHBER	Receive high bit-error rate alarm. Values are active or inactive.

Example of PA-E3 Serial Port Adapter

The following is sample output from the **show interfaces serial** command for a PA-E3 serial port adapter installed in chassis slot 2:

```
Router# show interfaces serial 2/0
```

```

Serial2/0 is up, line protocol is up
  Hardware is M1T-E3 pa
  Internet address is 172.17.1.1/24
  MTU 4470 bytes, BW 34010 Kbit, DLY 200 usec, rely 128/255, load 1/255
  Encapsulation HDLC, loopback not set, keepalive not set
  Last input 1w0d, output 00:00:48, output hang never
  Last clearing of “show interface” counters 1w0d
  Queueing strategy: fifo
  Output queue 0/40, 0 drops; input queue 0/75, 0 drops
  5 minute input rate 0 bits/sec, 0 packets/sec
  5 minute output rate 0 bits/sec, 0 packets/sec

```

```

20 packets input, 2080 bytes, 0 no buffer
Received 0 broadcasts, 0 runts, 0 giants, 0 parity
0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
11472 packets output, 3824748 bytes, 0 underruns
0 output errors, 0 applique, 0 interface resets
0 output buffer failures, 0 output buffers swapped out
0 carrier transitions
rxLOS inactive, rxLOF inactive, rxAIS inactive
txAIS inactive, rxRAI inactive, txRAI inactive

```

Table 8-34 describes significant fields shown in the display that are different from the fields described in Table 8-32 on page 8-139.

Table 8-34 *show interfaces serial Field Descriptions—PA-E3*

Field	Description
Last clearing of “show interface” counters	Time the counters were last cleared.
Queueing strategy	First-in, first-out queueing strategy (other queueing strategies that you might see are priority-list, custom-list, and weighted fair).
parity	Number of the parity errors on the interface.
applique	Indicates that an unrecoverable error has occurred on the E3 applique. The router then invokes an interface reset.
output buffer failures	Number of “no resource” errors received on the output.
output buffers swapped out	Number of packets swapped to DRAM.
rxLOS, rxLOF, rxAIS	Receive loss of signal, loss of frame, and alarm indication signal status. Values are inactive or active.
txAIS, rxRAI, txRAI	Transmit alarm indication signal, receive remote alarm indicator, and transmit remote alarm indicator status. Values are inactive or active. When the router receives an LOS, LOF, or AIS, the txRAI is active. When the remote router receives an LOS, LOF, or AIS, the rxRAI is active.

Example of 1-Port PA-T3 Serial Port Adapter Installed in a VIP2

The following is sample output from the **show interfaces serial** command for a 1-port PA-T3 serial port adapter installed in a VIP2 in chassis slot 1, in port adapter slot 0:

Router# **show interfaces serial 1/0/0**

```

Serial1/0/0 is up, line protocol is up
Hardware is cyBus PODS3 Serial
Internet address is 172.18.1.1/24
MTU 4470 bytes, BW 44736 Kbit, DLY 200 usec, rely 255/255, load 1/255
Encapsulation HDLC, loopback not set, keepalive set (10 sec)
Last input 00:00:05, output 00:00:02, output hang never
Last clearing of "show interface" counters 5d02h
Queueing strategy: fifo
Output queue 0/40, 0 drops; input queue 0/75, 27269 drops
5 minute input rate 0 bits/sec, 0 packets/sec
5 minute output rate 0 bits/sec, 0 packets/sec
 79039 packets input, 14195344 bytes, 0 no buffer
  Received 84506 broadcasts, 0 runts, 0 giants
    0 parity
 9574 input errors, 6714 CRC, 0 frame, 1 overrun, 0 ignored, 2859 abort
62472 packets output, 13751644 bytes, 0 underruns

```

```

0 output errors, 0 applique, 10 interface resets
0 output buffer failures, 0 output buffers swapped out
16 carrier transitions
rxLOS inactive, rxLOF inactive, rxAIS inactive
txAIS inactive, rxRAI inactive, txRAI inactive

```

Table 8-35 describes significant fields shown in the display that are different from the fields described in Table 8-32 on page 8-139.

Table 8-35 *show interfaces serial Field Descriptions—PA-T3*

Field	Description
Last clearing of “show interface” counters	Time the counters were last cleared.
Queueing strategy	First-in, first-out queueing strategy (other queueing strategies that you might see are priority-list, custom-list, and weighted fair).
parity	Number of the parity errors on the interface.
applique	Indicates that an unrecoverable error has occurred on the T3 applique. The router then invokes an interface reset.
output buffer failures	Number of “no resource” errors received on the output.
output buffers swapped out	Number of packets swapped to DRAM.
rxLOS, rxLOF, rxAIS	Receive loss of signal, loss of frame, and alarm indication signal status. Values are inactive or active.
txAIS, rxRAI, txRAI	Transmit alarm indication signal, receive remote alarm indicator, and transmit remote alarm indicator status. Values are inactive or active. When the router receives an LOS, LOF, or AIS, the txRAI is active. When the remote router receives an LOS, LOF, or AIS, the rxRAI is active.

Example of CT3IP Serial Interface

The following is sample output from the **show interfaces serial** command for the CT3IP serial interface:

```
Router# show interfaces serial 3/0/0:25
```

```

Serial3/0/0:25 is up, line protocol is up
Hardware is cyBus T3
Internet address is 10.25.25.2/24
MTU 1500 bytes, BW 1536 Kbit, DLY 20000 usec, rely 255/255, load 12/255
Encapsulation HDLC, loopback not set, keepalive not set
Last input 00:19:01, output 00:11:49, output hang never
Last clearing of “show interface” counters 00:19:39
Input queue: 0/75/0 (size/max/drops); Total output drops: 0
Queueing strategy: weighted fair
Output queue: 0/64/0 (size/threshold/drops)
  Conversations 0/1 (active/max active)
  Reserved Conversations 0/0 (allocated/max allocated)
5 minute input rate 69000 bits/sec, 90 packets/sec
5 minute output rate 71000 bits/sec, 90 packets/sec
  762350 packets input, 79284400 bytes, 0 no buffer
  Received 0 broadcasts, 0 runts, 0 giants
  150 input errors, 0 CRC, 0 frame, 150 overrun, 0 ignored, 0 abort
  763213 packets output, 80900472 bytes, 0 underruns
  0 output errors, 0 collisions, 0 interface resets
  0 output buffer failures, 0 output buffers swapped out
  0 carrier transitions no alarm present

```


Timeslot(s) Used:1-24, Transmitter delay is 0 flags, transmit queue length 5
non-inverted data

Table 8-36 describes significant fields relevant to the CT3IP shown in the display that are different from the fields described in Table 8-32 on page 8-139.

Table 8-36 *show interfaces serial Field Descriptions—CT3IP*

Field	Description
Timeslot(s) Used	Number of time slots assigned to the T1 channel.
Transmitter delay	Number of idle flags inserted between each HDLC frame.
transmit queue length	Number of packets allowed in the transmit queue.
non-inverted data	Indicates whether or not the interface is configured for inverted data.

Example of an HDLC Synchronous Serial Interface on a Cisco 7500 Series Router

The following is sample output from the **show interfaces serial** command for an HDLC synchronous serial interface on a Cisco 7500 series router:

```
Router# show interfaces serial 1/0

Serial1/0 is up, line protocol is up
  Hardware is cxBus Serial
  Internet address is 172.19.190.203, subnet mask is 255.255.255.0
  MTU 1500 bytes, BW 1544 Kbit, DLY 20000 usec, rely 255/255, load 1/255
  Encapsulation HDLC, loopback not set, keepalive set (10 sec)
  Last input 0:00:07, output 0:00:00, output hang never
  Last clearing of "show interface" counters 2w4d
  Output queue 0/40, 0 drops; input queue 0/75, 0 drops
  Five minute input rate 0 bits/sec, 0 packets/sec
  Five minute output rate 0 bits/sec, 0 packets/sec
    16263 packets input, 1347238 bytes, 0 no buffer
    Received 13983 broadcasts, 0 runts, 0 giants
    2 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 2 abort
    22146 packets output, 2383680 bytes, 0 underruns
    0 output errors, 0 collisions, 2 interface resets, 0 restarts
    1 carrier transitions
```

Table 8-32 on page 8-139 describes significant fields shown in the display.

Example of HDLC Encapsulation

The following example displays High-Level Data Link Control (HDLC) encapsulation on serial interface 0:

```
Router# show interfaces serial 0

Serial0 is up, line protocol is up (looped)
  Hardware is HD64570
  Internet address is 10.1.1.1, subnet mask is 255.255.255.0
  MTU 1500 bytes, BW 1544 Kbit, DLY 20000 usec, rely 255/255, load 1/255
  Encapsulation HDLC, loopback set, keepalive set (10 sec)
```

Table 8-32 on page 8-139 describes significant fields shown in the display.

Example of a G.703 Interface with Framing

The following is sample output from the **show interfaces serial** command for a G.703 interface on which framing is enabled:

```
Router# show interfaces serial 2/3
```

```
Serial2/3 is up, line protocol is up
  Hardware is cxBus Serial
  Internet address is 10.4.4.1, subnet mask is 255.255.255.0
  MTU 1500 bytes, BW 1544 Kbit, DLY 20000 usec, rely 255/255, load 1/255
  Encapsulation HDLC, loopback not set, keepalive not set
  Last input 0:00:21, output 0:00:21, output hang never
  Last clearing of "show interface" counters never
  Output queue 0/40, 0 drops; input queue 0/75, 0 drops
  Five minute input rate 0 bits/sec, 0 packets/sec
  Five minute output rate 0 bits/sec, 0 packets/sec
    53 packets input, 7810 bytes, 0 no buffer
    Received 53 broadcasts, 0 runts, 0 giants
    2 input errors, 2 CRC, 0 frame, 0 overrun, 0 ignored, 2 abort
    56 packets output, 8218 bytes, 0 underruns
    0 output errors, 0 collisions, 2 interface resets, 0 restarts
    1 carrier transitions
    2 alarm indications, 333 remote alarms, 332 rx LOF, 0 rx LOS
  RTS up, CTS up, DTR up, DCD up, DSR up
  BER inactive, NELR inactive, FELR inactive
```

[Table 8-32 on page 8-139](#) describes significant fields shown in the display.

Example with Frame Relay Encapsulation

When using Frame Relay encapsulation, use the **show interfaces serial** command to display information on the multicast data-link connection identifier (DLCI), the DLCI of the interface, and the DLCI used for the Local Management Interface (LMI).

The multicast DLCI and the local DLCI can be set using the **frame-relay multicast-dlci** and **frame-relay local-dlci** configuration commands. The status information is taken from the LMI, when active.

The following is sample output from the **show interfaces serial** command when Frame Relay encapsulation and LMI are enabled:

```
Router# show interfaces serial
```

```
Serial 2 is up, line protocol is up
  Hardware type is MCI Serial
  Internet address is 172.20.122.1, subnet mask is 255.255.255.0
  MTU 1500 bytes, BW 1544 Kbit, DLY 20000 usec, rely 255/255, load 1/255
  Encapsulation FRAME-RELAY, loopback not set, keepalive set (10 sec)
  multicast DLCI 1022, status defined, active
  source DLCI 20, status defined, active
  LMI DLCI 1023, LMI sent 10, LMI stat recvd 10, LMI upd recvd 2
  Last input 7:21:29, output 0:00:37, output hang never
  Output queue 0/100, 0 drops; input queue 0/75, 0 drops
  Five minute input rate 0 bits/sec, 0 packets/sec
  Five minute output rate 0 bits/sec, 0 packets/sec
    47 packets input, 2656 bytes, 0 no buffer
    Received 5 broadcasts, 0 runts, 0 giants
    5 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 57 abort
    518 packets output, 391205 bytes
    0 output errors, 0 collisions, 0 interface resets, 0 restarts
    1 carrier transitions
```

In this display, the multicast DLCI has been changed to 1022 using the **frame-relay multicast-dlci** interface configuration command.

The display shows the statistics for the LMI as the number of status inquiry messages sent (LMI sent), the number of status messages received (LMI recvd), and the number of status updates received (upd recvd). Refer to the *Frame Relay Interface* specification for additional explanations of this output.

Example with Frame Relay Queueing and Fragmentation at the Interface

The following is sample output from the **show interfaces serial** command when low-latency queueing and FRF.12 end-to-end fragmentation are configured on a Frame Relay interface:

```
Router# show interfaces serial 3/2

Serial3/2 is up, line protocol is up
  Hardware is M4T
  MTU 1500 bytes, BW 1544 Kbit, DLY 20000 usec,
    reliability 255/255, txload 1/255, rxload 1/255
  Encapsulation FRAME-RELAY, crc 16, loopback not set
  Keepalive set (10 sec)
  LMI enq sent 0, LMI stat recvd 0, LMI upd recvd 0, DTE LMI up
  LMI enq recvd 0, LMI stat sent 0, LMI upd sent 0
  LMI DLCI 1023 LMI type is CISCO frame relay DTE
  Fragmentation type: end-to-end, size 80, PQ interleaves 0
  Broadcast queue 0/64, broadcasts sent/dropped 0/0, interface broadcasts 0
  Last input 2d15h, output 2d15h, output hang never
  Last clearing of "show interface" counters 00:01:31
  Input queue: 0/75/0/0 (size/max/drops/flushes); Total output drops: 0
  Queueing strategy: weighted fair
  Output queue: 0/1000/64/0 (size/max total/threshold/drops)
    Conversations 0/0/256 (active/max active/max total)
    Reserved Conversations 0/0 (allocated/max allocated)
    Available Bandwidth 1094 kilobits/sec
  5 minute input rate 0 bits/sec, 0 packets/sec
  5 minute output rate 0 bits/sec, 0 packets/sec
    0 packets input, 0 bytes, 0 no buffer
    Received 0 broadcasts, 0 runts, 0 giants, 0 throttles
    0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
    0 packets output, 0 bytes, 0 underruns
    0 output errors, 0 collisions, 1 interface resets
    0 output buffer failures, 0 output buffers swapped out
    1 carrier transitions      DCD=up DSR=up DTR=up RTS=up CTS=up
```

Table 8-37 describes significant fields shown in the display that are different from the fields described in Table 8-32 on page 8-139.

Table 8-37 *show interfaces serial* Field Descriptions—Frame Relay Interface Queueing and Fragmentation

Field	Description
txload	Interface load in the transmit direction.
rxload	Interface load in the receive direction.
crc	Number of Layer 1 checksum errors during reception.
LMI enq sent	Number of Frame Relay status inquiry messages sent.
LMI stat recvd	Number of Frame Relay status request messages received.
LMI upd recvd	Number of single PVC asynchronous status messages received.
DTE LMI up	LMI peers are synchronized.

Table 8-37 *show interfaces serial Field Descriptions—Frame Relay Interface Queueing and Fragmentation (continued)*

Field	Description
LMI enq recvd	Number of Frame Relay status inquiry messages received.
LMI stat sent	Number of Frame Relay status request messages sent.
LMI upd sent	Number of single PVC asynchronous status messages sent.
Fragmentation type	Type of fragmentation: end-to-end, Cisco, or VoFR
size	Fragmentation size.
PQ interleaves	Number of priority queue frames that have interleaved data fragments.
Broadcast queue	Number on queue/queue depth.
broadcasts sent/dropped	Number of broadcasts sent and dropped.
interface broadcasts	Number of broadcasts sent on interface.
Input queue	size—Current size of the input queue. max—Maximum size of the queue. drops—Number of messages discarded. flushes—Number of times that data on queue has been discarded.
Queueing strategy	Type of queueing configured on the interface.
Output queue	size—Current size of the output queue. max total—Maximum number of frames that can be queued. threshold—Congestive-discard threshold. Number of messages in the queue after which new messages for high-bandwidth conversations are dropped. drops—Number of dropped messages.
Conversations	active—Number of currently active conversations. max active—Maximum number of conversations that have ever occurred at one time. max total—Maximum number of active conversations allowed.
throttles	Number of times the receiver on the port was disabled, possibly because of processor or buffer overload.
output buffer failures	Number of “no resource” errors received on the output.
output buffers swapped out	Number of packets swapped to DRAM.

Example with ANSI LMI

For a serial interface with the ANSI Local Management Interface (LMI) enabled, use the **show interfaces serial** command to determine the LMI type implemented. The following is sample output from the **show interfaces serial** command for a serial interface with the ANSI LMI enabled:

```
Router# show interfaces serial
```

```
Serial 1 is up, line protocol is up
  Hardware is MCI Serial
  Internet address is 172.18.121.1, subnet mask is 255.255.255.0
  MTU 1500 bytes, BW 1544 Kbit, DLY 20000 usec, rely 255/255, load 1/255
  Encapsulation FRAME-RELAY, loopback not set, keepalive set
  LMI DLCI 0, LMI sent 10, LMI stat recvd 10
  LMI type is ANSI Annex D
  Last input 0:00:00, output 0:00:00, output hang never
```

```
Output queue 0/40, 0 drops; input queue 0/75, 0 drops
```

```
Five minute input rate 0 bits/sec, 1 packets/sec
Five minute output rate 1000 bits/sec, 1 packets/sec
 261 packets input, 13212 bytes, 0 no buffer
  Received 33 broadcasts, 0 runts, 0 giants
   0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
 238 packets output, 14751 bytes, 0 underruns
   0 output errors, 0 collisions, 0 interface resets, 0 restarts
```

Notice that the **show interfaces serial** output for a serial interface with ANSI LMI shown in this display is very similar to that for encapsulation set to Frame Relay, as shown in the previous display. [Table 8-38](#) describes the few differences that exist.

Table 8-38 *show interfaces serial Field Descriptions—ANSI LMI*

Field	Description
LMI DLCI	Identifies the DLCI used by the LMI for this interface. The default is 1023.
LMI sent	Number of LMI packets that the router sent.
LMI type is ANSI Annex D	Indicates that the interface is configured for the ANSI-adopted Frame Relay specification T1.617 Annex D.

Example with LAPB Encapsulation

Use the **show interfaces serial** command to display operation statistics for an interface that uses Link Access Procedure, Balanced (LAPB) encapsulation. The following is partial sample output from the **show interfaces serial** command for a serial interface that uses LAPB encapsulation:

```
Router# show interfaces serial 1
```

```
LAPB state is SABMSENT, T1 3000, N1 12056, N2 20, k7, Protocol ip
VS 0, VR 0, RCNT 0, Remote VR 0, Retransmissions 2
IFRAMES 0/0 RNRs 0/0 REJs 0/0 SABMs 3/0 FRMRs 0/0 DISCs 0/0
```

[Table 8-39](#) shows the fields relevant to all LAPB connections.

Table 8-39 *show interfaces serial Field Descriptions—LAPB*

Field	Description
LAPB state is	State of the LAPB protocol.
T1 3000, N1 12056, ...	Current parameter settings.
Protocol	Protocol encapsulated on a LAPB link; this field is not present on interfaces configured for multiprotocol LAPB or X.25 encapsulations.
VS	Modulo 8 frame number of the next outgoing information frame.
VR	Modulo 8 frame number of the next information frame expected to be received.
RCNT	Number of received information frames that have not yet been acknowledged.
Remote VR	Number of the next information frame that the remote device expects to receive.
Retransmissions	Count of current retransmissions because of expiration of T1.

Table 8-39 *show interfaces serial Field Descriptions—LAPB (continued)*

Field	Description
Window is closed	No more frames can be transmitted until some outstanding frames have been acknowledged. This message should be displayed only temporarily.
IFRAMEs	Count of information frames in the form of sent/received.
RNRs	Count of Receiver Not Ready frames in the form of sent/received.
REJs	Count of Reject frames in the form of sent/received.
SABMs	Count of Set Asynchronous Balanced Mode commands in the form of sent/received.
FRMRs	Count of Frame Reject frames in the form of sent/received.
DISCs	Count of Disconnect commands in the form of sent/received.

Router# **show interfaces serial 1**

[Table 8-40](#) show the fields relevant to PPP connections.

Table 8-40 *show interfaces serial Field Descriptions—PPP Encapsulation*

Field	Description
lcp state	Link Control Protocol.
ncp ipcp state	Network Control Protocol Internet Protocol Control Protocol.
ncp osicp state	Network Control Protocol OSI (CLNS) Control Protocol.
ncp ipxcp state	Network Control Protocol IPX (Novell) Control Protocol.
ncp deccp state	Network Control Protocol DECnet Control Protocol.
ncp bridgecp state	Network Control Protocol Bridging Control Protocol.
ncp atalkcp state	Network Control Protocol AppleTalk Control Protocol.

Example with SDLC Connections

Use the **show interfaces serial** command to display the Synchronous Data Link Control (SDLC) information for a given SDLC interface. The following is sample output from the **show interfaces serial** command for an SDLC primary interface that supports the SDLLC function:

Router# **show interfaces serial**

```
Serial 0 is up, line protocol is up
Hardware is MCI Serial
MTU 1500 bytes, BW 1544 Kbit, DLY 20000 usec, rely 255/255, load 1/255
Encapsulation SDLC-PRIMARY, loopback not set
  Timers (msec): poll pause 100 fair poll 500. Poll limit 1
  [T1 3000, N1 12016, N2 20, K 7] timer: 56608 Last polled device: none
  SDLLC [ma: 0000.0C01.14--, ring: 7 bridge: 1, target ring: 10
    largest token ring frame 2052]
SDLC addr C1 state is CONNECT
  VS 6, VR 3, RCNT 0, Remote VR 6, Current retransmit count 0
  Hold queue: 0/12 IFRAMEs 77/22 RNRs 0/0 SNRMs 1/0 DISCs 0/0
  Poll: clear, Poll count: 0, chain: p: C1 n: C1
  SDLLC [largest SDLC frame: 265, XID: disabled]
Last input 00:00:02, output 00:00:01, output hang never
```

```

Output queue 0/40, 0 drops; input queue 0/75, 0 drops
Five minute input rate 517 bits/sec, 30 packets/sec
Five minute output rate 672 bits/sec, 20 packets/sec
  357 packets input, 28382 bytes, 0 no buffer
    Received 0 broadcasts, 0 runts, 0 giants
      0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
    926 packets output, 77274 bytes, 0 underruns
      0 output errors, 0 collisions, 0 interface resets, 0 restarts
      2 carrier transitions

```

Table 8-41 shows the fields relevant to all SDLC connections.

Table 8-41 *show interfaces serial Field Descriptions—SDLC Enabled*

Field	Description
Timers (msec): poll pause, fair poll, Poll limit	Current values of these timers for the primary SDLC interface.
T1, N1, N2, K	Values for these parameters for the primary SDLC interface.

Table 8-42 shows other data given for each SDLC secondary interface configured to be attached to the serial interface.

Table 8-42 *SDLC Secondary Interface Descriptions*

Field	Description
addr	Address of this SDLC secondary interface.
state is	<p>Current state of this connection, which is one of the following:</p> <ul style="list-style-type: none"> • DISCONNECT—No communication is being attempted to this secondary. • CONNECT—A normal connect state exists between this router and this secondary. • DISCSENT—This router has sent a disconnect request to this secondary and is awaiting its response. • SNRMSENT—This router has sent a connect request (SNRM) to this secondary and is awaiting its response. • THEMBUSY—This secondary has told this router that it is temporarily unable to receive any more information frames. • USBUSY—This router has told this secondary that it is temporarily unable to receive any more information frames. • BOTHBUSY—Both sides have told each other that they are temporarily unable to receive any more information frames. • ERROR—This router has detected an error and is waiting for a response from the secondary acknowledging this.
VS	Sequence number of the next information frame that this station sends.
VR	Sequence number of the next information frame from this secondary that this station expects to receive.

Table 8-42 SDLC Secondary Interface Descriptions (continued)

Field	Description
Remote VR	Last frame transmitted by this station that has been acknowledged by the other station.
Current retransmit count:	Number of times the current I-frame or sequence of I-frames has been retransmitted.
Hold queue	Number of frames in hold queue and maximum size of hold queue.
IFRAMEs, RNRs, SNRMs, DISCs	Sent/received count for these frames.
Poll	“Set” if this router has a poll outstanding to the secondary; “clear” if it does not.
Poll count	Number of polls in a row that have been given to this secondary at this time.
chain	Shows the previous (p) and next (n) secondary address on this interface in the <i>round robin loop</i> of polled devices.

Example with SDLLC

Use the **show interfaces serial** command to display the SDLLC statistics for SDLLC-configured interfaces. The following is sample output from the **show interfaces serial** command for a serial interface configured for SDLLC:

```
Router# show interfaces serial

Serial 0 is up, line protocol is up
  Hardware is MCI Serial
  MTU 1500 bytes, BW 1544 Kbit, DLY 20000 usec, rely 255/255, load 1/255
  Encapsulation SDLC-PRIMARY, loopback not set
    Timers (msec): poll pause 100 fair poll 500. Poll limit 1
    [T1 3000, N1 12016, N2 20, K 7] timer: 56608 Last polled device: none
    SDLLC [ma: 0000.0C01.14--, ring: 7 bridge: 1, target ring: 10
      largest token ring frame 2052]
  SDLC addr C1 state is CONNECT
    VS 6, VR 3, RCNT 0, Remote VR 6, Current retransmit count 0
    Hold queue: 0/12 IFRAMEs 77/22 RNRs 0/0 SNRMs 1/0 DISCs 0/0
    Poll: clear, Poll count: 0, chain: p: C1 n: C1
    SDLLC [largest SDLC frame: 265, XID: disabled]
  Last input 00:00:02, output 00:00:01, output hang never
  Output queue 0/40, 0 drops; input queue 0/75, 0 drops
  Five minute input rate 517 bits/sec, 30 packets/sec
  Five minute output rate 672 bits/sec, 20 packets/sec
    357 packets input, 28382 bytes, 0 no buffer
    Received 0 broadcasts, 0 runts, 0 giants
    0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
    926 packets output, 77274 bytes, 0 underruns
    0 output errors, 0 collisions, 0 interface resets, 0 restarts
    6608 Last polled device: none
    SDLLC [ma: 0000.0C01.14--, ring: 7 brid2 carrier transitions
```

Most of the output shown in the display is generic to all SDLLC-encapsulated interfaces and is described in the *Cisco IOS Bridging and IBM Networking Command Reference*, Volume 2 of 2: IBM Networking. [Table 8-43](#) shows the parameters specific to SDLLC.

Table 8-43 *SDLLC Parameter Descriptions*

Field	Description
SDLLC ma	Lists the MAC address configured for this interface. The last byte is shown as "--" to indicate that it is filled in with the SDLC address of the connection.
ring, bridge, target ring	Lists the parameters as configured by the sdllc traddr command.
largest token ring frame	Shows the largest Token Ring frame that is accepted on the Logical Link control, type 2 (LLC2) side of the connection.
largest SDLC frame	Shows the largest SDLC frame that is accepted and will be generated on the SDLC side of the connection.
XID	Enabled or disabled: Shows whether XID processing is enabled on the SDLC side of the connection. If enabled, it will show the XID value for this address.

Example with X.25

The following is partial sample output from the **show interfaces serial** command for a serial X.25 interface:

```
Router# show interfaces serial 1
```

```
X25 address 000000010100, state R1, modulo 8, idle 0, timer 0, nvc 1
  Window size: input 2, output 2, Packet size: input 128, output 128
  Timers: T20 180, T21 200, T22 180, T23 180, TH 0
  Channels: Incoming-only none, Two-way 1-1024, Outgoing-only none
(configuration on RESTART: modulo 8,
  Window size: input 2 output 2, Packet size: input 128, output 128
  Channels: Incoming-only none, Two-way 5-1024, Outgoing-only none)
  RESTARTs 3/2 CALLs 1000+2/1294+190/0+0/ DIAGs 0/0
```

The stability of the X.25 protocol requires that some parameters not be changed without a restart of the protocol. Any change to these parameters is held until a restart is sent or received. If any of these parameters changes, information about the router configuration at restart will be displayed as well as the values that are currently in effect.

[Table 8-44](#) describes significant fields shown in the display.

Table 8-44 *show interfaces serial Field Descriptions—X.25 Enabled*

Field	Description
X25 address	Address used to originate and accept calls.
state	State of the interface. Possible values follow: <ul style="list-style-type: none"> • R1 is the normal ready state. • R2 is the DTE restarting state. • R3 is the DCE restarting state. If the state is R2 or R3, the interface is awaiting acknowledgment of a Restart packet.
modulo	Modulo value; determines the packet sequence numbering scheme used.

Table 8-44 *show interfaces serial Field Descriptions—X.25 Enabled (continued)*

Field	Description
idle	Number of minutes for which the Cisco IOS software waits before closing idle virtual circuits that it originated or accepted.
timer	Value of the interface timer, which is zero unless the interface state is R2 or R3.
nvc	Default maximum number of simultaneous virtual circuits permitted to and from a single host for a particular protocol.
Window size: input, output	Default window sizes (in packets) for the interface. The x25 facility interface configuration command can be used to override these default values for the switched virtual circuits originated by the router.
Packet size: input, output	Default maximum packet sizes (in bytes) for the interface. The x25 facility interface configuration command can be used to override these default values for the switched virtual circuits originated by the router.
Timers:	Values of the X.25 timers: <ul style="list-style-type: none"> • T10 through T13 for a DCE device • T20 through T23 for a DTE device
TH	Packet acknowledgment threshold (in packets). This value determines how many packets are received before an explicit acknowledgment is sent. The default value (0) sends an explicit acknowledgment only when the incoming window is full.
Channels: Incoming-only, Two-way, Outgoing-only	Displays the virtual circuit ranges for this interface.
RESTARTs	Shows Restart packet statistics for the interface using the format Sent/Received.
CALLs	Successful calls sent + failed calls/calls received + calls failed/calls forwarded + calls failed. Calls forwarded are counted as calls sent.
DIAGs	Diagnostic messages sent and received.

Example with Accounting Option

The following example illustrates the **show interfaces serial** command with the **accounting** option on a Cisco 7500 series routers:

```
Router# show interfaces serial 1/0 accounting
```

```
Serial1/0
  Protocol    Pkts In   Chars In   Pkts Out   Chars Out
    IP          7344    4787842    1803     1535774
  Appletalk   33345    4797459    12781    1089695
    DEC MOP         0         0        127       9779
    ARP           7        420         39       2340
```

Table 8-45 describes the fields shown in the display.

Table 8-45 *show interfaces serial Field Descriptions—Accounting*

Field	Description
Protocol	Protocol that is operating on the interface.
Pkts In	Number of packets received for that protocol.
Chars In	Number of characters received for that protocol.
Pkts Out	Number of packets transmitted for that protocol.
Chars Out	Number of characters transmitted for that protocol.

Example with Cisco AS5800 Access Server

The following example shows the activity that occurred on the serial interface in shelf 1, slot 4, port 0 for time slot 2 in group 23:

```
Router# show interfaces serial 1/4/0:2:23
```

```
Serial1/4/0:2:23 is up, line protocol is up (spoofing)
Hardware is DS-T1
MTU 1500 bytes, BW 64 Kbit, DLY 20000 usec, rely 255/255, load 1/255
Encapsulation HDLC, loopback not set
Last input 00:00:01, output 00:00:01, output hang never
Last clearing of "show interface" counters 22:24:30
Queueing strategy: fifo
Output queue 0/40, 0 drops; input queue 0/75, 0 drops
5 minute input rate 0 bits/sec, 0 packets/sec

5 minute output rate 0 bits/sec, 0 packets/sec
  5274 packets input, 20122 bytes, 0 no buffer
  Received 0 broadcasts, 0 runts, 0 giants, 0 throttles
  0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
  5274 packets output, 30836 bytes, 0 underruns
  0 output errors, 0 collisions, 0 interface resets
  0 output buffer failures, 0 output buffers swapped out
  2 carrier transitions no alarm present
Timeslot(s) Used:24, subrate: 64Kb/s, transmit delay is 0 flags
```

[Table 8-46](#) describes the significant fields shown in the display that are different from the fields described in [Table 8-32 on page 8-139](#).

Table 8-46 *show interfaces serial Field Descriptions—Cisco AS5800*

Field	Description
Last clearing of "show interface" counters	Time at which the counters that measure cumulative statistics (such as number of bytes transmitted and received) were last reset to zero.
Queueing strategy	Displays the type of queueing configured for this interface. In the example output, the type of queueing configured is FIFO.
throttles	Number of times that the receiver on the port was disabled, possibly because of buffer or processor overload.
output buffer failures	Number of times that the output buffer has failed.
output buffer swapped out	Number of times that the output buffer has been swapped out.
Timeslot(s) Used	Number of time slots assigned to the T1 channel.

Table 8-46 *show interfaces serial Field Descriptions—Cisco AS5800 (continued)*

Field	Description
subrate	Bandwidth of each time slot.
transmit delay is ...	Number of idle flags inserted between each frame.

Example with a T3/E3 Shared Port Adapter

The following example shows the interface statistics on the first port of a T3/E3 SPA installed in subslot 0 of the SIP located in chassis slot 5.

Router# **show interfaces serial**

```
Serial5/0/0 is up, line protocol is up
Hardware is SPA-4T3E3
Internet address is 110.1.1.2/24
MTU 4470 bytes, BW 44210 Kbit, DLY 200 usec,
    reliability 255/255, txload 234/255, rxload 234/255
Encapsulation HDLC, crc 16, loopback not set
Keepalive set (10 sec)
Last input 00:00:05, output 00:00:00, output hang never
Last clearing of "show interface" counters never
Input queue: 0/75/0/0 (size/max/drops/flushes); Total output drops: 0
Queueing strategy: fifo
Output queue: 0/40 (size/max)
5 minute input rate 40685000 bits/sec, 115624 packets/sec
5 minute output rate 40685000 bits/sec, 115627 packets/sec
  4653081241 packets input, 204735493724 bytes, 0 no buffer
  Received 4044 broadcasts (0 IP multicast)
  0 runs, 0 giants, 0 throttles
    0 parity
  0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
  4652915555 packets output, 204728203520 bytes, 0 underruns
  0 output errors, 0 applique, 4 interface resets
  0 output buffer failures, 0 output buffers swapped out
  2 carrier transitions
  rxLOS inactive, rxLOF inactive, rxAIS inactive
  txAIS inactive, rxRAI inactive, txRAI inactive
```

[Table 8-47](#) describes the fields shown in the **show interfaces serial** output.



Note The fields appearing in the output will vary depending on card type, interface configuration, and the status of the interface.

Table 8-47 *T3/E3 SPA—Command Field Descriptions*

Field	Description
Serial	Name of the serial interface.
line protocol is	If the line protocol is up, the local router has received keepalive packets from the remote router. If the line protocol is down, the local router has not received keepalive packets from the remote router.
Hardware is	Designates the specific hardware type of the interface.
Internet address is	The IP address of the interface.

Table 8-47 T3/E3 SPA—Command Field Descriptions (continued)

Field	Description
MTU	The maximum packet size set for the interface.
BW	Bandwidth in kilobits per second.
DLY	Interface delay in microseconds.
reliability	Reliability of the interface as a fraction of 255 (255/255 is 100 percent reliability), calculated as an exponential average over 5 minutes.
txload	Transmit load on the interface as a fraction of 255 (255/255 is completely saturated), calculated as an exponential average over 5 minutes.
rxload	Receive load on the interface as a fraction of 255 (255/255 is completely saturated), calculated as an exponential average over 5 minutes.
encapsulation	Encapsulation method.
crc	CRC size in bits.
loopback	Indicates whether loopback is set or not.
keepalive	Indicates whether keepalives are set or not.
Last input	Number of hours, minutes, and seconds since the last packet was successfully received by an interface and processed locally on the router. Useful for knowing when a dead interface failed. This counter is updated only when packets are process switched, not when packets are fast switched.
Last ouput	Number of hours, minutes, and seconds since the last packet was successfully transmitted by an interface. Useful for knowing when a dead interface failed. This counter is updated only when packets are process-switched, not when packets are fast-switched.
output hang	Number of hours, minutes, and seconds (or never) since the interface was last reset because of a transmission that took too long. When the number of hours in any of the “last” fields exceeds 24 hours, the number of days and hours is printed. If that field overflows, asterisks are printed.
Last clearing of show interface	Time at which the counters that measure cumulative statistics (such as number of bytes transmitted and received) shown in this report were last reset to zero. Note that variables that might affect routing (for example, load and reliability) are not cleared when the counters are cleared. *** indicates the elapsed time is too large to be displayed. 0:00:00 indicates the counters were cleared more than 231 ms (and less than 232 ms) ago.

Table 8-47 T3/E3 SPA—Command Field Descriptions (continued)

Field	Description
Input queue	<i>size</i> —Current size of the input queue. <i>max</i> —Maximum size of the input queue. <i>drops</i> —Packets dropped because the queue was full. <i>flushes</i> —Number of times that data on queue has been discarded.
Total output drops	Total number of dropped packets.
Queueing strategy	First-in, first-out queueing strategy (other queueing strategies you might see are priority-list, custom-list, and weighted fair).
Output queue	<i>size</i> —Current size of the output queue. <i>max</i> —Maximum size of the output queue.
5-minute input rate	<p>Average number of bits and packets received per second in the last 5 minutes. If the interface is not in promiscuous mode, it senses network traffic it sends and receives (rather than all network traffic).</p> <p>The 5-minute input and output rates should be used only as an approximation of traffic per second during a given 5-minute period. These rates are exponentially weighted averages with a time constant of 5 minutes. A period of four time constants must pass before the average will be within two percent of the instantaneous rate of a uniform stream of traffic over that period.</p>
5-minute output rate	<p>Average number of bits and packets transmitted per second in the last 5 minutes. If the interface is not in promiscuous mode, it senses network traffic it sends and receives (rather than all network traffic).</p> <p>The 5-minute input and output rates should be used only as an approximation of traffic per second during a given 5-minute period. These rates are exponentially weighted averages with a time constant of 5 minutes. A period of four time constants must pass before the average will be within two percent of the instantaneous rate of a uniform stream of traffic over that period.</p>
rxLOS	Receive loss of signal status. Values are inactive or active.
rxLOF	Receive loss of frame status. Values are inactive or active.
rxAIS	Receive alarm indication signal status. Values are inactive or active.
txAIS	Transmit alarm indication signal status. Values are inactive or active.
rxRAI	Receive remote alarm indication signal status. Values are inactive or active.
txRAI	Transmit remote alarm indication signal status. Values are inactive or active.

Related Commands

Command	Description
show controllers serial	Displays controller statistics.

show tcam-mgr subslot

To display ternary content addressable memory (TCAM) manager information for a SPA, use the **show tcam-mgr subslot** command in privileged EXEC configuration mode.

show tcam-mgr subslot *slot/subslot* **inst-info**

show tcam-mgr subslot *slot/subslot* **region** *region-number* [**config** | **statistics**]

show tcam-mgr subslot *slot/subslot* {**rx-dest-mac** | **rx-vlan**} {**alloc-mbus** [**summary**] | **table**}

show tcam-mgr subslot *slot/subslot* **statistics**

Syntax Description		
	<i>slot</i>	Chassis slot number. Refer to the appropriate hardware manual for slot information. For MSCs, refer to the platform-specific SPA hardware installation guide or the corresponding “Identifying Slots and Subslots for MSCs and SPAs” topic in the platform-specific SPA software configuration guide.
	<i>/subslot</i>	Secondary slot number on a MSC where a SPA is installed. Refer to the platform-specific SPA hardware installation guide and the corresponding “Specifying the Interface Address on a SPA” topic in the platform-specific SPA software configuration guide for subslot information.
	inst-info	Specifies the display of Instance Control Block information for the SPA.

region <i>region-number</i> [config statistics]	<p>Specifies the display of region-related TCAM manager information, with the following options:</p> <ul style="list-style-type: none"> • region <i>region-number</i>—Displays TCAM manager information, where: <ul style="list-style-type: none"> – region 0—Specifies the destination MAC address TCAM region. – region 1—Specifies the VLAN ID TCAM region. • config—(Optional) Displays TCAM manager configuration information. • statistics—(Optional) Displays TCAM manager statistical information.
{ rx-dest-mac rx-vlan } { alloc-mbus [summary] table }	<p>Specifies the display of TCAM manager information related to the following areas:</p> <ul style="list-style-type: none"> • rx-dest-mac—Destination MAC address filtering for received frames. • rx-vlan—VLAN filtering for received frames. • alloc-mbus [summary]—Displays allocated Mask Block Unit (MBU) entry information related to the MAC or VLAN TCAM filters. There is no difference between the alloc-mbus and alloc-mbus summary form of the command. • table—Displays table entries for the MAC or VLAN TCAM filters. <p>Note The label and free-mbus [summary] forms of the command are not supported on SPAs.</p>

Defaults No default behavior or values

Command Modes Privileged EXEC

Command History	Release	Modification
	12.0(19)S	This command was introduced.
	12.2(20)S2	This command was integrated into Cisco IOS Release 12.2(20)S2 and support for the subslot , rx-dest-mac , and rx-vlan keywords were added for SPAs on the Cisco 7304 router.

Usage Guidelines Use the **show tcam-mgr subslot** command to display TCAM manager information for the destination MAC address and VLAN filter regions supported by the SPAs.

The TCAM manager allocates memory among the applications that it supports, in the form of regions. The SPAs support two TCAM regions, region 0 for destination MAC address filtering and region 1 for VLAN ID filtering of received frames.

Examples

The following examples provide sample output for several versions of the **show tcam-mgr subslot** command for a 4-Port 10/100 Fast Ethernet SPA located in the top subslot (0) of the MSC that is installed in slot 4 on a Cisco 7304 router:

- [show tcam-mgr subslot inst-info Example, page 8-162](#)
- [show tcam-mgr subslot region Example, page 8-162](#)
- [show tcam-mgr subslot region statistics Example, page 8-163](#)
- [show tcam-mgr subslot rx-dest-mac table Example, page 8-163](#)
- [show tcam-mgr subslot rx-vlan table Example, page 8-164](#)
- [show tcam-mgr subslot statistics Example, page 8-165](#)

show tcam-mgr subslot inst-info Example

The following shows sample output from the **show tcam-mgr subslot inst-info** command:

```
Router# show tcam-mgr subslot 4/0 inst-info
Instance Control Block Information :

CAM name                = SPA 4xFE/2xGE CAM2
Maximum key length      = 72 bits
TBU (TCAM Base Unit) length = 72 bits
V2M Ratio              = 8
TCAM Size               = 8192 TBUs
SRAM Size               = 0 words
Start index of first VC = 0
Label table size        = 0
```

show tcam-mgr subslot region Example

The following shows sample output from the **show tcam-mgr subslot region** command for the destination MAC address TCAM region (0) for the SPA:

```
Router# show tcam-mgr subslot 4/0 region 0

Region Configuration :

Region ID                = 0
Region name              = DA_FILTERING
Fixed size               = no
Region type (hash:mask   ) = Partial_Order_Indep_Order_Dep_At_Bottom
Application VMR V/M size = 12
Application VMR result size = 1
Vc region size (percentage) = 50

Region Information :

Region ID                = 0
Value cells size         = 4096
Mask cells size          = 512
MBUs size                = 512
Mask index start TBU     = 0
Mask index end TBU       = 511
First dynamic region     = yes
Last dynamic region      = yes
Size is fixed            = yes
Expansion unit MBUs      = 1
Lower Limit, llimit_p    = 450A6CF0
Upper Limit, ulimit_p    = 450AE4B4
Lower limit pointer index = 0
Upper limit pointer index = 511
```

```

Lower next pointer index = 0
Upper next pointer index = 4
Lower free entries       = 1
Upper free entries       = 507
Bottom pointer index     = 510
Free mask block units    = 508

```

```

Region ID                = 0
Region expansion count    = 0
Region Shifts             = 0
Region expansion failures = 0
Invalid direction hits    = 0
Invalid parameter hits    = 0
No free entry failures    = 0

```

show tcam-mgr subslot region statistics Example

The following shows sample output from the **show tcam-mgr subslot region statistics** command for the destination MAC address TCAM region (0) for the SPA:

```
Router# show tcam-mgr subslot 4/0 region 0 statistics
```

```

Region ID                = 0
Region expansion count    = 0
Region Shifts             = 0
Region expansion failures = 0
Invalid direction hits    = 0
Invalid parameter hits    = 0
No free entry failures    = 0

```

show tcam-mgr subslot rx-dest-mac table Example

The following shows partial output from the **show tcam-mgr subslot rx-dest-mac table** command:

```
Router# show tcam-mgr subslot 4/0 rx-dest-mac table
```

```
Dest mac filtering Table
```

```
-----
```

```
There are 15 entries in the table
```

```
Entry# 1:
```

```
Application ID           = 1
Value                   =
```

```

                                0 0 0 0 0 4 0 0 0 0 0 0
Mask                           =
```

```

                                0 0 0 0 0 C 0 0 0 0 0 0
Result                         =
```

```

                                0
Mask index                   = 511
Mask Physical Address        = 4088
Value cell index             = 7
Value cell Physical address  = 4095
Allocation direction         = bottom

```

```
Entry# 2:
```

```
Application ID           = 1
Value                   =
```

```

                                0 0 0 0 0 4 0 B0 64 FF 44 80
Mask                           =
```

```

                                0 0 0 0 0 F FF FF FF FF FF FF

```

show tcam-mgr subslot

```

Result                                     =

                                         4
Mask index                               = 2
Mask Physical Address                     = 16
Value cell index                         = 1
Value cell Physical address              = 17
Allocation direction                     = no direction

Entry# 3:
Application ID                           = 1
Value                                    =

                                         0 0 0 0 0 4 FF FF FF FF FF FF
Mask                                     =

                                         0 0 0 0 0 F FF FF FF FF FF FF
Result                                   =

                                         4
Mask index                               = 2
Mask Physical Address                     = 16
Value cell index                         = 2
Value cell Physical address              = 18
Allocation direction                     = no direction
.
.
.

```

show tcam-mgr subslot rx-vlan table Example

The following shows partial output from the **show tcam-mgr subslot rx-vlan table** command:

Router# **show tcam-mgr subslot 4/0 rx-vlan table**

RX VLAN filtering Table

There are 9 entries in the table

```

Entry# 1:
Application ID                           = 2
Value                                    =

                                         0 0 0 0 0 8 0 0 0 0 0 0
Mask                                     =

                                         0 0 0 0 0 C 0 0 0 0 0 0
Result                                   =

                                         0
Mask index                               = 1023
Mask Physical Address                     = 8184
Value cell index                         = 7
Value cell Physical address              = 8191
Allocation direction                     = bottom

Entry# 2:
Application ID                           = 2
Value                                    =

                                         0 0 0 0 0 0 0 0 0 0 0 0
Mask                                     =

                                         0 0 0 0 0 F 0 0 0 0 0 0

```

```

Result                                     =
                                           4
Mask index                               = 512
Mask Physical Address                     = 4096
Value cell index                         = 0
Value cell Physical address               = 4096
Allocation direction                     = top
.
.
.

```

show tcam-mgr subslot statistics Example

The following shows sample output from the **show tcam-mgr subslot statistics** command:

Router# **show tcam-mgr subslot 4/0 statistics**

```

Application entry alloc failures          = 0
TCAM entry alloc failures                 = 0
TCAM driver failures                     = 0
TCAM API invalid parameters               = 0
TCAM API application entry lookup failures = 0
TCAM API application entry mismatch failures = 0
TCAM API label table occupied failures    = 0
TCAM MGR free mbu vc failures             = 0
TCAM Mgr insertion/deletion time
  Insert time: total:0.0000 num:0         avg:0.0000
    check dupl: total:0.0000 num:0         avg:0.0000
    alloc mbu: total:0.0000 num:0          avg:0.0000
    queue appl: total:0.0000 num:0         avg:0.0000
    insert drv: total:0.0000 num:0         avg:0.0000
  Delete time: total:0.0000 num:0         avg:0.0000
    delete drv: total:0.0000 num:0        avg:0.0000
    delete mbu: total:0.0000 num:0        avg:0.0000
    delete appl: total:0.0000 num:0       avg:0.0000

Region ID                                = 0
Region name                              = DA_FILTERING
Fixed size                                = no
Region type (hash:mask)                   = Partial_Order_Indep_Order_Dep_At_Bottom
Application VMR V/M size                   = 12
Application VMR result size                = 1
Vc region size (percentage)               = 50

```

Related Commands

Command	Description
show controllers fastethernet	Displays Fast Ethernet interface information, transmission statistics and errors, and applicable MAC destination address and VLAN filtering tables.
show controllers gigabitethernet	Displays Gigabit Ethernet interface information, transmission statistics and errors, and applicable MAC destination address and VLAN filtering tables.

show upgrade file

The **show upgrade file** command is replaced by the **show upgrade fpd file** command. See the **show upgrade fpd file** command for more information.

show upgrade fpd file

To display the contents of an FPD image package file, enter the **show upgrade fpd file** command in privileged EXEC configuration mode.

show upgrade fpd file *file-url*

Syntax Description

<i>file-url</i>	Specifies the location of the FPD image package file, beginning with the location or type of storage device (examples include disk0 , slot0 , tftp , or ftp) and followed by the path to the FPD image.
-----------------	--

Defaults

No default behavior or values

Command Modes

Privileged EXEC

Command History

Release	Modification
12.2(20)S6	This command was introduced.

Usage Guidelines

This command provides information related to the FPD image package file. Most of the information in this command is useful for customer support purposes only.

In Cisco IOS Releases 12.2(20)S2 through 12.2(20)S5, the output generated by entering this command can be generated by entering the **show upgrade file** command.

Examples

The output in the following example displays information about the FPD image package file stored in the disk0: Flash card memory:

```
Router# show upgrade fpd file disk0:spa-fpd.122-20.S6.pkg
```

```
% Extracting compressed bundle spa_4fe2ge-fpd.bndl.zip ...
```

```
Content for the "spa_4fe2ge-fpd.bndl" bundle file:
```

```

          Bundle Name:4xFE/2xGE SPA FPD Bundle
          Bundle Version:0.5
    Number of Supported Cards:2
      Supported Card Type(s):SPA-4FE-7304 (0x435)
                           SPA-2GE-7304 (0x436)
    Bundle Header Format Version:4
      Bundle Header Length:128 bytes
      Bundle Data Length:4951592 bytes
      Bundle Magic Number:0xC5C0FBC0
      Bundle 32-Bit CRC:0x3B53C5C0
      Bundle Build Date:10/12/2004 (MM/DD/YYYY)
    Number of Images Bundled:1
      Bundle Name Prefix:spa_4fe2ge
```

```
Image #1:
```

show upgrade fpd file

```

Name                :Data & I/O FPGA
ID                  :1
Version             :4.17
Minimal H/W Version :0.0
Order in Bundle     :1
Header Length       :128 bytes
Data Length         :4951464 bytes
Total Length        :4951464 bytes (Data + Padding)
Magic Number        :0xC5C0FDC0
32-Bit CRC          :0x14613280
Build Date          :10/12/2004 (MM/DD/YYYY)
Image Format         :XSVF
Upgrade Path        :By Host
Upgrade Path Info    :0
Control Flag Value   :0x1
Estimated Upgrade Time:420 seconds

```

The output in the following example displays information about the FPD image package file stored at a TFTP server location:

```

Router# show upgrade fpd file tftp://mytftpserver/myfpdpgkd/spa-fpd.122-20.S6.pkg
Loading myfpdpgkd/spa-fpd.122-20.S6.pkg from 223.255.254.254 (via FastEthernet0):!

% Extracting compressed bundle spa_4fe2ge-fpd.bndl.zip
...!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!

Content for the "spa_4fe2ge-fpd.bndl" bundle file:

          Bundle Name:4xFE/2xGE SPA FPD Bundle
          Bundle Version:0.5
Number of Supported Cards:2
          Supported Card Type(s):SPA-4FE-7304 (0x435)
                                SPA-2GE-7304 (0x436)
Bundle Header Format Version:4
          Bundle Header Length:128 bytes
          Bundle Data Length:4951592 bytes
          Bundle Magic Number:0xC5C0FBC0
          Bundle 32-Bit CRC:0x3B53C5C0
          Bundle Build Date:10/12/2004 (MM/DD/YYYY)
Number of Images Bundled:1
          Bundle Name Prefix:spa_4fe2ge

Image #1:
Name                :Data & I/O FPGA
ID                  :1
Version             :4.17
Minimal H/W Version :0.0
Order in Bundle     :1
Header Length       :128 bytes
Data Length         :4951464 bytes
Total Length        :4951464 bytes (Data + Padding)
Magic Number        :0xC5C0FDC0
32-Bit CRC          :0x14613280
Build Date          :10/12/2004 (MM/DD/YYYY)
Image Format         :XSVF
Upgrade Path        :By Host
Upgrade Path Info    :0
Control Flag Value   :0x1
Estimated Upgrade Time:420 seconds

[OK - 703488 bytes]

```


Related Commands

Command	Description
upgrade hw-module subslot	Manually upgrades the current FPD image on the specified SPA.
upgrade fpd auto	Configures the router to automatically upgrade the FPD image when an FPD version incompatibility is detected.
upgrade fpd path	Specifies the location from where the FPD image package should be loaded when an automatic FPD upgrade is initiated by the router.
show hw-module subslot fpd	Displays the FPD version on each SPA in the router.
show upgrade fpd package default	Displays which FPD image package is needed for the router to properly support the SPAs.
show upgrade fpd progress	Displays the progress of the FPD upgrade while an FPD upgrade is taking place.
show upgrade fpd table	Displays various information used by the Cisco IOS software to manage the FPD image package file.

show upgrade fpd package default

To display which FPD image package is needed for the router to properly support the SPAs for the running Cisco IOS software release, enter the **show upgrade fpd package default** command in privileged EXEC configuration mode.

show upgrade fpd package default

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(20)S6	This command was introduced.

Usage Guidelines It is important to note that the output from this command is generated from the Cisco IOS image and provides information regarding the default FPD image package file that is needed for your particular Cisco IOS release. This command also lists the SPAs supported by the default FPD image package file for the running Cisco IOS image.

In Cisco IOS Releases 12.2(20)S2 through 12.2(20)S5, the output generated by entering this command can be generated by entering the **show upgrade package default** command.

Examples In the following example, the **show upgrade fpd package default** command output shows that the spa_fpd.122-20-S6.pkg FPD image package file is required if you install the SPA-4FE-7304 or the SPA-2GE-7304 on this particular router with this particular Cisco IOS release:

```
Router# show upgrade fpd package default
```

```
*****
This IOS release supports the following default FPD Image Package(s) for
automatic upgrade:
*****
```

```
SPA FPD Image Package:spa_fpd.122-20.S6.pkg
```

```
List of SPAs supported in this package:
```

No.	SPA Name	Minimal HW Ver.
1)	SPA-4FE-7304	0.0
2)	SPA-2GE-7304	0.0

Related Commands

Command	Description
upgrade hw-module subslot	Manually upgrades the current FPD image on the specified SPA.
upgrade fpd auto	Configures the router to automatically upgrade the FPD image when an FPD version incompatibility is detected.
upgrade fpd path	Specifies the location from where the FPD image package should be loaded when an automatic FPD upgrade is initiated by the router.
show hw-module subslot fpd	Displays the FPD version on each SPA in the router.
show upgrade fpd file	Displays the contents of an FPD image package file.
show upgrade fpd progress	Displays the progress of the FPD upgrade while an FPD upgrade is taking place.
show upgrade fpd table	Displays various information used by the Cisco IOS software to manage the FPD image package file.

show upgrade fpd progress

To view the progress of an FPD upgrade while an FPD upgrade is taking place, enter the **show upgrade fpd progress** command in privileged EXEC configuration mode.

show upgrade fpd progress

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values

Command Modes Privileged EXEC

Release	Modification
12.2(20)S6	This command was introduced.

Usage Guidelines In Cisco IOS Releases 12.2(20)S2 through 12.2(20)S5, the output generated by entering this command can be generated by entering the **show upgrade progress** command.

Examples The following example shows the type of information this command displays:

```
Router# show upgrade fpd progress
```

FPD Image Upgrade Progress Table:

```

=====
Slot Card Description      Field Programmable      Time
                             Device : "ID-Name"      Needed   Time Left   State
=====
 2/0 SPA-2GE-7304          1-4FE/2GE FPGA         00:06:00  00:05:17  Updating...
-----
 2/1 SPA-4FE-7304          1-4FE/2GE FPGA         --:--:--  --:--:--  Waiting...
=====

```

Command	Description
upgrade hw-module subslot	Manually upgrades the current FPD image on the specified SPA.
upgrade fpd auto	Configures the router to automatically upgrade the FPD image when an FPD version incompatibility is detected.
upgrade fpd path	Specifies the location from where the FPD image package should be loaded when an automatic FPD upgrade is initiated by the router.
show hw-module subslot fpd	Displays the FPD version on each SPA in the router.
show upgrade fpd file	Displays the contents of an FPD image package file.

Command	Description
show upgrade fpd package default	Displays which FPD image package is needed for the router to properly support the SPAs.
show upgrade fpd table	Displays various information used by the Cisco IOS software to manage the FPD image package file.

show upgrade fpd table

To view various information used by the Cisco IOS software to manage the FPD image package file, enter the **show upgrade fpd table** command in privileged EXEC configuration mode.

show upgrade fpd table

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(20)S6	This command was introduced.

Usage Guidelines This command provides version information used by the Cisco IOS image to manage the FPD image package file and to locate the correct FPD image within the FPD image package file to perform an FPD upgrade. Most of the information provided by this command is useful for customer support purposes.

In Cisco IOS Releases 12.2(20)S2 through 12.2(20)S5, the output generated by entering this command can be generated by entering the **show upgrade table** command.

Examples The following example displays various FPD information for Cisco IOS Release 12.2(20)S6:

```
Router# show upgrade fpd table
```

```
Field Programmable Devices (FPD) Bundle Information Table:
=====
```

Table Entry #1:

```
Bundle Card Type:SPA-4FE-7304 (0x435)
Platform Family:0x0
Bundle Name Prefix:spa_4fe2ge
Bundle Version:0.5
Minimal H/W Version:0.0
FPD Image Count:1
FPD Image Required:
```

FPD ID	FPD Name	Min. Required Version
1	Data & I/O FPGA	4.17

Table Entry #2:

```

Bundle Card Type:SPA-2GE-7304 (0x436)
Platform Family:0x0
Bundle Name Prefix:spa_4fe2ge
Bundle Version:0.5
Minimal H/W Version:0.0
FPD Image Count:1
FPD Image Required:

```

FPD ID	FPD Name	Min. Required Version
1	Data & I/O FPGA	4.17

Related Commands

Command	Description
upgrade hw-module subslot	Manually upgrades the current FPD image on the specified SPA.
upgrade fpd auto	Configures the router to automatically upgrade the FPD image when an FPD version incompatibility is detected.
upgrade fpd path	Specifies the location from where the FPD image package should be loaded when an automatic FPD upgrade is initiated by the router.
show hw-module subslot fpd	Displays the FPD version on each SPA in the router.
show upgrade fpd file	Displays the contents of an FPD image package file.
show upgrade fpd package default	Displays which FPD image package is needed for the router to properly support the SPAs.
show upgrade fpd progress	Displays the progress of the FPD upgrade while an FPD upgrade is taking place.

show upgrade package default

The **show upgrade package default** command is replaced by the **show upgrade fpd package default** command. See the **show upgrade fpd package default** command for more information.

show upgrade progress

The **show upgrade progress** command is replaced by the **show upgrade fpd progress** command. See the **show upgrade fpd progress** command for more information.

show upgrade table

The **show upgrade table** command is replaced by the **show upgrade fpd table** command. See the **show upgrade fpd table** command for more information.

speed

To configure the speed for a Fast Ethernet or Gigabit Ethernet interface, use the **speed** command in interface configuration mode. To return to the default setting, use the **no** form of this command.

speed { **10** | **100** | **1000** | **auto** }

no speed

Syntax Description	10	Configures the interface to transmit at 10 Mbps.
	100	Configures the interface to transmit at 100 Mbps.
	1000	Configures the interface to transmit at 1000 Mbps. This keyword is valid only for interfaces that support Gigabit Ethernet.
	auto	Enables Fast Ethernet autonegotiation. The interface automatically operates at 10 Mbps or 100 Mbps depending on environmental factors, such as the type of media and transmission speeds for the peer routers, hubs, and switches used in the network configuration. Autonegotiation is the default.

Defaults	auto
----------	-------------

Command Modes	Interface configuration
---------------	-------------------------

Command History	Release	Modification
	11.2(10)P	This command was introduced.
	12.1(7)E	The 1000 keyword was added for Gigabit Ethernet interfaces.
	12.2 S	This command was integrated into Cisco IOS Release 12.2 S.
	12.2(20)S2	This command was implemented on the 4-Port 10/100 Fast Ethernet SPA and the 2-Port 10/100/1000 Gigabit Ethernet SPA on the Cisco 7304 router.

Usage Guidelines	The speed command applies to SPA interfaces that are using RJ-45 media. Gigabit Ethernet interfaces using fiber media support 1000-Mbps speed only, and use the negotiation command to enable and disable autonegotiation.
------------------	--

To enable the autonegotiation capability on an RJ-45 interface, you must set either the **speed** command or the **duplex** command to **auto**. The default configuration is that both commands are set to **auto**.

Table 8-48 describes the interface behavior for different combinations of the **duplex** and **speed** command settings. The specified **duplex** command configured with the specified **speed** command produces the resulting system action.

If you specify both a **duplex** and **speed** setting other than **auto** on an RJ-45 interface, then autonegotiation is disabled for the interface.

**Note**

If you need to force an interface port to operate with certain settings and therefore disable autonegotiation, you must be sure that the remote link is configured for compatible link settings for proper transmission. This includes support of flow control on the link.

**Note**

Every interface on a 4-Port 10/100 Fast Ethernet SPA and 2-Port 10/100/1000 Gigabit Ethernet SPA supports transmission of pause frames to stop packet flow when the MSC is full. You cannot disable flow control for an interface on the 4-Port 10/100 Fast Ethernet SPA or 2-Port 10/100/1000 Gigabit Ethernet SPA. Therefore, flow control support is not configurable, but it is advertised during autonegotiation.

If you disable autonegotiation, then you must be sure that the remote device is configured to support flow control because flow control is automatically enabled for all interfaces on the 4-Port 10/100 Fast Ethernet SPA and the 2-Port 10/100/1000 Gigabit Ethernet SPA.

Table 8-48 *Relationship Between duplex and speed Commands*

duplex Command	speed Command	Resulting System Action
duplex auto	speed auto	Autonegotiates both speed and duplex mode. The interface advertises capability for the following link settings: <ul style="list-style-type: none"> • 10 Mbps and half duplex • 10 Mbps and full duplex • 100 Mbps and half duplex • 100 Mbps and full duplex • 1000 Mbps and half duplex (Gigabit Ethernet only) • 1000 Mbps and full duplex (Gigabit Ethernet only)
duplex auto	speed 10 or speed 100 or speed 1000	Autonegotiates the duplex mode. The interface advertises capability for the configured speed with capability for both half-duplex or full-duplex mode. For example, if the speed 100 command is configured with duplex auto , then the interface advertises the following capability: <ul style="list-style-type: none"> • 100 Mbps and half duplex • 100 Mbps and full duplex

Table 8-48 Relationship Between duplex and speed Commands (continued)

duplex Command	speed Command	Resulting System Action
duplex half or duplex full	speed auto	Autonegotiates the speed. The interface advertises capability for the configured duplex mode with capability for both 10-Mbps or 100-Mbps operation for Fast Ethernet interfaces, and 10-Mbps, 100-Mbps, and 1000-Mbps for Gigabit Ethernet interfaces. For example, if the duplex full command is configured with the speed auto command, then the interface advertises the following capability: <ul style="list-style-type: none"> • 10 Mbps and full duplex • 100 Mbps and full duplex • 1000 Mbps and full duplex (Gigabit Ethernet interfaces only)
duplex half	speed 10	Forces 10-Mbps and half-duplex operation, and disables autonegotiation on the interface.
duplex full	speed 10	Forces 10-Mbps and full-duplex operation, and disables autonegotiation on the interface.
duplex half	speed 100	Forces 100-Mbps and half-duplex operation, and disables autonegotiation on the interface.
duplex full	speed 100	Forces 100-Mbps and full-duplex operation, and disables autonegotiation on the interface.
duplex half	speed 1000	Forces 1000-Mbps and half-duplex operation, and disables autonegotiation on the interface (Gigabit Ethernet only).
duplex full	speed 1000	Forces 1000-Mbps and full-duplex operation, and disables autonegotiation on the interface (Gigabit Ethernet only).

Examples

The following example specifies advertisement of 10 Mbps operation only, and either full-duplex or half-duplex capability during autonegotiation for the second interface (port 1) on the SPA located in the bottom subslot (1) of the MSC that is installed in slot 2 of the Cisco 7304 router:

```
Router# configure terminal
Router(config)# interface fastethernet 2/1/1
Router(config-if)# speed 10
Router(config-if)# duplex auto
```

With this configuration, the interface advertises the following capabilities during autonegotiation:

- 10 Mbps and half duplex
- 10 Mbps and full duplex

**Note**

Flow control support is always advertised when autonegotiation is enabled.

Related Commands	Command	Description
	duplex	Configures the duplex operation on an interface.
	interface fastethernet	Selects a particular Fast Ethernet interface for configuration.
	interface gigabitethernet	Selects a particular Gigabit Ethernet interface for configuration.
	show controllers fastethernet	Displays Fast Ethernet interface information, transmission statistics and errors, and applicable MAC destination address and VLAN filtering tables.
	show controllers gigabitethernet	Displays Gigabit Ethernet interface information, transmission statistics and errors, and applicable MAC destination address and VLAN filtering tables.
	show interfaces fastethernet	Displays information about the Fast Ethernet interfaces.
	show interfaces gigabitethernet	Displays information about the Gigabit Ethernet interfaces.

t1 framing

To specify the type of framing used by T1 channels, use the **t1 framing** command in controller configuration mode.

Cisco 7500 Series Routers with Channelized T3 Interface Processor

t1 channel framing {**esf** | **sf**}

Channelized T3/E3 Shared Port Adapters

t1 channel framing {**esf** | **sf** [**hdlc-idle** {**0x7e** | **0xff**}] [**mode** {**j1**}]}

no t1 channel framing {**esf** | **sf** [**hdlc-idle** {**0x7e** | **0xff**}] [**mode** {**j1**}]}

Syntax Description

<i>channel</i>	Number indicating the T1 channel. <ul style="list-style-type: none"> On the CT3IP—1 to 28 On the CT3 SPA—0 to 23
esf	Specifies that Extended Super Frame (ESF) is used as the T1 framing type. This is the default for the CT3IP.
sf	Specifies that Super Frame (SF) is used as the T1 framing type. This is the default for the T3/E3 SPA.
hdlc-idle { 0x7e 0xff }	(Optional) Sets the idle pattern for the T1 interface to either 0x7e (the default) or 0xff .
mode { j1 }	(Optional) Specifies the JT-G704 Japanese frame type.

Defaults

esf (for C3TIP)
sf (for T3/E3 SPA)

Command Modes

Controller configuration

Command History

Release	Modification
11.3	This command was introduced.
12.0(14)S	This command was integrated into Cisco IOS Release 12.0(14)S. The hdlc-idle keyword option was added.
12.2S	This command was integrated into Cisco IOS Release 12.2S.
12.2(18)SXE	This command was integrated into Cisco IOS Release 12.2(18)SXE to support SPAs on the Cisco 7304 router. The mode keyword option was added.
12.0(31)S	This command was integrated into Cisco IOS Release 12.0(31)S.
12.2(25)S3	This command was integrated into Cisco IOS Release 12.2(25)S3.

Usage Guidelines

If you do not specify the **t1 framing** command, the default ESF is used.

**Note**

T1 channels on the CT3IP are numbered 1 to 28 rather than the more traditional zero-based scheme (0 to 27) used with other Cisco products. This numbering scheme ensures consistency with telco numbering schemes for T1 channels within channelized T3 equipment.

To return to the default mode, use the **no** form of this command. This command does not have a **no** form on the Cisco 7500 series router with the CT3IP.

Examples

The following example shows how to set the framing for the T1 6 and T1 8 on the CT3IP to Super Frame:

```
Router(config)# controller t3 9/0/0  
Router(config-controller)# t1 6 framing sf  
Router(config-controller)# t1 8 framing sf
```

Related Commands

Command	Description
controller	Configures a T1, E1, or T3 controller and enters controller configuration mode.
show controller	Displays controller configuration.

test hw-module subslot c2w

To test the Cisco 2 wire (c2w) device on a SPA, use the **test hw-module subslot c2w** command in privileged EXEC configuration mode.

```
test hw-module subslot slot/subslot c2w {read device-address port subaddress bytes | write
device-address port subaddress bytes}
```

Syntax Description		
<i>slot</i>		Chassis slot number. Refer to the appropriate hardware manual for slot information. For MSCs, refer to the platform-specific SPA hardware installation guide or the corresponding “Identifying Slots and Subslots for MSCs and SPAs” topic in the platform-specific SPA software configuration guide.
<i>/subslot</i>		Secondary slot number on a MSC where a SPA is installed. Refer to the platform-specific SPA hardware installation guide and the corresponding “Specifying the Interface Address on a SPA” topic in the platform-specific SPA software configuration guide for subslot information.
read		Reads from the specified c2w device.
write		Writes to the specified c2w device.
<i>device-address</i>		Specifies the hexadecimal address (0–FF) of the c2w device.
<i>port</i>		Specifies the hexadecimal address (0–FF) of the c2w port.
<i>subaddress</i>		Specifies the hexadecimal subaddress (0–FF) of the c2w device.
<i>bytes</i>		Specifies the number of bytes (1–8) to read or write.

Defaults No default behavior or values

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(20)S2	This command was introduced.

Usage Guidelines The **test hw-module subslot c2w** command is implemented on the 4-Port 10/100 Fast Ethernet SPA and the 2-Port 10/100/1000 Gigabit Ethernet SPA on the Cisco 7304 router.



Caution

The **test hw-module subslot c2w** command is not intended for production use and should be used only under the supervision of Cisco Systems technical support personnel. This command can produce unexpected operation of your SPA.

This command does not have a **no** form.

When you run any of the **test hw-module subslot** commands on a SPA, you will be warned that the command is not intended for use on a production network and that the command should be reserved for use only with Cisco Systems technical support personnel.

Because the **test hw-module subslot** commands can produce unexpected operation of your SPA, the system issues a confirmation prompt that defaults to “N” to deny execution of the command. The command is not executed if you press **Enter** or type “n.”

To run the command, type “y” at the confirmation prompt.

To restore the default SPA configuration and remove any changes to the SPA settings that you made using a **test hw-module subslot c2w** command, perform the following steps:

1. Use the **hw-module subslot stop** command to deactivate the SPA and all of its interfaces.
2. Use the **hw-module subslot start** command to reactivate the SPA and all of its interfaces.

Examples

The following output provides an example of the **test hw-module subslot c2w** command and the warning statement and confirmation prompt that appears with it:

```
Router# test hw-module subslot 4/0 c2w read 00 00 00 1
This command is not intended for production use
and should be used only under the supervision of
Cisco Systems technical support personnel.
```

```
This command can produce unexpected operation of your SPA.
Are you sure you want to continue? [N]n
```

test hw-module subslot failed

To send a failed event on a SPA, use the **test hw-module subslot failed** command in privileged EXEC configuration mode.

test hw-module subslot *slot/subslot* **failed** *failure-code*

Syntax Description	<i>slot</i>	Chassis slot number. Refer to the appropriate hardware manual for slot information. For MSCs, refer to the platform-specific SPA hardware installation guide or the corresponding “Identifying Slots and Subslots for MSCs and SPAs” topic in the platform-specific SPA software configuration guide.
	<i>/subslot</i>	Secondary slot number on a MSC where a SPA is installed. Refer to the platform-specific SPA hardware installation guide and the corresponding “Specifying the Interface Address on a SPA” topic in the platform-specific SPA software configuration guide for subslot information.
	failed <i>failure-code</i>	Tests the specified failure code in the hexadecimal range 0–FFFFFFFF.

Defaults	No default behavior or values
----------	-------------------------------

Command Modes	Privileged EXEC
---------------	-----------------

Command History	Release	Modification
	12.2(20)S2	This command was introduced.

Usage Guidelines	The test hw-module subslot failed command is implemented on the 4-Port 10/100 Fast Ethernet SPA and the 2-Port 10/100/1000 Gigabit Ethernet SPA on the Cisco 7304 router.
------------------	--

**Caution**

The **test hw-module subslot failed** command is not intended for production use and should be used only under the supervision of Cisco Systems technical support personnel. This command can produce unexpected operation of your SPA.

This command does not have a **no** form.

When you run any of the **test hw-module subslot** commands on a SPA, you will be warned that the command is not intended for use on a production network and that the command should be reserved for use only with Cisco Systems technical support personnel.

Because the **test hw-module subslot** commands can produce unexpected operation of your SPA, the system issues a confirmation prompt that defaults to “N” to deny execution of the command. The command is not executed if you press **Enter** or type “n.”

To run the command, type “y” at the confirmation prompt.

To restore the default SPA configuration and remove any changes to the SPA settings that you made using a **test hw-module subslot failed** command, perform the following steps:

1. Use the **hw-module subslot stop** command to deactivate the SPA and all of its interfaces.
2. Use the **hw-module subslot start** command to reactivate the SPA and all of its interfaces.

Examples

The following output provides an example of the **test hw-module subslot failed** command and the warning statement and confirmation prompt that appears with it:

```
Router# test hw-module subslot 4/0 failed 00000000
This command is not intended for production use
and should be used only under the supervision of
Cisco Systems technical support personnel.
```

```
This command can produce unexpected operation of your SPA.
Are you sure you want to continue? [N]n
```

test hw-module subslot mac

To test the Media Access Control (MAC) device on a SPA, use the **test hw-module subslot mac** command in privileged EXEC configuration mode.

```
test hw-module subslot slot/subslot mac config port {1000mbps-gmii | 1000mbps-rgmii |
100mbps | 10mbps} {full | half} {copper | fiber}
```

```
test hw-module subslot slot/subslot mac crc port {enable | disable}
```

```
test hw-module subslot slot/subslot mac loopback port {line | none | spi3}
```

Syntax Description

<i>slot</i>	Chassis slot number. Refer to the appropriate hardware manual for slot information. For MSCs, refer to the platform-specific SPA hardware installation guide or the corresponding “Identifying Slots and Subslots for MSCs and SPAs” topic in the platform-specific SPA software configuration guide.
<i>/subslot</i>	Secondary slot number on a MSC where a SPA is installed. Refer to the platform-specific SPA hardware installation guide and the corresponding “Specifying the Interface Address on a SPA” topic in the platform-specific SPA software configuration guide for subslot information.
config port	Tests a configuration value on the MAC device, where <i>port</i> is the number of the interface that you want to select on the SPA: <ul style="list-style-type: none"> On the 4-Port 10/100 Fast Ethernet SPA—0, 1, 2, or 3 On the 2-Port 10/100/1000 Gigabit Ethernet SPA—0 or 1
{ 1000mbps-gmii 1000mbps-rgmii 100mbps 10mbps }	Specifies a speed value to test on the MAC device of the selected interface on the SPA, where: <ul style="list-style-type: none"> 1000mbps-gmii—Specifies 1000-Mbps speed using the Gigabit Media Independent Interface (GMII). This option is only available for the Gigabit Ethernet SPAs. 1000mbps-rgmii—Specifies 1000-Mbps speed using the Reduced Gigabit Media Independent Interface (RGMII). This option is only available for Gigabit Ethernet SPAs. 100mbps—Specifies 100-Mbps speed. 10mbps—Specifies 10-Mbps speed.
{ full half }	Specifies the duplex mode to test on the MAC device of the selected interface on the SPA.
{ copper fiber }	Specifies the media type to test on the MAC device of the selected interface on the SPA, where: <ul style="list-style-type: none"> copper—Specifies the copper media type, which is used by the RJ-45 interface connector. fiber—Specifies a fiber media type, which is used by the Gigabit Interface Converter (GBIC) interface connector.

crc <i>port</i> { enable disable }	<p>Enables or disables appending of a cyclic redundancy check (CRC) on frames for the MAC device, where <i>port</i> is the number of the interface that you want to select on the SPA:</p> <ul style="list-style-type: none"> On the 4-Port 10/100 Fast Ethernet SPA—0, 1, 2, or 3 On the 2-Port 10/100/1000 Gigabit Ethernet SPA—0 or 1
loopback <i>port</i> { line none spi3 }	<p>Specifies a loopback option on the MAC device of the selected interface, where:</p> <ul style="list-style-type: none"> <i>port</i>—Number of the interface that you want to select on the SPA: <ul style="list-style-type: none"> On the 4-Port 10/100 Fast Ethernet SPA—0, 1, 2, or 3 On the 2-Port 10/100/1000 Gigabit Ethernet SPA—0 or 1 line—Specifies a loopback at the MAC device toward the line on the selected interface. none—Disables loopback at the MAC device on the selected interface. spi3—Specifies a loopback at the MAC device on the System Packet Interface Level 3 (SPI3) path between the MAC device and field-programmable gate array (FPGA) device. This is sometimes referred to as an internal loopback.

Defaults

No default behavior or values

Command Modes

Privileged EXEC

Command History

Release	Modification
12.2(20)S2	This command was introduced.

Usage Guidelines

The **test hw-module subslot mac** command is implemented on the 4-Port 10/100 Fast Ethernet SPA and the 2-Port 10/100/1000 Gigabit Ethernet SPA on the Cisco 7304 router.



Caution

The **test hw-module subslot mac** command is not intended for production use and should be used only under the supervision of Cisco Systems technical support personnel. This command can produce unexpected operation of your SPA.

This command does not have a **no** form.

When you run any of the **test hw-module subslot** commands on a SPA, you will be warned that the command is not intended for use on a production network and that the command should be reserved for use only with Cisco Systems technical support personnel.

Because the **test hw-module subslot** commands can produce unexpected operation of your SPA, the system issues a confirmation prompt that defaults to “N” to deny execution of the command. The command is not executed if you press **Enter** or type “n.”

To run the command, type “y” at the confirmation prompt.

To restore the default SPA configuration on an interface and remove any changes to the SPA settings that you made using a **test hw-module subslot mac** command, perform the following steps:

1. Use the **shutdown** command to disable the affected interface.
2. Use the **no shutdown** command to reenab the interface.

Examples

The following output provides an example of the **test hw-module subslot mac** command and the warning statement and confirmation prompt that appears with it:

```
Router# test hw-module subslot 4/0 mac config 0 10mbps full copper
This command is not intended for production use
and should be used only under the supervision of
Cisco Systems technical support personnel.
```

```
This command can produce unexpected operation of your SPA.
Are you sure you want to continue? [N]n
```

Related Commands

Command	Description
show controllers fastethernet	Displays Fast Ethernet interface information, transmission statistics and errors, and applicable MAC destination address and VLAN filtering tables.
show controllers gigabitethernet	Displays Gigabit Ethernet interface information, transmission statistics and errors, and applicable MAC destination address and VLAN filtering tables.
show hw-module subslot	Displays diagnostic information about internal hardware devices for SPAs.
show interfaces fastethernet	Displays the status and configuration settings for the Fast Ethernet interfaces.
show interfaces gigabitethernet	Displays the status and configuration settings for Gigabit Ethernet interfaces.

test hw-module subslot mdio

To read or write to the PHY device registers through the MAC MII data input/output (MDIO) interface on a SPA, use the **test hw-module subslot mdio** command in privileged EXEC configuration mode.

```
test hw-module subslot slot/subslot mdio {read phy-number phy-register-address | write
phy-number phy-register-address}
```


Syntax Description	slot	Chassis slot number. Refer to the appropriate hardware manual for slot information. For MSCs, refer to the platform-specific SPA hardware installation guide or the corresponding “Identifying Slots and Subslots for MSCs and SPAs” topic in the platform-specific SPA software configuration guide.
	lsubslot	Secondary slot number on a MSC where a SPA is installed. Refer to the platform-specific SPA hardware installation guide and the corresponding “Specifying the Interface Address on a SPA” topic in the platform-specific SPA software configuration guide for subslot information.
	read	Reads from the specified PHY device.
	write	Writes to the specified PHY device.
	phy-number	Number of the interface PHY device that you want to select on the SPA: <ul style="list-style-type: none"> On the 4-Port 10/100 Fast Ethernet SPA—0, 1, 2, or 3 On the 2-Port 10/100/1000 Gigabit Ethernet SPA—0 or 1
	phy-register-address	Address of the register (0–31) on the selected PHY device.

Defaults No default behavior or values

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(20)S2	This command was introduced.

Usage Guidelines The **test hw-module subslot mdio** command is implemented on the 4-Port 10/100 Fast Ethernet SPA and the 2-Port 10/100/1000 Gigabit Ethernet SPA on the Cisco 7304 router.



Caution

The **test hw-module subslot mdio** command is not intended for production use and should be used only under the supervision of Cisco Systems technical support personnel. This command can produce unexpected operation of your SPA.

This command does not have a **no** form.

When you run any of the **test hw-module subslot** commands on a SPA, you will be warned that the command is not intended for use on a production network and that the command should be reserved for use only with Cisco Systems technical support personnel.

Because the **test hw-module subslot** commands can produce unexpected operation of your SPA, the system issues a confirmation prompt that defaults to “N” to deny execution of the command. The command is not executed if you press **Enter** or type “n.”

To run the command, type “y” at the confirmation prompt.

To restore some of the default register values on a SPA interface that you made using a **test hw-module subslot mdio** command, perform the following steps:

1. Use the **shutdown** command to disable the affected interface.
2. Use the **no shutdown** command to reenable the interface.

To restore the default SPA configuration and remove any changes to the SPA settings that you made using a **test hw-module subslot mdio** command, perform the following steps:

1. Use the **hw-module subslot stop** command to deactivate the SPA and all of its interfaces.
2. Use the **hw-module subslot start** command to reactivate the SPA and all of its interfaces.

Examples

The following output provides an example of the **test hw-module subslot mdio** command and the warning statement and confirmation prompt that appears with it:

```
Router# test hw-module subslot 4/0 mdio read 0 31
This command is not intended for production use
and should be used only under the supervision of
Cisco Systems technical support personnel.
```

```
This command can produce unexpected operation of your SPA.
Are you sure you want to continue? [N]n
```

Related Commands

Command	Description
show hw-module subslot	Displays diagnostic information about internal hardware devices for SPAs.
show interfaces fastethernet detail	Displays low-level diagnostic information for the Fast Ethernet interfaces.
show interfaces gigabitethernet detail	Displays low-level diagnostic information for the Gigabit Ethernet interfaces.

test hw-module subslot pause

To enable, disable, and set the pause frame-related configuration on a SPA, use the **test hw-module subslot pause** command in privileged EXEC configuration mode.

```
test hw-module subslot slot/subslot pause port { disable | enable | set { threshold { fpga
fpga-pause-threshold-value | mac mac-pause-threshold-value } timer pause-timer-value } }
```

Syntax Description		
<i>slot</i>		Chassis slot number. Refer to the appropriate hardware manual for slot information. For MSCs, refer to the platform-specific SPA hardware installation guide or the corresponding “Identifying Slots and Subslots for MSCs and SPAs” topic in the platform-specific SPA software configuration guide.
<i>/subslot</i>		Secondary slot number on a MSC where a SPA is installed. Refer to the platform-specific SPA hardware installation guide and the corresponding “Specifying the Interface Address on a SPA” topic in the platform-specific SPA software configuration guide for subslot information.
pause port		Specifies pause frame-related configuration on the router, where <i>port</i> is the number of the interface that you want to select on the SPA: <ul style="list-style-type: none"> On the 4-Port 10/100 Fast Ethernet SPA—0, 1, 2, or 3 On the 2-Port 10/100/1000 Gigabit Ethernet SPA—0 or 1
disable		Disables pause frame flow control.
enable		Enables pause frame flow control.
set threshold		Specifies that a threshold register (either FPGA or MAC, as specified in the command line) will be set.
fpga <i>fpga-pause-threshold-value</i>		Configures the pause threshold register value in the SPA FPGA. The <i>fpga-pause-threshold</i> is expressed in usecs.
mac <i>mac-pause-threshold-value</i>		Configures the pause threshold register in the MAC. The <i>mac-pause-threshold-value</i> is expressed in bit times.
timer <i>pause-timer-value</i>		Configures the MAC pause timer value. The <i>pause-timer-value</i> is expressed in bit times.

Defaults No default behavior or values

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(20)S5	This command was introduced.

Usage Guidelines

Issuing this command could result in unexpected behaviors. It should not be used by end users.

Examples

The following output shows how to enable pause frame flow control and the warning statement and confirmation prompt that appears with it:

```
Router# test hw-module subslot 4/1 pause 1 enable
WARNING: This command is not intended for production use
and should be used only under the supervision of
Cisco Systems technical support personnel.
```

This command can produce unexpected operation of the SPA.
Are you sure you want to continue? [N]n

The following output shows how to set the pause threshold register value in the SPA FPGA and the warning statement and confirmation prompt that appears with it:

```
Router# test hw-module subslot 4/1 pause 1 set threshold fpga 4000
WARNING: This command is not intended for production use
and should be used only under the supervision of
Cisco Systems technical support personnel.
```

This command can produce unexpected operation of the SPA.
Are you sure you want to continue? [N]n

Related Commands

Command	Description
show hw-module subslot	Displays diagnostic information about internal hardware devices for SPAs.

test hw-module subslot phy

To test the physical interface (PHY) device on a SPA, use the **test hw-module subslot phy** command in privileged EXEC configuration mode.

```
test hw-module subslot slot/subslot phy config port {copper | fiber} {1000mbps | 100mbps | 10mbps | auto} {auto | full | half} {autoneg | force}
```

```
test hw-module subslot slot/subslot phy crossover port {auto | mdi | mdix}
```

```
test hw-module subslot slot/subslot phy loopback port {internal | line | none}
```

Syntax Description		
<i>slot</i>	Chassis slot number.	
	Refer to the appropriate hardware manual for slot information. For MSCs, refer to the platform-specific SPA hardware installation guide or the corresponding “Identifying Slots and Subslots for MSCs and SPAs” topic in the platform-specific SPA software configuration guide.	
<i>/subslot</i>	Secondary slot number on a MSC where a SPA is installed.	
	Refer to the platform-specific SPA hardware installation guide and the corresponding “Specifying the Interface Address on a SPA” topic in the platform-specific SPA software configuration guide for subslot information.	
config <i>port</i>	Tests a configuration value on the PHY device, where <i>port</i> is the number of the interface that you want to select on the SPA:	
	<ul style="list-style-type: none"> On the 4-Port 10/100 Fast Ethernet SPA—0, 1, 2, or 3 On the 2-Port 10/100/1000 Gigabit Ethernet SPA—0 or 1 	
{copper fiber}	Specifies the media type to test on the PHY device of the selected interface on the SPA, where:	
	<ul style="list-style-type: none"> copper—Specifies the copper media type, which is used by the RJ-45 interface connector. fiber—Specifies a fiber media type, which is used by the Gigabit Interface Converter (GBIC) interface connector. 	
{1000mbps 100mbps 10mbps auto}	Specifies a speed value to test on the PHY device of the selected interface on the SPA, where:	
	<ul style="list-style-type: none"> 1000mbps—Advertises 1000-Mbps speed only during autonegotiation when used with the autoneg keyword, or configures 1000 Mbps speed when used with the force keyword. This option is only supported for Gigabit Ethernet interfaces. 100mbps—Advertises 100-Mbps speed only during autonegotiation when used with the autoneg keyword, or configures 100 Mbps speed when used with the force keyword. 10mbps—Advertises 10-Mbps speed only during autonegotiation when used with the autoneg keyword, or configures 10 Mbps speed when used with the force keyword. auto—Advertises all of the supported speeds for autonegotiation for the selected interface when used with the autoneg keyword. 	

{ auto full half }	<p>Specifies the duplex mode to test on the PHY device of the selected interface on the SPA, where:</p> <ul style="list-style-type: none"> • auto—Advertises both the full- and half-duplex modes during autonegotiation when used with the autoneg keyword. • full—Advertises full-duplex mode only during autonegotiation when used with the autoneg keyword, or configures full-duplex mode when used with the force keyword. • half—Advertises half-duplex mode only during autonegotiation when used with the autoneg keyword, or configures half-duplex mode when used with the force keyword.
{ autoneg force }	<p>Specifies that the PHY device of the selected interface on the SPA is enabled overall for autonegotiation of transmission characteristics, or whether these values are forced to a particular value, where:</p> <ul style="list-style-type: none"> • autoneg—Advertises the configured speed and duplex values. • force—Disables autonegotiation. Configures the PHY device for the specified speed and duplex values.
crossover port { auto mdi mdix }	<p>Specifies the type of cable to test on the PHY device of the selected interface on the SPA, where:</p> <ul style="list-style-type: none"> • port—Number of the interface that you want to select on the SPA: <ul style="list-style-type: none"> – On the 4-Port 10/100 Fast Ethernet SPA—0, 1, 2, or 3 – On the 2-Port 10/100/1000 Gigabit Ethernet SPA—0 or 1 • auto—Specifies that the PHY device automatically detects the type of cable on the specified interface. • mdi—Specifies that the PHY device on the specified interface is configured for a media dependent interface (MDI) cable (a straight-through cable). • mdix—Specifies that the PHY device on the specified interface is configured for media dependent interface crossover (MDI-X) cable.
loopback port { internal line none }	<p>Specifies a loopback option on the PHY device of the selected interface on the SPA, where:</p> <ul style="list-style-type: none"> • port—Number of the interface that you want to select on the SPA: <ul style="list-style-type: none"> – On the 4-Port 10/100 Fast Ethernet SPA—0, 1, 2, or 3 – On the 2-Port 10/100/1000 Gigabit Ethernet SPA—0 or 1 • internal—Specifies internal loopback on the PHY device toward the MAC device on the SPA. • line—Specifies a loopback at the PHY device toward the line on the selected interface. • none—Disables loopback at the PHY device on the selected interface.

Defaults

No default behavior or values

Command Modes

Privileged EXEC

Command History

Release	Modification
12.2(20)S2	This command was introduced.

Usage Guidelines

The **test hw-module subslot phy** command is implemented on the 4-Port 10/100 Fast Ethernet SPA and the 2-Port 10/100/1000 Gigabit Ethernet SPA on the Cisco 7304 router.

**Caution**

The **test hw-module subslot phy** command is not intended for production use and should be used only under the supervision of Cisco Systems technical support personnel. This command can produce unexpected operation of your SPA.

This command does not have a **no** form.

When you run any of the **test hw-module subslot** commands on a SPA, you will be warned that the command is not intended for use on a production network and that the command should be reserved for use only with Cisco Systems technical support personnel.

Because the **test hw-module subslot** commands can produce unexpected operation of your SPA, the system issues a confirmation prompt that defaults to “N” to deny execution of the command. The command is not executed if you press **Enter** or type “n.”

To run the command, type “y” at the confirmation prompt.

To restore some of the default values on a SPA interface that you made using a **test hw-module subslot phy** command, perform the following steps:

1. Use the **shutdown** command to disable the affected interface.
2. Use the **no shutdown** command to reenable the interface.

To restore the default SPA configuration and remove any changes to the SPA settings that you made using a **test hw-module subslot phy** command, perform the following steps:

1. Use the **hw-module subslot stop** command to deactivate the SPA and all of its interfaces.
2. Use the **hw-module subslot start** command to reactivate the SPA and all of its interfaces.

Examples

The following output provides an example of the **test hw-module subslot phy** command and the warning statement and confirmation prompt that appears with it:

```
Router# test hw-module subslot 4/0 phy crossover 0 mdix
This command is not intended for production use
and should be used only under the supervision of
Cisco Systems technical support personnel.
```

```
This command can produce unexpected operation of your SPA.
Are you sure you want to continue? [N]n
```

Related Commands

Command	Description
show controllers fastethernet	Displays Fast Ethernet interface information, transmission statistics and errors, and applicable MAC destination address and VLAN filtering tables.
show controllers gigabitethernet	Displays Gigabit Ethernet interface information, transmission statistics and errors, and applicable MAC destination address and VLAN filtering tables.
show hw-module subslot	Displays diagnostic information about internal hardware devices for SPAs.

test hw-module subslot policyram

To test the policy table used by the field programmable gate array (FPGA) device for ternary content addressable memory (TCAM) lookup on a SPA, use the **test hw-module subslot policyram** command in privileged EXEC configuration mode.

```
test hw-module subslot slot/subslot policyram {read ram-virtual-address | write {ram-data |
[{deny | permit} [tunnel [ignoreda]]]}
```

Syntax Description		
	<i>slot</i>	Chassis slot number. Refer to the appropriate hardware manual for slot information. For MSCs, refer to the platform-specific SPA hardware installation guide or the corresponding “Identifying Slots and Subslots for MSCs and SPAs” topic in the platform-specific SPA software configuration guide.
	<i>/subslot</i>	Secondary slot number on a MSC where a SPA is installed. Refer to the platform-specific SPA hardware installation guide and the corresponding “Specifying the Interface Address on a SPA” topic in the platform-specific SPA software configuration guide for subslot information.
	read <i>ram-virtual-address</i>	Reads from the specified RAM address.
	write	Writes to the specified RAM address.
	<i>ram-data</i>	Value (0–15) to be written in the policy table.
	{ deny permit }	Specifies the corresponding RAM data value to deny or permit traffic.
	tunnel	Specifies use of Layer 2 tunneling.
	ignoreda	Specifies that the destination MAC address is ignored.

Defaults No default behavior or values

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(20)S2	This command was introduced.

Usage Guidelines The **test hw-module subslot policyram** command is implemented on the 4-Port 10/100 Fast Ethernet SPA and the 2-Port 10/100/1000 Gigabit Ethernet SPA on the Cisco 7304 router.



The **test hw-module subslot policyram** command is not intended for production use and should be used only under the supervision of Cisco Systems technical support personnel. This command can produce unexpected operation of your SPA.

This command does not have a **no** form.

When you run any of the **test hw-module subslot** commands on a SPA, you will be warned that the command is not intended for use on a production network and that the command should be reserved for use only with Cisco Systems technical support personnel.

Because the **test hw-module subslot** commands can produce unexpected operation of your SPA, the system issues a confirmation prompt that defaults to “N” to deny execution of the command. The command is not executed if you press **Enter** or type “n.”

To run the command, type “y” at the confirmation prompt.

To restore some of the default values on a SPA interface that you made using a **test hw-module subslot policyram** command, perform the following steps:

1. Use the **shutdown** command to disable the affected interface.
2. Use the **no shutdown** command to reenable the interface.

To restore the default SPA configuration and remove any changes to the SPA settings that you made using a **test hw-module subslot policyram** command, perform the following steps:

1. Use the **hw-module subslot stop** command to deactivate the SPA and all of its interfaces.
2. Use the **hw-module subslot start** command to reactivate the SPA and all of its interfaces.

Examples

The following output provides an example of the **test hw-module subslot policyram** command and the warning statement and confirmation prompt that appears with it:

```
Router# test hw-module subslot 4/0 policyram read 101
This command is not intended for production use
and should be used only under the supervision of
Cisco Systems technical support personnel.
```

```
This command can produce unexpected operation of your SPA.
Are you sure you want to continue? [N]n
```

Related Commands

Command	Description
show controllers fastethernet	Displays Fast Ethernet interface information, transmission statistics and errors, and applicable MAC destination address and VLAN filtering tables.
show controllers gigabitethernet	Displays Gigabit Ethernet interface information, transmission statistics and errors, and applicable MAC destination address and VLAN filtering tables.
show tcam-mgr subslot	Displays TCAM manager information for SPAs.
test hw-module subslot tcam	Tests the TCAM device on a SPA.

test hw-module subslot tcam

To test the ternary content addressable memory (TCAM) device on a SPA, use the **test hw-module subslot tcam** command in privileged EXEC configuration mode.

```
test hw-module subslot slot/subslot tcam insert port {dmac addr hex-mac-address mask
hex-mask | vlan vlan-id} {deny | permit}
```

```
test hw-module subslot slot/subslot tcam lookup port {dmac addr hex-mac-address mask
hex-mask | vlan vlan-id}
```

```
test hw-module subslot slot/subslot tcam read tcam-virtual-address
```

```
test hw-module subslot slot/subslot tcam remove {dmac addr hex-mac-address mask hex-mask |
vlan vlan-id}
```

```
test hw-module subslot slot/subslot tcam write {mask |value} tcam-virtual-address port
lookup-type {dmac hex-mac-address | vlan vlan-id}
```

Syntax Description

<i>slot</i>	Chassis slot number. Refer to the appropriate hardware manual for slot information. For MSCs, refer to the platform-specific SPA hardware installation guide or the corresponding “Identifying Slots and Subslots for MSCs and SPAs” topic in the platform-specific SPA software configuration guide.
<i>/subslot</i>	Secondary slot number on a MSC where a SPA is installed. Refer to the platform-specific SPA hardware installation guide and the corresponding “Specifying the Interface Address on a SPA” topic in the platform-specific SPA software configuration guide for subslot information.
insert <i>port</i> { dmac addr <i>hex-mac-address</i> mask <i>hex-mask</i> vlan <i>vlan-id</i> } { deny permit }	Tests the addition of a TCAM table entry on a SPA, where: <ul style="list-style-type: none"> <i>port</i>—Number of the interface that you want to select on the SPA: <ul style="list-style-type: none"> On the 4-Port 10/100 Fast Ethernet SPA—0, 1, 2, or 3 On the 2-Port 10/100/1000 Gigabit Ethernet SPA—0 or 1 dmac addr <i>hex-mac-address</i> mask <i>hex-mask</i>—Specifies the addition of a 48-bit destination MAC address (in hexadecimal) and its hexadecimal mask value to the TCAM table. vlan <i>vlan-id</i>—Specifies the addition of a virtual LAN (VLAN) identifier (0–4095) to the TCAM table. deny—Configures the TCAM table entry to deny traffic to the specified destination MAC address or VLAN identifier on the selected interface. permit—Configures the TCAM table entry to allow traffic to be passed to the specified destination MAC address or VLAN identifier on the selected interface.

lookup <i>port</i> { dmac addr <i>hex-mac-address</i> mask <i>hex-mask</i> vlan <i>vlan-id</i> }	<p>Tests the reading of a TCAM table entry on a SPA, where:</p> <ul style="list-style-type: none"> • <i>port</i>—Number of the interface that you want to select on the SPA: <ul style="list-style-type: none"> – On the 4-Port 10/100 Fast Ethernet SPA—0, 1, 2, or 3 – On the 2-Port 10/100/1000 Gigabit Ethernet SPA—0 or 1 • dmac addr <i>hex-mac-address</i> mask <i>hex-mask</i>—Specifies the 48-bit destination MAC address (in hexadecimal) and its hexadecimal mask value that you want to read from the TCAM table. • vlan <i>vlan-id</i>—Specifies the virtual LAN (VLAN) identifier (0–4095) that you want to read from the TCAM table.
read <i>tcam-virtual-address</i>	<p>Tests the reading of a TCAM table entry, where <i>tcam-virtual-address</i> is an address in the range 0–4294967295.</p>
remove { dmac addr <i>hex-mac-address</i> mask <i>hex-mask</i> vlan <i>vlan-id</i> }	<p>Tests the deletion of a TCAM table entry on a SPA, where:</p> <ul style="list-style-type: none"> • <i>port</i>—Number of the interface that you want to select on the SPA: <ul style="list-style-type: none"> – On the 4-Port 10/100 Fast Ethernet SPA—0, 1, 2, or 3 – On the 2-Port 10/100/1000 Gigabit Ethernet SPA—0 or 1 • dmac addr <i>hex-mac-address</i> mask <i>hex-mask</i>—Specifies the deletion from the TCAM table of the specified 48-bit destination MAC address (in hexadecimal) and its hexadecimal mask value. • vlan <i>vlan-id</i>—Specifies the deletion from the TCAM table of a virtual LAN (VLAN) identifier in the range 0–4095.
write <i>tcam-virtual-address</i>	<p>Tests writing to a TCAM table entry, where <i>tcam-virtual-address</i> is an address in the range 0–4294967295.</p>
write { mask <i>lvalue</i> } <i>tcam-virtual-address</i> <i>port</i> <i>lookup-type</i> { dmac <i>hex-mac-address</i> vlan <i>vlan-id</i> }	<p>Tests writing to a TCAM table entry, where:</p> <ul style="list-style-type: none"> • mask—Specifies writing of a mask cell. • value—Specifies writing of a value cell. • <i>tcam-virtual-address</i>—Specifies the virtual address of the TCAM table entry in the range 0–65535. • <i>port</i>—Number of the interface that you want to select on the SPA: <ul style="list-style-type: none"> – On the 4-Port 10/100 Fast Ethernet SPA—0, 1, 2, or 3 – On the 2-Port 10/100/1000 Gigabit Ethernet SPA—0 or 1 • <i>lookup-type</i>—Specifies the type (1 or 2) of TCAM lookup for the write operation. A value of “1” designates a destination MAC address lookup type, and a value of “2” designates a VLAN lookup type. <p>Note Values 0 and 3 are not supported on SPAs.</p> <ul style="list-style-type: none"> • dmac <i>hex-mac-address</i>—Writes the specified 48-bit destination MAC address (in hexadecimal) to the TCAM table. • vlan <i>vlan-id</i>—Writes the specified VLAN ID in the range 0–4095.

Defaults

No default behavior or values

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(20)S2	This command was introduced.

Usage Guidelines The **test hw-module subslot tcam** command is implemented on the 4-Port 10/100 Fast Ethernet SPA and the 2-Port 10/100/1000 Gigabit Ethernet SPA on the Cisco 7304 router.



Caution

The **test hw-module subslot tcam** command is not intended for production use and should be used only under the supervision of Cisco Systems technical support personnel. This command can produce unexpected operation of your SPA.

This command does not have a **no** form.

When you run any of the **test hw-module subslot** commands on a SPA, you will be warned that the command is not intended for use on a production network and that the command should be reserved for use only with Cisco Systems technical support personnel.

Because the **test hw-module subslot** commands can produce unexpected operation of your SPA, the system issues a confirmation prompt that defaults to “N” to deny execution of the command. The command is not executed if you press **Enter** or type “n.”

To run the command, type “y” at the confirmation prompt.

To restore some of the default values on a SPA interface that you made using a **test hw-module subslot tcam** command, perform the following steps:

1. Use the **shutdown** command to disable the affected interface.
2. Use the **no shutdown** command to reenable the interface.

To restore the default SPA configuration and remove any changes to the SPA settings that you made using a **test hw-module subslot tcam** command, perform the following steps:

1. Use the **hw-module subslot stop** command to deactivate the SPA and all of its interfaces.
2. Use the **hw-module subslot start** command to reactivate the SPA and all of its interfaces.

Examples The following output provides an example of the **test hw-module subslot tcam** command and the warning statement and confirmation prompt that appears with it:

```
Router# test hw-module subslot 4/0 tcam remove 0 vlan 0
This command is not intended for production use
and should be used only under the supervision of
Cisco Systems technical support personnel.
```

```
This command can produce unexpected operation of your SPA.
Are you sure you want to continue? [N]n
```

Related Commands

Command	Description
show controllers fastethernet	Displays Fast Ethernet interface information, transmission statistics and errors, and applicable MAC destination address and VLAN filtering tables.
show controllers gigabitethernet	Displays Gigabit Ethernet interface information, transmission statistics and errors, and applicable MAC destination address and VLAN filtering tables.
show tcam-mgr subslot	Displays TCAM manager information for SPAs.
test hw-module subslot policyram	Tests the policy RAM on a SPA.

test hw-module subslot temperature

To read temperature sensors on a SPA, use the **test hw-module subslot temperature** command in privileged EXEC configuration mode.

test hw-module subslot *slot/subslot* **temperature** *sensor-number*


Syntax Description	<i>slot</i>	Chassis slot number. Refer to the appropriate hardware manual for slot information. For MSCs, refer to the platform-specific SPA hardware installation guide or the corresponding “Identifying Slots and Subslots for MSCs and SPAs” topic in the platform-specific SPA software configuration guide.
	<i>/subslot</i>	Secondary slot number on a MSC where a SPA is installed. Refer to the platform-specific SPA hardware installation guide and the corresponding “Specifying the Interface Address on a SPA” topic in the platform-specific SPA software configuration guide for subslot information.
	temperature <i>sensor-number</i>	Reads the specified sensor (1 or 2) on the SPA.

Defaults No default behavior or values

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(20)S2	This command was introduced.

Usage Guidelines The **test hw-module subslot temperature** command is implemented on the 4-Port 10/100 Fast Ethernet SPA and the 2-Port 10/100/1000 Gigabit Ethernet SPA on the Cisco 7304 router.



Caution

The **test hw-module subslot temperature** command is not intended for production use and should be used only under the supervision of Cisco Systems technical support personnel. This command can produce unexpected operation of your SPA.

This command does not have a **no** form.

When you run any of the **test hw-module subslot** commands on a SPA, you will be warned that the command is not intended for use on a production network and that the command should be reserved for use only with Cisco Systems technical support personnel.

Because the **test hw-module subslot** commands can produce unexpected operation of your SPA, the system issues a confirmation prompt that defaults to “N” to deny execution of the command. The command is not executed if you press **Enter** or type “n.”

To run the command, type “y” at the confirmation prompt.

The **test hw-module subslot temperature** command does not modify any configuration settings. Therefore, you do not need to restore any default values after using the command.

Examples

The following output provides an example of the **test hw-module subslot temperature** command and the warning statement and confirmation prompt that appears with it:

```
Router# test hw-module subslot 4/0 temperature 1
This command is not intended for production use
and should be used only under the supervision of
Cisco Systems technical support personnel.
```

```
This command can produce unexpected operation of your SPA.
Are you sure you want to continue? [N]n
```

Related Commands

Command	Description
show environment	Displays power supply, fan, voltage, and temperature information for the router.

test tcam-mgr subslot

To test the ternary content addressable memory (TCAM) manager for a SPA, use the **test tcam-mgr subslot** command in privileged EXEC configuration mode.

```
test tcam-mgr subslot slot/subslot {delete | empty | fill}{rx-dest-mac | rx-vlan} value

test tcam-mgr subslot slot/subslot insert [bottom | top]{rx-dest-mac | rx-vlan} value

test tcam-mgr subslot slot/subslot fulltcam {off | on}

test tcam-mgr subslot slot/subslot off

test tcam-mgr subslot slot/subslot read mc-index value vc-index value
```

Syntax Description	slot	<p>Chassis slot number.</p> <p>Refer to the appropriate hardware manual for slot information. For MSCs, refer to the platform-specific SPA hardware installation guide or the corresponding “Identifying Slots and Subslots for MSCs and SPAs” topic in the platform-specific SPA software configuration guide.</p>
	/subslot	<p>Secondary slot number on a MSC where a SPA is installed.</p> <p>Refer to the platform-specific SPA hardware installation guide and the corresponding “Specifying the Interface Address on a SPA” topic in the platform-specific SPA software configuration guide for subslot information.</p>
	{delete empty fill}	<p>Specifies one of the following operations on the destination MAC address or VLAN TCAM tables for filtering received frames:</p> <ul style="list-style-type: none"> delete—Removes a TCAM region entry. empty—Empties a TCAM region by deleting entries. fill—Inserts entries into a TCAM region by replicating the value that you specify throughout the region.
	{rx-dest-mac rx-vlan} value	<p>Specifies which TCAM region upon which to perform the operation, where:</p> <ul style="list-style-type: none"> rx-dest-mac—Destination MAC address region for filtering received frames. rx-vlan—VLAN ID region for filtering received frames. <i>value</i>—Hexadecimal value of the entry on which to perform the specified insertion or deletion operation.

insert [bottom top]	<p>Specifies the addition of a single TCAM entry to the specified region, where:</p> <ul style="list-style-type: none"> • bottom—(Optional) Inserts the specified value at the bottom of the selected TCAM region. • top—(Optional) Inserts the specified value at the top of the selected TCAM region. <p>If you do not specify one of the optional keywords, then the entry is inserted anywhere in the middle of the TCAM region.</p>
fulltcam { off on }	Turns TCAM simulation off or on for all TCAM regions.
off	Disables the TCAM manager.
read mc-index <i>value</i> vc-index <i>value</i>	<p>Reads the specified index <i>value</i>, where:</p> <ul style="list-style-type: none"> • mc-index—Mask cell index. • vc-index—Value cell index, where <i>value</i> is in the range of 0 to 7. <p>To find the range of mask indexes, use the show tcam-mgr subslot region command.</p> <p>To find the mask and value cell index values for a particular entry, use the show tcam-mgr subslot table command.</p>

Defaults

No default behavior or values

Command Modes

Privileged EXEC

Command History

Release	Modification
12.0 S	This command was introduced.
12.2(20)S2	This command was integrated into Cisco IOS Release 12.2(20)S2 and support for the subslot , rx-dest-mac , and rx-vlan keywords were added for SPAs on the Cisco 7304 router.

Usage Guidelines

Use the **test tcam-mgr subslot** command to test the TCAM manager for the destination MAC address and VLAN filter regions supported by the SPAs.

The TCAM manager allocates memory among the applications that it supports, in the form of regions. The SPAs support two TCAM regions, region 0 for destination MAC address filtering and region 1 for VLAN ID filtering of received frames.

**Caution**

The **test tcam-mgr subslot** command is not intended for production use and should be used only under the supervision of Cisco Systems technical support personnel. This command can produce unexpected operation of your SPA.

Unlike when you run the **test hw-module subslot** commands for a SPA, when you run the **test tcam-mgr**

subslot commands the SPA *does not* provide a warning that the command is not intended for use on a production network and that the command should be reserved for use only with Cisco Systems technical support personnel.

This command does not have a **no** form.

You can obtain information about the TCAM region entries using the **show tcam-mgr subslot** privileged EXEC command.

To restore the default SPA configuration and remove any changes to the SPA settings that you made using a **test tcam-mgr subslot** command, perform the following steps:

1. Use the **hw-module subslot stop** command to deactivate the SPA and all of its interfaces.
2. Use the **hw-module subslot start** command to reactivate the SPA and all of its interfaces.

Examples

The following example removes the entry with the value 00112233 from the destination MAC address TCAM region for a SPA located in the top subslot (0) of the MSC that is installed in slot 4 on a Cisco 7304 router:

```
Router# test tcam-mgr subslot 4/0 delete rx-dest-mac 00112233
```

Related Commands

Command	Description
show controllers fastethernet	Displays Fast Ethernet interface information, transmission statistics and errors, and applicable MAC destination address and VLAN filtering tables.
show controllers gigabitethernet	Displays Gigabit Ethernet interface information, transmission statistics and errors, and applicable MAC destination address and VLAN filtering tables.
show tcam-mgr subslot	Displays TCAM manager information for SPAs.
test hw-module subslot policyram	Tests the policy table used by the FPGA device for TCAM lookup on a SPA.
test hw-module subslot tcam	Tests the TCAM device on a SPA.

ttb

To send a trace trail buffer in E3 g832 framing mode, use the **ttb** command in interface configuration mode. To disable the trace, use the **no** form of this command.

ttb { **country** | **rnode** | **serial** | **snode** | **soperator** | **x** } *line*

no ttb { **country** | **rnode** | **serial** | **snode** | **soperator** | **x** } *line*

Syntax Description

country <i>line</i>	Two-character country code.
rnode <i>line</i>	Receive node code.
serial <i>line</i>	M.1400 Serial
snode <i>line</i>	Sending Town/Node ID code.
soperator <i>line</i>	Sending Operator code.
x <i>line</i>	XO

Defaults

No default behavior or values

Command Modes

Interface configuration

Command History

Release	Modification
12.2S	This command was introduced.
12.2(18)SXE	This command was integrated into Cisco IOS Release 12.2(18)SXE.
12.0(31)S	This command was integrated into Cisco IOS Release 12.0(31)S.
12.2(25)S3	This command was integrated into Cisco IOS Release 12.2(25)S3.

Usage Guidelines

Use the **ttb** command to attach a header that contains fields to send to a remote device.

Examples

The following example starts a TTB message on the first port on slot 5.

```
Router# configure terminal
Router(config)# int serial 5/0/0
Router(config-if)# ttb country us
Router(config-if)# ttb snode 123
Router(config-if)# ttb rnode rn
Router(config-if)# ttb x 9
Router(config-if)# ttb serial 432
```

Related Commands

Command	Description
show controller serial	Displays controller statistics.

upgrade fpd auto

To configure the router to automatically upgrade the current FPD images on a SPA when an FPD version incompatibly is detected, enter the **upgrade fpd auto** global configuration command. To disable automatic FPD image upgrades, use the **no** form of this command.

upgrade fpd auto

no upgrade fpd auto

Syntax Description

This command has no arguments or keywords.

Defaults

This command is enabled by default if your router has any installed SPAs. The router will check the SPA FPD image during bootup or after an insertion of a SPA into an MSC subslot. If the router detects an incompatibility between an FPD image and a SPA, an automatic FPD upgrade attempt will occur unless the user has disabled automatic FPD upgrades by entering the **no upgrade fpd auto** command.

By default, the **upgrade fpd auto** will search the router's primary Flash file system for the FPD image package file. If you would like the router to search for the FPD image package file in a location other than the router's primary Flash file system when an FPD incompatibility is detected, enter the **upgrade fpd path fpd-pkg-dir-url** command to specify the location where the router should search for the FPD image package file. Once the FPD image package file is successfully located, the FPD upgrade process begins automatically.

Command Modes

Global configuration

Command History

Release	Modification
12.2(20)S2	This command was introduced.

Usage Guidelines

This command is enabled by default. In most cases, this default configuration should be retained.

By default, the **upgrade fpd auto** command instructs the router to search its primary Flash file system (for example, disk0:) for the FPD image package file. If you would like the router to search for the FPD image package file in a different location when an FPD incompatibility is detected, enter the **upgrade fpd path** command to have the router find the FPD image package file in a different location.

If this command is disabled but an FPD upgrade is required, the **upgrade hw-module subslot** command can be used to upgrade the SPA FPD image manually after the SPA is disabled because of the existing FPD incompatibility.

Upgrading the FPD image on a SPA places the SPA offline while the upgrade is taking place. The time required to complete an FPD image upgrade can be lengthy. The **show upgrade progress** command can be used to gather more information about estimated FPD download times for a particular SPA.

Examples

The following example shows the output displayed when a SPA requires an FPD image upgrade and the **upgrade fpd auto** command is *enabled*. The incompatible FPD image is automatically upgraded.

```
% Uncompressing the bundle ... [OK]
*Jan 13 22:38:47:%FPD_MGMT-3-INCOMP_FPD_VER:Incompatible 4FE/2GE FPGA (FPD ID=1) image
version detected for SPA-4FE-7304 card in subslot 2/0. Detected version = 4.12, minimal
required version = 4.13. Current HW version = 0.32.
*Jan 13 22:38:47:%FPD_MGMT-5-FPD_UPGRADE_ATTEMPT:Attempting to automatically upgrade the
FPD image(s) for SPA-4FE-7304 card in subslot 2/0 ...

*Jan 13 22:38:47:%FPD_MGMT-6-BUNDLE_DOWNLOAD:Downloading FPD image bundle for SPA-4FE-7304
card in subslot 2/0 ...
*Jan 13 22:38:49:%FPD_MGMT-6-FPD_UPGRADE_TIME:Estimated total FPD image upgrade time for
SPA-4FE-7304 card in subslot 2/0 = 00:06:00.
*Jan 13 22:38:49:%FPD_MGMT-6-FPD_UPGRADE_START:4FE/2GE FPGA (FPD ID=1) image upgrade in
progress for SPA-4FE-7304 card in subslot 2/0. Updating to version 4.13. PLEASE DO NOT
INTERRUPT DURING THE UPGRADE PROCESS (estimated upgrade completion time = 00:06:00)
...[.....]
(part of the output has been removed for brevity)
.....
.....]
SUCCESS - Completed XSVF execution.

*Jan 13 22:44:33:%FPD_MGMT-6-FPD_UPGRADE_PASSED:4FE/2GE FPGA (FPD ID=1) image upgrade for
SPA-4FE-7304 card in subslot 2/0 has PASSED. Upgrading time = 00:05:44.108
*Jan 13 22:44:33:%FPD_MGMT-6-OVERALL_FPD_UPGRADE:All the attempts to upgrade the required
FPD images have been completed for SPA-4FE-7304 card in subslot 2/0. Number of
successful/failure upgrade(s):1/0.
*Jan 13 22:44:33:%FPD_MGMT-5-CARD_POWER_CYCLE:SPA-4FE-7304 card in subslot 2/0 is being
power cycled for the FPD image upgrade to take effect.
```

Related Commands

Command	Description
upgrade hw-module subslot	Manually upgrades the current FPD image on the specified SPA.
upgrade fpd path	Specifies the location from where the FPD image package should be loaded when an automatic FPD upgrade is initiated by the router.
show hw-module subslot fpd	Displays the FPD version on each SPA in the router.
show upgrade fpd file	Displays the contents of an FPD image package file.
show upgrade fpd package default	Displays which FPD image package is needed for the router to properly support the SPAs.
show upgrade fpd progress	Displays the progress of the FPD upgrade while an FPD upgrade is taking place.
show upgrade fpd table	Displays various information used by the Cisco IOS software to manage the FPD image package file.

upgrade fpd path

To configure the router to search for an FPD image package file in a location other than the router’s primary Flash file system during an automatic FPD upgrade, enter the **upgrade fpd path** global configuration command to specify the new location that should be searched for an FPD image package file when an automatic FPD upgrade occurs. To return to the default setting of the router searching for the FPD image package file in the router's primary Flash file system when an automatic FPD upgrade is triggered, use the **no** form of this command.

```

upgrade fpd path fpd-pkg-dir-url

no upgrade fpd path fpd-pkg-dir-url

```

Syntax Description	<i>fpd-pkg-dir-url</i>	Specifies the location of the FPD image package file, beginning with the location or type of storage device (examples include disk0, slot0, tftp, or ftp) and followed by the path to the FPD image package file. It is important to note that the name of the FPD image package file should not be specified as part of <i>fpd-pkg-dir-url</i> ; the Cisco IOS will automatically download the correct FPD image package file once directed to the proper location.
--------------------	------------------------	--

Defaults	By default, the router checks its primary Flash file system for an FPD image package file when an incompatibility between an FPD image on the SPA and the running Cisco IOS image is detected. The upgrade fpd path command is used to specify a new location for a router to locate the FPD image package file if you want to store the FPD image package file in a location other than the router’s default Flash file system for automatic FPD upgrades.
----------	--

Command Modes	Global configuration
---------------	----------------------

Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>12.2(20)S2</td><td>This command was introduced.</td></tr> </table>	Release	Modification	12.2(20)S2	This command was introduced.
Release	Modification				
12.2(20)S2	This command was introduced.				

Usage Guidelines	<p>When specifying the path to the location of the new FPD image package file, do not include the filename in the path. The Cisco IOS will automatically download the correct FPD image package file once directed to the proper location, even if multiple FPD image package files of different versions are stored in the same location.</p> <p>If the upgrade fpd path command is not entered, the router will search the default primary Flash file system for the FPD image.</p>
------------------	--

Examples	<p>In the following example, the FPD image package file that is stored on the TFTP server using the path johnstftpserver/fpdfiles will now be scanned for the latest FPD image package file when an automatic FPD upgrade occurs.</p> <pre> upgrade fpd path tftp://johnstftpserver/fpdfiles/ </pre>
----------	---

In the following example, the FPD package file that is stored on the FTP server using the path johnsftpsrvr/fpdfiles will now be scanned for the latest FPD image package when an automatic FPD upgrade occurs. In this example, john is the username and XXXXXXXX is the FTP password.

```
upgrade fpd path ftp://john:XXXXXXX@johnsftpsrvr/fpdfiles/
```

Related Commands	Command	Description
	upgrade hw-module subslot	Manually upgrades the current FPD image on the specified SPA.
	upgrade fpd auto	Configures the router to automatically upgrade the FPD image when an FPD version incompatibility is detected.
	show hw-module subslot fpd	Displays the FPD version on each SPA in the router.
	show upgrade fpd file	Displays the contents of an FPD image package file.
	show upgrade fpd package default	Displays which FPD image package is needed for the router to properly support the SPAs.
	show upgrade fpd progress	Displays the progress of the FPD upgrade while an FPD upgrade is taking place.
	show upgrade fpd table	Displays various information used by the Cisco IOS software to manage the FPD image package file.

upgrade hw-module subslot

To manually upgrade the current FPD image package on a SPA, enter the **upgrade hw-module subslot** command in privileged EXEC configuration mode.

upgrade hw-module subslot *slot/subslot* **file** *file-url* [**force**]

Syntax Description

<i>slot</i>	Chassis slot number. Refer to the appropriate hardware manual for slot information. For MSCs, refer to the platform-specific SPA hardware installation guide or the corresponding “Identifying Slots and Subslots for MSCs and SPAs” topic in the platform-specific SPA software configuration guide.
<i>/subslot</i>	Secondary slot number on a MSC where a SPA is installed. Refer to the platform-specific SPA hardware installation guide and the corresponding “Specifying the Interface Address on a SPA” topic in the platform-specific SPA software configuration guide for subslot information.
file	Specifies that a file will be downloaded.
<i>file-url</i>	Specifies the location of the FPD image package file, beginning with the location or type of storage device (examples include disk0, slot0, tftp, or ftp) and followed by the path to the FPD image package file.
force	Forces the update of all compatible FPD images in the indicated FPD image package on the SPA that meet the minimal version requirements. Without this option, the manual upgrade will only upgrade incompatible FPD images.

Defaults

No default behavior or values, although it is important to note that the router containing the SPA is configured, by default, to upgrade the FPD images when it detects a version incompatibility between a the FPD image on the SPA and the FPD image required to run the SPA with the running Cisco IOS image. The **upgrade hw-module subslot** command is used to manually upgrade the FPD images; therefore, the **upgrade hw-module subslot** command should only be used when the automatic upgrade default configuration fails to find a compatible FPD image for one of the SPAs or when the automatic upgrade default configuration has been manually disabled. The **no upgrade fpd auto** command can be entered to disable automatic FPD upgrades.

If no FPD incompatibility is detected, this command will not upgrade SPA FPD images unless the **force** option is entered.

Command Modes

Privileged EXEC

Command History

Release	Modification
12.2(20)S2	This command was introduced.

Usage Guidelines

This command is used to manually upgrade the FPD images on a SPA. In most cases, the easiest and recommended method of upgrading FPD images is the automatic FPD upgrade, which is enabled by default. The automatic FPD upgrade will detect and automatically upgrade all FPD images when an FPD incompatibility is detected.

A manual FPD upgrade is usually used in the following situations:

- The target SPA was disabled by the system because of an incompatible FPD image (the system could not find the required FPD image package file).
- A recovery upgrade must be performed.
- A special bug fix to an FPD image is provided in the FPD image package file.

The FPD image upgrade process places the SPA offline. The time required to complete an FPD image upgrade can be lengthy. The **show upgrade progress** command can be used to gather more information about estimated FPD download times for a particular SPA.

Examples

The following example shows a sample manual FPD upgrade:

```
Router# upgrade hw-module subslot 2/0 file disk0:spa_fpd.122-20.S2.pkg
% Uncompressing the bundle ... [OK]

% The following FPD(s) will be upgraded for card in subslot 2/0 :

=====
Field Programmable   Current      Upgrade      Estimated
Device:"ID-Name"     Version      Version      Upgrade Time
=====
1-Data & I/O FPGA    4.12         4.13         00:06:00
=====

% Are you sure that you want to perform this operation? [no]:y
% Restarting the target card (subslot 2/0) for FPD image upgrade. Please wait ...

Router#
*Jan 14 00:37:17:%FPD_MGMT-6-FPD_UPGRADE_TIME:Estimated total FPD image upgrade time for
SPA-4FE-7304 card in subslot 2/0 = 00:06:00.
*Jan 14 00:37:17:%FPD_MGMT-6-FPD_UPGRADE_START:4FE/2GE FPGA (FPD ID=1) image upgrade in
progress for SPA-4FE-7304 card in subslot 2/0. Updating to version 4.13. PLEASE DO NOT
INTERRUPT DURING THE UPGRADE PROCESS (estimated upgrade completion time = 00:06:00)
...[.....(part of the output has been removed for brevity)....]
.....]
SUCCESS - Completed XSVF execution.

*Jan 14 00:42:59:%FPD_MGMT-6-FPD_UPGRADE_PASSED:4FE/2GE FPGA (FPD ID=1) image upgrade for
SPA-4FE-7304 card in subslot 2/0 has PASSED. Upgrading time = 00:05:42.596
*Jan 14 00:42:59:%FPD_MGMT-6-OVERALL_FPD_UPGRADE:All the attempts to upgrade the required
FPD images have been completed for SPA-4FE-7304 card in subslot 2/0. Number of
successful/failure upgrade(s):1/0.
*Jan 14 00:42:59:%FPD_MGMT-5-CARD_POWER_CYCLE:SPA-4FE-7304 card in subslot 2/0 is being
power cycled for the FPD image upgrade to take effect.
```

Related Commands	Command	Description
	upgrade fpd auto	Configures the router to automatically upgrade the FPD image when an FPD version incompatibility is detected.
	upgrade fpd path	Specifies the location from where the FPD image package should be loaded when an automatic FPD upgrade is initiated by the router.
	show hw-module subslot fpd	Displays the FPD version on each SPA in the router.
	show upgrade fpd file	Displays the contents of an FPD image package file.
	show upgrade fpd package default	Displays which FPD image package is needed for the router to properly support the SPAs.
	show upgrade fpd progress	Displays the progress of the FPD upgrade while an FPD upgrade is taking place.
	show upgrade fpd table	Displays various information used by the Cisco IOS software to manage the FPD image package file.

