



A through M

- [aaa group server radius, page 4](#)
- [address-family, page 5](#)
- [aggregate-address , page 6](#)
- [apply profile, page 9](#)
- [autodiscovery bgp signaling ldp , page 11](#)
- [boot poap, page 12](#)
- [bridge-domain , page 13](#)
- [checkpoint, page 14](#)
- [clear evb, page 16](#)
- [clear evb statistics, page 18](#)
- [clear fabric access, page 19](#)
- [clear fabric connectivity cable-plan, page 20](#)
- [clear fabric connectivity neighbors, page 21](#)
- [clear fabric database statistics, page 23](#)
- [clear fabricpath oam loopback, page 25](#)
- [clear FabricPath oam mtrace, page 26](#)
- [clear fabripath oam notification, page 27](#)
- [clear fabricpath oam traceroute, page 28](#)
- [configure profile, page 29](#)
- [copy scheduled-config, page 30](#)
- [db-jid, page 32](#)
- [db-security, page 33](#)
- [db-table, page 34](#)
- [debug evb, page 35](#)

- [default-information originate](#), page 37
- [define](#), page 38
- [description \(fabricpath-oam\)](#), page 40
- [dot1q \(fabricpath-oam\)](#), page 41
- [encapsulation dot1Q](#), page 42
- [errdisable detect cause](#), page 43
- [errdisable recovery cause](#), page 45
- [errdisable recovery interval](#), page 47
- [ether-type \(fabricpath-oam\)](#), page 48
- [evb mac](#), page 49
- [evb reinit-keep-alive](#), page 50
- [evb resource-wait-delay](#), page 51
- [fabric access attach device](#), page 52
- [fabric access attach group](#), page 53
- [fabric access create group](#), page 54
- [fabric access group](#), page 55
- [fabric access local-help](#), page 56
- [fabric access login](#), page 57
- [fabric access ping](#), page 58
- [fabric access prepend-id](#), page 59
- [fabric access send device](#), page 60
- [fabric access send group](#), page 61
- [fabric access server](#), page 63
- [fabric connectivity cable-plan enforce](#), page 65
- [fabric connectivity cable-plan generate](#), page 66
- [fabric connectivity cable-plan import](#), page 67
- [fabric connectivity mismatch action delay](#), page 71
- [fabric connectivity tier](#), page 72
- [fabric database mobility-domain](#), page 74
- [fabric database type](#), page 75
- [fabric forwarding anycast-gateway-mac](#), page 76
- [fabric forwarding control-segment](#), page 77
- [fabric forwarding conversational-aging](#), page 78

- [fabric forwarding conversational-learning](#), page 79
- [fabric forwarding identifier](#), page 80
- [fabric forwarding switch-role](#), page 81
- [fabricpath isis bfd](#), page 83
- [fabricpath oam profile](#), page 84
- [feature cable-management](#), page 85
- [feature evb](#), page 86
- [feature fabric](#), page 87
- [feature fabric access](#), page 88
- [feature fabric multicast](#), page 89
- [feature-set fabric](#), page 90
- [feature vn-segment-vlan-based](#), page 91
- [flow \(fabricpath-oam\)](#), page 92
- [hop \(fabricpath-oam\)](#), page 93
- [include profile](#), page 94
- [install feature-set fabric](#), page 95
- [instance](#), page 96
- [interface \(fabricpath-oam\)](#), page 98
- [ip \(fabricpath-oam\)](#), page 99
- [ip arp rarp fabric-forwarding](#), page 100
- [ip multicast fabric-forwarding](#), page 101
- [ipv6 \(fabricpath-oam\)](#), page 102
- [logging level evb](#), page 103
- [mac-address \(fabricpath-oam\)](#), page 105
- [match \(VLAN access-map\)](#), page 106
- [mtrace fabricpath](#), page 108

aaa group server radius

To create a RADIUS server group and enter RADIUS server group configuration mode, use the **aaa group server radius** command in global configuration mode. To delete a RADIUS server group, use the **no** form of this command.

aaa group server radius *group-name*

no aaa group server radius *group-name*

Syntax Description

group-name

RADIUS server group name. The name is alphanumeric and case-sensitive. The maximum length is 64 characters.

Command Default

A RADIUS server group is not configured.

Command Modes

Global configuration (config)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Examples

The following example shows how to create a RADIUS server group and enter RADIUS server configuration mode:

```
Device# configure terminal
Device(config)# aaa group server radius RadServer
Device(config-radius)#
```

The following example shows how to delete a RADIUS server group:

```
Device# configure terminal
Device(config)# no aaa group server radius RadServer
```

address-family

To configure multicast VPN (MVPN) for IPv4 or IPv6, use the **address-family** command in router configuration mode or neighbor configuration mode. To disable MVPN configuration, use the **no** form of this command.

address-family {ipv4 | ipv6} mvpn

no address-family {ipv4 | ipv6} mvpn

Syntax Description

ipv4	Configures the IPv4 address-family.
ipv6	Configures the IPv6 address-family.
mvpn	Configures Multicast VPN .

Command Default

No MVPN provisioning support is enabled.

Command Modes

Router configuration (config-router)
Neighbor configuration (config-router-neighbor)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

This command places the router in address family configuration mode (prompt: config-router-af), from which you can configure routing sessions that support Multicast VPN provisioning for IPv4 or IPv6.

Examples

The following example shows how to configure multicast VPN for IPv4:

```
Device> enable
Device# configure terminal
Device(config)# router bgp 100
Device(config-router)# address-family ipv4 mvpn
Device(config-router-af)# exit
```

The following example shows how to configure multicast VPN for IPv6:

```
Device> enable
Device# configure terminal
Device(config)# router bgp 100
Device(config-router)# address-family ipv6 mvpn
Device(config-router-af)# exit
```

aggregate-address

To create a summary address in a Border Gateway Protocol (BGP) routing table, use the **aggregate-address** command. To remove the summary address, use the **no** form of this command.

aggregate-address *address/length* [**advertise-map** *map-name*][**as-set**][**attribute-map** *map-name*][**summary-only**][**suppress-map** *map-name*]

no aggregate-address *address/length* [**advertise-map** *map-name*][**as-set**][**attribute-map** *map-name*][**summary-only**][**suppress-map** *map-name*]

Syntax Description

address/length	Specifies aggregate IP address and mask length. Valid values for length are as follows: <ul style="list-style-type: none"> IPv4 addresses from 1 to 32 IPv6 addresses from 1 to 128
advertise-map <i>map-name</i>	(Optional) Specifies the name of the route map used to select attribute information from specific routes.
as-set	(Optional) Generates the autonomous system set path information and community information from the contributing paths.
attribute-map <i>map-name</i>	(Optional) Specifies the name of the route map used to set the attribute information for specific routes. The map-name is an alphanumeric string up to 63 characters.
summary-only	(Optional) Filters all more-specific routes from updates.
suppress-map <i>map-name</i>	(Optional) Specifies the name of the route map used to conditionally filter more specific routes. The map-name is an alphanumeric string up to 63 characters.

Command Default

The atomic aggregate attribute is set automatically when an aggregate route is created with this command unless the **as-set** keyword is specified.

Command Modes

Address-family configuration mode
Neighbor address-family configuration mode
Router BGP configuration mode

Command History

Release	Modification
--	This command was introduced in an earlier Cisco NX-OS release.

Usage Guidelines

You can implement aggregate routing in BGP and mBGP either by redistributing an aggregate route into BGP or mBGP, or by using the conditional aggregate routing feature.

Using the **aggregate-address** command with no keywords will create an aggregate entry in the BGP or mBGP routing table if any more-specific BGP or mBGP routes are available that fall within the specified range. (A longer prefix which matches the aggregate must exist in the RIB.) The aggregate route will be advertised as coming from your autonomous system and will have the atomic aggregate attribute set to show that information might be missing. (By default, the atomic aggregate attribute is set unless you specify the **as-set** keyword.)

Using the **as-set** keyword creates an aggregate entry using the same rules that the command follows without this keyword, but the path advertised for this route will be an AS_SET consisting of all elements contained in all paths that are being summarized. Do not use this form of the **aggregate-address** command when aggregating many paths, because this route must be continually withdrawn and updated as autonomous system path reachability information for the summarized routes changes.

Using the **summary-only** keyword not only creates the aggregate route (for example, 192.*.*.*) but also suppresses advertisements of more-specific routes to all neighbors. If you want to suppress only advertisements to certain neighbors, you may use the **neighbor distribute-list** command, with caution. If a more-specific route leaks out, all BGP or mBGP routers will prefer that route over the less-specific aggregate you are generating (using longest-match routing).

Using the **suppress-map** keyword creates the aggregate route but suppresses advertisement of specified routes. You can use the match clauses of route maps to selectively suppress some more-specific routes of the aggregate and leave others unsuppressed. IP access lists and autonomous system path access lists match clauses are supported.

Using the **advertise-map** keyword selects specific routes that will be used to build different components of the aggregate route, such as AS_SET or community. This form of the **aggregate-address** command is useful when the components of an aggregate are in separate autonomous systems and you want to create an aggregate with AS_SET, and advertise it back to some of the same autonomous systems. You must remember to omit the specific autonomous system numbers from the AS_SET to prevent the aggregate from being dropped by the BGP loop detection mechanism at the receiving router. IP access lists and autonomous system path access lists match clauses are supported.

Using the **attribute-map** keyword allows attributes of the aggregate route to be changed. This form of the **aggregate-address** command is useful when one of the routes forming the AS_SET is configured with an attribute such as the community no-export attribute, which would prevent the aggregate route from being exported. An attribute map route map can be created to change the aggregate attributes.

This command requires the Enterprise Services license.

Examples

AS-Set Example

In This example, an aggregate BGP address is created in router configuration mode. The path advertised for this route will be an AS_SET consisting of all elements contained in all paths that are being summarized.

```
Device(config)# router bgp 64496
Device(config-router)# aggregate-address 10.0.0.0 255.0.0.0 as-set
```

Summary-Only Example

In This example, an aggregate BGP address is created in address family configuration mode and applied to the multicast database (SAFI) under the IP Version 4 address family. Because the **summary-only** keyword is configured, more-specific routes are filtered from updates.

```
Device(config)# router bgp 64496
Device(config-router)# address-family ipv4 multicast
Device(config-router-af)# aggregate-address 10.0.0.0 255.0.0.0 summary-only
```

Conditional Aggregation Example

In This example, a route map called MAP-ONE is created to match on an as-path access list. The path advertised for this route will be an AS_SET consisting of elements contained in paths that are matched in the route map.

```
Device(config)# ip as-path access-list 1 deny ^1234_
Device(config)# ip as-path access-list 1 permit .*
Device(config)# !
Device(config)# route-map MAP-ONE
Device(config-route-map)# match ip as-path 1
Device(config-route-map)# exit
Device(config)# router bgp 64496
Device(config-router)# address-family ipv4
Device(config-router-af)# aggregate-address 10.0.0.0 255.0.0.0 as-set advertise-map MAP-ONE
Device(config-router-af)# end
```


apply profile

To apply a configuration profile to configure hosts, use the **apply profile** command in global configuration mode. To remove the configuration profile use the **no** form of this command.

apply profile *profile-name* [**include-instance** *include-instance*] [**param-instance** *instance-name*]

no apply profile *profile-name* [**include-instance** *include-instance*] [**param-instance** *instance-name*]

Syntax Description

<i>profile-name</i>	Name of the profile that is created using the configure profile command.
include-instance <i>include-instance</i>	(Optional) Specifies the include instance name.
param-instance <i>instance-name</i>	(Optional) Specifies the parameter instance name.

Command Default

The port profile is not applied.

Command Modes

Global configuration (config)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

Configuration profiles provide an infrastructure to configure hosts based on a set of user-defined templates. You can define different templates for different types of hosts and enable them appropriately based on an event, such as host discovery. You can apply different profiles to different hosts and apply different values for the configuration for different hosts.

Use the **apply profile** command to apply a configuration profile on a host.

Use the **configure profile** command to create a configuration profile and add a parameter list and a parameter-list instance. You can either create one parameterized profile for each host or create one profile with parameterized argument and apply it with host-specific arguments. The parameter-list instance provides the actual values that are added in the configuration profile before the profile is applied. The parameter name in the instance must match the parameter name in the profile.

Examples

The following example shows how to create a configuration profile and apply it to a host instance, named HOST-1, to expand the profile and configure a new host:

```
Device(config)# configure profile sample
Device(conf-profile)# vlan $vlanId
Device(conf-profile-vlan)# vn-segment $segmentId
Device(conf-profile-vlan)# interface vlan $vlanId
```

```
Device(conf-profile-if-verify)# ip address $ipv4addr/$netmask1
Device(conf-profile-if-verify)# ipv6 address $ipv6addr/$netmask2
Device(conf-profile-if-verify)# ip access-group $aclnum out
Device(conf-profile-if-verify)# configure terminal
Device(config)# apply profile sample param-instance HOST-1
Device(config)# end
```

Related Commands

Command	Description
configure profile	Configures a profile.

autodiscovery bgp signaling ldp

To enable autodiscovery using Label Distribution Protocol (LDP) in a Layer 2 virtual forwarding interface (VFI), use the **autodiscovery bgp signaling ldp** command in L2 VFI configuration mode. To disable autodiscovery, use the **no** form of this command.

autodiscovery bgp signaling ldp

no autodiscovery bgp signaling ldp

This command has no arguments or keywords.

Command Default Layer 2 VFI autodiscovery is disabled.

Command Modes L2 VFI configuration (config-vfi)

Command History	Release	Modification
	--	This command was introduced in an earlier Cisco NX-OS release.

Examples The following example shows how to enable Layer 2 VFI as having BGP autodiscovered pseudowire members and specify that LDP signaling should be used for autodiscovery:

```
Device(config)# l2vpn vfi context vfi1
Device(config-vfi)# vpn id 100
Device(config-vfi)# autodiscovery bgp signaling ldp
Device(config-vfi-autodiscovery)#
```

boot poap

To reboot a device and apply the changes after you configure the device or install a new image, use the **boot poap** command in global configuration mode. To avoid rebooting the device, use the **no** form of this command.

boot poap [enable]

no boot poap

Syntax Description

enable	(Optional) Enables the boot POAP (Power On Auto Provisioning) functionality.
---------------	--

Command Modes

Global configuration (config)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

Rebooting the device is required in the following situations:

- If the configuration is supported only on the new image.
- If you configure the device after rebooting it.

You can avoid rebooting the device in the following situations:

- If there is no change in the image or in the configuration of device.
- If you want to apply only specific configuration updates on the device.

Examples

This example shows how to reboot a device after configuring the device or installing a new image:

```
Device# configure terminal
Device(config)# boot poap enable
```

Related Commands

Command	Description
copy scheduled-config	Configures a file that contains CLI commands and applies on the next reboot of the device.

bridge-domain

To enter bridge-domain configuration mode and configure a bridge domain, use the **bridge-domain** command. To remove the bridge-domain configurations, use the **no** form of this command.

bridge-domain *domain-id*

no bridge-domain *domain-id*

Syntax Description

<i>domain-id</i>	Specifies the Bridge-domain ID. The range is defined by the system-bridge-domain configuration.
------------------	---

Command Default

None

Command Modes

Global configuration mode

Command History

Release	Modification
--	This command was introduced in an earlier Cisco NX-OS release.

Usage Guidelines

Removing the bridge-domain configuration does not remove the underlying VLAN. If a VLAN is associated with a bridge domain, you cannot remove the VLAN without first removing the bridge domain. To remove the underlying VLAN, use the no vlan command after you remove the bridge domain. This command requires the MPLS Services license.

Examples

This example shows how to enter bridge-domain configuration mode and configure a bridge domain:

```
Device# configure terminal
Device(config)# bridge-domain 200
Device(config)#
```

checkpoint

To configure the rollback checkpoint, use the **checkpoint** command. To delete the checkpoint, use the **no** form of this command.

checkpoint {*name* | **description** *description* | **file** *name*}

no checkpoint

Syntax Description

<i>name</i>	Specifies the checkpoint name that is used in the checkpoint database. The name can contain any alphanumeric string up to 80 characters, without any spaces.
description <i>description</i>	Specifies the checkpoint description. The description can contain up to 80 alphanumeric characters, including space.
file <i>name</i>	Specifies the filename that is used to save the checkpoint.

Command Modes

Any command mode

Supported User Roles

network-admin

network-operator

vdc-admin

vdc-operator

Command History

Release	Modification
--	This command was introduced in an earlier Cisco NX-OS release.

Usage Guidelines

If you use the **checkpoint** command without a name, Cisco NX-OS software creates the file with the name auto-x, where x is a decimal number that increments each time you create an unnamed checkpoint file.

This command does not require a license.

Examples

This example shows how to configure the rollback checkpoint:

```
Device# checkpoint stable
```

This example shows how to delete the checkpoint file:

```
Device# no checkpoint
```

clear evb

To clear information associated with Edge Virtual Bridging (EVB), use the **clear evb** command in global configuration mode.

clear evb {**hosts**|**vsi**} [**force-standby**] [**interface ethernet** *slot-number*] [**ip** *ipv4-address*] [**ipv6** *ipv6-address*] [**mac** *mac-address*] [**vlan** *vlan-id*] [**vni** *vni-id*]

Syntax Description

hosts	Clears information about hosts in an EVB session.
vsi	Clears information about the Virtual Station Interface (VSI) in an EVB session.
force-standby	(Optional) Forces to clear standby entries in an EVB session.
interface ethernet <i>slot-number</i>	(Optional) Clears hosts or VSI entries by filtering interface.
ip <i>ipv4-address</i>	(Optional) Clears information about hosts or the VSI by filtering the IPv4 address.
ipv6 <i>ipv6-address</i>	(Optional) Clears information about hosts or the VSI by filtering the IPv6 address.
mac <i>mac-address</i>	(Optional) Clears information about hosts or the VSI by filtering the MAC address.
vlan <i>vlan-id</i>	(Optional) Clears information about hosts or the VSI by filtering the VLAN.
vni <i>vni-id</i>	(Optional) Clears information about hosts or the VSI by filtering the Virtual Network Identifier (VNI).

Command Default

None

Command Modes

Global configuration (config)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

Use the **feature evb** command to enable the EVB session.

Examples

This example shows how to clear information associated with an EVB session:

```
Device(config)# feature evb
Device(config)# clear evb hosts ip 192.0.2.1
```

Related Commands

Command	Description
feature evb	Enables the EVB session on a device.
clear evb statistics	Clears Edge Virtual Bridge (EVB) statistic counters.

clear evb statistics

To clear Edge Virtual Bridge (EVB) statistic counters, use the **clear evb statistics** command in global configuration mode.

clear evb statistics

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Global configuration (config)

Command History	Release	Modification
	7.0(0)N1(1)	This command was introduced.

Usage Guidelines Use the **feature evb** command to enable the EVB session. This command does not require a license.

Examples This example shows how to clear an EVB statistic counter:

```
Device(config)# feature evb  
Device(config)# clear evb statistics
```

Related Commands	Command	Description
	clear evb	Clears information associated with Edge Virtual Bridging (EVB).
	feature evb	Enables the EVB session on a device.

clear fabric access

To clear specific user sessions and disconnect specific user from the Extensible Messaging and Presence Protocol (XMPP) server, or to clear fabric access statistics, use the **clear fabric access** command in privileged EXEC mode.

clear fabric access{*statistics* | *user username*}

Syntax Description

statistics	Clears user statistics such as ping parameters.
user <i>username</i>	Clears the specified user connection.

Command Default

No statistics are cleared, and no session is cleared.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Examples

The following example show how to clear access statistics of the XMPP server:

```
Device# clear fabric access statistics
```

The following example show how to clear specific user sessions and disconnect a user specified as "spines":

```
Device# clear fabric access user spines
```

Related Commands

Command	Description
fabric access attach device	Attaches a remote device in the fabric network to an XMPP server.
fabric access attach group	Attaches a group of devices in the fabric network to an XMPP server.
fabric access create group	Creates one or more groups of devices on the fabric access network using the XMPP server.

clear fabric connectivity cable-plan

To clear the current cable plan, use the **clear fabric connectivity cable-plan** command in privileged EXEC mode.

clear fabric connectivity cable-plan

Syntax Description

This command has no arguments or keywords.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
6.0(2)N3(1)	This command was introduced.

Usage Guidelines

Before you import a new cable plan, use this command to clear the existing one.

To clear a cable plan that is already saved to the startup configuration, specify this command and then configure the **copy running-config startup-config** command.

Examples

The following example shows how to clear an existing cable plan:

```
Device(config)# feature lldp
Device(config)# feature cable-management
Device(config)# exit
Device# fabric connectivity cable-plan import bootflash:cp.xml

Success: Imported cable-plan: /bootflash/cp.xml
Device# clear fabric connectivity cable-plan
```

clear fabric connectivity neighbors

To clear all information about neighbors or subset of neighbors from the neighbor cache, use the **clear fabric connectivity neighbors** command in privileged EXEC mode.

clear fabric connectivity neighbors [**interface** {**ethernet** *slot-number/port-number* | **mgmt** *interface-number*}] **stale**]

Syntax Description

interface	(Optional) Clears cache of neighbors connected to an interface.
ethernet	(Optional) Specifies the Ethernet interface.
<i>slot-number/port-number</i>	(Optional) Slot number and port number.
mgmt <i>interface-number</i>	(Optional) Specifies the management interface and the interface number.
stale	(Optional) Clears neighbor cache information for stale or purged neighbors.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

Use this command to delete a single entry, all entries, or all error entries from the network neighbor cache. You should manually clear an already secured port in the neighbor cache if recabling is desired to immediately remove old or stale entries. If you have a switch that was previously in the network but has since gone stale (because it was removed or taken down), the only way to completely remove it from the neighbor cache is by using this command. You have to enable the cable management feature using the **feature cable-management** command to be able to use the **clear fabric connectivity neighbors** command.

Examples

The following example shows how to clear neighbor cache from the Ethernet interface:

```
Device# clear fabric connectivity neighbors interface ethernet 1/1
```

Related Commands

Command	Description
errdisable recovery cause	Enables automatic recovery of an application from an error-disabled state.
fabric connectivity cable-plan import	Imports a cable plan from a local or a remote location.

Command	Description
fabric connectivity mismatch action delay	Delays the port error-disable action on detecting cabling errors for a specified time.
fabric connectivity tier	Configures the tier level of a device.

clear fabric database statistics

To clear the external database statistics such as number of messages sent or received, pending requests, access errors, and access timeouts, use the **clear fabric database statistics** command in privileged EXEC mode.

Using LDAP or RADIUS

```
clear fabric database statistics [type {network | cabling | profile} [server-proto {ldap | radius} {host
hostname | ip ip-address} [port port-number]]]
```

Using XMPP

```
clear fabric database statistics [type {network | cabling | profile} [server-proto xmpp {host hostname |
ip ip-address} [port port-number] db-jid jid]]
```

Syntax Description

type	(Optional) Specifies the type of database.
network	(Optional) Specifies a network database.
cabling	(Optional) Specifies a cable management database.
profile	(Optional) Specifies a port or switch profile database.
server-proto	(Optional) Specifies a database protocol.
ldap	(Optional) Specifies the use of Lightweight Directory Access Protocol (LDAP).
radius	(Optional) Specifies the use of RADIUS.
xmpp	(Optional) Specifies the use of Extensible Messaging and Presence Protocol (XMPP).
host <i>hostname</i>	(Optional) Specifies the hostname of the server.
ip <i>ip-address</i>	(Optional) Specifies the IP address of the server.
port <i>port-number</i>	(Optional) Specifies the port number of the server.
db-jid <i>jid</i>	(Optional) Specifies the Jabber ID of the database.

Command Default

None

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

The **clear fabric database statistics** command is used to reset the database statistics counters to zero. But this command does not delete existing statistics memory. You can use the **show fabric database statistics** command to display per-server statistics including number of messages sent or received, pending requests, access errors, and timeouts.

Examples

The following example shows how to clear the database statistics of Jabber ID db@domain.com from the XMPP server:

```
Device# clear fabric database statistics type asset server-proto xmpp db-jid db@domain.com
```

Related Commands

Command	Description
show fabric database statistics	Displays fabric database statistics.

clear fabricpath oam loopback

To clear information about FabricPath Operation, Administration, and Maintenance (OAM) loopback, use the **clear fabricpath OAM loopback** command in privileged EXEC mode.

clear fabricpath oam loopback {**database** [**session** *session-handle*] | **session** *session-handle* | **statistics** [**session** *session-handle* | **summary**]}

Syntax Description

database	Clears information about FabricPath OAM loopback database.
session <i>session-handle</i>	Clears information about the FabricPath OAM loopback for a specific session.
statistics	Clears information about FabricPath OAM loopback statistics.
summary	Clears summary information about fabricpath OAM loopback statistics.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

To clear statistics for all sessions, use the **clear fabricpath oam loopback statistics** command. To clear statistics for a particular session, use the **clear fabricpath oam loopback statistics session** command. To clear summary statistics, use the **clear fabricpath oam loopback statistics summary** command.

Examples

The following example shows how to clear the FabricPath OAM loopback statistics.

```
Device# clear fabricpath oam loopback statistics
```

Related Commands

Command	Description
show fabricpath oam loopback	Shows statistics for FabricPath OAM loopback.

clear FabricPath oam mtrace

To clear information about FabricPath Operation, Administration, and Maintenance (OAM) mtrace, use the **clear fabricpath oam mtrace** command in privileged EXEC mode.

clear fabricpath oam mtrace {**database** [*session session-handle*] | **statistics** [**summary**]}

Syntax Description

database	Clears information about the FabricPath OAM mtrace database.
session <i>session-handle</i>	(Optional) Clears information about the FabricPath OAM mtrace for a specific session.
statistics	Clears FabricPath OAM mtrace statistics.
summary	(Optional) Clears FabricPath OAM mtrace statistics summary.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Examples

The following example shows how to clear the FabricPath OAM mtrace statistics command.

```
Device# clear fabricpath OAM mtrace statistics
```

Related Commands

Command	Description
show fabricpath oam mtrace	Shows statistics for fabricpath OAM mtrace.

clear fabripath oam notification

To clear information about FabricPath Operation, Administration, and Maintenance (OAM) notification, use the **clear fabricpath oam notification** command in privileged EXEC mode.

clear fabricpath oam notification {**database** | **statistics**}

Syntax Description

database	Clears information about FabricPath OAM notification database.
statistics	Clears information about FabricPath OAM notification statistics.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Examples

The following example shows how to clear the FabricPath OAM notification statistics command.

```
Device (#) clear fabricpath OAM notification statistics
```

Related Commands

Command	Description
show fabricpath oam notification	Shows information about for FabricPath OAM notification.

clear fabricpath oam traceroute

To clear information about FabricPath Operation, Administration, and Maintenance (OAM) traceroute, use the **clear fabricpath oam traceroute** command in privileged EXEC mode.

clear fabricpath oam traceroute {**database** [*session session-handle*] | **statistics** [**summary**]}

Syntax Description

database	Clears information about FabricPath OAM traceroute database.
session <i>session-handle</i>	(Optional) Clears information about for FabricPath OAM traceroute for a specific session.
statistics	Clears FabricPath OAM traceroute statistics.
summary	(Optional) Clears FabricPath OAM traceroute statistics summary.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Examples

The following example shows how to clear the FabricPath OAM traceroute statistics command.

```
Device# clear fabricpath OAM traceroute statistics
```

Related Commands

Command	Description
show fabric oam traceroute	Shows statistics for FabricPath OAM traceroute.

configure profile

To configure a profile, use the **configure profile** command in privileged EXEC mode. To remove a configured profile, use the **no** form of this command.

configure profile *profile-name*

no configure profile *profile-name*

Syntax Description

<i>profile-name</i>	Name of the profile to be configured.
---------------------	---------------------------------------

Command Default

A profile is not configured.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
6.0(2)N3(1)	This command was introduced.

Usage Guidelines

You can specify a maximum of 80 characters for the *profile-name* argument. Once you configure a profile name, this profile is available in the list of profiles that can be used to configure profile parameters. Use the **show running-config** command to display all configured profiles and their parameters.

When you configure a profile, the command mode changes to configuration profile mode. You can configure profile parameters into a template in the configuration profile mode.

Use the **show config-profile** command to view the list of configured profiles.

Examples

The following example shows how to configure a profile named pname:

```
Device# configure profile pname
Device(config-profile)#
```

The following example shows how to configure profile parameters in the configuration profile mode:

```
Device# configure profile sample
Device(config-profile)# vrf context sample-vrf
Device(config-profile-vrf)# end
```

copy scheduled-config

To configure a file containing CLI commands that you want to apply on the next reboot of the device, use the **copy scheduled-config** command in any command mode.

copy *filename* **scheduled-config**

Syntax Description

<i>filename</i>	Name of the configuration file .
scheduled-config	Specifies the schedule of the configuration at the specified source to apply on the next reboot of the device.

Command Default

None

Command Modes

Any command mode

Supported User Roles

network-admin

vdc-admin

Command History

Release	Modification
--	This command was introduced in an earlier Cisco NX-OS release.

Usage Guidelines

The **copy scheduled-config** command specifies the schedule of the configuration at the specified source to apply on the next reboot of the device. This command must be called explicitly within the POAP (Power On Auto Provisioning) script to allow the POAP boot process to continue at the next reboot. When PowerOn Auto Provisioning (POAP) is in progress, any important information or errors are displayed over the serial console, aiding the administrator to troubleshoot in case of problems.

This command does not require a license.



Note

This command is used in POAP script.

Examples

This example shows how to specify that the abc file to be applied to the running configuration when the device next reloads:

```
Device# configure terminal
```

```
Device(config)# copy abc scheduled-config
```

db-jid

To configure the Jabber ID of the database using Extensible Messaging and Presence Protocol (XMPP), use the **db-jid** command in fabric database server configuration mode. To remove the Jabber ID of the database, use the **no** form of this command.

db-jid *jid* [**key-type** *key-type-value*]

no db-jid *jid* [**key-type** *key-type-value*]

Syntax Description

<i>jid</i>	Jabber ID of the database.
key-type <i>key-type-value</i>	(Optional) Specifies the key type for the database queries. The valid value is 1.

Command Default

Jabber ID of the database is not configured.

Command Modes

Fabric database server configuration (config-fabric-db-server)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

You can specify the Jabber ID to which the database manager sends search queries by using the **db-jid** command.

Examples

The following example shows how to configure the Jabber ID db@domain.com using XMPP:

```
Device# configure
Device(config)# fabric database type asset
Device(config-fabric-db)# server protocol xmpp host host1
Device(config-fabric-db-server)# db-jid db@domain.com key-type 1
```

Related Commands

Command	Description
db-table	Configures a database table using LDAP.
user-jid	Configures the Jabber ID and password of the switch that is used to connect to the server.

db-security

To configure a database security, use the **db-security** command in fabric database server configuration mode.

db-table user *username* **password** *password* [**shared-secret** *name*]

no db-table user *username* **password** *password* [**shared-secret** *name*]

Syntax Description

user <i>username</i>	User ID.
password <i>password</i>	Password.
shared-secret <i>name</i>	Shared secret.

Command Default

The database security is not configured.

Command Modes

Fabric database server configuration (config-fabric-db-server)#

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

You can specify the database security mechanism by using the **db-security** command.

Examples

```
device# configure
device(config)# fabric database type network
device(config-fabric-db)# server protocol ldap host host1
device(config-fabric-db-server)# db-table ou=networks,dc=host,dc=com key-type 1
device(config-fabric-db-server)# db-security user cn=admin,dc=cisco,dc=com password cisco123
```

Related Commands

Command	Description
db-jid	Configures the Jabber ID of the database using XMPP.
db-table	Configures a database table using LDAP.

db-table

To configure a database table using Lightweight Directory Access Protocol (LDAP), use the **db-table** command in fabric database server configuration mode. To remove the database table, use the **no** form of this command.

db-table *table-name* [**key-type** *key-type-value*]

no db-table *table-name* [**key-type** *key-type-value*]

Syntax Description

<i>table-name</i>	Name of the database table.
key-type <i>key-type-value</i>	(Optional) Specifies the key type for the database queries. The valid value is 1.

Command Default

The database table is not configured.

Command Modes

Fabric database server configuration (config-fabric-db-server)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

You can specify the database table name to which the database manager sends search queries by using the **db-table** command.

Examples

The following example shows how to configure a database table using LDAP:

```
Device# configure terminal
Device(config)# fabric database type network
Device(config-fabric-db)# server protocol ldap host host1
Device(config-fabric-db-server)# db-table ou=networks,dc=host,dc=com key-type 1
```

Related Commands

Command	Description
db-jid	Configures the Jabber ID of the database using XMPP.

debug evb

To enable debugging of events associated with an Edge Virtual Bridging (EVB) session, use the **debug evb** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

debug evb {all | cli | errors | events | ha | periodic | pss | trace | verbose}

no debug evb {all | cli | errors | events | ha | periodic | pss | trace | verbose}

Syntax Description

all	Enables debugging of all events in an EVB session.
cli	Enables debugging of CLI command processing events only.
errors	Enables debugging of only errors in an EVB session.
events	Enables debugging of only general events in an EVB session.
ha	Enables debugging of only High Availability (HA) related events in an EVB session.
periodic	Enables debugging of only periodic events in an EVB session.
pss	Enables debugging of only persistent storage service (PSS) related events in an EVB session.
trace	Enables debugging of detailed processing traces in an EVB session.
verbose	Enables debugging of verbose mode in an EVB session.

Command Default

Debugging of events in an EVB session is disabled.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

Use the **feature evb** command to enable the EVB session. This, in turn, enables the **debug evb** command on the device.

Examples

The following example shows how to enable debugging of detail processing traces in an EVB session:

```
Device# configure terminal  
Device(config)# feature evb  
Device(config)# end  
Device# debug evb errors events
```

The following is sample output from the **show debug evb** command in an EVB session:

```
Device# show debug evb  
  
Debugs Enabled: errors events
```

default-information originate

To configure a Border Gateway Protocol (BGP) routing process to distribute a default route (network 0.0.0.0), use the **default-information originate** command in address family configuration mode. To disable the advertisement of a default route, use the **no** form of this command.

default-information originate

no default-information originate

Syntax Description This command has no arguments or keywords.

Command Modes Address family configuration (config-router-af)

Command History	Release	Modification
	7.0(0)N1(1)	This command was introduced.

Usage Guidelines The **default-information originate** command is used to configure a BGP routing process to advertise a default route (network 0.0.0.0). A redistribution statement must also be configured to complete this configuration or the default route will not be advertised.

Examples The following example configuration shows how to originate and redistribute a default route (0.0.0.0/0) in BGP:

```
Device(config)# router bgp 100
Device(config-router)# address-family ipv4 unicast
Device(config-router-af)# default-information originate
Device(config-router-af)# end
```

Related Commands	Command	Description
	address-family	Configures multicast VPN.

define

To create user-defined parameters for a parameter list, use the **define** command in parameter list configuration mode. To remove user-defined parameters from a parameter list, use the **no** form of this command.

define *parameter-name* [**integer**|**ipaddr**|**ipv6addr**|**mac-addr**|**string**] [*value*]

no define *parameter-name* [**integer**|**ipaddr**|**ipv6addr**|**mac-addr**|**string**] [*value*]

Syntax Description

<i>parameter-name</i>	Parameter name.
integer	(Optional). Specifies the data type as an integer.
ipaddr	(Optional). Specifies the address as an IPv4 address.
ipv6addr	(Optional). Specifies the address as an IPv6 address.
mac-addr	(Optional). Specifies the address as a MAC address.
string	(Optional). Specifies the data type as a string.
<i>value</i>	(Optional). Parameter data type or address type value or parameter description. <ul style="list-style-type: none"> • Use the <i>value</i> argument with the parameter name to describe the parameter. • Use the <i>value</i> argument with a data type or address type to assign a value.

Command Default

User-defined parameters are not created.

Command Modes

Parameter list configuration (config-param-list)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

User-defined parameters that you create using the **define** command are associated with a parameter list. A parameter list can be created using the **param-list** command.

You can use existing user-defined parameters and associate values (such as integer, IP address, and MAC address) to them.

Examples

The following example shows how to create a user-defined parameter param1 within the specified parameter list List1:

```
Device# configure terminal
Device(config)# param-list List1
Device(config-param-list)# define param1 integer 100
Device(config-param-list)# exit
```

Related Commands

Command	Description
instance	Configures a parameter list instance.

description (fabricpath-oam)

To configure a description for a FabricPath Operation, Administration, and Maintenance (OAM) profile, use the **description** command in FabricPath OAM profile configuration mode. To remove the FabricPath OAM profile description, use the **no** form of this command.

description *description*

no description

Syntax Description

<i>description</i>	The description for the FabricPath OAM profile. The range is 1 to 64 characters.
--------------------	--

Command Default

A description for the FabricPath OAM profile is not configured.

Command Modes

FabricPath OAM profile configuration (config-fp-oam-profile)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Examples

The following shows how to configure a description for a FabricPath OAM profile.

```
Device(config)# fabricpath oam profile 100
Device (config-fp-oam-profile)# description profile-description
```

Related Commands

Command	Description
fabricpath oam profile	Configures a FabricPath OAM profile.

dot1q (fabricpath-oam)

To specify that a FabricPath Operation, Administration, and Maintenance (OAM) flow profile must include a dot1q tag, use the **dot1q** command in FabricPath oam flow profile configuration mode. To remove the dot1q tag, use the **no** form of this command.

dot1q *vlan-id* [*cos service-value*]

no dot1q

Syntax Description

<i>vlan-id</i>	Specifies the flow profile VLAN ID.
cos <i>service-value</i>	(Optional) Specifies the class of service (CoS). The range is from 0 to 7.

Command Default

Dot1q tag is not included in the FabricPath OAM flow profile.

Command Modes

FabricPath OAM flow profile (config-fp-oam-profile-flow)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

802.1Q tunneling enables service providers to use a single VLAN to support customers who have multiple VLANs, while preserving customer VLAN IDs and keeping traffic in different customer VLANs segregated. Use this command to enter 802.1Q or 802.1ad configuration with CoS value.

Examples

The following example shows how to configure a FabricPath OAM flow profile and specify a 802.1Q tag.

```
Device(config)# fabricpath oam profile 100
Device (config-fp-oam-profile)# flow forward
Device (config-fp-oam-profile-flow)# dot1q 100 cos 5
```

Related Commands

Command	Description
fabricpath oam profile	Configures a FabricPath OAM profile.
flow (fabricpath-oam)	Configures the direction FabricPath OAM flow entropy.

encapsulation dot1Q

To enable IEEE 802.1Q encapsulation of traffic on a specified subinterface in a virtual LAN (VLAN), use the **encapsulation dot1q** command. To disable encapsulation, use the **no** form of this command.

encapsulation dot1Q *vlan-id*

no encapsulation dot1Q *vlan-id*

Syntax Description

<i>vlan-id</i>	Specifies the VLAN to set when the interface is in access mode. The range is from 1 to 4094 except for the VLANs reserved for internal switch use.
----------------	--

Command Default

No encapsulation

Command Modes

Subinterface configuration mode

Command History

Release	Modification
- -	This command was introduced in an earlier Cisco NX-OS release.

Usage Guidelines

IEEE 802.1Q encapsulation is configurable on Ethernet interfaces. IEEE 802.1Q is a standard protocol for interconnecting multiple switches and routers and for defining VLAN topologies.

Use the **encapsulation dot1q** command in subinterface range configuration mode to apply a VLAN ID to the subinterface.

This command does not require a license.

Examples

This example shows how to enable dot1Q encapsulation on a subinterface for VLAN 30:

```
Device(config-if)# interface fastethernet 4/1.100  
Device(config-subif)# encapsulation dot1q 30
```

errdisable detect cause

To enable error-disable (errdisable) detection for an application, use the **errdisable detect cause** command in global configuration mode. To disable error-disable detection, use the **no** form of this command.

errdisable detect cause {acl-exception | all | link-flap | loopback | miscabbling}

no errdisable detect cause {acl-exception | all | link-flap | loopback | miscabbling}

Syntax Description

acl-exception	Enables error-disabled detection for access-list installation failures.
all	Enables error-disabled detection for all causes.
link-flap	Enables error-disabled detection on link-state flapping.
loopback	Enables error-disabled detection on loopback detected by unidirectional link detection (UDLD).
miscabbling	Enables error-disabled detection on a miscabled port.

Command Default

Error-disable detection is enabled.

Command Modes

Global configuration (config)

Command History

Release	Modification
—	This command was introduced in a release earlier than Cisco NX-OS Release 7.0(0)N1(1).
7.0(0)N1(1)	This command was modified. The miscabbling keyword was added.

Examples

The following example shows how to disable error-disabled detection on a miscabled port:

```
Device# configure terminal
Device(config)# no errdisable detect cause miscabbling
```

Related Commands

Command	Description
errdisable recovery cause	Enables automatic recovery of an application from an error-disabled state.

Command	Description
errdisable recovery interval	Configures the error disable recovery timer.
fabric connectivity cable-plan import	Imports a cable plan from a local or a remote location.
show interface status err-disabled	Displays information about interfaces that are in error-disabled state.

errdisable recovery cause

To enable automatic recovery of an application from an error-disabled (errdisable) state, use the **errdisable recovery cause** command in global configuration mode. To return to the default setting, use the **no** form of this command.

errdisable recovery cause {all | bpduguard | failed-port-state | link-flap | loopback | miscabling | psecure-violation | security-violation | storm-control | udld | vpc-peerlink}

errdisable recovery cause {all | bpduguard | failed-port-state | link-flap | loopback | miscabling | psecure-violation | security-violation | storm-control | udld | vpc-peerlink}

Syntax Description

all	Enables the timer to recover from all causes.
bpduguard	Enables the timer to recover from the bridge protocol data unit (BPDU) guard error disable state.
failed-port-state	Enables the timer to recover from the Spanning Tree Protocol (STP) set port state failure.
link-flap	Enables the timer to recover from link-state flapping.
loopback	Enables timer to recover from the loopback error disabled state detected by Unidirectional Link Detection (UDLD).
miscabling	Enables the timer to automatically recover miscabled ports from an error-disabled state.
psecure-violation	Enables the timer to recover from the psecure-violation disable state.
security-violation	Enables the timer to recover from the 802.1x violation disable state.
storm-control	Enables the timer to recover from the storm control error-disabled state.
udld	Enables the timer to recover from the UDLD error-disabled state.
vpc-peerlink	Enables the timer to recover from an inconsistent virtual port channel (vPC) peer-link error-disabled state.

Command Default

Automatic recovery of any application from an error-disabled state is disabled.

Command Modes

Global configuration (config)

Command History

Release	Modification
—	This command was introduced in a release earlier than Cisco NX-OS Release 7.0(0)N1(1).
7.0(0)N1(1)	This command was modified. The miscabling keyword was added.

Usage Guidelines

Use the **errdisable recovery cause** command to enable an automatic recovery of an application on the interface from an error-disabled state. This command tries to bring the interface out of the error-disabled state once all the causes have timed out. The interface automatically tries to come up again after 300 seconds. To change this interval, use the **errdisable recovery interval** command.

This command does not require a license.

Examples

This example shows how to automatically recover miscabled ports from an error-disabled state:

```
Device# configure terminal
Device(config)# errdisable recovery cause miscabling
```

Related Commands

Command	Description
errdisable detect cause	Enables error-disable detection for an application.
errdisable recovery interval	Configures the error disable recovery timer.
fabric connectivity cable-plan import	Imports a cable plan from a local or a remote location.
show interface status err-disabled	Displays information about interfaces that are in error-disabled state.

errdisable recovery interval

To configure the error disable recovery timer, use the **errdisable recovery interval** in global configuration mode. To remove this configuration, use the **no** form of this command.

errdisable recovery interval *interval*

no errdisable recovery interval

Syntax Description

<i>interval</i>	Timer interval in seconds. The range is from 30 to 65535.
-----------------	---

Command Default

The default is 300 seconds.

Command Modes

Global configuration (config)

Command History

Release	Modification
—	This command was introduced in a release earlier than Cisco NX-OS Release 7.0(0)N1(1).

Usage Guidelines

Use the **errdisable recovery interval** command to configure the recovery timer. This command does not require a license.

Examples

This example shows how to configure the recovery timer:

```
Device# configure terminal
Device(config)# errdisable recovery interval 32
```

Related Commands

Command	Description
errdisable detect cause	Enables error-disable detection for an application.
errdisable recovery cause	Enables automatic recovery of an application from an error-disabled state.
fabric connectivity cable-plan import	Imports a cable plan from a local or a remote location.
show interface status err-disabled	Displays information about interfaces that are in error-disabled state.

ether-type (fabricpath-oam)

To configure the FabricPath Operation, Administration, and Maintenance (OAM) flow profile ether-type, use the **ether-type** command in FabricPath OAM flow profile configuration mode. To remove the ether-type, use the **no** form of this command.

ether-type *ether-type*

no ether-type

Syntax Description

<i>ether-type</i>	The flow profile ether-type. The range is from 0x0 to 0xffff.
-------------------	---

Command Default

Flow profile ether-type is not configured.

Command Modes

FabricPath OAM profile configuration (config-fp-oam-profile)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

Ether-type is the payload of an Ethernet Frame. In the FabricPath OAM packet header, the ether type comes after VLAN.

Examples

The following shows how to configure a description for a FabricPath OAM profile.

```
Device(config)# fabricpath oam profile 100
Device (config-fp-oam-profile)# ether-type 0x8903
```

Related Commands

Command	Description
fabricpath oam profile	Configures a FabricPath OAM profile.

evb mac

To configure the Virtual Station Interface (VSI) Discovery and Configuration Protocol (VDP) multicast MAC address for the Edge Virtual Bridge (EVB) feature on a device, use the **evb mac** command in global configuration mode. To return to the default, use the **no** form of this command.

evb mac *mac-address*

no evb mac *mac-address*

Syntax Description

<i>mac-address</i>	VDP multicast MAC address.
--------------------	----------------------------

Command Default

The VDP multicast MAC address for EVB is not configured.

Command Modes

Global configuration (config)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

To configure the device to use a VDP multicast MAC address, the EVB feature needs to be enabled globally on the device using the **feature evb** command.

Examples

This example shows how to configure a VDP multicast MAC address:

```
Device(config)# feature evb
Device(config)# evb mac 01-23-45-67-89-ab
```

Related Commands

Command	Description
feature evb	Enables the EVB session on a device.

evb reinit-keep-alive

To configure the Virtual Station Interface (VSI) Discovery and Configuration protocol (VDP) keepalive parameter for the Edge Virtual Bridging (EVB) feature on a device, use the **evb reinit-keep-alive** command in global configuration mode. To return to the default, use the **no** form of this command.

evb reinit-keep-alive *timer*

no evb reinit-keep-alive *timer*

Syntax Description

<i>timer</i>	Timer exponent to calculate the keepalive time in seconds. The range is from 20 to 31.
--------------	--

Command Default

The default reinit-keep-alive timer exponent is 22.

Command Modes

Global configuration (config)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

Use the **feature evb** command to enable the EVB feature globally on the device before configuring the keepalive parameter. After a VDP request is successful, a refresh request is expected within the keep-alive time. If the refresh request is not received within the keepalive time, device revokes the configuration changes. You must configure the correct reinit-keepalive EVB parameter to align with the network scale as each virtual machine contributes a refresh message as per the keepalive time.

Examples

The following examples shows how to configure the keepalive parameter for EVB:

```
Device(config)# feature evb  
Device(config)# evb reinit-keep-alive 21
```

Related Commands

Command	Description
evb resource-wait-delay	Configures the resource wait delay parameter for EVB.
feature evb	Enables the EVB session on a device.

evb resource-wait-delay

To configure the Virtual Station Interface (VSI) Discovery and Configuration protocol (VDP) resource wait delay parameter for the Edge Virtual Bridge (EVB) feature on a device, use the **evb resource-wait-delay** command in global configuration mode. To return to the default, use the **no** form of this command.

evb resource-wait-delay *timer*

no evb resource-wait-delay *timer*

Syntax Description

<i>timer</i>	Timer exponent to calculate the actual delay in seconds. The range is from 20 to 31.
--------------	--

Command Default

The default resource wait delay timer exponent is 20.

Command Modes

Global configuration (config)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

Use the **feature evb** command to enable the EVB feature globally on the device before configuring the resource wait delay parameter.

When a VDP request is received, a series of configuration changes are triggered on the device. The resource-wait-delay parameter indicates the maximum waiting time for a device to complete the configuration change. If the change is not completed within the wait delay parameter, then the VDP request fails. You can configure the resource-wait-delay EVB parameter to align with specific configuration scale and requirement.

Examples

The following example shows how to configure the VDP resource wait delay parameter:

```
Device(config)# feature evb
Device(config)# evb resource-wait-delay 25
```

Related Commands

Command	Description
evb reinit-keep-alive	Configures the keepalive parameter for EVB.
feature evb	Enables the EVB session on a device.

fabric access attach device

To attach a remote device in the fabric network to an Extensible Messaging and Presence Protocol (XMPP) server, use the **fabric access attach device** command in privileged EXEC mode.

fabric access attach device *device-name*

Syntax Description

<i>device-name</i>	Name of the remote device in the fabric network.
--------------------	--

Command Default

The remote device is not attached.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Examples

The following example shows how to attach a remote device to the XMPP server:

```
Device# fabric access attach device device1
```

Related Commands

Command	Description
clear fabric access	Clears specific user sessions and disconnect a specific user from the XMPP server, or clears fabric access statistics.
fabric access attach group	Attaches a group of devices in the fabric network to an XMPP server.
fabric access create group	Creates one or more groups of devices on the fabric access network using the XMPP server.

fabric access attach group

To attach a group of devices in the fabric network to an Extensible Messaging and Presence Protocol (XMPP) server, use the **fabric access attach group** command in privileged EXEC mode.

fabric access attach group *group-name*

Syntax Description

<i>group-name</i>	Name of the group of devices.
-------------------	-------------------------------

Command Default

The group of devices in the fabric network is not attached to the XMPP server.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

A group may consist of only one device.

Examples

The following example shows how to attach a group of devices to the fabric network through the XMPP server:

```
Device# fabric access attach group group1
```

Related Commands

Command	Description
clear fabric access	Clears specific user sessions and disconnect a specific user from the XMPP server, or clears fabric access statistics.
fabric access attach device	Attaches a remote device in the fabric network to an XMPP server.
fabric access attach group	Attaches a group of devices in the fabric network to an XMPP server.
fabric access create group	Creates one or more groups of devices on the fabric access network using the XMPP server.

fabric access create group

To create one or more groups of devices on the fabric access network using the Extensible Messaging and Presence Protocol (XMPP) server, use the **fabric access create group** command in privileged EXEC mode. To remove one or more groups of devices from the fabric access network, use the **no** form of this command.

fabric access create group *group-name1* [*group-name2*, *group-name3*...]

no fabric access create group *group-name1* [*group-name2*, *group-name3*...]

Syntax Description

<i>group-name1</i>	Name of the group of devices.
[<i>group-name2</i> , <i>group-name3</i> ...]	[Optional] Names of additional groups.

Command Default

A fabric access group is not created.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

A group may consist of only one device.

Examples

The following example shows how to create a group on the fabric access network using the XMPP server:

```
Device# fabric access create group group1
```

Related Commands

Command	Description
clear fabric access	Clears specific user sessions and disconnect a specific user from the XMPP server, or clears fabric access statistics.
fabric access attach device	Attaches a remote device in the fabric network to an XMPP server.

fabric access group

To configure a group to which the switch needs to join or subscribe to in a fabric access network, use the **fabric access group** command in global configuration mode. To remove the switch from a group, use the **no** form of this command.

fabric access group *group-name-1* [*group-name-2*, *group-name-3*,...]

no fabric access group

Syntax Description

<i>group-name-1</i>	Name of the group to which the switch needs to join or subscribe to.
[<i>group-name-2</i> , <i>group-name-3</i> , ...]	(Optional) Name of the additional groups.

Command Default

A switch in a fabric access network is not joined to any group.

Command Modes

Global configuration (config)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

Switches do not join all the groups in a fabric access network by default. The **fabric access group** command should be configured on all or required switches across the network in order to enable the switches to join the specified group(s) in a network.

Examples

The following example shows how to configure a switch to subscribe to group “spines” and group “rr”:

```
Device(config)# fabric access group spines rr
```

Related Commands

Command	Description
fabric access local-help	Gets the online command syntax help using the currently logged-in switch.
fabric access login	Logs in to a fabric access server.

fabric access local-help

To get the online command syntax help using the currently logged-in local switch instead of remote switches accessed via the fabric access group chat, use the **fabric access local-help** command in privileged EXEC mode. To disable the online help on the currently logged-in local switch, use the **no** form of this command.

fabric access local-help

no fabric access local-help

Syntax Description

This command has no arguments or keywords.

Command Default

Online help is not enabled for the currently logged-in local switch in the fabric access group chat mode.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

Online help can be used to find the available options after typing in a keyword. By default, online help is executed on the remote devices that generate several keyword options for each device in a network. To retrieve only those keywords related to the currently logged in device, the **fabric access local-help** command is used.

Examples

The following example shows how to enable the online-help option only for the currently logged-in local device in the fabric access group chat mode:

```
Device(config)# fabric access local-help
```


fabric access login

To log in to the fabric access server, use the **fabric access login** command in privileged EXEC mode. To log out of the server, use the **no** form of this command.

fabric access login *password*

no fabric access login

Syntax Description

<i>password</i>	Password for users to log in to the fabric access server. A password can contain any combination of alphanumeric characters.
-----------------	--

Command Default

Users are not logged in to the fabric access server.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Examples

The following example shows how to log in to the fabric access server:

Device# **fabric access login cisco123**

Related Commands

Command	Description
fabric access local-help	Gets the online command syntax help using the currently logged-in switch.
fabric access group	Configures a group to which the switch needs to join or subscribe to in a fabric access network.

fabric access ping

To check the network reachability of the switch to the fabric access server and to enable the Extensible Messaging and Presence Protocol (XMPP) ping, use the **fabric access ping** command in global configuration mode. To disable the ping, use the **no** form of this command.

fabric access ping [*interval seconds response seconds retry time*]

no fabric access ping

Syntax Description

interval <i>seconds</i>	(Optional) Specifies the frequency of XMPP ping messages that are sent out. The default interval is 60 seconds. The range is from 30 to 180.
response <i>seconds</i>	(Optional) Specifies the expected time to receive a ping response from the fabric access server. The default response value is 10 seconds. The range is from 3 to 30.
retry <i>time</i>	(Optional) Specifies the number of ping messages that are sent without receiving a successful response from the fabric access server. The default retry value is 5. The range is from 1 to 5.

Command Default

The network connectivity of the fabric access server is not verified.

Command Modes

Global configuration (config)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Examples

The following example shows how to configure the switch to send XMPP ping message to the fabric access server at a 120-second interval, with a 20-second response time expectancy and with and three retries:

```
Device(config)# fabric access ping interval 120 response 20 retry 3
```

Related Commands

Command	Description
fabric access group	Configures a group to which the switch needs to join or subscribe to in a fabric access network.

fabric access prepend-id

To enable the display of the device ID in the response message of a remote device in the fabric access group chat, use the **fabric access prepend-id** command in global configuration mode. To remove the device ID in the response message, use the **no** form of this command.

fabric access prepend-id

no fabric access prepend-id

Syntax Description This command has no arguments or keywords.

Command Default The device ID of a remote device is not displayed in the response message.

Command Modes Global configuration (config)

Command History	Release	Modification
	7.0(0)N1(1)	This command was introduced.

Usage Guidelines The **fabric access prepend-id** command enables the user to identify the device ID of a remote device from where the response was generated. This identification enables the local grep to find information about a specific device in a network using the device ID.

Examples The following example shows how to enable the device ID being displayed in the response message of a remote device:

```
Device(config)# fabric access prepend-id
```

Related Commands	Command	Description
	fabric access group	Configures a group to which the switch needs to join or subscribe to in a fabric access network.

fabric access send device

To send a command to a host device or a list of host devices without entering the fabric access group chat mode, use the **fabric access send device** command in privileged EXEC mode.

fabric access send device *device-jid1* [*device-jid2...device-jidn*] "*cli-command*"

Syntax Description

<i>device-jid</i>	The Jabber ID (JID) of the single peer device to be addressed. Multiple device JIDs (<i>device-jid2...device-jidn</i>) can also be specified.
" <i>cli-command</i> "	The command to be executed at the device(s) whose JID(s) are listed as the recipient(s) of this command. <ul style="list-style-type: none"> The CLI command must be within quotation marks.

Command Default

A command is not sent to the host device.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

To ensure the remote device is in the correct mode to accept the command(s), start the message to be sent with an **"end"** keyword followed by a space, semicolon, and the command. If there are multiple commands to be sent, each command should be separated by a space and semicolon.

Examples

The following example shows how to send a command to a host device with the JID p3-ac13-64t to enable **"feature lldp"** on that device:

```
Device(config)# fabric access send device p3-ac13-64t "end; conf; feature lldp"
```

The following example shows how to send a command to **"show host name"** on a list of host devices with the JIDs p1-sp1-48p, p1-sp2-48p, and p3-ac13-64t:

```
Device(config)# fabric access send device p1-sp1-48p p1-sp2-48p p3-ac13-64t "show hostname"
```

Related Commands

Command	Description
fabric access send group	Sends a CLI command to a group of devices without entering fabric access group chat mode.

fabric access send group

To send a CLI command to a group of devices without entering fabric access group chat mode, use the **fabric access send group** command in EXEC mode.

fabric access send group *group-name* "*cli-command*"

Syntax Description

<i>group-name</i>	Name of the group in the fabric access network to which messages are sent.
<i>"cli-command"</i>	CLI command to be executed for a group of devices in a fabric access network. Note The CLI command must be within quotation marks.

Command Default

No command is sent.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

Use the **fabric access send group** command to send CLI commands to a group in a fabric access network without entering fabric access group chat mode.



Note

You need to enable the fabric access feature to use the **fabric access send group** command. Use the **feature fabric access** command to enable fabric access on a device.

Examples

This example shows how to send CLI commands to a group with the group name "spines" in a fabric access network:

```
Device(config)# feature fabric access
Device(config)# exit
Device# fabric access send group spines "show hostname"
```

Related Commands

Command	Description
feature fabric access	Enables the fabric access feature for a fabric network.

Command	Description
fabric access send device	Sends a command to a host device or a list of host devices without entering the fabric access group chat mode.

fabric access server

To configure the fabric access server to be connected to from a device, use the **fabric access server** command in global configuration mode. To disconnect the device from the fabric access server, use the **no** form of this command.

fabric access server *dns-name* [**vrf** {*vrf-name*| **default** | **management**}] [**device** *device-name*] [**password** *password-name*]

no fabric access server

Syntax Description

<i>dns-name</i>	Fabric network server domain name.
vrf	(Optional) Configures virtual routing and forwarding (VRF) information for a fabric access server.
<i>vrf-name</i>	(Optional) Name of the VRF.
default	(Optional) Configures the default VRF name.
management	(Optional) Configures the management VRF name.
device	(Optional) Configures the device in the fabric network.
<i>device-name</i>	(Optional) Name of the device to be configured in the fabric network.
password	(Optional) Configures the password for a device in the fabric network.
<i>password-name</i>	(Optional) Password for the device.

Command Default

A fabric access server is not configured in a fabric network.

Command Modes

Global configuration (config)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

Use the **fabric access server** command to configure the fabric access server to be connected from the device that needs to be added to the fabric network. You need to configure the device name and password for the

device in the fabric access server. The device name has to be a unique name in the network on a fabric access server.

**Note**

You need to enable the fabric access feature to access and view the **fabric access server** command. Use the **feature fabric access** command to enable the fabric access feature on a device.

Examples

This example shows how to configure a fabric access server in a fabric network:

```
Device(config)# feature fabric access  
Device(config)# fabric access server host1.cisco.com management password test
```

Related Commands

Command	Description
feature fabric access	Enables the fabric access feature for a fabric network.
show fabric access connections	Displays the connection status of a device or a user that is connected in the fabric access network.

fabric connectivity cable-plan enforce

To enforce an imported cable plan, use the **fabric connectivity cable-plan enforce** command in global configuration mode. To stop enforcing a cable plan, use the **no** form of this command.

fabric connectivity cable-plan enforce

no fabric connectivity cable-plan enforce

Syntax Description This command has no arguments or keywords.

Command Default A cable plan is not enforced.

Command Modes Global configuration (config)

Command History	Release	Modification
	6.0(2)N3(1)	This command was introduced.

Usage Guidelines When the **fabric connectivity cable-plan enforce** command is configured, all type, length, value (TLV) fields received on a device are checked against the enforced cable plan. If no cable plan is enforced, checks are ignored.

After importing a cable plan if the cable plan is not enforced or if the **no fabric connectivity cable-plan enforce** command is configured, all cable plan checks are disabled. However, the imported cable plan will remain in the device.

Use the **show fabric connectivity cable-plan** command to view the currently enforced cable plan.

Examples The following example shows how to enforce an already imported cable plan:

```
Device(config)# fabric connectivity cable-plan enforce
```

Related Commands	Command	Description
	feature cable-management	Enables the cable management feature for a network

fabric connectivity cable-plan generate

To automatically generate a cable plan based on the topology of the data center neighbors, use the **fabric connectivity cable-plan generate** command in privileged EXEC mode.

fabric connectivity cable-plan generate [*plan-name*]

Syntax Description

<i>plan-name</i>	(Optional) Filename of the newly generated cable plan.
------------------	--

Command Default

A cable plan is not automatically generated.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
6.0(2)N3(1)	This command was introduced.

Usage Guidelines

The **fabric connectivity cable-plan generate** command creates a valid cable plan from the output of the **show fabric connectivity neighbors** command. You can modify the autogenerated cable plan to suit the link or connectivity endpoints within your data center.

If you do not specify a *plan-name*, then the filename is a generic time-stamped name.



Note

Before configuring this command you must enable the **feature lldp** command and then the **feature cable-management** command in global configuration mode.

Examples

The following example shows how to autogenerate a cable plan named cplan1:

```
Device# fabric connectivity cable-plan generate cplan1
```

Related Commands

Command	Description
feature cable-management	Enables the cable management feature for a network
show fabric connectivity neighbors	Displays cache information about fabric connectivity neighbors.

fabric connectivity cable-plan import

To import a cable plan from a local or a remote location, use the **fabric connectivity cable-plan import** command in privileged EXEC mode.

fabric connectivity cable-plan import [**ftp** | **scp** | **sftp** | **tftp**:] **bootflash:** [**vrf** *vrf-name*] [**update**] [**verbose**]

Syntax Description

ftp:	(Optional) Imports a cable plan from a remote FTP location.
scp:	(Optional) Imports a cable plan from a remote Secure Copy Protocol location.
sftp:	(Optional) Imports a cable plan from a remote Secure FTP location.
tftp:	(Optional) Imports a cable plan from a remote TFTP location.
bootflash:	Imports a cable plan from the local location.
vrf <i>vrf-name</i>	(Optional) Displays information about the specified virtual routing and forwarding instance.
update	(Optional) Updates the existing cable plan with a newly imported cable plan.
verbose	(Optional) Prints all errors regarding the cable plan file import to the console.

Command Default

Cable plans are not imported.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
6.0(2)N3(1)	This command was introduced.

Usage Guidelines

When you copy a cable plan from a remote location, you must specify the local location to save the file. If a remote import fails, the downloaded file is deleted automatically.

Once you configure the command, you have to enter the name of the source cable plan file and the destination cable plan file.

When you specify the **fabric connectivity cable-plan import bootflash:** command, the local cable plan file that exists in the bootflash is imported. Imported cable plans are stored in the device memory. Once imported, cable plans are persistent across reboots if you configure the **copy running-config startup-config** command.

Examples

The following example shows how the cp.xml file is imported from the local location:

```
Device# fabric connectivity cable-plan import bootflash:cp.xml
```

```
Success: Imported cable-plan: /bootflash/cp.xml
```

```
Device#
```

The following sample output from the **fabric connectivity cable-plan import bootflash: verbose** command displays cable plan import failures:

```
Device# fabric connectivity cable-plan import bootflash:cp_failure.xml verbose
```

```
/bootflash/cp_failure.xml:6: element LINK_INFO: Schemas validity error : Element
'{http://www.cisco.com/cableplan/Schema2}LINK_INFO',
  attribute 'destPort': [facet 'pattern'] The value 'Eth11' is not accepted by the pattern
'Eth[0-9]{1,3}/[0-9]{1,3}'.
/bootflash/cp_failure.xml:6: element LINK_INFO: Schemas validity error : Element
'{http://www.cisco.com/cableplan/Schema2}LINK_INFO',
  attribute 'destPort': 'Eth11' is not a valid value of the atomic type
'{http://www.cisco.com/cableplan/Schema2}portType'.
/bootflash/cp_failure.xml:7: element LINK_INFO: Schemas validity error : Element
'{http://www.cisco.com/cableplan/Schema2}LINK_INFO',
  attribute 'destPort': [facet 'pattern'] The value 'Et1/1' is not accepted by the pattern
'Eth[0-9]{1,3}/[0-9]{1,3}'.
/bootflash/cp_failure.xml:7: element LINK_INFO: Schemas validity error : Element
'{http://www.cisco.com/cableplan/Schema2}LINK_INFO',
  attribute 'destPort': 'Et1/1' is not a valid value of the atomic type
'{http://www.cisco.com/cableplan/Schema2}portType'.
/bootflash/cp_failure.xml:11: element LINK_INFO: Schemas validity error : Element
'{http://www.cisco.com/cableplan/Schema2}LINK_INFO',
  attribute 'destPort': [facet 'pattern'] The value 'Eth18881/2' is not accepted by the pattern
'Eth[0-9]{1,3}/[0-9]{1,3}'.
/bootflash/cp_failure.xml:11: element LINK_INFO: Schemas validity error : Element
'{http://www.cisco.com/cableplan/Schema2}LINK_INFO',
  attribute 'destPort': 'Eth18881/2' is not a valid value of the atomic type
'{http://www.cisco.com/cableplan/Schema2}portType'.
/bootflash/cp_failure.xml:13: element LINK_INFO: Schemas validity error : Element
'{http://www.cisco.com/cableplan/Schema2}LINK_INFO',
  attribute 'destPort': [facet 'pattern'] The value 'th1/2' is not accepted by the pattern
'Eth[0-9]{1,3}/[0-9]{1,3}'.
/bootflash/cp_failure.xml:13: element LINK_INFO: Schemas validity error : Element
'{http://www.cisco.com/cableplan/Schema2}LINK_INFO',
  attribute 'destPort': 'th1/2' is not a valid value of the atomic type
'{http://www.cisco.com/cableplan/Schema2}portType'.
```

```
Error: Failed to import cable-plan: Invalid cable-plan
```

```
Device#
```

The following is a sample cable plan for a data center with two spine devices and three leaf devices. This cable plan describes a data center that contains the following switches: spine1, spine2, leaf1, leaf2, and leaf3. The sourceChassis, spine2 is connected to destChassis, leaf1 through Ethernet 1/1. If your data center network has more interfaces than the ones described in the cable plan, a warning about the absence is logged.

```
<?xml version="1.0" encoding="UTF-8"?>
<CISCO_NETWORK_TYPES version="1.0" xmlns="http://www.cisco.com/cableplan/Schema2"
xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance"
xsi:schemaLocation="http://www.cisco.com/cableplan/Schema2 nxos-cable-plan-schema.xsd">
  <DATA_CENTER networkLocation="san-jose" idFormat="hostname">
    <CHASSIS_INFO sourceChassis="spine1" type="n7k">
      <LINK_INFO sourcePort="Eth2/1" destChassis="leaf1" destPort="Eth2/1"/>
      <LINK_INFO sourcePort="Eth2/2" destChassis="leaf2" destPort="Eth2/1"/>
      <LINK_INFO sourcePort="Eth2/3" destChassis="leaf3" destPort="Eth2/1"/>
    </CHASSIS_INFO>
    <CHASSIS_INFO sourceChassis="spine2.cisco.com" type="n7k">
      <LINK_INFO sourcePort="Eth1/1" destChassis="leaf1" destPort="Eth1/2"/>
      <LINK_INFO sourcePort="Eth1/2" destChassis="leaf2" destPort="Eth1/2"/>
      <LINK_INFO sourcePort="Eth1/3" destChassis="leaf3" destPort="Eth1/2"/>
    </CHASSIS_INFO>
  </DATA_CENTER>
</CISCO_NETWORK_TYPES>
```

```

    </CHASSIS_INFO>
  </DATA_CENTER>
</CISCO_NETWORK_TYPES>

```

The following paragraphs describe the lines and the XML tags and attributes associated with each line in the cable plan. These lines are required headings for XML processing and Cisco-specific headers that denote that this is a Cisco cable plan. The format must be exactly the same as shown in the following example for all cable plans. Failure to adhere to the format results in a rejected cable plan.

The `CISCO_NETWORK_TYPES` tag is required and it is the parent tag for the entire XML cable plan. The entire cable plan must be within this tag.

```

<?xml version="1.0" encoding="UTF-8"?>
<CISCO_NETWORK_TYPES version="1.0" xmlns="http://www.cisco.com/cableplan/Schema2"
xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance"
xsi:schemaLocation="http://www.cisco.com/cableplan/Schema2 nxos-cable-plan-schema.xsd ">

```

The `DATA_CENTER` tag is required and it houses all information about each chassis in the plan. The `networkLocation` tag is required and it specifies the location of the data center. The `idFormat` tag is required and it specifies the format in which IDs are present in subsequent entries. In the Cisco NX-OS Release 6.0(2)N3(1), the only supported format is "hostname". Cable plans that do not use "hostname" as the format are rejected.

```

<DATA_CENTER networkLocation="san-jose" idFormat="hostname">

```

The `CHASSIS_INFO` tag is required and it describes one single chassis. All interfaces that belong to the `sourceChassis` that administrators want to include in the cable plan must be within this tag. The `sourceChassis` tag is required and it describes the chassis that all subsequent interfaces (described below by `LINK_INFO` tags) belong to.

Include all details about the interfaces on a device inside the `CHASSIS_INFO` tag. If you need to check interfaces on another device, include them inside another `CHASSIS_INFO` tag. There is no limit to the number of unique `CHASSIS_INFO` tags in a cable plan.

In the following example, all interfaces within the `CHASSIS_INFO` tag belong to `spine1` chassis. The specified chassis name must be the fully qualified domain name of the device. If a domain name is configured for the hostname, the hostname must be followed by the domain name. For example, `spine1.cisco.com` if `spine1` is configured with the domain name, `cisco.com`.

The `type` tag is required and it specifies the type of chassis. In the Cisco NX-OS Release 6.0(2)N3(1), only Cisco Nexus switches are supported. This tag is not case sensitive. Cable plans that do not adhere to the "n#k" format are rejected.

```

<CHASSIS_INFO sourceChassis="spine1" type="n7k">

```

The `LINK_INFO` tag is required and it describes an interface connection from the `sourceChassis` to the `destChassis`. In the following example, the `spine1` source port on Ethernet 2/1 is connected to the `leaf1` destination port on Ethernet 2/1, `spine1` source port on Ethernet 2/2 is connected to `leaf2` destination port on Ethernet 2/1, and so on.

The `sourcePort` tag is required and it denotes the port on the `sourceChassis`. Source ports must be unique per chassis. For example, `spine1` must not specify multiple connections that come from port Ethernet 2/1. The cable plan import will not fail if you do not specify unique ports. However, a warning is displayed on the console and only the first entry is read and checked by the cable plan.

The `destChassis` tag is required and it denotes the destination chassis that the `sourceChassis` is connected to. The `destChassis` name must be the fully qualified domain name.

The destPort tag is required and it denotes the port on the destination chassis. Like the sourcePort, the destPort must be unique to the destChassis.

```
<LINK_INFO sourcePort="Eth2/1" destChassis="leaf1" destPort="Eth2/1"/>
<LINK_INFO sourcePort="Eth2/2" destChassis="leaf2" destPort="Eth2/1"/>
<LINK_INFO sourcePort="Eth2/3" destChassis="leaf3" destPort="Eth2/1"/>
```

Related Commands

Command	Description
clear fabric connectivity cable-plan	Clears the current cable plan.
feature cable-management	Enables the cable management feature for a network
show fabric connectivity cable-plan	Displays the cable plan available in the system memory.

fabric connectivity mismatch action delay

To delay the port error-disable action on detecting cabling errors for a specified time, use the **fabric connectivity mismatch action delay** command in global configuration mode. To remove this configuration, use the **no** form of this command

fabric connectivity mismatch action delay *time*

no fabric connectivity mismatch action delay *time*

Syntax Description	<i>time</i> Time in seconds to delay action. The range is from 30 to 3600.
---------------------------	--

Command Default	Delayed action on mismatched errors is not configured.
------------------------	--

Command Modes	Global configuration (config)
----------------------	-------------------------------

Command History	Release	Modification
	7.0(0)N1(1)	This command was introduced.

Usage Guidelines	Use this command to delay, by seconds, any action caused by mismatched errors. For example, if you set the action delay to 30 seconds and have errors configured to error-disable ports, then in case an error is detected at a network port, the port is error-disabled after a period of 30 seconds. If a valid entry is received within the wait period of 30 seconds, the port will remain open and not be error-disabled. You have to enable the cable management feature using the feature cable-management command to be able to configure the fabric connectivity mismatch action delay command.
-------------------------	--

Examples	The following example shows how to configure a time period to delay action caused by mismatch errors. Here the time to delay action is set to 35 seconds.
-----------------	---

```
Device# configure terminal
Device(conf)# feature cable-management
Device(conf)# fabric connectivity mismatch action delay 35
```

Related Commands	Command	Description
	show fabric connectivity neighbors	Displays cache information about fabric connectivity neighbors.
	fabric connectivity cable-plan import	Imports a cable plan from a local or a remote location.
	fabric connectivity tier	Configures the tier level of a device.

fabric connectivity tier

To configure the tier level of a device in the Dynamic Fabric Automation (DFA) fabric, use the **fabric connectivity tier** command in global configuration mode. To remove this configuration, use the **no** form of this command.

fabric connectivity tier *tier-level*

no fabric connectivity tier *tier-level*

Syntax Description

<i>tier-level</i>	Tier level of the device. The range is from 1 to 16, where 1 indicates a leaf, 2 indicates a level 1 spine, 3 indicates a level 2 spine, and so on.
-------------------	---

Command Default

Tier level of the device is not configured.

Command Modes

Global configuration (config)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced

Usage Guidelines

To detect and resolve miscabling issues in a Clos network, DFA provides the user the functionality to assign a sequential number (called the tier number) at each stage of the network topology. Every device in a stage can be associated with the corresponding tier level number assigned to the stage the device is in. All leaf switches (in the lowest level of the Clos stage) are provisioned with a tier level of 1, the next higher-level stage devices (1st stage of spine switches) are provisioned with a tier level value of 2, and the next higher-level stage devices (2nd stage of spine switches) are provisioned with a tier level of 3, and so on. Use the **fabric connectivity tier** command to assign the tier-level number for a specific device in the fabric. You have to enable the cable management feature using the **feature cable-management** command to be able to configure the **fabric connectivity tier** command.

Examples

The following example shows how you can assign a tier number to a specific device in the topology:

```
Device# configure terminal
Device(config)# feature cable-management
Device(config)# fabric connectivity tier 2
```

Related Commands

Command	Description
clear fabric connectivity neighbors	Clears all information about neighbors from the neighbor cache.

Command	Description
fabric connectivity cable-plan import	Imports a cable plan from a local or a remote location.
fabric connectivity mismatch action delay	Delays the port error-disable action on detecting cabling errors for a specified time.

fabric database mobility-domain

To configure the mobility domain name, use the **fabric database mobility-domain** command in global configuration mode. To remove the mobility domain name, use the **no** form of this command.

fabric database mobility-domain *domain-name*

no fabric database mobility-domain *domain-name*

Syntax Description

<i>domain-name</i>	Mobility domain name up to 128 characters.
--------------------	--

Command Default

The mobility domain name is not configured.

Command Modes

Global configuration (config)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

Use the **fabric database mobility-domain** command to configure the mobility domain name that is used to get the profile name if the profiles are stored remotely.

Examples

The following example shows how to configure the mobility domain name:

```
Device> enable
Device# configure terminal
Device(config)# install feature-set fabric
Device(config)# feature-set fabric
Device(config)# fabric database mobility-domain profile
```

Related Commands

Command	Description
feature-set fabric	Enables configuring host mobility-specific commands.

fabric database type

To configure the external database, use the **fabric database type** command in global configuration mode. To remove this configuration, use the **no** form of this command

fabric database type {network| profile}

no fabric database type {network| profile}

Syntax Description

network	Configures the network database.
profile	Configures the config-profile database.

Command Default

The external database is not configured.

Command Modes

Global configuration (config)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Examples

The following example shows how to configure a database type:

```
Device# configure terminal
Device(config)# fabric database type network
Device(config)# fabric database type profile
```

Related Commands

Command	Description
clear fabric database statistics	Clears the external database statistics such as number of messages sent or received, pending requests, access errors, and access timeouts
show fabric database statistics	Displays fabric database statistics.

fabric forwarding anycast-gateway-mac

To specify the MAC address of the server facing ports across all leaf nodes, use the **fabric forwarding anycast-gateway-mac** command in global configuration mode. To disable the anycast gateway MAC address, use the **no** form of this command.

fabric forwarding anycast-gateway-mac *mac-address*

no fabric forwarding anycast-gateway-mac *mac-address*

Syntax Description	<i>mac-address</i>	
---------------------------	--------------------	--

fabric forwarding control-segment

To configure a control segment under a switched virtual interface (SVI) in a default virtual routing and forwarding (VRF) instance, use the **fabric forwarding control-segment** command in interface configuration mode.

fabric forwarding control-segment

Syntax Description This command has no arguments or keywords.

Command Default A control segment is not configured.

Command Modes Interface configuration (config-if)

Command History	Release	Modification
	7.0(0)N1(1)	This command was introduced.

Usage Guidelines Use the **fabric forwarding control-segment** command to specify an SVI interface to be a fabric control VLAN interface on which adjacencies are established in the default VRF. You can configure only one SVI interface in the default VRF as a fabric control VLAN interface.



Note

You can also configure a control segment under a bridge domain.

Examples The following example shows how to specify an SVI interface to be a fabric control VLAN interface:

```
Device> enable
Device# configure terminal
Device(config)# interface vlan 2
Device(config-if)# fabric forwarding control-segment
```

Related Commands	Command	Description
	feature-set fabric	Enables configuring host mobility-specific commands.

fabric forwarding conversational-aging

To configure the conversational aging timeout value, use the **fabric forwarding conversational-aging** command in global configuration mode. To remove the aging timeout value, use the **no** form of this command.

fabric forwarding conversational-aging *timeout*

no fabric forwarding conversational-aging *timeout*

Syntax Description

<i>timeout</i>	Conversational aging timeout value in minutes. The range is from 15 to 1800. The default is 30.
----------------	---

Command Default

The timeout value is set to 30 minutes.

Command Modes

Global configuration (config)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

Use the **fabric forwarding conversational-aging** command to configure the aging timeout value that determines if a conditional route must be aged or not.

Examples

The following example shows how to set the conversational learning aging timeout value to 50 minutes:

```
Device> enable
Device# configure terminal
Device(config)# install feature-set fabric
Device(config)# feature-set fabric
Device(config)# fabric forwarding conversational-aging 50
```

Related Commands

Command	Description
feature-set fabric	Enables configuring host mobility-specific commands.

fabric forwarding conversational-learning

To enable Layer 3 conversational learning-based route download into the forwarding information base (FIB), use the **fabric forwarding conversational-learning** command in global configuration mode. To disable the conversational learning-based FIB route download, use the **no** form of this command.

fabric forwarding conversational-learning [all]

no fabric forwarding conversational-learning

Syntax Description	all (Optional) Enables conversational learning for all virtual routing and forwarding (VRF) instances.
---------------------------	---

Command Default	Conversational learning is disabled.
------------------------	--------------------------------------

Command Modes	Global configuration (config)
----------------------	-------------------------------

Command History	Release	Modification
	7.0(0)N1(1)	This command was introduced.

Usage Guidelines	Use the fabric forwarding conversational-learning command to enable Layer 3 conversational learning. After conversational learning is enabled, the host routes are downloaded into the FIB when a conversation is detected.
-------------------------	--



Note

If you use this command without the **all** keyword, it specifies that conversational learning is used for the default VRF.

Examples	The following example shows how to enable Layer 3 conversational learning for all VRFs:
-----------------	---

```
Device> enable
Device# configure terminal
Device(config)# install feature-set fabric
Device(config)# feature-set fabric
Device(config)# fabric forwarding conversational-learning all
```

Related Commands	Command	Description
	feature-set fabric	Enables configuring host mobility-specific commands.

fabric forwarding identifier

To specify a fabric forwarding identifier, use the **fabric forwarding identifier** command in global configuration mode. To remove this configuration, use the **no** form of this command.

fabric forwarding identifier *id*

no fabric forwarding identifier *id*

Syntax Description

identifier <i>id</i>	Specifies a fabric forwarding identifier number. The range is from 1 to 65535.
-----------------------------	--

Command Default

A fabric forwarding identifier is not specified.

Command Modes

Global configuration (config)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

Use this command to configure a fabric forwarding identifier.

Examples

The following example shows how to configure a fabric forwarding identifier:

```
Device# configure terminal
Device(config)# fabric forwarding identifier 1
```


fabric forwarding switch-role

To specify the role of a device in the network, use the **fabric forwarding switch-role** command in global configuration mode. To disable the role specified for a device, use the **no** form of the command.

fabric forwarding switch-role {**border** [**leaf** | **spine**] | **leaf** [**border**] | **spine** [**border**]}

no fabric forwarding switch-role

Syntax Description

border	Sets border as the role of a device.
leaf	Sets leaf as the role of a device.
spine	Sets spine as the role of a device.

Command Default

A device is configured as a leaf.

Command Modes

Global configuration (config)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

Use the **fabric forwarding switch-role** command to specify the role of a device. You can configure a device to act like a border, a spine or a leaf. A device sends notifications to registered components whenever there is a change in the role of a device. You can specify a combination of a border and a leaf or a spine on a device. Both Border Gateway Protocol (BGP) and Intermediate System-to-Intermediate System (ISIS) protocol restart when the role of a device changes.

Examples

The following example shows how to specify the role of a device to be a border and a spine:

```
Device> enable
Device# configure terminal
Device(config)# install feature-set fabric
Device(config)# feature-set fabric
Device(config)# fabric forwarding switch-role border spine
```

The following example shows how to specify the role of a device to be a border and a leaf.

```
Device> enable
Device# configure terminal
Device(config)# install feature-set fabric
Device(config)# feature-set fabric
Device(config)# fabric forwarding switch-role border leaf
```

Related Commands

Command	Description
feature-set fabric	Enables configuring host mobility-specific commands.

fabricpath isis bfd

To enable the FabricPath Bidirectional Forwarding (BFD) feature on an Intermediate System-to-Intermediate System (IS-IS) interface, use the **fabricpath isis bfd** command in interface configuration mode. To disable the FabricPath BFD feature on the IS-IS interface, use the **no** form of this command.

fabricpath isis bfd [**disable**]

no fabricpath isis bfd [**disable**]

Syntax Description

disable	(Optional) Disables the FabricPath feature on the IS-IS interface.
----------------	--

Command Default

The FabricPath feature is not enabled on the IS-IS interface.

Command Modes

Interface configuration (config-if)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

The **no fabricpath isis bfd** command disables the BFD on the interface, but if global BFD is configured, the interface inherits the global BFD and BFD remains enabled on that interface.

The **no fabricpath isis bfd disable** command disables the BFD on the interface even if global BFD is configured. This command overrides the global BFD configuration. No BFD is configured on that interface.

Examples

This example shows how to enable the FabricPath feature on an IS-IS interface:

```
Device(config-if)# fabricpath isis bfd
```

Related Commands

Command	Description
show fabricpath isis	Displays information about FabricPath IS-IS.
show fabricpath isis interface	Displays information about the FabricPath Intermediate System-to-Intermediate System (IS-IS) interface.

fabricpath oam profile

To configure a FabricPath Operation, Administration, and Maintenance (OAM) profile and enter FabricPath OAM profile configuration mode, use the **fabricpath oam profile** command in global configuration mode. To remove the FabricPath OAM profile, use the **no** form of this command.

fabricpath oam profile *profile-id*

no fabricpath oam profile *profile-id*

Syntax Description

<i>profile-id</i>	Profile ID. The range is from 1 to 1023.
-------------------	--

Command Default

A FabricPath OAM profile is not configured.

Command Modes

Global configuration (config)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

All FabricPath OAM profiles have default values. To display the FabricPath OAM profiles, use the **show run all** command. A FabricPath OAM profile with a profile ID of 1 is created by default, when the FabricPath feature is enabled.

Examples

The following example shows how to configure a FabricPath OAM profile with a profile ID of 100.

```
Device# configure terminal
Device(config)# fabricpath oam profile 100
Device(config-fp-oam-profile)#
```

Related Commands

Command	Description
show fabricpath oam loopback	Shows statistics for FabricPath OAM loopback.
show fabricpath oam mtrace	Shows statistics for fabricpath OAM mtrace.
show fabricpath oam notification	Shows information about for FabricPath OAM notification.
show fabric oam traceroute	Shows statistics for FabricPath OAM traceroute.

feature cable-management

To enable the cable management feature for a network, use the **feature cable-management** command in global configuration mode. To disable the feature, use the **no** form of this command.

feature cable-management

no feature cable-management

Syntax Description This command has no arguments or keywords.

Command Default Disabled

Command Modes Global configuration (config)

Command History	Release	Modification
	7.0(0)N1(1)	This command was introduced.

Usage Guidelines Use the **feature cable-management** command to enable the cable management feature. This command does not require a license.



Note

Enable the Link Layer Discovery Protocol (LLDP) by using the **feature lldp** command prior to enabling the cable management feature.

Examples This example shows how to enable the cable management feature:

```
Device# configure terminal
Device(config)# feature lldp
Device(config)# feature cable-management
Device(config)# exit
```

This example shows how to disable the cable management feature:

```
Device(config)# no feature cable-management
```

feature evb

To enable the Edge Virtual Bridging (EVB) feature on a device, use the **feature evb** command in global configuration mode. To disable EVB feature, use the **no** form of this command.

feature evb

no feature evb

Syntax Description This command has no arguments or keywords.

Command Default EVB is disabled.

Command Modes Global configuration (config)

Command History	Release	Modification
	7.0(0)N1(1)	This command was introduced.

Usage Guidelines You can enable or disable EVB globally on a device. You must use the **feature evb** command to enable and configure the EVB parameters.

Examples This example shows how to enable the EVB feature on a device:

```
Device(config)# feature evb
```

Related Commands	Command	Description
	evb reinit-keep-alive	Configures the keepalive parameter for EVB.
	evb resource-wait-delay	Configures the resource wait delay parameter for EVB.
	show evb	Displays information associated with Edge Virtual Bridging (EVB).

feature fabric

To enable fabric network services on a device, use the **feature fabric** command in global configuration mode. To disable the fabric network services, use the **no** form of this command.

feature fabric {**access**| **forwarding**| **multicast**}

no feature fabric {**access**| **forwarding**| **multicast**}

Syntax Description

access	Enables single point of access in an Extensible Messaging and Presence Protocol (XMPP) client for a fabric network.
forwarding	Enables the Host Mobility Manager (HMM) and release-specific HMM configuration commands.
multicast	Enables the Next-Gen Multicast VPN (NGMVPN) features associated with the fabric network services.

Command Default

Fabric network services are disabled.

Command Modes

Global configuration (config)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Examples

This example shows how to enable the fabric network services on a device:

```
Device# configure terminal
Device(config)# feature fabric access
Device(config)# feature fabric forwarding
Device(config)# feature fabric multicast
Device(config)# end
```

feature fabric access

To enable the fabric access feature for a fabric network, use the **feature fabric access** command in global configuration mode. To disable the fabric access feature, use the **no** form of this command.

feature fabric access

no feature fabric access

Syntax Description This command has no arguments or keywords.

Command Default Disabled

Command Modes Global configuration (config)

Command History	Release	Modification
	7.0(0)N1(1)	This command was introduced.

Usage Guidelines You must use the **feature fabric access** command to enable the fabric access feature. This command does not require a license.

Examples This example shows how to enable the fabric access feature on a device:

```
Device(config)# feature fabric access
```

This example shows how to disable the fabric access feature on a device:

```
Device(config)# no feature fabric access
```

Related Commands	Command	Description
	show fabric access connections	Displays the connection status of a device or a user that is connected in the fabric access network.

feature fabric multicast

To enable the Next-Generation Multicast VPN (NG-MVPN) features on a device, use the **feature fabric multicast** command in global configuration mode. To disable the NG-MVPN features on a device, use the **no** form of this command.

feature fabric multicast

no feature fabric multicast

This command has no arguments or keywords.

Command Default The NG-MVPN features are disabled.

Command Modes Global configuration (config)

Command History	Release	Modification
	7.0(0)N1(1)	This command was introduced.

Examples

The following example shows how to enable NG-MVPN features on a device:

```
Device(config)# feature fabric multicast
```

The following example shows how to disable NG-MVPN features on a device:

```
Device(config)# no feature fabric multicast
```

Related Commands	Command	Description
	feature-set fabric	Enables configuring host mobility-specific commands.

feature-set fabric

To enable configuring host mobility-specific commands, use the **install feature-set fabric** command in global configuration mode.

feature-set fabric

Syntax Description

This command has no arguments or keywords.

Command Modes

Global configuration (config)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

This command needs to be configured before configuring host mobility-specific commands.

Examples

The following example shows how to enable configuring host mobility-specific commands:

```
Device> enable
Device# configure terminal
Device(config)# feature-set fabric
```

Related Commands

Command	Description
install feature-set fabric	Enables configuring host mobility-specific commands.

feature vn-segment-vlan-based

To enable the (VLAN)-based virtual network (VN) segment feature on a device, use the **feature vn-segment-vlan-based** command in global configuration mode. To disable VLAN-based VN segment feature, use the **no** form of this command.

feature vn-segment-vlan-based

no feature vn-segment-vlan-based

Syntax Description This command has no arguments or keywords.

Command Default The VLAN-based virtual network segment is disabled.

Command Modes Global configuration (config)

Command History	Release	Modification
	7.0(0)N1(1)	This command was introduced.

Usage Guidelines You can enable or disable the VLAN-based VN segment feature globally on a device. The VLAN-based VN segment feature is enabled only if the feature-set fabricpath is enabled on the device.

Examples This example shows how to enable the VLAN-based VN segment feature on a device:
Device(config)# **feature vn-segment-vlan-based**

Related Commands	Command	Description
	vn-segment	Configures the segment identifier of the VLAN.
	vni	Configures the virtual network identifier.

flow (fabricpath-oam)

To configure the direction of FabricPath Operation, Administration, and Maintenance (OAM) packet flow and enter FabricPath OAM profile flow configuration mode, use the **flow** command in FabricPath OAM profile configuration mode. To remove the flow configuration, use the **no** form of this command.

flow {forward | reverse}

no flow {forward | reverse}

Syntax Description

forward	Configures the FabricPath OAM forward flow.
reverse	Configures the FabricPath OAM reverse flow.

Command Default

The direction of FabricPath OAM packet flow is not configured.

Command Modes

FabricPath oam profile configuration (config-fb-oam-profile)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

Use the **flow** command to configure the direction of flow entropy, forward or reverse, and enter FabricPath OAM profile flow configuration mode. You can configure specific information for forward or reverse flow entropy from FabricPath OAM profile flow configuration mode.

Examples

The following example shows how to configure the forward flow entropy for FabricPath OAM.

```
Device# configure terminal
Device(config)# fabricpath oam profile 100
Device(config-fb-oam-profile)# flow forward
Device(config-fb-oam-profile-flow)#
```

Related Commands

Command	Description
fabricpath oam profile	Configures a FabricPath OAM profile.
protocol (fabricpath-oam)	Configures the FabricPath OAM flow protocol number.

hop (fabricpath-oam)

To configure the hop limit for a FabricPath OAM service packet protocol header, use the **hop** command in FabricPath OAM profile configuration mode. To restore the hop limit to the default value, use the **no** form of this command.

hop *hop-limit*

no hop

Syntax Description

<i>hop-limit</i>	Hop limit. Range is from 1 to 255. Default is 64.
------------------	---

Command Default

The hop limit for FabricPath OAM service packets is 64 hops.

Command Modes

FabricPath OAM profile configuration (config-fb-oam-profile)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

Use the hop count specified in the FabricPath OAM packet header to determine the hop limit to address issues caused by infinite loops.

Examples

The following example shows how to configure a FabricPath OAM service packet hop limit of 25.

```
Device# configure terminal
Device(config)# fabricpath oam profile 100
Device(config-fb-oam-profile)# hop 25
```

Related Commands

Command	Description
fabricpath oam profile	Configures a FabricPath OAM profile.
protocol (fabricpath-oam)	Configures the FabricPath OAM flow protocol number.

include profile

To configure a set of VLAN profile instances to refer to a common virtual routing and forwarding (VRF) instance, use the **include profile** command in profile configuration mode. To remove the reference to a common VRF instance, use the **no** form of this command.

include profile *profile-name*

no include profile *profile-name*

Syntax Description	
<i>profile-name</i>	Name of the profile. The maximum number of characters allowed is 80.

Command Default	VLAN profile instances do not refer to a common VRF instance.
-----------------	---

Command Modes	Profile configuration (config-profile)
---------------	--

Command History	Release	Modification
	7.0(0)N1(1)	This command was introduced.

Usage Guidelines	Use the include profile command to configure a set of VRF profile instances to refer to a common VRF instance. For example, a set of VLANs can refer to the same VLAN VRF instance. Any configuration after you configure the first VLAN VRF instance will increment the reference count of the include instance. The configuration related to the VRF stays until the last instance referring to the VRF is present.
------------------	--

Examples	The following example shows how to configure a set of VLAN profile instances to refer to a common VRF instance:
----------	---

```
Device> enable
Device# configure profile p1
Device(config-profile)# configure profile p2
Device(config-profile)# include profile p1
```

Related Commands	Command	Description
	configure profile	Configures a profile.

install feature-set fabric

To enable configuring host mobility-specific commands, use the **install feature-set fabric** command in global configuration mode.

install feature-set fabric

Syntax Description

This command has no arguments or keywords.

Command Modes

Global configuration (config)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

This command needs to be configured before configuring host mobility-specific commands.

Examples

The following example shows how to enable configuring host mobility-specific commands:

```
Device> enable
Device# configure terminal
Device(config)# install feature-set fabric
```

Related Commands

Command	Description
feature-set fabric	Enables configuring host mobility-specific commands.

instance

To create an instance of a user-defined parameter list, use the **instance** command in parameter list configuration mode. To remove an instance of a user-defined parameter list, use the **no** form of this command.

instance *instance-name*

no instance *instance-name*

Syntax Description

<i>instance-name</i>	Parameter-list instance name.
----------------------	-------------------------------

Command Default

A user-defined parameter-list instance is not created.

Command Modes

Parameter list configuration (config-param-list)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

You can create instances of a parameter list for different hosts with various values. When you create an instance of a parameter list using the **instance** command, the device enters parameter instance configuration (config-param-inst) mode. The following options are available in this mode:

- **set** - Sets the parameter value.
- **this** - Displays information about the instance.
- **verify** - Verifies the instance with the specified device-profile.
- **end** - Exits parameter instance configuration mode and returns to EXEC mode.
- **exit** - Exits parameter instance configuration mode and returns to parameter list configuration mode.
- **pop** - Pops the mode from the stack or restores it from the specified name.
- **push** - Pushes the current mode to the stack or saves it with the specified name.
- **where** - Displays instance-related details (such as parameter-list name, instance name, and so on).

Examples

The following example shows to create an instance `inst1` under the user-defined parameter list `List1`:

```
Device# configure terminal
Device(config)# param-list List1
Device(config-param-list)# instance inst1
```



```
Device(config-param-list) # exit
```

Related Commands

Command	Description
define	Creates user-defined parameters for the specified parameter list.

interface (fabricpath-oam)

To configure a FabricPath Operation, Administration, and Maintenance (OAM) egress interface, use the **interface** command in FabricPath OAM profile configuration mode. To remove the egress interface configuration, use the **no** form of this command.

interface ethernet *slot-number/port-number* [- *slot-number/port-number*]
no interface

Syntax Description

ethernet	Specifies that the egress interface is an Ethernet interface.
<i>slot-number/port-number</i>	Interface ID or interface range.

Command Default

A FabricPath OAM egress interface is not configured.

Command Modes

FabricPath OAM profile configuration (config-fb-oam-profile)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

You can configure multiple egress interfaces to create an interface list in the fabric OAM profile. You can also enter a range of interface addresses of the same interface type. You can configure Ethernet or PortChannel interfaces.

Examples

The following example shows how to configure an egress ethernet interface.

```
Device# configure terminal
Device(config)# fabricpath oam profile 100
Device(config-fb-oam-profile)# interface Ethernet 1/1-1/3
```

Related Commands

Command	Description
fabricpath oam profile	Configures a FabricPath OAM profile.

ip (fabricpath-oam)

To configure a Layer 3 flow destination or source IPv4 address, use the **ip** command in FabricPath OAM profile flow configuration mode. To remove the IPv4 flow address, use the **no** form of this command.

ip {destination | source} *ip-address*

no ip {destination | source}

Syntax Description

destination	Specifies the FabricPath OAM profile flow destination address.
source	Specifies the FabricPath OAM profile flow source address.
<i>ip-address</i>	IP address.

Command Default

The IPv4 flow address is not configured.

Command Modes

FabricPath OAM profile flow configuration (config-fp-oam-profile-flow)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Examples

The following example shows how to configure the FabricPath flow IPv4 destination address.

```
Device# configure terminal
Device(config)# fabricpath oam profile 100
Device(config-fb-oam-profile)# flow forward
Device(config-fb-oam-profile-flow)# ip destination 172.31.10.10
```

Related Commands

Command	Description
fabricpath oam profile	Configures a FabricPath OAM profile.
flow (fabricpath-oam)	Configures the direction FabricPath OAM flow entropy.

ip arp rarp fabric-forwarding

To enable forwarding of Reverse Address Resolution Protocol (RARP) messages from a host to the fabric, and to set a rate-limit for the messages being forwarded, use the **ip arp rarp fabric-forwarding** command in global configuration mode. To disable forwarding of RARP messages from a host to the fabric, use the **no** form of this command.

ip arp rarp fabric-forwarding [**rate-limit** *rate-limit*]

no ip arp rarp fabric-forwarding [**rate-limit** *rate-limit*]

Syntax Description

rate-limit <i>rate-limit</i>	(Optional) Specifies the forwarding rate of the RARP frames.
Note	The default forwarding rate is 200 RARP frames per second. You can specify a forwarding rate in the range of 200 to 400 RARP frames per second.

Command Default

Forwarding of RARP messages from a host to the fabric is disabled.

Command Modes

Global configuration (config)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

If you want to enable forwarding of RARP messages and set the rate to the default value of 200 RARP frames per second, then use the **ip arp rarp fabric-forwarding** command.

If you want to enable forwarding of RARP messages and set the rate to a specific value, then include the use the **rate-limit** keyword and the *rate-limit* value.

Examples

The following example shows how to enable forwarding of RARP messages from a host to the fabric:

```
Device# configure terminal
Device(config)# ip arp rarp fabric-forwarding rate-limit 201
Device(config)# exit
```

ip multicast fabric-forwarding

To enable multicast enhanced fabric forwarding for a particular Virtual Routing and Forwarding (VRF), use the **ip multicast fabric-forwarding** command in global configuration mode. To disable fabric forwarding for the VRF, use the **no** form of this command.

{ip | ipv6} multicast fabric-forwarding

no {ip | ipv6} multicast fabric-forwarding

Syntax Description

ip	Enables IPv4 multicast fabric forwarding.
ipv6	Enables IPv6 multicast fabric forwarding.

Command Default

Multicast forwarding is disabled.

Command Modes

Global configuration (config)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Examples

The following example shows how to enable the fabric forwarding feature:

```
Device# configure terminal
Device(config)# ip multicast fabric-forwarding
Device(config)# ipv6 multicast fabric-forwarding
```

Related Commands

Command	Description
show fabric multicast globals	Displays the global state associated with the fabric multicast process.

ipv6 (fabricpath-oam)

To configure a Layer 3 flow destination or source IPv6 address, use the **ipv6** command in FabricPath OAM profile flow configuration mode. To remove the IPv6 flow address, use the **no** form of this command.

ipv6 {destination | source} *ip-address*

no ipv6 {destination | source}

Syntax Description

destination	Specifies the FabricPath OAM profile flow destination address.
source	Specifies the FabricPath OAM profile flow source address.
<i>ip-address</i>	IP address.

Command Default

The IPv6 flow address is not configured.

Command Modes

FabricPath OAM profile flow configuration (config-fp-oam-profile-flow)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Examples

The following example shows how to configure the FabricPath flow IPv6 destination address.

```
Device# configure terminal
Device(config)# fabricpath oam profile 100
Device(config-fb-oam-profile)# flow forward
Device(config-fb-oam-profile-flow)# ipv6 destination 2001:DB8:1::1
```

Related Commands

Command	Description
fabricpath oam profile	Configures a FabricPath OAM profile.
flow (fabricpath-oam)	Configures the direction FabricPath OAM flow entropy.

logging level evb

To enable the system log (syslog) filter level for an Edge Virtual Bridging (EVB) session, use the **logging level evb** command in global configuration mode. To disable the syslog filter level for EVB, use the **no** form of this command.

logging level evb *log-level*

no logging level evb *log-level*

Syntax Description

<i>log-level</i>	Sets the severity for the syslog filter level. The level values ranges from 0 to 7. The severity associated with the values are: <ul style="list-style-type: none">• 0-emerg—Sets severity levels for emergencies.• 1-alert—Sets severity levels for alerts.• 2-crit—Sets severity levels for critical issues.• 3-err—Sets severity levels for errors.• 4-warn—Sets severity levels for warnings.• 5-notif—Sets severity levels for notifications.• 6-inform—Sets severity levels for session information.• 7-debug—Sets severity levels for debugs.
------------------	---

Command Default

Syslog filter level with severity value 5 is enabled.

Command Modes

Global configuration (config)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

Use the **feature evb** command to enable the EVB session. This, in turn, enables the **evb** keyword in the **logging level** command on the device.

Examples

The following example shows how to set a syslog filter level of 4 for an EVB session:

```
Device# configure terminal
```

```
Device(config)# feature evb
Device(config)# logging level evb 4
Device(config)# end
```

The following example displays the default severity level and the user-defined syslog filter level for an EVB session:

```
Device# show logging level evb
```

Facility -----	Default Severity -----	Current Session Severity -----
evb	5	4
0 (emergencies)	1 (alerts)	2 (critical)
3 (errors)	4 (warnings)	5 (notifications)
6 (information)	7 (debugging)	

mac-address (fabricpath-oam)

To specify a FabricPath OAM flow destination or source MAC address, use the **mac-address** command in FabricPath OAM profile flow configuration mode. To remove the MAC address, use the **no** form of this command.

mac-address {**destination** | **source**} *mac-address*

no mac-address {**destination** | **source**}

Syntax Description

destination	Specifies the FabricPath OAM profile flow destination MAC address.
source	Specifies the FabricPath OAM profile flow source MAC address.
<i>mac-address</i>	MAC address.

Command Default

The MAC flow address is not configured.

Command Modes

FabricPath OAM profile flow configuration (config-fp-oam-profile-flow)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Examples

The following example shows how to configure the FabricPath OAM flow destination MAC address.

```
Device# configure terminal
Device(config)# fabricpath oam profile 100
Device(config-fb-oam-profile)# flow forward
Device(config-fb-oam-profile-flow)# mac-address destination 00-14-22-01-23-45
```

Related Commands

Command	Description
fabricpath oam profile	Configures a FabricPath OAM profile.
flow (fabricpath-oam)	Configures the direction FabricPath OAM flow entropy.

match (VLAN access-map)

To specify an access control list (ACL) for traffic filtering in a VLAN access map, use the **match** command in VLAN access-map configuration mode. To remove a **match** command from a VLAN access map, use the **no** form of this command.

match {ip | ipv6 | mac} address *access-list-name*

no match {ip | ipv6 | mac} address *access-list-name*

Syntax Description	ip	Specifies that the ACL is an IPv4 ACL.
	ipv6	Specifies that the ACL is an IPv6 ACL.
	mac	Specifies that the ACL is a MAC ACL.
	<i>access-list-name</i>	Specifies the ACL by name, which can be up to 64 alphanumeric, case-sensitive characters.

Command Default None

Command Modes VLAN access-map configuration

Command History	Release	Modification
	—	This command was introduced in a release earlier than Cisco NX-OS Release 7.0(0)N1(1).

Usage Guidelines

You can specify one or more **match** commands per entry in a VLAN access map.

By default, the device classifies traffic and applies IPv4 ACLs to IPv4 traffic, IPv6 ACLs to IPv6 traffic, and MAC ACLs to all other traffic.

This command does not require a license.

Examples

This example shows how to create a VLAN access map named `vlan-map-01` and add two entries that each have two **match** commands and one **action** command:

```
Device(config-access-map)# vlan access-map vlan-map-01
Device(config-access-map)# match ip address ip-acl-01
switch(config-access-map)# action forward
switch(config-access-map)# match mac address mac-acl-00f
switch(config-access-map)# vlan access-map vlan-map-01
switch(config-access-map)# match ip address ip-acl-320
switch(config-access-map)# match mac address mac-acl-00e
switch(config-access-map)# action drop
switch(config-access-map)# show vlan access-map
Vlan access-map vlan-map-01 10
    match ip: ip-acl-01
    match mac: mac-acl-00f
    action: forward
Vlan access-map vlan-map-01 20
    match ip: ip-acl-320
    match mac: mac-acl-00e
    action: drop
```

mtrace fabricpath

To trace the path from a source to a destination branch for FabricPath OAM, use the **mtrace fabricpath** command in privileged EXEC mode.

mtrace fabricpath [*tree id* | **ftag** *ftag-id*] {**profile** *profile-id* | **mac dst** *dst-mac* **etype** *etype* | **ip dst** *dst-ip* **src** *src-ip* | **forward flow** *flow-ent* {**I2** | **I3**} } [**ingress** *if-id*] {**vlan** *vlan-id* | **tag** *tag-id* | **dot1q** *dot1q-id* *intf-id*} [**use-host-vlan**] [**topology** *t-id*] [**reply mode** **out-of-band**] {**ipv4** *ip-addr* | **ipv6** *ipv6-addr* } [**data pattern** *data*] [**size** *size*][**validate**][**repeat** *repeat-count*][**switch-id** *sw-id*] [**verbose**]

Syntax Description

tree id	(Optional) Specifies the ID of the multicast tree to be verified.
ftag <i>ftag-id</i>	(Optional) Specifies the multicast Forwarding Tag (FTag) ID.
profile <i>profile-id</i>	Specifies the profile ID.
mac dst <i>dst-mac</i>	Specifies the destination MAC address.
etype <i>etype</i>	Specifies the ether type.
ip dst <i>dst-ip</i>	Specifies the destination IP address.
src <i>src-ip</i>	Specifies the source IP address.
forward flow <i>flow-ent</i>	Specifies the input flow entropy (128 bytes) from actual user data traffic so that FabricPath OAM packet takes the same path as user traffic.
I2	Specifies that the input flow entropy must be terminated until only Layer 2 entries are used. For example, MAC address, VLAN, and e-type. We recommend that you use only one string option.
I3	Specifies that the input flow entropy must be terminated until only Layer 3 entries are used. Note Only IPv4 and IPv6 entries can be processed
ingress <i>if-id</i>	(Optional) Specifies the ingress interface ID.
vlan <i>vlan-id</i>	Specifies the VLAN ID for the multicast tree to be verified.
tag <i>tag-id</i>	Specifies the tag ID. Note The VLAN ID and tag ID are mutually exclusive.

dot1q <i>dot1q-id intf-id</i>	Specifies the 802.1Q tag ID. Note The dot1q option is not available on Cisco Nexus 5000 series and 6000 series switches; it is available only on the Cisco Nexus 7000 series switches.
use-host-vlan	(Optional) Specifies that only VLAN input should be used. Use this keyword when enhanced forwarding is applied and you do not want to use translated VLAN. Use this option when you specify the ingress interface ID or when you specify the flow entropy through the profile keyword or through forward flow with IP address of customer traffic.
topology <i>t-id</i>	(Optional) Specifies the topology ID. Range is from 0 to 63. Default is 0.
reply mode out-of-band	(Optional) Specifies that the FabricPath OAM reply mode is out of band. By default, FabricPath OAM is replied in band (on the FabricPath network). Use the reply mode out-of-band keyword to change the mode of reply to out of band for input IPv4 or IPv6 addresses. For routing, only the default VRF is used.
ipv4 <i>ip-addr</i>	(Optional) Specifies the input IPv4 address for out-of-band reply.
ipv6 <i>ipv6-addr</i>	(Optional) Specifies the input IPv6 address for out-of-band reply.
data pattern <i>data</i>	(Optional) Specifies the data pattern.
size <i>size</i>	(Optional) Specifies the padding size of data TLV or test TLV. The total size must not be greater than the MTU of the egress interface.
validate	(Optional) Validates the ping command.
repeat <i>repeat-count</i>	(Optional) Specifies the repeat value.
interval <i>interval-value</i>	(Optional) Specifies the minimum send delay between requests, in milliseconds. The range is from 100 to 3600000. Default is 0 for synchronous ping, 1000 for asynchronous ping.
timeout <i>timeout-value</i>	(Optional) Specifies the timeout values in seconds. Range is from 1 to 36000.
hop <i>hop-count</i>	(Optional) Specifies the FabricPath OAM ping hop count. Range is from 1 to 64. Default is 63.

switch-id <i>sw-id</i>	(Optional) Sends an mtrace request to the specified switch ID.
verbose	(Optional) Displays additional information.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
7.0(0)N1(1)	This command was introduced.

Usage Guidelines

For a synchronous ping, traceroute, or mtrace, if the profile has multiple interfaces, only the first interface is selected. Use the **interface** keyword to overwrite the selected interface. Only one session is created.

The following rules are apply:

- If a tree ID is specified, an ether type cannot be specified.
- If a Layer 2 tree is specified, a source MAC cannot be specified.
- If a Layer 3 tree is specified, a source and destination MAC addresses cannot be specified.
- If flow entropy is specified, type of flow, either Layer 2 or Layer 3, must be specified. If the flow is Layer 2, the source MAC address is overwritten. If the flow is Layer 3, the source and destination MAC addresses are overwritten.

Examples

The following example shows how to specify a FabricPath mtrace for all trees.

```
Device# mtrace fabricpath vlan 10

Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
'D' - Destination Unreachable, 'X' - unknown return code,
'V' - VLAN nonexistent, 'v' - VLAN in suspended state,
'm' - malformed request, 'C' - Cross Connect Error,
'U' - Unknown RBridge nickname, 'n' - Not AF,
'*' - Success, Optional Tlv incomplete,
'I' - Interface not in forwarding state,
'S' - Service Tag nonexistent, 's' - Service Tag in suspended state,
'c' - Corrupted Data/Test

Sender handle: 3

FabricPath mtrace for multicast ftag 1, vlan 10

Code SwitchId Interface State TotalTime
=====
! 320 Rcvd on Eth1/48 fwd 2ms
! 3498 Rcvd on Eth1/47 fwd 2ms

FabricPath mtrace for multicast ftag 2, vlan 10

Code SwitchId Interface State TotalTime
=====
! 320 Rcvd on Eth1/48 fwd 2ms
```

```

! 3498 Rcvd on Eth1/47 fwd 2ms

FabricPath mtrace for multicast ftag 1, vlan 10

Code SwitchId Interface State TotalTime
=====
! 320 Rcvd on Eth1/48 fwd 2ms
! 3498 Rcvd on Eth1/47 fwd 2ms

FabricPath mtrace for multicast ftag 2, vlan 10

Code SwitchId Interface State TotalTime
=====
! 320 Rcvd on Eth1/48 fwd 2ms
! 3498 Rcvd on Eth1/47 fwd 3ms

FabricPath mtrace for multicast ftag 1, vlan 10

Code SwitchId Interface State TotalTime
=====
! 320 Rcvd on Eth1/48 fwd 2ms
! 3498 Rcvd on Eth1/47 fwd 3ms

```

The following example shows how to specify FabricPath mtrace for a specific tree.

```

Device(#) mtrace fabricpath tree 1 vlan 10 repeat 1

Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
'D' - Destination Unreachable, 'X' - unknown return code,
'V' - VLAN nonexistent, 'v' - VLAN in suspended state,
'm' - malformed request, 'C' - Cross Connect Error,
'U' - Unknown RBridge nickname, 'n' - Not AF,
'*' - Success, Optional Tlv incomplete,
'I' - Interface not in forwarding state,
'S' - Service Tag nonexistent, 's' - Service Tag in suspended state,
'c' - Corrupted Data/Test

Sender handle: 4

FabricPath mtrace for multicast ftag 1, vlan 10

Code SwitchId Interface State TotalTime
=====
! 3498 Rcvd on Eth1/47 fwd 2ms
! 320 Rcvd on Eth1/48 fwd 3ms

```

The following example shows how to specify FTag instead of tree.

```

Device(#) mtrace fabricpath ftag 1 vlan 10 repeat 1 verbose

Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
'D' - Destination Unreachable, 'X' - unknown return code,
'V' - VLAN nonexistent, 'v' - VLAN in suspended state,
'm' - malformed request, 'C' - Cross Connect Error,
'U' - Unknown RBridge nickname, 'n' - Not AF,
'*' - Success, Optional Tlv incomplete,
'I' - Interface not in forwarding state,
'S' - Service Tag nonexistent, 's' - Service Tag in suspended state,
'c' - Corrupted Data/Test

Sender handle: 6

FabricPath mtrace for multicast ftag 1, vlan 10

Code SwitchId Interface State TotalTime DownSwitchId Intf State
=====
! 3498 Rcvd on Eth1/47 fwd 2ms
! 320 Rcvd on Eth1/48 fwd 3ms

```

The following example shows how to specify a pair of trees.

```
Device(#) mtrace fabricpath ip dst 224.1.1.1 src 10.1.1.1 vlan 10 repeat 1
```

```
Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
'D' - Destination Unreachable, 'X' - unknown return code,
'V' - VLAN nonexistent, 'v' - VLAN in suspended state,
'm' - malformed request, 'C' - Cross Connect Error,
'U' - Unknown RBridge nickname, 'n' - Not AF,
'*' - Success, Optional Tlv incomplete,
'I' - Interface not in forwarding state,
'S' - Service Tag nonexistent, 's' - Service Tag in suspended state,
'c' - Corrupted Data/Test
```

```
Sender handle: 7
```

```
FabricPath mtrace for multicast ftag 1, vlan 10
```

```
Code SwitchId Interface State TotalTime
=====
! 320 Rcvd on Eth1/48 fwd 2ms
```

Related Commands

Command	Description
ping fabricpath	Tests the FabricPath OAM reachability.
traceroute fabricpath	Discovers the FabricPath route.