



Flexible Netflow Command Reference, Cisco IOS XE Release 3SE (Cisco WLC 5700 Series)

First Published: January 18, 2013

Last Modified: January 29, 2013

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883



CONTENTS

CHAPTER 1

cache (Flexible NetFlow) through match flow 1

- cache (Flexible NetFlow) 3
- clear flow exporter 8
- clear flow monitor 10
- clear sampler 12
- collect counter 14
- collect interface 18
- collect timestamp absolute 20
- collect transport tcp 22
- debug flow exporter 26
- debug flow monitor 28
- debug flow record 30
- debug sampler 35
- default (Flexible NetFlow) 37
- description (Flexible NetFlow) 39
- destination 41
- dscp (Flexible NetFlow) 43
- exporter 45
- export-protocol 47
- flow exporter 49
- flow monitor 51
- flow record 53
- ip flow monitor 55
- ipv6 flow monitor 59
- match datalink dot1q priority 63
- match datalink dot1q vlan 64
- match datalink ethertype 66
- match datalink mac 67

match datalink vlan 69

match flow 70

CHAPTER 2

match interface (Flexible NetFlow) through ttl (Flexible NetFlow) 73

match interface (Flexible NetFlow) 75

match ipv4 78

match ipv4 destination 81

match ipv4 source 84

match ipv4 ttl 87

match ipv6 89

match ipv6 destination 92

match ipv6 hop-limit 94

match ipv6 source 96

match transport 98

match transport icmp ipv4 100

match transport icmp ipv6 102

mode (Flexible NetFlow) 104

option (Flexible NetFlow) 106

record 111

sampler 116

show flow exporter 118

show flow interface 124

show flow monitor 126

show flow monitor cache aggregate 135

show flow monitor cache filter 141

show flow monitor cache sort 148

show flow record 152

show sampler 157

source (Flexible NetFlow) 160

template data timeout 162

transport (Flexible NetFlow) 164

ttl (Flexible NetFlow) 166



cache (Flexible NetFlow) through match flow

- [cache \(Flexible NetFlow\), page 3](#)
- [clear flow exporter, page 8](#)
- [clear flow monitor, page 10](#)
- [clear sampler, page 12](#)
- [collect counter, page 14](#)
- [collect interface, page 18](#)
- [collect timestamp absolute, page 20](#)
- [collect transport tcp, page 22](#)
- [debug flow exporter, page 26](#)
- [debug flow monitor, page 28](#)
- [debug flow record, page 30](#)
- [debug sampler, page 35](#)
- [default \(Flexible NetFlow\), page 37](#)
- [description \(Flexible NetFlow\), page 39](#)
- [destination, page 41](#)
- [dscp \(Flexible NetFlow\), page 43](#)
- [exporter, page 45](#)
- [export-protocol, page 47](#)
- [flow exporter, page 49](#)
- [flow monitor, page 51](#)
- [flow record, page 53](#)
- [ip flow monitor, page 55](#)
- [ipv6 flow monitor, page 59](#)
- [match datalink dot1q priority, page 63](#)

- [match datalink dot1q vlan, page 64](#)
- [match datalink ethertype, page 66](#)
- [match datalink mac, page 67](#)
- [match datalink vlan, page 69](#)
- [match flow, page 70](#)

cache (Flexible NetFlow)

To configure the flow cache parameter for a Flexible NetFlow flow monitor, use the **cache** command in Flexible NetFlow flow monitor configuration mode. To remove a flow cache parameter for a Flexible NetFlow flow monitor, use the **no** form of this command.

cache {*entries number*| **timeout** {*active seconds*| *inactive seconds*| **update seconds**| **event transaction-end**}| **type** {**immediate**| **normal**| **permanent**}}

no cache {*entries*| **timeout** {*active*| *inactive*| **update**| **event transaction-end**}| **type**}

Cisco IOS XE Release 3.2SE

cache {**timeout** {*active seconds*| *inactive seconds*| **update seconds**}| **type normal**}

no cache {**timeout** {*active*| *inactive*| **update**}| **type**}

Syntax Description

entries <i>number</i>	Specifies the maximum number of entries in the flow monitor cache. Range: 16 to 1048576. Default: 4096.
timeout <i>active seconds</i>	Specifies the active flow timeout in seconds. Range: 1 to 604800 (7 days). Default: 1800.
timeout <i>inactive seconds</i>	Specifies the inactive flow timeout in seconds. Range: 1 to 604800 (7 days). Default: 15.
timeout <i>update seconds</i>	Specifies the update timeout, in seconds, for a permanent flow cache. Range: 1 to 604800 (7 days). Default: 1800.
timeout event transaction-end	Specifies that the record is generated and exported in the NetFlow cache at the end of a transaction.
type	Specifies the type of the flow cache.
immediate	Configures an immediate cache type. This cache type will age out every record as soon as it is created.
normal	Configures a normal cache type. The entries in the flow cache will be aged out according to the timeout active seconds and timeout inactive seconds settings. This is the default cache type.
permanent	Configures a permanent cache type. This cache type disables flow removal from the flow cache.

Command Default

The default Flexible NetFlow flow monitor flow cache parameters are used.

The following flow cache parameters for a Flexible NetFlow flow monitor are enabled:

- Cache type: normal
- Maximum number of entries in the flow monitor cache: 4096
- Active flow timeout: 1800 seconds
- Inactive flow timeout: 15 seconds
- Update timeout for a permanent flow cache: 1800 seconds

Command Modes

Flexible NetFlow flow monitor configuration (config-flow-monitor)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	This command was modified. Support for this command implemented on the Cisco 7200 series routers.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
Cisco IOS XE Release 3.1S	This command was integrated into Cisco IOS XE Release 3.1S.
Cisco IOS XE Release 3.4S	This command was modified. The event transaction-end keyword was added.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE with support for the timeout and type normal keywords only.

Usage Guidelines

Each flow monitor has a cache that it uses to store all the flows it monitors. Each cache has various configurable elements, such as the number of entries and the time that a flow is allowed to remain in it. When a flow times out, it is removed from the cache and sent to any exporters that are configured for the corresponding flow monitor.

If a cache is already active (that is, you have applied the flow monitor to at least one interface in the router), your changes to the record, cache type, and cache size parameters will not take effect until you either reboot the router or remove the flow monitor from every interface and then reapply it. Therefore whenever possible you should customize the record, cache type, and cache size parameters for the cache before you apply the flow monitor to an interface. You can modify the timers, flow exporters, and statistics parameters for a cache while the cache is active.

cache entries

This command controls the size of the cache. Cache size should be based on a number of factors, including the number of flows expected, the time the flows are expected to last (based on the configured key fields and the traffic), and the timeout values configured for the cache. The size should be large enough to minimize emergency expiry.

Emergency expiry is caused by the Flexible NetFlow cache becoming full. When the Flexible NetFlow cache becomes full, the router performs “emergency expiry” where a number of flows are immediately aged, expired from the Flexible NetFlow cache, and exported in order to free up space for more flows.

For a permanent cache (flows never expire), the number of entries should be large enough to accommodate the number of flows expected for the entire duration of the cache entries. If more flows occur than there are cache entries, the excess flows are not recorded in the cache.

For an immediate cache (flows expire immediately), the number of entries simply controls the amount of history that is available for previously seen packets.

cache timeout active

This command controls the aging behavior of the normal type of cache. If a flow has been active for a long time, it is usually desirable to age it out (starting a new flow for any subsequent packets in the flow). This age out process allows the monitoring application that is receiving the exports to remain up to date. By default this timeout is 1800 seconds (30 minutes), but it can be adjusted according to system requirements. A larger value ensures that long-lived flows are accounted for in a single flow record; a smaller value results in a shorter delay between starting a new long-lived flow and exporting some data for it.

cache timeout inactive

This command controls the aging behavior of the normal type of cache. If a flow has not seen any activity for a specified amount of time, that flow will be aged out. By default, this timeout is 15 seconds, but this value can be adjusted depending on the type of traffic expected.

If a large number of short-lived flows is consuming many cache entries, reducing the inactive timeout can reduce this overhead. If a large number of flows frequently get aged out before they have finished collecting their data, increasing this timeout can result in better flow correlation.

cache timeout update

This command controls the periodic updates sent by the permanent type of cache. This behavior is similar to the active timeout, except that it does not result in the removal of the cache entry from the cache. By default this timer value is 1800 seconds (30 minutes).

cache timeout event transaction-end

To use this command, you must configure the **match connection transaction id** command and the **match application name** command for the flow record. This command causes the record to be generated and exported in the NetFlow cache at the end of a transaction. A transaction is a set of logical exchanges between endpoints. There is normally one transaction within a flow.

cache type immediate

This command specifies the immediate cache type. This type of cache will age out every record as soon as it is created, with the result that every flow contains just one packet. The commands that display the cache contents will provide a history of the packets seen.

The use of this cache type is appropriate when very small flows are expected and a minimum amount of latency between analyzing a packet and exporting a report is desired. We recommend using this command when you are sampling packet chunks because the number of packets per flow is typically very low.

**Caution**

This command may result in a large amount of export data that can overload low speed links and overwhelm any systems to which you are exporting. We recommended that you configure sampling to reduce the number of packets seen.

**Note**

The timeout settings have no effect for the immediate cache type.

cache type normal

This command specifies the normal cache type. This is the default cache type. The entries in the cache will be aged out according to the **timeout active seconds** and **timeout inactive seconds** settings. When a cache entry is aged out, it is removed from the cache and exported via any exporters configured for the monitor associated with the cache.

cache type permanent

This command specifies the permanent cache type. This type of cache never ages out any flows. This cache type is useful when the number of flows you expect to see has a limit and there is a need to keep long-term statistics on the router. For example, if the only key field is IP TOS, a limit of 256 flows can be seen, so to monitor the long-term usage of the IP TOS field, a permanent cache can be used. Update messages are exported via any exporters configured for the monitor associated with this cache in accordance with the **timeout update seconds** setting.

**Note**

When a cache becomes full, new flows will not be monitored. If this occurs, a “Flows not added” statistic will appear in the cache statistics.

**Note**

A permanent cache uses update counters rather than delta counters. This means that when a flow is exported, the counters represent the totals seen for the full lifetime of the flow and not the additional packets and bytes seen since the last export was sent.

Examples

The following example shows how to configure the number of entries for the flow monitor cache:

```
Router(config)# flow monitor FLOW-MONITOR-1
Router(config-flow-monitor)# cache entries 16
```

The following example shows how to configure the active timeout for the flow monitor cache:

```
Router(config)# flow monitor FLOW-MONITOR-1
Router(config-flow-monitor)# cache timeout active 4800
```

The following example shows how to configure the inactive timer for the flow monitor cache:

```
Router(config)# flow monitor FLOW-MONITOR-1
Router(config-flow-monitor)# cache timeout inactive 3000
```

The following example shows how to configure the permanent cache update timeout:

```
Router(config)# flow monitor FLOW-MONITOR-1
Router(config-flow-monitor)# cache timeout update 5000
```

The following example shows how to configure a normal cache:

```
Router(config)# flow monitor FLOW-MONITOR-1
Router(config-flow-monitor)# cache type normal
```

The following example shows how to configure a permanent cache:

```
Router(config)# flow monitor FLOW-MONITOR-1
Router(config-flow-monitor)# cache type permanent
```

The following example shows how to configure an immediate cache:

```
Router(config)# flow monitor FLOW-MONITOR-1
Router(config-flow-monitor)# cache type immediate
```

Related Commands

Command	Description
flow monitor	Creates a flow monitor, and enters Flexible NetFlow flow monitor configuration mode.

clear flow exporter

To clear the statistics for a Flexible NetFlow flow exporter, use the **clear flow exporter** command in privileged EXEC mode.

clear flow exporter {*name exporter-name* *statistics*| *statistics*}

Syntax Description

name	Specifies the name of a flow exporter.
<i>exporter-name</i>	Name of a flow exporter that was previously configured.
statistics	Clears the flow exporter statistics.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Examples

The following example clears the statistics for all of the flow exporters configured on the router:

```
Router# clear flow exporter statistics
```

The following example clears the statistics for the flow exporter named FLOW-EXPORTER-1:

```
Router# clear flow exporter name FLOW-EXPORTER-1 statistics
```

Related Commands

Command	Description
debug flow exporter	Enables debugging output for flow exporters.

clear flow monitor

To clear a Flexible NetFlow flow monitor, flow monitor cache, or flow monitor statistics and to force the export of the data in the flow monitor cache, use the **clear flow monitor** command in privileged EXEC mode.

clear flow monitor name *monitor-name* [**cache** [**force-export**]] **force-export** | **statistics**

Syntax Description

name	Specifies the name of a flow monitor.
<i>monitor-name</i>	Name of a flow monitor that was previously configured.
cache	(Optional) Clears the flow monitor cache information.
force-export	(Optional) Forces the export of the flow monitor cache statistics.
statistics	(Optional) Clears the flow monitor statistics.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers in Cisco IOS Release 12.2(33)SRC.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Usage Guidelines

cache

This keyword removes all entries from the flow monitor cache. These entries will not be exported and the data gathered in the cache will be lost.



Note The statistics for the cleared cache entries are maintained.

force-export

This keyword removes all entries from the flow monitor cache and exports them via all flow exporters assigned to the flow monitor. This action can result in a short-term increase in CPU usage. Use with caution.



Note The statistics for the cleared cache entries are maintained.

statistics

This keyword clears the statistics for this flow monitor.



Note The “Current entries” statistic will not be cleared because this is an indicator of how many entries are in the cache and the cache is not cleared with this command.

Examples

The following example clears the statistics and cache entries for the flow monitor named FLOW-MONITOR-1:

```
Router# clear flow monitor name FLOW-MONITOR-1
```

The following example clears the statistics and cache entries for the flow monitor named FLOW-MONITOR-1 and forces an export:

```
Router# clear flow monitor name FLOW-MONITOR-1 force-export
```

The following example clears the cache for the flow monitor named FLOW-MONITOR-1 and forces an export:

```
Router# clear flow monitor name FLOW-MONITOR-1 cache force-export
```

The following example clears the statistics for the flow monitor named FLOW-MONITOR-1:

```
Router# clear flow monitor name FLOW-MONITOR-1 statistics
```

Related Commands

Command	Description
debug flow monitor	Enables debugging output for flow monitors.

clear sampler

To clear the statistics for a Flexible NetFlow flow sampler, use the **clear sampler** command in privileged EXEC mode.

clear sampler [**name**] [*sampler-name*]

Syntax Description

name	(Optional) Specifies the name of a flow sampler.
<i>sampler-name</i>	(Optional) Name of a flow sampler that was previously configured.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Examples

The following example clears the sampler statistics for all flow samplers configured on the router:

```
Router# clear sampler
The following example clears the sampler statistics for the flow sampler named SAMPLER-1:

Router# clear sampler name SAMPLER-1
```


Related Commands

Command	Description
debug sampler	Enables debugging output for flow samplers.

collect counter

To configure the number of bytes or packets in a flow as a nonkey field for a flow record, use the **collect counter** command in Flexible NetFlow flow record configuration mode. To disable the use of the number of bytes or packets in a flow (counters) as a nonkey field for a flow record, use the **no** form of this command.

collect counter {bytes [long| replicated [long]| squared long]| packets [long| replicated [long]]}

no collect counter {bytes [long| replicated [long]| squared long]| packets [long| replicated [long]]}

Cisco Performance Monitor in Cisco IOS Release 15.1(3)T and 12.2(58)SE

collect counter {bytes [long| rate]| packets [dropped [long]| long]}

no collect counter {bytes [long| rate]| packets [dropped [long]| long]}

Cisco Catalyst 6500 Switches in Cisco IOS Release 12.2(50)SY

collect counter {bytes [long]| packets [long]}

no collect counter {bytes [long]| packets [long]}

Cisco IOS XE Release 3.2SE

no collect counter {bytes {layer2 long| long}| packets long}

no collect counter {bytes {layer2 long| long}| packets long}

Syntax Description

bytes	Configures the number of bytes seen in a flow as a nonkey field and enables collecting the total number of bytes from the flow.
layer 2 long	Enables collecting the total number of Layer 2 bytes or packets from the flow using a 64-bit counter rather than a 32-bit counter. For Cisco IOS XE Release 3.2SE, use the layer 2 long keywords rather than the long keyword.
long	(Optional) Enables collecting the total number of bytes or packets from the flow using a 64-bit counter rather than a 32-bit counter. For Cisco IOS XE Release 3.2SE, use the layer 2 long keywords rather than the long keyword.
replicated	Total number of replicated (multicast) IPv4 packets.
squared long	(Optional) Enables collecting the total of the square of the number of bytes from the flow.

packets	Configures the number of packets seen in a flow as a nonkey field and enables collecting the total number of packets from the flow.
rate	Configures the byte rate counter as a nonkey field.
dropped	Configures the dropped packet counter as a nonkey field.

Command Default

The number of bytes or packets in a flow is not configured as a nonkey field.

Command Modes

Flexible NetFlow flow record configuration (config-flow-record)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this Cisco was implemented on the 12000 series routers.
12.2(33)SRC	This command was modified. Support for this Cisco was implemented on the Cisco 7200 series routers in Cisco IOS Release 12.2(33)SRC.
12.4(22)T	This command was modified. The replicated keyword was added.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
15.1(3)T	This command was modified for the Cisco Performance Monitor. The replicated and squared long keywords were removed and the rate and dropped keywords were added.
12.2(58)SE	This command was modified for the Cisco Performance Monitor. The replicated and squared long keywords were removed and the rate and dropped keywords were added.
12.2(50)SY	This command was modified. The replicated and squared long keywords were removed.
Cisco IOS XE Release 3.2SE	This command was modified. The layer 2 long keyword combination was added. The replicated and squared long keywords were removed.

Usage Guidelines

This command can be used with both Flexible NetFlow and Performance Monitor. These products use different commands to enter the configuration mode in which you issue this command, however the mode prompt is the same for both products. For Flexible NetFlow, the mode is also known as Flexible NetFlow flow record configuration mode. For Performance Monitor, the mode is also known as Performance Monitor flow record configuration mode. Here we refer to them both as flow record configuration mode.

The Flexible NetFlow and Performance Monitor **collect** commands are used to configure nonkey fields for the flow monitor record and to enable capturing the values in the fields for the flow created with the record. The values in nonkey fields are added to flows to provide additional information about the traffic in the flows. A change in the value of a nonkey field does not create a new flow. In most cases the values for nonkey fields are taken from only the first packet in the flow.

Cisco Performance Monitor in Cisco IOS Release 15.1(3)T and 12.2(58)SE

The **rate** and **dropped** keywords were added and the **replicated** and **squared long** keywords were removed. You must first enter the **flow record type performance-monitor** command.

collect counter bytes

This command configures a 32-bit counter for the number of bytes seen in a flow.

collect counter packets

This command configures a 32-bit counter that is incremented for each packet seen in the flow. For extremely long flows it is possible for this counter to restart at 0 (wrap) when it reaches the limit of approximately 4 billion packets. On detection of a situation that would cause this counter to restart at 0, a flow monitor with a normal cache type exports the flow and starts a new flow.

collect counter packets long

This command configures a 64-bit counter that will be incremented for each packet seen in the flow. It is unlikely that a 64-bit counter will ever restart at 0.

collect counter bytes squared long

This counter can be used in conjunction with the byte and packet counters in order to calculate the variance of the packet sizes. Its value is derived from squaring each of the packet sizes in the flow and adding the results. This value can be used as part of a standard variance function.

The variance and standard deviation of the packet sizes for the flow can be calculated with the following formulas:

cbs: value from the **counter bytes squared** field

pkts: value from the **counter packets** field

bytes: value from the **counter bytes** field

Variance = (cbs/pkts) - (bytes/pkts)²

Standard deviation = square root of Variance

Example 1:

Packet sizes of the flow: 100, 100, 100, 100

Counter packets: 4

Counter bytes: 400, mean packet size = 100

Counter bytes squared: 40,000

Variance = (40,000/4) - (400/4)² = 0

Standard Deviation = 0

Size = 100 +/- 0

Example 2:

Packet sizes of the flow: 50, 150, 50, 150

Counter packets: 4

Counter bytes: 400, mean packet size = 100

Counter bytes squared: 50,000

Variance = (50,000/4) - (400/4)² = 2500

Standard deviation = 50

Size = 100 +/- 50

Examples

The following example configures the total number of bytes in the flows as a nonkey field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# collect counter bytes
```

The following example configures the total number of bytes in the flows as a nonkey field using a 64-bit counter:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# collect counter bytes long
```

The following example configures the sum of the number of bytes of each packet in the flow squared as a nonkey field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# collect counter bytes squared long
```

The following example configures the total number of packets from the flows as a nonkey field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# collect counter packets
```

The following example configures the total number of packets from the flows as a nonkey field using a 64-bit counter:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# collect counter packets long
```

The following example configures the total number of packets from the flows as a nonkey field using a 64-bit counter:

```
Router(config)# flow record type performance-monitor RECORD-1
Router(config-flow-record)# collect counter packets long
```

Related Commands

Command	Description
flow record	Creates a flow record for Flexible NetFlow.
flow record type performance-monitor	Creates a flow record for Performance Monitor.

collect interface

To configure the input and output interface as a nonkey field for a flow record, use the **collect interface** command in flow record configuration mode. To disable the use of the input and output interface as a nonkey field for a flow record, use the **no** form of this command.

collect interface {input| output}

no collect interface {input| output}

Cisco Catalyst 6500 Switches in Cisco IOS Release 12.2(50)SY

collect interface {input [physical]| output} [snmp]

no collect interface {input [physical]| output} [snmp]

Syntax Description

input	Configures the input interface as a nonkey field and enables collecting the input interface from the flows.
output	Configures the output interface as a nonkey field and enables collecting the output interface from the flows.

Command Default

The input and output interface is not configured as a nonkey field.

Command Modes

flow record configuration (config-flow-record)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	This command was integrated into Cisco IOS Release 12.2(33)SRC and implemented on the Cisco 7200 series routers.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE for the Cisco 7300 Network Processing Engine (NPE) series routers.
15.1(3)T	This command was integrated into Cisco IOS Release 15.1(3)T for Cisco Performance Monitor.
12.2(58)SE	This command was integrated into Cisco IOS Release 12.2(58)SE for Cisco Performance Monitor.

Release	Modification
12.2(50)SY	This command was modified. The physical and snmp keywords were added in Cisco IOS Release 12.2(50)SY.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Usage Guidelines

This command can be used with both Flexible NetFlow and Performance Monitor. These products use different commands to enter the configuration mode in which you issue this command, however the mode prompt is the same for both products. For Flexible NetFlow, the mode is also known as Flexible NetFlow flow record configuration mode. For Performance Monitor, the mode is also known as Performance Monitor flow record configuration mode. Here we refer to them both as flow record configuration mode.

The Flexible NetFlow and Performance Monitor **collect** commands are used to configure nonkey fields for the flow monitor record and to enable capturing the values in the fields for the flow created with the record. The values in nonkey fields are added to flows to provide additional information about the traffic in the flows. A change in the value of a nonkey field does not create a new flow. In most cases the values for nonkey fields are taken from only the first packet in the flow.

Cisco Performance Monitor in Cisco IOS Release 15.1(3)T and 12.2(58)SE

You must first enter the **flowrecordtypeperformance-monitor** command.

Examples

The following example configures the input interface as a nonkey field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# collect interface input
```

The following example configures the output interface as a nonkey field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# collect interface output
```

Examples

The following example configures the input interface as a nonkey field:

```
Router(config)# flow record type performance-monitor RECORD-1
Router(config-flow-record)# collect interface input
```

Related Commands

Command	Description
flow record	Creates a flow record for Flexible NetFlow.
flow record type performance-monitor	Creates a flow record for Performance Monitor.

collect timestamp absolute

To configure the absolute time of the first seen or last seen packet in a flow as a nonkey field for a flow record, use the **collect timestamp absolute** command in Flexible NetFlow flow record configuration mode. To disable the use of the first seen or last seen packet in a flow as a nonkey field for a flow record, use the **no** form of this command.

collect timestamp absolute {first| last}

no collect timestamp absolute {first| last}

Syntax Description

first	Configures the absolute time that the first packet was seen from the flows as a nonkey field and enables collecting time stamps based on the system uptime for the time the first packet was seen from the flows.
last	Configures the absolute time that the last packet was seen from the flows as a nonkey field and enables collecting time stamps based on the system uptime for the time the most recent packet was seen from the flows.

Command Default

The absolute time field is not configured as a nonkey field.

Command Modes

Flexible NetFlow flow record configuration (config-flow-record)

Command History

Release	Modification
Cisco IOS XE Release 3.2SE	This command was introduced.

Usage Guidelines

The Flexible NetFlow collect commands are used to configure nonkey fields for the flow monitor record and to enable capturing the values in the fields for the flow created with the record. The values in nonkey fields are added to flows to provide additional information about the traffic in the flows. A change in the value of a nonkey field does not create a new flow. In most cases the values for nonkey fields are taken from only the first packet in the flow.

Examples

The following example configures time stamps for the absolute time that the first packet was seen from the flows as a nonkey field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# collect timestamp absolute first
```


The following example configures the time stamps for the absolute time that the most recent packet was seen from the flows as a nonkey field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# collect timestamp absolute last
```

Related Commands

Command	Description
flow record	Creates a flow record, and enters Flexible NetFlow flow record configuration mode.

collect transport tcp

To configure one or more of the TCP fields as a nonkey field for a flow record, use the **collect transport tcp** command in flow record configuration mode. To disable the use of one or more of the TCP fields as a nonkey field for a flow record, use the **no** form of this command.

collect transport tcp {acknowledgement-number| destination-port| flags [ack| cwr| ece| fin| psh| rst| syn| urg]| header-length| maximum-segment-size| sequence-number| source-port| urgent-pointer| window-size| window-size-average| window-size-maximum| window-size-minimum}

no collect transport tcp {acknowledgement-number| destination-port| flags [ack| cwr| ece| fin| psh| rst| syn| urg]| header-length| maximum-segment-size| sequence-number| source-port| urgent-pointer| window-size| window-size-average| window-size-maximum| window-size-minimum}

Cisco Catalyst 6500 Switches in Cisco IOS Release 12.2(50)SY

collect transport tcp flags [ack| cwr| ece| fin| psh| rst| syn| urg]

no collect transport tcp flags [ack| cwr| ece| fin| psh| rst| syn| urg]

Cisco IOS XE Release 3.2SE

collect transport tcp flags [ack| cwr| ece| fin| psh| rst| syn| urg]

no collect transport tcp flags [ack| cwr| ece| fin| psh| rst| syn| urg]

Syntax Description

acknowledgement- number	Configures the TCP acknowledgement number as a nonkey field and enables collecting the value of the TCP acknowledgment number from the flow.
destination-port	Configures the TCP destination port as a nonkey field and enables collecting the value of the TCP destination port from the flow.
flags	Configures one or more of the TCP flags as a nonkey field and enables collecting the values from the flow.
ack	(Optional) Configures the TCP acknowledgment flag as a nonkey field.
cwr	(Optional) Configures the TCP congestion window reduced flag as a nonkey field.
ece	(Optional) Configures the TCP Explicit Congestion Notification echo (ECE) flag as a nonkey field.
fin	(Optional) Configures the TCP finish flag as a nonkey field.

psh	(Optional) Configures the TCP push flag as a nonkey field.
rst	(Optional) Configures the TCP reset flag as a nonkey field.
syn	(Optional) Configures the TCP synchronize flag as a nonkey field.
urg	(Optional) Configures the TCP urgent flag as a nonkey field.
header-length	Configures the TCP header length (in 32-bit words) as a nonkey field and enables collecting the value of the TCP header length from the flow.
maximum-segment-size	Configures the maximum segment size as a nonkey field and enables collecting the values from the flow.
sequence-number	Configures the TCP sequence number as a nonkey field and enables collecting the value of the TCP sequence number from the flow.
source-port	Configures the TCP source port as a nonkey field and enables collecting the value of the TCP source port from the flow.
urgent-pointer	Configures the TCP urgent pointer as a nonkey field and enables collecting the value of the TCP urgent pointer from the flow.
window-size	Configures the TCP window size as a nonkey field and enables collecting the value of the TCP window size from the flow.
window-size-average	Configures the average window size as a nonkey field and enables collecting the values from the flow.
window-size-maximum	Configures the maximum window size as a nonkey field and enables collecting the values from the flow.
window-size-minimum	Configures the minimum window size as a nonkey field and enables collecting the values from the flow.

Command Default The TCP fields are not configured as a nonkey field.

Command Modes Flow record configuration (config-flow-record)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	Support for this command was added for Cisco 7200 series routers in Cisco IOS Release 12.2(33)SRC.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE for the Cisco 7300 Network Processing Engine (NPE) series routers.
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY without the support of the acknowledgement-number , destination-port , header-length , sequence-number , source-port , urgent-pointer , and window-size keywords.
15.2(2)T	This command was integrated into Cisco IOS Release 15.2(2)T for Cisco Performance Monitor.
Cisco IOS XE Release 3.5S	This command was integrated into Cisco IOS XE Release 3.5S for Cisco Performance Monitor.
Cisco IOS XE Release 3.6S	This command was modified. The maximum-segment-size , window-size-average , window-size-maximum , and window-size-minimum keywords were added into Cisco IOS XE Release 3.6S for Cisco Performance Monitor.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE without the support for the acknowledgement-number , destination-port , header-length , sequence-number , source-port , urgent-pointer , and window-size keywords.

Usage Guidelines

This command can be used with both Flexible NetFlow and Performance Monitor. These products use different commands to enter the configuration mode in which you issue this command, however the mode prompt is the same for both products. For Performance Monitor, you must first enter the **flow record type performance-monitor** command before you can use this command.

Because the mode prompt is the same for both products, here we refer to the command mode for both products as flow record configuration mode. However, for Flexible NetFlow, the mode is also known as Flexible NetFlow flow record configuration mode; and for Performance Monitor, the mode is also known as Performance Monitor flow record configuration mode.

The **collect** commands are used to configure nonkey fields for the flow monitor record and to enable capturing the values in the fields for the flow created with the record. The values in nonkey fields are added to flows to provide additional information about the traffic in the flows. A change in the value of a nonkey field does not create a new flow. In most cases the values for nonkey fields are taken from only the first packet in the flow.

collect transport tcp flags ece

For more information about ECN echo, refer to RFC 3168 *The Addition of Explicit Congestion Notification (ECN) to IP*, at the following URL: <http://www.ietf.org/rfc/rfc3168.txt>.

Examples

The following example configures the TCP acknowledgment number as a nonkey field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# collect transport tcp acknowledgement-number
```

The following example configures the TCP source port as a nonkey field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# collect transport tcp source-port
```

The following example configures the TCP acknowledgment flag as a nonkey field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# collect transport tcp flags ack
```

The following example configures the TCP finish flag as a nonkey field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# collect transport tcp flags fin
```

The following example configures the TCP reset flag as a nonkey field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# collect transport tcp flags rst
```

Examples

The following example configures the TCP reset flag as a nonkey field:

```
Router(config)# flow record type performance-monitor RECORD-1
Router(config-flow-record)# collect transport tcp flags rst
```

Related Commands

Command	Description
flow record	Creates a flow record, and enters Flexible NetFlow flow record configuration mode.
flow record type performance-monitor	Creates a flow record, and enters Performance Monitor flow record configuration mode.

debug flow exporter

To enable debugging output for Flexible NetFlow flow exporters, use the **debug flow exporter** command in privileged EXEC mode. To disable debugging output, use the **no** form of this command.

debug flow exporter [[name] *exporter-name*] [error] [event] [packets *number*]

no debug flow exporter [[name] *exporter-name*] [error] [event] [packets *number*]

Syntax Description

name	(Optional) Specifies the name of a flow exporter.
<i>exporter-name</i>	(Optional) The name of a flow exporter that was previously configured.
error	(Optional) Enables debugging for flow exporter errors.
event	(Optional) Enables debugging for flow exporter events.
packets	(Optional) Enables packet-level debugging for flow exporters.
<i>number</i>	(Optional) The number of packets to debug for packet-level debugging of flow exporters. Range: 1 to 65535.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY.

Release	Modification
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Examples

The following example indicates that a flow exporter packet has been queued for process send:

```
Router# debug flow exporter
May 21 21:29:12.603: FLOW EXP: Packet queued for process send
```

Related Commands

Command	Description
clear flow exporter	Clears the Flexible NetFlow statistics for exporters.

debug flow monitor

To enable debugging output for Flexible NetFlow flow monitors, use the **debug flow monitor** command in privileged EXEC mode. To disable debugging output, use the **no** form of this command.

debug flow monitor [**error**] [[**name**] *monitor-name* [**cache**] [**error**] [**packets** *packets*]]

no debug flow monitor [**error**] [[**name**] *monitor-name* [**cache**] [**error**] [**packets** *packets*]]

Syntax Description

error	(Optional) Enables debugging for flow monitor errors.
name	(Optional) Specifies the name of a flow monitor.
<i>monitor-name</i>	(Optional) The name of a flow monitor that was previously configured.
cache	(Optional) Enables debugging for the flow monitor cache.
packets	(Optional) Enables packet-level debugging for flow monitors.
<i>packets</i>	(Optional) The number of packets to debug for packet-level debugging of flow monitors. Range: 1 to 65535.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY.

Release	Modification
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Examples

The following example shows that the cache for FLOW-MONITOR-1 was deleted:

```
Router# debug flow monitor FLOW-MONITOR-1 cache
May 21 21:53:02.839: FLOW MON:  'FLOW-MONITOR-1' deleted cache
```

Related Commands

Command	Description
clear flow monitor	Clears the Flexible NetFlow flow monitor.

debug flow record

To enable debugging output for Flexible NetFlow flow records, use the **debug flow record** command in privileged EXEC mode. To disable debugging output, use the **no** form of this command.

```
debug flow record [[name] record-name| netflow-original| netflow {ipv4| ipv6} record [peer]] netflow-v5|
options {exporter-statistics| interface-table| sampler-table| vrf-id-name-table}]
```

```
no debug flow record [[name] record-name| netflow-original| netflow {ipv4| ipv6} record [peer]] netflow-v5|
options {exporter-statistics| interface-table| sampler-table| vrf-id-name-table}]
```

Cisco Catalyst 6500 Switches in Cisco IOS Release 12.2(50)SY

```
debug flow record [[name] record-name| netflow-v5| options {exporter-statistics| interface-table|
sampler-table| vrf-id-name-table}| platform-original {ipv4| ipv6} record [detailed| error]]
```

```
no debug flow record [[name] record-name| netflow-v5| options {exporter-statistics| interface-table|
sampler-table| vrf-id-name-table}| platform-original {ipv4| ipv6} record [detailed| error]]
```

Cisco IOS XE Release 3.2SE

```
debug flow record [[name] record-name| netflow {ipv4| ipv6} record [peer]] netflow-v5| options
sampler-table ]
```

```
no debug flow record [[name] record-name| netflow {ipv4| ipv6} record [peer]] netflow-v5| options
sampler-table ]
```

Syntax Description

name	(Optional) Specifies the name of a flow record.
<i>record-name</i>	(Optional) Name of a user-defined flow record that was previously configured.
netflow-original	(Optional) Specifies the traditional IPv4 input NetFlow with origin autonomous systems.
netflow {ipv4 ipv6} record	(Optional) Specifies the name of the NetFlow predefined record. See the table below.
peer	(Optional) Includes peer information for the NetFlow predefined records that support the peer keyword. Note The peer keyword is not supported for every type of NetFlow predefined record. See the table below.
options	(Optional) Includes information on other flow record options.
exporter-statistics	(Optional) Includes information on the flow exporter statistics.

interface-table	(Optional) Includes information on the interface tables.
sampler-table	(Optional) Includes information on the sampler tables.
vrf-id-name-table	(Optional) Includes information on the virtual routing and forwarding (VRF) ID-to-name tables.
platform-original ipv4 <i>record</i>	Configures the flow monitor to use one of the predefined IPv4 records.
platform-original ipv6 <i>record</i>	Configures the flow monitor to use one of the predefined IPv6 records.
detailed	(Optional) Displays detailed information.
error	(Optional) Displays errors only.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.
12.4(20)T	This command was modified. The ipv6 keyword was added in Cisco IOS Release 12.4(20)T.
15.0(1)M	This command was modified. The vrf-id-name-table keyword was added.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY without support for the netflow-original , netflow , ipv4 , netflow , ipv6 and peer keywords. The platform-original ipv4 and platform-originalipv6 keywords were added.

Release	Modification
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE without the support for the netflow-original , options exporter-statistics , options interface-table and option vrf-id-name-table keywords.

Usage Guidelines

The table below describes the keywords and descriptions for the *record* argument.

Table 1: Keywords and Descriptions for the record Argument

Keyword	Description	IPv4 Support	IPv6 Support
as	Autonomous system record.	Yes	Yes
as-tos	Autonomous system and type of service (ToS) record.	Yes	—
bgp-nexthop-tos	BGP next-hop and ToS record.	Yes	—
bgp-nexthop	BGP next-hop record.	—	Yes
destination	Original 12.2(50)SY platform IPv4/IPv6 destination record.	Yes	Yes
destination-prefix	Destination prefix record. Note For IPv6, a minimum prefix mask length of 0 bits is assumed.	Yes	Yes
destination-prefix-tos	Destination prefix and ToS record.	Yes	—
destination-source	Original 12.2(50)SY platform IPv4/IPv6 destination-source record.	Yes	Yes
full	Original 12.2(50)SY platform IPv4/IPv6 full record.	Yes	Yes
interface-destination	Original 12.2(50)SY platform IPv4/IPv6 interface-destination record.	Yes	Yes

Keyword	Description	IPv4 Support	IPv6 Support
interface-destination-source	Original 12.2(50)SY platform IPv4/IPv6 interface-destination-source record.	Yes	Yes
interface-full	Original 12.2(50)SY platform IPv4/IPv6 interface-full record.	Yes	Yes
interface-source	Original 12.2(50)SY platform IPv4/IPv6 interface-source only record.	Yes	Yes
original-input	Traditional IPv4 input NetFlow.	Yes	Yes
original-output	Traditional IPv4 output NetFlow.	Yes	Yes
prefix	Source and destination prefixes record. Note For IPv6, a minimum prefix mask length of 0 bits is assumed.	Yes	Yes
prefix-port	Prefix port record. Note The peer keyword is not available for this record.	Yes	—
prefix-tos	Prefix ToS record.	Yes	—
protocol-port	Protocol ports record. Note The peer keyword is not available for this record.	Yes	Yes
protocol-port-tos	Protocol port and ToS record. Note The peer keyword is not available for this record.	Yes	—

Keyword	Description	IPv4 Support	IPv6 Support
source	Original 12.2(50)SY platform IPv4/IPv6 source only record.	Yes	Yes
source-prefix	Source autonomous system and prefix record. Note For IPv6, a minimum prefix mask length of 0 bits is assumed.	Yes	Yes
source-prefix-tos	Source prefix and ToS record.	Yes	—

Examples

The following example enables debugging for the flow record:

```
Router# debug flow record FLOW-record-1
```

Related Commands

Command	Description
flow record	Create a Flexible NetFlow flow record.

debug sampler

To enable debugging output for Flexible NetFlow samplers, use the **debug sampler** command in privileged EXEC mode. To disable debugging output, use the **no** form of this command.

debug sampler [**detailed**| **error**| [**name**] *sampler-name* [**detailed**| **error**| **sampling** *samples*]]

no debug sampler [**detailed**| **error**| [**name**] *sampler-name* [**detailed**| **error**| **sampling**]]

Syntax Description

detailed	(Optional) Enables detailed debugging for sampler elements.
error	(Optional) Enables debugging for sampler errors.
name	(Optional) Specifies the name of a sampler.
<i>sampler-name</i>	(Optional) Name of a sampler that was previously configured.
sampling <i>samples</i>	(Optional) Enables debugging for sampling and specifies the number of samples to debug.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Examples

The following sample output shows that the debug process has obtained the ID for the sampler named SAMPLER-1:

```
Router# debug sampler detailed
*Oct 28 04:14:30.883: Sampler: Sampler(SAMPLER-1: flow monitor FLOW-MONITOR-1 (ip,Et1/0,O)
get ID succeeded:1
*Oct 28 04:14:30.971: Sampler: Sampler(SAMPLER-1: flow monitor FLOW-MONITOR-1 (ip,Et0/0,I)
get ID succeeded:1
```

Related Commands

Command	Description
clear sampler	Clears the Flexible NetFlow sampler statistics.

default (Flexible NetFlow)

To configure the default values for a Flexible NetFlow (FNF) flow exporter, use the **default** command in Flexible NetFlow flow exporter configuration mode.

```
default {description| destination| dscp| export-protocol| option {application-table| exporter-stats|
interface-table| sampler-table| vrf-table}}| output-features| source| template data timeout| transport| ttl}
```

Cisco IOS XE Release 3.2SE

```
default {description| destination| dscp| export-protocol| option {exporter-stats| interface-table|
sampler-table}}| source| template data timeout| transport| ttl}
```

Syntax Description

description	Provides a description for the flow exporter.
destination	Configures the export destination.
dscp	Configures optional Differentiated Services Code Point (DSCP) values.
export-protocol	Configures the export protocol version.
option	Selects the option for exporting.
application-table	Selects the application table option.
exporter-stats	Selects the exporter statistics option.
interface-table	Selects the interface SNMP-index-to-name table option.
sampler-table	Selects the export sampler option.
vrf-table	Selects the VRF ID-to-name table option.
output-features	Sends export packets via the Cisco IOS output feature path.
source	Configures the originating interface.
template	Configures the flow exporter template.
data	Configure the flow exporter data.
timeout	Resends data based on a timeout.
transport	Configures the transport protocol.

ttl	Configures optional time-to-live (TTL) or hop limit.
------------	--

Command Modes

Flexible NetFlow flow exporter configuration (config-flow-exporter)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE without the support for the option application-table , option vrf-table , and output-features keywords.

Usage Guidelines

Use the **default** command to configure the default values for an FNF flow exporter. The flow exporter information is needed to export the data metrics to a specified destination, port number, and so on.

Examples

The following example shows how to set the default destination for an FNF flow exporter:

```
Router(config)# flow exporter e1
Router(config-flow-exporter)# default destination
```

Related Commands

Command	Description
flow exporter	Creates a flow exporter.

description (Flexible NetFlow)

To configure a description for a Flexible NetFlow flow sampler, flow monitor, flow exporter, or flow record, use the **description** command in the appropriate configuration mode. To remove a description, use the **no** form of this command.

description *description*

no description

Syntax Description

<i>description</i>	Text string that describes the flow sampler, flow monitor, flow exporter, or flow record.
--------------------	---

Command Default

The default description for a Flexible NetFlow flow sampler, flow monitor, flow exporter, or flow record is “User defined”.

Command Modes

Flexible NetFlow flow exporter configuration (config-flow-exporter) Flexible NetFlow flow monitor configuration (config-flow-monitor) Flexible NetFlow flow record configuration (config-flow-record) Flexible NetFlow sampler configuration (config-sampler)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
Cisco IOS XE 3.1S	This command was integrated into Cisco IOS XE Release 3.1S.
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Examples

The following example configures a description for a flow monitor:

```
Router(config)# flow monitor FLOW-MONITOR-1
Router(config-flow-monitor)# description Monitors traffic to 172.16.100.0 255.255.255.0
```

Related Commands

Command	Description
flow exporter	Creates a flow exporter.
flow monitor	Creates a flow monitor.
flow record	Creates a flow record.
sampler	Creates a flow sampler.

destination

To configure an export destination for a Flexible NetFlow flow exporter, use the **destination** command in Flexible NetFlow flow exporter configuration mode. To remove an export destination for a Flexible NetFlow flow exporter, use the **no** form of this command.

destination {{*ip-address*| *hostname*}} **vrf** *vrf-name*}

no destination

Syntax Description

<i>ip-address</i>	IP address of the workstation to which you want to send the NetFlow information.
<i>hostname</i>	Hostname of the device to which you want to send the NetFlow information.
vrf <i>vrf-name</i>	Specifies that the export data packets are to be sent to the named Virtual Private Network (VPN) routing and forwarding (VRF) instance for routing to the destination, instead of to the global routing table.

Command Default

An export destination is not configured.

Command Modes

Flexible NetFlow flow exporter configuration (config-flow-exporter)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
Cisco IOS XE Release 3.1S	This command was integrated into Cisco IOS XE Release 3.1S.
15.1(3)T	This command was modified. Support for the Cisco Performance Monitor was added.

Release	Modification
12.2(58)SE	This command was modified. Support for the Cisco Performance Monitor was added.
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY.
15.2(2)T	This command was integrated into Cisco IOS Release 15.2(2)T and added support for exporting data to a destination using an IPv6 address.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Usage Guidelines

Each flow exporter can have only one destination address or hostname.

For some releases, you can export data to a destination using an IPv6 address.

When you configure a hostname instead of the IP address for the device, the hostname is resolved immediately and the IP address is stored in the running configuration. If the hostname-to-IP-address mapping that was used for the original domain name system (DNS) name resolution changes dynamically on the DNS server, the router does not detect this, and the exported data continues to be sent to the original IP address, resulting in a loss of data. Resolving the hostname immediately is a prerequisite of the export protocol, to ensure that the templates and options arrive before the data

Examples

The following example shows how to configure the networking device to export the Flexible NetFlow cache entry to a destination system:

```
Router(config)# flow exporter FLOW-EXPORTER-1
Router(config-flow-exporter)# destination 10.0.0.4
```

The following example shows how to configure the networking device to export the Flexible NetFlow cache entry to a destination system using a VRF named VRF-1:

```
Router(config)# flow exporter FLOW-EXPORTER-1
Router(config-flow-exporter)# destination 172.16.10.2 vrf VRF-1
```

Related Commands

Command	Description
flow exporter	Creates a flow exporter.

dscp (Flexible NetFlow)

To configure a differentiated services code point (DSCP) value for Flexible NetFlow flow exporter datagrams, use the **dscp** command in Flexible NetFlow flow exporter configuration mode. To remove a DSCP value for Flexible NetFlow flow exporter datagrams, use the **no** form of this command.

dscp *dscp*

no dscp

Syntax Description

<i>dscp</i>	The DSCP to be used in the DSCP field in exported datagrams. Range: 0 to 63. Default: 0.
-------------	--

Command Default

The differentiated services code point (DSCP) value is 0.

Command Modes

Flexible NetFlow flow exporter configuration (config-flow-exporter)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
15.1(3)T	This command was modified. Support for the Cisco Performance Monitor was added.
12.2(58)SE	This command was modified. Support for the Cisco Performance Monitor was added.
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Examples

The following example sets 22 as the value of the DSCP field in exported datagrams:

```
Router(config)# flow exporter FLOW-EXPORTER-1
Router(config-flow-exporter)# dscp 22
```

Related Commands

Command	Description
flow exporter	Creates a flow exporter.

exporter

To configure a flow exporter for a flow monitor, use the **exporter** command in the appropriate configuration mode. To remove a flow exporter for a flow monitor, use the **no** form of this command.

exporter *exporter-name*

no exporter *exporter-name*

Syntax Description

<i>exporter-name</i>	Name of a flow exporter that was previously configured.
----------------------	---

Command Default

An exporter is not configured.

Command Modes

Flow monitor configuration (config-flow-monitor) Policy configuration (config-pmap-c) Policy monitor configuration (config-pmap-c-flowmon)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
Cisco IOS XE Release 3.1S	This command was integrated into Cisco IOS XE Release 3.1S.
15.1(3)T	This command was modified. Support for the Cisco Performance Monitor was added. Support was added for policy configuration mode and policy monitor configuration configuration mode.
12.2(58)SE	This command was modified. Support for the Cisco Performance Monitor was added.
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Usage Guidelines

You must have already created a flow exporter by using the **flow exporter** command before you can apply the flow exporter to a flow monitor with the **exporter** command.

For Performance Monitor, you can associate a flow exporter with a flow monitor while configuring either a flow monitor, policy map, or service policy.

Examples

The following example configures an exporter for a flow monitor:

```
Router(config)# flow monitor FLOW-MONITOR-1
Router(config-flow-monitor)# exporter EXPORTER-1
```

The following example shows one of the ways to configure a flow exporter for Performance Monitor:

```
Router(config)# policy-map type performance-monitor policy-4
Router(config-pmap)# class class-4
Router(config-pmap-c)# flow monitor monitor-4
Router(config-pmap-c-flowmon)# exporter exporter-4
```

Related Commands

Command	Description
flow exporter	Creates a flow exporter.
flow monitor	Creates a flow monitor.
flow monitor type performance-monitor	Creates a flow monitor for Performance Monitor.
policy-map type performance-monitor	Creates a policy map for Performance Monitor
service-policy type performance-monitor	Associates policy map with an interface for Performance Monitor.

export-protocol

To configure the export protocol for a Flexible NetFlow exporter, use the **export-protocol** command in Flexible NetFlow flow exporter configuration mode. To restore the use of the default export protocol for a Flexible NetFlow exporter, use the **no** form of this command.

export-protocol {netflow-v5| netflow-v9| ipfix}

no export-protocol

Cisco IOS XE Release 3.2SE

export-protocol netflow-v9

no export-protocol

Syntax Description

netflow-v5	Configures Netflow Version 5 export as the export protocol.
netflow-v9	Configures Netflow Version 9 export as the export protocol.
ipfix	Configures IPFIX as the export protocol. The export of extracted fields from NBAR is supported only over IPFIX.

Command Default

Netflow Version 9 export is used as the export protocol for a Flexible NetFlow exporter.

Command Modes

Flexible NetFlow flow exporter configuration (config-flow-exporter)

Command History

Release	Modification
12.4(22)T	This command was introduced.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7200 and Cisco 7300 Network Processing Engine (NPE) series routers.
Cisco IOS XE Release 3.1S	This command was integrated into Cisco IOS XE Release 3.1S.
15.1(3)T	This command was modified. Support for the Cisco Performance Monitor was added.
12.2(58)SE	This command was modified. Support for the Cisco Performance Monitor was added.

Release	Modification
15.2(4)M	This command was modified. The ipfix keyword was added in Cisco IOS Release 15.2(4)M.
Cisco IOS XE Release 3.8S	This command was integrated into Cisco IOS XE Release 3.8S.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE without the support for the netflow-v5 and ipfix keywords.

Usage Guidelines

The NetFlow Version 5 export protocol is supported only for flow monitors that use the Flexible NetFlow predefined records.

The export of extracted fields from NBAR is supported only over IPFIX.

Examples

The following example configures Netflow Version 5 export as the export protocol for a Flexible NetFlow exporter:

```
Router(config)# flow exporter FLOW-EXPORTER-1
Router(config-flow-exporter)# export-protocol netflow-v5
```

Related Commands

Command	Description
flow exporter	Creates a flow exporter

flow exporter

To create a Flexible NetFlow flow exporter, or to modify an existing Flexible NetFlow flow exporter, and enter Flexible NetFlow flow exporter configuration mode, use the **flow exporter** command in global configuration mode. To remove a Flexible NetFlow flow exporter, use the **no** form of this command.

flow exporter *exporter-name*

no flow exporter *exporter-name*

Syntax Description

<i>exporter-name</i>	Name of the flow exporter that is being created or modified.
----------------------	--

Command Default

Flexible NetFlow flow exporters are not present in the configuration.

Command Modes

Global configuration (config)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
Cisco IOS XE 3.1S	This command was integrated into Cisco IOS XE Release 3.1S.
15.1(2)S	This command was modified. A hash collision between the name supplied and any existing name is now possible. If this happens, you can retry, supplying another name
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Usage Guidelines

Flow exporters export the data in the flow monitor cache to a remote system, such as a server running Flexible NetFlow collector, for analysis and storage. Flow exporters are created as separate entities in the configuration. Flow exporters are assigned to flow monitors to provide data export capability for the flow monitors. You can create several flow exporters and assign them to one or more flow monitors to provide several export destinations. You can create one flow exporter and apply it to several flow monitors.

In Cisco IOS Release 15.1(2)S and later releases, a hash collision between the name supplied and any existing name is possible. If this happens, you can retry, supplying another name.

Examples

The following example creates a flow exporter named FLOW-EXPORTER-1 and enters Flexible NetFlow flow exporter configuration mode:

```
Router(config)# flow exporter FLOW-EXPORTER-1
Router(config-flow-exporter)#
```

The following example shows the output when there is a hash collision between the name supplied and any existing name:

```
Router(config-flow-exporter)# flow exporter FLOW-EXPORTER-1
% Flow Exporter: Failure creating Flow Exporter 'FLOW-EXPORTER-1' (Hash value in use).
```

Related Commands

Command	Description
clear flow exporter	Clears the statistics for flow exporters.
debug flow exporter	Enables debugging output for flow exporters.

flow monitor

To create a Flexible NetFlow flow monitor, or to modify an existing Flexible NetFlow flow monitor, and enter Flexible NetFlow flow monitor configuration mode, use the **flow monitor** command in global configuration mode or in QoS policy-map-class configuration mode. To remove a Flexible NetFlow flow monitor, use the **no** form of this command.

flow monitor *monitor-name*

no flow monitor *monitor-name*

Syntax Description

<i>monitor-name</i>	Name of the flow monitor that is being created or modified.
---------------------	---

Command Default

Flexible NetFlow flow monitors are not present in the configuration.

Command Modes

Global configuration (config)

QoS policy-map-class configuration (config-pmap-c)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
Cisco IOS XE Release 3.1S	This command was integrated into Cisco IOS XE Release 3.1S.
15.1(2)S	This command was modified. A hash collision between the name supplied and any existing name is now possible. If this happens, you can retry, supplying another name
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY.
15.2(4)M	This command was made available in QoS policy-map-class configuration mode.

Release	Modification
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Usage Guidelines

Flow monitors are the Flexible NetFlow component that is applied to interfaces to perform network traffic monitoring. Flow monitors consist of a record and a cache. You add the record to the flow monitor after you create the flow monitor. The flow monitor cache is automatically created at the time the flow monitor is applied to the first interface. Flow data is collected from the network traffic during the monitoring process based on the key and nonkey fields in the flow monitor's record and stored in the flow monitor cache.

In Cisco IOS Release 15.1(2)S and later releases, a hash collision between the name supplied and any existing name is possible. If this happens, you can retry, supplying another name.

Examples

The following example creates a flow monitor named FLOW-MONITOR-1 and enters Flexible NetFlow flow monitor configuration mode:

```
Router(config)# flow monitor FLOW-MONITOR-1
Router(config-flow-monitor)#
```

The following example shows the output when there is a hash collision between the name supplied and any existing name:

```
Router(config)# flow monitor FLOW-MONITOR-1
% Flow Monitor: could not create monitor.
```

Related Commands

Command	Description
clear flow monitor	Clears the flow monitor.
debug flow monitor	Enables debugging output for flow monitors.

flow record

To create a Flexible NetFlow flow record, or to modify an existing Flexible NetFlow flow record, and enter Flexible NetFlow flow record configuration mode, use the **flow record** command in global configuration mode. To remove a Flexible NetFlow flow record, use the **no** form of this command.

flow record *record-name*

no flow record *record-name*

Syntax Description

<i>record-name</i>	Name of the flow record that is being created or modified.
--------------------	--

Command Default

A Flexible NetFlow flow record is not configured.

Command Modes

Global configuration (config)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
15.1(2)S	This command was modified. A hash collision between the name supplied and any existing name is now possible. If this happens, you can retry, supplying another name
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Usage Guidelines

Flexible NetFlow uses key and nonkey fields just as original NetFlow does to create and populate flows in a cache. In Flexible NetFlow a combination of key and nonkey fields is called a *record*. Original NetFlow and

Flexible NetFlow both use the values in key fields in IP datagrams, such as the IP source or destination address and the source or destination transport protocol port, as the criteria for determining when a new flow must be created in the cache while network traffic is being monitored. A *flow* is defined as a stream of packets between a given source and a given destination. New flows are created whenever a packet that has a unique value in one of the key fields is analyzed.

In Cisco IOS Release 15.1(2)S and later releases, a hash collision between the name supplied and any existing name is possible. If this happens, you can retry, supplying another name.

Examples

The following example creates a flow record named FLOW-RECORD-1, and enters Flexible NetFlow flow record configuration mode:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)#
```

The following example shows the output when there is a hash collision between the name supplied and any existing name:

```
Router(config)# flow record FLOW-RECORD-1
% Flow Record: Failure creating new Flow Record (Hash value in use).
```

Related Commands

Command	Description
show flow record	Displays flow record status and statistics.

ip flow monitor

To enable a Flexible NetFlow flow monitor for IPv4 traffic that the router is receiving or forwarding, use the **ip flow monitor** command in interface configuration mode or subinterface configuration mode. To disable a Flexible NetFlow flow monitor, use the **no** form of this command.

ip flow monitor *monitor-name* [**sampler** *sampler-name*] [**multicast**| **unicast**] {**input**| **output**}

no ip flow monitor *monitor-name* [**sampler** *sampler-name*] [**multicast**| **unicast**] {**input**| **output**}

Cisco Catalyst 6500 Switches in Cisco IOS Release 12.2(50)SY

ip flow monitor *monitor-name* [**sampler** *sampler-name*] [**layer2-switched**| **multicast**| **unicast**] {**input**| **output**}

no ip flow monitor *monitor-name* [**sampler** *sampler-name*] [**layer2-switched**| **multicast**| **unicast**] {**input**| **output**}

Cisco IOS XE Release 3.2SE

ip flow monitor *monitor-name* [**sampler** *sampler-name*] {**input**| **output**}

no ip flow monitor *monitor-name* [**sampler** *sampler-name*] {**input**| **output**}

Syntax Description

<i>monitor-name</i>	Name of a flow monitor that was previously configured.
sampler <i>sampler-name</i>	(Optional) Enables a flow sampler for this flow monitor using the name of a sampler that was previously configured.
layer2-switched	(Optional) Applies the flow monitor for Layer 2-switched traffic only.
multicast	(Optional) Applies the flow monitor for multicast traffic only.
unicast	(Optional) Applies the flow monitor for unicast traffic only.
input	Monitors traffic that the router is receiving on the interface.
output	Monitors traffic that the router is transmitting on the interface.

Command Default

A flow monitor is not enabled.

Command Modes

Interface configuration (config-if) Subinterface configuration (config-subif)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.
12.4(22)T	This command was modified. The unicast and multicast keywords were added.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
12.2(50)SY	This command was modified. The layer2-switched keyword was added.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE without the support for the multicast and unicast keywords.

Usage Guidelines

You must have already created a flow monitor by using the **flow monitor** command before you can apply the flow monitor to an interface with the **ip flowmonitor** command to enable traffic monitoring with Flexible NetFlow.

ip flow monitor sampler

When a sampler is added to a flow monitor, only packets that are selected by the named sampler will be entered into the cache to form flows. Each use of a sampler causes separate statistics to be stored for that usage.

You cannot add a sampler to a flow monitor after the flow monitor has been enabled on an interface. You must remove the flow monitor from the interface prior to enabling the same flow monitor with a sampler. See the “Examples” section for more information.

**Note**

The statistics for each flow must be scaled to give the expected true usage. For example, with a 1 in 10 sampler it is expected that the packet and byte counters will have to be multiplied by 10.

Multicast Traffic and Unicast Traffic

In Cisco IOS Release 12.4(22)T and later releases, the default behavior of the **ip flow monitor** command is to analyze unicast *and* multicast traffic. If you need to monitor only unicast traffic, use the **unicast** keyword. If you need to monitor only multicast traffic, use the **multicast** keyword.

Examples

The following example enables a flow monitor for monitoring input traffic:

```
Router(config)# interface ethernet0/0
Router(config-if)# ip flow monitor FLOW-MONITOR-1 input
```

The following example enables a flow monitor for monitoring output traffic on a subinterface:

```
Router(config)# interface ethernet0/0.1
Router(config-if)# ip flow monitor FLOW-MONITOR-1 output
```

The following example enables a flow monitor for monitoring only multicast input traffic:

```
Router(config)# interface ethernet0/0
Router(config-if)# ip flow monitor FLOW-MONITOR-1 multicast input
```

The following example enables a flow monitor for monitoring only unicast output traffic:

```
Router(config)# interface ethernet0/0
Router(config-if)# ip flow monitor FLOW-MONITOR-1 unicast output
```

The following example enables the same flow monitor on the same interface for monitoring input and output traffic:

```
Router(config)# interface ethernet0/0
Router(config-if)# ip flow monitor FLOW-MONITOR-1 input
Router(config-if)# ip flow monitor FLOW-MONITOR-1 output
```

The following example enables two different flow monitors on the same interface for monitoring input and output traffic:

```
Router(config)# interface ethernet0/0
Router(config-if)# ip flow monitor FLOW-MONITOR-1 input
Router(config-if)# ip flow monitor FLOW-MONITOR-2 output
```

The following example enables the same flow monitor on two different interfaces for monitoring input and output traffic:

```
Router(config)# interface ethernet0/0
Router(config-if)# ip flow monitor FLOW-MONITOR-1 input
Router(config-if)# exit
Router(config)# interface ethernet1/0
Router(config-if)# ip flow monitor FLOW-MONITOR-1 output
```

The following example enables two different flow monitors on two different interfaces for monitoring input and output traffic:

```
Router(config)# interface ethernet0/0
Router(config-if)# ip flow monitor FLOW-MONITOR-1 input
Router(config-if)# exit
Router(config)# interface ethernet1/0
Router(config-if)# ip flow monitor FLOW-MONITOR-2 output
```

The following example enables a flow monitor for monitoring input traffic, with a sampler to limit the input packets that are sampled:

```
Router(config)# interface ethernet0/0
Router(config-if)# ip flow monitor FLOW-MONITOR-1 sampler SAMPLER-1 input
```

The following example enables a flow monitor for monitoring output traffic, with a sampler to limit the output packets that are sampled:

```
Router(config)# interface ethernet0/0
Router(config-if)# ip flow monitor FLOW-MONITOR-1 sampler SAMPLER-1 output
```

The following example enables two different flow monitors for monitoring input and output traffic, with a sampler on the flow monitor that is monitoring input traffic to limit the input packets that are sampled:

```
Router(config)# interface ethernet0/0
Router(config-if)# ip flow monitor FLOW-MONITOR-1 sampler SAMPLER-1 input
Router(config-if)# ip flow monitor FLOW-MONITOR-2 output
```

The following example enables two different flow monitors for monitoring input and output traffic, with a sampler on the flow monitor that is monitoring output traffic to limit the output packets that are sampled:

```
Router(config)# interface ethernet0/0
Router(config-if)# ip flow monitor FLOW-MONITOR-2 input
Router(config-if)# ip flow monitor FLOW-MONITOR-2 sampler SAMPLER-2 output
```

The following example shows what happens when you try to add a sampler to a flow monitor that has already been enabled on an interface without a sampler:

```
Router(config)# interface Ethernet0/0
Router(config-if)# ip flow monitor FLOW-MONITOR-1 sampler SAMPLER-2 input
% Flow Monitor: Flow Monitor 'FLOW-MONITOR-1' is already on in full mode and cannot be
enabled with a sampler.
```

The following example shows how to remove a flow monitor from an interface so that it can be enabled with the sampler:

```
Router(config)# interface Ethernet0/0
Router(config-if)# no ip flow monitor FLOW-MONITOR-1 input
Router(config-if)# ip flow monitor FLOW-MONITOR-1 sampler SAMPLER-2 input
```

The following example shows what happens when you try to remove a sampler from a flow monitor on an interface by entering the **flow monitor** command again without the **sampler** keyword and argument:

```
Router(config)# interface Ethernet0/0
Router(config-if)# ip flow monitor FLOW-MONITOR-1 input
% Flow Monitor: Flow Monitor 'FLOW-MONITOR-1' is already on in sampled mode and cannot be
enabled in full mode.
```

The following example shows how to remove the flow monitor that was enabled with a sampler from the interface so that it can be enabled without the sampler:

```
Router(config)# interface Ethernet0/0
Router(config-if)# no ip flow monitor FLOW-MONITOR-1 sampler SAMPLER-2 input
Router(config-if)# ip flow monitor FLOW-MONITOR-1 input
```

Related Commands

Command	Description
flow monitor	Creates a flow monitor.
sampler	Creates a flow sampler.

ipv6 flow monitor

To enable a Flexible NetFlow flow monitor for IPv6 traffic that the router is receiving or forwarding, use the **ipv6 flow monitor** command in interface configuration mode or subinterface configuration mode. To disable a Flexible NetFlow flow monitor, use the **no** form of this command.

ipv6 flow monitor *monitor-name* [**sampler** *sampler-name*] [**multicast**| **unicast**] {**input**| **output**}

no ipv6 flow monitor *monitor-name* [**sampler** *sampler-name*] [**layer2-bridged**] [**multicast**| **unicast**] {**input**| **output**}

Cisco Catalyst 6500 Switches in Cisco IOS Release 12.2(50)SY

ipv6 flow monitor *monitor-name* [**sampler** *sampler-name*] **unicast** {**input**| **output**}

no ipv6 flow monitor *monitor-name* [**sampler** *sampler-name*] [**layer2-bridged**] **unicast** {**input**| **output**}

Cisco IOS XE Release 3.2SE

ipv6 flow monitor *monitor-name* [**sampler** *sampler-name*] {**input**| **output**}

no ipv6 flow monitor *monitor-name* [**sampler** *sampler-name*] [**layer2-bridged**] {**input**| **output**}

Syntax Description

<i>monitor-name</i>	Name of a flow monitor that was previously configured.
sampler <i>sampler-name</i>	(Optional) Enables a flow sampler for this flow monitor using the name of a sampler that was previously configured.
multicast	(Optional) Applies the flow monitor for multicast traffic only.
unicast	(Optional) Applies the flow monitor for unicast traffic only.
input	Monitors traffic that the router is receiving on the interface.
output	Monitors traffic that the router is transmitting on the interface.
layer2-bridged	Monitors IPv6 Layer 2 Bridged traffic that the router is transmitting on the interface.

Command Default

A flow monitor is not enabled.

Command Modes

Interface configuration (config-if) Subinterface configuration (config-subif)

Command History

Release	Modification
12.4(20)T	This command was introduced.
12.4(22)T	This command was modified. The unicast and multicast keywords were added.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7200 and Cisco 7300 Network Processing Engine (NPE) series routers.
12.2(50)SY	This command was modified. The multicast keyword was not supported.
15.1(1)SY	This command was modified. The layer2-bridged keyword was added.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE without the support for the multicast and unicast keywords.

Usage Guidelines

You must have already created a flow monitor by using the **flow monitor** command before you can apply the flow monitor to an interface with the **ipv6 flow monitor** command to enable traffic monitoring with Flexible NetFlow.

ipv6 flow monitor sampler

When a sampler is added to a flow monitor, only packets that are selected by the named sampler will be entered into the cache to form flows. Each use of a sampler causes separate statistics to be stored for that usage.

You cannot add a sampler to a flow monitor after the flow monitor has been enabled on an interface. You must remove the flow monitor from the interface prior to enabling the same flow monitor with a sampler. See the “Examples” section for more information.

**Note**

The statistics for each flow must be scaled to give the expected true usage. For example, with a 1 in 10 sampler it is expected that the packet and byte counters will have to be multiplied by 10.

Multicast Traffic and Unicast Traffic

In Cisco IOS Release 12.4(22)T and later releases, the default behavior of the **ip flow monitor** command is to analyze unicast *and* multicast traffic. If you need to monitor only unicast traffic, use the **unicast** keyword. If you need to monitor only multicast traffic, use the **multicast** keyword.

Examples

The following example enables a flow monitor for monitoring input IPv6 traffic:

```
Router(config)# interface ethernet0/0
Router(config-if)# ipv6 flow monitor FLOW-MONITOR-1 input
```


The following example enables a flow monitor for monitoring output IPv6 traffic on a subinterface:

```
Router(config)# interface ethernet0/0.1
Router(config-if)# ipv6 flow monitor FLOW-MONITOR-1 output
```

The following example enables a flow monitor for monitoring only multicast input traffic:

```
Router(config)# interface ethernet0/0
Router(config-if)# ipv6 flow monitor FLOW-MONITOR-1 multicast input
```

The following example enables a flow monitor for monitoring only unicast output traffic:

```
Router(config)# interface ethernet0/0
Router(config-if)# ipv6 flow monitor FLOW-MONITOR-1 unicast output
```

The following example enables the same flow monitor on the same interface for monitoring input and output IPv6 traffic:

```
Router(config)# interface ethernet0/0
Router(config-if)# ipv6 flow monitor FLOW-MONITOR-1 input
Router(config-if)# ipv6 flow monitor FLOW-MONITOR-1 output
```

The following example enables two different flow monitors on the same interface for monitoring input and output IPv6 traffic:

```
Router(config)# interface ethernet0/0
Router(config-if)# ipv6 flow monitor FLOW-MONITOR-1 input
Router(config-if)# ipv6 flow monitor FLOW-MONITOR-2 output
```

The following example enables the same flow monitor on two different interfaces for monitoring input and output IPv6 traffic:

```
Router(config)# interface ethernet0/0
Router(config-if)# ipv6 flow monitor FLOW-MONITOR-1 input
Router(config-if)# exit
Router(config)# interface ethernet1/0
Router(config-if)# ipv6 flow monitor FLOW-MONITOR-1 output
```

The following example enables two different flow monitors on two different interfaces for monitoring input and output IPv6 traffic:

```
Router(config)# interface ethernet0/0
Router(config-if)# ipv6 flow monitor FLOW-MONITOR-1 input
Router(config-if)# exit
Router(config)# interface ethernet1/0
Router(config-if)# ipv6 flow monitor FLOW-MONITOR-2 output
```

The following example enables a flow monitor for monitoring input IPv6 traffic, with a sampler to limit the input packets that are sampled:

```
Router(config)# interface ethernet0/0
Router(config-if)# ipv6 flow monitor FLOW-MONITOR-1 sampler SAMPLER-1 input
```

The following example enables a flow monitor for monitoring output IPv6 traffic, with a sampler to limit the output packets that are sampled:

```
Router(config)# interface ethernet0/0
Router(config-if)# ipv6 flow monitor FLOW-MONITOR-1 sampler SAMPLER-1 output
```

The following example enables two different flow monitors for monitoring input and output IPv6 traffic, with a sampler on the flow monitor that is monitoring input IPv6 traffic to limit the input packets that are sampled:

```
Router(config)# interface ethernet0/0
Router(config-if)# ipv6 flow monitor FLOW-MONITOR-1 sampler SAMPLER-1 input
Router(config-if)# ipv6 flow monitor FLOW-MONITOR-2 output
```

The following example enables two different flow monitors for monitoring input and output IPv6 traffic, with a sampler on the flow monitor that is monitoring output IPv6 traffic to limit the output packets that are sampled:

```
Router(config)# interface ethernet0/0
Router(config-if)# ipv6 flow monitor FLOW-MONITOR-2 input
Router(config-if)# ipv6 flow monitor FLOW-MONITOR-2 sampler SAMPLER-2 output
```

The following example shows what happens when you try to add a sampler to a flow monitor that has already been enabled on an interface without a sampler:

```
Router(config)# interface Ethernet0/0
Router(config-if)# ipv6 flow monitor FLOW-MONITOR-1 sampler SAMPLER-2 input
% Flow Monitor: Flow Monitor 'FLOW-MONITOR-1' is already on in full mode and cannot be
enabled with a sampler.
```

The following example shows how to remove a flow monitor from an interface so that it can be enabled with the sampler:

```
Router(config)# interface Ethernet0/0
Router(config-if)# no ipv6 flow monitor FLOW-MONITOR-1 input
Router(config-if)# ipv6 flow monitor FLOW-MONITOR-1 sampler SAMPLER-2 input
```

The following example shows what happens when you try to remove a sampler from a flow monitor on an interface by entering the **flow monitor** command again without the **sampler** keyword and argument:

```
Router(config)# interface Ethernet 0/0
Router(config-if)# ipv6 flow monitor FLOW-MONITOR-1 input
% Flow Monitor: Flow Monitor 'FLOW-MONITOR-1' is already on in sampled mode and cannot be
enabled in full mode.
```

The following example shows how to remove the flow monitor that was enabled with a sampler from the interface so that it can be enabled without the sampler:

```
Router(config)# interface Ethernet 0/0
Router(config-if)# no ipv6 flow monitor FLOW-MONITOR-1 sampler SAMPLER-2 input
Router(config-if)# ipv6 flow monitor FLOW-MONITOR-1 input
```

Related Commands

Command	Description
flow monitor	Creates a flow monitor.
sampler	Creates a flow sampler.

match datalink dot1q priority

To configure the 802.1Q (dot1q) priority as a key field for a Flexible NetFlow flow record, use the **match datalink dot1q priority** command in Flexible NetFlow flow record configuration mode. To disable the use of the 802.1Q priority as a key field for a Flexible NetFlow flow record, use the **no** form of this command.

match datalink dot1q priority

no match datalink dot1q priority

Command Default The 802.1Q priority is not configured as a key field.

Command Modes Flexible NetFlow flow record configuration (config-flow-record)

Command History	Release	Modification
	Cisco IOS XE Release 3.2SE	This command was introduced. Only the switch ports support it.

Usage Guidelines The Flexible NetFlow **match** commands are used to configure key fields for the flow monitor record and to enable capturing the values in the fields for the flow created with the record.

Examples The following example configures the 802.1Q priority of traffic being received by the router as a key field for a Flexible NetFlow flow record

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# match datalink dot1q priority
```

Related Commands	Command	Description
	flow record	Creates a flow record.

match datalink dot1q vlan

To configure the 802.1Q (dot1q) VLAN value as a key field for a Flexible NetFlow flow record, use the **match datalink dot1q vlan** command in Flexible NetFlow flow record configuration mode. To disable the use of the 802.1Q VLAN value as a key field for a Flexible NetFlow flow record, use the **no** form of this command.

```
match datalink dot1q vlan {input| output}
no match datalink dot1q vlan {input| output}
```

Syntax Description

input	Configures the 802.1Q VLAN ID of traffic being received by the router as a key field.
output	Configures the 802.1Q VLAN ID of traffic being transmitted by the router as a key field.

Command Default

The 802.1Q VLAN ID is not configured as a key field.

Command Modes

Flexible NetFlow flow record configuration (config-flow-record)

Command History


Release	Modification
12.4(22)T	This command was introduced.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7200 and Cisco 7300 Network Processing Engine (NPE) series routers.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE. Only the switch ports support it.

Usage Guidelines

The **input** and **output** keywords of the **match datalink dot1q vlan** command are used to specify the observation point that is used by the **match datalink dot1q vlan** command to create flows based on the unique 802.1q VLAN IDs in the network traffic. For example, when you configure a flow record with the **match datalink dot1q vlan input** command to monitor the simulated denial of service (DoS) attack in the figure below and apply the flow monitor to which the flow record is assigned in either input (ingress) mode on Ethernet interface

0/0.1 on R3 or output (egress) mode on Ethernet interface 1/0.1 on R3, the observation point is always Ethernet 0/0.1 on R3. The 802.1q VLAN ID that is used as a key field is 5.

Figure 16: Simulated DoS Attack (c)



The observation point of **match** commands that do not have the input and/or output keywords is always the interface to which the flow monitor that contains the flow record with the **match** commands is applied.

Examples

The following example configures the 802.1Q VLAN ID of traffic being received by the router as a key field for a Flexible NetFlow flow record

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# match datalink dot1q vlan input
```

Related Commands

Command	Description
flow record	Creates a flow record.

match datalink ethertype

To configure the ethertype as a key field for a Flexible NetFlow flow record, use the **match datalink ethertype** command in Flexible NetFlow flow record configuration mode. To disable the use of the ethertype as a key field for a Flexible NetFlow flow record, use the **no** form of this command.

match datalink ethertype

no match datalink ethertype

Command Default

The ethertype is not configured as a key field.

Command Modes

Flexible NetFlow flow record configuration (config-flow-record)

Command History

Release	Modification
Cisco IOS XE Release 3.2SE	This command was introduced.

Usage Guidelines

The Flexible NetFlow **match** commands are used to configure key fields for the flow monitor record and to enable capturing the values in the fields for the flow created with the record.

Examples

The following example configures the ethertype of traffic being received by the router as a key field for a Flexible NetFlow flow record

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# match datalink ethertype
```

Related Commands

Command	Description
flow record	Creates a flow record.

match datalink mac

To configure the use of MAC addresses as a key field for a Flexible NetFlow flow record, use the **match datalink mac** command in Flexible NetFlow flow record configuration mode. To disable the use of MAC addresses as a key field for a Flexible NetFlow flow record, use the **no** form of this command.

match datalink mac {destination| source} address {input| output}

no match datalink mac {destination| source} address {input| output}

Syntax Description

destination address	Configures the use of the destination MAC address as a key field.
source address	Configures the use of the source MAC address as a key field.
input	Packets received by the router.
output	Packets transmitted by the router.

Command Default

MAC addresses are not configured as a key field.

Command Modes

Flexible NetFlow flow record configuration (config-flow-record)

Command History


Release	Modification
12.4(22)T	This command was introduced.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7200 and Cisco 7300 Network Processing Engine (NPE) series routers.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Usage Guidelines

The **input** and **output** keywords of the **match datalink mac** command are used to specify the observation point that is used by the **match datalink mac** command to create flows based on the unique MAC addresses in the network traffic. For example, when you configure a flow record with the **match datalink mac destination address input** command to monitor the simulated denial of service (DoS) attack in the figure below and apply the flow monitor to which the flow record is assigned in either input (ingress) mode on Ethernet interface

0/0.1 on R3 or output (egress) mode on Ethernet interface 1/0.1 on R3, the observation point is always Ethernet 0/0.1 on R3. The destination MAC address that is used a key field is aaaa.bbbb.cc04.

Figure 17: Simulated DoS Attack (d)



- When the destination output mac address is configured, the value is the destination mac address of the output packet, even if the monitor the flow record is applied to is input only.
- When the destination input mac address is configured, the value is the destination mac address of the input packet, even if the monitor the flow record is applied to is output only.
- When the source output mac address is configured, the value is the source mac address of the output packet, even if the monitor the flow record is applied to is input only.
- When the source input mac address is configured, the value is the source mac address of the input packet, even if the monitor the flow record is applied to is output only.

Examples

The following example configures the use of the destination MAC address of packets that are received by the router as a key field for a Flexible NetFlow flow record:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# match datalink mac destination address input
```

The following example configures the use of the source MAC addresses of packets that are transmitted by the router as a key field for a Flexible NetFlow flow record:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# match datalink mac source address output
```

Related Commands

Command	Description
flow record	Creates a flow record.

match datalink vlan

To configure the VLAN ID as a key field for a Flexible NetFlow flow record, use the **match datalink vlan** command in Flexible NetFlow flow record configuration mode. To disable the use of the VLAN ID value as a key field for a Flexible NetFlow flow record, use the **no** form of this command.

match datalink vlan {input| output}

no match datalink vlan {input| output}

Syntax Description

input	Configures the VLAN ID of traffic being received by the router as a key field.
output	Configures the VLAN ID of traffic being transmitted by the router as a key field.

Command Default

The VLAN ID is not configured as a key field.

Command Modes

Flexible NetFlow flow record configuration (config-flow-record)

Command History

Release	Modification
12.2(50)SY	This command was introduced.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE. Only the switch ports support it.

Examples

The following example configures the VLAN ID of traffic being received by the router as a key field for a Flexible NetFlow flow record:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# match datalink vlan input
```

Related Commands

Command	Description
flow record	Creates a flow record.

match flow

To configure the flow direction and the flow sampler ID number as key fields for a flow record, use the **match flow** command in Flexible NetFlow flow record configuration or policy inline configuration mode. To disable the use of the flow direction and the flow sampler ID number as key fields for a flow record, use the **no** form of this command.

match flow {direction| sampler}

no match flow {direction| sampler}

Cisco Catalyst 6500 Switches in Cisco IOS Release 12.2(50)SY and 15.1(1)SY

match flow {cts {destination| source} group-tag| direction}

no match flow {cts {destination| source} group-tag| direction}

Syntax Description

direction	Configures the direction in which the flow was monitored as a key field.
sampler	Configures the flow sampler ID as a key field.
cts destination group-tag	Configures the CTS destination field group as a key field.
cts source group-tag	Configures the CTS source field group as a key field.

Command Default

The CTS destination or source field group, flow direction and the flow sampler ID are not configured as key fields.

Command Modes

Flexible NetFlow flow record configuration (config-flow-record) Policy inline configuration (config-if-spolicy-inline)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.

Release	Modification
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
15.1(3)T	This command was integrated into Cisco IOS Release 15.1(3)T for Cisco Performance Monitor. Support was added for policy inline configuration mode.
12.2(58)SE	This command was modified. Support for the Cisco Performance Monitor was added.
12.2(50)SY	This command was modified. The cts destination group-tag and cts source group-tag keywords were added. The sampler keyword was removed.
15.1(1)SY	This command was modified. Support for the Cisco Performance Monitor was added.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE without the support for the sampler keyword.

Usage Guidelines

This command can be used with both Flexible NetFlow and Performance Monitor. These products use different commands to enter the configuration mode in which you issue this command.

A flow record requires at least one key field before it can be used in a flow monitor. The key fields differentiate flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

Cisco Performance Monitor in Cisco IOS Release 15.1(3)T and 12.2(58)SE

You must first enter the **service-policy type performance-monitor inline** command.

match flow direction

This field indicates the direction of the flow. This is of most use when a single flow monitor is configured for input and output flows. It can be used to find and eliminate flows that are being monitored twice, once on input and once on output. This field may also be used to match up pairs of flows in the exported data when the two flows are flowing in opposite directions.

match flow sampler

This field contains the ID of the flow sampler used to monitor the flow. This is useful when more than one flow sampler is being used with different sampling rates. The flow exporter **option sampler-table** command will export options records with mappings of the flow sampler ID to the sampling rate so the collector can calculate the scaled counters for each flow.

Examples

The following example configures the direction the flow was monitored in as a key field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# match flow direction
```

The following example configures the flow sampler ID as a key field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# match flow sampler
```

The following example configures the CTS destination fields group as a key field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# match flow cts destination group-tag
```

The following example configures the CTS source fields group as a key field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# match flow cts source group-tag
```

The following example shows how to use the policy inline configuration mode to configure a service policy for Performance Monitor. The policy specifies that packets traversing Ethernet interface 0/0 that match the flow sampler ID will be monitored based on the parameters specified in the flow monitor configuration named fm2:

```
Router(config)# interface ethernet 0/0
Router(config-if)# service-policy type performance-monitor inline input
Router(config-if-spolicy-inline)# match flow sampler
Router(config-if-spolicy-inline)# flow monitor fm-2
Router(config-if-spolicy-inline)# exit
```

Related Commands

Command	Description
class-map	Creates a class map to be used for matching packets to a specified class.
flow exporter	Creates a flow exporter.
flow record	Creates a flow record.
service-policy type performance-monitor	Associates a Performance Monitor policy with an interface.



match interface (Flexible NetFlow) through ttl (Flexible NetFlow)

- [match interface \(Flexible NetFlow\), page 75](#)
- [match ipv4, page 78](#)
- [match ipv4 destination, page 81](#)
- [match ipv4 source, page 84](#)
- [match ipv4 ttl, page 87](#)
- [match ipv6, page 89](#)
- [match ipv6 destination, page 92](#)
- [match ipv6 hop-limit, page 94](#)
- [match ipv6 source, page 96](#)
- [match transport, page 98](#)
- [match transport icmp ipv4, page 100](#)
- [match transport icmp ipv6, page 102](#)
- [mode \(Flexible NetFlow\), page 104](#)
- [option \(Flexible NetFlow\), page 106](#)
- [record, page 111](#)
- [sampler, page 116](#)
- [show flow exporter, page 118](#)
- [show flow interface, page 124](#)
- [show flow monitor, page 126](#)
- [show flow monitor cache aggregate, page 135](#)
- [show flow monitor cache filter, page 141](#)
- [show flow monitor cache sort, page 148](#)
- [show flow record, page 152](#)

- [show sampler](#), page 157
- [source \(Flexible NetFlow\)](#), page 160
- [template data timeout](#), page 162
- [transport \(Flexible NetFlow\)](#), page 164
- [ttl \(Flexible NetFlow\)](#), page 166

match interface (Flexible NetFlow)

To configure input and output interfaces as key fields for a flow record, use the **match interface** command in Flexible NetFlow flow record configuration mode. To disable the use of the input and output interfaces as key fields for a flow record, use the **no** form of this command.

match interface {input| output}

no match interface {input| output}

Cisco Catalyst 6500 Switches in Cisco IOS Release 12.2(50)SY

match interface {input [physical]| output} [snmp]

no match interface {input [physical]| output} [snmp]

Syntax Description

input	Configures the input interface as a key field.
physical	(Optional) Configures the physical input interface as a key field and enables collecting the input interface from the flows.
output	Configures the output interface as a key field.
snmp	(Optional) Configures the simple network management protocol (SNMP) index of the input interface as a key field.

Command Default

The input and output interfaces are not configured as key fields.

Command Modes

Flexible NetFlow flow record configuration (config-flow-record)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.

Release	Modification
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
12.2(50)SY	This command was modified. The physical and snmp keywords were added.
15.2(2)T	This command was modified. Support for the Cisco Performance Monitor was added.
Cisco IOS XE Release 3.5S	This command was modified. Support for the Cisco Performance Monitor was added.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Usage Guidelines

This command can be used with both Flexible NetFlow and Performance Monitor. These products use different commands to enter the configuration mode in which you issue this command, however the mode prompt is the same for both products. For Performance Monitor, you must first enter the **flow record type performance-monitor** command before you can use this command.

Because the mode prompt is the same for both products, here we refer to the command mode for both products as flow record configuration mode. However, for Flexible NetFlow, the mode is also known as Flexible NetFlow flow record configuration mode; and for Performance Monitor, the mode is also known as Performance Monitor flow record configuration mode.

A flow record requires at least one key field before it can be used in a flow monitor. The key fields differentiate flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

Examples

The following example configures the input interface as a key field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# match interface input
```

The following example configures the output interface as a key field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# match interface output
```

The following example configures the output interface as a key field:

```
Router(config)# flow record type performance-monitor RECORD-1
Router(config-flow-record)# match interface output
```

Related Commands

Command	Description
flow record	Creates a flow record, and enters Flexible NetFlow flow record configuration mode.

Command	Description
flow record type performance-monitor	Creates a flow record, and enters Performance Monitor flow record configuration mode.

match ipv4

To configure one or more of the IPv4 fields as a key field for a flow record, use the **match ipv4** command in Flexible NetFlow flow record configuration mode. To disable the use of one or more of the IPv4 fields as a key field for a flow record, use the **no** form of this command.

```
match ipv4 {dscp| header-length| id| option map| precedence| protocol| tos| version}
no match ipv4 {dscp| header-length| id| option map| precedence| protocol| tos| version}
```

Cisco Performance Monitor in Cisco IOS Release 15.1(3)T and 12.2(58)SE

```
match ipv4 protocol
no match ipv4 protocol
```

Cisco Catalyst 6500 Switches in Cisco IOS Release 12.2(50)SY

```
match ipv4 {dscp| precedence| protocol| tos}
no match ipv4 {dscp| precedence| protocol| tos}
```

Cisco IOS XE Release 3.2SE

```
match ipv4 {protocol| tos| version}
match ipv4 {protocol| tos| version}
```

Syntax Description

dscp	Configures the IPv4 differentiated services code point (DSCP) (part of type of service [ToS]) as a key field.
header-length	Configures the IPv4 header length (in 32-bit words) as a key field.
id	Configures the IPv4 ID as a key field.
option map	Configures the bitmap representing which IPv4 options have been seen as a key field.
precedence	Configures the IPv4 precedence (part of ToS) as a key field.
protocol	Configures the IPv4 protocol as a key field.
tos	Configures the IPv4 ToS as a key field.
version	Configures the IP version from IPv4 header as a key field.

Command Default

The use of one or more of the IPv4 fields as a key field for a user-defined flow record is not enabled by default.

Command Modes

flow record configuration (config-flow-record)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
15.1(3)T	This command was modified for the Cisco Performance Monitor. The dscp , header-length , id , option map , precedence , tos , and version keywords were removed.
12.2(58)SE	This command was modified for the Cisco Performance Monitor. The dscp , header-length , id , option map , precedence , tos , and version keywords were removed.
12.2(50)SY	This command was modified. The header-length , id , option map , and version keywords were not supported in Cisco IOS Release 12.2(50)SY.
Cisco IOS XE Release 3.2SE	This command was modified. The dscp , header-length , id , option map , and precedence keywords were removed.

Usage Guidelines

This command can be used with both Flexible NetFlow and Performance Monitor. These products use different commands to enter the configuration mode in which you issue this command.

A flow record requires at least one key field before it can be used in a flow monitor. The key fields differentiate flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

**Note**

Some of the keywords of the **match ipv4** command are documented as separate commands. All of the keywords for the **match ipv4** command that are documented separately start with **match ipv4**. For example, for information about configuring the IPv4 time-to-live (TTL) field as a key field for a flow record, refer to the **match ipv4 ttl** command.

Cisco Performance Monitor in Cisco IOS Release 15.1(3)T and 12.2(58)SE

Only the **protocol** keyword is available. You must first enter the **flow record type performance-monitor** command.

Examples

The following example configures the IPv4 DSCP field as a key field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# match ipv4 dscp
```

The following example configures the IPv4 DSCP field as a key field for Cisco Performance Monitor:

```
Router(config)# flow record type performance-monitor FLOW-RECORD-1
Router(config-flow-record)# match ipv4 dscp
```

Related Commands

Command	Description
flow record	Creates a flow record.
flow record type performance-monitor	Creates a flow record for Cisco Performance Monitor.

match ipv4 destination

To configure the IPv4 destination address as a key field for a flow record, use the **match ipv4 destination** command in Flexible NetFlow flow record configuration mode. To disable the IPv4 destination address as a key field for a flow record, use the **no** form of this command.

match ipv4 destination {address | {mask| prefix} [minimum-mask *mask*]}

no match ipv4 destination {address | {mask| prefix} [minimum-mask *mask*]}

Cisco Performance Monitor in Cisco IOS Release 15.1(3)T and 12.2(58)SE

match ipv4 destination {address| prefix [minimum-mask *mask*]}

no match ipv4 destination {address| prefix [minimum-mask *mask*]}

Cisco Catalyst 6500 Switches in Cisco IOS Release 12.2(50)SY

match ipv4 destination address

no match ipv4 destination address

Cisco IOS XE Release 3.2SE

match ipv4 destination address

no match ipv4 destination address

Syntax Description

address	Configures the IPv4 destination address as a key field.
mask	Configures the mask for the IPv4 destination address as a key field.
prefix	Configures the prefix for the IPv4 destination address as a key field.
minimum-mask <i>mask</i>	(Optional) Specifies the size, in bits, of the minimum mask. The range is 1 to 32.

Command Default

The IPv4 destination address is not configured as a key field.

Command Modes

Flexible NetFlow flow record configuration (config-flow-record)

Command History

Release	Modification
12.4(9)T	This command was introduced.

Release	Modification
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Gigabit Switch Router (GSR).
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
15.1(3)T	This command was modified for the Cisco Performance Monitor. The mask keyword was removed.
12.2(58)SE	This command was modified for the Cisco Performance Monitor. The mask keyword was removed.
12.2(50)SY	This command was modified. The mask , prefix , and minimum-mask keywords were removed.
Cisco IOS XE Release 3.2SE	This command was modified. The mask , prefix , and minimum-mask keywords were removed.

Usage Guidelines

This command can be used with both Flexible NetFlow and Performance Monitor. These products use different commands to enter the configuration mode in which you issue this command.

A flow record requires at least one key field before it can be used in a flow monitor. The key fields differentiate flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

Cisco Performance Monitor in Cisco IOS Release 15.1(3)T and 12.2(58)SE

The **mask** keyword is not available. You must first enter the **flow record type performance-monitor** command.

Examples

The following example configures a 16-bit IPv4 destination address prefix as a key field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# match ipv4 destination prefix minimum-mask 16
```

The following example specifies a 16-bit IPv4 destination address mask as a key field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# match ipv4 destination mask minimum-mask 16
```

The following example specifies a 16-bit IPv4 destination address mask as a key field for Cisco Performance Monitor:

```
Router(config)# flow record type performance-monitor FLOW-RECORD-1
Router(config-flow-record)# match ipv4 destination mask minimum-mask 16
```

Related Commands

Command	Description
flow record	Creates a flow record.
flow record type performance-monitor	Creates a flow record for Cisco Performance Monitor.

match ipv4 source

To configure the IPv4 source address as a key field for a flow record, use the **match ipv4 source** command in Flexible NetFlow flow record configuration mode. To disable the use of the IPv4 source address as a key field for a flow record, use the **no** form of this command.

```
match ipv4 source {address | {mask| prefix} [minimum-mask mask]}
no match ipv4 source {address | {mask| prefix} [minimum-mask mask]}
```

Cisco Performance Monitor in Cisco IOS Release 15.1(3)T and 12.2(58)SE

```
match ipv4 source {address| prefix [minimum-mask mask]}
no match ipv4 source {address| prefix [minimum-mask mask]}
```

Cisco Catalyst 6500 Switches in Cisco IOS Release 12.2(50)SY

```
match ipv4 source address
no match ipv4 source address
```

Cisco IOS XE Release 3.2SE

```
match ipv4 source address
no match ipv4 source address
```

Syntax Description

address	Configures the IPv4 source address as a key field.
mask	Configures the mask for the IPv4 source address as a key field.
prefix	Configures the prefix for the IPv4 source address as a key field.
minimum-mask mask	(Optional) Specifies the size, in bits, of the minimum mask. Range: 1 to 128.

Command Default

The IPv4 source address is not configured as a key field.

Command Modes

Flexible NetFlow flow record configuration (config-flow-record)

Command History

Release	Modification
12.4(9)T	This command was introduced.

Release	Modification
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
15.1(3)T	This command was modified for the Cisco Performance Monitor. The mask keyword was removed.
12.2(58)SE	This command was modified for the Cisco Performance Monitor. The mask keyword was removed.
12.2(50)SY	This command was modified. The mask , prefix , and minimum-mask keywords were removed.
Cisco IOS XE Release 3.2SE	This command was modified. The mask , prefix , and minimum-mask keywords were removed.

Usage Guidelines

This command can be used with both Flexible NetFlow and Performance Monitor. These products use different commands to enter the configuration mode in which you issue this command.

A flow record requires at least one key field before it can be used in a flow monitor. The key fields differentiate flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

Cisco Performance Monitor in Cisco IOS Release 15.1(3)T and 12.2(58)SE

The **mask** keyword is not available. You must first enter the **flow record type performance-monitor** command.
match ipv4 source prefix minimum-mask

The source address prefix field is the network part of the source address. The optional minimum mask allows a more information to be gathered about large networks.

match ipv4 source mask minimum-mask

The source address mask is the number of bits that make up the network part of the source address. The optional minimum mask allows a minimum value to be configured. This command is useful when there is a minimum mask configured for the source prefix field and the mask is to be used with the prefix. In this case, the values configured for the minimum mask should be the same for the prefix and mask fields.

Alternatively, if the collector knows the minimum mask configuration of the prefix field, the mask field can be configured without a minimum mask so that the true mask and prefix can be calculated.

Examples

The following example configures a 16-bit IPv4 source address prefix as a key field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# match ipv4 source prefix minimum-mask 16
```

The following example specifies a 16-bit IPv4 source address mask as a key field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# match ipv4 source mask minimum-mask 16
```

The following example specifies a 16-bit IPv4 source address mask as a key field for Cisco Performance Monitor:

```
Router(config)# flow record type performance-monitor FLOW-RECORD-1
Router(config-flow-record)# match ipv4 source mask minimum-mask 16
```

Related Commands

Command	Description
flow record	Creates a flow record.
flow record type performance-monitor	Creates a flow record for Cisco Performance Monitor.

match ipv4 ttl

To configure the IPv4 time-to-live (TTL) field as a key field for a flow record, use the **match ipv4 ttl** command in Flow NetFlow flow record configuration mode. To disable the use of the IPv4 TTL field as a key field for a flow record, use the **no** form of this command.

match ipv4 ttl

no match ipv4 ttl

Syntax Description

This command has no arguments or keywords.

Command Default

The IPv4 time-to-live (TTL) field is not configured as a key field.

Command Modes

Flow NetFlow flow record configuration (config-flow-record)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers in Cisco IOS Release 12.2(33)SRC.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
15.2(2)T	This command was modified. Support for the Cisco Performance Monitor was added.
Cisco IOS XE Release 3.5S	This command was modified. Support for the Cisco Performance Monitor was added.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.5S for Cisco Performance Monitor.

Usage Guidelines

This command can be used with both Flexible NetFlow and Performance Monitor. These products use different commands to enter the configuration mode in which you issue this command, however the mode prompt is the same for both products. For Performance Monitor, you must first enter the **flow record type performance-monitor** command before you can use this command.

Because the mode prompt is the same for both products, here we refer to the command mode for both products as flow record configuration mode. However, for Flexible NetFlow, the mode is also known as Flexible NetFlow flow record configuration mode; and for Performance Monitor, the mode is also known as Performance Monitor flow record configuration mode.

A flow record requires at least one key field before it can be used in a flow monitor. The key fields differentiate flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

Examples

The following example configures IPv4 TTL as a key field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# match ipv4 ttl
The following example configures the IPv4 TTL as a key field:
```

```
Router(config)# flow record type performance-monitor RECORD-1
Router(config-flow-record)# match ipv4 ttl
```

Related Commands

Command	Description
flow record	Creates a flow record, and enters Flexible NetFlow flow record configuration mode.
flow record type performance-monitor	Creates a flow record, and enters Performance Monitor flow record configuration mode.

match ipv6

To configure one or more of the IPv6 fields as a key field for a flow record, use the **match ipv6** command in Flexible NetFlow flow record configuration mode. To disable the use of one or more of the IPv6 fields as a key field for a flow record, use the **no** form of this command.

```
match ipv6 {dscp| flow-label| next-header| payload-length| precedence| protocol| traffic-class| version}
no match ipv6 {dscp| flow-label| next-header| payload-length| precedence| protocol| traffic-class| version}
```

Cisco Catalyst 6500 Switches in Cisco IOS Release 12.2(50)SY

```
match ipv6 {dscp| precedence| protocol| tos}
no match ipv6 {dscp| precedence| protocol| tos}
```

Cisco IOS XE Release 3.2SE

```
match ipv6 {protocol| traffic-class| version}
no match ipv6 {protocol| traffic-class| version}
```

Syntax Description

dscp	Configures the IPv6 differentiated services code point DSCP (part of type of service (ToS)) as a key field.
flow-label	Configures the IPv6 flow label as a key field.
next-header	Configures the IPv6 next header as a key field.
payload-length	Configures the IPv6 payload length as a key field.
precedence	Configures the IPv6 precedence (part of ToS) as a key field.
protocol	Configures the IPv6 protocol as a key field.
tos	Configures the IPv6 ToS as a key field.
traffic-class	Configures the IPv6 traffic class as a key field.
version	Configures the IPv6 version from IPv6 header as a key field.

Command Default

The IPv6 fields are not configured as a key field.

Command Modes

Flexible Netflow flow record configuration (config-flow-record)

Command History

Release	Modification
12.4(20)T	This command was introduced.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7200 and Cisco 7300 Network Processing Engine (NPE) series routers.
12.2(50)SY	This command was modified. The flow-label , next-header , payload-length , traffic-class , and version keywords were removed.
15.2(2)T	This command was modified. Support for the Cisco Performance Monitor was added.
Cisco IOS XE Release 3.5S	This command was modified. Support for the Cisco Performance Monitor was added.
Cisco IOS XE Release 3.2SE	This command was modified. The dscp , flow-label , next-header , payload-length , and precedence keywords were removed.

Usage Guidelines

This command can be used with both Flexible NetFlow and Performance Monitor. These products use different commands to enter the configuration mode in which you issue this command, however the mode prompt is the same for both products. For Performance Monitor, you must first enter the **flow record type performance-monitor** command before you can use this command.

Because the mode prompt is the same for both products, here we refer to the command mode for both products as flow record configuration mode. However, for Flexible NetFlow, the mode is also known as Flexible NetFlow flow record configuration mode; and for Performance Monitor, the mode is also known as Performance Monitor flow record configuration mode.

A flow record requires at least one key field before it can be used in a flow monitor. The key fields differentiate flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.



Note

Some of the keywords of the **match ipv6** command are documented as separate commands. All of the keywords for the **match ipv6** command that are documented separately start with **match ipv6**. For example, for information about configuring the IPv6 hop limit as a key field for a flow record, refer to the **match ipv6 hop-limit** command.

Examples

The following example configures the IPv6 DSCP field as a key field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# match ipv6 dscp
```

The following example configures the IPv6 DSCP field as a key field:

```
Router(config)# flow record type performance-monitor RECORD-1
Router(config-flow-record)# match ipv6 dscp
```

Related Commands

Command	Description
flow record	Creates a flow record, and enters Flexible NetFlow flow record configuration mode.
flow record type performance-monitor	Creates a flow record, and enters Performance Monitor flow record configuration mode.

match ipv6 destination

To configure the IPv6 destination address as a key field for a flow record, use the **match ipv6 destination** command in Flexible Netflow flow record configuration mode. To disable the IPv6 destination address as a key field for a flow record, use the **no** form of this command.

```
match ipv6 destination {address| {mask| prefix} [minimum-mask mask]}
no match ipv6 destination {address| {mask| prefix} [minimum-mask mask]}
```

Cisco Catalyst 6500 Switches in Cisco IOS Release 12.2(50)SY

```
match ipv6 destination address
no match ipv6 destination address
```

Cisco IOS XE Release 3.2SE

```
match ipv6 destination address
no match ipv6 destination address
```

Syntax Description

address	Configures the IPv6 destination address as a key field.
mask	Configures the mask for the IPv6 destination address as a key field.
prefix	Configures the prefix for the IPv6 destination address as a key field.
minimum-mask mask	(Optional) Specifies the size, in bits, of the minimum mask. Range: 1 to 128.

Command Default

The IPv6 destination address is not configured as a key field.

Command Modes

Flexible NetFlow flow record configuration (config-flow-record)

Command History

Release	Modification
12.4(20)T	This command was introduced.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7200 and Cisco 7300 Network Processing Engine (NPE) series routers.

Release	Modification
12.2(50)SY	This command was modified. The mask , prefix , and minimum-mask keywords were removed.
15.2(2)T	This command was modified. Support for the Cisco Performance Monitor was added.
Cisco IOS XE Release 3.5S	This command was modified. Support for the Cisco Performance Monitor was added.
Cisco IOS XE Release 3.2SE	This command was modified. The mask , prefix , and minimum-mask keywords were removed.

Usage Guidelines

This command can be used with both Flexible NetFlow and Performance Monitor. These products use different commands to enter the configuration mode in which you issue this command, however the mode prompt is the same for both products. For Performance Monitor, you must first enter the **flow record type performance-monitor** command before you can use this command.

Because the mode prompt is the same for both products, here we refer to the command mode for both products as flow record configuration mode. However, for Flexible NetFlow, the mode is also known as Flexible NetFlow flow record configuration mode; and for Performance Monitor, the mode is also known as Performance Monitor flow record configuration mode.

A flow record requires at least one key field before it can be used in a flow monitor. The key fields differentiate flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

Examples

The following example configures a 16-bit IPv6 destination address prefix as a key field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# match ipv6 destination prefix minimum-mask 16
```

The following example specifies a 16-bit IPv6 destination address mask as a key field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# match ipv6 destination mask minimum-mask 16
```

The following example configures a 16-bit IPv6 destination address mask as a key field:

```
Router(config)# flow record type performance-monitor RECORD-1
Router(config-flow-record)# match ipv6 destination mask minimum-mask 16
```

Related Commands

Command	Description
flow record	Creates a flow record, and enters Flexible NetFlow flow record configuration mode.
flow record type performance-monitor	Creates a flow record, and enters Performance Monitor flow record configuration mode.

match ipv6 hop-limit

To configure the IPv6 hop limit as a key field for a flow record, use the **match ipv6 hop-limit** command in Flexible NetFlow flow record configuration mode. To disable the use of a section of an IPv6 packet as a key field for a flow record, use the **no** form of this command.

```
match ipv6 hop-limit
no match ipv6 hop-limit
```

Syntax Description

This command has no arguments or keywords.

Command Default

The use of the IPv6 hop limit as a key field for a user-defined flow record is not enabled by default.

Command Modes

Flexible NetFlow flow record configuration (config-flow-record)

Command History

Release	Modification
12.4(20)T	This command was introduced.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7200 and Cisco 7300 Network Processing Engine (NPE) series routers.
15.2(2)T	This command was modified. Support for the Cisco Performance Monitor was added.
Cisco IOS XE Release 3.5S	This command was modified. Support for the Cisco Performance Monitor was added.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Usage Guidelines

This command can be used with both Flexible NetFlow and Performance Monitor. These products use different commands to enter the configuration mode in which you issue this command, however the mode prompt is the same for both products. For Performance Monitor, you must first enter the **flow record type performance-monitor** command before you can use this command.

Because the mode prompt is the same for both products, here we refer to the command mode for both products as flow record configuration mode. However, for Flexible NetFlow, the mode is also known as Flexible NetFlow flow record configuration mode; and for Performance Monitor, the mode is also known as Performance Monitor flow record configuration mode.

A flow record requires at least one key field before it can be used in a flow monitor. The key fields differentiate flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

Examples

The following example configures the hop limit of the packets in the flow as a key field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# match ipv6 hop-limit
```

The following example configures the hop limit of the packets in the flow as a key field:

```
Router(config)# flow record type performance-monitor RECORD-1
Router(config-flow-record)# match ipv6 hop-limit
```

Related Commands

Command	Description
flow record	Creates a flow record, and enters Flexible NetFlow flow record configuration mode.
flow record type performance-monitor	Creates a flow record, and enters Performance Monitor flow record configuration mode.

match ipv6 source

To configure the IPv6 source address as a key field for a flow record, use the **match ipv6 source** command in Flexible NetFlow flow record configuration mode. To disable the use of the IPv6 source address as a key field for a flow record, use the **no** form of this command.

```
match ipv6 source {address| {mask| prefix} [minimum-mask mask]}
no match ipv6 source {address| {mask| prefix} [minimum-mask mask]}
```

Cisco Catalyst 6500 Switches in Cisco IOS Release 12.2(50)SY

```
match ipv6 source address
no match ipv6 source address
```

Cisco IOS XE Release 3.2SE

```
match ipv6 source address
no match ipv6 source address
```

Syntax Description

address	Configures the IPv6 source address as a key field.
mask	Configures the mask for the IPv6 source address as a key field.
prefix	Configures the prefix for the IPv6 source address as a key field.
minimum-mask <i>mask</i>	(Optional) Specifies the size, in bits, of the minimum mask. Range: 1 to 128.

Command Default

The IPv6 source address is not configured as a key field.

Command Modes

Flexible NetFlow flow record configuration (config-flow-record)

Command History

Release	Modification
12.4(20)T	This command was introduced.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7200 and Cisco 7300 Network Processing Engine (NPE) series routers.

Release	Modification
12.2(50)SY	This command was modified. The mask , prefix , and minimum-mask keywords were removed.
15.2(2)T	This command was modified. Support for the Cisco Performance Monitor was added.
Cisco IOS XE Release 3.5S	This command was modified. Support for the Cisco Performance Monitor was added.
Cisco IOS XE Release 3.2SE	This command was modified. The mask , prefix , and minimum-mask keywords were removed.

Usage Guidelines

This command can be used with both Flexible NetFlow and Performance Monitor. These products use different commands to enter the configuration mode in which you issue this command, however the mode prompt is the same for both products. For Performance Monitor, you must first enter the **flow record type performance-monitor** command before you can use this command.

Because the mode prompt is the same for both products, here we refer to the command mode for both products as flow record configuration mode. However, for Flexible NetFlow, the mode is also known as Flexible NetFlow flow record configuration mode; and for Performance Monitor, the mode is also known as Performance Monitor flow record configuration mode.

A flow record requires at least one key field before it can be used in a flow monitor. The key fields differentiate flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

Examples

The following example configures a 16-bit IPv6 source address prefix as a key field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# match ipv6 source prefix minimum-mask 16
```

The following example specifies a 16-bit IPv6 source address mask as a key field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# match ipv6 source mask minimum-mask 16
```

The following example configures the 16-bit IPv6 source address mask as a key field:

```
Router(config)# flow record type performance-monitor RECORD-1
Router(config-flow-record)# match ipv6 source mask minimum-mask 16
```

Related Commands

Command	Description
flow record	Creates a flow record, and enters Flexible NetFlow flow record configuration mode.
flow record type performance-monitor	Creates a flow record, and enters Performance Monitor flow record configuration mode.

match transport

To configure one or more of the transport fields as a key field for a flow record, use the **match transport** command in Flexible NetFlow flow record configuration mode. To disable the use of one or more of the transport fields as a key field for a flow record, use the **no** form of this command.

```
match transport {destination-port| igmp type| source-port}
no match transport {destination-port| igmp type| source-port}
```

Cisco Catalyst 6500 Switches in Cisco IOS Release 12.2(50)SY

```
match transport {destination-port| source-port}
no match transport {destination-port| source-port}
```

Syntax Description

destination-port	Configures the transport destination port as a key field.
igmp type	Configures time stamps based on the system uptime as a key field.
source-port	Configures the transport source port as a key field.

Command Default

The transport fields are not configured as a key field.

Command Modes

Flexible NetFlow flow record configuration (config-flow-record)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
12.2(50)SY	This command was modified. The igmp type keyword combination was removed.

Release	Modification
15.2(2)T	This command was modified. Support for the Cisco Performance Monitor was added.
Cisco IOS XE Release 3.5S	This command was modified. Support for the Cisco Performance Monitor was added.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Usage Guidelines

This command can be used with both Flexible NetFlow and Performance Monitor. These products use different commands to enter the configuration mode in which you issue this command, however the mode prompt is the same for both products. For Performance Monitor, you must first enter the **flow record type performance-monitor** command before you can use this command.

Because the mode prompt is the same for both products, here we refer to the command mode for both products as flow record configuration mode. However, for Flexible NetFlow, the mode is also known as Flexible NetFlow flow record configuration mode; and for Performance Monitor, the mode is also known as Performance Monitor flow record configuration mode.

A flow record requires at least one key field before it can be used in a flow monitor. The key fields differentiate flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

Examples

The following example configures the destination port as a key field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# match transport destination-port
```

The following example configures the source port as a key field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# match transport source-port
```

The following example configures the source port as a key field:

```
Router(config)# flow record type performance-monitor RECORD-1
Router(config-flow-record)# match transport source-port
```

Related Commands

Command	Description
flow record	Creates a flow record, and enters Flexible NetFlow flow record configuration mode.
flow record type performance-monitor	Creates a flow record, and enters Performance Monitor flow record configuration mode.

match transport icmp ipv4

To configure the ICMP IPv4 type field and the code field as key fields for a flow record, use the **match transport icmp ipv4** command in Flexible NetFlow flow record configuration mode. To disable the use of the ICMP IPv4 type field and code field as key fields for a flow record, use the **no** form of this command.

```
match transport icmp ipv4 {code| type}
no match transport icmp ipv4 {code| type}
```

Syntax Description

code	Configures the IPv4 ICMP code as a key field.
type	Configures the IPv4 ICMP type as a key field.

Command Default

The ICMP IPv4 type field and the code field are not configured as key fields.

Command Modes

Flexible NetFlow flow record configuration (config-flow-record)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
15.2(2)T	This command was modified. Support for the Cisco Performance Monitor was added.
Cisco IOS XE Release 3.5S	This command was modified. Support for the Cisco Performance Monitor was added.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Usage Guidelines

This command can be used with both Flexible NetFlow and Performance Monitor. These products use different commands to enter the configuration mode in which you issue this command, however the mode prompt is the same for both products. For Performance Monitor, you must first enter the **flow record type performance-monitor** command before you can use this command.

Because the mode prompt is the same for both products, here we refer to the command mode for both products as flow record configuration mode. However, for Flexible NetFlow, the mode is also known as Flexible NetFlow flow record configuration mode; and for Performance Monitor, the mode is also known as Performance Monitor flow record configuration mode.

A flow record requires at least one key field before it can be used in a flow monitor. The key fields differentiate flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

Examples

The following example configures the IPv4 ICMP code field as a key field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# match transport icmp ipv4 code
The following example configures the IPv4 ICMP type field as a key field:
```

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# match transport icmp ipv4 type
The following example configures the IPv4 ICMP type field as a key field:
```

```
Router(config)# flow record type performance-monitor RECORD-1
Router(config-flow-record)# match transport icmp ipv4 type
```

Related Commands

Command	Description
flow record	Creates a flow record, and enters Flexible NetFlow flow record configuration mode.
flow record type performance-monitor	Creates a flow record, and enters Performance Monitor flow record configuration mode.

match transport icmp ipv6

To configure the internet control message protocol ICMP IPv6 type field and the code field as key fields for a flow record, use the **match transport icmp ipv6** command in Flexible NetFlow flow record configuration mode. To disable the use of the ICMP IPv6 type field and code field as key fields for a flow record, use the **no** form of this command.

```
match transport icmp ipv6 {code| type}
no match transport icmp ipv6 {code| type}
```

Syntax Description

code	Configures the ICMP code as a key field.
type	Configures the ICMP type as a key field.

Command Default

The ICMP IPv6 type field and the code field are not configured as key fields.

Command Modes

Flexible Netflow flow record configuration (config-flow-record)

Command History

Release	Modification
12.4(20)T	This command was introduced.
12.2(33)SRE	This command was modified. Support for this command was implemented on for the Cisco 7200 and Cisco 7300 Network Processing Engine (NPE) series routers.
15.2(2)T	This command was modified. Support for the Cisco Performance Monitor was added.
Cisco IOS XE Release 3.5S	This command was modified. Support for the Cisco Performance Monitor was added.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Usage Guidelines

This command can be used with both Flexible NetFlow and Performance Monitor. These products use different commands to enter the configuration mode in which you issue this command, however the mode prompt is the same for both products. For Performance Monitor, you must first enter the **flow record type performance-monitor** command before you can use this command.

Because the mode prompt is the same for both products, here we refer to the command mode for both products as flow record configuration mode. However, for Flexible NetFlow, the mode is also known as Flexible

NetFlow flow record configuration mode; and for Performance Monitor, the mode is also known as Performance Monitor flow record configuration mode.

A Flow Record requires at least one key field before it can be used in a Flow Monitor. The Key fields differentiate Flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

Examples

The following example configures the IPv6 ICMP code field as a key field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# match transport icmp ipv6 code
```

The following example configures the IPv6 ICMP type field as a key field:

```
Router(config)# flow record FLOW-RECORD-1
Router(config-flow-record)# match transport icmp ipv6 type
```

The following example configures the IPv6 ICMP type field as a key field:

```
Router(config)# flow record type performance-monitor RECORD-1
Router(config-flow-record)# match transport icmp ipv6 type
```

Related Commands

Command	Description
flow record	Creates a flow record, and enters Flexible NetFlow flow record configuration mode.
flow record type performance-monitor	Creates a flow record, and enters Performance Monitor flow record configuration mode.

mode (Flexible NetFlow)

To specify the type of sampling and the packet interval for a Flexible NetFlow sampler, use the **mode** command in Flexible NetFlow sampler configuration mode. To unconfigure the type of sampling and the packet interval for a Flexible NetFlow sampler, use the **no** form of this command.

```
mode {deterministic| random} 1 out-of window-size
no mode
```

Syntax Description

deterministic	Enables deterministic mode sampling for the sampler.
random	Enables random mode sampling for the sampler.
1 out-of <i>window-size</i>	Specifies the window size from which to select packets. Range: 2 to 32768.

Command Default

The mode and the packet interval for a sampler are not configured.

Command Modes

Flexible NetFlow sampler configuration (config-sampler)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Usage Guidelines

Deterministic Mode

In deterministic mode, packets are chosen periodically based on the configured interval. This mode has less overhead than random mode and can be useful when the router samples traffic that is random in nature.

Random Mode

In random mode, packets are chosen in a manner that should eliminate any bias from traffic patterns and counter any attempt by users to avoid monitoring.

Examples

The following example enables deterministic sampling with a window size of 1000:

```
Router(config)# sampler SAMPLER-1  
Router(config-sampler)# mode deterministic 1 out-of 1000
```

The following example enables random sampling with a window size of 1000:

```
Router(config)# sampler SAMPLER-1  
Router(config-sampler)# mode random 1 out-of 1000
```

Related Commands

Command	Description
clear sampler	Clears the sampler statistics.
debug sampler	Enables debugging output for samplers.
show sampler	Displays sampler status and statistics.

option (Flexible NetFlow)

To configure optional data parameters for a flow exporter for Flexible NetFlow or the Cisco Performance Monitor, use the **option** command in Flexible NetFlow flow exporter configuration mode. To remove optional data parameters for a flow exporter, use the **no** form of this command.

option {application-attributes| application-table| exporter-stats| class-qos-table| interface-table| policy-qos-table| sampler-table| sub-application-table| vrf-table} [*timeout seconds*]

no option {application-attributes| application-table| class-qos-table| exporter-stats| interface-table| policy-qos-table| sampler-table| sub-application-table| vrf-table}

Cisco Catalyst 6500 Switches in Cisco IOS Release 12.2(50)SY

option {exporter-stats| interface-table| sampler-table| vrf-table} [*timeout seconds*]

no option {exporter-stats| interface-table| sampler-table| vrf-table}

Cisco IOS XE Release 3.2SE

option {exporter-stats| interface-table| sampler-table} [*timeout seconds*]

option {exporter-stats| interface-table| sampler-table} [*timeout seconds*]

Syntax Description

application-attributes	Configures the application attributes option for flow exporters.
application-table	Configures the application table option for flow exporters.
class-qos-table	Configures the QoS class table option for flow exporters.
exporter-stats	Configures the exporter statistics option for flow exporters.
interface-table	Configures the interface table option for flow exporters.
policy-qos-table	Configures the QoS policy table option for flow exporters.
sampler-table	Configures the export sampler information option for flow exporters.
sub-application-table	Configures the subapplication table option for flow exporters.
vrf-table	Configures the virtual routing and forwarding (VRF) ID-to-name table option for flow exporters.

timeout <i>seconds</i>	(Optional) Configures the option resend time in seconds for flow exporters. The range is from 1 to 86400. The default is 600.
-------------------------------	---

Command Default The optional data parameters are not configured.

Command Modes Flexible NetFlow flow exporter configuration (config-flow-exporter)

Command History	Release	Modification
	12.4(9)T	This command was introduced.
	12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
	12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
	12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.
	15.0(1)M	This command was modified. The application-table and vrf-table keywords were added.
	12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
	Cisco IOS XE Release 3.1S	This command was integrated into Cisco IOS XE Release 3.1S.
	15.1(3)T	This command was modified. Support for the Cisco Performance Monitor was added.
	12.2(58)SE	This command was modified. Support for the Cisco Performance Monitor was added.
	12.2(50)SY	This command was modified. The application-table keyword was removed.
	Cisco IOS XE Release 3.5S	This command was modified. The application-attributes keyword was added.
	15.2(1)S2	This command was modified. The sub-application-table keyword was added.
	Cisco IOS XE Release 3.7S	This command was integrated into Cisco IOS XE Release 3.7S.
	15.2(4)M2	This command was modified. The class-qos-table and policy-qos-table keywords were added.

Release	Modification
15.3(1)T	This command was integrated into Cisco IOS Release 15.3(1)T.
Cisco IOS XE Release 3.2SE	This command was modified. The application-attributes , application-table , and vrf-table keywords were removed.

Usage Guidelines

The **option** command can be used with both Flexible NetFlow and the Cisco Performance Monitor.

Use the **timeout** keyword to alter the frequency at which reports are sent.

option application-attributes

The **option application-attributes** command causes the periodic sending of network-based application recognition (NBAR) application attributes to the collector.

The following application attributes are sent to the collector per protocol:

- Application-Group—Groups applications that belong to the same networking application.
- Category—Provides first-level categorization for each application.
- Encrypted—Specifies whether the application is an encrypted networking protocol.
- P2P-Technology—Specifies whether the application is based on peer-to-peer technology.
- Sub-Category—Provides second-level categorization for each application.
- Tunnel-Technology—Specifies whether the application tunnels the traffic of other protocols.

option application-table

The **option application-table** command enables the periodic sending of an options table that allows the collector to map NBAR application IDs provided in the flow records to application names.

option class-qos-table

The **option class-qos-table** command enables the periodic sending of an options table that allows the collector to map QoS class IDs to class names in the flow records.

option exporter-stats

The **option exporter-stats** command enables the periodic sending of exporter statistics, including the number of records, bytes, and packets sent. This command allows the collector to estimate packet loss for the export records it receives.

option interface-table

The **option interface-table** enables the periodic sending of an options table that allows the collector to map the interface Simple Network Management Protocol (SNMP) indexes provided in flow records to interface names.

option policy-qos-table

The **option policy-qos-table** command enables the periodic sending of an options table that allows the collector to map QoS policy IDs to policy names in the flow records.

option sampler-table

The **option sampler-table** command enables the periodic sending of an options table that provides complete information about the configuration of each sampler and allows the collector to map the sampler ID provided in any flow record to a configuration that it can use to scale up the flow statistics.

option sub-application-table

The **option sub-application-table** command enables the periodic sending of an options table that allows the collector to map NBAR subapplication tags, subapplication names, and subapplication descriptions provided in the flow records to application IDs.

option vrf-table

The **option vrf-table** command enables the periodic sending of an options table that allows the collector to map the VRF IDs provided in the flow records to VRF names.

Examples

The following example shows how to enable the periodic sending of NBAR application attributes to the collector:

```
Device(config)# flow exporter FLOW-EXPORTER-1
Device(config-flow-exporter)# option application-attributes
```

The following example shows how to enable the periodic sending of an options table that allows the collector to map QoS class IDs provided in flow records to class names:

```
Device(config)# flow exporter FLOW-EXPORTER-1
Device(config-flow-exporter)# option class-qos-table
```

The following example shows how to enable the periodic sending of an options table that allows the collector to map QoS policy IDs provided in flow records to policy names:

```
Device(config)# flow exporter FLOW-EXPORTER-1
Device(config-flow-exporter)# option policy-qos-table
```

The following example shows how to enable the periodic sending of exporter statistics, including the number of records, bytes, and packets sent:

```
Device(config)# flow exporter FLOW-EXPORTER-1
Device(config-flow-exporter)# option exporter-stats
```

The following example shows how to enable the periodic sending of an options table that allows the collector to map the interface SNMP indexes provided in flow records to interface names:

```
Device(config)# flow exporter FLOW-EXPORTER-1
Device(config-flow-exporter)# option interface-table
```

The following example shows how to enable the periodic sending of an options table that allows the collector to map NBAR application IDs provided in flow records to application names:

```
Device(config)# flow exporter FLOW-EXPORTER-1
Device(config-flow-exporter)# option application-table
```

The following example shows how to enable the periodic sending of an options table that details the configuration of each sampler and allows the collector to map the sampler ID provided in any flow record to a configuration that the collector can use to scale up the flow statistics:

```
Device(config)# flow exporter FLOW-EXPORTER-1
Device(config-flow-exporter)# option sampler-table
```

The following example shows how to enable the periodic sending of an options table that allows the collector to map the NBAR subapplication tags, subapplication names, and subapplication descriptions provided in flow records to application IDs:

```
Device(config)# flow exporter FLOW-EXPORTER-1
Device(config-flow-exporter)# option sub-application-table
```

The following example shows how to enable the periodic sending of an options table that allows the collector to map the VRF IDs provided in flow records to VRF names:

```
Device(config)# flow exporter FLOW-EXPORTER-1
Device(config-flow-exporter)# option vrf-table
```

Related Commands

Command	Description
flow exporter	Creates a flow exporter.

record

To configure a flow record for a Flexible NetFlow flow monitor, use the **record** command in Flexible NetFlow flow monitor configuration mode. To remove a flow record for a Flexible NetFlow flow monitor, use the **no** form of this command.

record {*record-name*| **netflow-original**| **netflow** {**ipv4**| **ipv6**} *record* [**peer**]}

no record

Cisco Catalyst 6500 Switches in Cisco IOS Release 12.2(50)SY

record {*record-name*| **platform-original** {**ipv4**| **ipv6**} *record*}

no record

Cisco IOS XE Release 3.2SE

record *record-name*

no record

Syntax Description

<i>record-name</i>	Name of a user-defined flow record that was previously configured.
netflow-original	Configures the flow monitor to use the Flexible NetFlow implementation of original NetFlow with origin autonomous systems.
netflow ipv4	Configures the flow monitor to use one of the predefined IPv4 records.
netflow ipv6	Configures the flow monitor to use one of the predefined IPv6 records. This keyword is not supported on the Cisco ASR 1000 Series Aggregation Services router.
<i>record</i>	Name of the predefined record. See the table below for a listing of the available records and their definitions.
peer	(Optional) Configures the flow monitor to use one of the predefined records with peer autonomous systems. The peer keyword is not supported for every type of Flexible NetFlow predefined record. See the table below.
platform-original ipv4	Configures the flow monitor to use one of the predefined IPv4 records.

platform-original ipv4	Configures the flow monitor to use one of the predefined IPv6 records.
------------------------	--

Command Default A flow record is not configured.

Command Modes Flexible NetFlow flow monitor configuration (config-flow-monitor)

Command History	Release	Modification
	12.4(9)T	This command was introduced.
	12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
	12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
	12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.
	12.4(20)T	This command was modified. The ipv6 keyword was added.
	12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
	Cisco IOS XE 3.1S	This command was integrated into Cisco IOS XE Release 3.1S.
	12.2(50)SY	This command was modified. The netflow-original , netflow ipv4 , and netflow ipv6 keywords were removed. The platform-originalipv4a nd platform-originalipv4 keywords were added.
	Cisco IOS XE Release 3.2SE	This command was modified. The netflow-original , netflow ipv4 , and netflow ipv6 keywords were removed.

Usage Guidelines Each flow monitor requires a record to define the contents and layout of its cache entries. The flow monitor can use one of the wide range of predefined record formats, or advanced users may create their own record formats.



Note You must use the **no ip flowmonitor command** to remove a flow monitor from all of the interfaces to which you have applied it before you can modify the parameters for the **record** command for the flow monitor.

The table below describes the keywords and descriptions for the *record* argument.

Table 2: Keywords and Descriptions for the record Argument

Keyword	Description	IPv4 Support	IPv6 Support
as	Autonomous system record.	Yes	Yes
as-tos	Autonomous system and ToS record.	Yes	—
bgp-nexthop-tos	BGP next-hop and ToS record.	Yes	—
bgp-nexthop	BGP next-hop record.	—	Yes
destination	Original 12.2(50)SY platform IPv4/IPv6 destination record.	Yes	Yes
destination-prefix	Destination Prefix record. Note For IPv6, a minimum prefix mask length of 0 bits is assumed.	Yes	Yes
destination-prefix-tos	Destination prefix and ToS record.	Yes	—
destination-source	Original 12.2(50)SY platform IPv4/IPv6 destination-source record.	Yes	Yes
full	Original 12.2(50)SY platform IPv4/IPv6 full record.	Yes	Yes
interface-destination	Original 12.2(50)SY platform IPv4/IPv6 interface-destination record.	Yes	Yes
interface-destination-source	Original 12.2(50)SY platform IPv4/IPv6 interface-destination-source record.	Yes	Yes
interface-full	Original 12.2(50)SY platform IPv4/IPv6 interface-full record.	Yes	Yes

Keyword	Description	IPv4 Support	IPv6 Support
interface-source	Original 12.2(50)SY platform IPv4/IPv6 interface-source only record.	Yes	Yes
original-input	Traditional IPv4 input NetFlow.	Yes	Yes
original-output	Traditional IPv4 output NetFlow.	Yes	Yes
prefix	Source and destination prefixes record. Note For IPv6, a minimum prefix mask length of 0 bits is assumed.	Yes	Yes
prefix-port	Prefix port record. Note The peer keyword is not available for this record.	Yes	--
prefix-tos	Prefix ToS record.	Yes	--
protocol-port	Protocol ports record. Note The peer keyword is not available for this record.	Yes	Yes
protocol-port-tos	Protocol port and ToS record. Note The peer keyword is not available for this record.	Yes	—
source-prefix	Source autonomous system and prefix record. Note For IPv6, a minimum prefix mask length of 0 bits is assumed.	Yes	Yes
source-prefix-tos	Source Prefix and ToS record.	Yes	—

Examples

The following example configures the flow monitor to use the NetFlow original record:

```
Router(config)# flow monitor FLOW-MONITOR-1
Router(config-flow-monitor)# record netflow-original
```

The following example configures the flow monitor to use a user-defined record named collect-ipv4-data:

```
Router(config)# flow monitor FLOW-MONITOR-1
Router(config-flow-monitor)# record collect-ipv4-data
```

The following example configures the flow monitor to use the Flexible NetFlow IPv4 destination prefix record:

```
Router(config)# flow monitor FLOW-MONITOR-1
Router(config-flow-monitor)# record netflow ipv4 destination-prefix
```

The following example configures the flow monitor to use a the Flexible NetFlow IPv6 destination prefix record:

```
Router(config)# flow monitor FLOW-MONITOR-1
Router(config-flow-monitor)# record netflow ipv6 destination-prefix
```

Related Commands

Command	Description
flow monitor	Creates a flow monitor.

sampler

To create a Flexible NetFlow flow sampler, or to modify an existing Flexible NetFlow flow sampler, and to enter Flexible NetFlow sampler configuration mode, use the **sampler** command in global configuration mode. To remove a sampler, use the **no** form of this command.

```
sampler sampler-name
no sampler sampler-name
```

Syntax Description

<i>sampler-name</i>	Name of the flow sampler that is being created or modified.
---------------------	---

Command Default

Flexible NetFlow flow samplers are not configured.

Command Modes

Global configuration (config)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
15.1(2)S	This command was modified. A hash collision between the name supplied and any existing name is now possible. If this happens, you can retry, supplying another name.
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Usage Guidelines

Flow samplers are used to reduce the load placed by Flexible NetFlow on the networking device to monitor traffic by limiting the number of packets that are analyzed. You configure a rate of sampling that is 1 out of

a range of 2 to 32,768 packets. For example, a rate of 1 out of 2 results in analysis of 50 percent of the packets sampled. Flow samplers are applied to interfaces in conjunction with a flow monitor to implement sampled Flexible NetFlow.

To enable flow sampling, you configure the record that you want to use for traffic analysis and assign it to a flow monitor. When you apply a flow monitor with a sampler to an interface, the sampled packets are analyzed at the rate specified by the sampler and compared with the flow record associated with the flow monitor. If the analyzed packets meet the criteria specified by the flow record, they are added to the flow monitor cache.

In Cisco IOS Release 15.1(2)S and later releases, a hash collision between the name supplied and any existing name is possible. If this happens, you can retry, supplying another name.

Examples

The following example creates a flow sampler name SAMPLER-1:

```
Router(config)# sampler SAMPLER-1  
Router(config-sampler)#
```

The following example shows the output when there is a hash collision between the name supplied and any existing name:

```
Router(config-sampler)# sampler SAMPLER-1  
% sampler: Failed to create a new Sampler (Hash value in use).  
Router(config)#
```

Related Commands

Command	Description
clear sampler	Clears the flow sampler statistics.
debug sampler	Enables debugging output for flow samplers.
mode	Configures a packet interval for a flow sampler.
show sampler	Displays flow sampler status and statistics.

show flow exporter

To display Flexible NetFlow flow exporter status and statistics, use the **show flow exporter** command in privileged EXEC mode.

```
show flow exporter [export-ids {netflow-v5| netflow-v9}| [name] exporter-name [statistics| templates]
[option application {engines| table}]]
```

Cisco IOS XE Release 3.2SE

```
show flow exporter [export-ids netflow-v9| [name] exporter-name [statistics| templates]]
```

Syntax Description

export-ids netflow-v5	(Optional) Displays the NetFlow Version 5 export fields that can be exported and their IDs.
export-ids netflow-v9	(Optional) Displays the NetFlow Version 9 export fields that can be exported and their IDs.
name	(Optional) Specifies the name of a flow exporter.
exporter-name	(Optional) Name of a flow exporter that was previously configured.
statistics	(Optional) Displays flow exporter statistics.
templates	(Optional) Displays flow exporter template information.
option application engines	(Optional) Displays the application engines option for flow exporters.
option application table	(Optional) Displays the application table option for flow exporters.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.

Release	Modification
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
Cisco IOS XE 3.1S	This command was modified. The option and application keywords were added.
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY.
15.2(2)T	This command was modified. The ability to display IPv6 addresses was added.
Cisco IOS XE 3.5S	This command was modified. The ability to display IPv6 addresses was added.
Cisco IOS XE Release 3.2SE	This command was modified. The export-ids netflow-v5 , option application engines , and option application table keywords were removed.

Examples

The following example displays the status and statistics for all of the flow exporters configured on a router:

```
Router# show flow exporter

Flow Exporter FLOW-MONITOR-1:
  Description:           Exports to the datacenter
  Export protocol:       NetFlow Version 9
  Transport Configuration:
    Destination IP address: 172.16.10.2
    Source IP address:     172.16.6.2
    Source Interface:      Ethernet0/0
    Transport Protocol:    UDP
    Destination Port:      650
    Source Port:           55864
    DSCP:                  0x3F
    TTL:                   15
    Output Features:       Used

Flow Exporter FLOW-MONITOR-2:
  Description:           Exports to the datacenter
  Export protocol:       NetFlow Version 9
  Transport Configuration:
    Destination IP address: 2222::2/64
    Source IP address:     1111::1/64
    Transport Protocol:    UDP
    Destination Port:      4739
    Source Port:           49936
    DSCP:                  0x0
    TTL:                   255
    Output Features:       Not Used

Options Configuration:
  exporter-stats (timeout 120 seconds)
  interface-table (timeout 120 seconds)
  sampler-table (timeout 120 seconds)
```

The table below describes the significant fields shown in the display.

Table 3: show flow exporter Field Descriptions

Field	Description
Flow Exporter	The name of the flow exporter that you configured.
Description	The description that you configured for the exporter, or the default description “User defined”.
Transport Configuration	The transport configuration fields for this exporter.
Destination IP address	The IP address of the destination host.
Source IP address	The source IP address used by the exported packets.
Transport Protocol	The transport layer protocol used by the exported packets.
Destination Port	The destination UDP port to which the exported packets are sent.
Source Port	The source UDP port from which the exported packets are sent.
DSCP	The differentiated services code point (DSCP) value.
TTL	The time-to-live value.

The following example displays the NetFlow Version 9 export IDs for all of the flow exporters configured on a router. This output will vary according to the flow record configured:

```
Router# show flow exporter export-ids netflow-v9
```

Export IDs used by fields in NetFlow-common export format:

```

ip version          : 60
ip tos              : 194
ip dscp             : 195
ip precedence       : 196
ip protocol         : 4
ip ttl              : 192
ip ttl minimum      : 52
ip ttl maximum      : 53
ip length header    : 189
ip length payload   : 204
ip section header   : 313
ip section payload  : 314
routing source as   : 16
routing destination as : 17
routing source as peer : 129
routing destination as peer : 128
routing source traffic-index : 92
routing destination traffic-index : 93
routing forwarding-status : 89
routing is-multicast : 206
routing next-hop address ipv4 : 15

```

```

routing next-hop address ipv4 bgp      : 18
routing next-hop address ipv6 bgp      : 63
ipv4 header-length                     : 207
ipv4 tos                               : 5
ipv4 total-length                      : 190
ipv4 total-length minimum              : 25
ipv4 total-length maximum              : 26
ipv4 id                                : 54
ipv4 fragmentation flags                : 197
ipv4 fragmentation offset               : 88
ipv4 source address                    : 8
ipv4 source prefix                     : 44
ipv4 source mask                       : 9
ipv4 destination address                : 12
ipv4 destination prefix                 : 45
ipv4 destination mask                  : 13
ipv4 options                           : 208
transport source-port                   : 7
transport destination-port              : 11
transport icmp-ipv4 type                : 176
transport icmp-ipv4 code                : 177
transport igmp type                     : 33
transport tcp source-port                : 182
transport tcp destination-port           : 183
transport tcp sequence-number            : 184
transport tcp acknowledgement-number     : 185
transport tcp header-length              : 188
transport tcp window-size                : 186
transport tcp urgent-pointer             : 187
transport tcp flags                      : 6
transport udp source-port                : 180
transport udp destination-port           : 181
transport udp message-length             : 205
interface input snmp                    : 10
interface output snmp                   : 14
interface name                           : 82
interface description                    : 83
flow direction                          : 61
flow exporter                           : 144
flow sampler                            : 48
flow sampler algorithm export            : 49
flow sampler interval                    : 50
flow sampler name                        : 84
flow class                              : 51
v9-scope system                         : 1
v9-scope interface                      : 2
v9-scope linecard                       : 3
v9-scope cache                          : 4
v9-scope template                       : 5
counter flows                           : 3
counter bytes                           : 1
counter bytes long                       : 1
counter packets                         : 2
counter packets long                    : 2
counter bytes squared long               : 198
counter bytes permanent                  : 85
counter packets permanent                : 86
counter bytes squared permanent          : 199
counter bytes exported                   : 40
counter packets exported                 : 41
counter flows exported                   : 42
timestamp sys-uptime first               : 22
timestamp sys-uptime last                : 21

```

The following example displays the status and statistics for all of the flow exporters configured on a router:

```

Router# show flow exporter name FLOW-MONITOR-1 statistics

Flow Exporter FLOW-MONITOR-1:
  Packet send statistics:
    Ok 0
    No FIB 0
    Adjacency failure 0

```

```

Enqueued to process level 488
Enqueueing failed 0
IPC failed 0
Output failed 0
Fragmentation failed 0
Encap fixup failed 0
No destination address 0
Client send statistics:
  Client: Flow Monitor FLOW-MONITOR-1
    Records added 558
    Packets sent 486 (51261 bytes)
    Packets dropped 0 (0 bytes)
    No Packet available errors 0

```

The table below describes the significant fields shown in the display.

Table 4: show flow exporter name exporter-name statistics Field Descriptions

Field	Description
Flow Exporter	The name of the flow exporter that you configured.
Packet send statistics	The packet transmission statistics for this exporter.
Ok	The number of packets that have been sent successfully.
No FIB	No entry in the Forwarding Information Base (FIB) to forward to.
Adjacency failure	No Cisco Express Forwarding (CEF) adjacency available for forwarding.
Enqueued to process level	Packets that were sent to the processor for forwarding.
Enqueueing failed	Packets that could not be queued for transmission.
IPC failed	Packets for which interprocess communication (IPC) failed.
Output failed	Packets that were dropped because the output queue was full.
Fragmentation failed	Packets that were not able to be fragmented.
Encap fixup failed	Packets that were not able to be encapsulated for transmission on the egress interface.
No destination address	No destination address configured for the exporter.
Client send statistics	Statistics for the flow monitors that are using the exporters.
Client	The name of the flow monitor that is using the exporter.

Field	Description
Records added	The number of flow records that have been added for this flow monitor.
Packets sent	The number of packets that have been exported for this flow monitor.
Packets dropped	The number of packets that were dropped for this flow monitor.
No Packet available error	The number of times that no packets were available to transmit the records.

The following example displays the template format for the exporters configured on the router. This output will vary according to the flow record configured:

```
Router# show flow exporter FLOW_EXPORTER-1 templates
```

```
Flow Exporter FLOW-MONITOR-1:
  Client: Flow Monitor FLOW-MONITOR-1
  Exporter Format: NetFlow Version 9
  Template ID      : 256
  Record Size     : 53
  Template layout
```

Field	Type1	Offset2	Size3
-----	-----	-----	-----
ipv4 source address	8	0	4
ipv4 destination address	12	4	4
interface input snmp	10	8	4
flow sampler	48	12	4
transport source-port	7	16	2
transport destination-port	11	18	2
ip tos	194	20	1
ip protocol	4	21	1
ipv4 source mask	9	22	1
ipv4 destination mask	13	23	1
transport tcp flags	6	24	1
routing source as	16	25	2
routing destination as	17	27	2
routing next-hop address ipv4	15	29	4
interface output snmp	14	33	4
counter bytes	1	37	4
counter packets	2	41	4
timestamp sys-uptime first	22	45	4
timestamp sys-uptime last	21	49	4
-----	-----	-----	-----

Related Commands

Command	Description
clear flow exporter	Clears the statistics for exporters.
debug flow exporter	Enables debugging output for flow exporters.
flow exporter	Creates a flow exporter.

show flow interface

To display the Flexible NetFlow configuration and status for an interface, use the **show flow interface** command in privileged EXEC mode.

show flow interface [*type number*]

Syntax Description

<i>type</i>	(Optional) The type of interface on which you want to display Flexible NetFlow accounting configuration information.
<i>number</i>	(Optional) The number of the interface on which you want to display Flexible NetFlow accounting configuration information.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Examples

The following example displays the Flexible NetFlow accounting configuration on Ethernet interfaces 0/0 and 0/1:

```
Router# show flow interface ethernet 1/0

Interface Ethernet1/0
  FNF:  monitor:      FLOW-MONITOR-1
        direction:   Output
```



```

      traffic(ip):      on
Router# show flow interface ethernet 0/0
Interface Ethernet0/0
  FNF:  monitor:      FLOW-MONITOR-1
        direction:    Input
        traffic(ip):   sampler SAMPLER-2#

```

The table below describes the significant fields shown in the display.

Table 5: show flow interface Field Descriptions

Field	Description
Interface	The interface to which the information applies.
monitor	The name of the flow monitor that is configured on the interface.
direction:	<p>The direction of traffic that is being monitored by the flow monitor.</p> <p>The possible values are:</p> <ul style="list-style-type: none"> • Input—Traffic is being received by the interface. • Output—Traffic is being transmitted by the interface.
traffic(ip)	<p>Indicates if the flow monitor is in normal mode or sampler mode.</p> <p>The possible values are:</p> <ul style="list-style-type: none"> • on—The flow monitor is in normal mode. • sampler—The flow monitor is in sampler mode (the name of the sampler will be included in the display).

Related Commands

Command	Description
show flow monitor	Displays flow monitor status and statistics.

show flow monitor

To display the status and statistics for a Flexible NetFlow flow monitor, use the **show flow monitor** command in privileged EXEC mode.

```
show flow monitor [[name] monitor-name [cache [format {csv| record| table}]] [statistics]]
```

Syntax Description

name	(Optional) Specifies the name of a flow monitor.
monitor-name	(Optional) Name of a flow monitor that was previously configured.
cache	(Optional) Displays the contents of the cache for the flow monitor.
format	(Optional) Specifies the use of one of the format options for formatting the display output.
csv	(Optional) Displays the flow monitor cache contents in comma separated variables (CSV) format.
record	(Optional) Displays the flow monitor cache contents in record format.
table	(Optional) Displays the flow monitor cache contents in table format.
statistics	(Optional) Displays the statistics for the flow monitor.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.

Release	Modification
12.4(20)T	This command was modified. Support for displaying IPv6 data in Flexible NetFlow flow monitor caches was added.
15.0(1)M	This command was modified. Support for displaying virtual routing and forwarding (VRF) and Network Based Application Recognition (NBAR) data in Flexible NetFlow flow monitor caches was added.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7200 and Cisco 7300 Network Processing Engine (NPE) series routers.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Usage Guidelines

The **cache** keyword uses the table format by default.

The uppercase field names in the display output of the **show flowmonitor monitor-name cache** command are key fields that Flexible NetFlow uses to differentiate flows. The lowercase field names in the display output of the **show flow monitor monitor-name cache** command are nonkey fields from which Flexible NetFlow collects values as additional data for the cache.

Examples

The following example displays the status for a flow monitor:

```
Router# show flow monitor FLOW-MONITOR-1

Flow Monitor FLOW-MONITOR-1:
  Description:      Used for basic traffic analysis
  Flow Record:      netflow-original
  Flow Exporter:    EXP-DC-TOPEKA
                   EXP-DC-PHOENIX

  Cache:
    Type:           normal
    Status:         allocated
    Size:           4096 entries / 311316 bytes
    Inactive Timeout: 15 secs
    Active Timeout:  1800 secs
    Update Timeout:  1800 secs
```

The table below describes the significant fields shown in the display.

Table 6: show flow monitor monitor-name Field Descriptions

Field	Description
Flow Monitor	Name of the flow monitor that you configured.
Description	Description that you configured or the monitor, or the default description "User defined".
Flow Record	Flow record assigned to the flow monitor.
Flow Exporter	Exporters that are assigned to the flow monitor.

Field	Description
Cache	Information about the cache for the flow monitor.
Type	Flow monitor cache type. The possible values are: <ul style="list-style-type: none"> • immediate—Flows are expired immediately. • normal—Flows are expired normally. • Permanent—Flows are never expired.
Status	Status of the flow monitor cache. The possible values are: <ul style="list-style-type: none"> • allocated—The cache is allocated. • being deleted—The cache is being deleted. • not allocated—The cache is not allocated.
Size	Current cache size.
Inactive Timeout	Current value for the inactive timeout in seconds.
Active Timeout	Current value for the active timeout in seconds.
Update Timeout	Current value for the update timeout in seconds.

The following example displays the status, statistics, and data for the flow monitor named FLOW-MONITOR-1:

```
Router# show flow monitor FLOW-MONITOR-1 cache
```

```

Cache type:                               Normal
Cache size:                               4096
Current entries:                           8
High Watermark:                           10
Flows added:                              1560
Flows aged:                               1552
  - Active timeout ( 1800 secs)            24
  - Inactive timeout ( 15 secs)            1528
  - Event aged                             0
  - Watermark aged                         0
  - Emergency aged                         0
IP TOS:                                    0x00
IP PROTOCOL:                              6
IPv4 SOURCE ADDRESS:                       10.10.10.2
IPv4 DESTINATION ADDRESS:                  172.16.10.2
TRNS SOURCE PORT:                          20
TRNS DESTINATION PORT:                    20
INTERFACE INPUT:                           Et0/0
FLOW SAMPLER ID:                           0
ip source as:                              0
ip destination as:                         0
ipv4 next hop address:                     172.16.7.2
ipv4 source mask:                          /0
ipv4 destination mask:                     /24

```

```

tcp flags:          0x00
interface output:   Et1/0
counter bytes:      198520
counter packets:    4963
timestamp first:    10564356
timestamp last:     12154104

```

The table below describes the significant fields shown in the display.

Table 7: show flow monitor monitor-name cache Field Descriptions

Field	Description
Cache type	Flow monitor cache type. The possible values are: <ul style="list-style-type: none"> • Immediate—Flows are expired immediately. • Normal—Flows are expired normally. • Permanent—Flows are never expired.
Cache Size	Number of entries in the cache.
Current entries	Number of entries in the cache that are in use.
High Watermark	Highest number of cache entries seen.
Flows added	Flows added to the cache since the cache was created.
Flows aged	Flows expired from the cache since the cache was created.
Active timeout	Current value for the active timeout in seconds.
Inactive timeout	Current value for the inactive timeout in seconds.
Event aged	Number of flows that have been aged by an event such as using the force-export option for the clear flow monitor command.
Watermark aged	Number of flows that have been aged because they exceeded the maximum high watermark value.
Emergency aged	Number of flows that have been aged because the cache size was exceeded.
IP TOS	IP type of service (ToS) value.
IP PROTOCOL	Protocol number.
IPv4 SOURCE ADDRESS	IPv4 source address.
IPv4 DESTINATION ADDRESS	IPv4 destination address.

Field	Description
TRNS SOURCE PORT	Source port for the transport protocol.
TRNS DESTINATION PORT	Destination port for the transport protocol.
INTERFACE INPUT	Interface on which the input is received.
FLOW SAMPLER ID	Flow sampler ID number.
ip source as	Border Gateway Protocol (BGP) source autonomous system number.
ip destination as	BGP destination autonomous system number.
ipv4 next hop address	IPv4 address of the next hop to which the packet is forwarded.
ipv4 source mask	IPv4 source address mask.
ipv4 destination mask	IPv4 destination address mask.
tcp flags	Value of the TCP flags.
interface output	Interface on which the input is transmitted.
counter bytes	Number of bytes that have been counted.
counter packets	Number of packets that have been counted.
timestamp first	Time stamp of the first packet in the flow.
timestamp last	Time stamp of the last packet in the flow.

The following example displays the status, statistics, and data for the flow monitor named FLOW-MONITOR-1 in a table format:

```
Router# show flow monitor FLOW-MONITOR-1 cache format table
```

```

Cache type:                      Normal
Cache size:                      4096
Current entries:                  4
High Watermark:                  6
Flows added:                     90
Flows aged:                      86
  - Active timeout ( 1800 secs)  0
  - Inactive timeout ( 15 secs)  86
  - Event aged                   0
  - Watermark aged               0
  - Emergency aged              0
IP TOS   IP PROT   IPV4 SRC ADDR   IPV4 DST ADDR   TRNS SRC PORT   TRNS DST PORT
=====
0x00      1    10.251.10.1   172.16.10.2      0                02
0x00      1    10.251.10.1   172.16.10.2      0             20484
0xC0     17   172.16.6.1     224.0.0.9       520             5202

```

```
0x00          6  10.10.11.1      172.16.10.5          25          252
Router#
```

The following example displays the status, statistics, and data for the flow monitor named FLOW-MONITOR-IPv6 (the cache contains IPv6 data) in record format:

```
Router# show flow monitor name FLOW-MONITOR-IPv6 cache format record
```

```
Cache type:                      Normal
Cache size:                      4096
Current entries:                 6
High Watermark:                 8
Flows added:                    1048
Flows aged:                    1042
- Active timeout ( 1800 secs)   11
- Inactive timeout ( 15 secs)  1031
- Event aged                   0
- Watermark aged               0
- Emergency aged               0
IPv6 FLOW LABEL:                0
IPv6 EXTENSION MAP:             0x00000040
IPv6 SOURCE ADDRESS:            2001:DB8:1:ABCD::1
IPv6 DESTINATION ADDRESS:       2001:DB8:4:ABCD::2
TRNS SOURCE PORT:               3000
TRNS DESTINATION PORT:          55
INTERFACE INPUT:                Et0/0
FLOW DIRECTION:                 Input
FLOW SAMPLER ID:                0
IP PROTOCOL:                    17
IP TOS:                         0x00
ip source as:                   0
ip destination as:              0
ipv6 next hop address:          ::
ipv6 source mask:               /48
ipv6 destination mask:         /0
tcp flags:                      0x00
interface output:               Null
counter bytes:                  521192
counter packets:                9307
timestamp first:                9899684
timestamp last:                 11660744
```

The table below describes the significant fields shown in the display.

Table 8: show flow monitor monitor-name cache format record Field Descriptions

Field	Description
Cache type	Flow monitor cache type. The possible values are: <ul style="list-style-type: none"> • Immediate—Flows are expired immediately. • Normal—Flows are expired normally. • Permanent—Flows are never expired.
Cache Size	Number of entries in the cache.
Current entries	Number of entries in the cache that are in use.
High Watermark	Highest number of cache entries seen.
Flows added	Flows added to the cache since the cache was created.

Field	Description
Flows aged	Flows expired from the cache since the cache was created.
Active timeout	Current value for the active timeout in seconds.
Inactive timeout	Current value for the inactive timeout in seconds.
Event aged	Number of flows that have been aged by an event such as using the force-export option for the clear flow monitor command.
Watermark aged	Number of flows that have been aged because they exceeded the maximum high watermark value.
Emergency aged	Number of flows that have been aged because the cache size was exceeded.
IPV6 FLOW LABEL	Label number for the flow.
IPV6 EXTENSION MAP	Pointer to the IPv6 extensions.
IPV6 SOURCE ADDRESS	IPv6 source address.
IPV6 DESTINATION ADDRESS	IPv6 destination address.
TRNS SOURCE PORT	source port for the transport protocol.
TRNS DESTINATION PORT	Destination port for the transport protocol.
INTERFACE INPUT	Interface on which the input is received.
FLOW DIRECTION	Input or output.
FLOW SAMPLER ID	Flow sampler ID number.
IP PROTOCOL	IP protocol number.
IP TOS	IP ToS number.
ip source as	BGP source autonomous system number.
ip destination as	BGP destination autonomous system number.
ipv6 next hop address	IPv4 address of the next hop to which the packet is forwarded.
ipv6 source mask	IPv6 source address mask.
ipv6 destination mask	IPv6 destination address mask.

Field	Description
tcp flags	Value of the TCP flags.
interface output	Interface on which the input is transmitted.
counter bytes	Number of bytes that have been counted.
counter packets	Number of packets that have been counted.
timestamp first	Time stamp of the first packet in the flow.
timestamp last	Time stamp of the last packet in the flow.

The following example displays the status and statistics for a flow monitor:

```
Router# show flow monitor FLOW-MONITOR-1 statistics
```

```

Cache type:                      Normal
Cache size:                      4096
Current entries:                  4
High Watermark:                  6
Flows added:                     116
Flows aged:                      112
- Active timeout ( 1800 secs)    0
- Inactive timeout ( 15 secs)    112
- Event aged                     0
- Watermark aged                 0
- Emergency aged                 0

```

The table below describes the significant fields shown in the display.

Table 9: show flow monitor monitor-name statistics Field Descriptions

Field	Description
Cache Type	Flow monitor cache type. The possible values are: <ul style="list-style-type: none"> • Immediate—Flows are expired immediately. • Normal—Flows are expired normally. • Permanent—Flows are never expired.
Cache Size	Size of the cache.
Current entries	Number of entries in the cache that are in use.
High Watermark	Highest number of cache entries seen.
Flows added	Flows added to the cache since the cache was created.
Flows aged	Flows expired from the cache since the cache was created.

Field	Description
Active Timeout	Current value for the active timeout in seconds.
Inactive Timeout	Current value for the inactive timeout in seconds.
Event aged	Number of flows that have been aged by an event such as using the force-export option for the clear flow monitor command.
Watermark aged	Number of flows that have been aged because they exceeded the maximum high watermark value.
Emergency aged	Number of flows that have been aged because the cache size was exceeded.

Related Commands

Command	Description
clear flow monitor	Clears the flow monitor.
debug flow monitor	Enables debugging output for flow monitors.

show flow monitor cache aggregate

To display aggregated flow statistics from a flow monitor cache, use the **show flow monitor cache aggregate** command in privileged EXEC mode.

show flow monitor [**name**] *monitor-name* **cache aggregate** {*options* [... *options*]} [**collect** *options* [... *options*]] [**record** *record-name*] [**format** {**csv**|**record**|**table**}]

Syntax Description

name	(Optional) Specifies the name of a flow monitor.
<i>monitor-name</i>	Name of a flow monitor that was previously configured.
options	Fields upon which aggregation is performed; and from which additional data from the cache is displayed when the collect keyword is used. You can specify multiple values for the <i>options</i> argument. See the “Usage Guidelines” section.
collect	(Optional) Displays additional data from the cache. See the “Usage Guidelines” section.
record <i>record-name</i>	Specifies the name of a user-defined flow record or a predefined flow record. See the first table below for a listing of the available predefined records and their definitions.
format	(Optional) Specifies the use of one of the format options for formatting the display output.
csv	Displays the flow monitor cache contents in comma-separated variables (CSV) format.
record	Displays the flow monitor cache contents in record format.
table	Displays the flow monitor cache contents in table format.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.4(22)T	This command was introduced.

Release	Modification
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7200 and Cisco 7300 Network Processing Engine (NPE) series routers.
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Usage Guidelines

Flexible NetFlow—Top N Talkers Support

The **show flow monitor cache aggregate** command is one of a set of three commands that make up the Flexible NetFlow—Top N Talkers Support feature. The Flexible NetFlow—Top N Talkers Support feature is used to manipulate the display output from the Flexible NetFlow cache to facilitate the analysis of network traffic.

The other two commands that make up the Flexible NetFlow—Top N Talkers Support feature are **show flow monitor cache filter** and **show flow monitor cache sort**. The three commands can be used together or on their own, depending on your requirements. For more detailed information about these commands, see the **show flow monitor cache filter** command and the **show flow monitor cache sort** command. For information about how the three commands are used together, refer to the “Configuring Cisco IOS Flexible NetFlow—Top N Talkers Support” module in the *Configuring Cisco IOS Flexible NetFlow Configuration Guide*.

Flow Aggregation

Flow aggregation using the **show flow monitor cache aggregate** command allows you to dynamically display the flow information in a cache using a different flow record than the cache was originally created from. Only the fields in the cache will be available for the aggregated flows.



Note

The key and nonkey fields in the flows are defined in the flow record that you assigned to the flow monitor from which the cache data is being aggregated.

Aggregation helps you achieve a higher-level view of the traffic in your network by combining flow data from multiple flows based on the criteria that interest you, for example, displaying flow data for:

- All the HTTP traffic in your network.
- All the traffic being forwarded to a specific Border Gateway Protocol (BGP) next hop.
- Identifying a device that is sending several types of traffic to one or more hosts in your network, perhaps as part of a denial of service (DoS) attack.

Aggregation options Argument

The options that you can use for the *options* argument of the **show flow monitor cache aggregate** command are dependent on the fields that are used for the user-defined flow record that you configured for the flow monitor using the **record** command. To identify the options that you can use, use the **show flow record record-name** command in privileged EXEC mode, where *record-name* is the name of the record that you configured for the flow monitor.

For example, if you assigned the “NetFlow Original” predefined record to a flow monitor, you use the **show flow record netflow-original** command to display its key (match) and nonkey (collect) fields. The following is partial output from the **show flow record netflow-original** command:

```
flow record netflow-original:
  Description:      Traditional IPv4 input NetFlow with origin ASs
  No. of users:     2
  Total field space: 53 bytes
  Fields:
    match ipv4 tos
    match ipv4 protocol
    match ipv4 source address
    match ipv4 destination address
  .
  .
  .
    collect counter packets
    collect timestamp sys-uptime first
    collect timestamp sys-uptime last
```

The fields from this partial output that you can use for the *option* argument follow the **match** (key fields) and **collect** (nonkey fields) words. For example, you can use the “ipv4 tos” field to aggregate the flows as shown in the first example in the “Examples section.”

Cache Data Fields Displayed

By default the data fields from the cache that are shown in the display output of the **show flow monitor cache aggregate** command are limited to the field used for aggregation and the counter fields such as flows, number of bytes, and the number of packets. The following is partial output from the **show flow monitor FLOW-MONITOR-3 cache aggregate ipv4 destination address** command:

IPv4 DST ADDR	flows	bytes	pkts
=====	=====	=====	=====
224.192.16.1	2	97340	4867
224.192.18.1	3	96080	4804
224.192.16.4	4	79760	3988
224.192.45.12	3	77480	3874
255.255.255.255	1	52	1

Notice that the data contains only the IPv4 destination addresses for which flows have been aggregated and the counter values.

The flow monitor (FLOW-MONITOR-3) referenced by the **show flow monitor FLOW-MONITOR-3 cache aggregate ipv4 destination address** command uses the “NetFlow Original” predefined record, which contains the following key and nonkey fields:

- match ipv4 tos
- match ipv4 protocol
- match ipv4 source address
- match ipv4 destination address
- match transport source-port
- match transport destination-port
- match interface input
- match flow sampler
- collect routing source as
- collect routing destination as

- collect routing next-hop address ipv4
- collect ipv4 source mask
- collect ipv4 destination mask
- collect transport tcp flags
- collect interface output
- collect counter bytes
- collect counter packets
- collect timestamp sys-uptime first
- collect timestamp sys-uptime last

The **collect** keyword is used to include additional cache data in the display output of the **show flow monitor cache aggregate** command. The following partial output from the **show flow monitor FLOW-MONITOR-3 cache aggregate ipv4 destination address collect transport tcp flags** command shows the transport TCP flags data from the cache:

IPV4 DST ADDR	tcp flags	flows	bytes	pkts
224.192.16.1	0x00	4	165280	8264
224.192.18.1	0x00	4	158660	7933
224.192.16.4	0x00	3	146740	7337
224.192.45.12	0x00	4	145620	7281
255.255.255.255	0x00	1	52	1
224.0.0.13	0x00	1	54	1

You can add cache data fields after the **collect** keyword to show additional data from the cache in the display output of the **show flow monitor cache aggregate** command.

Keywords and Descriptions for the *record* Argument

The table below describes the keywords for the *record* argument.

Table 10: Keywords and Descriptions for the Aggregate record Argument

Keyword	Description	IPv4 Support	IPv6 Support
as	Autonomous system record.	Yes	Yes
as-tos	Autonomous system and ToS record.	Yes	No
bgp-nexthop-tos	BGP next-hop and ToS record.	Yes	No
bgp-nexthop	BGP next-hop record.	No	Yes
destination-prefix	Destination prefix record. Note For IPv6, a minimum prefix mask length of 0 bits is assumed.	Yes	Yes

Keyword	Description	IPv4 Support	IPv6 Support
destination-prefix-tos	Destination prefix and ToS record.	Yes	No
original-input	Traditional IPv4 input NetFlow.	Yes	Yes
original-output	Traditional IPv4 output NetFlow.	Yes	Yes
prefix	Source and destination prefixes record. Note For IPv6, a minimum prefix mask length of 0 bits is assumed.	Yes	Yes
prefix-port	Prefix port record. Note The peer keyword is not available for this record.	Yes	No
prefix-tos	Prefix ToS record.	Yes	No
protocol-port	Protocol ports record. Note The peer keyword is not available for this record.	Yes	Yes
protocol-port-tos	Protocol port and ToS record. Note The peer keyword is not available for this record.	Yes	No
source-prefix	Source autonomous system and prefix record. Note For IPv6, a minimum prefix mask length of 0 bits is assumed.	Yes	Yes
source-prefix-tos	Source prefix and ToS record.	Yes	No

Examples

The following example aggregates the flow monitor cache data on the destination and source IPv4 addresses:

```
Router# show flow monitor FLOW-MONITOR-1 cache aggregate ipv4 destination address ipv4
source address
```

```
Processed 26 flows
Aggregated to 17 flows
IPV4 SRC ADDR      IPV4 DST ADDR      flows      bytes      pkts
=====
10.251.10.1        172.16.10.2        2          1400828    1364
192.168.67.6       172.16.10.200      1           19096     682
10.234.53.1        172.16.10.2        3          73656     2046
172.30.231.193     172.16.10.2        3          73616     2045
10.10.10.2         172.16.10.2        2          54560     1364
192.168.87.200     172.16.10.2        2          54560     1364
10.10.10.4         172.16.10.4        1          27280     682
10.10.11.1         172.16.10.5        1          27280     682
10.10.11.2         172.16.10.6        1          27280     682
10.10.11.3         172.16.10.7        1          27280     682
10.10.11.4         172.16.10.8        1          27280     682
10.1.1.1           172.16.10.9        1          27280     682
10.1.1.2           172.16.10.10       1          27280     682
10.1.1.3           172.16.10.11       1          27280     682
172.16.1.84        172.16.10.19       2          54520     1363
172.16.1.85        172.16.10.20       2          54520     1363
172.16.6.1         224.0.0.9          1           52        1
```

The table below describes the significant fields shown in the display.

Table 11: show flow monitor cache aggregate Field Descriptions

Field	Description
IPV4 SOURCE ADDRESS	IPv4 source address.
IPV4 DESTINATION ADDRESS	IPv4 destination address.
flows	Numbers of flows associated with the source/destination IP address combination
bytes	Number of bytes contained in the flows.
packets	Number of packets contained in the flows.

Related Commands

Command	Description
show flow monitor cache filter	Filters the display output of flow records from a flow monitor cache.
show flow monitor cache sort	Sorts the display output of flow records from a flow monitor cache.

show flow monitor cache filter

To filter the display output of statistics from the flows in a flow monitor cache, use the **show flow monitor cache filter** command in privileged EXEC mode.

show flow monitor [**name**] *monitor-name* **cache filter** *options* [**regex** *regex*] [... *options* [**regex** *regex*]]
[**format** {**csv**|**record**|**table**}]

Syntax Description

name	(Optional) Specifies the name of a flow monitor.
<i>monitor-name</i>	Name of a flow monitor that was previously configured.
<i>options</i>	Fields upon which filtering is performed. You can specify multiple values for the <i>options</i> argument. See the “Usage Guidelines” section.
regex <i>regex</i>	(Optional) Match the field specified with the <i>options</i> argument against a regular expression. See the “Usage Guidelines” section.
format	(Optional) Specifies the use of one of the format options for formatting the display output.
csv	Displays the flow monitor cache contents in comma-separated variables (CSV) format.
record	Displays the flow monitor cache contents in record format.
table	Displays the flow monitor cache contents in table format.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.4(22)T	This command was introduced.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7200 and Cisco 7300 Network Processing Engine (NPE) series routers.
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY.

Release	Modification
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Usage Guidelines

Flexible NetFlow—Top N Talkers Support

The **show flow monitor cache filter** command is one of a set of three commands that make up the Flexible NetFlow—Top N Talkers Support feature. The Flexible NetFlow—Top N Talkers Support feature is used to manipulate the display output from the Flexible NetFlow cache to facilitate the analysis of network traffic.

The other two commands that make up the Flexible NetFlow—Top N Talkers Support feature are **show flow monitor cache sort** and **show flow monitor cache aggregate**. The three commands can be used together or on their own, depending on your requirements. For more detailed information about these commands, see the **show flow monitor cache sort** command and the **show flow monitor cache aggregate** command. For information about how the three commands are used together, refer to the “Configuring Cisco IOS Flexible NetFlow—Top N Talkers Support” module in the *Configuring Cisco IOS Flexible NetFlow Configuration Guide*.

Filter options Argument

The options that you can use for the *options* argument of the **show flow monitor cache filter** command are dependent on the fields that are used for the record that you configured for the flow monitor using the **record** command. To identify the options that you can use, use the **show flow record record-name** command in privileged EXEC mode, where *record-name* is the name of the record that you configured for the flow monitor.

For example, if you assigned the “NetFlow Original” predefined record to a flow monitor, you use the **show flow record netflow-original** command to display its key (match) and nonkey (collect) fields. The following is partial output from the **show** command:

```
flow record netflow-original:
  Description:      Traditional IPv4 input NetFlow with origin ASs
  No. of users:      2
  Total field space: 53 bytes
  Fields:
    match ipv4 tos
    match ipv4 protocol
    match ipv4 source address
    match ipv4 destination address
  .
  .
  .
    collect counter packets
    collect timestamp sys-uptime first
    collect timestamp sys-uptime last
```

The fields from this partial output that you can use for the *option* argument follow the **match** (key fields) and **collect** (nonkey fields) words. For example, you can use the “ipv4 tos” field to filter the flows as shown in the first example in the “Examples” section.

Filtering Criteria

The following are examples of the types of filtering criteria available for the **show flow monitor cache filter** command:

- Perform an exact match on any numerical fields in either decimal or hexadecimal format. For example, these two commands match flows in the flow monitor cache that contain either “0xA001” or “1”:
 - **show flow monitor FLOW-MONITOR-1 cache filter transport source-port 0xA001**

- **show flow monitor FLOW-MONITOR-1 cache filter transport source-port 1**
- Perform a match on a range for any numerical fields in either decimal or hexadecimal format. For example, these two commands match flows in the flow monitor cache that contain either “0xA000 0xB000” or “1 1024”:
 - **show flow monitor FLOW-MONITOR-1 cache filter transport source-port 0xA000 0xB000**
 - **show flow monitor FLOW-MONITOR-1 cache filter transport source-port 1 1024**
- Perform an exact match for any alphanumerical field. For example, this command matches flows in the flow monitor cache having a MAC address of ABCD:0012:01FE:
 - **show flow monitor FLOW-MONITOR-1 cache filter datalink mac source address ABCD:0012:01FE**
- Perform a regular-expression match on any alphanumerical field. For example, this command matches flows in the flow monitor cache having a MAC address that starts with ABCD:
 - **show flow monitor FLOW-MONITOR-1 cache filter datalink mac source address regexp ABCD:***
- Perform a match on flag fields with an implicit <and>. For example, this command matches flows in the flow monitor cache that contain the **urg** and **syn** TCP flags:
 - **show flow monitor FLOW-MONITOR-1 cache filter transport tcp flags urg syn**
- Perform a match against flags that are not present. For example, this command matches flows in the flow monitor cache that contain the **syn** and **rst** TCP flags and do not contain the **urg** and **fin** TCP flags:
 - **show flow monitor FLOW-MONITOR-1 cache filter transport tcp flags syn rst not urg fin**
- Perform an exact match on an IP address field. For example, this command matches flows in the flow monitor cache that contain the source IPv4 address “192.168.0.1”:
 - **show flow monitor FLOW-MONITOR-1 cache filter ipv4 source address 192.168.0.1**
- Perform a prefix match on an IPv4 or IPv6 address field. For example, these two commands match flows in the flow monitor cache that contain either “192.168.0.0 255.255.0.0” or “7:20ac::/64”:
 - **show flow monitor FLOW-MONITOR-1 cache filter ipv4 source address 192.168.0.0 255.255.0.0**
 - **show flow monitor FLOW-MONITOR-1 cache filter ipv6 source address 7:20ac::/64**
- Perform a match on a range of relative time stamps. For example, this command matches flows in the flow monitor cache that were created within the last “500” seconds:
 - **show flow monitor FLOW-MONITOR-1 cache filter timestamp sys-uptime first 0 500 seconds**
- Perform a match on range of the time stamp that is configured (uptime or absolute). For example, this command matches flows in the flow monitor cache that were created between 0800 and 0815, within the last 24 hours:

- **show flow monitor FLOW-MONITOR-1 cache filter timestamp sys-uptime last 08:00:00 08:15:00 t**

- Perform an exact match on an interface. For example, this command matches flows in the flow monitor cache which are received on Ethernet interface 0/0.

- **show flow monitor FLOW-MONITOR-1 cache filter interface input Ethernet0/0**

- Perform a regular-expression match on an interface. For example, this command matches flows in the flow monitor cache that begin with Ethernet0/ and have either 1, 2, or 3 as the port number:

- **show flow monitor FLOW-MONITOR-1 cache filter interface input regexp Ethernet0/1**

Regular Expressions

The table below shows the syntax for regular expressions.

Table 12: Syntax for Regular Expressions

Option	Description
*	Match zero or more characters in this position.
?	Match any one character in this position.
	Match any one character in this position.
()	Match one of a choice of characters in a range. For example, aa:(0033 4455):3456 matches either aa:0033:3456 or aa:4455:3456.
[]	Match any character in the range specified, or one of the special characters. For example, [0-9] is all of the digits. [*] is the “*” character, and [[] is the “[” character.

Examples

The following example filters the flow monitor cache data on the source IPv4 address of 10.234.53.1:

```
Router# show flow monitor FLOW-MONITOR-1 cache filter ipv4 source address 10.234.53.1

Cache type:                               Normal
Cache size:                               4096
Current entries:                           26
High Watermark:                           26
Flows added:                               87
Flows aged:                                61
  - Active timeout ( 1800 secs)             0
  - Inactive timeout ( 15 secs)             61
  - Event aged                               0
  - Watermark aged                           0
  - Emergency aged                           0
IPV4 SOURCE ADDRESS:                       10.234.53.1
IPV4 DESTINATION ADDRESS:                   172.16.10.2
TRNS SOURCE PORT:                           0
```

```

TRANS DESTINATION PORT:      2048
INTERFACE INPUT:             Et0/0.1
FLOW SAMPLER ID:             0
IP TOS:                       0x00
IP PROTOCOL:                  1
ip source as:                 0
ip destination as:            0
ipv4 next hop address:        172.16.7.2
ipv4 source mask:              /0
ipv4 destination mask:        /24
tcp flags:                    0x00
interface output:             Et1/0.1
counter bytes:                24724
counter packets:              883
timestamp first:              16:03:56.007
timestamp last:               16:27:07.063
IPV4 SOURCE ADDRESS:          10.234.53.1
IPV4 DESTINATION ADDRESS:      172.16.10.2
TRANS SOURCE PORT:            20
TRANS DESTINATION PORT:       20
INTERFACE INPUT:             Et0/0.1
FLOW SAMPLER ID:             0
IP TOS:                       0x00
IP PROTOCOL:                  6
ip source as:                 0
ip destination as:            0
ipv4 next hop address:        172.16.7.2
ipv4 source mask:              /0
ipv4 destination mask:        /24
tcp flags:                    0x00
interface output:             Et1/0.1
counter bytes:                35320
counter packets:              883
timestamp first:              16:03:56.267
timestamp last:               16:27:07.323
IPV4 SOURCE ADDRESS:          10.234.53.1
IPV4 DESTINATION ADDRESS:      172.16.10.2
TRANS SOURCE PORT:            21
TRANS DESTINATION PORT:       21
INTERFACE INPUT:             Et0/0.1
FLOW SAMPLER ID:             0
IP TOS:                       0x00
IP PROTOCOL:                  6
ip source as:                 0
ip destination as:            0
ipv4 next hop address:        172.16.7.2
ipv4 source mask:              /0
ipv4 destination mask:        /24
tcp flags:                    0x00
interface output:             Et1/0.1
counter bytes:                35320
counter packets:              883
timestamp first:              16:03:56.327
timestamp last:               16:27:07.363
Matched 3 flows

```

The table below describes the significant fields shown in the display.

Table 13: show flow monitor monitor-name cache filter Field Descriptions

Field	Description
Cache type	Flow monitor cache type. The possible values are: <ul style="list-style-type: none"> • Immediate—Flows are expired immediately. • Normal—Flows are expired normally. • Permanent—Flows are never expired.
Cache Size	Number of entries in the cache.
Current entries	Number of entries in the cache that are in use.
High Watermark	Highest number of cache entries seen.
Flows added	Flows added to the cache since the cache was created.
Flows aged	Flows expired from the cache since the cache was created.
Active timeout	Current value for the active timeout in seconds.
Inactive timeout	Current value for the inactive timeout in seconds.
Event aged	Number of flows that have been aged by an event such as using the force-export option for the clear flow monitor command.
Watermark aged	Number of flows that have been aged because they exceeded the maximum high watermark value.
Emergency aged	Number of flows that have been aged because the cache size was exceeded.
IPV4 SOURCE ADDRESS	IPv4 source address.
IPV4 DESTINATION ADDRESS	IPv4 destination address.
TRNS SOURCE PORT	source port for the transport protocol.
TRNS DESTINATION PORT	Destination port for the transport protocol.
INTERFACE INPUT	Interface on which the input is received.
FLOW DIRECTION	Input or output.
FLOW SAMPLER ID	Flow sampler ID number.

Field	Description
IP PROTOCOL	IP protocol number.
IP TOS	IP ToS number.
ip source as	BGP source autonomous system number.
ip destination as	BGP destination autonomous system number.
ipv4 next hop address	IPv4 address of the next hop to which the packet is forwarded.
ipv4 source mask	IPv4 source address mask.
ipv4 destination mask	IPv4 destination address mask.
tcp flags	Value of the TCP flags.
interface output	Interface on which the input is transmitted.
counter bytes	Number of bytes that have been counted.
counter packets	Number of packets that have been counted.
timestamp first	Time stamp of the first packet in the flow.
timestamp last	Time stamp of the last packet in the flow.

Related Commands

Command	Description
show flow monitor cache aggregate	Displays aggregated flow records of flows in a flow monitor cache.
show flow monitor cache sort	Sorts the display output of flow records from a flow monitor cache.

show flow monitor cache sort

To sort the display output of statistics from the flows in a flow monitor cache, use the **show flow monitor cache sort** command in privileged EXEC mode.

show flow monitor [**name**] *monitor-name* **cache sort** *options* [**top** [*number*]] [**format** {**csv**|**record**|**table**}]

Syntax Description

name	(Optional) Specifies the name of a flow monitor.
<i>monitor-name</i>	Name of a flow monitor that was previously configured.
options	Fields upon which aggregation can be performed. See the “Usage Guidelines” section.
top	(Optional) Limits the display output to the 20 highest volume flows (top talkers) unless overridden by the specification of a value for the <i>number</i> argument.
<i>number</i>	(Optional) Overrides the default value of top talkers to display.
format	(Optional) Specifies the use of one of the format options for formatting the display output.
csv	Displays the flow monitor cache contents in comma-separated variables (CSV) format.
record	Displays the flow monitor cache contents in record format.
table	Displays the flow monitor cache contents in table format.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.4(22)T	This command was introduced.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7200 and Cisco 7300 Network Processing Engine (NPE) series routers.

Release	Modification
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Usage Guidelines

Flexible NetFlow—Top N Talkers Support

The **show flow monitor cache sort** command is one of a set of three commands that make up the Flexible NetFlow—Top N Talkers Support feature. The Flexible NetFlow—Top N Talkers Support feature is used to manipulate the display output from the Flexible NetFlow cache to facilitate the analysis of network traffic.

The other two commands that make up the Flexible NetFlow—Top N Talkers Support feature are **show flow monitor cache filter** and **show flow monitor cache aggregate**. The three commands can be used together or on their own, depending on your requirements. For more detailed information about these commands, see the **show flow monitor cache filter** command and the **show flow monitor cache aggregate** command. For information about how the three commands are used together, refer to the “Configuring Cisco IOS Flexible NetFlow—Top N Talkers Support” module in the *Configuring Cisco IOS Flexible NetFlow Configuration Guide*.

Flow Sorting

The flow sorting function of the Flexible NetFlow—Top N Talkers Support feature sorts flow data from the Flexible NetFlow cache based on the criteria that you specify, and displays the data. You can also use the flow sorting function of the Flexible NetFlow—Top N Talkers Support feature to limit the display output to a specific number of entries (Top N Talkers) by using the **top** keyword.

Sort options Argument

The options that you can use for the *options* argument of the **show flow monitor cache filter** command are dependent on the fields that are used for the record that you configured for the flow monitor using the **record** command. To identify the options that you can use, use the **show flow record record-name** command in privileged EXEC mode, where *record-name* is the name of the record that you configured for the flow monitor.

For example, if you assigned the “NetFlow Original” predefined record to a flow monitor, you use the **show flow record netflow-original** command to display its key (match) and nonkey (collect) fields. The following is partial output from the **show** command:

```
flow record netflow-original:
  Description:      Traditional IPv4 input NetFlow with origin ASs
  No. of users:     2
  Total field space: 53 bytes
  Fields:
    match ipv4 tos
    match ipv4 protocol
    match ipv4 source address
    match ipv4 destination address
  .
  .
  .
    collect counter packets
    collect timestamp sys-uptime first
    collect timestamp sys-uptime last
```

The fields from this partial output that you can use for the *option* argument follow the **match** (key fields) and **collect** (nonkey fields) words. For example, you can use the “ipv4 tos” field to sort the flows as shown in the first example in the “Examples” section.

Examples

The following example sorts the flow monitor cache data on the IPv4 ToS value and limits the display output to the top two flows:

```
Router# show flow monitor FLOW-MONITOR-3 cache sort ipv4 tos top 2
```

```
Processed 17 flows
Aggregated to 17 flows
Showing the top 2 flows
IPV4 SOURCE ADDRESS:      10.1.1.1
IPV4 DESTINATION ADDRESS: 224.192.16.1
TRNS SOURCE PORT:         0
TRNS DESTINATION PORT:    3073
INTERFACE INPUT:          Et0/0
FLOW SAMPLER ID:          0
IP TOS:                    0x55
IP PROTOCOL:               1
ip source as:              0
ip destination as:         0
ipv4 next hop address:     0.0.0.0
ipv4 source mask:          /24
ipv4 destination mask:    /0
tcp flags:                 0x00
interface output:          Null
counter bytes:             33680
counter packets:           1684
timestamp first:           18:39:27.563
timestamp last:            19:04:28.459
```

```
IPV4 SOURCE ADDRESS:      10.1.1.1
IPV4 DESTINATION ADDRESS: 224.192.16.1
TRNS SOURCE PORT:         0
TRNS DESTINATION PORT:    0
INTERFACE INPUT:          Et0/0
FLOW SAMPLER ID:          0
IP TOS:                    0x55
IP PROTOCOL:               1
ip source as:              0
ip destination as:         0
ipv4 next hop address:     0.0.0.0
ipv4 source mask:          /24
ipv4 destination mask:    /0
tcp flags:                 0x00
interface output:          Et3/0.1
counter bytes:             145040
counter packets:           7252
timestamp first:           18:42:34.043
timestamp last:            19:04:28.459
```

The table below describes the significant fields shown in the display.

Table 14: show flow monitor monitor-name cache sort Field Descriptions

Field	Description
IPV4 SOURCE ADDRESS	IPv4 source address.
IPV4 DESTINATION ADDRESS	IPv4 destination address.
TRNS SOURCE PORT	source port for the transport protocol.
TRNS DESTINATION PORT	Destination port for the transport protocol.
INTERFACE INPUT	Interface on which the input is received.

Field	Description
FLOW DIRECTION	Input or output.
FLOW SAMPLER ID	Flow sampler ID number.
IP PROTOCOL	IP protocol number.
IP TOS	IP ToS number.
ip source as	BGP source autonomous system number.
ip destination as	BGP destination autonomous system number.
ipv4 next hop address	IPv4 address of the next hop to which the packet is forwarded.
ipv4 source mask	IPv4 source address mask.
ipv4 destination mask	IPv4 destination address mask.
tcp flags	Value of the TCP flags.
interface output	Interface on which the input is transmitted.
counter bytes	Number of bytes that have been counted.
counter packets	Number of packets that have been counted.
timestamp first	Time stamp of the first packet in the flow.
timestamp last	Time stamp of the last packet in the flow.

Related Commands

Command	Description
show flow monitor cache aggregate	Displays aggregated flow records of flows in a flow monitor cache.
show flow monitor cache filter	Filters the display output of flow records from a flow monitor cache.

show flow record

To display the status and statistics for a Flexible NetFlow flow record, use the **show flow record** command in privileged EXEC mode.

show flow record *[[name] record-name| netflow-original| netflow {ipv4| ipv6} record [peer]]*

Cisco Catalyst 6500 Switches in Cisco IOS Release 12.2(50)SY

show flow record *[[name] record-name| platform-original {ipv4| ipv6} record]*

Cisco IOS XE Release 3.2SE

show flow record *[[name] record-name]*

Syntax Description

name	(Optional) Specifies the name of a flow record.
<i>record-name</i>	(Optional) Name of a user-defined flow record that was previously configured.
netflow-original	(Optional) Specifies the Flexible NetFlow implementation of original NetFlow with origin autonomous systems.
netflow ipv4	(Optional) Configures the flow monitor to use one of the IPv4 predefined records.
netflow ipv6	(Optional) Configures the flow monitor to use one of the IPv6 predefined records.
<i>record</i>	(Optional) Name of the predefined record. See the first table below for a listing of the available records and their definitions.
peer	(Optional) Configures the flow monitor to use one of the predefined records with peer autonomous systems. The peer keyword is not supported for every type of Flexible NetFlow predefined record. See the first table below.
platform-original ipv4	Configures the flow monitor to use one of the predefined IPv4 records.
platform-original ipv6	Configures the flow monitor to use one of the predefined IPv6 records.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.
12.4(20)T	This command was modified. The ipv6 keyword was added.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
12.2(50)SY	This command was modified. The netflow-original , netflow ipv4 , and netflow ipv6 keywords were removed. The platform-originalipv4 and platform-originalipv6 keywords were added.
Cisco IOS XE Release 3.2SE	This command was modified. The netflow-original , netflow ipv4 , and netflow ipv6 keywords were removed.

Usage Guidelines

The table below describes the keywords and descriptions for the *record* argument.

Table 15: Keywords and Descriptions for the record Argument

Keyword	Description	IPv4 Support	IPv6 Support
as	Autonomous system record.	Yes	Yes
as-tos	Autonomous system and Type of Service (ToS) record.	Yes	—
bgp-nexthop-tos	BGP next-hop and ToS record.	Yes	—
bgp-nexthop	BGP next-hop record.	—	Yes

Keyword	Description	IPv4 Support	IPv6 Support
destination	Original platform IPv4/IPv6 destination record.	Yes	Yes
destination-prefix	Destination prefix record. Note For IPv6, a minimum prefix mask length of 0 bits is assumed.	Yes	Yes
destination-prefix-tos	Destination prefix and ToS record.	Yes	—
destination-source	Original platform IPv4/IPv6 destination-source record.	Yes	Yes
full	Original platform IPv4/IPv6 full record.	Yes	Yes
interface-destination	Original platform IPv4/IPv6 interface-destination record.	Yes	Yes
interface-destination-source	Original platform IPv4/IPv6 interface-destination-source record.	Yes	Yes
interface-full	Original platform IPv4/IPv6 interface-full record.	Yes	Yes
interface-source	Original platform IPv4/IPv6 interface-source only record.	Yes	Yes
original-input	Traditional IPv4 input NetFlow.	Yes	Yes
original-output	Traditional IPv4 output NetFlow.	Yes	Yes

Keyword	Description	IPv4 Support	IPv6 Support
prefix	Source and destination prefixes record. Note For IPv6, a minimum prefix mask length of 0 bits is assumed.	Yes	Yes
prefix-port	Prefix port record. Note The peer keyword is not available for this record.	Yes	—
prefix-tos	Prefix ToS record.	Yes	
protocol-port	Protocol ports record. Note The peer keyword is not available for this record.	Yes	Yes
protocol-port-tos	Protocol port and ToS record. Note The peer keyword is not available for this record.	Yes	—
source	Original platform IPv4/IPv6 source only record.	Yes	Yes
source-prefix	Source autonomous system and prefix record. Note For IPv6, a minimum prefix mask length of 0 bits is assumed.	Yes	Yes
source-prefix-tos	Source prefix and ToS record.	Yes	—

Examples

The following example displays the status and statistics for the original Flexible NetFlow record:

```
Router# show flow record FLOW-RECORD-1 platform-original ipv4 destination
flow record FLOW_RECORD-1:
  Description: Flow Record for IPv4 traffic
```

```
No. of users:      3
Total field space: 53 bytes
Fields:
  match interface input
  match transport destination-port
  match transport source-port
  match ipv4 destination address
  match ipv4 source address
  match ipv4 protocol
  match ipv4 tos
  collect counter bytes
  collect counter packets
  collect timestamp sys-uptime last
  collect timestamp sys-uptime first
  collect ipv4 destination mask
  collect ipv4 source mask
  collect routing destination as
  collect routing source as
  collect transport tcp flags
  collect routing next-hop address ipv4
  collect interface output
```

The table below describes the significant fields shown in the display.

Table 16: show flow record netflow-original Field Descriptions

Field	Description
Description	Description that you configured for the record, or the default description “User defined.”
No. of users	Number of monitors in the configuration that use the flow record.
Total field space	Number of bytes required to store these fields for one flow.
Fields	The fields that are included in this record. For more information about the fields, refer to the match and collect commands.

Related Commands

Command	Description
record	Configures a flow record for a flow monitor.

show sampler

To display the status and statistics for a Flexible NetFlow sampler, use the **show sampler** command in privileged EXEC mode.

show sampler *[[name] sampler-name]*

Syntax Description

name	(Optional) Specifies the name of a flow sampler.
<i>sampler-name</i>	(Optional) Name of a sampler that was previously configured.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Examples

The following example displays the status and statistics for all of the flow samplers configured:

```
Router# show sampler

Sampler SAMPLER-1:
  ID: 1
  Description: User defined
  Type: random
  Rate: 1 out of 3
  Samples: 189
  Requests: 23243
  Users (2):
    flow monitor FLOW-MONITOR-1 (ip,Et0/0,Input) 65 out of 10786
```

```

    flow monitor FLOW-MONITOR-2 (ipv6,Et0/0, Input) 124 out of 12457
Sampler sampler-2:
  ID:                2
  Description:       User defined
  Type:              deterministic
  Rate:              1 out of 100
  Samples:           1
  Requests:          124
  Users (1):
    flow monitor FLOW-MONITOR-1 (ip,Et0/0,Input) 1 out of 124

```

The table below describes the significant fields shown in the display.

Table 17: show sampler Field Descriptions

Field	Description
ID	ID number of the flow sampler. This is used to identify the sampler at the collector.
Description	Description that you configured for the flow sampler, or the default description “User defined.”
Type	Sampling mode that you configured for the flow sampler. <ul style="list-style-type: none"> • deterministic—Deterministic mode of sampling. • random—Random mode of sampling.
Rate	Window size (for packet selection) that you configured for the flow sampler. Range: 2 to 32768.
Samples	Number of packets sampled since the flow sampler was configured or the router was restarted. This is equivalent to the number of times a positive response was received when the sampler was queried to determine if the traffic needed to be sampled. Refer to the explanation of the “Requests” field in this table.
Requests	Number of times the flow sampler was queried to determine if the traffic needed to be sampled.
Users	Interfaces on which the flow sampler is configured.

Related Commands

Command	Description
clear sampler	Clears the flow sampler statistics.
debug sampler	Enables debugging output for flow samplers.
sampler	Creates a flow sampler.

source (Flexible NetFlow)

To configure the source IP address interface for all of the packets sent by a Flexible NetFlow flow exporter, use the **source** command in Flexible NetFlow flow exporter configuration mode. To remove the source IP address interface for all of the packets sent by a Flexible NetFlow flow exporter, use the **no** form of this command.

```
source interface-type interface-number
no source
```

Syntax Description

<i>interface-type</i>	Type of interface whose IP address you want to use for the source IP address of the packets sent by a Flexible NetFlow flow exporter.
<i>interface-number</i>	Interface number whose IP address you want to use for the source IP address of the packets sent by a Flexible NetFlow flow exporter.

Command Default

The IP address of the interface over which the Flexible NetFlow datagram is transmitted is used as the source IP address.

Command Modes

Flexible NetFlow flow exporter configuration (config-flow-exporter)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers in Cisco IOS Release 12.2(33)SRC.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Usage Guidelines

The benefits of using a consistent IP source address for the datagrams that NetFlow sends include the following:

- The source IP address of the datagrams exported by Flexible NetFlow is used by the destination system to determine from which router the Flexible NetFlow data is arriving. If your network has two or more paths that can be used to send Flexible NetFlow datagrams from the router to the destination system and you do not specify the source interface from which the source IP address is to be obtained, the router uses the IP address of the interface over which the datagram is transmitted as the source IP address of the datagram. In this situation the destination system might receive Flexible NetFlow datagrams from the same router, but with different source IP addresses. When the destination system receives Flexible NetFlow datagrams from the same router with different source IP addresses, the destination system treats the Flexible NetFlow datagrams as if they were being sent from different routers. To avoid having the destination system treat the Flexible NetFlow datagrams as if they were being sent from different routers, you must configure the destination system to aggregate the Flexible NetFlow datagrams it receives from all of the possible source IP addresses in the router into a single Flexible NetFlow flow.
- If your router has multiple interfaces that can be used to transmit datagrams to the destination system, and you do not configure the **source** command, you will have to add an entry for the IP address of each interface into any access lists that you create for permitting Flexible NetFlow traffic. Creating and maintaining access lists for permitting Flexible NetFlow traffic from known sources and blocking it from unknown sources is easier when you limit the source IP address for Flexible NetFlow datagrams to a single IP address for each router that is exporting Flexible NetFlow traffic.

**Caution**

The interface that you configure as the **source** interface must have an IP address configured, and it must be up.

**Tip**

When a transient outage occurs on the interface that you configured with the **source** command, the Flexible NetFlow exporter reverts to the default behavior of using the IP address of the interface over which the datagrams are being transmitted as the source IP address for the datagrams. To avoid this problem, use a loopback interface as the source interface because loopback interfaces are not subject to the transient outages that can occur on physical interfaces.

Examples

The following example shows how to configure Flexible NetFlow to use a loopback interface as the source interface for NetFlow traffic:

```
Router(config)# flow exporter FLOW-EXPORTER-1
Router(config-flow-exporter)# source loopback 0
```

Related Commands

Command	Description
flow exporter	Creates a flow exporter.

template data timeout

To configure the template resend timeout for a flow exporter, use the **template data timeout** command in Flexible NetFlow flow exporter configuration mode. To remove the template resend timeout for a flow exporter, use the **no** form of this command.

template data timeout *seconds*
no template data timeout

Syntax Description

<i>seconds</i>	Configures resending of templates based on the timeout value in seconds, that you enter. Range: 1 to 86400. Default: 600.
----------------	---

Command Default

The default template resend timeout for a flow exporter is 600 seconds.

Command Modes

Flexible NetFlow flow exporter configuration (config-flow-exporter)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
Cisco IOS XE Release 3.1S	This command was integrated into Cisco IOS XE Release 3.1S.
15.1(3)T	This command was modified. Support for the Cisco Performance Monitor was added.
12.2(58)SE	This command was modified. Support for the Cisco Performance Monitor was added.
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Usage Guidelines

This command can be used with both Flexible NetFlow and Performance Monitor.

Examples

The following example configures resending templates based on a timeout of 1000 seconds:

```
Router(config)# flow exporter FLOW-EXPORTER-1
Router(config-flow-exporter)# template data timeout 1000
```

Related Commands

Command	Description
flow exporter	Creates a flow exporter.

transport (Flexible NetFlow)

To configure the transport protocol for a flow exporter for Flexible NetFlow or Performance Monitor, use the **transport** command in Flexible NetFlow flow exporter configuration mode. To remove the transport protocol for a flow exporter, use the **no** form of this command.

```
transport udp udp-port
no transport
```

Syntax Description

udp udp-port	Specifies User Datagram Protocol (UDP) as the transport protocol and the UDP port number.
--------------	---

Command Default

Flow exporters use UDP on port 9995.

Command Modes

Flexible NetFlow flow exporter configuration (config-flow-exporter)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
Cisco IOS XE Release 3.1S	This command was integrated into Cisco IOS XE Release 3.1S.
15.1(3)T	This command was modified. Support for the Cisco Performance Monitor was added.
12.2(58)SE	This command was modified. Support for the Cisco Performance Monitor was added.
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Usage Guidelines

This command can be used with both Flexible NetFlow and Performance Monitor.

Examples

The following example configures UDP as the transport protocol and a UDP port number of 250:

```
Router(config)# flow exporter FLOW-EXPORTER-1
Router(config-flow-exporter)# transport udp 250
```

Related Commands

Command	Description
flow exporter	Creates a flow exporter.

ttl (Flexible NetFlow)

To configure the time-to-live (TTL) value for a flow exporter for Flexible NetFlow or Performance Monitor, use the **ttl** command in Flexible NetFlow flow exporter configuration mode. To remove the TTL value for a flow exporter, use the **no** form of this command.

```
ttl ttl
no ttl
```

Syntax Description

ttl	Time-to-live (TTL) value for exported datagrams. Range: 1 to 255. Default: 255.
-----	---

Command Default

Flow exporters use a TTL of 255.

Command Modes

Flexible NetFlow flow exporter configuration (config-flow-exporter)

Command History

Release	Modification
12.4(9)T	This command was introduced.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.0(33)S	This command was modified. Support for this command was implemented on the Cisco 12000 series routers.
12.2(33)SRC	This command was modified. Support for this command was implemented on the Cisco 7200 series routers.
12.2(33)SRE	This command was modified. Support for this command was implemented on the Cisco 7300 Network Processing Engine (NPE) series routers.
Cisco IOS XE Release 3.1S	This command was integrated into Cisco IOS XE Release 3.1S.
15.1(3)T	This command was modified. Support for the Cisco Performance Monitor was added.
12.2(58)SE	This command was modified. Support for the Cisco Performance Monitor was added.
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Usage Guidelines

This command can be used with both Flexible NetFlow and Performance Monitor.

Examples

The following example specifies a TTL of 15:

```
Router(config)# flow exporter FLOW-EXPORTER-1
Router(config-flow-exporter)# ttl 15
```

Related Commands

Command	Description
flow exporter	Creates a flow exporter.

