

# crypto isakmp aggressive-mode disable through crypto mib topn

- crypto isakmp client configuration address-pool local, page 3
- crypto isakmp client configuration browser-proxy, page 4
- crypto isakmp client configuration group, page 6
- crypto isakmp client firewall, page 11
- crypto isakmp default policy, page 13
- crypto isakmp enable, page 16
- crypto isakmp fragmentation, page 18
- crypto isakmp identity, page 19
- crypto isakmp invalid-spi-recovery, page 21
- crypto isakmp keepalive, page 22
- crypto isakmp key, page 25
- crypto isakmp nat keepalive, page 29
- crypto isakmp peer, page 31
- crypto isakmp policy, page 33
- crypto isakmp profile, page 37
- crypto key decrypt rsa, page 40
- crypto key encrypt rsa, page 42
- crypto key export ec, page 44
- crypto key export rsa pem, page 47
- crypto key generate ec keysize, page 50
- crypto key generate rsa, page 52
- crypto key import ec, page 58

I

• crypto key import rsa pem, page 61

- crypto key lock rsa, page 65
- crypto key move rsa, page 67
- crypto key pubkey-chain rsa, page 69
- crypto key storage, page 71
- crypto key unlock rsa, page 73
- crypto key zeroize ec, page 75
- crypto key zeroize pubkey-chain, page 77
- crypto key zeroize rsa, page 78
- crypto keyring, page 80
- crypto logging ezvpn, page 82
- crypto logging ikev2, page 84
- crypto logging session, page 86
- crypto map (global IPsec), page 87
- crypto map (interface IPsec), page 94
- crypto map (Xauth), page 98
- crypto map client configuration address, page 100
- crypto map gdoi fail-close, page 102
- crypto map (isakmp), page 104
- crypto map isakmp-profile, page 106
- crypto map local-address, page 108
- crypto map redundancy replay-interval, page 110
- crypto mib ipsec flowmib history failure size, page 112
- crypto mib ipsec flowmib history tunnel size, page 114
- crypto mib topn, page 116

# crypto isakmp client configuration address-pool local

To configure the IP address local pool to reference Internet Key Exchange (IKE) on your router, use the **crypto isakmp client configuration address-pool local** command in global configuration mode. To restore the default value, use the **no** form of this command.

crypto isakmp client configuration address-pool local pool-name

no crypto isakmp client configuration address-pool local

Syntax Description	pool-name		Specifies the name of a local address pool.
Command Default	IP address local pools of	lo not reference IKE.	
Command Modes			
Commanu Moues	Global configuration		
<b>Command History</b>	Release	Modification	
	12.0(4)XE	This command was in	troduced.
	12.0(7)T	This command was in	tegrated into Cisco IOS release 12.0(7)T.
	12.2(33)SRA	This command was in	tegrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX		borted in the Cisco IOS Release 12.2SX train. Support lease of this train depends on your feature set, platform, e.
Evennlee			1. 4. HZT
Examples	The following example	references IP address local po	ols to IKE on your router, with "ire" as the <i>pool-name</i> :
	crypto isakmp clien	t configuration address-po	ool local ire
<b>Related Commands</b>			[]
nelaleu commanus	Command		Description
	ip local pool		Configures a local pool of IP addresses to be used when a remote peer connects to a point-to-point interface.

# crypto isakmp client configuration browser-proxy

To configure browser-proxy parameters for an Easy VPN remote device and to enter ISAKMP browser proxy configuration mode, use the **crypto isakmp client configuration browser-proxy** command in global configuration mode. To disable the browser-proxy parameters, use the **no** form of this command.

crypto isakmp client configuration browser-proxy browser-proxy-name

no crypto isakmp client configuration browser-proxy browser-proxy-name

Syntax Description	browser-proxy-name		Name of the browser proxy.
Command Default	Browser-proxy parame	ters are not set.	
Command Modes	Global configuration (c	config)	
Command History	Release	Modification	
	12.4(2)T	This command was	introduced.
	12.2(33)SRA	This command was	integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX		pported in the Cisco IOS 12.2SX family of releases. 12.2SX release is dependent on your feature set, platform, are.
Usage Guidelines		roxy server, the proxy IP add	dress and port number are separated with a colon. The of IP addresses.
	After enabling this com	mand, you may specify the	following subcommand:
		es proxy parameters for you about this command and the	r Easy VPN remote device (see the <b>proxy</b> command for e acceptable parameters).
Examples	The following example	shows various browser-prox	xy parameter settings for a browser proxy named "bproxy":
	proxy auto-detect crypto isakmp client proxy none crypto isakmp client proxy server 10.1.2	st 10.2.2.*,www.*org	-proxy bproxy

### **Related Commands**

ſ

Command	Description
proxy	Configures proxy parameters for an Easy VPN remote device.

# crypto isakmp client configuration group

To specify to which group a policy profile will be defined and to enter crypto ISAKMP group configuration mode, use the **crypto isakmp client configuration group** command in global configuration mode. To remove this command and all associated subcommands from your configuration, use the **no** form of this command.

crypto isakmp client configuration group {group-name| default}

no crypto isakmp client configuration group

#### **Syntax Description**

group-name	Group definition that identifies which policy is enforced for users.
default	Policy that is enforced for all users who do not offer a group name that matches a group-name argument. The default keyword can only be configured locally.

### **Command Default** No default behavior or values

**Command Modes** Global configuration (config)

<b>Command History</b>	Release	Modification
	12.2(8)T	This command was introduced.
	12.3(2)T	The <b>access-restrict</b> , <b>firewall are-u-there</b> , <b>group-lock</b> , <b>include-local-lan</b> , and <b>save-password</b> commands were added. These commands are added during Mode Configuration. In addition, this command was modified so that output for this command will show that the preshared key is either encrypted or unencrypted.
	12.3(4)T	The backup-gateway, max-logins, max-users, and pfs commands were added.
	12.2(18)SXD	This command was integrated into Cisco IOS Release 12.2(18)SXD.
	12.4(2)T	The <b>browser-proxy</b> command was added.
	12.4(6)T	The <b>firewall policy</b> command was added.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.4(9)T	The crypto aaa attribute list, dhcp server, and dhcp timeout commands were added.

Release	Modification
12.4(11)T	The <b>dhcp giaddr</b> command was added.

#### **Usage Guidelines**

Use the crypto isakmp client configuration group command to specify group policy information that needs to be defined or changed. You may wish to change the group policy on your router if you decide to connect to the client using a group ID that does not match the *group-name*argument.

After enabling this command, which puts you in Internet Security Association Key Management Protocol (ISAKMP) group configuration mode, you can specify characteristics for the group policy using the following commands:

- access-restrict--Ties a particular Virtual Private Network (VPN) group to a specific interface for access to the Cisco IOS gateway and the services it protects.
- acl -- Configures split tunneling.
- auto-update client --Configures auto upgrade.
- **backup-gateway** --Configures a server to "push down" a list of backup gateways to the client. These gateways are tried in order in the case of a failure of the previous gateway. The gateways may be specified using IP addresses or host names.
- banner --Specifies a mode configuration banner.
- browser-proxy -- Applies a browser-proxy map to a group.
- configuration url --Specifies on a server the URL an Easy VPN remote device must use to get a configuration in a Mode Configuration Exchange.
- configuration version --Specifies on a server the version a Cisco Easy VPN remote device must use to get a particular configuration in a Mode Configuration Exchange.
- crypto aaa attribute list --Defines a AAA attribute list of per-user attributes on a local Easy VPN server.
- dhcp giadd r--Configures an IP address on the Easy VPN server for the Dynamic Host Configuration
  Protocol (DHCP) to use. The DHCP server uses the giaddr keyword to determine the scope for the client
  IP address assignment. If the giaddr keyword is not configured, the Easy VPN server must be configured
  with a loopback interface to communicate with the DHCP server, and the IP address on the loopback
  interface determines the scope for the client IP address assignment.
- dhcp server -- Configures multiple DHCP server entries.
- dhcp timeout -- Controls the wait time before the next DHCP server on the list is tried.
- dns --Specifies the primary and secondary Domain Name Service (DNS) servers for the group.
- · domain -- Specifies group domain membership.
- firewall are-u-there-- Adds the Firewall-Are-U-There attribute to the server group if your PC is running the Black Ice or Zone Alarm personal firewalls.
- firewall policy --Specifies the CPP firewall policy push name for the crypto ISAKMP client configuration group on a local AAA server.

- group-lock--Use if preshared key authentication is used with Internet Key Exchange (IKE). Allows you to enter your extended authentication (Xauth) username. The group delimiter is compared against the group identifier sent during IKE aggressive mode.
- include-local-lan --Configures the Include-Local-LAN attribute to allow a nonsplit-tunneling connection to access the local subnetwork at the same time as the client.
- **key** --Specifies the IKE preshared key when defining group policy information for Mode Configuration push.
- max-logins --Limits the number of simultaneous logins for users in a specific user group.
- max-users --Limits the number of connections to a specific server group.
- netmask --Subnet mask to be used by the client for local connectivity.
- **pfs** --Configures a server to notify the client of the central-site policy regarding whether PFS is required for any IPsec SA. Because the client device does not have a user interface option to enable or disable PFS negotiation, the server will notify the client device of the central site policy via this parameter. The Diffie-Hellman (D-H) group that is proposed for PFS will be the same that was negotiated in Phase 1 of the IKE negotiation.
- pool --Refers to the IP local pool address used to allocate internal IP addresses to clients.
- save-password --Saves your Xauth password locally on your PC.
- split-dns --Specifies a list of domain names that must be tunneled or resolved to the private network.
- wins --Specifies the primary and secondary Windows Internet Naming Service (WINS) servers for the group.

Output for the **crypto isakmp client configuration group** command (using the **key** subcommand) will show that the preshared key is either encrypted or unencrypted. An output example for an unencrypted preshared key would be as follows:

crypto isakmp client configuration group key test An output example for a type 6 encrypted preshared key would be as follows:

crypto isakmp client configuration group

#### key 6 JK\_JHZPeJV\_XFZTKCQFYAAB

### Session Monitoring and Limiting for Easy VPN Clients

It is possible to mimic the functionality provided by some RADIUS servers for limiting the number of connections to a specific server group and also for limiting the number of simultaneous logins for users in that group.

To limit the number of connections to a specific server group, use the **max-users** subcommand. To limit the number of simultaneous logins for users in the server group, use the **max-logins** subcommand.

The following example shows the RADIUS attribute-value (AV) pairs for the maximum users and maximum logins parameters:

```
ipsec:max-users=1000
ipsec:max-logins=1
```

The **max-users** and **max-logins** commands can be enabled together or individually to control the usage of resources by any groups or individuals.

If you use a RADIUS server, such as a CiscoSecure access control server (ACS), it is recommended that you enable this session control on the RADIUS server if the functionality is provided. In this way, usage can be

controlled across a number of servers by one central repository. When enabling this feature on the router itself, only connections to groups on that specific device are monitored, and load-sharing scenarios are not accurately accounted for.

### **Examples**

The following example shows how to define group policy information for Mode Configuration push. In this example, the first group name is "cisco" and the second group name is "default." Thus, the default policy will be enforced for all users who do not offer a group name that matches "cisco."

```
crypto isakmp client configuration group cisco
key cisco
dns 10.2.2.2 10.2.2.3
wins 10.6.6.6
domain cisco.com
pool fred
acl 199
!
crypto isakmp client configuration group default
key cisco
dns 10.2.2.2 10.3.2.3
pool fred
acl 199
```

### **Related Commands**

I

Command	Description
access-restrict	Ties a particular VPN group to a specific interface for access to the Cisco IOS gateway and the services it protects.
acl	Configures split tunneling.
backup-gateway	Configures a server to "push down" a list of backup gateways to the client.
browser-proxy	Applies browser-proxy parameter settings to a group.
crypto isakmp keepalive	Adds the Firewall-Are-U-There attribute to the server group if your PC is running the Black Ice or Zone Alarm personal firewalls.
dns	Specifies the primary and secondary DNS servers.
domain (isakmp-group)	Specifies the DNS domain to which a group belongs.
firewall are-u-there	Adds the Firewall-Are-U-There attribute to the server group if your PC is running the Black Ice or Zone Alarm personal firewalls.
firewall policy	Specifies the CPP firewall policy push name for the crypto ISAKMP client configuration group on a local AAA server.

Command	Description
group-lock	Allows you to enter your Xauth username, including the group name, when preshared key authentication is used with IKE.
include-local-lan	Configures the Include-Local-LAN attribute to allow a nonsplit-tunneling connection to access the local subnetwork at the same time as the client.
key (isakmp-group)	Specifies the IKE preshared key for Group-Policy attribute definition.
max-logins	Limits the number of simultaneous logins for users in a specific server group.
max-users	Limits the number of connections to a specific server group.
pool (isakmp-group)	Defines a local pool address.
save-password	Saves your Xauth password locally on your PC.
set aggressive-mode client-endpoint	Specifies the Tunnel-Client-Endpoint attribute within an ISAKMP peer configuration.

# crypto isakmp client firewall

To define the Central Policy Push (CPP) firewall policypush on a server, use the **crypto isakmp client firewall** command in global configuration mode. To remove the CPP that was configured, use the **no** form of this command.

crypto isakmp client firewall *policy-name* {required| optional} *firewall-type* nocrypto isakmp client firewall *policy-name* {required| optional} *firewall-type* 

### **Syntax Description**

policy-name	Uniquely identifies a policy. A policy name can be associated with an Easy VPN client group configuration on the server (local group configuration) or on the authentication, authorization, and accounting (AAA) server.
required	Policy is mandatory. If the CPP policy is defined as mandatory and is included in the Easy VPN server configuration, the tunnel setup is allowed only if the Cisco VPN Client confirms this policy. If the policy is not confirmed, the tunnel is terminated.
optional	Policy is optional. If the CPP policy is defined as optional and is included in the Easy VPN server configuration, the tunnel setup continues even if the Cisco VPN Client does not confirm the defined policy.
firewall-type	Type of firewall. See the table below for a list of acceptable firewall types.

### **Command Default** CPP is not configured.

**Command Modes** Global configuration (config)

Command History	Release	Modification
	12.4(6)T	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.

**Usage Guidelines** The table below lists firewall types that may be used for the *firewall-type* argument.

1

#### Table 1: Acceptable Firewall Types

Firewall Type		
Cisco-Integrated-firewall (centra	-policy-push)	
Cisco-Security-Agent (check-pre	sence)	
Zonelabs-Zonealarm (both)		
Zonelabs-ZonealarmPro (both)		

### **Examples**

The following example defines the CPP policy name as "hw-client-g-cpp." The "Cisco-Security-Agent" policy type is mandatory. The CPP inbound list is "192" and the outbound list is "sample":

crypto isakmp client firew	all hw-client-g-cpp required Cisco-Security-Agent
policy central-policy-pus	h access-list in 192
policy central-policy-pus	h access-list out sample
policy check-presence	

#### **Related Commands**

Command	Description
policy	Specifies the CPP policy.

# crypto isakmp default policy

To enable default policies for Internet Security Association and Key Management Protocol (ISAKMP) protection suite, use the **crypto isakmp default policy** command in global configuration mode. To disable the default IKE policies, use the **no** form of this command.

# crypto isakmp default policy

no crypto isakmp default policy

- **Syntax Description** This command has no arguments or keywords.
- **Command Default** The default ISAKMP policies are enabled.
- **Command Modes** Global configuration (config)

Release	Modification
12.4(20)T	This command was introduced.
Cisco IOS XE Release 2.4	This command was implemented on the Cisco ASR 1000 series routers.

# Usage Guidelin

**Command History** 

Note

Security threats, as well as the cryptographic technologies to help protect against them, are constantly changing. For more information about the latest Cisco cryptographic recommendations, see the Next Generation Encryption (NGE) white paper.

If you have neither manually configured ISAKMP policies with the **crypto isakmp policy** command nor issued the **no crypto isakmp default policy** command, IPsec will use the default ISAKMP policies to negotiate IKE proposals. There are eight default ISAKMP default policies supported (see the table below). The default ISAKMP policies define the following policy set parameters:

- The priority, 65507-65514, where 65507 is the highest priority and 65514 is the lowest priority.
- The authentication method, Rivest, Shamir, and Adelman (RSA) or preshared keys (PSK).
- The encryption method, Advanced Encryption Standard (AES) or Triple Data Encryption Standard (3DES).
- The hash function, Secure Hash Algorithm (SHA-1) or Message-Digest algorithm 5 (MD5).
- The Diffie-Hellman (DH) group specification DH2 or DH5.
  - DH2 specifies the 768-bit Diffie-Hellman group.

• DH5 specifies the 1536-bit Diffie-Hellman group.

#### **Table 2: Default ISAKMP Policies**

Priority	Authentication	Encryption	Hash	Diffie-Hellman
65507	RSA	AES	SHA	DH5
65508	PSK	AES	SHA	DH5
65509	RSA	AES	MD5	DH5
65510	PSK	AES	MD5	DH5
65511	RSA	3DES	SHA	DH2
65512	PSK	3DES	SHA	DH2
65513	RSA	3DES	MD5	DH2
65514	PSK	3DES	MD5	DH2

### **Examples**

The following example disables the default ISAKMP policies and shows the resulting output of the **show crypto isakmp default policy** command, which is blank:

```
Router#

configure terminal

Router(config)# no crypto isakmp default policy

Router(config)# exit

Router#show crypto isakmp default policy

Router#

!There is no output since the default IKE policies have been disabled.
```

The following example enables the default ISAKMP policies and displays the resulting output of the **show crypto isakmp default policy** command. The default policies are displayed because there are no user configured policies, and the default policies have not been disabled.

```
Router#
configure terminal
Router(config) # crypto isakmp default policy
Router (config) #exit
Router# show crypto isakmp default policy
Default IKE policy
Default protection suite of priority 65507
        encryption algorithm: AES - Advanced Encryption Standard (128 bit key.
        hash algorithm:
                                  Secure Hash Standard
        authentication method: Rivest-Shamir-Adleman Signature
        Diffie-Hellman group:
                                  #5 (1536 bit)
                                  86400 seconds, no volume limit
        lifetime:
Default protection suite of priority 65508
encryption algorithm: AES - Advanced Encryption Standard (128 bit key.
                                  Secure Hash Standard
        hash algorithm:
        authentication method:
                                  Pre-Shared Key
                                  #5 (1536 bit)
        Diffie-Hellman group:
        lifetime:
                                  86400 seconds, no volume limit
Default protection suite of priority 65509
```

	encryption algorithm: hash algorithm: authentication method: Diffie-Hellman group: lifetime:	AES - Advanced Encryption Standard Message Digest 5 Rivest-Shamir-Adleman Signature #5 (1536 bit) 86400 seconds, no volume limit	(128 )	bit k	ey.
Default	protection suite of pri-				
	<pre>encryption algorithm: hash algorithm: authentication method: Diffie-Hellman group: lifetime:</pre>	AES - Advanced Encryption Standard Message Digest 5 Pre-Shared Key #5 (1536 bit) 86400 seconds, no volume limit	(128 ]	bit k	ey.
Default	protection suite of pri-				
	encryption algorithm: hash algorithm:	Three key triple DES Secure Hash Standard			
		Rivest-Shamir-Adleman Signature			
	Diffie-Hellman group:	#2 (1024 bit)			
	lifetime:	86400 seconds, no volume limit			
Default	protection suite of pri-				
	encryption algorithm:	Three key triple DES			
	hash algorithm:	Secure Hash Standard			
	authentication method:				
	Diffie-Hellman group: lifetime:	#2 (1024 bit) 86400 seconds, no volume limit			
Dofault	protection suite of pri-				
Deraurt	encryption algorithm:	Three key triple DES			
	hash algorithm:	Message Digest 5			
	authentication method:				
	Diffie-Hellman group:	#2 (1024 bit)			
	lifetime:	86400 seconds, no volume limit			
Default	protection suite of pri-	ority 65514			
	encryption algorithm:	Three key triple DES			
	hash algorithm:	Message Digest 5			
	authentication method:	-			
	Diffie-Hellman group: lifetime:	#2 (1024 bit)			
	TTTECTWE:	86400 seconds, no volume limit			

### **Related Commands**

ſ

Command	Description
show crypto isakmp default policy	Displays the default ISAKMP policies currently in use.

# crypto isakmp enable

To globally enable Internet Key Exchange (IKE) for your peer router, use the **crypto isakmp enable**command in global configuration mode. To disable IKE for the peer, use the **no** form of this command.

#### crypto isakmp enable

no crypto isakmp enable

- **Syntax Description** This command has no arguments or keywords.
- **Command Default** IKE is enabled.
- **Command Modes** Global configuration

<b>Command History</b>	Release	Modification
	11.3 T	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

# **Usage Guidelines** IKE is enabled by default. IKE does not have to be enabled for individual interfaces, but is enabled globally for all interfaces at the router.

If you do not want IKE to be used for your IPSec implementation, you can disable IKE for all your IP Security peers. If you disable IKE for one peer, you must disable it for all IPSec peers.

If you disable IKE, you will have to make these concessions at the peers:

• You must manually specify all the IPSec security associations (SAs) in the crypto maps at the peers. (Crypto map configuration is described in the chapter "Configuring IPSec Network Security" in the *Cisco IOS Security Configuration Guide*.)

- The IPSec SAs of the peers will never time out for a given IPSec session.
- During IPSec sessions between the peers, the encryption keys will never change.
- Anti-replay services will not be available between the peers.
- Certification authority (CA) support cannot be used.



Effective with Cisco IOS Release 12.3(2)T, a device is prevented from responding to Internet Security Association and Key Management Protocol (ISAKMP) by default unless there is a crypto map applied to an interface or if Easy VPN is configured.

**Examples** 

The following example disables IKE at one peer. (The same command should be issued for all remote peers.)

no crypto isakmp enable

# crypto isakmp fragmentation

To enable fragmentation of large Internet Key Exchange (IKE) packets into a series of smaller IKE packets to avoid fragmentation at the User Datagram Protocol (UDP) layer, use the **crypto isakmp fragmentation** command in global configuration mode. To disable fragmentation, use the **no** form of this command.

crypto isakmp fragmentation

no crypto isakmp fragmentation

- **Syntax Description** This command has no arguments or keywords.
- **Command Default** Fragmentation is not allowed.
- **Command Modes** Global configuration (config)

<b>Command History</b>	Release	Modification
	12.4(15)T7	This command was introduced.

### Usage Guidelin 🔦

Note

Security threats, as well as the cryptographic technologies to help protect against them, are constantly changing. For more information about the latest Cisco cryptographic recommendations, see the Next Generation Encryption (NGE) white paper.

Do not configure IKE fragmentation on a Cisco IOS router with Cisco Easy VPN Client versions 5.01 through 5.03. Versions earlier than version 5.01 and version 5.04 or a later release should be all right.



The **crypto isakmp fragmentation** command is only applicable when the IOS Router is acting as an Easy VPN server and the remote peer is a Cisco IPsec VPN client.

Examples

The following example shows that fragmentation has been enabled:

```
crypto isakmp fragmentation
crypto isakmp policy 1
encryption 3des
crypto isakmp profile ezvpn-SW
match group frag-clients
vrf frags
```

# crypto isakmp identity

To define the ISAKMP identity used by the router when participating in the Internet Key Exchange (IKE) protocol, use the **crypto isakmp identity** command in global configuration mode. To reset the ISAKMP identity to the default value (address), use the **no** form of this command.

crypto isakmp identity {address| dn| hostname}

no crypto isakmp identity

### **Syntax Description**

address	Sets the ISAKMP identity to the IP address of the interface that is used to communicate to the remote peer during IKE negotiations.
dn	Sets the ISAKMP identity to the distinguished name (DN) of the router certificate.
hostname	Sets the ISAKMP identity to the host name concatenated with the domain name (for example, myhost.example.com).

----

### **Command Default** The IP address is used for the ISAKMP identity.

**Command Modes** Global configuration

ReleaseModification11.3TThis command was introduced.12.4(4)TSupport for IPv6 was added.12.2SXThis command is supported in the Cisco IOS Release 12.2SX train. Support<br/>in a specific 12.2SX release of this train depends on your feature set, platform,<br/>and platform hardware.

#### **Usage Guidelines**

**Command History** 

Use this command to specify an ISAKMP identity either by IP address, DN or host name. An ISAKMP identity is set whenever you specify preshared keys or RSA signature authentication.

The **address** keyword is typically used when only one interface (and therefore only one IP address) will be used by the peer for IKE negotiations, and the IP address is known.

The dn keyword should be used if the DN of a router certificate is to be specified and chosen as the ISAKMP identity during IKE processing. The dn keyword is used only for certificate-based authentication.

The **hostname** keyword should be used if more than one interface on the peer might be used for IKE negotiations, or if the interface's IP address is unknown (such as with dynamically assigned IP addresses).

As a general rule, you should set all peers' identities in the same way, either by IP address or by host name.

Examples

The following example uses preshared keys at two peers and sets both their ISAKMP identities to the IP address.

At the local peer (at 10.0.0.1) the ISAKMP identity is set and the preshared key is specified:

```
crypto isakmp identity address
crypto isakmp key sharedkeystring address 192.168.1.33
At the remote peer (at 192.168.1.33) the ISAKMP identity is set and the same preshared key is specified:
```

```
crypto isakmp identity address crypto isakmp key sharedkeystring address 10.0.0.1
```

```
Ŋ
```

Note

In the preceding example if the **crypto isakmp identity** command had not been performed, the ISAKMP identities would have still been set to IP address, the default identity.

The following example uses preshared keys at two peers and sets both their ISAKMP identities to the hostname.

At the local peer the ISAKMP identity is set and the preshared key is specified:

```
crypto isakmp identity hostname
crypto isakmp key sharedkeystring hostname RemoteRouter.example.com
ip host RemoteRouter.example.com 192.168.0.1
At the remote peer the ISAKMP identity is set and the same preshared key is specified:
```

```
crypto isakmp identity hostname
crypto isakmp key sharedkeystring hostname LocalRouter.example.com
ip host LocalRouter.example.com 10.0.0.1 10.0.0.2
```

In the example, hostnames are used for the peers' identities because the local peer has two interfaces that might be used during an IKE negotiation.

In the example the IP addresses are also mapped to the hostnames; this mapping is not necessary if the routers' hostnames are already mapped in DNS.

### **Related Commands**

Command	Description
crypto ipsec security-association lifetime	Specifies the authentication method within an IKE policy.
crypto isakmp key	Configures a preshared authentication key.

# crypto isakmp invalid-spi-recovery

To initiate the Internet Key Exchange (IKE) security association (SA) to notify the receiving IP Security (IPSec) peer that there is an "Invalid SPI" error, use the **crypto isakmp invalid-spi-recovery** command in global configuration mode. To disable the notification process, use the **no** form of this command.

crypto isakmp invalid-spi-recovery

no crypto isakmp invalid-spi-recovery

- **Syntax Description** This command has no arguments or keywords.
- **Command Default** The IKE notification process is not enabled.
- **Command Modes** Global configuration

Release	Modification
12.3(2)T	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA
12.2(33)SXH	This command was integrated into Cisco IOS Release 12.2(33)SXH.

Usage Guidelines This command allows you to configure your router so that when an invalid security parameter index error (shown as "Invalid SPI") occurs, an IKE SA is initiated. The "IKE" module, which serves as a checkpoint in the IPSec session, recognizes the "Invalid SPI" situation. The IKE module then sends an "Invalid Error" message to the packet-receiving peer so that synchronization of the security association databases (SADBs) of the two peers can be attempted. As soon as the SADBs are resynchronized, packets are no longer dropped.

Note

SPI recovery initiates a new IKE SA only for static peers.

∕!∖ Caution

Using this command to initiate an IKE SA to notify an IPSec peer of an "Invalid SPI" error can result in a denial-of-service (DoS) attack.

### **Examples**

**Command H** 

The following example shows that the IKE module process has been initiated to notify the receiving peer that there is an "Invalid SPI" error:

Router (config) # crypto isakmp invalid-spi-recovery

# crypto isakmp keepalive

To allow the gateway to send dead peer detection (DPD) keepalive messages to the peer, use the **crypto isakmp keepalive**command in global configuration mode. To disable keepalives, use the **no** form of this command.

crypto isakmp keepalive seconds [ retry-seconds ] [periodic| on-demand]

no crypto isakmp keepalive seconds [ retry-seconds ] [periodic| on-demand]

Syntax Description	seconds	<ul> <li>When the periodic keyword is used, this argument is the number of seconds between DPD messages; the range is from 10 to 3600 seconds.</li> <li>When the on-demand keyword is used, this argument is the number of seconds during which traffic is not received from the peer before DPD retry messages are sent if there is data (IPSec) traffic to send; the range is from 10 to 3600 seconds.</li> <li>Note If you do not specify a time interval, an error message appears.</li> </ul>
	retry-seconds	(Optional) Number of seconds between DPD retry messages if the DPD retry message is missed by the peer; the range is from 2 to 60 seconds.
		Once 1 DPD message is missed by the peer, the router moves to a more aggressive state and sends the DPD retry message at the faster retry interval, which is the number of seconds between DPD retries if the DPD message is missed by the peer. The default DPD retry message is sent every 2 seconds. Five aggressive DPD retry messages can be missed before the tunnel is marked as down.
		Note To configure DPD with IPsec High Availability (HA), the recommendation is to use a value other than the default (which is 2 seconds). A keepalive timer of 10 seconds with 5 retries seems to work well with HA because of the time that it takes for the router to get into active mode.
	periodic	(Optional) DPD messages are sent at regular intervals.
	on-demand	(Optional) The default behavior. DPD retries are sent on demand.
		Note Because this option is the default, the <b>on-demand</b> keyword does not appear in configuration output.

#### **Command Default** No DPD messages are sent.

**Command Modes** Global configuration (config)

### **Command History**

Release	Modification
12.2(8)T	This command was introduced.
12.3(7)T	The <b>periodic</b> and <b>on-demand</b> keywords were added.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(33)SXH	This command was integrated into Cisco IOS Release 12.2(33)SXH.

#### **Usage Guidelines**

Use the crypto isakmp keepalive command to enable the gateway to send DPD messages to the peer. DPD is a keepalives scheme that allows the router to query the liveliness of its Internet Key Exchange (IKE) peer.

Use the **periodic** keyword to configure your router so that DPD messages are "forced" at regular intervals. This forced approach results in earlier detection of dead peers than with the on-demand approach. If you do not configure the periodic option, the router defaults to the on-demand approach.

Note

When the **crypto isakmp keepalive** command is configured, the Cisco IOS software negotiates the use of Cisco IOS keepalives or DPD, depending on which protocol the peer supports.

Note

Cisco IOS VPN Client connections are not supported if you configure the **crypto isakmp keepalive** command with the **periodic** keyword on a Cisco IOS device.

#### Examples

The following example shows how to configure DPD messages to be sent every 60 seconds and a DPD retry message every 3 seconds between retries if the peer does not respond one time:

#### crypto isakmp keepalive 60 3

The 60 indicates that a keepalive or DPD message is sent every 60 seconds. Once a DPD message is missed by the peer, the router moves to a more aggressive state, sending DPD retry messages every 3 seconds. After 5 aggressive DPD retries, the tunnel is marked as down.

In this example, if the router has sent a DPD message at time x and has not received a response within x + 60, then the DPD retry is sent again at x + 60 and then aggressively at time intervals of x + 63, x + 66, x + 69, and x + 72. At x + 75, a decision is made by the router to bring down the tunnel and DELETE payload is sent to the peer. The DPD retry message is not sent at x + 75 and only DELETE payload is sent. Therefore,

the number of aggressive DPD retry messages that can be missed before marking the tunnel as down is 5 (sent at intervals x + 60, x + 63, x + 66, x + 69, and x + 72).

The following example shows that periodic DPD messages are to be sent at intervals of 10 seconds:

#### crypto isakmp keepalive 10 periodic

The following example shows that the above periodic behavior is being disabled:

#### crypto isakmp keepalive 10 on-demand

The following example shows that DPD has been configured with IPsec HA. The number of seconds between DPD messages is 10, and the number of seconds between DPD retries is 5. DPD messages are to be sent at regular intervals.

```
crypto isakmp keepalive 10 5 periodic
```

### **Related Commands**

Command	Description
acl	Configures split tunneling.

# crypto isakmp key

I

To configure a preshared authentication key, use the **crypto isakmp key command in**global configuration mode. To delete a preshared authentication key, use the **no** form of this command.

**crypto isakmp key** *enc-type-digit keystring* {**address** *peer-address* [*mask* ]| **ipv6** *ipv6-address/ipv6-prefix*| **hostname** *hostname* } **[no-xauth]** 

**no crypto isakmp key** *enc-type-digit keystring* {**address** *peer-address* [*mask*]| **ipv6** *ipv6-address/ipv6-prefix*| **hostname** *hostname*} [**no-xauth**]

Syntax Description	enc-type-digit	<ul> <li>Specifies whether the password to be used is encrypted or unencrypted.</li> <li>0Specifies that an unencrypted password follows.</li> <li>6Specifies that an encrypted password follows.</li> </ul>
	keystring	Specifies the preshared key. Use any combination of alphanumeric or special characters up to 128 bytes. Special characters include the following: !?"#\$%&'()*+,/:;<=>@[\]^_`~. (Type "CTRL-V" before the "?" symbol to avoid invoking help.) This preshared key must be identical at both peers.
	address	Use this keyword if the remote peer Internet Security Association Key Management Protocol (ISAKMP) identity was set with its IP or IPv6 address. The <i>peer-address</i> argument specifies the IP or IPv6 address of the remote peer.
	peer-address	Specifies the IP address of the remote peer.
	mask	(Optional) Specifies the subnet address of the remote peer. (The argument can be used only if the remote peer ISAKMP identity was set with its IP address.)
	ipv6	Specifies that an IPv6 address of a remote peer will be used.
	ipv6-address	IPv6 address of the remote peer. This argument must be in the form documented in RFC 2373 where the address is specified in hexadecimal using 16-bit values between colons.
	ipv6-prefix	IPv6 prefix of the remote peer.

hostname hostname	Fully qualified domain name (FQDN) of the peer. The <b>hostname</b> keyword and <i>hostname</i> argument are not supported by IPv6.
no-xauth	(Optional) Use this keyword if router-to-router IP Security (IPSec) is on the same crypto map as a Virtual Private Network (VPN)-client-to-Cisco-IOS IPSec. This keyword prevents the router from prompting the peer for extended authentication (Xauth) information (username and password).

**Command Default** There is no default preshared authentication key.

## **Command Modes** Global configuration

<b>Command History</b>	Release	Modification
	11.3T	This command was introduced.
	12.1(1)T	The mask argument was added.
	12.2(4)T	The <b>no-xauth</b> keyword was added.
	12.3(2)T	This command was modified so that output shows that the preshared key is either encrypted or unencrypted.
	12.2(18)SXD	This command was integrated into Cisco IOS Release 12.2(18)SXD.
	12.4(4)T	The <b>ipv6</b> keyword and the <i>ipv6-address</i> and <i>ipv6-prefix</i> arguments were added.
	Cisco IOS XE Release 2.1	This command was introduced on Cisco ASR 1000 Series Routers.

### **Usage Guidelines**

You must use this command to configure a key whenever you specify preshared keys in an Internet Key Exchange (IKE) policy; you must enable this command at both peers.

If an IKE policy includes preshared keys as the authentication method, these preshared keys must be configured at both peers--otherwise the policy cannot be used (the policy will not be submitted for matching by the IKE process). The **crypto isakmp key** command is the second task required to configure the preshared keys at the peers. (The first task is accomplished using the **crypto isakmp identity** command.)

Use the address keyword if the remote peer ISAKMP identity was set with its IP address.

With the address keyword, you can also use the mask argument to indicate the remote peer ISAKMP identity will be established using the preshared key only. If the mask argument is used, preshared keys are no longer restricted between two users.

Note	

If you specify mask, you must use a subnet address. (The subnet address 0.0.0.0 is not recommended because it encourages group preshared keys, which allow all peers to have the same group key, thereby reducing the security of your user authentication.)

When using IKE main mode, preshared keys are indexed by IP address only because the identity payload has not yet been received. This means that the hostname keyword in the identity statement is not used to look up a preshared key and will be used only when sending and processing the identity payloads later in the main mode exchange. The identity keyword can be used when preshared keys are used with IKE aggressive mode, and keys may be indexed by identity types other than IP address as the identity payload is received in the first IKE aggressive mode packet.

If **crypto isakmp identity hostname** is configured as identity, the preshared key must be configured with the peer's IP address for the process to work when using IKE in main mode.

Use the **no-xauth** keyword to prevent the router from prompting the peer for Xauth information (username and password). This keyword disables Xauth for static IPSec peers. The **no-xauth** keyword should be enabled when configuring the preshared key for router-to-router IPSec--not VPN-client-to-Cisco-IOS IPSec.

Output for the **crypto isakmp key** command will show that the preshared key is either encrypted or unencrypted. An output example for an unencrypted preshared key would be as follows:

crypto isakmp key test123 address 10.1.0.1 An output example for a type 6 encrypted preshared key would be as follows:

crypto isakmp key 6 RHZE[JACMUI\bcbTdELISAAB address 10.1.0.1

Examples

In the following example, the remote peer "RemoteRouter" specifies an ISAKMP identity by address:

crypto isakmp identity address Now, the preshared key must be specified at each peer.

In the following example, the local peer specifies the preshared key and designates the remote peer by its IP address and a mask:

crypto isakmp key 0 sharedkeystring address 172.21.230.33 255.255.255.255 In the following example for IPv6, the peer specifies the preshared key and designates the remote peer with an IPv6 address:

crypto isakmp key 0 my-preshare-key-0 address ipv6 3ffe:1001::2/128

Commands	Command	Description
	crypto ipsec security-association lifetime	Specifies the authentication method within an IKE policy.
	crypto isakmp identity	Defines the identity the router uses when participating in the IKE protocol.
	ip host	Defines a static host name-to-address mapping in the host cache.

## Related Commands

# crypto isakmp nat keepalive

I

To allow an IPsec node to send Network Address Translation (NAT) keepalive packets, use the **crypto isakmp nat keepalive** command in global configuration mode. To disable NAT keepalive packets, use the **no** form of this command.

crypto isakmp nat keepalive seconds

no crypto isakmp nat keepalive

Syntax Description	seconds		Number of seconds between keepalive packets; the range is from 5 to 3600.
			1
Command Default	NAT keepalive packets are	e not sent.	
Command Modes	Global configuration (con	fig)	
<b>Command History</b>	Release	Modifica	ition
	12.2(13)T	This con	nmand was introduced.
Usage Guidelines	connection between two p IPsec does not send or rec	eers. A NAT keepalive pacleive a packet within a speci	users to keep the dynamic NAT mapping alive during a ket is sent by the peer that is behind the NAT device if fied time period. With CSCul35051, if both peers are NAT keepalive packets according to its configured
	If this command is enabled time.	d, users should ensure that th	e idle value is shorter than the NAT mapping expiration
Note		,	nternet Security Association Key Management ne keepalive for that SA is sent based on the existing
Note	1 5	11	imer to avoid SA rekey collisions. If there are many n the device can experience high CPU usage.

### **Examples**

The following example shows how to enable NAT keepalives to be sent every 20 seconds:

```
crypto isakmp policy 1
authentication pre-share
crypto isakmp key 1234 address 209.165.202.130
crypto isakmp nat keepalive 20
!
crypto ipsec transform-set t2 esp-des esp-sha-hmac
no crypto engine accelerator
!
crypto map test2 10 ipsec-isakmp
set peer 209.165.202.130
set transform-set t2
match address 101
```

# crypto isakmp peer

To enable an IP Security (IPSec) peer for Internet Key Exchange (IKE) querying of authentication, authorization, and accounting (AAA) for tunnel attributes in aggressive mode, use the **crypto isakmp peer** command in global configuration mode. To disable this functionality, use the **no** form of this command.

crypto isakmp peer {address {ipv4-address| ipv6 ipv6-address}| hostname fqdn-hostname} no crypto isakmp peer {address {ipv4-address| ipv6 ipv6-address}| hostname fqdn-hostname}

# **Syntax Description**

address ip-address	Address of the peer router.
ipv4-address	IPv4 address of the peer router.
ipv6 ipv6-address	IPv6 address of the peer router.
hostname	Hostname of the peer router.
fqdn-hostname	Fully qualified domain name (FQDN) of the peer router.

# Command Default None

# **Command Modes** Global configuration

<b>Command History</b>	Release	Modification
	12.2(8)T	This command was introduced.
	12.2(15)T	The <b>vrf</b> keyword and <i>fvrf-name</i> argument were added.
	12.2(18)SXD	This command was integrated into Cisco IOS Release 12.2(18)SXD.
	12.4(4)T	The <b>ipv6</b> keyword and <i>ipv6-address</i> argument were added.
	Cisco IOS XE Release 2.1	This command was introduced on Cisco ASR 1000 Series Routers.

# **Usage Guidelines**

I

After enabling this command, you can use the **set aggressive-mode client-endpoint** and **set aggressive-mode password** commands to specify RADIUS tunnel attributes in the Internet Security Association and Key Management Protocol (ISAKMP) peer policy for IPSec peers.

Instead of keeping your preshared keys on the hub router, you can scale your preshared keys by storing and retrieving them from an AAA server. The preshared keys are stored in the AAA server as Internet Engineering Task Force (IETF) RADIUS tunnel attributes and are retrieved when a user tries to "speak" to the hub router. The hub router retrieves the preshared key from the AAA server and the spokes (the users) initiate aggressive mode to the hub by using the preshared key that is specified in the ISAKMP peer policy as a RADIUS tunnel attribute.

#### Examples

The following example shows how to initiate aggressive mode using RADIUS tunnel attributes:

```
crypto isakmp peer ip-address 209.165.200.230 vrf vpn1
set aggressive-mode client-endpoint user-fqdn user@cisco.com
set aggressive-mode password cisco123
```

### **Related Commands**

Command	Description
crypto map isakmp authorization list	Enables IKE querying of AAA for tunnel attributes in aggressive mode.
set aggressive-mode client-endpoint	Specifies the Tunnel-Client-Endpoint attribute within an ISAKMP peer configuration.
set aggressive-mode password	Specifies the Tunnel-Password attribute within an ISAKMP peer configuration.

# crypto isakmp policy

To define an Internet Key Exchange (IKE) policy, use the **crypto isakmp policy** command in global configuration mode. To delete an IKE policy, use the **no** form of this command.

crypto isakmp policy priority

no crypto isakmp policy priority

### Syntax Description

*priority priority priority* 

**Command Default** Default IKE policies are in use.

**Command Modes** Global configuration (config)

<b>Command History</b>	Release	Modification	
	11.3T	This command was introduced.	
	12.4(4)T	Support for IPv6 was added.	
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.	
	12.4(20)T	The command default was modified. Support for eight default IKE (ISAKMP) policies was added.	
	Cisco IOS XE Release 2.4	This command was implemented on the Cisco ASR 1000 series routers.	

# Usage Guidelin

Note

Security threats, as well as the cryptographic technologies to help protect against them, are constantly changing. For more information about the latest Cisco cryptographic recommendations, see the Next Generation Encryption (NGE) white paper.

IKE policies define a set of parameters to be used during the IKE negotiation. Use this command to specify the parameters to be used during an IKE negotiation. (These parameters are used to create the IKE security association [SA].)

This command invokes the Internet Security Association Key Management Protocol (ISAKMP) policy configuration (config-isakmp) command mode. While in the ISAKMP policy configuration command mode, some of the commands for which you can specify parameters are as follows:

- authentication ; default = RSA signatures
- encryption (IKE policy) ; default = 56-bit DES-CBC
- group (IKE policy) ; default = 768-bit Diffie-Hellman
- hash (IKE policy) ; default = SHA-1
- lifetime (IKE policy); def ault = 86,400 seconds (one day)

If you do not specify any given parameter, the default value will be used for that parameter.

To exit the config-isakmp command mode, type exit.

You can configure multiple IKE policies on each peer participating in IPsec. When the IKE negotiation begins, it tries to find a common policy configured on both peers, starting with the highest priority policies as specified on the remote peer.

**Examples** The following example shows how to manually configure two policies for the peer:

```
crypto isakmp policy 15
hash md5
authentication rsa-sig
group 2
lifetime 5000
crypto isakmp policy 20
authentication pre-share
lifetime 10000
The above configuration results in the following policies:
```

```
Router# show crypto isakmp policy
Protection suite priority 15
 encryption algorithm: DES - Data Encryption Standard (56 bit keys)
hash algorithm: Message Digest 5
 authentication method: Rivest-Shamir-Adleman Signature
Diffie-Hellman Group: #2 (1024 bit)
lifetime: 5000 seconds, no volume limit
Protection suite priority 20
 encryption algorithm: DES -
                             Data Encryption Standard (56 bit keys)
 hash algorithm: Secure Hash Standard
authentication method: preshared Key
 Diffie-Hellman Group: #1 (768 bit)
lifetime: 10000 seconds, no volume limit
Default protection suite
 encryption algorithm: DES - Data Encryption Standard (56 bit keys)
hash algorithm: Secure Hash Standard
 authentication method: Rivest-Shamir-Adleman Signature
 Diffie-Hellman Group: #1 (768 bit)
 lifetime: 86400 seconds, no volume limit
```

The following sample output from the **show crypto isakmp policy** command displays the default IKE policies when the manually configured IKE policies with priorities 15 and 20 have been removed.

```
Router(config)# no crypto isakmp policy 15
Router(config)# no crypto isakmp policy 20
Router(config)# exit
```

R1# show crypto isakmp policy Default IKE policy Protection suite of priority 65507 encryption algorithm: AES - Advanced Encryption Standard (128 bit key. hash algorithm: Secure Hash Standard authentication method: Rivest-Shamir-Adleman Signature #5 (1536 bit) Diffie-Hellman group: 86400 seconds, no volume limit lifetime: Protection suite of priority 65508 encryption algorithm: AES - Advanced Encryption Standard (128 bit key. hash algorithm: Secure Hash Standard authentication method: Pre-Shared Key Diffie-Hellman group: #5 (1536 bit.) 86400 seconds, no volume limit lifetime: Protection suite of priority 65509 encryption algorithm: AES - Advanced Encryption Standard (128 bit key. hash algorithm: Message Digest 5 Rivest-Shamir-Adleman Signature authentication method: Diffie-Hellman group: #5 (1536 bit) lifetime: 86400 seconds, no volume limit Protection suite of priority 65510 encryption algorithm: AES - Advanced Encryption Standard (128 bit key. hash algorithm: Message Digest 5 authentication method: Pre-Shared Key Diffie-Hellman group: #5 (1536 bit) lifetime: 86400 seconds, no volume limit Protection suite of priority 65511 encryption algorithm: Three key triple DES hash algorithm: Secure Hash Standard authentication method: Rivest-Shamir-Adleman Signature Diffie-Hellman group: #2 (1024 bit) lifetime: 86400 seconds, no volume limit Protection suite of priority 65512 encryption algorithm: Three key triple DES hash algorithm: Secure Hash Standard authentication method: Pre-Shared Key #2 (1024 bit) Diffie-Hellman group: lifetime: 86400 seconds, no volume limit Protection suite of priority 65513 encryption algorithm: Three key triple DES hash algorithm: Message Digest 5 Rivest-Shamir-Adleman Signature authentication method: Diffie-Hellman group: #2 (1024 bit) lifetime: 86400 seconds, no volume limit Protection suite of priority 65514 Three key triple DES encryption algorithm: hash algorithm: Message Digest 5 authentication method: Pre-Shared Key #2 (1024 bit) Diffie-Hellman group: lifetime: 86400 seconds, no volume limit

#### **Related Commands**

Command	Description
encryption (IKE policy)	Specifies the encryption algorithm within an IKE policy.
group (IKE policy)	Specifies the Diffie-Hellman group identifier within an IKE policy.
hash (IKE policy)	Specifies the hash algorithm within an IKE policy.
lifetime (IKE policy)	Specifies the lifetime of an IKE SA.
show crypto isakmp default policy	Displays the default IKE (ISAKMP) policies currently in use.

Command	Description
show crypto isakmp policy	Displays the parameters for each IKE policy.
# crypto isakmp profile

To define an Internet Security Association and Key Management Protocol (ISAKMP) profile and to audit IP security (IPsec) user sessions, use the **crypto isakmp profile**command in global configuration mode. To delete a crypto ISAKMP profile, use the no form of this command.

crypto isakmp profile profile-name[accounting aaa-list] **no crypto isakmp profile** *profile-name*[**accounting** *aaa-list*]

#### **Syntax Description**

profile-name	Name of the user profile. To associate a user profile with the RADIUS server, the user profile name must be identified.
accounting aaa-list	(Optional) Name of a client accounting list.

**Command Default** No profile exists if the command is not used.

#### **Command Modes** Global configuration

### **Command History**

Release	Modification
12.2(15)T	This command was introduced.
12.2(18)SXD	This command was integrated into Cisco IOS Release 12.2(18)SXD.
12.4(2)T	Support for dynamic virtual tunnel interfaces was added.
12.4(4)T	Support for IPv6 was added.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
Cisco IOS XE Release 2.1	This command was introduced on Cisco ASR 1000 Series Routers.

#### **Usage Guidelines Defining an ISAKMP Profile**

An ISAKMP profile can be viewed as a repository of Phase 1 and Phase 1.5 commands for a set of peers. The Phase 1 configuration includes commands to configure such things as keepalive, identity matching, and the authorization list. The Phase 1.5 configuration includes commands to configure such things as extended authentication (Xauth) and mode configuration.

The peers are mapped to an ISAKMP profile when their identities are matched (as given in the identification [ID] payload of the Internet Key Exchange [IKE]) against the identities defined in the ISAKMP profile. To

uniquely map to an ISAKMP profile, no two ISAKMP profiles should match the same identity. If the peer identity is matched in two ISAKMP profiles, the configuration is invalid. Also, there must be at least one **match identity** command defined in the ISAKMP profile for it to be complete.

After enabling this command and entering ISAKMP profile configuration mode, you can configure the following commands:

- accounting -- Enables authentication, authorization, and accounting (AAA) accounting.
- ca trust-point -- Specifies certificate authorities.
- client --Specifies client configuration settings.
- default -- Lists subcommands for the crypto isakmp profile command.
- description -- Specifies a description of this profile.
- initiate mode --Initiates a mode.
- · isakmp authorization -- ISAKMP authorization parameters.
- keepalive -- Sets a keepalive interval.
- keyring --Specifies a keyring.
- · local-address -- Specifies the interface to use as the local address of this ISAKMP profile.
- match -- Matches the values of the peer.
- qos-group -- Applies a quality of service (QoS) policy class map for this profile.
- self-identity -- Specifies the identity.
- virtual-template --Specifies the virtual template for the dynamic interface.
- vrf --Specifies the Virtual Private Network routing and forwarding (VRF) instance to which the profile is related.

#### **Auditing IPSec User Sessions**

Use this command to audit multiple user sessions that are terminating on the IPSec gateway.



The **crypto isakmp profile** command and the **crypto map (global IPSec)**command are mutually exclusive. If a profile is present (the **crypto isakmp profile** command has been used), with no accounting configured but with the global command present (the **crypto isakmp profile** command without the **accounting** keyword), accounting will occur using the attributes in the global command.

#### **Dynamic Virtual Tunnel Interfaces**

Support for dynamic virtual tunnel interfaces allows for the virtual profile to be mapped into a specified virtual template.

#### **Examples**

**Examples** 

The following example shows how to define an ISAKMP profile and match the peer identities:

```
crypto isakmp profile vpnprofile
match identity address 10.76.11.53
```

#### **Examples**

The following accounting example shows that an ISAKMP profile is configured:

```
aaa new-model
1
1
aaa authentication login cisco-client group radius
aaa authorization network cisco-client group radius
aaa accounting network acc start-stop broadcast group radius
aaa session-id common
1
crypto isakmp profile cisco
vrf cisco
match identity group cclient
client authentication list cisco-client
 isakmp authorization list cisco-client
client configuration address respond
accounting acc
1
crypto dynamic-map dynamic 1
set transform-set aswan
 set isakmp-profile cisco
reverse-route
!
1
radius-server host 172.16.1.4 auth-port 1645 acct-port 1646
radius-server key nsite
```

### **Related Commands**

Command	Description
crypto ma p (global IPsec)	Enters crypto map configuration mode and creates or modifies a crypto map entry, creates a crypto profile that provides a template for configuration of dynamically created crypto maps, or configures a client accounting list.
debug crypto isakmp	Displays messages about IKE events.
match identity	Matches an identity from a peer in an ISAKMP profile.
tunnel protection	Associates a tunnel interface with an IP Security (IPsec) profile.
virtual template	Specifies which virtual template to be used to clone virtual access interfaces.

# crypto key decrypt rsa

To delete the encrypted RSA key and leave only the unencrypted key on the running router, use the **crypto key decrypt rsa** command in global configuration mode.

crypto key decrypt [write] rsa [name key-name] passphrase passphrase

Syntax Description	write	(Optional) Clear text (unencrypted) key is immediately written to NvRAM.
		If the <b>write</b> keyword is not issued, the configuration must be manually written to NvRAM; otherwise, the key will remain encrypted the next time the router is reloaded.
	name key-name	(Optional) Name of the RSA key pair that is to be decrypted.
	passphrase passphrase	Passphrase that is used to decrypt the RSA key. The passphrase must match the passphrase that was specified via the <b>crypto key encrypt rsa</b> command.

# **Command Default** The private key running on the router is encrypted.

**Command Modes** Global configuration

 Command History
 Release
 Modification

 12.3(7)T
 This command was introduced.

 12.2(18)SXE
 This command was integrated into Cisco IOS Release 12.2(18)SXE.

**Usage Guidelines** Use the **crypto key decrypt rsa** command to store the decrypted private key in NvRAM the next time NvRAM is written (which is immediately if the **write** keyword is issed).

### **Examples** The following example shows how to decrypt the RSA key "pki1-72a.cisco.com":

Router(config)# crypto key decrypt write rsa name pki1-72a.cisco.com passphrase cisco1234

# **Related Commands**

I

ſ

Command	Description
crypto key encrypt rsa	Encrypts the RSA private key.
show crypto key mypubkey rsa	Displays the RSA public keys of your router.

# crypto key encrypt rsa

To encrypt the RSA private key, use the crypto key encrypt rsacommand in global configuration mode.

crypto key encrypt [write] rsa [name key-name] passphrase passphrase

5	<b>/ntax</b>	1100	rri	ntic	n
0	mun	003		μιι	, 11

write	(Optional) Router configuration is immediately written to NVRAM.
	If the <b>write</b> keyword is not issued, the configuration must be manually written to NvRAM; otherwise, the encrypted key will be lost next time the router is reloaded.
name key-name	(Optional) Name of the RSA key pair that is to be encrypted.
	If a key name is not specified, the default key name, <i>routername.domainname</i> , i s used.
passphrase passphrase	Passphrase that is used to encrypt the RSA key. To access the RSA key pair, the passphrase must be specified.

# **Command Default** RSA keys are not encrypted.

### **Command Modes** Global configuration

Command History	Release	Modification
	12.3(7)T	This command was introduced.
	12.2(18)SXE	This command was integrated into Cisco IOS Release 12.2(18)SXE.

**Usage Guidelines** The private key is encrypted (protected) via the specified passphrase. After the key is protected, it may continue to be used by the router; that is Internet Key Exchange (IKE) tunnels and encrypted key export attempts should continue to work because the key remains "unlocked."

To lock the key, which can be used to disable the router, issue the **crypto key lock rsa** privileged EXEC command. (When you lock the encrypted key, all functions which use the locked key are disabled.)

I

Examples	The following example shows how to encrypt the RSA key "pki1-72a.cisco.com." Thereafter, the <b>show crypto key mypubkey rsa</b> command is issued to verify that the RSA key is encrypted and unlocked.			
	Router(config)# crypto key encrypt rsa name pki1-72a.cisco.com passphrase cisco1234 Router(config)# exit Router# show crypto key mypubkey rsa % Key pair was generated at:00:15:32 GMT Jun 25 2003			
	Key name:pki1-72a.cisco.com			
	Usage:General Purpose Key			
	*** The key is protected and UNLOCKED. ***			
	Key is not exportable.			
	Key Data:			
	305C300D 06092A86 4886F70D 01010105 00034B00 30480241 00E0CC9A 1D23B52C			
	CD00910C ABD392AE BA6D0E3F FC47A0EF 8AFEE340 0EC1E62B D40E7DCC			
	23C4D09E			
	03018B98 E0C07B42 3CFD1A32 2A3A13C0 1FF919C5 8DE9565F 1F020301 0001			
	% Key pair was generated at:00:15:33 GMT Jun 25 2003			
	Key name:pki1-72a.cisco.com.server			
	Usage:Encryption Key			
	Key is exportable.			
	Key Data:			
	307C300D 06092A86 4886F70D 01010105 00036B00 30680261 00D3491E 2A21D383			
	854D7DA8 58AFBDAC 4E11A7DD E6C40AC6 66473A9F 0C845120 7C0C6EC8 1FFF5757			
	3A41CE04 FDCB40A4 B9C68B4F BC7D624B 470339A3 DE739D3E F7DDB549 91CD4DA4			
	DF190D26 7033958C 8A61787B D40D28B8 29BCD0ED 4E6275C0 6D020301 0001			
	Router#			

# **Related Commands**

I

Command	Description
crypto key decrypt rsa	Deletes the encrypted RSA key and leaves only the unencrypted key on the running router.
crypto key lock rsa	Locks the RSA private key in a router.
show crypto key mypubkey rsa	Displays the RSA public keys of your router.

# crypto key export ec

To export an Elliptic Curve (EC) key pair, use the **crypto key export ec** command in global configuration mode.

crypto key export ec key-label pem {terminal| url url} {3des| des} passphrase

#### **Syntax Description**

key-label	Name of the EC key pair to export.
	The <i>key-label</i> argument must match the key pair name that was specified through the <b>crypto key generate ec keysize</b> command.
pem	Exports to a PEM-formatted file.
terminal	Displays the EC key pair in PEM format on the console terminal.
url url	Specifices the URL of the file system where the device should export the EC key pair.
3des	Exports the EC key pair using the Triple Data Encryption Standard (3DES) encryption algorithm.
des	Exports the EC key pair using the DES encryption algorithm.
passphrase	Specifies the passphrase to be used to encrypt the PEM file for import.
	<b>Note</b> The passphrase can be any phrase that is at least eight characters in length. It can include spaces and punctuation, excluding the question mark (?), which has special meaning to the parser.

**Command Default** EC key pairs are not exported.

**Command Modes** Global configuration (config)

### **Command History**

ry	Release	Modification
	15.2(4)M	This command was introduced.

#### **Usage Guidelines**

IPsec and public key infrastructure (PKI) both support the ability to generate, export, and import EC (ECDSA-256 and ECDSA-384) key pairs. The **crypto key export ec** command lets you export EC key pairs to PEM-formatted files. Then, you can import the PEM files back into a Cisco IOS router or other PKI applications.

```
Note
```

Before you export an EC key pair to a PEM file, ensure that the EC key pair is exportable. To generate an exportable EC key pair, use the **crypto key generate ec keysize** command and specify the **exportable** keyword.

#### **Examples**

The following example shows how to generate, export, import, and verify the status of an EC key pair named Device 1 Key:

```
! Generate the key pair
Device (config) # crypto key generate ec keysize 256 exportable label Device_1_Key
The name for the keys will be: Device 1 Key
 EC key pair created successfully
! Archive the key pair to a remote location, and use a good password.
Device (config) # crypto key export ec Device_1_Key pem url nvram: 3des mypassword
% Key name: Device 1 Key
   Usage: Signature Key
Exporting public key.
Destination filename [Device 1 Key-sign.pub]?
Writing file to nvram: Device 1 Key-sign.pub
Exporting private key...
Destination filename [Device_1_Key-sign.prv]?
Writing file to nvram: Device 1 Key-sign.prv
 Import the key as a different name.
Device (config) # crypto key import ec Device_1_Key url nvram:Device_1_Key mypassword
% Importing public Signature key or certificate PEM file...
Source filename [Device 1 Key-sign.pub]?
Reading file from nvram: Device 1 Key-sign.pub
% Importing private Signature key PEM file...
Source filename [Device 1 Key-sign.prv]?
Reading file from nvram: Device 1 Key-sign.prv
% Key pair import succeeded.
! After the key has been imported, it is no longer exportable.
! Verify the status of the key.
Device# show crypto key mypubkey ec
% Key pair was generated at: 17:26:53 PST Jun 7 2012
Key name: Device_1_Key
Key type: EC KEYS
Storage Device: private-config
 Usage: Signature Key
 Key is not exportable.
 Key Data:
  30593013 06072A86 48CE3D02 0106082A 8648CE3D 03010703 420004A3 E483C98C
  BABE4CAD 9822F5F1 06FDFD4B F70D0103 03C266B6 DA368DB9 AB01C5AB 7333F5B9
```

3478E0FE 6CA67598 FB828F47 A92AFE70 93EFE828 2620A611 699E52

1

Command	Description
crypto key generate ec keysize	Generates EC key pairs.
crypto key import ec	Imports EC keys in PEM-formatted files.
crypto key zeroize ec	Deletes EC keys from a device.

# crypto key export rsa pem

To export Rivest, Shamir, and Adelman (RSA) keys in privacy-enhanced mail (PEM)-formatted files, use the **crypto key export rsa pem**command in global configuration mode.

crypto key export rsa key-label pem {terminal| url url} {3des| des} passphrase

**Syntax Description** 

1 1 1 1		
rsa key-label	Name of the RSA key pair that will be exported.	
	The key-label argument must match the key pair name	
	that was specified through the crypto key generate	
	rsa command.	
terminal	RSA key pair will be displayed in PEM format on the	
	console terminal.	
url url	URL of the file system where the router should export	
	the RSA key pair.	
3des	Export the RSA key pair using the Triple Data	
	Encryption Standard (3DES) encryption algorithm.	
des	Export the RSA key pair using the DES encryption	
	algorithm.	
passphrase	Passphrase that is used to encrypt the PEM file for	
	import.	
	<b>Note</b> The passphrase can be any phrase that is at	
	least eight characters in length; it can include	
	spaces and punctuation, excluding the	
	question mark (?), which has special	
	meaning to the Cisco IOS parser.	

### **Command Default** No default behavior or values

**Command Modes** Global configuration

I

Command History Release		Modification
	12.3(4)T	This command was introduced.
	15.2(2)SA2	This command was implemented on the Cisco ME 2600X Series Ethernet Access Switches.

# Usage Guidelin

Note

Security threats, as well as the cryptographic technologies to help protect against them, are constantly changing. For more information about the latest Cisco cryptographic recommendations, see the Next Generation Encryption (NGE) white paper.

The **crypto key export rsa pem** command allows RSA key pairs to be exported in PEM-formatted files. The PEM files can then be imported back into a Cisco IOS router or other public key infrastructure (PKI) applications.

Note

Before an RSA key pair is exported in a PEM file, ensure that the RSA key pair is exportable. To generate an exportable RSA key pair, issue the **crypto key generate rsa** command and specify the **exportable** keyword.

#### **Examples**

The following example shows how to generate, export, bring the key back (import), and verify the status of the RSA key pair "mycs":

```
! Generate the key pair
Router (config) # crypto key generate rsa general-purpose label mycs exportable
The name for the keys will be: mycs
Choose the size of the key modulus in the range of 360 to 2048 for your General Purpose
Keys. Choosing a key modulus greater than 512 may take a few minutes.
How many bits in the modulus [512]: 1024
% Generating 1024 bit RSA keys ...[OK]
! Archive the key pair to a remote location, and use a good password.
Router (config) # crypto key export rsa mycs pem url nvram: 3des PASSWORD
% Key name: mycs
Usage: General Purpose Key
Exporting public key...
Destination filename [mycs.pub]?
Writing file to nvram:mycs.pub
Exporting private key...
Destination filename [mycs.prv]?
Writing file to nvram:mycs.prv
! Import the key as a different name.
Router(config) # crypto key import rsa mycs2 pem url nvram:mycs PASSWORD
% Importing public key or certificate PEM file...
Source filename [mycs.pub]?
Reading file from nvram:mycs.pub
% Importing private key PEM file...
Source filename [mycs.prv]?
Reading file from nvram:mycs.prv% Key pair import succeeded.
! After the key has been imported, it is no longer exportable.
! Verify the status of the key.
Router# show crypto key mypubkey rsa
% Key pair was generated at: 18:04:56 GMT Jun 6 2003
Key name: mycs
Usage: General Purpose Key
```

Key is exportable. Key Data: 30819F30 0D06092A 864886F7 0D010101 05000381 8D003081 89028181 00E65253 9C30C12E 295AB73F B1DF9FAD 86F88192 7D4FA4D2 8BA7FB49 9045BAB9 373A31CB A6B1B8F4 329F2E7E 8A50997E AADBCFAA 23C29E19 C45F4F05 DBB2FA51 4B7E9F79 A1095115 759D6BC3 5DFB5D7F BCF655BF 6317DB12 A8287795 7D8DC6A3 D31B2486 C9C96D2C 2F70B50D 3B4CDDAE F661041A 445AE11D 002EEF08 F2A627A0 5B020301 0001 % Key pair was generated at: 18:17:25 GMT Jun 6 2003 Key name: mycs2 Usage: General Purpose Key Key is not exportable. Key Data: 30819F30 0D06092A 864886F7 0D010101 05000381 8D003081 89028181 00E65253 9C30C12E 295AB73F B1DF9FAD 86F88192 7D4FA4D2 8BA7FB49 9045BAB9 373A31CB A6B1B8F4 329F2E7E 8A50997E AADBCFAA 23C29E19 C45F4F05 DBB2FA51 4B7E9F79 A1095115 759D6BC3 5DFB5D7F BCF655BF 6317DB12 A8287795 7D8DC6A3 D31B2486 C9C96D2C 2F70B50D 3B4CDDAE F661041A 445AE11D 002EEF08 F2A627A0 5B020301 0001

#### **Related Commands**

I

Command	Description
crypto key generate rsa	Generates RSA key pairs.
crypto key import rsa pem	Imports RSA keys in PEM-formatted files.

# crypto key generate ec keysize

To generate an Elliptic Curve (EC) key pair, use the **crypto key generate ec keysize** command in global configuration mode.

crypto key generate ec keysize {256| 384} [exportable] [label key-label]

256	Specifies a 256-bit key size.
384	Specifies a 384-bit key size.
exportable	(Optional) Specifies that the key pair can be exported to another Cisco device, such as a router.
label key-label	(Optional) Specifies the name to be used for the EC key pair when it is being exported.
	If a key label is not specified, the fully qualified domain name (FQDN) of the router is used.
	384 exportable

- **Command Default** The EC key pairs do not exist.
- **Command Modes** Global configuration (config)

<b>Command History</b>	Release	Modification
	15.1(2)T	This command was introduced.
	15.2(4)M	This command was modified. The <b>exportable</b> keyword was added.

Use this command to generate EC key pairs for your Cisco device (such as a router). IPsec and public key infrastructure (PKI) both support the ability to generate, export, and import EC (ECDSA-256 and ECDSA-384) key pairs.

### **Examples** The following example generates a 256-bit EC key pair with a label named Device\_1\_Key.

Device (config) # crypto key generate ec keysize 256 label Device\_1\_Key The following example generates an exportable 384-bit EC key pair with a label named Device\_2\_Key.

Device (config) # crypto key generate ec keysize 384 exportable label Device\_2\_Key

### **Related Commands**

I

I

Command	Description
сору	Copies any file from a source to a destination.
crypto key export ec	Exports EC key pairs.
crypto key export rsa pem	Exports RSA key pairs in PEM-formatted files.
crypto key generate rsa	Generates RSA keys.
crypto key import ec	Imports EC key pairs.
crypto key import rsa pem	Exports RSA key pairs in PEM-formatted files.
crypto key storage	Sets the default storage location for RSA key pairs.
crypto key zeroize ec	Deletes EC keys from a device.
debug crypto engine	Displays debug messages about crypto engines.
hostname	Specifies or modifies the hostname for the network server.
ip domain-name	Defines a default domain name to complete unqualified hostnames (names without a dotted-decimal domain name).
show crypto key mypubkey ec	Displays the EC public keys of the device.
show crypto key mypubkey rsa	Displays the RSA public keys of the device.
show crypto pki certificates	Displays information about your PKI certificate, certification authority, and any registration authority certificates.

# crypto key generate rsa

To generate Rivest, Shamir, and Adelman (RSA) key pairs, use the **crypto key generate rsa** commandinglobal configuration mode.

crypto key generate rsa [general-keys| usage-keys| signature| encryption] [label key-label] [exportable] [modulus modulus-size] [storage devicename :] [redundancy] [on devicename :]

#### **Syntax Description**

general-keys	(Optional) Specifies that a general-purpose key pair will be generated, which is the default.		
usage-keys	(Optional) Specifies that two RSA special-usage key pairs, one encryption pair and one signature pair, will be generated.		
signature	(Optional) Specifies that the RSA public key generated will be a signature special usage key.		
encryption	(Optional) Specifies that the RSA public key generated will be an encryption special usage key.		
label key-label	(Optional) Specifies the name that is used for an RSA key pair when they are being exported.		
	If a key label is not specified, the fully qualified domain name (FQDN) of the router is used.		
exportable	(Optional) Specifies that the RSA key pair can be exported to another Cisco device, such as a router.		
modulus modulus-size	(Optional) Specifies the IP size of the key modulus.		
	By default, the modulus of a certification authority (CA) key is 1024 bits. The recommended modulus for a CA key is 2048 bits. The range of a CA key modulus is from 350 to 4096 bits.		
	<b>Note</b> Effective with Cisco IOS XE Release 2.4 and Cisco IOS Release 15.1(1)T, the maximum key size was expanded to 4096 bits for private key operations. The maximum for private key operations prior to these releases was 2048 bits.		
storage devicename :	(Optional) Specifies the key storage location. The name of the storage device is followed by a colon (:).		
redundancy	(Optional) Specifies that the key should be synchronized to the standby CA.		

on devicename :	(Optional) Specifies that the RSA key pair will be created on the specified device, including a Universal Serial Bus (USB) token, local disk, or NVRAM. The name of the device is followed by a colon (:). Keys created on a USB token must be 2048 bits or less.
-----------------	--

**Command Default** RSA key pairs do not exist.

**Command Modes** Global configuration

**Command History** 

I

Release	Modification	
11.3	This command was introduced.	
12.2(8)T	The key-label argumentwas added.	
12.2(15)T	The <b>exportable</b> keyword was added.	
12.2(18)SXD	This command was integrated into Cisco IOS Release 12.2(18)SXD.	
12.4(4)T	The <b>storage</b> keyword and <i>devicename</i> : argument were added.	
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.	
12.4(11)T	The <b>storage</b> keyword and <i>devicename</i> : argument were implemented on the Cisco 7200VXR NPE-G2 platform.	
	The <b>signature</b> , <b>encryption</b> and <b>on</b> keywords and <i>devicename</i> : argument were added.	
12.4(24)T	Support for IPv6 Secure Neighbor Discovery (SeND) was added.	
XE 2.4	The maximum RSA key size was expanded from 2048 to 4096 bits for private key operations.	
15.0(1)M	This command was modified. The <b>redundancy</b> keyword was introduced.	
15.1(1)T	This command was modified. The range value for the <b>modulus</b> keyword value is extended from 360 to 2048 bits to 360 to 4096 bits.	
15.2(2)SA2	This command was implemented on the Cisco ME 2600X Series Ethernet Access Switches.	

Note

# Usage Guidelin

Security threats, as well as the cryptographic technologies to help protect against them, are constantly changing. For more information about the latest Cisco cryptographic recommendations, see the Next Generation Encryption (NGE) white paper.

Use this command to generate RSA key pairs for your Cisco device (such as a router).

RSA keys are generated in pairs--one public RSA key and one private RSA key.

If your router already has RSA keys when you issue this command, you will be warned and prompted to replace the existing keys with new keys.



Before issuing this command, ensure that your router has a hostname and IP domain name configured (with the **hostname** and **ip domain-name** commands). You will be unable to complete the **crypto key generate rsa** command without a hostname and IP domain name. (This situation is not true when you generate only a named key pair.)



Secure Shell (SSH) may generate an additional RSA key pair if you generate a key pair on a router having no RSA keys. The additional key pair is used only by SSH and will have a name such as {*router\_FQDN*}.server. For example, if a router name is "router1.cisco.com," the key name is "router1.cisco.com.server."

This command is not saved in the router configuration; however, the RSA keys generated by this command are saved in the private configuration in NVRAM (which is never displayed to the user or backed up to another device) the next time the configuration is written to NVRAM.



Note

If the configuration is not saved to NVRAM, the generated keys are lost on the next reload of the router.

There are two mutually exclusive types of RSA key pairs: special-usage keys and general-purpose keys. When you generate RSA key pairs, you will be prompted to select either special-usage keys or general-purpose keys.

#### Special-Usage Keys

If you generate special-usage keys, two pairs of RSA keys will be generated. One pair will be used with any Internet Key Exchange (IKE) policy that specifies RSA signatures as the authentication method, and the other pair will be used with any IKE policy that specifies RSA encrypted keys as the authentication method.

A CA is used only with IKE policies specifying RSA signatures, not with IKE policies specifying RSA-encrypted nonces. (However, you could specify more than one IKE policy and have RSA signatures specified in one policy and RSA-encrypted nonces in another policy.)

If you plan to have both types of RSA authentication methods in your IKE policies, you may prefer to generate special-usage keys. With special-usage keys, each key is not unnecessarily exposed. (Without special-usage keys, one key is used for both authentication methods, increasing the exposure of that key.)

#### **General-Purpose Keys**

If you generate general-purpose keys, only one pair of RSA keys will be generated. This pair will be used with IKE policies specifying either RSA signatures or RSA encrypted keys. Therefore, a general-purpose key pair might get used more frequently than a special-usage key pair.

#### **Named Key Pairs**

If you generate a named key pair using the *key-label*argument, you must also specify the **usage-keys** keyword or the **general-keys** keyword. Named key pairs allow you to have multiple RSA key pairs, enabling the Cisco IOS software to maintain a different key pair for each identity certificate.

#### Modulus Length

When you generate RSA keys, you will be prompted to enter a modulus length. The longer the modulus, the stronger the security. However a longer modules takes longer to generate (see the table below for sample times) and takes longer to use.

#### Table 3: Sample Times by Modulus Length to Generate RSA Keys

Router	360 bits	512 bits	1024 bits	2048 bits (maximum)
Cisco 2500	11 seconds	20 seconds	4 minutes, 38 seconds	More than 1 hour
Cisco 4700	Less than 1 second	1 second	4 seconds	50 seconds

Cisco IOS software does not support a modulus greater than 4096 bits. A length of less than 512 bits is normally not recommended. In certain situations, the shorter modulus may not function properly with IKE, so we recommend using a minimum modulus of 2048 bits.



Note

As of Cisco IOS Release 12.4(11)T, peer *public* RSA key modulus values up to 4096 bits are automatically supported. The largest private RSA key modulus is 4096 bits. Therefore, the largest RSA private key a router may generate or import is 4096 bits. However, RFC 2409 restricts the private key size to 2048 bits or less for RSA encryption. The recommended modulus for a CA is 2048 bits; the recommended modulus for a client is 2048 bits.

Additional limitations may apply when RSA keys are generated by cryptographic hardware. For example, when RSA keys are generated by the Cisco VPN Services Port Adapter (VSPA), the RSA key modulus must be a minimum of 384 bits and must be a multiple of 64.

Specifying a Storage Location for RSA Keys

When you issue the **crypto key generate rsa** command with the **storage** *devicename* : keyword and argument, the RSA keys will be stored on the specified device. This location will supersede any **crypto key storage** command settings.

#### Specifying a Device for RSA Key Generation

As of Cisco IOS Release 12.4(11)T and later releases, you may specify the device where RSA keys are generated. Devices supported include NVRAM, local disks, and USB tokens. If your router has a USB token configured and available, the USB token can be used as cryptographic device in addition to a storage device. Using a USB token as a cryptographic device allows RSA operations such as key generation, signing, and authentication of credentials to be performed on the token. The private key never leaves the USB token and is not exportable.

RSA keys may be generated on a configured and available USB token, by the use of the **on** *devicename* : keyword and argument. Keys that reside on a USB token are saved to persistent token storage when they are generated. The number of keys that can be generated on a USB token is limited by the space available. If you attempt to generate keys on a USB token and it is full you will receive the following message:

% Error in generating keys:no available resources

Key deletion will remove the keys stored on the token from persistent storage immediately. (Keys that do not reside on a token are saved to or deleted from nontoken storage locations when the **copy**or similar command is issued.)

For information on configuring a USB token, see "Storing PKI Credentials" chapter in the Cisco IOS Security Configuration Guide, Release 12.4T. For information on using on-token RSA credentials, see the "Configuring and Managing a Cisco IOS Certificate Server for PKI Deployment" chapter in the Cisco IOS Security Configuration Guide, Release 12.4T.

#### Specifying RSA Key Redundancy Generation on a Device

You can specify redundancy for existing keys only if they are exportable.

The following example generates a general-usage 1024-bit RSA key pair on a USB token with the label "ms2" with crypto engine debugging messages shown:

Router(config)# crypto key generate rsa label ms2 modulus 2048 on usbtoken0: The name for the keys will be: ms2 % The key modulus size is 2048 bits % Generating 1024 bit RSA keys, keys will be on-token, non-exportable... Jan 7 02:41:40.895: crypto\_engine: Generate public/private keypair [OK] Jan 7 02:44:09.623: crypto\_engine: Create signature Jan 7 02:44:10.467: crypto\_engine: Verify signature Jan 7 02:44:10.467: CryptoEngine0: CRYPTO\_ISA\_RSA\_CREATE\_PUBKEY(hw)(ipsec) Jan 7 02:44:10.467: CryptoEngine0: CRYPTO\_ISA\_RSA\_PUB\_DECRYPT(hw)(ipsec)

Now, the on-token keys labeled "ms2" may be used for enrollment.

The following example generates special-usage RSA keys:

```
Router (config) # crypto key generate rsa usage-keys

The name for the keys will be: myrouter.example.com

Choose the size of the key modulus in the range of 360 to 2048 for your Signature Keys.

Choosing a key modulus greater than 512 may take a few minutes.

How many bits in the modulus[512]? <return>

Generating RSA keys... [OK].

Choose the size of the key modulus in the range of 360 to 2048 for your Encryption Keys.

Choosing a key modulus greater than 512 may take a few minutes.

How many bits in the modulus[512]? <return>

Generating RSA keys.... [OK].
```

The following example generates general-purpose RSA keys:

Note

You cannot generate both special-usage and general-purpose keys; you can generate only one or the other.

```
Router(config)# crypto key generate rsa general-keys
The name for the keys will be: myrouter.example.com
Choose the size of the key modulus in the range of 360 to 2048 for your General Purpose
Keys. Choosing a key modulus greater than 512 may take a few minutes.
How many bits in the modulus[512]? <return>
Generating RSA keys... [OK].
```

Examples

The following example generates the general-purpose RSA key pair "exampleCAkeys":

```
crypto key generate rsa general-keys label exampleCAkeys
crypto ca trustpoint exampleCAkeys
enroll url
http://exampleCAkeys/certsrv/mscep/mscep.dll
rsakeypair exampleCAkeys 1024 1024
```

The following example specifies the RSA key storage location of "usbtoken0:" for "tokenkey1":

crypto key generate rsa general-keys label tokenkey1 storage usbtoken0:

The following example specifies the redundancy keyword:

Router(config) # crypto key generate rsa label MYKEYS redundancy The name for the keys will be: MYKEYS

Choose the size of the key modulus in the range of 360 to 2048 for your

General Purpose Keys. Choosing a key modulus greater than 512 may take

a few minutes.

How many bits in the modulus [512]:

% Generating 512 bit RSA keys, keys will be non-exportable with redundancy...[OK]

Command	Description
сору	Copies any file from a source to a destination, use the copy command in privileged EXEC mode.
crypto key storage	Sets the default storage location for RSA key pairs.
debug crypto engine	Displays debug messages about crypto engines.
hostname	Specifies or modifies the hostname for the network server.
ip domain-name	Defines a default domain name to complete unqualified hostnames (names without a dotted-decimal domain name).
show crypto key mypubkey rsa	Displays the RSA public keys of your router.
show crypto pki certificates	Displays information about your PKI certificate, certification authority, and any registration authority certificates.

# crypto key import ec

To import an Elliptic Curve (EC) key pair, use the **crypto key import ec** command in global configuration mode.

crypto key import ec key-label [exportable] {terminal url url} passphrase

#### **Syntax Description**

key-label	Name of the EC key pair to be imported to the device.
	The <i>key-label</i> argument must match the key pair name that was specified through the <b>crypto key generate ec keysize</b> command.
exportable	(Optional) Specifies that the imported EC key pair can be exported to another Cisco device such as a router.
terminal	Specifies that the certificates and EC key pairs will be manually imported via copy-and-paste to the console terminal.
url url	Specifies the URL of the file system from which the router should import certificates and EC key pairs.
passphrase	Specifies the passphrase that was used to encrypt the PEM file for import.
	<b>Note</b> The passphrase can be any phrase that is at least eight characters in length. It can include spaces and punctuation, excluding the question mark (?), which has special meaning to the parser.

**Command Default** EC key pairs are not imported.

**Command Modes** Global configuration (config)

# Command History

ry	Release	Modification
	15.2(4)M	This command was introduced.

I

ſ

Usage Guidelines	IPsec and public key infrastructure (PKI) both support the ability to generate, export, and import EC (ECDSA-256 and ECDSA-384) key pairs. The <b>crypto key import ec</b> command lets you import EC key pairs into PEM-formatted files. The files can be previously exported from another Cisco IOS router or generated by other PKI applications.
	You can specify a device from which to import EC key pairs. Devices supported include NVRAM and local disks.
	If the device on which the EC key pair is to be imported does not have enough space for this key, then a message appears stating that the importation of the key pair has failed.
	To delete EC key pairs from a device, use the crypto key zeroize ec command.
Examples	The following example shows how to generate, export, import, and verify the status of an EC key pair named Device_1_Key:
	! Generate the key pair
	: Device(config)# <b>crypto key generate ec keysize 256 exportable label Device_1_Key</b> The name for the keys will be: Device_1_Key
	EC key pair created successfully
	! Archive the key pair to a remote location, and use a good password.
	<pre>Device(config)# crypto key export ec Device_1_Key pem url nvram: 3des mypassword % Key name: Device_1_Key Usage: Signature Key Exporting public key</pre>
	Destination filename [Device_1_Key-sign.pub]? Writing file to nvram:Device_1_Key-sign.pub Exporting private key
	Destination filename [Device_1_Key-sign.prv]? Writing file to nvram:Device_1_Key-sign.prv ! ! Import the key as a different name.
	! Device(config)# crypto key import ec Device 1 Key url nvram:Device 1 Key mypassword
	<pre>% Importing public Signature key or certificate PEM file Source filename [Device_1_Key-sign.pub]? Reading file from nvram:Device 1 Key-sign.pub</pre>
	% Importing private Signature key PEM file Source filename [Device_1_Key-sign.prv]?
	Reading file from nvram:Device_1_Key-sign.prv % Key pair import succeeded.
	After the key has been imported, it is no longer exportable.
	! Verify the status of the key. !
	Device# <b>show crypto key mypubkey ec</b> % Key pair was generated at: 17:26:53 PST Jun 7 2012 Key name: Device_1_Key Key type: EC KEYS
	Storage Device: private-config Usage: Signature Key Key is not exportable.
	Key Data: 30593013 06072A86 48CE3D02 0106082A 8648CE3D 03010703 420004A3 E483C98C BABE4CAD 9822F5F1 06FDFD4B F70D0103 03C266B6 DA368DB9 AB01C5AB 7333F5B9 3478E0FE 6CA67598 FB828F47 A92AFE70 93EFE828 2620A611 699E52

1

Command	Description
crypto key export ec	Exports EC keys in PEM-formatted files.
crypto key generate ec keysize	Generates EC key pairs.
crypto key zeroize ec	Deletes EC keys from a device.

# crypto key import rsa pem

To import Rivest, Shamir, and Adelman (RSA) keys in privacy-enhanced mail (PEM)-formatted files, use the **crypto key import rsa pem**command in global configuration mode.

crypto key import rsa *key-label* pem [usage-keys| signature| encryption| general-purpose] {storage| terminal [ *passphrase* ]| url url} [exportable] [on *devicename* :]

#### Syntax Description

key-label	Name of the RSA key pair that is imported to the device.
	The <i>key-label</i> argument must match the key pair name that was specified through the <b>crypto key generate rsa</b> command.
usage-keys	(Optional) Specifies that two RSA special usage key pairs, one encryption pair and one signature pair, are imported.
signature	(Optional) Specifies that RSA signature keys are imported.
encryption	(Optional) Specifies that RSA encryption keys are imported.
general-purpose	(Optional) Specifies a General Purpose Key.
storage	Stores the key on the specified device.
terminal	Specifies the certificates and RSA key pairs are manually imported to the console terminal.
passphrase	Passphrase that is used to encrypt the PEM file for import.
	<b>Note</b> The passphrase can be any phrase that is at least eight characters in length; it can include spaces and punctuation, excluding the question mark (?), which has special meaning to the Cisco IOS parser.
url url	URL of the file system where the router should import certificates and RSA key pairs.
exportable	(Optional) Specifies that the imported RSA key pair can be exported to another Cisco device such as a router.

on devicename :	(Optional) Specifies that the imported RSA key pair is created on the specified device. Devices supported include local disks, NVRAM, and USB tokens. The name of the device is followed by a colon (:). Keys created on a USB token have a maximum size of 1024-bits.
-----------------	---

**Command Default** RSA general-purpose key pair type is expected for import.

# **Command Modes** Global configuration (config)

#### **Command History**

Release Modification	
12.3(4)T	This command was introduced.
12.4(11)T	This command was modified. The <b>signature</b> , <b>encryption</b> , and <b>on</b> keywords and <i>devicename</i> : argument were added.
15.0(1)M	This command was modified. The <b>terminal</b> keyword and <i>passphrase</i> argument were added.
15.2(2)SA2	This command was implemented on the Cisco ME 2600X Series Ethernet Access Switches.

# Usage Guidelin

Note

Security threats, as well as the cryptographic technologies to help protect against them, are constantly changing. For more information about the latest Cisco cryptographic recommendations, see the Next Generation Encryption (NGE) white paper.

The **crypto key import rsa pem** command allows RSA key pairs to be imported into PEM-formatted files. The files can be previously exported from another Cisco IOS router or generated by other public key infrastructure (PKI) applications.

As of Cisco IOS Release 12.4(11)T and later releases, the device can be specified for where RSA keys are generated. Devices supported include NVRAM, local disks and USB tokens. If the router has a USB token configured and available, the USB token can be used as cryptographic device in addition to a storage device. Using a USB token as a cryptographic device allows RSA operations such as key generation, signing and authentication of credentials to be performed on the token. The private key never leaves the USB token and is not exportable.

RSA keys may be imported to a configured and available USB token by using the **on** *devicename* : keyword and argument. Keys that reside on a USB token, or on-token keys, are saved to persistent token storage when they are imported. Key deletion removes the on-token keys from persistent storage immediately. (Keys that

do not reside on a token are saved to or deleted from nontoken storage locations when the **write memory** or similar command is issued.)

If the device, on which the RSA key is to be imported, does not have enough space for this key, then a message appears saying that the importation of the key has failed.

For information on configuring a USB token, see "Storing PKI Credentials" module. For information on using on-token RSA credentials, see "Configuring and Managing a Cisco IOS Certificate Server for PKI Deployment" module.

**Examples** The following example shows that an encryption key has been imported successfully to a configured and available USB token, shown with crypto engine and crypto PKI transaction debugging messages:

Router# configure terminal Enter configuration commands, one per line. End with CNTL/Z. Router(config)# crypto key import rsa label encryption on usbtoken0 url nvram:e password

% Importing public Encryption key or certificate PEM file... filename [e-encr.pub]? Reading file from nvram:e-encr.pub % Importing private Encryption key PEM file... Source filename [e-encr.prv]? Reading file from nvram:e-encr.prv % Key pair import succeeded.

The following example shows how to generate, export, import, and verify the status of the RSA key pair "mycs":

! Generate the key pair Router(config) # crypto key generate rsa general-purpose label mycs exportable The name for the keys will be: mycs Choose the size of the key modulus in the range of 360 to 2048 for your General Purpose Keys. Choosing a key modulus greater than 512 may take a few minutes. How many bits in the modulus [512]: 1024 % Generating 1024 bit RSA keys ...[OK] ! Archive the key pair to a remote location, and use a good password. Router (config) # crypto key export rsa mycs pem url nvram: 3des PASSWORD % Kev name: mvcs Usage: General Purpose Key Exporting public key... Destination filename [mycs.pub]? Writing file to nvram:mycs.pub Exporting private key... Destination filename [mycs.prv]? Writing file to nvram:mycs.prv ! Import the key as a different name. Router(config) # crypto key import rsa mycs2 pem url nvram:mycs PASSWORD % Importing public key or certificate PEM file... Source filename [mycs.pub]? Reading file from nvram:mycs.pub % Importing private key PEM file... Source filename [mycs.prv]? Reading file from nvram:mycs.prv% Key pair import succeeded. ! After the key has been imported, it is no longer exportable. ! Verify the status of the key.

Router# show crypto key mypubkey rsa % Key pair was generated at: 18:04:56 GMT Jun 6 2003 Key name: mycs Usage: General Purpose Key Key is exportable. Key Data: 30819F30 0D06092A 864886F7 0D010101 05000381 8D003081 89028181 00E65253 9C30C12E 295AB73F B1DF9FAD 86F88192 7D4FA4D2 8BA7FB49 9045BAB9 373A31CB A6B1B8F4 329F2E7E 8A50997E AADBCFAA 23C29E19 C45F4F05 DBB2FA51 4B7E9F79 A1095115 759D6BC3 5DFB5D7F BCF655BF 6317DB12 A8287795 7D8DC6A3 D31B2486 C9C96D2C 2F70B50D 3B4CDDAE F661041A 445AE11D 002EEF08 F2A627A0 5B020301 0001 % Key pair was generated at: 18:17:25 GMT Jun 6 2003 Key name: mycs2 Usage: General Purpose Key Key is not exportable. Key Data: 30819F30 0D06092A 864886F7 0D010101 05000381 8D003081 89028181 00E65253 9C30C12E 295AB73F B1DF9FAD 86F88192 7D4FA4D2 8BA7FB49 9045BAB9 373A31CB A6B1B8F4 329F2E7E 8A50997E AADBCFAA 23C29E19 C45F4F05 DBB2FA51 4B7E9F79 A1095115 759D6BC3 5DFB5D7F BCF655BF 6317DB12 A8287795 7D8DC6A3 D31B2486 C9C96D2C 2F70B50D 3B4CDDAE F661041A 445AE11D 002EEF08 F2A627A0 5B020301 0001

Command	Description
crypto key export pem	Exports RSA keys in PEM-formatted files.
crypto key generate rsa	Generates RSA key pairs.

# crypto key lock rsa

To lock the RSA private key in a router, use the crypto key lock rsacommand in privileged EXEC mode.

crypto key lock rsa [name key-name] [all] [passphrase [ passphrase ]]

### **Syntax Description**

I

name key-name	(Optional) Specifies the name of the RSA key pair that is to be locked. The name must match the name that was specified via the <b>crypto key encrypt rsa</b> command.
all	(Optional ) Locks all the encrypted keys.
passphrase passphrase	(Optional ) Specifies the passphrase that is used to lock the RSA key. The passphrase must match the passphrase that was specified via the <b>crypto key</b> <b>encrypt rsa</b> command.

**Command Default** RSA keys are encrypted, but not locked.

**Command Modes** Privileged EXEC (#)

<b>Command History</b>	Release	Modification
	12.3(7)T	This command was introduced.
	12.2(18)SXE	This command was integrated into Cisco IOS Release 12.2(18)SXE.
	15.0(1)M	This command was modified in a release earlier than Cisco IOS Release 15.0(1)M. The <b>all</b> keyword was added.
	Cisco IOS XE Release 2.1	This command was implemented on the Cisco ASR 1000 Series Aggregation Services Routers.

### **Usage Guidelines** When the crypto key lock rsa command is issued, the unencrypted copy of the key is deleted. Because the

private key is not available, all RSA operations will fail.

This command affects only the "run-time" access to the key; that is, it does not affect the key that is stored in NVRAM.

#### **Examples**

The following example shows how to lock the key "pki1-72a.cisco.com." Thereafter, the **show crypto key mypubkey rsa** command is issued to verify that the key is protected (encrypted) and locked.

```
Router# crypto key lock rsa name pkil-72a.cisco.com passphrase ciscol234
!
Router# show crypto key mypubkey rsa
% Key pair was generated at:20:29:41 GMT Jun 20 2003
Key name:pkil-72a.cisco.com
Usage:General Purpose Key
**** The key is protected and LOCKED. ***
Key is exportable.
Key Data:
305C300D 06092A86 4886F70D 01010105 00034B00 30480241 00D7808D C5FF14AC
0D2B55AC 5D199F2F 7CB4B355 C555E07B 6D0DECBE 4519B1F0 75B12D6F 902D6E9F
B6FDAD8D 654EF851 5701D5D7 EDA047ED 9A2A619D 5639DF18 EB020301 0001
```

Command	Description
crypto key encrypt rsa	Encrypts the RSA private key.
crypto key unlock rsa	Unlocks the RSA private key in a router.
show crypto key mypubkey rsa	Displays the RSA public keys of your router.

# crypto key move rsa

To move an existing Cisco IOS generated Rivest, Shamir, and Adelman (RSA) key pair from one storage location to another storage location, use the **crypto key move rsa** command in global configuration mode.

crypto key move rsa keylabel [non-exportable] [on| storage] [redundancy routername] location

#### **Syntax Description**

keylabel	Specifies name of the existing RSA key pair.
non-exportable	(Optional) Specifies that the RSA key pair cannot be exported once the key pair is moved to the eToken device.
on	(Optional) Specifies that the RSA key pair will be placed on a configured USB token and stored in the PIN protected flash portion of the USB token. Any subsequent RSA operations will be performed on the USB token.
storage	(Optional) Specifies that the RSA key pair will be stored on the specified device, for example a smart card. The key pair will be loaded back into Cisco IOS for any subsequent RSA operations.
location	Identifies the storage location where the RSA key pair will be moved.
redundancy	(Optional) Specifies that the key should be synchronized to the standby CA.

**Command Default** The RSA key pair remains stored on the current device.

# **Command Modes** Global configuration

<b>Command History</b>	Release	Modification
	12.4(15)T	This command was introduced.
	15.0(1)M	This command was modified. The <b>redundancy</b> keyword was introduced.
	Cisco IOS XE Release 3.6	This command was integrated into Cisco IOS XE Release 3.6.

Usage Guidelines

When an existing RSA key pair is generated in Cisco IOS, stored on a USB token, and used for an enrollment, it may be necessary to move those existing RSA key pairs to an alternate location for permanent storage.

Generating the key on the router and moving it to the token requires less than a minute. Generating a key on the token using the **on** keyword could require 5 to 10 minutes and is dependent on hardware key generation routines available on the USB token.

Using the **crypto key move rsa**command allows the storage location of a newly generated key to be changed if the **storage** keyword or **on** keyword was not specified when the key was first generated and the key has not yet been written out to a storage location. You can always move an exportable key.

Note

If you make the key nonexportable by issuing the **non-exportable**keyword, the key cannot be made exportable again. Also, once you specify the **on** keyword with the target device, either to move an existing key or during key generation, the command cannot be undone.

Examples

The following example moves an existing RSA key pair to a configured and available USB token, "tokenA," as a nonexportable key pair stored in the PIN protected flash portion of the designated USB token:

crypto key move rsa keypairname non-exportable on tokenA

ls	Command	Description
	binary file	Specifies the binary file location on the registrar and the destination binary file location on the petitioner.
	template file	Specifies the source template file location on the registrar and the destination template file location on the petitioner.

# crypto key pubkey-chain rsa

To enter public key configuration mode (so you can manually specify other devices' RSA public keys), use the **crypto key pubkey-chain rsa**command in global configuration mode.

crypto key pubkey-chain rsa

- **Syntax Description** This command has no arguments or keywords.
- **Command Default** No default behavior or values.
- **Command Modes** Global configuration

<b>Command History</b>	Release	Modification
	11.3 T	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

# **Use this command to enter public key chain configuration mode. Use this command when you need to manually specify other IPSec peers' RSA public keys. You need to specify other peers' keys when you configure RSA encrypted nonces as the authentication method in an Internet Key Exchange policy at your peer router.**

**Examples** 

The following example specifies the RSA public keys of two other IPSec peers. The remote peers use their IP address as their identity.

```
Router(config) # crypto key pubkey-chain rsa
Router(config-pubkey-chain) # addressed-key 10.5.5.1
Router(config-pubkey-key) # key-string
Router(config-pubkey) # 00302017 4A7D385B 1234EF29 335FC973
Router(config-pubkey)# 2DD50A37 C4F4B0FD 9DADE748 429618D5
Router(config-pubkey) # 18242BA3 2EDFBDD3 4296142A DDF7D3D8
Router(config-pubkey) # 08407685 2F2190A0 0B43F1BD 9A8A26DB
Router(config-pubkey) # 07953829 791FCDE9 A98420F0 6A82045B
Router(config-pubkey) # 90288A26 DBC64468 7789F76E EE21
Router(config-pubkey) # quit
Router(config-pubkey-key) # exit
Router(config-pubkey-chain)# addressed-key 10.1.1.2
Router(config-pubkey-key)# key-string
Router(config-pubkey) # 0738BC7A 2BC3E9F0 679B00FE 53987BCC
Router(config-pubkey) # 01030201 42DD06AF E228D24C 458AD228
Router (config-pubkey) # 58BB5DDD F4836401 2A2D7163 219F882E
Router(config-pubkey) # 64CE69D4 B583748A 241BED0F 6E7F2F16
```

1

Router(config-pubkey) # 0DE0986E DF02031F 4B0B0912 F68200C4
Router(config-pubkey) # C625C389 0BFF3321 A2598935 C1B1
Router(config-pubkey) # quit
Router(config-pubkey-key) # exit
Router(config-pubkey-chain) # exit
Router(config) #

Command	Description
address	Specifies the IP address of the remote RSA public key of the remote peer you will manually configure.
addressed-key	Specifies the RSA public key of the peer you will manually configure.
key-string (IKE)	Specifies the RSA public key of a remote peer.
named-key	Specifies which peer RSA public key you will manually configure.
show crypto key pubkey-chain rsa	Displays peer RSA public keys stored on your router.

# crypto key storage

To set the default storage location for newly created Rivest, Shamir, and Adelman (RSA) key pairs, use the **crypto key storage**command in global configuration mode. To store keys on the most recently logged-in USB token (or on NVRAM if there is no token), use the **no** form of this command.

crypto key storage *device*:

nocrypto key storage device:

Syntax Description	device:	Name of the device where the RSA key pairs will be stored by default.
		5

**Command Default** RSA key pairs are stored on NVRAM.

# **Command Modes** Global configuration

<b>Command History</b>	Release	Modification
	12.4(4)T	This command was introduced.
	12.4(11)T	This command was integrated into the Cisco 7200VXR NPE-G2 platform.
	Cisco IOS XE Release 3.6	This command was integrated into Cisco IOS XE Release 3.6.

**Usage Guidelines** You may specify a default storage location, other than NVRAM, for newly created USB token RSA keys. The storage location specified by the **crypto key generate rsa** command for RSA keys will override the location specified by the **crypto key storage** command. The name of the designated device is followed by a colon (:).

Regardless of configuration settings, existing keys will be stored on the devices from where they were originally loaded.

Note

The USB token must be logged into the router for the RSA keys to be read or written.

#### **Examples**

The following example shows how to store new keys in NVRAM by default, regardless of where the token is inserted:

crypto key storage nvram:

1

The following example shows how to store new keys on usbtoken0: by default:

crypto key storage usbtoken0:

The following example shows how to store new keys on most recently logged-in token, or on NVRAM if there is no token:

no crypto key storage

Command	Description
crypto key generate rsa	Generates RSA key pairs and specifies RSA key storage location (other than the default location).
crypto pki token user-pin	Creates a PIN that automatically allows the router to log into the USB token at router startup.
## crypto key unlock rsa

To unlock the RSA private key in a router, use the **crypto key unlock rsa**command in privileged EXEC mode.

crypto key unlock rsa [name key-name] [all] [passphrase [ passphrase ]]

#### **Syntax Description**

name key-name	(Optional) Specifies the name of the RSA key pair that is to be unlocked. The name must match the name that was specified via the <b>crypto key encrypt rsa</b> command.
all	(Optional ) Unlocks all the locked key pairs.
passphrase passphrase	(Optional) Specifies the passphrase that is used to unlock the RSA key. The passphrase must match the passphrase that was specified via the <b>crypto key</b> <b>encrypt rsa</b> command.

### **Command Default** The encrypted private key is locked.

**Command Modes** Privileged EXEC (#)

<b>Command History</b>	Release	Modification
	12.3(7)T	This command was introduced.
	12.2(18)SXE	This command was integrated into Cisco IOS Release 12.2(18)SXE.
	15.0(1)M	This command was modified in a release earlier than Cisco IOS Release 15.0(1)M. The <b>all</b> keyword was added.
	Cisco IOS XE Release 2.1	This command was implemented on the Cisco ASR 1000 Series Aggregation Services Routers.

#### **Usage Guidelines**

I

**delines** When a router with an encrypted RSA key (via the **crypto key encrypt rsa** command) initially boots up, the key does not exist in plain text and is therefore considered to be locked. Because the private key is not available, all RSA operations will fail. After you unlock the private key, RSA operations will function again.

This command affects only the "run-time" access to the key; that is, it does not affect the key that is stored in NVRAM.

1

## Examples

The following example shows how to unlock the key "pki1-72a.cisco.com":

Router# crypto key unlock rsa name pki1-72a.cisco.com passphrase cisco1234

#### **Related Commands**

Command	Description
crypto key encrypt rsa	Encrypts the RSA private key.
crypto key lock rsa	Locks the RSA private key in a router.
show crypto key mypubkey rsa	Displays the RSA public keys of your router.

## crypto key zeroize ec

To delete all Elliptic Curve (EC) key pairs from your router, use the **crypto key zeroize ec** command in global configuration mode.

crypto key zeroize ec [ key-pair-label ]

Syntax Description	key-pair-label	(Optional) Specifies the name of the key pair that the router will delete.
Command Default	No default behavior or values.	
Command Modes	Global configuration (config)	
<b>Command History</b>	Release	Modification
	11.3 T	This command was introduced.
	12.2(8)T	The key-pair-labelargument was added.
	12.2(18)SXD	This command was integrated into Cisco IOS Release 12.2(18)SXD.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.

#### **Usage Guidelines**

This command deletes all EC key pairs that were previously generated by your router unless you include the *key-pair-label* argument, which will delete only the specified EC key pair. If you issue this command, you must also perform two additional tasks for each trustpoint that is associated with the key pair that was deleted:

- Ask the certification authority (CA) administrator to revoke your router's certificates at the CA; you must supply the challenge password you created when you originally obtained the router's certificates using the **crypto ca enroll** command.
- Manually remove the router's certificates from the configuration by removing the configured trustpoint (using the **no crypto ca trustpoint** *name*command .)



Note

This command cannot be undone (after you save your configuration), and after EC keys have been deleted, you cannot use certificates or the CA or participate in certificate exchanges with other IP security (IPsec) peers unless you reconfigure CA interoperability by regenerating EC keys, getting the CA's certificate, and requesting your own certificate again.

This command is not saved to the configuration.

**Examples** 

The following example deletes the general-purpose EC key pair that was previously generated for the router. After deleting the EC key pair, the administrator contacts the CA administrator and requests that the certificate of the router be revoked. The administrator then deletes the certificate of the router from the configuration.

```
crypto key zeroize ec
crypto ca certificate chain
no certificate
```

#### **Related Commands**

Command	Description
certificate	Adds certificates manually.
crypto ca certificate chain	Enters the certificate chain configuration mode.
crypto ca trustpoint	Declares the CA that your router should use.
crypto key zeroize pubkey-chain	Deletes the remote peer's public key from the cache.
crypto key zeroize rsa	Deletes all RSA key pairs from the router.
show crypto ca timers	Specifies which key pair to associate with the certificate.

## crypto key zeroize pubkey-chain

I

To delete the remote peer's public key from the cache, use the **crypto key zeroize pubkey-chain** command in global configuration mode.

crypto key zeroize pubkey-chain [ index ]

Syntax Description	index	(Optional) Specifies an index entry to be deleted. If no index entry is specified, then all the index entries are deleted. The acceptable range of index entries is from 1 to 65535.
Command Default	No default behavior or values.	
Command Modes	Global configuration (config)	
Command History	Release	Modification
	15.1(3)T	This command was introduced.
Usage Guidelines		ete the peer router's public keys in order to help debug signature verification ys are cached by default with the lifetime of the certificate revocation list tt.
Examples	The following example deletes all p	oublic key index entries:
	Router> enable Router# configure terminal Router (config)# crypto key zo	eroize pubkey-chain
Related Commands	Command	Description
	crypto key zeroize ec	Deletes all EC key pairs from the router.
	crypto key zeroize rsa	Deletes all RSA key pairs from the router.

## crypto key zeroize rsa

To delete all RSA keys from your router, use the **crypto key zeroize rsa** command in global configuration mode.

crypto key zeroize rsa [key-pair-label]

Syntax Description	key-pair-label	(Optional) Specifies the name of the key pair that router will delete.

**Command Default** No default behavior or values.

**Command Modes** Global configuration (config)

<b>Command History</b>	Release	Modification
	11.3 T	This command was introduced.
	12.2(8)T	The key-pair-labelargument was added.
	12.2(18)SXD	This command was integrated into Cisco IOS Release 12.2(18)SXD.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.

#### **Usage Guidelines**

This command deletes all Rivest, Shamir, and Adelman (RSA) keys that were previously generated by your router unless you include the *key-pair-label* argument, which will delete only the specified RSA key pair. If you issue this command, you must also perform two additional tasks for each trustpoint that is associated with the key pair that was deleted:

- Ask the certification authority (CA) administrator to revoke your router's certificates at the CA; you must supply the challenge password you created when you originally obtained the router's certificates using the **crypto ca enroll** command.
- Manually remove the router's certificates from the configuration by removing the configured trustpoint (using the **no crypto ca trustpoint** *name*command .)



This command cannot be undone (after you save your configuration), and after RSA keys have been deleted, you cannot use certificates or the CA or participate in certificate exchanges with other IP Security (IPSec) peers unless you reconfigure CA interoperability by regenerating RSA keys, getting the CA's certificate, and requesting your own certificate again.

This command is not saved to the configuration.

**Examples** 

The following example deletes the general-purpose RSA key pair that was previously generated for the router. After deleting the RSA key pair, the administrator contacts the CA administrator and requests that the certificate of the router be revoked. The administrator then deletes the certificate of the router from the configuration.

```
crypto key zeroize rsa
crypto ca certificate chain
no certificate
```

#### **Related Commands**

Command	Description
certificate	Adds certificates manually.
crypto ca certificate chain	Enters the certificate chain configuration mode.
crypto ca trustpoint	Declares the CA that your router should use.
crypto key zeroize ec	Deletes all EC key pairs from the router.
crypto key zeroize pubkey-chain	Deletes the remote peer's public key from the cache.
show crypto ca timers	Specifies which key pair to associate with the certificate.

## crypto keyring

To define a crypto keyring to be used during Internet Key Exchange (IKE) authentication, use the **crypto keyring**command in global configuration mode. To remove the keyring, use the **no** form of this command.

crypto keyring keyring-name [vrf fvrf-name]

**no crypto keyring** keyring-name [**vrf** fvrf-name]

#### **Syntax Description**

1	keyring-name	Name of the crypto keyring.
	vrf fvrf-name	(Optional) Front door virtual routing and forwarding (FVRF) name to which the keyring will be referenced. The <i>fvrf-name</i> must match the FVRF name that was defined during virtual routing and forwarding (VRF) configuration. The <b>vrf</b> keyword and <i>fvrf-name</i> argument are not supported by IPv6.

**Command Default** All the Internet Security Association and Key Management Protocol (ISAKMP) keys that were defined in the global configuration are part of the default global keyring.

### **Command Modes** Global configuration (config)

<b>Command History</b>	Release	Modification
	12.2(15)T	This command was introduced.
	12.4(4)T	Support for IPv6 was added.
	12.2(33)SXH	This command was integrated into Cisco IOS Release 12.2(33)SXH.
	Cisco IOS XE Release 2.1	This command was introduced on Cisco ASR 1000 Series Routers.

**Usage Guidelines** A keyring is a repository of preshared and Rivest, Shamir, and Adelman (RSA) public keys. The keyring is used in the ISAKMP profile configuration mode. The ISAKMP profile successfully completes authentication of peers if the peer keys are defined in the keyring that is attached to this profile.

Examples

The following example shows that a keyring and its usage have been defined:

crypto keyring vpnkeys pre-shared-key address 10.72.23.11 key vpnsecret crypto isakmp profile vpnprofile keyring vpnkeys

### **Related Commands**

ſ

0	Command	Description
ľ	ore-shared-key	Defines a preshared key to be used for IKE authentication.

## crypto logging ezvpn

To enable Easy VPN syslog messages on a server, use the **crypto logging ezvpn** command in global configuration mode. To disable syslog messages on the server, use the no form of this command.

crypto logging ezvpn [group group-name]

**no crypto logging ezvpn** [group group-name]

#### Syntax Description

group group-name

provide the second	Optional) Group name. If a group name is not provided, syslog messages are enabled for all Easy /PN connections to the server. If a group name is provided, syslog messages are enabled only for that particular group.
--	---

**Command Default** Syslog messages are not enabled.

#### **Command Modes** Global configuration (config)

<b>Command History</b>	Release	Modification
	12.4(4)T	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS 12.2SX family of releases. Support in a specific 12.2SX release is dependent on your feature set, platform, and platform hardware.

#### **Examples**

The following configuration shows that syslog messages are to be displayed for group 1.

crypto logging ezvpn group group\_1 The following is an example of a typical Easy VPN syslog message:

timestamp: %CRYPTO-6-VPN TUNNEL STATUS: (Server) <event message> User=<username> Group=<groupname> Client\_public\_addr=<ip\_addr> Server\_public\_addr=<ip addr> The following is an example of an authentication-passed event Easy VPN syslog message:

Jul 25 23:33:06.847: %CRYPTO-6-VPN\_TUNNEL\_STATUS: (Server) Authentication PASS ED User=blue Group=Cisco1760group Client\_public\_addr=10.20.20.1 Server public addr=10.20.20.2

I

#### The following is an example of a "Group does not exist" Easy VPN syslog message:

\*Jun 30 18:02:58.107: %CRYPTO-6-VPN\_TUNNEL\_STATUS: Group: group\_1 does not exist

## crypto logging ikev2

To enable Internet Key Exchange Version 2 (IKEv2) syslog messages, use the **crypto logging ikev2** command in global configuration mode. To disable syslog messages, use the **no** form of this command.

crypto logging ikev2

no crypto logging ikev2

- **Syntax Description** This command has no keywords or arguments.
- **Command Default** IKEv2 syslog messages are not enabled.
- **Command Modes** Global configuration (config)

<b>Command History</b>	Release	Modification
	15.1(1)T	This command was introduced.
	Cisco IOS XE Release 3.3S	This command was integrated into Cisco IOS XE Release 3.3S.
	15.2(4)S	This command was integrated into Cisco IOS Release 15.2(4)S.

#### **Examples**

The following configuration shows how to enable IKEv2 syslog messages:

Router(config) # crypto logging ikev2

### **Related Commands**

Command	Description
crypto ikev2 certificate-cache	Specifies the cache size to store certificates fetched from HTTP URLs.
crypto ikev2 cookie-challenge	Enables IKEv2 cookie challenge.
crypto ikev2 diagnose error	Enables IKEv2 error diagnosis.
crypto ikev2 dpd	Defines DPD globally for all peers.
crypto ikev2 http-url cert	Enables HTTP CERT support.
crypto ikev2 limit	Defines call admission control for all peers.
crypto ikev2 nat	Defines NAT keepalive globally for all peers.

I

ſ

Command	Description
crypto ikev2 window	Specifies the IKEv2 window size.

of the standard system logging buffer.

1

## crypto logging session

To generate crypto logging messages, use the **crypto logging session**command in global configuration mode. To disable logging messages, use the **no** form of this command.

#### crypto logging session

no crypto logging session

Syntax Description	session	Generates the log of active or up sessions, and inactive or down sessions.
Command Default	Crypto logging messages are not generated	ted.
Command Modes	Global configuration (config)	
Command History	Release	Modification
	12.3(4)T	This command was introduced.
Usage Guidelines	Crypto logging messages allow users to made on their device.	receive notification for every crypto EZVPN group or session that
Examples	The following example shows how to e	nable crypto logging syslog messages for all the sessions:
	Router(config)# crypto logging se	ssion
Related Commands	Command	Description
	crypto logging ezvpn	Enables Easy VPN syslog messages on a server.
	show logging	Displays the state of system logging and the content

## crypto map (global IPsec)

To enter crypto map configuration mode and create or modify a crypto map entry, to create a crypto profile that provides a template for configuration of dynamically created crypto maps, or to configure a client accounting list, use the **crypto map** command in global configuration mode. To delete a crypto map entry, profile, or set, use the **no** form of this command.

crypto map [ipv6] map-name seq-num [ipsec-manual]

**crypto map [ipv6]** *map-name seq-num* [**ipsec-isakmp** [**dynamic** *dynamic-map-name*| **discover**| **profile** *profile-name*]]

no crypto map [ipv6] map-name [ seq-num ]

crypto map [ipv6] map-name client accounting list aaalist

no crypto map [ipv6] map-name [client accounting list]

crypto map map-name seq num [gdoi]

no crypto map map-name [ seq-num ]

### **Syntax Description**

ipv6	(Optional) Specifies an IPv6 crypto map. For IPv4 crypto maps, use the command without this keyword.
	<b>Note</b> IPv6 addresses are not supported on dynamic crypto maps.
map-name	Identifies the crypto map set.
seq-num	Sequence number you assign to the crypto map entry. See additional explanation for using this argument in the "Usage Guidelines" section.
ipsec-manual	(Optional) Indicates that Internet Key Exchange (IKE) will not be used to establish the IP Security (IPsec) security associations (SAs) for protecting the traffic specified by this crypto map entry.
	Note The ipsec-manual keyword is not supported by the virtual private network Shared Port Adapter (VPN SPA) beginning with Cisco IOS Release 12.2(33)SXH5 or 12.2(33)SXI1. If the ipsec-manual keyword is entered for images after those releases, the following error message appears beneath the keyword entry line: "Manually-keyed crypto map configuration is not supported by the current crypto engine."
ipsec-isakmp	(Optional) Indicates that IKE will be used to establish the IPsec for protecting the traffic specified by this crypto map entry.

1

dynamic	(Optional) Specifies that this crypto map entry must reference a preexisting dynamic crypto map.
	<b>Note</b> Dynamic crypto maps are policy templates used in processing negotiation requests from a peer IPsec device. If you use this keyword, none of the crypto map configuration commands will be available.
dynamic-map-name	(Optional) Name of the dynamic crypto map set that should be used as the policy template.
discover	(Optional) Enables peer discovery. By default, peer discovery is disabled.
profile	(Optional) Designates a crypto map as a configuration template. The security configurations of this crypto map will be cloned as new crypto maps are created dynamically on demand.
profile-name	(Optional) Name of the crypto profile being created.
client accounting list	Designates a client accounting list.
aaalist	(Optional) AAA list name.
gdoi	(Optional) Indicates that the key management mechanism is Group Domain of Interpretation (GDOI).

**Command Default** No crypto maps exist. Peer discovery is disabled.

## **Command Modes** Global configuration (config)

### **Command History**

Release	Modification
11.2	This command was introduced.
11.3T	The following keywords and arguments were added:
	• ipsec-manual
	• ipsec-isakmp
	• dynamic
	• dynamic-map-name

Release	Modification
12.0(5)T	The <b>discover</b> keyword was added to support Tunnel Endpoint Discovery (TED).
12.2(4)T	The <b>profile</b> <i>profile-name</i> keyword-argument pair was added to allow the generation of a crypto map profile that is cloned to create dynamically created crypto maps on demand.
12.2(11)T	This command was implemented on the Cisco 1760, Cisco AS5300, Cisco AS5400, and Cisco AS5800 platforms.
12.2(15)T	The client accounting list <i>aaalist</i> keyword-argument pair was added.
12.2(18)SXD	This command was integrated into Cisco IOS Release 12.2(18)SXD.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB without support for the <b>gdoi</b> keyword.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(33)SXH5, 12.2(33)SXI1	The <b>ipsec-manual</b> keyword is not supported by the VPN SPA beginning with Cisco IOS Release 12.2(33)SXH5 or 12.2(33)SXI1.
12.4(6)T	The <b>gdoi</b> keyword was added.
Cisco IOS XE 2.1	This command was implemented on Cisco ASR 1000 series routers.
15.1(4) M	This command was modified. The <b>ipv6</b> keyword was added.



Note

Security threats, as well as the cryptographic technologies to help protect against them, are constantly changing. For more information about the latest Cisco cryptographic recommendations, see the Next Generation Encryption (NGE) white paper.

Use this command to create a new crypto map entry or profile. Use the **crypto map ipv6** *map-name seq-num*command without any keyword to modify an existing IPv6 crypto map entry or profile. For IPv4 crypto maps, use the **crypto map** *map-name seq-num*command without any keyword to modify the existing crypto map entry or profile.

After a crypto map entry is created, you cannot change the parameters specified at the global configuration level because these parameters determine the configuration commands that are valid at the crypto map level. For example, after a map entry has been created using the **ipsec-isakmp** keyword, you cannot change it to the option specified by the **ipsec-manual** keyword; you must delete and reenter the map entry.

After you define crypto map entries, you can assign the crypto map set to interfaces using the crypto map(interface IPsec) command.

#### **Crypto Map Functions**

Crypto maps provide two functions: filtering and classifying the traffic to be protected and defining the policy to be applied to that traffic. The first affects the flow of traffic on an interface; the second affects the negotiation performed (via IKE) on behalf of that traffic.

IPsec crypto maps define the following:

- What traffic should be protected
- To which IPsec peers the protected traffic can be forwarded--these are the peers with which an SA can be established
- Which transform sets are acceptable for use with the protected traffic
- How keys and SAs should be used or managed (or what the keys are, if IKE is not used)

#### Multiple Crypto Map Entries with the Same Map Name Form a Crypto Map Set

A crypto map set is a collection of crypto map entries, each with a different *seq-num* argument but the same *map-name*argument. Therefore, for an interface, you could have certain traffic forwarded to one IPsec peer with specified security applied to that traffic and other traffic forwarded to the same or different IPsec peer with different IPsec security applied. To accomplish differential forwarding, you would create two crypto maps, each with the same *map-name* argument but different *seq-num* argument. Crypto profiles must have unique names within a crypto map set.



If a deny statement (which specifies the conditions under which a packet cannot pass the access control list) in an access control list belongs to a crypto map in a crypto map set, the IPsec logic causes a jump to the next crypto map in the crypto map set, hoping for a better possible match. VPN Service Adapter (VSA) hardware has a restriction of 14 jumps.

#### **Sequence Numbers**

The number you assign to the *seq-num* argument should not be arbitrary. This number is used to rank multiple crypto map entries within a crypto map set. Within a crypto map set, a crypto map entry with a lower *seq-num* is evaluated before a map entry with a higher *seq-num*; that is, the map entry with the lower number has a higher priority.

For example, assume that a crypto map set contains three crypto map entries: mymap 10, mymap 20, and mymap 30. The crypto map set named "mymap" is applied to serial interface 0. When traffic passes through serial interface 0, traffic is evaluated first for mymap 10. If the traffic matches any access list permit statement entry in the extended access list in mymap 10, the traffic will be processed according to the information defined in mymap 10 (which includes establishing IPsec SAs when necessary). If the traffic does not match the mymap 10 access list, the traffic will be evaluated for mymap 20, and then mymap 30, until the traffic matches a permit entry in a map entry. (If the traffic does not match a permit entry in any crypto map entry, it will be forwarded without any IPsec security.)

#### **Dynamic Crypto Maps**

Refer to the "Usage Guidelines" section of the **crypto dynamic-map** command for a discussion on dynamic crypto maps.

Crypto map entries that reference dynamic map sets should be the lowest priority map entries, allowing inbound SA negotiation requests to try to match the static maps first. If the request does not match any of the static maps, it will be evaluated against the dynamic map set.

If a crypto map entry references a dynamic crypto map set, make it the lowest priority map entry by giving it the highest *seq-num* value of all the map entries in a crypto map set.

Create dynamic crypto map entries using the **crypto dynamic-map** command. After you create a dynamic crypto map set, add the dynamic crypto map set to a static crypto map set with the **crypto map**(global IPsec)command using the **dynamic** keyword.



IPv6 keywords are not supported on dynamic crypto maps.

#### TED

Tunnel Endpoint Discovery (TED) is an enhancement to the IPsec feature. Defining a dynamic crypto map allows you to dynamically determine an IPsec peer; however, only the receiving router has this ability. With TED, the initiating router can dynamically determine an IPsec peer for secure IPsec communications.

Dynamic TED helps to simplify the IPsec configuration on individual routers within a large network. Each node has a simple configuration that defines the local network that the router is protecting and the IPsec transforms that are required.



TED helps only in discovering peers; otherwise, TED does not function any differently from normal IPsec. Thus, TED does not improve the scalability of IPsec (in terms of performance or the number of peers or tunnels).

#### **Crypto Map Profiles**

Crypto map profiles are created using the **profile** *profile-name* keyword and argument combination. Crypto map profiles are used as configuration templates for dynamically creating crypto maps on demand for use with the L2TP Security feature. The relevant SAs in the crypto map profile will be cloned and used to protect IP traffic on the L2TP tunnel.



\_\_\_\_ Note

The set peer and match address commands are ignored by crypto profiles and should not be configured in the crypto map definition.

#### **Examples**

The following example shows the minimum required crypto map configuration when IKE will be used to establish the SAs:

```
crypto map mymap 10 ipsec-isakmp
match address 101
set transform-set my_t_set1
set peer 10.0.0.1
The following example shows the minimum required IPv6 crypto map configuration when IKE
will be used to establish the SAs:
crypto map ipv6 CM_V6 10 ipsec-isakmp
match address ACL_IPV6_1
set peer 2001:DB8:0:ABCD::1
The following example shows the minimum required crypto map configuration when the SAs are manual
```

The following example shows the minimum required crypto map configuration when the SAs are manually established:

```
crypto transform-set someset ah-md5-hmac esp-des
crypto map mymap 10 ipsec-manual
match address 102
set transform-set someset
set peer 10.0.0.5
set session-key inbound ah 256 98765432109876549876543210987654
```

```
set session-key outbound ah 256 fedcbafedcbafedcfedcbafedcbafedc
set session-key inbound esp 256 cipher 0123456789012345
set session-key outbound esp 256 cipher abcdefabcdefabcd
The following example shows the minimum required IPv6 crypto map configuration when the SAs
are manually established:
crypto map ipv6 CM_V6 ipsec-manual
match address ACL_V6_2
set transform-set someset
set peer 2001:DB8:0:ABCD::1
set session-key inbound ah 256 98765432109876549876543210987654
set session-key outbound ah 256 fedcbafedcbafedcfedcbafedcbafedc
set session-key inbound esp 256 cipher 0123456789012345
set session-key outbound esp 256 cipher abcdefabcdefabcd
The following example shows how to configure an IPsec crypto map set that includes a reference to a dynamic
```

I he following example shows how to configure an IPsec crypto map set that includes a reference to a dynamic crypto map set.

Crypto map "mymap 10" allows SAs to be established between the router and either or both the remote IPsec peers for traffic matching access list 101. Crypto map "mymap 20" allows either of the two transform sets to be negotiated with the remote peer for traffic matching access list 102.

Crypto map entry "mymap 30" references the dynamic crypto map set "mydynamicmap," which can be used to process inbound SA negotiation requests that do not match "mymap" entries 10 or 20. In this case, if the peer specifies a transform set that matches one of the transform sets specified in "mydynamicmap," for a flow permitted by the access list 103, IPsec will accept the request and set up SAs with the remote peer without previously knowing about the remote peer. If the request is accepted, the resulting SAs (and temporary crypto map entry) are established according to the settings specified by the remote peer.

The access list associated with "mydynamicmap 10" is also used as a filter. Inbound packets that match any access list permit statement in this list are dropped for not being IPsec protected. (The same is true for access lists associated with static crypto maps entries.) Outbound packets that match a permit statement without an existing corresponding IPsec SA are also dropped.

```
crypto map mymap 10 ipsec-isakmp
match address 101
set transform-set my_t_set1
set peer 10.0.0.1
set peer 10.0.0.2
crypto map mymap 20 ipsec-isakmp
match address 102
set transform-set my_t_set1 my_t_set2
set peer 10.0.0.3
crypto map mymap 30 ipsec-isakmp dynamic mydynamicmap
!
crypto dynamic-map mydynamicmap 10
match address 103
set transform-set my_t_set1 my_t_set2 my_t_set3
The following example shows how to configure TED on a Cisco router:
```

crypto map testtag 10 ipsec-isakmp dynamic dmap discover The following example shows how to configure a crypto profile to be used as a template for dynamically created crypto maps when IPsec is used to protect an L2TP tunnel:

crypto map 12tpsec 10 ipsec-isakmp profile 12tp The following example shows how to configure a crypto map for a GDOI group member:

```
crypto map diffint 10 gdoi
set group diffint
```

### **Related Commands**

I

I

Command	Description
crypto dynamic-map	Creates a dynamic crypto map entry and enters crypto map configuration command mode.
crypto isakmp profile	Audits IPsec user sessions.
crypto map (interface IPSec)	Applies a previously defined crypto map set to an interface.
crypto map local-address	Specifies and names an identifying interface to be used by the crypto map for IPsec traffic.
match address (IPSec)	Specifies an extended access list for a crypto map entry.
set peer (IPsec)	Specifies an IPsec peer in a crypto map entry.
set pfs	Specifies that IPsec should ask for PFS when requesting new SAs for this crypto map entry, or that IPsec requires PFS when receiving requests for new SAs.
set session-key	Specifies the IPsec session keys within a crypto map entry.
set transform-set	Specifies which transform sets can be used with the crypto map entry.
show crypto map (IPsec)	Displays the crypto map configuration.

## crypto map (interface IPsec)

To apply a previously defined crypto map set to an interface, use the crypto map command in interface configuration mode. To remove the crypto map set from the interface, use the **no** form of this command.

crypto map map-name [redundancy standby-group-name [stateful]]

**no crypto map** [map-nam e] [**redundancy** standby-group-name [**stateful**]]

#### **Syntax Description**

map-name	Name that identifies the crypto map set. This is the name assigned when the crypto map was created.
	When the <b>no</b> form of the command is used, this argument is optional. Any value supplied for the argument is ignored.
redundancy	(Optional) Defines a backup IP security (IPsec) peer. Both routers in the standby group are defined by the redundancy <i>standby-group-name</i> argument and share the same virtual IP address.
standby-group-name	(Optional) Refers to the name of the standby group as defined by Hot Standby Router Protocol (HSRP) standby commands.
stateful	(Optional) Enables IPsec stateful failover for the crypto map.

**Command Default** No crypto maps are assigned to interfaces.

**Command Modes** Interface configuration (config-if)

#### **Command History**

Release Modification	
11.2	This command was introduced.
12.1(9)E	This command was modified. The redundancy keyword and <i>standby-group-name</i> argument were added.
12.2(8)T	This command was modified. The redundancy keyword and <i>standby-group-name</i> argument were added.
12.2(11)T	This command was implemented on the Cisco AS5300 and Cisco AS5800 platforms.

Release	Modification	
12.2(9)YE	This command was modified. The redundancy keyword and <i>standby-group-name</i> argument were added.	
12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.	
12.3(11)T	This command was modified. The stateful keyword was added.	
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.	
12.2SX This command is supported in the Cisco IOS Release 12.2SX train. Su a specific 12.2SX release of this train depends on your feature set, pla and platform hardware.		

#### Usage Guidelin

Security threats, as well as the cryptographic technologies to help protect against them, are constantly changing. For more information about the latest Cisco cryptographic recommendations, see the Next Generation Encryption (NGE) white paper.

Use this command to assign a crypto map set to an interface. You must assign a crypto map set to an interface before that interface can provide IPsec services. Only one crypto map set can be assigned to an interface. If multiple crypto map entries have the same map name but a different sequence number, they are considered to be part of the same set and will all be applied to the interface. The crypto map entry that has the lowest sequence number is considered the highest priority and will be evaluated first. A single crypto map set can contain a combination of **ipsec-isakmp**and **ipsec-manual crypto map** entries.



A crypto map applied to a loopback interface is not supported.

The standby name must be configured on all devices in the standby group, and the standby address must be configured on at least one member of the group. If the standby name is removed from the router, the IPSec security associations (SAs) will be deleted. If the standby name is added again, regardless of whether the same name or a different name is used, the crypto map (using the **redundancy** option) will have to be reapplied to the interface.

Note

A virtual IP address must be configured in the standby group to enable either stateless or stateful redundancy.

The **stateful** keyword enables stateful failover of The Internet Key Exchange (IKE) and IPsec sessions. Stateful Switchover (SSO) must also be configured for IPsec stateful failover to operate correctly.

Note

Note

A crypto map cannot be applied to a tunnel interface. If you try to apply the tunnel interface to a crypto map, an error message is displayed as follows: crypto map is configured on tunnel interface. Currently only Group Domain of Interpretation (GDOI) crypto map is supported on tunnel interface.

#### **Examples**

The following example shows how to connect all remote Virtual Private Network (VPN) gateways to the router via 192.168.0.3::

```
crypto map mymap 1 ipsec-isakmp
set peer 10.1.1.1
reverse-route
set transform-set esp-3des-sha
match address 102
Interface FastEthernet 0/0
ip address 192.168.0.2 255.255.0
standby name group1
standby ip 192.168.0.3
crypto map mymap redundancy group1
access-list 102 permit ip 192.168.1.0 0.0.0.255 10.0.0.0 0.0.255.255
```

The crypto map on the interface binds this standby address as the local tunnel endpoint for all instances of mymap and, at the same time, ensures that stateless HSRP failover is facilitated between an active and standby device that belongs to the same standby group, named group1.

Reverse route injection (RRI) is also enabled to provide the ability for only the active device in the HSRP group to be advertising itself to inside devices as the next hop VPN gateway to the remote proxies. If a failover occurs, routes are deleted on the former active device and created on the new active device.

The following example shows how to configure IPSec stateful failover on the crypto map named to-per-outside:

```
crypto map to-peer-outside 10 ipsec-isakmp
set peer 209.165.200.225
set transform-set trans1
match address peer-outside
interface Ethernet0/0
ip address 209.165.201.1 255.255.255.224
standby 1 ip 209.165.201.3
standby 1 preempt
standby 1 name HA-out
standby 1 track Ethernet1/0
crypto map to-peer-outside redundancy HA-out stateful
```

## Related Commands Com

Command	Description
crypto map (global IPsec)	Creates or modifies a crypto map entry and enters the crypto map configuration mode.
crypto map local-address	Specifies and names an identifying interface to be used by the crypto map for IPsec traffic.
redundancy inter-device	Configures redundancy and enters inter-device configuration mode.
show crypto map (IPsec)	Displays the crypto map configuration.

I

I

I

Command	Description
standby ip	Assigns an IP address that is to be shared among the members of the HSRP group and owned by the primary IP address.
standby name	Assigns a user-defined group name to the HSRP redundancy group.

## crypto map (Xauth)

To configure Internet Key Exchange (IKE) extended authentication (Xauth) on a router, use the **crypto map** command in global configuration mode. To restore the default value, use the **no** form of this command.

#### crypto map [ipv6] map-name client authentication list list-name

no crypto map [ipv6] map-name [client authentication list]

#### **Syntax Description**

ipv6	(Optional) Specifies an IPv6 crypto map. For IPv4 crypto maps, use the command without this keyword.
map-name	Name you assign to the crypto map set.
client authentication list	Designates an extended user authentication method.
list-name	Character string used to name the list of authentication methods activated when a user logs in. The list name must match the list name defined during AAA configuration.

### **Command Default** Xauth is disabled.

**Command Modes** Global configuration (config)

<b>Command History</b>	Release	Modification
	12.1(1)T	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
	15.1(4)M	This command was modified. The <b>ipv6</b> keyword was added.

#### **Usage Guidelines**

Before configuring Xauth, you should complete the following tasks:

- Set up an authentication list using AAA commands.
- Configure an IP Security transform.

- Configure a crypto map.
- Configure Internet Security Association Key Management Protocol (ISAKMP) policy.

After enabling Xauth, you should apply the crypto map on which Xauth is configured to the router interface.

**Examples** The following example shows how to configure user authentication (a list of authentication methods called *xauthlist*) on an existing static crypto map called *xauthmap* :

crypto map xauthmap client authentication list xauthlist The following example shows how to configure user authentication (a list of authentication methods called *CM\_V6list*) on an existing static IPv6 crypto map called CM\_V6:

crypto map ipv6 CM\_V6 client authentication list CM\_V6list The following example shows how to configure user authentication (a list of authentication methods called *xauthlist*) on a dynamic crypto map called *xauthdynamic* that has been applied to a static crypto map called *xauthmap*:

crypto map xauthmap client authentication list xauthlist crypto map xauthmap 10 ipsec-isakmp dynamic xauthdynamic

### Related Commands

Command	Description
aaa authentication login	Sets AAA authentication at login.
crypto ipsec transform-set	Defines a transform set, which is an acceptable combination of security protocols and algorithms, and enters crypto transform configuration mode.
crypto isakmp key	Configures a preshared authentication key.
crypto isakmp policy	Defines an IKE policy, and enters ISAKMP policy configuration mode.
crypto map (global configuration)	Creates or modifies a crypto map entry, and enters the crypto map configuration mode.
interface	Enters the interface configuration mode.

## crypto map client configuration address

To configure IKE Mode Configuration on your router, use the **crypto map client configuration address** command in global configuration mode. To disable IKE Mode Configuration, use the **no** form of this command.

#### crypto map tag client configuration address [initiate| respond]

no crypto map tag client configuration address

Syntax Description	tag	The name that identifies the crypto map.
	initiate	(Optional) A keyword that indicates the router will attempt to set IP addresses for each peer.
	respond	(Optional) A keyword that indicates the router will accept requests for IP addresses from any requesting peer.

Command Default	IKE Mode Configuration is not enabled.
-----------------	--

### **Command Modes** Global configuration

Command HistoryReleaseModification12.0(4)XEThis command was introduced.12.0(7)TThis command was implemented in Cisco IOS release 12.0(7)T.12.2(33)SRAThis command was integrated into Cisco IOS Release 12.2(33)SRA.12.2SXThis command is supported in the Cisco IOS Release 12.2SX train. Support<br/>in a specific 12.2SX release of this train depends on your feature set, platform,<br/>and platform hardware.

## **Usage Guidelines** At the time of this publication, this feature is an IETF draft with limited support. Therefore this feature was not designed to enable the configuration mode for every IKE connection by default.

#### **Examples**

The following examples configure IKE Mode Configuration on your router:

crypto map dyn client configuration address initiate crypto map dyn client configuration address respond

### **Related Commands**

ſ

Command	Description
crypto map (global)	Creates or modifies a crypto map entry and enters the crypto map configuration mode

## crypto map gdoi fail-close

To specify that the crypto map is to work in fail-close mode, use the **crypto map gdoi fail-close** command in global configuration mode. To disable fail-close mode, use the **no** form of this command.

crypto map [ipv6]map-name gdoi fail-close

no crypto map[ipv6]map-name gdoi fail-close

Syntax Description ipv6 S	Specifies an IPv6 crypto map.	
	Specifies an IPv6 crypto map.	

**Command Default** The crypto map is not in fail-close mode.

**Command Modes** Global configuration (config)

<b>Command History</b>	Release	Modification
	12.4(22)T	This command was introduced.
	15.2(3)T	This command was modified. The <b>ipv6</b> keyword was added.

#### Examples

The following example shows how to activate fail-close mode for an IPv4 crypto map named map1. This example also defines two extended IP access lists. Unencrypted traffic from access list 102 is allowed before the group member is registered:

```
Router> enable
Router# configure terminal
Router(config)# crypto map map1 gdoi fail-close
Router(config-crypto-map-fail-close)# match address 102
Router(config-crypto-map-fail-close)# activate
Router(config-crypto-map-fail-close)# exit
Router(config)# crypto map map1 10 gdoi
Router(config-crypto-map)# set group ks1_group
Router(config-crypto-map)# match address 101
Router(config-crypto-map)# exit
Router(config)# access-list 101 deny ip 10.0.1.0 0.0.255 10.0.1.0 0.0.0.255
Router(config)# end
The following example shows how to activate fail-close mode for an IPv6 crypto map named map2. This
```

example also defines two IPv6 access lists. Unencrypted traffic from access list ACL\_GETV6\_ANY6 is allowed before the group member is registered:

```
Router> enable
Router# configure terminal
Router(config)# crypto map ipv6 map2 gdoi fail-close
Router(config-crypto-map-fail-close)# match address ACL_GETV6_ANY6
Router(config-crypto-map-fail-close)# activate
```

ſ

Router(config-crypto-map-fail-close)# exit
Router(config)# crypto map ipv6 map2 20 gdoi
Router(config-crypto-map)# set group ks2\_group
Router(config-crypto-map)# match address ACL\_GETV6\_ANY5
Router(config)# ipv6 access-list ACL\_GETV6\_ANY5
Router(config-ipv6-acl)# deny tcp 2001:DB8:0000::/48 2001:DB8:0001::/48 eq telnet
Router(config)# ipv6 access-list ACL\_GETV6\_ANY6
Router(config)# ipv6 access-list ACL\_GETV6\_ANY6
Router(config-ipv6-acl)# deny tcp any eq telnet any
Router(config-ipv6-acl)# end

## crypto map (isakmp)

To enable Internet Key Exchange (IKE) querying of authentication, authorization, and accounting (AAA) for tunnel attributes in aggressive mode, use the **crypto map**command in global configuration mode. To restore the default value, use the **no** form of this command.

crypto map [ipv6] map-name isakmp authorization list list-name

no crypto map [ipv6] map-name [isakmp authorization list]

#### **Syntax Description**

ipv6	(Optional) Specifies an IPv6 crypto map. For IPv4 crypto maps, use the command without this keyword.
map-name	Name you assign to the crypto map set.
isakmp authorization list	Specifies the Internet Security Association Key Management Protocol (ISAKMP) configuration settings and authorization parameters.
list-name	Character string used to name the list of authorization methods activated when a user logs in. The list name must match the list name defined during AAA configuration.

### **Command Default** No default behavior or values.

### **Command Modes** Global configuration (config)

<b>Command History</b>	Release	Modification
	12.1(1)T	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
	15.1(4)M	This command was modified. The <b>ipv6</b> keyword was added.

#### Usage Guidelines U

Use this command to enable key lookup from an AAA server.

interface

I

	Preshared keys deployed in a large-scale Virtual Private Network (VPN) without a certification authority with dynamic IP addresses, are accessed during aggression mode of IKE negotiation through an AAA ser Thus, users have their own key, which is stored on an external AAA server. This allows for the central management of the user database, linking it to an existing database and allowing all users to have their o unique and secure pre-shared keys.		
	<ul> <li>Before configuring this command, you should perform the following tasks:</li> <li>Set up an authorization list using AAA commands.</li> <li>Configure an IPsec transform.</li> <li>Configure a crypto map.</li> </ul>		
	Configure an ISAKMP policy using IPsec and I	KE commands.	
	After enabling this command, you should apply the previously defined crypto map to the interface.		
Examples	The following example shows how to configure the crypto map command for IPv4 crypto maps:		
	crypto map ikessaaamap isakmp authorization list ikessaaalist crypto map ikessaaamap 10 ipsec-isakmp dynamic ikessaaadyn The following example shows how to configure the crypto map command for IPv6 crypto maps: crypto map ipv6 CM_V6 isakmp authorization list aaa crypto map ipv6 CM_V6 10 ipsec-isakmp dynamic aaadyn		
Related Commands	Command Description		
	aaa authorization	Sets parameters that restrict a user's network access.	
	crypto ipsec transform-set	Defines a transform set, which is an acceptable combination of security protocols and algorithms, and enters crypto transform configuration mode.	
	crypto isakmp key	Configures a preshared authentication key.	
	crypto isakmp policy	Defines an IKE policy and enters ISAKMP policy configuration mode.	
	crypto map (global configuration)	Creates or modifies a crypto map entry and enters the crypto map configuration mode.	

Enters interface configuration mode.

## crypto map isakmp-profile

To configure an Internet Security Association and Key Management Protocol (ISAKMP) profile on a crypto map, use the **crypto map isakmp-profile** command in global configuration mode. To restore the default values on the crypto map, use the **no** form of this command.

crypto map map-name isakmp-profile isakmp-profile-name

no crypto map map-name isakmp-profile isakmp-profile-name

#### **Syntax Description**

map-name	Name assigned to the crypto map set.
isakmp-profile-name	Character string used to name the ISAKMP profile that is used during an Internet Key Exchange (IKE) Phase 1 and Phase 1.5 exchange. The <i>isakmp-profile-name</i> must match the ISAKMP profile name that was defined during the ISAKMP profile configuration.

- **Command Default** No default behavior or values
- **Command Modes** Global configuration

<b>Command History</b>	Release	Modification
	12.2(15)T	This command was introduced.
	Cisco IOS XE Release 2.6	This command was integrated into Cisco IOS XE Release 2.6.
<b>Usage Guidelines</b> This command describes the ISAKMP profile to use to start the IKE exchange. Before command, you must set up the ISAKMP profile.		

**Examples** The following example shows that an ISAKMP profile is configured on a crypto map:

crypto map vpnmap isakmp-profile vpnprofile

<b>Related Commands</b>	Command	Description
	crypto ipsec transform-set	Defines a transform setan acceptable combination of security protocols and algorithms.

I

ſ

Command	Description
crypto map (global)	Creates or modifies a crypto map entry.

## crypto map local-address

To specify and name an identifying interface to be used by the crypto map for IPSec traffic, use the **crypto map local-address**command in global configuration mode. To remove this command from the configuration, use the **no** form of this command.

crypto map map-name local-address interface-id

no crypto map map-name local-address

#### **Syntax Description**

map-name	Name that identifies the crypto map set. This is the name assigned when the crypto map was created.
interface-id	The identifying interface that should be used by the router to identify itself to remote peers.
	If Internet Key Exchange is enabled and you are using a certification authority (CA) to obtain certificates, this should be the interface with the address specified in the CA certificates.

**Command Default** No default behavior or values.

**Command Modes** Global configuration

<b>Command History</b>	Release	Modification
	11.3 T	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

#### **Usage Guidelines**

If you apply the same crypto map to two interfaces and do not use this command, two separate security associations (with different local IP addresses) could be established to the same peer for similar traffic. If you are using the second interface as redundant to the first interface, it could be preferable to have a single security association (with a single local IP address) created for traffic sharing the two interfaces. Having a single security association decreases overhead and makes administration simpler.

This command allows a peer to establish a single security association (and use a single local IP address) that is shared by the two redundant interfaces.

If applying the same crypto map set to more than one interface, the default behavior is as follows:

- Each interface will have its own security association database.
- The IP address of the local interface will be used as the local address for IPSec traffic originating from/destined to that interface.

However, if you use a local-address for that crypto map set, it has multiple effects:

- Only one IPSec security association database will be established and shared for traffic through both interfaces.
- The IP address of the specified interface will be used as the local address for IPSec (and IKE) traffic originating from or destined to that interface.

One suggestion is to use a loopback interface as the referenced local address interface, because the loopback interface never goes down.

**Examples** The following example assigns crypto map set "mymap" to the S0 interface and to the S1 interface. When traffic passes through either S0 or S1, the traffic will be evaluated against the all the crypto maps in the "mymap" set. When traffic through either interface matches an access list in one of the "mymap" crypto maps, a security association will be established. This same security association will then apply to both S0 and S1 traffic that matches the originally matched IPSec access list. The local address that IPSec will use on both interfaces will be the IP address of interface loopback0.

```
interface S0
  crypto map mymap
interface S1
  crypto map mymap
crypto map mymap local-address loopback0
```

#### **Related Commands**

Command	Description
crypto map (interface IPSec)	Applies a previously defined crypto map set to an interface.

## crypto map redundancy replay-interval

To modify the interval at which inbound and outbound replay updates are passed from an active device to a standby device, use the **crypto map redundancy replay-interval** command in global configuration mode. To return to the default functionality, use the **no** form of this command.

crypto map map-name redundancy replay-interval inbound in-value outbound out-value

no crypto map map-name redundancy replay-interval inbound in-value outbound out-value

### Syntax Description

map-name	Name that identifies the crypto map set. This is the name assigned when the crypto map was created.
inbound in-value	Number of inbound packets that are processed before an anti-replay update is sent from the active router to the standby router.
outbound out-value	Number of outbound packets that are processed before an anti-replay update is sent from the active router to the standby router.

# Command Defaultinboundin-value : one update every 1,000 packetsoutboundout-value : one update every 100,000 packets

### **Command Modes** Global configuration

<b>Command History</b>	Release	Modification
	12.3(11)T	This command was introduced.

#### Usage Guidelin

Note

This command can be used only in conjunction with IPSec stateful failover on a crypto map.

Stateful failover enables a router to continue processing and forwarding packets after a planned or unplanned outage occurs; that is, a backup (secondary) router automatically takes over the tasks of the active (primary) router if the active router loses connectivity for any reason.

The **crypto map redundancy replay-interval** command allows you to modify the interval in which an IP redundancy-enabled crypto map sends anti-replay updates from the active router to the standby router.

### Examples

I

The following example shows how to enable replay checking for the crypto map "to-peer-outside" and enable IPSec stateful failover:

crypto map to-peer-outside redundancy replay-interval inbound 1000 outbound 10000
crypto map to-peer-outside 10 ipsec-isakmp
set peer 209.165.200.225
set transform-set trans1
match address peer-outside
!
interface Ethernet0/0
ip address 209.165.201.1 255.255.255.224
standby 1 ip 209.165.201.3
standby 1 preempt
standby 1 name HA-out
standby 1 track Ethernet1/0
crypto map to-peer-outside redundancy HA-out stateful

## crypto mib ipsec flowmib history failure size

To change the size of the IP Security (IPSec) MIB failure history table, use the **crypto mib ipsec flowmib history failure size**command in global configuration mode.

crypto mib ipsec flowmib history failure size number

Syntax Description	number		Size of the failure history table.
Command Default	If this command is not	used, the default table size is 2	200.
Command Modes	Global configuration		
Command History	Release Modification		
	12.1(4)E	This command was in	ntroduced.
	12.2(4)T	This command was in	ntegrated into Cisco IOS Release 12.2(4)T.
	12.2(14)8	This command was in	ntegrated into Cisco IOS Release 12.2(14)S.
	12.2(33)SRA	This command was in	ntegrated into Cisco IOS Release 12.2(33)SRA.
	12.28X		ported in the Cisco IOS Release 12.2SX train. Support elease of this train depends on your feature set, platform, e.
Usage Guidelines	Use the <b>crypto mib ipsec flowmib history failure size</b> command to change the size of a failure history table. <b>If you do not configure the size of a failure history table, the default of 200 will be</b> implemented. A failure history table stores the reason for tunnel failure and the time failure occurred. A failure history table can be used as a simple method to distinguish between a normal and an abnormal tunnel termination. That is, if a tunnel entry in the tunnel history table has no associated failure record, the tunnel must have terminated normally. However, every failure does not correspond to a tunnel. Supported setup failures are recorded in the failure table, but a history table is not associated because a tunnel was never set up.		
Examples	The following example shows the size of a failure history table configured to be 140:		
	crypto mib ipsec fl	owmib history failure size 140	

### **Related Commands**

ſ

Command	Description
crypto mib ipsec flowmib history tunnel size	Changes the size of the IPSec tunnel history table.
show crypto mib ipsec flowmib history failure size	Displays the size of the IPSec failure history table.

## crypto mib ipsec flowmib history tunnel size

To change the size of the IP Security (IPSec) tunnel history table, use the **crypto mib ipsec flowmib history tunnel size** command in global configuration mode.

crypto mib ipsec flowmib history tunnel size number

Syntax Description	number	Size of the tunnel history table.

**Command Default** The default table size is 200.

**Command Modes** Global configuration

<b>Command History</b>	Release	Modification
	12.1(4)E	This command was introduced.
	12.2(4)T	This command was integrated into Cisco IOS Release 12.2(4)T.
	12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

#### **Usage Guidelines**

Use the **crypto mib ipsec flowmib history tunnel size**command to change the size of a tunnel history table. If you do not configure the size of a tunnel history table, the default of 200 will be implemented.

A tunnel history table stores the attribute and statistics records, which contain the attributes and the last snapshot of the traffic statistics of a given tunnel. A tunnel history table accompanies a failure table, so you can display the complete history of a given tunnel. However, a tunnel history table does not accompany every failure table because every failure does not correspond to a tunnel. Thus, supported setup failures are recorded in the failure table, but an associated history table is not recorded because a tunnel was never set up.

As an optimization, a tunnel endpoint table can be combined with a tunnel history table. However, if a tunnel endpoint table is combined, all three tables (the failure history table, tunnel history table, and the endpoint table) must remain the same size even though the MIB allows each table to be distinct.

### **Examples** The following example shows the size of a tunnel history table configured to be 130:

crypto mib ipsec flowmib history tunnel size 130

### **Related Commands**

I

Command	Description
crypto mib ipsec flowmib history failure size	Changes the size of the IPSec failure history table.
show crypto mib ipsec flowmib history tunnel size	Displays the size of the IPSec tunnel history table.

## crypto mib topn

To configure TopN sampling parameters, use the **crypto mib topn**command in global configuration mode. To disable TopN sampling, use the **no** form of this command.

crypto mib topn [interval seconds] [stop seconds]

no crypto mib topn [interval seconds] [stop seconds]

#### **Syntax Description**

interval seconds	(Optional) Specifies the number of seconds between samples. The allowable range is from 60 to 86400 (60 seconds to 24 hours). The default is 300 (5 minutes). Defined in the MIB as TopnMinSampleInterval.
stop seconds	(Optional) Specifies the time, in seconds, from when this command is executed until sampling ceases.
	The allowable range is from 0 to 604800. A zero (0) indicates continuous sampling and is the default. For any value other than 0, the stop time value must be greater than or equal to the sampling interval value. Defined in the MIB as TopnStopTime.

**Command Default** No TopN sampling parameters are configured.

### **Command Modes** Global configuration

### **Command History**

Release	Modification
12.1(6)E	This command was introduced.
12.2(9)YE	This command was integrated into Cisco IOS Release 12.2(9)YE.
12.2(9)YO1	This command was integrated into Cisco IOS Release 12.2(9)YO1.
12.2(13)T	This command was integrated into Cisco IOS Release 12.2(13)T.
12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.28X	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
	12.1(6)E 12.2(9)YE 12.2(9)YO1 12.2(13)T 12.2(14)S 12.2(33)SRA

I

ſ

. . . ..

Usage Guidelines	5	cording to your chosen criteria. You will not see the stop parameter	
	than zero. Otherwise, the current sam is enabled), and sampling occurs conti	<b>ng configuration</b> command if the stop parameter is set at a value greater appling parameters are recorded in the active configuration (if sampling nuously (at the specified intervals) until, and after, the device is rebooted. your criteria queries performed by XSM clients (such as VPN Device issed.	
	subset of the IPSec MIB Export (IPS of active Internet Key Exchange (IKI the VPN Device Manager (VDM) ap	racteristics of the IP Security (IPSec) MIBs. TopN ( <b>topn</b> ) is a special MX) interface that provides a set of queries that allows ranked reports E) or IPSec tunnels to be obtained depending on certain criteria. While plication retrieves and presents the data elements defined in the IKE and t use the Simple Network Management Protocol (SNMP) interface.	
Examples	The following example shows the <b>crypto mib topn</b> command being enabled with an interval frequency of 240 seconds and a designated stop time of 1200 seconds (20 minutes). At that time, the assigned sampling ceases.		
	crypto mib topn interval 240 st	op 1200	
Related Commands	Command	Description	
	xsm	Enables XSM client access to the router.	