



## ip source-track through ivrf

---

- [ip ssh, page 2](#)
- [ip ssh dh min size, page 4](#)
- [ip ssh dscp, page 5](#)
- [ip ssh pubkey-chain, page 7](#)
- [ip ssh stricthostkeycheck, page 8](#)
- [ip ssh version, page 9](#)
- [ip verify unicast reverse-path, page 11](#)
- [ipv6 tacacs source-interface, page 15](#)

# ip ssh

To configure Secure Shell (SSH) control parameters on your router, use the **ip ssh** command in global configuration mode. To restore the default value, use the **no** form of this command.

**ip ssh** [*timeout seconds*] **authentication-retries** *integer*]

**no ip ssh** [*timeout seconds*] **authentication-retries** *integer*]

## Syntax Description

<b>timeout</b>	(Optional) The time interval that the router waits for the SSH client to respond.  This setting applies to the SSH negotiation phase. Once the EXEC session starts, the standard timeouts configured for the vty apply. By default, there are 5 vtys defined (0-4), therefore 5 terminal sessions are possible. After the SSH executes a shell, the vty timeout starts. The vty timeout defaults to 10 minutes.
<i>seconds</i>	(Optional) The number of seconds until timeout disconnects, with a maximum of 120 seconds. The default is 120 seconds.
<b>authentication- retries</b>	(Optional) The number of attempts after which the interface is reset.
<i>integer</i>	(Optional) The number of retries, with a maximum of 5 authentication retries. The default is 3.

## Command Default

SSH control parameters are set to default router values.

## Command Modes

Global configuration (config)

## Command History

Release	Modification
12.0(5)S	This command was introduced.
12.1(1)T	This command was integrated into Cisco IOS Release 12.1(1) T.
12.2(17a)SX	This command was integrated into Cisco IOS Release 12.2(17a)SX.
12.2(33)SRA	This command was integrated into Cisco IOS release 12.(33)SRA.
Cisco IOS XE Release 2.4	This command was implemented on the Cisco ASR 1000 series routers.

### Usage Guidelines

Before you configure SSH on your router, you must enable the SSH server using the **crypto key generate rsa** command.

### Examples

The following examples configure SSH control parameters on your router:

```
ip ssh timeout 120
ip ssh authentication-retries 3
```

## ip ssh dh min size

To configure the modulus size on the Secure Shell (SSH) server, use the **ip ssh dh min size** command in privileged EXEC mode. To disable the configuration, use the **no** form of this command.

**ip ssh dh min size** [ *number* ]

**no ip ssh dh min size**

### Syntax Description

<i>number</i>	(Optional) Minimum number of bits in the key size. The default is 1024.
---------------	---

### Command Default

Bit key support is disabled.

### Command Modes

Privileged EXEC (#)

### Command History

Release	Modification
12.4(20)T	This command was introduced.
15.1(2)S	This command was integrated into Cisco IOS Release 15.1(2)S.

### Usage Guidelines

Use the **ip ssh dh min size** command to ensure that the CLI is successfully parsed from either the client side or the server side.

### Examples

The following example shows how to set the minimum modulus size to 2048 bits:

```
Router> enable
Router# ip ssh dh min size 2048
```

### Related Commands

Command	Description
<b>show ip ssh</b>	Displays the status of SSH server connections.

## ip ssh dscp

To specify the IP differentiated services code point (DSCP) value that can be set for a Secure Shell (SSH) configuration, use the **ip ssh dscp** command in global configuration mode. To restore the default value, use the **no** form of this command.

**ip ssh dscp** *number*

**no ip ssh dscp** *number*

### Syntax Description

<i>number</i>	Value that can be set. The default value is 0 (zero). <ul style="list-style-type: none"><li>• <i>number</i> --0 through 63.</li></ul>
---------------	---

### Command Default

The IP DSCP value is not specified.

### Command Modes

Global configuration (config)

### Command History

Release	Modification
12.4(20)S	This command was introduced.
12.2SR	This command is supported in the Cisco IOS Release 12.2SR train. Support in a specific 12.2SR train depends on your feature set, platform, and platform hardware.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX train depends on your feature set, platform, and platform hardware.
12.4(22)T	This command was integrated into Cisco IOS Release 12.4(22)T.

### Usage Guidelines

IP DSCP values can be configured on both the SSH client and the SSH server for SSH traffic that is generated on either end.

### Examples

The following example shows that the DSCP value is set to 35:

```
Router(config)# ip ssh dscp 35
```

**Related Commands**

Command	Description
ip ssh precedence	Specifies the IP precedence value that may be set.

# ip ssh pubkey-chain

To configure Secure Shell RSA (SSH-RSA) keys for user and server authentication on the SSH server, use the **ip ssh pubkey-chain** command in global configuration mode. To remove SSH-RSA keys for user and server authentication on the SSH server, use the **no** form of this command.

**ip ssh pubkey-chain**

**no ip ssh pubkey-chain**

**Syntax Description** This command has no arguments or keywords.

**Command Default** SSH-RSA keys are not configured.

**Command Modes** Global configuration (config)

Command History	Release	Modification
	15.0(1)M	This command was introduced.
	15.1(1)S	This command was integrated into Cisco IOS Release 15.1(1)S.

**Usage Guidelines** Use the **ip ssh pubkey-chain** command to ensure SSH server and user public key authentication.

**Examples** The following example shows how to enable public key generation:

```
Router(config)# ip ssh pubkey-chain
```

Related Commands	Command	Description
	<b>ip ssh stricthostkeycheck</b>	Enables strict host key checking on the SSH server.

# ip ssh stricthostkeycheck

To enable strict host key checking on the Secure Shell (SSH) server, use the **ip ssh stricthostkeycheck** command in global configuration mode. To disable strict host key checking, use the **no** form of this command.

**ip ssh stricthostkeycheck**

**no ip ssh stricthostkeycheck**

## Syntax Description

This command has no arguments or keywords.

## Command Default

Strict host key checking on the SSH server is not enabled.

## Command Modes

Global configuration (config)

## Command History

Release	Modification
15.0(1)M	This command was introduced.
15.1(1)S	This command was integrated into Cisco IOS Release 15.1(1)S.

## Usage Guidelines

Use the **ip ssh stricthostkeycheck** command to ensure SSH server side strict checking. Configuring the **ip ssh stricthostkeycheck** command authenticates all servers.



### Note

This command is not available on SSH Version 1.

- If the **ip ssh pubkey-chain** command is not configured, the **ip ssh stricthostkeycheck** command will lead to connection failure in SSH Version 2.

## Examples

The following example shows how to enable strict host key checking:

```
Router(config)# ip ssh stricthostkeycheck
```

## Related Commands

Command	Description
<b>ip ssh pubkey-chain</b>	Configures SSH-RSA keys for user and server authentication on the SSH server.



## ip ssh version

To specify the version of Secure Shell (SSH) to be run on a router, use the **ip ssh version** command in global configuration mode. To disable the version of SSH that was configured and to return to compatibility mode, use the **no** form of this command.

**ip ssh version** [1| 2]

**no ip ssh version** [1| 2]

### Syntax Description

<b>1</b>	(Optional) Router runs only SSH Version 1.
<b>2</b>	(Optional) Router runs only SSH Version 2.

### Command Default

If this command is not configured, SSH operates in compatibility mode, that is, Version 1 and Version 2 are both supported.

### Command Modes

Global configuration

### Command History

Release	Modification
12.3(4)T	This command was introduced.
12.3(2)XE	This command was integrated into Cisco IOS Release 12.3(2)XE.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.
12.3(7)JA	This command was integrated into Cisco IOS Release 12.3(7)JA.
12.0(32)SY	This command was integrated into Cisco IOS Release 12.0(32)SY.
12.4(20)T	This command was integrated into Cisco IOS Release 12.4(20)T.
15.2(2)SA2	This command was implemented on the Cisco ME 2600X Series Ethernet Access Switches.

### Usage Guidelines

You can use this command with the **2** keyword to ensure that your router will not inadvertently establish a weaker SSH Version 1 connection.

## Examples

The following example shows that only SSH Version 1 support is configured:

```
Router (config)# ip ssh version 1
```

The following example shows that only SSH Version 2 is configured:

```
Router (config)# ip ssh version 2
```

The following example shows that SSH Versions 1 and 2 are configured:

```
Router (config)# no ip ssh version
```

## Related Commands

Command	Description
debug ip ssh	Displays debug messages for SSH.
disconnect ssh	Terminates a SSH connection on your router.
<b>ip ssh</b>	Configures SSH control parameters on your router.
ip ssh rsa keypair-name	Specifies which RSA key pair to use for a SSH connection.
show ip ssh	Displays the SSH connections of your router.

# ip verify unicast reverse-path



## Note

This command was replaced by the **ip verify unicast source reachable-via** command effective with Cisco IOS Release 12.0(15)S. The **ip verify unicast source reachable-via** command allows for more flexibility and functionality, such as supporting asymmetric routing, and should be used for any Reverse Path Forward implementation. The **ip verify unicast reverse-path** command is still supported.

To enable Unicast Reverse Path Forwarding (Unicast RPF), use the **ip verify unicast reverse-path** command in interface configuration mode. To disable Unicast RPF, use the **no** form of this command.

**ip verify unicast reverse-path** [ *list* ]

**no ip verify unicast reverse-path** [ *list* ]

## Syntax Description

<i>list</i>	(Optional) Specifies a numbered access control list (ACL) in the following ranges: <ul style="list-style-type: none"> <li>• 1 to 99 (IP standard access list)</li> <li>• 100 to 199 (IP extended access list)</li> <li>• 1300 to 1999 (IP standard access list, expanded range)</li> <li>• 2000 to 2699 (IP extended access list, expanded range)</li> </ul>
-------------	--

## Command Default

Unicast RPF is disabled.

## Command Modes

Interface configuration (config-if)

## Command History

Release	Modification
11.1(CC) 12.0	This command was introduced. This command was not included in Cisco IOS Release 11.2 or 11.3 12.1(2)T Added ACL support using the <i>list</i> argument. Added per-interface statistics on dropped or suppressed packets.

Release	Modification
12.0(15)S	The <b>ip verify unicast source reachable-via</b> command replaced this command, and the following keywords were added to the <b>ip verify unicast source reachable-via</b> command: <b>allow-default</b> , <b>allow-self-ping</b> , <b>rx</b> , and <b>any</b> .
12.1(8a)E	The <b>ip verify unicast reverse-path</b> command was integrated into Cisco IOS Release 12.1(8a)E.
12.2(14)S	The <b>ip verify unicast reverse-path</b> command was integrated into Cisco IOS Release 12.2(14)S.
12.2(14)SX	The <b>ip verify unicast reverse-path</b> command was integrated into Cisco IOS Release 12.2(14)SX.
12.2(33)SRA	The <b>ip verify unicast reverse-path</b> command was integrated into Cisco IOS Release 12.2(33)SRA.

### Usage Guidelines

Use the **ip verify unicast reverse-path interface** command to mitigate problems caused by malformed or forged (spoofed) IP source addresses that are received by a router. Malformed or forged source addresses can indicate denial of service (DoS) attacks on the basis of source IP address spoofing.

When Unicast RPF is enabled on an interface, the router examines all packets that are received on that interface. The router checks to ensure that the source address appears in the Forwarding Information Base (FIB) and that it matches the interface on which the packet was received. This "look backwards" ability is available only when Cisco Express Forwarding is enabled on the router because the lookup relies on the presence of the FIB. Cisco Express Forwarding generates the FIB as part of its operation.

To use Unicast RPF, enable Cisco Express Forwarding switching or distributed Cisco Express Forwarding switching in the router. There is no need to configure the input interface for Cisco Express Forwarding switching. As long as Cisco Express Forwarding is running on the router, individual interfaces can be configured with other switching modes.



#### Note

It is very important for Cisco Express Forwarding to be configured globally in the router. Unicast RPF will not work without Cisco Express Forwarding.



#### Note

Unicast RPF is an input function and is applied on the interface of a router only in the ingress direction.

The Unicast Reverse Path Forwarding feature checks to determine whether any packet that is received at a router interface arrives on one of the best return paths to the source of the packet. The feature does this by doing a reverse lookup in the Cisco Express Forwarding table. If Unicast RPF does not find a reverse path for the packet, Unicast RPF can drop or forward the packet, depending on whether an ACL is specified in the Unicast Reverse Path Forwarding command. If an ACL is specified in the command, then when (and only when) a packet fails the Unicast RPF check, the ACL is checked to determine whether the packet should be dropped (using a deny statement in the ACL) or forwarded (using a permit statement in the ACL). Whether

a packet is dropped or forwarded, the packet is counted in the global IP traffic statistics for Unicast RPF drops and in the interface statistics for Unicast RPF.

If no ACL is specified in the Unicast Reverse Path Forwarding command, the router drops the forged or malformed packet immediately and no ACL logging occurs. The router and interface Unicast RPF counters are updated.

Unicast RPF events can be logged by specifying the logging option for the ACL entries used by the Unicast Reverse Path Forwarding command. Log information can be used to gather information about the attack, such as source address, time, and so on.

### Where to Use RPF in Your Network

Unicast RPF may be used on interfaces in which only one path allows packets from valid source networks (networks contained in the FIB). Unicast RPF may also be used in cases for which a router has multiple paths to a given network, as long as the valid networks are switched via the incoming interfaces. Packets for invalid networks will be dropped. For example, routers at the edge of the network of an Internet service provider (ISP) are likely to have symmetrical reverse paths. Unicast RPF may still be applicable in certain multi-homed situations, provided that optional Border Gateway Protocol (BGP) attributes such as weight and local preference are used to achieve symmetric routing.

With Unicast RPF, all equal-cost "best" return paths are considered valid. This means that Unicast RPF works in cases where multiple return paths exist, provided that each path is equal to the others in terms of the routing cost (number of hops, weights, and so on) and as long as the route is in the FIB. Unicast RPF also functions where Enhanced Internet Gateway Routing Protocol (EIGRP) variants are being used and unequal candidate paths back to the source IP address exist.

For example, routers at the edge of the network of an ISP are more likely to have symmetrical reverse paths than routers that are in the core of the ISP network. Routers that are in the core of the ISP network have no guarantee that the best forwarding path out of the router will be the path selected for packets returning to the router. In this scenario, you should use the new form of the command, **ip verify unicast source reachable-via**, if there is a chance of asymmetrical routing.

## Examples

The following example shows that the Unicast Reverse Path Forwarding feature has been enabled on a serial interface:

```
ip cef
! or "ip cef distributed" for RSP+VIP based routers
!
interface serial 5/0/0
 ip verify unicast reverse-path
```

The following example uses a very simple single-homed ISP to demonstrate the concepts of ingress and egress filters used in conjunction with Unicast RPF. The example illustrates an ISP-allocated classless interdomain routing (CIDR) block 192.168.202.128/28 that has both inbound and outbound filters on the upstream interface. Be aware that ISPs are usually not single-homed. Hence, provisions for asymmetrical flows (when outbound traffic goes out one link and returns via a different link) need to be designed into the filters on the border routers of the ISP.

```
ip cef distributed
!
interface Serial 5/0/0
 description Connection to Upstream ISP
 ip address 192.168.200.225 255.255.255.255
 no ip redirects
 no ip directed-broadcast
 no ip proxy-arp
 ip verify unicast reverse-path
 ip access-group 111 in
```

```

ip access-group 110 out
!
access-list 110 permit ip 192.168.202.128 10.0.0.31 any
access-list 110 deny ip any any log
access-list 111 deny ip host 10.0.0.0 any log
access-list 111 deny ip 172.16.0.0 255.255.255.255 any log
access-list 111 deny ip 10.0.0.0 255.255.255.255 any log
access-list 111 deny ip 172.16.0.0 255.255.255.255 any log
access-list 111 deny ip 192.168.0.0 255.255.255.255 any log
access-list 111 deny ip 209.165.202.129 10.0.0.31 any log
access-list 111 permit ip any any

```

The following example demonstrates the use of ACLs and logging with Unicast RPF. In this example, extended ACL 197 provides entries that deny or permit network traffic for specific address ranges. Unicast RPF is configured on Ethernet interface 0 to check packets arriving at that interface.

For example, packets with a source address of 192.168.201.10 arriving at Ethernet interface 0 are dropped because of the deny statement in ACL 197. In this case, the ACL information is logged (the logging option is turned on for the ACL entry) and dropped packets are counted per-interface and globally. Packets with a source address of 192.168.201.100 arriving at Ethernet interface 0 are forwarded because of the permit statement in ACL 197. ACL information about dropped or suppressed packets is logged (the logging option is turned on for the ACL entry) to the log server.

```

ip cef distributed
!
int eth0/1/1
 ip address 192.168.200.1 255.255.255.255
 ip verify unicast reverse-path 197
!
int eth0/1/2
 ip address 192.168.201.1 255.255.255.255
!
access-list 197 deny ip 192.168.201.0 10.0.0.63 any log-input
access-list 197 permit ip 192.168.201.64 10.0.0.63 any log-input
access-list 197 deny ip 192.168.201.128 10.0.0.63 any log-input
access-list 197 permit ip 192.168.201.192 10.0.0.63 any log-input
access-list 197 deny ip host 10.0.0.0 any log-input
access-list 197 deny ip 172.16.0.0 255.255.255.255 any log-input
access-list 197 deny ip 10.0.0.0 255.255.255.255 any log-input
access-list 197 deny ip 172.16.0.0 255.255.255.255 any log-input
access-list 197 deny ip 192.168.0.0 255.255.255.255 any log-input

```

## Related Commands

Command	Description
<b>ip cef</b>	Enables Cisco Express Forwarding on the route processor card.

## ipv6 tacacs source-interface

To specify an interface to use for the source address in TACACS packets, use the **ipv6 tacacs source-interface** command in global configuration mode. To remove the specified interface from the configuration, use the **no** form of this command.

**ipv6 tacacs source-interface** *interface*

**no ipv6 tacacs source-interface** *interface*

### Syntax Description

interface	Interface to be used for the source address in TACACS packets.
-----------	--

### Command Default

No interface is specified.

### Command Modes

Global configuration (config)

### Command History

Release	Modification
Cisco IOS XE Release 3.2S	This command was introduced.

### Usage Guidelines

The **ipv6 tacacs source-interface** command specifies an interface to use for the source address in TACACS packets.

### Examples

The following example shows how to configure the Gigabit Ethernet interface to be used as the source address in TACACS packets:

```
Router(config)# ipv6 tacacs source-interface GigabitEthernet 0/0/0
```

### Related Commands

Command	Description
<b>tacacs server</b>	Configures the TACACS+ server for IPv6 or IPv4 and enters TACACS+ server configuration mode.

