



radius attribute nas-port-type through rd

- [radius-server attribute nas-port format, page 2](#)
- [radius-server configure-nas, page 7](#)
- [radius-server dead-criteria, page 9](#)
- [radius-server load-balance, page 12](#)
- [radius-server vsa send, page 16](#)
- [rd, page 18](#)

radius-server attribute nas-port format

To set the NAS-Port format used for RADIUS accounting features and restore the default NAS-port format, or to set the global attribute 61 session format e string or configure a specific service port type for attribute 61 support, use the **radius-server attribute nas-port format** command in global configuration mode. To stop sending attribute 61 to the RADIUS server, use the **no** form of this command.

NAS-Port for RADIUS Accounting Features and Restoring Default NAS-Port Format

radius-server attribute nas-port format *format*

no radius-server attribute nas-port format *format*

Extended NAS-Port Support

radius-server attribute nas-port format *format* [*string*] [**type** *nas-port-type*]

no radius-server attribute nas-port format *format* [*string*] [**type** *nas-port-type*]

Syntax Description

<i>format</i>	<p>NAS-Port format. Possible values for the format argument are as follows:</p> <ul style="list-style-type: none"> • a--Standard NAS-Port format • b--Extended NAS-Port format • c--Carrier-based format • d--PPPoX (PPP over Ethernet or PPP over ATM) extended NAS-Port format • e--C onfigurable NAS-Port format
<i>string</i>	<p>(Optional) Represents all of a specific port type for format e. It is possible to specify multiple values with this argument.</p>
type <i>nas-port-type</i>	<p>(Optional) Allows you to globally specify different format strings to represent specific physical port types.</p> <p>You may set one of the extended NAS-Port-Type attribute values:</p> <ul style="list-style-type: none"> • type 30 --PPP over ATM (PPPoA) • type 31 --PPP over Ethernet (PPPoE) over ATM (PPPoEoA) • type 32 --PPPoE over Ethernet (PPPoEoE) • type 33 --PPPoE over VLAN (PPPoEoVLAN) • type 34 --PPPoE over Q-in-Q (PPPoEoQinQ)

Command Default Standard NAS-Port format for NAS-Port for RADIUS accounting features and restoring default NAS-Port format or extended NAS-Port support.

Command Modes Global configuration

Command History	Release	Modification
	11.3(7)T	This command was introduced.
	11.3(9)DB	The PPP extended NAS-Port format was added.
	12.1(5)T	The PPP extended NAS-Port format was expanded to support PPPoE over ATM and PPPoE over IEEE 802.1Q VLANs.
	12.2(4)T	Format e was introduced.
	12.2(11)T	Format e was extended to support PPPoX information.
	12.3(3)	Format e was extended to support Session ID U.
	12.3(7)XI1	Format e was extended to allow the format string to be NAS-Port-Type attribute specific. The following keyword and arguments were added: <i>string</i> , type <i>nas-port-type</i> .
	12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
	12.2(33)SRC	This command was integrated into Cisco IOS Release 12.2(33)SRC.

Usage Guidelines The **radius-server attribute nas-port format** command configures RADIUS to change the size and format of the NAS-Port attribute field (RADIUS IETF attribute 5).

The following NAS-Port formats are supported:

- Standard NAS-Port format--This 16-bit NAS-Port format indicates the type, port, and channel of the controlling interface. This is the default format used by Cisco IOS software.
- Extended NAS-Port format--The standard NAS-Port attribute field is expanded to 32 bits. The upper 16 bits of the NAS-Port attribute display the type and number of the controlling interface; the lower 16 bits indicate the interface that is undergoing authentication.

- Shelf-slot NAS-Port format--This 16-bit NAS-Port format supports expanded hardware models requiring shelf and slot entries.
- PPP extended NAS-Port format--This NAS-Port format uses 32 bits to indicate the interface, virtual path identifier (VPI), and virtual channel indicator (VCI) for PPPoA and PPPoEoA, and the interface and VLAN ID for PPPoE over Institute of Electrical and Electronic Engineers (IEEE) standard 802.1Q VLANs.

Format e

Before Cisco IOS Release 12.2(4)T formats a through c did not work with Cisco platforms such as the AS5400. For this reason, a configurable format e was developed. Format e requires you to explicitly define the usage of the 32 bits of attribute 25 (NAS-Port). The usage is defined with a given parser character for each NAS-Port field of interest for a given bit field. By configuring a single character in a row, such as x, only one bit is assigned to store that given value. Additional characters of the same type, such as x, will provide a larger available range of values to be stored. The table below shows how the ranges may be expanded:

Table 1: Format e Ranges

Character	Range
x	0-1
xx	0-3
xxx	0-7
xxxx	0-F
xxxxx	0-1F

It is imperative that you know what the valid range is for a given parameter on a platform that you want to support. The Cisco IOS RADIUS client will bitmask the determined value to the maximum permissible value on the basis of configuration. Therefore, if one has a parameter that turns out to have a value of 8, but only 3 bits (xxx) are configured, 8 and 0x7 will give a result of 0. Therefore, you must always configure a sufficient number of bits to capture the value required correctly. Care must be taken to ensure that format e is configured to properly work for all NAS port types within your network environment.

The table below shows the supported parameters and their characters:

Table 2: Supported Parameters and Characters

Supported Parameters	Characters
Zero	0 (always sets a 0 to that bit)
One	1 (always sets a 0 to that bit)
DS0 shelf	f
DS0 slot	s

Supported Parameters	Characters
DS0 adaptor	a
DS0 port	p (physical port)
DS0 subinterface	i
DS0 channel	c
Async shelf	F
Async slot	S
Async port	P
Async line	L (modern line number, that is, physical terminal [TTY] number)
PPPoX slot	S
PPPoX adaptor	A
PPPoX port	P
PPPoX VLAN ID	V
PPPoX VPI	I
PPPoX VCI	C
Session ID	U

All 32 bits that represent the NAS-Port must be set to one of the above characters because this format makes no assumptions for empty fields.

Access Router

The DS0 port on a T1-based card and on a T3-based card will give different results. On T1-based cards, the physical port is equal to the virtual port (because these are the same). So, **p** and **d** will give the same information for a T1 card. However, on a T3 system, the port will give you the physical port number (because there can be more than one T3 card for a given platform). As such, **d** will give you the virtual T1 line (as per configuration on a T3 controller). On a T3 system, **p** and **d** will be different, and one should capture both to properly identify the physical device. As a working example for the Cisco AS5400, the following configuration is recommended:

```
Router (config)# radius-server attribute nas-port format e SSSSPPPPPPPPPSSSSppppppccccc
```

This will give one an asynchronous slot (0-16), asynchronous port (0-512), DS0 slot (0-16), DS0 physical port (0-32), DS0 virtual port (0-32), and channel (0-32). The parser has been implemented to explicitly require 32-bit support, or it will fail.

Finally, format e is supported for channel-associated signaling (CAS), PRI, and BRI-based interfaces.



Extended NAS-Port-Type Attribute Support

Examples

Related Commands

Command	Description
radius attribute nas-port-type	Configures subinterfaces such as Ethernet, vLANs, stacked VLAN (Q-in-Q), virtual circuit (VC), and VC ranges.
radius-server attribute 61 extended	Enables extended, non-RFC-compliant NAS-Port-Type attribute (RADIUS attribute 61).
vpdn aaa attribute	Enables the LNS to send PPP extended NAS-Port format values to the RADIUS server for accounting.

radius-server configure-nas

To have the Cisco router or access server query the vendor-proprietary RADIUS server for the static routes and IP pool definitions used throughout its domain when the device starts up, use the **radius-server configure-nas** command in global configuration mode. To discontinue the query of the RADIUS server, use the no form of this command.

radius-server configure-nas

no radius-server configure-nas

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Global configuration

Command History	Release	Modification
	11.3	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS release 12.(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines Use the **radius-server configure-nas** command to have the Cisco router query the vendor-proprietary RADIUS server for static routes and IP pool definitions when the router first starts up. Some vendor-proprietary implementations of RADIUS let the user define static routes and IP pool definitions on the RADIUS server instead of on each individual network access server in the network. As each network access server starts up, it queries the RADIUS server for static route and IP pool information. This command enables the Cisco router to obtain static routes and IP pool definition information from the RADIUS server.



Note Because the **radius-server configure-nas** command is performed when the Cisco router starts up, it will not take effect until you issue a **copy system:running-config nvram:startup-config** command.

Examples The following example shows how to tell the Cisco router or access server to query the vendor-proprietary RADIUS server for already-defined static routes and IP pool definitions when the device first starts up:

```
radius-server configure-nas
```

Related Commands

Command	Description
radius-server host non-standard	Identifies that the security server is using a vendor-proprietary implementation of RADIUS.

radius-server dead-criteria

To force one or both of the criteria--used to mark a RADIUS server as dead--to be the indicated constant, use the **radius-server dead-criteria** command in global configuration mode. To disable the criteria that were set, use the **no** form of this command.

radius-server dead-criteria [**time** *seconds*] [**tries** *number-of-tries*]

no radius-server dead-criteria [**time** *seconds*] [**tries** *number-of-tries*]

Syntax Description

time <i>seconds</i>	<p>(Optional) Minimum amount of time, in seconds, that must elapse from the time that the router last received a valid packet from the RADIUS server to the time the server is marked as dead. If a packet has not been received since the router booted, and there is a timeout, the time criterion will be treated as though it has been met. You can configure the time to be from 1 through 120 seconds.</p> <ul style="list-style-type: none"> If the <i>seconds</i> argument is not configured, the number of seconds will range from 10 to 60 seconds, depending on the transaction rate of the server. <p>Note Both the time criterion and the tries criterion must be met for the server to be marked as dead.</p>
tries <i>number-of-tries</i>	<p>(Optional) Number of consecutive timeouts that must occur on the router before the RADIUS server is marked as dead. If the server performs both authentication and accounting, both types of packets will be included in the number. Improperly constructed packets will be counted as though they were timeouts. All transmissions, including the initial transmit and all retransmits, will be counted. You can configure the number of timeouts to be from 1 through 100.</p> <ul style="list-style-type: none"> If the <i>number-of-tries</i> argument is not configured, the number of consecutive timeouts will range from 10 to 100, depending on the transaction rate of the server and the number of configured retransmissions. <p>Note Both the time criterion and the tries criterion must be met for the server to be marked as dead.</p>

Command Default

The number of seconds and number of consecutive timeouts that occur before the RADIUS server is marked as dead will vary, depending on the transaction rate of the server and the number of configured retransmissions.

Command Modes

Global configuration (config)

Command History

Release	Modification
12.2(15)T	This command was introduced.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines**Note**

Both the time criterion and the tries criterion must be met for the server to be marked as dead.

The **no** form of this command has the following cases:

- If neither the *seconds* nor the *number-of-tries* argument is specified with the **no radius-server dead-criteria** command, both time and tries will be reset to their defaults.
- If the *seconds* argument is specified using the originally set value, the time will be reset to the default value range (10 to 60).
- If the *number-of-tries* argument is specified using the originally set value, the number of tries will be reset to the default value range (10 to 100).

Examples

The following example shows how to configure the router so that it will be considered dead after 5 seconds and 4 tries:

```
Router (config)# radius-server dead-criteria time 5 tries 4
```

The following example shows how to disable the time and number-of-tries criteria that were set for the **radius-server dead-criteria** command.

```
Router (config)# no radius-server dead-criteria
```

The following example shows how to disable the time criterion that was set for the **radius-server dead-criteria** command.

```
Router (config)# no radius-server dead-criteria time 5
```

The following example shows how to disable the number-of-tries criterion that was set for the **radius-server dead-criteria** command.

```
Router (config)# no radius-server dead-criteria tries 4
```

Related Commands

Command	Description
debug aaa dead-criteria transactions	Displays AAA dead-criteria transaction values.
show aaa dead-criteria	Displays dead-criteria information for a AAA server.
show aaa server-private	Displays the status of all private RADIUS servers.
show aaa servers	Displays information about the number of packets sent to and received from AAA servers.

radius-server load-balance

To enable RADIUS server load balancing for the global RADIUS server group referred to as “radius” in the authentication, authorization and accounting (AAA) method lists, use the radius-server load-balance command in global configuration mode. To disable RADIUS server load balancing, use the **no** form of this command.

radius-server load-balance method least-outstanding [batch-size *number*] [ignore-preferred-server]
no radius-server load-balance

Syntax Description

method least-outstanding	Enables least outstanding mode for load balancing.
batch-size	(Optional) The number of transactions to be assigned per batch.
<i>number</i>	(Optional) The number of transactions in a batch. <ul style="list-style-type: none"> • The default is 25. • The range is 1-2147483647. <p>Note Batch size may impact throughput and CPU load. It is recommended that the default batch size, 25, be used because it is optimal for high throughput, without adversely impacting CPU load.</p>
ignore-preferred-server	(Optional) Indicates if a transaction associated with a single AAA session should attempt to use the same server or not. <ul style="list-style-type: none"> • If set, preferred server setting will not be used. • Default is to use the preferred server.

Command Default

If this command is not configured, global RADIUS server load balancing will not occur.

Command Modes

Global configuration

Command History

Release	Modification
12.2(28)SB	This command was introduced.
12.4(11)T	This command was integrated into Cisco IOS Release 12.4(11)T.
12.2(33)SRC	This command was integrated into Cisco IOS Release 12.2(33)SRC.

Examples

The following example shows how to enable load balancing for global RADIUS server groups. It is shown in three parts: the current configuration of RADIUS command output, debug output, and AAA server status information. You can use the delimiting characters to display only the relevant parts of the configuration.

Examples

The following shows the relevant RADIUS configuration:

```
Router# show running-config | inc radius
aaa authentication ppp default group radius
aaa accounting network default start-stop group radius
radius-server host 192.0.2.238 auth-port 2095 acct-port 2096 key cisco
radius-server host 192.0.2.238 auth-port 2015 acct-port 2016 key cisco
radius-server load-balance method least-outstanding batch-size 5
```

The lines in the current configuration of RADIUS command output above are defined as follows:

- The **aaa authentication ppp** command authenticates all PPP users using RADIUS.
- The **aaa accounting** command enables the sending of all accounting requests to the AAA server after the client is authenticated and after the disconnect using the keyword **start-stop**.
- The **radius-server host** command defines the IP address of the RADIUS server host with the authorization and accounting ports specified and the authentication and encryption key identified.
- The **radius-server load-balance** command enables load balancing for the global RADIUS server groups with the batch size specified.

Examples

The debug output below shows the selection of preferred server and processing of requests for the configuration above.

```
Router# show debug
General OS:
  AAA server group server selection debugging is on
Router#
<sending 10 pppoe requests>
Router#
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT(00000014):No preferred server available.
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT:Obtaining least loaded server.
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT:No more transactions in batch. Obtaining a new
server.
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT:Obtaining a new least loaded server.
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT:Server[0] load:0
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT:Server[1] load:0
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT:Selected Server[0] with load 0
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT:[5] transactions remaining in batch.
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT(00000014):Server (192.0.2.238:2095,2096) now being
used as preferred server
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT(00000015):No preferred server available.
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT:Obtaining least loaded server.
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT:[4] transactions remaining in batch. Reusing
server.
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT(00000015):Server (192.0.2.238:2095,2096) now being
used as preferred server
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT(00000016):No preferred server available.
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT:Obtaining least loaded server.
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT:[3] transactions remaining in batch. Reusing
server.
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT(00000016):Server (192.0.2.238:2095,2096) now being
used as preferred server
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT(00000017):No preferred server available.
```

```

*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT:Obtaining least loaded server.
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT:[2] transactions remaining in batch. Reusing
server.
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT(00000017):Server (192.0.2.238:2095,2096) now being
used as preferred server
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT(00000018):No preferred server available.
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT:Obtaining least loaded server.
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT:[1] transactions remaining in batch. Reusing
server.
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT(00000018):Server (192.0.2.238:2095,2096) now being
used as preferred server
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT(00000019):No preferred server available.
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT:Obtaining least loaded server.
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT:No more transactions in batch. Obtaining a new
server.
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT:Obtaining a new least loaded server.
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT:Server[1] load:0
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT:Server[0] load:5
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT:Selected Server[1] with load 0
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT:[5] transactions remaining in batch.
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT(00000019):Server (192.0.2.238:2015,2016) now being
used as preferred server
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT(0000001A):No preferred server available.
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT:Obtaining least loaded server.
*Feb 28 13:40:32.199:AAA/SG/SERVER_SELECT:[4] transactions remaining in batch. Reusing
server.
*Feb 28 13:40:32.203:AAA/SG/SERVER_SELECT(0000001A):Server (192.0.2.238:2015,2016) now being
used as preferred server
*Feb 28 13:40:32.203:AAA/SG/SERVER_SELECT(0000001B):No preferred server available.
*Feb 28 13:40:32.203:AAA/SG/SERVER_SELECT:Obtaining least loaded server.
*Feb 28 13:40:32.203:AAA/SG/SERVER_SELECT:[3] transactions remaining in batch. Reusing
server.
*Feb 28 13:40:32.203:AAA/SG/SERVER_SELECT(0000001B):Server (192.0.2.238:2015,2016) now being
used as preferred server
*Feb 28 13:40:32.203:AAA/SG/SERVER_SELECT(0000001C):No preferred server available.
*Feb 28 13:40:32.203:AAA/SG/SERVER_SELECT:Obtaining least loaded server.
*Feb 28 13:40:32.203:AAA/SG/SERVER_SELECT:[2] transactions remaining in batch. Reusing
server.
*Feb 28 13:40:32.203:AAA/SG/SERVER_SELECT(0000001C):Server (192.0.2.238:2015,2016) now being
used as preferred server
*Feb 28 13:40:32.203:AAA/SG/SERVER_SELECT(0000001D):No preferred server available.
*Feb 28 13:40:32.203:AAA/SG/SERVER_SELECT:Obtaining least loaded server.
*Feb 28 13:40:32.203:AAA/SG/SERVER_SELECT:[1] transactions remaining in batch. Reusing
server
.
.
.

```

Server Status Information for Global RADIUS Server Group Example

The output below shows the AAA server status for the global RADIUS server group configuration example.

```

Router# show aaa server
RADIUS:id 4, priority 1, host 192.0.2.238, auth-port 2095, acct-port 2096
  State:current UP, duration 3175s, previous duration 0s
  Dead:total time 0s, count 0
  Quarantined:No
  Authen:request 6, timeouts 1
    Response:unexpected 1, server error 0, incorrect 0, time 1841ms
    Transaction:success 5, failure 0
  Author:request 0, timeouts 0
    Response:unexpected 0, server error 0, incorrect 0, time 0ms
    Transaction:success 0, failure 0
  Account:request 5, timeouts 0
    Response:unexpected 0, server error 0, incorrect 0, time 3303ms
    Transaction:success 5, failure 0
  Elapsed time since counters last cleared:2m
RADIUS:id 5, priority 2, host 192.0.2.238, auth-port 2015, acct-port 2016
  State:current UP, duration 3175s, previous duration 0s
  Dead:total time 0s, count 0
  Quarantined:No
  Authen:request 6, timeouts 1
    Response:unexpected 1, server error 0, incorrect 0, time 1955ms

```

```

Transaction:success 5, failure 0
Author:request 0, timeouts 0
Response:unexpected 0, server error 0, incorrect 0, time 0ms
Transaction:success 0, failure 0
Account:request 5, timeouts 0
Response:unexpected 0, server error 0, incorrect 0, time 3247ms
Transaction:success 5, failure 0
Elapsed time since counters last cleared:2m
Router#

```

The output shows the status of two RADIUS servers. Both servers are up and, in the last 2 minutes, have processed successfully:

- 5 out of 6 authentication requests
- 5 out of 5 accounting requests

Related Commands

Command	Description
debug aaa sg-server selection	Shows why the RADIUS and TACACS+ server group system in a router is selecting a particular server.
debug aaa test	Shows when the idle timer or dead timer has expired for RADIUS server load balancing.
load-balance	Enables RADIUS server load balancing for named RADIUS server groups.
radius-server host	Enables RADIUS automated testing for load balancing.
test aaa group	Tests RADIUS load balancing server response manually.

radius-server vsa send

To configure the network access server (NAS) to recognize and use vendor-specific attributes (VSAs), use the **radius-server vsa send** command in global configuration mode. To disable the NAS from using VSAs, use the **no** form of this command.

radius-server vsa send [accounting| authentication| cisco-nas-port] [3gpp2]

no radius-server vsa send [accounting| authentication| cisco-nas-port] [3gpp2]

Syntax Description

accounting	(Optional) Limits the set of recognized VSAs to only accounting attributes.
authentication	(Optional) Limits the set of recognized VSAs to only authentication attributes.
cisco-nas-port	(Optional) Returns the Cisco NAS port VSA. Note Due to the IETF requirement for including NAS port information in attribute 87 (Attr87), the Cisco NAS port is obsoleted by default.
3gpp2	(Optional) Adds Third Generation Partnership Project 2 (3GPP2) Cisco VSAs to the 3GPP2 packet type.

Command Default

NAS is not configured to recognize and use VSAs.

Command Modes

Global configuration (config)

Command History

Release	Modification
11.3T	This command was introduced.
12.2(27)SBA	This command was integrated into Cisco IOS Release 12.2(27)SBA.
12.2(33)SRA	This command was modified. The cisco-nas-port and 3gpp2 keywords were added to provide backward compatibility for Cisco VSAs.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
Cisco IOS XE Release 3.3S	This command was integrated into Cisco IOS XE Release 3.3S.

Release	Modification
Cisco IOS XE Release 3.8S	This command was modified. The accounting and authentication keywords were enabled by default for NAS to use VSAs in accounting and authentication requests, respectively.

Usage Guidelines

The IETF draft standard specifies a method for communicating vendor-specific information between the NAS and the RADIUS server by using the VSA (attribute 26). VSAs allow vendors to support their own extended attributes not suitable for general use. The **radius-server vsa send** command enables the NAS to recognize and use both accounting and authentication VSAs. Use the **accounting** keyword with the **radius-server vsa send** command to limit the set of recognized VSAs to accounting attributes only. Use the **authentication** keyword with the **radius-server vsa send** command to limit the set of recognized VSAs to authentication attributes only. Use the **show running-config all** command to see the default **radius-server vsa send accounting** and **radius-server vsa send authentication** commands.

The Cisco RADIUS implementation supports one vendor-specific option using the format recommended in the specification. The Cisco vendor ID is 9, and the supported option has vendor-type 1, which is named cisco-avpair. The value is a string with the following format:

"protocol : attribute separator value"

In the preceding example, *protocol* is a value of the Cisco protocol attribute for a particular type of authorization; *attribute* and *value* are an appropriate attribute-value (AV) pair defined in the Cisco TACACS+ specification; and *separator* is = for mandatory attributes. This solution allows the full set of features available for TACACS+ authorization to also be used for RADIUS.

For example, the following AV pair causes the Multiple Named IP Address Pools feature to be activated during IP authorization (that is, during the PPP Internet Protocol Control Protocol [IPCP] address assignment):

```
cisco-avpair= "ip:addr-pool=first"
```

The following example causes a NAS Prompt user to have immediate access to EXEC commands.

```
cisco-avpair= "shell:priv-lvl=15"
```

Other vendors have their own unique vendor IDs, options, and associated VSAs. For more information about vendor IDs and VSAs, see RFC 2138, *Remote Authentication Dial-In User Service (RADIUS)*.

Examples

The following example shows how to configure the NAS to recognize and use vendor-specific accounting attributes:

```
Device(config)# radius-server vsa send accounting
```

Related Commands

Command	Description
aaa nas port extended	Replaces the NAS-Port attribute with RADIUS IETF attribute 26 and displays extended field information.
show running-config all	Displays complete configuration information, including the default settings and values.

rd

To specify a route distinguisher (RD) for a VPN routing and forwarding (VRF) instance, use the **rd** command in VRF configuration mode. To remove a route distinguisher, use the **no** form of this command.

rd *route-distinguisher*

no rd *route-distinguisher*

Syntax Description

<i>route-distinguisher</i>	An 8-byte value to be added to an IPv4 prefix to create a VPN IPv4 prefix.
----------------------------	--

Command Default

No RD is specified.

Command Modes

VRF configuration (config-vrf)

Command History

Release	Modification
12.0(5)T	This command was introduced.
12.0(21)ST	This command was integrated into Cisco IOS 12.0(21)ST.
12.0(22)S	This command was integrated into Cisco IOS 12.0(22)S.
12.2(13)T	This command was integrated into Cisco IOS 12.2(13)T.
12.2(14)S	This command was integrated into Cisco IOS 12.2(14)S.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(33)SRB	Support for IPv6 was added.
12.2(33)SB	This command was integrated into Cisco IOS Release 12.2(33)SB.
12.2(33)SXI	This command was integrated into Cisco IOS Release 12.2(33)SXI.
12.2(54)SG	This command was integrated into Cisco IOS Release 12.2(54)SG.
Cisco IOS XE Release 3.1S	This command was integrated into Cisco IOS XE Release 3.1S.
15.1(2)SNG	This command was implemented on the Cisco ASR 901 Series Aggregation Services Routers.

Usage Guidelines

An RD creates routing and forwarding tables and specifies the default route distinguisher for a VPN. The RD is added to the beginning of the customer's IPv4 prefixes to change them into globally unique VPN-IPv4 prefixes.

An RD is either:

- ASN-related--Composed of an autonomous system number and an arbitrary number.
- IP-address-related--Composed of an IP address and an arbitrary number.

You can enter an RD in either of these formats:

16-bit autonomous-system-number : your 32-bit number For example, 101:3.

32-bit IP address : your 16-bit number For example, 192.168.122.15:1.

Examples

The following example shows how to configure a default RD for two VRFs. It illustrates the use of both autonomous-system-number-relative and IP-address-relative RDs:

```
Router(config)# ip vrf vrf1
Router(config-vrf)# rd 100:3
Router(config-vrf)# exit
Router(config)# ip vrf vrf2
Router(config-vrf)# rd 10.13.0.12:200
```

The following is an example of a VRF for IPv4 and IPv6 that has common policies defined in the global part of the VRF configuration:

```
vrf definition vrf2
 rd 200:1
 route-target both 200:2
!
 address-family ipv4
 exit-address-family
!
 address-family ipv6
 exit-address-family
end
```

Related Commands

Command	Description
ip vrf	Configures a VRF routing table.
show ip vrf	Displays the set of defined VRFs and associated interfaces.
vrf definition	Configures a VRF routing table and enters VRF configuration mode.

rd