



IGRP Commands

Use the commands in this chapter to configure and monitor Interior Gateway Routing Protocol (IGRP). For IGRP configuration information and examples, refer to the “Configuring IGRP” chapter of the *Cisco IOS IP Configuration Guide*.

default-metric (IGRP)

To set metrics for IGRP or Enhanced IGRP (EIGRP), use the **default-metric** command in router configuration mode. To remove the metric value and restore the default state, use the **no** form of this command.

default-metric *bandwidth delay reliability loading mtu*

no default-metric *bandwidth delay reliability loading mtu*

Syntax Description

<i>bandwidth</i>	Minimum bandwidth of the route (in kbps). It can be 0 or any positive integer.
<i>delay</i>	Route delay (in tens of microseconds). It can be 0 or any positive number that is a multiple of 39.1 nanoseconds.
<i>reliability</i>	Likelihood of successful packet transmission expressed as a number from 0 to 255. The value 255 means 100 percent reliability; 0 means no reliability.
<i>loading</i>	Effective bandwidth of the route expressed as a number from 0 to 255 (255 is 100 percent loading).
<i>mtu</i>	Maximum transmission unit (MTU) size of the route in bytes. It can be 0 or any positive integer.

Defaults

Only connected routes and interface static routes can be redistributed without a default metric.

Command Modes

Router configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

A default metric is required to redistribute a protocol into IGRP or EIGRP, unless you use the **redistribute** command. Automatic metric translations occur between IGRP and EIGRP. You do not need default metrics to redistribute IGRP or EIGRP into itself.



Note

The default metric command does not affect EIGRP-to-EIGRP or IGRP-to-EIGRP distribution. To configure EIGRP-to-EIGRP or IGRP-to-EIGRP distribution, use route maps.

Metric defaults have been carefully set to work for a wide variety of networks. Take great care when changing these values.

Keeping the same metrics is supported only when redistributing from IGRP, EIGRP, or static routes.

Examples

The following example takes redistributed Routing Information Protocol (RIP) metrics and translates them into IGRP metrics with values as follows: bandwidth = 1000, delay = 100, reliability = 250, loading = 100, and MTU = 1500.

```
router igrp 109
 network 172.16.0.0
 redistribute rip
 default-metric 1000 100 250 100 1500
```

Related Commands

Command	Description
redistribute (IP)	Redistributes routes from one routing domain into another routing domain.

distribute-list in (RIP, IGRP, EIGRP)

To filter networks received in updates, use the **distribute-list in** command in address family or router configuration mode. To disable this function, use the **no** form of this command.

distribute-list {*access-list-number* | **prefix** *prefix-list-name* [**gateway** *prefix-list-name*]} **in**
[*interface-type* *interface-number*]

no distribute-list {*access-list-number* | **prefix** *prefix-list-name* [**gateway** *prefix-list-name*]} **in**
[*interface-type* *interface-number*]

Syntax Description

<i>access-list-number</i>	Standard IP access list number. The list defines which networks are to be received and which are to be suppressed in routing updates.
prefix <i>prefix-list-name</i>	Name of a prefix list. The list defines which networks are to be received and which are to be suppressed in routing updates, based upon matching the network prefix to the prefixes in the list.
gateway <i>prefix-list-name</i>	(Optional) Name of the prefix list to be applied to the gateway of the prefix being updated.
in	Applies the access list to incoming routing updates.
<i>interface-type</i>	(Optional) Interface type.
<i>interface-number</i>	(Optional) Interface number on which the access list should be applied to incoming updates. If no interface is specified, the access list will be applied to all incoming updates.

Defaults

This command is disabled by default.

Command Modes

Address family configuration
Router configuration

Command History

Release	Modification
10.0	This command was introduced.
11.2	The <i>access-list-number</i> , <i>interface-type</i> , and <i>interface-number</i> arguments were added.
12.0	The <i>prefix-list-name</i> argument was added.
12.0(7)T	Address family configuration mode was added.

Usage Guidelines

This command is not supported in Intermediate System-to-Intermediate System (IS-IS) or Open Shortest Path First (OSPF).

Using a prefix list allows filtering based upon the prefix length, making it possible to filter either on the prefix list, the gateway, or both for incoming updates.

Specify either an access list or a prefix list with the **distribute-list in** command.

Use the **gateway** keyword only with the **prefix-list** keyword.

To suppress networks from being advertised in updates, use the **distribute-list out** command.

Examples

In the following example, the BGP routing process accepts only two networks—network 0.0.0.0 and network 192.168.0.0:

```
access-list 1 permit 0.0.0.0
access-list 1 permit 192.168.0.0
access-list 1 deny 0.0.0.0 255.255.255.255
router bgp
 network 192.168.0.0
 distribute-list 1 in
```

In the following example, The RIP process accepts only prefixes with prefix lengths of /8 to /24:

```
ip prefix-list max24 seq 5 permit 0.0.0.0/0 ge 8 le 24
router rip
 network 192.168.0.0
 distribute-list prefix max24 in
```

In the following example, the RIP process filters on packet length and accepts routing updates from address 192.168.1.1 only:

```
ip prefix-list max24 seq 5 permit 0.0.0.0/0 ge 8 le 24
ip prefix-list allowlist seq5 permit 192.168.1.1/32
router rip
 network 10.108.0.0
 distribute-list prefix max24 gateway allowlist in
```

Related Commands

Command	Description
access-list (IP extended)	Defines an extended IP access list.
distribute-list out (RIP, IGRP, EIGRP)	Suppresses networks from being advertised in updates.
ip prefix-list	Creates an entry in a prefix list.
redistribute (IP)	Redistributes routes from one routing domain into another routing domain.

distribute-list out (RIP, IGRP, EIGRP)

To suppress networks from being advertised in updates, use the **distribute-list out** command in address family or router configuration mode. To disable this function, use the **no** form of this command.

distribute-list { *access-list-number* | **prefix** *prefix-list-name* [**gateway** *prefix-list-name*] } **out**
[*interface-name* | *routing-process* | *as-number*]

no distribute-list { *access-list-number* | **prefix** *prefix-list-name* [**gateway** *prefix-list-name*] } **out**
[*interface-name* | *routing-process* | *as-number*]

Syntax Description

<i>access-list-number</i>	Standard IP access list number. The list defines which networks are to be received and which are to be suppressed in routing updates.
prefix <i>prefix-list-name</i>	Name of a prefix list. The list defines which networks are to be received and which are to be suppressed in routing updates, based upon matching the network prefix to the prefixes in the list.
gateway <i>prefix-list-name</i>	(Optional) Name of the prefix list to be applied to the gateway of the prefix being updated.
out	Applies the access list to outgoing routing updates.
<i>interface-name</i>	(Optional) Name of a particular interface.
<i>routing-process</i>	(Optional) Name of a particular routing process, or the keyword static or connected .
<i>as-number</i>	(Optional) Autonomous system number.

Defaults

This command is disabled by default.

Command Modes

Address family configuration
Router configuration

Command History

Release	Modification
10.0	This command was introduced.
11.2	The <i>access-list-number</i> argument was added.
12.0	The <i>prefix-list-name</i> argument was added.
12.0(7)T	Address family configuration mode was added.

Usage Guidelines

When redistributing networks, a routing process name can be specified as an optional trailing argument to the **distribute-list** command. Specifying an argument causes the access list or prefix list to be applied to only those routes derived from the specified routing process. After the process-specific access list or prefix list is applied, any access list or prefix list specified by a **distribute-list** command without a process name argument will be applied. Addresses not specified in the **distribute-list** command will not be advertised in outgoing routing updates.

Specify either an access list or a prefix list with the **distribute-list in** command.

Use the **gateway** keyword only with the **prefix-list** keyword.

**Note**

To filter networks received in updates, use the **distribute-list in** command.

Examples

The following example causes only one network (network 192.168.0.0) to be advertised by a RIP routing process:

```
access-list 1 permit 192.168.0.0
access-list 1 deny 0.0.0.0 255.255.255.255
router rip
 network 192.168.0.0
 distribute-list 1 out
```

Related Commands

Command	Description
access-list (IP extended)	Defines an extended IP access list.
distribute-list in (RIP, IGRP, EIGRP)	Filters networks received in updates.
ip prefix-list	Creates an entry in a prefix list.

ip split-horizon (IGRP)

To enable the split horizon mechanism, use the **ip split-horizon** command in interface configuration mode. To disable the split horizon mechanism, use the **no** form of this command.

ip split-horizon

no ip split-horizon

Syntax Description

This command has no arguments or keywords.

Defaults

Default behavior varies with media type.

Command Modes

Interface configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

For all interfaces except those for which either Frame Relay or Switched Multimegabit Data Service (SMDS) encapsulation is enabled, the default condition for this command is **ip split-horizon**; in other words, the split horizon feature is active. If the interface configuration includes either the **encapsulation frame-relay** or **encapsulation smds** command, then the default is for split horizon to be disabled. Split horizon is not disabled by default for interfaces using any of the X.25 encapsulations.



Note

For networks that include links over X.25 packet-switched networks (PSNs), the **neighbor** router configuration command can be used to defeat the split horizon feature. You can as an alternative *explicitly* specify the **no ip split-horizon** command in your configuration. However, if you do so you *must* similarly disable split horizon for all routers in any relevant multicast groups on that network.



Note

If split horizon has been disabled on an interface and you want to enable it, use the **ip split-horizon** command to restore the split horizon mechanism.



Note

In general, changing the state of the default for the **ip split-horizon** command is not recommended, unless you are certain that your application requires a change in order to advertise routes properly. If split horizon is disabled on a serial interface (and that interface is attached to a PSN), you *must* disable split horizon for all routers and access servers in any relevant multicast groups on that network.

Examples

The following simple example disables split horizon on a serial link. The serial link is connected to an X.25 network.

```
interface serial 0
 encapsulation x25
 no ip split-horizon
```

Related Commands

Command	Description
network (IGRP)	Specifies a list of networks for the IGRP or EIGRP routing process.

metric holddown

To keep new Interior Gateway Routing Protocol (IGRP) routing information from being used for a certain period of time, use the **metric holddown** command in router configuration mode. To disable this feature, use the **no** form of this command.

metric holddown

no metric holddown

Syntax Description

This command has no arguments or keywords.

Defaults

This command is disabled by default.

Command Modes

Router configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

The *holddown* state keeps new routing information from being used for a certain period of time. This function can prevent routing loops caused by slow convergence. It is sometimes advantageous to disable the *holddown* state to increase the ability of the network to quickly respond to topology changes; this command provides this function.

Use the **metric holddown** command if other routers or access servers within the IGRP autonomous system are not configured with the **no metric holddown** command. If all routers are not configured the same way, you increase the possibility of routing loops being created.

Examples

The following example disables metric holddown:

```
router igrp 15
 network 10.108.0.0
 network 192.168.7.0
 no metric holddown
```

Related Commands

Command	Description
metric maximum-hops	Causes the IP routing software to advertise as unreachable those routes with a hop count higher than is specified by the command (IGRP only).
metric weights (EIGRP)	Allows the tuning of the IGRP or EIGRP metric calculation.
timers basic (IGRP)	Adjusts IGRP network timers.

metric maximum-hops

To have the IP routing software advertise as unreachable those routes with a hop count higher than is specified by the command (Interior Gateway Routing Protocol [IGRP] only), use the **metric maximum-hops** command in router configuration mode. To reset the value to the default, use the **no** form of this command.

metric maximum-hops *hops-number*

no metric maximum-hops *hops-number*

Syntax Description	<i>hops-number</i>	Maximum hop count (in decimal). The default value is 100 hops; the maximum number of hops that can be specified is 255.
--------------------	--------------------	---

Defaults	100 hops
----------	----------

Command Modes	Router configuration
---------------	----------------------

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	This command provides a safety mechanism that breaks any potential <i>count-to-infinity</i> problems. It causes the IP routing software to advertise as unreachable routes with a hop count greater than the value assigned to the <i>hops-number</i> argument.
------------------	---

Examples	<p>In the following example, a router in autonomous system 71 attached to network 10.0.0.0 wants a maximum hop count of 200, doubling the default. The network administrators configured the router hop count to 200 because they have a complex WAN that can generate a large hop count under normal (nonlooping) operations.</p> <pre>router igrp 71 network 10.0.0.0 metric maximum-hops 200</pre>
----------	---

Related Commands	Command	Description
	metric holddown	Keeps new IGRP routing information from being used for a certain period of time.
	metric weights (EIGRP)	Allows the tuning of the IGRP or EIGRP metric calculations.

metric weights (IGRP)

To allow the tuning of the IGRP or Enhanced IGRP (EIGRP) metric calculations, use the **metric weights** command in router configuration mode. To reset the values to their defaults, use the **no** form of this command.

metric weights *tos k1 k2 k3 k4 k5*

no metric weights

Syntax Description	<i>tos</i>	Type of service must always be zero.
	<i>k1 k2 k3 k4 k5</i>	Constants that convert an IGRP or EIGRP metric vector into a scalar quantity.

Defaults	<i>tos</i> : 0
	<i>k1</i> : 1
	<i>k2</i> : 0
	<i>k3</i> : 1
	<i>k4</i> : 0
	<i>k5</i> : 0

Command Modes	Router configuration
---------------	----------------------

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines Use this command to alter the default behavior of IGRP routing and metric computation and allow the tuning of the IGRP metric calculation for a particular type of service (ToS).

If *k5* equals 0, the composite IGRP or EIGRP metric is computed according to the following formula:

metric = [*k1* * bandwidth + (*k2* * bandwidth)/(256 - load) + *k3* * delay]

If *k5* does not equal zero, an additional operation is performed:

metric = metric * [*k5*/(reliability + *k4*)]

Bandwidth is inverse minimum bandwidth of the path in BPS scaled by a factor of $2.56 * 10^{12}$. The range is from a 1200-bps line to 10 terabits per second.

Delay is in units of 10 microseconds. The range of delay is from 10 microseconds to 168 seconds. A delay of all ones indicates that the network is unreachable.

The delay parameter is stored in a 32-bit field, in increments of 39.1 nanoseconds. The range of delay is from 1 (39.1 nanoseconds) to hexadecimal FFFFFFFF (decimal 4,294,967,040 nanoseconds). A delay of all ones (that is, a delay of hexadecimal FFFFFFFF) indicates that the network is unreachable.

Table 4 lists the default values used for several common media.

Table 4 *Bandwidth Values by Media Type*

Media Type	Delay	Bandwidth
Satellite	5120 (2 seconds)	5120 (500 megabits)
Ethernet	25600 (1 [ms])	256000 (10 megabits)
1.544 Mbps	512000 (20,000 [ms])	1,657,856 bits
64 kbps	512000 (20,000 [ms])	40,000,000 bits
56 kbps	512000 (20,000 [ms])	45,714,176 bits
10 kbps	512000 (20,000 [ms])	256,000,000 bits
1 kbps	512000 (20,000 [ms])	2,560,000,000 bits

Reliability is given as a fraction of 255. That is, 255 is 100 percent reliability or a perfectly stable link.

Load is given as a fraction of 255. A load of 255 indicates a completely saturated link.

Examples

The following example sets the metric weights to slightly different values than the defaults:

```
router igrp 109
 network 192.168.0.0
 metric weights 0 2 0 2 0 0
```

Related Commands

Command	Description
bandwidth (interface)	Sets a bandwidth value for an interface.
delay (interface)	Sets a delay value for an interface.
metric holddown	Keeps new IGRP routing information from being used for a certain period of time.
metric maximum-hops	Causes the IP routing software to advertise as unreachable those routes with a hop count higher than is specified by the command (IGRP only).

neighbor (IGRP)

To define a neighboring router with which to exchange routing information, use the **neighbor** command in router configuration mode. To remove an entry, use the **no** form of this command.

neighbor *ip-address*

no neighbor *ip-address*

Syntax Description	<i>ip-address</i>	IP address of a peer router with which routing information will be exchanged.
--------------------	-------------------	---

Defaults	No neighboring routers are defined.
----------	-------------------------------------

Command Modes	Router configuration
---------------	----------------------

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	This command permits the point-to-point (nonbroadcast) exchange of routing information. When used in combination with the passive-interface router configuration command, routing information can be exchanged between a subset of routers and access servers on a LAN.
------------------	--

Multiple **neighbor** commands can be used to specify additional neighbors or peers.

Examples	In the following example, Interior Gateway Routing Protocol (IGRP) updates are sent to all interfaces on network 192.168.0.0 except Ethernet interface 1. However, in this case a neighbor router configuration command is included. This command permits the sending of routing updates to specific neighbors. One copy of the routing update is generated per neighbor.
----------	--

```
router igrp 109
 network 192.168.0.0
 passive-interface ethernet 1
 neighbor 192.168.20.4
```

Related Commands	Command	Description
	passive-interface	Disables sending routing updates on an interface.

network (IGRP)

To specify a list of networks for the Enhanced Interior Gateway Routing Protocol (IGRP) routing process, use the **network** command in router configuration mode. To remove an entry, use the **no** form of this command.

network *network-number*

no network *network-number*

Syntax Description	<i>network-number</i> IP address of the directly connected networks.					
Defaults	No networks are specified.					
Command Modes	Router configuration					
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>10.0</td><td>This command was introduced.</td></tr></table>		Release	Modification	10.0	This command was introduced.
Release	Modification					
10.0	This command was introduced.					
Usage Guidelines	<p>The network number specified must not contain any subnet information. There is no limit to the number of network commands you can use on the router.</p> <p>IGRP or Enhanced IGRP (EIGRP) sends updates to the interfaces in the specified networks. Also, if a network interface is not specified, it will not be advertised in any IGRP or EIGRP update.</p>					
Examples	<p>The following example configures a router for IGRP and assigns autonomous system 109. The network commands indicate the networks directly connected to the router.</p> <pre>router igrp 109 network 10.108.0.0 network 192.168.7.0</pre>					
Related Commands	<table><tr><th>Command</th><th>Description</th></tr><tr><td>router igrp</td><td>Configures the IGRP routing process.</td></tr></table>		Command	Description	router igrp	Configures the IGRP routing process.
Command	Description					
router igrp	Configures the IGRP routing process.					

offset-list (IGRP)

To add an offset to incoming and outgoing metrics to routes learned via Interior Gateway Routing Protocol (IGRP), use the **offset-list** command in router configuration mode. To remove an offset list, use the **no** form of this command.

offset-list {*access-list-number* | *access-list-name*} {**in** | **out**} *offset* [*interface-type* *interface-number*]

no offset-list {*access-list-number* | *access-list-name*} {**in** | **out**} *offset* [*interface-type* *interface-number*]

Syntax Description

<i>access-list-number</i>	Standard access list number to be applied. Access list number 0 indicates all access lists. If the <i>offset</i> argument is 0, no action is taken. For IGRP, the offset is added to the delay component only.
<i>access-list-name</i>	Standard access name to be applied.
in	Applies the access list to incoming metrics.
out	Applies the access list to outgoing metrics.
<i>offset</i>	Positive offset to be applied to metrics for networks matching the access list. If the offset is 0, no action is taken.
<i>interface-type</i>	(Optional) Interface type to which the offset list is applied.
<i>interface-number</i>	(Optional) Interface number to which the offset list is applied.

Defaults

This command is disabled by default.

Command Modes

Router configuration

Command History

Release	Modification
10.0	This command was introduced.
10.3	The <i>interface-type</i> and <i>interface-number</i> arguments were added.
11.2	The <i>access-list-name</i> argument was added.

Usage Guidelines

The offset value is added to the routing metric. An offset list with an interface type and interface number is considered extended and takes precedence over an offset list that is not extended. Therefore, if an entry passes the extended offset list and the normal offset list, the offset of the extended offset list is added to the metric.

Examples

In the following example, the router applies an offset of 10 to the delay component of the router only to access list 121:

```
offset-list 21 out 10
```

In the following example, the router applies an offset of 10 to routes learned from Ethernet interface 0:

```
offset-list 21 in 10 ethernet 0
```

router igrp

To configure the Interior Gateway Routing Protocol (IGRP) routing process, use the **router igrp** command in global configuration mode. To shut down an IGRP routing process, use the **no** form of this command.

router igrp *as-number*

no router igrp *as-number*

Syntax Description

<i>as-number</i>	Autonomous system number that identifies the routes to the other IGRP routers. It is also used to tag the routing information.
------------------	--

Defaults

No IGRP routing process is defined.

Command Modes

Global configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

It is not necessary to have a registered autonomous system number to use IGRP. If you do not have a registered number, you are free to create your own. We recommend that if you do have a registered number, you use it to identify the IGRP process.

Examples

The following example configures an IGRP routing process and assigns process number 109:

```
router igrp 109
```

Related Commands

Command	Description
network (IGRP)	Specifies a list of networks for the IGRP or EIGRP routing process.

set metric (IGRP)

To set the metric value for Interior Gateway Routing Protocol (IGRP) in a route map, use the **set metric** route-map configuration command. To return to the default metric value, use the **no** form of this command.

set metric *bandwidth delay reliability loading mtu*

no set metric *bandwidth delay reliability loading mtu*

Syntax Description	<i>bandwidth</i>	Metric value or IGRP bandwidth of the route, in kbps. It can be in the range from 0 to 4294967295.
	<i>delay</i>	Route delay (in tens of microseconds). It can be in the range from 0 to 4294967295.
	<i>reliability</i>	Likelihood of successful packet transmission expressed as a number from 0 to 255. The value 255 means 100 percent reliability; 0 means no reliability.
	<i>loading</i>	Effective bandwidth of the route expressed as a number from 0 to 255 (255 is 100 percent loading).
	<i>mtu</i>	Minimum maximum transmission unit (MTU) size of the route, in bytes. It can be in the range from 0 to 4294967295.

Defaults	No metric will be set in the route map.
-----------------	---

Command Modes	Route-map configuration
----------------------	-------------------------

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines

**Note**

We recommend that you consult your Cisco technical support representative before changing the default value.

Use the **route-map** global configuration command, and the **match** and **set** route-map configuration commands, to define the conditions for redistributing routes from one routing protocol into another. Each **route-map** command has a list of **match** and **set** commands associated with it. The **match** commands specify the *match criteria*—the conditions under which redistribution is allowed for the current **route-map** command. The **set** commands specify the *set actions*—the particular redistribution actions to perform if the criteria enforced by the **match** commands are met. The **no route-map** command deletes the route map.

The **set** route-map configuration commands specify the redistribution *set actions* to be performed when all of the match criteria of a route map are met. When all match criteria are met, all set actions are performed.

Examples

The following example sets the bandwidth to 10,000, the delay to 10, the reliability to 255, the loading to 1, and the MTU to 1500:

```
set metric 10000 10 255 1 1500
```

Related Commands

Command	Description
route-map (IP)	Defines the conditions for redistributing routes from one routing protocol into another.

timers basic (IGRP)

To adjust Interior Gateway Routing Protocol (IGRP) network timers, use the **timers basic** command in router configuration mode. To restore the default timers, use the **no** form of this command.

timers basic *update invalid holddown flush [sleeptime]*

no timers basic

Syntax Description		
<i>update</i>		Rate (in seconds) at which updates are sent. This is the fundamental timing parameter of the routing protocol. The default is 90 seconds.
<i>invalid</i>		Interval of time (in seconds) after which a route is declared invalid; it should be at least three times the value of the <i>update</i> argument. A route becomes invalid when there is an absence of updates that refresh the route. The route then enters <i>holddown</i> state. The route is marked inaccessible and advertised as unreachable. However, the route is still used for forwarding packets. The default is 270 seconds.
<i>holddown</i>		Interval (in seconds) during which routing information regarding better paths is suppressed. It should be at least three times the value of the <i>update</i> argument. A route enters into a hold-down state when an update packet is received that indicates the route is unreachable. The route is marked inaccessible and advertised as unreachable. However, the route is still used for forwarding packets. When <i>holddown</i> expires, routes advertised by other sources are accepted and the route is no longer inaccessible. The default is 280 seconds.
<i>flush</i>		Amount of time (in seconds) that must pass before the route is removed from the routing table; the interval specified must be at least the sum of the <i>invalid</i> argument and the <i>holddown</i> argument. If it is less than this sum, the proper <i>holddown</i> interval cannot elapse, which results in a new route being accepted before the <i>holddown</i> interval expires. The default is 630 seconds.
<i>sleeptime</i>		(Optional) Interval (in milliseconds) for postponing routing updates in the event of a flash update. The value of the <i>sleeptime</i> argument should be less than the <i>update</i> value. If the <i>sleeptime</i> value is greater than the <i>update</i> value, routing tables will become unsynchronized. The default is 0 milliseconds.

Defaults

update: 90 seconds
invalid: 270 seconds
holddown: 280 seconds
flush: 630 seconds
sleeptime: 0 milliseconds

Command Modes

Router configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

The basic timing parameters for IGRP are adjustable. Because IGRP is executing a distributed, asynchronous routing algorithm, these timers must be the same for all routers and access servers in the network.

**Note**

The current and default timer values can be seen by inspecting the output of the **show ip protocols EXEC** command. The relationships of the various timers should be preserved as described previously.

Examples

The following example sets updates to be broadcast every 5 seconds. If a router is not heard from in 15 seconds, the route is declared unusable. Further information is suppressed for an additional 15 seconds. At the end of the suppression period, the route is flushed from the routing table.

```
router igrp 109
 timers basic 5 15 15 30
```

**Note**

By setting a short update period, you run the risk of congesting slow-speed serial lines; however, this is not a serious concern on faster-speed Ethernets and T1-rate serial lines. Also, if you have many routes in your updates, you can cause the routers to spend an excessive amount of time processing updates.

Related Commands

Command	Description
show ip protocols	Displays the parameters and current state of the active routing protocol process.

traffic-share balanced

To balance traffic distribution among routes when there are multiple routes for the same destination network that have different costs, use the **traffic-share balanced** command in router configuration mode. To disable this function, use the **no** form of the command.

traffic-share balanced

no traffic-share balanced

Syntax Description

This command has no arguments or keywords.

Defaults

Traffic is distributed proportionately to the ratios of the metrics.

Command Modes

Router configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

This command applies to Interior Gateway Routing Protocol (IGRP) and Enhanced IGRP (EIGRP) routing protocols only. With the default setting, routes that have higher metrics represent less-preferable routes and get less traffic.

Examples

In the following example, traffic is balanced across multiple routes:

```
router igrp 5
 traffic-share balanced
 variance 1
```

Related Commands

Command	Description
variance (IGRP)	Controls load balancing in an EIGRP and IGRP internetwork.

variance (IGRP)

To control load balancing in an Enhanced IGRP-based internetwork, use the **variance** command in router configuration mode. To reset the variance to the default value, use the **no** form of this command.

variance *multiplier*

no variance

Syntax Description	<i>multiplier</i>	Metric value used for load balancing. It can be a value from 1 to 128. The default is 1, which means equal-cost load balancing.
---------------------------	-------------------	---

Defaults	1 (equal-cost load balancing)
-----------------	-------------------------------

Command Modes	Router configuration
----------------------	----------------------

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	<p>Setting a variance value lets the Cisco IOS software determine the feasibility of a potential route. A route is feasible if the next router in the path is closer to the destination than the current router and if the metric for the entire path is within the variance. Only paths that are feasible can be used for load balancing and included in the routing table.</p>
-------------------------	--

If the following two conditions are met, the route is deemed feasible and can be added to the routing table:

- The local best metric must be greater than the metric learned from the next router.
- The multiplier times the local best metric for the destination must be greater than or equal to the metric through the next router.

Examples	The following example sets a variance value of 4:
-----------------	---

```
router igrp 109
 variance 4
```