



CNS Agents

CNS agents is a collection of services that can provide remote event-driven configuring of Cisco IOS networking devices and remote execution of some command-line interface (CLI) commands.

Feature History for the CNS Feature

Release	Modification
12.2(25)S	This feature was introduced.

Finding Support Information for Platforms and Cisco IOS Software Images

Use Cisco Feature Navigator to find information about platform support and Cisco IOS software image support. Access Cisco Feature Navigator at <http://www.cisco.com/go/fn>. You must have an account on Cisco.com. If you do not have an account or have forgotten your username or password, click **Cancel** at the login dialog box and follow the instructions that appear.

Contents

- [Prerequisites for CNS Agents, page 1](#)
- [Restrictions for CNS Agents, page 2](#)
- [Information About CNS Agents, page 2](#)
- [How to Configure CNS Agents, page 4](#)
- [Configuration Examples for CNS Agents, page 15](#)
- [Additional References, page 16](#)
- [Command Reference, page 18](#)

Prerequisites for CNS Agents

- Configure a transport protocol on the remote router that is compatible with the remote router's external interface. [Table 1](#) lists the supported transport protocols that can be used depending on the router interface.



Corporate Headquarters:

Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA

Copyright © 2004 Cisco Systems, Inc. All rights reserved.

- Create the configuration template in the CNS configuration-engine provisioning database. (This task is best done by a senior network designer.)

Table 1 Router Interface and Transport Protocols Required by CNS Services

Router Interface	Transport Protocol		
	SLARP	ATM InARP	PPP (IPCP)
T1	Yes	Yes	Yes
ADSL	No	Yes	Yes
Serial	Yes	No	Yes

Restrictions for CNS Agents

Remote Router

- The remote router must run a Cisco IOS Release 12.2(25)S or later release image that supports the CNS configuration agent and CNS event agent. These include the following:
 - Ports must be prepared on the remote router for connection to the network.
 - You must ensure that the remote router is configured using Cisco Configuration Express.

CNS Configuration Engine

- The CNS configuration engine must be the Cisco Intelligence Engine 2100 (Cisco IE2100) series and must be running software version 1.3.
- The configuration engine must have access to an information database of attributes for building a configuration. This database can reside on the Cisco IE2100 itself.
- Configuration templates must be prepared on the CNS configuration engine before installation of the remote router.
- The user of CNS flow-through provisioning and the CNS configuration engine must be familiar with designing network topologies, designing configuration templates, and using the CNS configuration engine.

Information About CNS Agents

To configure CNS agents, you should understand the following concepts:

- [CNS, page 3](#)
- [CNS Configuration Agent, page 3](#)
- [CNS Exec Agent, page 3](#)
- [CNS Event Agent, page 3](#)
- [Initial CNS Configuration, page 3](#)
- [Incremental CNS Configuration, page 4](#)
- [CNS IDs, page 4](#)

CNS

CNS is a foundation technology for linking users to networking services and provides the infrastructure for the automated configuration of large numbers of network devices. Many IP networks are quite complex with many devices, and each device must currently be configured individually. When standard configurations do not exist or have been modified, the time involved in initial installation and subsequent upgrading is considerable. The volume of smaller, more standardized, customer networks is also growing faster than the number of available network engineers. Internet service providers (ISPs) now need a method for sending out partial configurations to introduce new services. To address all these issues, CNS has been designed to provide “plug-and-play” network services using a central directory service and distributed agents. CNS features include CNS configuration and event agents and a flow-through provisioning structure. The configuration and event agents use a CNS configuration engine to provide methods for automating initial Cisco IOS device configurations, incremental configurations, and synchronized configuration updates, and the configuration engine reports the status of the configuration load as an event to which a network monitoring or workflow application can subscribe. The CNS flow-through provisioning uses the CNS configuration and event agents to provide an automated workflow, eliminating the need for an on-site technician.

CNS Configuration Agent

The CNS configuration agent is involved in the initial configuration and subsequent partial configurations on a Cisco IOS device. To activate the CNS configuration agent, enter any of the **cns config** command-line interface (CLI) commands.

CNS Exec Agent

The CNS exec agent allows a remote application to execute an EXEC mode CLI command on a Cisco IOS device by sending an event message that contains the command. A restricted set of EXEC CLI commands—**show** commands—is supported.

CNS Event Agent

Although other CNS agents may be configured, no other CNS agents are operational until the **cns event** command is entered because the CNS event agent provides a transport connection to the CNS event bus for all other CNS agents. The other CNS agents use the connection to the CNS event bus to send and receive messages. The CNS event agent does not read or modify the messages.

Initial CNS Configuration

When a routing device first comes up, it connects to the configuration server component of the CNS configuration agent by establishing a TCP connection through the use of **cns config initial**, a standard command-line interface (CLI) command. The device issues a request and identifies itself by providing a unique configuration ID to the configuration server.

When the CNS web server receives a request for a configuration file, it invokes the Java servlet and executes the corresponding embedded code. The embedded code directs the CNS web server to access the directory server and file system to read the configuration reference for this device (configuration ID)

and template. The Configuration Agent prepares an instantiated configuration file by substituting all the parameter values specified in the template with valid values for this device. The configuration server forwards the configuration file to the CNS web server for transmission to the routing device.

The CNS configuration agent accepts the configuration file from the CNS web server, performs XML parsing, checks syntax (optional), and loads the configuration file. The routing device reports the status of the configuration load as an event to which a network monitoring or workflow application can subscribe.

Incremental CNS Configuration

Once the network is up and running, new services can be added using the CNS configuration agent. Incremental (partial) configurations can be sent to routing devices. The actual configuration can be sent as an event payload by way of the event gateway (push operation) or as a signal event that triggers the device to initiate a pull operation.

The routing device can check the syntax of the configuration before applying it. If the syntax is correct, the routing device applies the incremental configuration and publishes an event that signals success to the configuration server. If the device fails to apply the incremental configuration, it publishes an event that indicates an error.

Once the routing device has applied the incremental configuration, it can write the configuration to NVRAM or wait until signaled to do so.

CNS IDs

The CNS identifier (ID) is a text string that is used exclusively with a particular CNS agent. The CNS ID is used by the CNS agent to identify itself to the server application with which it communicates. For example, the CNS configuration agent will include the configuration ID when communicating between the networking device and the configuration server. The configuration server uses the CNS configuration ID as a key to locate the attribute containing the Cisco IOS CLI configuration intended for the device that originated the configuration pull.

The network administrator must ensure a match between the CNS agent ID as defined on the routing device and the CNS agent ID contained in the directory attribute that corresponds to the configuration intended for the routing device. Within the routing device, the default value of the CNS agent ID is always set to the host name. If the host name changes, the CNS agent ID also changes. If the CNS agent ID is set using the CLI, any change will be followed by a message sent to syslog or an event message will be sent.

The CNS agent ID does not address security issues.

How to Configure CNS Agents

This section contains the following tasks:

- [Deploying the CNS Router, page 5](#) (required)
- [Configuring CNS Security Features, page 7](#) (optional)
- [Determining the CNS Agent ID, page 8](#) (required)
- [Enabling and Configuring the CNS Agents, page 9](#) (required)

- [Configuring Advanced CNS Features, page 12](#) (optional)
- [Monitoring and Verifying the CNS Agents, page 14](#) (optional)

Deploying the CNS Router

Perform this task to manually install an initial CNS configuration.

Your remote router arrives from the factory with a bootstrap configuration. Upon initial power-on, the router automatically pulls a full initial configuration from the CNS configuration engine, although you can optionally arrange for this manually as well. After initial configuration, you can optionally arrange for periodic incremental (partial) configurations for synchronization purposes.

For more details on using the Cisco CNS configuration engine to automatically install the initial CNS configuration, refer to the *Cisco CNS Configuration Engine Administrator's Guide* at <http://www.cisco.com/univercd/cc/td/doc/product/rtrmgmt/cns/ce/rel13/ag13/index.htm>.

Initial CNS Configuration

Initial configuration of the remote router occurs automatically when the router is initialized on the network. Optionally, you can perform this configuration manually.


CNS assigns the remote router a unique IP address or host name. After resolving the IP address (using SLARP, ATM InARP, or PPP protocols), the system optionally uses DNS reverse lookup to assign a host name to the router and invokes the CNS agent to download the initial configuration from the CNS configuration engine.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **cns config connect-intf** *type number* [**ping-interval** *seconds*] [**retries** *number*]
4. **config-cli** {*type* [*number*] | *interface-config-cmd*}
or
line-cli {*modem-cmd* | *line-config-cmd*}
5. Repeat Step 4 to add all required CLI commands.
6. **exit**
7. **cns config initial** {*host-name* | *ip-address*} [**encrypt**] [*port-number*] [**page** *page*] [**syntax-check**] [**no-persist**] [*source ip-address*] [**event**] [*inventory*]
8. **exit**

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> Enter your password if prompted.
Step 2	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 3	cns config connect-intf <i>type number</i> [ping-interval <i>seconds</i>] [retries <i>number</i>] Example: Router(config)# cns config connect-intf serial ping-interval 1 retries 1	Specifies the interface for connecting to the CNS configuration engine and enters connect-interface configuration mode.
Step 4	config-cli { <i>type [number] interface-config-cmd</i> } or line-cli { <i>modem-cmd line-config-cmd</i> } Example: Router(config-cns-conn-if)# config-cli encapsulation ppp or Example: Router(config-cns-conn-if)# line-cli modem inout	Specifies commands to configure the interface. or Specifies commands to configure modem lines to enable dialout and to configure the modem dialout line.
Step 5	Repeat Step 4 to add all required CLI commands. Example: Router(config-cns-conn-if)# config-cli ip directed-broadcast	Repeat Step 4 to add other CLI commands to configure the interface or to configure the modem lines.
Step 6	exit Example: Router(config-cns-conn-if)# exit	Exits connect-interface configuration mode and returns to global configuration mode.

	Command or Action	Purpose
Step 7	<p>cns config initial {<i>host-name</i> <i>ip-address</i>} [encrypt] [<i>port-number</i>] [page <i>page</i>] [syntax-check] [no-persist] [source <i>ip-address</i>] [event] [<i>inventory</i>]</p> <p>Example: Router(config)# cns config initial 10.1.1.1 no-persist</p>	<p>Starts the CNS configuration agent, connects to the CNS configuration engine, and initiates an initial configuration. You can use this command only before the system boots for the first time.</p> <p>Note The optional encrypt keyword is available only in images that support SSL.</p> <p> Caution If you write the new configuration to NVRAM by omitting the no-persist keyword, the original bootstrap configuration is overwritten.</p>
Step 8	<p>exit</p> <p>Example: Router(config)# exit</p>	<p>Exits global configuration mode and returns to privileged EXEC mode.</p>

What to Do Next

If you do not need to configure CNS security features, proceed to the [“Determining the CNS Agent ID” section on page 8](#).

Configuring CNS Security Features

Perform this optional task to configure CNS trusted servers.

CNS Trusted Servers

The **cns trusted-server** command can be used to specify a trusted server for an individual CNS agent or for all the CNS agents. To avoid security violations, you can build a list of trusted servers from which CNS agents can receive messages. An attempt to connect to a server not on the list will result in an error message being displayed.

Configure a CNS trusted server when a CNS agent will redirect its response to a server address that is not explicitly configured on the command line for the specific CNS agent. For example, the CNS exec agent may have one server configured but receive a message from the CNS event bus that overrides the configured server. The new server address has not been explicitly configured, so the new server address is not a trusted server. An error will be generated when the CNS exec agent tries to respond to this new server address unless the **cns trusted-server** command has been configured for the new server address.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **cns trusted-server** {**all-agents** | **config** | **event** | **exec**} *host-name* | *ip-address*

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> Enter your password if prompted.
Step 2	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 3	cns trusted-server { all-agents config event exec } <i>host-name</i> <i>ip-address</i> Example: Router# cns trusted-server event 10.19.2.5	Configures a CNS trusted server for the specified host name or IP address.

Determining the CNS Agent ID

Perform this task to determine the CNS agent IDs. CNS agent IDs can be configured for the CNS event agent or CNS configuration agent. By default, the value of **hostname** is set as the CNS agent ID.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **cns id** *type number* {**dns-reverse** | **ipaddress** | **mac-address**} [**event**]
or
cns id {**hardware-serial** | **hostname** | **string** *string*} [**event**]
4. **exit**

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> Enter your password if prompted.
Step 2	configure terminal Example: Router# configure terminal	Enters global configuration mode.

	Command or Action	Purpose
Step 3	<pre>cns id type number {dns-reverse ipaddress mac-address} [event]</pre> <p>or</p> <pre>cns id {hardware-serial hostname string string} [event]</pre> <p>Example: Router(config)# cns id fastethernet 0/1 ipaddress event</p> <p>or</p> <p>Example: Router(config)# cns id hardware-serial event</p>	<p>Specifies a unique CNS ID and interface type and number from which to retrieve the unique ID.</p> <p>or</p> <p>Specifies a unique CNS ID assigned from the hardware serial number, device host name, or an arbitrary text string.</p> <p>The following information applies to either version of the syntax.</p> <ul style="list-style-type: none"> Use the optional event keyword to specify an event agent ID.
	<p>Step 4</p> <pre>exit</pre> <p>Example: Router(config)# exit</p>	<p>Exits global configuration mode, and returns to privileged EXEC mode.</p>

Enabling and Configuring the CNS Agents

Perform this task to enable and configure the various CNS agents.

CNS Event Agent Parameters

The CNS event agent command—**cns event**—has several parameters that can be configured. The **failover-time** keyword is useful if you have a backup CNS event gateway configured. If the CNS event agent is trying to connect to the gateway and it discovers that the route to the backup gateway is available before the route to the primary gateway, the *seconds* argument specifies how long the CNS event agent will continue to search for a route to the primary gateway before attempting to link to the backup gateway.

Unless you are using a bandwidth-constrained link, you should set a keepalive timeout and retry count. Doing so allows the management network to recover gracefully should a Cisco IE2100 configuration engine ever fail. Without the keepalive data, such a failure requires manual intervention on every device. The *seconds* value multiplied by the *retry-count* value determines the length of idle time before the CNS event agent will disconnect and attempt to reconnect to the gateway. We recommend a minimum *retry-count* value of 2.

If the optional **source** keyword is used, the source IP address might be a secondary IP address of a specific interface to allow a management network to run on top of a production network.



Note

Although other CNS agents may be configured, no other CNS agents are operational until the **cns event** command is entered because the CNS event agent provides a transport connection to the CNS event bus for all other CNS agents.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **cns config partial** {*host-name* | *ip-address*} [**encrypt**] [*port-number*] [**source** *ip-address*] [**inventory**]
4. **cns exec** [*host-name* | *ip-address*] [**encrypt** [*enc-port-number*]] [*port-number*] [**source** *ip-address*]
5. **cns event** {*host-name* | *ip-address*} [**encrypt**] [*port-number*] [**backup**] [**failover-time** *seconds*] [**keepalive** *seconds* *retry-count*] [**source** *ip-address*]
6. **exit**

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted.
Step 2	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 3	cns config partial { <i>host-name</i> <i>ip-address</i> } [encrypt] [<i>port-number</i>] [source <i>ip-address</i>] [inventory] Example: Router(config)# cns config partial 172.28.129.22 80	(Optional) Starts the CNS configuration agent, which provides CNS configuration services to Cisco IOS clients, and initiates an incremental (partial) configuration. <ul style="list-style-type: none"> • Use the optional <i>port-number</i> argument to specify the port number for the configuration server. The default is 80. • Use the optional source keyword and <i>ip-address</i> argument to specify the use of an IP address as the source for CNS configuration agent communications. • Use the optional inventory keyword to send an inventory of the line cards and modules in the router to the CNS configuration engine as part of the HTTP request. Note The optional encrypt keyword is available only in images that support SSL.

	Command or Action	Purpose
Step 4	<p>cns exec [<i>host-name</i> <i>ip-address</i>] [encrypt [<i>enc-port-number</i>]] [<i>port-number</i>] [source <i>ip-address</i>]</p> <p>Example: Router(config)# cns exec 10.1.2.3 93 source 172.17.2.2</p>	<p>(Optional) Enables and configures the CNS exec agent, which provides CNS exec services to Cisco IOS clients.</p> <ul style="list-style-type: none"> Use the optional <i>port-number</i> argument to specify the port number for the exec server. The default is 80. Use the optional source keyword and <i>ip-address</i> argument to specify the use of an IP address as the source for CNS exec agent communications. <p>Note The optional encrypt keyword is available only in images that support SSL.</p>
Step 5	<p>cns event {<i>hostname</i> <i>ip-address</i>} [encrypt] [<i>port-number</i>] [backup] [failover-time <i>seconds</i>] [keepalive <i>seconds</i> <i>retry-count</i>] [source <i>ip-address</i>]</p> <p>Example: Router(config)# cns event 172.28.129.22 source 172.22.2.1</p>	<p>Configures the CNS event gateway, which provides CNS event services to Cisco IOS clients.</p> <ul style="list-style-type: none"> The optional encrypt keyword is available only in images that support SSL. Use the optional <i>port-number</i> argument to specify the port number for the event server. The default is 11011 with no encryption and 11012 with encryption. Use the optional backup keyword to indicate that this is the backup gateway. Before configuring a backup gateway, ensure that a primary gateway is configured. Use the optional failover-time keyword and <i>seconds</i> argument to specify a time interval in seconds to wait for the primary gateway route after the route to the backup gateway is established. Use the optional keepalive keyword with the <i>seconds</i> and <i>retry-count</i> arguments to specify the keepalive timeout in seconds and the retry count. Use the optional source keyword and <i>ip-address</i> argument to specify the use of an IP address as the source for CNS event agent communications. <p>Note Until the cns event command is entered, no transport connections to the CNS event bus are made and therefore no other CNS agents are operational.</p>
Step 6	<p>exit</p> <p>Example: Router(config)# exit</p>	<p>Exits global configuration mode and returns to privileged EXEC mode.</p>

What to Do Next

If you do not need to configure any advanced CNS features, proceed to the [“Monitoring and Verifying the CNS Agents”](#) section on page 14.

Configuring Advanced CNS Features

Perform this task to configure more advanced CNS features. After the CNS agents are operational, you can configure some other features. You can enable the CNS inventory agent—that is, send an inventory of the router's line cards and modules to the CNS configuration engine—and enter CNS inventory mode.

Some other advanced features allow you to use the Software Developer's Toolkit (SDK) to specify how CNS notifications should be sent or how to access MIB information. Two encapsulation methods can be used: either nongranular (SNMP) encapsulation or granular (XML) encapsulation.

Incremental Configuration

Incremental or partial configuration allows the remote router to be incrementally configured after its initial configuration. You must perform these configurations manually through the CNS configuration engine. The registrar allows you to change the configuration templates, edit parameters, and submit the new configuration to the router without a software or hardware restart.

Prerequisites

This task assumes that CNS is operational and that the required CNS agents are configured.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **cns config partial** {*host-name* | *ip-address*} [**encrypt**] [*port-number*] [**source** *ip-address*] [**inventory**]
4. **logging cns-events** [*severity-level*]
5. **cns mib-access encapsulation** {**snmp** | **xml** [*size bytes*]}
6. **cns notification encapsulation** {**snmp** | **xml**}
7. **cns inventory**
8. **transport event**
9. **exit**

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example: Router> enable	<ul style="list-style-type: none"> • Enter your password if prompted.
Step 2	configure terminal	Enters global configuration mode.
	Example: Router# configure terminal	

	Command or Action	Purpose
Step 3	<p>cns config partial {<i>host-name</i> <i>ip-address</i>} [encrypt] [<i>port-number</i>] [source <i>ip-address</i>] [inventory]</p> <p>Example: Router(config)# cns config partial 172.28.129.22 80</p>	<p>(Optional) Starts the CNS configuration agent, which provides CNS configuration services to Cisco IOS clients, and initiates an incremental (partial) configuration.</p> <ul style="list-style-type: none"> Use the optional <i>port-number</i> argument to specify the port number for the configuration server. The default is 80. Use the optional source keyword and <i>ip-address</i> argument to specify the use of an IP address as the source for CNS configuration agent communications. Use the optional inventory keyword to send an inventory of the line cards and modules in the router to the CNS configuration engine as part of the HTTP request. <p>Note The optional encrypt keyword is available only in images that support SSL.</p>
Step 4	<p>logging cns-events [<i>severity-level</i>]</p> <p>Example: Router(config)# logging cns-events 2</p>	<p>(Optional) Enables XML-formatted system event message logging to be sent through the CNS event bus.</p> <ul style="list-style-type: none"> Use the optional <i>severity-level</i> argument to specify the number or name of the desired severity level at which messages should be logged. The default is level 7 (debugging).
Step 5	<p>cns mib-access encapsulation {snmp xml [<i>size bytes</i>]}</p> <p>Example: Router(config)# cns mib-access encapsulation snmp</p>	<p>(Optional) Specifies the type of encapsulation to use when accessing MIB information.</p> <ul style="list-style-type: none"> Use the snmp keyword to specify that nongranular encapsulation is used to access MIB information. Use the xml keyword to specify that granular encapsulation is used to access MIB information. The optional size keyword specifies the maximum size for response events, in bytes. The default byte value is 3072.
Step 6	<p>cns notifications encapsulation {snmp xml}</p> <p>Example: Router(config)# cns notifications encapsulation xml</p>	<p>(Optional) Specifies the type of encapsulation to use when sending CNS notifications.</p> <ul style="list-style-type: none"> Use the snmp keyword to specify that nongranular encapsulation is used when CNS notifications are sent. Use the xml keyword to specify that granular encapsulation is used when CNS notifications are sent.
Step 7	<p>cns inventory</p> <p>Example: Router(config)# cns inventory</p>	<p>Enables the CNS inventory agent and enters CNS inventory mode.</p> <ul style="list-style-type: none"> An inventory of the router's line cards and modules is sent to the CNS configuration engine.

	Command or Action	Purpose
Step 8	transport event Example: Router(cns-inv)# transport event	Specifies that inventory requests are sent out with each CNS inventory agent message.
Step 9	exit Example: Router(cns-inv)# exit	Exits CNS inventory mode and returns to global configuration mode. <ul style="list-style-type: none"> Repeat this command to return to privileged EXEC mode.

Monitoring and Verifying the CNS Agents

Perform this optional task to display the status of the CNS event agent connection and to display a list of subjects about the CNS event agent connection.

SUMMARY STEPS

1. **enable**
2. **show cns event connections**
3. **show cns event subject** [*name*]

DETAILED STEPS

Step 1 enable

Enables privileged EXEC mode. Enter your password if prompted.

```
Router> enable
```

Step 2 show cns event connections

Use this command to display the status of the CNS event agent connection—such as whether it is connecting to the gateway, connected, or active—and to display the gateway used by the event agent and its IP address and port number.

```
Router# show cns event connections
```

```
The currently configured primary event gateway:
```

```
    hostname is 10.1.1.1.
```

```
    port number is 11011.
```

```
Event-Id is Internal test1
```

```
Keepalive setting:
```

```
    none.
```

```
Connection status:
```

```
    Connection Established.
```

```
The currently configured backup event gateway:
```

```
    none.
```

```
The currently connected event gateway:
```

```
    hostname is 10.1.1.1.
```

```
    port number is 11011.
```

Step 3 **show cns event subject** [*name*]

Use this command to display a list of subjects of the CNS event agent that are subscribed to by applications.

```
Router# show cns event subject
```

The list of subjects subscribed by applications.

```
cisco.cns.mibaccess:request
cisco.cns.config.load
cisco.cns.config.reboot
cisco.cns.exec.cmd
```

Configuration Examples for CNS Agents

This section contains the following configuration examples:

- [Deploying the CNS Router: Example, page 15](#)
- [Configuring a Partial Configuration: Example, page 15](#)
- [Enabling and Configuring CNS Agents: Example, page 16](#)

Deploying the CNS Router: Example

The following example shows an initial configuration on a remote router. The host name of the remote router is the unique ID. The CNS configuration engine IP address is 172.28.129.22.

```
Router(config)# cns config connect-intf serial ping-interval 1 retries 1
Router(config-cns-conn-if)# config-cli ip address negotiated
Router(config-cns-conn-if)# config-cli encapsulation ppp
Router(config-cns-conn-if)# config-cli ip directed-broadcast
Router(config-cns-conn-if)# config-cli no keepalive
Router(config-cns-conn-if)# config-cli no shutdown
Router(config-cns-conn-if)# exit
Router(config)# hostname RemoteRouter
RemoteRouter(config)# ip route 172.28.129.22 255.255.255.0 10.11.11.1
RemoteRouter(config)# cns id Ethernet 0 ipaddress
RemoteRouter(config)# cns config initial 10.1.1.1 no-persist
RemoteRouter(config)# cns mib-access encapsulation xml
RemoteRouter(config)# cns notifications encapsulation xml
RemoteRouter(config)# cns inventory
Router(cns_inv)# transport event
Router(cns_inv)# exit
```

Configuring a Partial Configuration: Example

Incremental or partial configuration allows the remote router to be incrementally configured after its initial configuration. You must perform these configurations manually through the CNS configuration engine. The registrar allows you to change the configuration templates, edit parameters, and submit the new configuration to the router without a software or hardware restart.

The following example shows incremental (partial) configuration on a remote router. The CNS configuration engine IP address is 172.28.129.22, and the port number is 80.

```
Router(config)# cns config partial 172.28.129.22 80
```

Enabling and Configuring CNS Agents: Example

The following example shows various CNS agents being enabled and configured starting with the configuration agent being enabled with the **cns config partial** command to configure an incremental (partial) configuration on a remote router. The CNS configuration engine IP address is 172.28.129.22, and the port number is 80. The CNS exec agent is enabled with an IP address of 172.28.129.23, and the CNS event agent is enabled with an IP address of 172.28.129.24. Until the CNS event agent is enabled, no other CNS agents are operational.

```
Router(config)# cns config partial 172.28.129.22 80
Router(config)# cns exec 172.28.129.23 source 172.22.2.2
Router(config)# cns event 172.28.129.24 source 172.22.2.1
Router(config)# exit
```

Additional References

The following sections provide references related to CNS agents.

Related Documents

Related Topic	Document Title
CNS event agent	<i>CNS Event Agent</i> feature document, Release 12.2(2)T
CNS configuration engine	<i>Cisco Intelligence Engine 2100 Configuration Registrar Manual</i> , Release 1.1 or later
CNS flow-through provisioning	<i>CNS Flow-Through Provisioning</i> feature document, Release 12.2(8)T

Standards

Standards	Title
No new or modified standards are supported by this feature, and support for existing standards has not been modified by this feature.	—

MIBs

MIBs	MIBs Link
No new or modified MIBs are supported by this feature, and support for existing MIBs has not been modified by this feature.	To locate and download MIBs for selected platforms, Cisco IOS releases, and feature sets, use Cisco MIB Locator found at the following URL: http://www.cisco.com/go/mibs

RFCs

RFCs	Title
No new or modified RFCs are supported by this feature, and support for existing RFCs has not been modified by this feature.	—

Technical Assistance

Description	Link
Technical Assistance Center (TAC) home page, containing 30,000 pages of searchable technical content, including links to products, technologies, solutions, technical tips, and tools. Registered Cisco.com users can log in from this page to access even more content.	http://www.cisco.com/public/support/tac/home.shtml

Command Reference

This section documents new and modified commands only.

- [announce config](#)
- [clear cns config stats](#)
- [clear cns counters](#)
- [clear cns event stats](#)
- [cns config cancel](#)
- [cns config connect-intf](#)
- [cns config initial](#)
- [cns config notify](#)
- [cns config partial](#)
- [cns config retrieve](#)
- [cns event](#)
- [cns exec](#)
- [cns id](#)
- [cns inventory](#)
- [cns mib-access encapsulation](#)
- [cns notifications encapsulation](#)
- [cns trusted-server](#)
- [config-cli](#)
- [debug cns exec](#)
- [line-cli](#)
- [logging cns-events](#)
- [show cns config stats](#)
- [show cns event connections](#)
- [show cns event stats](#)
- [show cns event subject](#)
- [transport event](#)

announce config

To specify that an unsolicited configuration inventory is sent out by the CNS inventory agent at bootup, use the **announce config** command in CNS inventory configuration mode. To disable the sending of the configuration inventory, use the **no** form of this command.

announce config

no announce config

Syntax Description This command has no arguments or keywords.

Defaults Disabled

Command Modes CNS inventory configuration

Command History	Release	Modification
	12.3(1)	This command was introduced.
	12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.

Usage Guidelines Use this command to limit inventory requests by the CNS inventory agent. When configured, the routing device details will be announced on the CNS event bus, but the routing device will not respond to any queries from the CNS event bus.

Examples The following example shows how to configure the CNS inventory agent to send out an unsolicited configuration inventory one time only at bootup:

```
Router(config)# cns inventory  
Router(cns_inv)# announce config
```

Related Commands	Command	Description
	cns inventory	Enables the CNS inventory agent and enters CNS inventory configuration mode.

clear cns config stats

To clear the statistics about the CNS configuration agent, use the **clear cns config stats** command in privileged EXEC mode.

clear cns config stats

Syntax Description This command has no arguments or keywords.

Defaults No statistics are cleared.

Command Modes Privileged EXEC

Command History	Release	Modification
	12.3(1)	This command was introduced.
	12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.

Usage Guidelines The **clear cns config stats** command clears all the statistics displayed by the **show cns config stats** command.

Examples The following example shows how to clear all of the statistics for the CNS configuration agent:

```
Router# clear cns config stats
```

Related Commands	Command	Description
	show cns config stats	Displays statistics about the CNS configuration agent.

clear cns counters

To clear all CNS statistics, use the **clear cns counters** command in privileged EXEC mode.

clear cns counters

Syntax Description This command has no arguments or keywords.

Defaults No statistics are cleared.

Command Modes Privileged EXEC

Command History	Release	Modification
	12.3(1)	This command was introduced.
	12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.

Usage Guidelines The **clear cns counters** command clears all the statistics tracked and displayed by CNS agents.

Examples The following example shows how to clear all of the statistics used by CNS:

```
Router# clear cns counters
```

Related Commands	Command	Description
	show cns config stats	Displays statistics about the CNS configuration agent.
	show cns event stats	Displays statistics about the CNS event agent.
	show cns image stats	Displays statistics about the CNS image agent.

clear cns event stats

To clear the statistics about the CNS event agent, use the **clear cns event stats** command in privileged EXEC mode.

clear cns event stats

Syntax Description This command has no arguments or keywords.

Defaults No statistics are cleared.

Command Modes Privileged EXEC

Command History	Release	Modification
	12.3(1)	This command was introduced.
	12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.

Usage Guidelines The **clear cns event stats** command clears all the statistics displayed by the **show cns event stats** command.

Examples The following example shows how to clear all of the statistics for the CNS event agent:

```
Router# clear cns event stats
```

Related Commands	Command	Description
	show cns event stats	Displays statistics about the CNS event agent.

cns config cancel

To remove a partial Cisco Networking Services (CNS) configuration from the list of outstanding partial configurations, use the **cns config cancel** command in EXEC mode.

cns config cancel *queue-id*

Syntax Description	<i>queue-id</i>	Indicates which partial configuration in the list of outstanding partial configurations to remove from the list. This list can be displayed by issuing the show cns config outstanding command in EXEC mode.
---------------------------	-----------------	---

Defaults	No default behavior or values.
-----------------	--------------------------------

Command Modes	Privileged EXEC
----------------------	-----------------

Command History	Release	Modification
	12.2(2)T	This command was introduced.
	12.0(18)ST	This command was integrated into Cisco IOS Release 12.0(18)ST.
	12.0(22)S	This command was integrated into Cisco IOS Release 12.0(22)S.
	12.2(8)T	This command was implemented on additional platforms.
	12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.

Usage Guidelines	Incremental (partial) configurations take place in two steps:
	<ol style="list-style-type: none">1. The configuration agent receives the partial configuration. It checks the configuration commands for syntax, publishes the success or failure of the read and syntax-check operation to the sync-status subject "cisco.cns.config.sync-status," and stores the configuration.2. The configuration agent receives a second event message directing it to either apply or cancel the stored configuration.
	Use the cns config cancel command in error scenarios where the second event message is not received and you need to remove the configuration from the list of outstanding configurations. Currently the maximum number of outstanding configurations is one.

Examples	The following example shows the process of checking the existing outstanding CNS configurations and cancelling the configuration with the <i>queue-id</i> of 1:
-----------------	---

```
Router# show cns config outstanding
```

The outstanding configuration information:

```
queue id   identifier      config-id
1          identifierREAD  config_idREAD
```

```
Router# cns config cancel 1
```

```
Router# show cns config outstanding
```

The outstanding configuration information:

```
queue id    identifier    config-id
```

Related Commands

Command	Description
cns config partial	Starts the CNS configuration agent, which provides CNS configuration services to Cisco IOS clients.
cns event	Configures the CNS event gateway, which provides CNS event services to Cisco IOS clients.
show cns event connections	Displays the status of the CNS event agent connection.
show cns config outstanding	Displays information about incremental CNS configurations that have started but not yet completed.

cns config connect-intf

To specify the interface for connecting to the Cisco Networking Services (CNS) configuration engine, use the **cns config connect-intf** command in global configuration mode. To disable this interface for the connection, use the **no** form of this command.

cns config connect-intf *type number* [**ping-interval** *seconds*] [**retries** *number*]

no cns config connect-intf *type number*

Syntax Description

<i>type number</i>	Interface type and number for the connecting interface.
ping-interval <i>seconds</i>	(Optional) Interval between successive ping attempts. Values are from 1 to 30 seconds. The default is 10 seconds.
retries <i>number</i>	(Optional) Number of times that a ping will be retried. Values are from 1 to 30 seconds. The default is 5 seconds.

Defaults

The ping interval defaults to 10 seconds.
The number of retries defaults to 5.

Command Modes

Global configuration

Command History

Release	Modification
12.2(8)T	This command was introduced.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.

Usage Guidelines

Use this command to connect to the CNS configuration engine using a specific type of interface. You must specify the interface type but need not specify the interface number; the router's bootstrap configuration finds the connecting interface, regardless of the slot in which the card resides or the modem dialout line for the connection, by trying different candidate interfaces or lines until it successfully pings the registrar.

Use this command to enter CSN Connect-interface configuration mode (config-cns-conn-if). Then use one of the following bootstrap-configuration commands to connect to the registrar for initial configuration:

- **config-cli** followed by commands that, used as is, configure the interface.
- **line-cli** followed by a command to configure modem lines to enable dialout and, after that, commands to configure the modem dialout line.

The **config-cli** command accepts the special directive character "&," which acts as a placeholder for the interface name. When the configuration is applied, the & is replaced with the interface name. Thus, for example, if we are able to connect using FastEthernet0/0, the command

```
config-cli ip route 0.0.0.0 0.0.0.0 &
```

generates the command

```
ip route 0.0.0.0 0.0.0.0 FastEthernet0/0.
```

Similarly, the command

```
config-virtual terminal line (vty) cns id & ipaddress
```

generates the command

```
cns id FastEthernet0/0 ipaddress
```

Examples

In the following example, the user connects to a configuration engine using the async interface and issues a number of commands:

```
Router(config)# cns config connect-intf Async
Router(config-cns-conn-if)# config-cli encapsulation ppp
Router(config-cns-conn-if)# config-cli ip unnumbered FastEthernet0/0
Router(config-cns-conn-if)# config-cli dialer rotary-group 0
Router(config-cns-conn-if)# line-cli modem InOut
Router(config-cns-conn-if)# line-cli ...<other line commands>...
Router(config-cns-conn-if)# exit
```

These commands result in the following configuration being applied:

```
line 65
modem InOut
.
.
.
interface Async65
encapsulation ppp
dialer in-band
dialer rotary-group 0
```

Related Commands

Command	Description
cns config cancel	Cancels an incremental two-phase synchronization configuration.
cns config initial	Starts the CNS configuration agent and initiates an initial configuration.
cns config notify	Detects CNS configuration changes and sends an event containing the previous and current configuration.
cns config partial	Starts the CNS configuration agent, which provides CNS configuration services to Cisco IOS clients.

cns config initial

To enable the CNS configuration agent and initiate a download of the initial configuration, use the **cns config initial** command in global configuration mode. To remove an existing **cns config initial** command from the running configuration of the routing device, use the **no** form of this command.

cns config initial {*host-name* | *ip-address*} [**encrypt**] [*port-number*] [**page** *page*] [**syntax-check**] [**no-persist**] [**source** *ip-address*] [**event**] [**inventory**]

no cns config initial

Syntax Description	
<i>host-name</i>	Host name of the configuration server.
<i>ip-address</i>	IP address of the configuration server.
encrypt	(Optional) Uses a Secure Socket Layer (SSL) encrypted link to the event gateway. Note This keyword is available only in images that support SSL.
<i>port-number</i>	(Optional) Port number of the configuration service. The value is from 0 to 65535. The default is 80 with no encryption and 443 with encryption.
page <i>page</i>	(Optional) Web page where the configuration is located. The default is /cns/config.asp.
syntax-check	(Optional) Turns on syntax checking.
no-persist	(Optional) Suppresses the default automatic writing to NVRAM of the configuration pulled as a result of issuing the cns config initial command. If not present, issuing the cns config initial command causes the resultant configuration to be automatically written to NVRAM.
source <i>ip-address</i>	(Optional) IP address to use as the source of CNS communications.
event	(Optional) Sends an event to the event bus notifying successful completion of the configuration or warning that the configuration contained errors. If the CNS event agent is not configured, the event will be saved until the CNS event agent is enabled. If the event keyword is not specified, a log message is sent to the console of the device after the configuration is complete.
inventory	(Optional) Sends an inventory of the line cards and modules in the router to the CNS configuration engine as part of the HTTP request.

Defaults

The port number defaults to 80 with no encryption and 443 with encryption.
Default web page of the initial configuration is /cns/config.asp.

Command Modes

Global configuration

Command History

Release	Modification
12.2(2)T	This command was introduced.
12.0(18)ST	This command was integrated into Cisco IOS Release 12.0(18)ST.
12.0(22)S	This command was integrated into Cisco IOS Release 12.0(22)S.

Release	Modification
12.2(2)XB	This command was implemented on Cisco IAD2420 series Integrated Access Devices (IADs).
12.2(8)T	The source and encrypt keywords were added.
12.3(1)	The inventory keyword was added.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.

Usage Guidelines

Use this command when a basic configuration—called a bootstrap configuration—is added to multiple routers before being deployed. When a router is initially powered (or each time a router is reloaded when the **no-persist** keyword is used) the **cns config initial** command will cause a configuration file—called an initial configuration—for the router to be downloaded from the configuration server. The initial configuration can be unique for each router.

When the configuration has been received by the router, each line of the configuration will be applied in the same order as it was received. If the Cisco IOS parser has an error with one of the lines of the configuration, then all the configuration up to this point will be applied to the router, but none of the configuration beyond the error will be applied. If an error occurs, the command will retry until it successfully completes. Once the configuration has successfully completed the **cns config initial** command will be removed from the running configuration. By default, NVRAM will be updated except when the **no-persist** keyword is configured.

When this command is used with the **event** keyword, a single message will be published on the event bus after the configuration is complete. The event bus will display one of the following status messages:

- `cisco.mgmt.cns.config.complete`—CNS configuration agent successfully applied the initial configuration.
- `cisco.mgmt.cns.config.warning`—CNS configuration agent fully applied the initial configuration, but encountered possible semantic errors.

Examples

The following example shows how to enable the CNS configuration agent and initiate an initial configuration:

```
Router# cns config initial 10.19.4.5 page /cns/config/first.asp
```

Related Commands

Command	Description
cns config connect-intf	Specifies the interface for connecting to the CNS configuration engine.
cns config notify	Detects CNS configuration changes and sends an event containing the previous and current configuration.
cns config retrieve	Returns the configuration of a routing device if the CNS configuration agent is enabled and the partial configuration is complete.
cns event	Configures the CNS event gateway, which provides CNS event services to Cisco IOS clients.
show cns config status	Displays information about the status of the CNS configuration agent.

cns config notify

To notify CNS agents of configuration changes on Cisco IOS devices, use the **cns config notify** command in global configuration mode. To disable notifications, use the **no** form of this command.

cns config notify {**all** | **diff**} [**interval** *minutes*] [**no_cns_events**] [**old-format**]

no cns config notify {**all** | **diff**} [**interval** *minutes*] [**no_cns_events**] [**old-format**]

Syntax Description

all	Captures all configuration commands for the config-changed event output.
diff	Captures commands that change configuration for the config-changed event output.
interval <i>minutes</i>	(Optional) Specifies the amount of time after the last configuration change that the config-changed event is sent. The default is 5 minutes. The timer starts when you make a configuration change and you remain in configuration mode after the configuration change. If you enter the end command, the config-changed event is sent immediately.
no_cns_events	(Optional) Disables event notification for configurations changed through an XML file. If the configuration is changed using the command-line interface (CLI), the config-changed event will be sent.
old-format	(Optional) Provides the event notification in the old XML format for backwards compatibility.

Defaults

The interval defaults to 5 minutes.

Command Modes

Global configuration

Command History

Release	Modification
12.2(8)T	This command was introduced.
12.2(11)T	The diff keyword was removed.
12.3(1)	The diff and old-format keywords were added.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.

Usage Guidelines

When the **cns config notify** command is enabled, commands entered in configuration mode are detected. If the **all** keyword is specified, the command is stored for future notification. If the **diff** keyword is specified, the command is stored for future notification if the software determines that the command will cause a configuration change. The **diff** keyword also allows the software to store information about the command including previous configuration states, source of the change (for example, a telnet user), and the time of configuration.

The stored information is formatted in XML and sent as part of a CNS config agent change notification event. A CNS config agent change notification event is sent to the CNS event bus when configuration mode is exited or no activity from that source has occurred for the configured interval time.

You must enable the CNS event agent using the **cns event** command before configuring this command. If the CNS event agent is not configured, the notification event will be queued and sent when the CNS event agent is enabled. If the CNS config notify queue is full, subsequent events are dropped and a “lost” CNS config change notification is sent when the CNS event agent is enabled.

Use the **no_cns_events** for applications that already record configuration changes sent to the routing device through the CNS event bus.

Use the **old-format** keyword to generate XML output—only the entered command and previous configuration state—that is compatible with the versions of this commands when the **diff** keyword was removed.

Examples

The following example detects configuration changes for all configuration commands:

```
Router(config)# cns config notify all
```

Related Commands

Command	Description
cns config cancel	Cancels an incremental two-phase synchronization configuration.
cns config connect-intf	Specifies the interface for connecting to the CNS configuration engine.
cns config initial	Starts the CNS configuration agent and initiates an initial configuration.
cns config partial	Starts the CNS configuration agent, which provides CNS configuration services to Cisco IOS clients.
cns event	Enables and configures CNS event agent services.

cns config partial

To start the CNS configuration agent and accept a partial configuration, use the **cns config partial** command in global configuration mode. To shut down the CNS partial configuration agent, use the **no** form of this command.

cns config partial {*host-name* | *ip-address*} [**encrypt**] [*port-number*] [**source** *ip-address*]
[**inventory**]

no cns config partial

Syntax Description	
<i>host-name</i>	Host name of the configuration server.
<i>ip-address</i>	IP address of the configuration server.
encrypt	(Optional) Uses a Secure Socket Layer (SSL) encrypted link between the router and the web server. Note This keyword is available only in images that support SSL.
<i>port-number</i>	(Optional) Port number of the configuration service. The value is from 0 to 65535. The default is 80 with no encryption and 443 with encryption.
source <i>ip-address</i>	(Optional) IP address to use for the source of this device.
inventory	(Optional) Sends an inventory of the line cards and modules in the router to the CNS configuration engine as part of the HTTP request.

Defaults The port number defaults to 80 with no encryption and 443 with encryption.

Command Modes Global configuration

Command History	Release	Modification
	12.2(2)T	This command was introduced.
	12.0(18)ST	This command was integrated into Cisco IOS Release 12.0(18)ST.
	12.0(22)S	This command was integrated into Cisco IOS Release 12.0(22)S.
	12.2(2)XB	This command was implemented on Cisco IAD2420 series Integrated Access Devices (IADs).
	12.2(8)T	The source and encrypt keywords were added.
	12.3(1)	The inventory keyword was added.
	12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.

Usage Guidelines Use this command to start the CNS partial configuration agent. You must enable the CNS event agent using the **cns event** command before configuring this command. The CNS event agent sends an event with the subject "cisco.mgmt.cns.config.load" to specify whether configuration data can be pushed to the CNS partial configuration agent or pulled from a configuration server by the CNS partial configuration agent.

In the push model, the event message delivers the configuration data to the partial configuration agent.

In the pull model, the event message triggers the partial configuration agent to pull the configuration data from the CNS configuration engine. The event message contains information about the CNS configuration engine, not the actual configuration data. The host name or IP address is the address of the CNS configuration engine from which the configuration is pulled. Use the **cns trusted-server** command to specify which CNS configuration engines can be used by the CNS partial configuration agent.

When the configuration has been received by the router, each line of the configuration will be applied in the same order as it was received. If the IOS parser has an error with one of the lines of the configuration, then all the configuration up to this point will be applied to the router, but none of the configuration beyond the error will be applied. If an error occurs, the command will retry until it successfully completes. In the pull mode, the command will not retry after an error. By default, NVRAM will be updated except when the **no-persist** keyword is configured.

A single message will be published on the CNS event bus after the partial configuration is complete. The CNS event bus will display one of the following status messages:

- **cisco.mgmt.cns.config.complete**—CNS configuration agent successfully applied the partial configuration.
- **cisco.mgmt.cns.config.warning**—CNS configuration agent fully applied the partial configuration, but encountered possible semantic errors.
- **cisco.mgmt.cns.config.failure**—CNS configuration agent encountered an error and was not able to apply the configuration.

Examples

The following example shows how to configure the CNS partial configuration agent to accept events from the event gateway at 172.28.129.22. The CNS partial configuration agent will connect to the CNS configuration server at 172.28.129.22, port number 80. The CNS partial configuration agent requests are redirected to a configuration server at 172.28.129.40, port number 80.

```
Router(config)# cns event 172.28.129.22
Router(config)# cns trusted-server config 172.28.129.40
Router(config)# cns config partial 172.28.129.22
```

Related Commands

Command	Description
cns config initial	Starts the CNS configuration agent and initiates an initial configuration.
cns event	Enables and configures CNS event agent services.
cns trusted-server	Specifies a trusted server for CNS agents.
show cns config outstanding	Displays information about incremental CNS configurations that have started but are not yet completed.

cns config retrieve

To request the configuration of a routing device, use the **cns config retrieve** command in EXEC mode.

```
cns config retrieve {host-name | ip-address} [encrypt] [port-number] [page page]
[overwrite-startup] [syntax-check] [no-persist] [source ip-address] [event] [inventory]
```

Syntax Description

<i>host-name</i>	Host name of the configuration server.
<i>ip-address</i>	IP address of the configuration server.
encrypt	(Optional) Uses a Secure Socket Layer (SSL) encrypted link to the event gateway. Note This keyword is available only in images that support SSL.
<i>port-number</i>	(Optional) Port number of the configuration service. The value is from 0 to 65535. The default is 80 with no encryption and 443 with encryption.
page page	(Optional) Web page where the configuration is located. The default is /cns/config.asp.
overwrite-startup	(Optional) Replaces the startup configuration file. Does not apply to the running configuration file.
syntax-check	(Optional) Turns on syntax checking.
no-persist	(Optional) Suppresses the default automatic writing to NVRAM of the configuration pulled as a result of issuing the cns config retrieve command. If not present, issuing the cns config retrieve command causes the resultant configuration to be automatically written to NVRAM.
source ip-address	(Optional) IP address to use as the source of CNS communications.
event	(Optional) Sends an event to the CNS event bus stating successful completion of the configuration, a warning that the configuration contained errors, or a message noting that the configuration failed. If the CNS event agent is not configured, the event will be saved until the CNS event agent is enabled. If the event keyword is not specified, a log message is sent to the console of the device after the configuration is complete.
inventory	(Optional) Sends an inventory of the line cards and modules in the router to the CNS configuration engine as part of the HTTP request.

Defaults

The port number defaults to 80 with no encryption and 443 with encryption.
Default web page of the initial configuration is /cns/config.asp.

Command Modes

EXEC

Command History

Release	Modification
12.2(2)T	This command was introduced.
12.0(18)ST	This command was integrated into Cisco IOS Release 12.0(18)ST.
12.0(22)S	This command was integrated into Cisco IOS Release 12.0(22)S.

Release	Modification
12.3(1)	The inventory keyword was added.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.

Usage Guidelines

Use this command to request the configuration of a device from a configuration server. Use the **cns trusted-server** command to specify which configuration server can be used (trusted).

When the configuration has been received by the router, each line of the configuration will be applied in the same order as it was received. If the IOS parser has an error with one of the lines of the configuration, then all the configuration up to this point will be applied to the router, but none of the configuration beyond the error will be applied. If an error occurs, the command will not retry.

A single message will be published on the event bus after the partial configuration is complete. The event bus will display one of the following status messages:

- cisco.mgmt.cns.config.complete—CNS configuration agent successfully applied the configuration.
- cisco.mgmt.cns.config.warning—CNS configuration agent fully applied the configuration, but encountered possible semantic errors.
- cisco.mgmt.cns.config.failure—CNS configuration agent encountered an error and was not able to apply the configuration.

The **cns config retrieve** command can be used with Command Scheduler commands (for example, **kron policy-list** and **cli** commands) in environments where it is not practical to use the CNS event agent and the **cns config partial** command. Configured within the **cli** command, the **cns config retrieve** command can be used to poll the configuration server to detect configuration changes.

Examples

The following example shows how to request a configuration from a trusted server at 10.1.1.1:

```
Router(config)# cns trusted-server all 10.1.1.1
Router(config)# cns config retrieve 10.1.1.1
```

Related Commands

Command	Description
cli	Specifies EXEC CLI commands within a Command Scheduler policy list.
cns config initial	Starts the CNS configuration agent and initiates an initial configuration.
cns trusted-server	Specifies a trusted server for CNS agents.
kron policy-list	Specifies a name for a Command Scheduler policy and enters kron-policy configuration mode.
show cns config status	Displays information about the status of the CNS configuration agent.

cns event

To configure the CNS event gateway, which provides CNS event services to Cisco IOS clients, use the **cns event** command in global configuration mode. To remove the specified event gateway from the gateway list, use the **no** form of this command.

cns event {*host-name* | *ip-address*} [**encrypt**] [*port-number*] [**backup**] [**failover-time** *seconds*]
[**keepalive** *seconds* *retry-count*] [**source** *ip-address*]

no cns event {*host-name* | *ip-address*} [**encrypt**] [*port-number*] [**backup**] [**failover-time** *seconds*]
[**keepalive** *seconds* *retry-count*] [**source** *ip-address*]

Syntax Description

<i>host-name</i>	Host name of the event gateway.
<i>ip-address</i>	IP address of the event gateway.
encrypt	(Optional) Uses a Secure Socket Layer (SSL) encrypted link to the event gateway. Note This keyword is available only in images that support SSL.
<i>port-number</i>	(Optional) Port number for the event gateway. The default is 11011 with no encryption or 11012 with encryption.
backup	(Optional) Indicates that this is the backup gateway. If omitted, indicates that this is the primary gateway. Before you can configure a backup gateway, you must already have configured a primary gateway. Optional keywords, if omitted, are set as for the primary gateway.
failover-time <i>seconds</i>	(Optional) Specifies a time interval in seconds to wait for the primary gateway route after the route to the backup gateway is established. The default is 3.
keepalive <i>seconds</i> <i>retry-count</i>	(Optional) Keepalive timeout in seconds and retry count.
source <i>ip-address</i>	(Optional) IP address to use as the source for CNS communications.

Defaults

The event gateway port number default is 11011 with no encryption or 11012 with encryption.
The number of seconds to wait for a primary gateway route defaults to 3.
The system uses format 2.

Command Modes

Global configuration

Command History

Release	Modification
12.2(2)T	This command was introduced.
12.0(18)ST	This command was integrated into the Cisco IOS 12.0(18)ST Release.
12.0(22)S	This command was integrated into Cisco IOS Release 12.0(22)S.
12.2(2)XB	This command was implemented on Cisco IAD2420 series Integrated Access Devices (IADs).
12.2(8)T	The encrypt , init-retry , source , and force-fmt1 keywords were added.

Release	Modification
12.3(1)	The init-retry keyword was replaced with the failover-time keyword. The force-fmt1 keyword was removed.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.

Usage Guidelines

The CNS event agent must be enabled before any of the other CNS agents are configured because the CNS event agent provides a transport connection to the CNS event bus for all other CNS agents. The other CNS agents use the connection to the CNS event bus to send and receive messages. The CNS event agent does not read or modify the messages.

The **failover-time** keyword is useful if you have a backup CNS event gateway configured. If the CNS event agent is trying to connect to the gateway and it discovers that the route to the backup is available before the route to the primary gateway, the *seconds* argument specifies how long the CNS event agent will continue to search for a route to the primary gateway before attempting to link to the backup gateway.

Unless you are using a bandwidth-constrained link, you should set a keepalive timeout and retry count. Doing so allows the management network to recover gracefully should a Cisco IE2100 configuration engine ever fail. Without the keepalive data, such a failure requires manual intervention on every device. The *seconds* multiplied by the *retry-count* determines the length of idle time before the CNS event agent will disconnect and attempt to reconnect to the gateway. We recommend a minimum *retry-count* of two.

If the optional **source** keyword is used, the source IP address might be a secondary IP address of a specific interface to allow a management network to run on top of a production network.

Examples

The following example shows how to set the address of the primary CNS event gateway to the configuration engine software running on IP address 10.1.2.3, port 11011, with a keepalive of 60 seconds and a retry count of 5:

```
Router(config)# cns event 10.1.2.3 11011 keepalive 60 5
```

Related Commands

Command	Description
cns id	Sets the unique event ID or config ID router identifier.
show cns event status	Displays status information about the CNS event agent.

cns exec

To enable and configure the CNS exec agent, which provides CNS exec services to Cisco IOS clients, use the **cns exec** command in global configuration mode. To disable the use of CNS exec agent services, use the **no** form of this command.

cns exec [*host-name* | *ip-address*] [**encrypt** [*enc-port-number*]] [*port-number*] [**source** *ip-address*]

no cns exec [*host-name* | *ip-address*] [**encrypt** [*enc-port-number*]] [*port-number*] [**source** *ip-address*]

Syntax Description	<i>host-name</i>	(Optional) Host name of the exec server.
	<i>ip-address</i>	(Optional) IP address of the exec server.
	encrypt	(Optional) Uses a Secure Socket Layer (SSL) encrypted link to the exec agent server.
	Note This keyword is available only in images that support SSL.	
	<i>enc-port-number</i>	(Optional) Port number for the encrypted exec server. The default is 443.
	<i>port-number</i>	(Optional) Port number for the exec server. The default is 80.
	source	(Optional) Specifies the use of an IP address defined by the <i>ip-address</i> argument as the source for CNS exec agent communications.
	<i>ip-address</i>	(Optional) IP address.

Defaults

The default exec server port number is 80.
The default encrypted exec server port number is 443.

Command Modes

Global configuration

Command History

Release	Modification
12.3(1)	This command was introduced.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.

Usage Guidelines

The CNS exec agent allows a remote application to execute an EXEC mode command-line interface (CLI) command on a Cisco IOS device by sending an event message containing the command. A restricted set of EXEC CLI commands—**show** commands—are supported.

In previous Cisco IOS Releases the CNS exec agent was enabled when the CNS configuration agent was enabled through the **cns config partial** command.

Examples

The following example shows how to enable the CNS exec agent with an IP address of 10.1.2.3 for the exec agent server, a port number of 93, and a source IP address of 172.17.2.2:

```
Router(config)# cns exec 10.1.2.3 93 source 172.17.2.2
```

Related Commands	Command	Description
	cns event	Enables and configures CNS event agent services.
	show cns event subject	Displays a list of CNS event agent subjects that are subscribed to by applications.

cns id

To set the unique event ID, or config ID Cisco IOS device identifier used by CNS services, use the **cns id** command in global configuration mode. To set the identifier to the host name of the Cisco IOS device, use the **no** form of this command.

If ID Choice Is IP Address or MAC Address

```
cns id type number {dns-reverse | ipaddress | mac-address} [event]
```

```
no cns id type number {dns-reverse | ipaddress | mac-address} [event]
```

If ID Choice Is Anything Else

```
cns id {hardware-serial | hostname | string string} [event]
```

```
no cns id {hardware-serial | hostname | string string} [event]
```

Syntax Description		
	<i>type number</i>	Type of interface (for example, ethernet , group-async , loopback , or virtual-template) and the interface number. Indicates from which interface the IP or MAC address should be retrieved in order to define the unique ID.
	dns-reverse	Uses DNS reverse lookup to retrieve the host name of the Cisco IOS device and assign it as the unique ID.
	ipaddress	Uses the IP address specified in the <i>type number</i> arguments as the unique ID.
	mac-address	Uses the MAC address specified in the <i>type number</i> arguments as the unique ID.
	event	(Optional) Sets this ID to be the event ID value, which is used to identify the Cisco IOS device for CNS event services. If both optional keywords are omitted, the event ID is set to the host name of the Cisco IOS device.
	hardware-serial	Uses the hardware serial number as the unique ID.
	hostname	Uses the host name as the unique ID. This is the system default.
	string <i>string</i>	Uses an arbitrary text string—typically the host name—as the unique ID.

Defaults

The system defaults to the host name of the Cisco IOS device as the unique ID.

Command Modes

Global configuration

Command History

Release	Modification
12.2(2)XB	This command was introduced on Cisco IAD2420 series IADs.
12.2(8)T	This command was integrated into Cisco IOS Release 12.2(8)T.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.

Usage Guidelines

Use this command to set the unique ID to the CNS configuration agent, which then pulls the initial configuration template to the Cisco IOS device during bootup.

You can set one or both IDs: the config ID value for CNS configuration services, and the event ID value for CNS event services. To set all values, use the command twice.

To set the CNS event ID to the host name of the Cisco IOS device, use the **no** form of this command with the **event** keyword. To set the CNS config ID to the host name of the Cisco IOS device, use the **no** form of this command without the **event** keyword.

Examples

The following example shows how to pass the host name of the Cisco IOS device as the config ID value:

```
Router(config)# cns id hostname
```

The following example shows how to pass the hardware serial number of the Cisco IOS device as the event ID value:

```
Router(config)# cns id hardware-serial event
```

Related Commands

Command	Description
cns event	Enables the CNS event gateway, which provides CNS event services to Cisco IOS clients.

cns inventory

To enable the CNS inventory agent—that is, to send an inventory of the router's line cards and modules to the CNS configuration engine—and enter CNS inventory mode, use the **cns inventory** command in global configuration mode. To disable the CNS inventory agent, use the **no** form of this command.

cns inventory

no cns inventory

Syntax Description This command has no arguments or keywords.

Defaults Disabled

Command Modes Global configuration

Command History	Release	Modification
	12.2(8)T	This command was introduced.
	12.3(1)	The config , event , and notify oir keywords were removed.
	12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.

Usage Guidelines Use this command with the **announce config** and **transport event** CNS inventory configuration mode commands to specify when to notify the CNS configuration engine of changes to the router's port-adaptor and interface inventory. A transport must be specified in CNS inventory configuration mode before any of the CNS inventory commands are executed.

Examples The following example shows how to enable the CNS inventory agent and enter CNS inventory configuration mode:

```
Router(config)# cns inventory
Router(cns_inv)#
```

Related Commands	Command	Description
	announce config	Specifies that an unsolicited configuration inventory is sent out by the CNS inventory agent at bootup.
	cns config initial	Starts the CNS configuration agent and initiates an initial configuration.
	transport events	Specifies that inventory events are sent out by the CNS inventory agent.

cns mib-access encapsulation

To specify whether CNS should use nongranular (SNMP) or granular (XML) encapsulation to access MIBs, use the **cns mib-access encapsulation** command in global configuration mode. To disable the currently specified encapsulation, use the **no** form of this command.

cns mib-access encapsulation {snmp | xml [*size bytes*]}

no cns mib-access encapsulation {snmp | xml}

Syntax Description

snmp	Enables nongranular (SNMP) encapsulation for MIB access.
xml	Enables granular (XML) encapsulation for MIB access.
size bytes	(Optional) Maximum size in bytes for response events. The default is 3072.

Defaults

For XML encapsulation, a maximum size of 3072 bytes.

Command Modes

Global configuration

Command History

Release	Modification
12.2(8)T	This command was introduced on Cisco 2600 series and Cisco 3600 series routers.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.

Examples

The following example specifies that XML be used to access MIBs:

```
Router(config)# cns mib-access encapsulation xml
```

Related Commands

Command	Description
cns notifications encapsulation	Specifies whether CNS notifications should be sent using nongranular (SNMP) or granular (XML) encapsulation.

cns notifications encapsulation

To specify whether CNS notifications should be sent using nongranular (SNMP) or granular (XML) encapsulation, use the **cns notifications encapsulation** command in global configuration mode. To disable the currently specified encapsulation, use the **no** form of this command.

cns notifications encapsulation {snmp | xml}

no cns notifications encapsulation {snmp | xml}

Syntax Description

snmp	Uses nongranular (SNMP) encapsulation to send notifications.
xml	Uses granular (XML) encapsulation to send notifications.

Defaults

This command is disabled.

Command Modes

Global configuration

Command History

Release	Modification
12.2(8)T	This command was introduced on Cisco 2600 series and Cisco 3600 series routers.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.

Examples

The following example shows how to specify that granular notifications should be sent:

```
Router(config)# cns notifications encapsulation xml
```

Related Commands

Command	Description
cns mib-access encapsulation	Specifies whether CNS should use granular (XML) or nongranular (SNMP) encapsulation to access MIBs.

cns trusted-server

To specify a trusted server for CNS agents, use the **cns trusted-server** command in global configuration mode. To disable the use of a trusted server for a CNS agent, use the **no** form of this command.

cns trusted-server { **all-agents** | **config** | **event** | **exec** } { *host-name* | *ip-address* }

no cns trusted-server { **all-agents** | **config** | **event** | **exec** }

Syntax Description

all-agents	Specifies a trusted server for all CNS agents.
config	Specifies a trusted server for CNS config agent.
event	Specifies a trusted server for CNS event agent.
exec	Specifies a trusted server for CNS exec agent.
<i>host-name</i>	Host name of the trusted server.
<i>ip-address</i>	IP address of the trusted server.

Defaults

all-agents

Command Modes

Global configuration

Command History

Release	Modification
12.3(1)	This command was introduced.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.

Usage Guidelines

Use the **cns trusted-server** command to specify a trusted server for an individual CNS agent or all the CNS agents. In previous Cisco IOS Releases CNS agents could connect to any server and this could expose the system to security violations. An attempt to connect to a server not on the list will result in an error message being displayed. For backwards compatibility the configuration of a server address using the configuration command-line interface (CLI) for a CNS agent will result in an implicit trust of the server. The implicit trusted server commands apply only to commands in configuration mode, not EXEC mode commands.

Use this command when a CNS agent will redirect its response to a server address that is not explicitly configured on the command line for the specific CNS agent. For example, the CNS exec agent may have one server configured but receive a message from the CNS Event Bus that overrides the configured server. The new server address has not been explicitly configured so the new server address is not a trusted server. An error will be generated when the CNS exec agent tries to respond to this new server address unless the **cns trusted-server** command has been configured for the new server address.

Examples

The following example shows how to configure server 10.19.2.5 as a trusted server for the CNS event agent:

```
Router# cns trusted-server event 10.19.2.5
```

The following example shows how to configure server 10.2.2.8 as an implicit trusted server for the CNS image agent:

```
Router# cns image server 10.2.2.8 status 10.2.2.8
```

Related Commands

Command	Description
cns config	Configures CNS configuration agent services.
cns event	Enables and configures CNS event agent services.
cns image	Configures CNS image agent services.

config-cli

To connect to the CNS configuration engine using a specific type of interface, use the **config-cli** command in CNS Connect-interface configuration mode.

config-cli {*type* [*number*] | *interface-config-cmd*}

Syntax Description

<i>type</i>	Type of interface. Indicates from which interface the IP or MAC address should be retrieved in order to define the unique ID.
<i>number</i>	(Optional) Interface number. Indicates from which interface the IP or MAC address should be retrieved in order to define the unique ID.
<i>interface-config-cmd</i>	Command that configures the interface. The <i>type</i> argument must be configured before other interface configuration commands.

Defaults

No default behavior or values.

Command Modes

CNS Connect-interface configuration

Command History

Release	Modification
12.2(8)T	This command was introduced on Cisco 2600 series and Cisco 3600 series routers.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.

Usage Guidelines

Begin by using the **cns config connect-intf** command to enter CNS Connect-interface configuration (config-cns-conn-if) submode. Then use either this or its companion CNS bootstrap-configuration command to connect to the CNS configuration engine for initial configuration:

- **config-cli** connects to the registrar using a specific type of interface. You must specify the interface type but need not specify the interface number; the router's bootstrap configuration finds the connecting interface, regardless of the slot in which the card resides, by trying different candidate interfaces until it can ping the configuration engine.
- **line-cli** connects to the registrar using modem dialup lines.

Immediately after either of the commands, enter additional configuration commands as appropriate.

Examples

The following example enters CNS Connect-interface Configuration mode, connects to a configuration engine using an asynchronous interface, and issues a number of commands:

```
Router(config)# cns config connect-intf Async
Router(config-cns-conn-if)# config-cli encapsulation ppp
Router(config-cns-conn-if)# config-cli ip unnumbered FastEthernet0/0
Router(config-cns-conn-if)# config-cli dialer rotary-group 0
Router(config-cns-conn-if)# line-cli modem InOut
Router(config-cns-conn-if)# line-cli ...<other line commands>...
Router(config-cns-conn-if)# exit
```

These commands apply the following configuration:

```
line 65
modem InOut
.
.
.
interface Async65
encapsulation ppp
dialer in-band
dialer rotary-group 0
```

Related Commands

Command	Description
cns config connect-intf	Specifies the interface for connecting to the CNS configuration engine.
line-cli	Connects to the CNS configuration engine using a modem dialup line.

debug cns exec

To display debugging messages about CNS exec agent services, use the **debug cns exec** command in privileged EXEC mode. To disable debugging output, use the **no** or **undebug** form of this command.

debug cns exec {agent | all | decode | messages}

no debug cns exec {agent | all | decode | messages}

undebug cns exec {agent | all | decode | messages}

Syntax Description

agent	Displays debugging messages related to the exec agent.
all	Displays all debugging messages.
decode	Displays debugging messages related to image agent connections.
messages	Displays debugging output related to messages generated by exec agent services.

Defaults

Debugging output is disabled.

Command Modes

Privileged EXEC

Command History

Release	Modification
12.3(1)	This command was introduced.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.

Usage Guidelines

Use the **debug cns exec** command to troubleshoot CNS exec agent services.

Examples

The following example shows a debugging message for the CNS exec agent when a response has been posted to HTTP:

```
Router# debug cns exec agent
```

```
4d20h: CNS exec agent: response posted
```

Related Commands

Command	Description
cns exec	Configures CNS exec agent services.

line-cli

To connect to the CNS configuration engine using a modem dialup line, use the **line-cli** command in CNS Connect-interface configuration mode.

line-cli { *modem-cmd* | *line-config-cmd* }

Syntax Description

<i>modem-cmd</i>	Modem line command that enables dialout. Indicates from which line or interface the IP or MAC address should be retrieved in order to define the unique ID.
<i>line-config-cmd</i>	Command that configures the line. The <i>modem-cmd</i> argument must be configured before other line configuration commands.

Defaults

No default behavior or values.

Command Modes

CNS Connect-interface configuration

Command History

Release	Modification
12.2(8)T	This command was introduced on Cisco 2600 series and Cisco 3600 series routers.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.

Usage Guidelines

Use this command to connect to the CNS configuration engine using a modem dialout line. The bootstrap configuration on the router finds the connecting interface, regardless of the slot in which the card resides or the modem dialout line for the connection, by trying different candidate interfaces or lines until it successfully pings the registrar.

Enter this command in CNS connect-interface-config (config-cns-conn-if) submode. Then use one of the following bootstrap-configuration commands to connect to the registrar for initial configuration:

- **config-cli** followed by commands that, used as is, configure the interface.
- **line-cli** followed by a command to configure modem lines to enable dialout and, after that, commands to configure the modem dialout line.

The **config-cli** command accepts the special directive character “&,” which acts as a placeholder for the interface name. When the configuration is applied, the & is replaced with the interface name. Thus, for example, if we are able to connect using FastEthernet0/0, the following is the case:

- The command **config-cli ip route 0.0.0.0 0.0.0.0 &** generates the command **config ip route 0.0.0.0 0.0.0.0 FastEthernet0/0**.
- The command **cns id & ipaddress** generates the command **cns id FastEthernet0/0 ipaddress**

Examples

The following example enters connect-interface-config if submode, connects to a configuration engine using an asynchronous interface, and issues a number of commands:

```
Router(config)# cns config connect-intf Async
Router(config-cns-conn-if)# config-cli encapsulation ppp
Router(config-cns-conn-if)# config-cli ip unnumbered FastEthernet0/0
Router(config-cns-conn-if)# config-cli dialer rotart-group 0
Router(config-cns-conn-if)# line-cli modem InOut
Router(config-cns-conn-if)# line-cli ...<other line commands>...
Router(config-cns-conn-if)# exit
```

These commands apply the following configuration:

```
line 65
modem InOut
.
.
.
interface Async65
encapsulation ppp
dialer in-band
dialer rotary-group 0
```

Related Commands

Command	Description
cns config connect-intf	Specifies the interface for connecting to the CNS configuration engine.
config-cli	Connects to the CNS configuration engine using a specific type of interface.

logging cns-events

To enable XML-formatted system event message logging to be sent through the CNS event bus, use the **logging cns-events** command in global configuration mode. To disable the ability to send system logging event messages through the CNS event bus, use the **no** form of this command.

logging cns-events [*severity-level*]

no logging cns-events

Syntax Description

<i>severity-level</i>	The number or name of the desired severity level at which messages should be logged. Messages at or numerically lower than the specified level are logged. Severity levels are as follows (enter the number or the keyword): { 0 emergencies }— System is unusable { 1 alerts }—Immediate action needed { 2 critical }—Critical conditions { 3 errors }—Error conditions { 4 warnings }—Warning conditions { 5 notifications }—Normal but significant conditions { 6 informational }—Informational messages { 7 debugging }— Debugging messages
-----------------------	---

Defaults

Level 7: debugging

Command Modes

Global configuration

Command History

Release	Modification
12.2(2)T	This command was introduced.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.

Usage Guidelines

Before you configure this command you must enable the CNS event agent with the **cns event** command because the CNS event agent sends out the CNS event logging messages. The generation of many CNS event logging messages can negatively impact the publishing time of standard CNS event messages that must be sent to the network.

If the **debug cns event** command is active when the **logging cns-events** command is configured, the logging of CNS events is disabled.

Examples

In the following example, the user enables XML-formatted CNS system error message logging to the CNS event bus for messages at levels 0 through 4:

```
Router(config)# logging cns-events 4
```

Related Commands

Command	Description
cns event	Configures CNS event gateway, which provides CNS event services to Cisco IOS clients.
debug cns event	Displays CNS event agent debugging messages.

show cns config stats

To display statistics about the CNS configuration agent, use the **show cns config stats** command in privileged EXEC mode.

show cns config stats

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Modes	Privileged EXEC
----------------------	-----------------

Command History	Release	Modification
	12.2(2)T	This command was introduced.
	12.2(8)T	This command was implemented on Cisco 2600 series and Cisco 3600 series routers.
	12.3(1)	Additional output fields were added.
	12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.

Usage Guidelines	This command displays the following statistics on the CNS configuration agent:
-------------------------	--

- The number of configurations requests received
- The number of configurations completed
- The number of configurations failed
- The number of configurations pending
- The number of configurations cancelled
- The time stamp of the last configuration received
- The time stamp of the initial configuration received

Examples	The following is sample output from the show cns config stats command:
-----------------	---

```
Router# show cns config stats

6 configuration requests received.
4 configurations completed.
1 configurations failed.
1 configurations pending.
0 configurations cancelled.
The time of last received configuration is *May 5 2003 10:42:15 UTC.
Initial Config received *May 5 2003 10:45:15 UTC.
```

Related Commands	Command	Description
	clear cns config stats	Clears all the statistics about the CNS configuration agent.
	show cns config outstanding	Displays information about incremental CNS configurations that have started but not yet completed.

show cns event connections

To display the status of the CNS event agent connection, use the **show cns event connections** command in privileged EXEC mode.

show cns event connections

Syntax Description This command has no arguments or keywords.

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(8)T	This command was introduced.
	12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.

Usage Guidelines Use the **show cns event connections** command to display the status of the event agent connection—such as whether it is connecting to the gateway, connected, or active—and to display the gateway used by the event agent and its IP address and port number.

Examples The following example displays the IP address and port number of the primary and backup gateways:

```
Router# show cns event connections

The currently configured primary event gateway:
    hostname is 10.1.1.1.
    port number is 11011.
Event-Id is Internal test1
Keepalive setting:
    none.
Connection status:
    Connection Established.
The currently configured backup event gateway:
    none.
The currently connected event gateway:
    hostname is 10.1.1.1.
    port number is 11011.
```

Related Commands	Command	Description
	show cns event stats	Displays statistics about the CNS event agent connection.
	show cns event subject	Displays a list of subjects about the CNS event agent connection.

show cns event stats

To display statistics about the CNS event agent connection, use the **show cns event stats** command in privileged EXEC mode.

show cns event stats

Syntax Description

This command has no arguments or keywords.

Command Modes

Privileged EXEC

Command History

Release	Modification
12.2(2)T	This command was introduced.
12.0(18)ST	This command was integrated into Cisco IOS Release 12.0(18)ST.
12.0(22)S	This command was integrated into Cisco IOS Release 12.0(22)S.
12.2(8)T	This command was implemented on the Cisco 2600 series and the Cisco 3600 series routers.
12.3(1)	Output was changed to display statistics generated since last cleared.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.

Usage Guidelines

Use this command to display the following statistics for the CNS event agent:

- Number of events received
- Number of events sent
- Number of events not processed successfully
- Number of events in the queue
- Time stamp showing when statistics were last cleared (time stamp is router time)
- Number of events received since the statistics were cleared
- Time stamp of latest event received (time stamp is router time)
- Time stamp of latest event sent
- Number of applications using the Event Agent
- Number of subjects subscribed

Examples

The following example displays statistics for the CNS event agent:

```
Router# show cns event stats

0 events received.
1 events sent.
0 events not processed.
0 events in the queue.
0 events sent to other IOS applications.
```



```
Event agent stats last cleared at Apr 4 2003 00:55:25 UTC
No events received since stats cleared
The time stamp of the last received event is *Mar 30 2003 11:04:08 UTC
The time stamp of the last sent event is *Apr 11 2003 22:21:23 UTC
3 applications are using the event agent.
0 subjects subscribed.
1 subjects produced.
0 subjects replied.
```

Related Commands

Command	Description
clear cns event stats	Clears all the statistics about the CNS event agent.
cns event	Enables and configures CNS event agent services.
show cns event connections	Displays the status of the CNS event agent connection.
show cns event subject	Displays a list of subjects about the CNS event agent connection.

show cns event subject

To display a list of subjects about the CNS event agent connection, use the **show cns event subject** command in privileged EXEC mode.

show cns event subject [*name*]

Syntax Description

<i>name</i>	(Optional) Displays a list of applications that are subscribing to this specific subject name.
-------------	--

Command Modes

Privileged EXEC

Command History

Release	Modification
12.2(2)T	This command was introduced.
12.0(18)ST	This command was integrated into Cisco IOS Release 12.0(18)ST.
12.0(22)S	This command was integrated into Cisco IOS Release 12.0(22)S.
12.2(8)T	This command was implemented on the Cisco 2600 series and the Cisco 3600 series.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.

Usage Guidelines

Use the **show cns event subject** command to display a list of subjects of the event agent that are subscribed to by applications.

Examples

The following example displays the IP address and port number of the primary and backup gateways:

```
Router# show cns event subject
```

```
The list of subjects subscribed by applications.
cisco.cns.mibaccess:request
cisco.cns.config.load
cisco.cns.config.reboot
cisco.cns.exec.cmd
```

Related Commands

Command	Description
show cns event connections	Displays the status of the CNS event agent connection.
show cns event stats	Displays statistics about the CNS event agent connection.

transport event

To specify that inventory events are sent out by the CNS inventory agent, use the **transport event** command in CNS inventory configuration mode. To disable the transport of inventory events, use the **no** form of this command.

transport event

no transport event

Syntax Description This command has no arguments or keywords.

Defaults Disabled

Command Modes CNS inventory configuration

Command History	Release	Modification
	12.3(1)	This command was introduced.
	12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.

Usage Guidelines Use this command to send out inventory requests with each CNS inventory agent message. When configured, the routing device will respond to queries from the CNS event bus. Online insertion and removal (OIR) events on the routing device will be reported to the CNS event bus.

Examples The following example shows how to enable the CNS inventory agent and configure it to send out inventory events:

```
Router(config)# cns inventory  
Router(cns_inv)# transport event
```

Related Commands	Command	Description
	cns inventory	Enables the CNS inventory agent and enters CNS inventory configuration mode.

CCVP, the Cisco logo, and Welcome to the Human Network are trademarks of Cisco Systems, Inc.; Changing the Way We Work, Live, Play, and Learn is a service mark of Cisco Systems, Inc.; and Access Registrar, Aironet, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, CCSP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Enterprise/Solver, EtherChannel, EtherFast, EtherSwitch, Fast Step, Follow Me Browsing, FormShare, GigaDrive, HomeLink, Internet Quotient, IOS, iPhone, IP/TV, iQ Expertise, the iQ logo, iQ Net Readiness Scorecard, iQuick Study, LightStream, Linksys, MeetingPlace, MGX, Networkers, Networking Academy, Network Registrar, PIX, ProConnect, ScriptShare, SMARTnet, StackWise, The Fastest Way to Increase Your Internet Quotient, and TransPath are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or Website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0711R)

Copyright © 2004 Cisco Systems, Inc. All rights reserved.