



Debug Commands

The commands in this section are for troubleshooting the GGSN. For information about other debug commands, see *Cisco IOS Debug Command Reference*.



Caution

Because debugging output is assigned high priority in the CPU process, it can diminish the performance of the router or even render it unusable. For this reason, use **debug** commands only to troubleshoot specific problems or during troubleshooting sessions with Cisco technical support staff. Moreover, it is best to use **debug** commands during periods of lower network traffic and fewer users. Debugging during these periods decreases the likelihood that increased **debug** command processing overhead will affect system use.

This chapter contains the following:

- [TID/IMSI/MSISDN-Based Conditionally Triggered Debugging, page 756](#)
- [debug condition, page 758](#)
- [debug diameter, page 762](#)
- [debug ggsn csg-group slb, page 763](#)
- [debug ggsn quota-server, page 765](#)
- [debug gprs category fsm event, page 767](#)
- [debug gprs dcca, page 770](#)
- [debug gprs dfp, page 773](#)
- [debug gprs dhcp, page 775](#)
- [debug gprs gtp, page 777](#)
- [debug gprs gtp parsing, page 779](#)
- [debug gprs gtp ppp, page 781](#)
- [debug gprs gtp ppp-regeneration, page 784](#)
- [debug gprs prepaid stand-alone, page 791](#)
- [debug gprs radius, page 792](#)
- [debug gprs redundancy, page 794](#)
- [debug gprs verbose, page 810](#)
- [debug ip iscsi, page 811](#)
- [debug record-storage-module, page 824](#)

TID/IMSI/MSISDN-Based Conditionally Triggered Debugging

When the TID/IMSI/MSISDN-based conditionally triggered debugging feature is enabled, the GGSN generates debugging messages for PDP contexts that match a particular tunnel ID (TID), International Mobile Subscriber Identity (IMSI) value, or Mobile Station ISDN number (MSISDN) entering or leaving the GGSN. The GGSN will not generate debugging output for PDP contexts containing a different TID, IMSI, or MSISDN value.

Normally, the GGSN will generate debugging messages for every PDP context, resulting in a large number of messages that consume system resources and can make it difficult to find the specific information you need. By limiting the number of debugging messages, you can receive messages related to only to PDP contexts you want to troubleshoot.

Usage Guidelines for TID/IMSI/MSISDN-Based Conditional Debugging

Use the following guidelines when configuring TID/IMSI/MSISDN-based conditional debugging on a GGSN.

1. Before enabling a **debug gprs** command, first enable TID/IMSI/MSISDN-based debugging using the **debug condition calling** command. Ensure that the TID/IMSI or MSISDN string match the ones from the Create PDP Context Request.

Examples:

For a create request with TID 12345678090000B0, you would enter:

```
GGSN# debug condition calling 12345678090000B0
Condition 1 set
GGSN#
```

For a create request with IMSI 214365790000000, you would enter:

```
GGSN# debug condition calling 214365790000000
Condition 2 set
GGSN#
```

For a create request with MSISDN 1112223344, you would enter:

```
GGSN# debug condition calling msisdn-1112223344
Condition 3 set
GGSN#
```

To verify the set conditions, enter:

```
GGSN# show debug condition all
Condition 1: calling 12345678090000B0 (0 flags triggered)
Condition 2: calling 214365790000000 (0 flags triggered)
Condition 3: calling 1112223344 (0 flags triggered)
GGSN#
```

2. After turning on TID, IMSI, or MSISDN-based debugging, turn on GPRS debugging by entering the **debug gprs gtp** or the **debug gprs charging** commands.

Once this step is completed, when Create PDP Context Requests are received, the GGSN will display debug messages for those create requests with either a matching TID, IMSI, or MSISDN.

3. Because the **no debug all** command does not disable conditional debug flags, to ensure that you do not receive a flood of debugging messages when disabling debugging, turn off GPRS debug flags first using the **no debug all** command as follows:

```
GGSN# no debug all
All possible debugging has been turned off
GGSN#

GGSN# show debug condition all
Condition 1: calling 12345678090000B0 (1 flags triggered)
Condition 2: calling 214365790000000 (1 flags triggered)
Condition 3: calling 1112223344 (1 flags triggered)

GGSN#
```

4. Disable the conditional debug flags using the **no debug condition all** command:

```
GGSN# no debug condition all
Removing all conditions may cause a flood of debugging messages to result, unless
specified debugging flags are first removed.

Proceed with the removal of all conditions [yes/no] y
2 conditions have been removed
```

5. Verify that the conditional debug flags have been removed using the **show debug condition all** command:

```
GGSN# show debug condition all
% No conditions found
```

debug condition

To limit output for some debug commands based on specified conditions, use the **debug condition** command in privileged EXEC mode. To remove the specified condition, use the **no** form of this command.

debug condition {**called** *dial-string* | **calling** *dial-string* | **calling** [*tid* | *imsi* | **msisdn**-*msisdn*] | **ip** *ip-address* | **next-call gprs** {**apn** *apn-name* | **peer** *sgsn-ip-address* | <cr>} | **username** *username* | **vcid** *vc-id*}

no debug condition {*condition-id* | **all**}

Syntax Description

called <i>dial-string</i>	Generates debugging messages for interfaces with the called party number.
calling <i>dial-string</i>	Generates debugging messages for interfaces with the calling party number.
calling [<i>tid</i> <i>imsi</i> <i>string</i> msisdn - <i>msisdn</i>]	Displays events related to GTP processing on the GGSN based on tunnel identifier (TID), international mobile system identifier (IMSI), or Mobile Station ISDN number (MSISDN) in a PDP Context Create Request message.
ip <i>ip-address</i>	Generates debugging messages for the IP address specified.
next-call gprs	Generates debugging messages for the next call seen by the GGSN. Up to 5 next-call conditional debugs settings, or PDPs with next-call debug conditions can be set at any given time.
apn <i>apn-name</i>	Generates debugging messages for the next call seen from a specific APN.
peer <i>sgsn-ip-address</i>	Generates debugging messages for the next call from a specific SGSN.
<cr> (carriage return/Enter)	Generates debugging messages for any next call.
username <i>username</i>	Generates debugging messages for interfaces with the specified username.
vcid <i>vc-id</i>	Generates debugging messages for the VC ID specified.
<i>condition-id</i>	Removes the condition indicated.
all	Removes all conditional debugging conditions.

Defaults

No default behavior or values.

Command History

Release	Modification
12.3(2)XB	This command was introduced on the GGSN.
12.3(8)XU	This command was integrated into Cisco IOS Release 12.3(8)XU.
12.3(11)YJ	This command was integrated into Cisco IOS Release 12.3(11)YJ.
12.3(14)YQ	This command was integrated into Cisco IOS Release 12.3(14)YQ.
12.3(14)YU	This command was integrated into the Cisco IOS Release 12.3(14)YU and the msisdn keyword option was added.
12.4(2)XB	This command was integrated into Cisco IOS Release 12.4(2)XB.
12.4(9)XG	This command was integrated into Cisco IOS Release 12.4(9)XG.
12.4(15)XQ	This command was integrated into Cisco IOS Release 12.4(15)XQ.

Release	Modification
12.4(22)YE	This command was integrated into Cisco IOS Release 12.4(22)YE and the next-call gprs keyword options were added.
12.4(22)YE1	This command was integrated into Cisco IOS Release 12.4(22)YE1.
12.4(22)YE2	This command was integrated into Cisco IOS Release 12.4(22)YE2.
12.4(24)YE	This command was integrated into Cisco IOS Release 12.4(24)YE.
12.4(24)YE1	This command was integrated into Cisco IOS Release 12.4(24)YE1.
12.4(24)YE2	This command was integrated into Cisco IOS Release 12.4(24)YE2.
12.4(24)YE3	This command was integrated into Cisco IOS Release 12.4(24)YE3.

Usage Guidelines

Ensure that you enable TID/IMSI/MSISDN-based conditional debugging using the **debug condition calling** command before configuring the **debug gprs gtp** and **debug gprs charging**.

In addition, ensure that you disable the **debug gprs gtp** and **debug gprs charging** commands using the **no debug all** command before disabling conditional debugging using the **no debug condition** command. This will prevent a flood of debug messages when you disable conditional debugging.



Note

Conditional debugging does not apply to **debug gprs gtp events**, **debug gprs gtp messages**, or **debug gprs gtp packets**. For **debug gprs gtp parsing**, the conditional debugging starts to limit its output only after the PDP context is created (the TID value is not empty).

For more information on using the GGSN TID/IMSI/MSISDN-based conditional debugging, see [“TID/IMSI/MSISDN-Based Conditionally Triggered Debugging” section on page 756](#).

debug condition next-call

Up to 5 next-call conditional debugs settings, or PDPs with next-call debug conditions can be set at any given time.

To monitor and manage the next-call conditional debugging, use the:

- **show debugging condition** command to display existing debug next-call conditions or PDPs with next-call debug conditions
- **clear gprs gtp debug next-call** command to clear debugs set for existing PDPs
- **no debug condition** command with the **next-call** keyword specified to remove a next-call debug condition.

For conditional debugging for an APN, use the **debug condition called** command in privileged EXEC mode.

Examples

Example 1

The following examples configure a conditional debug session based on a TID 12345678090000B0, IMSI 214365790000000, and MSISDN 408525823010:

```
GGSN# debug condition calling 12345678090000B0
Condition 1 set
GGSN#
```

```
GGSN# debug condition calling 214365790000000
Condition 2 set
```

GGSN#

```
GGSN# debug condition calling msisdn 408525823010
Condition 3 set
GGSN#
```

Example 2

The following examples configure a conditional debug session for calls seen by a specific APN named “APN1”:

```
GGSN# debug condition next-call gprs apn APN1
```

Example 3

The following example stops all conditional debugging:

```
Router# no debug conditional all
All possible debugging has been turned off
Router#
```

debug aaa coa

To display debug information for CoA processing, use the **debug aaa coa** command in privileged EXEC mode. To disable debugging output, use the **no** form of this command.

debug aaa coa

no debug aaa coa

Syntax Description

This command has no keywords or arguments

Defaults

Debugging for POD packets is not enabled.

Command History

Release	Modification
12.4(15)XQ	This command was introduced.
12.4(22)YE	This command was integrated into Cisco IOS Release 12.4(22)YE.
12.4(22)YE1	This command was integrated into Cisco IOS Release 12.4(22)YE1.
12.4(22)YE2	This command was integrated into Cisco IOS Release 12.4(22)YE2.
12.4(24)YE	This command was integrated into Cisco IOS Release 12.4(24)YE.
12.4(24)YE1	This command was integrated into Cisco IOS Release 12.4(24)YE1.
12.4(24)YE2	This command was integrated into Cisco IOS Release 12.4(24)YE2.
12.4(24)YE3	This command was integrated into Cisco IOS Release 12.4(24)YE3.

Usage Guidelines

Use the **debug aaa coa** to display debug information for CoA processing.

Examples

The following is an example of debug information for CoA processing:

```
SAMI 5/3: *Mar 4 23:51:02.820: COA: 10.10.10.10 request queued
SAMI 5/3: *Mar 4 23:51:02.820: ++++++ CoA Attribute List ++++++
SAMI 5/3: *Mar 4 23:51:02.820: 410414A8 0 00000009 string-session-id(337) 15
080808012521869
SAMI 5/3: *Mar 4 23:51:02.820: 4189D04C 0 00000009 qos-profile(507) 28
25621F9301FEFE245E1414003200
SAMI 5/3: *Mar 4 23:51:02.820:
SAMI 5/3: *Mar 4 23:51:02.820: COA: Sending ACK from port 1700 to 10.10.10.10/1700
```

debug diameter

To display information about Diameter processing on the gateway GPRS support node (GGSN), use the **debug diameter** command in privileged EXEC mode.

debug diameter {dcca | connection | error | packet | event | fsm | failover | all}

Syntax Description

dcca	Displays Diameter Credit Control Application-related information.
connection	Displays Diameter peer connection information.
error	Displays errors related to Diameter processing.
packet	Displays Diameter packets.
event	Displays Diameter-related events.
fsm	Displays Diameter-related fault state machine messages.
failover	Displays information about DCCA server switchovers.
all	Displays all Diameter-related information.

Defaults

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
12.3(14)YQ	This command was introduced.
12.4(2)XB	This command was integrated into Cisco IOS Release 12.4(2)XB.
12.4(9)XG	This command was integrated into Cisco IOS Release 12.4(9)XG.
12.4(15)XQ	This command was integrated into Cisco IOS Release 12.4(15)XQ.
12.4(22)YE	This command was integrated into Cisco IOS Release 12.4(22)YE.
12.4(22)YE1	This command was integrated into Cisco IOS Release 12.4(22)YE1.
12.4(22)YE2	This command was integrated into Cisco IOS Release 12.4(22)YE2.
12.4(24)YE	This command was integrated into Cisco IOS Release 12.4(24)YE.
12.4(24)YE1	This command was integrated into Cisco IOS Release 12.4(24)YE1.
12.4(24)YE2	This command was integrated into Cisco IOS Release 12.4(24)YE2.
12.4(24)YE3	This command was integrated into Cisco IOS Release 12.4(24)YE3.

Usage Guidelines

This command is useful for system operators and development engineers if problems are encountered with Diameter processing.

Examples

The following configuration example displays Diameter-related events:

```
debug diameter event
```

debug ggsn csg-group slb

To display debug information for CSG group server load balancing (SLB) processing, use the **debug csg-group slb** command in privileged EXEC mode. To disable debugging output, use the **no** form of this command.

debug ggsn csg-group slb

no debug ggsn csg-group slb

Syntax Description This command has no keywords or arguments

Defaults Disabled.

Command History	Release	Modification
	12.4(24)YE	This command was introduced.

Usage Guidelines Use the **debug ggsn csg-group slb** to display debug information for CSG group SLB processing.

Examples The following is an example of debug information for CSG group SLB processing:

```
SAMI 4/6: Nov 26 11:01:30.831: GPRS:Selecting a CSG for prefix = 24.24.24.2
SAMI 4/6: Nov 26 11:01:30.831: GPRS:CSG csg1 selected for 24.24.24.2
SAMI 4/6: Nov 26 11:01:30.831: GPRS:Adding subnet to CSG mapping entry, prefix =
24.24.24.2, Mask = 255.255.255.255, CSG = csg1
SAMI 4/5: Nov 26 11:01:31.059: GPRS:Selecting a CSG for prefix = 24.24.24.1
SAMI 4/5: Nov 26 11:01:31.059: GPRS:CSG csg2 selected for 24.24.24.1
SAMI 4/5: Nov 26 11:01:31.059: GPRS:Adding subnet to CSG mapping entry, prefix =
24.24.24.1, Mask = 255.255.255.255, CSG = csg2
SAMI 4/3: Nov 26 11:57:24.247: GPRS:Recieved the Subnet CSG mapping add message for APN 2
CSG csg1 Prefix (24.24.24.0) mask (255.255.255.0)
SAMI 4/3: Nov 26 11:57:24.247: GPRS:Adding subnet to CSG mapping entry, prefix =
24.24.24.0, Mask = 255.255.255.0, CSG = csg1
SAMI 4/3: Nov 26 11:57:24.247: GPRS:Recieved the Subnet CSG mapping add message for APN 2
CSG csg1 Prefix (24.24.24.0) mask (255.255.255.0)
SAMI 4/3: Nov 26 11:57:24.247: GPRS:CSG mapping entry found prefix = 24.24.24.0, subnet =
255.255.255.0, CSG = csg1
SAMI 4/3: Nov 26 11:57:24.247: GPRS:Incrementing the reference count for Subnet to CSG
mapping entry, prefix = 24.24.24.0, Mask = 255.255.255.0, CSG = csg1
SAMI 4/3: Nov 26 11:57:24.251: GPRS:Recieved the Subnet CSG mapping add message for APN 2
CSG csg2 Prefix (25.25.25.0) mask (255.255.255.0)
SAMI 4/3: Nov 26 11:57:24.251: GPRS:Adding subnet to CSG mapping entry, prefix =
25.25.25.0, Mask = 255.255.255.0, CSG = csg2
SAMI 4/3: Nov 26 11:57:24.251: GPRS:Recieved the Subnet CSG mapping add message for APN 2
CSG csg2 Prefix (25.25.25.0) mask (255.255.255.0)
SAMI 4/3: Nov 26 11:57:24.251: GPRS:CSG mapping entry found prefix = 25.25.25.0, subnet =
255.255.255.0, CSG = csg2
SAMI 4/3: Nov 26 11:57:24.251: GPRS:Incrementing the reference count for Subnet to CSG
mapping entry, prefix = 25.25.25.0, Mask = 255.255.255.0, CSG = csg2
SAMI 4/5: Nov 26 11:57:25.895: GPRS:Selecting a CSG for prefix = 24.24.24.0
```

```
SAMI 4/5: Nov 26 11:57:25.895: GPRS:CSG csg1 selected for 24.24.24.1
SAMI 4/5: Nov 26 11:57:25.895: GPRS:Adding subnet to CSG mapping entry, prefix =
24.24.24.0, Mask = 255.255.255.0, CSG = csg1
SAMI 4/5: Nov 26 11:57:25.899: GPRS:Selecting a CSG for prefix = 25.25.25.0
SAMI 4/5: Nov 26 11:57:25.899: GPRS:CSG csg2 selected for 25.25.25.1
SAMI 4/5: Nov 26 11:57:25.899: GPRS:Adding subnet to CSG mapping entry, prefix =
25.25.25.0, Mask = 255.255.255.0, CSG = csg2
SAMI 4/6: Nov 26 11:57:25.679: GPRS:Selecting a CSG for prefix = 24.24.24.0
SAMI 4/6: Nov 26 11:57:25.679: GPRS:CSG csg1 selected for 24.24.24.2
SAMI 4/6: Nov 26 11:57:25.679: GPRS:Adding subnet to CSG mapping entry, prefix =
24.24.24.0, Mask = 255.255.255.0, CSG = csg1
SAMI 4/6: Nov 26 11:57:25.683: GPRS:Selecting a CSG for prefix = 25.25.25.0
SAMI 4/6: Nov 26 11:57:25.683: GPRS:CSG csg2 selected for 25.25.25.2
SAMI 4/6: Nov 26 11:57:25.683: GPRS:Adding subnet to CSG mapping entry, prefix = 25.25.25.0,
Mask = 255.255.255.0, CSG = csg2
```

debug ggsn quota-server

To display debug information related to quota server processing on the GGSN, use the **debug ggsn quota-server** privileged EXEC command.

debug ggsn quota-server [detail | packets [dump] | events | parsing | errors]

Syntax Description

detail	Displays extended details about quota server operations on the GGSN.
packets	Displays packets sent between the quota server process on the GGSN and the CSG. Optionally, displays output in hexadecimal notation.
events	Displays events related to quota server processing on the GGSN.
parsing	Displays details about GTP TLV parsing between the quota server and the Content Services Gateway.
errors	Displays errors related to quota server processing on the GGSN

Defaults

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
12.3(14)YQ	This command was introduced.
12.4(9)T	This command was integrated into Cisco IOS Release 12.4(9)T.
12.3(14)YU	This command was integrated into Cisco IOS Release 12.3(14)YU.
12.4(2)XB	This command was integrated into Cisco IOS Release 12.4(2)XB.
12.4(9)XG	This command was integrated into Cisco IOS Release 12.4(9)XG.
12.4(15)XQ	This command was integrated into Cisco IOS Release 12.4(15)XQ.
12.4(22)YE	This command was integrated into Cisco IOS Release 12.4(22)YE.
12.4(22)YE1	This command was integrated into Cisco IOS Release 12.4(22)YE1.
12.4(22)YE2	This command was integrated into Cisco IOS Release 12.4(22)YE2.
12.4(24)YE	This command was integrated into Cisco IOS Release 12.4(24)YE.
12.4(24)YE1	This command was integrated into Cisco IOS Release 12.4(24)YE1.
12.4(24)YE2	This command was integrated into Cisco IOS Release 12.4(24)YE2.
12.4(24)YE3	This command was integrated into Cisco IOS Release 12.4(24)YE3.

Usage Guidelines

This command is useful for system operators and development engineers if problems are encountered with communication between the GGSN quota server process and the CSG.

Examples

The following example enables the display of detailed quota server processing debug output—pre-allocated quota and quota push:

```
Router#debug ggsn quota-server detail
ggsn quota-server details debugging is on
Router#
Jun  2 02:40:39.391: GGSN-QS:Encoding QUOTA PUSH REQUEST
Jun  2 02:40:39.391: GGSN-QS:Adding TLV USER_INDEX
Jun  2 02:40:39.391: GGSN-QS:  IP Address: 3.3.3.1  User ID: 12345
Jun  2 02:40:39.391: GGSN-QS:Adding TLV SERVICE_ID: 1
Jun  2 02:40:39.391: GGSN-QS:Adding TLV QUADRANS_GRANTED
Jun  2 02:40:39.391: GGSN-QS:  Quadrans: 1250  Threshold: 1000  Units: SECONDS
Jun  2 02:40:39.391: GGSN-QS:Adding TLV QUADRANS_GRANTED
Jun  2 02:40:39.391: GGSN-QS:  Quadrans: 5000  Threshold: 5000  Units: BYTES_IP
Jun  2 02:40:39.391: GGSN-QS:Adding TLV TIMEOUT: 50000
Jun  2 02:40:39.391: GGSN-QS:Adding TLV TARIFF_TIME: 1147698000
Jun  2 02:40:39.391: GGSN-QS:Sending QUOTA_PUSH_REQ from QS (4.4.4.4:3386) to CSG
(30.1.1.1:3386)
Jun  2 02:40:39.395: pak=0x6523B5B0, datagramstart=0x200143D8, network_start=0x200143BC
datagramsize 91
Jun  2 02:40:39.395: GGSN-QS msgtype 0xF0, seq 1, len 85, from 4.4.4.4:3386 to
30.1.1.1:3386
200143D0:                0FF00055 00017E01                .p.U..~.
200debug ggsn quota-server detail143E0: FC005001 31000000 4A002E00 46001400
|.P.1...J...F...
200143F0: 09030303 01313233 34350015 00013100      ....12345....1.
20014400: 2D000E00 00000000 0004E201 03000003      -.....b.....
20014410: E8002D00 0E000000 00000013 88020300      h.-.....
20014420: 00138800 17000400 00C35000 4D000444      .....CP.M..D
20014430: 687B50                                h{P
Jun  2 02:40:39.395: GGSN-QS:Received Data Record Transfer Response from (30.1.1.1:3386)
Sequence number 1
Jun  2 02:40:39.395: GGSN-QS:Cause = 128
Jun  2 02:40:39.395: GGSN-QS:Request Responded Sequence Number = 1
Jun  2 02:40:39.395: GGSN-QS:Private Ext IE length 32 QM Rsp length 29
Jun  2 02:40:39.395: GGSN-QS:Received message QUOTA_PUSH_RESP from CSG
Jun  2 02:40:39.395: GGSN-QS:UserIndex TLV: IP Address 3.3.3.1 UserName/MSISDN 12345
Jun  2 02:40:39.395: GGSN-QS:Session ID TLV: 1736898353
Jun  2 02:40:39.395: GGSN-QS:Service ID TLV: 1
Jun  2 02:40:39.399: GGSN-QS:Detected real CSG 30.1.1.1 for virtual CSG 30.1.1.1
Jun  2 02:40:39.399: GGSN-QS:real CSG newly detected
ggsn quota-server details debugging is on
Router#
```

debug gprs category fsm event

To display debug information related to service-aware GGSN category events, and state transactions, use the **debug gprs category fsm event** privileged EXEC command.

debug gprs category fsm event

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	12.3(14)YQ	This command was introduced.
	12.4(9)T	This command was integrated into Cisco IOS Release 12.4(9)T.
	12.3(14)YU	This command was integrated into Cisco IOS Release 12.3(14)YU.
	12.4(2)XB	This command was integrated into Cisco IOS Release 12.4(2)XB.
	12.4(9)XG	This command was integrated into Cisco IOS Release 12.4(9)XG.
	12.4(15)XQ	This command was integrated into Cisco IOS Release 12.4(15)XQ.
	12.4(22)YE	This command was integrated into Cisco IOS Release 12.4(22)YE.
	12.4(22)YE1	This command was integrated into Cisco IOS Release 12.4(22)YE1.
	12.4(22)YE2	This command was integrated into Cisco IOS Release 12.4(22)YE2.
	12.4(24)YE	This command was integrated into Cisco IOS Release 12.4(24)YE.
	12.4(24)YE1	This command was integrated into Cisco IOS Release 12.4(24)YE1.
	12.4(24)YE2	This command was integrated into Cisco IOS Release 12.4(24)YE2.
	12.4(24)YE3	This command was integrated into Cisco IOS Release 12.4(24)YE3.

Usage Guidelines This command is useful for system operators and development engineers if problems are encountered with eGGSN processing.

Examples **Example 1—PDPs with Pre-Allocated Quota**
The following example enables the display of eGGSN events and state transactions—pre-allocated quota. This is PDP context create, prepaid subscriber data transfer, and then context teardown.

PDP Context Create:

```
Router#debug gprs category fsm event
eGGSN category fsm event debugging is on
Router#
Jun  2 02:55:08.491: GPRS:1234050000000010:created service-aware subblock
```

```

Jun  2 02:55:11.383: GPRS:1234050000000010:it is the only one PDP of the user, need CCR
msg
Jun  2 02:55:11.383: GPRS:1234050000000010:sent ccr_init
Jun  2 02:55:11.823: GPRS:1234050000000010:create new category 1
Jun  2 02:55:11.823: GPRS:1234050000000010:shdb 0xFB00001C created for category 1 (handle
0x8C000007)
Jun  2 02:55:11.823: GPRS:1234050000000010:successfully create a category
Jun  2 02:55:14.623: GPRS:1234050000000010:created sync_object for CREATE_PDP
Jun  2 02:55:14.623: GPRS:1234050000000010:get 1 impacted categories into sync_object for
CREATE_PDP
Jun  2 02:55:14.623: GPRS:1234050000000010:insert category 1 from sync_object for
CREATE_PDP
Jun  2 02:55:14.623: GPRS:1234050000000010:number of really impacted by CREATE_PDP = 1
Jun  2 02:55:14.623: GPRS:1234050000000010:FSM_ggsn_rcvd_quota
Jun  2 02:55:14.623: GPRS:1234050000000010:category 1 trans from INIT to PENDING QP on
event CCA_QUOTA
Jun  2 02:55:14.627: GPRS:1234050000000010:FSM_ggsn_rcvd_qp_ack_in_qp
Jun  2 02:55:14.627: GPRS:1234050000000010:remove category 1 from sync_object for
CREATE_PDP 0 still pending in the sync_object
Jun  2 02:55:14.627: GPRS:1234050000000010:send Create PDP Context Res to SGSN
Jun  2 02:55:14.627: GPRS:1234050000000010:delete sync object for CREATE_PDP, it has 0
categories
Jun  2 02:55:14.627: GPRS:1234050000000010:category 1 trans from PENDING QP to AUTHORIZED
on event CSG_QP_ACK
Router#
Router#

```

PDP Context Delete:

```

Router#
Jun  2 02:55:31.455: GPRS:1234050000000010:look up category by 1 found 65EEB128
Jun  2 02:55:31.455: GPRS:1234050000000010:FSM_ggsn_rcvd_stop
Jun  2 02:55:31.455: GPRS:category 1 report usage queue size = 2
Jun  2 02:55:31.455: GPRS:1234050000000010:usage unit has total_octets 0
Jun  2 02:55:31.455: GPRS:1234050000000010:usage unit has total_octets 300
Jun  2 02:55:31.455: GPRS:1234050000000010:category 1 , usage 6615E470
Jun  2 02:55:31.455: GPRS:1234050000000010:no sync_object for service stop
Jun  2 02:55:31.455: %GPRSFLTMG-4-CHARGING: GSN: 0.0.0.0, TID: 0000000000000000, APN:
NULL, Reason: 1, unexpected CSG usage report cause
Jun  2 02:55:31.455: GPRS:1234050000000010:send CCR_UPDATE to DCCA server return ok
Jun  2 02:55:31.455: GPRS:releasing 2 usages in category
Jun  2 02:55:31.455: GPRS:release_usage_parameter
Jun  2 02:55:31.455: GPRS:1234050000000010:category 1 trans from AUTHORIZED to IDLE on
event CSG_SERVICE_STOP
Jun  2 02:55:34.939: GPRS:1234050000000010:eggsn_get_final_usage_report
Jun  2 02:55:34.939: GPRS:1234050000000010:freeing all categories
Jun  2 02:55:34.939: GPRS:1234050000000010:delete_category 1
Jun  2 02:55:34.939: GPRS:1234050000000010:freeing service-aware subblock
Router#

```

Example 2—PDPs without Pre-Allocated Quota

The following example enables the display of eGGSN events and state transactions—for PDPs without pre-allocated quota.

PDP Context Create:

```
Router#debug gprs category fsm event
eGGSN category fsm event debugging is on
Router#
Jun  2 02:58:45.727: GPRS:1234050000000010:created service-aware subblock
Jun  2 02:58:48.623: GPRS:1234050000000010:it is the only one PDP of the user, need CCR
msg
Jun  2 02:58:48.623: GPRS:1234050000000010:sent ccr_init
Router#
```

PDP Context Delete:

```
Router#
Jun  2 02:59:06.975: GPRS:1234050000000010:eggsn_get_final_usage_report
Jun  2 02:59:06.975: GPRS:1234050000000010:freeing all categories
Jun  2 02:59:06.975: GPRS:1234050000000010:freeing service-aware subblock
Router
```

debug gprs dcca

To display troubleshooting information about Diameter Credit Control Application (DCCA) processing on the gateway GPRS support node (GGSN), use the **debug gprs dcca** privileged EXEC command.

debug gprs dcca

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	12.3(14)YQ	This command was introduced.
	12.4(9)T	This command was integrated into Cisco IOS Release 12.4(9)T.
	12.3(14)YU	This command was integrated into Cisco IOS Release 12.3(14)YU.
	12.4(2)XB	This command was integrated into Cisco IOS Release 12.4(2)XB.
	12.4(9)XG	This command was integrated into Cisco IOS Release 12.4(9)XG.
	12.4(15)XQ	This command was integrated into Cisco IOS Release 12.4(15)XQ.
	12.4(22)YE	This command was integrated into Cisco IOS Release 12.4(22)YE.
	12.4(22)YE1	This command was integrated into Cisco IOS Release 12.4(22)YE1.
	12.4(22)YE2	This command was integrated into Cisco IOS Release 12.4(22)YE2.
	12.4(24)YE	This command was integrated into Cisco IOS Release 12.4(24)YE.
	12.4(24)YE1	This command was integrated into Cisco IOS Release 12.4(24)YE1.
	12.4(24)YE2	This command was integrated into Cisco IOS Release 12.4(24)YE2.
	12.4(24)YE3	This command was integrated into Cisco IOS Release 12.4(24)YE3.

Usage Guidelines This command is useful for system operators and development engineers if Diameter protocol problems are encountered on the GGSN.

Examples

Example 1

The following is a sample of DCCA debug information with pre-allocated quota.

```
Router#debug gprs dcca
```

```
Router#
```

```
Jun  2 03:13:45.827: GPRS:1234050000000010:GPRS:DCCA: 3GPP-IMSI : 214350000000000
Jun  2 03:13:45.831: GPRS:1234050000000010:GPRS:DCCA: 3GPP-Charging-Id : 613053186
Jun  2 03:13:45.831: GPRS:1234050000000010:GPRS:DCCA: 3GPP-PDP-Type : 0
Jun  2 03:13:45.831: GPRS:1234050000000010:GPRS:DCCA: 3GPP-CG-Address : 20.1.1.1
```

```

Jun  2 03:13:45.831: GPRS:1234050000000010:GPRS:DCCA: 3GPP-QoS-Profile :
99-0911012964FFFF1100FFFF
Jun  2 03:13:45.831: GPRS:1234050000000010:GPRS:DCCA: 3GPP-SGSN-Address : 11.20.1.1
Jun  2 03:13:45.831: GPRS:1234050000000010:GPRS:DCCA: 3GPP-GGSN-Address : 10.20.61.1
Jun  2 03:13:45.831: GPRS:1234050000000010:GPRS:DCCA: 3GPP-IMSI-MCC-MNC : 21435
Jun  2 03:13:45.831: GPRS:1234050000000010:GPRS:DCCA: 3GPP-GGSN-MCC-MNC : 001002
Jun  2 03:13:45.831: GPRS:1234050000000010:GPRS:DCCA: 3GPP-NSAPI : 1
Jun  2 03:13:45.831: GPRS:1234050000000010:GPRS:DCCA: 3GPP-Selection-Mode : 0
Jun  2 03:13:45.831: GPRS:1234050000000010:3GPP-Charging-Char : 0100
Jun  2 03:13:45.831: GPRS:1234050000000010:GPRS DCCA: Starting Tx timer , value = 100000
Jun  2 03:13:45.831: GPRS:1234050000000010:DCCA FSM:Event = CCR_INITIAL, Old State = IDLE,
New State = PENDING_I
Jun  2 03:13:46.287: GPRS:1234050000000010:GPRS DCCA: Result-Code = 2001
Jun  2 03:13:46.287: GPRS:1234050000000010:GPRS DCCA: Stopping Tx timer
Jun  2 03:13:46.287: GPRS:1234050000000010:GPRS DCCA: Result-Code for Category : 1 =
2001
Jun  2 03:13:46.287: GPRS:1234050000000010:DCCA FSM:Event = CCA_SUCCESS, Old State =
PENDING_I, New State = OPEN
Router#
Router#show gprs gtp pdp tid 1234050000000010 ser all
Diameter Credit Control: Enabled
Current Billing status: Prepaid
Reason to convert to postpaid: N/A
Charging Profile Index: 1
DCCA profile name: dcca-profile1, Source: charging profile
Rule base id: 1, Source: DCCA server
ServiceID  State          Quota(octets)

1          AUTHORIZED      5000
Router#

PDP being deleted

```

Example 2

The following is a sample of DCCA debug information without pre-allocated quota.

```

Router#show debug
GPRS:
  GPRS DCCA Events debugging is on

Router#
Jun  2 03:05:07.743: GPRS:1234050000000010:GPRS:DCCA: 3GPP-IMSI : 214350000000000
Jun  2 03:05:07.743: GPRS:1234050000000010:GPRS:DCCA: 3GPP-Charging-Id : 613053181
Jun  2 03:05:07.743: GPRS:1234050000000010:GPRS:DCCA: 3GPP-PDP-Type : 0
Jun  2 03:05:07.743: GPRS:1234050000000010:GPRS:DCCA: 3GPP-CG-Address : 20.1.1.1
Jun  2 03:05:07.743: GPRS:1234050000000010:GPRS:DCCA: 3GPP-QoS-Profile :
99-0911012964FFFF1100FFFF
Jun  2 03:05:07.743: GPRS:1234050000000010:GPRS:DCCA: 3GPP-SGSN-Address : 11.20.1.1
Jun  2 03:05:07.743: GPRS:1234050000000010:GPRS:DCCA: 3GPP-GGSN-Address : 10.20.61.1
Jun  2 03:05:07.743: GPRS:1234050000000010:GPRS:DCCA: 3GPP-IMSI-MCC-MNC : 21435
Jun  2 03:05:07.743: GPRS:1234050000000010:GPRS:DCCA: 3GPP-GGSN-MCC-MNC : 001002
Jun  2 03:05:07.743: GPRS:1234050000000010:GPRS:DCCA: 3GPP-NSAPI : 1
Jun  2 03:05:07.743: GPRS:1234050000000010:GPRS:DCCA: 3GPP-Selection-Mode : 0
Jun  2 03:05:07.743: GPRS:1234050000000010:3GPP-Charging-Char : 0100
Jun  2 03:05:07.743: GPRS:1234050000000010:GPRS DCCA: Starting Tx timer , value = 100000
Jun  2 03:05:07.743: GPRS:1234050000000010:DCCA FSM:Event = CCR_INITIAL, Old State = IDLE,
New State = PENDING_I
Jun  2 03:05:08.167: GPRS:1234050000000010:GPRS DCCA: Result-Code = 2001
Jun  2 03:05:08.167: GPRS:1234050000000010:GPRS DCCA: Stopping Tx timer
Jun  2 03:05:08.167: GPRS:1234050000000010:DCCA FSM:Event = CCA_SUCCESS, Old State =
PENDING_I, New State = OPEN
Router#
gprs5-72b#sgpt 1234050000000010 ser all

```

```

Diameter Credit Control: Enabled
Current Billing status: Prepaid
Reason to convert to postpaid: N/A
Charging Profile Index: 1
DCCA profile name: dcca-profile1, Source: charging profile
Rule base id: 1, Source: DCCA server
ServiceID State Quota(octets)

```

```
gprs5-72b#clear gprs gtp pdp all
```

```
PDP deleted
```

```
Router#
```

```

Jun  2 03:05:28.459: GPRS:1234050000000010:GPRS:DCCA: 3GPP-IMSI : 214350000000000
Jun  2 03:05:28.459: GPRS:1234050000000010:GPRS:DCCA: 3GPP-Charging-Id : 613053181
Jun  2 03:05:28.459: GPRS:1234050000000010:GPRS:DCCA: 3GPP-PDP-Type : 0
Jun  2 03:05:28.459: GPRS:1234050000000010:GPRS:DCCA: 3GPP-CG-Address : 20.1.1.1
Jun  2 03:05:28.459: GPRS:1234050000000010:GPRS:DCCA: 3GPP-QoS-Profile :
99-0911012964FFFF1100FFFF
Jun  2 03:05:28.459: GPRS:1234050000000010:GPRS:DCCA: 3GPP-SGSN-Address : 11.20.1.1
Jun  2 03:05:28.459: GPRS:1234050000000010:GPRS:DCCA: 3GPP-GGSN-Address : 10.20.61.1
Jun  2 03:05:28.459: GPRS:1234050000000010:GPRS:DCCA: 3GPP-IMSI-MCC-MNC : 21435
Jun  2 03:05:28.459: GPRS:1234050000000010:GPRS:DCCA: 3GPP-GGSN-MCC-MNC : 001002
Jun  2 03:05:28.459: GPRS:1234050000000010:GPRS:DCCA: 3GPP-NSAPI : 1
Jun  2 03:05:28.459: GPRS:1234050000000010:GPRS:DCCA: 3GPP-Selection-Mode : 0
Jun  2 03:05:28.459: GPRS:1234050000000010:3GPP-Charging-Char : 0100
Jun  2 03:05:28.463: GPRS:1234050000000010:GPRS DCCA: Stopping Tx timer
Jun  2 03:05:28.463: GPRS:1234050000000010:DCCA FSM:Event = CCR_FINAL, Old State = OPEN,
New State = PENDING_T
Jun  2 03:05:28.463: GPRS:1234050000000010:GPRS DCCA: Stopping Tx timer
Jun  2 03:05:28.871: GPRS:GPRS DCCA: DCCA request was cancelled, Dropping AAA reply
Router#
Router#sgpt 1234050000000010 ser all
%ERROR: Cannot find the PDP
Router#

```

debug gprs dfp

To display debug messages for GPRS DFP weight calculation, use the **debug gprs dfp** command in privileged EXEC mode. To disable debugging output, use the **no** form of this command.

debug gprs dfp

no debug gprs dfp

Syntax Description

This command has no arguments or keywords.

Defaults

No default behavior or values.

Command History

Release	Modification
12.1(9)E	This command was introduced.
12.2(4)MX	This command was integrated into Cisco IOS Release 12.2(4)MX.
12.2(8)YD	This command was integrated into Cisco IOS Release 12.2(8)YD.
12.2(8)YW	This command was integrated into Cisco IOS Release 12.2(8)YW.
12.3(2)XB	This command was integrated into Cisco IOS Release 12.3(2)XB.
12.3(8)XU	This command was integrated into Cisco IOS Release 12.3(8)XU.
12.3(11)YJ	This command was integrated into Cisco IOS Release 12.3(11)YJ.
12.3(14)YQ	This command was integrated into Cisco IOS Release 12.3(14)YQ.
12.3(14)YU	This command was integrated into Cisco IOS Release 12.3(14)YU.
12.4(2)XB	This command was integrated into Cisco IOS Release 12.4(2)XB.
12.4(9)XG	This command was integrated into Cisco IOS Release 12.4(9)XG.
12.4(15)XQ	This command was integrated into Cisco IOS Release 12.4(15)XQ.
12.4(22)YE	This command was integrated into Cisco IOS Release 12.4(22)YE.
12.4(22)YE1	This command was integrated into Cisco IOS Release 12.4(22)YE1.
12.4(22)YE2	This command was integrated into Cisco IOS Release 12.4(22)YE2.
12.4(24)YE	This command was integrated into Cisco IOS Release 12.4(24)YE.
12.4(24)YE1	This command was integrated into Cisco IOS Release 12.4(24)YE1.
12.4(24)YE2	This command was integrated into Cisco IOS Release 12.4(24)YE2.
12.4(24)YE3	This command was integrated into Cisco IOS Release 12.4(24)YE3.

Usage Guidelines

See the following caution before using **debug** commands:

**Caution**

Because debugging output is assigned high priority in the CPU process, it can render the system unusable. For this reason, use **debug** commands only to troubleshoot specific problems or during troubleshooting sessions with Cisco technical support staff. Moreover, it is best to use **debug** commands during periods of lower network flows and fewer users. Debugging during these periods reduces the effect these commands have on other users on the system.

This command displays debug messages for GPRS DFP weight calculation. To display debug messages for the DFP agent subsystem, use the **debug ip dfp agent** command.

Examples

The following example configures a debug session to check all GPRS DFP weight calculation:

```
Router# debug gprs dfp  
GPRS DFP debugging is on  
Router#
```

The following example stops all debugging:

```
Router# no debug all  
All possible debugging has been turned off  
Router#
```

debug gprs dhcp

To display information about Dynamic Host Configuration Protocol (DHCP) processing on the gateway GPRS support node (GGSN), use the **debug gprs dhcp** command in privileged EXEC mode. To disable debugging output, use the **no** form of this command.

debug gprs dhcp

no debug gprs dhcp

Syntax Description

This command has no arguments or keywords.

Defaults

No default behavior or values.

Command History

Release	Modification
12.2(4)MX	This command was introduced.
12.2(8)YD	This command was integrated into Cisco IOS Release 12.2(8)YD.
12.2(8)YW	This command was integrated into Cisco IOS Release 12.2(8)YW.
12.3(2)XB	This command was integrated into Cisco IOS Release 12.3(2)XB.
12.3(8)XU	This command was integrated into Cisco IOS Release 12.3(8)XU.
12.3(11)YJ	This command was integrated into Cisco IOS Release 12.3(11)YJ.
12.3(14)YQ	This command was integrated into Cisco IOS Release 12.3(14)YQ.
12.3(14)YU	This command was integrated into Cisco IOS Release 12.3(14)YU.
12.4(2)XB	This command was integrated into Cisco IOS Release 12.4(2)XB.
12.4(9)XG	This command was integrated into Cisco IOS Release 12.4(9)XG.
12.4(15)XQ	This command was integrated into Cisco IOS Release 12.4(15)XQ.
12.4(22)YE	This command was integrated into Cisco IOS Release 12.4(22)YE.
12.4(22)YE1	This command was integrated into Cisco IOS Release 12.4(22)YE1.
12.4(22)YE2	This command was integrated into Cisco IOS Release 12.4(22)YE2.
12.4(24)YE	This command was integrated into Cisco IOS Release 12.4(24)YE.
12.4(24)YE1	This command was integrated into Cisco IOS Release 12.4(24)YE1.
12.4(24)YE2	This command was integrated into Cisco IOS Release 12.4(24)YE2.
12.4(24)YE3	This command was integrated into Cisco IOS Release 12.4(24)YE3.

Usage Guidelines

This command is useful for system operators and development engineers if problems are encountered with DHCP processing on the GGSN. To display standard debug messages between the DHCP client on the router and a DHCP server, you can also use the **debug dhcp** or **debug dhcp detail** commands with the **debug gprs dhcp** command.

**Caution**

Because the **debug gprs dhcp** command generates a significant amount of output, use it only when traffic on the GPRS network is low, so other activity on the system is not adversely affected.

Examples

The following example shows sample output for DHCP processing on the GGSN:

```
Router# debug gprs dhcp
2d13h: GPRS:DHCP req:TID 1111111100000099, Req 1
2d13h: GPRS:Requesting IP address for pdp 1111111100000099 from server 172.16.0.8 tableid
0
2d13h: GPRS:DHCP ip allocation pass (10.88.17.43) for pdp 1111111100000099
2d13h: GPRS:Using DHCP ip address 10.88.17.43 for pdp 1111111100000099
```

The following example shows sample output for standard debug messaging for DHCP processing on the router between the DHCP client and a DHCP server:

```
2d13h: DHCP: proxy allocate request
2d13h: DHCP: new entry. add to queue
2d13h: DHCP: SDiscover attempt # 1 for entry:
2d13h: DHCP: SDiscover: sending 283 byte length DHCP packet
2d13h: DHCP: SDiscover with directed serv 172.16.0.8, 283 bytes
2d13h: DHCP: XID MATCH in dhcpc_for_us()
2d13h: DHCP: Received a BOOTREP pkt
2d13h: DHCP: offer received from 172.16.0.8
2d13h: DHCP: SRequest attempt # 1 for entry:
2d13h: DHCP: SRequest- Server ID option: 172.16.0.8
2d13h: DHCP: SRequest- Requested IP addr option: 10.88.17.43
2d13h: DHCP: SRequest placed lease len option: 604800
2d13h: DHCP: SRequest: 301 bytes
2d13h: DHCP: SRequest: 301 bytes
2d13h: DHCP: XID MATCH in dhcpc_for_us()
2d13h: DHCP: Received a BOOTREP pkt
2d13h: DHCP Proxy Client Pooling: ***Allocated IP address: 10.88.17.43
```

Related Commands

Command	Description
debug dhcp	Displays debug messages between the DHCP client on the router and a DHCP server.

debug gprs gtp

To display information about the GPRS Tunneling Protocol (GTP), use the **debug gprs gtp** command in privileged EXEC mode. To disable debugging output, use the **no** form of this command.

debug gprs gtp { events | messages | packets }

no debug gprs gtp { events | messages | packets }

Syntax Description

events	Displays events related to GTP processing on the GGSN.
messages	Displays GTP signaling messages that are sent between the SGSN and GGSN.
packets	Displays GTP packets that are sent between the SGSN and GGSN.

Defaults

No default behavior or values.

Command History

Release	Modification
12.1(1)GA	This command was introduced.
12.1(5)T	This command was integrated into Cisco IOS Release 12.1(5)T.
12.2(4)MX	This command was integrated into Cisco IOS Release 12.2(4)MX, and the ppp {details events} option was added.
12.2(8)YD	This command was integrated into Cisco IOS Release 12.2(8)YD.
12.2(8)YW	This command was integrated into Cisco IOS Release 12.2(8)YW.
12.3(2)XB	This command was integrated into Cisco IOS Release 12.3(2)XB.
12.3(8)XU	This command was integrated into Cisco IOS Release 12.3(8)XU.
12.3(11)YJ	This command was integrated into Cisco IOS Release 12.3(11)YJ.
12.3(14)YQ	This command was integrated into Cisco IOS Release 12.3(14)YQ.
12.3(14)YU	This command was integrated into Cisco IOS Release 12.3(14)YU.
12.4(2)XB	This command was integrated into Cisco IOS Release 12.4(2)XB.
12.4(9)XG	This command was integrated into Cisco IOS Release 12.4(9)XG.
12.4(15)XQ	This command was integrated into Cisco IOS Release 12.4(15)XQ.
12.4(22)YE	This command was integrated into Cisco IOS Release 12.4(22)YE.
12.4(22)YE1	This command was integrated into Cisco IOS Release 12.4(22)YE1.
12.4(22)YE2	This command was integrated into Cisco IOS Release 12.4(22)YE2.
12.4(24)YE	This command was integrated into Cisco IOS Release 12.4(24)YE.
12.4(24)YE1	This command was integrated into Cisco IOS Release 12.4(24)YE1.
12.4(24)YE2	This command was integrated into Cisco IOS Release 12.4(24)YE2.
12.4(24)YE3	This command was integrated into Cisco IOS Release 12.4(24)YE3.

Usage Guidelines

This command is useful for system operators and development engineers if problems are encountered with communication between the GGSN and the SGSN using GTP.

**Caution**

Because the **debug gprs gtp** command generates a significant amount of output, use it only when traffic on the GPRS network is low, so other activity on the system is not adversely affected.

Examples

The following example enables the display of events related to GTP processing on the GGSN:

```
Router# debug gprs gtp events
```

The following example enables the display of GTP signaling messages:

```
Router# debug gprs gtp messages
```

The following example enables the display of GTP packets sent between the SGSN and GGSN:

```
Router# debug gprs gtp packets
```

The following example enables the display of GTP PPP events between the SGSN and GGSN:

```
Router# debug gprs gtp ppp events
```

The following example enables the display of detailed GTP PPP debug output along with GTP PPP events between the SGSN and GGSN:

```
Router# debug gprs gtp ppp details
```

```
Router# debug gprs gtp ppp events
```

debug gprs gtp parsing

To display information about the parsing of GPRS Tunneling Protocol (GTP) information elements (IEs) in signaling requests, use the **debug gprs gtp parsing** command in privileged EXEC mode. To disable debugging output, use the **no** form of this command.

debug gprs gtp parsing

no debug gprs gtp parsing

Syntax Description

This command has no arguments or keywords.

Defaults

No default behavior or values.

Command History

Release	Modification
12.2(4)MX	This command was introduced.
12.2(8)YD	This command was integrated into Cisco IOS Release 12.2(8)YD.
12.2(8)YW	This command was integrated into Cisco IOS Release 12.2(8)YW.
12.3(2)XB	This command was integrated into Cisco IOS Release 12.3(2)XB.
12.3(8)XU	This command was integrated into Cisco IOS Release 12.3(8)XU.
12.3(11)YJ	This command was integrated into Cisco IOS Release 12.3(11)YJ.
12.3(14)YQ	This command was integrated into Cisco IOS Release 12.3(14)YQ.
12.3(14)YU	This command was integrated into Cisco IOS Release 12.3(14)YU.
12.4(2)XB	This command was integrated into Cisco IOS Release 12.4(2)XB.
12.4(9)XG	This command was integrated into Cisco IOS Release 12.4(9)XG.
12.4(15)XQ	This command was integrated into Cisco IOS Release 12.4(15)XQ.
12.4(22)YE	This command was integrated into Cisco IOS Release 12.4(22)YE.
12.4(22)YE1	This command was integrated into Cisco IOS Release 12.4(22)YE1.
12.4(22)YE2	This command was integrated into Cisco IOS Release 12.4(22)YE2.
12.4(24)YE	This command was integrated into Cisco IOS Release 12.4(24)YE.
12.4(24)YE1	This command was integrated into Cisco IOS Release 12.4(24)YE1.
12.4(24)YE2	This command was integrated into Cisco IOS Release 12.4(24)YE2.
12.4(24)YE3	This command was integrated into Cisco IOS Release 12.4(24)YE3.

Usage Guidelines

This command is useful for system operators and development engineers to verify parsing of GTP IEs in signaling requests that are received by GDM or by the GGSN. If the packet is parsed successfully, you will receive a message along with the TID for the packet as shown in the following example:

```
GPRS:TID:7300000000000000:Packet Parsed successfully
```

The **debug gprs gtp parsing** command can be used to verify GDM or GGSN processing of IEs.

**Caution**

Because the **debug gprs gtp parsing** command generates a significant amount of output, use it only when traffic on the GPRS network is low, so other activity on the system is not adversely affected.

Examples

The following example enables the display of debug messages that occur while GDM or the GGSN parses GTP IEs:

```
Router# debug gprs gtp parsing
```

debug gprs gtp ppp

To display information about PPP PDP type processing on the gateway GPRS support node (GGSN), use the **debug gprs gtp ppp** command in privileged EXEC mode. To disable debugging output, use the **no** form of this command.

debug gprs gtp ppp {events | details}

no debug gprs gtp ppp {events | details}

Syntax Description

events	Displays messages specific to certain conditions that are occurring during PPP PDP type processing.
details	Displays more extensive and lower-level messages related to PPP PDP type processing.

Defaults

No default behavior or values.

Command History

Release	Modification
12.2(4)MX	This command was introduced.
12.2(8)YD	This command was integrated into Cisco IOS Release 12.2(8)YD.
12.2(8)YW	This command was integrated into Cisco IOS Release 12.2(8)YW.
12.3(2)XB	This command was integrated into Cisco IOS Release 12.3(2)XB.
12.3(8)XU	This command was integrated into Cisco IOS Release 12.3(8)XU.
12.3(11)YJ	This command was integrated into Cisco IOS Release 12.3(11)YJ.
12.3(14)YQ	This command was integrated into Cisco IOS Release 12.3(14)YQ.
12.3(14)YU	This command was integrated into Cisco IOS Release 12.3(14)YU.
12.4(2)XB	This command was integrated into Cisco IOS Release 12.4(2)XB.
12.4(9)XG	This command was integrated into Cisco IOS Release 12.4(9)XG.
12.4(15)XQ	This command was integrated into Cisco IOS Release 12.4(15)XQ.
12.4(22)YE	This command was integrated into Cisco IOS Release 12.4(22)YE.
12.4(22)YE1	This command was integrated into Cisco IOS Release 12.4(22)YE1.
12.4(22)YE2	This command was integrated into Cisco IOS Release 12.4(22)YE2.
12.4(24)YE	This command was integrated into Cisco IOS Release 12.4(24)YE.
12.4(24)YE1	This command was integrated into Cisco IOS Release 12.4(24)YE1.
12.4(24)YE2	This command was integrated into Cisco IOS Release 12.4(24)YE2.
12.4(24)YE3	This command was integrated into Cisco IOS Release 12.4(24)YE3.

Usage Guidelines

This command is useful for system operators and development engineers if problems are encountered with PPP PDP type processing on the GGSN.

You can enable both forms of the **debug gprs gtp ppp** command at the same time, as separate command line entries. The **events** keyword generates output specific to certain conditions that are occurring, which helps qualify the output being received using the **details** option.

**Caution**

Because the **debug gprs gtp ppp** command generates a significant amount of output, use it only when traffic on the GPRS network is low, so other activity on the system is not adversely affected.

Examples

The following debug examples provide sample output for a Create PDP Context request and clear PDP context using PPP PDP type on the GGSN. The examples show output while both debug events and details are enabled on the GGSN.

Example 1

The following example displays details and events output related to PPP PDP context processing for a Create PDP Context requested received by the GGSN:

```
Router# debug gprs gtp ppp events
GTP PPP events display debugging is on
Router# debug gprs gtp ppp details
GTP PPP details display debugging is on
7200b#
3d23h: GPRS:
3d23h: GTP-PPP Fa1/0: Create new gtp_ppp_info
3d23h: GPRS:
3d23h: GTP-PPP: domain gprs.cisco.com not in any VPDN group
3d23h: GPRS:
3d23h: GTP-PPP: aaa-group accounting not configured under APN gprs.cisco.com
3d23h: GPRS:GTP-PPP: Don't cache internally generated pak's header
3d23h: %LINK-3-UPDOWN: Interface Virtual-Access2, changed state to up
3d23h: GPRS:
3d23h: GTP-PPP Vi2: gtp_ppp_cstate_react changing states
3d23h: GPRS:GTP-PPP: pdp_entry 0x62F442A4, recv ppp data pak
3d23h: GPRS:GTP-PPP Vi2: proc_udp_input pak's linktype = 30
3d23h: GPRS:GTP-PPP: pdp_entry 0x62F442A4, recv ppp data pak
3d23h: GPRS:GTP-PPP Vi2: proc_udp_input pak's linktype = 30
3d23h: GPRS:GTP-PPP: pdp_entry 0x62F442A4, recv ppp data pak
3d23h: GPRS:GTP-PPP Vi2: proc_udp_input pak's linktype = 30
3d23h: GPRS:
3d23h: GTP-PPP: Vi2: Concat names user00 & gprs.cisco.com
3d23h: GPRS:
3d23h: GTP-PPP: New username after concat: user00@gprs.cisco.com
3d23h: GPRS:
3d23h: GTP-PPP: Vi2: Concat names user00@gprs.cisco.com & gprs.cisco.com
3d23h: GPRS:
3d23h: GTP-PPP: New username after concat: user00@gprs.cisco.com
3d23h: GPRS:GTP-PPP: pdp_entry 0x62F442A4, recv ppp data pak
3d23h: GPRS:GTP-PPP Vi2: proc_udp_input pak's linktype = 30
3d23h: GPRS:GTP-PPP: pdp_entry 0x62F442A4, recv ppp data pak
3d23h: GPRS:GTP-PPP Vi2: proc_udp_input pak's linktype = 30
3d23h: GPRS:GTP-PPP: pdp_entry 0x62F442A4, recv ppp data pak
3d23h: GPRS:GTP-PPP Vi2: proc_udp_input pak's linktype = 30
3d23h: GPRS:GTP-PPP: pdp_entry 0x62F442A4, recv ppp data pak
3d23h: GPRS:GTP-PPP Vi2: proc_udp_input pak's linktype = 30
3d23h: %LINEPROTO-5-UPDOWN: Line protocol on Interface Virtual-Access2, changed state to up
```

```
3d23h: GPRS:GTP-PPP: pdp_entry 0x62F442A4, recv ppp data pak
3d23h: GPRS:GTP-PPP Vi2: proc_udp_input pak's linktype = 30
3d23h: GPRS:GTP-PPP: pdp_entry 0x62F442A4, recv ppp data pak
3d23h: GPRS:GTP-PPP Vi2: proc_udp_input pak's linktype = 30
3d23h: GPRS:
3d23h: GTP-PPP Vi2: gtp_ppp_protocol_up is notified about intf UP
3d23h: GPRS:
3d23h: GTP-PPP Vi2: PDP w/ MS addr 98.102.0.1 inserted into IP radix tree
```

Example 2

The following example displays both details and events related to PPP PDP type processing after clearing PDP contexts on the GGSN:

```
Router# clear gprs gtp pdp-context all
3d23h: GPRS:GTP-PPP: pdp_entry 0x62F442A4, recv ppp data pak
3d23h: GPRS:GTP-PPP Vi2: proc_udp_input pak's linktype = 30
3d23h: GPRS:GTP-PPP: pdp_entry 0x62F442A4, recv ppp data pak
3d23h: GPRS:GTP-PPP Vi2: proc_udp_input pak's linktype = 30
3d23h: GPRS:
3d23h: GTP-PPP Vi2: gtp_ppp_pdp_terminate shutting down the vaccess
3d23h: GPRS:
3d23h: GTP-PPP Vi2: gtp_ppp_pdp_shut_va shutting down intf
3d23h: %LINK-3-UPDOWN: Interface Virtual-Access2, changed state to down
3d23h: GPRS:
3d23h: GTP-PPP Vi2: gtp_ppp_cstate_react changing states
3d23h: GPRS:
3d23h: GTP-PPP Vi2: gtp_ppp_free_va resetting intf vectors
3d23h: %LINEPROTO-5-UPDOWN: Line protocol on Interface Virtual-Access2, changed state to
down
```

debug gprs gtp ppp-regeneration

To display information about PPP regeneration processing on the GGSN, use the **debug gprs gtp ppp-regeneration** privileged EXEC command. To disable debugging output, use the **no** form of this command.

debug gprs gtp ppp-regeneration {events | details}

no debug gprs gtp ppp-regeneration {events | details}

Syntax Description

events	Displays messages specific to certain conditions that are occurring during PPP regeneration processing.
details	Displays more extensive and lower-level messages related to PPP regeneration processing.

Defaults

No default behavior or values.

Command History

Release	Modification
12.2(4)MX	This command was introduced.
12.2(8)YD	This command was incorporated in Cisco IOS Release 12.2(8)YD.
12.2(8)YW	This command was incorporated in Cisco IOS Release 12.2(8)YW.
12.3(2)XB	This command was incorporated in Cisco IOS Release 12.3(2)XB.
12.3(8)XU	This command was incorporated in Cisco IOS Release 12.3(8)XU.
12.3(11)YJ	This command was incorporated in Cisco IOS Release 12.3(11)YJ.
12.3(14)YQ	This command was incorporated in Cisco IOS Release 12.3(14)YQ.
12.3(14)YU	This command was integrated into Cisco IOS Release 12.3(14)YU.
12.4(2)XB	This command was integrated into Cisco IOS Release 12.4(2)XB.
12.4(9)XG	This command was integrated into Cisco IOS Release 12.4(9)XG.
12.4(15)XQ	This command was integrated into Cisco IOS Release 12.4(15)XQ.
12.4(22)YE	This command was integrated into Cisco IOS Release 12.4(22)YE.
12.4(22)YE1	This command was integrated into Cisco IOS Release 12.4(22)YE1.
12.4(22)YE2	This command was integrated into Cisco IOS Release 12.4(22)YE2.
12.4(24)YE	This command was integrated into Cisco IOS Release 12.4(24)YE.
12.4(24)YE1	This command was integrated into Cisco IOS Release 12.4(24)YE1.
12.4(24)YE2	This command was integrated into Cisco IOS Release 12.4(24)YE2.
12.4(24)YE3	This command was integrated into Cisco IOS Release 12.4(24)YE3.

Usage Guidelines

This command is useful for system operators and development engineers if problems are encountered with communication between GDM and a GGSN.

You can enable both forms of the **debug gprs gtp ppp-regeneration** command at the same time, as separate command line entries. The **events** keyword generates output specific to certain conditions that are occurring, which helps qualify the output being received using the **details** option.

**Caution**

Because the **debug gprs gtp ppp-regeneration** command generates a significant amount of output, use it only when traffic on the GPRS network is low, so other activity on the system is not adversely affected.

Examples

The following debug examples provide sample output for a create PDP context request and clear PDP context using PPP regeneration on the GGSN. The examples show output while both debug events and details are enabled on the GGSN.

Example 1

The following example displays details and events output related to PPP regeneration processing for a create PDP context requested received by the GGSN:

```
Router# debug gprs gtp ppp-regeneration details
GTP PPP regeneration details display debugging is on
Router# debug gprs gtp ppp-regeneration events
GTP PPP regeneration events display debugging is on
06:24:02: PPP-REGEN state counters: pending counter is 0
06:24:02:           State[IDLE] counter is 0
06:24:02:           State[AUTHORIZING] counter is 0
06:24:02:           State[VPDN CONNECTING] counter is 0
06:24:02:           State[PPP NEGOTIATING] counter is 0
06:24:02:           State[PPP CONNECTED] counter is 0
06:24:02:           State[PPP TERMINATING] counter is 0
06:24:02: PPP-REGEN state counters: pending counter is 1
06:24:02:           State[IDLE] counter is 1
06:24:02:           State[AUTHORIZING] counter is 0
06:24:02:           State[VPDN CONNECTING] counter is 0
06:24:02:           State[PPP NEGOTIATING] counter is 0
06:24:02:           State[PPP CONNECTED] counter is 0
06:24:02:           State[PPP TERMINATING] counter is 0
06:24:02: GPRS:101111111500001:Authen: PAP username: tomyl@corporate_1.com
06:24:02: GPRS:101111111500001:Session timer started
06:24:02: GPRS:Processing PPP regen reqQ
06:24:02: GPRS:101111111500001:Processing Initiate PPP regen from reqQ
06:24:02: GPRS:101111111500001:got event [REQUEST PPP REGEN] in state [IDLE]
06:24:02: PPP-REGEN state counters: pending counter is 1
06:24:02:           State[IDLE] counter is 0
06:24:02:           State[AUTHORIZING] counter is 1
06:24:02:           State[VPDN CONNECTING] counter is 0
06:24:02:           State[PPP NEGOTIATING] counter is 0
06:24:02:           State[PPP CONNECTED] counter is 0
06:24:02:           State[PPP TERMINATING] counter is 0
06:24:02: GPRS:101111111500001:state [IDLE->AUTHORIZING] on event [REQUEST PPP REGEN]
06:24:02: GPRS:101111111500001:Got VPN authorization info
06:24:02: GPRS:101111111500001:got event [AUTHOR SUCCESS] in state [AUTHORIZING]
06:24:02: PPP-REGEN state counters: pending counter is 1
06:24:02:           State[IDLE] counter is 0
06:24:02:           State[AUTHORIZING] counter is 0
06:24:02:           State[VPDN CONNECTING] counter is 1
06:24:02:           State[PPP NEGOTIATING] counter is 0
06:24:02:           State[PPP CONNECTED] counter is 0
```

```

06:24:02:                State[PPP TERMINATING] counter is 0
06:24:02: GPRS:101111111500001:state [AUTHORIZING->VPDN CONNECTING] on event [AUTHOR
SUCCESS]
06:24:02: GPRS:101111111500001:Author succeeded, establishing the tunnel
06:24:02: GPRS:101111111500001:Create/Clone vaccess to negotiate PPP
06:24:02: GPRS:101111111500001:no need to set NS ppp_config
06:24:02: GPRS:101111111500001:MS no static IP addr. Get one via IPCP
06:24:02: GPRS:101111111500001:VPDN to inform PPP regen: CONNECTED
06:24:02: GPRS:101111111500001:got event [VPDN CONNECTED] in state [VPDN CONNECTING]
06:24:02: PPP-REGEN state counters: pending counter is 1
06:24:02:                State[IDLE] counter is 0
06:24:02:                State[AUTHORIZING] counter is 0
06:24:02:                State[VPDN CONNECTING] counter is 0
06:24:02:                State[PPP NEGOTIATING] counter is 1
06:24:02:                State[PPP CONNECTED] counter is 0
06:24:02:                State[PPP TERMINATING] counter is 0
06:24:02: GPRS:101111111500001:state [VPDN CONNECTING->PPP NEGOTIATING] on event [VPDN
CONNECTED]
06:24:02: GPRS:101111111500001:Start PPP negotiations on vaccess
06:24:02: %LINK-3-UPDOWN: Interface Virtual-Access2, changed state to up
06:24:02: GPRS:101111111500001:IPCP is up
06:24:02: GPRS:101111111500001:LNS allocates 10.100.1.1 for MS
06:24:02: GPRS:101111111500001:IP addr 10.100.1.1 is negotiated for MS
06:24:02: GPRS:101111111500001:PPP connected
06:24:02: GPRS:101111111500001:got event [PPP NEGOTIATED] in state [PPP NEGOTIATING]
06:24:02: PPP-REGEN state counters: pending counter is 0
06:24:02:                State[IDLE] counter is 0
06:24:02:                State[AUTHORIZING] counter is 0
06:24:02:                State[VPDN CONNECTING] counter is 0
06:24:02:                State[PPP NEGOTIATING] counter is 0
06:24:02:                State[PPP CONNECTED] counter is 1
06:24:02:                State[PPP TERMINATING] counter is 0
06:24:02: GPRS:101111111500001:state [PPP NEGOTIATING->PPP CONNECTED] on event [PPP
NEGOTIATED]
06:24:02: GPRS:101111111500001:PPP succeeded negotiation, session established
06:24:02: GPRS:101111111500001:Session timer stopped
06:24:03: %LINEPROTO-5-UPDOWN: Line protocol on Interface Virtual-Access2, changed state
to up

```

Example 2

The following example displays both details and events related to PPP regeneration processing after clearing PDP contexts on the GGSN:

```

Router# clear gprs gtp pdp-context all
06:28:05: PPP-REGEN state counters: pending counter is 0
06:28:05:                State[IDLE] counter is 0
06:28:05:                State[AUTHORIZING] counter is 0
06:28:05:                State[VPDN CONNECTING] counter is 0
06:28:05:                State[PPP NEGOTIATING] counter is 0
06:28:05:                State[PPP CONNECTED] counter is 1
06:28:05:                State[PPP TERMINATING] counter is 0
06:28:05: GPRS:101111111500001:PPP regen current state PPP CONNECTED
06:28:05: GPRS:101111111500001:GTP disconnecting the PPP regen session
06:28:05: GPRS:Processing PPP regen reqQ
06:28:05: GPRS:101111111500001:Processing Disconnect PPP  regen from reqQ
06:28:05: GPRS:101111111500001:got event [CANCEL REGEN'ED PPP] in state [PPP CONNECTED]
06:28:05: PPP-REGEN state counters: pending counter is 1
06:28:05:                State[IDLE] counter is 0
06:28:05:                State[AUTHORIZING] counter is 0
06:28:05:                State[VPDN CONNECTING] counter is 0
06:28:05:                State[PPP NEGOTIATING] counter is 0
06:28:05:                State[PPP CONNECTED] counter is 0

```

```
06:28:05: State[PPP TERMINATING] counter is 1
06:28:05: GPRS:101111111500001:state [PPP CONNECTED->PPP TERMINATING] on event [CANCEL
REGEN'ED PPP]
06:28:05: GPRS:101111111500001:Cancel request after VPND tunnel is up
06:28:05: PPP-REGEN state counters: pending counter is 1
06:28:05: State[IDLE] counter is 0
06:28:05: State[AUTHORIZING] counter is 0
06:28:05: State[VPDN CONNECTING] counter is 0
06:28:05: State[PPP NEGOTIATING] counter is 0
06:28:05: State[PPP CONNECTED] counter is 0
06:28:05: State[PPP TERMINATING] counter is 1
06:28:05: GPRS:101111111500001:PPP down
06:28:05: GPRS:101111111500001:got event [PPP FAILED] in state [PPP TERMINATING]
06:28:05: PPP-REGEN state counters: pending counter is 1
06:28:05: State[IDLE] counter is 1
06:28:05: State[AUTHORIZING] counter is 0
06:28:05: State[VPDN CONNECTING] counter is 0
06:28:05: State[PPP NEGOTIATING] counter is 0
06:28:05: State[PPP CONNECTED] counter is 0
06:28:05: State[PPP TERMINATING] counter is 0
06:28:05: GPRS:101111111500001:state [PPP TERMINATING->IDLE] on event [PPP FAILED]
06:28:05: GPRS:101111111500001:LCP went down
06:28:05: GPRS:101111111500001:VPDN disconnect
06:28:05: GPRS:101111111500001:got event [CLEANUP CONTEXT] in state [IDLE]
06:28:05: GPRS:101111111500001:state [IDLE->IDLE] on event [CLEANUP CONTEXT]
06:28:05: GPRS:101111111500001:Freeing context structure
06:28:05: GPRS:101111111500001:VPDN handle invalid, no need to free it
06:28:05: GPRS:101111111500001:remove PPP regen context from Vi2
06:28:05: GPRS:101111111500001:Session timer stopped
06:28:05: PPP-REGEN state counters: pending counter is 0
06:28:05: State[IDLE] counter is 0
06:28:05: State[AUTHORIZING] counter is 0
06:28:05: State[VPDN CONNECTING] counter is 0
06:28:05: State[PPP NEGOTIATING] counter is 0
06:28:05: State[PPP CONNECTED] counter is 0
06:28:05: State[PPP TERMINATING] counter is 0
06:28:05: GPRS:101111111500001:PPP regen context 0x633F196C released
06:28:05: %LINK-3-UPDOWN: Interface Virtual-Access2, changed state to down
06:28:06: %LINEPROTO-5-UPDOWN: Line protocol on Interface Virtual-Access2, changed state
to down
```

debug gprs iscsi

To display information about the GPRS iSCSI processing, use the **debug gprs iscsi** command in privileged EXEC mode. To disable debugging output, use the **no** form of this command.

debug gprs gtp {errors | events | messages}

no debug gprs gtp {errors | events | messages}

Syntax Description

errors	Displays error messages related to GPRS iSCSI processing on the GGSN.
events	Displays events related to GPRS iSCSI processing on the GGSN.
messages	Displays signaling messages related to GPRS iSCSI.

Defaults

No default behavior or values.

Command History

Release	Modification
12.4(15)XQ	This command was introduced.
12.4(22)YE	This command was integrated into Cisco IOS Release 12.4(22)YE.
12.4(22)YE1	This command was integrated into Cisco IOS Release 12.4(22)YE1.
12.4(22)YE2	This command was integrated into Cisco IOS Release 12.4(22)YE2.
12.4(24)YE	This command was integrated into Cisco IOS Release 12.4(24)YE.
12.4(24)YE1	This command was integrated into Cisco IOS Release 12.4(24)YE1.
12.4(24)YE2	This command was integrated into Cisco IOS Release 12.4(24)YE2.
12.4(24)YE3	This command was integrated into Cisco IOS Release 12.4(24)YE3.

Usage Guidelines

This command is useful for system operators and development engineers if problems are encountered with communication between the GGSN and the SAN using iSCSI.

Examples

The following example displays GPRS iSCSI debugging:

```
Router#
SAMI 9/3: GPRS:Fn is ggsn_iscsi_send_leftover_dtrs_to_cgw
SAMI 9/3: GPRS:Fn is ggsn_iscsi_send_leftover_dtrs_to_cgw
SAMI 9/3: GPRS:ISCSI: data_len = 246, error code = 0
SAMI 9/3: GPRS:GGSN_ISCSI_MSG
SAMI 9/3: GPRS:ISCSI_READ_ACK_RCVD
SAMI 9/3: GPRS:
  ISCSI: Retrieved DTR Val is iscsi_hdr.dtr_typ_val 2
SAMI 9/3: GPRS:ISCSI: dtr_typ_val = 2 fn:send_retrieved_dtr_to_cgw
SAMI 9/3: GPRS:ISCSI: SAN has sent the record for a read request
SAMI 9/3: GPRS:ISCSI: ISCSI_DYNAMIC send_retrieved_dtr_to_cgw
SAMI 9/3: GPRS:ISCSI: gtp_msg_send_iscsi_retrieved_drt_req is called
SAMI 9/3: GPRS:retrieved cdr from ISCSI
SAMI 9/3: GPRS:Fn is gtp_msg_send_iscsi_retrieved_drt_req, pak val is 4AE35EE4
pak-datagramstart is 7C53FA18 pak->datagramsize is 232
```

```
SAMI 9/3: GPRS:ISCSI: data_len = 246, error code = 0
SAMI 9/3: GPRS:GGSN_ISCSI_MSG
SAMI 9/3: GPRS:ISCSI_READ_ACK_RCVD
SAMI 9/3: GPRS:
  ISCSI: Retrieved DTR Val is iscsi_hdr.dtr_typ_val 2
SAMI 9/3: GPRS:ISCSI: dtr_typ_val = 2 fn:send_retrieved_dtr_to_cgw
SAMI 9/3: GPRS:ISCSI: SAN has sent the record for a read request
SAMI 9/3: GPRS:ISCSI: ISCSI_DYNAMIC send_retrieved_dtr_to_cgw
SAMI 9/3: GPRS:ISCSI: gtp_msg_send_iscsi_retrieved_drt_req is called
SAMI 9/3: GPRS:retrieved cdr from ISCSI
SAMI 9/3: GPRS:Fn is gtp_msg_send_iscsi_retrieved_drt_req, pak val is 41056464
pak-datagramstart is 7C003058 pak->datagramsize is 232

SAMI 9/3: GPRS:ISCSI: data_len = 246, error code = 0
SAMI 9/3: GPRS:GGSN_ISCSI_MSG
SAMI 9/3: GPRS:ISCSI_READ_ACK_RCVD
SAMI 9/3: GPRS:
  ISCSI: Retrieved DTR Val is iscsi_hdr.dtr_typ_val 2
SAMI 9/3: GPRS:ISCSI: dtr_typ_val = 2 fn:send_retrieved_dtr_to_cgw
SAMI 9/3: GPRS:ISCSI: SAN has sent the record for a read request
SAMI 9/3: GPRS:ISCSI: ISCSI_DYNAMIC send_retrieved_dtr_to_cgw
SAMI 9/3: GPRS:ISCSI: gtp_msg_send_iscsi_retrieved_drt_req is called
SAMI 9/3: GPRS:retrieved cdr from ISCSI
SAMI 9/3: GPRS:Fn is gtp_msg_send_iscsi_retrieved_drt_req, pak val is 415563FC
pak-datagramstart is 7C53FD58 pak->datagramsize is 232

SAMI 9/3: GPRS:ISCSI: data_len = 246, error code = 0
SAMI 9/3: GPRS:GGSN_ISCSI_MSG
SAMI 9/3: GPRS:ISCSI_READ_ACK_RCVD
SAMI 9/3: GPRS:
  ISCSI: Retrieved DTR Val is iscsi_hdr.dtr_typ_val 2
SAMI 9/3: GPRS:ISCSI: dtr_typ_val = 2 fn:send_retrieved_dtr_to_cgw
SAMI 9/3: GPRS:ISCSI: SAN has sent the record for a read request
SAMI 9/3: GPRS:ISCSI: ISCSI_DYNAMIC send_retrieved_dtr_to_cgw
SAMI 9/3: GPRS:ISCSI: gtp_msg_send_iscsi_retrieved_drt_req is called
SAMI 9/3: GPRS:retrieved cdr from ISCSI
SAMI 9/3: GPRS:Fn is gtp_msg_send_iscsi_retrieved_drt_req, pak val is 41056BDC
pak-datagramstart is 7C003D58 pak->datagramsize is 232

SAMI 9/3: GPRS:Fn is ggsn_iscsi_send_leftover_dtrs_to_cgw
SAMI 9/3: GPRS:Fn is ggsn_iscsi_send_leftover_dtrs_to_cgw
SAMI 9/3: GPRS:ISCSI: data_len = 1162, error code = 0
SAMI 9/3: GPRS:GGSN_ISCSI_MSG
SAMI 9/3: GPRS:ISCSI_READ_ACK_RCVD
SAMI 9/3: GPRS:
  ISCSI: Retrieved DTR Val is iscsi_hdr.dtr_typ_val 1
SAMI 9/3: GPRS:ISCSI: dtr_typ_val = 1 fn:send_retrieved_dtr_to_cgw
SAMI 9/3: GPRS:ISCSI: SAN has sent the record for a read request
SAMI 9/3: GPRS:ISCSI: ISCSI_PENDING send_retrieved_dtr_to_cgw cgw_down_flags 300
SAMI 9/3: GPRS:ISCSI: gtp_msg_send_iscsi_retrieved_drt_req is called
SAMI 9/3: GPRS:retrieved cdr from ISCSI
SAMI 9/3: GPRS:Fn is gtp_msg_send_iscsi_retrieved_drt_req, pak val is 4AE3B10C
pak-datagramstart is 7C5512D8 pak->datagramsize is 1132

SAMI 9/3: GPRS:Fn is ggsn_iscsi_send_leftover_dtrs_to_cgw
SAMI 9/3: GPRS:Fn is ggsn_iscsi_send_leftover_dtrs_to_cgw
SAMI 9/3: GPRS:ISCSI: data_len = 0, error code = 3
SAMI 9/3: GPRS:ISCSI retrieved empty record 3
SAMI 9/3: GPRS:GGSN_ISCSI_MSG
SAMI 9/3: GPRS:ISCSI_READ_ACK_RCVD
SAMI 9/3: GPRS:Empty iSCSI record was rcvd, so send leftover DTRs to CG
SAMI 9/3: GPRS:Fn is ggsn_iscsi_send_leftover_dtrs_to_cgw
SAMI 9/3: GPRS:ISCSI: data_len = 0, error code = 3
```

```
SAMI 9/3: GPRS:ISCSI retrieved empty record 3
SAMI 9/3: GPRS:GGSN_ISCSI_MSG
SAMI 9/3: GPRS:ISCSI_READ_ACK_RCVD
SAMI 9/3: GPRS:Empty iSCSI record was rcvd, so send leftover DTRs to CG
SAMI 9/3: GPRS:Fn is ggsn_iscsi_send_leftover_dtrs_to_cgw
SAMI 9/3: GPRS:ISCSI: data_len = 0, error code = 3
SAMI 9/3: GPRS:ISCSI retrieved empty record 3
SAMI 9/3: GPRS:GGSN_ISCSI_MSG
SAMI 9/3: GPRS:ISCSI_READ_ACK_RCVD
SAMI 9/3: GPRS:Empty iSCSI record was rcvd, so send leftover DTRs to CG
SAMI 9/3: GPRS:Fn is ggsn_iscsi_send_leftover_dtrs_to_cgw
SAMI 9/3: GPRS:ISCSI: data_len = 0, error code = 3
SAMI 9/3: GPRS:ISCSI retrieved empty record 3
SAMI 9/3: GPRS:GGSN_ISCSI_MSG
SAMI 9/3: GPRS:ISCSI_READ_ACK_RCVD
SAMI 9/3: GPRS:Empty iSCSI record was rcvd, so send leftover DTRs to CG
SAMI 9/3: GPRS:Fn is ggsn_iscsi_send_leftover_dtrs_to_cgw
SAMI 9/3: GPRS:ISCSI: data_len = 0, error code = 3
SAMI 9/3: GPRS:ISCSI retrieved empty record 3
SAMI 9/3: GPRS:GGSN_ISCSI_MSG
SAMI 9/3: GPRS:ISCSI_READ_ACK_RCVD
SAMI 9/3: GPRS:Empty iSCSI record was rcvd, so send leftover DTRs to CG
SAMI 9/3: GPRS:Fn is ggsn_iscsi_send_leftover_dtrs_to_cgw
SAMI 9/3: GPRS:ISCSI: data_len = 0, error code = 3
SAMI 9/3: GPRS:ISCSI retrieved empty record 3
SAMI 9/3: GPRS:GGSN_ISCSI_MSG
SAMI 9/3: GPRS:ISCSI_READ_ACK_RCVD
SAMI 9/3: GPRS:Empty iSCSI record was rcvd, so send leftover DTRs to CG
SAMI 9/3: GPRS:Fn is ggsn_iscsi_send_leftover_dtrs_to_cgw
SAMI 9/3: GPRS:Fn is ggsn_iscsi_send_leftover_dtrs_to_cgw
Router#
```

debug gprs prepaid stand-alone

To display information about GGSN standalone prepaid quota enforcement processing, use the **debug gprs prepaid stand-alone** command in privileged EXEC mode. To disable debugging output, use the **no** form of this command.

debug gprs prepaid stand-alone {errors | events | timers}

no debug gprs prepaid stand-alone {errors | events | timers}

Syntax Description

errors	Displays errors related to GPRS standalone prepaid quota enforcement.
events	Displays events related to GPRS standalone prepaid quota enforcement.
timers	Displays timer events related to GPRS standalone prepaid quota enforcement.

Defaults

No default behavior or values.

Command History

Release	Modification
12.4(22)YE	This command was introduced.
12.4(22)YE1	This command was integrated into Cisco IOS Release 12.4(22)YE1.
12.4(22)YE2	This command was integrated into Cisco IOS Release 12.4(22)YE2.
12.4(24)YE	This command was integrated into Cisco IOS Release 12.4(24)YE.
12.4(24)YE1	This command was integrated into Cisco IOS Release 12.4(24)YE1.
12.4(24)YE2	This command was integrated into Cisco IOS Release 12.4(24)YE2.
12.4(24)YE3	This command was integrated into Cisco IOS Release 12.4(24)YE3.

Usage Guidelines

This command is useful for system operators and development engineers if problems are encountered with GGSN stand-alone mode prepaid quota enforcement.

Examples

The following example displays errors related to GGSN standalone prepaid quota enforcement:

```
Router# debug gprs prepaid stand-alone errors
```

debug gprs radius

To display information about Remote Access Dial-In User Service (RADIUS) processing on the gateway GPRS support node (GGSN), use the **debug gprs radius** command in privileged EXEC mode. To disable debugging output, use the **no** form of this command.

debug gprs radius

no debug gprs radius

Syntax Description

This command has no arguments or keywords.

Defaults

No default behavior or values.

Command History

Release	Modification
12.2(4)MX	This command was introduced.
12.2(8)YD	This command was integrated into Cisco IOS Release 12.2(8)YD.
12.2(8)YW	This command was integrated into Cisco IOS Release 12.2(8)YW.
12.3(2)XB	This command was integrated into Cisco IOS Release 12.3(2)XB.
12.3(8)XU	This command was integrated into Cisco IOS Release 12.3(8)XU.
12.3(11)YJ	This command was integrated into Cisco IOS Release 12.3(11)YJ.
12.3(14)YQ	This command was integrated into Cisco IOS Release 12.3(14)YQ.
12.3(14)YU	This command was integrated into Cisco IOS Release 12.3(14)YU.
12.4(2)XB	This command was integrated into Cisco IOS Release 12.4(2)XB.
12.4(9)XG	This command was integrated into Cisco IOS Release 12.4(9)XG.
12.4(15)XQ	This command was integrated into Cisco IOS Release 12.4(15)XQ.
12.4(22)YE	This command was integrated into Cisco IOS Release 12.4(22)YE.
12.4(22)YE1	This command was integrated into Cisco IOS Release 12.4(22)YE1.
12.4(24)YE	This command was integrated into Cisco IOS Release 12.4(24)YE.
12.4(24)YE1	This command was integrated into Cisco IOS Release 12.4(24)YE1.
12.4(24)YE2	This command was integrated into Cisco IOS Release 12.4(24)YE2.
12.4(24)YE3	This command was integrated into Cisco IOS Release 12.4(24)YE3.

Usage Guidelines

This command is useful for system operators and development engineers if problems are encountered with communication between a RADIUS server and the GGSN.

**Caution**

Because the **debug gprs radius** command generates a significant amount of output, use it only when traffic on the GPRS network is low, so other activity on the system is not adversely affected.

Examples

The following example enables the display of debug messages related to RADIUS processing on the GGSN:

```
Router# debug gprs radius
```

debug gprs redundancy

To display debug messages, errors, events, or packets related to GTP session redundancy (GTP-SR), use the **debug gprs redundancy** privileged EXEC command. To disable debugging output, use the **no** form of this command.

debug gprs redundancy [**debug** | **errors** | **events** | **packets**]

no debug gprs redundancy [**debug** | **errors** | **events** | **packets**]

Syntax Description

debug	Displays debug messages related to GTP-SR.
errors	Displays errors related to GTP-SR.
events	Displays events related to GTP-SR.
packets	Displays packets related to GTP-SR packets.

Defaults

Disabled.

Command Modes

Global configuration

Command History

Release	Modification
12.3(11)YJ	This command was introduced.
12.3(14)YQ	This command was incorporated in Cisco IOS Release 12.3(14)YQ.
12.4(9)T	This command was integrated into Cisco IOS Release 12.4(9)T.
12.3(14)YU	This command was integrated into Cisco IOS Release 12.3(14)YU.
12.4(2)XB	This command was integrated into Cisco IOS Release 12.4(2)XB.
12.4(9)XG	This command was integrated into Cisco IOS Release 12.4(9)XG.
12.4(15)XQ	This command was integrated into Cisco IOS Release 12.4(15)XQ.
12.4(22)YE1	This command was integrated into Cisco IOS Release 12.4(22)YE1.
12.4(22)YE2	This command was integrated into Cisco IOS Release 12.4(22)YE2.

Usage Guidelines

This command displays debug level messages, errors, events, or packets for GTP-SR. It is useful for system operators and development engineers if problems are encountered with communication between the two GGSNs configured as an redundant pair and on which GTP-SR is enabled.

Examples

Example 1.

The following sample outputs is for a GGSN switchover and switchover of standby to active. There is no PDP context involved in this debug collection.

Active GGSN:

```
Router-a#show gprs redundancy
```

GPRS redundancy is enabled and Unit-Status is Standby

Redundancy Transport Infrastructure status

Redundancy Infrastructure state: STANDBY HOT
Peer Redundancy Infrastructure state: ACTIVE

GGSN Redundancy system up since: 21:29:21 EDT Aug 19 2000
Time of last switchover: never
Total Number of Switchovers: 2

GPRS Redundancy Statistics

Last cleared: never

CheckPointed-From-Active Statistics

Total Number of Messages:	129
Number of Context Setup messages:	19
Number of Context Modify messages:	3
Number of Context Remove messages:	19
Number of Path Setup messages:	34
Number of Path Modify messages:	5
Number of Path Remove messages:	34
Number of CGF Ready messages:	1
Number of CGF Modify messages:	0
Number of CGF Remove messages:	0
Number of Internal State messages:	7

Router-a#**debug gprs redundancy**

GPRS CF packets debugging is on

GPRS CF events debugging is on

GPRS CF errors debugging is on

GPRS CF debug debugging is on

Router-a#

Router-a#

Router-a#

SAMI 10/2: 000064: Jun 1 2006 18:19:00.975 EDT: %HSRP-6-STATECHANGE:

GigabitEthernet0/0.1100 Grp 51 state Standby -> Active

SAMI 10/2: 000065: Jun 1 2006 18:19:00.975 EDT: GTP-SR:

RF_Status=403-RF_STATUS_MAINTENANCE_ENABLE RFState=9-ACTIVE-FAST operand=0

RFPeerState=13-ACTIVE

SAMI 10/2: 000066: Jun 1 2006 18:19:00.979 EDT: GTP-SR: RF_Event=200-RF_PROG_ACTIVE_FAST

RFState=9-ACTIVE-FAST operand=0 RFPeerState=13-ACTIVE

SAMI 10/2: 000067: Jun 1 2006 18:19:00.979 EDT: GTP-SR: Received RF Progression Active Fast

SAMI 10/2: 000068: Jun 1 2006 18:19:00.979 EDT: GTP-SR: RF_Event=201-RF_PROG_ACTIVE_DRAIN

RFState=10-ACTIVE-DRAIN operand=0 RFPeerState=13-ACTIVE

SAMI 10/2: 000069: Jun 1 2006 18:19:00.979 EDT: GTP-SR: Received RF Progression Active Drain

SAMI 10/2: 000070: Jun 1 2006 18:19:00.979 EDT: GTP-SR:

RF_Event=202-RF_PROG_ACTIVE_PRECONFIG RFState=11-ACTIVE_PRECONFIG operand=0

RFPeerState=13-ACTIVE

SAMI 10/2: 000071: Jun 1 2006 18:19:00.979 EDT: GTP-SR: Received RF Progression Active PreConfig

SAMI 10/2: 000072: Jun 1 2006 18:19:00.979 EDT: GTP-SR:

RF_Event=203-RF_PROG_ACTIVE_POSTCONFIG RFState=12-ACTIVE_POSTCONFIG operand=0

RFPeerState=13-ACTIVE

SAMI 10/2: 000073: Jun 1 2006 18:19:00.979 EDT: GTP-SR: Received RF Progression Active PostConfig

SAMI 10/2: 000074: Jun 1 2006 18:19:00.979 EDT: GTP-SR: RF_Event=204-RF_PROG_ACTIVE

RFState=13-ACTIVE operand=0 RFPeerState=13-ACTIVE

SAMI 10/2: 000075: Jun 1 2006 18:19:00.979 EDT: GTP-SR: Received RF Progression Active

SAMI 10/2: 000076: Jun 1 2006 18:19:00.979 EDT: GTP-SR: Start of the Standby-to-Active transition

```

SAMI 10/2: 000077: Jun  1 2006 18:19:00.979 EDT: GTP-SR: Old State Standby,Event Active
Fast Received, New State Active
SAMI 10/2: 000078: Jun  1 2006 18:19:00.979 EDT: GTP-SR:Context Type  OWN, Handler Sync,
Context Event OWN Ready, Context Sub Event No Sub Event
SAMI 10/2: 000079: Jun  1 2006 18:19:00.979 EDT: GTP-SR:State of Redundancy Context is
Initialized
SAMI 10/2: 000080: Jun  1 2006 18:19:00.979 EDT: GTP-SR: Event OWN Ready, Sub Event No Sub
Event
SAMI 10/2: 000081: Jun  1 2006 18:19:00.979 EDT: GTP-SR: Removing element from state-list
Initialized, final count 2
SAMI 10/2: 000082: Jun  1 2006 18:19:00.979 EDT: GTP-SR: adding element in state-list Bulk
Synch Ready, final count 2
SAMI 10/2: 000083: Jun  1 2006 18:19:00.979 EDT: GTP-SR:Context Type  CGF, Handler Sync,
Context Event CGF Ready, Context Sub Event No Sub Event
SAMI 10/2: 000084: Jun  1 2006 18:19:00.979 EDT: GTP-SR:State of Redundancy Context is
Initialized
SAMI 10/2: 000085: Jun  1 2006 18:19:00.979 EDT: GTP-SR: Event CGF Ready, Sub Event No Sub
Event
SAMI 10/2: 000086: Jun  1 2006 18:19:00.979 EDT: GTP-SR: Removing element from state-list
Initialized, final count 1
SAMI 10/2: 000087: Jun  1 2006 18:19:00.979 EDT: GTP-SR: adding element in state-list Bulk
Synch Ready, final count 3
SAMI 10/2: 000088: Jun  1 2006 18:19:00.979 EDT: GTP-SR: Invalid shdb 0x0
SAMI 10/2: 000089: Jun  1 2006 18:19:00.979 EDT: GTP-SR: Transition CG 10.0.250.114 to
(state 0)
SAMI 10/2: 000090: Jun  1 2006 18:19:00.979 EDT: GTP-SR: Invalid shdb 0x0
SAMI 10/2: 000091: Jun  1 2006 18:19:00.979 EDT: GTP-SR: Transition CG 10.0.250.115 to
(state 0)
SAMI 10/2: 000092: Jun  1 2006 18:19:00.983 EDT: GTP-SR: SHDB AVL tree cleanup to start in
10 sec
SAMI 10/2: 000093: Jun  1 2006 18:19:00.983 EDT: GTP-SR: Completion of Standby-to-Active
transition
SAMI 10/2: 000094: Jun  1 2006 18:19:00.983 EDT: GTP-SR: Chkpt Status Flow Off Indication
SAMI 10/2: 000095: Jun  1 2006 18:19:00.987 EDT: %HSRP-6-STATECHANGE:
GigabitEthernet0/0.301 Grp 51 state Standby -> Active
SAMI 10/2: 000096: Jun  1 2006 18:19:00.987 EDT: GTP-SR:
RF_Status=400-RF_STATUS_PEER_PRESENCE RFState=13-ACTIVE operand=0 RFPeerState=13-ACTIVE
SAMI 10/2: 000097: Jun  1 2006 18:19:00.987 EDT: GTP-SR: zero elements to move to other
list
SAMI 10/2: 000098: Jun  1 2006 18:19:00.987 EDT: GTP-SR: zero elements to move to other
list
SAMI 10/2: 000099: Jun  1 2006 18:19:00.987 EDT: GTP-SR: RF_Status=401-RF_STATUS_PEER_COMM
RFState=13-ACTIVE operand=0 RFPeerState=1-DISABLED
SAMI 10/2: 000100: Jun  1 2006 18:19:01.107 EDT: %HSRP-6-STATECHANGE:
GigabitEthernet0/0.1151 Grp 51 state Standby -> Active
SAMI 10/2: 000101: Jun  1 2006 18:19:01.155 EDT: %HSRP-6-STATECHANGE:
GigabitEthernet0/0.250 Grp 51 state Standby -> Active
SAMI 10/2: 000102: Jun  1 2006 18:19:01.295 EDT: %HSRP-6-STATECHANGE:
GigabitEthernet0/0.1101 Grp 51 state Standby -> Active
SAMI 10/2: 000103: Jun  1 2006 18:19:01.355 EDT: %HSRP-6-STATECHANGE:
GigabitEthernet0/0.1251 Grp 51 state Standby -> Active
SAMI 10/2: 000104: Jun  1 2006 18:19:01.451 EDT: %HSRP-6-STATECHANGE:
GigabitEthernet0/0.1201 Grp 51 state Standby -> Active
SAMI 10/2: 000105: Jun  1 2006 18:19:01.459 EDT: %HSRP-6-STATECHANGE:
GigabitEthernet0/0.220 Grp 51 state Standby -> Active
Router-2#
SAMI 10/2: 000106: Jun  1 2006 18:19:10.983 EDT: GTP-SR: SHDB AVL tree cleanup has 3 nodes
removed, 0 leftover
Router-a#
Router-a#
Router-a#
SAMI 10/2: 000107: Jun  1 2006 18:20:25.947 EDT: GTP-SR: Chkpt Status Flow Off Indication
SAMI 10/2: 000108: Jun  1 2006 18:20:25.947 EDT: GTP-SR:
RF_Status=400-RF_STATUS_PEER_PRESENCE RFState=13-ACTIVE operand=1 RFPeerState=1-DISABLED

```

```

SAMI 10/2: 000109: Jun  1 2006 18:20:25.947 EDT: GTP-SR: RF_Status=401-RF_STATUS_PEER_COMM
RFState=13-ACTIVE operand=1 RFPeerState=1-DISABLED
SAMI 10/2: 000110: Jun  1 2006 18:20:25.947 EDT: GTP-SR:
RF_Event=300-RF_PROG_PLATFORM_SYNC RFState=13-ACTIVE operand=0 RFPeerState=0-UNKNOWN
SAMI 10/2: 000111: Jun  1 2006 18:20:25.947 EDT: GTP-SR: Received RF Progression Platform
Sync
SAMI 10/2: 000112: Jun  1 2006 18:20:53.899 EDT: GTP-SR:
RF_Event=102-RF_PROG_STANDBY_CONFIG RFState=13-ACTIVE operand=0 RFPeerState=5-STANDBY
COLD-CONFIG
SAMI 10/2: 000113: Jun  1 2006 18:20:53.899 EDT: GTP-SR: Received RF Progression Standby
Config
SAMI 10/2: 000114: Jun  1 2006 18:20:53.899 EDT: GTP-SR:
RF_Event=103-RF_PROG_STANDBY_FILESYS RFState=13-ACTIVE operand=0 RFPeerState=6-STANDBY
COLD-FILESYS
SAMI 10/2: 000115: Jun  1 2006 18:20:53.899 EDT: GTP-SR: Received RF Progression Stadnby
Filesys
SAMI 10/2: 000116: Jun  1 2006 18:20:53.899 EDT: GTP-SR: RF_Event=104-RF_PROG_STANDBY_BULK
RFState=13-ACTIVE operand=0 RFPeerState=7-STANDBY COLD-BULK
SAMI 10/2: 000117: Jun  1 2006 18:20:53.899 EDT: GTP-SR: Received RF Progression Standby
Bulk
SAMI 10/2: 000118: Jun  1 2006 18:20:53.899 EDT: GTP-SR: Active GGSN sending Bulk Sync
finished Msg
SAMI 10/2: 000119: Jun  1 2006 18:20:53.899 EDT: GTP-SR: packing csg_path vaddr:
10.0.250.91
SAMI 10/2: 000120: Jun  1 2006 18:20:53.899 EDT: GTP-SR: packing csg_path port: 4386
SAMI 10/2: 000121: Jun  1 2006 18:20:53.899 EDT: GTP-SR: packing csg_path state: 1
SAMI 10/2: 000122: Jun  1 2006 18:20:53.899 EDT: GTP-SR: Ckpt Message was sucessfully sent
SAMI 10/2: 000123: Jun  1 2006 18:20:53.899 EDT: GTP-SR: Removing element from state-list
Bulk Synch Ready, final count 2
SAMI 10/2: 000124: Jun  1 2006 18:20:53.899 EDT: GTP-SR: adding element in state-list
Synched, final count 1
SAMI 10/2: 000125: Jun  1 2006 18:20:53.899 EDT: GTP-SR: sync next charging id 0x1C0AA436,
local rsn 0x6B76EBDE
SAMI 10/2: 000126: Jun  1 2006 18:20:53.899 EDT: GTP-SR: Packing Pair Boot time 21:29:21
EDT Aug 19 2000
SAMI 10/2: 000127: Jun  1 2006 18:20:53.899 EDT: GTP-SR: Packing Switcover Count 3
SAMI 10/2: 000128: Jun  1 2006 18:20:53.899 EDT: GTP-SR: Packing local restart_count 21
SAMI 10/2: 000129: Jun  1 2006 18:20:53.899 EDT: GTP-SR: Ckpt Message was sucessfully sent
SAMI 10/2: 000130: Jun  1 2006 18:20:53.899 EDT: GTP-SR: Removing element from state-list
Bulk Synch Ready, final count 1
SAMI 10/2: 000131: Jun  1 2006 18:20:53.899 EDT: GTP-SR: adding element in state-list
Synched, final count 2
SAMI 10/2: 000132: Jun  1 2006 18:20:53.899 EDT: GTP-SR: sync cgf gw 10.0.250.114,
operatemode NOT ACTIVE, nextseq 0x7530
SAMI 10/2: 000133: Jun  1 2006 18:20:53.899 EDT: GTP-SR: sync cgf gw 10.0.250.115,
operatemode NOT ACTIVE, nextseq 0x7530
SAMI 10/2: 000134: Jun  1 2006 18:20:53.899 EDT: GTP-SR: Ckpt Message was sucessfully sent
SAMI 10/2: 000135: Jun  1 2006 18:20:53.899 EDT: GTP-SR: Removing element from state-list
Bulk Synch Ready, final count 0
SAMI 10/2: 000136: Jun  1 2006 18:20:53.899 EDT: GTP-SR: adding element in state-list
Synched, final count 3
SAMI 10/2: 000137: Jun  1 2006 18:20:53.899 EDT: GTP-SR:Active took time of 0 msec to
transfer data for bulk sync
SAMI 10/2: 000138: Jun  1 2006 18:20:53.899 EDT: GTP-SR: Empty list to sync
SAMI 10/2: 000139: Jun  1 2006 18:20:53.899 EDT: GTP-SR: Redundancy RF Event Received is
Standby Bulk Sync End
SAMI 10/2: 000140: Jun  1 2006 18:20:53.899 EDT: GTP-SR: Redundancy Event is Invalid
SAMI 10/2: 000141: Jun  1 2006 18:20:53.899 EDT: GTP-SR: RF_Event=105-RF_PROG_STANDBY_HOT
RFState=13-ACTIVE operand=0 RFPeerState=8-STANDBY HOT
SAMI 10/2: 000142: Jun  1 2006 18:20:53.899 EDT: GTP-SR: Received RF Progression Standby
Hot
Router-b
Router-b#show gprs redundancy
GPRS redundancy is enabled and Unit-Status is Active

```

```

Redundancy Transport Infrastructure status
  Redundancy Infrastructure state:          ACTIVE
  Peer Redundancy Infrastructure state:     STANDBY HOT

  GGSN Redundancy system up since:        21:29:21 EDT Aug 19 2000
  Time of last switchover:
  Total Number of Switchovers:            3

GPRS Redundancy Statistics
  Last cleared: never

CheckPointed-To-Standby Statistics

  Total Number of Messages:                3
  Number of Context Setup messages:        0
  Number of Context Modify messages:       0
  Number of Context Remove messages:       0
  Number of Path Setup messages:           0
  Number of Path Modify messages:          0
  Number of Path Remove messages:          0
  Number of CGF Ready messages:            1
  Number of CGF Modify messages:           0
  Number of CGF Remove messages:           0
  Number of Internal State messages:       1

```

Example 2

The following sample outputs is for PDP context setup, prepaid subscriber traffic, and then PDP context teardown. The debug is given for both active and Standby GGSN. There is no GGSN switchover.

Active GGSN:

```

Router-a#debug gprs redundancy
GPRS CF packets debugging is on
GPRS CF events debugging is on
GPRS CF errors debugging is on
GPRS CF debug debugging is on
Router-a#show gprs redundancy
GPRS redundancy is enabled and Unit-Status is Active

Redundancy Transport Infrastructure status
  Redundancy Infrastructure state:          ACTIVE
  Peer Redundancy Infrastructure state:     STANDBY HOT

  GGSN Redundancy system up since:        21:29:21 EDT Aug 19 2000
  Time of last switchover:
  Total Number of Switchovers:            4

GPRS Redundancy Statistics
  Last cleared: never

CheckPointed-To-Standby Statistics

  Total Number of Messages:                3
  Number of Context Setup messages:        0
  Number of Context Modify messages:       0
  Number of Context Remove messages:       0
  Number of Path Setup messages:           0
  Number of Path Modify messages:          0
  Number of Path Remove messages:          0
  Number of CGF Ready messages:            1
  Number of CGF Modify messages:           0
  Number of CGF Remove messages:           0

```

Number of Internal State messages: 1

```
Router-a#
SAMI 10/2: 000073: Aug 24 2000 23:18:55.947 EDT: GTP-SR:pdpmcb handle for pdpmcb
(0x24D2FC3C) is (0x3A000001)
SAMI 10/2: 000074: Aug 24 2000 23:18:55.963 EDT: GTP-SR: Need to allocate redundancy
context
SAMI 10/2: 000075: Aug 24 2000 23:18:55.963 EDT: GTP-SR: adding element in state-list
Initialized, final count 2
SAMI 10/2: 000076: Aug 24 2000 23:18:55.963 EDT: GTP-SR: Need to allocate redundancy
context
SAMI 10/2: 000077: Aug 24 2000 23:18:55.963 EDT: GTP-SR: adding element in state-list
Initialized, final count 3
SAMI 10/2: 000078: Aug 24 2000 23:18:55.963 EDT: GTP-SR:Context Type Path, Handler Sync,
Context Event Path Setup, Context Sub Event No Sub Event
SAMI 10/2: 000079: Aug 24 2000 23:18:55.963 EDT: GTP-SR:State of Redundancy Context is
Initialized
SAMI 10/2: 000080: Aug 24 2000 23:18:55.963 EDT: GTP-SR: Event Path Setup, Sub Event No
Sub Event
SAMI 10/2: 000081: Aug 24 2000 23:18:55.963 EDT: GTP-SR: Removing element from state-list
Initialized, final count 2
SAMI 10/2: 000082: Aug 24 2000 23:18:55.963 EDT: GTP-SR: adding element in state-list
Dynamic Sync Ready, final count 1
SAMI 10/2: 000083: Aug 24 2000 23:18:55.963 EDT: GTP-SR: Need to allocate redundancy
context
SAMI 10/2: 000084: Aug 24 2000 23:18:55.963 EDT: GTP-SR: adding element in state-list
Initialized, final count 3
SAMI 10/2: 000085: Aug 24 2000 23:18:55.963 EDT: GTP-SR:Context Type Path, Handler Sync,
Context Event Path Setup, Context Sub Event No Sub Event
SAMI 10/2: 000086: Aug 24 2000 23:18:55.963 EDT: GTP-SR:State of Redundancy Context is
Initialized
SAMI 10/2: 000087: Aug 24 2000 23:18:55.963 EDT: GTP-SR: Event Path Setup, Sub Event No
Sub Event
SAMI 10/2: 000088: Aug 24 2000 23:18:55.963 EDT: GTP-SR: Removing element from state-list
Initialized, final count 2
SAMI 10/2: 000089: Aug 24 2000 23:18:55.963 EDT: GTP-SR: adding element in state-list
Dynamic Sync Ready, final count 2
SAMI 10/2: 000090: Aug 24 2000 23:18:55.963 EDT: GTP-SR:packing pathcb->gtpv 1
SAMI 10/2: 000091: Aug 24 2000 23:18:55.963 EDT: GTP-SR:Local IP address 166.11.0.11, and
port 2123
SAMI 10/2: 000092: Aug 24 2000 23:18:55.963 EDT: GTP-SR:Remote IP address 10.10.50.3, and
port 2123
SAMI 10/2: 000093: Aug 24 2000 23:18:55.963 EDT: GTP-SR:packing pathcb->num_data_socks 0
SAMI 10/2: 000094: Aug 24 2000 23:18:55.963 EDT: GTP-SR:packing pathcb->flags 9
SAMI 10/2: 000095: Aug 24 2000 23:18:55.963 EDT: GTP-SR:packing
pathcb->restart_count_remote 1
SAMI 10/2: 000096: Aug 24 2000 23:18:55.963 EDT: GTP-SR: Different lengths during path
create: allowed: 63, packed: 23
SAMI 10/2: 000097: Aug 24 2000 23:18:55.963 EDT: GTP-SR: Ckpt Message was sucessfully sent
SAMI 10/2: 000098: Aug 24 2000 23:18:55.963 EDT: GTP-SR: Removing element from state-list
Dynamic Sync Ready, final count 1
SAMI 10/2: 000099: Aug 24 2000 23:18:55.963 EDT: GTP-SR: adding element in state-list
Synched, final count 4
SAMI 10/2: 000100: Aug 24 2000 23:18:55.963 EDT: GTP-SR:packing pathcb->gtpv 1
SAMI 10/2: 000101: Aug 24 2000 23:18:55.963 EDT: GTP-SR:Local IP address 166.11.0.11, and
port 2152
SAMI 10/2: 000102: Aug 24 2000 23:18:55.963 EDT: GTP-SR:Remote IP address 10.10.50.3, and
port 2152
SAMI 10/2: 000103: Aug 24 2000 23:18:55.967 EDT: GTP-SR:packing pathcb->num_data_socks 0
SAMI 10/2: 000104: Aug 24 2000 23:18:55.967 EDT: GTP-SR:packing pathcb->flags 8
SAMI 10/2: 000105: Aug 24 2000 23:18:55.967 EDT: GTP-SR:packing
pathcb->restart_count_remote 0
SAMI 10/2: 000106: Aug 24 2000 23:18:55.967 EDT: GTP-SR: Different lengths during path
create: allowed: 63, packed: 23
```

```

SAMI 10/2: 000107: Aug 24 2000 23:18:55.967 EDT: GTP-SR: Ckpt Message was sucessfully sent
SAMI 10/2: 000108: Aug 24 2000 23:18:55.967 EDT: GTP-SR: Removing element from state-list
Dynamic Sync Ready, final count 0
SAMI 10/2: 000109: Aug 24 2000 23:18:55.967 EDT: GTP-SR: adding element in state-list
Synched, final count 5
SAMI 10/2: 000110: Aug 24 2000 23:18:55.967 EDT: GTP-SR: Empty list to sync
SAMI 10/2: 000111: Aug 24 2000 23:18:55.967 EDT: GTP-SR: Empty list to sync
SAMI 10/2: 000112: Aug 24 2000 23:19:01.583 EDT: GTP-SR: Creating red context for category
ID 4 username 1000000000000000 on APN ms-apn
SAMI 10/2: 000113: Aug 24 2000 23:19:01.583 EDT: GTP-SR: Need to allocate redundancy
context
SAMI 10/2: 000114: Aug 24 2000 23:19:01.583 EDT: GTP-SR: adding element in state-list
Initialized, final count 3
SAMI 10/2: 000115: Aug 24 2000 23:19:01.583 EDT: GTP-SR: Removing element from state-list
Initialized, final count 2
SAMI 10/2: 000116: Aug 24 2000 23:19:01.583 EDT: GTP-SR: adding element in state-list
Synched, final count 6
SAMI 10/2: 000117: Aug 24 2000 23:19:01.583 EDT: GPRS:0100000000000050:shdb 0x95000008
created for category 4 (handle 0xD0000001)
SAMI 10/2: 000118: Aug 24 2000 23:19:01.591 EDT: GTP-SR: Don't checkpoint QP4QR Clear for
Create/Update after a Quota Push Resp
SAMI 10/2: 000119: Aug 24 2000 23:19:01.591 EDT: GTP-SR:Context Type PDP, Handler Sync,
Context Event Context Setup, Context Sub Event No Sub Event
SAMI 10/2: 000120: Aug 24 2000 23:19:01.591 EDT: GTP-SR:State of Redundancy Context is
Initialized
SAMI 10/2: 000121: Aug 24 2000 23:19:01.591 EDT: GTP-SR: Event Context Setup, Sub Event No
Sub Event
SAMI 10/2: 000122: Aug 24 2000 23:19:01.591 EDT: GTP-SR: Removing element from state-list
Initialized, final count 1
SAMI 10/2: 000123: Aug 24 2000 23:19:01.591 EDT: GTP-SR: adding element in state-list
Dynamic Sync Ready, final count 1
SAMI 10/2: 000124: Aug 24 2000 23:19:01.591 EDT: GTP-SR: for pdpmcb: 221 bytes to be
packed
SAMI 10/2: 000125: Aug 24 2000 23:19:01.591 EDT: GTP-SR: pdpmcb bitmap = 14346
SAMI 10/2: 000126: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpmcb->user-name
911000000000000000
SAMI 10/2: 000127: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpmcb->msisdn
910100000000000000F000
SAMI 10/2: 000128: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpmcb->selection_mode 0
SAMI 10/2: 000129: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpmcb->remove_staticIP 0
SAMI 10/2: 000130: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpmcb->llcframenum 0
SAMI 10/2: 000131: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpmcb->idle_timeout 3600
SAMI 10/2: 000132: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpmcb->session_timeout 0
SAMI 10/2: 000133: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpmcb->pdpmcb_handle
973078529
SAMI 10/2: 000134: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpmcb->shdb 2080374789
SAMI 10/2: 000135: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing apn_name ms-apn
SAMI 10/2: 000136: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing apnvalue ms-apn
SAMI 10/2: 000137: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpmcb->teid 4194305
SAMI 10/2: 000138: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpmcb->imsi
0100000000000000F0
SAMI 10/2: 000139: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing
pdpmcb->pdpaddr.static_addr_allocated 0
SAMI 10/2: 000140: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing
pdpmcb->pdpaddr.dynamic_addr_allocated 1
SAMI 10/2: 000141: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing
pdpmcb->pdpaddr.dynamic_addr_requested 1
SAMI 10/2: 000142: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing
pdpmcb->pdpaddr.addr_source 3
SAMI 10/2: 000143: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing
pdpmcb->pdpaddr.allocated_prefix_len 16
SAMI 10/2: 000144: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing
pdpmcb->pdpaddr.aggregate_prefix_len 16

```

```

SAMI 10/2: 000145: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing
pdpmb->pdpaddr.pdp_type_org 1
SAMI 10/2: 000146: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing
pdpmb->pdpaddr.pdp_type_num 33
SAMI 10/2: 000147: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpmb->pdpaddr.addrrlen 6
SAMI 10/2: 000148: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpmb-ggsn_addr_si
166.11.0.11
SAMI 10/2: 000149: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpmb-ggsn_addr_data
166.11.0.11
SAMI 10/2: 000150: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpmb->msisdn_len
9nGTP-SR:packing aaa charging profile index -1,
SAMI 10/2: 000151: Aug 24 2000 23:19:01.591 EDT: GTP-SR:pdpmb encoded len_t 0
SAMI 10/2: 000152: Aug 24 2000 23:19:01.591 EDT: GTP-SR: pdpcb bitmap = 0
SAMI 10/2: 000153: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpcb->teid_cntl_remote 1
SAMI 10/2: 000154: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpcb->teid_data_local
4194306
SAMI 10/2: 000155: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpcb->teid_data_remote
1000
SAMI 10/2: 000156: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpcb->tid
0100000000000050
SAMI 10/2: 000157: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing naspi = 5
SAMI 10/2: 000158: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpcb->internal_flags
9175041
SAMI 10/2: 000159: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpcb->mnrflag 0
SAMI 10/2: 000160: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpcb->open_cdr_sent 0
SAMI 10/2: 000161: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpcb->charging_reserved 0
SAMI 10/2: 000162: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpcb->pri 1
SAMI 10/2: 000163: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpcb->fastswitchable 0
SAMI 10/2: 000164: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpcb-sgsn_addr_sig
10.10.50.3
SAMI 10/2: 000165: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpcb-sgsn_addr_data
10.10.50.3
SAMI 10/2: 000166: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpcb->sequence_sig 1
SAMI 10/2: 000167: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpcb->fl_sig_up 0
SAMI 10/2: 000168: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpcb->fl_data1_up 0
SAMI 10/2: 000169: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpcb->fl_sig_down 0
SAMI 10/2: 000170: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpcb->fl_data1_down 0
SAMI 10/2: 000171: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpcb->fl_data2 0
SAMI 10/2: 000172: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpcb->cause 128
SAMI 10/2: 000173: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpcb->restart_count 0
SAMI 10/2: 000174: Aug 24 2000 23:19:01.591 EDT: GTP-SR: packing pdpcb->create_time Aug 24
2000 23:18:56
SAMI 10/2: 000175: Aug 24 2000 23:19:01.591 EDT: GTP-SR: packing pdpcb->last_access_time
Aug 24 2000 23:18:56
SAMI 10/2: 000176: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing
pdpb->gtpv1_qos_req.qos_profile 1521093531
SAMI 10/2: 000177: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing
pdpb->gtpv1_qos_neg.qos_profile 1521093531
SAMI 10/2: 000178: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpcb->teid_cntl_remote 1
SAMI 10/2: 000179: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpcb->teid_data_local
4194306
SAMI 10/2: 000180: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpcb->teid_data_remote
1000
SAMI 10/2: 000181: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpcb->charging_id
471179447
SAMI 10/2: 000182: Aug 24 2000 23:19:01.591 EDT: GTP-SR:packing pdpcb->cdr_recseqnum 0
SAMI 10/2: 000183: Aug 24 2000 23:19:01.591 EDT: GTP-SR: packing of
pdpb->reorder_required FF
SAMI 10/2: 000184: Aug 24 2000 23:19:01.591 EDT: GPRS:0100000000000050:
GTP-SR: Successfully pack PDP
SAMI 10/2: 000185: Aug 24 2000 23:19:01.591 EDT: GTP-SR: rulebase ID MS packed
SAMI 10/2: 000186: Aug 24 2000 23:19:01.591 EDT: GTP-SR: cc_session ccfh 0
failover_supported 1 reqnum 1 packed

```

```

SAMI 10/2: 000187: Aug 24 2000 23:19:01.591 EDT: GTP-SR: cc_session dest_host
ips-clcis1.cisco.com dest_realm cisco.com packed
SAMI 10/2: 000188: Aug 24 2000 23:19:01.591 EDT: GTP-SR: category ID 4 packed:
SAMI 10/2: 000189: Aug 24 2000 23:19:01.591 EDT: GTP-SR: sync data len 164
SAMI 10/2: 000190: Aug 24 2000 23:19:01.591 EDT: GTP-SR: active shdb 0x95000008
SAMI 10/2: 000191: Aug 24 2000 23:19:01.591 EDT: GTP-SR: CSG session ID 27599459844129
SAMI 10/2: 000192: Aug 24 2000 23:19:01.591 EDT: GTP-SR: chrg last svc rec seqnum 0
SAMI 10/2: 000193: Aug 24 2000 23:19:01.591 EDT: GTP-SR: category state AUTHORIZED
SAMI 10/2: 000194: Aug 24 2000 23:19:01.591 EDT: GTP-SR: category state trigger flags
0x3
SAMI 10/2: 000195: Aug 24 2000 23:19:01.591 EDT: GTP-SR: category sub flags 0x0
SAMI 10/2: 000196: Aug 24 2000 23:19:01.591 EDT: GTP-SR: sync flag 0x0
SAMI 10/2: 000197: Aug 24 2000 23:19:01.591 EDT: GTP-SR: quotas included
SAMI 10/2: 000198: Aug 24 2000 23:19:01.591 EDT: GTP-SR: last req timestamp 0
SAMI 10/2: 000199: Aug 24 2000 23:19:01.591 EDT: GTP-SR: last req seqnum 0
SAMI 10/2: 000200: Aug 24 2000 23:19:01.595 EDT: GTP-SR: Ckpt Message was sucessfully sent
SAMI 10/2: 000201: Aug 24 2000 23:19:01.595 EDT: GTP-SR: Removing element from state-list
Dynamic Sync Ready, final count 0
SAMI 10/2: 000202: Aug 24 2000 23:19:01.595 EDT: GTP-SR: adding element in state-list
Synched, final count 7
SAMI 10/2: 000203: Aug 24 2000 23:19:01.595 EDT: GTP-SR: Empty list to sync
SAMI 10/2: 000204: Aug 24 2000 23:19:03.939 EDT: GTP-SR:Context Type PDP, Handler Sync,
Context Event Context Setup, Context Sub Event No Sub Event
SAMI 10/2: 000205: Aug 24 2000 23:19:03.939 EDT: GTP-SR:State of Redundancy Context is
Synched
SAMI 10/2: 000206: Aug 24 2000 23:19:03.939 EDT: GTP-SR: Event Context Setup, Sub Event No
Sub Event
SAMI 10/2: 000207: Aug 24 2000 23:19:04.463 EDT: GTP-SR: Checkpoint SGSN init deletion via
a category before final MCB deletion
SAMI 10/2: 000208: Aug 24 2000 23:19:04.463 EDT: GTP-SR:Context Type Category, Handler
Update, Context Event Category update, Context Sub Event No Sub Event
SAMI 10/2: 000209: Aug 24 2000 23:19:04.463 EDT: GTP-SR:State of Redundancy Context is
Synched
SAMI 10/2: 000210: Aug 24 2000 23:19:04.463 EDT: GTP-SR: Event Category update, Sub Event
No Sub Event
SAMI 10/2: 000211: Aug 24 2000 23:19:04.463 EDT: GTP-SR: MCB internal flags 0x5802 packed
SAMI 10/2: 000212: Aug 24 2000 23:19:04.463 EDT: GTP-SR: cc_session reqnum 1 packed
SAMI 10/2: 000213: Aug 24 2000 23:19:04.463 EDT: GTP-SR: category ID 4 packed:
SAMI 10/2: 000214: Aug 24 2000 23:19:04.463 EDT: GTP-SR: sync data len 52
SAMI 10/2: 000215: Aug 24 2000 23:19:04.463 EDT: GTP-SR: active shdb 0x95000008
SAMI 10/2: 000216: Aug 24 2000 23:19:04.463 EDT: GTP-SR: CSG session ID 27599459844129
SAMI 10/2: 000217: Aug 24 2000 23:19:04.463 EDT: GTP-SR: chrg last svc rec seqnum 0
SAMI 10/2: 000218: Aug 24 2000 23:19:04.463 EDT: GTP-SR: category state
PENDING_SERVICE_STOP
SAMI 10/2: 000219: Aug 24 2000 23:19:04.463 EDT: GTP-SR: category state trigger flags
0x3
SAMI 10/2: 000220: Aug 24 2000 23:19:04.463 EDT: GTP-SR: category sub flags 0x0
SAMI 10/2: 000221: Aug 24 2000 23:19:04.463 EDT: GTP-SR: sync flag 0xA
SAMI 10/2: 000222: Aug 24 2000 23:19:04.463 EDT: GTP-SR: quotas not included
SAMI 10/2: 000223: Aug 24 2000 23:19:04.463 EDT: GTP-SR: last req timestamp 0
SAMI 10/2: 000224: Aug 24 2000 23:19:04.463 EDT: GTP-SR: last req seqnum 0
SAMI 10/2: 000225: Aug 24 2000 23:19:04.463 EDT: GTP-SR: Different lengths during category
sync: allowed 188, packed 56
SAMI 10/2: 000226: Aug 24 2000 23:19:04.463 EDT: GTP-SR: Ckpt Message was sucessfully sent
SAMI 10/2: 000227: Aug 24 2000 23:19:04.467 EDT: GTP-SR: Checkpoint final MCB deletion
after sending a CCR Final
SAMI 10/2: 000228: Aug 24 2000 23:19:04.467 EDT: GTP-SR:Context Type PDP, Handler Delete,
Context Event Context Remove, Context Sub Event No Sub Event
SAMI 10/2: 000229: Aug 24 2000 23:19:04.467 EDT: GTP-SR:State of Redundancy Context is
Synched
SAMI 10/2: 000230: Aug 24 2000 23:19:04.467 EDT: GTP-SR: Event Context Remove, Sub Event
No Sub Event
SAMI 10/2: 000231: Aug 24 2000 23:19:04.467 EDT: GTP-SR: Checkpoint final MCB deletion

```

```

SAMI 10/2: 000232: Aug 24 2000 23:19:04.467 EDT: GTP-SR:Context Type PDP, Handler Delete,
Context Event Context Remove, Context Sub Event No Sub Event
SAMI 10/2: 000233: Aug 24 2000 23:19:04.467 EDT: GTP-SR:State of Redundancy Context is
Synched
SAMI 10/2: 000234: Aug 24 2000 23:19:04.467 EDT: GTP-SR: Event Context Remove, Sub Event
No Sub Event
SAMI 10/2: 000235: Aug 24 2000 23:19:04.467 EDT: GTP-SR: Different lengths during PDP
delete: allowed: 40, packed: 0
SAMI 10/2: 000236: Aug 24 2000 23:19:04.467 EDT: GTP-SR: Ckpt Message was sucessfully sent
SAMI 10/2: 000237: Aug 24 2000 23:19:04.467 EDT: GTP-SR: Removing element from state-list
Synched, final count 6
SAMI 10/2: 000238: Aug 24 2000 23:19:04.467 EDT: GTP-SR: adding element in state-list
Delete, final count 1
SAMI 10/2: 000239: Aug 24 2000 23:19:04.467 EDT: GTP-SR: Removing element from state-list
Delete, final count 0
SAMI 10/2: 000240: Aug 24 2000 23:19:04.467 EDT: GTP-SR: No redundancy context for sending
a down event to standby
SAMI 10/2: 000241: Aug 24 2000 23:19:04.471 EDT: GTP-SR: Removing element from state-list
Synched, final count 5
Router-a#
Router-a#

```

Standby GGSN:

```

Router-b#debug gprs redundancy
GPRS CF packets debugging is on
GPRS CF events debugging is on
GPRS CF errors debugging is on
GPRS CF debug debugging is on
Router-b#sh gprs redun
GPRS redundancy is enabled and Unit-Status is Standby

```

Redundancy Transport Infrastructure status

```

Redundancy Infrastructure state:          STANDBY HOT
Peer Redundancy Infrastructure state:    ACTIVE

```

```

GGSN Redundancy system up since:        21:29:21 EDT Aug 19 2000
Time of last switchover:                 never
Total Number of Switchovers:             4

```

GPRS Redundancy Statistics

```
Last cleared: never
```

CheckPointed-From-Active Statistics

```

Total Number of Messages:                3
Number of Context Setup messages:         0
Number of Context Modify messages:        0
Number of Context Remove messages:        0
Number of Path Setup messages:            0
Number of Path Modify messages:           0
Number of Path Remove messages:           0
Number of CGF Ready messages:             1
Number of CGF Modify messages:            0
Number of CGF Remove messages:           0
Number of Internal State messages:        1

```

```
Router-b#
```

```

SAMI 10/2: 000065: Jun 1 2006 18:28:06.591 EDT: GTP-SR: Redundancy RF Event Received is
Create Redundancy Context
SAMI 10/2: 000066: Jun 1 2006 18:28:06.591 EDT: GTP-SR: Redundancy Event is Path Setup
SAMI 10/2: 000067: Jun 1 2006 18:28:06.591 EDT: GTP-SR: Need to allocate redundancy
context

```

```

SAMI 10/2: 000068: Jun  1 2006 18:28:06.591 EDT: GTP-SR: adding element in state-list
Initialized, final count 4
SAMI 10/2: 000069: Jun  1 2006 18:28:06.591 EDT: GTP-SR Packet Dump: Len for dump:
org_len=63, len=63
SAMI 10/2: 000070: Jun  1 2006 18:28:06.591 EDT:  1  0  0  0  0  0  0  0  9  1  A6 B  0  B
8  4B
SAMI 10/2: 000071: Jun  1 2006 18:28:06.591 EDT:  A  A  32 3  8  4B 1  0  0  0  0  0  0  0
0  0
SAMI 10/2: 000072: Jun  1 2006 18:28:06.591 EDT:  0  0  0  0  0  0  0  0  0  0  0  0  0  0
0  0
SAMI 10/2: 000073: Jun  1 2006 18:28:06.595 EDT:  0  0  0  0  0  0  0  0  0  0  0  0  0  0
0
SAMI 10/2: 000074: Jun  1 2006 18:28:06.595 EDT: GTP-SR: un-packing u_path->gtpv 1
SAMI 10/2: 000075: Jun  1 2006 18:28:06.595 EDT: GTP-SR: Local IP address 166.11.0.11, and
port 2123
SAMI 10/2: 000076: Jun  1 2006 18:28:06.595 EDT: GTP-SR: Remote IP address 10.10.50.3, and
port 2123
SAMI 10/2: 000077: Jun  1 2006 18:28:06.595 EDT: GTP-SR: un-packing u_path->num_data_socks
0
SAMI 10/2: 000078: Jun  1 2006 18:28:06.595 EDT: GTP-SR: un-packing u_path->flags 9
SAMI 10/2: 000079: Jun  1 2006 18:28:06.595 EDT: GTP-SR: un-packing restart_count_remote 1
SAMI 10/2: 000080: Jun  1 2006 18:28:06.595 EDT: GTP-SR:Context Type  Path, Handler Sync,
Context Event Path Setup, Context Sub Event No Sub Event
SAMI 10/2: 000081: Jun  1 2006 18:28:06.595 EDT: GTP-SR:State of Redundancy Context is
Initialized
SAMI 10/2: 000082: Jun  1 2006 18:28:06.595 EDT: GTP-SR: Event Path Setup, Sub Event No
Sub Event
SAMI 10/2: 000083: Jun  1 2006 18:28:06.595 EDT: GTP-SR: Removing element from state-list
Initialized, final count 3
SAMI 10/2: 000084: Jun  1 2006 18:28:06.595 EDT: GTP-SR: adding element in state-list Bulk
Synch Ready, final count 2
SAMI 10/2: 000085: Jun  1 2006 18:28:06.595 EDT: GTP-SR: Redundancy RF Event Received is
Create Redundancy Context
SAMI 10/2: 000086: Jun  1 2006 18:28:06.595 EDT: GTP-SR: Redundancy Event is Path Setup
SAMI 10/2: 000087: Jun  1 2006 18:28:06.595 EDT: GTP-SR: Need to allocate redundancy
context
SAMI 10/2: 000088: Jun  1 2006 18:28:06.595 EDT: GTP-SR: adding element in state-list
Initialized, final count 4
SAMI 10/2: 000089: Jun  1 2006 18:28:06.595 EDT: GTP-SR Packet Dump: Len for dump:
org_len=63, len=63
SAMI 10/2: 000090: Jun  1 2006 18:28:06.595 EDT:  1  0  0  0  0  0  0  0  8  1  A6 B  0  B
8  68
SAMI 10/2: 000091: Jun  1 2006 18:28:06.595 EDT:  A  A  32 3  8  68 0  0  0  0  0  0  0  0
0  0
SAMI 10/2: 000092: Jun  1 2006 18:28:06.595 EDT:  0  0  0  0  0  0  0  0  0  0  0  0  0  0
0  0
SAMI 10/2: 000093: Jun  1 2006 18:28:06.595 EDT:  0  0  0  0  0  0  0  0  0  0  0  0  0  0
0
SAMI 10/2: 000094: Jun  1 2006 18:28:06.595 EDT: GTP-SR: un-packing u_path->gtpv 1
SAMI 10/2: 000095: Jun  1 2006 18:28:06.595 EDT: GTP-SR: Local IP address 166.11.0.11, and
port 2152
SAMI 10/2: 000096: Jun  1 2006 18:28:06.595 EDT: GTP-SR: Remote IP address 10.10.50.3, and
port 2152
SAMI 10/2: 000097: Jun  1 2006 18:28:06.595 EDT: GTP-SR: un-packing u_path->num_data_socks
0
SAMI 10/2: 000098: Jun  1 2006 18:28:06.595 EDT: GTP-SR: un-packing u_path->flags 8
SAMI 10/2: 000099: Jun  1 2006 18:28:06.595 EDT: GTP-SR: un-packing restart_count_remote 0
SAMI 10/2: 000100: Jun  1 2006 18:28:06.595 EDT: GTP-SR:Context Type  Path, Handler Sync,
Context Event Path Setup, Context Sub Event No Sub Event
SAMI 10/2: 000101: Jun  1 2006 18:28:06.595 EDT: GTP-SR:State of Redundancy Context is
Initialized
SAMI 10/2: 000102: Jun  1 2006 18:28:06.595 EDT: GTP-SR: Event Path Setup, Sub Event No
Sub Event

```

```

SAMI 10/2: 000103: Jun  1 2006 18:28:06.595 EDT: GTP-SR: Removing element from state-list
Initialized, final count 3
SAMI 10/2: 000104: Jun  1 2006 18:28:06.595 EDT: GTP-SR: adding element in state-list Bulk
Synch Ready, final count 3
SAMI 10/2: 000105: Jun  1 2006 18:28:12.223 EDT: GTP-SR: Redundancy RF Event Received is
Create Redundancy Context
SAMI 10/2: 000106: Jun  1 2006 18:28:12.223 EDT: GTP-SR: Redundancy Event is Context Setup
SAMI 10/2: 000107: Jun  1 2006 18:28:12.223 EDT: GTP-SR: Need to allocate redundancy
context
SAMI 10/2: 000108: Jun  1 2006 18:28:12.223 EDT: GTP-SR: adding element in state-list
Initialized, final count 4
SAMI 10/2: 000109: Jun  1 2006 18:28:12.223 EDT: GTP-SR Packet Dump: Len for dump:
org_len=755, len=128
SAMI 10/2: 000110: Jun  1 2006 18:28:12.223 EDT:  1  1  39 31 31 30 30 30 30 30 30 30 30
30 30 30
SAMI 10/2: 000111: Jun  1 2006 18:28:12.223 EDT:  30 30 30 0  0  0  0  91 1  0  0  0  0  0
0  F0
SAMI 10/2: 000112: Jun  1 2006 18:28:12.223 EDT:  0  0  0  0  0  0  E 10 0  0  0  0  0  0
0  0
SAMI 10/2: 000113: Jun  1 2006 18:28:12.223 EDT:  C0 23 1  8  5  63 69 73 63 6F 31 31 31
63 69 73
SAMI 10/2: 000114: Jun  1 2006 18:28:12.227 EDT:  63 6F 0  7C 0  0  5  0  0  8  0  0  0  0
0  0
SAMI 10/2: 000115: Jun  1 2006 18:28:12.227 EDT:  0  0  0  40 0  1  1  0  0  0  0  0  0  0
F0 B  1
SAMI 10/2: 000116: Jun  1 2006 18:28:12.227 EDT:  0  1  0  0  0  0  0  0  0  0  0  0  0  0
0  0
SAMI 10/2: 000117: Jun  1 2006 18:28:12.227 EDT:  0  0  0  1  1  0  0  0  3  10 10 1  21 0
6  0
SAMI 10/2: 000118: Jun  1 2006 18:28:12.227 EDT:  ...

SAMI 10/2: 000119: Jun  1 2006 18:28:12.231 EDT: GTP-SR:pdpmcb handle for pdpmcb
(0x24AA0CCC) is (0x41000001)
SAMI 10/2: 000120: Jun  1 2006 18:28:12.231 EDT: GTP-SR: un-packing # of PDPs packed = 1
SAMI 10/2: 000121: Jun  1 2006 18:28:12.231 EDT: GTP-SR: un-packing pdpmcb->user-name
911000000000000000
SAMI 10/2: 000122: Jun  1 2006 18:28:12.231 EDT: GTP-SR: un-packing pdpmcb->msisdn
910100000000000000F000
SAMI 10/2: 000123: Jun  1 2006 18:28:12.235 EDT: GTP-SR: un-packing pdpmcb->selection_mode
0
SAMI 10/2: 000124: Jun  1 2006 18:28:12.235 EDT: GTP-SR: un-packing
pdpmcb->remove_staticIP 0
SAMI 10/2: 000125: Jun  1 2006 18:28:12.235 EDT: GTP-SR: un-packing pdpmcb->llcframenum 0
SAMI 10/2: 000126: Jun  1 2006 18:28:12.235 EDT: GTP-SR: un-packing pdpmcb->idle_timeout
3600
SAMI 10/2: 000127: Jun  1 2006 18:28:12.235 EDT: GTP-SR: un-packing
pdpmcb->session_timeout 0
SAMI 10/2: 000128: Jun  1 2006 18:28:12.235 EDT: GTP-SR: pdpmcb bitmap = 30730
SAMI 10/2: 000129: Jun  1 2006 18:28:12.235 EDT: GTP-SR: apn name is ms-apn
SAMI 10/2: 000130: Jun  1 2006 18:28:12.235 EDT: GTP-SR: packing pdpmcb->teid 4194305
SAMI 10/2: 000131: Jun  1 2006 18:28:12.235 EDT: GTP-SR: un-packing pdpmcb->imsi
01000000000000F0
SAMI 10/2: 000132: Jun  1 2006 18:28:12.235 EDT: GTP-SR: un-packing
pdpmcb->pdpaddr.pdp_addr 11.1.0.1
SAMI 10/2: 000133: Jun  1 2006 18:28:12.235 EDT: GTP-SR: un-packing
pdpmcb->pdpaddr.static_addr_allocated 0
SAMI 10/2: 000134: Jun  1 2006 18:28:12.235 EDT: GTP-SR: un-packing
pdpmcb->pdpaddr.dynamic_addr_allocated 1
SAMI 10/2: 000135: Jun  1 2006 18:28:12.235 EDT: GTP-SR: un-packing
pdpmcb->pdpaddr.dynamic_addr_requested 1
SAMI 10/2: 000136: Jun  1 2006 18:28:12.235 EDT: GTP-SR: un-packing
pdpmcb->pdpaddr.addr_source 3
SAMI 10/2: 000137: Jun  1 2006 18:28:12.235 EDT: GTP-SR: un-packing
pdpmcb->pdpaddr.allocated_prefix_len 16

```

```

SAMI 10/2: 000138: Jun  1 2006 18:28:12.235 EDT: GTP-SR: un-packing
pdpmb->pdpaddr.aggregate_prefix_len 16
SAMI 10/2: 000139: Jun  1 2006 18:28:12.235 EDT: GTP-SR: un-packing
pdpmb->pdpaddr.pdp_type_org 1
SAMI 10/2: 000140: Jun  1 2006 18:28:12.235 EDT: GTP-SR: un-packing
pdpmb->pdpaddr.pdp_type_num 33
SAMI 10/2: 000141: Jun  1 2006 18:28:12.235 EDT: GTP-SR: un-packing
pdpmb->pdpaddr.addr_len 6
SAMI 10/2: 000142: Jun  1 2006 18:28:12.235 EDT: GTP-SR: un-packing
pdpmb->pdpaddr.dhcp_addr 0.0.0.0
SAMI 10/2: 000143: Jun  1 2006 18:28:12.235 EDT: GTP-SR: un-packing pdpmb-ggsn_addr_si
166.11.0.11
SAMI 10/2: 000144: Jun  1 2006 18:28:12.235 EDT: GTP-SR: un-packing pdpmb-ggsn_addr_data
166.11.0.11
SAMI 10/2: 000145: Jun  1 2006 18:28:12.235 EDT: GTP-SR: un-packing pdpmb->msisdn_len 9
SAMI 10/2: 000146: Jun  1 2006 18:28:12.247 EDT: GTP-SR: Got teid=4194305, as requested
SAMI 10/2: 000147: Jun  1 2006 18:28:12.247 EDT: GTP-SR: un-packing
pdpb->gtpv1_qos_req_qos_profile 1521093531
SAMI 10/2: 000148: Jun  1 2006 18:28:12.247 EDT: GTP-SR: un-packing
pdpb->gtpv1_qos_neg_qos_profile 1521093531
SAMI 10/2: 000149: Jun  1 2006 18:28:12.247 EDT: GTP-SR: un-packing pdpb bitmap = 0
SAMI 10/2: 000150: Jun  1 2006 18:28:12.247 EDT: GTP-SR: un-packing
pdpb->tid0100000000000050
SAMI 10/2: 000151: Jun  1 2006 18:28:12.251 EDT: GTP-SR: un-packing nsapi = 5
SAMI 10/2: 000152: Jun  1 2006 18:28:12.251 EDT: GTP-SR: un-packing pdpb->internal_flags
9175041
SAMI 10/2: 000153: Jun  1 2006 18:28:12.251 EDT: GTP-SR: un-packing pdpb->mnrgflag 0
SAMI 10/2: 000154: Jun  1 2006 18:28:12.251 EDT: GTP-SR: un-packing pdpb->open_cdr_sent
0
SAMI 10/2: 000155: Jun  1 2006 18:28:12.251 EDT: GTP-SR: un-packing
pdpb->charging_reserved 0
SAMI 10/2: 000156: Jun  1 2006 18:28:12.251 EDT: GTP-SR: un-packing pdpb->pri 1
SAMI 10/2: 000157: Jun  1 2006 18:28:12.251 EDT: GTP-SR: un-packing pdpb->fastswitchable
0
SAMI 10/2: 000158: Jun  1 2006 18:28:12.251 EDT: GTP-SR: un-packing pdpb-sgsn_addr_sig
10.10.50.3
SAMI 10/2: 000159: Jun  1 2006 18:28:12.251 EDT: GTP-SR: un-packing pdpb-sgsn_addr_data
10.10.50.3
SAMI 10/2: 000160: Jun  1 2006 18:28:12.251 EDT: GTP-SR: un-packing of pdpb->sequence_sig
1
SAMI 10/2: 000161: Jun  1 2006 18:28:12.251 EDT: GTP-SR: un-packing of pdpb->fl_sig_up 0
SAMI 10/2: 000162: Jun  1 2006 18:28:12.251 EDT: GTP-SR: un-packing of pdpb->fl_data1_up
0
SAMI 10/2: 000163: Jun  1 2006 18:28:12.251 EDT: GTP-SR: un-packing of pdpb->fl_sig_down
0
SAMI 10/2: 000164: Jun  1 2006 18:28:12.251 EDT: GTP-SR: un-packing of
pdpb->fl_data1_down 0
SAMI 10/2: 000165: Jun  1 2006 18:28:12.251 EDT: GTP-SR: un-packing of pdpb->fl_data2 0
SAMI 10/2: 000166: Jun  1 2006 18:28:12.251 EDT: GTP-SR: un-packing of pdpb->cause 128
SAMI 10/2: 000167: Jun  1 2006 18:28:12.251 EDT: GTP-SR: un-packing of
pdpb->restart_count 0
SAMI 10/2: 000168: Jun  1 2006 18:28:12.251 EDT: GTP-SR: un-packing of pdpb->create_time
Apr 13 2006 01:25:25
SAMI 10/2: 000169: Jun  1 2006 18:28:12.251 EDT: GTP-SR: un-packing of
pdpb->last_access_time Apr 13 2006 01:25:25
SAMI 10/2: 000170: Jun  1 2006 18:28:12.251 EDT: GTP-SR: unpacking pdpb->teid_cntl_remote
1
SAMI 10/2: 000171: Jun  1 2006 18:28:12.251 EDT: GTP-SR: unpacking pdpb->teid_data_local
4194306
SAMI 10/2: 000172: Jun  1 2006 18:28:12.251 EDT: GTP-SR: unpacking pdpb->teid_data_remote
1000
SAMI 10/2: 000173: Jun  1 2006 18:28:12.251 EDT: GTP-SR: unpacking pdpb->charging_id
471179447
SAMI 10/2: 000174: Jun  1 2006 18:28:12.251 EDT: GTP-SR: unpacking pdpb->cdr_recseqnum 0

```

```

SAMI 10/2: 000175: Jun  1 2006 18:28:12.251 EDT: GTP-SR: un-packing of
pdpcb->reorder_required FF
SAMI 10/2: 000176: Jun  1 2006 18:28:12.251 EDT: GTP-SR: We wanted teid 4194306, and got
4194306
SAMI 10/2: 000177: Jun  1 2006 18:28:12.251 EDT: GTP-SR: Got teid 4194306 as requested
SAMI 10/2: 000178: Jun  1 2006 18:28:12.251 EDT: pdp_create_by_tid on standby:tid
100000050, pdp 24A90B24
SAMI 10/2: 000179: Jun  1 2006 18:28:12.251 EDT: GPRS:0100000000000050:
GTP-SR: Successfully unpack PDP
SAMI 10/2: 000180: Jun  1 2006 18:28:12.251 EDT: GTP-SR: rulebase ID MS unpacked
SAMI 10/2: 000181: Jun  1 2006 18:28:12.251 EDT: GTP-SR: cc_session ccfh 0
failover_supported 1 regnum 1 packed
SAMI 10/2: 000182: Jun  1 2006 18:28:12.251 EDT: GTP-SR: new cc_session dest_host
ips-clcis1.cisco.com unpacked
SAMI 10/2: 000183: Jun  1 2006 18:28:12.251 EDT: GTP-SR: new cc_session dest_realm
cisco.com unpacked
SAMI 10/2: 000184: Jun  1 2006 18:28:12.251 EDT: GTP-SR: Unpacking 1 categories
SAMI 10/2: 000185: Jun  1 2006 18:28:12.251 EDT: GTP-SR: Unpacking category of ID 4
SAMI 10/2: 000186: Jun  1 2006 18:28:12.255 EDT: GTP-SR: Creating red context for category
ID 4 username 1000000000000000 on APN ms-apn
SAMI 10/2: 000187: Jun  1 2006 18:28:12.255 EDT: GTP-SR: Need to allocate redundancy
context
SAMI 10/2: 000188: Jun  1 2006 18:28:12.255 EDT: GTP-SR: adding element in state-list
Initialized, final count 5
SAMI 10/2: 000189: Jun  1 2006 18:28:12.255 EDT: GTP-SR: Removing element from state-list
Initialized, final count 4
SAMI 10/2: 000190: Jun  1 2006 18:28:12.255 EDT: GTP-SR: adding element in state-list
Synched, final count 1
SAMI 10/2: 000191: Jun  1 2006 18:28:12.255 EDT: GPRS:0100000000000050:shdb 0xC6000008
created for category 4 (handle 0xDE000001)
SAMI 10/2: 000192: Jun  1 2006 18:28:12.255 EDT: GTP-SR: red context installed for the new
category (shdb: active 0x95000008, standby 0xC6000008)
SAMI 10/2: 000193: Jun  1 2006 18:28:12.255 EDT: GTP-SR: new category ID 4 unpacked:
SAMI 10/2: 000194: Jun  1 2006 18:28:12.255 EDT: GTP-SR:      sync data len 164
SAMI 10/2: 000195: Jun  1 2006 18:28:12.255 EDT: GTP-SR:      active shdb 0x95000008
SAMI 10/2: 000196: Jun  1 2006 18:28:12.255 EDT: GTP-SR:      CSG session ID 27599459844129
SAMI 10/2: 000197: Jun  1 2006 18:28:12.255 EDT: GTP-SR:      chrg last svc rec seqnum 0
SAMI 10/2: 000198: Jun  1 2006 18:28:12.255 EDT: GTP-SR:      category state AUTHORIZED
SAMI 10/2: 000199: Jun  1 2006 18:28:12.255 EDT: GTP-SR:      category state trigger flags
0x3
SAMI 10/2: 000200: Jun  1 2006 18:28:12.255 EDT: GTP-SR:      category sub flags 0x0
SAMI 10/2: 000201: Jun  1 2006 18:28:12.255 EDT: GTP-SR:      sync flag 0x0
SAMI 10/2: 000202: Jun  1 2006 18:28:12.255 EDT: GTP-SR:      quotas included
SAMI 10/2: 000203: Jun  1 2006 18:28:12.255 EDT: GTP-SR:      last req timestamp 0
SAMI 10/2: 000204: Jun  1 2006 18:28:12.255 EDT: GTP-SR:      last req seqnum 0
SAMI 10/2: 000205: Jun  1 2006 18:28:12.255 EDT: GTP-SR: address received from active with
radius source is

SAMI 10/2: 000206: Jun  1 2006 18:28:12.259 EDT: GTP-SR:Context Type  PDP, Handler Sync,
Context Event Context Setup, Context Sub Event No Sub Event
SAMI 10/2: 000207: Jun  1 2006 18:28:12.259 EDT: GTP-SR:State of Redundancy Context is
Initialized
SAMI 10/2: 000208: Jun  1 2006 18:28:12.259 EDT: GTP-SR: Event Context Setup, Sub Event No
Sub Event
SAMI 10/2: 000209: Jun  1 2006 18:28:12.259 EDT: GTP-SR: Removing element from state-list
Initialized, final count 3
SAMI 10/2: 000210: Jun  1 2006 18:28:12.259 EDT: GTP-SR: adding element in state-list Bulk
Synch Ready, final count 4
SAMI 10/2: 000211: Jun  1 2006 18:28:15.091 EDT: GTP-SR: Redundancy RF Event Received is
Update Redundancy Context
SAMI 10/2: 000212: Jun  1 2006 18:28:15.091 EDT: GTP-SR: Redundancy Event is Category
update
SAMI 10/2: 000213: Jun  1 2006 18:28:15.091 EDT: GTP-SR: red context found (active shdb
0x95000008, standby shdb 0xC6000008)

```

```

SAMI 10/2: 000214: Jun  1 2006 18:28:15.091 EDT: GTP-SR Packet Dump: Len for dump:
org_len=188, len=128
SAMI 10/2: 000215: Jun  1 2006 18:28:15.091 EDT:  7C 0  0  5  0  0  58 2  0  0  0  1  0
34 34 0
SAMI 10/2: 000216: Jun  1 2006 18:28:15.091 EDT:  0  0  0  0  0  0  0  0  0  0  0  0  0
0  95
SAMI 10/2: 000217: Jun  1 2006 18:28:15.091 EDT:  0  0  8  0  0  19 1A 0  0  0  21 0  0  0
0  0
SAMI 10/2: 000218: Jun  1 2006 18:28:15.091 EDT:  0  0  9  0  0  0  3  0  0  A  0  0  0  0
0  0
SAMI 10/2: 000219: Jun  1 2006 18:28:15.091 EDT:  0  0  0  0  0  0  0  0  0  0  0  0  0  0
0  0
SAMI 10/2: 000220: Jun  1 2006 18:28:15.095 EDT:  0  0  0  0  0  0  0  0  0  0  0  0  0  0
0  0
SAMI 10/2: 000221: Jun  1 2006 18:28:15.095 EDT:  0  0  0  0  0  0  0  0  0  0  0  0  0  0
0  0
SAMI 10/2: 000222: Jun  1 2006 18:28:15.095 EDT:  0  0  0  0  0  0  0  0  0  0  0  0  0  0
0  0
SAMI 10/2: 000223: Jun  1 2006 18:28:15.095 EDT:  ...

SAMI 10/2: 000224: Jun  1 2006 18:28:15.095 EDT: GTP-SR: category found with handle
0xDE000001 shdbs: active 0x95000008 standby 0xC6000008 (MCB shdbs: active 0x7C000005,
standby 0xC6000008)
SAMI 10/2: 000225: Jun  1 2006 18:28:15.095 EDT: GTP-SR: MCB internal flags 0x5802
unpacked
SAMI 10/2: 000226: Jun  1 2006 18:28:15.095 EDT: GTP-SR: cc_session regnum 1 unpacked and
installed
SAMI 10/2: 000227: Jun  1 2006 18:28:15.095 EDT: GTP-SR: Unpacking category of ID 4
SAMI 10/2: 000228: Jun  1 2006 18:28:15.095 EDT: GTP-SR: sync obj created in prep for MCB
deletion
SAMI 10/2: 000229: Jun  1 2006 18:28:15.095 EDT: GTP-SR: category ID 4 unpacked:
SAMI 10/2: 000230: Jun  1 2006 18:28:15.095 EDT: GTP-SR: sync data len 52
SAMI 10/2: 000231: Jun  1 2006 18:28:15.095 EDT: GTP-SR: active shdb 0x95000008
SAMI 10/2: 000232: Jun  1 2006 18:28:15.095 EDT: GTP-SR: CSG session ID 27599459844129
SAMI 10/2: 000233: Jun  1 2006 18:28:15.095 EDT: GTP-SR: chrg last svc rec seqnum 0
SAMI 10/2: 000234: Jun  1 2006 18:28:15.095 EDT: GTP-SR: category state
PENDING_SERVICE_STOP
SAMI 10/2: 000235: Jun  1 2006 18:28:15.095 EDT: GTP-SR: category state trigger flags
0x3
SAMI 10/2: 000236: Jun  1 2006 18:28:15.095 EDT: GTP-SR: category sub flags 0x0
SAMI 10/2: 000237: Jun  1 2006 18:28:15.095 EDT: GTP-SR: sync flag 0xA
SAMI 10/2: 000238: Jun  1 2006 18:28:15.095 EDT: GTP-SR: quotas not included
SAMI 10/2: 000239: Jun  1 2006 18:28:15.095 EDT: GTP-SR: last req timestamp 0
SAMI 10/2: 000240: Jun  1 2006 18:28:15.095 EDT: GTP-SR: last req seqnum 0
SAMI 10/2: 000241: Jun  1 2006 18:28:15.095 EDT: GTP-SR: Redundancy RF Event Received is
Redundancy Context Delete
SAMI 10/2: 000242: Jun  1 2006 18:28:15.095 EDT: GTP-SR: Redundancy Event is Context
Remove
SAMI 10/2: 000243: Jun  1 2006 18:28:15.095 EDT: GTP-SR Packet Dump: Len for dump:
org_len=40, len=40
SAMI 10/2: 000244: Jun  1 2006 18:28:15.095 EDT:  0  0  0  0  0  0  0  0  0  0  0  0  0  0
0  0
SAMI 10/2: 000245: Jun  1 2006 18:28:15.095 EDT:  0  0  0  0  0  0  0  0  0  0  0  0  0  0
0  0
SAMI 10/2: 000246: Jun  1 2006 18:28:15.095 EDT:  0  0  0  0  0  0  0  0  0
SAMI 10/2: 000247: Jun  1 2006 18:28:15.095 EDT: GPRS:GTP-SR: Deleting v1 MCB on the
standby
SAMI 10/2: 000248: Jun  1 2006 18:28:15.095 EDT: GPRS:0100000000000050:GTP-SR: Deleting v1
PDP on the standby
SAMI 10/2: 000249: Jun  1 2006 18:28:15.095 EDT: GTP-SR: MCB deletion sync obj deleted
SAMI 10/2: 000250: Jun  1 2006 18:28:15.095 EDT: GTP-SR: Removing element from state-list
Synched, final count 0
SAMI 10/2: 000251: Jun  1 2006 18:28:15.095 EDT: GTP-SR: Removing element from state-list
Bulk Synch Ready, final count 3

```

```

SAMI 10/2: 000252: Jun  1 2006 18:29:15.103 EDT: GTP-SR: Redundancy RF Event Received is
Redundancy Context Delete
SAMI 10/2: 000253: Jun  1 2006 18:29:15.103 EDT: GTP-SR: Redundancy Event is Path Remove
SAMI 10/2: 000254: Jun  1 2006 18:29:15.103 EDT: GTP-SR:Context Type  Path, Handler
Delete, Context Event Path Remove, Context Sub Event No Sub Event
SAMI 10/2: 000255: Jun  1 2006 18:29:15.103 EDT: GTP-SR:State of Redundancy Context is
Bulk Synch Ready
SAMI 10/2: 000256: Jun  1 2006 18:29:15.103 EDT: GTP-SR: Event Path Remove, Sub Event No
Sub Event
SAMI 10/2: 000257: Jun  1 2006 18:29:15.103 EDT: GTP-SR: Removing element from state-list
Bulk Synch Ready, final count 2
SAMI 10/2: 000258: Jun  1 2006 18:29:15.103 EDT: GTP-SR: Redundancy RF Event Received is
Redundancy Context Delete
SAMI 10/2: 000259: Jun  1 2006 18:29:15.103 EDT: GTP-SR: Redundancy Event is Path Remove
SAMI 10/2: 000260: Jun  1 2006 18:29:15.103 EDT: GTP-SR:Context Type  Path, Handler
Delete, Context Event Path Remove, Context Sub Event No Sub Event
SAMI 10/2: 000261: Jun  1 2006 18:29:15.103 EDT: GTP-SR:State of Redundancy Context is
Bulk Synch Ready
SAMI 10/2: 000262: Jun  1 2006 18:29:15.103 EDT: GTP-SR: Event Path Remove, Sub Event No
Sub Event
SAMI 10/2: 000263: Jun  1 2006 18:29:15.103 EDT: GTP-SR: Removing element from state-list
Bulk Synch Ready, final count 1

```

Related Commands

Command	Description
clear gprs redundancy statistics	Clears statistics related to GTP-SR.
gprs redundancy	Enables GTP-SR on a GGSN.
gprs redundancy charging sync-window cdr rec-seqnum	Configures the window size used to determine when the CDR record sequence number must be synchronized to the Standby GGSN.
gprs redundancy charging sync-window gtp seqnum	Configures the window size used to determine when the GTP' sequence number must be synchronized to the Standby GGSN.
show gprs redundancy	Displays statistics related to GTP-SR.

debug gprs verbose

To set the debug verbosity level, use the **debug gprs verbose** command in privileged EXEC command.

debug gprs verbose *level*

Syntax Description	<i>level</i>	Level of messages to display. Valid values are: • 1—Displays critical debug messages. • 2—Displays diagnostic debug messages. • 3—Displays all detailed debug messages.
---------------------------	--------------	---

Defaults	3
-----------------	---

Command Modes	Privileged EXEC
----------------------	-----------------

Command History	Release	Modification
	12.4(22)YE	This command was introduced.
	12.4(22)YE1	This command was integrated into Cisco IOS Release 12.4(22)YE1.
	12.4(22)YE2	This command was integrated into Cisco IOS Release 12.4(22)YE2.
	12.4(24)YE	This command was integrated into Cisco IOS Release 12.4(24)YE.
	12.4(24)YE1	This command was integrated into Cisco IOS Release 12.4(24)YE1.
	12.4(24)YE2	This command was integrated into Cisco IOS Release 12.4(24)YE2.
	12.4(24)YE3	This command was integrated into Cisco IOS Release 12.4(24)YE3.

Usage Guidelines	This command is useful for system operators and development engineers if Diameter protocol problems are encountered on the GGSN.
-------------------------	--

Examples	The following example configures the GGSN to display only critical debug messages: Router# debug gprs verbose 1
-----------------	--

debug ip iscsi

To display information about the iSCSI processing on the GGSN, use the **debug ip iscsi** command in privileged EXEC mode. To disable debugging output, use the **no** form of this command.

debug ip iscsi {all | error | event | packet} [detail]

no debug ip iscsi {all | error | event | packet} [detail]

Syntax Description	all	Displays all iSCSI debug information.
	error	Displays error messages related to iSCSI processing on the GGSN.
	event	Displays events related to iSCSI processing on the GGSN.
	packet	Displays iSCSI packets that are sent between the GGSN and SAN.
	detail	(Optional) Displays detailed packet and event information.

Defaults No default behavior or values.

Command History	Release	Modification
	12.4(15)XQ	This command was introduced.
	12.4(22)YE	This command was integrated into Cisco IOS Release 12.4(22)YE.
	12.4(22)YE1	This command was integrated into Cisco IOS Release 12.4(22)YE1.
	12.4(22)YE2	This command was integrated into Cisco IOS Release 12.4(22)YE2.
	12.4(24)YE	This command was integrated into Cisco IOS Release 12.4(24)YE.
	12.4(24)YE1	This command was integrated into Cisco IOS Release 12.4(24)YE1.
	12.4(24)YE2	This command was integrated into Cisco IOS Release 12.4(24)YE2.
	12.4(24)YE3	This command was integrated into Cisco IOS Release 12.4(24)YE3.

Usage Guidelines This command is useful for system operators and development engineers if problems are encountered with communication between the GGSN and the SAN using iSCSI.

Examples The following example displays iSCSI debugging at the time of login:

```

=====
Router#debug ip iscsi all
iSCSI All debugging is on

Router#show debug
iSCSI:
  iSCSI Events debugging is on
  iSCSI Events Detailed debugging is on
  iSCSI Packets debugging is on
  iSCSI Packets Detailed debugging is on
  iSCSI Error debugging is on

```

```

Router#conf t
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#gprs iscsi LINUX
Router(config)#end
Router#
SAMI 9/3: iSCSI Event: iSCSI Connection Event (0), State Change from(0) -> To(1)
SAMI 9/3: iSCSI Event: Socket Connect Success
SAMI 9/3: iSCSI Event: iSCSI Connection Event (4), State Change from(1) -> To(2)
SAMI 9/3: iSCSI Event: Send CONN Up Msg to RX
SAMI 9/3: INTR->TGT (HEADER + DATA):
493DEE20: 43810000 00000092 C.....
493DEE30: 30303030 31000000 00000000 00000000 00001.....
493DEE40: 00000001 00000000 00000000 00000000 .....
493DEE50: 00000000 00000000 496E6974 6961746F .....Initiato
493DEE60: 724E616D 653D6971 6E2E3139 38372D30 rName=ign.1987-0
493DEE70: 372E636F 6D2E6369 73636F3A 6D777462 7.com.cisco:mwtb
493DEE80: 6732352D 7375702D 30392D33 00546172 g25-sup-09-3.Tar
493DEE90: 6765744E 616D653D 69716E2E 32303032 getName=ign.2002
493DEEA0: 2D31302E 6564752E 756E682E 696F6C2E -10.edu.unh.iol.
493DEEB0: 69736373 692E6472 61667432 302D7461 iscsi.draft20-ta
493DEEC0: 72676574 3A310053 65737369 6F6E5479 rget:1.SessionTy
493DEED0: 70653D4E 6F726D61 6C004175 74684D65 pe=Normal.AuthMe
493DEEE0: 74686F64 3D4E6F6E 65000000 thod=None...
SAMI 9/3: iSCSI Event: Starting Login Timer (5)
SAMI 9/3: iSCSI Event: New Connection Event - 0
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 23810000 00000027 30303030 31000000 #.....'00001...
4B5A7260: 00000000 00000000 00000001 00000001 .....
4B5A7270: 00000005 00000000 00000000 00000000 .....
4B5A7280:
SAMI 9/3: TGT->INTR:Data:
493E6E50: 41757468 4D657468 AuthMeth
493E6E60: 6F643D4E 6F6E6500 54617267 6574506F od=None.TargetPo
493E6E70: 7274616C 47726F75 70546167 3D310000 rtalGroupTag=1..
493E6E80:
SAMI 9/3: iSCSI Event: Data-In: Read (40) bytes of Data Segment
SAMI 9/3: INTR->TGT (HEADER + DATA):
493DEE20: 43870000 00000133 C.....3
493DEE30: 30303030 31000000 00000000 00000000 00001.....
493DEE40: 00000001 00000002 00000000 00000000 .....
493DEE50: 00000000 00000000 48656164 65724469 .....HeaderDi
493DEE60: 67657374 3D4E6F6E 65004461 74614469 gest=None.DataDi
493DEE70: 67657374 3D4E6F6E 65004D61 78526563 gest=None.MaxRec
493DEE80: 76446174 61536567 6D656E74 4C656E67 vDataSegmentLeng
493DEE90: 74683D33 32373638 00446566 61756C74 th=32768.Default
493DEEA0: 54696D65 32576169 743D3500 44656661 Time2Wait=5.Defa
493DEEB0: 756C7454 696D6532 52657461 696E3D35 ultTime2Retain=5
493DEEC0: 0049464D 61726B65 723D4E6F 004F464D .IFMarker=No.OFM
493DEED0: 61726B65 723D4E6F 00457272 6F725265 arker=No.ErrorRe
493DEEE0: 636F7665 72794C65 76656C3D 3000496E coveryLevel=0.In
493DEEF0: 69746961 6C523254 3D596573 00496D6D itialR2T=Yes.Imm
493DEF00: 65646961 74654461 74613D59 6573004D ediateData=Yes.M
493DEF10: 61784275 7273744C 656E6774 683D3136 axBurstLength=16
493DEF20: 33383400 46697273 74427572 73744C65 384.FirstBurstLe
493DEF30: 6E677468 3D313633 3834004D 61784F75 ngth=16384.MaxOu
493DEF40: 74737461 6E64696E 67523254 3D31004D tstandingR2T=1.M
493DEF50: 6178436F 6E6E6563 74696F6E 733D3100 axConnections=1.
493DEF60: 44617461 50445549 6E4F7264 65723D59 DataPDUInOrder=Y
493DEF70: 65730044 61746153 65717565 6E636549 es.DataSequenceI
493DEF80: 6E4F7264 65723D59 65730000 nOrder=Yes..
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 23870000 000000C2 30303030 31000F53 #.....B00001..S
4B5A7260: 00000000 00000000 00000002 00000001 .....
4B5A7270: 00000005 00000000 00000000 00000000 .....

```

```

4B5A7280:
SAMI 9/3: TGT->INTR:Data:
493E6E50: 48656164 65724469 HeaderDi
493E6E60: 67657374 3D4E6F6E 65004461 74614469 gest=None.DataDi
493E6E70: 67657374 3D4E6F6E 65004465 6661756C gest=None.Default
493E6E80: 7454696D 65325761 69743D35 00446566 tTime2Wait=5.Def
493E6E90: 61756C74 54696D65 32526574 61696E3D aultTime2Retain=
493E6EA0: 35004572 726F7252 65636F76 6572794C 5.ErrorRecoveryL
493E6EB0: 6576656C 3D300049 6D6D6564 69617465 evel=0.Immediate
493E6EC0: 44617461 3D596573 004D6178 4F757473 Data=Yes.MaxOuts
493E6ED0: 74616E64 696E6752 32543D31 004D6178 tandingR2T=1.Max
493E6EE0: 436F6E6E 65637469 6F6E733D 31004669 Connections=1.Fi
493E6EF0: 72737442 75727374 4C656E67 74683D31 rstBurstLength=1
493E6F00: 36333834 004D6178 42757273 744C656E 6384.MaxBurstLen
493E6F10: 6774683D 31363338 34000000 gth=16384...
SAMI 9/3: iSCSI Event: Data-In: Read (196) bytes of Data Segment
SAMI 9/3: iSCSI Event: iSCSI Connection Event (6), State Change from(2) -> To(3)
SAMI 9/3: iSCSI Event: Starting Full Feature Phase Timer (5)
SAMI 9/3: iSCSI Event: iSCSI Session Event (0), State Change from(0) -> To(1)
SAMI 9/3: iSCSI Event-Det: handle scsi cmd req
SAMI 9/3: iSCSI Event-Det: run pending queue
SAMI 9/3: iSCSI Event-Det: send scsi command
SAMI 9/3: INTR->TGT HEAD:
493DEE20: 01C00000 00000000 .@.....
493DEE30: 00000000 00000000 00000001 00000000 .....
493DEE40: 00000001 00000003 00000000 00000000 .....
493DEE50: 00000000 00000000 .....
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 21800000 00000000 00000000 00000000 !.....
4B5A7260: 00000001 00000000 00000003 00000002 .....
4B5A7270: 00000006 00000000 00000000 00000000 .....
4B5A7280:
SAMI 9/3: SCSI Event: Test unit ready command successful
SAMI 9/3: iSCSI Event-Det: handle scsi cmd req
SAMI 9/3: iSCSI Event-Det: run pending queue
SAMI 9/3: iSCSI Event-Det: send scsi command
SAMI 9/3: INTR->TGT HEAD:
493DEE20: 01C00000 00000000 .@.....
493DEE30: 00000000 00000000 00000002 000000FF .....
493DEE40: 00000002 00000004 A0000000 00000000 .....
493DEE50: 00FF0000 00000000 .....
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 25800000 00000030 00000000 00000000 %.....0.....
4B5A7260: 00000002 FFFFFFFF 00000000 00000003 .....
4B5A7270: 00000006 00000000 00000000 00000000 .....
4B5A7280:
SAMI 9/3: iSCSI Event: recv_data for itt 2, cmdnd 0xA0, buflen 255, offset 0 exp offset 0,
flags 0x80 datasn 0

SAMI 9/3: TGT->INTR:Data:
414F59E0: 00000028 00000000 00000000 00000000 ...(.
414F59F0: 00010000 00000000 00020000 00000000 .....
414F5A00: 00030000 00000000 00040000 00000000 .....
414F5A10:
SAMI 9/3: iSCSI Event: Data-In: Read (48) bytes of Data Segment
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 21820000 00000000 00000000 00000000 !.....
4B5A7260: 00000002 00000000 00000004 00000003 .....
4B5A7270: 00000007 00000001 00000000 000000CF .....0
4B5A7280:
SAMI 9/3: iSCSI Event-Det: handle scsi cmd req
SAMI 9/3: iSCSI Event-Det: run pending queue
SAMI 9/3: iSCSI Event-Det: send scsi command
SAMI 9/3: INTR->TGT HEAD:

```

```

493DEE20:                                01C00000 00000000                .@.....
493DEE30: 00000000 00000000 00000003 000000FF                .....
493DEE40: 00000003 00000005 12000000 FF000000                .....
493DEE50: 00000000 00000000                                .....
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 25800000 000000FF 00000000 00000000    %.....
4B5A7260: 00000003 FFFFFFFF 00000000 00000004    .....
4B5A7270: 00000007 00000000 00000000 00000000    .....
4B5A7280:
SAMI 9/3: iSCSI Event: recv_data for itt 3, cmdnd 0x12, bufflen 255, offset 0 exp offset 0,
flags 0x80 datasn 0

SAMI 9/3: TGT->INTR:Data:
493D6960:                00000402 1F008000 554E482D                .....UNH-
493D6970: 494F4C20 66696C65 2D6D6F64 65207461    IOL file-mode ta
493D6980: 72676574 312E3220 00000000 00000000    rget1.2 .....
493D6990: 00000000 00000000 00000000 00000000    .....
493D69A0: 00000000 00000000 00000000 00000000    .....
493D69B0: 00000000 00000000 00000000 00000000    .....
493D69C0: 00000000 00000000 00000000 00000000    .....
493D69D0: 00000000 00000000 00000000 00000000    .....
493D69E0: 00000000 00000000 00000000 00000000    .....
493D69F0: 00000000 00000000 00000000 00000000    .....
493D6A00: 00000000 00000000 00000000 00000000    .....
493D6A10: 00000000 00000000 00000000 00000000    .....
493D6A20: 00000000 00000000 00000000 00000000    .....
493D6A30: 00000000 00000000 00000000 00000000    .....
493D6A40: 00000000 00000000 00000000 00000000    .....
493D6A50: 00000000 00000000 00000000 00000000    .....
493D6A60: 00000000                                ....
SAMI 9/3: iSCSI Event: Data-In: Read (256) bytes of Data Segment
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 21800000 00000000 00000000 00000000    !.....
4B5A7260: 00000003 00000000 00000005 00000004    .....
4B5A7270: 00000008 00000001 00000000 00000000    .....
4B5A7280:
SAMI 9/3: SCSI Event: Processing inquire LUN response
SAMI 9/3: SCSI Event: Calling Device Add - 414F59E0
SAMI 9/3: SCSI Event: scsi add device
SAMI 9/3: SCSI Event: lun_in_inquiry 1
SAMI 9/3: iSCSI Event-Det: handle scsi cmd req
SAMI 9/3: iSCSI Event-Det: run pending queue
SAMI 9/3: iSCSI Event-Det: send scsi command
SAMI 9/3: INTR->TGT HEAD:
493DEE20:                                01C00000 00000000                .@.....
493DEE30: 00010000 00000000 00000004 000000FF                .....
493DEE40: 00000004 00000006 12000000 FF000000                .....
493DEE50: 00000000 00000000                                .....
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 25800000 000000FF 00000000 00000000    %.....
4B5A7260: 00000004 FFFFFFFF 00000000 00000005    .....
4B5A7270: 00000008 00000000 00000000 00000000    .....
4B5A7280:
SAMI 9/3: iSCSI Event: recv_data for itt 4, cmdnd 0x12, bufflen 255, offset 0 exp offset 0,
flags 0x80 datasn 0

SAMI 9/3: TGT->INTR:Data:
493A3D40: 00000402 1F008000 554E482D 494F4C20                .....UNH-IOL
493A3D50: 66696C65 2D6D6F64 65207461 72676574    file-mode target
493A3D60: 312E3220 00000000 00000000 00000000    1.2 .....
493A3D70: 00000000 00000000 00000000 00000000    .....
493A3D80: 00000000 00000000 00000000 00000000    .....
493A3D90: 00000000 00000000 00000000 00000000    .....
493A3DA0: 00000000 00000000 00000000 00000000    .....

```

```

493A3DB0: 00000000 00000000 00000000 00000000 .....
493A3DC0: 00000000 00000000 00000000 00000000 .....
493A3DD0: 00000000 00000000 00000000 00000000 .....
493A3DE0: 00000000 00000000 00000000 00000000 .....
493A3DF0: 00000000 00000000 00000000 00000000 .....
493A3E00: 00000000 00000000 00000000 00000000 .....
493A3E10: 00000000 00000000 00000000 00000000 .....
493A3E20: 00000000 00000000 00000000 00000000 .....
493A3E30: 00000000 00000000 00000000 00000000 .....
493A3E40:
SAMI 9/3: iSCSI Event: Data-In: Read (256) bytes of Data Segment
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 21800000 00000000 00000000 00000000 !.....
4B5A7260: 00000004 00000000 00000006 00000005 .....
4B5A7270: 00000009 00000001 00000000 00000000 .....
4B5A7280:
SAMI 9/3: SCSI Event: Processing inquire LUN response
SAMI 9/3: SCSI Event: Calling Device Add - 41E1B98C
SAMI 9/3: SCSI Event: scsi add device
SAMI 9/3: SCSI Event: lun_in_inquiry 2
SAMI 9/3: iSCSI Event-Det: handle scsi cmd req
SAMI 9/3: iSCSI Event-Det: run pending queue
SAMI 9/3: iSCSI Event-Det: send scsi command
SAMI 9/3: INTR->TGT HEAD:
493DEE20:          01C00000 00000000          .@.....
493DEE30: 00020000 00000000 00000005 000000FF .....
493DEE40: 00000005 00000007 12000000 FF000000 .....
493DEE50: 00000000 00000000          .....
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 25800000 000000FF 00000000 00000000 %.....
4B5A7260: 00000005 FFFFFFFF 00000000 00000006 .....
4B5A7270: 00000009 00000000 00000000 00000000 .....
4B5A7280:
SAMI 9/3: iSCSI Event: recv_data for itt 5, cmdnd 0x12, buflen 255, offset 0 exp offset 0,
flags 0x80 datasn 0

SAMI 9/3: TGT->INTR:Data:
4B643390:          00000402 1F008000 554E482D          .....UNH-
4B6433A0: 494F4C20 66696C65 2D6D6F64 65207461 IOL file-mode ta
4B6433B0: 72676574 312E3220 00000000 00000000 rget1.2 .....
4B6433C0: 00000000 00000000 00000000 00000000 .....
4B6433D0: 00000000 00000000 00000000 00000000 .....
4B6433E0: 00000000 00000000 00000000 00000000 .....
4B6433F0: 00000000 00000000 00000000 00000000 .....
4B643400: 00000000 00000000 00000000 00000000 .....
4B643410: 00000000 00000000 00000000 00000000 .....
4B643420: 00000000 00000000 00000000 00000000 .....
4B643430: 00000000 00000000 00000000 00000000 .....
4B643440: 00000000 00000000 00000000 00000000 .....
4B643450: 00000000 00000000 00000000 00000000 .....
4B643460: 00000000 00000000 00000000 00000000 .....
4B643470: 00000000 00000000 00000000 00000000 .....
4B643480: 00000000 00000000 00000000 00000000 .....
4B643490: 00000000          ....
SAMI 9/3: iSCSI Event: Data-In: Read (256) bytes of Data Segment
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 21800000 00000000 00000000 00000000 !.....
4B5A7260: 00000005 00000000 00000007 00000006 .....
4B5A7270: 0000000A 00000001 00000000 00000000 .....
4B5A7280:
SAMI 9/3: SCSI Event: Processing inquire LUN response
SAMI 9/3: SCSI Event: Calling Device Add - 4B63DC5C
SAMI 9/3: SCSI Event: scsi add device
SAMI 9/3: SCSI Event: lun_in_inquiry 3

```

```

SAMI 9/3: iSCSI Event-Det: handle scsi cmd req
SAMI 9/3: iSCSI Event-Det: run pending queue
SAMI 9/3: iSCSI Event-Det: send scsi command
SAMI 9/3: INTR->TGT HEAD:
493DEE20: 01C00000 00000000 .@.....
493DEE30: 00030000 00000000 00000006 000000FF .....
493DEE40: 00000006 00000008 12000000 FF000000 .....
493DEE50: 00000000 00000000 .....
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 25800000 000000FF 00000000 00000000 %.....
4B5A7260: 00000006 FFFFFFFF 00000000 00000007 .....
4B5A7270: 0000000A 00000000 00000000 00000000 .....
4B5A7280:
SAMI 9/3: iSCSI Event: recv_data for itt 6, cmnd 0x12, buflen 255, offset 0 exp offset 0,
flags 0x80 datasn 0

SAMI 9/3: TGT->INTR:Data:
4198DBD0: 00000402 1F008000 554E482D 494F4C20 .....UNH-IOL
4198DBE0: 66696C65 2D6D6F64 65207461 72676574 file-mode target
4198DBF0: 312E3220 00000000 00000000 00000000 1.2 .....
4198DC00: 00000000 00000000 00000000 00000000 .....
4198DC10: 00000000 00000000 00000000 00000000 .....
4198DC20: 00000000 00000000 00000000 00000000 .....
4198DC30: 00000000 00000000 00000000 00000000 .....
4198DC40: 00000000 00000000 00000000 00000000 .....
4198DC50: 00000000 00000000 00000000 00000000 .....
4198DC60: 00000000 00000000 00000000 00000000 .....
4198DC70: 00000000 00000000 00000000 00000000 .....
4198DC80: 00000000 00000000 00000000 00000000 .....
4198DC90: 00000000 00000000 00000000 00000000 .....
4198DCA0: 00000000 00000000 00000000 00000000 .....
4198DCB0: 00000000 00000000 00000000 00000000 .....
4198DCC0: 00000000 00000000 00000000 00000000 .....
4198DCD0:
SAMI 9/3: iSCSI Event: Data-In: Read (256) bytes of Data Segment
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 21800000 00000000 0000
Router#0000 00000000 !.....
4B5A7260: 00000006 00000000 00000008 00000007 .....
4B5A7270: 0000000B 00000001 00000000 00000000 .....
4B5A7280:
SAMI 9/3: SCSI Event: Processing inquire LUN response
SAMI 9/3: SCSI Event: Calling Device Add - 4B63C60C
SAMI 9/3: SCSI Event: scsi add device
SAMI 9/3: SCSI Event: lun_in_inquiry 4
SAMI 9/3: iSCSI Event-Det: handle scsi cmd req
SAMI 9/3: iSCSI Event-Det: run pending queue
SAMI 9/3: iSCSI Event-Det: send scsi command
SAMI 9/3: INTR->TGT HEAD:
493DEE20: 01C00000 00000000 .@.....
493DEE30: 00040000 00000000 00000007 000000FF .....
493DEE40: 00000007 00000009 12000000 FF000000 .....
493DEE50: 00000000 00000000 .....
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 25800000 000000FF 00000000 00000000 %.....
4B5A7260: 00000007 FFFFFFFF 00000000 00000008 .....
4B5A7270: 0000000B 00000000 00000000 00000000 .....
4B5A7280:
SAMI 9/3: iSCSI Event: recv_data for itt 7, cmnd 0x12, buflen 255, offset 0 exp offset 0,
flags 0x80 datasn 0

SAMI 9/3: TGT->INTR:Data:
4B63C720: 00000402 1F008000 554E482D 494F4C20 .....UNH-IOL
4B63C730: 66696C65 2D6D6F64 65207461 72676574 file-mode target

```

```

4B63C740: 312E3220 00000000 00000000 00000000 1.2 .....
4B63C750: 00000000 00000000 00000000 00000000 .....
4B63C760: 00000000 00000000 00000000 00000000 .....
4B63C770: 00000000 00000000 00000000 00000000 .....
4B63C780: 00000000 00000000 00000000 00000000 .....
4B63C790: 00000000 00000000 00000000 00000000 .....
4B63C7A0: 00000000 00000000 00000000 00000000 .....
4B63C7B0: 00000000 00000000 00000000 00000000 .....
4B63C7C0: 00000000 00000000 00000000 00000000 .....
4B63C7D0: 00000000 00000000 00000000 00000000 .....
4B63C7E0: 00000000 00000000 00000000 00000000 .....
4B63C7F0: 00000000 00000000 00000000 00000000 .....
4B63C800: 00000000 00000000 00000000 00000000 .....
4B63C810: 00000000 00000000 00000000 00000000 .....
4B63C820:
SAMI 9/3: iSCSI Event: Data-In: Read (256) bytes of Data Segment
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 21800000 00000000 00000000 00000000 !.....
4B5A7260: 00000007 00000000 00000009 00000008 .....
4B5A7270: 0000000C 00000001 00000000 00000000 .....
4B5A7280:
SAMI 9/3: SCSI Event: Processing inquire LUN response
SAMI 9/3: SCSI Event: Calling Device Add - 493A3378
SAMI 9/3: SCSI Event: scsi add device
SAMI 9/3: SCSI Event: max= 5 lun_in_inquiry= 5
SAMI 9/3: iSCSI Event-Det: handle scsi cmd req
SAMI 9/3: iSCSI Event-Det: run pending queue
SAMI 9/3: iSCSI Event-Det: send scsi command
SAMI 9/3: INTR->TGT HEAD:
493DEE20: 01C00000 00000000 .@.....
493DEE30: 00000000 00000000 00000008 000000FF .....
493DEE40: 00000008 0000000A 25000000 00000000 .....%.....
493DEE50: 00000000 00000000 .....
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 25800000 00000008 00000000 00000000 %.....
4B5A7260: 00000008 FFFFFFFF 00000000 00000009 .....
4B5A7270: 0000000C 00000000 00000000 00000000 .....
4B5A7280:
SAMI 9/3: iSCSI Event: recv_data for itt 8, cmdn 0x25, buflen 255, offset 0 exp offset 0,
flags 0x80 datasn 0

SAMI 9/3: TGT->INTR:Data:
493D65D0: 003FFFFFF 00000200 .?.....
493D65E0:
SAMI 9/3: iSCSI Event: Data-In: Read (8) bytes of Data Segment
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 21820000 00000000 00000000 00000000 !.....
4B5A7260: 00000008 00000000 0000000A 00000009 .....
4B5A7270: 0000000D 00000001 00000000 000000F7 .....w
4B5A7280:
SAMI 9/3: SCSI Event: Processing read capacity response
SAMI 9/3: SCSI Event: max= 5 lun= 1
SAMI 9/3: iSCSI Event-Det: handle scsi cmd req
SAMI 9/3: iSCSI Event-Det: run pending queue
SAMI 9/3: iSCSI Event-Det: send scsi command
SAMI 9/3: INTR->TGT HEAD:
493DEE20: 01C00000 00000000 .@.....
493DEE30: 00010000 00000000 00000009 000000FF .....
493DEE40: 00000009 0000000B 25000000 00000000 .....%.....
493DEE50: 00000000 00000000 .....
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 25800000 00000008 00000000 00000000 %.....
4B5A7260: 00000009 FFFFFFFF 00000000 0000000A .....
4B5A7270: 0000000D 00000000 00000000 00000000 .....

```

```

4B5A7280:
SAMI 9/3: iSCSI Event: recv_data for itt 9, cmdnd 0x25, bufflen 255, offset 0 exp offset 0,
flags 0x80 datasn 0

SAMI 9/3: TGT->INTR:Data:
41637830:                                003FFFFFFF                .?..
41637840: 00000200                                ....
SAMI 9/3: iSCSI Event: Data-In: Read (8) bytes of Data Segment
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 21820000 00000000 00000000 00000000  !.....
4B5A7260: 00000009 00000000 0000000B 0000000A  .....
4B5A7270: 0000000E 00000001 00000000 000000F7  .....w
4B5A7280:
SAMI 9/3: SCSI Event: Processing read capacity response
SAMI 9/3: SCSI Event: max= 5 lun= 2
SAMI 9/3: iSCSI Event-Det: handle scsi cmd req
SAMI 9/3: iSCSI Event-Det: run pending queue
SAMI 9/3: iSCSI Event-Det: send scsi command
SAMI 9/3: INTR->TGT HEAD:
493DEE20:                                01C00000 00000000                .@.....
493DEE30: 00020000 00000000 0000000A 000000FF  .....
493DEE40: 0000000A 0000000C 25000000 00000000  .....%.
493DEE50: 00000000 00000000                                .....
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 25800000 00000008 00000000 00000000  %.....
4B5A7260: 0000000A FFFFFFFF 00000000 0000000B  .....
4B5A7270: 0000000E 00000000 00000000 00000000  .....
4B5A7280:
SAMI 9/3: iSCSI Event: recv_data for itt 10, cmdnd 0x25, bufflen 255, offset 0 exp offset
0, flags 0x80 datasn 0

SAMI 9/3: TGT->INTR:Data:
4ADE19D0:                                003FFFFFFF                .?..
4ADE19E0: 00000200                                ....
SAMI 9/3: iSCSI Event: Data-In: Read (8) bytes of Data Segment
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 21820000 00000000 00000000 00000000  !.....
4B5A7260: 0000000A 00000000 0000000C 0000000B  .....
4B5A7270: 0000000F 00000001 00000000 000000F7  .....w
4B5A7280:
SAMI 9/3: SCSI Event: Processing read capacity response
SAMI 9/3: SCSI Event: max= 5 lun= 3
SAMI 9/3: iSCSI Event-Det: handle scsi cmd req
SAMI 9/3: iSCSI Event-Det: run pending queue
SAMI 9/3: iSCSI Event-Det: send scsi command
SAMI 9/3: INTR->TGT HEAD:
493DEE20:                                01C00000 00000000                .@.....
493DEE30: 00030000 00000000 0000000B 000000FF  .....
493DEE40: 0000000B 0000000D 25000000 00000000  .....%.
493DEE50: 00000000 00000000                                .....
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 25800000 00000008 00000000 00000000  %.....
4B5A7260: 0000000B FFFFFFFF 00000000 0000000C  .....
4B5A7270: 0000000F 00                                .....
Router#000000 00000000 00000000  .....
4B5A7280:
SAMI 9/3: iSCSI Event: recv_data for itt 11, cmdnd 0x25, bufflen 255, offset 0 exp offset
0, flags 0x80 datasn 0

SAMI 9/3: TGT->INTR:Data:
4ADE1B10: 003FFFFFFF 00000200                                .?.....
SAMI 9/3: iSCSI Event: Data-In: Read (8) bytes of Data Segment
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 21820000 00000000 00000000 00000000  !.....

```

```

4B5A7260: 0000000B 00000000 0000000D 0000000C .....
4B5A7270: 00000010 00000001 00000000 000000F7 .....w
4B5A7280:
SAMI 9/3: SCSI Event: Processing read capacity response
SAMI 9/3: SCSI Event: max= 5 lun= 4
SAMI 9/3: iSCSI Event-Det: handle scsi cmd req
SAMI 9/3: iSCSI Event-Det: run pending queue
SAMI 9/3: iSCSI Event-Det: send scsi command
SAMI 9/3: INTR->TGT HEAD:
493DEE20:          01C00000 00000000          .@.....
493DEE30: 00040000 00000000 0000000C 000000FF .....
493DEE40: 0000000C 0000000E 25000000 00000000 .....%.....
493DEE50: 00000000 00000000          .....
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 25800000 00000008 00000000 00000000 %.....
4B5A7260: 0000000C FFFFFFFF 00000000 0000000D .....
4B5A7270: 00000010 00000000 00000000 00000000 .....
4B5A7280:
SAMI 9/3: iSCSI Event: recv_data for itt 12, cmdnd 0x25, bufflen 255, offset 0 exp offset
0, flags 0x80 datasn 0

SAMI 9/3: TGT->INTR:Data:
4B642580:          0003FFFF          ....
4B642590: 00000200          ....
SAMI 9/3: iSCSI Event: Data-In: Read (8) bytes of Data Segment
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 21820000 00000000 00000000 00000000 !.....
4B5A7260: 0000000C 00000000 0000000E 0000000D .....
4B5A7270: 00000011 00000001 00000000 000000F7 .....w
4B5A7280:
SAMI 9/3: SCSI Event: Processing read capacity response
SAMI 9/3: SCSI Event: Max= 5 lun= 5
SAMI 9/3: SCSI Event: device discovery completed
SAMI 9/3: SCSI Event:
Creating File System on sda0
SAMI 9/3: SCSI Event: Read command, lba(0), nblocks(1)
SAMI 9/3: iSCSI Event-Det: handle scsi cmd req
SAMI 9/3: iSCSI Event-Det: run pending queue
SAMI 9/3: iSCSI Event-Det: send scsi command
SAMI 9/3: INTR->TGT HEAD:
493DEE20:          01C00000 00000000          .@.....
493DEE30: 00000000 00000000 0000000D 00000200 .....
493DEE40: 0000000D 0000000F 28000000 00000000 .....(.....
493DEE50: 01000000 00000000          .....
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 25800000 00000200 00000000 00000000 %.....
4B5A7260: 0000000D FFFFFFFF 00000000 0000000E .....
4B5A7270: 00000011 00000000 00000000 00000000 .....
4B5A7280:
SAMI 9/3: iSCSI Event: recv_data for itt 13, cmdnd 0x28, bufflen 512, offset 0 exp offset
0, flags 0x80 datasn 0

SAMI 9/3: TGT->INTR:Data:
4B5A8B00: 00000000 00000000 00000000 00000000 .....
4B5A8B10: 00000000 00000000 00000000 00000000 .....
4B5A8B20: 00000000 00000000 00000000 00000000 .....
4B5A8B30: 00000000 00000000 00000000 00000000 .....
4B5A8B40: 00000000 00000000 00000000 00000000 .....
4B5A8B50: 00000000 00000000 00000000 00000000 .....
4B5A8B60: 00000000 00000000 00000000 00000000 .....
4B5A8B70: 00000000 00000000 00000000 00000000 .....
4B5A8B80: 00000000 00000000 00000000 00000000 .....
4B5A8B90: 00000000 00000000 00000000 00000000 .....
4B5A8BA0: 00000000 00000000 00000000 00000000 .....

```

```

4B5A8BB0: 00000000 00000000 00000000 00000000 .....
4B5A8BC0: 00000000 00000000 00000000 00000000 .....
4B5A8BD0: 00000000 00000000 00000000 00000000 .....
4B5A8BE0: 00000000 00000000 00000000 00000000 .....
4B5A8BF0: 00000000 00000000 00000000 00000000 .....
4B5A8C00: 00000000 00000000 00000000 00000000 .....
4B5A8C10: 00000000 00000000 00000000 00000000 .....
4B5A8C20: 00000000 00000000 00000000 00000000 .....
4B5A8C30: 00000000 00000000 00000000 00000000 .....
4B5A8C40: 00000000 00000000 00000000 00000000 .....
4B5A8C50: 00000000 00000000 00000000 00000000 .....
4B5A8C60: 00000000 00000000 00000000 00000000 .....
4B5A8C70: 00000000 00000000 00000000 00000000 .....
4B5A8C80: 00000000 00000000 00000000 00000000 .....
4B5A8C90: 00000000 00000000 00000000 00000000 .....
4B5A8CA0: 00000000 00000000 00000000 00000000 .....
4B5A8CB0: 00000000 00000000 E6F06A79 00000000 .....fpjy....
4B5A8CC0: 00000000 00000000 00000000 00000000 .....
4B5A8CD0: 00000000 00000000 00000000 00000000 .....
4B5A8CE0: 00000000 00000000 00000000 00000000 .....
4B5A8CF0: 00000000 00000000 00000000 000055AA .....U*
4B5A8D00:
SAMI 9/3: iSCSI Event: Data-In: Read (512) bytes of Data Segment
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 21800000 00000000 00000000 00000000 !.....
4B5A7260: 0000000D 00000000 0000000F 0000000E .....
4B5A7270: 00000012 00000001 00000000 00000000 .....
4B5A7280:
SAMI 9/3: SCSI Event:
Creating File System on sdal
SAMI 9/3: SCSI Event: Read command, lba(0), nblocks(1)
SAMI 9/3: iSCSI Event-Det: handle scsi cmd req
SAMI 9/3: iSCSI Event-Det: run pending queue
SAMI 9/3: iSCSI Event-Det: send scsi command
SAMI 9/3: INTR->TGT HEAD:
493DEE20: 01C00000 00000000 .....@.....
493DEE30: 00010000 00000000 0000000E 00000200 .....
493DEE40: 0000000E 00000010 28000000 00000000 .....(.....
493DEE50: 01000000 00000000 .....
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 25800000 00000200 00000000 00000000 %.....
4B5A7260: 0000000E FFFFFFFF 00000000 0000000F .....
4B5A7270: 00000012 00000000 00000000 00000000 .....
4B5A7280:
SAMI 9/3: iSCSI Event: recv_data for itt 14, cmdnd 0x28, buflen 512, offset 0 exp offset
0, flags 0x80 datasn 0

SAMI 9/3: TGT->INTR:Data:
4B5A8B00: 33C08ED0 BC007CFB 5007501F FCBE1B7C 3@.P<.|{P.P.|>.|
4B5A8B10: BF1B0650 57B9E501 F3A4CBBB BE07B104 ?..PW9e.s$K=>.1.
4B5A8B20: 386E007C 09751383 C510E2F4 CD188BF5 8n.|.u..E.btM..u
4B5A8B30: 83C61049 7419382C 74F6A0B5 07B4078B .F.It.8,tv 5.4..
4B5A8B40: F0AC3C00 74FCBB07 00B40ECD 10EBF288 p,<.t|;.4.M.kr.
4B5A8B50: 4E10E846 00732AFE 4610807E 040B740B N.hF.s~F...t.
4B5A8B60: 807E040C 7405A0B6 0775D280 46020683 .~..t. 6.uR.F...
4B5A8B70: 46080683 560A00E8 21007305 A0B607EB F...V..h!.s. 6.k
4B5A8B80: BC813EFE 7D55AA74 0B807E10 0074C8A0 <.>~}U*t..~..tH
4B5A8B90: B707EBA9 8BFC1E57 8BF5CBBF 05008A56 7.k).|.W.uK?...V
4B5A8BA0: 00B408CD 1372238A C1243F98 8ADE8AFC .4.M.r#.A$?...^.|
4B5A8BB0: 43F7E38B D186D6B1 06D2EE42 F7E23956 Cwc.Q.V1.RnBwb9V
4B5A8BC0: 0A772372 05394608 731CB801 02BB007C .w#r.9F.s.8..;|.
4B5A8BD0: 8B4E028B 5600CD13 73514F74 4E32E48A .N..V.M.sQOtN2d.
4B5A8BE0: 5600CD13 EBE48A56 0060BBAA 55B441CD V.M.kd.V.`;*U4AM
4B5A8BF0: 13723681 FB55AA75 30F6C101 742B6160 .r6.{U*u0vA.t+a`

```

```

4B5A8C00: 6A006A00 FF760AFF 76086A00 68007C6A j.j..v..v.j.h.|j
4B5A8C10: 016A10B4 428BF4CD 13616173 0E4F740B .j.4B.tM.aas.Ot.
4B5A8C20: 32E48A56 00CD13EB D661F9C3 496E7661 2d.V.M.kVayCInva
4B5A8C30: 6C696420 70617274 6974696F 6E207461 lid partition ta
4B5A8C40: 626C6500 4572726F 72206C6F 6164696E ble.Error loadin
4B5A8C50: 67206F70 65726174 696E6720 73797374 g operating syst
4B5A8C60: 656D004D 69737369 6E67206F 70657261 em.Missing opera
4B5A8C70: 74696E67 20737973 74656D00 00000000 ting system.....
4B5A8C80: 00000000 00000000 00000000 00000000 .....
4B5A8C90: 00000000 00000000 00000000 00000000 .....
4B5A8CA0: 00000000 00000000 00000000 00000000 .....
4B5A8CB0: 00000000 002C4463 656289D3 00000000 .....,Dceb.S....
4B5A8CC0: 00000000 00000000 00000000 00000000 .....
4B5A8CD0: 00000000 00000000 00000000 00000000 .....
4B5A8CE0: 00000000 00000000 00000000 00000000 .....
4B5A8CF0: 00000000 00000000 00000000 000055AA .....U*
4B5A8D00:
SAMI 9/3: iSCSI Event: Data-In: Read (512) bytes of Data Segment
SAMI 9/3: TGT->INTR:Header:
4B5A7250:
SAMI 9/3: %SYS-5-CONFIG_I: Configured from console by console
SAMI 9/3: %RSM-4-UNEXPECTED: Error: Drive sda4 unusable (Invalid DOS media or no media in
slot) -Process= "RSM Process", ipl= 0, pid= 193, -Traceback= 0x446E45DC 0x442AD9BC
0x442AB94C 0x442A6318 0x442A648C 0x442AB41C 0x442A3B28 0x45602878 0x45605C50
SAMI 9/3: %GPRSISCSIFLTMG-4-GPRS_ISCSI_OPEN_SUCCESS: Succeeded to establish connection
with SAN with session id 13
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 20800000 00000000 00000000 00000000 .....
4B5A7260: FFFFFFFF 0000001C 0000001E 0000001C .....
4B5A7270: 00000020 00000000 00000000 00000000 ... .....
4B5A7280:
SAMI 9/3: INTR->TGT (HEADER + DATA):
4B5A5B50: 40800000 00000000 00000000 00000000 @.....
4B5A5B60: FFFFFFFF 0000001C 0000001C 0000001E .....
4B5A5B70: 00000000 00000000 00000000 00000000 .....
4B5A5B80:
SAMI 9/3: iSCSI Event-Det: Connection timer event (0)
SAMI 9/3: iSCSI Event: FFP Timeout Event Active Tasks(0)
SAMI 9/3: iSCSI Event: Starting Full Feature Phase Timer (5)
SAMI 9/3: INTR->TGT (HEADER + DATA):
4B5A5B50: 40800000 00000000 00000000 00000000 @.....
4B5A5B60: 0000001C FFFFFFFF 0000001C 0000001E .....
4B5A5B70: 00000000 00000000 00000000 00000000 .....
4B5A5B80:
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 20800000 00000000 00000000 00000000 .....
4B5A7260: 0000001C FFFFFFFF 0000001E 0000001C .....
4B5A7270: 00000020 00000000 00000000 00000000 ... .....
4B5A7280:
SAMI 9/3: iSCSI Event-Det: Connection timer event (0)
SAMI 9/3: iSCSI Event: FFP Timeout Event Active Tasks(0)
SAMI 9/3: iSCSI Event: Starting Full Feature Phase Timer (5)
SAMI 9/3: INTR->TGT (HEADER + DATA):
4B5A5B50: 40800000 00000000 00000000 00000000 @.....
4B5A5B60: 0000001D FFFFFFFF 0000001C 0000001F .....
4B5A5B70: 00000000 00000000 00000000 00000000 .....
4B5A5B80:
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 20800000 00000000 00000000 00000000 .....
4B5A7260: 0000001D FFFFFFFF 0000001F 0000001C .....
4B5A7270: 00000020 00000000 00000000 00000000 ... .....
4B5A7280:
SAMI 9/3: iSCSI Event-Det: Connection timer event (0)
SAMI 9/3: iSCSI Event: FFP Timeout Event Active Tasks(0)

```

```

SAMI 9/3: iSCSI Event: Starting Full Feature Phase Timer (5)
SAMI 9/3: INTR->TGT (HEADER + DATA):
4B5A5B50: 40800000 00000000 00000000 00000000 @.....
4B5A5B60: 0000001E FFFFFFFF 0000001C 00000020 .....
4B5A5B70: 00000000 00000000 00000000 00000000 .....
4B5A5B80:
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 20800000 00000000 00000000 00000000 .....
4B5A7260: 0000001E FFFFFFFF 00000020 0000001C .....
4B5A7270: 00000020 00000000 00000000 00000000 ... ..
4B5A7280:
SAMI 9/3: iSCSI Event-Det: Connection timer event (0)
SAMI 9/3: iSCSI Event: FFP Timeout Event Active Tasks(0)
SAMI 9/3: iSCSI Event: Starting Full Feature Phase Timer (5)
SAMI 9/3: INTR->TGT (HEADER + DATA):
4B5A5B50: 40800000 00000000 00000000 00000000 @.....
4B5A5B60: 0000001F FFFFFFFF 0000001C 00000021 .....!
4B5A5B70: 00000000 00000000 00000000 00000000 .....
4B5A5B80:
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 20800000 00000000 00000000 00000000 .....
4B5A7260: 0000001F FFFFFFFF 00000021 0000001C .....!....
4B5A7270: 00000020 00000000 00000000 00000000 ... ..
4B5A7280:
SAMI 9/3: iSCSI Event-Det: Connection timer event (0)
SAMI 9/3: iSCSI Event: FFP Timeout Event Active Tasks(0)
SAMI 9/3: iSCSI Event: Starting Full Feature Phase Timer (5)
SAMI 9/3: INTR->TGT (HEADER + DATA):
4B5A5B50: 40800000 00000000 00000000 00000000 @.....
4B5A5B60: 00000020 FFFFFFFF 0000001C 00000022 ... .."
4B5A5B70: 00000000 00000000 00000000 00000000 .....
4B5A5B80:
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 20800000 00000000 00000000 00000000 .....
4B5A7260: 00000020 FFFFFFFF 00000022 0000001C ... .."....
4B5A7270: 00000020 00000000 00000000 00000000 ... ..
4B5A7280:
SAMI 9/3: iSCSI Event-Det: Connection timer event (0)
SAMI 9/3: iSCSI Event: FFP Timeout Event Active Tasks(0)
SAMI 9/3: iSCSI Event: Starting Full Feature Phase Timer (5)
SAMI 9/3: INTR->TGT (HEADER + DATA):
4B5A5B50: 40800000 00000000 00000000 00000000 @.....
4B5A5B60: 00000021 FFFFFFFF 0000001C 00000023 ...!.....#
4B5A5B70: 00000000 00000000 00000000 00000000 .....
4B5A5B80:
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 20800000 00000000 00000000 00000000 .....
4B5A7260: 00000021 FFFFFFFF 00000023 0000001C ...!.....#....
4B5A7270: 00000020 00000000 00000000 00000000 ... ..
4B5A7280:
SAMI 9/3: iSCSI Event-Det: Connection timer event (0)
SAMI 9/3: iSCSI Event: FFP Timeout Event Active Tasks(0)
SAMI 9/3: iSCSI Event: Starting Full Feature Phase Timer (5)
SAMI 9/3: INTR->TGT (HEADER + DATA):
4B5A5B50: 40800000 00000000 00000000 00000000 @.....
4B5A5B60: 00000022 FFFFFFFF 0000001C 00000024 ...".....$
4B5A5B70: 00000000 00000000 00000000 00000000 .....
4B5A5B80:
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 20800000 00000000 00000000 00000000 .....
4B5A7260: 00000022 FFFFFFFF 00000024 0000001C ...".....$....
4B5A7270: 00000020 00000000 00000000 00000000 ... ..
4B5A7280:
SAMI 9/3: iSCSI Event-Det: Connection timer event (0)

```

```

SAMI 9/3: iSCSI Event: FFP Timeout Event Active Tasks(0)
SAMI 9/3: iSCSI Event: Starting Full Feature Phase Timer (5)
SAMI 9/3: INTR->TGT (HEADER + DATA):
4B5A5B50: 40800000 00000000 00000000 00000000 @.....
4B5A5B60: 00000023 FFFFFFFF 0000001C 00000025 ...#.....%
4B5A5B70: 00000000 00000000 00000000 00000000 .....
Router#
4B5A5B80:
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 20800000 00000000 00000000 00000000 .....
4B5A7260: 00000023 FFFFFFFF 00000025 0000001C ...#.....%....
4B5A7270: 00000020 00000000 00000000 00000000 ... .....
4B5A7280:
SAMI 9/3: iSCSI Event-Det: Connection timer event (0)
SAMI 9/3: iSCSI Event: FFP Timeout Event Active Tasks(0)
SAMI 9/3: iSCSI Event: Starting Full Feature Phase Timer (5)
SAMI 9/3: INTR->TGT (HEADER + DATA):
4B5A5B50: 40800000 00000000 00000000 00000000 @.....
4B5A5B60: 00000024 FFFFFFFF 0000001C 00000026 ...$......&
4B5A5B70: 00000000 00000000 00000000 00000000 .....
4B5A5B80:
SAMI 9/3: TGT->INTR:Header:
4B5
Router#
Router#
Router#A7250: 20800000 00000000 00000000 00000000 .....
4B5A7260: 00000024 FFFFFFFF 00000026 0000001C ...$......&....
4B5A7270: 00000020 00000000 00000000 00000000 ... .....
4B5A7280:
Router#
Router#
SAMI 9/3: iSCSI Event-Det: Connection timer event (0)
SAMI 9/3: iSCSI Event: FFP Timeout Event Active Tasks(0)
SAMI 9/3: iSCSI Event: Starting Full Feature Phase Timer (5)
SAMI 9/3: INTR->TGT (HEADER + DATA):
4B5A5B50: 40800000 00000000 00000000 00000000 @.....
4B5A5B60: 00000025 FFFFFFFF 0000001C 00000027 ...%......'
4B5A5B70: 00000000 00000000 00000000 00000000 .....
4B5A5B80:
SAMI 9/3: TGT->INTR:Header:
4B5A7250: 20800000 00000000 00000000 00000000 .....
4B5A7260: 00000025 FFFFFFFF 00000027 0000001C ...%......'....
4B5A7270: un al 00000020 00000000 00000000 00000000 ... .....
4B5A7280: 1
All possible debugging has been turned off
Router#sh ip iscsi session
ID          TARGET          STATE          CONNECTIONS
-----
13          LINUX            Logged In      1
=====

```

debug record-storage-module

To display debugging information related to the record storage module (RSM), use the **debug record-storage-module** command in privileged EXEC model. To disable debugging output, use the **no** form of this command.

debug record-storage-module [**all** | **dsm** | **error** | **event**]

no debug record-storage-module [**all** | **dsm** | **error** | **event**]

Syntax Description

all	Displays all RSM flags.
dsm	Displays data store manager debug information.
error	Displays RSM-related errors.
event	Displays RSM-related events.

Defaults

No default behavior or values.

Command History

Release	Modification
12.4(15)XQ	This command was introduced.
12.4(22)YE	This command was integrated into Cisco IOS Release 12.4(22)YE.
12.4(22)YE1	This command was integrated into Cisco IOS Release 12.4(22)YE1.
12.4(22)YE2	This command was integrated into Cisco IOS Release 12.4(22)YE2.
12.4(24)YE	This command was integrated into Cisco IOS Release 12.4(24)YE.
12.4(24)YE1	This command was integrated into Cisco IOS Release 12.4(24)YE1.
12.4(24)YE2	This command was integrated into Cisco IOS Release 12.4(24)YE2.
12.4(24)YE3	This command was integrated into Cisco IOS Release 12.4(24)YE3.

Usage Guidelines

This command is useful for system operators and development engineers if problems are encountered with communication between the GGSN and the SCSI target.

Examples

The following example displays RSM-related debugging at the time of the write process:

```
Router#
SAMI 9/3: %GPRSFLTMG-4-CHARGING: GSN: 32.0.0.2, TID: 0000000000000000, APN: NULL, Reason:
3, GSN GTP' Transfer Failure
Router#
SAMI 9/3: RSM-Event-Det: Write by appl GGSN for profile LINUX
SAMI 9/3: RSM-FUNC: Write Handler
SAMI 9/3: RSM-DSM-DET: Allocate write buffer
SAMI 9/3: RSM-DSM-DET: rem_len= 260966, bytes= 1178
SAMI 9/3: RSM-DSM: Write to file now
SAMI 9/3: RSM-DSM-DET: sda3:/root/00000001/00000001.dat exists
SAMI 9/3: RSM-DSM: Size of sda3:/root/00000001/00000001.dat is 780686
SAMI 9/3: RSM-DSM-DET: Write to sda3:/root/00000001/00000001.dat
SAMI 9/3: RSM-DSM-DET: sda3:/root/00000001/00000001.dat size is 781864 bytes
```

```
SAMI 9/3: RSM-DSM-DET: Call the write response handler
Router#show debug
Record Storage Module:
  RSM DSM debugging is on
  RSM DSM DETAIL debugging is on
  RSM EVENT DETAIL debugging is on
  RSM EVENT debugging is on
  RSM ERROR debugging is on
```

The following example displays RSM-related debugging at the time of the read process:

```
Router#
SAMI 9/3: RSM-Event-Det: Read by appl GGSN for profile LINUX
SAMI 9/3: RSM-DSM-DET: Allocate read buffer
SAMI 9/3: RSM-DSM-DET: Data buffer empty, read from disk
SAMI 9/3: RSM-DSM: Read from file sda3:/root/00000001/00000001.dat
SAMI 9/3: RSM-DSM-DET: Read fd is illegal in drive sda3
SAMI 9/3: RSM-DSM-DET: sda3:/root/00000001/00000001.dat exists
SAMI 9/3: RSM-DSM-DET: Read from off = 778460
SAMI 9/3: RSM-FUNC: Read in buffer
SAMI 9/3: RSM-DSM-DET: Read 262144 byte from sda3:/root/00000001/00000001.dat
SAMI 9/3: RSM-DSM-DET: Complete Record, next rec offset= 262
SAMI 9/3: RSM-Event-Det: Read record= 246 bytes
SAMI 9/3: RSM-Event-Det: Read by appl GGSN for profile LINUX
SAMI 9/3: RSM-DSM-DET: Complete Record, next rec offset= 524
SAMI 9/3: RSM-Event-Det: Read record= 246 bytes
SAMI 9/3: RSM-Event-Det: Read by appl GGSN for profile LINUX
SAMI 9/3: RSM-DSM-DET: Complete Record, next rec offset= 786
SAMI 9/3: RSM-Event-Det: Read record= 246 bytes
SAMI 9/3: RSM-Event-Det: Read by appl GGSN for profile LINUX
SAMI 9/3: RSM-DSM-DET: Complete Record, next rec offset= 1048
SAMI 9/3: RSM-Event-Det: Read record= 246 bytes
SAMI 9/3: RSM-Event-Det: Read by appl GGSN for profile LINUX
SAMI 9/3: RSM-DSM-DET: Complete Record, next rec offset= 2226
SAMI 9/3: RSM-Event-Det: Read record= 1162 bytes
SAMI 9/3: RSM-Event-Det: Read by appl GGSN for profile LINUX
SAMI 9/3: RSM-DSM-DET: Complete Record, next rec offset= 3404
SAMI 9/3: RSM-Event-Det: Read record= 1162 bytes
SAMI 9/3: RSM-Event-Det: Read by appl GGSN for profile LINUX
SAMI 9/3: RSM-DSM-DET: Next Record is not in buffer
SAMI 9/3: RSM-FUNC: Copy partial record to next buffer
SAMI 9/3: RSM-DSM-DET: copy= 0 bytes from offset= 3404 to offset= 2016
SAMI 9/3: RSM-DSM-DET: Data buffer empty, read from disk
SAMI 9/3: RSM-DSM: Read from file sda3:/root/00000001/00000001.dat
SAMI 9/3: RSM-FUNC: Read in buffer
SAMI 9/3: RSM-DSM-DET: Read 262144 byte from sda3:/root/00000001/00000001.dat
SAMI 9/3: RSM-DSM-DET: Chk if more data exists
SAMI 9/3: RSM-DSM-DET: Get next read file
SAMI 9/3: RSM-DSM-DET: sda3:/root/00000001/00000002.dat (File not found)
SAMI 9/3: RSM-DSM-DET: Get next read dir
SAMI 9/3: RSM-DSM-DET: sda3:/root/00000002/ does not exist
SAMI 9/3: RSM-DSM: Check next read drive sda3
SAMI 9/3: RSM-DSM: file sda3:/root/00000001/00000001.dat is the file currently read
SAMI 9/3: RSM-Error: Disk is empty
SAMI 9/3: RSM-DSM: Zero bytes read
SAMI 9/3: RSM-DSM-DET: Bytes in write buffer = 0
SAMI 9/3: RSM-Event: Disk is empty-No more records to Read
SAMI 9/3: RSM-Event-Det: Read record= 0 bytes
SAMI 9/3: RSM-Event-Det: Read by appl GGSN for profile LINUX
SAMI 9/3: RSM-DSM-DET: Bytes in write buffer = 0
SAMI 9/3: RSM-Event: Disk is empty-No more records to Read
SAMI 9/3: RSM-Event-Det: Read record= 0 bytes
SAMI 9/3: RSM-Event-Det: Read by appl GGSN for profile LINUX
SAMI 9/3: RSM-DSM-DET: Bytes in write buffer = 0
```

```
SAMI 9/3: RSM-Event: Disk is empty-No more records to Read
SAMI 9/3: RSM-Event-Det: Read record= 0 bytes
SAMI 9/3: RSM-Event-Det: Read by appl GGSN for profile LINUX
SAMI 9/3: RSM-DSM-DET: Bytes in write buffer = 0
SAMI 9/3: RSM-Event: Disk is empty-No more records to Read
SAMI 9/3: RSM-Event-Det: Read record= 0 bytes
SAMI 9/3: RSM-Event-Det: Read by appl GGSN for profile LINUX
SAMI 9/3: RSM-DSM-DET: Bytes in write buffer = 0
SAMI 9/3: RSM-Event: Disk is empty-No more records to Read
SAMI 9/3: RSM-Event-Det: Read record= 0 bytes
SAMI 9/3: RSM-Event-Det: Read by appl GGSN for profile LINUX
SAMI 9/3: RSM-DSM-DET: Bytes in write buffer = 0
SAMI 9/3: RSM-Event: Disk is empty-No more records to Read
SAMI 9/3: RSM-Event-Det: Read record= 0 bytes
```