



# Cable Commands: snmp through w

Revised: May 27, 2013, OL-15510-16

## New Commands

Command	Cisco IOS Software Release
test cable voice	12.3(23)BC
tos (multicast qos)	12.2(33)SCA
vrf (multicast qos)	12.2(33)SCA
weekend duration	12.3(23)BC2
weekend off	12.3(23)BC2
weekend peak-time1	12.3(23)BC2
tag	12.2(33)SCC
threshold	12.2(33)SCC
tos	12.2(33)SCC
upstream	12.2(33)SCC
upstream(config-lb-group)	12.2(33)SCC
upgrade fpga auto-upgrade	12.2(33)SCG
upgrade fpga file	12.2(33)SCG
snmp-server enable traps docsis-resil	12.2(33)SCG2
snmp-server host traps docsis-resil	12.2(33)SCG2
tlv	12.2(33)SCH

## Modified Commands

Command	Cisco IOS Software Release
upstream cable connector	12.2(33)SCB
upgrade hw-module subslot fpd file	12.2(33)SCB
weekend duration	12.2(33)SCB
weekend off	12.2(33)SCB

Command	Cisco IOS Software Release
weekend peak-time1	12.2(33)SCB
upstream cable connector	12.2(33)SCD
weekend duration	12.2(33)SCD2
weekend peak-time1	12.2(33)SCD2
snmp-server enable traps cable	12.2(33)SCG

# snmp manager

To create a DOCSIS configuration file that specifies the IP address for the Simple Network Management Protocol (SNMP) manager, use the **snmp manager** command in cable config-file configuration mode. To disable this function, use the **no** form of this command.

**snmp manager** *ip-address*

**no snmp manager**

## Syntax Description

<i>ip-address</i>	Specifies an IP address for the SNMP manager.
-------------------	---

## Defaults

No SNMP manager is defined.

## Command Modes

Cable config-file configuration (config-file)

## Command History

Release	Modification
12.1(2)EC1	This command was introduced.
12.2(4)BC1	Support was added to the Release 12.2 BC train.

## Usage Guidelines

For SNMP commands that affect the operation of the CMTS, see the *Cisco IOS Configuration Fundamentals Command Reference Guide*.

## Examples

The following example shows how to specify the IP address of the SNMP manager in a DOCSIS configuration file:

```
router(config)# cable config-file snmp.cm
router(config-file)# snmp manager 10.10.1.1
router(config-file)# exit
router(config)#
```

## Related Commands

Command	Description
<b>cable config-file</b>	Creates a DOCSIS configuration file and enters configuration file mode.
<b>access-denied</b>	Disables access to the network.
<b>channel-id</b>	Specifies upstream channel ID.
<b>cpe max</b>	Specifies CPE information.
<b>download</b>	Specifies download information for the configuration file.
<b>frequency</b>	Specifies downstream frequency.
<b>option</b>	Provides config-file options.

Command	Description
<b>privacy</b>	Specifies privacy options for baseline privacy images.
<b>service-class</b>	Specifies service class definitions for the configuration file.
<b>timestamp</b>	Enables time-stamp generation.

# snmp-server enable traps cable

To enable the sending of Simple Network Management Protocol (SNMP) traps for cable related events, use the **snmp-server enable traps cable** command in global configuration mode. To disable the sending of traps, use the **no** form of this command.

## Cisco uBR10012 Universal Broadband Router

```
snmp-server enable traps cable [admission_control] [cm-chover] [cm-onoff]
[cm-remote-query] [dmic-lock] [enfrule-violation] [hccp-failover] [hopping] [metering]
[rfswitch-polling] [sfp-link]
```

```
no snmp-server enable traps cable [admission_control] [cm-chover] [cm-onoff]
[cm-remote-query] [dmic-lock] [enfrule-violation] [hccp-failover] [hopping] [metering]
[rfswitch-polling] [sfp-link]
```

## Cisco uBR7225VXR and Cisco uBR7246VXR Universal Broadband Routers

```
snmp-server enable traps cable [admission_control] [cm-chover] [cm-onoff]
[cm-remote-query] [dmic-lock] [enfrule-violation] [hccp-failover] [hopping] [metering]
```

```
no snmp-server enable traps cable [admission_control] [cm-chover] [cm-onoff]
[cm-remote-query] [dmic-lock] [enfrule-violation] [hccp-failover] [hopping] [metering]
```

Syntax Description		
<b>admission_control</b>		Enables traps for Service Flow Admission Control (SFAC), as defined in CISCO-CABLE-ADMISSION-CTRL-MIB.
<b>cm-chover</b>		Enables traps that are sent upon completion of CMTS channel override operations, as defined in CISCO-DOCS-EXT-MIB.
<b>cm-onoff</b>		Enables traps for CM online/offline status changes, as defined in CISCO-DOCS-EXT-MIB.
<b>cm-remote-query</b>		Enables traps that are sent when the remote polling of CMs has been completed, as defined in CISCO-DOCS-REMOTE-QUERY-MIB.
<b>dmic-lock</b>		Enables traps that are sent when a cable modem fails the dynamic shared-secret security checks, as defined in CISCO-DOCS-EXT-MIB.
<b>enfrule-violation</b>		Enables traps that are sent when a user violates their quality of service (QoS) profile, as defined in the CISCO-CABLE-QOS-MONITOR-MIB.
<b>hccp-failover</b>		Enables traps for Hot Standby Connection-to-Connection Protocol (HCCP) redundancy switchover events, as defined in CISCO-CABLE-AVAILABILITY-MIB.
<b>hopping</b>		Enables traps for spectrum hopping events, as defined in CISCO-CABLE-SPECTRUM-MIB.
<b>metering</b>		Enables traps that are sent to indicate success or failure in creating the metering record file or streaming it to the collection server, as defined in CISCO-CABLE-METERING-MIB.

<b>rfswitch-polling</b>	Enables traps that are sent when the connectivity between the Cisco CMTS and the Cisco RF Switch is lost, as defined in CISCO-CABLE-AVAILABILITY-MIB.
<b>sfp-link</b>	Enables the traps that are sent when the SFP port link status changes on the Cisco Wideband SPA, and on the Cisco uBR-MC3GX60V line card, as defined in CISCO-CABLE-WIDEBAND-MIB.

**Command Default**

No SNMP traps for cable-related events are enabled. You can specify one type of trap or any combination of traps. When the **snmp-server enable traps cable** command is given without any options, all cable-related traps are enabled.

**Command Modes**

Global configuration (config)

**Command History**

Release	Modification
12.0(5)T	This command, with the <b>cm-chover</b> and <b>cm-onoff</b> options, was added.
12.0(7)XR2, 12.1(1)T	The <b>cm-remote-query</b> option, along with the CISCO-DOCS-REMOTE-QUERY-MIB MIB, was introduced.
12.1(2)EC1	This command was supported on the 12.1 EC train.
12.1(7)CX1	The <b>hopping</b> and <b>cmts-event</b> options were introduced.
12.2(4)BC1	This command was supported on the Cisco uBR10012 universal broadband router. The <b>cmts-event</b> option was also removed as redundant.
12.2(8)BC1	The <b>hccp-failover</b> option was supported on the Cisco uBR10012 router.
12.2(11)BC1	The <b>hccp-failover</b> option was supported on the Cisco uBR7200 series router.
12.2(15)BC1	The <b>enforce-rule</b> option was added to generate traps for subscribers who violate their enforce-rule QoS profile.
12.2(15)BC21	The <b>dmic-lock</b> and <b>usage</b> options were added.
12.3BC	The <b>admission_control</b> , <b>metering</b> , and <b>rfswitch-polling</b> options were added.
12.2(33)SCG	The <b>sfp-link</b> option was added to generate traps when the SFP port link status changed on the Cisco uBR10012 router.

**Usage Guidelines**

For other SNMP commands that affect the operation of the CMTS, see the [Cisco CMTS Universal Broadband Router Series MIB Specifications Guide](#).

**Examples**

The following example shows how to enable all traps for cable-related events except HCCP switchover on the CMTS:

```
Router# configure terminal
Router(config)# snmp-server enable traps cable cm-chover cm-onoff cm-remote-query hopping
Router(config)#
```

The following example shows how to enable traps for any HCCP switchovers that occur on the CMTS:

```
Router# configure terminal
Router(config)# snmp-server enable traps cable hccp-failover
Router(config)#
```

The following example shows how to enable traps for when a user violates the maximum bandwidth for the quality of service (QoS) profile specified by their enforce-rule.

```
Router# configure terminal
Router(config)# snmp-server enable traps cable enforce-rule
Router(config)#
```

The following example shows how to enable traps for to see the SFP port link status on the Cisco uBR10012 router

```
Router# configure terminal
Router(config)# snmp-server enable traps cable sfp-link
Router(config)#
```

#### Related Commands

Command	Description
<b>cable modem remote-query</b>	Enables and configures the remote-query feature to gather CM performance statistics on the CMTS.
<b>debug cable remote-query</b>	Turns on debugging to gather information from remote CMs.
<b>show cable modem remote-query</b>	Displays the statistics accumulated by the remote-query feature.

# snmp-server enable traps docsis-cm

To enable one or more Simple Network Management Protocol (SNMP) traps for DOCSIS 1.1 events, use the **snmp-server enable traps docsis-cm** command in global configuration mode. To disable the SNMP traps, use the **no** form of this command.

**Cisco uBR905 and Cisco uBR925 cable access routers, and Cisco CVA122 Cable Voice Adapter**

**snmp-server enable traps docsis-cm** [**bpi** | **bpkm** | **dccack** | **dccreq** | **dccrsp** | **dhcp** | **dsack** | **dsreq** | **dsrsp** | **dynsa** | **swupevc** | **swupfail** | **swupinit** | **swupsucc** | **tlv**]

**no snmp-server enable traps docsis-cm** [**bpi** | **bpkm** | **dccack** | **dccreq** | **dccrsp** | **dhcp** | **dsack** | **dsreq** | **dsrsp** | **dynsa** | **swupevc** | **swupfail** | **swupinit** | **swupsucc** | **tlv**]

Syntax Description	
<b>bpi</b>	(Optional) Enables Baseline Privacy Interface (BPI) initialization failure traps.
<b>bpkm</b>	(Optional) Enables Baseline Privacy Key Management (BPKM) initialization failure traps.
<b>dccack</b>	(Optional) Enables dynamic channel change acknowledgement failure traps.
<b>dccreq</b>	(Optional) Enables dynamic channel change request failure traps.
<b>dccrsp</b>	(Optional) Enables dynamic channel change response failure traps.
<b>dhcp</b>	(Optional) Enables DHCP failure traps.
<b>dsack</b>	(Optional) Enables dynamic service acknowledgement failure traps.
<b>dsreq</b>	(Optional) Enables dynamic service request failure traps.
<b>dsrsp</b>	(Optional) Enables dynamic service response failure traps.
<b>dynsa</b>	(Optional) Enables dynamic SA failure traps.
<b>swupevc</b>	(Optional) Enables secure software upgrade code verification certificate (CVC) failure traps.
<b>swupfail</b>	(Optional) Enables secure software upgrade failure traps.
<b>swupinit</b>	(Optional) Enables secure software upgrade initialization failure traps.
<b>swupsucc</b>	(Optional) Enables secure software upgrade success traps.
<b>tlv</b>	(Optional) Enables unknown Type/Length/Value (TLV) traps.

**Defaults** No traps are enabled. If no options are specified, all DOCSIS-related traps are enabled.

**Command Modes** Global configuration

Command History	Release	Modification
	12.2(15)CZ	This command was introduced on the Cisco uBR905 and Cisco uBR925 cable access routers, and the Cisco CVA122 Cable Voice Adapter.



**Usage Guidelines**

This command enables the sending of SNMP traps when DOCSIS-related events occur. Multiple traps can be enabled at the same time.

**Note**

The traps are described in the DOCS-CABLE-DEVICE-TRAP-MIB MIB, which is an extension of the CABLE DEVICE MIB that is defined in RFC 2669.

**Examples**

The following example shows the BPI+ and secure software download traps being enabled:

```
Router# config terminal
Router(config)# snmp-server enable traps docsis-cm bpi bpkw swupcvc swupfail swupinit
swupsucc
Router(config)#
```

**Related Commands**

Command	Description
<b>show snmp</b>	Checks the status of SNMP communications.
<b>snmp-server manager</b>	Starts the SNMP manager process.

## snmp-server enable traps docsis-cmts

To enable the sending of Simple Network Management Protocol (SNMP) traps for DOCSIS-related events, use the **snmp-server enable traps docsis-cmts** command in global configuration mode. To disable the sending of traps, use the **no** form of this command.

**snmp-server enable traps docsis-cmts** [*docsis-events*]

**no snmp-server enable traps docsis-cmts** [*docsis-events*]

<b>Syntax Description</b>	<div> <i>docsis-events</i> </div> <div> <p>Specifies one or more of the following DOCSIS event types:</p> <ul style="list-style-type: none"> <li>• <b>bpi</b>—Enables traps for BPI initialization failure events.</li> <li>• <b>bpkm</b>—Enables traps for BPKM failure events.</li> <li>• <b>dccack</b>—Enables traps for the failure of Dynamic Channel Change Acknowledgement (DCC-ACK) requests.</li> <li>• <b>dccreq</b>—Enables traps for the failure of Dynamic Channel Change Request (DCC-REQ) requests.</li> <li>• <b>dccrsp</b>—Enables traps for the failure of Dynamic Channel Change Response (DCC-RSP) requests.</li> <li>• <b>dsac</b>—Enables traps for the failure of Dynamic Service Acknowledgement (DSx-ACK) requests.</li> <li>• <b>dsreq</b>—Enables traps for the failure of Dynamic Service Request (DSx-REQ) requests.</li> <li>• <b>dsrsp</b>—Enables traps for the failure of Dynamic Service Response (DSx-RSP) requests.</li> <li>• <b>dynsa</b>—Enables traps for the failure of Dynamic Service Addition (DSA-ACK) requests.</li> <li>• <b>regack</b>—Enables traps for the failure of Registration Acknowledgement (REG-ACK) requests.</li> <li>• <b>regreq</b>—Enables traps for the failure of Registration Request (REG-REQ) requests.</li> <li>• <b>regrsp</b>—Enables traps for the failure of Registration Response (REG-RSP) requests.</li> </ul> </div>
<b>Defaults</b>	<div> <p>No SNMP traps for DOCSIS-related events are enabled. When the <b>snmp-server enable traps docsis-cmts</b> command is given without any options, all DOCSIS-related traps are enabled.</p> </div>
<b>Command Modes</b>	<div> <p>Global configuration (config)</p> </div>

Command History	Release	Modification
	12.1(7)CX1, 12.2(4)BC1	This command, along with the <a href="#">DOCS-CABLE-DEVICE-TRAP-MIB</a> MIB, was introduced.

**Usage Guidelines**

This command enables traps that are defined in the [DOCS-CABLE-DEVICE-TRAP-MIB](#) MIB. For other SNMP commands that affect the operation of the CMTS, see the *Cisco IOS Configuration Fundamentals Command Reference Guide*.

**Examples**

The following example shows how to enable traps for the failure of DOCSIS registration-related events on the CMTS:

```
router(config)# snmp-server enable traps docsis-cmts reqack reqreq regrsp
router(config)#
```

Related Commands	Command	Description
	<b>snmp-server enable traps cable</b>	Enables traps for cable-related events.

# snmp-server enable traps docsis-resil

To enable Simple Network Management Protocol (SNMP) traps for Wideband Resiliency specific events on the Cisco CMTS, use the **snmp-server enable traps docsis-resil** command in global configuration mode. To disable SNMP traps, use the **no** form of this command.

**snmp-server enable traps docsis-resil** [*resil-events*]

**no snmp-server enable traps docsis-resil** [*resil-events*]

<b>Syntax Description</b>	<p><i>resil-events</i></p> <p>Specifies one or more of the following wideband resiliency specific event types:</p> <ul style="list-style-type: none"> <li>• <b>cm-pmode</b>—Enables the wideband resiliency cable modem partial service trap.</li> <li>• <b>cm-recover</b>—Enables the wideband resiliency cable modem full service trap.</li> <li>• <b>event</b>—Enables the wideband resiliency event trap.</li> <li>• <b>rf-down</b>—Enables the wideband resiliency RF channel down status trap.</li> <li>• <b>rf-up</b>—Enables the wideband resiliency RF channel up status trap.</li> </ul>				
<b>Defaults</b>	No SNMP traps for wideband resiliency specific events are enabled. When the <b>snmp-server enable traps docsis-resil</b> command is given without any options, all wideband resiliency specific traps are enabled.				
<b>Command Modes</b>	Global configuration (config)				
<b>Command History</b>	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>12.2(33)SCG2</td><td>This command was introduced.</td></tr> </table>	Release	Modification	12.2(33)SCG2	This command was introduced.
Release	Modification				
12.2(33)SCG2	This command was introduced.				
<b>Usage Guidelines</b>	<p>This command enables traps that are defined in the <a href="#">CISCO-DOCS-EXT-MIB.my</a> MIB.</p> <p>For other SNMP commands that affect the operation of the Cisco CMTS, see the <i>Cisco IOS Configuration Fundamentals Command Reference Guide</i>.</p>				
<b>Examples</b>	<p>The following example shows how to enable traps when the RF channel logical status changes to DOWN on the Cisco CMTS:</p> <pre>router(config)# snmp-server enable traps docsis-resil rf-down router(config)#</pre>				

**Associated Features** The `snmp-server enable traps docsis-resil` command is associated with the [Wideband Modem Resiliency](#) feature.

Related Commands	Command	Description
	<code>cable resiliency traps-interval</code>	Sets the interval at which traps must be sent for Wideband Resiliency related events for each cable modem on the Cisco CMTS.
	<code>show cable modem resiliency</code>	Displays resiliency status of the cable modem in resiliency mode on the Cisco CMTS router.
	<code>snmp-server enable traps cable</code>	Enables traps for cable-related events on the Cisco CMTS.

# snmp-server host traps docsis-resil

To enable Wideband Resiliency trap notifications to a specific Simple Network Management Protocol (SNMP) host on the Cisco CMTS, use the **snmp-server host traps docsis-resil** command in global configuration mode. To disable Wideband Resiliency trap notifications to a specific SNMP host, use the **no** form of this command.

**snmp-server host *ipaddr* traps *string* docsis-resil**

**no snmp-server host *ipaddr* traps *string***

Syntax Description	<i>ipaddr</i>	IPv4 or IPv6 address of the SNMP notification host.
	<i>string</i>	SNMPv1 community string, SNMPv2c community string, or SNMPv3 username.

**Command Default** Wideband Resiliency trap notifications are not sent to an SNMP host.

**Command Modes** Global configuration (config)

Command History	Release	Modification
	12.2(33)SCG2	This command was introduced.

**Usage Guidelines** Use this command to start or stop sending Wideband Resiliency traps to a specific SNMP host.

**Examples** The following example shows how to enable Wideband Resiliency trap notifications to an SNMP host:

```
Router# configure terminal
Router(config)# snmp-server host 172.17.2.0 traps snmp-host01 docsis-resil
```

**Associated Features** The **snmp-server host traps docsis-resil** command is associated with the [Wideband Modem Resiliency](#) feature.

Related Commands	<b>cable resiliency traps-interval</b>	Sets the interval at which traps must be sent for Wideband Resiliency related events for each cable modem on the Cisco CMTS.
	<b>show cable modem resiliency</b>	Displays resiliency status of the cable modem in resiliency mode on the Cisco CMTS router.
	<b>snmp-server enable traps docsis-resil</b>	Enables SNMP Wideband Resiliency traps for Wideband Resiliency specific events on the Cisco CMTS.

# switchover pxf restart

To configure the maximum number of PXF crashes that are allowed within a specified time period, use the **switchover pxf restart** command in redundancy configuration (main-cpu) mode. To reset the router to its default values, use the **no** form of this command.

**switchover pxf restart** *number-of-crashes time-period*

**no switchover pxf restart**

## Syntax Description

<i>number-of-crashes</i>	Maximum number of PXF crashes that are allowed within the specified time period. If the PXF processors crash this many times within the given time period, the router switches over to the redundant PRE1 module. The valid range is 1 to 25, with a default of 2.
<i>time-period</i>	Time period, in hours, that PXF crashes are monitored. The valid range is 0 to 120 hours, with a default of 5.

## Defaults

2 PXF crashes within 5 hours are allowed (**switchover pxf restart 2 5**)

## Command Modes

Redundancy configuration, main-cpu mode (config-r-mc)

## Command History

Release	Modification
12.2(15)BC2	This command was introduced for the Cisco uBR10012 router.

## Usage Guidelines

The PXF processors that are onboard the PRE1 module automatically restart themselves if a crash occurs. Occasional crashes could be expected, but repeated crashes could indicate a hardware problem.

The **switchover pxf restart** command specifies the maximum number of times that a PXF processor can crash during a specified time period before the router switches over to the redundant PRE1 module. If the PXF processors crash this number of times, the router assumes a hardware problem and initiates a switchover to the redundant PRE1 module.



### Note

When a switchover occurs because of repeated PXF crashes, the router displays the following system message: C10KEVENTMGR-3-PXF\_FAIL\_SWITCHOVER: Multiple PXF failures, switchover to redundant PRE initiated.

## Examples

The following example shows how to configure the router so that if five PXF crashes occur within a one-hour period, the router should initiate a switchover to the redundant PRE1 module.

```
Router# config t
Router(config)# redundancy
Router(config-r)# main-cpu
Router(config-r-mc)# switchover pxf restart 5 1
Router(config-r-mc)# exit
```

```
Router(config-f)# exit  
Router(config)#
```

**Related Commands**

Command	Description
<b>main-cpu</b>	Enters main-CPU redundancy configuration mode, so that you can configure the synchronization of the active and standby Performance Routing Engine (PRE1) modules.
<b>redundancy</b>	Configures the synchronization of system files between the active and standby PRE1 modules.
<b>redundancy force-failover main-cpu</b>	Forces a manual switchover between the active and standby PRE1 modules.



# switchover timeout

To configure the switchover timeout period of the PRE1 module, use the **switchover timeout** command in redundancy configuration (main-cpu) mode. To reset the timeout period to its default value, use the **no** form of this command.

**switchover timeout** *timeout-period*

**no switchover timeout**

## Syntax Description

<i>timeout-period</i>	Specifies the timeout, in milliseconds. The valid range is 0 to 25000 milliseconds (25 seconds), where 0 specifies no timeout period.
-----------------------	---

## Defaults

The default is 0.

## Command Modes

Redundancy configuration, main-cpu mode

## Command History

Release	Modification
12.2(11)BC3	This command was introduced for the Cisco uBR10012 router.

## Usage Guidelines

The **switchover timeout** command specifies how long the standby PRE module should wait when it does not detect a heartbeat from the active PRE module before initiating a switchover and assuming responsibility as the active PRE module. If set to 0, the standby PRE module initiates a switchover immediately when the active PRE module misses a scheduled heartbeat.

## Examples

The following example shows how to set the timeout period to 60 milliseconds:

```
Router# config t
Router(config)# redundancy
Router(config-r)# main-cpu
Router(config-r-mc)# switchover timeout 60
Router(config-r-mc)# exit
Router(config-f)# exit
Router(config)#
```

## Related Commands

Command	Description
<b>main-cpu</b>	Enters main-CPU redundancy configuration mode, so that you can configure the synchronization of the active and standby Performance Routing Engine (PRE1) modules.

Command	Description
<b>redundancy</b>	Configures the synchronization of system files between the active and standby PRE1 modules.
<b>redundancy force-failover main-cpu</b>	Forces a manual switchover between the active and standby PRE1 modules.

# tag

To add a tag to a restricted load balancing group (RLBG), use the **tag** command in the config-lb-group configuration mode. To remove the tag, use the **no** form of this command.

**tag** *tag-name*

**no tag** *tag-name*

<b>Syntax Description</b>	<i>tag-name</i>	The name of the tag that has been created and configured for the load balancing group.
---------------------------	-----------------	--

<b>Command Default</b>	No default behavior or values.
------------------------	--------------------------------

<b>Command Modes</b>	DOCSIS load balancing group mode (config-lb-group)
----------------------	--

<b>Command History</b>	Release	Modification
	12.2(33)SCC	This command was introduced.

<b>Usage Guidelines</b>	You can use the <b>tag</b> command to add a tag to a RLBG, only if the tag is already created using the <b>cable tag</b> command for the DOCSIS load balancing group on the CMTS.
-------------------------	---

<b>Examples</b>	The following example shows how to add a tag to a RLBG using the <b>tag</b> command.
-----------------	--

```
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# cable load-balance docsis-group 1
Router(config-lb-group)# restricted
Router(config-lb-group)# tag CSCO
Router(config-lb-group)#
```

<b>Related Commands</b>	Command	Description
	<b>cable load-balance docsis-group</b>	Configures a DOCSIS load balancing group on the CMTS.
	<b>show cable load-balance docsis-group</b>	Displays real-time configuration, statistical, and operational information for load balancing operations on the router.
	<b>cable tag</b>	Configures a tag for a DOCSIS load balancing group on the CMTS.

## test cable dcc (Supporting Dynamic Channel Change)

To move a specified cable modem or a group of cable modems to another channel, or to test Dynamic Channel Change (DCC) for load balancing on the Cisco CMTS, use the following command in privileged EXEC mode.

```
test cable dcc {source-interface [cable slot/subslot/cable-interface-index | integrated-cable
slot/subslot/cable-interface-index | modular-cable slot/subslot/cable-interface-index] | sid |
ip-addr | mac-addr | frequency frequency}
{destination-interface [cable slot/subslot/cable-interface-index | integrated-cable
slot/subslot/cable-interface-index | modular-cable slot/subslot/cable-interface-index]
upstream-port}
{init-tech | force | tlv}
```

### Syntax Description

<i>source-interface</i>	Source interface of the cable modem. Use any one of the following options: <ul style="list-style-type: none"> <li><b>cable</b>—Specifies the name of the source downstream interface for the DCC transaction.</li> <li><b>integrated-cable</b>—Specifies the name of the integrated-cable interface to which the cable modem belongs.</li> <li><b>modular-cable</b>—Specifies the name of the modular-cable interface to which the cable modem belongs.</li> <li><i>slot/subslot/cable-interface-index</i>—Slot, subslot, and downstream controller number assigned to the cable modem.</li> </ul>
<b>sid</b>	(Optional) Specifies the primary Service ID (sid) value of the cable modem for that interface.
<b>ip-addr</b>	Specifies the IP address of the cable modem to be moved for DCC test.
<b>mac-addr</b>	Specifies the MAC address of the cable modem to be moved for DCC test.
<b>frequency</b> <i>frequency</i>	Specifies the DCC downstream frequency parameter. <i>frequency</i> —New downstream frequency in Hz. The valid range is between 55000000 to 1050000000 Hz.
<i>destination-interface</i>	Destination interface of the cable modem. Use any one of the following options: <ul style="list-style-type: none"> <li><b>cable</b>—Specifies the name of the target or destination downstream interface to which the cable modem should be moved.</li> <li><b>integrated-cable</b>—Specifies the name of the integrated-cable interface to which the cable modem should be moved.</li> <li><b>modular-cable</b>—Specifies the name of the modular-cable interface to which the cable modem should be moved.</li> <li><i>slot/subslot/cable-interface-index</i>—Slot, subslot, and downstream controller number assigned to the cable modem.</li> </ul>
<b>upstream-port</b>	Specifies the upstream port of the destination interface.

<i>init-tech</i>	(Optional) DOCSIS 3.0 GLBG DCC initialization techniques. The valid range is from 1 to 4.  <b>Note</b> If <i>init-tech</i> is not specified, its value is taken as 0.
<i>force</i>	(Optional) Target modem or group of modems that are forced to move to the specified downstream interface or upstream channel.  <b>Note</b> This option is available only when <i>init-tech</i> is set to 0 and is used to move cable modems with Internet Group Management Protocol (IGMP) or Resource-reservation protocol (RSVP) configuration.  <b>Note</b> This option cannot be used with the <i>tlv</i> option.
<i>tlv</i>	(Optional) Specifies the type-length-value (TLV) in a DCC request message. This is represented as HEX data.  <b>Note</b> <i>force</i> option is not available if the <i>tlv</i> option is used.

### Command Default

Test functions are disabled by default.

### Command Modes

Privileged EXEC (#)

### Command History

Release	Modification
12.3(17a)BC	This command was introduced on the Cisco uBR10012 router and the Cisco uBR7246VXR router, with supporting broadband processing engines (BPEs) or cable interface line cards on the respective routers.
12.2(33)SCF2	The <i>force</i> argument was introduced.

### Examples

The following examples illustrate DCC verification, using the **test cable dcc** command.

The following example shows how to move a target cable modem, specified by MAC address, IP address, or the primary SID value on the source interface to a target downstream with the specified frequency using DCC initialization technique 0:

```
Router# test cable dcc [<mac-addr>|<ip-addr>|<cable-if-src><sid>] frequency <freq-value>
Frequency-value: <55000000-858000000> New Downstream Frequency in HZ.
```

The following example shows how to move a target cable modem, specified by MAC address, IP address, or the primary SID value on the source interface to a upstream channel on a target downstream with the DCC-REQ TLV given in the specified HEX data.

```
Router# test cable dcc [<mac-addr>|<ip-addr>|<cable-if-src><sid>] TLV <Hex-data>
```

The following example shows how to move all cable modems on a source interface to a target downstream with the specified frequency using DCC initialization technique 0.

```
Router# test cable dcc <cable-if-src> frequency <frequency-value>
Frequency-value: <55000000-858000000> New Downstream Frequency in HZ.
```

The following example shows how to force a cable modem to move to a modular-cable interface 7/0/0:2 with init-tech set to 0:

```
Router# test cable dcc 0023.4ed0.db25 modular-Cable 7/0/0:0 0 0 force
Router# show cable modem 0023.4ed0.db25
```

Load for five secs: 1%/0%; one minute: 1%; five minutes: 1%

Time source is hardware calendar, \*10:00:48.167 SGT Wed Nov 16 2011

MAC Address	IP Address	I/F	MAC State	Prim RxPwr Sid (dBmv)	Timing Offset	Num CPE	I P
0023.4ed0.db25	30.11.2.118	C7/0/0/U0	offline	19 0.50	1862	0	N

### Usage Guidelines

This command is subject to the restrictions and prerequisites described in [Load Balancing, Dynamic Channel Change, and Dynamic Bonding Change on the Cisco CMTS Routers](#).

The Cisco CMTS does not support the *force* option for **test cable dcc tlv** command where *tlv* is a HEXDATA node.

### Related Commands

Command	Description
<b>cable load-balance group (Supporting Dynamic Channel Change)</b>	Sets multiple parameters for load balancing with DCC.
<b>cable load-balance group dcc-init-technique (Supporting Dynamic Channel Change)</b>	Sets the initialization technique for Dynamic Channel Change (DCC) for load balancing.
<b>cable load-balance group policy (Supporting Dynamic Channel Change)</b>	Sets the type of service flow policy (PacketCable MultiMedia (PCMM) or Unsolicited Grant Service (UGS)) for use with load balancing and DCC.
<b>cable load-balance group threshold (Supporting Dynamic Channel Change)</b>	Sets the threshold levels for corresponding service flow types for the specified load balancing group, supporting Dynamic Channel Change (DCC).
<b>show controllers cable</b>	Displays statistics for Dynamic Channel Change (DCC) for load balancing.
<b>show cable modem</b>	Displays the information about registered and unregistered cable modems.

# test cable voice

To manually set voice tag of a cable modem, use the test cable voice command in privileged EXEC mode.

```
test cable voice {mac-addr | ip-addr}
```

Syntax Description	<i>mac-addr</i>	Specifies the MAC address of an individual CM, or of any CPE devices or hosts behind that CM.
	<i>ip-addr</i>	Specifies the IP address of an individual CM, or of any CPE devices or hosts behind that CM.

Command Default	No voice tags are enabled
-----------------	---------------------------

Command Modes	Privileged EXEC (#)
---------------	---------------------

Command History	Release	Modification
	12.3(23)BC	This command was introduced for the Cisco uBR10012 router.

Usage Guidelines	The <b>test cable voice</b> command is intended for use by Cisco Systems technical support personnel.
------------------	---

Examples	The following example shows how to enable the voice tag of a cable modem:
----------	---

```
Router# test cable voice 209.165.200.225
```

Related Commands	Commands	Description
	show cable modem voice	Displays the detected voice-enabled modems.
	clear cable modem voice	Clears the voice tag that is set for a cable modem.

# test packetcable gate create

To create a test PacketCable or PCMM gate, use the **test packetcable gate create** command in privileged EXEC mode. The number of requested gates is created with the subscriber address, which must be specified. The gates created with this command are used by other test commands, such as gate-info or gate-delete, to test functionality.

**test packetcable gate create** *subscriber addr* [**dqos** | **multimedia**] [ *# of gates* ]

## Syntax Description

<i>subscriber addr</i>	IP address of the subscriber for whom to create test packets.
<b>dqos</b>	Specifies a PacketCable Dynamic Quality of Service (DQoS) CMS.
<b>multimedia</b>	Specifies a PCMM CMS.
<i># of gates</i>	Designates the number of test gates to create for the specified IP address.

## Command Modes

Privileged EXEC (#)

## Command History

Release	Modification
12.3(13a)BC	This command was enhanced to support PCMM on the Cisco uBR10012 router and the Cisco uBR7246VXR router.

## Usage Guidelines

This command is supported for PC or PCMM on the Cisco CMTS.

## Related Commands

Command	Description
<b>test packetcable gc client-accept</b>	Sends a client-accept request to a Packetcable or PCMM Call Management Server (CMS).
<b>test packetcable gc gate-alloc</b>	Sends a gate allocation message to the Packetcable DQoS processor
<b>test packetcable gc gate-delete</b>	Sends a gate-delete request to either the Packetcable Multimedia or PC DQoS message processor.
<b>test packetcable gc gate-info</b>	Sends a gate information request to the Packetcable Multimedia message processor
<b>test packetcable gc gate-set multimedia</b>	Send a test gate-set request to the Packetcable Multimedia message processor.
<b>test packetcable gc initiate</b>	Adds a test Call Management Server (CMS) for either PacketCable (DQoS) or PCMM.



# test packetcable gc client-accept

To send a client-accept request to a Packetcable or PCMM Call Management Server (CMS), and to initiate a session with that server, use the **test packetcable gc client-accept** command in Privileged EXEC mode.

**test packetcable gc client-accept**

**Command Modes** Privileged EXEC (#)

Command History	Release	Modification
	12.3(13a)BC	This command was enhanced to support PCMM on the Cisco uBR10012 router and the Cisco uBR7246VXR router.

**Usage Guidelines** This command is supported for PC or PCMM on the Cisco CMTS. The CMS-to-client session that starts as a result of using this command can be viewed with multiple **show**, **debug** and **test** commands.

**Examples** The following example illustrates a test client-accept request:

```
Router# test packetcable gc client-accept
```

Related Commands	Command	Description
	<b>test packetcable gc gate-alloc</b>	Sends a gate allocation message to the Packetcable DQoS processor
	<b>test packetcable gc gate-delete</b>	Sends a gate-delete request to either the Packetcable Multimedia or PC DQoS message processor.
	<b>test packetcable gc gate-info</b>	Sends a gate information request to the Packetcable Multimedia message processor
	<b>test packetcable gc gate-set multimedia</b>	Send a test gate-set request to the Packetcable Multimedia message processor.
	<b>test packetcable gc initiate</b>	Adds a test Call Management Server (CMS) for either PacketCable (DQoS) or PCMM.
	<b>test packetcable gate create</b>	Creates a test PacketCable or PCMM gate.

# test packetcable gc gate-alloc

To send a gate allocation message to the Packetcable DQoS processor, use the **test packetcable gc gate-alloc** command in privileged EXEC mode. This test message generates from the gate controller that is specified by the GC address value. The gate is allocated for the subscriber address specified in the command.

**test packetcable gc gate-alloc** *gc-addr subscriber-addr*

## Syntax Description

<i>gc-addr</i>	IP address for the gate controller to test.
<i>subscriber-addr</i>	IP address for the subscriber to test.

## Command Modes

Privileged EXEC (#)

## Command History

Release	Modification
12.3(13a)BC	This command was enhanced to support PCMM on the Cisco uBR10012 router and the Cisco uBR7246VXR router.

## Usage Guidelines

This command is supported for PC or PCMM on the Cisco CMTS.

## Related Commands

Command	Description
<b>test packetcable gc client-accept</b>	Sends a client-accept request to a Packetcable or PCMM Call Management Server (CMS).
<b>test packetcable gc gate-delete</b>	Sends a gate-delete request to either the Packetcable Multimedia or PC DQoS message processor.
<b>test packetcable gc gate-info</b>	Sends a gate information request to the Packetcable Multimedia message processor
<b>test packetcable gc gate-set multimedia</b>	Send a test gate-set request to the Packetcable Multimedia message processor.
<b>test packetcable gc initiate</b>	Adds a test Call Management Server (CMS) for either PacketCable (DQoS) or PCMM.
<b>test packetcable gate create</b>	Creates a test PacketCable or PCMM gate.

# test packetcable gc gate-delete

To send a gate-delete request to either the Packetcable Multimedia or PC DQoS message processor, use the **test packetcable gc gate-delete** command in privileged EXEC mode. The request includes the subscriber ID and gate ID specified in the command. The message is sent to either the DQoS or PCMM processor depending on the type of server that was used when the GC address was added.

**test packetcable gc gate-delete** *gc-addr subscriber-id gate-id*

<b>Syntax Description</b>	<i>gc addr</i>	IP address of the gate controller.
	<i>subscriber-id</i>	The subscriber identifier to be inserted into the gate-set message.
	<i>gate-id</i>	Gate identifier for the gate that generates the test message.

<b>Command Modes</b>	Privileged EXEC (#)
----------------------	---------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.3(13a)BC	This command was enhanced to support PCMM on the Cisco uBR10012 router and the Cisco uBR7246VXR router.

<b>Usage Guidelines</b>	This command is supported for PC or PCMM on the Cisco CMTS.
-------------------------	---

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>test packetcable gc client-accept</b>	Sends a client-accept request to a Packetcable or PCMM Call Management Server (CMS).
	<b>test packetcable gc gate-alloc</b>	Sends a gate allocation message to the Packetcable DQoS processor
	<b>test packetcable gc gate-info</b>	Sends a gate information request to the Packetcable Multimedia message processor
	<b>test packetcable gc gate-set multimedia</b>	Send a test gate-set request to the Packetcable Multimedia message processor.
	<b>test packetcable gc initiate</b>	Adds a test Call Management Server (CMS) for either PacketCable (DQoS) or PCMM.
	<b>test packetcable gate create</b>	Creates a test PacketCable or PCMM gate.

# test packetcable gc gate-info

To send a gate information request to the Packetcable Multimedia message processor, as if originating from the gate controller address specified, use the **test packetcable gc gate-info** command in privileged EXEC mode. The gate ID must be specified when using this command.

**test packetcable gc gate-info** *gc-addr gate-id*

## Syntax Description

<i>gc addr</i>	IP address of the gate controller.
<i>gate-id</i>	Gate identifier for the gate that generates the test message.

## Command Modes

Privileged EXEC (#)

## Command History

Release	Modification
12.3(13a)BC	This command was enhanced to support PCMM on the Cisco uBR10012 router and the Cisco uBR7246VXR router.

## Usage Guidelines

This command is supported for PC or PCMM on the Cisco CMTS.

## Related Commands

Command	Description
<b>test packetcable gc client-accept</b>	Sends a client-accept request to a Packetcable or PCMM Call Management Server (CMS).
<b>test packetcable gc gate-alloc</b>	Sends a gate allocation message to the Packetcable DQoS processor
<b>test packetcable gc gate-delete</b>	Sends a gate-delete request to either the Packetcable Multimedia or PC DQoS message processor.
<b>test packetcable gc gate-set multimedia</b>	Send a test gate-set request to the Packetcable Multimedia message processor.
<b>test packetcable gc initiate</b>	Adds a test Call Management Server (CMS) for either PacketCable (DQoS) or PCMM.
<b>test packetcable gate create</b>	Creates a test PacketCable or PCMM gate.

# test packetcable gc gate-set multimedia

To send a test gate-set request to the Packetcable Multimedia message processor, as if it comes from the gate controller, use the **test packetcable gc gate-set multimedia** command in privileged EXEC mode.

The gate ID, subscriber ID, gate state and traffic profile information are included in the test gate-set message. Other traffic profile information, like traffic profile details, display static values by default.

**test packetcable gc gate-set** *gc-addr* **multimedia** *subscriber-id* *state* *gate-id* *traffic-type* *service-class-name*

## Syntax Description

<i>gc addr</i>	IP address of the gate controller.
<b>dqos</b>	Specifies a PacketCable Dynamic Quality of Service (DQoS) Call Management Server (CMS).
<b>multimedia</b>	Specifies a PCMM Call Management Server (CMS).
<i>subscriber-id</i>	The subscriber identifier to be inserted into the gate-set message.
<i>state</i>	State for the test gate, either Committed, Authorized, or Reserved.
<i>gate-id</i>	The gate identifier to be inserted into the gate-set message.
<i>traffic-type</i>	Traffic profile information to be inserted into the gate-set message.
<i>service-class-name</i>	Service class information for the gate-set message.

## Command Modes

Privileged EXEC (#)

## Command History

Release	Modification
12.3(13a)BC	This command was introduced to support PCMM on the Cisco uBR10012 router and the Cisco uBR7246VXR router.

## Usage Guidelines

This command is supported for PCMM on the Cisco CMTS.

## Related Commands

Command	Description
<b>test packetcable gc client-accept</b>	Sends a client-accept request to a Packetcable or PCMM Call Management Server (CMS).
<b>test packetcable gc gate-alloc</b>	Sends a gate allocation message to the Packetcable DQoS processor
<b>test packetcable gc gate-delete</b>	Sends a gate-delete request to either the Packetcable Multimedia or PC DQoS message processor.
<b>test packetcable gc gate-info</b>	Sends a gate information request to the Packetcable Multimedia message processor
<b>test packetcable gc initiate</b>	Adds a test Call Management Server (CMS) for either PacketCable (DQoS) or PCMM.
<b>test packetcable gate create</b>	Creates a test PacketCable or PCMM gate.

# test packetcable gc initiate

To add a test Call Management Server (CMS) for either PacketCable (DQoS) or PCMM, use the **test packetcable gc initiate** command in privileged EXEC mode.

**test packetcable gc initiate** [**dqos** | **multimedia**] *GC-IP*

<b>Syntax Description</b>	<b>dqos</b>	(Optional) Specifies a PacketCable Dynamic Quality of Service (DQoS) CMS.
	<b>multimedia</b>	(Optional) Specifies a PCMM CMS.
	<i>GC-IP</i>	IP address of the gate controller.

<b>Command Modes</b>	Privileged EXEC (#)
----------------------	---------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.3(13a)BC	This command was enhanced to support PCMM on the Cisco uBR10012 router and the Cisco uBR7246VXR router.

<b>Usage Guidelines</b>	This command is supported for PC or PCMM on the Cisco CMTS. The type of CMS added determines the type of gate that is created. This gate type is used in all future PacketCable <b>test</b> commands that use the gate controller address specified.
-------------------------	--

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>test packetcable gc client-accept</b>	Sends a client-accept request to a Packetcable or PCMM Call Management Server (CMS).
	<b>test packetcable gc gate-alloc</b>	Sends a gate allocation message to the Packetcable DQoS processor
	<b>test packetcable gc gate-delete</b>	Sends a gate-delete request to either the Packetcable Multimedia or PC DQoS message processor.
	<b>test packetcable gc gate-info</b>	Sends a gate information request to the Packetcable Multimedia message processor
	<b>test packetcable gc gate-set multimedia</b>	Send a test gate-set request to the Packetcable Multimedia message processor.
	<b>test packetcable gate create</b>	Creates a test PacketCable or PCMM gate.

# threshold

To specify the load limit beyond which load balancing occurs, use the **threshold** command in the config-lb-group configuration mode. To remove the specified load limit, use the **no** form of this command.

```
threshold {load {minimum 1-100 | 1-100} | pcmm 1-100 | stability 0-100 | ugs 1-100}
```

```
no threshold {load {minimum | 1-100} | pcmm 1-100 | stability 0-100 | ugs 1-100}
```

## Syntax Description

<b>load {minimum}</b>	Specifies interface load threshold settings as a percentage value. You can also set minimum number of modems/flows difference ranging from 1 to 100 before load balancing starts.
<b>pcmm</b>	Specifies PCMM service flow threshold as a percentage value.
<b>stability</b>	Specifies stability condition detection threshold as a percentage value.
<b>ugs</b>	Specifies stability detection threshold as a percentage value.

## Command Default

No default behavior or values.

## Command Modes

DOCSIS load balancing group mode (config-lb-group)

## Command History

Release	Modification
12.2(33)SCC	This command was introduced.

## Examples

The following example shows how to configure the threshold of the DOCSIS LBG using the **threshold** command.

```
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# cable load-balance docsis-group 1
Router(config-lb-group)# threshold load minimum 10
Router(config-lb-group)#
```

## Related Commands

Command	Description
<b>cable load-balance docsis-group</b>	Configures a DOCSIS load balancing group on the CMTS.
<b>show cable load-balance docsis-group</b>	Displays real-time configuration, statistical, and operational information for load balancing operations on the router.

# timestamp

To create a DOCSIS configuration file that enables timestamp generation, use the **timestamp** command in cable config-file configuration mode. To disable this function, use the **no** form of this command.

**timestamp**

**no timestamp**

**Syntax Description** This command has no arguments or keywords.

**Command Default** No default behaviors or values

**Command Modes** Cable config-file configuration (config-file)

Command History	Release	Modification
	12.1(2)EC1	This command was introduced.
	12.2(4)BC1	Support was added to the Release 12.2 BC train.

**Usage Guidelines** The DOCSIS specification supports the optional time-stamping of DOCSIS configuration files by adding a field to the file that shows the time that the file was sent to the CM. This prevents someone from trying to subvert DOCSIS security by replaying a valid DOCSIS configuration file to another CM. The timestamp is expressed as the number of seconds since midnight on January 1, 1900.

**Examples** The following example shows how to enable timestamp generation for the DOCSIS configuration file.

```
router(config)# cable config-file upgrade.cm
router(config-file)# timestamp
router(config-file)# exit
router(config)#
```

Related Commands	Command	Description
	<b>cable config-file</b>	Creates a DOCSIS configuration file and enters configuration file mode.
	<b>access-denied</b>	Disables access to the network.
	<b>channel-id</b>	Specifies upstream channel ID.
	<b>cpe max</b>	Specifies CPE information.
	<b>download</b>	Specifies download information for the configuration file.
	<b>frequency</b>	Specifies downstream frequency.
	<b>option</b>	Provides config-file options.



Command	Description
<b>privacy</b>	Specifies privacy options for baseline privacy images.
<b>service-class</b>	Specifies service class definitions for the configuration file.
<b>snmp manager</b>	Specifies Simple Network Management Protocol (SNMP) options.

# tlv

To configure a TLV type tag matching rule, use the **tlv** command in CMTS-tag configuration mode.

**tlv** *type value*

<b>Syntax Description</b>	<i>type</i>	Specifies the type identifier. It can be one of the following: <ul style="list-style-type: none"> <li>• <b>mracs</b> - Multiple Receive Channel Support.</li> <li>• <b>mtcs</b> - Multiple Transmit Channel Support.</li> <li>• <b>ufrs</b> - Upstream Frequency Range Support.</li> </ul>
	<i>value</i>	Specifies a decimal number value for the type tag. The range is 0 to 255.

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	CMTS tag configuration mode (config-cmts-tag).
----------------------	--

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.2(33)SCH	This command was introduced.

**Examples** The following example shows how to configure the **tlv** command:

```
Router# enable
Router(config)# cable tag 1
Router(config-cmts-tag)# tlv mracs 3
```

**Related Commands**

Command	Description
<b>cable tag</b>	To configure a tag for a DOCSIS load balancing group on the CMTS.

# tos

To configure the Type of Service (ToS) byte in the header of Layer 2 tunneled packets, use the **tos** command in DEPI tunnel configuration mode. To disable a configured ToS value, use the **no** form of this command.

**tos** *value*

**no tos** *value*

## Syntax Description

<i>value</i>	Value of the ToS byte for IP packets in a Layer 2 Tunnel Protocol version 3 (L2TPv3) data session. The valid values range from 0 to 255. The default value is 0.
--------------	--

## Command Default

None

## Command Modes

DEPI tunnel configuration

## Command History

Release	Modification
12.2(33)SCC	This command was introduced.

## Usage Guidelines

The **tos** command allows you to manually configure the value of the ToS byte used in the headers of Layer 2 tunneled packets.

## Examples

The following example shows how to assign a ToS value of 100:

```
Router# configure terminal
Router(config)# depi-tunnel rf6
Router(config-depi-tunnel)# tos 100
```

## Related Commands

Command	Description
<b>depi-tunnel</b>	Specifies the name of the depi-tunnel and enters the DEPI tunnel configuration mode.

## tos (multicast qos)

To set type of service (ToS) low byte, high byte, and mask values within a multicast QoS group, use the **tos** command in multicast QoS configuration mode. To disable the type of service, use the **no** form of this command.

**tos** *low-byte high-byte mask*

**no tos** *low-byte high-byte mask*

<b>Syntax Description</b>	<i>low-byte</i>	Specifies the minimum ToS data bytes for a multicast QoS group. The valid range is 0–255.
	<i>high-byte</i>	Specifies the maximum ToS data bytes for a multicast QoS group. The valid range is 0–255.
	<i>mask</i>	Specifies the ToS mask for a multicast QoS group. The valid range is 0–255.

**Command Default** ToS parameters are not defined for a specific multicast QoS group.

**Command Modes** Multicast QoS configuration (config-mqos)

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.2(33)SCA	This command was introduced.

**Usage Guidelines** The three precedence bits in the ToS byte in the IP header specifies a class of service assignment for each packet. Those packets with the precedence bit set in the ToS field are given higher priority.

**Examples** The following example defines the low and high ToS rates and the mask value using the **tos** command:

```
Router(config)# cable multicast qos group 20 priority 55 global
Router(config-mqos)# tos 1 6 15
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>cable multicast qos group</b>	Specifies and configures a cable multicast QoS group.
	<b>show interface bundle multicast-sessions</b>	Displays multicast session information for a specific virtual cable bundle.
	<b>show interface cable multicast-sessions</b>	Displays multicast session information for a specific cable interface.

# upgrade fpga auto-upgrade

To perform a firmware Field-Programmable Gate Array (FPGA) automatic upgrade on the PRE4 module on the Cisco uBR10012 router, use the **upgrade fpga auto-upgrade** command in privileged EXEC mode.

**upgrade fpga auto-upgrade** { **debug-off** | **debug-on** | **disable** | **enable** | **show** }

## Syntax Description

<b>debug-off</b>	Turns off debugging of the firmware FPGA auto upgrade of the PRE4 module.
<b>debug-on</b>	Turns on debugging of the firmware FPGA auto upgrade of the PRE4 module.
<b>disable</b>	Disables auto upgrade of the FPGA.
<b>enable</b>	Enables auto upgrade of the FPGA.
<b>show</b>	Displays information on the FPGA upgrade on the Cisco uBR10012 router.

## Command Default

FPGA auto upgrade is enabled by default.

## Command Modes

Privileged EXEC (#)

## Command History

Release	Modification
12.2(33)SCG	This command was introduced.

## Usage Guidelines

The FPGA auto upgrade feature enables automatic upgrade of the FPGA image on the PRE4 module on the Cisco uBR10012 router. To disable auto upgrade of the FPGA, use the **upgrade fpga auto-upgrade disable** command.

## Examples

The following example shows how to activate the FPGA debugging on the Cisco uBR10012 router:

```
Router# upgrade fpga auto-upgrade debug-on
Router#
```

The following example shows how to disable automatic upgrade of the FPGA firmware on the Cisco uBR10012 router:

```
Router# upgrade fpga auto-upgrade disable
```

The following example shows how to display the FPGA version, which is the FPGA in the flash on the PRE4 module:

```
Router# upgrade fpga auto-upgrade show

Alternative IOFPGA Running, version - 0x05111800
Default IOFPGA version - 0x00000000
Alternative IOFPGA version - 0x00000000
Bundle IOFPGA version - 0x0A0A0D01
IOFPGA auto-upgrade enabled - No
IOFPGA auto-upgrade debug - No
IOFPGA auto-upgrade test mode - (Default IOFPGA:flash image verify error)
```

Table 254 describes the significant fields shown in the display.

**Table 254** upgrade fpga auto-upgrade show Field Descriptions

Field	Description
Alternative IOFPGA Running, version	Alternative IOFPGA image that is running, and its version.
Default IOFPGA version	Default IOFPGA version.
Alternative IOFPGA version	Alternative IOFPGA version.
Bundled IOFPGA version	Bundled IOFPGA version.
IOFPGA auto-upgrade enabled	IOFPGA auto-upgrade is enabled.
IOFPGA auto-upgrade debug	IOFPGA debug is turned on.
IOFPGA auto-upgrade test mode	IOFPGA test mode is turned on.

#### Associated Features

The **upgrade fpga auto-upgrade** command is used to automatically upgrade of the FPGA on the PRE4 module on the Cisco uBR10012 router.

- *Cisco uBR10012 Universal Broadband Router Performance Routing Engine Module*

#### Related Commands

Command	Description
<b>upgrade fpga file</b>	Upgrades the FPGA on the PRE4 module on the Cisco uBR10012 router.

# upgrade fpga file

To upgrade the Field-Programmable Gate Array (FPGA) image on the Performance Routing Engine 4 (PRE4) module on the Cisco uBR10012 router, use the **upgrade fpga file** command in privileged EXEC mode.

**upgrade fpga** **{alt | def}** **file** *{url}* *{version}*

Syntax Description	<b>alt</b>	Specifies the alternative IOFPGA version.
	<b>def</b>	Specifies the default IOFPGA version.
	<i>url</i>	URL of the IOFPGA file.
	<i>version</i>	Version of the IOFPGA file.

**Command Default** FPGA is disabled by default.

**Command Modes** Privileged EXEC (#)

Command History	Release	Modification
	12.2(33)SCB	This command was introduced.
	12.2(33)SCG	This command is modified. The argument <i>version</i> is added to the command.

**Usage Guidelines** Use this command to upgrade the FPGA image on the PRE4 module on the Cisco uBR10012 router.



## Note

In Cisco IOS Releases 12.2(33)SCG, you must specify the version of the IOFPGA file to manually upgrade the PRE4 module.

If you are using a PRE4 VE board and running Cisco IOS Release 12.2(33)SCG, use the **upgrade fpga {alt | def} file {url}** command to upgrade the PRE4 module.

**Examples** The following example shows how to upgrade the FPGA on the Cisco uBR10012 router:

```
Router# upgrade fpga alt file disk0:pre4_iofpga.bin 0x0A0A0D01
```

**Associated Features** The **upgrade fpga file** command is used to manually upgrade the FPGA on the PRE4 module on the Cisco uBR10012 router. For more information, see

- [Cisco uBR10012 Universal Broadband Router Performance Routing Engine Module](#)



Related Commands	Command	Description
	<b>upgrade fpga auto-upgrade</b>	Performs automatic upgrade of the IOFPGA on the PRE4 module on the Cisco uBR10012 router.

# upstream

To add upstream channels to an upstream bonding group, use the **upstream** command in upstream bonding configuration submode. To disable this configuration, use the **no** form of this command.

**upstream** *number*

**no upstream** *number*

## Syntax Description

<i>number</i>	Upstream channel number. The valid range is from 0 to 7.
---------------	--

## Command Default

None

## Command Modes

Upstream bonding configuration submode (config-upstream-bonding)

## Command History

Release	Modification
12.2(33)SCC	This command was introduced in Cisco IOS Release 12.2(33)SCC.

## Usage Guidelines

DOCSIS 3.0-certified cable modems can support only four upstream channels on an upstream bonding group. These cable modems cannot accept additional upstream channels that you have added to an upstream bonding group.

## Examples

The following example shows how to add upstream channels to an upstream bonding group on a cable interface line card on a Cisco uBR10012 router:

```
Router# configure terminal
Router(config)# interface cable7/1/0
Router(config-if)# cable upstream bonding-group 20
Router(config-upstream-bonding)# upstream 0
Router(config-upstream-bonding)# upstream 1
Router(config-upstream-bonding)# upstream 2
Router(config-upstream-bonding)# upstream 3
```

## Related Commands

Command	Description
<b>cable upstream bonding-group</b>	Creates an upstream bonding group on a cable interface.
<b>cable fiber-node</b>	Creates a fiber node and enters cable fiber-node configuration mode.

# upstream (config-lb-group)

To set upstream channels in a DOCSIS load balancing group, use the **upstream** command in the config-lb-group configuration mode. To disable the upstream channel configuration, use the **no** form of this command.

## Cisco uBR10012 Router

**upstream cable** *slot/subslot/port upstream-list*

**no upstream cable** *slot/subslot/port upstream-list*

## Cisco uBR7225VXR and Cisco uBR7246VXR Routers

**upstream cable** *slot/port upstream-list*

**no upstream cable** *slot/port upstream-list*

Syntax Description	
<b>cable</b> <i>slot/subslot/port</i>	Specifies the CMTS interface slot, subslot, and port number parameters. <ul style="list-style-type: none"> <li><i>slot</i>—Slot where the line card resides. Ther permitted range is from 5 to 8.</li> <li><i>subslot</i>—Subslot where the line card resides. The available slots are 0 or 1.</li> <li><i>port</i>—The downstream controller number on the line card. The permitted <i>port</i> range is from 0 to 4.</li> </ul>
<b>cable</b> <i>slot/port</i>	Specifies the CMTS interface slot and port number parameters on the Cisco uBR7246VXR or Cisco uBR7225VXR router. <ul style="list-style-type: none"> <li><i>slot</i>—Slot where the line card resides. <ul style="list-style-type: none"> <li>Cisco uBR7225VXR router—The valid range is from 1 to 2.</li> <li>Cisco uBR7246VXR router—The valid range is from 3 to 6.</li> </ul> </li> <li><i>port</i>—Downstream controller number on the line card. The permitted <i>port</i> values are 0 or 1.</li> </ul>
<i>upstream-list</i>	Upstream channel list ranging from 0 to 7.

**Command Default** None

**Command Modes** DOCSIS load balancing group mode (config-lb-group)

Command History	Release	Modification
	12.2(33)SCC	This command was introduced.

---

**Examples**

The following example shows how to set upstream channels in a DOCSIS LBG using the upstream command.

```
Router# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Router(config)# cable load-balance docsis-group 1
Router(config-lb-group)# upstream cable 1/0/1 2
Router(config-lb-group)#
```

---

**Related Commands**

Command	Description
<b>cable load-balance docsis-group</b>	Configures a DOCSIS load balancing group on the CMTS.
<b>show cable load-balance docsis-group</b>	Displays real-time configurational, statistical, and operational information of load balancing operations on the router.

# upstream cable connector

To configure an upstream cable connector for a fiber node, use the **upstream cable connector** command in cable fiber node configuration mode. To disable the configuration, use the **no** form of this command.

## Cisco uBR10012 Router

**upstream cable** *slot/subslot* **connector** *port-number*

**no upstream cable** *slot/subslot* **connector** *port-number*

## Cisco uBR7225VXR and Cisco uBR7246VXR Routers

**upstream cable** *slot* **connector** *port-number*

**no upstream cable** *slot* **connector** *port-number*

Syntax Description		
<b>cable</b> <i>slot/subslot</i>	Identifies the cable interface on the Cisco uBR10012 router.	<ul style="list-style-type: none"> <li><i>slot</i>—Chassis slot number of the cable interface line card. The valid range is from 5 to 8.</li> <li><i>subslot</i>—Secondary slot number of the cable interface line card. Valid subslots are 0 or 1.</li> </ul>
<b>cable</b> <i>slot</i>	Identifies the cable interface on the Cisco uBR7246VXR or Cisco uBR7225VXR router.	<ul style="list-style-type: none"> <li><i>slot</i>—Slot where the line card resides. <ul style="list-style-type: none"> <li>Cisco uBR7246VXR router: The valid range is from 3 to 6.</li> <li>Cisco uBR7225VXR router: The valid range is from 1 to 2.</li> </ul> </li> </ul>
<b>connector</b>	Specifies the physical upstream port connector on the cable interface line card.	
<i>port-number</i>	A range of physical port numbers on the cable interface line card. The <i>port-number</i> can be one or more port numbers or a range of port numbers separated by a hyphen or combinations of both.	<ul style="list-style-type: none"> <li>Cisco uBR10012 router—The valid range for port numbers is from 0 to 19.</li> <li>Cisco uBR7246VXR or Cisco uBR7225VXR router—The valid range for port numbers is from 0 to 7.</li> </ul>

**Command Default** None

**Command Modes** Cable fiber node configuration (config-fiber-node)

**Command History**

Release	Modification
12.2(33)SCC	This command was introduced in Cisco IOS Release 12.2(33)SCC.
12.2(33)SCD	Added support for Cisco uBR7246VXR and Cisco uBR7225VXR routers.

**Examples**

The following example shows how to configure an upstream cable connector for a fiber node on a Cisco uBR10012 router:

```
Router# configure terminal  
Router(config)# cable fiber-node 2  
Router(config-fiber-node)# upstream cable 5/0 connector 2
```

**Related Commands**

Command	Description
<b>cable upstream bonding-group</b>	Creates an upstream bonding group on a cable interface line card.
<b>cable fiber-node</b>	Creates a fiber node and enters cable fiber-node configuration mode.

# upstream freq-range

To configure the Cisco CMTS router for the range of frequencies that are acceptable on upstreams, use the **upstream freq-range** command in global configuration mode. To restore the default value of North American ranges, use the **no** form of this command.

**upstream freq-range [european | japanese | north american]**

**no upstream freq-range**

## Syntax Description

<b>european</b>	Configures the Cisco CMTS router to accept upstream frequency ranges that conform with the EuroDOCSIS specifications (5 MHz to 65 MHz).
<b>japanese</b>	Configures the Cisco CMTS router to accept upstream frequency ranges that conform to the expanded range used in Japan (5 MHz to 55 MHz).
<b>north american</b>	Configures the Cisco CMTS router to accept upstream frequency ranges that conform to the DOCSIS specifications (5 MHz to 42 MHz).

## Defaults

North American (DOCSIS, 5 MHz to 42 MHz)

## Command Modes

Global configuration

## Command History

Release	Modification
12.2(15)BC2	This command was introduced for the Cisco uBR7246VXR and Cisco uBR10012 universal broadband routers.

## Usage Guidelines

In Cisco IOS Release 12.2(15)BC2 and later, the Cisco CMTS router supports three different modes of operation, depending on the cable interface line cards being used. The range of frequencies that are allowed in each mode are as follows:

- North American DOCSIS (Annex B)—Upstreams use frequencies between 5 MHz and 42 MHz.
- European EuroDOCSIS (Annex A)—Upstreams use frequencies between 5 MHz and 65 MHz.
- Japanese Expanded Range (Annex B)—Upstreams use frequencies between 5 MHz and 55 MHz.

To configure the router so that it supports the proper range of upstream frequencies, use the **upstream freq-range** command. After you have configured the router with the **upstream freq-range** command, the **cable upstream frequency** command then accepts only frequencies that are in the configured range.



### Note

This command configures only the range of frequencies that can be configured on an upstream. It does not configure the upstreams for the DOCSIS (Annex B) or EuroDOCSIS (Annex A) modes of operation, which is done using the **cable downstream annex** interface command. (Annex C mode is not supported.)

The allowable range for the upstream channel frequency depends on the cable interface line card and Cisco IOS software release being used. See **Table 2-12 on page 2-367** for the currently supported values.

## Examples

The following example shows how to configure the Cisco CMTS router to support the EuroDOCSIS upstream frequency range of 5 MHz to 65 MHz:

```
Router# configure terminal
Router(config)# upstream freq-range european
Router(config)#
```

The following example shows how to configure the Cisco CMTS router to support the expanded Japanese upstream frequency range of 5 MHz to 55 MHz:

```
Router# configure terminal
Router(config)# upstream freq-range japanese
Router(config)#
```

The following example shows how to configure the Cisco CMTS router for its default configuration (DOCSIS upstream frequency range of 5 MHz to 42 MHz):

```
Router# configure terminal
Router(config)# upstream freq-range north american
Router(config)#
```

The following example shows all of the commands that are needed to configure the cable interface and upstream on a Cisco uBR-MC28U/X cable interface line card to support a frequency in the EuroDOCSIS upstream frequency range of 5 MHz to 65 MHz:

```
Router# configure terminal
Router(config)# upstream freq-range european
Router(config)# interface 3/0
Router(config-if)# cable downstream annex a
Router(config-if)# cable upstream 0 frequency 62500000
Router(config-if)#
```

## Related Commands

Command	Description
<b>cable spectrum-group (global configuration)</b>	Creates spectrum groups, which contain one or more upstream frequencies.
<b>cable upstream frequency</b>	Configures a fixed frequency of the upstream radio frequency (RF) carrier for an upstream port.
<b>show controllers cable</b>	Displays information about the cable interface, including the upstream center frequency.



# voice-port

To enter voice-port configuration mode, use the **voice-port** command in global configuration mode.

**Cisco uBR924, uBR925 cable access routers, Cisco CVA122 Cable Voice Adapter**

**voice-port** *number*

<b>Syntax Description:</b>	<i>number</i>	Identifies the voice port. Valid entries are <b>0</b> (which corresponds to the RJ-11 connector labeled V1) and <b>1</b> (which corresponds to the RJ-11 connector labeled V2).
----------------------------	---------------	---

<b>Defaults</b>	No default behavior or values.
-----------------	--------------------------------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

Command History	Release	Modification
	12.0(4)XI1	Support was added for the Cisco uBR924 cable access router.
	12.1(5)XU1	Support was added for the Cisco CVA122 Cable Voice Adapter.
	12.2(2)XA	Support was added for the Cisco uBR925 cable access router.

<b>Usage Guidelines</b>	Use the <b>voice-port</b> global configuration command to enter voice-port configuration mode. Use the <b>exit</b> command to exit the voice-port configuration mode and return to the global configuration mode. See the <i>Cisco IOS Multiservice Applications Command Reference</i> , available on Cisco.com and the Documentation CD-ROM for a list of subcommands that are supported by the <b>voice-port</b> command.
-------------------------	---

<b>Examples</b>	The following example shows how to enter the voice-port configuration mode for port 0, the first voice port (labeled “V1+V2”) on the router.
-----------------	--

```
Router# configure terminal
Router(config)# voice-port 0
Router(config-voice-port)#
```

Related Commands	Command	Description
	<b>dial-peer voice</b>	Enters dial-peer configuration mode, defines the type of dial peer, and defines the tag number associated with a dial peer.

# vrf (multicast qos)

To specify the name for a virtual routing and forwarding (VRF) instance, use the **vrf** command in multicast QoS configuration mode. To disable the VRF instance, use the **no** form of this command.

**vrf** *name*

**no vrf** *name*

## Syntax Description

<i>name</i>	Specifies the routing and forwarding instance that is populated with multicast Virtual Private Network (MVPN) routes.
-------------	---

## Command Default

A VRF name is not defined for the multicast QoS group.

## Command Modes

Multicast QoS configuration (config-mqos)

## Command History

Release	Modification
12.2(33)SCA	This command was introduced.

## Usage Guidelines

If a multicast QoS (MQoS) group is not defined for the named VRF instance, you will see an error message. You must either define a specific MQoS group for each VRF instance, or define a default MQoS that can be assigned in those situations where no matching MQoS group is found.

## Examples

The following example identifies a multicast QoS group VRF name using the **vrf** command:

```
Router(config)# cable multicast qos group 20 priority 55 global
Router(config-mqos)# vrf name1
```

## Related Commands

Command	Description
<b>cable multicast qos group</b>	Specifies and configures a cable multicast QoS group.
<b>show interface bundle multicast-sessions</b>	Displays multicast session information for a specific virtual cable bundle.
<b>show interface cable multicast-sessions</b>	Displays multicast session information for a specific cable interface.

## weekend duration

To configure different subscriber monitoring options over weekends on a Cisco CMTS router, use the **weekend duration** command in enforce-rule configuration mode. To remove the weekend monitoring configuration and to return to the same monitoring conditions for all days of the week, use the **no weekend** form of this command.

**weekend duration** *minutes* **avg-rate** *rate* **sample-interval** *interval* [**penalty** *duration*]  
 { **downstream** | **upstream** } [**enforce**]

**no weekend duration** *minutes* **avg-rate** *rate* **sample-interval** *interval* [**penalty** *duration*]  
 { **downstream** | **upstream** } [**enforce**]

**no weekend**

Syntax Description		
<i>minutes</i>		Specifies the size of the sliding window (in minutes) during which subscriber usage is monitored. The valid range is 10 to 44640 with a default of 360 minutes (6 hours).
<b>avg-rate</b> <i>rate</i>		Specifies the average sampling rate in kilobits per second for the specified duration. The valid range is 1 to 400000 kilobits with no default.
<b>sample-interval</b> <i>interval</i>		Specifies how often (in minutes) the CMTS router should sample a service flow to get an estimate of subscriber usage. The valid range is 1 to 30, with a default value of 15.
<b>penalty</b> <i>minutes</i>		(Optional) Specifies the period (in minutes) during which a cable modem (CM) can be under penalty. The valid range is 1 to 10080.
<b>downstream</b>		Specifies monitoring of traffic in the downstream direction.
<b>upstream</b>		Specifies monitoring of traffic in the upstream direction.
<b>enforce</b>		(Optional) Specifies that the enforce-rule QoS profile should be applied automatically if a user violates their registered QoS profile.

**Command Default** Weekend monitoring is disabled.

**Command Modes** Enforce-rule configuration (enforce-rule)

Command History	Release	Modification
	12.3(23)BC2	This command was introduced.
	12.2(33)SCD2	The <b>penalty</b> keyword option was added.

## Usage Guidelines



### Note

This command is applicable only after the **monitoring-basics** command is configured with the keyword **legacy**.

The **weekend duration** command works similarly to the **duration** command for subscriber traffic monitoring. Use the **weekend duration** command when you want to configure different monitoring parameters for subscribers on weekends.

This command can only be used when you have already configured the **duration** or **peak-time1** commands as weekday monitoring conditions for an enforce-rule.

If you still want to monitor traffic over the weekend, but want to return to the same monitoring conditions for every day of the week, use the **no weekend** command. This command removes the weekend monitoring conditions, but still performs monitoring over the weekends according to the other monitoring options that you have configured in the enforce-rule.

If you want to disable monitoring entirely over the weekend, use the **weekend off** command.

The **penalty** duration, which is configured using the **weekend duration** command, is unique to weekends, and takes precedence over the global penalty duration configured using the **penalty-period** command.

## Examples

The following example specifies automatic monitoring of upstream traffic over the weekend if a subscriber is identified as violating their QoS profile. The monitoring will take place every 10 minutes and last for 5 minutes, with traffic sampled at an average rate of 2 kb/s:

```
Router(enforce-rule)# weekend duration 5 avg-rate 2 sample-interval 10 penalty 11 upstream
enforce
```

## Related Commands

Command	Description
<b>duration</b>	Specifies the time period and sample rate to be used for monitoring subscribers.
<b>peak-time1</b>	Specifies peak and offpeak monitoring times on a Cisco CMTS router.
<b>penalty-period</b>	Specifies the period during which an enforced quality of service (QoS) profile should be in force for subscribers who violate their registered QoS profile.
<b>weekend off</b>	Disables peak and offpeak monitoring on weekends on a Cisco CMTS router.
<b>weekend peak-time1</b>	Configures peak and offpeak subscriber monitoring over weekends on a Cisco CMTS router.

# weekend off

To disable peak and offpeak monitoring on weekends on a Cisco CMTS router, use the **weekend off** command in enforce-rule configuration mode. To re-enable the configuration for weekend monitoring, use the **no** form of this command.

**weekend off**

**no weekend off**

## Syntax Description

This command has no arguments or keywords.

## Command Default

Weekend monitoring is enabled once you configure the **weekend duration** or **weekend peak-time1** commands.

## Command Modes

Enforce-rule configuration (enforce-rule)

## Command History

Release	Modification
12.3(23)BC2	This command was introduced.
12.2(33)SCB	This command was integrated into Cisco IOS Release 12.2(33)SCB. Support for the Cisco uBR7225VXR router was added.

## Usage Guidelines

Use the **weekend off** command to disable previously configured weekend monitoring and stop the CMTS router from monitoring cable modems (CMs) with that enforce-rule over the weekend. This command allows you to retain or modify your weekend monitoring configuration without enabling it for actual monitoring use on the CMTS router.

To perform weekend monitoring according to the same parameters used for weekday monitoring, use the **no weekend** command.

## Examples

The following example shows how to disable weekend monitoring when weekend peak-time monitoring has previously been configured on a Cisco CMTS router:

```
Router(config)# cable qos enforce-rule test
Router(enforce-rule)# weekend peak-time1 8 duration 60 avg-rate 100 peak-time2 20 duration
60 avg-rate 10000 duration 90 avg-rate 20000 sample-interval 20 downstream enforce
Router(enforce-rule)# weekend off
```

## Related Commands

Command	Description
<b>weekend duration</b>	Configures different subscriber monitoring options over weekends on a Cisco CMTS router.
<b>weekend peak-time1</b>	Configures peak and offpeak subscriber monitoring over weekends on a Cisco CMTS router.

# weekend peak-time1

To configure peak and offpeak subscriber monitoring over weekends on a Cisco CMTS router, use the **weekend peak-time1** command in enforce-rule configuration mode. To remove the peak and offpeak weekend monitoring configuration, use the **no** form of this command.

**weekend peak-time1** {*hour* | *hour:minutes*} **duration** *minutes* **avg-rate** *rate* [**peak-time2** {*hour* | *hour:minutes*} **duration** *minutes* **avg-rate** *rate*] [**duration** *offpeak-minutes* **avg-rate** *offpeak-rate*] **sample-interval** *minutes* [**penalty** *minutes*] {**downstream** | **upstream**}[**enforce**]

**no weekend peak-time1** {*hour* | *hour:minutes*} **duration** *minutes* **avg-rate** *rate* [**peak-time2** {*hour* | *hour:minutes*} **duration** *minutes* **avg-rate** *rate*] [**duration** *offpeak-minutes* **avg-rate** *offpeak-rate*] **sample-interval** *minutes* [**penalty** *minutes*] {**downstream** | **upstream**}[**enforce**]

## Syntax Description

<i>hour</i>   <i>hour:minutes</i>	Specifies the time of day, in either hh or hh:mm format, during which monitoring occurs for the peak time.  If the time is specified in hour (hh), the valid range is 1 to 23 using a 24-hour clock.  If the time is specified in hour:minutes (hh:mm), the valid range for hour is 1 to 23 using a 24-hour clock, and the valid range for minutes is 0 to 59.
<b>duration</b> <i>minutes</i>	Specifies the size of the sliding window (in minutes) during which the subscriber usage is monitored for the first peak time, and optionally for a second peak time when used with the <b>peak-time2</b> keyword. The valid range is 60 to 1440.
<b>avg-rate</b> <i>rate</i>	Specifies the average sampling rate in kilobits per second for the specified duration. The valid range is 1 to 400000 kilobits with no default.
<b>duration</b> <i>offpeak-minutes</i>	(Optional) Specifies the size of the sliding window during which the subscriber usage is monitored for the remaining offpeak time (time not specified for peak monitoring). Valid range is 60 to 1440 minutes.
<b>avg-rate</b> <i>offpeak-rate</i>	Specifies the average sampling rate in kilobits per second for the specified offpeak duration. The valid range is 1 to 400000 kilobits with no default.
<b>peak-time2</b>	(Optional) Specifies the time of day during which monitoring occurs for a second peak time. The time can be specified either in hours or hour:minutes format.
<b>sample-interval</b> <i>minutes</i>	Specifies how often (in minutes) the CMTS router should sample a service flow to get an estimate of subscriber usage. The valid range is 1 to 30, with a default value of 15.
<b>penalty</b> <i>minutes</i>	(Optional) Specifies the period (in minutes) during which a cable modem can be under penalty. The range is 1 to 10080.
<b>downstream</b>	Specifies monitoring of traffic in the downstream direction.
<b>upstream</b>	Specifies monitoring of traffic in the upstream direction.
<b>enforce</b>	(Optional) Specifies that the enforce-rule QoS profile should be applied automatically if a user violates their registered QoS profile.

## Command Default

Weekend monitoring is disabled. The only default value for the **weekend peak-time1** command is the 15-minute sample interval.

**Command Modes** Enforce-rule configuration (enforce-rule)

Command History	Release	Modification
	12.3(23)BC2	This command was introduced.
	12.2(33)SCD2	The minute-level granularity (hh:mm) for <b>weekend peak-time1</b> and <b>peak-time2</b> duration, and the <b>penalty</b> keyword option were added.

## Usage Guidelines



### Note

This command is applicable only after the **monitoring-basics** command is configured with the keyword **peak-offpeak**.

The **weekend peak-time1** command is similar to the **peak-time1** command for subscriber traffic monitoring. Use the **weekend peak-time1** command when you want to configure different peak and offpeak monitoring parameters for subscribers on weekends.

This command can only be used when you have already configured the **duration** or **peak-time1** commands as weekday monitoring conditions for an enforce-rule.

The **penalty** duration, which is configured using the **weekend peak-time1** command, is unique to weekends, and takes precedence over the global penalty duration configured using the **penalty-period** command.

## Examples

The following example shows configuration of two peak monitoring windows on the weekend, with the first monitoring period beginning at 8:00 A.M. for one hour and the second monitoring period beginning at 8:00 P.M. for one hour, and monitoring at all other times of the weekend for 1-1/2 hours (90 minutes) for downstream traffic. The unique penalty period for both **weekend peaktime1** and **peaktime2** is configured as 60 minutes:

```
Router(enforce-rule)# weekend peak-time1 8 duration 60 avg-rate 10000 peak-time2 20
duration 60 avg-rate 100 duration 90 avg-rate 20000 sample-interval 20 penalty 60
downstream enforce
```

Related Commands	Command	Description
	<b>peak-time1</b>	Specifies peak and offpeak monitoring times on a Cisco CMTS router.
	<b>weekend duration</b>	Configures different subscriber monitoring options over weekends on a Cisco CMTS router.
	<b>penalty-period</b>	Specifies the period for which an enforced quality of service (QoS) profile should be in force for subscribers who violate their registered QoS profile.
	<b>weekend off</b>	Disables peak and offpeak monitoring on weekends on a Cisco CMTS router.

■ weekend peak-time1