

certificate reload

To configure Secure Socket Layer (SSL) Encryption Support enabled to read the profile security certificate from the file specified in the **servercert** command, use the **certificate reload** command in customer profile configuration mode.

certificate reload

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values.

Command Modes Profile configuration

Command History	Release	Modification
	12.1(5)T	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines There is not a **no** form for this command.
The TN3270 server must be configured for security.

Examples The following example configures the TN3270 server with SSL Encryption Support to read the profile security certificate from the file specified in the **servercert** command:

```
certificate reload
```

Related Commands	Command	Description
	servercert	Specifies the location of the TN3270 server's security certificate in the Flash memory.

channel-protocol

To define a data rate of either 3 MBps or 4.5 MBps for Parallel Channel Interfaces, use the **channel-protocol** command in interface configuration mode. To return to the default rate of 3 MBps, use the **no** form of this command.

channel-protocol [s | s4]

no channel-protocol

Syntax Description

s	(Optional) Specifies a data rate of 3 MBps.
s4	(Optional) Specifies a data rate of 4.5 MBps.

Defaults

If no value is specified, the default data rate for the Parallel Channel Adapter (PCA) and the Parallel Channel Port Adapter (PCPA) is 3 MBps.

Command Modes

Interface configuration

Command History

Release	Modification
10.2	This command was introduced.
12.1	This command was integrated into Cisco IOS Release 12.1M.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

This command is valid on Parallel Channel Interfaces.

Examples

The following example specifies a data rate of 4.5 MBps for the interface:

```
channel-protocol s4
```

claw (backup)

To configure a Common Link Access for Workstations (CLAW) device (read and write subchannel) for communication with a mainframe TCP/IP stack in offload mode and configure individual members of a CLAW backup group for the IP Host Backup feature, use the **claw** command in IP host backup configuration mode. To remove the CLAW device, use the **no** form of this command.

claw *path device-address ip-address host-name device-name host-app device-app* [**broadcast**]

no claw *device-address*

Syntax Description		
	<i>path</i>	Hexadecimal value in the range from 0000 to FFFF. This value specifies the logical channel path and consists of two digits for the physical connection (either on the host or on the ESCON director), one digit for the channel logical address, and one digit for the control unit logical address. If the path is not specified in the input/output configuration program (IOCP), the default value for channel logical address and control unit logical address is 0.
	<i>device-address</i>	Hexadecimal value in the range from 00 to FE. This is the unit address associated with the control unit number and path as specified in the host IOCP file. The device address must have an even-numbered value.
	<i>ip-address</i>	IP address specified in the HOME statement of the host TCP/IP application configuration file.
	<i>host-name</i>	Host name specified in the device statement in the host TCP/IP application configuration file.
	<i>device-name</i>	CLAW workstation name specified in the device statement in the host TCP/IP application configuration file.
	<i>host-app</i>	Host application name as specified in the host application file. When connected to the IBM TCP host offerings, this value will be tcPIP , which is the constant specified in the host TCP/IP application file. When attached to other applications, this value must match the value hard coded in the host application.
	<i>device-app</i>	CLAW workstation application specified in the host TCPIP application. When connected to the IBM TCP host offerings, this value will be tcPIP , which is the constant specified in the host TCP/IP application file. When attached to other applications, this value must match the value hard coded in the host application.
	broadcast	(Optional) Enables broadcast processing for this subchannel.

Defaults No default behavior or values.

Command Modes IP host backup configuration

Command History

Release	Modification
12.0	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

This command defines information that is specific to the hardware interface and the IBM channels supported on the interface.

CLAW devices are used to switch IP packets between a mainframe and a channel-attached router.

At most, 128 statements can be configured per interface because each interface is limited to 256 subchannels. Each CLAW device uses a read channel and a write channel. There is also a restriction of 64 unique paths.

A limit of 32 CLAW device configuration commands is recommended.

Duplicate IP addresses are invalid for nonbackup configurations.

Duplicate IP addresses are permitted if they appear within a backup group of only **claw** or **offload** interface configuration commands. All configuration commands in one backup group must specify the **backup** keyword.

You can use the **path** interface configuration command to specify a number of paths that belong to a backup group. In that case, a **claw** IP host backup configuration command is used that needs no *path* variable or **backup** keyword.

Examples

The following examples show two methods for entering the same IP host backup group information. The first group of commands is the long form, using the **claw** interface configuration command. The second group is the shortcut, using the **path** interface configuration command and a **claw** IP host backup configuration command.

Long form:

```
claw c000 00 10.92.10.5 sysa router1 tcpip tcpip
claw c100 00 10.92.10.5 sysa router1 tcpip tcpip
claw c200 00 10.92.10.5 sysa router1 tcpip tcpip
```

Shortcut form:

```
path c000 c100 c200
  claw 00 10.92.10.5 sysa router1 tcpip tcpip
```

Related Commands

Command	Description
claw (primary)	Configures a CLAW device (read and write subchannel) for communication with a mainframe TCP/IP stack in IP datagram mode and also configures individual members of a CLAW backup group for the IP Host Backup feature.
offload (backup)	Configures a backup group of Offload devices.

Command	Description
offload (primary)	Configures an Offload device (read and write subchannel) for communication with a mainframe TCP/IP stack in offload mode and also configures individual members of an Offload backup group for the IP Host Backup feature.
show extended channel packing names	Displays CLAW packing names and their connection state.
show extended channel packing stats	Displays CLAW packing statistics.
show extended channel statistics	Displays statistical information about subchannels on the physical interface of a CMCC adapter and displays information that is specific to the interface channel devices. The information generally is useful only for diagnostic tasks performed by technical support personnel.
show extended channel subchannel	Displays information about the CMCC adapter physical interfaces and displays information that is specific to the interface channel connection. The information displayed generally is useful only for diagnostic tasks performed by technical support personnel.

claw (primary)

To configure a Common Link Access for Workstations (CLAW) device (read and write subchannel) for communication with a mainframe TCP/IP stack in IP datagram mode and also configure individual members of a CLAW backup group for the IP Host Backup feature, use the **claw** command in interface configuration mode. To remove the CLAW device, use the **no** form of this command.

claw *path device-address ip-address host-name device-name host-app device-app* [**broadcast**] [**backup**]

no **claw** *path device-address*

Syntax Description

<i>path</i>	Hexadecimal value in the range from 0000 to FFFF. This value specifies the logical channel path and consists of two digits for the physical connection (either on the host or on the ESCON director), one digit for the channel logical address, and one digit for the control unit logical address. If the path is not specified in the input/output configuration program (IOCP), the default value for channel logical address and control unit logical address is 0.
<i>device-address</i>	Hexadecimal value in the range from 00 to FE. This is the unit address associated with the control unit number and path as specified in the host IOCP file. The device address must have an even-numbered value.
<i>ip-address</i>	IP address specified in the HOME statement of the host TCP/IP application configuration file.
<i>host-name</i>	Host name specified in the device statement in the host TCP/IP application configuration file.
<i>device-name</i>	CLAW workstation name specified in the device statement in the host TCP/IP application configuration file.
<i>host-app</i>	Host application name as specified in the host application file. When connected to the IBM TCP host offerings, or if the CLAW packing feature is not enabled on the mainframe TCPIP stack, this value will be tcpip , which is the constant specified in the host TCP/IP application file. When attached to other applications, this value must match the value hard coded in the host application. The value packed can be used for the <i>host-app</i> argument to enable the CLAW packing feature.
<i>device-app</i>	CLAW workstation application specified in the host TCPIP application. If connected to the IBM TCP host offerings, or if the CLAW packing feature is not enabled on the mainframe TCPIP stack, this value will be tcpip , which is the constant specified in the host TCP/IP application file. When attached to other applications, this value must match the value hard coded in the host application. The value packed can be used for the <i>device-app</i> argument to enable the CLAW packing feature.
broadcast	(Optional) Enables broadcast processing for this subchannel.
backup	(Optional) Enables this CLAW connection to be used as part of a backup group of CLAW connections for the specified IP address.

Defaults

No default behavior or values.

Command Modes Interface configuration

Command History	Release	Modification
	10.2	This command was introduced.
	12.0	The following options were added: <ul style="list-style-type: none"> • backup • packed
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines This command defines information that is specific to the hardware interface and the IBM channels supported on the interface. When used with the **path** command, the **claw** command provides a quick way to configure a CLAW backup group.

CLAW devices are used to switch IP packets between a mainframe and a channel-attached router.

At most, 128 statements can be configured per interface because each interface is limited to 256 subchannels. Each CLAW device uses a read channel and a write channel. There is also a restriction of 64 unique paths.

A limit of 32 CLAW device configuration commands is recommended.

Duplicate IP addresses are invalid for nonbackup configurations.

Duplicate IP addresses are permitted if they appear within a backup group of only **claw** or **offload** interface configuration commands. All configuration commands in one backup group must specify the **backup** keyword.

You can use the **path** interface configuration command to specify a number of paths that belong to a backup group. In that case, a **claw** IP host backup configuration command is used that needs no *path* variable or **backup** keyword. You can use the **packed** value as an optional keyword for the *host-app* and *device-app* arguments.

Examples The following example shows how to enable IBM channel attach routing on channel interface 3/0, which is supporting an ESCON direct connection to the mainframe:

```
interface channel 3/0
ip address 172.18.4.49 255.255.255.248
claw c020 F4 172.18.4.52 HOSTB RTRA TCPIP TCPIP
```

The following example shows how to enable CLAW packing:

```
interface Channel 3/0
ip address 172.18.4.49 255.255.255.248
claw c010 F2 172.18.4.50 HOSTA RTRA PACKED PACKED
```

The following example shows how an IP host backup group is specified using the **backup** keyword:

```
interface Channel3/0
no ip address
no keepalive
```

```
no shutdown
claw 0100 C0 10.30.1.2 CISCOVM EVAL TCPIP TCPIP backup
claw 0110 C0 10.30.1.2 CISCOVM EVAL TCPIP TCPIP backup
claw 0120 C0 10.30.1.2 CISCOVM EVAL TCPIP TCPIP backup
claw 0110 C2 10.30.1.3 CISCOVM EVAL TCPIP TCPIP
```

Related Commands

Command	Description
claw (backup)	Configures a CLAW device (read and write subchannel) for communication with a mainframe TCP/IP stack in offload mode and also configures individual members of a CLAW backup group for the IP Host Backup feature.
offload (backup)	Configures a backup group of Offload devices.
offload (primary)	Configures an Offload device (read and write subchannel) for communication with a mainframe TCP/IP stack in offload mode and also configures individual members of an Offload backup group for the IP Host Backup feature.
show extended channel packing names	Displays CLAW packing names and their connection state.
show extended channel packing stats	Displays CLAW packing statistics.
show extended channel statistics	Displays statistical information about subchannels on the physical interface of a CMCC adapter and displays information that is specific to the interface channel devices. The information generally is useful only for diagnostic tasks performed by technical support personnel.
show extended channel subchannel	Displays information about the CMCC adapter physical interfaces and displays information that is specific to the interface channel connection. The information displayed generally is useful only for diagnostic tasks performed by technical support personnel.

clear alps circuits

To remove configured Airline Product Set (ALPS) circuits, use the **clear alps circuits** command in user EXEC or privileged EXEC mode.

clear alps circuits [**ipaddr** *address* | **name** *string*]

Syntax Description	ipaddr <i>address</i>	(Optional) Clear ALPS circuits for peer with specified IP address.
	name <i>string</i>	(Optional) Clear ALPS circuits for peer with specified name.

Defaults If no IP address or name is specified, the command clears all ALPS circuits.

Command Modes EXEC

Command History	Release	Modification
	11.3(6)T	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples The following example clears the ALPS circuit named CKT1:

```
Router# clear alps circuits name CKT1
```

Related Commands	Command	Description
	alps auto-reset	Automatically resets a nonresponsive ALC ASCU in the DOWN state.
	show alps circuits	Displays the status of the ALPS circuits.

clear alps counters

To clear all counters relevant to the ALPS feature, use the **clear alps counters** command in user EXEC or privileged EXEC mode.

clear alps counters

Syntax Description This command has no arguments or keywords.

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	11.3(6)T	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples The following example clears all counters for the ALPS feature:

```
Router# clear alps counters
```

Related Commands	Command	Description
	encapsulation uts	Specifies that the P1024C UTS protocol will be used on the serial interface.
	show alps circuits	Displays the status of the ALPS circuits.
	show alps peers	Displays the status of the ALPS partner peers.

clear bridge

To remove any learned entries from the forwarding database and to clear the transmit and receive counts for any statically or system-configured entries, use the **clear bridge** command in privileged EXEC mode.

clear bridge *bridge-group*

Syntax Description	<i>bridge-group</i>	Bridge group number specified in the bridge protocol command.
---------------------------	---------------------	--

Defaults	No default behavior or values.
-----------------	--------------------------------

Command Modes	Privileged EXEC
----------------------	-----------------

Command History	Release	Modification
	10.0	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples	The following example shows the use of the clear bridge command: Router# clear bridge 1
-----------------	--

Related Commands	Command	Description
	bridge address	Filters frames with a particular MAC-layer station source or destination address.
	bridge protocol	Defines the type of Spanning Tree Protocol.

clear bridge multicast

To clear transparent bridging multicast state information, use the **clear bridge multicast** command in user EXEC or privileged EXEC mode.

```
clear bridge [bridge-group] multicast [router-ports | groups | counts]  
                [group-address] [interface-unit] [counts]
```

Syntax Description

<i>bridge-group</i>	(Optional) Bridge group number specified in the bridge protocol command.
router-ports	(Optional) Clear multicast router ports.
groups	(Optional) Clear multicast groups.
counts	(Optional) Clear RX and TX counts.
<i>group-address</i>	(Optional) Multicast IP address associated with a specific multicast group.
<i>interface-unit</i>	(Optional) Specific interface, such as Ethernet 0.

Defaults

No default behavior or values.

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
11.2	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

If you do not specify arguments or keywords as part of the command, the command clears router ports, group ports, and counts for all configured bridge groups.

Use the **show bridge multicast** command to list transparent bridging multicast state information, then use specific pieces of state information in the **clear bridge multicast** command.

Examples

The following example clears router ports, group ports, and counts for bridge group 1:

```
Router# clear bridge 1 multicast
```

The following example clears the group and count information for the group identified as 235.145.145.223, interface Ethernet 0/3 for bridge group 1:

```
Router# clear bridge 1 multicast groups 235.145.145.223 Ethernet0/3 counts
```

Related Commands

Command	Description
bridge cmf	Enables CMF for all configured bridge groups.
show bridge multicast	Displays transparent bridging multicast state information.

clear dlsw circuit

To cause all data-link switching plus (DLSw+) circuits to be closed, use the **clear dlsw circuit** command in privileged EXEC configuration mode.

clear dlsw circuit [*circuit-id*]

Syntax Description

<i>circuit-id</i>	Circuit ID for a specific remote circuit. The valid range is from 0 to 4294967295.
-------------------	--

Command Modes

Privileged EXEC

Command History

Release	Modification
11.2 F	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

A user can specify a circuit ID of a specific circuit to clear rather than clearing all circuits.



Caution

This command also drops the associated Logical Link Control, type 2 (LLC2) session. The command usage should be used with caution and under the advice of a Cisco engineer.

Examples

The following example closes all DLSw+ circuits:

```
Router# clear dlsw circuit
```

clear dlsw history

To clear all currently inactive circuits from the DLSw+ circuit history, use the **clear dlsw history** privileged EXEC command.

clear dlsw history

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	12.1	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples The following example clears all inactive circuits from the DLSW+ circuit history:

```
clear dlsw history
```

clear dlsw local-circuit

To cause all locally-switched DLSw+ circuits to be closed, use the **clear dlsw local-circuit** privileged EXEC command.

```
clear dlsw local-circuit [circuit-id]
```


Syntax Description	<i>circuit-id</i> Circuit ID for a specific remote circuit. The valid range is 0 to 4294967295.
--------------------	---

Defaults	No default behavior or values.
----------	--------------------------------

Command Modes	Privileged EXEC
---------------	-----------------

Command History	Release	Modification
	12.1	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	A user can specify a circuit ID of a specific circuit to clear rather than clearing all local-switched circuits.
------------------	--


Caution

This command also drops the associated LLC2 session. The command usage should be used with caution and under the advice of a Cisco engineer.

Examples	The following example closes the locally-switched DLSw+ circuit with ID number 100: <pre>clear dlsw local-circuit 100</pre>
----------	--

clear dls w reachability

To remove all entries from the data-link switching plus (DLSw+) reachability cache, use the **clear dls w reachability** command in privileged EXEC configuration mode.

clear dls w reachability

Syntax Description This command has no arguments or keywords.

Command Modes Privileged EXEC

Command History	Release	Modification
	11.2 F	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines This command does not affect existing sessions.

Examples The following example removes all entries from the DLSw+ reachability cache:

```
Router# clear dls w reachability
```

clear dlsw statistics

To reset to zero the number of frames that have been processed in the local, remote, and group cache, use the **clear dlsw statistics** command in privileged EXEC configuration mode.

clear dlsw statistics

Syntax Description This command has no arguments or keywords.

Command Modes Privileged EXEC

Command History	Release	Modification
	11.2 F	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples The following example resets to zero the number of frames in the local, remote, and group cache:

Router# **clear dlsw statistics**

clear dlsw transparent

To clear DLSw+ transparent local MAC entries, use the **clear dlsw transparent** privileged EXEC command.

clear dlsw transparent

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	12.1	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines This command is designed to be used in networks that employ DLSw+ Ethernet redundancy without transparent mappings.

Examples The following example clears DLSw+ transparent local MAC entries:

```
clear dlsw transparent
```

clear drip counters

To clear duplicate ring protocol (DRiP) counters from the Route Switch Module (RSM) interfaces, use the **clear drip counters** command in privileged EXEC mode.

clear drip counters

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Defaults	Disabled
-----------------	----------

Command Modes	Privileged EXEC
----------------------	-----------------

Command History	Release	Modification
	11.3(4)T	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	Use the clear drip counters command if you want to check whether the router is receiving any packets. The counters will start at 0. If the counters are incrementing, DRiP is active on the router.
-------------------------	--

Examples	The following example clears DRiP counters: Router# clear drip counters
-----------------	---

Related Commands	Command	Description
	interface vlan	Configures a Token Ring or Ethernet interface on the RSM.
	show drip	Displays the status of the DRiP database.

clear extended counters

To clear the extended interface counters associated with Cisco Mainframe Channel Connection (CMCC) features, use the **clear extended counters** command in user EXEC or privileged EXEC mode.

clear extended counters [**channel** *slot/port* [**csna** | **icmp-stack** | **ip-stack** | **llc2** | **statistics** | **tcp-connections** | **tcp-stack** | **tg** | **tn3270-server** | **udp-stack**]]

Syntax Description		
channel	(Optional)	Specifies a channel interface.
<i>slot</i>	(Optional)	Slot number.
<i>port</i>	(Optional)	Port number.
csna	(Optional)	Clears Cisco Systems Network Architecture (CSNA) feature counters.
icmp-stack	(Optional)	Clears Internet Control Message Protocol (ICMP) stack counters.
ip-stack	(Optional)	Clears IP stack counters.
llc2	(Optional)	Clears Logical Link Control, type 2 (LLC2) counters.
statistics	(Optional)	Clears subchannel statistic counters.
tcp-connections	(Optional)	Clears TCP connection counters.
tcp-stack	(Optional)	Clears TCP stack counters.
tg	(Optional)	Clears Transmission Group (TG) counters.
tn3270-server	(Optional)	Clears TN3270 server counters.
udp-stack	(Optional)	Clears User Datagram Protocol (UDP) stack counters.

Command Modes	User EXEC Privileged EXEC
---------------	------------------------------

Command History	Release	Modification
	11.3	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	<p>This command is valid on both the physical and virtual channel interfaces. To clear counters for a selected CMCC feature, you must specify the channel interface on which the feature is configured or running.</p> <p>Counters displayed using the show extended channel EXEC command are cleared using this command.</p> <p>Entering any form of this command will prompt the user for a confirmation before clearing any counters. A "CLEAR-5-EXT_COUNT" message is displayed to indicate completion of the command.</p>
------------------	---

These counters will be cleared in the **show** commands and remain uncleared when obtained through the Simple Network Management Protocol (SNMP) interface.

Examples

The following example shows how to clear the extended interface counters:

```
Router# clear extended counters
```

Related Commands

Command	Description
show extended channel csna	Displays information about the CSNA subchannels configured on the specified CMCC interface.
show extended channel icmp-stack	Displays information about the ICMP stack running on the CMCC channel interfaces.
show extended channel ip-stack	Displays information about the IP stack running on CMCC channel interfaces.
show extended channel lan	Displays the internal LANs and adapters configured on a CMCC adapter.
show extended channel llc2	Displays information about the LLC2 sessions running on the CMCC adapter interfaces.
show extended channel statistics	Displays statistical information about subchannels on the physical interface of a CMCC adapter and displays information that is specific to the interface channel devices. The information generally is useful only for diagnostic tasks performed by technical support personnel.
show extended channel tcp-connections	Displays information about the TCP sockets on a channel interface.
show extended channel tcp-stack	Displays information about the TCP stack running on CMCC adapter interfaces.
show extended channel udp-listeners	Displays information about the UDP listener sockets running on the CMCC adapter interfaces.
show extended channel udp-stack	Displays information about the UDP stack running on the CMCC adapter interfaces.

clear ncia circuit

To drop a specified native client interface architecture (NCIA) circuit, use the **clear ncia circuit** command in privileged EXEC configuration mode.

clear ncia circuit [*id-number*]

Syntax Description	<i>id-number</i>	(Optional) Number assigned to identify the circuit. If no circuit ID number is specified, the command drops all circuits.
--------------------	------------------	---

Command Modes	Privileged EXEC
---------------	-----------------

Command History	Release	Modification
	11.2	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	If no circuit ID number is specified, the command drops all circuits.
------------------	---

Examples	The following example clears the active NCIA circuit identified as 791F8C: Router# clear ncia circuit 791F8C
----------	--

Related Commands	Command	Description
	show ncia circuits	Displays the state of all circuits involving this MAC address as a source and destination.

clear ncia client

To terminate a specified active client connection, use the **clear ncia client** command in privileged EXEC configuration mode.

clear ncia client [*ip-address*]

Syntax Description

<i>ip-address</i>	(Optional) IP address of the client. If no IP address is specified in the command, the command terminates all active client connections.
-------------------	--

Command Modes

Privileged EXEC

Command History

Release	Modification
11.2	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

If no IP address is specified in the command, the command terminates all active client connections.

Examples

The following example terminates the active connection to the client identified by the IP address 10.2.20.126:

```
Router# clear ncia client 10.2.20.126
```

Related Commands

Command	Description
show ncia client	Displays the status of the NCIA client.

clear ncia client registered

To release the control block of a specified registered client after terminating the active connection to it, use the **clear ncia client registered** command in privileged EXEC configuration mode.

clear ncia client registered [*ip-address*]

Syntax Description

ip-address (Optional) IP address of the registered client. If no IP address is specified in the command, the command releases the control blocks of all registered clients after terminating any active connections to them.

Command Modes

Privileged EXEC

Command History

Release	Modification
11.2	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

If no IP address is specified in the command, the command releases the control blocks of all registered clients after terminating any active connections to them.

Examples

The following example terminates the active connection to the registered client identified by the IP address 10.2.20.126 and releases its control block:

```
Router# clear ncia client registered 10.2.20.126
```

Related Commands

Command	Description
show ncia client	Displays the status of the NCIA client.

clear netbios-cache

To clear the entries of all dynamically learned NetBIOS names, use the **clear netbios-cache** command in privileged EXEC mode.

clear netbios-cache

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	10.0	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines The Cisco IOS software automatically learns NetBIOS names. This command clears those entries. This command will not remove statically defined name cache entries.

Examples The following example clears all dynamically learned NetBIOS names:

```
Router# clear netbios-cache
```

Related Commands	Command	Description
	netbios enable-name-cache	Enables NetBIOS name caching.
	netbios name-cache timeout	Enables NetBIOS name caching and sets the time that entries can remain in the NetBIOS name cache.
	show netbios-cache	Displays a list of NetBIOS cache entries.

clear rif-cache

To clear the entire Routing Information Field (RIF) cache, use the **clear rif-cache** command in privileged EXEC mode.

clear rif-cache

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	10.0	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines Some entries in the RIF cache are dynamically added and others are static.

Examples The following example clears the entire RIF cache:

```
Router# clear rif-cache
```

Related Commands	Command	Description
	rif	Enters static source-route information into the RIF cache.
	rif timeout	Determines the number of minutes an inactive RIF entry is kept. RIF information is maintained in a cache whose entries are aged.
	show rif	Displays the current contents of the RIF cache.

clear source-bridge

To clear the source-bridge statistical counters, use the **clear source-bridge** command in privileged EXEC mode.

clear source-bridge

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	10.0	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples The following example clears the source-bridge statistical counters:

```
Router# clear source-bridge
```

Related Commands	Command	Description
	clear bridge	Removes any learned entries from the forwarding database and clears the transmit and receive counts for any statically or system-configured entries.

clear sse

To reinitialize the Silicon Switch Processor (SSP) on the Cisco 7000 series routers with RSP7000, use the **clear sse** command in privileged EXEC mode.

clear sse

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Defaults	Disabled.
-----------------	-----------

Command Modes	Privileged EXEC
----------------------	-----------------

Command History	Release	Modification
	10.3	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines	The silicon switching engine (SSE) is on the SSP board in the Cisco 7000 series routers with RSP7000.
-------------------------	---

Examples	The following example re initializes the SSP:
-----------------	---

```
Router# clear sse
```

clear vlan statistics

To remove virtual LAN statistics from any statically or system-configured entries, use the **clear vlan statistics** command in privileged EXEC mode.

clear vlan statistics

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	11.2	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples The following example clears VLAN statistics:

```
Router# clear vlan statistics
```

Related Commands	Command	Description
	show vlan counters	Displays the software-cached counter values.

client ip

To add an IP subnet to a client subnet response-time group, use the **client ip** command in response-time configuration mode. To remove an IP subnet from a client subnet response-time group, use the **no** form of this command.

client ip *ip-address* [*ip-mask*]

no client ip *ip-address* [*ip-mask*]

Syntax Description

<i>ip-address</i>	IP subnet being added to the response-time group.
<i>ip-mask</i>	(Optional) Mask applied to a client IP address to determine the client's membership in a client subnet group. When the mask is applied to a connecting client's IP address and the resulting address is equal to the defined IP address, the client becomes a member of the client group. The default mask is 255.255.255.255.

Defaults

The default mask is 255.255.255.255.

Command Modes

Response-time configuration

Command History

Release	Modification
11.2(18)BC	This command was introduced.
12.0(5)T	This command was integrated into Cisco IOS Release 12.0 T.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples

The following example adds an IP subnet to a client subnet response-time group:

```
tn3270-server
response-time group acctg
client ip 10.1.2.3 255.0.0.0
```

Related Commands

Command	Description
response-time group	Configures a client subnet group for response-time measurements.
show extended channel tn3270-server response-time application	Displays information about application response-time client groups.
show extended channel tn3270-server response-time global	Displays information about the global response-time client group.

Command	Description
show extended channel tn3270-server response-time link	Displays information about host link response-time client groups.
show extended channel tn3270-server response-time listen-point	Displays information about listen point response-time client groups.
show extended channel tn3270-server response-time subnet	Displays information about Subnet response-time client groups.
tn3270-server	Starts the TN3270 server on a CMCC adapter and enters TN3270 server configuration mode.

client ip lu

To define a specific logical unit (LU) or range of LUs to a client at the IP address or subnet, use the **client ip lu** command in TN3270 PU configuration mode. To cancel this definition, use the **no** form of this command.

client [**printer**] **ip** *ip-address* [*ip-mask*] **lu** *first-locaddr* [*last-locaddr*]

no client [**printer**] **ip** *ip-address* [*ip-mask*] **lu** *first-locaddr* [*last-locaddr*]

Syntax Description	printer	(Optional) Specifies that a client connection from the nailed IP addresses will be nailed to one of the specified LUs only if the client session negotiates a model type of 328x, where x is any alphanumeric character. Moreover, it ensures that a printer matching the IP address condition can be used only on an LU nailed as a printer LU.
		If the printer keyword is not specified for any client statement that has this IP address set, all model types can use this range of LUs.
	<i>ip-address</i>	Specifies the remote client IP address.
	<i>ip-mask</i>	(Optional) The mask applied to the remote device address. Multiple client IP addresses in the same subnet can be nailed to the same range of local address.
	<i>first-locaddr</i>	Defines a single local address to nail.
	<i>last-locaddr</i>	(Optional) Defines the end range of inclusive local address to be nailed from <i>first-locaddr</i> to <i>last-locaddr</i> .

Defaults No LUs are nailed. They are all available to any client.

Command Modes TN3270 PU configuration mode

Command History	Release	Modification
	11.3	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines This command is valid only on the virtual channel interface. Multiple statements can be configured for one IP address or nail type either on one PU or multiple PUs. But each LU can appear in only one **client** statement.

A client with a nailed IP address can request one of the nailed LUs via the TN3270 device name. If the requested LU is not available then the connection is rejected.

A client with a nailed IP address cannot request an LU outside the range of nailed LUs for its type (screen or printer).

A client with a nonnailed IP address cannot request an LU that is configured as nailed.

The command will be rejected if some of the local address are already nailed. If the local address are in use by other remote clients, the nailing statement will take effect only when the local address is made available.

To cancel the definition, the **no client** form of the command must be entered exactly as the **client** command was originally configured. If a range of local address was specified, to cancel this definition the whole range of local address must be specified. There is no way to cancel only one local address if a whole range of local address was configured.

Examples

In the following example, local address from 1 to 50 are reserved for remote devices in the 10.69.176.0 subnet:

```
interface channel 2/2
tn3270-server
pu BAGE4
  client ip 10.69.176.28 255.255.255.0 lu 1 50
```

In the following example, local address 1 to 40 are reserved for screen devices in the 10.69.176.0 subnet, and 41 to 50 are reserved for printers in that subnet:

```
interface channel 2/2
tn3270-server
pu BAGE4
  client ip 10.69.176.28 255.255.255.0 lu 1 40
  client printer ip 10.69.176.28 255.255.255.0 lu 41 50
```

In the following example, an attempt to cancel a definition is rejected because it does not specify the full range of local address and the second attempt fails to specify the correct nail type:

```
interface channel 2/2
tn3270-server
pu BAGE4
  client printer ip 10.69.176.50 255.255.255.0 lu 1 100
  no client printer ip 10.69.176.50 255.255.255.0 lu 1
  %Invalid LU range specified
  no client ip 10.69.176.50 255.255.255.0 lu 1 100
  %client ip 10.69.176.50 nail type not matched with configured nail type printer
```

Related Commands

Command	Description
pu (DLUR)	Creates a PU entity that has no direct link to a host and enters DLUR PU configuration mode.

client ip pool

To nail clients to pools, use the **client ip pool** command in listen-point configuration mode. To remove clients from pools, use the **no** form of this command.

client ip *ip-address* [*ip-mask*] **pool** *poolname*

no client ip *ip-address* [*ip-mask*] **pool** *poolname*

Syntax Description	<i>ip-address</i>	Remote client IP address.
	<i>ip-mask</i>	(Optional) Mask applied to the remote device address. The mask is part of the matching function that determines whether a client is governed by the nailing statement. The default is 255.255.255.255. Multiple client IP addresses in the same subnet can be nailed to the same range of local address.
	<i>poolname</i>	Specifies a unique pool name. The pool name cannot exceed eight characters in length.

Defaults No clients are nailed to pools.

Command Modes Listen-point configuration

Command History	Release	Modification
	11.2(18)BC	This command was introduced.
	12.0(5)T	This command was integrated into Cisco IOS Release 12.0(5)T.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines If the pool is configured while logical unit (LU)s are in use, existing clients are allowed to complete their sessions. A pool name can be identical to an LU name. When assigning an LU, the TN3270 server searches the LU name space first for specific requests, such as connections that specify a device name on CONNECT or LU name in the terminal type negotiation. The request is assumed to be directed to the specific LU rather than to the pool. Make sure the name spaces do not clash.

Examples The following is an example of the **client ip pool** command that nails the client at IP address 10.1.2.3 with an IP mask of 255.255.255.0 to the pool named POOL-1:

```
tn3270-server
pool POOL-1 cluster layout 10slp
listen-point 172.18.4.18
client ip 10.1.2.3 255.255.255.0 pool POOL-1
```

Related Commands

Command	Description
listen-point	Defines an IP address for the TN3270 server.
pool	Defines pool names for the TN3270 server and specifies the number of screens and printers in each logical cluster.
pu (listen-point)	Creates a PU entity that has a direct link to a host and enters listen-point PU configuration mode.
pu dlur (listen-point)	Creates a PU entity that has no direct link to a host and enters listen-point PU configuration mode.
tn3270-server	Starts the TN3270 server on a CMCC adapter and enters TN3270 server configuration mode.

client lu maximum

To limit the number of logical unit (LU) sessions that can be established for each client IP address or IP subnet address, use the **client lu maximum** TN3270 server configuration command. To remove a single LU limit associated with a particular IP address, use the **no** form of this command.

client [*ip-address* [*ip-mask*]] **lu maximum** *number*

no client [*ip-address* [*ip-mask*]]

Syntax Description

<i>ip-address</i>	(Optional) IP address of the client. The value for the <i>ip</i> argument is optional when setting the maximum number of LU sessions. If no IP address is specified, then the limit is applied to all clients.
<i>ip-mask</i>	(Optional) IP network mask for the client. The default is 255.255.255.255.
<i>number</i>	(Optional) Maximum number of LU sessions. The allowed value is from 0 to 65535.

Defaults

The default is that there is no limit on the number of concurrent sessions from one client IP address. The default value for the *ip-mask* argument is 255.255.255.255. In the **no** form of this command, the default value for the *number* argument is 65535.

Command Modes

TN3270 server configuration

Command History

Release	Modification
12.0	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

This command is valid only on the virtual channel interface. An instance of the **client** (lu limit) command on a given tn3270-server is uniquely identified by the *ip-mask* and the logical AND of the *ip-address* with that mask. For example, if the command is entered as the following:

```
client 10.1.1.62 255.255.255.192 lu maximum 2
```

Then it will be stored (and subsequently displayed by **write term**) as:

```
client 10.1.1.0 255.255.255.192 lu maximum 2
```

The maximum specified on the command can be changed by reissuing the command with the new value. It is not necessary to remove the command first.

When you use the **no client** command, only the corresponding **client lu maximum** statement is removed, as identified by the IP address and IP address mask combination. You cannot use the **no client** command to specify an unlimited number of LU sessions. The **lu maximum** keyword is optional in the **no** form of the command.

For example, if a service bureau has 8000 clients and each client IP address is limited to four LU sessions, you will never need more than 32000 concurrent LU definitions even when the service is running at 100 percent capacity.

Examples

The following example limits all clients to a maximum of two LU sessions:

```
client lu maximum 2
```

The following example limits a client at IP address 10.1.1.28 to a maximum of three LU sessions:

```
client 10.1.1.28 lu maximum 3
```

The LU limit can be applied to different subnets as shown in the following example. The most exact match to the client IP address is chosen. Clients with IP addresses that reside in the subnet 10.1.1.64 (those with IP addresses in the range from 10.1.1.64 through 10.1.1.127) are limited to a maximum of five LU sessions while other clients with IP addresses in the subnet 10.1.1.0 are limited to a maximum of four LU sessions.

```
client 10.1.1.0 255.255.255.0 lu maximum 4
client 10.1.1.64 255.255.255.192 lu maximum 5
```

The following example prevents an LU session for the client at IP address 10.1.1.28:

```
client 10.1.1.28 lu maximum 0
```

Related Commands

Command	Description
maximum-lus	Limits the number of LU control blocks that will be allocated for TN3270 server use.

client pool

To nail clients to pools, use the **client pool** command in listen-point configuration mode. To remove clients from pools, use the **no** form of this command.

client {[**ip** *ip-address* [*ip-mask*]] | [**name** *DNS-name* [*DNS-domain-identifier*]] | [**domain-name** *DNS-domain*] | [**domain-id** *DNS-domain-identifier*]} **pool** *poolname*

no client {[**ip** *ip-address* [*ip-mask*]] | [**name** *DNS-name* [*DNS-domain-identifier*]] | [**domain-name** *DNS-domain*] | [**domain-id** *DNS-domain-identifier*]} **pool** *poolname*

Syntax Description		
ip <i>ip-address</i>		Remote client IP address.
<i>ip-mask</i>		(Optional) Mask applied to the remote device address. The mask is part of the matching function that determines whether a client is governed by the nailing statement. The default is 255.255.255.255. Multiple client IP addresses in the same subnet can be nailed to the same pool.
name <i>DNS-name</i>		(Optional) Alphanumeric string that specifies a client machine name. The string can contain up to 24 characters. If a valid <i>DNS-domain-identifier</i> is not present, this name must be fully qualified. If this name is not fully qualified, any dot that forms the boundary between the Domain Name System (DNS) name and the DNS domain must be included here if it is not already present in the DNS domain.
<i>DNS-domain-identifier</i>		(Optional) A numeric identifier that specifies a domain name. The valid value range is from 1 to 255. Each domain-id command statement can have only one <i>DNS-domain-identifier</i> value.
domain-name <i>DNS-domain</i>		(Optional) Alphanumeric string that specifies a domain name suffix, including all dots (.) but not delimited by dots. The string can contain up to 80 characters. All dots must be included when the string is appended to a configured DNS-name. If the DNS-domain starts with a dot, then the dot must be included if it is not already at the end of the DNS-name.
domain-id <i>DNS-domain-identifier</i>		(Optional) Numeric identifier that specifies that a domain name suffix will be appended to the name configured in the domain-id command. The valid value range is from 1 to 255. Each domain-id command statement can have only one <i>DNS-domain-identifier</i> value.
		The domain id is originally specified in the domain-id command.
<i>poolname</i>		Specifies a unique pool name. The pool name cannot exceed eight characters in length.

Defaults No default behavior or values.

Command Modes Listen-point configuration

Command History

Release	Modification
11.2(18)BC	This command was introduced.
12.0(5)T	This command was integrated in Cisco IOS Release 12.0 T.
12.1(5)T	This command was modified to include the name , domain-name , and domain-id keywords. The name of the command was changed from client ip pool to client pool .
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

If the pool is configured while logical units (LU)s are in use, existing clients are allowed to complete their sessions. A pool name can be identical to an LU name. When assigning an LU, the TN3270 server searches the LU name space first for specific requests, such as connections that specify a device name on CONNECT or LU name in the terminal type negotiation. The request is assumed to be directed to the specific LU rather than to the pool. Make sure the LU names do not conflict.

Examples**Nailing Clients to Pools by IP Address**

The following is an example of the **client pool** command with the **ip** keyword configured. The command nails the client at IP address 10.1.2.3 with an IP mask of 255.255.255.0 to the pool named POOL-1:

```
tn3270-server
 pool POOL-1 cluster layout 10s1p
 listen-point 172.18.4.18
 client ip 10.1.2.3 255.255.255.0 pool POOL-1
```

Nailing Clients to Pools by Device Name

The following is an example of the **client pool** command with the **name** keyword configured. The command nails the client at device name user1.cisco.com to the pool named POOL-2:

```
tn3270-server
 pool POOL-2 cluster layout 4s1p
 listen-point 172.18.5.168
 pu T240CA 91922363 token-adapter 31 12 rmac 4000.4000.0001
 allocate lu 1 pool POOL-2 clusters 1
 client name user1.cisco.com pool POOL-2
```

Nailing Clients to Pools by Device Name Using a Domain ID

The following is an example of the **client pool** command with the **name** keyword and the optional *DNS-domain-identifier* argument configured. The command nails the client at device name lucy-isdn49.cisco.com to the pool named POOL-2:

```
tn3270-server
 domain-id 23 .cisco.com
 pool POOL-2 cluster layout 4s1p
 listen-point 172.18.5.168
 pu T240CA 91922363 token-adapter 31 12 rmac 4000.4000.0001
 allocate lu 1 pool POOL-2 clusters 1
 client name lucy-isdn49 23 pool POOL-2
```

Nailing Clients to Pools by Domain Name

The following is an example of the **client pool** command with the **domain-name** keyword configured. The command nails any client at domain name cisco.com to the pool named POOL-2:

```
tn3270-server
 pool POOL-2 cluster layout 4slp
 listen-point 172.18.5.168
 pu T240CA 91922363 token-adapter 31 12 rmac 4000.4000.0001
 allocate lu 1 pool POOL-2 clusters 1
 client domain-name .cisco.com pool POOL-2
```

Nailing Clients to Pools by Domain Name Using a Domain ID

The following is an example of the **client pool** command with the **domain-id** keyword configured. The command nails any client at domain name cisco.com to the pool named POOL-2:

```
tn3270-server
 domain-id 23 .cisco.com
 pool POOL-2 cluster layout 4slp
 listen-point 172.18.5.168
 pu T240CA 91922363 token-adapter 31 12 rmac 4000.4000.0001
 allocate lu 1 pool POOL-2 clusters 1
 client domain-id 23 pool POOL-2
```

Related Commands

Command	Description
listen-point	Defines an IP address for the TN3270 server.
pool	Defines pool names for the TN3270 server and specifies the number of screens and printers in each logical cluster.
pu dlur (listen-point)	Creates a PU entity that has no direct link to a host and enters listen-point PU configuration mode.
pu (listen-point)	Creates a PU entity that has a direct link to a host and enters listen-point PU configuration mode.
tn3270-server	Starts the TN3270 server on a CMCC adapter and enters TN3270 server configuration mode.
domain-id	Specifies a domain name suffix that the TN3270 server appends to a configured machine name to form a fully-qualified name when configuring inverse DNS nailing.

cmpc

To configure a Cisco Multipath Channel (CMPC or CMPC+) read subchannel and a CMPC (or CMPC+) write subchannel, use the **cmpc** command in interface configuration mode. To remove a subchannel definition and to deactivate the transmission group, use the **no** form of this command.

cmpc *path device tg-name* {**read** | **write**}

no cmpc *path device*

Syntax Description

<i>path</i>	Hexadecimal value in the range from 0000 to FFFF. This value specifies the logical channel path and consists of two digits for the physical connection (either on the host or on the ESCON director), one digit for the channel logical address, and one digit for the control unit logical address. If the path is not specified in the input/output configuration program (IOCP), the default value for channel logical address and control unit logical address is 0.
<i>device</i>	Hexadecimal value in the range from 00 to FF. This is the unit address associated with the control unit number and path as specified in the host IOCP file.
<i>tg-name</i>	Name of the CMPC or CMPC+ Transmission Group (TG). The maximum length of the name is eight characters.
read	Same read value as specified in the Transport Resource List (TRL) major node.
write	Same write value as specified in the TRL major node.

Defaults

No default is specified.

Command Modes

Interface configuration

Command History

Release	Modification
11.3	This command was introduced.
12.0(3)T	Support was added for the CMPC+ feature.
12.3(4)T	CMPC is no longer available in Cisco IOS release 12.3(4).
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

Each **cmpc** configuration command in a given CMPC or CMPC+ TG specifies the same TG name. The corresponding **tg** command specifies the same TG name. Together, the **cmpc** and **tg** commands make up the TG specification.

The **cmpc** command defines the read/write subchannel addresses that CMPC or CMPC+ uses to connect to the host. The command corresponds to the definitions in the TRL major node on the host. Configure the **cmpc** command on a Cisco Mainframe Channel Connection (CMCC) adapter physical interface.

Configure one read subchannel and one write subchannel. If CMPC or CMPC+ is configured on a CMCC adapter with two physical interfaces, the read and write CMPC or CMPC+ subchannels may be configured on separate physical interfaces.

The **no cmpr** command deactivates the CMPC or CMPC+ subchannel. If the TG is used for a non-High-Performance Routing (HPR) connection, all sessions using the TG will be terminated immediately. If the TG is an HPR connection, all sessions using the TG will be terminated if no other HPR connection is available to the host.

Examples

The following example configures a read and a write subchannel on path C020 for the CMPC or CMPC+ TG named CONFIGE:

```
cmpr C020 F8 CONFIGE READ
cmpr C020 F9 CONFIGE WRITE
```

Related Commands

Command	Description
tg (CMPC+)	Defines IP connection parameters for the CMPC+ transmission group.
show extended channel cmpr	Displays information about each CMPC or CMPC+ subchannel configured on the specified channel interface.
show extended channel tg	Displays configuration, operational information, and statistics information for CMPC or CMPC+ transmission groups configured on the virtual interface of the specified CMCC adapter.
show extended channel subchannel	Displays information about the CMCC adapter physical interfaces and displays information that is specific to the interface channel connection. The information displayed generally is useful only for diagnostic tasks performed by technical support personnel.
show extended channel statistics	Displays statistical information about subchannels on the physical interface of a CMCC adapter and displays information that is specific to the interface channel devices. The information generally is useful only for diagnostic tasks performed by technical support personnel.

csna

To configure Systems Network Architecture (SNA) support on a Cisco Mainframe Channel Connection (CMCC) physical channel interface, use the **csna** command in interface configuration mode. This command is used to specify the path and device or subchannel on a physical channel of the router to communicate with an attached mainframe. To delete the Cisco Systems Network Architecture (CSNA) device path, use the **no** form of this command.

csna *path device* [**maxpiu** *value*] [**time-delay** *value*] [**length-delay** *value*]

no *csna path device*

Syntax Description

<i>path</i>	Hexadecimal value in the range from 0000 to FFFF. This value specifies the logical channel path and consists of two digits for the physical connection (either on the host or on the ESCON director), one digit for the channel logical address, and one digit for the control unit logical address. If the path is not specified in the input/output configuration program input/output configuration program (IOCP), the default value for channel logical address and control unit logical address is 0.
<i>device</i>	Hexadecimal value in the range from 00 to FF. This is the unit address associated with the control unit number and path as specified in the host IOCP file.
maxpiu <i>value</i>	(Optional) Maximum channel I/O block size in bytes that is sent across the physical channel from the CMCC adapter to the attached mainframe. The range is from 4096 to 65535 bytes. The default is 20470 bytes.
time-delay <i>value</i>	(Optional) Number of milliseconds (ms) a host-bound SNA frame may be delayed in order to maximize the channel I/O block size. The range is from 0 to 100 ms. The default is 10 ms.
length-delay <i>value</i>	(Optional) Amount of SNA frame data in bytes the Cisco Systems Network Architecture (CSNA) subchannel accumulates before sending the accumulated channel I/O block to the attached mainframe. The range is from 0 to 65535 bytes. The default is 20470 bytes.

Defaults

maxpiu *value*: 20470 bytes
time-delay *value*: 10 ms
length-delay *value*: 20470 bytes

Command Modes

Interface configuration

Command History

Release	Modification
11.0	This command was introduced.

Release	Modification
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

The **maxpiu**, **time-delay** and **length-delay** keywords control the characteristics of host-bound traffic for the CSNA subchannel. The channel protocol used by CSNA allows multiple SNA frames to be blocked into one channel I/O block, reducing the channel bandwidth utilization and mainframe and CMCC adapter process utilization.

The **maxpiu** keyword allows you to set the maximum size of a host-bound channel I/O block.

The **time-delay** keyword instructs the CSNA subchannel to delay sending the channel I/O block for the specified time in milliseconds, from the time the first SNA packet is blocked. This can increase the network latency for an SNA packet by up to the specified time delay.

The **length-delay** keyword instructs the CSNA subchannel to delay sending the channel I/O block until it contains the number of bytes specified by the **length-delay** keyword. An accumulated block is sent to the mainframe if one of the following conditions is true:

- **Time delay** expires
- Channel I/O block reaches the **length-delay** size
- Channel I/O block reaches the **maxpiu** size.

A time delay value of 0 instructs the CSNA subchannel to send SNA packets to the mainframe as soon as they are received from the network. A length delay value of 0 instructs the CSNA subchannel to ignore this parameter.

The **no csna** command deactivates and removes the CSNA subchannel configuration. It also deactivates all Logical Link Control, type 2 (LLC2) sessions established over the subchannel.

Examples

The following example shows CSNA, offload, and Common Link Access for Workstations (CLAW) configured on a channel interface. CSNA has no dependencies to CLAW, offload, or CMPC.

```
interface channel 1/0
 no ip address
 no keepalive
 offload c700 c0 172.18.1.127 TCPIP OS2TCP TCPIP TCPIP TCPIP API
 claw C700 c2 172.18.1.219 EVAL CISCOVM AAA BBB
 csna c700 c4
 csna c700 c5 maxpiu 65535 time-delay 100 length-delay 65535
 csna c700 c6 maxpiu 65535 time-delay 100
```

Related Commands

Command	Description
adapter	Configures internal adapters.
lan	Configures an internal LAN on a CMCC adapter interface and enters the internal LAN configuration mode.
show extended channel connection-map llc2	Displays the number of active LLC2 connections for each SAP and the mapping of the internal MAC adapter and the SAP to the resource that activated the SAP.

Command	Description
show extended channel csna	Displays information about the CSNA subchannels configured on the specified CMCC interface.
show extended channel statistics	Displays statistical information about subchannels on the physical interface of a CMCC adapter and displays information that is specific to the interface channel devices. The information generally is useful only for diagnostic tasks performed by technical support personnel.
show extended channel subchannel	Displays information about the CMCC adapter physical interfaces and displays information that is specific to the interface channel connection. The information displayed generally is useful only for diagnostic tasks performed by technical support personnel.