



Cisco IOS Service Advertisement Framework Command Reference

March 2011

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Cisco and the Cisco Logo are trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and other countries. A listing of Cisco's trademarks can be found at www.cisco.com/go/trademarks. Third party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1005R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

Cisco IOS Service Advertisement Framework Command Reference

© 2011 Cisco Systems, Inc. All rights reserved.



CONTENTS

Introduction SAF-1

Cisco SAF Commands SAF-2

accept-lifetime	SAF-3
authentication key-chain (EIGRP)	SAF-6
authentication mode (EIGRP)	SAF-8
bandwidth-percent	SAF-10
clear eigrp service-family	SAF-13
dampening-change	SAF-15
dampening-interval	SAF-17
debug eigrp service-family	SAF-19
default (SAF)	SAF-22
default external-client	SAF-23
eigrp log-neighbor-changes	SAF-24
eigrp log-neighbor-warnings	SAF-26
eigrp router-id	SAF-28
eigrp stub (service-family)	SAF-30
exit-service-family	SAF-32
exit-sf-interface	SAF-33
exit-sf-topology	SAF-34
external-client	SAF-35
hello-interval	SAF-37
hold-time	SAF-39
keepalive (SAF)	SAF-41
key	SAF-42
key chain	SAF-45
key-string (authentication)	SAF-48
maximum-service (EIGRP)	SAF-51
metric weights (EIGRP)	SAF-53
neighbor (service-family)	SAF-56
password (SAF)	SAF-59

remote-neighbors	SAF-60
send-lifetime	SAF-62
service-family	SAF-65
service-family external-client listen	SAF-67
sf-interface	SAF-69
show eigrp plugins	SAF-71
show eigrp protocols	SAF-73
show eigrp service-family	SAF-76
show eigrp service-family external-client	SAF-84
show eigrp service-family ipv4 topology	SAF-87
show eigrp service-family ipv6 topology	SAF-91
show eigrp tech-support	SAF-95
shutdown (service-family)	SAF-97
split-horizon (EIGRP)	SAF-99
timers graceful-restart purge-time	SAF-101
topology	SAF-103
username (SAF)	SAF-105



Introduction

This book contains the commands used to configure and maintain the Cisco Service Advertisement Framework (Cisco SAF) feature. The commands are listed alphabetically.

For Cisco SAF configuration information and examples, see the *Cisco IOS Service Advertisement Framework Configuration Guide*.



Cisco SAF Commands

accept-lifetime

To set the time period during which the authentication key on a key chain is received as valid, use the **accept-lifetime** command in key chain key configuration mode. To revert to the default value, use the **no** form of this command.

accept-lifetime *start-time* { **infinite** | *end-time* | **duration** *seconds* }

no accept-lifetime [*start-time* { **infinite** | *end-time* | **duration** *seconds* }]

Syntax Description

<i>start-time</i>	Beginning time that the key specified by the key command is valid to be received. The syntax can be either of the following: <i>hh:mm:ss Month date year</i> <i>hh:mm:ss date Month year</i> <ul style="list-style-type: none"> <i>hh</i>—hours <i>mm</i>—minutes <i>ss</i>—seconds <i>Month</i>—first three letters of the month <i>date</i>—date (1–31) <i>year</i>—year (four digits) The default start time and the earliest acceptable date is January 1, 1993.
infinite	Key is valid to be received from the <i>start-time</i> value on.
<i>end-time</i>	Key is valid to be received from the <i>start-time</i> value until the <i>end-time</i> value. The syntax is the same as that for the <i>start-time</i> value. The <i>end-time</i> value must be after the <i>start-time</i> value. The default end time is an infinite time period.
duration <i>seconds</i>	Length of time (in seconds) that the key is valid to be received. The range is from 1 to 2147483646.

Command Default

The authentication key on a key chain is received as valid forever (the starting time is January 1, 1993, and the ending time is infinite).

Command Modes

Key chain key configuration (config-keychain-key)

Command History

Release	Modification
11.1	This command was introduced.
12.4(6)T	Support for IPv6 was added.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Release	Modification
15.0(1)M	This command was integrated into Cisco IOS Release 15.0(1)M.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.

Usage Guidelines

Only DRP Agent, Enhanced Interior Gateway Routing Protocol (EIGRP), Service Advertisement Framework (SAF), and Routing Information Protocol (RIP) Version 2 use key chains.

Specify a *start-time* value and one of the following values: **infinite**, *end-time*, or **duration seconds**.

We recommend running Network Time Protocol (NTP) or some other time synchronization method if you assign a lifetime to a key.

If the last key expires, authentication will continue and an error message will be generated. To disable authentication, you must manually delete the last valid key.

Examples

The following example configures a key chain named chain1. The key named key1 will be accepted from 1:30 p.m. to 3:30 p.m. and will be sent from 2:00 p.m. to 3:00 p.m. The key named key2 will be accepted from 2:30 p.m. to 4:30 p.m. and will be sent from 3:00 p.m. to 4:00 p.m. The overlap allows for migration of keys or a discrepancy in the set time of the router. There is a 30-minute leeway on each side to handle time differences.

```
Router(config)# key chain chain1
Router(config-keychain)# key 1
Router(config-keychain-key)# key-string key1
Router(config-keychain-key)# accept-lifetime 13:30:00 Jan 25 1996 duration 7200
Router(config-keychain-key)# send-lifetime 14:00:00 Jan 25 1996 duration 3600
Router(config-keychain-key)# exit
Router(config-keychain)# key 2
Router(config-keychain)# key-string key2
Router(config-keychain)# accept-lifetime 14:30:00 Jan 25 1996 duration 7200
Router(config-keychain)# send-lifetime 15:00:00 Jan 25 1996 duration 3600
```

The following example configures a key chain named chain1 for EIGRP address-family. The key named key1 will be accepted from 1:30 p.m. to 3:30 p.m. and be sent from 2:00 p.m. to 3:00 p.m. The key named key2 will be accepted from 2:30 p.m. to 4:30 p.m. and be sent from 3:00 p.m. to 4:00 p.m. The overlap allows for migration of keys or a discrepancy in the set time of the router. There is a 30-minute leeway on each side to handle time differences.

```
Router(config)# router eigrp virtual-name
Router(config-router)# address-family ipv4 autonomous-system 4453
Router(config-router-af)# network 10.0.0.0
Router(config-router-af)# af-interface ethernet0/0
Router(config-router-af-interface)# authentication key-chain trees
Router(config-router-af-interface)# authentication mode md5
Router(config-router-af-interface)# exit
Router(config-router-af)# exit
Router(config-router)# exit
Router(config)# key chain chain1
Router(config-keychain)# key 1
Router(config-keychain-key)# key-string key1
Router(config-keychain-key)# accept-lifetime 13:30:00 Jan 25 1996 duration 7200
Router(config-keychain-key)# send-lifetime 14:00:00 Jan 25 1996 duration 3600
Router(config-keychain-key)# exit
```



```

Router(config-keychain)# key 2
Router(config-keychain-key)# key-string key2
Router(config-keychain-key)# accept-lifetime 14:30:00 Jan 25 1996 duration 7200
Router(config-keychain-key)# send-lifetime 15:00:00 Jan 25 1996 duration 3600

```

The following named configuration example configures a key chain named chain1 for EIGRP service-family. The key named key1 will be accepted from 1:30 p.m. to 3:30 p.m. and be sent from 2:00 p.m. to 3:00 p.m. The key named key2 will be accepted from 2:30 p.m. to 4:30 p.m. and be sent from 3:00 p.m. to 4:00 p.m. The overlap allows for migration of keys or a discrepancy in the set time of the router. There is a 30-minute leeway on each side to handle time differences.

```

Router(config)# router eigrp virtual-name
Router(config-router)# service-family ipv4 autonomous-system 4453
Router(config-router-sf)# network 10.0.0.0
Router(config-router-sf)# sf-interface ethernet0/0
Router(config-router-sf-interface)# authentication key-chain trees
Router(config-router-sf-interface)# authentication mode md5
Router(config-router-sf-interface)# exit
Router(config-router-sf)# exit
Router(config-router)# exit
Router(config)# key chain chain1
Router(config-keychain)# key 1
Router(config-keychain-key)# key-string key1
Router(config-keychain-key)# accept-lifetime 13:30:00 Jan 25 1996 duration 7200
Router(config-keychain-key)# send-lifetime 14:00:00 Jan 25 1996 duration 3600
Router(config-keychain-key)# exit
Router(config-keychain)# key 2
Router(config-keychain-key)# key-string key2
Router(config-keychain-key)# accept-lifetime 14:30:00 Jan 25 1996 duration 7200
Router(config-keychain-key)# send-lifetime 15:00:00 Jan 25 1996 duration 3600

```

Related Commands

Command	Description
authentication key-chain	Specifies an authentication key chain EIGRP.
authentication mode (EIGRP)	Specifies the type of authentication used in EIGRP packets for the EIGRP instance.
key	Identifies an authentication key on a key chain.
key chain	Defines an authentication key-chain needed to enable authentication for routing protocols.
key-string (authentication)	Specifies the authentication string for a key.
network	Specifies the network for an EIGRP routing process.
router eigrp	Configures the EIGRP process.
send-lifetime	Sets the time period during which an authentication key on a key chain is valid to be sent.
service-family	Configures VRF metrics for a Cisco SAF service-family.
sf-interface	Configure interface-specific commands for a Cisco SAF service family.
show key chain	Displays authentication key information.

authentication key-chain (EIGRP)

To specify an authentication key chain for Enhanced Interior Gateway Routing Protocol (EIGRP), use the **authentication key-chain** (EIGRP) command in address-family interface configuration mode or service-family interface configuration mode. To remove the authentication key-chain, use the **no** form of this command.

authentication key-chain *name-of-chain*

no authentication key-chain *name-of-chain*

Syntax Description	<i>name-of-chain</i>	Group of keys that are valid.
---------------------------	----------------------	-------------------------------

Command Default	No key chains are specified for EIGRP.
------------------------	--

Command Modes	Address-family interface configuration (router-config-af-interface) Service-family interface configuration (router-config-sf-interface)
----------------------	--

Command History	Release	Modification
	15.0(1)M	This command was introduced.
	12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
	12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
	Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.
	12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.

Usage Guidelines	The key-chain command has no effect until the authentication mode md5 command is configured. Only one authentication key chain is applied to EIGRP at one time. That is, if you configure a second authentication key-chain command, the first is overridden.
-------------------------	---

Examples	The following example configures EIGRP to apply authentication to address-family autonomous system 1 and identifies a key chain named SITE1:
-----------------	--

```
Router(config)# router eigrp virtual-name
Router(config-router)# address-family ipv4 autonomous-system 1
Router(config-router-af)# af-interface ethernet0/0
Router(config-router-af-interface)# authentication key-chain SITE1
Router(config-router-af-interface)# authentication mode md5
```

The following example configures EIGRP to apply authentication to service-family autonomous system 1 and identifies a key chain named SITE1:

```
Router(config)# router eigrp virtual-name  
Router(config-router)# service-family ipv4 autonomous-system 1  
Router(config-router-sf)# sf-interface ethernet0/0  
Router(config-router-sf-interface)# authentication key-chain SITE1  
Router(config-router-sf-interface)# authentication mode md5
```

Related Commands

Command	Description
authentication mode (EIGRP)	Specifies the type of authentication used in EIGRP address-family packets for the EIGRP instance.
key chain	Defines an authentication key chain needed to enable authentication for routing protocols.
router eigrp	Configures the EIGRP address-family process.

authentication mode (EIGRP)

To specify the type of authentication used in Enhanced Interior Gateway Routing Protocol (EIGRP) address-family or service-family packets for an EIGRP instance, use the **authentication mode** command in address family interface configuration mode or service family interface configuration mode. To disable a configured authentication type, use the **no** form of this command.

authentication mode { **hmac-sha-256** { **0** | **7** } *password* | **md5** }

no authentication mode

Syntax Description

hmac-sha-256	Specifies the Hash-based Message Authentication Code (HMAC)-Secure Hash Algorithms (SHA)-256 authentication.
0	Indicates no password encryption. The default is 0.
7	Indicates explicit password encryption.
<i>password</i>	Password string to be used with SHA authentication. The string can contain 1 to 32 characters including whitespaces, except that the first character cannot be a number.
md5	Specifies message digest algorithm 5 (MD5) authentication.

Command Default

No authentication mode is provided for EIGRP packets.

Command Modes

Address family interface configuration (config-router-af-interface)
Service family interface configuration (config-router-sf-interface)

Command History

Release	Modification
15.0(1)M	This command was introduced.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.
12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.
15.1(2)S	This command was modified. The hmac-sha-256 keyword and the <i>encryption-type</i> and <i>password</i> arguments were added.

Usage Guidelines

Configure authentication to prevent unapproved sources from introducing unauthorized or false service messages.

When the **authentication mode** (EIGRP) command is used in conjunction with the **authentication key-chain** command, an MD5 keyed digest is added to each EIGRP packet.

To configure basic HMAC-SHA-256 authentication, use the **authentication mode hmac-sha-256** command on each interface of each router that should use authentication.

Examples

The following example shows how to configure the interface to use MD5 authentication in address-family packets:

```
Router(config)# router eigrp virtual-name
Router(config-router)# address-family ipv4 autonomous-system 1
Router(config-router-af)# af-interface ethernet0/0
Router(config-router-af-interface)# authentication key-chain TEST1
Router(config-router-af-interface)# authentication mode md5
```

The following example configures the interface to use MD5 authentication in service-family packets:

```
Router(config)# router eigrp virtual-name
Router(config-router)# service-family ipv4 autonomous-system 1
Router(config-router-sf)# sf-interface ethernet0/0
Router(config-router-sf-interface)# authentication key-chain TEST1
Router(config-router-sf-interface)# authentication mode md5
```

The following example shows how to configure the interface to use basic SHA authentication with password password1 in address-family packets:

```
Router(config)# router eigrp virtual-name
Router(config-router)# address-family ipv6 autonomous-system 4453
Router(config-router-af)# af-interface ethernet 0
Router(config-router-af-interface)# authentication mode hmac-sha-256 7 password1
```

The following example shows how to configure an interface to use basic SHA authentication with password password1 in service-family packets:

```
Router(config)# router eigrp virtual-name
Router(config-router)# service-family ipv4 autonomous-system 6473
Router(config-router-sf)# sf-interface ethernet 0
Router(config-router-sf-interface)# authentication mode hmac-sha-256 7 password1
```

Related Commands

Command	Description
address-family (EIGRP)	Enters address family configuration mode to configure an EIGRP routing instance.
af-interface	Enters address family interface configuration mode to configure interface-specific EIGRP commands.
authentication key-chain	Specifies the type of authentication used in EIGRP address-family or service-family packets for the EIGRP instance.
key chain	Defines an authentication key chain needed to enable authentication for routing protocols.
router eigrp	Configures the EIGRP address-family process.

bandwidth-percent

To configure the percentage of bandwidth that may be used by an Enhanced Interior Gateway Routing Protocol (EIGRP) address family or service family on an interface, use the **bandwidth-percent** command in address-family interface configuration mode or service-family interface configuration mode. To restore the default value, use the **no** form of this command.

bandwidth-percent *maximum-bandwidth-percentage*

no bandwidth-percent

Syntax Description	<i>maximum-bandwidth-percentage</i>	Percent of configured bandwidth that EIGRP may use to send packets. Valid range is 1 to 999999. The default is 50 percent.
---------------------------	-------------------------------------	--

Command Default	EIGRP limits bandwidth usage to 50 percent of the configured interface bandwidth.
------------------------	---

Command Modes	Address-family interface configuration (config-router-af-interface) Service-family interface configuration (config-router-sf-interface)
----------------------	--

Command History	Release	Modification
	15.0(1)M	This command was introduced.
	12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
	12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
	Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.
	12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.

Usage Guidelines	Use the bandwidth-percent command to configure a different percentage of bandwidth for use by EIGRP than specified for the link by using the bandwidth interface command. Values greater than 100 percent may be configured. This option might be useful if the link bandwidth is set artificially low for other reasons. The default bandwidth percent uses 50 percent of the configured bandwidth of the link.
-------------------------	--

Examples	The following example uses up to 75 percent (42 kbps) of a 56-kbps serial link for address-family autonomous system 4453:
-----------------	---

```
Router(config)# router eigrp virtual-name
Router(config-router)# address-family ipv4 autonomous-system 4453
Router(config-router-af)# af-interface ethernet0/0
Router(config-router-af-interface)# bandwidth-percent 75
```

The following example uses up to 75 percent (42 kbps) of a 56-kbps serial link for service-family autonomous system 4533:

```
Router(config)# router eigrp virtual-name
```

```
Router(config-router)# service-family ipv4 autonomous-system 4533  
Router(config-router-sf)# sf-interface serial 0  
Router(config-router-sf-interface)# bandwidth-percent 75
```

Related Commands

Command	Description
address-family (EIGRP)	Enters address-family configuration mode to configure an EIGRP routing instance.
af-interface	Enters address-family interface configuration mode to configure interface-specific EIGRP commands.
router eigrp	Configures the EIGRP address-family process.
service-family	Configures VRF metrics for an EIGRP service-family.
sf-interface	Configures interface-specific commands for an EIGRP service-family.

■ bandwidth-percent

clear eigrp service-family

To clear information for a Cisco SAF service family, use the **clear eigrp service-family** command in privileged EXEC mode.

```
clear eigrp service-family
{external-client name |
 {ipv4 | ipv6} [vrf vrf-name] autonomous-system-number
 neighbors [neighbor-address | interface-type interface-number] [soft]}
```

Syntax Description

external-client	Deletes a specified external client.
<i>name</i>	Specifies the name of the external client.
ipv4	Deletes neighbors formed using the IPv4 protocol family.
ipv6	Deletes neighbors formed using the IPv6 protocol family.
vrf	(Optional) Specifies all virtual routing forwarding (VRF) instance tables or a specific VRF table for an IP address.
<i>vrf-name</i>	(Optional) Names a specific VRF table for the specified IP address.
<i>autonomous-system-number</i>	Specifies the autonomous system number.
neighbors	Deletes neighbors formed using the IP protocol family.
<i>neighbor-address</i>	(Optional) IP address of neighbor.
<i>interface-type</i>	(Optional) Deletes from the neighbor table the interface type and number that all entries learned through this interface.
<i>interface-number</i>	(Optional) Specifies the interface number for the <i>interface-type</i> argument.
soft	(Optional) Resyncs with peer without an adjacency reset.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
15.0(1)M	This command was introduced.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.
12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.

Usage Guidelines

Use the **clear eigrp service-family** command in privileged EXEC mode to remove information related to Cisco SAF service-family neighbors and external clients.



Note

Using the **clear eigrp service-family ipv6** commands requires an IPv6-enabled SAF client, which currently does not exist.

Examples

The following example clears an EIGRP service-family External Client named “example_2” from Cisco SAF:

```
Router> enable
Router# show eigrp service-family external-client

External SAF Connected Clients
Client Label      Client No.      Client API Handle  File Descriptor
example_1         1                1                  1
example_2         2                2                  2

Router# clear eigrp service-family external-client example_2

Router# show eigrp service-family external-client

External SAF Connected Clients
Client Label      Client No.      Client API Handle  File Descriptor
example_1         1                1                  1
```

Related Commands

Command	Description
show eigrp service-family	Displays information about the EIGRP IPv4 or IPv6 service families.
show eigrp service-family external-client	Displays information about the EIGRP service-family External Clients.

dampening-change

To set a threshold percentage to minimize or dampen the effect of frequent routing changes through an interface in an Enhanced Interior Gateway Routing Protocol (EIGRP) address family or service family, use the **dampening-change** command in address-family interface configuration mode or service-family interface configuration mode. To restore the default value, use the **no** form of this command.

dampening-change [*change-percentage*]

no dampening-change

Syntax Description

<i>change-percentage</i>	(Optional) The percentage a metric must change before the value is stored for future decisions on advertisements. Value range is 1 to 100. If a <i>change-percentage</i> value is not specified, the default is 50 percent of the computed metric.
--------------------------	---

Command Default

No threshold percentage is configured.

Command Modes

Address-family interface configuration (config-router-af-interface)
Service-family interface configuration (config-router-sf-interface)

Command History

Release	Modification
15.0(1)M	This command was introduced.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.
12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.

Usage Guidelines

The **dampening-change** command is supported only for Mobile Ad Hoc Networking (MANET) router-to-radio links.

When a peer metric changes on an interface that is configured with the **dampening-change** command, EIGRP multiplies the dampening-change percentage with the old peer metric and compares the result (the threshold) to the difference between the old and new metrics. If the metric difference is greater than the calculated threshold, then the new metric is applied and routes learned from that peer are updated and advertised to other peers. If the metric difference is less than the threshold, the new metric is discarded.

There are exceptions that will result in an immediate update regardless of the dampening-change setting:

- An interface is down.
- A route is down.
- A change in metric which results in the router selecting a new next hop.

Peer metric changes that do not exceed a configured change percentage and that do not result in a routing change do not result in an update being sent to other adjacencies. Peer metric changes are based on the stored last-update of the peer. Peer metric changes that exceed the threshold value are stored and used for future comparisons.

Examples

The following example configures an EIGRP address family to accept a peer metric change if the change is greater than 75 percent of the last updated value:

```
Router(config)# router eigrp virtual-name
Router(config-router)# address-family ipv4 autonomous-system 5400
Router(config-router-af)# af-interface ethernet0/0
Router(config-router-af-interface)# dampening-change 75
```

The following example configures an EIGRP service family to accept a peer metric change if the change is greater than 75 percent of the last updated value:

```
Router(config)# router eigrp virtual-name
Router(config-router)# service-family ipv4 autonomous-system 4533
Router(config-router-sf)# sf-interface serial 0
Router(config-router-sf-interface)# dampening-change 75
```

Related Commands

Command	Description
address-family (EIGRP)	Enters address-family configuration mode to configure an EIGRP routing instance.
af-interface	Enters address-family interface configuration mode to configure interface-specific EIGRP commands.
dampening-interval	Sets a threshold time interval to minimize or dampen the effect of frequent routing changes through an interface in an EIGRP address family or service family.
router eigrp	Configures the EIGRP address-family process.
service-family	Specifies service-family configuration mode.
sf-interface	Configures interface-specific commands under a service family.

dampening-interval

To set a threshold time interval to minimize or dampen the effect of frequent routing changes through an interface in an Enhanced Interior Gateway Routing Protocol (EIGRP) address family or service family, use the **dampening-interval** command in address-family interface configuration mode or service-family interface configuration mode. To restore to the default value, use the **no** form of this command.

dampening-interval [*interval*]

no dampening-interval [*interval*]

Syntax Description

<i>interval</i>	(Optional) Time interval, in seconds, that must elapse before a route change will cause an update to occur. Value range is 1 to 65535. If an <i>interval</i> value is not specified, the default is 30 seconds.
-----------------	---

Command Default

A dampening interval is not enabled.

Command Modes

Address-family interface configuration (config-router-af-interface)
Service-family interface configuration (config-router-sf-interface)

Command History

Release	Modification
15.0(1)M	This command was introduced.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.
12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.

Usage Guidelines

The **dampening-interval** command is supported only in Mobile Ad Hoc Networking (MANET) Router-to-Radio links.

When a peer metric changes on an interface that is configured with a dampening interval, EIGRP will apply the metric change only if the time difference since the last metric changed exceeds the specified interval. If the time difference is less than the specified interval, the update is discarded.

There are exceptions that result in an immediate update regardless of the dampening interval settings:

- An interface is down.
- A route is down.
- A change in metric that results in the router selecting a new next hop.

Examples

The following example configures EIGRP address-family Ethernet interface 0/0 to limit the metric change frequency to no more than one change in a 45-second interval:

```
Router(config)# router eigrp virtual-name
Router(config-router)# address-family ipv4 autonomous-system 5400
Router(config-router-af)# af-interface ethernet0/0
Router(config-router-af-interface)# dampening-interval 45
```

The following example configures EIGRP service-family Serial interface 0 to limit the metric change frequency to no more than one change in a 30 second interval:

```
Router(config)# router eigrp virtual-name
Router(config-router)# service-family ipv4 autonomous-system 4533
Router(config-router-sf)# sf-interface serial0
Router(config-router-sf-interface)# dampening-interval 30
```

Related Commands

Command	Description
address-family (EIGRP)	Enters address-family configuration mode to configure an EIGRP routing instance.
af-interface	Enters address-family interface configuration mode to configure interface-specific EIGRP commands.
dampening-change	Sets a threshold percentage to minimize or dampen the effect of frequent routing changes through an interface in an EIGRP address family or service family.
router eigrp	Configures the EIGRP address-family process.
service-family	Specifies service-family configuration mode.
sf-interface	Configures interface-specific commands under a service family.
shutdown	Disables service family on the interface.

debug eigrp service-family

To troubleshoot an Enhanced Interior Gateway Routing Protocol (EIGRP) service-family external client, client, neighbor, notification, topology, or a VRF instance, use the **debug eigrp service-family** command in privileged EXEC mode.

```
debug eigrp service-family
  [external-client {client client-label | messages [client-label] | protocol [client-label]}]
  | {ipv4 | ipv6} [[vrf vrf-name | autonomous-system-number | service-instance-number] |
  | client client-label
  | neighbor neighbor-ip-address
  | notifications
  topology service-instance-number]
```

Syntax	Description
external-client	(Optional) Displays information for a Cisco SAF External Client.
client	Displays information for managing clients and TCP connections.
messages	(Optional) Reliability metric. The range is 0 to 255, entered in increments of 2.5 where 255 is 100-percent reliable.
protocol	(Optional) Displays information on an external-client protocol.
<i>client-label</i>	(Optional) Displays a client , message , or protocol debug for the specified Cisco SAF External Client.
ipv4	Specifies the IP Version 4 address family for this debug.
ipv6	Specifies the IP Version 6 address family for this debug.
vrf	(Optional) Specifies all virtual routing forwarding (VRF) instance tables or a specific VRF table for an IP address.
<i>vrf-name</i>	(Optional) Specifies a VRF table for an IP address.
<i>autonomous-system-number</i>	The Autonomous system number.
<i>service-instance-number</i>	(Optional) Service-instance number between 1 and 65535. Service instance numbers display as: service:subservice:instance.instance.instance.instance.
client	(Optional) Displays EIGRP client information.
<i>client-label</i>	(Optional) A specific client.
neighbors	(Optional) Displays EIGRP neighbor debugging information.
<i>neighbor-ip-address</i>	(Optional) The IP address of the neighbor.
notifications	(Optional) Displays EIGRP notification debugging information.
topology	(Optional) Specifies a service topology.
<i>service-instance-number</i>	(Optional) Service-instance number between 1 and 65535. Topology service instance numbers display as: service:subservice:instance.instance.instance.instance.

Command Modes Privileged EXEC (#)

Command History

Release	Modification
15.0(1)M	This command was introduced.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.
12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.

Usage Guidelines

Use the **debug eigrp service-family external-client client** command to display information to help manage clients and TCP connections. Use the **debug eigrp service-family external-client messages** command to display message content and decoded messages. Use the **debug eigrp service-family external-client protocol** command to display encode and decode information to help manage the interaction with the Cisco SAF internal API.

**Note**

Using the **debug eigrp service-family ipv6** commands requires an IPv6-enabled SAF client, which currently does not exist.

Examples

The following is sample output of a Cisco SAF External-Client debugging message:

```
Router# debug eigrp service-family external-client messages

*Jun 11 14:25:10.051: 2 found c1 c1
*Jun 11 14:25:10.051: SAF-EC: 100 byte message from c1
*Jun 11 14:25:10.051: 0001 0050 7F5A 9BC7 D285 A1D8 3C54 552F 37AE 655B 0014 0005 2253
4146 2200
*Jun 11 14:25:10.051: 0000 0006 0005 756E 616D 6500 0000 1005 0002 6331 0000 1003 0004
0001 0000
*Jun 11 14:25:10.051: 1001 0002 6331 0000 1004 0004 0000 0005 0008 0014 45F4 57A9 42CF
0556 4077
*Jun 11 14:25:10.051: 7AA3 B94A 703F 1BA3 ACA7
*Jun 11 14:25:10.051:
*Jun 11 14:25:10.051:
Class: Success Response Method: Register
*Jun 11 14:25:10.051: Packet Length: 52 Not including 20 byte Saf Header
*Jun 11 14:25:10.051: Magic Cookie: 7F5A9BC7 Transaction ID: D285A1D83C54552F37AE65
Router#5B
*Jun 11 14:25:10.051: Realm: 014: Length: 5: "SAF"
*Jun 11 14:25:10.051: Keep Alive: 1006: Length: 4: 360000
*Jun 11 14:25:10.051: Client Handle: 1002: Length: 4: 2
*Jun 11 14:25:10.051: Message Integrity: 008: Length: 20:
86839D4C64E36476D743AAF26112D28C32E3DF99
*Jun 11 14:25:10.051: 0101 0034 7F5A 9BC7 D285 A1D8 3C54 552F 37AE 655B 0014 0005 2253
4146 2200
*Jun 11 14:25:10.051: 0000 1006 0004 0005 7E40 1002 0004 0000 0002 0008 0014 8683 9D4C
64E3 6476
*Jun 11 14:25:10.051: D743 AAF2 6112 D28C 32E3 DF99
*Jun 11 14:25:10.055:
*Jun 11 14:25:10.055: SAF-EC: kicked timer 360000
```

The following is sample output of a Cisco SAF External-Client debugging protocol message:


```
Router# debug eigrp service-family external-client protocol

*Jun 11 14:27:11.467: SAF-EC: attribute found, type: 1005
*Jun 11 14:27:11.467: No error
*Jun 11 14:27:11.467:
Class: Request Method: Register
*Jun 11 14:27:11.467: Packet Length: 80 bytes Not including 20 byte Saf Header
*Jun 11 14:27:11.467: Magic Cookie: 7F5A9BC7 Transaction ID: 8F1F3F36EE43784D0DFABEA6
*Jun 11 14:27:11.467: Realm: 014: Length: 5: "SAF"
*Jun 11 14:27:11.467: Username: 006: Length: 5: uname
*Jun 11 14:27:11.467: Client Label: 1005: Length: 2: c1
*Jun 11 14:27:11.467: Protocol Version: 1003: Length: 4: 10000
*Jun 11 14:27:11.467: Client Name: 1001: Length: 2: c1
*Jun 11 14:27:11.467: Page Size: 1004: Length: 4: 5

Router#

*Jun 11 14:27:11.467: Message Integrity: 008: Length: 20:
AB3D7C39E4E0673B1539750D6E21A79ACFCE51F8
*Jun 11 14:27:11.467: SAF-EC: request start.
*Jun 11 14:27:11.467: SAF-EC: client successfully registered. client_handle 3

Router#
```

Related Commands

Command	Description
exit-service-family	Exits service-family configuration mode.
router eigrp	Configures the EIGRP process.
service-family	Specifies service-family configuration mode.

default (SAF)

To reset an Enhanced Interior Gateway Routing Protocol (EIGRP) service-family external clients to their default values, use the **default** command in external-client ? configuration mode.

default { **exit** | **keepalive** | **password** *password* | **username** *username* }

Syntax Description

<i>client-name</i>	Specifies a client name, entered up to 64 characters.
--------------------	---

Command Default

The external-client options are set at their configured values.

Command Modes

External-client configuration (config-external-client-mode)

Command History

Release	Modification
15.0(1)M	This command was introduced.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.
12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.

Examples

The following example sets an external-client named example to its keepalive default value:

```
Router(config)# service-family external-client listen ipv4 4533
Router(config-external-client)# external-client example
Router(config-external-client-mode)# default keepalive
```

Related Commands

Command	Description
external-client	Configures a Cisco SAF External-Client.
service-family external-client listen	Configure a Cisco SAF Forwarder listen TCP port for the Cisco SAF Forward to listen on,

default external-client

To reset Enhanced Interior Gateway Routing Protocol (EIGRP) service-family External Clients to their default values, use the **default external-client** command in external-client configuration mode.

default external-client *client-name*

Syntax Description

<i>client-name</i>	A Client name, up to 64 characters.
--------------------	-------------------------------------

Command Default

The external-client options are set to their configured values.

Command Modes

External-client configuration (config-external-client)

Command History

Release	Modification
15.0(1)M	This command was introduced.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.
12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.

Examples

The following example sets an External Client to its default values:

```
Router(config)# service-family external-client listen ipv4 4533
Router(config-external-client)# default external-client example
```

Related Commands

Command	Description
external-client	Configures a Cisco SAF External Client.
service-family external-client listen	Configure a TCP port for a Cisco External Client which interfaces to a Cisco SAF Forwarder.

eigrp log-neighbor-changes

To enable the logging of changes in Enhanced Interior Gateway Routing Protocol (EIGRP) neighbor adjacencies, use the **eigrp log-neighbor-changes** command in router configuration mode, address-family configuration mode, or service-family configuration mode. To disable the logging of changes in EIGRP neighbor adjacencies, use the **no** form of this command.

eigrp log-neighbor-changes

no eigrp log-neighbor-changes

Syntax Description This command has no arguments or keywords.

Command Default Adjacency changes are logged.

Command Modes

- Router configuration (config-router)
- Address-family configuration (config-router-af)
- Service-family configuration (config-router-sf)

Command History	Release	Modification
	11.2	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
	15.0(1)M	This command was modified. Address-family configuration mode and service-family configuration mode were added.
	12.2(33)SRE	This command was modified. Address-family configuration mode and service-family configuration mode were added.
	12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
	Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.

Usage Guidelines This command enables the logging of neighbor adjacency changes to monitor the stability of the routing system and to help detect problems. Logging is enabled by default. To disable the logging of neighbor adjacency changes, use the **no** form of this command.

To enable the logging of changes for EIGRP address-family neighbor adjacencies, use the **eigrp log-neighbor-changes** command in address-family configuration mode.

To enable the logging of changes for EIGRP service-family neighbor adjacencies, use the **eigrp log-neighbor-changes** command in service-family configuration mode.

Examples

The following configuration disables logging of neighbor changes for EIGRP process 209:

```
Router(config)# router eigrp 209  
Router(config-router)# no eigrp log-neighbor-changes
```

The following configuration enables logging of neighbor changes for EIGRP process 209:

```
Router(config)# router eigrp 209  
Router(config-router)# eigrp log-neighbor-changes
```

The following example shows how to disable logging of neighbor changes for EIGRP address-family with autonomous-system 4453:

```
Router(config)# router eigrp virtual-name  
Router(config-router)# address-family ipv4 autonomous-system 4453  
Router(config-router-af)# no eigrp log-neighbor-changes  
Router(config-router-af)# exit-address-family
```

The following configuration enables logging of neighbor changes for EIGRP service-family process 209:

```
Router(config)# router eigrp 209  
Router(config-router)# service-family ipv4 autonomous-system 4453  
Router(config-router-sf)# eigrp log-neighbor-changes  
Router(config-router-sf)# exit-service-family
```

Related Commands

Command	Description
address-family (EIGRP)	Enters address-family configuration mode to configure an EIGRP routing instance.
exit-address-family	Exits address-family configuration mode.
exit-service-family	Exits service-family configuration mode.
router eigrp	Configures the EIGRP routing process.
service-family	Specifies service-family configuration mode.

eigrp log-neighbor-warnings

To enable the logging of Enhanced Interior Gateway Routing Protocol (EIGRP) neighbor warning messages, use the **eigrp log-neighbor-warnings** command in router configuration mode, address-family configuration mode, or service-family configuration mode. To disable the logging of EIGRP neighbor warning messages, use the **no** form of this command.

eigrp log-neighbor-warnings [*seconds*]

no eigrp log-neighbor-warnings

Syntax Description

<i>seconds</i>	(Optional) The time interval (in seconds) between repeated neighbor warning messages. The range is from 1 to 65535. The default is 10.
----------------	--

Command Default

Neighbor warning messages are logged at 10-second intervals.

Command Modes

Router configuration (config-router)
 Address-family configuration (config-router-af)
 Service-family configuration (config-router-sf)

Command History

Release	Modification
12.0(5)	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
15.0(1)M	This command was modified. Address-family and service-family configuration modes were added.
12.2(33)SRE	This command was modified. Address-family and service-family configuration modes were added.
12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.

Usage Guidelines

When neighbor warning messages occur, they are logged by default. With this command, you can disable and enable neighbor warning messages, and you can configure the interval between repeated neighbor warning messages.

To enable the logging of warning messages for an EIGRP address family, use the **eigrp log-neighbor-warnings** command in address-family configuration mode.

To enable the logging of warning messages for an EIGRP service family, use the **eigrp log-neighbor-warnings** command in service-family configuration mode.

Examples

The following command will log neighbor warning messages for EIGRP process 209 and repeat the warning messages in 5-minute (300 seconds) intervals:

```
Router(config)# router eigrp 209  
Router(config-router)# eigrp log-neighbor-warnings 300
```

The following example logs neighbor warning messages for the service family with autonomous system number 4453 and repeats the warning messages in five-minute (300 second) intervals:

```
Router(config)# router eigrp virtual-name  
Router(config-router)# service-family ipv4 autonomous-system 4453  
Router(config-router-sf)# eigrp log-neighbor-warnings 300
```

The following example logs neighbor warning messages for the address family with autonomous system number 4453 and repeats the warning messages in five-minute (300 second) intervals:

```
Router(config)# router eigrp virtual-name  
Router(config-router)# address-family ipv4 autonomous-system 4453  
Router(config-router-af)# eigrp log-neighbor-warnings 300
```

Related Commands

Command	Description
address-family (EIGRP)	Enters address-family configuration mode to configure an EIGRP routing instance.
exit-address-family	Exits address-family configuration mode.
exit-service-family	Exits service-family configuration mode.
router eigrp	Configures the EIGRP routing process.
service-family	Specifies service-family configuration mode.

eigrp router-id

To set the router ID used by Enhanced Interior Gateway Routing Protocol (EIGRP) when communicating with its neighbors, use the **eigrp router-id** command in router configuration mode, address-family configuration mode, or service-family configuration mode. To remove the configured router ID, use the **no** form of this command.

eigrp router-id *router-id*

no eigrp router-id *router-id*

Syntax Description

<i>router-id</i>	EIGRP router ID in IP address format.
------------------	---------------------------------------

Command Default

EIGRP automatically selects an IP address to use as the router ID when an EIGRP process is started. The highest local IP address is selected and loopback interfaces are preferred. The router ID is not changed unless the EIGRP process is removed with the **no router eigrp** command or if the router ID is manually configured with the **eigrp router-id** command.

Command Modes

Router configuration (config-router)
 Address-family configuration (config-router-af)
 Service-family configuration (config-router-sf)

Command History

Release	Modification
12.1	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
15.0(1)M	This command was modified. Address-family configuration mode and service-family configuration mode were added.
12.2(33)SRE	This command was modified. Address-family configuration mode and service-family configuration mode were added.
12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.

Usage Guidelines

The router ID is used to identify the originating router for external routes. If an external route is received with the local router ID, the route is discarded. The router ID can be configured with any IP address with two exceptions; 0.0.0.0 and 255.255.255.255 are not legal values and cannot be entered. A unique value should be configured for each router.

In EIGRP named IPv4, named IPv6, and Cisco Service Advertisement Framework (SAF) configurations, the *router-id* is also included for identifying internal routes and loop detection.

Examples

The following example configures 172.16.1.3 as a fixed router ID:

```
Router(config)# router eigrp 209  
Router(config-router)# eigrp router-id 172.16.1.3
```

The following example configures 172.16.1.3 as a fixed router ID for service-family autonomous-system 4533:

```
Router(config)# router eigrp 209  
Router(config-router)# service-family ipv4 autonomous-system 4453  
Router(config-router-sf)# eigrp router-id 172.16.1.3
```

The following example configures 172.16.1.3 as a fixed router ID for address-family autonomous-system 4533:

```
Router(config)# router eigrp virtual-name  
Router(config-router)# address-family ipv4 autonomous-system 4453  
Router(config-router-af)# eigrp router-id 172.16.1.3
```

Related Commands

Command	Description
address-family (EIGRP)	Enters address-family configuration mode to configure an EIGRP routing instance.
router eigrp	Configures the EIGRP routing process.
service-family	Specifies service-family configuration mode.

eigrp stub (service-family)

To configure a router as an Enhanced Interior Gateway Routing Protocol (EIGRP) stub, use the **eigrp stub** command in service-family configuration mode. To disable the EIGRP stub routing feature, use the **no** form of this command.

eigrp stub [**receive-only** | **connected**]

no eigrp stub

Syntax Description

receive-only	(Optional) Sets the router as a receive-only neighbor.
connected	(Optional) Advertises connected routes.

Command Default

Stub routing is not enabled.

Command Modes

Service-family configuration (config-router-sf)

Command History

Release	Modification
15.0(1)M	This command was introduced.
12.2(33)SRE	This command was modified. Address-family configuration mode and service-family configuration mode were added.
12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.
12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.

Usage Guidelines

Use the **eigrp stub** command to configure a router as a stub that does not advertise all of its services to other routers.

The **eigrp stub** command can be modified with several options. The **receive-only** keyword will restrict the router from sharing any of its services with any other router in that EIGRP autonomous system.

The **connected** keyword permits the EIGRP stub routing feature to send only connected services.

If no keywords are used with the **eigrp stub** command, the **eigrp stub connected** is configured, by default.



Note

Multi-access interfaces, such as ATM, Ethernet, Frame Relay, ISDN PRI, and X.25, are supported by the EIGRP Stub Routing feature only when all routers on that interface, except the hub, are configured as stub routers.

Examples

The following example configures a router as a receive-only stub that advertises no services:

```
Router(config)# router eigrp virtual-name
Router(config-router)# service-family ipv4 autonomous-system 4533
Router(config-router-sf)# eigrp stub receive-only
```

The following example configures a router as a stub that advertises only connected services:

```
Router(config)# router eigrp virtual-name
Router(config-router)# service-family ipv4 autonomous-system 4533
Router(config-router-sf)# eigrp stub connected
```

The following example also configures a router as a stub that advertises only connected services:

```
Router(config)# router eigrp virtual-name
Router(config-router)# service-family ipv4 autonomous-system 4533
Router(config-router-sf)# eigrp stub
```

Related Commands

Command	Description
router eigrp	Configures the EIGRP routing process.
service-family	Specifies service-family configuration mode.

exit-service-family

To exit Enhanced Interior Gateway Routing Protocol (EIGRP) service-family configuration mode, use the **exit-service-family** command in service-family configuration mode.

exit-service-family

Syntax Description This command has no arguments or keywords.

Command Modes Service-family configuration (config-router-sf)

Command History	Release	Modification
	15.0(1)M	This command was introduced.
	12.2(33)SRE	This command was modified. Address-family configuration mode and service-family configuration mode were added.
	12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
	Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.
	12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.

Usage Guidelines Use the **exit-service-family** command to exit service-family configuration mode and return to router configuration mode.

Examples The following example exits service-family configuration mode:

```
Router(config)# router eigrp virtual-name
Router(config-router)# service-family ipv4 autonomous-system 4533
Router(config-router-sf)# exit-service-family
Router(config-router)#
```

Related Commands	Command	Description
	router eigrp	Configures the EIGRP process.
	service-family	Specifies service-family configuration mode.

exit-sf-interface

To exit Enhanced Interior Gateway Routing Protocol (EIGRP) service-family interface configuration mode, use the **exit-sf-interface** command in service-family interface configuration mode.

exit-sf-interface

Syntax Description

This command has no arguments or keywords.

Command Modes

Service-family interface configuration (config-router-sf-interface)

Command History

Release	Modification
15.0(1)M	This command was introduced.
12.2(33)SRE	This command was modified. Address-family configuration mode and service-family configuration mode were added.
12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.
12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.

Usage Guidelines

Use the **exit-sf-interface** command to exit service-family interface configuration mode and return to service-family configuration mode.

Examples

The following example exits service-family interface configuration mode:

```
Router(config)# router eigrp virtual-name  
Router(config-router)# service-family ipv4 autonomous-system 4533  
Router(config-router-sf)# sf-interface default  
Router(config-router-sf-interface)# no shutdown  
Router(config-router-sf-interface)# exit-sf-interface  
Router(config-router-sf)#
```

Related Commands

Command	Description
exit-service-family	Exits service-family configuration mode.
router eigrp	Configures the EIGRP process.
service-family	Specifies service-family configuration mode.
sf-interface	Configures interface-specific commands under a service family.
shutdown	Disables a service family on the interface.

exit-sf-topology

To exit Enhanced Interior Gateway Routing Protocol (EIGRP) service-family topology configuration mode, use the **exit-sf-topology** command in service-family topology configuration mode.

exit-sf-topology

Syntax Description

This command has no arguments or keywords.

Command Modes

Service-family topology configuration (config-router-sf-topology)

Command History

Release	Modification
15.0(1)M	This command was introduced.
12.2(33)SRE	This command was modified. Address-family configuration mode and service-family configuration mode were added.
12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.
12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.

Usage Guidelines

Use the **exit-sf-topology** command to exit service-family topology configuration mode and return to service-family configuration mode.

Examples

The following example exits service-family topology configuration mode:

```
Router(config)# router eigrp virtual-name
Router(config-router)# service-family ipv4 autonomous-system 4533
Router(config-router-sf)# topology base
Router(config-router-sf-topology)# exit-sf-topology
Router(config-router-sf)#
```

Related Commands

Command	Description
exit-service-family	Exits service-family configuration mode.
exit-sf-interface	Exits service-family interface configuration mode.
router eigrp	Configures the EIGRP process.
service-family	Specifies service-family configuration mode.
sf-interface	Configures interface-specific commands under a service family.
topology	Enables topology configuration mode.

external-client

To configure a Cisco Service Advertisement Framework (Cisco SAF) External Client, use the **external-client** command in external-client configuration mode. To configure a Cisco SAF External Client to a topology, use the **external-client** command in service-family topology configuration mode. To remove the associated external-client configuration, use the **no** form on this command.

The **basename** keyword is only available in external-client configuration mode.

external-client *client-label* **basename**

no external-client

Syntax Description

<i>client-label</i>	A client label. The client label can be a maximum of 64 characters.
basename	Available only in external-client configuration mode. Specify the basename keyword in external-client configuration mode to allow SAF external clients to use a naming convention based on the client-label. The naming convention takes the form of <i>client-label@[1-50]</i> . You can specify a maximum of 50 SAF external clients. For example, if the external-client command specifies a client label of <i>example</i> , then the basename for a SAF external client would be <i>example@1</i> . Another SAF external client would be <i>example@2</i> , and so on up to a maximum of 50 basenames (<i>@50</i>).

Command Default

No service-family external-client configurations exist.

Command Modes

External-client configuration (config-external-client)
Service-family topology (config-router-sf-topology)

Command History

Release	Modification
15.0(1)M	This command was introduced.
12.2(33)SRE	This command was modified. Address-family configuration mode and service-family configuration mode were added.
12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.
12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.

Usage Guidelines

Use the **external-client** command in service-family topology configuration mode to share the configuration with multiple clients. The **no** form of this command in service-family topology configuration mode removes a client in that topology. The **no** form of this command in external-client configuration mode removes the TCP connection from the clients to the forwarder.

Use the **service-family external-client listen** command in router configuration mode to configure a Cisco SAF External-Client listen port that the external client can connect to.

**Note**

Using the **service-family external-client listen ipv6** commands requires an IPv6-enabled SAF client, which currently does not exist.

Examples

The following example assigns a Cisco SAF External Client with the username “example” to the topology base:

```
Router(config)# router eigrp virtual-name
Router(config-router)# service-family ipv4 autonomous-system 4533
Router(config-router-sf)# sf-interface default
Router(config-router-sf-interface)# no shutdown
Router(config-router-sf-interface)# exit sf-interface
Router(config-router-sf)# topology base
Router(config-router-sf-topology)# external-client example
```

Related Commands

Command	Description
service-family external-client listen	Configures a Cisco SAF Forwarder listen TCP port.
service-family	Specifies service-family configuration mode.
sf-interface	Configures interface-specific commands under a service family.
shutdown	Disables a specific routing instance without removing any existing configuration parameters for a service family.
topology	Configures service topology-specific commands for a service family.

hello-interval

To configure the hello interval for the Enhanced Interior Gateway Routing Protocol (EIGRP) address-family or service-family configurations, use the **hello-interval** command in address-family interface configuration mode or service-family interface configuration mode. To configure the default hello interval, use the **no** form of this command.

hello-interval *seconds*

no hello-interval

Syntax Description

<i>seconds</i>	Hello interval in seconds. The range is 1 to 65535. The default is 60 for low-speed nonbroadcast multiaccess (NBMA) networks, and 5 for all other networks.
----------------	---

Command Default

The EIGRP hello interval is 60 seconds for low-speed NBMA networks and 5 seconds for all other networks.

Command Modes

Address-family interface configuration (config-router-af-interface)
Service-family interface configuration (config-router-sf-interface)

Command History

Release	Modification
15.0(1)M	This command was introduced.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.
12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.

Usage Guidelines

The 60-second default applies only to low-speed, NBMA media. Low speed is considered a rate of T1 or slower, as specified by the **bandwidth** command in interface configuration mode.

For the purposes of EIGRP, Frame Relay and Switched Multimegabit Data Service (SMDS) networks are considered to be NBMA if the interface has not been configured to use physical multicasting. Otherwise, Frame Relay and SMDS networks are not considered to be NBMA.

Examples

The following example configures a 10-second hello interval for address-family Ethernet interface 0/0:

```
Router(config)# router eigrp virtual-name
Router(config-router)# address-family ipv4 autonomous-system 4453
Router(config-router-af-interface)# af-interface ethernet0/0
Router(config-router-af-interface)# hello-interval 10
```

The following example sets a 10 second hello-interval for service-family Ethernet interface 0/0:

```
Router(config)# router eigrp virtual-name
Router(config-router)# service-family ipv4 autonomous-system 4533
Router(config-router-sf)# sf-interface Ethernet 0/0
Router(config-router-sf-interface)# hello-interval 10
```

Related Commands

Command	Description
address-family (EIGRP)	Enters address-family configuration mode to configure an EIGRP routing instance.
af-interface	Enters address-family interface configuration mode to configure interface-specific EIGRP commands.
hold-time	Configures the hold time for EIGRP address-family or service-family configurations.
router eigrp	Configures the EIGRP address-family process.
service-family	Specifies service-family configuration mode.
sf-interface	Configures interface-specific commands under a service family.

hold-time

To configure the hold time for Enhanced Interior Gateway Routing Protocol (EIGRP) address-family or service-family configurations, use the **hold-time** command in address-family interface configuration mode or service-family interface configuration mode. To configure the default hold time, use the **no** form of this command.

hold-time *seconds*

no hold-time

Syntax Description

<i>seconds</i>	Interval, in seconds, before a neighbor is considered down. Valid range is 1 to 65535 seconds (approximately 18 hours). The default is 180 seconds for low-speed nonbroadcast multiaccess (NBMA) networks and 15 seconds for all other networks.
----------------	--

Command Default

The EIGRP hold time is 180 seconds for NBMA networks and 15 seconds for all other networks.

Command Modes

Address-family interface configuration (config-router-af-interface)
Service-family interface configuration (config-router-sf-interface)

Command History

Release	Modification
15.0(1)M	This command was introduced.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.
12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.

Usage Guidelines

On very congested and large networks, the default hold time may not be sufficient for all routers and access servers to receive hello packets from neighbors. In this case, increase the hold time duration. The hold time should be at least three times the hello interval. If a router does not receive a hello packet within the specified hold time, services through this router are considered unavailable. Increasing the hold time will delay route convergence across the network.

Examples

The following example sets a 50-second hold time for address-family Ethernet interface 0/0:

```
Router(config)# router eigrp virtual-name
Router(config-router)# address-family ipv4 autonomous-system 4453
Router(config-router-af-interface)# af-interface ethernet0/0
Router(config-router-af-interface)# hold-time 50
```

The following example sets a 40-second hold time for service-family Ethernet interface 0/0:

```
Router(config)# router eigrp virtual-name
Router(config-router)# service-family ipv4 autonomous-system 4533
Router(config-router-sf)# sf-interface Ethernet 0/0
Router(config-router-sf-interface)# hold-time 40
```

Related Commands

Command	Description
address-family (EIGRP)	Enters address-family configuration mode to configure an EIGRP routing instance.
af-interface	Enters address-family interface configuration mode to configure interface-specific EIGRP commands.
router eigrp	Configures the EIGRP routing process.
hello-interval	Configures the hello interval for EIGRP address-family or service-family configurations.
router eigrp	Configures the EIGRP address-family process.
service-family	Specifies service-family configuration mode.
sf-interface	Configures interface-specific commands under service-family.

keepalive (SAF)

To specify a time interval for sending keepalives messages for a Cisco SAF External Clients, use the **keepalive** command in external-client configuration mode. To reset the keepalive to its default value, use the **no** form of this command.

keepalive *interval_in_milliseconds*

no keepalive

Syntax Description

interval_in_milliseconds The keepalive time interval in milliseconds, between 5000 and 3600000.

Command Default

7900 milliseconds.

Command Modes

External-client configuration (config-external-client-mode)

Command History

Release	Modification
15.0(1)M	This command was introduced.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.
12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.

Usage Guidelines

Examples

The following example configures a keepalive of 8000 milliseconds for a Cisco SAF External Client named example.

```
Router(config)# service-family external-client listen ipv4 2444
Router(config-external-client)# external-client example
Router(config-external-client-mode)# keepalive 8000
```

Related Commands

Command	Description
external-client	Configures a Cisco SAF External-Clients.
service-family external-client listen	Configures a Cisco SAF External-client listen TCP port.

key

To identify an authentication key on a key chain, use the **key** command in key-chain configuration mode. To remove the key from the key chain, use the **no** form of this command.

key *key-id*

no key *key-id*

Syntax Description

<i>key-id</i>	Identification number of an authentication key on a key chain. The range of keys is from 0 to 2147483647. The key identification numbers need not be consecutive.
---------------	---

Command Default

No key exists on the key chain.

Command Modes

Key-chain configuration (config-keychain)

Command History

Release	Modification
11.1	This command was introduced.
12.4(6)T	Support for IPv6 was added.
12.2(33)SRB	This command was integrated into Cisco IOS Release 12.2(33)SRB.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
15.0(1)M	This command was integrated into Cisco IOS Release 15.0M.
12.2(33)SRE	This command was modified. The address-family configuration mode was added.
12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
Cisco IOS XE Release 2.5	This command was modified. The address-family configuration mode was added.

Usage Guidelines

Only DRP Agent, Enhanced Interior Gateway Routing Protocol (EIGRP), and Routing Information Protocol (RIP) Version 2 use key chains.

It is useful to have multiple keys on a key chain so that the software can sequence through the keys as they become invalid after time, based on the **accept-lifetime** and **send-lifetime** key chain key command settings.

Each key has its own key identifier, which is stored locally. The combination of the key identifier and the interface associated with the message uniquely identifies the authentication algorithm and Message Digest 5 (MD5) authentication key in use. Only one authentication packet is sent, regardless of the number of valid keys. The software starts looking at the lowest key identifier number and uses the first valid key.

If the last key expires, authentication will continue and an error message will be generated. To disable authentication, you must manually delete the last valid key.

To remove all keys, remove the key chain by using the **no key chain** command.

Examples

The following example configures a key chain named chain1. The key named key1 will be accepted from 1:30 p.m. to 3:30 p.m. and be sent from 2:00 p.m. to 3:00 p.m. The key named key2 will be accepted from 2:30 p.m. to 4:30 p.m. and be sent from 3:00 p.m. to 4:00 p.m. The overlap allows for migration of keys or a discrepancy in the set time of the router. There is a 30-minute leeway on each side to handle time differences.

```
Router(config)# interface ethernet 0
Router(config-if)# ip rip authentication key-chain chain1
Router(config-if)# ip rip authentication mode md5
!
Router(config)# router rip
Router(config-router)# network 172.19.0.0
Router(config-router)# version 2
!
Router(config)# key chain chain1
Router(config-keychain)# key 1
Router(config-keychain-key)# key-string key1
Router(config-keychain-key)# accept-lifetime 13:30:00 Jan 25 1996 duration 7200
Router(config-keychain-key)# send-lifetime 14:00:00 Jan 25 1996 duration 3600
Router(config-keychain-key)# exit
Router(config-keychain)# key 2
Router(config-keychain-key)# key-string key2
Router(config-keychain-key)# accept-lifetime 14:30:00 Jan 25 1996 duration 7200
Router(config-keychain-key)# send-lifetime 15:00:00 Jan 25 1996 duration 3600
```

The following named configuration example configures a key chain named chain1 for EIGRP address-family. The key named key1 will be accepted from 1:30 p.m. to 3:30 p.m. and be sent from 2:00 p.m. to 3:00 p.m. The key named key2 will be accepted from 2:30 p.m. to 4:30 p.m. and be sent from 3:00 p.m. to 4:00 p.m. The overlap allows for migration of keys or a discrepancy in the set time of the router. There is a 30-minute leeway on each side to handle time differences.

```
Router(config)# router eigrp virtual-name
Router(config-router)# address-family ipv4 autonomous-system 4453
Router(config-router-af)# network 10.0.0.0
Router(config-router-af)# af-interface ethernet0/0
Router(config-router-af-interface)# authentication key-chain trees
Router(config-router-af-interface)# authentication mode md5
Router(config-router-af-interface)# exit
Router(config-router-af)# exit
Router(config-router)# exit
Router(config)# key chain chain1
Router(config-keychain)# key 1
Router(config-keychain-key)# key-string key1
Router(config-keychain-key)# accept-lifetime 13:30:00 Jan 25 1996 duration 7200
Router(config-keychain-key)# send-lifetime 14:00:00 Jan 25 1996 duration 3600
Router(config-keychain-key)# exit
Router(config-keychain)# key 2
Router(config-keychain-key)# key-string key2
Router(config-keychain-key)# accept-lifetime 14:30:00 Jan 25 1996 duration 7200
Router(config-keychain-key)# send-lifetime 15:00:00 Jan 25 1996 duration 3600
```

The following named configuration example configures a key chain named chain1 for EIGRP service-family. The key named key1 will be accepted from 1:30 p.m. to 3:30 p.m. and be sent from 2:00 p.m. to 3:00 p.m. The key named key2 will be accepted from 2:30 p.m. to 4:30 p.m. and be sent from 3:00 p.m. to 4:00 p.m. The overlap allows for migration of keys or a discrepancy in the set time of the router. There is a 30-minute leeway on each side to handle time differences.

```
Router(config)# router eigrp virtual-name
Router(config-router)# service-family ipv4 autonomous-system 4453
Router(config-router-sf)# network 10.0.0.0
Router(config-router-sf)# sf-interface ethernet0/0
Router(config-router-sf-interface)# authentication key-chain trees
Router(config-router-sf-interface)# authentication mode md5
Router(config-router-sf-interface)# exit
Router(config-router-sf)# exit
Router(config-router)# exit
Router(config)# key chain chain1
Router(config-keychain)# key 1
Router(config-keychain-key)# key-string key1
Router(config-keychain-key)# accept-lifetime 13:30:00 Jan 25 1996 duration 7200
Router(config-keychain-key)# send-lifetime 14:00:00 Jan 25 1996 duration 3600
Router(config-keychain-key)# exit
Router(config-keychain)# key 2
Router(config-keychain-key)# key-string key2
Router(config-keychain-key)# accept-lifetime 14:30:00 Jan 25 1996 duration 7200
Router(config-keychain-key)# send-lifetime 15:00:00 Jan 25 1996 duration 3600
```

Related Commands

Command	Description
accept-lifetime	Sets the time period during which the authentication key on a key chain is received as valid.
authentication key-chain	Specifies an authentication key chain EIGRP.
authentication mode (EIGRP)	Specifies the type of authentication used in EIGRP packets for the EIGRP instance.
key chain	Defines an authentication key-chain needed to enable authentication for routing protocols.
key-string (authentication)	Specifies the authentication string for a key.
network	Specifies the network for an EIGRP routing process.
router eigrp	Configures the EIGRP process.
send-lifetime	Sets the time period during which an authentication key on a key chain is valid to be sent.
service-family	Configures VRF metrics for a Cisco SAF service-family.
sf-interface	Configure interface-specific commands for a Cisco SAF service family.
show key chain	Displays authentication key information.

key chain

To define an authentication key chain needed to enable authentication for routing protocols and enter key-chain configuration mode, use the **key chain** command in global configuration mode. To remove the key chain, use the **no** form of this command.

key chain *name-of-chain*

no key chain *name-of-chain*

Syntax Description

<i>name-of-chain</i>	Name of a key chain. A key chain must have at least one key and can have up to 2147483647 keys.
----------------------	---

Command Default

No key chain exists.

Command Modes

Global configuration (config)

Command History

Release	Modification
11.1	This command was introduced.
12.4(6)T	Support for IPv6 was added.
12.2(33)SRB	This command was integrated into Cisco IOS Release 12.2(33)SRB.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
15.0(1)M	This command was integrated into Cisco IOS Release 15.0M.
12.2(33)SRE	This command was modified. The address-family configuration mode was added.
12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
Cisco IOS XE Release 2.5	This command was modified. The address-family configuration mode was added.

Usage Guidelines

Only DRP Agent, Enhanced Interior Gateway Routing Protocol (EIGRP), and Routing Information Protocol (RIP) Version 2 use key chains.

You must configure a key chain with keys to enable authentication.

Although you can identify multiple key chains, we recommend using one key chain per interface per routing protocol. Upon specifying the **key chain** command, you enter key chain configuration mode.

Examples

The following example configures a key chain named chain1. The key named key1 will be accepted from 1:30 p.m. to 3:30 p.m. and be sent from 2:00 p.m. to 3:00 p.m. The key named key2 will be accepted from 2:30 p.m. to 4:30 p.m. and be sent from 3:00 p.m. to 4:00 p.m. The overlap allows for migration of keys or a discrepancy in the set time of the router. There is a 30-minute leeway on each side to handle time differences.

```
Router(config)# interface ethernet 0
Router(config-if)# ip rip authentication key-chain chain1
Router(config-if)# ip rip authentication mode md5
!
Router(config)# router rip
Router(config-router)# network 172.19.0.0
Router(config-router)# version 2
!
Router(config)# key chain chain1
Router(config-keychain)# key 1
Router(config-keychain-key)# key-string key1
Router(config-keychain-key)# accept-lifetime 13:30:00 Jan 25 1996 duration 7200
Router(config-keychain-key)# send-lifetime 14:00:00 Jan 25 1996 duration 3600
Router(config-keychain-key)# exit
Router(config-keychain)# key 2
Router(config-keychain-key)# key-string key2
Router(config-keychain-key)# accept-lifetime 14:30:00 Jan 25 1996 duration 7200
Router(config-keychain-key)# send-lifetime 15:00:00 Jan 25 1996 duration 3600
```

The following named configuration example configures a key chain named chain1 for EIGRP address-family. The key named key1 will be accepted from 1:30 p.m. to 3:30 p.m. and be sent from 2:00 p.m. to 3:00 p.m. The key named key2 will be accepted from 2:30 p.m. to 4:30 p.m. and be sent from 3:00 p.m. to 4:00 p.m. The overlap allows for migration of keys or a discrepancy in the set time of the router. There is a 30-minute leeway on each side to handle time differences.

```
Router(config)# router eigrp virtual-name
Router(config-router)# address-family ipv4 autonomous-system 4453
Router(config-router-af)# network 10.0.0.0
Router(config-router-af)# af-interface ethernet0/0
Router(config-router-af-interface)# authentication key-chain trees
Router(config-router-af-interface)# authentication mode md5
Router(config-router-af-interface)# exit
Router(config-router-af)# exit
Router(config-router)# exit
Router(config)# key chain chain1
Router(config-keychain)# key 1
Router(config-keychain-key)# key-string key1
Router(config-keychain-key)# accept-lifetime 13:30:00 Jan 25 1996 duration 7200
Router(config-keychain-key)# send-lifetime 14:00:00 Jan 25 1996 duration 3600
Router(config-keychain-key)# exit
Router(config-keychain)# key 2
Router(config-keychain-key)# key-string key2
Router(config-keychain-key)# accept-lifetime 14:30:00 Jan 25 1996 duration 7200
Router(config-keychain-key)# send-lifetime 15:00:00 Jan 25 1996 duration 3600
```

The following named configuration example configures a key chain named trees for service-family. The key named chestnut will be accepted from 1:30 pm to 3:30 pm and be sent from 2:00 pm to 3:00 pm. The key birch will be accepted from 2:30 pm to 4:30 pm and be sent from 3:00 pm to 4:00 pm. The overlap allows for migration of keys or a discrepancy in the set time of the router. There is a 30-minute leeway on each side to handle time differences.

```
Router(config)# router eigrp virtual-name
Router(config-router)# service-family ipv4 autonomous-system 4453
Router(config-router-sf)# sf-interface ethernet
Router(config-router-sf-interface)# authentication key chain trees
Router(config-router-sf-interface)# authentication mode md5
```

```

Router(config-router-sf-interface)# exit
Router(config-router-sf)# exit
Router(config-router)# exit
Router(config)# key chain chain1
Router(config-keychain)# key 1
Router(config-keychain-key)# key-string chestnut
Router(config-keychain-key)# accept-lifetime 13:30:00 Jan 25 1996 duration 7200
Router(config-keychain-key)# send-lifetime 14:00:00 Jan 25 1996 duration 3600
Router(config-keychain-key)# exit
Router(config-keychain)# key 2
Router(config-keychain-key)# key-string birch
Router(config-keychain-key)# accept-lifetime 14:30:00 Jan 25 1996 duration 7200
Router(config-keychain-key)# send-lifetime 15:00:00 Jan 25 1996 duration 3600

```

Related Commands

Command	Description
accept-lifetime	Sets the time period during which the authentication key on a key chain is received as valid.
ip rip authentication key-chain	Enables authentication for RIP Version 2 packets and specifies the set of keys that can be used on an interface.
ip authentication key-chain eigrp	Enables authentication of EIGRP packets.
key	Identifies an authentication key on a key chain.
key-string (authentication)	Specifies the authentication string for a key.
send-lifetime	Sets the time period during which an authentication key on a key chain is valid to be sent.
show key chain	Displays authentication key information.

key-string (authentication)

To specify the authentication string for a key, use the **key-string** (authentication) command in key chain key configuration mode. To remove the authentication string, use the **no** form of this command.

key-string *text*

no key-string *text*

Syntax Description

<i>text</i>	Authentication string that must be sent and received in the packets using the routing protocol being authenticated. The string can contain from 1 to 80 uppercase and lowercase alphanumeric characters, except that the first character cannot be a number.
-------------	--

Command Default

No authentication string for a key exists.

Command Modes

Key chain key configuration (config-keychain-key)

Command History

Release	Modification
11.1	This command was introduced.
12.4(6)T	Support for IPv6 was added.
12.2(33)SRB	This command was integrated into Cisco IOS Release 12.2(33)SRB.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
15.0(1)M	This command was integrated into Cisco IOS Release 15.0M.
12.2(33)SRE	This command was modified. The address-family configuration mode was added.
12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
Cisco IOS XE Release 2.5	This command was modified. The address-family configuration mode was added.

Usage Guidelines

Only DRP Agent, Enhanced Interior Gateway Routing Protocol (EIGRP), and Routing Information Protocol (RIP) Version 2 use key chains. Each key can have only one key string.

If password encryption is configured (with the **service password-encryption** command), the software saves the key string as encrypted text. When you write to the terminal with the **more system:running-config** command, the software displays key-string 7 encrypted text.

Examples

The following example configures a key chain named chain1. The key named key1 will be accepted from 1:30 p.m. to 3:30 p.m. and be sent from 2:00 p.m. to 3:00 p.m. The key named key2 will be accepted from 2:30 p.m. to 4:30 p.m. and be sent from 3:00 p.m. to 4:00 p.m. The overlap allows for migration of keys or a discrepancy in the set time of the router. There is a 30-minute leeway on each side to handle time differences.

```
Router(config)# interface ethernet 0
Router(config-if)# ip rip authentication key-chain chain1
Router(config-if)# ip rip authentication mode md5
!
Router(config)# router rip
Router(config-router)# network 172.19.0.0
Router(config-router)# version 2
!
Router(config)# key chain chain1
Router(config-keychain)# key 1
Router(config-keychain-key)# key-string key1
Router(config-keychain-key)# accept-lifetime 13:30:00 Jan 25 1996 duration 7200
Router(config-keychain-key)# send-lifetime 14:00:00 Jan 25 1996 duration 3600
Router(config-keychain-key)# exit
Router(config-keychain)# key 2
Router(config-keychain-key)# key-string key2
Router(config-keychain-key)# accept-lifetime 14:30:00 Jan 25 1996 duration 7200
Router(config-keychain-key)# send-lifetime 15:00:00 Jan 25 1996 duration 3600
```

The following example configures a key chain named chain1 for EIGRP address-family. The key named key1 will be accepted from 1:30 p.m. to 3:30 p.m. and be sent from 2:00 p.m. to 3:00 p.m. The key named key2 will be accepted from 2:30 p.m. to 4:30 p.m. and be sent from 3:00 p.m. to 4:00 p.m. The overlap allows for migration of keys or a discrepancy in the set time of the router. There is a 30-minute leeway on each side to handle time differences.

```
Router(config)# eigrp virtual-name
Router(config-router)# address-family ipv4 autonomous-system 4453
Router(config-router-af)# network 10.0.0.0
Router(config-router-af)# af-interface ethernet0/0
Router(config-router-af-interface)# authentication key-chain trees
Router(config-router-af-interface)# authentication mode md5
Router(config-router-af-interface)# exit
Router(config-router-af)# exit
Router(config-router)# exit
Router(config)# key chain chain1
Router(config-keychain)# key 1
Router(config-keychain-key)# key-string key1
Router(config-keychain-key)# accept-lifetime 13:30:00 Jan 25 1996 duration 7200
Router(config-keychain-key)# send-lifetime 14:00:00 Jan 25 1996 duration 3600
Router(config-keychain-key)# exit
Router(config-keychain)# key 2
Router(config-keychain-key)# key-string key2
Router(config-keychain-key)# accept-lifetime 14:30:00 Jan 25 1996 duration 7200
Router(config-keychain-key)# send-lifetime 15:00:00 Jan 25 1996 duration 3600
```

The following named configuration example configures a key chain named trees for service-family. The key named chestnut will be accepted from 1:30 pm to 3:30 pm and be sent from 2:00 pm to 3:00 pm. The key birch will be accepted from 2:30 pm to 4:30 pm and be sent from 3:00 pm to 4:00 pm. The overlap allows for migration of keys or a discrepancy in the set time of the router. There is a 30-minute leeway on each side to handle time differences.

```
Router(config)# router eigrp virtual-name
Router(config-router)# service-family ipv4 autonomous-system 4453
Router(config-router-sf)# sf-interface ethernet
Router(config-router-sf-interface)# authentication key chain trees
Router(config-router-sf-interface)# authentication mode md5
```

■ key-string (authentication)

```

Router(config-router-sf-interface)# exit
Router(config-router-sf)# exit
Router(config-router)# exit
Router(config)# key chain chain1
Router(config-keychain)# key 1
Router(config-keychain-key)# key-string chestnut
Router(config-keychain-key)# accept-lifetime 13:30:00 Jan 25 1996 duration 7200
Router(config-keychain-key)# send-lifetime 14:00:00 Jan 25 1996 duration 3600
Router(config-keychain-key)# exit
Router(config-keychain)# key 2
Router(config-keychain-key)# key-string birch
Router(config-keychain-key)# accept-lifetime 14:30:00 Jan 25 1996 duration 7200
Router(config-keychain-key)# send-lifetime 15:00:00 Jan 25 1996 duration 3600

```

Related Commands

Command	Description
accept-lifetime	Sets the time period during which the authentication key on a key chain is received as valid.
ip authentication key-chain eigrp	Enables authentication of EIGRP packets.
key	Identifies an authentication key on a key chain.
key chain	Defines an authentication key-chain needed to enable authentication for routing protocols.
send-lifetime	Sets the time period during which an authentication key on a key chain is valid to be sent.
service password-encryption	Encrypts passwords.
show key chain	Displays authentication key information.

maximum-service (EIGRP)

To specify the maximum number of services that are permitted in a Cisco SAF service family, use the **maximum-service** command in service-family configuration mode. To disable this service, use the **no** form on this command.

maximum-service *number* [*threshold-value*] [**dampened** | **reset-time** *interval* | **restart** *interval* | **restart-count** *count* | **warning-only**]

no maximum-service

Syntax Description		
<i>number</i>		Limit of maximum services, entered by a number from 1 to 4294967295.
<i>threshold-value</i>		(Optional) Threshold value (%) that enables a warning message, entered by a number between 1 and 100. The default is 75 percent.
dampened		(Optional) Exponentially increases the restart time interval.
reset-time		(Optional) Specifies the duration after which the restart history is cleared.
<i>interval</i>		(Optional) Specifies the reset-time interval, in minutes, entered using a number between 1 and 65535.
restart		(Optional) Automatically reestablishes a peering session that was disabled because the maximum-service limit had been exceeded.
<i>interval</i>		(Optional) Specifies the restart interval, in minutes, entered using a number between 1 and 65535.
restart-count		(Optional) Specifies the number of times a peer is auto-restarted.
<i>count</i>		(Optional) Specifies the number of times to restart, entered using a number between 1 and 65535.
warning-only		(Optional) Generates a warning-only message when the limit is exceeded.

Command Default

Command Modes Service-family configuration (config-router-sf)

Command History	Release	Modification
	15.0(1)M	This command was introduced.
	12.2(33)SRE	This command was modified. The address-family configuration mode was added.
	12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
	Cisco IOS XE Release 2.5	This command was modified. The address-family configuration mode was added.
	12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.

Usage Guidelines

To specify how much memory is consumed from services received, use the **maximum-service** command in service-family configuration mode. To disable this function, use the **no** form on this command.

When the amount of memory exceeds the maximum amount configured, the router disables the peering session (by default):

- If the **restart** keyword is configured, the router automatically reestablishes the peering session at the configured time interval. If the restart interval is not configured, a disabled session stays down by default after the maximum-service limit is exceeded.
- If the **warning-only** keyword is configured, the router only sends a log message, but continues peering with the sender. If the neighbor is terminated, the neighbor remains down until the **clear eigrp service-family** command is configured.

Use the **show eigrp service-family ipv4** command with the **neighbor** keyword to verify neighbor configurations.

Examples

The following example sets the restart interval to 30 minutes, retries the restart 5 times, and clears the restart history after 60 minutes for service-family IPv4 autonomous-system 4533:

```
Router(config)# router eigrp virtual-name
Router(config-router)# service-family ipv4 autonomous-system 4533
Router(config-router-sf)# maximum-service 1000 restart 30 restart-count 5 dampened
reset-time 60
```

The following example sets the maximum memory services to 1000 kilobytes, that are allowed from service-family IPv4 autonomous-system 4533:

```
Router(config)# router eigrp virtual-name
Router(config-router)# service-family ipv4 autonomous-system 4533
Router(config-router-sf)# maximum-service 1000
```

The following example sets the maximum memory services to 500 kilobytes that are allowed from service-family IPv4 autonomous-system 4533 and configures a warning to display when the maximum-service limit has been exceeded.

```
Router(config)# router eigrp virtual-name
Router(config-router)# service-family ipv4 autonomous-system 4533
Router(config-router-sf)# maximum-service 500 warning-only
```

Related Commands

Command	Description
clear eigrp service-family	Clears information for a Cisco SAF service family.
router eigrp	Configures the EIGRP process.
service-family	Configures commands under service-family mode.
sf-interface	Configures interface-specific commands under a service family.
show eigrp service-family	Displays information for a Cisco SAF service family.

metric weights (EIGRP)

To tune Enhanced Interior Gateway Routing Protocol (EIGRP) metric calculations, use the **metric weights** command in router configuration mode or address family configuration mode. To reset the values to their defaults, use the **no** form of this command.

metric weights *tos k1 k2 k3 k4 k5*

no metric weights

Syntax Description

<i>tos</i>	Type of service. This value must always be zero.
<i>k1 k2 k3 k4 k5</i>	Constants that convert an EIGRP metric vector into a scalar quantity. Valid values are 0 to 255. Default values are: <ul style="list-style-type: none"> <i>tos</i>: 0 <i>k1</i>: 1 <i>k2</i>: 0 <i>k3</i>: 1 <i>k4</i>: 0 <i>k5</i>: 0

Command Default

EIGRP metric K values are set to their default values.

Command Modes

Router configuration (config-router)
Address family configuration (config-router-af)

Command History

Release	Modification
10.0	This command was introduced.
12.4(6)T	Support for IPv6 was added.
12.2(33)SRB	This command was integrated into Cisco IOS Release 12.2(33)SRB.
Cisco IOS XE Release 2.1	This command was integrated into Cisco IOS XE Release 2.1.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
15.0(1)M	This command was modified. The address-family configuration mode was added.
12.2(33)SRE	This command was modified. The address-family configuration mode was added.
12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
Cisco IOS XE Release 2.5	This command was modified. The address-family configuration mode was added.

Usage Guidelines

Use this command to alter the default behavior of EIGRP routing and metric computation and allow the tuning of the EIGRP metric calculation for a particular type of service (ToS).

If k5 equals 0, the composite EIGRP metric is computed according to the following formula:

$$\text{metric} = [k1 * \text{bandwidth} + (k2 * \text{bandwidth}) / (256 - \text{load}) + k3 * \text{delay}]$$

If k5 does not equal zero, an additional operation is performed:

$$\text{metric} = \text{metric} * [k5 / (\text{reliability} + k4)]$$

Bandwidth is inverse minimum bandwidth of the path in bps scaled by a factor of $2.56 * 10^{12}$. The range is from a 1200-bps line to 10 terabits per second.

Delay is in units of 10 microseconds. The range of delay is from 10 microseconds to 168 seconds. A delay of all ones indicates that the network is unreachable.

The delay parameter is stored in a 32-bit field, in increments of 39.1 nanoseconds. The range of delay is from 1 (39.1 nanoseconds) to hexadecimal FFFFFFFF (decimal 4,294,967,040 nanoseconds). A delay of all ones (that is, a delay of hexadecimal FFFFFFFF) indicates that the network is unreachable.

Table 1 lists the default values used for several common media.

Table 1 *Bandwidth Values by Media Type*

Media Type	Delay	Bandwidth
Satellite	51,200,000 (2 seconds)	5120 (500 megabits)
Ethernet	25600 (1 millisecond [ms])	256,000 (10 megabits)
1.544 Mbps	51,200,000 (20 ms)	1,657,856 bits
64 kbps	51,200,000 (20 ms)	40,000,000 bits
56 kbps	51,200,000 (20 ms)	45,714,176 bits
10 kbps	51,20,000 (20 ms)	256,000,000 bits
1 kbps	51,200,000 (20 ms)	2,560,000,000 bits

Reliability is given as a fraction of 255. That is, 255 is 100 percent reliability or a perfectly stable link.

Load is given as a fraction of 255. A load of 255 indicates a completely saturated link.

Examples

The following example sets the metric weights to slightly different values than the defaults:

```
Router(config)# router eigrp 109
Router(config-router)# network 192.168.0.0
Router(config-router)# metric weights 0 2 0 2 0 0
```

The following example configures an address-family metric weight to tos: 0; K1: 2; K2: 0; K3: 2; K4: 0; K5: 0.

```
Router(config)# router eigrp virtual-name
Router(config-router)# address-family ipv4 autonomous-system 4533
Router(config-router-af)# metric weights 0 2 0 2 0 0
```

Related Commands

Command	Description
address-family (EIGRP)	Enters address-family configuration mode to configure an EIGRP routing instance.
bandwidth (interface)	Sets a bandwidth value for an interface.
delay (interface)	Sets a delay value for an interface.
ipv6 router eigrp	Configures the EIGRP for IPv6 routing process.
metric holddown	Keeps new EIGRP routing information from being used for a certain period of time.
metric maximum-hops	Causes the IP routing software advertise as unreachable routes with a hop count higher than is specified by the command (EIGRP only).
router eigrp	Configures the EIGRP address-family process.

neighbor (service-family)

To configure properties of an Enhanced Interior Gateway Routing Protocol (EIGRP) service-family neighbor, use the **neighbor** command in service-family configuration mode. To remove the properties of the neighbor, use the **no** form of this command.

```
neighbor {ip-address {interface-type interface-number |
```

```
    loopback loopback-interface-number [remote maximum-hops] |
```

```
    description description-string
```

```
    maximum-service maximum-service-limit [threshold-value] [warning-only]
```

```
    | dampened [reset-time minutes] [restart minutes] [restart-count number] }}
```

```
no neighbor {ip-address {interface-type interface-number | loopback loopback-interface-number
```

```
    | description description-string
```

```
    | maximum-service}}
```

Syntax Description

<i>ip-address</i>	IP address of the service-family neighbor, in A.B.C.D. format.
<i>interface-type</i>	Specifies the interface type.
<i>interface-number</i>	Specifies the interface number.
loopback	Specifies the loopback interface.
<i>loopback-interface-number</i>	Specifies the loopback interface number.
remote	(Optional) Specifies that the neighbor is remote.
<i>maximum-hops</i>	(Optional) Specifies the maximum number of hops, entered using a number from 3 to 100.
description	(Optional) Specifies a description for the neighbor.
<i>description-string</i>	Specifies the description string for the neighbor.
maximum-service	(Optional) Configures the maximum number of services acceptable from all neighbors.
<i>maximum-service-limit</i>	Specifies the limit of maximum services, entered by a number from 1 to 4294967295.
<i>threshold-value</i>	(Optional) Threshold value (%) that enables a warning message, entered by a number between 1 and 100. The default is 75 percent.
warning-only	(Optional) Generates a warning-only message when the configured limit is exceeded.
dampened	(Optional) Exponentially increases the restart-time interval.
reset-time	(Optional) Specifies the duration after which the system clears the restart history.
<i>minutes</i>	(Optional) Specifies the reset-time interval, in minutes, entered using a number between 1 and 65535.
restart	(Optional) Automatically reestablishes a peering session that was disabled because the maximum-service limit had been exceeded.
<i>minutes</i>	(Optional) Specifies the restart interval, in minutes, entered using a number between 1 and 65535.

restart-count	(Optional) Specifies the number of times that a peer is auto-restarted.
<i>number</i>	(Optional) Specifies the restart-count interval in minutes, entered using a number between 1 and 65535.

Command Default No neighbor establishments are configured.

Command Modes Service-family configuration (config-router-sf)

Command History	Release	Modification
	15.0(1)M	This command was introduced.
	12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
	12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
	Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.
	12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.

Usage Guidelines To configure a neighbor router with which to exchange routing information, use the **neighbor** command in service-family configuration mode. This command permits the point-to-point (non-broadcast) exchange of routing information. You can repeat this command to configure multiple neighbors.

Use the **neighbor ip-address loopback interface-number remote maximum-hops** command to configure neighbors that are multiple hops away and are not on the same subnet as the router. This command can be used only with loopback interfaces.

To configure the amount of memory used to store services from all EIGRP service-family neighbors, use the **neighbor maximum-service** command in service-family configuration mode. To disable this function, use the **no** form on this command.

When the amount of memory exceeds the maximum amount configured, the router disables the peering session (by default):

- If the **restart** keyword is configured, the router automatically reestablishes the peering session at the configured time interval. If the restart-interval is not configured, a disabled session stays down by default after the maximum-service limit is exceeded.
- If the **warning-only** keyword is configured, the router sends only a log message, but continues peering with the sender. If the neighbor is terminated, the neighbor remains down until the **clear eigrp service-family** command is configured.

Use the **show eigrp service-family ipv4** command with the **neighbor** keyword to verify neighbor configurations.

Examples

The following example sets the maximum hops to three for the remote neighbor 10.1.10.2 on Ethernet interface 0/0:

```
Router(config)# router eigrp virtual-name
Router(config-router)# service-family ipv4 autonomous-system 4533
Router(config-router-sf)# neighbor 10.1.10.2
Router(config-router-sf)# Ethernet 0/0
Router(config-router-sf)# remote 3
```

The following example sets the restart interval to 30 minutes, retries the restart five times, and clears the restart history after 60 minutes for neighbor 10.1.10.1:

```
Router(config)# router eigrp virtual-name
Router(config-router)# service-family ipv4 autonomous-system 4533
Router(config-router-sf)# neighbor 10.1.10.1
Router(config-router-sf)# reset-time 60
```

The following example set the maximum memory services to 1000 kilobytes that are allowed from neighbor 10.1.10.1:

```
Router(config)# router eigrp virtual-name
Router(config-router)# service-family ipv4 autonomous-system 4533
Router(config-router-sf)# neighbor 10.1.10.1
Router(config-router-sf)# maximum-service 1000
```

The following example set the maximum memory services to 500 kilobytes that are allowed from neighbor 10.1.10.1 and configures a warning to display when the maximum-service limit has been exceeded:

```
Router(config)# router eigrp virtual-name
Router(config-router)# service-family ipv4 autonomous-system 4533
Router(config-router-sf)# neighbor 10.1.10.1
Router(config-router-sf)# maximum-service 500 warning-only
```

Related Commands

Command	Description
clear eigrp service-family	Clears information for a Cisco SAF service family.
neighbor peer-group	Configures an EIGRP service-family neighbor to a peer group.
router eigrp	Configures the EIGRP process.
service-family	Configures commands under service-family mode.
sf-interface	Configures interface-specific commands under service-family.

password (SAF)

To configure a password for a Cisco SAF External Client, use the **password** command in external-client label configuration mode. To reset the password, use the **no** form on this command.

password *password-name*

no password *password-name*

Syntax Description

<i>password-name</i>	Specifies the name of the password for a Cisco SAF External-Client, entered using 11 to 64 characters.
----------------------	--

Command Default

No passwords are configured.

Command Modes

External-client label configuration (config-external-client-mode)

Command History

Release	Modification
15.0(1)M	This command was introduced.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.
12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.

Usage Guidelines

Use the **password** command to set a password for a Cisco SAF External Client.

Examples

The following example configures a password named example for a Cisco SAF External Client:

```
Router(config)# service-family external-client listen ipv4 2444  
Router(config-external-client)# external-client example  
Router(config-external-client-mode)# password example
```

Related Commands

Command	Description
external-client	Configures Cisco SAF External-Clients.
service-family external-client listen	Configures Cisco SAF External-client listen TCP ports.

remote-neighbors

To configure a Service Advertisement Framework (SAF) process that enables remote neighbors to accept inbound connections from any remote IP address, use the **remote-neighbors source** command in service-family configuration mode. To remove the configuration, use the **no** form of this command.

remote-neighbors source *interface* { **unicast-listen** | **mcast-group** *group-address* } [**allow-list** *access-list-name*] [**max-neighbors** *max-remote-peers*]

no remote-neighbors

Syntax Description		
<i>interface</i>		Specifies the loopback interface to use as the source for packets that are sent to remote neighbors. Only loopback interfaces are permitted.
unicast-listen		Accepts connections initiated by remote neighbors and forms remote neighbor relationships without having to manually configure the remote neighbor IP address.
mcast-group		Uses IP multicast to discover remote neighbors and form remote neighbor relationships.
<i>group-address</i>		Multicast address that EIGRP will use to discover remote neighbors and exchange information. Only routers using the same group address will discover one another as neighbors.
allow-list (Optional)		Uses an access list (Access Control List) to specify the remote IP addresses from which EIGRP neighbor connections may be accepted. If you do not use the allow-list keyword, then all IP addresses (permit any) will be accepted.
<i>access-list-name</i> (Optional)		Name of the access list to use with the allow-list keyword.
max-neighbors (Optional)		Uses a maximum number of remote neighbors. If you do not use this keyword, the maximum number of remote neighbors is limited only by available memory and bandwidth.
<i>max-remote-peers</i> (Optional)		Maximum number of remote neighbors that a member of the multicast group may accept. The range is from 1 to 65535.

Command Default No remote neighbors are specified.

Command Modes Service-family configuration (config-router-sf)

Command History	Release	Modification
	15.1(2)S	This command was introduced.
	Cisco IOS XE Release 3.3S	This command was integrated into Cisco IOS XE Release 3.3S.

Usage Guidelines

Configure the **allow-list** keyword for enhanced security. This keyword allows only specific IP addresses to connect to the remote neighbor.

Examples

The following example shows how to use unicast to configure remote neighbors to accept inbound connections from IP addresses that match an access list:

```
Router(config)# router eigrp virtual-name
Router(config-router)# service-family ipv4 autonomous-system 4453
Router(config-router-sf-interface)# remote-neighbors source Loopback1 unicast-listen
allow-list myNeighborList
```

The following example shows how to use multicast to discover similarly configured routers as remote neighbors, with no restriction on neighbor IP addresses (no allow-list specified), and a maximum of 30 neighbors:

```
Router(config)# router eigrp virtual-name
Router(config-router)# service-family ipv4 autonomous-system 4453
Router(config-router-sf-interface)# remote-neighbors source Loopback2 multicast-group
224.44.56.1 max-neighbors 30
```

Related Commands

Command	Description
service-family (SAF)	Enters service-family configuration mode.
neighbor (EIGRP)	Defines a neighboring router with which to exchange routing information on a router that is running Enhanced Interior Gateway Routing Protocol (EIGRP).

send-lifetime

To set the time period during which an authentication key on a key chain is valid to be sent, use the **send-lifetime** command in key chain key configuration mode. To revert to the default value, use the **no** form of this command.

send-lifetime *start-time* {**infinite** | *end-time* | **duration** *seconds*}

no send-lifetime [*start-time* {**infinite** | *end-time* | **duration** *seconds*}]

Syntax Description

<i>start-time</i>	Beginning time that the key specified by the key command is valid to be sent. The syntax can be either of the following: <i>hh:mm:ss Month date year</i> <i>hh:mm:ss date Month year</i> <ul style="list-style-type: none"> <i>hh</i>—hours <i>mm</i>—minutes <i>ss</i>—seconds <i>Month</i>—first three letters of the month <i>date</i>—date (1–31) <i>year</i>—year (four digits) The default start time and the earliest acceptable date is January 1, 1993.
infinite	Key is valid to be sent from the <i>start-time</i> value on.
<i>end-time</i>	Key is valid to be sent from the <i>start-time</i> value until the <i>end-time</i> value. The syntax is the same as that for the <i>start-time</i> value. The <i>end-time</i> value must be after the <i>start-time</i> value. The default end time is an infinite time period.
duration <i>seconds</i>	Length of time (in seconds) that the key is valid to be sent.

Command Default

Forever (the starting time is January 1, 1993, and the ending time is infinite)

Command Modes

Key chain key configuration (config-keychain-key)

Command History

Release	Modification
11.1	This command was introduced.
12.4(6)T	Support for IPv6 was added.
12.2(33)SRB	This command was integrated into Cisco IOS Release 12.2(33)SRB.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
15.0(1)M	This command was integrated into Cisco IOS Release 15.0M.

12.2(33)SRE	This command was modified. The address-family configuration mode was added.
12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
Cisco IOS XE Release 2.5	This command was modified. The address-family configuration mode was added.

Usage Guidelines

Specify a *start-time* value and one of the following values: **infinite**, *end-time*, or **duration seconds**.

We recommend running Network Time Protocol (NTP) or some other time synchronization method if you intend to set lifetimes on keys.

If the last key expires, authentication will continue and an error message will be generated. To disable authentication, you must manually delete the last valid key.

Examples

The following example configures a key chain named chain1. The key named key1 will be accepted from 1:30 p.m. to 3:30 p.m. and be sent from 2:00 p.m. to 3:00 p.m. The key named key2 will be accepted from 2:30 p.m. to 4:30 p.m. and be sent from 3:00 p.m. to 4:00 p.m. The overlap allows for migration of keys or a discrepancy in the set time of the router. There is a 30-minute leeway on each side to handle time differences.

```
Router(config)# interface ethernet 0
Router(config-if)# ip rip authentication key-chain chain1
Router(config-if)# ip rip authentication mode md5
!
Router(config)# router rip
Router(config-router)# network 172.19.0.0
Router(config-router)# version 2
!
Router(config)# key chain chain1
Router(config-keychain)# key 1
Router(config-keychain-key)# key-string key1
Router(config-keychain-key)# accept-lifetime 13:30:00 Jan 25 1996 duration 7200
Router(config-keychain-key)# send-lifetime 14:00:00 Jan 25 1996 duration 3600
Router(config-keychain-key)# exit
Router(config-keychain)# key 2
Router(config-keychain-key)# key-string key2
Router(config-keychain-key)# accept-lifetime 14:30:00 Jan 25 1996 duration 7200
Router(config-keychain-key)# send-lifetime 15:00:00 Jan 25 1996 duration 3600
```

The following example configures a key chain named chain1 for EIGRP address-family. The key named key1 will be accepted from 1:30 p.m. to 3:30 p.m. and be sent from 2:00 p.m. to 3:00 p.m. The key named key2 will be accepted from 2:30 p.m. to 4:30 p.m. and be sent from 3:00 p.m. to 4:00 p.m. The overlap allows for migration of keys or a discrepancy in the set time of the router. There is a 30-minute leeway on each side to handle time differences.

```
Router(config)# eigrp virtual-name
Router(config-router)# address-family ipv4 autonomous-system 4453
Router(config-router-af)# network 10.0.0.0
Router(config-router-af)# af-interface ethernet0/0
Router(config-router-af-interface)# authentication key-chain trees
Router(config-router-af-interface)# authentication mode md5
Router(config-router-af-interface)# exit
Router(config-router-af)# exit
Router(config-router)# exit
Router(config)# key chain chain1
Router(config-keychain)# key 1
```

```

Router(config-keychain-key) # key-string key1
Router(config-keychain-key) # accept-lifetime 13:30:00 Jan 25 1996 duration 7200
Router(config-keychain-key) # send-lifetime 14:00:00 Jan 25 1996 duration 3600
Router(config-keychain-key) # exit
Router(config-keychain) # key 2
Router(config-keychain-key) # key-string key2
Router(config-keychain-key) # accept-lifetime 14:30:00 Jan 25 1996 duration 7200
Router(config-keychain-key) # send-lifetime 15:00:00 Jan 25 1996 duration 3600

```

The following named configuration example configures a key chain named chain1 for a Cisco SAF service family. The key named key1 will be accepted from 1:30 p.m. to 3:30 p.m. and be sent from 2:00 p.m. to 3:00 p.m. The key named key2 will be accepted from 2:30 p.m. to 4:30 p.m. and be sent from 3:00 p.m. to 4:00 p.m. The overlap allows for migration of keys or a discrepancy in the set time of the router. There is a 30-minute leeway on each side to handle time differences.

```

Router(config) # eigrp virtual-name
Router(config-router) # service-family ipv4 autonomous-system 4453
Router(config-router-sf) # network 10.0.0.0
Router(config-router-sf) # sf-interface ethernet0/0
Router(config-router-sf-interface) # authentication key-chain trees
Router(config-router-sf-interface) # authentication mode md5
Router(config-router-sf-interface) # exit
Router(config-router-sf) # exit
Router(config-router) # exit
Router(config) # key chain chain1
Router(config-keychain) # key 1
Router(config-keychain-key) # key-string key1
Router(config-keychain-key) # accept-lifetime 13:30:00 Jan 25 1996 duration 7200
Router(config-keychain-key) # send-lifetime 14:00:00 Jan 25 1996 duration 3600
Router(config-keychain-key) # exit
Router(config-keychain) # key 2
Router(config-keychain-key) # key-string key2
Router(config-keychain-key) # accept-lifetime 14:30:00 Jan 25 1996 duration 7200
Router(config-keychain-key) # send-lifetime 15:00:00 Jan 25 1996 duration 3600

```

Related Commands

Command	Description
accept-lifetime	Sets the time period during which the authentication key on a key chain is received as valid.
key	Identifies an authentication key on a key chain.
key chain	Defines an authentication key chain needed to enable authentication for routing protocols.
key-string (authentication)	Specifies the authentication string for a key.
show key chain	Displays authentication key information.

service-family

To configure virtual routing and forwarding (VRF) metrics for a Cisco SAF service-family, use the **service-family ipv4** command in router configuration mode. To disable the service-family configuration, use the **no** form on this command.

service-family {ipv4 | ipv6} [vrf vrf-name] autonomous-system autonomous-system-number

no service-family {ipv4 | ipv6} [vrf vrf-name] autonomous-system autonomous-system-number

Syntax Description		
ipv4		Specifies the IP Version 4 address family and enters service-family configuration mode.
ipv6		Specifies the IP Version 6 address family and enters service-family configuration mode.
vrf		(Optional) Specifies all virtual routing forwarding (VRF) instance tables or a specific VRF table for an IP address.
<i>vrf-name</i>		(Optional) Names a specific VRF table for an IPv4 address.
autonomous-system		Specifies the autonomous system.
<i>autonomous-system-number</i>		Specifies the autonomous system number.

Command Default No service family configurations exist.

Command Modes Router configuration (config-router)

Command History	Release	Modification
	15.0(1)M	This command was introduced.
	12.2(33)SRE	This command was modified. The address-family configuration mode was added.
	12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
	Cisco IOS XE Release 2.5	This command was modified. The address-family configuration mode was added.
	12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.

Usage Guidelines

Use the **service-family** command to enter service-family configuration mode.

**Note**

Using the **service-family ipv6** commands requires an IPv6-enabled SAF client, which currently does not exist.

Examples

The following example configures a service-family autonomous-system number 4533:

```
Router(config)# router eigrp virtual-name  
Router(config-router)# service-family ipv4 autonomous-system 4533
```

Related Commands

Command	Description
exit-service-family	Exits service-family configuration mode.
router eigrp	Configures the EIGRP process.

service-family external-client listen

To configure a Cisco SAF External-Client TCP port, use the **service-family external-client listen** command in global configuration mode. To remove the associated external-client configuration, use the **no** form on this command.

service-family external-client listen { **ipv4** | **ipv6** } *tcp-port-number* *vrf-name*

no service-family external-client listen

Syntax Description

ipv4	Specifies the IP Version 4 address family.
ipv6	Specifies the IP Version 6 address family.
<i>tcp-port-number</i>	The TCP port number to listen on. Port numbers range between 1024 and 65536.
<i>vrf-name</i>	VRF name to listen on. Default is base.

Command Default

No external-client configurations exist.

Command Modes

Global configuration (config)

Command History

Release	Modification
15.0(1)M	This command was introduced.
12.2(33)SRE	This command was modified. The address-family configuration mode was added.
12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
Cisco IOS XE Release 2.5	This command was modified. The address-family configuration mode was added.
12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.

Usage Guidelines

Use the **service-family external-client listen** command to configure a TCP port on which the Cisco SAF Forwarder is to listen. The **no** form of this command removes all clients from the Cisco SAF network, the External-Client database, tears down all sockets, and removes the TCP listen socket.



Note

Using the **service-family external-client listen ipv6** commands requires an IPv6-enabled SAF client, which currently does not exist.

Use the **show eigrp service-family external-client** command to verify information on EIGRP external clients.

Examples

The following example configures an external-client TCP port number 4355 for the Cisco SAF Forwarder to listen on:

```
Router(config)# service-family external-client listen ipv4 4355
```

Related Commands	Command	Description
	show eigrp service-family external-client	Displays information on Cisco SAF External Clients.

sf-interface

To configure interface-specific commands for a Cisco SAF service family, use the **sf-interface** command in service-family configuration mode. To disable the service-family mode, use the **no** form on this command.

sf-interface { *interface-type interface-number* | **default** }

no sf-interface { *interface-type interface-number* | **default** }

Syntax Description

<i>interface-type</i>	Specifies the interface type.
<i>interface-number</i>	Specifies the interface number.
default	Specifies the service-family default interface configuration.

Command Modes

Service-family configuration (config-router-sf)

Command History

Release	Modification
15.0(1)M	This command was introduced.
12.2(33)SRE	This command was modified. The address-family configuration mode was added.
12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
Cisco IOS XE Release 2.5	This command was modified. The address-family configuration mode was added.
12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.

Usage Guidelines

Use the **sf-interface default** command to set the Cisco SAF default configuration for all interfaces on the router.

Use the **sf-interface interface-type interface-number** command to apply a Cisco SAF configuration to a specific interface. Any configuration using this command overrides the default configuration.

Examples

The following example places a router in service-family configuration mode and enables Ethernet interface 0/0, while disabling all other interfaces:

```
Router(config)# router eigrp virtual-name
Router(config-router)# service-family ipv4 autonomous-system 4533
Router(config-router-sf)# sf-interface default
Router(config-router-sf-interface)# shutdown
Router(config-router-sf-interface)# Ethernet 0/0
Router(config-router-sf-interface)# no shutdown
```

Related Commands

Command	Description
exit-service-family	Exits service-family configuration mode.
exit sf-interface	Exits service-family interface configuration mode.
router eigrp	Configures the EIGRP process.
service-family	Configures commands under service-family mode.
shutdown	Disables a service family on the interface.

show eigrp plugins

To display general information including the versions of the Enhanced Interior Gateway Routing Protocol (EIGRP) protocol features that are currently running, use the **show eigrp plugins** command in user EXEC or privileged EXEC mode.

show eigrp [*vrf-name*] [*as-number*] **plugins** [*plugin-name*] [**detailed**]

Syntax Description	vrf-name	(Obsolete) (Optional) Specifies a particular VPN routing and forwarding (VRF) instance name.
	Note	This keyword and argument are obsolete and configuring them has no effect on the output displayed.
	as-number	(Obsolete) (Optional) Autonomous system number.
	Note	This argument is obsolete and configuring it has no effect on the output displayed.
	plugin-name	(Optional) Name of an EIGRP plugin to display.
	detailed	(Optional) Displays detailed information about EIGRP features.

Command Modes	User EXEC (>)
	Privileged EXEC (#)

Command History	Release	Modification
	12.4(15)T	This command was introduced.
	12.2(33)SXI	This command was integrated into Cisco IOS Release 12.2(33)SXI.
	15.0(1)M	This command was modified. The vrf keyword, the <i>name</i> , and the <i>as-number</i> arguments were removed.
	12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
	12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
	Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.

Usage Guidelines

Use the **show eigrp plugins** command in user EXEC or privileged EXEC mode to determine if a particular EIGRP feature is available in your Cisco IOS image. This command displays a summary of information about EIGRP service families and address families.

This command is useful when contacting Cisco technical support.

Examples

The following example shows how to display EIGRP plugin information:

```
Router# show eigrp plugins

EIGRP feature plugins:::
  eigrp-release       :   5.00.00 : Portable EIGRP Release
```

■ show eigrp plugins

```

          : 19.00.00 : Source Component Release(rel5)
  igrp2   : 3.00.00 : Reliable Transport/Dual Database
  bfd     : 1.01.00 : BFD Platform Support
  mtr     : 1.00.01 : Multi-Topology Routing(MTR)
  eigrp-pfr : 1.00.01 : Performance Routing Support
  ipv4-af : 2.01.01 : Routing Protocol Support
  ipv4-sf : 1.01.00 : Service Distribution Support
  external-client : 1.02.00 : Service Distribution Client Support
  ipv6-af : 2.01.01 : Routing Protocol Support
  ipv6-sf : 1.01.00 : Service Distribution Support
  snmp-agent : 1.01.01 : SNMP/SNMPv2 Agent Support

```

Table 2 describes the significant fields shown in the display.

Table 2 *show eigrp plugins Field Descriptions*

Field	Description
eigrp release	Displays the portable EIGRP release version.
igrp2	Displays the reliable transport and dual database version.
bfd	Displays the EIGRP-BFD feature version.
mtr	Displays the EIGRP multitopology routing (MTR) version.
eigrp-pfr	Displays the EIGRP performance routing feature version.
ipv4-af	Displays the EIGRP IPv4 routing protocol feature version.
ipv4-sf	Displays the EIGRP IPv4 service distribution feature version.
external-client	Displays the EIGRP service distribution client support feature version.
ipv6-af	Displays the EIGRP IPv6 routing protocol feature version.
ipv6-sf	Displays the EIGRP IPv6 service distribution feature version.
snmp-agent	Displays the EIGRP SNMP and SNMPv2 Agent Support version.

■ Related Commands

Command	Description
clear eigrp service-family	Clears entries from the EIGRP neighbor table.
show eigrp service-family external-client	Displays information about the EIGRP service-family external clients.
show eigrp service-family ipv4 topology	Displays information from the EIGRP IPv4 service-family topology table.
show eigrp service-family ipv6 topology	Displays information from the EIGRP IPv6 service-family topology table.
show eigrp tech-support	Generates a report of all EIGRP-related information.

show eigrp protocols

To display general information about Enhanced Interior Gateway Routing Protocol (EIGRP) protocols that are currently running, use the **show eigrp protocols** command in user EXEC or privileged EXEC mode.

show eigrp protocols [*vrf vrf-name*]

Syntax Description

vrf vrf-name	(Optional) Displays information about the specified VRF.
---------------------	--

Command Modes

User EXEC (>)
Privileged EXEC (#)

Command History

Release	Modification
15.0(1)M	This command was introduced.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.
12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.

Usage Guidelines

Use the **show eigrp protocols** command in user EXEC or privileged EXEC mode to see a summary of information on EIGRP IPv4 service families or address families.

Examples

The following example shows how to display general EIGRP information:

```
Router# show eigrp protocols

EIGRP-IPv4 Protocol for AS(10)
Metric weight K1=1, K2=0, K3=1, K4=0, K5=0
NSF-aware route hold timer is 240
Router-ID: 1.1.1.1
Topology : 0 (base)
Active Timer: 3 min
Distance: internal 90 external 170
Maximum path: 4
Maximum hopcount 100
Maximum metric variance 1
EIGRP-IPv4 Protocol for AS(5) VRF(red)
Metric weight K1=1, K2=0, K3=1, K4=0, K5=0
NSF-aware route hold timer is 240
Router-ID: 1.1.1.1
Topology : 0 (base)
Active Timer: 3 min
Distance: internal 90 external 170
Maximum path: 4
Maximum hopcount 100
Maximum metric variance 1
```

```
Total Prefix Count: 0
Total Redist Count: 0
```

The following example shows how to display general EIGRP information for VRF1:

```
Router# show eigrp protocols vrf vrf1

EIGRP-IPv4 Protocol for AS(5) VRF(vrf1)
Metric weight K1=1, K2=0, K3=1, K4=0, K5=0
NSF-aware route hold timer is 240
Router-ID: 1.1.1.1
Topology : 0 (base)
Active Timer: 3 min
Distance: internal 90 external 170
Maximum path: 4
Maximum hopcount 100
Maximum metric variance 1
Total Prefix Count: 0
Total Redist Count: 0
```

Table 3 describes the significant fields shown in the display.

Table 3 *show eigrp protocols Field Descriptions*

Field	Description
EIGRP-IPv4 Protocol for AS(10)	EIGRP instance and AS number.
Metric weight	EIGRP metric calculations.
NSF-aware route hold timer	Route-hold timer value for an NSF-aware router.
Router-ID	Router ID.
Topology	Number of entries in the EIGRP topology table.
Active Timer	EIGRP routing active time limit.
Distance	Internal and external administrative distance.
Maximum path	Maximum number of parallel routes that EIGRP can support.
Maximum hop count	Maximum hop count (in decimal).
Maximum metric variance	Metric variance used to find feasible paths for a route.
EIGRP-IPv4 Protocol	EIGRP instance and AS number for VRF Red.
Total Prefix Count	The aggregate sum of the prefixes in an EIGRP instance topology table. It includes prefixes learned from all neighbors or from redistribution.
Total Redist Count	The number of prefixes redistributed into an EIGRP process.

Related Commands	Command	Description
	clear eigrp service-family	Clears entries from the EIGRP neighbor table.
	show eigrp service-family external-client	Displays information about the EIGRP service-family external clients.
	show eigrp service-family ipv4 topology	Displays information from the EIGRP IPv4 service-family topology table.
	show eigrp service-family ipv6 topology	Displays information from the EIGRP IPv6 service-family topology table.
	show tech-support	Generates a report of all EIGRP-related information.

show eigrp service-family

To display information for an Enhanced Interior Gateway Routing Protocol (EIGRP) IPv4 or IPv6 service family, use the **show eigrp service-family** command in user EXEC or privileged EXEC mode.

```
show eigrp service-family {ipv4 | ipv6} [vrf vrf-name] autonomous-system-number
    {accounting |
    clients [detail] |
    events [starting-event-number ending-event-number] | [errmsg starting-event-number
    ending-event-number] | [type] |
    interfaces [interface-type interface-number] | detail interface-type interface-number] |
    neighbors [detail | interface-type interface-number] |
    sia-event [starting-event-number ending-event-number] |
    sia-statistics [ip-address] |
    subscriptions [detail] |
    timers |
    traffic}
```

Syntax Description

ipv4	Specifies the IP Version 4 address family.
ipv6	Specifies the IP Version 6 address family.
vrf	(Optional) Specifies all virtual routing forwarding (VRF) instance tables or a specific VRF table for an IP address.
<i>vrf-name</i>	(Optional) Names a specific VRF table for an IPv4 address.
<i>autonomous-system-number</i>	Specifies the autonomous system number.
accounting	Displays accounting information.
clients	Displays Client information. If the clients keyword is used without the optional detail keyword,
detail	(Optional) Displays detailed client data.
events	Displays logged event information.
<i>starting-event-number</i>	(Optional) Specifies the starting event number between 1 and 4294967295.
<i>ending-event-number</i>	(Optional) Specifies the ending event number between 1 and 4294967295.
errmsg	(Optional) Displays logged error message events.
<i>starting-event-number</i>	(Optional) Specifies the starting event number between 1 and 4294967295.
<i>ending-event-number</i>	(Optional) Specifies the ending event number between 1 and 4294967295.
type	(Optional) Displays the event types being logged.
interfaces	Displays interface information.
<i>interface-type</i>	(Optional) Specifies the interface type.
<i>interface-number</i>	(Optional) Specifies the interface number.
detail	(Optional) Displays detailed information about an interface (or interfaces).
<i>interface-type</i>	(Optional) Specifies the interface type.

<i>interface-number</i>	(Optional) Specifies the interface number.
neighbors	Displays neighbors discovered by Cisco SAF.
detail	(Optional) Displays detailed information about a neighbor interface (or interfaces).
<i>interface-type</i>	(Optional) Specifies the neighbor interface type.
<i>interface-number</i>	(Optional) Specifies the neighbor interface number.
sia-event	Displays logged Stuck In Active (SIA) information.
<i>starting-event-number</i>	(Optional) Specifies the starting event number between 1 and 4294967295.
<i>ending-event-number</i>	(Optional) Specifies the ending event number between 1 and 4294967295.
sia-statistics	Displays logged SIA statistic information.
<i>ip-address</i>	(Optional) Specifies the IP address of the neighbor to display information about.
subscriptions	Displays subscription information.
detail	(Optional) Displays detailed information about a subscription.
timers	Displays timer information.
traffic	Displays traffic statistical information.

Command Modes

User EXEC (>)
Privileged EXEC (#)

Command History

Release	Modification
15.0(1)M	This command was introduced.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.
12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.

Usage Guidelines

Using **show eigrp service-family ipv4** command in user EXEC or privileged EXEC mode to see a summary of information on EIGRP IPv4 service families.

**Note**

Using the **show eigrp service-family ipv6** commands requires an IPv6-enabled SAF client, which currently does not exist.

Examples

The following is sample output from the **show eigrp service-family ipv4 accounting** command:

```
Router> enable
Router# show eigrp service-family ipv4 4453 accounting

EIGRP-SFv4 VR(saf) Accounting for AS(22)/ID(10.0.0.1)

Total Prefix Count: 3   States: A-Adjacency, P-Pending, D-Down

State Address/Source   Interface      Prefix   Restart   Restart/
                Count                Count      Reset(s)
A      10.0.0.2         Et0/0          2         0          0
```

[Table 4](#) describes the significant fields shown in the **show eigrp service-family ipv4 accounting** command output.

Table 4 *show eigrp service-family ipv4 accounting Field Descriptions*

Field	Description
EIGRP SFv4 VR(saf) Accounting	Identifies the EIGRP instance along with the AS number, router ID, and table ID.
Total Prefix Count	Shows the aggregate sum of the prefixes in an EIGRP instance topology table. It includes prefixes learned from all neighbors or from redistribution.
States: A-Adjacency, P-Pending, D-Down	<p>A-Adjacency: Indicates a stable adjacency with the neighbor or a normal redistribution state.</p> <p>P-Pending: Neighbor adjacency or redistribution in a suspended or penalized state because the maximum prefix limit has been exceeded.</p> <p>D-Down: Neighbor adjacency or redistribution is suspended permanently until a manual reset is performed with the clear ip route command.</p>
Address/Source	Shows the peer IP address of the redistribution source.
Interface	Specifies the interface type.
Prefix Count	<p>Displays the total number of learned prefixes by source.</p> <p>Note Routes can be learned for the same prefix from multiple sources, and the sum of all prefix counts in this column may be greater than the figure displayed in the Prefix Count field.</p>
Restart Count	Number of times that a route source has exceeded the maximum-prefix limit.
Restart/Reset(s)	Displays the time, in seconds, that a route source is in a P (pending) state. If the route source is in an A (stable or normal) state, the displayed time, in seconds, is the time period until penalization history is reset.

The following is sample output from the **show eigrp service-family ipv4 clients** command:

```
Router> enable
Router# show eigrp service-family ipv4 autonomous-system 1 clients

EIGRP-SFv4 VR(saf) Clients for AS(1)ID(10.0.0.1)

Client                               Callback
Handle  Name                               Context/pid/Registered (Y/N)
  1  example                               0x00000000/   3/N
  2  CME                               0x00000000/   3/N
```

The following is sample output from the **show eigrp service-family ipv4 clients detail** command:

```
Router> enable
Router# show eigrp service-family ipv4 autonomous-system 1 clients detail

EIGRP-SFv4 VR(saf) Clients for AS(1)ID(10.0.0.1)

Client                               Callback
Handle  Name                               Context/pid/Registered (Y/N)
  1  Test                               0x00000000/   3/N
      Subscribed Services/Notifications: 0/0
      Published Services/Size(kB): 0/0
      Sequence Number Updated: 0

  2  CME                               0x00000000/   3/N
      Subscribed Services/Notifications: 1/1
      Published Services/Size(kB): 1/2
      Sequence Number Updated: 2
```

[Table 5](#) describes the significant fields shown in the **show eigrp service-family ipv4 clients** command output.

Table 5 *show eigrp service-family ipv4 clients Field Descriptions*

Field	Description
Client Handle	Displays the Cisco SAF Client handle assigned to this client.
Name	Displays the name given to the Cisco SAF Client on registering.
Context	Displays the context given to the specified Cisco SAF Client on registering, used in callbacks.
Pid	Displays the Process ID of a specified client.
Callback Registered (Y/N)	Displays whether a specified client has registered for callbacks.
Subscribed Services	Displays the number of services that a specified Cisco SAF Client has subscribed to.
Notifications	Displays the number of notifications received by the specified client.
Published Services	Displays the number of services that the specified client has currently published.
Size	Displays the total size (kilobytes) of the service the specified client has currently published.
Sequence Number Updated	Displays the number of times that the specified client has updated the sequence number of an existing service.

The following is sample output from the **show eigrp service-family ipv4 interfaces** command:

```
Router> enable
Router# show eigrp service-family ipv4 4453 interfaces

EIGRP service-family neighbors for process 4453

Xmit Queue Mean    Pacing Time    Multicast    Pending
Interface  Peers  Un/Reliable SRTTUn/Reliable Flow Timer    Services
Se0         1      0/0      28      0/15      127         0
Se1         1      0/0      44      0/15      211         0
```

The following is sample output from the **show eigrp service-family ipv4 interfaces detail** command:

```
Router> enable
Router# show eigrp service-family ipv4 4453 interfaces detail Loopback 1

Xmit Queue Mean    Pacing Time    Multicast    Pending
Interface  Peers  Un/Reliable SRTTUn/Reliable Flow Timer    Services
Lo1         166    0/0      48      0/1      258         0
Hello-interval is 5, Hold-time is 15
Split-horizon is enabled
Next xmit serial <none>
Un/reliable mcasts: 0/0  Un/reliable ucasts: 10148/67233
Mcast exceptions: 0  CR packets: 0  ACKs suppressed: 8719
Retransmissions sent: 2696  Out-of-sequence rcvd: 594
Interface has all stub peers
Topology-ids on interface - 0
Authentication mode is not set[GFM1]EIGRP service-family neighbors for process 4453
```

[Table 6](#) describes the significant fields shown in the **show eigrp service-family ipv4 interfaces** command output.

Table 6 *show eigrp service-family ipv4 interfaces Field Descriptions*

Field	Description
Interface	Interface over which EIGRP is configured.
Peers	Number of directly connected EIGRP neighbors.
Xmit Queue	Transmit queues.
Un/Reliable	Number of packets remaining in the Unreliable and Reliable transmit queues.
Mean SRTT	Mean smooth round-trip time interval in milliseconds.
Pacing Time	Pacing time.
Un/Reliable	Pacing time used to determine when reliable and unreliable EIGRP packets should be sent out.
Multicast Flow Timer	Maximum number of seconds for which the system sends multicast EIGRP packets.
Pending Services	Number of services in the packets that are sitting in the transmit queue waiting to be sent.

The following is sample output from the **show eigrp service-family ipv4 neighbors** command:

```
Router> enable
Router# show eigrp service-family ipv4 4453 neighbors

EIGRP SFv4 VR(test) Service-Family Neighbors for AS(4453)
```

Address	Interfaces (sec)	Hold Uptime ((sec)	SRTT (msec)	RTO	Q Cnt	Seq Num
10.1.1.1	Ethernet0/0	13 00:00:41	30	1014	0	16
10.1.2.1	Ethernet0/0	14 00:02:02	20	200	0	10

The following is sample output from the **show eigrp service-family ipv4 neighbors detail** command:

```
Router> enable
Router# show eigrp service-family ipv4 4453 neighbors detail

EIGRP SFv4 VR(test) Service-Family Neighbors for AS(4453)
```

Address	Interfaces (sec)	Hold Uptime ((sec)	SRTT (msec)	RTO	Q Cnt	Seq Num
10.1.1.1	Ethernet0/0	14 00:00:41	1	3000	0	80
Version 5.0/3.0, Retrans: 1, Retries: 0						
Topology-ids from peer - 0						
Receive-Only Peer Advertising (No) Routes						
Suppressing queries						
10.1.2.1	Ethernet0/1	13 00:02:02	28	200	0	883
Version 5.0/3.0, Retrans: 1, Retries: 0, Prefixes: 1						
Topology-ids from peer - 0						
Stub Peer Advertising (CONNECYTED) Routes						

[Table 7](#) describes the significant fields shown in the **show eigrp service-family ipv4 neighbors** command output.

Table 7 *show eigrp service-family ipv4 neighbors Field Descriptions*

Field	Description
Address	IP address of the peer.
Interfaces	Interface on which the router is receiving hello packets from the peer.
Hold Uptime	Length of time, in seconds, that the router will wait to hear from the peer before declaring it down.
SRTT	Smooth round-trip time. This is the number of milliseconds it takes for an EIGRP packet to be sent to this neighbor and for the local router to receive an acknowledgement of that packet.
RTO	Retransmission timeout, in milliseconds. The amount of time the system waits before retransmitting a packet from the retransmission queue to a neighbor.
Q Cnt	Number of packets (update, query, and reply) that the system is ready to send.
Seq Num	Sequence number of the last update, query, or replay packet that was received from this neighbor.
Version	EIGRP version and EIGRP packet version of the neighbor.
Receive-Only Peer Advertising	Neighbor is configured as an EIGRP stub, receive-only, router.

Table 7 *show eigrp service-family ipv4 neighbors Field Descriptions (continued)*

Field	Description
Stub Peer Advertising (CONNECTED)	Neighbor is configured as an EIGRP stub, connected, router.
Suppressing queries	EIGRP queries are not sent to this peer because it is receive-only.

The following is sample output from the **show eigrp service-family ipv4 traffic** command:

```
Router> enable
Router# show eigrp service-family ipv4 4453 traffic

EIGRP service-family Traffic Statistics for process 4453
  Hello sent/received: 218/205
  Updates sent/received: 7/23
  Queries sent/received: 2/0
  Replies sent/received: 0/2
  Acks sent/received: 21/14
  SIA-Queries sent/received: 0/0
  SIA-Replies sent/received 0/0
  Hello Process ID: 121
  PDM Process ID: 120
  Socket Queue: 0/2000/2/0
    (current/max/highest/drops)
  Input Queue: 0/2000/2/0
    (current/max/highest/drops)
```

[Table 8](#) describes the significant fields shown in the **show eigrp service-family ipv4 traffic** command output.

Table 8 *show eigrp service-family ipv4 traffic Field Descriptions*

Field	Description
process	Autonomous system number specified in the configuration command.
Hellos	Displays the number of sent and received hello messages.
Updates	Displays the number of sent and received update messages.
Queries	Displays the number of sent and received query messages.
Replies	Displays the number of sent and received reply messages.
Acks	Displays the number of sent and received acknowledge messages.
SIA-Queries	Displays the number of sent and received stuck-in-active queries.
SIA-Replies	Displays the number of sent and received stuck-in-active replies.
Hello Process ID	Displays the hello process ID.
PDM Process ID	Displays the PDM process ID.

Table 8 *show eigrp service-family ipv4 traffic Field Descriptions (continued)*

Field	Description
Socket Queue	Displays the current, maximum, and highest seen queue depth for the output socket. Displays the number of packets dropped due to the queue being full.
Input Queue	Displays the current, maximum, and highest seen queue depth for the input socket. Displays the number of packets dropped due to the queue being full.

Related Commands

Command	Description
clear eigrp service-family	Clears entries from the EIGRP neighbor table.
show eigrp service-family external-client	Displays information about the EIGRP service-family external clients.
show eigrp service-family ipv4 topology	Displays information from the EIGRP IPv4 service-family topology table.
show eigrp service-family ipv6 topology	Displays information from the EIGRP IPv6 service-family topology table.

show eigrp service-family external-client

To display information about Cisco Service Advertisement Framework (Cisco SAF) external clients, use the **show eigrp service-family external-client** command in user EXEC or privileged EXEC mode.

show eigrp service-family external-client [*client-label*]

Syntax Description

client-label (Optional) Displays detailed client information for the specified client label.

Command Modes

User EXEC (>)
Privileged EXEC (#)

Command History

Release	Modification
15.0(1)M	This command was introduced.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.
12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.
15.1(2)S	The command was modified. The output was revised to include additional information about the clients, such as basename and socket ID.
Cisco IOS XE Release 3.3S	The command was modified. The output was revised to include additional information about the clients, such as basename and socket ID.

Usage Guidelines

Use the **show eigrp service-family external-client** command in user or privileged EXEC mode to see a summary of the information about Cisco SAF external clients that are currently registered with the Cisco SAF system.

Examples

The following is sample output from the **show eigrp service-family external-client** command if any clients are registered:

```
Router# show eigrp service-family external-client
SAF External Clients
```

```
example-using-basename (basename)
```

Client Handle	Socket FD	Keep (ms)	Address	Port	Tag
1	1	3268319	10.1.1.1	47519	@12
2	2	3268347	192.168.100.101	36997	@1

```
example-configured-but-no-clients-connected
No connected clients
```

```
example-client-without-basename
```

Client Handle	Socket FD	Keep (ms)	Address	Port	Tag
3	3	208373	10.1.1.2	51294	--

Table 9 describes the significant fields shown in the display.

Table 9 *show eigrp service-family external-client Field Descriptions*

Field	Description
Client Handle	Specifies the Cisco SAF internal client handle.
Socket FD (File Descriptor)	Specifies the socket API file descriptor for this Cisco SAF External Client.
Keep (ms)	Specifies the remaining keepalive time (in milliseconds) before the client will be disconnected if no further communications are received from the client.
Address	Specifies the IP address of the selected external client.
Port	Specifies the TCP port number of the selected external client.
Tag	Specifies the identifying tag provided by the client if the <i>client-label</i> argument was configured using the basename keyword. The basename keyword allows SAF external clients to uniquely identify themselves using the naming convention in the form of <i>client-label@tag</i> (where tag is a number from 1 to 50).

The following is sample output from the **show eigrp service-family external-client client-label** command if the specified client is registered:

```
Router# show eigrp service-family external-client example-using-basename@12
SAF External Client "example-using-basename" (basename)
  Listening on port 1024, keepalive time 3600000 ms
  VR(saf) SFv4 AS(1) Topology(base)

Client  Socket   Keep  Address                Port  Tag
Handle  FD      (ms)
1        1      3322871  10.1.1.1              47519  @12
  Client name "thisistheclientnameweprovided"
  Page size 1, currently allowed to send 1
  Protocol version 1.0
  2 subscriptions
```

Table 10 describes the significant fields shown in the display.

Table 10 *show eigrp service-family external-client client-label Field Descriptions*

Field	Description
Client name	Specifies the descriptive name provided by the client to identify itself.
Page size	Specifies the page size provided by the client and specifies the number of additional requests allowed to be sent at the time the show command is issued (between 0 and the number specified for Page size).
Protocol version	Specifies the version of the SAF External Client protocol being used by the client to communicate with the SAF forwarder.
subscriptions	Specifies the number of SAF subscriptions owned by the client. When the number of subscriptions is 0, this field displays “No subscriptions”.

Related Commands

Command	Description
clear eigrp service-family	Clears entries from the EIGRP neighbor table.
show eigrp service-family	Displays EIGRP IPv4 service-family information.
show eigrp service-family ipv4 topology	Displays information in the EIGRP IPv4 service-family topology table.
show eigrp service-family ipv6 topology	Displays information in the EIGRP IPv6 service-family topology table.
external-client	Configures a Cisco SAF Service Advertisement Framework (Cisco SAF) External Client.

show eigrp service-family ipv4 topology

To display topology information for an Enhanced Interior Gateway Routing Protocol (EIGRP) IPv4 service family, use the **show eigrp service-family ipv4 topology** command in user EXEC or privileged EXEC mode.

```
show eigrp service-family ipv4 [vrf vrf-name] autonomous-system-number topology
[service-instance-number |
active |
all-links |
detail-links |
pending
service-type [connected | external | internal | local | redistributed | summary] |
summary |
zero-successors]
```

Syntax Description	
vrf	(Optional) Specifies all virtual routing forwarding (VRF) instance tables or a specific VRF table for an IP address.
<i>vrf-name</i>	(Optional) Names a specific VRF table for an IPv4 address.
<i>autonomous-system-number</i>	Specifies the autonomous-system number.
<i>service-instance-number</i>	(Optional) Displays detailed information about the specified service-instance number. Service-instance numbers display as service:subservice:instance.instance.instance. Service-instance numbers can range from 1:1:0.0.0.1 to 65534:65534:FFFFFFFF.FFFFFFFFFF.FFFFFFFFFF.FFFFFFFFFE.
active	(Optional) Displays only active entries in the topology table.
all-links	(Optional) Displays all service sources (including non-feasible sources) in the topology table.
detail-links	(Optional) Specifies all links in the topology table.
pending	(Optional) Displays all active entries in the topology table that are waiting either for an update or reply from a neighbor.
service-type	(Optional) Specifies the service with the given type in the topology table.
connected	(Optional) Displays only connected services.
external	(Optional) Displays all external services.
internal	(Optional) Displays all internal services.
local	(Optional) Display all locally originated services.
redistributed	(Optional) Displays all redistributed services.
summary	(Optional) Displays all summary services.
summary	(Optional) Specifies a summary of the topology table.
zero-successors	(Optional) Displays only services in the topology table that have zero successors.

Command Modes	
	User EXEC (>)
	Privileged EXEC (#)

Command History

Release	Modification
15.0(1)M	This command was introduced.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.
12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.

Usage Guidelines

Use the **show eigrp service-family ipv4 topology** command in user EXEC or privileged EXEC mode to see a summary of information on EIGRP IPv4 service-families services.

Examples

The following is sample output from the **show eigrp service-family ipv4 topology** command:

```
Router> enable
Router# show eigrp service-family ipv4 4453 topology

EIGRP-SFv4 Topology Table for process 4453

Codes: P - Passive, A - Active, U - Update, Q - Query, R - Reply, r - Reply status

P 1:2:0.0.0.3, 2 successors, FD is 0
    via 10.16.80.28 (46251776/46226176), Ethernet0
    via 10.16.81.28 (46251776/46226176), Ethernet1
    via 10.16.80.31 (46277376/46251776), Serial0

P 4:5:0.0.0.6, 1 successors, FD is 37200
    via Connected, Ethernet1
    via 10.16.81.28 (307200/281600), Ethernet1S
    via 10.16.80.28 (307200/281600), Ethernet0
    via 10.16.80.31 (332800/307200), Serial0
```

The following is sample output from the **show eigrp service-family ipv4 topology** command for a specified service:

```
Router> enable
Router# show eigrp service-family ipv4 4453 topology 1:2:0.0.0.3

EIGRP-SFv4 VR(example) Topology Table entry for AS(4453)/ID(10.1.1.1)1:2:0.0.0.3
State is Passive, Query origin flag is 1, 1 Successor(s), FD is 409600
Service Description Blocks:
1:2:3:0.0.0.3 (Ethernet0/0), from 10.2.1.1, Send flag is 0x0
Composite metric is (409600/128256), Route is External
Vector metric:
    Minimum bandwidth is 10000 Kbit
    Total delay is 6000 microseconds
    Reliability is 255/255
    Load is 1/255
    Minimum MTU is 1500
    Hop count is 1
External data:
    Originating router is 10.89.245.1
    AS number of route is 0
    External protocol is Connected, external metric is 0
    Administrator tag is 0 (0x00000000)
```

Codes: P - Passive, A - Active, U - Update, Q - Query, R - Reply, r - Reply status

```
P 1:2:0.0.0.3, 2 successors, FD is 0
  via 10.16.80.28 (46251776/46226176), Ethernet0
  via 10.16.81.28 (46251776/46226176), Ethernet1
  via 10.16.80.31 (46277376/46251776), Serial0

P 4:5:0.0.0.6, 1 successors, FD is 37200
  via Connected, Ethernet1
  via 10.16.81.28 (307200/281600), Ethernet1S
  via 10.16.80.28 (307200/281600), Ethernet0
  via 10.16.80.31 (332800/307200), Serial0
```

Table 11 describes the significant fields shown in the **show eigrp service-family ipv4 topology** command output.

Table 11 *show eigrp service-family ipv4 topology Field Descriptions*

Field	Description
Codes	State of this topology table entry. Passive and Active refer to the EIGRP state with respect to this destination; Update, Query, and Reply refer to the type of packet that is being sent.
P	Passive—No EIGRP computations are being performed for this destination.
A	Active—EIGRP computations are being performed for this destination.
U	Update—Indicates that an update packet was sent to this destination.
Q	Query—Indicates that an query packet was sent to this destination.
R	Reply—Indicates that an reply packet was sent to this destination.
r	Reply status—A flag set after the service has sent a query and is waiting for a reply.
1:2:0.0.0.3	Service number.
successors	Number of successors. Corresponds to the number of next hops in the IP routing table. If “successors” is capitalized, then the route or next hop is in a transition state.
FD	Flexible distance—The best metric to reach the destination or the best metric that was known when the service went active.
via	IP address of the peer that told the service about this destination. The first n of these entries, where n is the number of successors, is the current successors. The remaining entries in the list are feasible successors. If “all-links” or “detailed-links” is specified, the feasible successors are followed by sources that are neither successors nor feasible successors.

Table 11 *show eigrp service-family ipv4 topology Field Descriptions*

Field	Description
(46251776/46226176)	Two EIGRP metric numbers. The first number represents the cost to the destination; the second number is the metric that this peer advertised.
Ethernet0	Indicates the interface from which this information was learned.

Related Commands

Command	Description
clear eigrp service-family	Clears entries from the EIGRP neighbor table.
show eigrp service-family	Displays information about Cisco SAF service-family Clients, External Clients, and subscriptions.
show eigrp service-family external-client	Displays information about the Cisco SAF service-family External Clients.
show eigrp service-family ipv6 topology	Displays information from the Cisco SAF IPv6 service-family topology table.

show eigrp service-family ipv6 topology

To display topology information for an Enhanced Interior Gateway Routing Protocol (EIGRP) IPv6 service family, use the **show eigrp service-family ipv6 topology** command in user EXEC or privileged EXEC mode.

```
show eigrp service-family ipv6 [vrf vrf-name] autonomous-system-number topology
[service-instance-number |
active |
all-links |
detail-links |
pending
service-type [connected | external | internal | local | redistributed | summary] |
summary |
zero-successors]
```

Syntax Description	
vrf	(Optional) Specifies all virtual routing forwarding (VRF) instance tables or a specific VRF table for an IP address.
<i>vrf-name</i>	(Optional) Names a specific VRF table for an IPv6 address.
<i>autonomous-system-number</i>	Specifies the autonomous-system number.
<i>service-instance-number</i>	(Optional) Displays detailed information about the specified service-instance number. Service-instance numbers display as service:subservice:instance.instance.instance. Service-instance numbers can range from 1:1:0.0.0.1 to 65534:65534:FFFFFFFF.FFFFFFFFFF.FFFFFFFFFF.FFFFFFFFFE.
active	(Optional) Displays only active entries in the topology table.
all-links	(Optional) Displays all service sources (including non-feasible sources) in the topology table.
detail-links	(Optional) Specifies all links in the topology table.
pending	(Optional) Displays all active entries in the topology table that are waiting for an update or reply from a neighbor.
service-type	(Optional) Specifies the service with the given type in the topology table.
connected	(Optional) Displays only connected services.
external	(Optional) Displays all external services.
internal	(Optional) Displays all internal services.
local	(Optional) Display all locally originated services.
redistributed	(Optional) Displays all redistributed services.
summary	(Optional) Displays all summary services.
summary	(Optional) Specifies a summary of the topology table.
zero-successors	(Optional) Displays only services in the topology table that have zero successors.

Command Modes	
	User EXEC (>)
	Privileged EXEC (#)

Command History

Release	Modification
15.0(1)M	This command was introduced.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.
12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.

Usage Guidelines

Use the **show eigrp service-family ipv6 topology** command in user EXEC or privileged EXEC mode to see a summary of information on EIGRP IPv6 service-family topology services.

**Note**

Using the **show eigrp service-family ipv6 topology** commands requires an IPv6-enabled SAF client, which currently does not exist.

Examples

The following is sample output from the **show eigrp service-family ipv6 topology** command:

```
Router> enable
Router# show eigrp service-family ipv6 4453 topology

EIGRP-SFv4 Topology Table for process 4453

Codes: P - Passive, A - Active, U - Update, Q - Query, R - Reply, r - Reply status

P 1:2:0.0.0.3, 2 successors, FD is 0
  via 10.16.80.28 (46251776/46226176), Ethernet0
  via 10.16.81.28 (46251776/46226176), Ethernet1
  via 10.16.80.31 (46277376/46251776), Serial0

P 4:5:0.0.0.6, 1 successors, FD is 37200
  via Connected, Ethernet1
  via 10.16.81.28 (307200/281600), Ethernet1S
  via 10.16.80.28 (307200/281600), Ethernet0
  via 10.16.80.31 (332800/307200), Serial0
```

The following is sample output from the **show eigrp service-family ipv6 topology** command for a specified service:

```
Router> enable
Router# show eigrp service-family ipv6 4453 topology 1:2:0.0.0.3

EIGRP-SFv4 VR(example) Topology Table entry for AS(4453)
State is Passive, Query origin flag is 1, 1 Successor(s), FD is 409600
Service Description Blocks:
1:2:3:0.0.0.3 (Ethernet0/0), from 10.2.1.1, Send flag is 0x0
Composite metric is (409600/128256), Route is External
Vector metric:
  Minimum bandwidth is 10000 Kbit
  Total delay is 6000 microseconds
  Reliability is 255/255
  Load is 1/255
  Minimum MTU is 1500
  Hop count is 1
External data:
  Originating router is 10.89.245.1
```



```

AS number of route is 0
External protocol is Connected, external metric is 0
Administrator tag is 0 (0x00000000)

```

Codes: P - Passive, A - Active, U - Update, Q - Query, R - Reply, r - Reply status

```

P 1:2:0.0.0.3, 2 successors, FD is 0
  via 10.16.80.28 (46251776/46226176), Ethernet0
  via 10.16.81.28 (46251776/46226176), Ethernet1
  via 10.16.80.31 (46277376/46251776), Serial0

P 4:5:0.0.0.6, 1 successors, FD is 37200
  via Connected, Ethernet1
  via 10.16.81.28 (307200/281600), Ethernet1S
  via 10.16.80.28 (307200/281600), Ethernet0
  via 10.16.80.31 (332800/307200), Serial0

```

Table 12 describes the significant fields shown in the **show eigrp service-family ipv6 topology** command output.

Table 12 *show eigrp service-family ipv6 topology Field Descriptions*

Field	Description
Codes:	State of this topology table entry. Passive and Active refer to the EIGRP state with respect to this destination; Update, Query, and Reply refer to the type of packet that is being sent.
P	Passive—No EIGRP computations are being performed for this destination.
A	Active—EIGRP computations are being performed for this destination.
U	Update—Indicates that an update packet was sent to this destination.
Q	Query—Indicates that an query packet was sent to this destination.
R	Reply—Indicates that an reply packet was sent to this destination.
r	Reply status—A flag set after the service has sent a query and is waiting for a reply.
1:2:0.0.0.3	Service number.
successors	Number of successors. Corresponds to the number of next hops in the IP routing table. If “successors” is capitalized, then the route or next hop is in a transition state.
FD	Flexible distance—The best metric to reach the destination or the best metric that was known when the service went active.

Table 12 *show eigrp service-family ipv6 topology Field Descriptions*

Field	Description
via	IP address of the peer that told the service about this destination. The first n of these entries, where n is the number of successors, is the current successors. The remaining entries in the list are feasible successors. If “all-links” or “detailed-links” is specified, the feasible successors are followed by sources that are neither successors nor feasible successors.
(46251776/46226176)	Two EIGRP metric numbers. The first number represents the cost to the destination; the second number is the metric that this peer advertised.
Ethernet0	Indicates the interface from which this information was learned.

Related Commands

Command	Description
clear eigrp service-family	Clears entries from the EIGRP neighbor table.
show eigrp service-family	Displays information about Cisco SAF IPv4 service-family Clients, External Clients, and subscriptions.
show eigrp service-family external-client	Displays information about Cisco SAF service-family External Clients.
show eigrp service-family ipv4 topology	Displays information from Cisco SAF IPv4 service-family topology table.

show eigrp tech-support

To generate a report of Enhanced Interior Gateway Routing Protocol (EIGRP) internal state information, use the **show eigrp tech-support** command in privileged EXEC mode.

show eigrp tech-support [detailed]

Syntax Description	detailed	(Optional) Displays additional detail not shown with the basic command.
--------------------	-----------------	---

Command Modes	Privileged EXEC (#)
---------------	---------------------

Command History	Release	Modification
	15.0(1)M	This command was introduced.
	12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
	12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
	Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.
	12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.

Usage Guidelines	Use the show eigrp tech-support command in privileged EXEC mode to display various internal EIGRP states.
------------------	--



Note

This command is useful for debugging and troubleshooting by Cisco technical support, but it is not intended for normal EIGRP administration tasks. This command should not be used without guidance from Cisco technical support.

Examples	The following is sample output from the show eigrp tech-support detailed command:
----------	--

```
Router# show eigrp tech-support detailed

EIGRP Internal Process States

procinfoQ:
1: 0x54ABD10 vrid:2 afi:1 as:2 tableid:0 vrfid:0 tid:0 name:
topo_ddbQ(1) 0x55243E8 tableid:0 name:base
topo_ddbQ.count: 1
procinfoQ.count: 1

deadQ:
ddbQ:
1: 0x55243E8 name:base
ddbQ.count: 1
-----
EIGRP-IPv4 Protocol for AS(2)
{vrid:2 afi:1 as:2 tableid:0 vrfid:0 tid:0 name: }
PIDs: Hello: 204 PDM: 203
```

show eigrp tech-support

```

Router-ID: 6.6.6.6
Threads: procinfo: 0x4A3EC70 ddb: 0x4A3EE50
workQ:
iidxQ: Se2/0 Se2/1 Se3/0 Et0/1
count: 4
temp_iidxQ:
passive_iidxQ: Et0/0
count: 1
peerQ:
static_peerQ:
suspendQ:
networkQ: 1.0.0.0
2.0.0.0
count: 2
summaryQ: 2.0.0.0/16 - Et0/1 (intf: 1)
1.0.0.0/8 - Et0/1 (intf: 1)
count: 2
Socket Queue: 0/2000/2/0 (current/max/highest/drops)
Input Queue: 0/2000/2/0 (current/max/highest/drops)
GRS/NSF: enabled hold-timer: 240
Active Timer: 3 min
Distance: internal 90 external 170
Max Path: 4
Max Hopcount: 100
Variance: 1
-----

```

Related Commands

Command	Description
show eigrp plugins	Displays general information including the versions of the EIGRP protocol features currently running.

shutdown (service-family)

To disable an Enhanced Interior Gateway Routing Protocol (EIGRP) service family, or all service families and address families configured for a router preventing neighbor discovery and establishment and remove all services and registered clients, use the **shutdown** command in router configuration, service-family configuration mode, or service-family interface configuration mode.

To disable neighbor discovery and establishment on an interface, use the **shutdown** command in service-family interface configuration mode. This configuration does not affect clients or any locally published (connected) services.

To reenable the service-family protocol, use the **no** form of this command.

shutdown

no shutdown

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	Service-family protocol is enabled.
------------------------	-------------------------------------

Command Modes	Router configuration (config-router) Service-family configuration (config-router-sf) Service-family interface configuration (config-router-sf-interface)
----------------------	--

Command History	Release	Modification
	15.0(1)M	This command was introduced.
	12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
	12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
	Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.
	12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.

Usage Guidelines	Use the shutdown command to disable the service-family protocol for a specific routing instance. The service-family protocol continues to run and the current service-family configurations are available; however the service-family protocol will not create any adjacencies on any interface and will clear the service-family topology database.
-------------------------	---

Examples

The following example shows the placement of the **shutdown** command for each configuration level:

```
Router(config-router)# shutdown  
Router(config-router-sf)# shutdown  
Router(config-router-sf-interface)# shutdown
```

Related Commands

Command	Description
router eigrp	Configures the EIGRP process.
sf-interface	Configures interface-specific commands under the service-family interface configuration mode.

split-horizon (EIGRP)

To enable Enhanced Interior Gateway Routing Protocol (EIGRP) split-horizon, use the **split-horizon** command in address-family interface configuration mode or service-family interface configuration mode. To disable EIGRP split-horizon, use the **no** form of this command.

split-horizon

no split-horizon

Syntax Description

This command has no arguments or keywords.

Command Default

EIGRP split-horizon is enabled by default. However, for ATM interfaces and subinterfaces **split-horizon** is disabled by default.

Command Modes

Address-family interface configuration (config-router-af-interface)
Service-family interface configuration (config-router-sf-interface)

Command History

Release	Modification
15.0(1)M	This command was introduced.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.
12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.

Usage Guidelines

The split-horizon rule prohibits a router from advertising a route through an interface that the router itself uses to reach the destination. The following are general rules for EIGRP split-horizon:

- Split-horizon behavior is turned on by default.
- When you change the EIGRP split-horizon setting on an interface, all adjacencies with EIGRP neighbors reachable over that interface are reset.
- Split-horizon should typically be disabled only on non-broadcast multi-access interfaces.
- The EIGRP split-horizon behavior is not controlled or influenced by the **ip split-horizon** command.

To configure split-horizon for an EIGRP address family, use the **split-horizon** command in address-family interface configuration mode.

To configure split-horizon for an EIGRP service family, use the **split-horizon** command in service-family interface configuration mode.

Examples

The following example disables EIGRP split-horizon for serial interface 3/0 in address-family 5400:

```
Router(config)# router eigrp virtual-name
Router(config-router)# address-family ipv4 autonomous-system 5400
Router(config-router-af)# af-interface serial3/0
Router(config-router-af-interface)# no split-horizon
```

The following example disables EIGRP split-horizon for serial interface 3/0 in service-family 5400:

```
Router(config)# router eigrp virtual-name
Router(config-router)# service-family ipv4 autonomous-system 5400
Router(config-router-sf)# sf-interface serial3/0
Router(config-router-sf-interface)# no split-horizon
```

Related Commands

Command	Description
address-family (EIGRP)	Enters address-family configuration mode to configure an EIGRP routing instance.
af-interface	Enters address-family interface configuration mode to configure interface-specific EIGRP commands.
router eigrp	Configures the EIGRP address-family process.
service-family ipv4	Configures commands under service-family configuration mode.
sf-interface	Configures interface-specific commands under service-family configuration mode.

timers graceful-restart purge-time

To set the route-hold timer to determine how long a nonstop forwarding (NSF)-aware router that is running Enhanced Interior Gateway Routing Protocol (EIGRP) will hold routes for an inactive peer, use the **timers graceful-restart purge-time** command in router configuration, address-family, or service-family configuration mode. To return the route-hold timer to the default value, use the **no** form of this command.

timers graceful-restart purge-time *seconds*

no timers graceful-restart purge-time

Syntax Description	<i>seconds</i>	Time, in seconds, for which EIGRP will hold routes for an inactive peer. The configurable time range is from 20 to 300 seconds. The default is 240 seconds.
---------------------------	----------------	---

Command Default	EIGRP NSF awareness is enabled by default. The default value for the route-hold timer is 240 seconds.
------------------------	---

Command Modes	Router configuration (config-router) Address-family configuration (config-router-af) Service-family configuration (config-router-sf)
----------------------	--

Command History	Release	Modification
	15.0(1)M	This command was introduced. This command replaces the timers nsf route-hold command.
	12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
	12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
	Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.
	12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.

Usage Guidelines	The route-hold timer sets the maximum period of time for which the NSF-aware router will hold known routes for an NSF-capable neighbor during a switchover operation or a well-known failure condition. The route-hold timer is configurable so that you can tune network performance and avoid undesired effects, such as “black holing” routes if the switchover operation takes too much time. When this timer expires, the NSF-aware router scans the topology table and discards any stale routes, allowing EIGRP peers to find alternate routes instead of waiting during a long switchover operation.
-------------------------	--

Examples

The following configuration example sets the route-hold timer value for an NSF-aware address family. In the example, the route-hold timer is set to 1 minute:

```
Router(config)# router eigrp virtual-name
Router(config-router)# address-family ipv4 autonomous-system 1
Router(config-router-af)# timers graceful-restart purge-time 60
```

The following configuration example sets the route-hold timer value for an NSF-aware service-family. In this example, the route-hold timer is set to 300 seconds:

```
Router(config)# router eigrp virtual-name
Router(config-router)# service-family ipv4 autonomous-system 4533
Router(config-router-sf)# timers graceful-restart purge-time 300
```

Related Commands

Command	Description
debug eigrp nsf	Displays EIGRP NSF-specific events in the console of a router.
debug ip eigrp notifications	Displays EIGRP events and notifications in the console of the router.
show eigrp neighbors	Displays the neighbors discovered by IP EIGRP.
show ip protocols	Displays the parameters and current state of the active routing protocol process.

topology

To configure topology-specific commands for an Enhanced Interior Gateway Routing Protocol (EIGRP) service family, use the **topology** command in service-family interface configuration mode. To disable the service-family topology configuration mode, use the **no** form of this command.

topology {base}

no topology {base}

Syntax Description

base	Configures the base topology.
-------------	-------------------------------

Command Modes

Service-family configuration (config-router-sf)

Command History

Release	Modification
15.0(1)M	This command was introduced.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.
12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.

Usage Guidelines

Use the **topology** command to configure Cisco SAF for multitopology networks.



Note

In Cisco IOS Release 15.0(1)M, only the base topology is supported.

Use the **show eigrp service-family ipv4 topology** command to verify the topology base configuration.

Examples

The following example configures the base topology:

```
Router(config)# router eigrp virtual-name
Router(config-router)# service-family ipv4 autonomous-system 4533
Router(config-router-sf)# sf-interface default
Router(config-router-sf-interface)# no shutdown
Router(config-router-sf-interface)# exit-sf-interface
Router(config-router-sf)# topology base
```

Related Commands	Command	Description
	exit-service-family	Exits service-family configuration mode.
	exit sf-interface	Exits service-family interface configuration mode.
	router eigrp	Configures the EIGRP process.
	sf-interface	Configures interface-specific commands under the service-family interface configuration mode.
	show eigrp service-family ipv4 topology	Displays information on EIGRP service-family IPv4 topologies.
	shutdown	Disables service family on the interface.

username (SAF)

To configure username for a Cisco SAF External-Client, use the **username** command in external-client label configuration mode. To negate the username, use the **no** form of this command.

username *name*

no username *name*

Syntax Description

<i>name</i>	Specifies the name for the external client between 1 and 64 characters.
-------------	---

Command Modes

External-client label configuration (config-external-client-mode)

Command History

Release	Modification
15.0(1)M	This command was introduced.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
12.2(33)XNE	This command was integrated into Cisco IOS Release 12.2(33)XNE.
Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.
12.2(33)SX14	This command was integrated into Cisco IOS Release 12.2(33)SX14.

Usage Guidelines

Use the **username** command to configure Cisco SAF External Clients. Entering a new username value overwrites the old value, but the new value will only take affect after the Cisco SAF External Client re-registers.

Use the **show eigrp service-family ipv4 external-client** command to verify the Cisco SAF External Client configuration.

Examples

The following example configures a Cisco SAF External Client named example:

```
Router(config)# service-family external-client listen ipv4 2444
Router(config-external-client)# external-client example
Router(config-external-client-mode)# username example
```

Related Commands

Command	Description
external-client	Configures Cisco SAF External Clients.
service-family external-client listen	Configures Cisco SAF External Client listen TCP ports.
show eigrp service-family ipv4 external-client	Displays information on Cisco SAF External Clients.