



Enabling Network Virtualization Satellite Mode on the Cisco ASR 903 Router

January 2013

OL-28667-01

This document describes how to enable Network Virtualization Satellite Mode on the Cisco ASR 903 Router and contains the following sections:

- [Overview, page 1](#)
- [Limitations, page 1](#)
- [Installing a Satellite Image on the Cisco ASR 903 Router, page 2](#)
- [Removing a Satellite Image from the Cisco ASR 903 Router, page 3](#)
- [Satellite Mode Configuration Sequence, page 3](#)
- [Upgrading the Satellite Image, page 3](#)
- [Services and Support, page 3](#)

Overview

The Satellite Network Virtualization (nV) feature allows you to configure remote routers to act as remote virtual switch interfaces on the ASR 9000. IOS XE Release 3.8 introduces support for nV mode on the Cisco ASR 903 Router, allowing it to act as a satellite nV device, controlled by the ASR 9000 using the IOS XR CLI.

Limitations

The following limitations apply when enabling nV satellite mode on the Cisco ASR 903 Router.

- An in-service software upgrade (ISSU) is not supported while the router is acting as an nV satellite device.
- RSP redundancy is not supported while the router is acting as a satellite nV device.



Americas Headquarters:

Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA

- Online Insertion and Removal (OIR) of interface modules (IMs) is not supported when the router is operating in nV satellite mode.
- Supported connections to the satellite host include
 - Gigabit Ethernet interfaces
 - Ethernet transported over optical interfaces
 - 10 Gigabit Ethernet interfaces (slots 1 and 2 only)
 Other connection types are not supported.
- Local switching on the satellite device is not supported. The packets are always sent to the host for layer 2 and layer 3 switching.
- Network clocking is not supported when the router is operating in nV satellite mode.
- Reverting from a satellite mode image to the base image requires that you download the original image using TFTP; an inband download is not supported. For more information, see [Removing a Satellite Image from the Cisco ASR 903 Router, page 3](#).

Installing a Satellite Image on the Cisco ASR 903 Router

Follow these steps to install a satellite nV image on the Cisco ASR 903 Router.

-
- Step 1** Download a Cisco ASR 903 Router satellite nV image from Cisco.com and copy the image to a TFTP server.
- Step 2** Create a console connection to the management port of the Cisco ASR 903 Router. For more information about creating a console connection, see [Cisco ASR 903 Series Aggregation Services Router Hardware Installation Guide](#).
- Step 3** Copy nV compatible binary image to flash or bootflash.
- ```
Router# copy
tftp://10.10.10.10//tftpboot//asr903rsp1_sat-universalk9_npe.03.08.00.S.153-1.S.bin
bootflash:
```
- Step 4** Set the configuration register to 0x2042.
- ```
Router(config)# config-register 0x2042
```
- Step 5** Erase the existing configuration.
- ```
Router# write erase
```
- Step 6** Specify the boot image.
- ```
Router(config)# boot system boot-
flash:asr903rsp1_sat-universalk9_npe.03.08.00.S.153-1.S.bin
```
- Step 7** Save the configuration.
- ```
Router# copy running-configuration startup-configuration
```
- Step 8** Reload the router
- ```
Router(config)# reload
```
- The system boots in nV mode and is detectable by the nV host.

**Note**

You can use the **show nv satellite status** command to verify the image version.

Removing a Satellite Image from the Cisco ASR 903 Router

Restoring the Cisco ASR 903 Router to a normal IOS XE image requires that you load an image in ROMmon mode using trivial file transfer protocol (TFTP). For instructions on how to remove a satellite image from the Cisco ASR 903 Router, please contact Cisco support.

Satellite Mode Configuration Sequence

When booting to a satellite nV image, the Cisco ASR 903 Router

- enables Ethernet ports in IEEE mode.
- enables inter-chassis links (IC links).
- uses Satellite Discovery and Control (SDAC) to establish a connection to the host nV device.
- establishes a control path between the host nV device and the Cisco ASR 903 Router.

Once the connection is established, the ASR 9000 provides an IP address, software, and configuration commands to the Cisco ASR 903 Router. For instructions on configuring Satellite nV on the ASR 9000 and managing satellite nV devices, see [Configuring the Satellite Network Virtualization \(nV\) System on the Cisco ASR 9000 Series Router](#).

Upgrading the Satellite Image

After you connect the satellite to the host, the host verifies the satellite software version. If there is a version mismatch, the host displays a syslog notification indicating that the satellite device requires an image upgrade. To upgrade the image using the host satellite device, see [Configuring the Satellite Network Virtualization \(nV\) System on the Cisco ASR 9000 Series Router](#).

Use the **show nv satellite status** command to verify the image version.

Services and Support

For information on obtaining documentation, obtaining support, providing documentation feedback, security guidelines, and also recommended aliases and general Cisco documents, see the monthly *What's New* in Cisco Product Documentation, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

© 2013, Cisco Systems, Inc. All rights reserved.

