



Generic Routing Encapsulation Commands

This module describes the commands used to configure generic routing encapsulation (GRE).

For detailed information about GRE concepts, configuration tasks, and examples, refer to the *Cisco IOS XR Virtual Private Network Configuration Guide for the Cisco CRS Router*.

- [interface tunnel-ip, page 2](#)
- [keepalive, page 3](#)
- [tunnel destination, page 4](#)
- [tunnel dfbit disable, page 6](#)
- [tunnel mode, page 8](#)
- [tunnel source, page 10](#)
- [tunnel tos, page 12](#)
- [tunnel ttl, page 14](#)

interface tunnel-ip

To configure a tunnel interface, use the **interface tunnel-ip** command in the interface global configuration mode. To disable this feature, use the **no** form of this command.

interface tunnel-ip *number*

no interface tunnel-ip *number*

Syntax Description

| | |
|---------------|--|
| <i>number</i> | Specifies the instance number of the interface to be configured. |
|---------------|--|

Command Default

None

Command Modes

interface configuration

Command History

| Release | Modification |
|---------------|------------------------------|
| Release 3.9.0 | This command was introduced. |

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes the proper task IDs. If you suspect user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **interface tunnel-ip** command to enter the interface global configuration mode.

Task ID

| Task ID | Operations |
|-----------|-------------|
| interface | read, write |

Examples

This example shows how to configure a tunnel interface:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-ip 400
RP/0/RP0/CPU0:router(config-if)#
```

keepalive

To enable keepalive for a tunnel interface, use the **keepalive** command. To remove keepalive, use the **no** form of this command.

keepalive [*time_in_seconds* [*retry_num*]]

no keepalive

Syntax Description

| | |
|------------------------|--|
| <i>time_in_seconds</i> | Specifies the frequency (in seconds) at which keepalive check is performed. The default is 10 seconds. The minimum value is 1 second. |
| <i>retry_num</i> | Specifies the number of keepalive retries before declaring that a tunnel destination is unreachable. The default is 3 retries. The minimum value is 1 retry. |

Command Default

None

Command Modes

interface configuration

Command History

| Release | Modification |
|---------------|------------------------------|
| Release 3.9.0 | This command was introduced. |

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes the proper task IDs. If you suspect user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **keepalive** command to enable keepalive for a tunnel interface.

Task ID

| Task ID | Operations |
|-----------|-------------|
| interface | read, write |

Examples

The following example shows how to configure interface tunnel:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-ip 400
RP/0/RP0/CPU0:router(config-if)# keepalive 30
```

tunnel destination

To specify a tunnel interface's destination, use the **tunnel destination** command. To remove the destination, use the **no** form of this command.



Note

The tunnel will not be operational until the tunnel destination is specified.

tunnel destination *A.B.C.D*

no tunnel destination *A.B.C.D*

Syntax Description

| | |
|----------------|---|
| <i>A.B.C.D</i> | Specifies the IPv4 address of the host destination. |
|----------------|---|

Command Default

None

Command Modes

interface configuration

Command History

| Release | Modification |
|---------------|------------------------------|
| Release 3.9.0 | This command was introduced. |

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes the proper task IDs. If you suspect user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

| Task ID | Operations |
|-----------|-------------|
| interface | read, write |

Examples

The following example shows how to configure interface tunnel:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-ip 400
RP/0/RP0/CPU0:router(config-if)# tunnel destination 10.10.10.1
```

Related Commands

| Command | Description |
|---|---|
| tunnel dfbit disable , page 6 | Configures the DF bit setting in the tunnel transport header. |

| Command | Description |
|--|---|
| tunnel mode, page 8 | Sets the encapsulation mode of the tunnel interface. |
| tunnel source, page 10 | Sets a tunnel interface's source address. |
| tunnel tos, page 12 | Specifies the value of the TOS field in the tunnel encapsulating packets. |
| tunnel ttl, page 14 | Configures the Time-To-Live (TTL) for packets entering the tunnel. |

tunnel dfbit disable

To configure the DF bit setting in the tunnel transport header, use the **tunnel dfbit disable** command. To revert to the default DF bit setting value, use the **no** form of this command.

tunnel dfbit disable

no tunnel dfbit disable

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes interface configuration

| Command History | Release | Modification |
|-----------------|---------------|------------------------------|
| | Release 3.9.0 | This command was introduced. |

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes the proper task IDs. If you suspect user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **tunnel dfbit disable** command specifies the DF bit setting in the tunnel transport header. The default is to always set the DF bit. Hence, use the **tunnel dfbit disable** command to override the default.

| Task ID | Task ID | Operations |
|---------|-----------|-------------|
| | interface | read, write |

Examples The following example shows how to configure interface tunnel:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-ip 400
RP/0/RP0/CPU0:router(config-if)# tunnel dfbit disable
```

| Related Commands | Command | Description |
|------------------|--|--|
| | tunnel destination, page 4 | Specifies a tunnel interface's destination. |
| | tunnel mode, page 8 | Sets the encapsulation mode of the tunnel interface. |
| | tunnel source, page 10 | Sets a tunnel interface's source address. |

| Command | Description |
|-------------------------------------|---|
| tunnel tos, page 12 | Specifies the value of the TOS field in the tunnel encapsulating packets. |
| tunnel ttl, page 14 | Configures the Time-To-Live (TTL) for packets entering the tunnel. |

tunnel mode

To set the encapsulation mode of the tunnel interface, use the **tunnel mode** command. To remove the encapsulation mode, use the **no** form of this command.



Note

The tunnel will not be operational until the encapsulation mode is specified. Only one mode can be specified for a tunnel instance at any given time.

tunnel mode gre ipv4

no tunnel mode

Syntax Description

This command has no arguments or keywords.

Command Default

Disabled

Command Modes

interface configuration

Command History

| Release | Modification |
|---------------|------------------------------|
| Release 3.9.0 | This command was introduced. |

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes the proper task IDs. If you suspect user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

| Task ID | Operations |
|-----------|-------------|
| interface | read, write |

Examples

The following example shows how to configure interface tunnel:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-ip 400
RP/0/RP0/CPU0:router(config-if)# tunnel mode gre ipv4
```

Related Commands

| Command | Description |
|---|---|
| tunnel dfbit disable , page 6 | Configures the DF bit setting in the tunnel transport header. |

| Command | Description |
|--|---|
| tunnel destination, page 4 | Specifies a tunnel interface's destination. |
| tunnel source, page 10 | Sets a tunnel interface's source address. |
| tunnel tos, page 12 | Specifies the value of the TOS field in the tunnel encapsulating packets. |
| tunnel ttl, page 14 | Configures the Time-To-Live (TTL) for packets entering the tunnel. |

tunnel source

To set a tunnel interface's source address, use the **tunnel source** command. To remove the source address, use the **no** form of this command.



Note

The tunnel will not be operational until the tunnel source is specified.

tunnel source {interface_name| A.B.C.D}

no tunnel source {interface_name| A.B.C.D}

Syntax Description

| | |
|-----------------------|---|
| <i>interface_name</i> | Specifies the name of the interface whose IP address will be used as the source address of the tunnel. The interface name can be of a loopback interface or a physical interface. |
| <i>A.B.C.D</i> | Specifies the IPv4 address to use as the source address for packets in the tunnel. |

Command Default

None

Command Modes

interface configuration

Command History

| Release | Modification |
|---------------|------------------------------|
| Release 3.9.0 | This command was introduced. |

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes the proper task IDs. If you suspect user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

| Task ID | Operations |
|-----------|-------------|
| interface | read, write |

Examples

The following example shows how to configure interface tunnel:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-ip 400
RP/0/RP0/CPU0:router(config-if)# tunnel source 10.10.10.1
```

Related Commands

| Command | Description |
|--|---|
| tunnel destination, page 4 | Specifies a tunnel interface's destination. |
| tunnel dfbit disable, page 6 | Configures the DF bit setting in the tunnel transport header. |
| tunnel mode, page 8 | Sets the encapsulation mode of the tunnel interface. |
| tunnel tos, page 12 | Specifies the value of the TOS field in the tunnel encapsulating packets. |
| tunnel ttl, page 14 | Configures the Time-To-Live (TTL) for packets entering the tunnel. |

tunnel tos

To specify the value of the TOS field in the tunnel encapsulating packets, use the **tunnel tos** command. To revert to the default TOS value, use the **no** form of this command.

tunnel tos *tos_value*

no tunnel tos *tos_value*

Syntax Description

| | |
|------------------|--|
| <i>tos_value</i> | Specifies the value of the TOS field in the tunnel encapsulating packets. The TOS value ranges between 0 to 255. |
|------------------|--|

Command Default

Copies the TOS/COS bits of the internal IP header to the GRE IP header. In case of labeled payload, EXP bits are copied to TOS bits of the GRE IP header.

Command Modes

interface configuration

Command History

| Release | Modification |
|---------------|------------------------------|
| Release 3.9.0 | This command was introduced. |

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes the proper task IDs. If you suspect user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

| Task ID | Operations |
|-----------|-------------|
| interface | read, write |

Examples

The following example shows how to configure interface tunnel:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-ip 400
RP/0/RP0/CPU0:router(config-if)# tunnel tos 100
```

Related Commands

| Command | Description |
|---|---|
| tunnel destination , page 4 | Specifies a tunnel interface's destination. |
| tunnel dfbit disable , page 6 | Configures the DF bit setting in the tunnel transport header. |
| tunnel mode , page 8 | Sets the encapsulation mode of the tunnel interface. |

| Command | Description |
|--|--|
| tunnel source, page 10 | Sets a tunnel interface's source address. |
| tunnel ttl, page 14 | Configures the Time-To-Live (TTL) for packets entering the tunnel. |

tunnel ttl

To configure the Time-To-Live (TTL) for packets entering the tunnel, use the **tunnel ttl** command. To revert to the default TTL value, use the **no** form of this command.

tunnel ttl *ttl_value*

no tunnel ttl *ttl_value*

Syntax Description

| | |
|------------------|--|
| <i>ttl_value</i> | Specifies the value of TTL for packets entering the tunnel. The TTL value ranges between 1 to 255. |
|------------------|--|

Command Default

The default TTL value is set to 255.

Command Modes

interface configuration

Command History

| Release | Modification |
|---------------|------------------------------|
| Release 3.9.0 | This command was introduced. |

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes the proper task IDs. If you suspect user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

This command specifies the Time-To-Live for packets entering the tunnel so that the packets are not dropped inside the carrier network before reaching the tunnel destination.

Task ID

| Task ID | Operations |
|-----------|-------------|
| interface | read, write |

Examples

The following example shows how to configure interface tunnel:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-ip 400
RP/0/RP0/CPU0:router(config-if)# tunnel source 10.10.10.1
```

Related Commands

| Command | Description |
|---|---|
| tunnel destination , page 4 | Specifies a tunnel interface's destination. |

| Command | Description |
|--|---|
| tunnel dfbit disable, page 6 | Configures the DF bit setting in the tunnel transport header. |
| tunnel mode, page 8 | Sets the encapsulation mode of the tunnel interface. |
| tunnel tos, page 12 | Specifies the value of the TOS field in the tunnel encapsulating packets. |
| tunnel source, page 10 | Sets a tunnel interface's source address. |

 tunnel ttl