



## RCMD Commands

---

This module describes the commands used to configure and diagnose RCMD.

For detailed information about RCMD concepts, configuration tasks, and examples, see the *Implementing RCMD* module in the *Routing Configuration Guide for Cisco NCS 6000 Series Routers*.

- [router-convergence](#), page 2
- [monitor-convergence \(IS-IS\)](#), page 4
- [monitor-convergence \(OSPF\)](#), page 6
- [collect-diagnostics \(RCMD\)](#), page 7
- [event-buffer-size \(RCMD\)](#), page 9
- [max-events-stored \(RCMD\)](#), page 11
- [monitoring-interval \(RCMD\)](#), page 13
- [node disable \(RCMD\)](#), page 15
- [priority \(RCMD\)](#), page 17
- [protocol \(RCMD\)](#), page 19
- [storage-location](#), page 21

# router-convergence

To configure route convergence monitoring and enter router convergence monitoring and diagnostics (rcmd) configuration mode, use the **router-convergence** command in XR Config mode. To remove all router convergence monitoring configurations and exit the rcmd mode, use the **no** form of this command.

**router-convergence [disable]**

**no router-convergence**

Syntax Description	disable	[Optional] Disables the monitoring of route convergence on the entire router.
--------------------	---------	---

**Command Default** RCMD is disabled.

**Command Modes** XR Config

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	rcmd	read, write

**Examples** This example shows how to configure router-convergence command and enable rcmd configuration mode:

```
RP/0/RP0/CPU0:router#configure
RP/0/RP0/CPU0:router(config)#router-convergence
RP/0/RP0/CPU0:router(config-rcmd)#
```

Related Commands	Command	Description
	<a href="#">monitor-convergence (IS-IS)</a> , <a href="#">on page 4</a>	Enables route convergence monitoring for IS-IS protocol.

Command	Description
<a href="#">monitor-convergence (OSPF), on page 6</a>	Enables OSPF route convergence monitoring.

# monitor-convergence (IS-IS)

To enable route convergence monitoring for IS-IS protocol, use the **monitor-convergence** command in address family configuration mode. To disable, route convergence monitoring, use the **no** form of this command.

**monitor-convergence**

**no monitor-convergence**

**Syntax Description** This command has no keywords or arguments.

**Command Default** Route convergence monitoring is disabled.

**Command Modes**

- Address family IPv4 unicast
- Address family IPv4 multicast
- Address family IPv6 unicast
- Address family IPv6 multicast

Release	Modification
Release 5.0.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Operation
isis	read, write

**Examples** This example shows how to configure route convergence monitoring for IS-IS under IPv6 multicast SAFI:

```
RP/0/RP0/CPU0:router#configure
RP/0/RP0/CPU0:router(config)#router isis isp
RP/0/RP0/CPU0:router(config-isis)#address-family ipv6 multicast
RP/0/RP0/CPU0:router(config-isis-af)#monitor-convergence
```

**Related Commands**

Command	Description
<a href="#">router-convergence</a> , <a href="#">on page 2</a>	Configures route convergence monitoring and enters router convergence monitoring and diagnostics (rcmd) configuration mode.
<a href="#">monitor-convergence (OSPF)</a> , <a href="#">on page 6</a>	Enables OSPF route convergence monitoring.

# monitor-convergence (OSPF)

To enable OSPF route convergence monitoring, use the **monitor-convergence** command in router OSPF configuration mode. To disable OSPF route convergence monitoring, use the **no** form of this command.

**monitor-convergence**

**no monitor-convergence**

**Syntax Description** This command has no keywords or arguments.

**Command Default** Monitor Convergence is disabled.

**Command Modes** Router configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	ospf	read, write

**Examples** This example shows how to enable route convergence monitoring for an OSPF process:

```
RP/0/RP0/CPU0:router#configure
RP/0/RP0/CPU0:router(config)#router ospf 100
RP/0/RP0/CPU0:router(config-ospf)#monitor-convergence
```

Related Commands	Command	Description
	<a href="#">router-convergence</a> , on page 2	Configures route convergence monitoring and enters router convergence monitoring and diagnostics (rcmd) configuration mode.
	<a href="#">monitor-convergence (IS-IS)</a> , on page 4	Enables route convergence monitoring for IS-IS protocol.

# collect-diagnostics (RCMD)

To collect diagnostics on specified node, use the **collect-diagnostic** command in router-convergence configuration mode. To disable collection of diagnostics, use the **no** form of this command.

**collect-diagnostics** *location*

**no collect-diagnostics** *location*

## Syntax Description

<i>location</i>	Specifies the line-card location.
-----------------	-----------------------------------

## Command Default

Diagnostics collection is disabled.

## Command Modes

Router-convergence configuration

## Command History

Release	Modification
Release 5.0.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

For enabling diagnostics collection on specific line-card locations, you can user can specify partially qualified semantics. However, it is not allowed to configure over-lapping locations so as to avoid errors. The following combinations of Rack and Slot are accepted:

- \*/\*/\*
- R/\*/\*
- R/S/\*

If a wildcard combination for any location is already disabled, then any other combination that overlaps with it would be rejected. For example,

- If \*/\*/\* is disabled, then all other disable commands will be rejected
- If R/\*/\* is disabled, then disable for \*/\*/\* and R/S/\* will be rejected
- If R/S/\* is disabled, then disable for \*/\*/\* and R/\*/\* will be rejected

**Task ID**

Task ID	Operation
rcmd	read, write

**Examples**

This example shows how to enable RCMD diagnostics collection on node 0/3/CPU0:

```
RP/0/RP0/CPU0:router#configure
RP/0/RP0/CPU0:router#router-convergence
RP/0/RP0/CPU0:router(config-rcmd)#collect-diagnostics 0/3/CPU0
```

**Related Commands**

Command	Description
<a href="#">router-convergence, on page 2</a>	Configures route convergence monitoring and enters router convergence monitoring and diagnostics (rcmd) configuration mode.



## event-buffer-size (RCMD)

To specify event buffer size (in terms of number of events) for storing event traces, use the **event-buffer-size** command in router-convergence configuration mode. To disable buffer size configuration, use the **no** form of this command.

**event-buffer-size** *number*

**no event-buffer-size**

<b>Syntax Description</b>	<i>number</i>	Specifies the Specify the number of events. The range is 100 to 500.
---------------------------	---------------	--

<b>Command Default</b>	100 events.
------------------------	-------------

<b>Command Modes</b>	Router-convergence configuration
----------------------	----------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.0.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
	The event-buffer-size configuration controls the ltrace buffer size. Ltraces will be stored for only the configured number of events. The default is 100 events and can be set based on the expected churn in the network. Value for event buffer impact memory usage on all RPs and monitored LCs.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	rcmd	read, write

<b>Examples</b>	This example shows how to configure event buffer size as 500 events:
	RP/0/RP0/CPU0:router# <b>configure</b>
	RP/0/RP0/CPU0:router (config)# <b>router-convergence</b>
	RP/0/RP0/CPU0:router (config-rcmd)# <b>event-buffer-size 500</b>

**Related Commands**

Command	Description
<a href="#">router-convergence</a> , on page 2	Configures route convergence monitoring and enters router convergence monitoring and diagnostics (rcmd) configuration mode.

## max-events-stored (RCMD)

To configure maximum number of events to be stored in the RCMD server, use the **max-events-stored** command in router-convergence configuration mode. To remove the number of events to be stored, use the **no** form of this command.

**max-events-stored** *number*

### Syntax Description

<i>number</i>	Specifies the maximum number of events stored. The range is 10 to 500.
---------------	--

### Command Default

100 events.

### Command Modes

Router-convergence configuration

### Command History

Release	Modification
Release 5.0.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The max-events-stored configuration controls the number of events that are stored in RCMD server, before the older events are deleted. The default is 100 events and can be set based on the expected churn in the network. Value for events stored impact memory usage by RCMD server.

### Task ID

Task ID	Operations
rcmd	read, write

### Examples

This example shows how to configure 500 number of events to be stored in RCMD server:

```
RP/0/RP0/CPU0:router#configure
RP/0/RP0/CPU0:router(config)#router-convergence
RP/0/RP0/CPU0:router(config-rcmd)#max-events-stored 500
```

**Related Commands**

Command	Description
<a href="#">router-convergence</a> , <a href="#">on page 2</a>	Configures route convergence monitoring and enters router convergence monitoring and diagnostics (rcmd) configuration mode.

## monitoring-interval (RCMD)

To configure interval (in minutes) in which to collect logs, use the **monitoring-interval** command in router-convergence configuration mode. To disable monitoring interval configuration, use the **no** form of this command.

**monitoring-interval** *minutes*

**no monitoring-interval** *minutes*

### Syntax Description

<i>minutes</i>	Specifies the interval (in minutes) for collecting logs. The range is 5 to 120 minutes.
----------------	---

### Command Default

Periodic monitoring interval is 15 minutes.

### Command Modes

Router-convergence configuration

### Command History

Release	Modification
Release 5.0.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The monitoring-interval timer controls the collection, processing, and archival (optional) of convergence data by RCMD server.

Periodic processing can get triggered if number of events detected exceed configured sizing parameters to prevent loss of data . However, this is not guaranteed since the mechanism is throttled.

To collect logs manually, use the **rcmd trigger-data-collect** command. Syslogs are generated when high churn is detected and collection mechanism is getting throttled. This indicates possible loss of data for some events. Throttling mechanism is for one processing every minute.

### Task ID

Task ID	Operations
rcmd	read, write

### Examples

This example shows how to configure monitoring interval as 5 minutes:

```
RP/0/RP0/CPU0:router#configure
RP/0/RP0/CPU0:router(config)#router-convergence
RP/0/RP0/CPU0:router(config-rcmd)#monitoring-interval 5
```

### Related Commands

Command	Description
<a href="#">router-convergence</a> , on page 2	Configures route convergence monitoring and enters router convergence monitoring and diagnostics (rcmd) configuration mode.

## node disable (RCMD)

To disable monitoring of route convergence on specified location, use the **node disable** command in router-convergence configuration mode. To reinstate, monitoring on specified location, use the **no** form of this command.

**node** *node-id* **disable**

**no** **node** *node-id* **disable**

### Syntax Description

<i>node-id</i>	Specifies line card locations for which RCMD monitoring be disabled. Disables RCMD monitoring on the specified node. No data from this node will be available in the reports that are generated. You can enter specific LCs or use wild cards.
----------------	--

### Command Default

Update times are gathered and reported for all LCs. Diagnostic mode is disabled on all LCs.

### Command Modes

Router-convergence configuration

### Command History

Release	Modification
Release 5.0.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Disable monitoring on specific LCs or racks for better scalability. Disable monitoring on LCs whose update times is not going to impact the core IGP/LDP convergence that RCMD is measuring.

On LCs where monitoring is enabled, the diagnostic mode can be enabled (with threshold value) for triggering script using EEM infra for debug data collection from the router. Use diagnostic mode only for debugging purpose since it is more CPU intensive as compared to normal RCMD monitoring.

Only the following combinations of Rack and Slot are acceptable:

- \*/\*/\*
- R/\*/\*
- R/S/\*

If a wildcard combination for any location is already disabled, then any other combination that overlaps with it would be rejected. For example,

- If \*/\*/\* is disabled, then all other disable commands would be rejected

- If R/\*/\* is disabled, then disable for \*/\*/\* and R/S/\* would be rejected
- If R/S/\* is disabled, then disable for \*/\*/\* and R/\*/\* would be rejected

**Task ID**

Task ID	Operations
rcmd	read, write

**Examples**

This example shows how to disable monitoring on all nodes with Rack 0 and any slot (used wild card \*) :

```
RP/0/RP0/CPU0:router#configure
RP/0/RP0/CPU0:router(config)#router-convergence
RP/0/RP0/CPU0:router(config-rcmd)#node 0/*/* disable
```

**Related Commands**

Command	Description
<a href="#">router-convergence, on page 2</a>	Configures route convergence monitoring and enters router convergence monitoring and diagnostics (rcmd) configuration mode.



## priority (RCMD)

To configure RCMD reporting parameters for low/high/critical/medium priority updates, use the **priority** command in RCMD protocol configuration mode. To disable setting up priority use the **no** form of this command.

**priority** {Critical| High| Low| Medium} [disable] [leaf-network *leaf-network-number*] [threshold *value*]  
**no priority** {Critical| High| Low| Medium}

### Syntax Description

<b>Critical</b>	Configures the monitoring of route convergence for critical routes.
<b>High</b>	Configures the monitoring of route convergence for high priority routes.
<b>Low</b>	Configures the monitoring of route convergence for low priority routes.
<b>Medium</b>	Configures the monitoring of route convergence for medium priority routes.
<b>disable</b>	Disables the monitoring of route convergence for specified priority.
<b>leaf-network</b>	Configures the monitoring of route convergence for leaf networks. Lists up to 100 leaf networks that were added or deleted as part of SPF.
<i>leaf-network-number</i>	Specifies the maximum number of leaf networks monitored. The range is 10 to 100.
<b>threshold</b>	Sets the threshold value for convergence in milliseconds. If the convergence time exceeds this configured value, diagnostics collection will be triggered.
<i>value</i>	Specifies the threshold value (in msec). The range is 0 to 4294967295.

### Command Default

None

### Command Modes

Router-convergence protocol configuration

### Command History

Release	Modification
Release 5.0.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **priority** command for collecting data and applying threshold for particular protocol and prefix priority. Maximum of 100 leaf networks can get logged because of scalability reasons. No default value available for threshold and this needs to be determined with deployment experience for specific network. Threshold specification is required for triggering diagnostics collection. Disable monitoring for medium and or low priority routes to help scale better. No specific order is guaranteed for leaf networks and first N prefixes that change are logged.

**Task ID**

Task ID	Operations
rcmd	read, write

**Examples**

This example shows how Configures the monitoring of route convergence for critical routes for 100 leaf networks and at a threshold value of 1 millisecond for OSPF protocol:

```
RP/0/RP0/CPU0:router#configure
RP/0/RP0/CPU0:router(config)#router-convergence
RP/0/RP0/CPU0:router(config-rcmd)#protocol OSPF
RP/0/RP0/CPU0:router(config-rcmd-proto)#priority high
RP/0/RP0/CPU0:router(config-rcmd-proto-prio)#leaf-network 100
RP/0/RP0/CPU0:router(config-rcmd-proto-prio)#threshold 1
```

**Related Commands**

Command	Description
<a href="#">router-convergence, on page 2</a>	Configures route convergence monitoring and enters router convergence monitoring and diagnostics (rcmd) configuration mode.

## protocol (RCMD)

To specify the protocol for which to configure RCMD parameters, use the **protocol** command in router-convergence configuration mode. To remove the protocol from RCMD, use the **no** form of this command.

**protocol** {ISIS| OSPF}

**no protocol** {ISIS| OSPF}

### Syntax Description

<b>ISIS</b>	Configures parameters related to OSPF protocol within RCMD
<b>OSPF</b>	Configures parameters related to IS-IS protocol within RCMD

### Command Default

None

### Command Modes

Router-convergence configuration

### Command History

Release	Modification
Release 5.0.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

RCMD monitoring needs to be enabled for a specific OSPF or ISIS protocol instance.

### Task ID

Task ID	Operations
rcmd	read, write

### Examples

This example shows how to enable RCMD parameters for OSPF protocol:

```
RP/0/RP0/CPU0:router(config)#router
RP/0/RP0/CPU0:router(config)#router-convergence
RP/0/RP0/CPU0:router(config-rcmd)#protocol OSPF
RP/0/RP0/CPU0:router(config-rcmd-proto)#priority high
RP/0/RP0/CPU0:router(config-rcmd-proto-prio)#leaf-network 100
RP/0/RP0/CPU0:router(config-rcmd-proto-prio)#threshold 1
```

**Related Commands**

Command	Description
<a href="#">router-convergence</a> , on page 2	Configures route convergence monitoring and enters router convergence monitoring and diagnostics (rcmd) configuration mode.

## storage-location

To specify where to store the extended routing-diagnostics that are collected when threshold exceeds, use the **storage-location** command in router-convergence configuration mode. To disable storing routing-diagnostics to a specific location, use the **no** form of this command.

**storage-location** [**diagnostics** *directory-path* | **diagnostics-size** *maximum-directory-size* | **reports** *directory-path* | **reports-size** *maximum-directory-size*]

**no storage-location**

### Syntax Description

<b>diagnostics</b>	Specifies an absolute directory path for storing diagnostic reports.
<i>directory-path</i>	Specifies the path of the absolute directory for storing diagnostic reports.
<b>diagnostics-size</b>	Specifies the maximum size of diagnostics directory.
<i>maximum-directory-size</i>	Specified the size of the diagnostics directory. The range is 5% to 80%.
<b>reports</b>	Specifies an absolute directory path for storing reports.
<i>directory-path</i>	Specifies the path of the absolute directory for storing reports.
<b>reports-size</b>	Specifies the maximum size of the reports directory. The range is 5% to 80%.

### Command Default

No default storage location. Mechanism is disabled.

### Command Modes

Router-convergence configuration

### Command History

Release	Modification
Release 5.0.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The storage location can be local disk or remote tftp space.

RCMD server can periodically archive reports in XML format for persistency. This mechanism is enabled when archival location is configured. Debug data collected in diagnostics mode is dumped to the configured diagnostic location (else it would get lost). When using local disk, the percentage of disk space to be used can

be specified, and RCMD server will delete older reports on reaching the limit. Archival (specifically on local disk) is CPU intensive. Use a remote XML server to periodically collect reports from the router and archive on the server's local storage.

### Task ID

Task ID	Operations
rcmd	read, write

### Examples

This example shows how to configure storage location as *tftp://202.153.144.25/auto/tftp-chanvija-blr/rcmd/dump/reports* for reports and */harddisk:/rcmd\_logs* for diagnostics:

```
RP/0/RP0/CPU0:router#configure
RP/0/RP0/CPU0:router(config)#router-convergence
RP/0/RP0/CPU0:router(config-rcmd)#storage-location
RP/0/RP0/CPU0:router(config-rcmd-store)#diagnostics /harddisk:/rcmd_logs
RP/0/RP0/CPU0:router(config-rcmd-store)#reports
tftp://202.153.144.25/auto/tftp-chanvija-blr/rcmd/dump/reports
```

### Related Commands

Command	Description
<a href="#">router-convergence, on page 2</a>	Configures route convergence monitoring and enters router convergence monitoring and diagnostics (rcmd) configuration mode.