

Keychain Management Commands

This module describes the commands used to configure keychain management.

For detailed information about keychain management concepts, configuration tasks, and examples, see the *Implementing Keychain Management on* configuration module in the *System Security Configuration Guide for Cisco NCS 6000 Series Routers*.

- [accept-lifetime](#), page 1
- [accept-tolerance](#), page 3
- [key \(key chain\)](#), page 4
- [key chain \(key chain\)](#), page 5
- [key-string \(keychain\)](#), page 6
- [send-lifetime](#), page 8
- [show key chain](#), page 10

accept-lifetime

To set the time period during which the authentication key on a keychain is received as valid, use the **accept-lifetime** command in key configuration mode. To revert to the default value, use the **no** form of this command.

accept-lifetime *start-time* [**duration** *duration value*| **infinite**| *end-time*]

no accept-lifetime *start-time* [**duration** *duration value*| **infinite**| *end-time*]

Syntax Description	
<i>start-time</i>	Start time, in <i>hh:mm:ss day month year</i> format, in which the key becomes valid. The range is from 0:0:0 to 23:59:59. The range for the number of days of the month is from 1 to 31. The range for the years is from 1993 to 2035.
duration <i>duration value</i>	(Optional) Determines the lifetime of the key in seconds. The range is from 1-2147483646.

accept-lifetime

infinite	(Optional) Specifies that the key never expires after it becomes valid.
<i>end-time</i>	(Optional) Time, in <i>hh:mm:ss day month year</i> format, after which the key expires. The range is from 0:0:0 to 23:59:59.

Command Default

None

Command Modes

Key configuration

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
system	read, write

The following example shows how to use the **accept-lifetime** command:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# key chain isis-keys
RP/0/RP0/CPU0:router(config-isis-keys)# key 8
RP/0/RP0/CPU0:router(config-isis-keys-0x8)# accept-lifetime 1:00:00 June 29 2006 infinite
```

Related Commands

Command	Description
key (key chain), on page 4	Creates or modifies a keychain key.
key chain (key chain), on page 5	Creates or modifies a keychain.
key-string (keychain), on page 6	Specifies the text for the key string.
send-lifetime, on page 8	Sends the valid key.
show key chain, on page 10	Displays the keychain.

accept-tolerance

To specify the tolerance or acceptance limit, in seconds, for an accept key that is used by a peer, use the **accept-tolerance** command in keychain configuration mode. To disable this feature, use the **no** form of this command.

accept-tolerance [*value*] **infinite**]

no accept-tolerance [*value*] **infinite**]

Syntax Description

<i>value</i>	(Optional) Tolerance range, in seconds. The range is from 1 to 8640000.
infinite	(Optional) Specifies that the tolerance specification is infinite. The accept key never expires. The tolerance limit of infinite indicates that an accept key is always acceptable and validated when used by a peer.

Command Default

The default value is 0, which is no tolerance.

Command Modes

Keychain configuration

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

If you do not configure the **accept-tolerance** command, the tolerance value is set to zero.

Even though the key is outside the active lifetime, the key is deemed acceptable as long as it is within the tolerance limit (for example, either prior to the start of the lifetime, or after the end of the lifetime).

Task ID

Task ID	Operations
system	read, write

The following example shows how to use the **accept-tolerance** command:

```
RP/0/RP0/CPU0:router# configure
```

```
RP/0/RP0/CPU0:router(config)# key chain isis-keys
RP/0/RP0/CPU0:router(config-isis-keys)# accept-tolerance infinite
```

Related Commands

Command	Description
accept-lifetime, on page 1	Accepts the valid key.
key chain (key chain), on page 5	Creates or modifies a keychain.
show key chain, on page 10	Displays the keychain.

key (key chain)

To create or modify a keychain key, use the **key** command in keychain-key configuration mode. To disable this feature, use the **no** form of this command.

key *key-id*

no key *key-id*

Syntax Description

<i>key-id</i>	48-bit integer key identifier of from 0 to 281474976710655.
---------------	---

Command Default

No default behavior or values

Command Modes

Keychain-key configuration

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

For a Border Gateway Protocol (BGP) keychain configuration, the range for the *key-id* argument must be from 0 to 63. If the range is above the value of 63, the BGP keychain operation is rejected.

Task ID

Task ID	Operations
system	read, write

The following example shows how to use the **key** command:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# key chain isis-keys
RP/0/RP0/CPU0:router(config-isis-keys)# key 8
RP/0/RP0/CPU0:router(config-isis-keys-0x8)#
```

Related Commands

Command	Description
accept-lifetime, on page 1	Accepts the valid key.
key chain (key chain), on page 5	Creates or modifies a keychain.
key-string (keychain), on page 6	Specifies the text for the key string.
send-lifetime, on page 8	Sends the valid key.
show key chain, on page 10	Displays the keychain.

key chain (key chain)

To create or modify a keychain, use the **key chain** command . To disable this feature, use the **no** form of this command.

key chain *key-chain-name*

no key chain *key-chain-name*

Syntax Description

<i>key-chain-name</i>	Specifies the name of the keychain. The maximum number of characters is 48.
-----------------------	---

Command Default

No default behavior or values

Command Modes

XR Config

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

You can configure a keychain for Border Gateway Protocol (BGP) as a neighbor, session group, or neighbor group. BGP can use the keychain to implement a hitless key rollover for authentication.

Task ID

Task ID	Operations
system	read, write

The following example shows that the name of the keychain isis-keys is for the **key chain** command:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# key chain isis-keys
RP/0/RP0/CPU0:router(config-isis-keys)#
```

Related Commands

Command	Description
accept-lifetime, on page 1	Accepts the valid key.
accept-tolerance, on page 3	Configures a tolerance value to accept keys for the keychain.
key (key chain), on page 4	Creates or modifies a keychain key.
key-string (keychain), on page 6	Specifies the text for the key string.
send-lifetime, on page 8	Sends the valid key.
show key chain, on page 10	Displays the keychain.

key-string (keychain)

To specify the text string for the key, use the **key-string** command in keychain-key configuration mode. To disable this feature, use the **no** form of this command.

key-string [clear| password] *key-string-text*

no key-string [clear| password] *key-string-text*

Syntax Description

clear	Specifies the key string in clear-text form.
password	Specifies the key in encrypted form.
<i>key-string-text</i>	Text string for the key, which is encrypted by the parser process before being saved to the configuration. The text string has the following character limitations: <ul style="list-style-type: none"> • Plain-text key strings—Minimum of 1 character and a maximum of 32. • Encrypted key strings—Minimum of 4 characters and no maximum.

Command Default

The default value is clear.

Command Modes

Keychain-key configuration

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Command History

Release	Modification
Release 3.3.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

For an encrypted password to be valid, the following statements must be true:

- String must contain an even number of characters, with a minimum of four.

- The first two characters in the password string must be decimal numbers and the rest must be hexadecimal.
- The first two digits must not be a number greater than 53.

Either of the following examples would be valid encrypted passwords:

1234abcd

or

50aefd

Task ID

Task ID	Operations
system	read, write

The following example shows how to use the **keystring** command:

```
RP/0/RP0/CPU0:router: # configure
RP/0/RP0/CPU0:router(config) # key chain isis-keys
RP/0/RP0/CPU0:router(config-isis-keys) # key 8
RP/0/RP0/CPU0:router(config-isis-keys-0x8) # key-string password 850aefd
```

Related Commands

Command	Description
accept-lifetime, on page 1	Accepts the valid key.
key (key chain), on page 4	Creates or modifies a keychain key.
key chain (key chain), on page 5	Creates or modifies a keychain.
send-lifetime, on page 8	Sends the valid key.
show key chain, on page 10	Displays the keychain.

send-lifetime

To send the valid key and to authenticate information from the local host to the peer, use the **send-lifetime** command in keychain-key configuration mode. To disable this feature, use the **no** form of this command.

send-lifetime *start-time* [**duration** *duration value*| **infinite**| *end-time*]

no send-lifetime *start-time* [**duration** *duration value*| **infinite**| *end-time*]

Syntax Description

<i>start-time</i>	Start time, in <i>hh:mm:ss day month year</i> format, in which the key becomes valid. The range is from 0:0:0 to 23:59:59. The range for the number of days of the month to start is from 1 to 31. The range for the years is from 1993 to 2035.
duration <i>duration value</i>	(Optional) Determines the lifetime of the key in seconds.
infinite	(Optional) Specifies that the key never expires once it becomes valid.
<i>end-time</i>	(Optional) Time, in <i>hh:mm:ss day month year</i> format, after which the key expires. The range is from 0:0:0 to 23:59:59

Command Default

No default behavior or values

Command Modes

Keychain-key configuration

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
system	read, write

The following example shows how to use the **send-lifetime** command:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# key chain isis-keys
RP/0/RP0/CPU0:router(config-isis-keys)# key 8
RP/0/RP0/CPU0:router(config-isis-keys-0x8)# send-lifetime 1:00:00 June 29 2006 infinite
```

Related Commands

Command	Description
accept-lifetime, on page 1	Accepts the valid key.

Command	Description
key (key chain), on page 4	Creates or modifies a keychain key.
key chain (key chain), on page 5	Creates or modifies a keychain.
key-string (keychain), on page 6	Specifies the text for the key string.

show key chain

To display the keychain, use the **show key chain** command.

show key chain *key-chain-name*

Syntax Description

<i>key-chain-name</i>	Names of the keys in the specified keychain. The maximum number of characters is 32.
-----------------------	--

Command Default

No default behavior or values

Command Modes

XR EXEC

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
system	read

When a secure key storage becomes available, it is desirable for keychain management to alternatively prompt you for a master password and display the key label after decryption. The following example displays only the encrypted key label for the **show key chain** command:


```
RP/0/RP0/CPU0:router# show key chain isis-keys

Key-chain: isis-keys/ -

accept-tolerance -- infinite
Key 8 -- text "8"
    cryptographic-algorithm -- MD5
    Send lifetime: 01:00:00, 29 Jun 2006 - Always valid [Valid now]
    Accept lifetime: 01:00:00, 29 Jun 2006 - Always valid [Valid now]
```

Related Commands

Command	Description
accept-lifetime, on page 1	Accepts the valid key.
accept-tolerance, on page 3	Configures a tolerance value to accept keys for the keychain.
key (key chain), on page 4	Creates or modifies a keychain key.
key chain (key chain), on page 5	Creates or modifies a keychain.
key-string (keychain), on page 6	Specifies the text for the key string.
send-lifetime, on page 8	Sends the valid key.

 show key chain