



Cisco IOS XR MPLS Command Reference for the Cisco XR 12000 Series Router, Release 4.1

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

Text Part Number: OL-24701-01

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses used in this document are not intended to be actual addresses. Any examples, command display output, and figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses in illustrative content is unintentional and coincidental.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <http://www.cisco.com/go/trademarks>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

© 2013 Cisco Systems, Inc. All rights reserved.



CONTENTS

Preface

Preface xi

Changes to This Document xi

Obtaining Documentation and Submitting a Service Request xi

CHAPTER 1

MPLS Label Distribution Protocol Commands 1

backoff 3

clear mpls ldp msg-counters neighbor 5

clear mpls ldp neighbor 7

clear mpls ldp forwarding 8

default-route 10

discovery hello 12

discovery instance-tlv disable 14

discovery targeted-hello 15

discovery transport-address 17

downstream-on-demand 19

explicit-null 21

graceful-restart (MPLS LDP) 23

holdtime (MPLS LDP) 26

igp auto-config disable 28

igp sync delay 30

igp sync delay on-proc-restart 32

interface (MPLS LDP) 34

label accept 36

label advertise 38

label allocate 41

log graceful-restart 43

log neighbor 45

log nsr	47
log session-protection	48
maximum interfaces (MPLS LDP)	50
mpls ldp	52
neighbor password	53
neighbor password disable	55
neighbor targeted	56
nsr (MPLS-LDP)	58
router-id (MPLS LDP)	60
session protection	62
show mpls ldp backoff	64
show mpls ldp bindings	66
show mpls ldp discovery	72
show mpls ldp forwarding	77
show mpls ldp graceful-restart	82
show mpls ldp igp sync	84
show mpls ldp interface	87
show mpls ldp neighbor	90
show mpls ldp parameters	96
show mpls ldp statistics msg-counters	99
show mpls ldp summary	101
signalling dscp (LDP)	104
snmp-server traps mpls ldp	106

CHAPTER 2**MPLS Forwarding Commands 109**

mpls ip-ttl-propagate	110
mpls label range	112
mpls mtu	114
show mpls forwarding	116
show mpls forwarding exact-route	121
show mpls interfaces	125
show mpls label range	128
show mpls label table	130
show mpls lsd applications	133
show mpls lsd clients	135

[show mpls traffic-eng fast-reroute database](#) 137

[show mpls traffic-eng fast-reroute log](#) 142

CHAPTER 3

MPLS Traffic Engineering Commands 145

[adjustment-threshold \(MPLS-TE\)](#) 150

[admin-weight](#) 152

[affinity](#) 154

[affinity-map](#) 158

[application \(MPLS-TE\)](#) 160

[attribute-flags](#) 162

[attribute-names](#) 164

[auto-bw \(MPLS-TE\)](#) 166

[auto-bw collect frequency \(MPLS-TE\)](#) 168

[autoroute announce](#) 170

[autoroute metric](#) 172

[auto-tunnel backup \(MPLS-TE\)](#) 174

[backup-bw](#) 176

[backup-path tunnel-te](#) 179

[bw-limit \(MPLS-TE\)](#) 181

[clear mpls lmp](#) 183

[clear mpls traffic-eng auto-bw \(MPLS-TE EXEC\)](#) 184

[clear mpls traffic-eng auto-tunnel backup unused](#) 186

[clear mpls traffic-eng auto-tunnel mesh](#) 188

[clear mpls traffic-eng counters auto-tunnel mesh](#) 189

[clear mpls traffic-eng counters auto-tunnel backup](#) 190

[clear mpls traffic-eng counters global](#) 191

[clear mpls traffic-eng counters signaling](#) 192

[clear mpls traffic-eng counters soft-preemption](#) 194

[clear mpls traffic-eng fast-reroute log](#) 196

[clear mpls traffic-eng link-management statistics](#) 197

[clear mpls traffic-eng pce](#) 198

[collect-bw-only \(MPLS-TE\)](#) 199

[destination \(MPLS-TE\)](#) 201

[direction \(GMPLS\)](#) 203

[disable \(explicit-path\)](#) 205

ds-te bc-model	207
ds-te mode	209
ds-te te-classes	211
exclude srlg (auto-tunnel backup)	214
explicit-path	216
fast-reroute	218
fast-reroute protect	220
fast-reroute timers promotion	222
flooding-igp (GMPLS)	224
flooding thresholds	226
forwarding-adjacency	228
index exclude-address	230
index exclude-srlg	232
index next-address	234
interface (MPLS-TE)	236
interface (SRLG)	238
interface tunnel-gte	240
interface tunnel-te	242
ipcc interface (MPLS-TE)	244
ipcc routed (MPLS-TE)	246
ipv4 unnumbered (MPLS)	248
link-management timers bandwidth-hold	250
link-management timers periodic-flooding	252
link-management timers preemption-delay	254
lmp hello (GMPLS)	255
lmp neighbor (MPLS-TE)	257
lmp router-id (MPLS-TE)	259
match (GMPLS)	261
maxabs (MPLS-TE)	263
mpls traffic-eng	265
mpls traffic-eng auto-bw apply (MPLS-TE)	266
mpls traffic-eng fast-reroute promote	268
mpls traffic-eng level	269
mpls traffic-eng link-management flood	271
mpls traffic-eng path-protection switchover gmpls	273

mpls traffic-eng pce activate-pcep	275
mpls traffic-eng pce reoptimize	277
mpls traffic-eng reoptimize (EXEC)	279
mpls traffic-eng router-id (MPLS-TE router)	281
mpls traffic-eng repotimize mesh group	283
nhop-only (auto-tunnel backup)	284
overflow threshold (MPLS-TE)	286
passive (GMPLS)	288
path-option (MPLS-TE)	290
path-selection ignore overload (MPLS-TE)	293
path-selection loose-expansion affinity (MPLS-TE)	295
path-selection loose-expansion metric (MPLS-TE)	297
path-selection metric (MPLS-TE)	299
path-selection metric (interface)	301
pce address (MPLS-TE)	303
pce deadtimer (MPLS-TE)	305
pce keepalive (MPLS-TE)	307
pce peer (MPLS-TE)	309
pce reoptimize (MPLS-TE)	311
pce request-timeout (MPLS-TE)	313
pce tolerance keepalive (MPLS-TE)	315
policy-class	317
priority (MPLS-TE)	319
record-route	321
remote (GMPLS)	323
reoptimize (MPLS-TE)	325
reoptimize timers delay (MPLS-TE)	327
router-id secondary (MPLS-TE)	330
show explicit-paths	332
show mpls traffic-eng affinity-map	334
show mpls traffic-eng autoroute	336
show mpls traffic-eng auto-tunnel backup	338
show mpls traffic-eng auto-tunnel mesh	341
show mpls traffic-eng collaborator-timers	343
show mpls traffic-eng counters signaling	345

show mpls traffic-eng ds-te te-class	350
show mpls traffic-eng forwarding	352
show mpls traffic-eng forwarding-adjacency	355
show mpls traffic-eng igp-areas	356
show mpls traffic-eng link-management admission-control	358
show mpls traffic-eng link-management advertisements	362
show mpls traffic-eng link-management bandwidth-allocation	365
show mpls traffic-eng link-management bfd-neighbors	368
show mpls traffic-eng link-management igp-neighbors	370
show mpls traffic-eng link-management interfaces	372
show mpls traffic-eng link-management statistics	375
show mpls traffic-eng link-management summary	377
show mpls traffic-eng lmp	379
show mpls traffic-eng maximum tunnels	383
show mpls traffic-eng pce peer	386
show mpls traffic-eng pce tunnels	388
show mpls traffic-eng preemption log	390
show mpls traffic-eng topology	391
show mpls traffic-eng tunnels	401
show mpls traffic-eng tunnels auto-bw brief	427
show srlg	429
signalled-name	432
signalling advertise explicit-null (MPLS-TE)	433
snmp traps mpls traffic-eng	435
srlg	437
switching (GMPLS)	439
switching endpoint (GMPLS)	441
switching transit (GMPLS)	443
timers loose-path (MPLS-TE)	445
timers removal unused (auto-tunnel backup)	447
topology holddown sigerr (MPLS-TE)	449
tunnel-id (auto-tunnel backup)	451

CHAPTER 4
RSVP Infrastructure Commands 453

authentication (RSVP)	456

[bandwidth \(RSVP\) 458](#)

[bandwidth mam \(RSVP\) 460](#)

[bandwidth rdm \(RSVP\) 462](#)

[clear rsvp authentication 464](#)

[clear rsvp counters authentication 466](#)

[clear rsvp counters all 468](#)

[clear rsvp counters chkpt 470](#)

[clear rsvp counters events 472](#)

[clear rsvp counters messages 474](#)

[clear rsvp counters oor 476](#)

[clear rsvp counters prefix-filtering 478](#)

[key-source key-chain \(RSVP\) 480](#)

[life-time \(RSVP\) 482](#)

[rsvp 484](#)

[rsvp interface 485](#)

[rsvp neighbor 487](#)

[show rsvp authentication 489](#)

[show rsvp counters 495](#)

[show rsvp counters oor 499](#)

[show rsvp counters prefix-filtering 501](#)

[show rsvp fast-reroute 504](#)

[show rsvp graceful-restart 507](#)

[show rsvp hello instance 511](#)

[show rsvp hello instance interface-based 514](#)

[show rsvp interface 516](#)

[show rsvp request 519](#)

[show rsvp reservation 521](#)

[show rsvp sender 524](#)

[show rsvp session 527](#)

[signalling dscp \(RSVP\) 530](#)

[signalling graceful-restart 532](#)

[signalling hello graceful-restart refresh interval 534](#)

[signalling hello graceful-restart refresh misses 536](#)

[signalling prefix-filtering access-list 538](#)

[signalling prefix-filtering default-deny-action 540](#)

signalling rate-limit	542
signalling refresh interval	544
signalling refresh missed	546
signalling refresh reduction bundle-max-size	548
signalling refresh reduction disable	550
signalling refresh reduction reliable	552
signalling refresh reduction summary	555
window-size (RSVP)	557

CHAPTER 5

MPLS OAM Commands 559

clear mpls oam counters	560
echo disable-vendor-extension	562
echo revision	563
mpls oam	565
ping mpls ipv4	566
ping mpls traffic-eng	571
ping pseudowire (AToM)	575
ping mpls mldp (P2MP)	579
ping mpls mldp (MP2MP)	586
show mpls oam	593
show mpls oam database	595
traceroute mpls ipv4	597
traceroute mpls multipath	601
traceroute mpls traffic-eng	605
traceroute mpls mldp (P2MP)	608
traceroute mpls mldp (MP2MP)	614



Preface

The *Cisco IOS XR MPLS Command Reference for the Cisco XR 12000 Series Router* preface contains these sections:

- [Changes to This Document](#), page xi
- [Obtaining Documentation and Submitting a Service Request](#), page xi

Changes to This Document

[Changes to This Document](#) lists the technical changes made to this document since it was first printed.

Table 1: Changes to This Document

Revision	Date	Change Summary
OL-26062-02	June 2012	Republished for Cisco IOS XR Release 4.2.1.
OL-26062-01	December 2011	Initial release of this document.

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS version 2.0.



MPLS Label Distribution Protocol Commands

This module describes the commands used to configure Label Distribution Protocol (LDP) in a Multiprotocol Label Switching (MPLS) network.

LDP provides a standard methodology for hop-by-hop (or dynamic label) distribution in an MPLS network by assigning labels to routes that have been chosen by the underlying Interior Gateway Protocol (IGP) routing protocols. The resulting labeled paths, called *label switch paths* (LSPs), forward labeled traffic across an MPLS backbone.

LDP also provides the means for label switching routers (LSRs) to request, distribute, and release label prefix binding information to peer routers in a network. LDP enables LSRs to discover potential peers and establish LDP sessions with those peers to exchange label binding information.

For detailed information about MPLS concepts, configuration tasks, and examples, see *Cisco IOS XR MPLS Configuration Guide for the Cisco XR 12000 Series Router*.

- [backoff, page 3](#)
- [clear mpls ldp msg-counters neighbor, page 5](#)
- [clear mpls ldp neighbor, page 7](#)
- [clear mpls ldp forwarding, page 8](#)
- [default-route, page 10](#)
- [discovery hello, page 12](#)
- [discovery instance-tlv disable, page 14](#)
- [discovery targeted-hello, page 15](#)
- [discovery transport-address, page 17](#)
- [downstream-on-demand, page 19](#)
- [explicit-null, page 21](#)
- [graceful-restart \(MPLS LDP\), page 23](#)
- [holdtime \(MPLS LDP\), page 26](#)
- [igp auto-config disable, page 28](#)
- [igp sync delay, page 30](#)

- [igp sync delay on-proc-restart, page 32](#)
- [interface \(MPLS LDP\), page 34](#)
- [label accept, page 36](#)
- [label advertise, page 38](#)
- [label allocate, page 41](#)
- [log graceful-restart, page 43](#)
- [log neighbor, page 45](#)
- [log nsr, page 47](#)
- [log session-protection, page 48](#)
- [maximum interfaces \(MPLS LDP\), page 50](#)
- [mpls ldp, page 52](#)
- [neighbor password, page 53](#)
- [neighbor password disable, page 55](#)
- [neighbor targeted, page 56](#)
- [nsr \(MPLS-LDP\), page 58](#)
- [router-id \(MPLS LDP\), page 60](#)
- [session protection, page 62](#)
- [show mpls ldp backoff, page 64](#)
- [show mpls ldp bindings, page 66](#)
- [show mpls ldp discovery, page 72](#)
- [show mpls ldp forwarding, page 77](#)
- [show mpls ldp graceful-restart, page 82](#)
- [show mpls ldp igp sync, page 84](#)
- [show mpls ldp interface, page 87](#)
- [show mpls ldp neighbor, page 90](#)
- [show mpls ldp parameters, page 96](#)
- [show mpls ldp statistics msg-counters, page 99](#)
- [show mpls ldp summary, page 101](#)
- [signalling dscp \(LDP\), page 104](#)
- [snmp-server traps mpls ldp, page 106](#)

backoff

To configure the parameters for the Label Distribution Protocol (LDP) backoff mechanism, use the **backoff** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

backoff *initial maximum*

no backoff

Syntax Description

<i>initial</i>	Initial backoff delay, in seconds. Range is 5 to 50331.
<i>maximum</i>	Maximum backoff delay, in seconds. Range is 5 to 50331.

Command Default

initial : 15

maximum : 120

Command Modes

MPLS LDP configuration

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The LDP backoff mechanism prevents two incompatibly configured label switch routers from engaging in an unthrottled sequence of session setup failures. If a session setup attempt fails (due to incompatibility), each Label Switching Router (LSR) delays the next attempt, increasing the delay exponentially with each successive failure until the maximum backoff delay is reached.

Task ID

Task ID	Operations
mpls-ldp	read, write

Examples

The following example shows how to configure the initial backoff delay to 30 seconds and the maximum backoff delay to 240 seconds:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls ldp
RP/0/0/CPU0:router(config-ldp)# backoff 30 240
```

Related Commands

Command	Description
show mpls ldp backoff, on page 64	Displays information about the configured session setup backoff parameters and LDP peers.
show mpls ldp parameters, on page 96	Displays current LDP parameter settings.

clear mpls ldp msg-counters neighbor

To clear the Label Distribution Protocol (LDP) message counters, use the **clear mpls ldp msg-counters neighbor** command in EXEC mode.

clear mpls ldp msg-counters neighbor {*ip-address* | **all**}

Syntax Description

<i>ip-address</i>	LSR or LDP ID of the neighbor.
all	Clears LDP message counters for all neighbors.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **clear mpls ldp msg-counters neighbor** command to clear the statistics on message counters for a specific neighbor (IP address) or for all neighbors. These message counters count the number of LDP protocol messages sent to and received from LDP neighbors.

Task ID

Task ID	Operations
mpls-ldp	read, write

Examples

The following example shows how to clear message counters for neighbor 10.20.20.20:

```
RP/0/0/CPU0:router# clear mpls ldp msg-counters neighbor 10.20.20.20
```

 `clear mpls ldp msg-counters neighbor`**Related Commands**

Command	Description
show mpls ldp statistics msg-counters , on page 99	Displays statistics about the type and count of the messages sent and received from neighbors.

clear mpls ldp neighbor

To force Label Distribution Protocol (LDP) session restart, use the **clear mpls ldp neighbor** command in EXEC mode.

clear mpls ldp neighbor [*ip-address*]

Syntax Description	<i>ip-address</i>	(Optional) Neighbor IP address or LDP ID.

Command Default	No default behavior or values

Command Modes	EXEC

Command History	Release	Modification
	Release 3.3.0	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **clear mpls ldp neighbor** command to restart a single LDP session or all LDP sessions (without restarting the LDP process itself).

Task ID	Task ID	Operations
	mpls-ldp	read, write

Examples	The following example shows how to force an unconditional LDP session restart:

```
RP/0/0/CPU0:router# clear mpls ldp neighbor 10.20.20.20
```

Related Commands	Command	Description
	show mpls ldp neighbor , on page 90	Displays information about LDP neighbors.

clear mpls ldp forwarding

To clear (or reset) the MPLS Label Distribution Protocol (LDP) forwarding rewrites, use the **clear mpls ldp forwarding** command in EXEC mode.

clear mpls ldp forwarding [*IP -address*]

Syntax Description

IP-address

(Optional) IPv4 address, specified in four-part, dotted-decimal notation.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 4.0.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

This command resets LDP installed forwarding state for all prefixes or a given prefix. It is useful when installed LDP forwarding state needs to be reprogrammed in LSD and MPLS forwarding.

Task ID

Task ID	Operations
mpls-ldp	read, write

Examples

This is a sample output from the **clear mpls ldp forwarding** command:

```
RP/0/0/CPU0:router# clear mpls ldp forwarding
```

Related Commands

Command	Description
show mpls ldp forwarding	Displays the LDP forwarding state installed in MPLS forwarding.
show mpls forwarding	Displays the contents of the MPLS Label Forwarding Information Base (LFIB).
graceful-restart (MPLS LDP), on page 23	Configures the LDP graceful restart feature.
show mpls ldp bindings, on page 66	Displays the contents of LDP LIB.

default-route

To enable Multiprotocol Label Switching (MPLS) switching for IP default route by allocating and advertising non-null label, use the **default-route** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

default-route

no default-route

Syntax Description

This command has no arguments or keywords.

Command Default

Allocates null (implicit or explicit) local label for IP default route prefix 0.0.0.0/0.

Command Modes

MPLS LDP configuration

Command History

Release	Modification
Release 3.3.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

When the IP default route 0.0.0.0/0 is configured on an egress router, it is advertised through Interior Gateway Protocol (IGP) to other routers to enable default IP forwarding. When MPLS LDP is configured and establishing label switch paths (LSPs) for other prefixes, you can emulate default forwarding and switching for MPLS in the same way as IP forwarding. To do so, allocate a non-null local label and advertise this label to its peers.

Task ID

Task ID	Operations
mpls-ldp	read, write

Examples

The following example shows how to enable default MPLS switching for default prefix:

```
RP/0/0/CPU0:router(config-ldp)# default-route
```

Related Commands

Command	Description
show mpls ldp bindings, on page 66	Displays LDP label bindings.
show mpls ldp forwarding, on page 77	Displays LDP installed forwarding state.

discovery hello

To configure the interval between transmission of consecutive Label Distribution Protocol (LDP) discovery hello messages and the holdtime for a discovered LDP neighbor, use the **discovery hello** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

discovery hello {**holdtime** *seconds* | **interval** *seconds*}

no discovery hello {**holdtime** | **interval**}

Syntax Description

holdtime	Sets the time, in seconds, a discovered LDP neighbor is remembered without receipt of an LDP hello message from the neighbor. Default is 15.
interval	Sets the time, in seconds, between consecutive hello messages. Default is 5.
<i>seconds</i>	Time value, in seconds. Range is 1 to 65535 (65535 means infinite).

Command Default

holdtime: 15

interval: 5

Command Modes

MPLS LDP configuration

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-ldp	read, write

Examples

The following example shows how to configure the link hello holdtime to 30 seconds:

```
RP/0/0/CPU0:router(config-ldp)# discovery hello holdtime 30
```


The following example shows how to configure the link hello interval to 10 seconds:

```
RP/0/0/CPU0:router(config-ldp)# discovery hello interval 10
```

Related Commands

Command	Description
discovery targeted-hello, on page 15	Configures targeted-hello messages.

discovery instance-tlv disable

To disable transmit and receive processing for Type-Length-Value (TLV), use the **discovery instance-tlv disable** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

discovery instance-tlv disable

no discovery instance-tlv disable

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes MPLS LDP configuration

Command History	Release	Modification
	Release 3.4.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	mpls-ldp	read, write

Examples The following example shows how to disable transmit and receive processing for TLV:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls ldp
RP/0/0/CPU0:router(config-ldp)# discovery instance-tlv disable
```

Related Commands	Command	Description
	discovery targeted-hello , on page 15	Configures targeted-hello messages.

discovery targeted-hello

To configure the interval between transmission of consecutive Label Distribution Protocol (LDP) discovery targeted-hello messages, the hold time for a discovered targeted LDP neighbor, and to accept targeted hello from peers, use the **discovery targeted-hello** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

discovery targeted-hello {**accept** [**from** *acl*]| **holdtime** *seconds*| **interval** *seconds*}

no discovery targeted-hello {**accept** | **holdtime** | **interval**}

Syntax Description

accept	Accepts targeted hellos from any source.
from <i>acl</i>	(Optional) Accepts targeted hellos from LDP peers as permitted by the access-list.
holdtime	Configures the time a discovered LDP neighbor is remembered without receipt of an LDP hello message from a neighbor.
interval	Displays time between consecutive hello messages.
<i>seconds</i>	Time value, in seconds. Range is 1 to 65535.

Command Default

accept : Targeted hello messages are not accepted from any source (neighbor).

holdtime : 90

interval : 10

Command Modes

MPLS LDP configuration

Command History

Release	Modification
Release 3.2	Support was added for the from <i>acl</i> keyword and argument under the accept command.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

LDP supports IPv4 standard access lists only.

Task ID

Task ID	Operations
mpls-ldp	read, write

Examples

The following example shows how to configure the targeted-hello holdtime to 45 seconds:

```
RP/0/0/CPU0:router(config-ldp)# discovery targeted-hello holdtime 45
```

The following example shows how to configure the targeted-hello interval to 5 seconds:

```
RP/0/0/CPU0:router(config-ldp)# discovery targeted-hello interval 5
```

The following example shows how to configure acceptance of targeted hellos from all peers:

```
RP/0/0/CPU0:router(config-ldp)# discovery targeted-hello accept
```

The following example shows how to configure acceptance of targeted hello from peers 10.1.1.1 and 10.2.2.2 only:

```
RP/0/0/CPU0:router(config)# ipv4 access-list peer_acl_10
RP/0/0/CPU0:router(config-ipv4-acl)# permit 10.1.1.1
RP/0/0/CPU0:router(config-ipv4-acl)# permit 10.2.2.2
RP/0/0/CPU0:router(config-ldp)# discovery targeted-hello accept from peer_acl_10
```

Related Commands

Command	Description
show mpls ldp discovery, on page 72	Displays LDP discovery information.
show mpls ldp parameters, on page 96	Displays LDP parameters information.

discovery transport-address

To provide an alternative address for a TCP connection, use the **discovery transport-address** command in MPLS LDP interface configuration mode. To return to the default behavior, use the **no** form of this command.

discovery transport-address {*ip-address* | **interface**}

no discovery transport-address {*ip-address* | **interface**}

Syntax Description

<i>ip-address</i>	IP address to be advertised as the transport address in discovery hello messages.
interface	Advertises the IP address of the interface as the transport address in discovery hello messages.

Command Default

LDP advertises its LDP router ID as the transport address in LDP discovery hello messages.

Command Modes

MPLS LDP interface configuration

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Establishing an LDP session between two routers requires a session TCP connection. To establish the session TCP connection, each router must know the transport address (IP address) of the other router.

The LDP discovery mechanism provides the means for a router to advertise transport addresses. Transport address is implicit or explicit. Implicit addresses do not appear as part of the contents of the discovery hello messages sent to the peer. If explicit, the advertisement appears as part of the contents of discovery hello messages sent to the peer.

The **discovery transport-address** command modifies the default behavior described above. Using the **interface** keyword, LDP advertises the IP address of the interface in LDP discovery hello messages sent from the interface. Using the *ip-address* argument, LDP advertises the IP address in LDP discovery hello messages sent from the interface.



Note

When a router has multiple links connecting it to its peer device, the router must advertise the same transport address in the LDP discovery hello messages it sends on all such interfaces.

Task ID

Task ID	Operations
mpls-ldp	read, write

Examples

The following example shows how to specify an exiting address (10.10.3.1) as the transport address on an interface POS 0/1/0/0:

```
RP/0/0/CPU0:router(config-ldp)# interface POS 0/1/0/0
RP/0/0/CPU0:router(config-ldp-if)# discovery transport-address 10.10.3.1

RP/0/0/CPU0:router# show mpls ldp neighbor

Peer LDP Identifier: 10.44.44.44:0
  TCP connection: 10.44.44.44:65520 - 10.10.3.1:646
  Graceful Restart: Yes (Reconnect Timeout: 15 sec, Recovery: 180 sec)
  State: Oper; Msgs sent/rcvd: 13/9
  Up time: 00:00:11
  LDP Discovery Sources:
    POS 0/1/0/0
  Addresses bound to this peer:
    10.10.3.2      10.44.44.44
```

Related Commands

Command	Description
show mpls ldp discovery, on page 72	Displays the status of the LDP discovery process.
show mpls ldp neighbor, on page 90	Displays information about LDP neighbors.

downstream-on-demand

To configure MPLS Label Distribution Protocol (LDP) downstream-on-demand mode, use the **downstream-on-demand** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

downstream-on-demand with *access-list*

nodownstream-on-demand with *access-list*

Syntax Description

with	Displays access list of LDP peers.
<i>access-list</i>	IP access-list name.

Command Default

No default behavior or values

Command Modes

MPLS LDP configuration

Command History

Release	Modification
Release 4.0.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operation
mpls-ldp	read, write

Examples

This is a sample output from the **downstream-on-demand** command:

```
RP/0/0/CPU0:router(config-ldp)# downstream-on-demand with access-list
```

Related Commands

Command	Description
graceful-restart (MPLS LDP), on page 23	Configures the LDP graceful restart feature.
show mpls ldp bindings, on page 66	Displays the contents of LDP LIB.

explicit-null

To configure a router to advertise explicit null labels instead of implicit null labels, use the **explicit-null** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

explicit-null [*to peer-acl*] **for** *prefix-acl* [*to peer-acl*]]
no explicit-null

Syntax Description

to <i>peer-acl</i>	(Optional) Specifies LDP peers for which explicit-null is advertised instead of implicit-null. Range is 1 to 99.
for <i>prefix-acl</i>	(Optional) Specifies prefixes for which explicit-null is advertised instead of implicit-null. Range is 1 to 99.

Command Default

Implicit null is advertised as default null label for routes, such as directly connected routes.

Command Modes

MPLS LDP configuration

Command History

Release	Modification
Release 3.2	Support was added for the for and to keywords

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Normally, LDP advertises an implicit null label for directly connected routes. The implicit null label causes the previous hop router to perform next to last router hop popping.

The **explicit-null** command advertises the explicit-null labels in place of implicit null labels for directly connected prefixes.

LDP supports IPv4 standard access lists only.

Task ID

Task ID	Operations
mpls-ldp	read, write

Examples

The following command shows how to advertise explicit null for all directly connected routes to all LDP peers:

```
RP/0/0/CPU0:router(config-ldp)# explicit-null
```

The following command sequence shows how to advertise explicit-null for directly connected route 192.168.0.0 to all LDP peers and implicit-null for all other directly connected routes:

```
RP/0/0/CPU0:router(config)# ipv4 access-list pfx_acl_192_168
RP/0/0/CPU0:router(config-ipv4-acl)# permit 192.168.0.0
RP/0/0/CPU0:router(config-ldp)# explicit-null for pfx_acl_192_168
```

The following command sequence shows how to send explicit-null for all directly connected routes to peers 10.1.1.1 and 10.2.2.2 and implicit-null to all other peers:

```
RP/0/0/CPU0:router(config)# ipv4 access-list peer_acl_10
RP/0/0/CPU0:router(config-ipv4-acl)# permit 10.1.1.1
RP/0/0/CPU0:router(config-ipv4-acl)# permit 10.2.2.2
RP/0/0/CPU0:router(config-ldp)# explicit-null to peer_acl_10
```

The following command shows how to advertise explicit-null for prefix 192.168.0.0 to peers 10.1.1.1 and 10.2.2.2 and advertise implicit-null for all other applicable routes to all other peers:

```
RP/0/0/CPU0:router(config-ldp)# explicit-null for pfx_acl_192_168 to peer_acl_10
```

Related Commands

Command	Description
show mpls ldp bindings, on page 66	Displays the contents of LDP LIB.
show mpls ldp forwarding, on page 77	Displays the contents of the LDP forwarding database.
show mpls ldp parameters, on page 96	Displays current LDP parameter settings.

graceful-restart (MPLS LDP)

To configure graceful restart, use the **graceful-restart** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

graceful-restart [**reconnect-timeout** *seconds*] **forwarding-state-holdtime** *seconds*]

no graceful-restart [**reconnect-timeout** | **forwarding-state-holdtime**]

Syntax Description

reconnect-timeout *seconds*

(Optional) Configures the time that the local LDP sends to its graceful restartable peer, indicating how long its neighbor should wait for reconnection in the event of a LDP session failure, in seconds. Range is 60 to 1800.

forwarding-state-holdtime *seconds*

(Optional) Configures the time the local forwarding state is preserved (without being reclaimed) after the local LDP control plane restarts, in seconds. Range is 60 to 1800.

Command Default

By default, graceful restart is disabled.

reconnect-timeout: 120

forwarding-state-holdtime: 180

Command Modes

MPLS LDP configuration

Command History

Release	Modification
Release 3.2	This command was supported.
Release 3.9.0	The maximum value for the seconds argument is 1800.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the LDP graceful restart capability to achieve nonstop forwarding (NSF) during an LDP control plane communication failure or restart. To configure graceful restart between two peers, enable LDP graceful restart on both label switch routers (LSRs).

When an LDP graceful restart session is established and there is control plane failure, the peer LSR starts graceful restart procedures, initially keeps the forwarding state information pertaining to the restarting peer, and marks this state as stale. If the restarting peer does not reconnect within the reconnect timeout, the stale forwarding state is removed. If the restarting peer reconnects within the reconnect time period, it is provided recovery time to resynchronize with its peer. After this time, any unsynchronized state is removed.

The value of the forwarding state hold time keeps the forwarding plane state associated with the LDP control-plane in case of a control-plane restart or failure. If the control plane fails, the forwarding plane retains the LDP forwarding state for twice the forwarding state hold time. The value of the forwarding state hold time is also used to start the local LDP forwarding state hold timer after the LDP control plane restarts. When the LDP graceful restart sessions are renegotiated with its peers, the restarting LSR sends the remaining value of this timer as the recovery time to its peers. Upon local LDP restart with graceful restart enabled, LDP does not replay forwarding updates to MPLS forwarding until the forwarding state hold timer expires.

**Note**

In the presence of a peer relationship, any change to the LDP graceful restart configuration will restart LDP sessions. If LDP configuration changes from nongraceful restart to graceful restart, all the sessions are restarted. Only graceful restart sessions are restarted upon graceful restart to nongraceful restart configuration changes.

Task ID

Task ID	Operations
mpls-ldp	read, write

Examples

The following example shows how to configure an existing session for graceful restart:

```
RP/0/0/CPU0:router(config-ldp)# graceful-restart
```

```
RP/0/0/CPU0:router:Apr  3 10:56:05.392 : mpls_ldp[336]: %ROUTING-LDP-5-NBR_CHANGE : Nbr
2.2.2.2:0, DOWN
RP/0/0/CPU0:router:Apr  3 10:56:05.392 : mpls_ldp[336]: %ROUTING-LDP-5-NBR_CHANGE : Nbr
3.3.3.3:0, DOWN
RP/0/0/CPU0:router:Apr  3 10:56:09.525 : mpls_ldp[336]: %ROUTING-LDP-5-NBR_CHANGE : Nbr
3.3.3.3:0, UP
RP/0/0/CPU0:router:Apr  3 10:56:11.114 : mpls_ldp[336]: %ROUTING-LDP-5-NBR_CHANGE : Nbr
2.2.2.2:0, UP
```

```
RP/0/0/CPU0:router# show mpls ldp neighbor brief
```

Peer	GR Up Time	Discovery	Address
3.3.3.3:0	Y 00:01:04	3	8
2.2.2.2:0	N 00:01:02	2	5

```
RP/0/0/CPU0:router# show mpls ldp graceful-restart
```

```
Forwarding State Hold timer : Not Running
GR Neighbors                : 1
```

Neighbor ID	Up	Connect Count	Liveness Timer	Recovery Timer
3.3.3.3	Y	1	-	-

Related Commands

Command	Description
show mpls ldp forwarding, on page 77	Displays the contents of the LDP forwarding database.
show mpls ldp graceful-restart, on page 82	Displays information related to graceful restart.
show mpls ldp neighbor, on page 90	Displays information about LDP neighbors.
show mpls ldp parameters, on page 96	Displays current LDP parameter settings.
show mpls ldp summary, on page 101	Displays summarized information regarding the LDP process.

holdtime (MPLS LDP)

To change the time for which an Label Distribution Protocol (LDP) session is maintained in the absence of LDP messages from the session peer, use the **holdtime** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

holdtime *seconds*

no holdtime

Syntax Description

<i>seconds</i>	Time, in seconds, that an LDP session is maintained in the absence of LDP messages from the session peer. Range is 15 to 65535.

Command Default

seconds: 180

Command Modes

MPLS LDP configuration

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-ldp	read, write

Examples

The following example shows how to change the hold time of LDP sessions to 30 seconds:

```
RP/0/0/CPU0:router(config-ldp)# holdtime 30
```

Related Commands

Command	Description
show mpls ldp parameters, on page 96	Displays current LDP parameter settings.

igp auto-config disable

To disable Label Distribution Protocol (LDP) auto-configuration, use the **igp auto-config disable** command in MPLS LDP interface configuration mode. To return to the default behavior, use the **no** form of this command.

igp auto-config disable

no igp auto-config disable

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes MPLS LDP interface configuration

Command History	Release	Modification
	Release 3.5.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

IGP auto-configuration can be enabled on ISIS and OSPF. Configuration details are described in *Cisco IOS XR Routing Configuration Guide for the Cisco XR 12000 Series Router*.

Task ID	Task ID	Operations
	mpls-ldp	read, write

Examples The following example shows how to disable LDP auto-configuration on POS 0/1/0/3:

```
RP/0/0/CPU0:router(config)# mpls ldp
RP/0/0/CPU0:router(config-ldp)# interface pos 0/1/0/3
RP/0/0/CPU0:router(config-ldp-if)# igp auto-config disable
```

Related Commands	Command	Description
	show mpls ldp interface , on page 87	Displays information about LDP-enabled interfaces.

igp sync delay

To enable Label Distribution Protocol (LDP) Interior Gateway Protocol (IGP) sync delay timer feature, use the **igp sync delay** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

igp sync delay *seconds*

no igp sync delay

Syntax Description

<i>seconds</i>	Time, in seconds, that declaration of LDP sync state being up is delayed after session establishment upon link coming up. Range is 5 to 300.

Command Default

LDP does not delay declaration of sync up and notifies IGP as soon as sync up conditions are met for a link.

Command Modes

MPLS LDP configuration

Command History

Release	Modification
Release 3.3.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

- By default, LDP declares LDP sync up as soon as all the requisite conditions are met, namely:
 - LDP session is up.
 - LDP has sent all its label bindings to at least one peer.
 - LDP has received at least one label binding from a peer.

This minimizes traffic loss on link up but can still lead to substantial traffic loss under certain circumstances (for example, when interoperating with an LSR with ordered mode operation). It may be necessary to delay declaration of sync up after the session comes up by configuring a timeout period.

- When the graceful-restart event is configured, the IGP sync delay timer does not take effect.

Task ID

Task ID	Operations
mpls-ldp	read, write

Examples

The following example shows how to configure LDP to delay declaration of sync-up to 30 seconds:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls ldp
RP/0/0/CPU0:router(config-ldp)# igp sync delay 30
```

Related Commands

Command	Description
show mpls ldp igp sync , on page 84	Displays LDP IGP sync information for link(s).

igp sync delay on-proc-restart

To delay the declaration of synchronization events to the Interior Gateway Protocol (IGP) when the label distribution protocol (LDP) fails or restarts, use the **igp sync delay on-proc restart** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

igp sync delay on-proc restart *seconds*

no igp sync delay on-proc restart *seconds*

Syntax Description

<i>seconds</i>	Time, in seconds, duration of process-level delay for synchronization events when the LDP fails or restarts. Range is from 60 to 600.

Command Default

This command is disabled by default.

Command Modes

MPLS LDP configuration

Command History

Release	Modification
Release 3.8.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **igp sync delay on-proc restart** command enables a process-level delay for synchronization events when the LDP fails or restarts. This delay defers the sending of sync-up events to the IGP until most or all the LDP sessions converge and also allows the LDP to stabilize. This allows the LDP process failure to be less stressful because IGP's receive all the sync-up events in bulk. This means that the IGP is required to run the shortest path first (SPF) and link-state advertisements (LSAs) only one time with an overall view of the sync-up events.

Task ID

Task ID	Operations
mpls-ldp	read, write

Examples

The following example shows how to configure LDP to delay the declaration of synchronization events to IGP by 60 seconds:

```
RP/0/0/CPU0:router# configure
```

```
RP/0/0/CPU0:router(config)# mpls ldp
RP/0/0/CPU0:router(config-ldp)# igp sync delay on-proc restart 60
```

The following example shows the status following execution of the command:

```
RP/0/0/CPU0:router# show mpls ldp igp sync

Process Restart Sync Delay: 60 sec, Gloal timer running (15 sec remaining)
GigabitEthernet0/3/0/2:
Sync status: Deferred
....
```

When the timer is not running, the output displays the following:

```
Process Restart Sync Delay: 60 sec, Global timer not running
```

Related Commands

Command	Description
show mpls ldp igp sync, on page 84	Displays LDP IGP sync information for link(s).

interface (MPLS LDP)

To configure or enable Multiprotocol Label Switching (MPLS) Label Distribution Protocol (LDP) on an interface, use the **interface** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

interface *type interface-path-id*

no interface *type interface-path-id*

Syntax Description

<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.

Command Default

No default behavior or values

Command Modes

MPLS LDP configuration

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

When you configure LDP on an interface, the LDP process begins neighbor discovery, sending link hello messages on the interface. This can result in a session setup with discovered neighbors. When LDP is enabled on tunnel-te interfaces, targeted discovery procedures apply.

LDP interface configuration supports forward reference; accordingly, it is possible to configure a nonexistent interface under LDP.



Note

You cannot enable LDP on loopback interfaces.

MPLS LDP is supported over Generic Route Encapsulation (GRE) tunnels by configuring the tunnel-ip interface. LDP establishes a link session (as opposed to a targeted LDP session) over the GRE tunnel.

Task ID

Task ID	Operations
mpls-ldp	read, write

Examples

The following example shows how to configure LDP on POS interface 0/1/0/0:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls ldp
RP/0/0/CPU0:router(config-ldp)# interface POS 0/1/0/0
RP/0/0/CPU0:router(config-ldp-if)#
```

The following example shows how to configure LDP on an MPLS TE tunnel:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls ldp
RP/0/0/CPU0:router(config-ldp)# interface tunnel-te 123
RP/0/0/CPU0:router(config-ldp-if)#
```

Related Commands

Command	Description
show mpls ldp parameters, on page 96	Displays current LDP parameter settings.
show mpls ldp neighbor, on page 90	Displays LDP neighbor session parameters.

label accept

To control the receipt of labels (remote bindings) for a set of prefixes from a peer, use the **label accept** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

label accept for prefix-acl from ip-address

no label accept for prefix-acl from ip-address

Syntax Description

for prefix-acl	Accepts and retains remote bindings for prefixes that are permitted by the prefix access list <i>prefix-acl</i> argument.
from ip-address	Displays the peer IP address.

Command Default

LDP accepts and retains label bindings for all prefixes from all peers.

Command Modes

MPLS LDP configuration

Command History

Release	Modification
Release 3.3.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

By default, LDP accepts labels (as remote bindings) for all prefixes from all its peers. To save resources (such as memory) configure the access list to specify label and binding acceptance for a set of prefixes from a peer.

If the inbound label filtering policy changes such that it now allows previously denied prefixes from a peer, you must reset the LDP session with the peer using the **clear mpls ldp neighbor** command.

LDP supports IPv4 standard access lists only.



Note

Label acceptance control is also referred to as LDP inbound label filtering.

Task ID

Task ID	Operations
mpls-ldp	read, write

Examples

The following example shows how to configure inbound label filtering policy. In this example, an LSR is configured to accept and retain label bindings for prefixes 192.168.1.1 (pfx_acl_1) from peer 1.1.1.1, prefix 192.168.2.2 (pfx_acl_2) from peer 2.2.2.2, and prefixes 192.168.1.1, 192.168.2.2, 192.168.3.3 (pfx_acl_3) from peer 3.3.3.3:

```
RP/0/0/CPU0:router(config-ldp)# label accept
RP/0/0/CPU0:router(config-ldp-lbl-acpt)# for pfx_acl_1 from 1.1.1.1
RP/0/0/CPU0:router(config-ldp-lbl-acpt)# for pfx_acl_2 from 2.2.2.2
RP/0/0/CPU0:router(config-ldp-lbl-acpt)# for pfx_acl_3 from 3.3.3.3
```

Related Commands

Command	Description
label advertise, on page 38	Controls advertisement of LDP local label bindings (outbound label filtering).
clear mpls ldp neighbor, on page 7	Resets LDP neighbor sessions.
show mpls ldp bindings, on page 66	Displays LDP binding information.

label advertise

To control the advertisement of local labels, use the **label advertise** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

label advertise [**disable**| **for** *prefix-acl* [**to** *peer-acl*]] **interface** *type interface-path-id*

no label advertise [**disable**| **for** *prefix-acl* [**to** *peer-acl*]] **interface** *type interface-path-id*

Syntax Description

disable	(Optional) Disables label advertisement to all peers for all prefixes.
for <i>prefix-acl</i>	(Optional) Specifies prefix destinations for which labels will be advertised.
to <i>peer-acl</i>	(Optional) Specifies which LDP neighbors will receive label advertisements.
interface	(Optional) Specifies an interface for label allocation and advertisement of its interface IP address.
<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.

Command Default

LDP advertises labels for all known prefixes to all peers. LDP does not advertise labels for local interfaces addresses other than Loopback interfaces.

Command Modes

MPLS LDP configuration

Command History

Release	Modification
Release 3.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **label advertise** command determines how the label switch router (LSR) advertises local labels. The following rules describe the effects of running multiple commands:

- Every command has a prefix-acl or peer-acl pair associated with it, as follows:
 - In the absence of the **for** or **to** keywords, the access list pair is (none, none).
 - When using the **for** keyword without the **to** keyword, the access list is (prefix-acl, none).
- A prefix can have a maximum of one (prefix-acl, peer-acl) pair, as follows:
 - A (prefix-acl, peer-acl) pair applies to a prefix only if the prefix-acl matches the prefix. A match occurs if the prefix-acl permits the prefix.
 - If more than one (prefix-acl, peer-acl) pair from multiple **label advertise** commands matches a prefix, the (prefix-acl, peer-acl) pair in the first command applies to the prefix.
- When an LSR is ready to advertise a label for a prefix, the LSR determines whether a (prefix-acl, peer-acl) pair applies to the prefix.
 - If none applies, and if the **disable** keyword has been configured for the command, the label for the prefix is not advertised to any peer; otherwise, the label is advertised to all peers.
 - If a (prefix-acl, peer-acl) pair applies to the prefix, and if the prefix-acl denies the prefix, the label is not advertised to any peer.
 - If the prefix-acl permits the prefix and the peer-acl is none (that is, the command that applies to the prefix is an **label advertise for prefix-acl** command without the **to** keyword), the label is advertised to all peers.
 - If the prefix-acl permits the prefix and there is a peer-acl, the label is advertised to all peers permitted by the peer-acl.

Normally, LDP advertises labels for non-BGP routes present in the routing table. Additionally, LDP advertises labels from /32 IP addresses on Loopback interfaces and does not advertise /32 addresses for other non-Loopback interfaces. To control advertisement of labels for /32 IP addresses on these interfaces, use the **label advertise interface** command.

LDP supports IPv4 standard access lists only.


Note

Label advertisement control is also referred to as LDP outbound label filtering.

Task ID

Task ID	Operations
mpls-ldp	read, write

Examples

The following example shows how to disable advertisement of all locally assigned labels to all peers:

```
RP/0/0/CPU0:router(config-ldp)# label advertise
RP/0/0/CPU0:router(config-ldp-lbl-advt)# disable
```

The following example shows how to send labels only for prefixes 10.1.1.0 and 20.1.1.0 to all peers:

```
RP/0/0/CPU0:router(config)# ipv4 access-list pfx_acl_1
RP/0/0/CPU0:router(config-ipv4-acl)# permit 10.1.1.0
RP/0/0/CPU0:router(config-ipv4-acl)# permit 20.1.1.0

RP/0/0/CPU0:router(config-ldp)# label advertise
RP/0/0/CPU0:router(config-ldp-lbl-advt)# disable
RP/0/0/CPU0:router(config-ldp-lbl-advt)# for pfx_acl_1
```

The following example shows how to send labels for prefix 10.0.0.0 to peers 10.1.1.1 and 10.2.2.2, labels for prefix 20.0.0.0 to peer 20.1.1.1, and labels for all other prefixes to all other peers:

```
RP/0/0/CPU0:router(config)# ipv4 access-list pfx_acl_10
RP/0/0/CPU0:router(config-ipv4-acl)# permit 10.0.0.0

RP/0/0/CPU0:router(config)# ipv4 access-list pfx_acl_20
RP/0/0/CPU0:router(config-ipv4-acl)# permit 20.0.0.0

RP/0/0/CPU0:router(config)# ipv4 access-list peer_acl_10
RP/0/0/CPU0:router(config-ipv4-acl)# permit 10.1.1.1
RP/0/0/CPU0:router(config-ipv4-acl)# permit 10.2.2.2

RP/0/0/CPU0:router(config)# ipv4 access-list peer_acl_20
RP/0/0/CPU0:router(config-ipv4-acl)# permit 20.1.1.1

RP/0/0/CPU0:router(config-ldp)# label advertise
RP/0/0/CPU0:router(config-ldp-lbl-advt)# for pfx_acl_10 to peer_acl_10
RP/0/0/CPU0:router(config-ldp-lbl-advt)# for pfx_acl_20 to peer_acl_20
```



Note

To advertise pfx_acl_10 to peer_acl_10 and pfx_acl_20 to peer_acl_20 and disable all other advertisements to all other peers, include the **disable** keyword with the **label advertise** command.

The following example shows how to use the **interface** keyword to advertise /32 IP address for POS 0/1/0/0:

```
RP/0/0/CPU0:router(config-ldp)# label advertise
RP/0/0/CPU0:router(config-ldp-lbl-advt)# interface POS 0/1/0/0
```

Related Commands

Command	Description
show mpls ldp neighbor, on page 90	Displays information about LDP neighbors.
show mpls ldp bindings, on page 66	Displays information about LDP label bindings.

label allocate

To control allocation of local label only for a set of prefixes, use the **label allocate** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

label allocate for {*prefix-acl* | **host-routes**}

no label allocate

Syntax Description

for	Specifies set of prefixes for which local label needs to be allocated.
<i>prefix-acl</i>	IP access-list name or number. Range is from 1 to 99.
host-routes	Allocates the label for host routes only.

Command Default

LDP allocates local label for all learned routes (prefixes).

Command Modes

MPLS LDP configuration

Command History

Release	Modification
Release 3.3.0	This command was introduced.
Release 3.9.0	The host-routes keyword was added.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Local label allocation control lets you override the default label allocation policy and provides many benefits, including reduced memory usage and fewer forwarding and network updates.

By default, LDP allocates local labels for all learned routes. There are times when you may want to limit label allocation for a given set of prefixes; for example, when using LDP in the core network to provide MPLS transport from one edge to another edge. In such cases, it is necessary to set up label switch packets (LSPs) for Loopback /32 addresses for provider edge (PE) routers (rendering it unnecessary to allocate and advertise local labels for other Interior Gateway Protocol (IGP) prefixes).

LDP supports IPv4 standard access lists only.

Task ID

Task ID	Operations
mpls-ldp	read, write

Examples

The following example shows how to configure LDP to limit allocation of local labels to prefixes 192.168.1.1, 192.168.2.2, and 192.168.3.3 only:

```
RP/0/0/CPU0:router(config)# ipv4 access-list pfx_acl_1
RP/0/0/CPU0:router(config-ipv4-acl)# permit 192.168.1.1
RP/0/0/CPU0:router(config-ipv4-acl)# permit 192.168.2.2
RP/0/0/CPU0:router(config-ipv4-acl)# permit 192.168.3.3

RP/0/0/CPU0:router(config-ldp)# label allocate for pfx_acl_1
```

Related Commands

Command	Description
show mpls ldp bindings, on page 66	Displays information about LDP label bindings.
show mpls ldp forwarding, on page 77	Displays the contents of the LDP forwarding database.

log graceful-restart

To set up notification describing graceful-restart (GR) session events, use the **log graceful-restart** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

log graceful-restart

no log graceful-restart

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes MPLS LDP configuration

Command History	Release	Modification
	Release 3.3.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **log graceful-restart** command to receive a syslog/console message when a graceful restart-related session event occurs, including LDP graceful restart session disconnection, reconnection, and timeout.



Note

A logging message is issued upon graceful restart session events.

Task ID	Task ID	Operations
	mpls-ldp	read, write

Examples The following example shows how to enable logging messages for graceful restart session events:

```
RP/0/0/CPU0:router(config-ldp) # log graceful-restart
```

The following sample output shows the logging events that can be displayed on the console:

```
RP/0/0/CPU0:router: mpls_ldp[340]: %ROUTING-LDP-5-GR : GR session 4.4.4.4:0 (instance 1)
```

disconnected

RP/0/0/CPU0:router: mpls_ldp[340]: %ROUTING-LDP-5-GR : GR session 4.4.4.4:0 (instance 2)
reconnected

RP/0/0/CPU0:router: mpls_ldp[340]: %ROUTING-LDP-5-GR : GR session 5.5.5.5:0 (instance 3)
timed out

RP/0/0/CPU0:router: mpls_ldp[336]: %ROUTING-LDP-5-GR_RESTART_COMPLETE : GR forwarding state
hold timer has expired

Related Commands

Command	Description
show mpls ldp neighbor, on page 90	Displays information about LDP neighbors.
show mpls ldp graceful-restart, on page 82	Displays information about LDP GR sessions.

log neighbor

To enable logging of notices describing session changes, use the **log neighbor** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

log neighbor

no log neighbor

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes MPLS LDP configuration

Command History	Release	Modification
	Release 3.2	This command was supported.
	Release 3.3.0	The log neighbor command replaced the former log neighbor changes command.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **log neighbor** command to receive a syslog or console message when a neighbor goes up or down.

Task ID	Task ID	Operations
	mpls-ldp	read, write

Examples The following example shows how to enable logging messages for neighbor session up and down events:

```
RP/0/0/CPU0:router(config-ldp)# log neighbor
```



Note

A logging message is issued when an LDP session state changes from up to down (and down to up).

The following shows sample output of logging events that can be displayed on the console:

```
RP/0/0/CPU0:router:10 21:11:32.111:mpls_ldp[113]:%LDP-5-NBR_CHANGE: Nbr 10.44.44.44:0, DOWN
```

Related Commands

Command	Description
show mpls ldp neighbor, on page 90	Displays information about LDP neighbors.

log nsr

To enable logging of nonstop routing (NSR) synchronization events, use the **log nsr** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

log nsr

no log nsr

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes MPLS LDP configuration

Command History	Release	Modification
	Release 3.6.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	mpls-ldp	read, write

Examples The following example shows how to enable logging of NSR synchronization events:

```
RP/0/0/CPU0:router(config-ldp) # log nsr
```

log session-protection

To enable logging of notices describing LDP session protection events, use the **log session-protection** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

log session-protection

no log session-protection

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes MPLS LDP configuration

Command History	Release	Modification
	Release 3.3.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **log session-protection** command to receive a syslog or console message when LDP session protection event occurs. These events include LDP session protection initiation, recovery, and timeout.

Task ID	Task ID	Operations
	mpls-ldp	read, write

Examples The following example shows how to enable logging messages for session protection events:

```
RP/0/0/CPU0:router(config-ldp)# log session-protection
```



Note

Logging messages are issued when session protection events occur.

The following sample output shows the logging events that are displayed on the console:

```
RP/0/0/CPU0:router:Apr 21 12:15:01.742: mpls_ldp[315]:%ROUTING-LDP-5-SESSION_PROTECTION:
Session hold up initiated for peer 4.4.4.4:0
```

```
RP/0/0/CPU0:router:Apr 21 12:18:04.987: mpls_ldp[315]:%ROUTING-LDP-5-SESSION_PROTECTION:  
Session recovery succeeded for peer 4.4.4.4:0
```

Related Commands

Command	Description
show mpls ldp neighbor, on page 90	Displays information about LDP neighbors.

maximum interfaces (MPLS LDP)

To configure upper limit on maximum number of LDP configured interfaces, use the **maximum interfaces** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

maximum interfaces *number*

no maximum interfaces

Syntax Description

<i>number</i>	Maximum number of LDP configured interfaces. Default is 800.

Command Default

By default, you can enable LDP on up to 800 interfaces.

Command Modes

MPLS LDP configuration

Command History

Release	Modification
Release 3.3.0	This command was introduced.
Release 3.5.1	Support for this command was removed.
Release 3.8.0	This command was moved to 'hidden' status and is no longer valid.
Release 4.0.1	This command was removed.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-ldp	read, write

Examples

The following example shows how to set an upper limit of 150 as maximum number of LDP interfaces, which can be enabled on the box:

```
RP/0/0/CPU0:router(config-ldp)# maximum interfaces 150
```

Related Commands

Command	Description
show mpls ldp discovery, on page 72	Displays LDP discovery information.
show mpls ldp summary, on page 101	Displays LDP summary information.

mpls ldp

To enter MPLS Label Distribution Protocol (LDP) configuration mode, use the **mpls ldp** command in global configuration mode.

mpls ldp

Syntax Description

This command has no arguments or keywords.

Command Default

No default behavior or values

Command Modes

Global configuration

Command History

Release	Modification
Release 3.9.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-ldp	read, write

Examples

The following example shows how to MPLS LDP configuration mode:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls ldp
RP/0/0/CPU0:router(config-ldp)
```


neighbor password

To configure password authentication using the TCP Message Digest 5 (MD5) option for a neighbor, use the **neighbor password** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

neighbor *IP-address* **password** {**clear** | **encrypted**} *password*

no neighbor *IP-address* **password**

Syntax Description

<i>IP-address</i>	Neighbor IP address.
clear	Clears the password for the encryption parameter to specify that an unencrypted password will follow.
encrypted	Specifies that an encrypted password will follow.
<i>password</i>	Clear text or encrypted password string.

Command Default

LDP sessions are negotiated without any password (and MD5).

Command Modes

MPLS LDP configuration

Command History

Release	Modification
Release 3.2	The command was changed to use clear and encrypted instead of the numbers 0/7 .
Release 3.8.0	The command functionality was modified in the way the neighbor password command was being used for configuring global default passwords.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

This security feature is enabled per neighbor, so that a session establishment attempt is allowed only when a password match has been configured. This option must be configured so that both peer passwords match.

To override the default password for a specific neighbor, use the **neighbor IP-address password** command, where the *IP-address* argument is the IP address of the neighbor.

**Note**

The global default password must be configured before being able to override the default password for a specific neighbor.

Task ID

Task ID	Operations
mpls-ldp	read, write

Examples

The following example shows how to configure the password *abc* for neighbor 10.20.20.20:

```
RP/0/0/CPU0:router(config-ldp)# neighbor 10.20.20.20 password clear abc
```

Related Commands

Command	Description
neighbor targeted, on page 56	Configures transmission of targeted hellos towards a neighbor.

neighbor password disable

To override an individual neighbor which requires no password, use the **neighbor password disable** command in MPLS LDP configuration mode.

neighbor *IP-address* **password disable**

Syntax Description

<i>IP-address</i>	Neighbor IP address.

Command Default

LDP sessions are negotiated without any password (and MD5).

Command Modes

MPLS LDP configuration

Command History

Release	Modification
Release 3.8.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The system uses the global password to compute each neighbor's effective password and overrides the global password with the individual neighbor password, if configured. The session remains stable if you shift from an individual neighbor password to an equal global password. However, if the effective password changes during configuration, the session might be rendered unstable.



Note

You must configure the password for an individual neighbor using the neighbor's LSR ID.

Task ID

Task ID	Operations
mpls-ldp	read, write

Examples

The following example shows how to override the individual password *abc*, for the neighbor:

```
RP/0/0/CPU0:router(config-ldp)# neighbor 10.20.20.20 password disable abc
RP/0/0/CPU0:router(config-ldp)#
```

neighbor targeted

To configure transmission of targeted hellos toward a neighbor for setting up an LDP session, use the **neighbor targeted** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

neighbor *IP address* **targeted**

no neighbor *IP address* **targeted**

Syntax Description

IP address

Neighbor IP address.

Command Default

No default behavior or values

Command Modes

MPLS LDP configuration

Command History

Release

Release 3.3.0

Modification

This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID

mpls-ldp

Operations

read, write

Examples

The following example shows how to set up a targeted discovery session for neighbor 200.1.1.1:

```
RP/0/RP0/CPU0:router(config-ldp)# neighbor 200.1.1.1 targeted
```

Related Commands

Command	Description
neighbor password , on page 53	Configures password authentication using MD5.
show mpls ldp neighbor , on page 90	Displays information about LDP neighbors.

Command	Description
show mpls ldp discovery, on page 72	Displays information about LDP discovery sources.

nsr (MPLS-LDP)

To configure nonstop routing for LDP protocols in the event of a disruption in service, use the **nsr** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

nsr

no nsr

Syntax Description This command has no arguments or keywords.

Command Default By default, MPLS LDP NSR is disabled.

Command Modes MPLS LDP configuration

Command History	Release	Modification
	Release 3.6.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

A disruption in service may include any of the following events:

- Route processor (RP) or distributed route processor (DRP) failover
- LDP process restart
- In-service system upgrade (ISSU)
- Minimum disruption restart (MDR)

Enabling NSR causes events such as these to be invisible to the routing peers and provide minimal service disruption.



Note

The LDP Process restart is supported by NSR only if the NSR process-failures switchover is configured, else the process restart causes the session to be unstable.

Task ID	Task ID	Operations
	mpls-ldp	read, write

Examples

The following example shows how to enable MPLS LDP NSR:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls ldp
RP/0/0/CPU0:router(config-ldp)# nsr
```

Related Commands

Command	Description
nsr process-failures switchover	Configures switchover as a recovery action for active instances to switch over to a standby RP or a DRP, to maintain NSR. For more information, see <i>Cisco IOS XRIP Addresses and Services Command Reference for the Cisco XR 12000 Series Router</i> .
show mpls ldp neighbor , on page 90	Displays standby node specific information.

router-id (MPLS LDP)

To specify the IP address of a preferred interface or a specific IP address as the LDP router ID, use the **router-id** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

router-id *IP-address*

no router-id

Syntax Description

<i>IP-address</i>	32-bit router ID value specified in four-part, dotted-decimal notation.

Command Default

LDP uses router ID as determined by global router ID agent, IP Address Repository Manager (IP ARM).

Command Modes

MPLS LDP configuration

Command History

Release	Modification
Release 3.2	This command was supported.
Release 3.4.0	Deprecated interface keyword.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **router-id** command lets you specify an interface with an IP address to be used as the LDP router ID (which is necessary when an IP address selected as the LDP router ID might not be advertisable by the routing protocol to a neighboring router). In such cases, use the **router-id** command to select the IP address of the specified loopback interface (if the interface is operational) or a specific IP address.

LDP uses the router ID from different sources in the following order:

- 1 Configured LDP router ID.
- 2 Global router ID (if configured).
- 3 Calculated (computed) using the primary IPv4 address of the highest numbered configured loopback address. We recommend configuring at least one loopback address.



Note

We recommend that you configure an IP address for the LDP router-id to avoid unnecessary session flaps.

Task ID

Task ID	Operations
mpls-ldp	read, write

Examples

The following example shows how to specify an IP address as the LDP router ID:

```
RP/0/0/CPU0:router(config-ldp)#router-id 10.0.0.1
```

Related Commands

Command	Description
show mpls ldp discovery, on page 72	Displays the status of the LDP discovery process.
show mpls ldp neighbor, on page 90	Displays information about LDP neighbors.
show mpls ldp parameters, on page 96	Displays current LDP parameter settings.

session protection

To enable the LDP session protection feature for keeping LDP peer session up by means of targeted discovery following the loss of link discovery with a peer, use the **session protection** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

session protection [**duration** *seconds*| **infinite**] [**for** *peer-acl*]

no session protection

Syntax Description

duration <i>seconds</i>	(Optional) Specifies the protection duration, that is, the number of seconds that targeted discovery should continue following the loss of link discovery to a neighbor. Range is 30 to 2147483.
infinite	(Optional) Specifies session protection to last forever after loss of link discovery.
for <i>peer-acl</i>	(Optional) Specifies set of LDP peers for which session protection is to be enabled.

Command Default

By default, session protection is disabled. When enabled without peer-acl and duration, session protection is provided for all LDP peers and continues for 24 hours after a link discovery loss.

Command Modes

MPLS LDP configuration

Command History

Release	Modification
Release 3.3.0	This command was introduced.
Release 3.4.0	Default value for duration keyword changed from infinite to 24 hours. The infinite keyword was added for duration value.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

LDP session protection feature allows you to enable the automatic setup of targeted hello adjacencies with all or a set of peers and specify the duration for which session needs to be maintained using targeted hellos after loss of link discovery.

LDP supports only IPv4 standard access lists.

Task ID

Task ID	Operations
mpls-ldp	read, write

Examples

The following example shows how to enable session protection for all discovered peers with unlimited duration to maintain the session after link discovery loss:

```
RP/0/0/CPU0:router(config-ldp)# session protection
```

The following example shows how to enable session protection for a set of peers (as permitted by a peer ACL) with duration of 30 seconds to maintain the session after link discovery loss:

```
RP/0/0/CPU0:router(config-ldp)# session protection for peer_acl duration 30
```

Related Commands

Command	Description
show mpls ldp neighbor, on page 90	Displays information about LDP neighbors.

show mpls ldp backoff

To display information about the configured session setup backoff parameters and any potential LDP peers with which session setup attempts are being throttled, use the **show mpls ldp backoff** command in EXEC mode.

show mpls ldp backoff [*location node-id* | *standby*]

Syntax Description

location <i>node-id</i>	(Optional) Displays location information for the specified node ID.
standby	(Optional) Displays standby-node-specific information.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was supported.
Release 3.9.0	The location and standby keywords were added.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

You must enable the MPLS LDP application to use the **show mpls ldp backoff** command.

Task ID

Task ID	Operations
mpls-ldp	read

Examples

The following shows a sample output from the **show mpls ldp backoff** command:

```
RP/0/0/CPU0:router# show mpls ldp backoff

Backoff Time:
  Initial:15 sec, Maximum:120 sec

Backoff Table: (2 entries)
```

```

LDP Id                Backoff (sec)  Waiting (sec)
-----
33.33.33.33:0         15          15
11.11.11.11:0         30          30

```

This table describes the significant fields shown in the display.

Table 2: show mpls ldp backoff Command Field Descriptions

Field	Description
Backoff Time	Initial and maximum backoff time parameters, in seconds.
Backoff Table	List of discovered LDP neighbors for which session setup is being delayed because of previous failures to establish a session due to incompatible configuration. The backoff table incorporates the following information: LDP Id Identifies the LDP neighbors. Backoff (sec) Specifies the time that the session setup is delayed. Waiting (sec) Specifies an approximate time the session setup has been delayed.

Related Commands

Command	Description
backoff , on page 3	Configures LDP backoff parameters.
show mpls ldp forwarding , on page 77	Displays the contents of MPLS forwarding table.
show mpls ldp bindings , on page 66	Displays the contents of LDP LIB.

show mpls ldp bindings

To display the contents of the Label Information Base (LIB), use the **show mpls ldp bindings** command in EXEC command.

show mpls ldp bindings [*IP-address /prefix {mask| length}*] [**advertisement-acls**] [**brief**] [**detail**] [**local**] [**local-label** *label* [*to label*]] [**local-only**] [**neighbor** *address*] [**remote-only**][**remote-label** *label* [*to label*]] [**summary**] [**location** *node-id*] **standby**

Syntax Description

<i>IP-address /prefix</i>	(Optional) Destination prefix/mask length, written in A.B.C.D format.
<i>mask</i>	Network mask, written in A.B.C.D format.
<i>length</i>	Mask length, in bits. Range is 0 to 32.
advertisement-acls	(Optional) Displays the label bindings as applied for (advertisement) outbound label filtering ACLs.
brief	(Optional) Displays all the prefixes in the LDP database.
detail	(Optional) Displays the total counts of advertised-to and remote-binding peers in IP address sort order, with remote bindings in tabular format.
local	(Optional) Displays the local label bindings.
local-label <i>label</i> [<i>to label</i>]	(Optional) Displays entries matching local label values. Add the <i>label to label</i> argument to indicate the label range.
local-only	(Optional) Displays binding matches with a local label only.
neighbor <i>address</i>	(Optional) Displays the label bindings assigned by the selected neighbor.
remote-only	(Optional) Displays bindings matches with a remote label only.
remote-label <i>label</i> [<i>to label</i>]	(Optional) Displays entries matching the label values assigned by a neighbor router. Add the <i>label to label</i> argument to indicate the label range. Range is from 0 to 2147483647.
summary	(Optional) Displays a summary of the contents of the Label Information Base (LIB).
location <i>node-id</i>	(Optional) Displays location information for the specified node ID.
standby	(Optional) Displays standby-node-specific information.

Command Default

No default behavior or values

Command Modes EXEC

Command History	Release	Modification
	Release 3.2	The advertisement-acls keyword was supported.
	Release 3.6.3	The location , standby , remote-only , remote-label , and local-only keywords were added.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show mpls ldp bindings** command displays local and remote label bindings learned from neighbors for non-BGP routes (such as IGP prefixes and static routes).

You can choose to view the entire database or a subset of entries according to the following criteria:

- Prefix
- Input or output label values or ranges
- Neighbor advertising the label



Note The **show mpls ldp bindings summary** command displays summarized information from the LIB and is used when testing scalability or when deployed in a large scale network.

Task ID	Task ID	Operations
	mpls-ldp	read

Examples The following sample output displays the contents of the LIB for the default routing domain:

```
RP/0/0/CPU0:router# show mpls ldp bindings

 5.41.0.0/16 , rev 4
    local binding: label:IMP-NULL
    No remote bindings
 5.43.9.98/32 , rev 6
    local binding: label:IMP-NULL
    No remote bindings
10.10.2.0/24 , rev 12
    local binding: label:IMP-NULL
    remote bindings :
      lsr:10.255.255.255:0, label:16
      lsr:10.256.256.256:0, label:IMP-NULL
```

show mpls ldp bindings

```

10.10.3.0/24 , rev 10
  local binding: label:IMP-NULL
  remote bindings :
    lsr:10.255.255.255:0, label:IMP-NULL
    lsr:10.256.256.256:0, label:22
22.22.22.22/32 , rev 14
  local binding: label:16
  remote bindings :
    lsr:10.255.255.255:0, label:17
    lsr:10.256.256.256:0, label:IMP-NULL
33.33.33.33/32 , rev 2
  local binding: label:IMP-NULL
  remote bindings :
    lsr:10.255.255.255:0, label:18
    lsr:10.256.256.256:0, label:23

```

The following sample output shows detailed information for the total counts of advertised-to and remote-binding peers in IP address sort order, with remote bindings for 150.150.150.150/32:

```
RP/0/0/CPU0:router# show mpls ldp bindings 150.150.150.150/32 detail
```

```

150.150.150.150/32, rev 2
  Local binding: label: IMP-NULL
  Advertised to: (6 peers)
    120.120.120.120:0  130.130.130.130:0  150.150.150.1:0  150.150.150.2:0
    150.150.150.3:0   150.150.150.4:0
  Remote bindings:    (3 peers)
    Peer              Label
    -----
    120.120.120.120:0  27018
    130.130.130.130:0  26017
    160.160.160.160:0  27274

```

The following sample output specifies a network number and displays labels learned from label switched router (LSR) 10.255.255.255 for all networks. The **neighbor** keyword is used to suppress the output of remote labels learned from other neighbors:

```
RP/0/0/CPU0:router# show mpls ldp bindings neighbor 10.255.255.255
```

```

10.10.2.0/24 , rev 12
  local binding: label:IMP-NULL
  remote bindings :
    lsr:10.255.255.255, label:16
10.10.3.0/24 , rev 10
  local binding: label:IMP-NULL
  remote bindings :
    lsr:10.255.255.255:0, label:IMP-NULL
22.22.22.22/32 , rev 14
  local binding: label:16
  remote bindings :
    lsr:10.255.255.255:0, label:17
33.33.33.33/32 , rev 2
  local binding: label:IMP-NULL
  remote bindings :
    lsr:10.255.255.255:0, label:18
44.44.44.44/32 , rev 16
  local binding: label:17
  remote bindings :
    lsr:10.255.255.255:0, label:IMP-NULL

```

This table describes the significant fields shown in the display.

Table 3: show mpls ldp bindings and show mpls ldp bindings neighbor Command Field Descriptions

Field	Description
a.b.c.d/n	IP prefix and mask for a particular destination (network/mask).
rev	Revision number (rev) that is used internally to manage label distribution for this destination.
local binding	Locally assigned label for a prefix.
remote bindings	Outgoing labels for this destination learned from other LSRs. ¹ Each item in this list identifies the LSR from which the outgoing label was learned and reflects the label associated with that LSR. Each LSR in the transmission path is identified by its LDP identifier.
(rewrite)	Binding has been written into MPLS forwarding and is in use.
(no route)	Route is not valid. LDP times it out before the local binding is deleted.

¹ Label switched routers.

The following sample output summarizes the content by using the **summary** keyword:

```
RP/0/0/CPU0:router# show mpls ldp bindings summary
```

```
LIB Summary:
  Total Prefix      : 20
  Revision No       : Current:34, Advertised:34
  Local Bindings    : 14
    NULL           : 10 (implicit:10, explicit:0)
    Non-NULL: 4 (lowest:48, highest:51)
  Remote Bindings: 24
```

This table describes the significant fields shown in the display.

Table 4: show mpls ldp bindings summary Command Field Descriptions

Field	Description
Total Prefix	Number of prefixes (routes) known to LDP LIB. All invalid and timed-out routes display as no-routes.

Field	Description
Revision No	Current revision number of LIB entries as well as the minimum revision number that has been advertised to all peers.
Local Bindings	Total number of local bindings, with information on how many of them are Null, non-null, and lowest/highest label assigned or allocated by LDP.
Remote Bindings	Number of remote bindings.

The following sample output shows the access-list advertisement:

```
RP/0/0/CPU0:router# show mpls ldp bindings advertisement-acls

Advertisement Spec:
  Prefix ACL = 'pfx_11'
  Prefix ACL = 'pfx_22'
  Prefix ACL = 'pfx_40_1'; Peer ACL = 'peer_11'

5.41.0.0/16 , rev 82
11.11.11.11/32 , rev 69
  Advert ACL(s): Prefix ACL 'pfx_11'
20.20.20.20/32 , rev 83
22.22.22.22/32 , rev 78
  Advert ACL(s): Prefix ACL 'pfx_22'
40.1.1.0/24 , rev 79
  Advert ACL(s): Prefix ACL 'pfx_40_1'; Peer ACL 'peer_11'
```

This table describes the significant fields shown in the display.

Table 5: show mpls ldp bindings advertisement-acls Command Field Descriptions

Field	Description
Advertisement Spec	Lists all prefix and peer access-lists used as outbound label advertisement control.
Advert ACL(s)	Lists the first matching rule (if any) for the prefix entry for outbound label advertisement control (for prefix-acl).

The following sample output shows all the prefixes in the LDP database using the **brief** keyword:

```
RP/0/0/CPU0:router# show mpls ldp bindings brief

Prefix                Local Advertised Remote Bindings
Label (peers)         (peers)
-----
1.1.2.2/32            -          0          1
1.2.3.4/32            16010      396        0
4.4.4.4/32            16004      396        3
10.0.0.0/24           19226      396       395
```

The following sample output shows that the binding matches with a local label:

```
RP/0/0/CPU0:router# show mpls ldp bindings local-only

10.12.32.2/32, rev 4
  Local binding: label: IMP-NULL
  No remote bindings
```

The following sample output shows that the binding matches with a remote label:

```
RP/0/0/CPU0:router# show mpls ldp bindings remote-only

10.26.4.0/24, rev 0
  No local binding
  Remote bindings: (1 peers)
    Peer          Label
    -----
    10.6.6.6:0    IMP-NULL
10.43.4.0/24, rev 0
  No local binding
  Remote bindings: (1 peers)
    Peer          Label
    -----
    10.4.4.4:0    IMP-NULL
10.46.4.0/24, rev 0
  No local binding
  Remote bindings: (2 peers)
    Peer          Label
    -----
    10.4.4.4:0    IMP-NULL
    10.6.6.6:0    IMP-NULL
```

Related Commands

Command	Description
label accept, on page 36	Configures the LDP remote label acceptance.
label advertise, on page 38	Configures the LDP local label advertisement control.
show mpls ldp neighbor, on page 90	Displays information on the LDP neighbors.
show mpls ldp forwarding, on page 77	Displays the contents of the LDP forwarding database.

show mpls ldp discovery

To display the status of the LDP discovery process, use the **show mpls ldp discovery** command in EXEC mode.

show mpls ldp discovery [*IP-address type interface-path-id*] **brief** | **link** | **targeted** | **summary**] [**detail**] [**location** *node-id*] **standby**]

Syntax Description

<i>IP-address</i>	(Optional) Neighbor IP address.
<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
brief	(Optional) Displays concise information about a specified LDP-enabled interface.
link	(Optional) Displays link information for LDP discovery.
targeted	(Optional) Displays targeted information for LDP discovery.
summary	(Optional) Displays summarized information for LDP discovery.
detail	(Optional) Displays detailed information (including, inbound label filtering, session KAs, and session protection state) for an LDP session.
location <i>node-id</i>	(Optional) Displays location information for the specified node ID.
standby	(Optional) Displays standby node-specific information.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was supported.
Release 3.3.0	The summary keyword was added.

Release	Modification
Release 3.6.3	The following items were added: • The location keyword was added. • The standby keyword was added. • Sample output was added for the brief keyword.
Release 3.9.0	The following items were added: • The link keyword was added. • The targeted keyword was added.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show mpls ldp discovery command** shows both link discovery and targeted discovery. When no interface filter is specified, this command generates a list of interfaces running the LDP discovery process. This command also displays neighbor discovery information for the default routing domain.

Task ID

Task ID	Operations
mpls-ldp	read

Examples

The following sample output is from the **show mpls ldp discovery** command:

```
RP/0/0/CPU0:router# show mpls ldp discovery

Local LDP Identifier: 10.44.44.44:0
Discovery Sources:
  Interfaces:
    POS 0/1/0/0 : xmit/recv
      LDP Id: 10.33.33.33:0, Transport address: 10.33.33.33
      Hold time: 15 sec (local:15 sec, peer:15 sec)
```

This table describes the significant fields shown in the display.

Table 6: show mpls ldp discovery Command Field Descriptions

Field	Description
Local LDP Identifier	LDP identifier for the local router. An LDP identifier is a 6-byte construct displayed in the form IP address:number. By convention, the first 4 bytes of the LDP identifier constitute the router ID; integers, starting with 0, constitute the final two bytes of the IP address:number construct.
Interfaces	Interfaces engaged in LDP discovery activity, as follows: xmit field Indicates that the interface is transmitting LDP discovery hello packets. recv field indicates that the interface is receiving LDP discovery hello packets. The LDP identifiers indicate the LDP neighbors discovered on the interface.
Transport Address	Address associated with this LDP peer (advertised in hello messages).
LDP Id	LDP identifier of the LDP peer.
Hold time	State of the forwarding hold timer and its current value.

The following sample output summarizes information for LDP discovery by using the **summary** keyword:

```
RP/0/0/CPU0:router# show mpls ldp discovery summary

LDP Identifier: 139.0.0.1:0
Interfaces:
  Configured: 2
  Enabled   : 1
Discovery:
  Hello xmit: 1 (1 link)
  Hello recv: 1 (1 link)
```

This table describes the significant fields shown in the display.

Table 7: show mpls ldp discovery summary Command Field Descriptions

Field	Description
LDP Identifier	The LDP identifier for the local router.

Field	Description
Interfaces	Summary of interfaces engaged in LDP activity. Configured Number of interfaces configured for LDP. Enabled Number of interfaces on which LDP is actively enabled and is thus sending LDP hellos. An interface configured for LDP is enabled only if running IP and not in the down state.
Discovery	Summary of LDP discovery process. Hello xmit Number of local LDP discovery sources (including link and targeted hellos) emitting LDP hellos. Hello rcv Number of discovered hello sources via link or targeted hello mechanics.

The following sample output MPLS LDP discovery hello information in brief form:

RP/0/0/CPU0:router# **show mpls ldp discovery brief**

Local LDP Identifier: 150.150.150.150:0

Discovery Source	Peer LDP Id	Holdtime	Session
BE35	130.130.130.130:0	15	Y
Gi0/6/0/6	160.160.160.160:0	15	Y
Gi0/6/2/7.1	174.1.1.2:0	45	Y
Target: 120.120.120.120	120.120.120.120:0	90	Y
Target: 150.150.150.1	150.150.150.1:0	120	Y

Related Commands

Command	Description
discovery hello, on page 12	Configures LDP link hello parameters.
discovery targeted-hello, on page 15	Configures LDP targeted-hello parameters.
neighbor targeted, on page 56	Configures LDP targeted neighbor.
session protection, on page 62	Configures LDP session protection.

Command	Description
interface (MPLS LDP), on page 34	Configures LDP on an interface.
show mpls ldp neighbor, on page 90	Displays information about LDP neighbors.

show mpls ldp forwarding

To display the Label Distribution Protocol (LDP) forwarding state installed in MPLS forwarding, use the **show mpls ldp forwarding** command in EXEC mode.

show mpls ldp forwarding [*IP -address*] [*{mask|length}*] [**fast-reroute**] [**detail**] [**next-hop**] **address** *IP-address* | **interface** *interface-path-id* | **label** *label-value* | **neighbor** *IP -address* | **unlabelled**] [**local-label** *label-value*] [**location** *node-id*] **summary** | **standby**]

Syntax Description

<i>IP-address</i>	(Optional) IP address, specified in four-part, dotted-decimal notation.
<i>mask</i>	Network mask.
<i>length</i>	Mask length, in bits. Range is 0 to 32.
detail	(Optional) Displays detailed information for the LDP timestamp that is used for the routing and forwarding update.
fast-reroute	(Optional) Displays the prefix that is LFA FRR protected in nature.
next-hop	Matches prefixes by next-hop IP address.
local-label <i>label-value</i>	(Optional) Displays the prefix with the specified local label. Range is from 0 to 1048575.
neighbor	Matches prefixes with a path through specified LDP neighbor.
unlabelled	Matches prefixes containing unlabelled paths.
location <i>node-id</i>	(Optional) Displays location information for the specified node ID.
summary	(Optional) Displays the summary information for the LDP forwarding information base (LFIB).
standby	(Optional) Displays standby-node specific information.

Command Default No default behavior or values

Command Modes EXEC

Release	Modification
Release 3.2	This command was supported.
Release 3.3.0	Sample output was modified.
Release 3.9.0	The following items were added: • The detail keyword. • Sample output for the detail keyword. • The local-label keyword. • The location keyword. • The standby keyword.
Release 4.0.1	These items were added: • The fast-reroute keyword. • The summary keyword. • The next-hop keyword. • The neighbor keyword. • The unlabelled keyword.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show mpls ldp forwarding** command displays the LDP forwarding entries and provides LDP view of its installed forwarding entries.

Task ID	Task ID	Operations
	mpls-ldp	read

Examples

This is a sample output from the **show mpls ldp forwarding** command:

```
RP/0/0/CPU0:router# show mpls ldp forwarding
```

Prefix	Label In	Label Out	Outgoing Interface	Next Hop	GR Stale
2.2.2.2/32	22	ImpNull	PO0/2/0/1	12.0.0.2	N N
3.0.0.1/32	24	20	PO0/2/0/1	12.0.0.2	N N
3.0.0.2/32	25	21	PO0/2/0/1	12.0.0.2	N N
3.0.0.3/32	26	22	PO0/2/0/1	12.0.0.2	N N
4.4.4.4/32	20	ExpNullv4	tt10	4.4.4.4	N N
4.4.4.5/32	21	ExpNullv4	tt10	4.4.4.4	N N
123.0.0.0/24	23	ImpNull	PO0/2/0/1	12.0.0.2	N N
3.3.3.3/32	16000	16001	PO0/2/0/3.1	131.1.1.4	Y N
		16002	PO0/2/0/3.2	131.1.2.4	Y N
		16003	PO0/2/0/3.3	131.1.3.4	N N
		16002	PO0/2/0/1	192.11.1.1 (!)	Y N
		Unlabelled	PO0/2/0/2	192.11.2.1 (!)	N N

**Note**

The (!) symbol refers to a non-primary LFA backup path.

This sample output shows detailed information for the LDP timestamp that is used for routing and forwarding update from the **detail** keyword:

```
RP/0/0/CPU0:router# show mpls ldp forwarding 1.1.1.1/32 detail
```

Prefix	Label In	Label Out	Outgoing Interface	Next Hop	GR Stale
3.3.3.3/32	16000	16001	PO0/2/0/3.1	131.1.1.4	N N
		[Protected; path-id 1 backup-path-id 33; peer 13.13.13.1:0]			
		16002	PO0/2/0/3.2	131.1.2.4	Y N
		[Protected; path-id 2 backup-path-id 33; peer 13.13.13.1:0]			
		16003	PO0/2/0/3.3	131.1.3.4	N N
		[Protected; path-id 3 backup-path-id 34; peer 13.13.13.2:0]			
		16002	PO0/2/0/1	192.11.1.1 (!)	Y N
		[Backup; path-id 33; peer 14.14.14.1:0]			
		Unlabelled	PO0/2/0/2	192.11.2.1 (!)	N N
		[Backup; path-id 34]			

```
Routing update : Mar 31 13:35:25.348 (00:55:32 ago)
Forwarding update: Mar 31 13:35:25.349 (00:55:32 ago)
```

**Note**

The (!) symbol refers to a non-primary LFA backup path.

This sample output shows only LDP prefixes with protection (ECMP or secondary LFA backups) update from the **fast-reroute** keyword:

This sample output shows the statistics of protected prefixes and protected paths from the **summary** keyword:

```
RP/0/0/CPU0:router# show mpls ldp forwarding summary
Forwarding Server (LSD):
  Connected: Yes
```

show mpls ldp forwarding

```

Forwarding State Holdtime: 360 sec
Forwarding States:
Interfaces: 10
Local labels: 8
Rewrites:
  Prefix:
    Total: 8 (0 with ECMP, 8 FRR protected)
    Labelled:
      Primary pathset : 8 labelled (0 partial), 0 unlabelled
      Backup pathset  : 8 labelled (0 partial), 0 unlabelled
      Complete pathset: 8 labelled (0 partial), 0 unlabelled
  Paths:
    Total: 16 (8 backup, 8 FRR protected)
    Labelled: 16 (8 backup)

```

This table describes the significant fields shown in the display.

Table 8: show mpls ldp forwarding Command Field Descriptions

Field	Description
Prefix/mask	Prefix on the FEC ² for an MPLS forwarding entry.
Label In	Local label assigned to the prefix/mask.
Label Out	Outgoing label for the prefix/mask.
Outgoing Interface	Outgoing physical interface.
Next Hop	Next Hop address.
GR	Graceful restart status (Y or N).
Stale	Status of the entry, stale or not stale. An entry is marked stale when the next-hop graceful restart neighbor disconnects and is unmarked when neighbor reconnects and refreshes the label.
Chkpt	Status of the entry, checkpointed or not checkpointed.
path-id	Primary Path-id.
Backup-path-id	The backup path-id is the path-id of the path protecting a given primary path. A protecting path can be primary path or a non-primary path.
Peer	Displays next-hop LDP peer's LDP identifier.
Connected	Displays LDP connection state with LSD forwarding server.
Forwarding State Holdtime	Displays time that LDP has registered with LSD server to keep LDP forwarding state intact upon LDP disconnect event.

Field	Description
Interfaces	Number of LDP enabled MPLS interfaces.
Local Labels	Number of LDP allocated local labels from LSD.
Rewrites	Counts of Forwarding rewrites. Displays total number of known IPv4 prefixes alongwith information on number of prefixes with more than one ECMP path. This also displays number of prefixes with LFA-FRR protection. The labelled set prints the counts related to prefixes with none, all, partial labelled paths as shown by unlabeled, labelled, and partial keywords. This information is available for primary, backup, and complete path set.
Paths	Forwarding path counts. Displays count of total number of known forwarding paths, along with number of backup paths and number of FRR protected paths. It also displays the count of labelled paths indicating how many of non-primary paths are labelled.

² Forwarding Equivalence Class.

Related Commands

Command	Description
graceful-restart (MPLS LDP), on page 23	Configures the LDP graceful restart feature.
show mpls ldp bindings, on page 66	Displays the contents of LDP LIB.

show mpls ldp graceful-restart

To display the status of the Label Distribution Protocol (LDP) graceful restart, use the **show mpls ldp graceful-restart** command in EXEC mode.

show mpls ldp graceful-restart [**location** *node-id* | **standby**]

Syntax Description

location <i>node-id</i>	(Optional) Displays location information for the specified node ID.
standby	(Optional) Displays standby-node-specific information.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was supported.
Release 3.9.0	The location and standby keywords were added.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show mpls ldp graceful-restart** command displays LDP graceful-restart-related information when the **graceful-restart** command is enabled.

Task ID

Task ID	Operations
mpls-ldp	read

Examples

The following shows a sample output from the **show mpls ldp graceful-restart** command:

```
RP/0/0/CPU0:router# show mpls ldp graceful-restart
```

```
Forwarding State Hold timer : Not Running
GR Neighbors                : 1
```

```
Neighbor ID      Up    Connect Count  Liveness Timer      Recovery Timer
```

```

-----
10.0.0.2      Y      1      -      -

```

This table describes the significant fields shown in the display.

Table 9: show mpls ldp graceful-restart Command Field Descriptions

Field	Description
Forwarding State Hold timer	State of the hold timer—running or not running.
GR Neighbors	Number of graceful restartable neighbors.
Neighbor ID	Router ID of each neighbor.
Up	Neighbor up or down.
Connect Count	Number of times the same neighbor has reconnected.
Liveness Timer	State of the liveness timer (running or not running) and its expiration time, if running.
Recovery Timer	State of the recovery timer (running or not running) and its expiration time, if running.

Related Commands

Command	Description
graceful-restart (MPLS LDP), on page 23	Configures the LDP graceful restart feature.
show mpls ldp neighbor, on page 90	Displays information about LDP neighbors.

show mpls ldp igp sync

To display Label Distribution Protocol (LDP) Interior Gateway Protocol (IGP) synchronization information on interface(s), use the **show mpls ldp igp sync** command in EXEC mode.

show mpls ldp igp sync [*interface type interface-path-id*] [*location node-id* | **standby**]

Syntax Description

interface	(Optional) Displays the interface type.
<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	(Optional) Physical interface or a virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
location <i>node-id</i>	(Optional) Displays location information for the specified node ID.
standby	(Optional) Displays standby-node-specific information.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.3.0	This command was introduced.
Release 3.9.0	The location and standby keywords were added.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

LDP IGP synchronization addresses traffic loss issues as a result of synchronization between MPLS LDP and IP (IGP). For instance, upon a link up, IGP can advertise a link before MPLS converges on the link. Also, the IGP link is still used even when MPLS session goes down and MPLS LSP is broken on this link. The use of IGP link is determined based on MPLS LDP convergence synchronization status on the link.

Use the **show mpls ldp igp sync** command to display MPLS convergence status. The configuration for LDP IGP synchronization resides in IGP (OSPF, ISIS); accordingly, LDP displays and advertises this information for all LDP-enabled interfaces (regardless if the interface is configured for LDP IGP).

Task ID

Task ID	Operations
mpls-ldp	read

Examples

The following shows a sample output from the **show mpls ldp igp sync** command:

```
RP/0/0/CPU0:router# show mpls ldp igp sync

GigabitEthernet0/3/0/0:
  Sync status: Ready
  Peers:
    2.2.2.2:0
    3.3.3.3:0 (GR)
  GR-only Reachability:
    4.4.4.4:0 (Chkpt-created)

POS0/2/0/0:
  Sync status: Not ready
                (Deferred; 24 sec remaining)

POS0/2/0/1:
  Sync status: Not ready
```

This table describes the significant fields shown in the display.

Table 10: show mpls ldp igp sync Command Field Descriptions

Field	Description
Sync status	MPLS LDP convergence status on a given link. Ready indicates that the link is converged and is ready to be used by IGP. Not Ready with Deferred means that the link fulfills LDP IGP synchronization requirements but is deferred by LDP IGP synchronization delay timeout configuration setting. Not Ready means that the link is not ready to be used by IGP.
Peers	List of peers converged on the given link. If the peer session is GR ³ -enabled, output is tagged as GR. If GR-only reachability is indicated due to a GR neighbor record recovered from checkpoint after local start, then Chkpt-created flag is also set.
GR-only Reachability	List of GR ⁴ peers which are not currently converged on a given link but still in the forwarding state.

³ Graceful Restart.

 show mpls ldp igp sync

⁴ Graceful Restart.

Related Commands

Command	Description
igp sync delay, on page 30	Configures LDP IGP sync delay timeout.

show mpls ldp interface

To display information about LDP-enabled interfaces, use the **show mpls ldp interfaces** command in EXEC mode.

show mpls ldp interface [*type interface-path-id* | **summary**] [**brief**] [**location** *node-id* | **standby**]

Syntax Description

<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
summary	(Optional) Displays summary information about a specified LDP-enabled interface.
brief	(Optional) Displays concise information about a specified LDP-enabled interface.
detail	(Optional) Displays detailed information about a specified LDP-enabled interface.
location <i>node-id</i>	(Optional) Displays location information for the specified node ID.
standby	(Optional) Displays standby-node-specific information.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.5.0	This command was introduced.
Release 3.9.0	The location and standby keywords were added.
Release 4.2.0	The detail keyword was added.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-ldp	read

Examples

The following shows a sample output from the **show mpls ldp interface** command:

```
RP/0/0/CPU0:router# show mpls ldp interface
```

```
Interface GigabitEthernet0/3/0/3
  No LDP config
Interface POS0/2/0/0
  No LDP config
  Auto-config items:
    ospf/100/0
Interface POS0/2/0/1
  No LDP config
  Auto-config items:
    ospf/100/0
Interface POS0/2/0/2
  No LDP config
  Auto-config items:
    ospf/100/0
Interface POS0/2/0/3
  No LDP config
  Auto-config items:
    ospf/100/0
```

This table describes the significant fields shown in the display.

Table 11: show mpls ldp interface Command Field Descriptions

Field	Description
Auto-config items	Lists IGP's that specify an interface for MPLS LDP auto-configuration: OSPF <i>ospf instance area</i> ISIS <i>isis instance</i>

The following shows a sample output from the **show mpls ldp interface detail** command for the mesh groups:

```
RP/0/0/CPU0:router# show mpls ldp interface detail
```

```
Interface GigabitEthernet0/2/0/0 (0x20200040)
  Enabled via config: LDP interface
Interface GigabitEthernet0/2/0/1 (0x20200060)
  Disabled via config: IGP Auto-config disable
  Ignoring: LDP interface
Interface GigabitEthernet0/2/0/2 (0x20200080)
  Disabled via config: IGP Auto-config disable
  Ignoring: LDP interface
Interface tunnel-te1 (0x200000f0)
  Disabled
Interface tunnel-te100 (0x20000110)
  Enabled via config: TE Mesh-group 123, TE Mesh-group all
Interface tunnel-te101 (0x20000130)
  Enabled via config: TE Mesh-group 123, TE Mesh-group all
```

Related Commands

Command	Description
igp auto-config disable, on page 28	Disables LDP auto-configuration.

show mpls ldp neighbor

To display the status of Label Distribution Protocol (LDP) sessions, use the **show mpls ldp neighbor** command in EXEC mode.

show mpls ldp neighbor [*IP-address*] [*type interface-path-id*] [**brief**] [**detail**] [**gr**] [**location** *node-id*] [**non-gr**] [**sp**] [**standby**]

Syntax Description

<i>IP-address</i>	(Optional) Neighbor IP address.
<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
brief	(Optional) Displays the existing LDP sessions in brief format.
detail	(Optional) Displays detailed information (including, inbound label filtering, session KAs, and session protection state) for an LDP session.
gr	(Optional) Displays graceful restartable neighbors.
location <i>node-id</i>	(Optional) Displays location information for the specified node ID.
non-gr	(Optional) Displays non-graceful restartable neighbors.
sp	(Optional) Displays neighbors with session protection.
standby	(Optional) Displays standby-node-specific information.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was introduced.

Release	Modification
Release 3.3.0	Introduced two new keywords: • sp keyword filters sessions with session protection capability • detail keyword displays detailed information including session protection state and hold time
Release 3.6.0	Support was added for the standby keyword.
Release 3.9.0	The following items were added: • The tunnel-gte interface type was added. • The location keyword was added. • Sample output for the brief keyword was modified to add the NSR and IPv4 Label columns.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show mpls ldp neighbor** command provides information about all LDP neighbors in the entire routing domain—conversely, the show output is filtered to display:

- LDP neighbors with specific IP addresses
- LDP neighbors on a specific interface
- LDP neighbors that are graceful restartable
- LDP neighbors that are nongraceful restartable
- LDP neighbors enabled with session protection

Task ID

Task ID	Operations
mpls-ldp	read

Examples

The following shows a sample output from the **show mpls ldp neighbor** command using an IP address:

```
RP/0/0/CPU0:router# show mpls ldp neighbor 10.22.22.22

Peer LDP Identifier: 10.22.22.22:0
TCP connection: 10.22.22.22:646 - 10.33.33.33:65530
Graceful Restart: No
State: Oper; Msgs sent/rcvd: 46/43
Up time: 00:31:21
LDP Discovery Sources:
```

```

POS 0/2/0/0
  Addresses bound to this peer:
    10.22.22.22    10.10.2.1

```

The following shows a sample output from the **show mpls ldp neighbor** command using the **non-gr** keyword:

```

RP/0/0/CPU0:router# show mpls ldp neighbor non-gr

Peer LDP Identifier: 10.44.44.44:0
  TCP connection: 10.44.44.44:65535 - 10.33.33.33:646
  Graceful Restart: No
  State: Oper; Msgs sent/rcvd: 49/46
  Up time: 00:33:33
  LDP Discovery Sources:
    POS 0/1/0/0
  Addresses bound to this peer:
    10.44.44.44    10.10.3.2
Peer LDP Identifier: 10.22.22.22:0
  TCP connection: 10.22.22.22:646 - 10.33.33.33:65530
  Graceful Restart: No
  State: Oper; Msgs sent/rcvd: 48/45
  Up time: 00:33:11
  LDP Discovery Sources:
    POS 0/2/0/0
  Addresses bound to this peer:
    10.22.22.22    10.10.2.1

```

This table describes the significant fields shown in the display.

Table 12: show mpls ldp neighbor Command Field Descriptions

Field	Description
Peer LDP Identifier	LDP identifier of the neighbor (peer) for this session.
TCP connection	TCP connection used to support the LDP session, shown in the following format: neighbor IP address peer port local IP address local port
Graceful Restart	Graceful-restart status (Y or N).
State	State of the LDP session. Generally this is Oper (operational), but transient is another possible state.
Msgs sent/rcvd	Number of LDP messages sent to and received from the session peer. The count includes the transmission and receipt of periodic keepalive messages, which are required for maintenance of the LDP session.
Up time	The length of time that this session has been up for (in <i>hh:mm:ss</i> format).

Field	Description
LDP Discovery Sources	The source(s) of LDP discovery activity leading to the establishment of the LDP session.
Addresses bound to this peer	The known interface addresses of the LDP session peer. These are addresses that might appear as “next hop” addresses in the local routing table. They are used to maintain the LFIB ⁵ .

⁵ LFIB = Label Forwarding Information Base.

The following shows a sample output from the **show mpls ldp neighbor** command using the **brief** keyword:

```
RP/0/0/CPU0:router# show mpls ldp neighbor brief
```

Peer	GR	NSR	Up Time	Discovery	Address	IPv4 Label
2.2.2.2:0	N	Y	01:39:50	1	4	19
3.3.3.3:0	N	N	01:38:04	1	3	5

This table describes the significant fields shown in the display.

Table 13: show mpls ldp neighbor brief Command Field Descriptions

Field	Description
Peer	LDP identifier of the neighbor (peer) for this session.
GR	Graceful-restart status (Y or N).
Up Time	Time the session has been up (in hh:mm:ss format).
Discovery	Number of LDP discovery sources corresponding to the neighbor.
Address	Number of addresses bound to this peer.

The following shows a sample output from the **show mpls ldp neighbor** command using the **detail** keyword:

```
RP/0/0/CPU0:router# show mpls ldp neighbor detail
```

```
Peer LDP Identifier: 2.2.2.2:0
TCP connection: 2.2.2.2:11707 - 1.1.1.1:646
Graceful Restart: No
Session Holdtime: 180 sec
State: Oper; Msgs sent/rcvd: 33/29
Up time: 00:13:37
LDP Discovery Sources:
  POS0/2/0/1
  Targeted Hello (1.1.1.1 ->2.2.2.2, active)
Addresses bound to this peer:
  23.0.0.2 2.0.0.2      123.0.4.2      10.42.37.119
  10.2.2.2
Peer holdtime: 180 sec; KA interval: 60 sec; Peer state: Estab
```

```

Clients: Dir Adj Client
Inbound label filtering: accept acl 'pfx_acl2'
Session Protection:
  Enabled, state: Ready
  Duration: 30 seconds

```

This table describes the significant fields shown in the display.

Table 14: show mpls ldp neighbor detail Command Field Descriptions

Field	Description
Peer LDP Identifier	LDP identifier of the neighbor (peer) for this session.
TCP connection	TCP connection used to support the LDP session, shown in the following format: neighbor IP address peer port local IP address local port
Graceful Restart	Graceful-restart status (Y or N).
Session Holdtime	Session hold time, in seconds.
State	State of the LDP session (operational or transient).
Msgs sent/rcvd	Number of LDP messages sent to and received from the session peer. The count includes the transmission and receipt of periodic keepalive messages, which are required for maintenance of the LDP session.
Up time	Time the session has been up for (in <i>hh:mm:ss</i> format).
Peer holdtime	Time to keep LDP peer session up without receipt of LDP protocol message from a peer.
Peer state	Peer session state.
Peer holdtime	Time to keep LDP peer session up without receipt of LDP protocol message from a peer.
Clients	LDP (internal) clients requesting session with a neighbor.
Inbound label filtering	LDP neighbor inbound filtering policy.

Field	Description
Session Protection	State of the session protection: Incomplete Targeted discovery requested but not yet up. Ready Targeted discovery and at least one link hello adjacency to the peer are up. Protecting Targeted discovery is up and there is no link hello adjacency to the peer. Targeted discovery is protecting and backing up link discoveries.
Duration	Maximum time to maintain session through targeted discovery upon loss of primary link discovery.
Holdtimer	When in “protecting” state, time to keep LDP peer session up without receipt of LDP protocol message from a peer.

Related Commands

Command	Description
graceful-restart (MPLS LDP), on page 23	Configures the LDP graceful restart feature.
label accept, on page 36	Configures the LDP inbound label filtering feature.
session protection, on page 62	Configures the LDP session protection feature.
show mpls ldp discovery, on page 72	Displays the status of the LDP discovery process.

show mpls ldp parameters

To display current LDP parameters, use the **show mpls ldp parameters** command in EXEC mode.

show mpls ldp parameters [*location node-id* | *standby*]

Syntax Description

location <i>node-id</i>	(Optional) Displays location information for the specified node ID.
standby	(Optional) Displays standby-node-specific information.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was supported.
Release 3.9.0	The location and standby keywords were added.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show mpls ldp parameters** command displays all LDP operational and configuration parameters.

Task ID

Task ID	Operations
mpls-ldp	read
network	read

Examples

The following shows a sample output from the **show mpls ldp parameters** command:

```
RP/0/0/CPU0:router# show mpls ldp parameters

LDP Parameters:
  Protocol Version: 1
  Router ID: 10.11.11.11
  Null Label: Implicit
```

```

Session:
  Hold time: 180 sec
  Keepalive interval: 60 sec
  Backoff: Initial:15 sec, Maximum:120 sec
Discovery:
  Link Hellos:      Holdtime:15 sec, Interval:5 sec
  Targeted Hellos: Holdtime:90 sec, Interval:10 sec
                  (Accepting peer ACL 'peer_acl_10')
Graceful Restart:
  Enabled (Configured)
  Reconnect Timeout:120 sec, Forwarding State Holdtime:180 sec
Timeouts:
  Binding with no-route: 300 sec
  LDP application recovery (with LSD): 360 sec
OOR state
Memory: Normal

```

This table describes the significant fields shown in the display.

Table 15: show mpls ldp parameters Command Field Descriptions

Field	Description
Protocol Version	Version of LDP running on the platform.
Router ID	Currently used router ID.
Null Label	LDP use of implicit-null or explicit-null as label for prefixes where it has to use a null label.
Session Hold time	Time LDP session is to be maintained with an LDP peer without receiving LDP traffic or an LDP keepalive message from the peer.
Session Keepalive interval	Time interval between consecutive transmissions of LDP keepalive messages to an LDP peer.
Session Backoff	Initial maximum backoff time for sessions.
Discovery Link Hellos	Time to remember that a neighbor platform wants an LDP session without receiving an LDP hello message from the neighbor (hold time), and the time interval between the transmission of consecutive LDP hello messages to neighbors (interval).
Discovery Targeted Hellos	Indicates the time: - To remember that a neighbor platform wants an LDP session when the neighbor platform is not directly connected to the router or the neighbor platform has not sent an LDP hello message. This intervening interval is known as <i>hold time</i>. - Interval between the transmission of consecutive hello messages to a neighbor not directly connected to the router and if targeted hellos are being accepted, displaying peer-acl (if any).

Field	Description
Graceful Restart	Status of graceful-restart status (Y or N).
Timeouts	Various timeouts (of interest) that the LDP is using. One timeout is <i>binding no route</i> , which indicates how long the LDP waits for an invalid route before deleting it. It also shows restart recovery time for LSD and LDP.
OOR state	Out of resource memory state: Normal, Major, or Critical.

Related Commands

Command	Description
backoff , on page 3	Configures the parameters for the LDP backoff mechanism.
discovery hello , on page 12	Configures the interval between transmission of LDP discovery messages.
explicit-null , on page 21	Configures a router to advertise an explicit-null label.
graceful-restart (MPLS LDP) , on page 23	Configures the LDP graceful restart feature.
holdtime (MPLS LDP) , on page 26	Configures keepalive message hold time for LDP sessions.
neighbor targeted , on page 56	Specifies the preferred interface or IP address of a Loopback interface for determining the LDP router ID.

show mpls ldp statistics msg-counters

To display statistics of the messages exchanged between neighbors, use the **show mpls ldp statistics msg-counters** command in EXEC mode.

show mpls ldp statistics msg-counters [*IP-address*] [**location** *node-id* | **standby**]

Syntax Description

<i>IP-address</i>	(Optional) Neighbor IP address.
location <i>node-id</i>	(Optional) Displays location information for the specified node ID.
standby	(Optional) Displays standby-node-specific information.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was supported.
Release 3.9.0	The location and standby keywords were added.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show mpls ldp statistics msg-counters** command can provide counter information about different types of messages sent and received between neighbors.

Task ID

Task ID	Operations
mpls-ldp	read

Examples

The following shows a sample output from the **show mpls ldp statistics msg-counters** command:

```
RP/0/0/CPU0:router# show mpls ldp statistics msg-counters

Peer LDP Identifier: 10.33.33.33:0
Msg Sent: (80)
```

show mpls ldp statistics msg-counters

```

Init          : 1
Address       : 1
Address_Withdraw : 0
Label_Mapping : 5
Label_Withdraw : 0
Label_Release : 0
Notification  : 0
KeepAlive     : 73

Msg Rcvd: (81)
Init          : 1
Address       : 1
Address_Withdraw : 0
Label_Mapping : 8
Label_Withdraw : 0
Label_Release : 0
Notification  : 0
KeepAlive     : 71

```

Table 16: [show mpls ldp statistics msg-counters Command Field Descriptions](#), on page 100 describes the significant fields shown in the display.

Table 16: show mpls ldp statistics msg-counters Command Field Descriptions

Field	Description
Peer LDP Identifier	LDP identifier of the neighbor (peer).
Msg Sent	Summary of messages sent to the LDP peer.
Msg Rcvd	Summary of messages received from the LDP peer.

Related Commands

Command	Description
clear mpls ldp msg-counters neighbor , on page 5	Clears MPLS LDP message counter values.
show mpls ldp bindings , on page 66	Displays the contents of LDP LIB.
show mpls ldp neighbor , on page 90	Displays LDP neighbor information.

show mpls ldp summary

To display a summary of LDP information, use the **show mpls ldp summary** command in EXEC mode.

show mpls ldp summary [*location node-id* | *standby*]

Syntax Description

location <i>node-id</i>	(Optional) Displays location information for the specified node ID.
standby	(Optional) Displays standby-node-specific information.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was supported.
Release 3.9.0	The location and standby keywords were added.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show mpls ldp summary** command can provide information about the number of LDP neighbors, interfaces, forwarding state (rewrites), servers connection/registration, and graceful-restart information.

Task ID

Task ID	Operations
mpls-ldp	read

Examples

The following shows a sample output from the **show mpls ldp summary** command:

```
RP/0/0/CPU0:router# show mpls ldp summary

Routes       : 4
Neighbors    : 1 (1 GR)
Hello Adj    : 1
Interfaces: 4 (1 forward reference, 2 LDP configured)
Addresses    : 3
Clients      : 0
```

show mpls ldp summary

```

Servers      :
              Connected  Registered
              -----  -
SysDB        Y          Y
IM           Y          Y
IPv4 ARM     Y          -
LSD          Y          Y
RIBv4        Y          Y

```

This table describes the significant fields shown in the display.

Table 17: show mpls ldp summary Command Field Descriptions

Field	Description
Routes	Number of known IP routes (prefixes).
Neighbors	Number of LDP neighbors, including targeted and graceful restartable neighbors.
Hello Adj	Number of discovered LDP discovery sources.
Interfaces	Number of known IP interfaces and number of LDP configured interfaces. LDP is configured on a forward-referenced interface which may not exist or for which no IP address is configured.
Addresses	Number of known local IP addresses.
Clients	Number of external LDP clients. This number is always zero.
Servers	Connection and registration status with servers: SysDB ⁶ , IM ⁷ , IPv4 ARM ⁸ , LSD ⁹ , and IPv4 RIBv4 ¹⁰ .

⁶ SysDB = System Database.

⁷ IM = Interface Manager.

⁸ IPv4 ARM = IPv4 Address Resource Manager.

⁹ LSD = Label Switching Database.

¹⁰ RIBv4 = Routing Information Base.

Related Commands

Command	Description
show mpls ldp bindings, on page 66	Displays the contents of LDP LIB.
show mpls ldp discovery, on page 72	Displays the status of the LDP discovery process.
show mpls ldp forwarding, on page 77	Displays the contents of the LDP forwarding database.
show mpls ldp graceful-restart, on page 82	Displays the status of the LDP graceful restart.

Command	Description
show mpls ldp parameters, on page 96	Displays current LDP parameter settings.

signalling dscp (LDP)

To assign label distribution protocol (LDP) signaling packets a differentiated service code point (DSCP) to assign higher priority to the control packets while traversing the network, use the **signalling dscp** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

signalling dscp *dscp*

no signalling dscp

Syntax Description

<i>dscp</i>	DSCP priority value. Range is 0 to 63.

Command Default

LDP control packets are sent with precedence 6 (*dscp*: 48)

Command Modes

MPLS LDP configuration

Command History

Release	Modification
Release 3.3.0	This command was supported.
Release 3.4.0	

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

DSCP marking improves signaling setup and teardown times.

Ordinarily, when LDP sends hello discovery or protocol control messages, these are marked using the default control packet precedence value (6, or *dscp* 48). You can use the **signalling dscp** command to override that DSCP value to ensure that all control messages sent are marked with a specified DSCP.



Note

While the **signalling dscp** command controls LDP signaling packets (Discovery hellos and protocol messages), it has no effect on ordinary IP or MPLS data packets.

Task ID

Task ID	Operations
mpls-ldp	read, write

Examples

The following example shows how to assign LDP packets a DSCP value of 56:

```
RP/0/0/CPU0:router(config-ldp) # signalling dscp 56
```

snmp-server traps mpls ldp

To inform a network management system of session and threshold cross changes, use the **snmp-server traps mpls ldp** command in global configuration mode.

snmp-server traps mpls ldp {up | down | threshold}

Syntax Description

up	Displays the session-up notification.
down	Displays the session-down notification.
threshold	Displays the session-backoff-threshold crossed notification.

Command Default

LDP does not send SNMP traps.

Command Modes

Global configuration

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **snmp-server traps mpls ldp** command sends notifications to the SNMP server. There are three types of traps sent by LDP:

Session up

Generated when sessions go up.

Session down

Generated when sessions go down.

Threshold

Generated when attempts to establish a session fails. The predefined value is 8.

Task ID

Task ID	Operations
mpls-ldp	read, write
mpls-te	read, write
snmp	read, write

Examples

The following example shows how to enable LDP SNMP trap notifications for Session up:

```
RP/0/0/CPU0:router(config)# snmp-server traps mpls ldp up
```

 `snmp-server traps mpls ldp`



MPLS Forwarding Commands

This module describes the commands used to configure and use Multiprotocol Label Switching (MPLS) forwarding.

For detailed information about MPLS concepts, configuration tasks, and examples, see *Cisco IOS XR MPLS Configuration Guide for the Cisco XR 12000 Series Router*.

- [mpls ip-ttl-propagate, page 110](#)
- [mpls label range, page 112](#)
- [mpls mtu, page 114](#)
- [show mpls forwarding, page 116](#)
- [show mpls forwarding exact-route, page 121](#)
- [show mpls interfaces, page 125](#)
- [show mpls label range, page 128](#)
- [show mpls label table, page 130](#)
- [show mpls lsd applications, page 133](#)
- [show mpls lsd clients, page 135](#)
- [show mpls traffic-eng fast-reroute database, page 137](#)
- [show mpls traffic-eng fast-reroute log, page 142](#)

mpls ip-ttl-propagate

To configure the behavior controlling the propagation of the IP Time-To-Live (TTL) field to and from the MPLS header, use the **mpls ip-ttl-propagate** command in global configuration mode. To return to the default behavior, use the **no** form of this command.

mpls ip-ttl-propagate disable [**forwarded** | **local**]

no mpls ip-ttl-propagate

Syntax Description

disable	Disables the propagation of IP TTL to and from the MPLS header for both forwarded and local packets.
forwarded	(Optional) Disables the propagation of IP TTL to and from the MPLS header for only the forwarded packets. This prevents the traceroute command from displaying the MPLS-enabled nodes beyond the device under the configuration.
local	(Optional) Disables the propagation of IP TTL to the MPLS header for only locally generated packets. This prevents the traceroute command from displaying the MPLS-enabled nodes beyond the device under the configuration.

Command Default

Enabled

Command Modes

Global configuration

Command History

Release	Modification
Release 3.2	This command was introduced.
Release 3.9.0	Both forwarded and local keywords were added as optional.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

By default, the IP TTL is propagated to the MPLS header when IP packets enter the MPLS domain. Within the MPLS domain, the MPLS TTL is decremented at each MPLS hop. When an MPLS encapsulated IP packet exits the MPLS domain, the MPLS TTL is propagated to the IP header. When propagation is disabled, the MPLS TTL is set to 255 during the label imposition phase and the IP TTL is not altered.

Task ID

Task ID	Operations
mpls-te	read, write
mpls-ldp	read, write

Examples

The following example shows how to disable IP TTL propagation:

```
RP/0/0/CPU0:router(config)# mpls ip-ttl-propagate disable
```

The following example shows how to disable IP TTL propagation for forwarded MPLS packets:

```
RP/0/0/CPU0:router(config)# mpls ip-ttl-propagate disable forwarded
```

The following example shows how to disable IP TTL propagation for locally generated MPLS packets:

```
RP/0/0/CPU0:router(config)# mpls ip-ttl-propagate disable local
```

mpls label range

To configure the dynamic range of local labels available for use on packet interfaces, use the **mpls label range** command in global configuration mode. To return to the default behavior, use the **no** form of this command.

mpls label range table *table-id minimum maximum*

no mpls label range table *table-id minimum maximum*

Syntax Description

table <i>table-id</i>	Identifies a specific label table; the global label table has table-id = 0. If no table is specified, the global table is assumed. Currently, you can specify table 0 only.
<i>minimum</i>	Smallest allowed label in the label space. Default is 16000.
<i>maximum</i>	Largest allowed label in the label space. Default is 1048575.

Command Default

table-id: 0
minimum: 16000
maximum: 1048575

Command Modes

Global configuration

Command History

Release	Modification
Release 3.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The label range defined by the **mpls label range** command is used by all MPLS applications that allocate local labels (for dynamic label switching Label Distribution Protocol [LDP], MPLS traffic engineering, and so on).

Labels 0 through 15 are reserved by the Internet Engineering Task Force (IETF) (see the draft-ietf-mpls-label-encaps-07.txt for details) and cannot be included in the range using the **mpls label range** command.

Labels 16 through 15999 are reserved for Layer 2 VPN static pseudowires. You should not configure Layer 2 VPN static pseudowires which fall within the dynamic range. If more Layer 2 VPN static pseudowires are required, restrict the dynamic label range using this configuration.

**Note**

- Labels outside the current range and which are allocated by MPLS applications remain in circulation until released.
- You must understand the maximum labels that are supported for each platform versus the labels that are supported for the CLI.

Task ID

Task ID	Operations
mpls-te	read, write
mpls-ldp	read, write

Examples

The following example shows how to configure the size of the local label space using a *minimum* of 16200 and a *maximum* of 120000:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls label range 16200 120000
```

Related Commands

Command	Description
show mpls label range, on page 128	Displays the range of the MPLS local label space.

mpls mtu

To configure the maximum packet size or maximum transmission unit (MTU) size on an MPLS interface, use the **mpls mtu** command in global configuration mode. To disable this feature, use the **no** form of this command.

mpls mtu *bytes*

no mpls mtu *bytes*

Syntax Description

<i>bytes</i>	MTU size, in bytes. The range is from 68 to 65535.

Command Default

The default MTU value is 1500.

Command Modes

Global configuration

Command History

Release	Modification
Release 3.6.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Each interface has a default maximum packet size or MTU size. This number generally defaults to the largest size possible for that interface type. On serial interfaces, the MTU size varies, but cannot be set smaller than 68 bytes.

Task ID

Task ID	Operations
mpls-te	read, write
mpls-ldp	read, write
mpls-static	read, write

Examples

The following example specifies an MTU of 70 bytes on an MPLS interface:

```
RP/0/0/CPU0:router# interface Loopback0
```

```
RP/0/0/CPU0:router(config-if)# mpls mtu 70
```

show mpls forwarding

To display the contents of the MPLS Label Forwarding Information Base (LFIB), use the **show mpls forwarding** command in EXEC mode.

show mpls forwarding [**detail**] [**hardware**{**ingress** | **egress**}] [**interface** *type interface-path-id*] [**location** *node-id*] [**labels** *low-value* [*high-value*]] [**prefix**{*network/mask*| **ipv4 unicast** *network/mask*}] [**private**] [**summary**] [**tunnels** *tunnel-id*] [**vrf** *vrf-name*]

Syntax Description

detail	(Optional) Displays information in long form (includes length of encapsulation, length of Media Access Control [MAC] string, maximum transmission unit [MTU], Packet switched, and label stack).
hardware	(Optional) Displays the hardware location entry.
ingress	(Optional) Reads information from the ingress PSE.
egress	(Optional) Reads information from the egress PSE.
interface	(Optional) Displays information for the specified interface.
<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
labels <i>low-value</i> [<i>high-value</i>]	(Optional) Entries with a local labels range. Ranges for both <i>low-value</i> and <i>high-value</i> are 0 to 1048575.
location <i>node-id</i>	(Optional) Displays hardware resource counters on the designated node.
prefix <i>network/mask</i> [/length]	(Optional) Displays the destination address and mask/prefix length. Note The forward slash (/) between <i>network</i> and <i>mask</i> is required.
ipv4 unicast	(Optional) Displays the IPv4 unicast address.
private	(Optional) Displays private information.
summary	(Optional) Displays summarized information.
tunnels <i>tunnel-id</i>	(Optional) Displays entries either for a specified label switch path (LSP) tunnel or all LSP tunnel entries.

vrf *vrf-name* (Optional) Displays entries for VPN routing and forwarding (VRF).

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was introduced.
Release 3.9.0	The hardware , egress , and ingress keywords were added. The ipv4 and unicast keywords were added.

Usage Guidelines

The optional keywords and arguments described allow specification of a subset of the entire MPLS forwarding table.

The *node-id* argument is entered in the *rack/slot/module* notation.

Task ID

Task ID	Operations
mpls-te	read, write
mpls-ldp	read, write
mpls-static	read, write

Examples

The following sample output is from the **show mpls forwarding** command using the **location** keyword and a specific node ID:

```
RP/0/0/CPU0:router# show mpls forwarding location 0/2/CPU0
```

Local Label	Outgoing Label	Outgoing Interface	Next Hop	Bytes Switched
16000	Unlabelled	ce01::ce01/128 [V]	Gi0/1/0/0	ce01:10::2
16001	Aggregate	router: Per-VRF Aggr[V]	\	
		router 0		
16021	16020	P2MP TE:10	Gi0/2/0/3	172.99.1.2
	16040	P2MP TE:10	Gi0/2/0/3	172.99.2.2
	16045	P2MP TE:10	PO0/1/0/4	172.16.1.2

The following sample output shows detailed information for the LSP tunnels:

```
RP/0/0/CPU0:router# show mpls forwarding prefix 10.241.4.0/24 detail
```

Local Label	Outgoing Label	Prefix or ID	Outgoing Interface	Next Hop	Bytes Switched
16057	16058	10.241.4.0/24	Gi0/1/0/23	10.114.4.11	0

```

Updated May 10 20:00:15.983
MAC/Encaps: 14/18, MTU: 9202
Label Stack (Top -> Bottom): { 16058 }
Packets Switched: 0

    16058          10.241.4.0/24          Te0/4/0/0    10.114.8.11    0
Updated May 10 20:00:15.983
MAC/Encaps: 14/18, MTU: 9086
Label Stack (Top -> Bottom): { 16058 }
Packets Switched: 0

```

The following sample output shows the number of P2MP TE heads and midpoints and the number of P2MP route updates that are received from the MRIB from the **summary** keyword:

```

RP/0/0/CPU0:router# show mpls forwarding summary

Forwarding entries:
Label switching: 91647
MPLS TE tunnel head: 1351, protected: 1
MPLS TE midpoint: 0, protected: 0
MPLS TE internal: 1351, protected: 1
MPLS P2MP TE tunnel head: 499
MPLS P2MP TE tunnel midpoint/tail: 999 Forwarding updates:
messages: 3925
  p2p updates: 229115
  p2mp updates: 13519
    add/modify:12020, deletes:1499,
    dropped:0 (iir trigger drops:0)) Labels in use:
Reserved: 3
Lowest: 0
Highest: 112979
Deleted stale label entries: 0

```

This table describes the significant fields shown in the display.

Table 18: show mpls forwarding Field Descriptions

Field	Description
Local Label	Label assigned by this router.
Outgoing Label	Label assigned by the next hop or downstream peer. Some of the entries that display in this column are: Unlabeled No label for the destination from the next hop, or label switching is not enabled on the outgoing interface. Pop Label Next hop advertised an implicit-null label for the destination.
Prefix or Tunnel ID	Address or tunnel to which packets with this label are going.
Outgoing Interface	Interface through which packets with this label are sent.

Field	Description
Next Hop	IP address of neighbor that assigned the outgoing label.
Bytes Switched	Number of bytes switched with this incoming label.
TO	Timeout: Indicated by an "*" if entry is being timed out in forwarding.
Mac/Encaps	Length in bytes of Layer 2 header, and length in bytes of packet encapsulation, including Layer 2 header and label header.
MTU	MTU ¹¹ of labeled packet.
Label Stack	All the outgoing labels on the forwarded packet.
Packets Switched	Number of packets switched with this incoming label.
Label switching	Number of Label switching LFIB ¹² forwarding entries.
IPv4 label imposition	Number of IPv4 label imposition forwarding entries (installed at ingress LSR).
MPLS TE tunnel head	Number of forwarding entries (installed at ingress LSR) on MPLS TE tunnel head.
MPLS TE fast-reroute	Number of forwarding entries (installed at PLR) for MPLS-TE fast reroute.
Forwarding updates	Number of forwarding updates sent from LSD (RP/DRP) to LFIB/MPLS (RP/DRP/LC) using BCDL mechanism, indicating the total number of updates and total number of BCDL messages.
Labels in use	Local labels in use (installed in LFIB). These usually indicate the lowest and highest label in use (allocated by applications). Furthermore, some reserved labels, such as explicit-nullv4, explicit-nullv6, are installed in the forwarding plane. The label range is 0 to 15.

¹¹ MTU = Maximum Transmission Unit.

¹² LFIB = Label Forwarding Information Base.

Related Commands

Command	Description
show mpls forwarding exact-route, on page 121	Displays the exact path for the source and destination address pair.

show mpls forwarding exact-route

To display the exact path for the source and destination address pair, use the **show mpls forwarding exact-route** command in EXEC mode.

show mpls forwarding exact-route *label label-number* {**bottom-label** *value*| **ipv4** *source-address destination-address*| **ipv6***source-addressdestination-address*} [**detail**] [**protocol** *protocol* **source-port** *source-port* **destination-port** *destination-port* **ingress-interface** *type interface-path-id*] [**location** *node-id*] [**policy-class** *value*] [**hardware** {**ingress** | **egress**}]

Syntax Description

label <i>label-number</i>	Displays the exact path for a source and destination address pair.
bottom-label <i>value</i>	Displays the bottom label value. Range is 0 to 1048575.
ipv4 <i>source-address destination-address</i>	Displays the exact path for IPv4 payload. The IPv4 source address in x.x.x.x format. The IPv4 destination address in x.x.x.x format.
ipv6 <i>source-address destination-address</i>	Displays the exact path for IPv6 payload. The IPv6 source address in x::x::x format. The IPv6 destination address in x::x::x format.
detail	(Optional) Displays detailed information.
protocol <i>protocol</i>	(Optional) Displays the specified protocol for the route.
source-port <i>source-port</i>	Sets the UDP source port. The range is from 0 to 65535.
destination-port <i>destination-port</i>	Sets the UDP destination port. The range is from 0 to 65535.
ingress-interface	Sets the ingress interface.
<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
location <i>node-id</i>	(Optional) Displays hardware resource counters on the designated node.
policy-class <i>value</i>	(Optional) Displays the policy-based tunnel selection (PBTS) to direct traffic into specific TE tunnels. The policy-class attribute maps the correct traffic class to this policy. The range for the policy-class value is from 1 to 7.
hardware	(Optional) Displays the hardware location entry.

ingress	(Optional) Reads information from the ingress PSE.
egress	(Optional) Reads information from the egress PSE.

Command Default No default behavior or values

Command Modes EXEC

Release	Modification
Release 3.6.0	Added command parameters for 7-tuple.
Release 3.9.0	The following keywords and arguments were added: • detail keyword • location keyword and <i>node-id</i> argument • policy-class keyword and <i>value</i> argument • hardware, ingress, and egress keywords

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show mpls forwarding exact-route** command displays information in long form and includes the following information:

- Encapsulation length
- Media Access Control (MAC) string length
- Maximum transmission unit (MTU)
- Packet switching information
- Label stacking information

Task ID	Operations
mpls-te	read, write
mpls-ldp	read, write
mpls-static	read, write

Examples

The following shows a sample output from the **show mpls forwarding exact-route** command:

```
RP/0/0/CPU0:router# show mpls forwarding exact-route label 16000 ipv4 10.74.1.6 127.0.0.15
protocol tcp source-port 3503 destination-port 3503 ingress-interface pos 0/3/4/3
```

Local Label	Outgoing Label	Prefix or ID	Outgoing Interface	Next Hop	Bytes Switched
16000	16001	5.5.5.5/32	PO0/1/5/1	1.24.1.192	N/A
Via: PO0/1/5/1, Next Hop: point2point					
MAC/Encaps: 4/8, MTU: 1500					
Label Stack (Top -> Bottom): { 16001 }					

This table describes the significant fields shown in the display.

Table 19: show mpls forwarding exact-route Field Descriptions

Field	Description
Local Label	Label assigned by this router.
Outgoing Label	Label assigned by the next hop or downstream peer. Some of the entries that display in this column are: Unlabeled No label for the destination from the next hop, or label switching is not enabled on the outgoing interface. Pop Label Next hop advertised an implicit-null label for the destination.
Prefix or Tunnel ID	Address or tunnel to which packets with this label are going.
Outgoing Interface	Interface through which packets with this label are sent.
Next Hop	IP address of neighbor that assigned the outgoing label.
Bytes Switched	Number of bytes switched with this incoming label.
TO	Timeout: Indicated by an "*" if entry is being timed out in forwarding.

Field	Description
MAC/Encaps	Length in bytes of Layer 2 header, and length in bytes of packet encapsulation, including Layer 2 header and label header.
MTU	MTU ¹³ of labeled packet.
Label Stack	All the outgoing labels on the forwarded packet.
Packets Switched	Number of packets switched with this incoming label.
Label switching	Number of Label switching LFIB ¹⁴ forwarding entries.
IPv4 label imposition	Number of IPv4 label imposition forwarding entries (installed at ingress LSR).
MPLS TE tunnel head	Number of forwarding entries (installed at ingress LSR) on MPLS TE tunnel head.
MPLS TE fast-reroute	Number of forwarding entries (installed at PLR) for MPLS-TE fast reroute.
Forwarding updates	Number of forwarding updates sent from LSD (RP/DRP) to LFIB/MPLS (RP/DRP/LC) using BCDL mechanism, indicating the total number of updates and total number of BCDL messages.
Labels in use	Local labels in use (installed in LFIB). These usually indicate the lowest and highest label in use (allocated by applications). Furthermore, some reserved labels, such as explicit-nullv4, explicit-nullv6, are installed in the forwarding plane. The label range is 0 to 15.

¹³ MTU = Maximum Transmission Unit.

¹⁴ LFIB = Label Forwarding Information Base.

Related Commands

Command	Description
show mpls forwarding , on page 116	Displays the contents of the MPLS LFIB.

show mpls interfaces

To display information about one or more interfaces that have been configured for MPLS, use the **show mpls interfaces** command in EXEC mode.

show mpls interfaces [*type interface-path-id*] [**location** *node-id*] [**detail**]

Syntax Description

<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
location <i>node-id</i>	(Optional) Displays hardware resource counters on the designated node.
detail	(Optional) Displays detailed information for the designated node.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

This command displays MPLS information about a specific interface or about all interfaces where MPLS is configured.

Task ID

Task ID	Operations
mpls-te	read, write
mpls-ldp	read, write

Task ID	Operations
mpls-static	read, write

Examples

The following shows a sample output from the **show mpls interfaces** command:

```
RP/0/0/CPU0:router# show mpls interfaces
```

```

Interface          LDP      Tunnel   Enabled
-----
POS0/4/0/0         Yes      Yes      Yes
POS0/4/0/1         Yes      Yes      Yes
POS0/4/0/2         Yes      Yes      Yes

```

The following shows a sample output from the **show mpls interfaces** command using the **detail** keyword:

```
RP/0/0/CPU0:router# show mpls interfaces detail
```

```

Interface POS0/4/0/0:
  LDP labelling enabled
  LSP labelling enabled (TE-Control)
  MPLS enabled
  MTU = 4474
Interface POS0/4/0/1:
  LDP labelling enabled
  LSP labelling enabled (TE-Control)
  MPLS enabled
  MTU = 4474
Interface POS0/4/0/2:
  LDP labelling enabled
  LSP labelling enabled (TE-Control)
  MPLS enabled
  MTU = 4474

```

The following shows a sample output from the **show mpls interfaces** command using the **location** keyword:

```
RP/0/0/CPU0:router# show mpls interfaces location pos 0/4/0/0
```

```

Interface          LDP      Tunnel   Enabled
-----
POS0/4/0/0         Yes      Yes      Yes

```

```
RP/0/0/CPU0:router# show mpls interfaces pos 0/4/0/0 detail
```

```

Interface POS0/4/0/0:
  LDP labelling enabled
  LSP labelling enabled (TE-Control)
  MPLS enabled
  MTU = 4474

```

This table describes the significant fields in the sample display.

Table 20: show mpls interfaces Command Field Descriptions

Field	Description
LDP	State of LDP labelling.
Tunnel	State of LSP Tunnel labelling.

Field	Description
MTU	MTU ¹⁵ of labeled packet.
Caps	Capsulation switching chains installed on an interface.
M	MPLS switching capsulation/switching chains are installed on the interface and are ready to switch MPLS traffic.

¹⁵ MTU = Maximum Transmission Unit.

show mpls label range

To display the range of local labels available for use on packet interfaces, use the **show mpls label range** command in EXEC mode.

show mpls label range

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes EXEC

Command History	Release	Modification
	Release 3.2	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

You can use the **show mpls label range** command to configure a range for local labels that is different from the default range.

Task ID	Task ID	Operations
	mpls-te	read, write
	mpls-ldp	read, write
	mpls-static	read, write

Examples The following shows a sample output from the **show mpls label range** command:

```
RP/0/0/CPU0:router# show mpls label range
Range for dynamic labels: Min/Max: 16000/144000
```

This table describes the significant fields shown in the display.

Table 21: show mpls label range Command Field Descriptions

Field	Description
Range for dynamic labels	Minimum and maximum allowable range for local labels (which differs from the default range).

Related Commands

Command	Description
mpls label range, on page 112	Configures a range of values for use as local labels.

show mpls label table

To display the local labels contained in the MPLS label table, use the **show mpls label table** command in EXEC mode.

show mpls label table *table-index* [**application** *application*] [**label** *label-value*] [**summary**] [**detail**]

Syntax Description

<i>table-index</i>	Index of the label table to display. The global label table is 0. Currently, you can specify table 0 only.
application <i>application</i>	(Optional) Displays all labels owned by the selected application. Options are: bgp-ipv4 , bgp-spr , bgp-vpn-ipv4 , internal , ldp , none , l2vpn , static , te-control , te-link , and test .
label <i>label-value</i>	(Optional) Displays a selected label based on the label value. Range is 0 to 1048575.
summary	(Optional) Displays a summary of local labels.
detail	(Optional) Displays detailed information for the MPLS label table.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was introduced.
Release 3.9.0	The detail keyword was added.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note

Labels 16 to 15999 are reserved for static Layer 2 VPN pseudowires.

Task ID

Task ID	Operations
mpls-te	read, write
mpls-ldp	read, write
mpls-static	read, write

Examples

The following shows a sample output from the **show mpls label table** command:

```
RP/0/0/CPU0:router# show mpls label table 0
```

```

Table Label   Owner      State  Rewrite
-----
0       0       LSD        InUse  Yes
0       1       LSD        InUse  Yes
0       2       LSD        InUse  Yes
0       3       LSD        InUse  Yes
0      16      TE-Link    InUse  Yes

```

This table describes the significant fields shown in the display.

Table 22: show mpls label table Command Field Descriptions

Field	Description
Table	Table ID.
Label	Label index.
Owner	Application that allocated the label. All labels displaying "InUse" state have an owner.

Field	Description
State	InUse Label allocated and in use by an application. Alloc Label allocated but is not yet in use by an application. Pend Label was in use by an application that has terminated unexpectedly, and the application has not reclaimed the label. Pend-S Label was in use by an application, but the MPLS LSD¹⁶ server has recently restarted and the application has not reclaimed the label.
Rewrite	Number of initiated rewrites.

¹⁶ LSD = Label Switching Database.

Related Commands

Command	Description
show mpls forwarding, on page 116	Displays entries in the MPLS forwarding table. Label switching entries are indexed by their local label.
show mpls lsd applications, on page 133	Displays MPLS applications that are registered with the MPLS LSD server.

show mpls lsd applications

To display the MPLS applications registered with the MPLS Label Switching Database (LSD) server, use the **show mpls lsd applications** command in EXEC mode.

show mpls lsd applications [**application** *application*]

Syntax Description

application <i>application</i>	(Optional) Displays all labels owned by the selected application. Options are: bgp-ipv4 , bgp-spk , bgp-vpn-ipv4 , internal , ldp , none , l2vpn , static , te-control , te-link , and test .

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was introduced.
Release 3.9.0	The application keyword was added.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

MPLS applications include Traffic Engineering (TE) control, TE Link Management, and label distribution protocol (LDP). The application must be registered with MPLS LSD for its features to operate correctly. All applications are clients (see the [show mpls lsd clients](#), on page 135 command), but not all clients are applications.

Task ID

Task ID	Operations
mpls-te	read, write
mpls-ldp	read, write
mpls-static	read, write

Examples

The following shows a sample output from the **show mpls lsd applications** command:

```
RP/0/0/CPU0:router# show mpls lsd applications
```

Type	State	RecoveryTime	Node
LDP	Active	300	0/0/CPU0
TE-Control	Active	100	0/0/CPU0
TE-Link	Active	600	0/0/CPU0

This table describes the significant fields shown in the display.

Table 23: show mpls lsd applications Command Field Descriptions

Field	Description
Type	LSD application type.
State	Active Application registered with MPLS LSD and is functioning correctly. Recover Application registered with MPLS LSD and is recovering after recently restarting. In this state, the RecoveryTime value indicates how many seconds are left before the application becomes active. Zombie Application not reregistered after an unexpected termination. In this case, RecoveryTime indicates how many seconds are left before MPLS LSD gives up on the application.
RecoveryTime	Seconds remaining before MPLS LSD gives up or resumes the application.
Node	Node expressed in standard <i>rack/slot/module</i> notation.

Related Commands

Command	Description
show mpls lsd clients, on page 135	Displays MPLS clients connected to the MPLS LSD server.

show mpls lsd clients

To display the MPLS clients connected to the MPLS Label Switching Database (LSD) server, use the **show mpls lsd clients** command in EXEC mode.

show mpls lsd clients

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes EXEC

Command History	Release	Modification
	Release 3.2	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

MPLS clients include Traffic Engineering (TE) Control, TE Link Management, Label Distribution Protocol (LDP), and Bulk Content Downloader (BCDL) Agent. Not all clients are applications (see the **show mpls lsd applications** command), but all applications are clients.

Task ID	Task ID	Operations
	mpls-te	read, write
	mpls-ldp	read, write
	mpls-static	read, write

Examples The following shows a sample output from the **show mpls lsd clients** command:

```
RP/0/0/CPU0:router# show mpls lsd clients
```

Id	Services	Node
0	BA (p=none)	0/0/CPU0
1	A (TE-Link)	0/0/CPU0
2	A (LDP)	0/0/CPU0

```
3  A(TE-Control)          0/0/CPU0
```

The following table describes the significant fields shown in the display.

Table 24: show mpls lsd clients Command Field Descriptions

Field	Description
Id	Client identification number.
Services	A(xxx) means that this client is an application and xxx is the application name, BA(yyy) means that this client is a BCDL Agent and yyy is expert data. Depending on system conditions, there can be multiple BCDL Agent clients (this is normal).
Node	Node expressed in standard rack/slot/module notation.

Related Commands

Command	Description
show mpls lsd applications	Displays MPLS applications registered with the MPLS LSD server.

show mpls traffic-eng fast-reroute database

To display the contents of the fast reroute (FRR) database, use the **show mpls traffic-eng fast-reroute database** command in EXEC mode.

show mpls traffic-eng fast-reroute database [*ip-address*] [*ip-address /length*] [**afi-all** { **safi-all** | **unicast** } { *ip-address* | *ip-address/length* }] [**backup-interface**] [**tunnel** *tunnel-id*] [**unresolved**] [**interface** *type interface-path-id*] [**ipv4** { **safi-all** | **unicast** } { *ip-address* | *ip-address/length* }] [**labels** *low-number high-number*] [**state** { **active** | **complete** | **partial** | **ready** }] [**role** { **head** | **midpoint** }] [**summary**] [**location** *node-id*]

Syntax Description

<i>ip-address</i>	(Optional) IP address of the destination network.
<i>ip-address/length</i>	(Optional) Bit combination indicating the portion of the IP address that is being used for the subnet address.
afi-all	(Optional) Returns data for all specified address family identifiers.
safi-all	(Optional) Returns data for all sub-address family identifiers.
unicast	(Optional) Returns unicast data only.
backup-interface	(Optional) Displays entries with the specified backup interface.
tunnel <i>tunnel-id</i>	(Optional) Tunnel and tunnel ID to which packets with this label are going. The summary suboption is available.
unresolved	(Optional) Displays entries whose backup interface has not yet been fully resolved.
interface	(Optional) Displays entries with this primary outgoing interface. The summary keyword is available.
<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
ipv4	(Optional) Displays only IPv4 data.
labels	(Optional) Displays database entries that possess in-labels assigned by this router (local labels). Specify either a starting value or a range of values. The state suboption is available.

state	(Optional) Filters the database according to the state of the entry: active FRR rewrite is in the forwarding active database (where it can be placed onto appropriate incoming packets). complete FRR rewrite is assembled, ready or active. partial FRR rewrite is fully created; its backup routing information is still incomplete. ready FRR rewrite was created but is not in the forwarding active state.
role	(Optional) Displays entries associated either with the tunnel head or tunnel midpoint . The summary suboption is available.
summary	(Optional) Displays summarized information about the FRR database.
location <i>node-id</i>	(Optional) Displays hardware resource counters on the designated node.

Command Default No default behavior or values

Command Modes EXEC

Command History	Release	Modification
	Release 3.2	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

For fast reroute (FRR) information in regards to multicast label forwarding, see *Cisco IOS XR Software Multicast Command Reference for the Cisco XR 12000 Series Router*.

If the location is specified, Fast-Reroute (FRR) entries for both Point-to-Point (P2P) and P2MP tunnels are available. If the location is not specified, only P2P tunnel entries are available.

Task ID

Task ID	Operations
mpls-te	read

Examples

The following shows a sample output from the **show mpls traffic-eng fast-reroute database** command:

```
RP/0/0/CPU0:router# show mpls traffic-eng fast-reroute database
```

```
Tunnel head FRR information:
Tunnel      Out intf/label    FRR intf/label    Status
-----
tt4000      PO0/3/0/0:34      tt1000:34         Ready
tt4001      PO0/3/0/0:35      tt1001:35         Ready
tt4002      PO0/3/0/0:36      tt1001:36         Ready
```

**Note**

The Prefix field indicates the IP address where packets with this label are headed.

The following sample output displays filtering of the FRR database using the **backup-interface** keyword:

```
RP/0/0/CPU0:router# show mpls traffic-eng fast database backup-interface
```

```
LSP midpoint FRR information:
LSP Identifier      Out Intf/      FRR Intf/      Status
                    Label         Label
-----
10.10.10.10 1006 [54]      Gi0/6/5/2:Pop  tt1060:Pop     Ready
```

The following sample output displays the FRR database filtered by the primary outgoing interface:

```
RP/0/0/CPU0:router# show mpls traffic-eng fast-reroute database interface pos0/3/0/0
```

```
Tunnel head FRR information:
Tunnel      Out intf/label    FRR intf/label    Status
-----
tt4000      PO0/3/0/0:34      tt1000:34         Ready
tt4001      PO0/3/0/0:35      tt1001:35         Ready
tt4002      PO0/3/0/0:36      tt1001:36         Ready
```

The following sample output displays a summary of the FRR database with the role as head:

```
RP/0/0/CPU0:router# show mpls traffic-eng fast-reroute database role head summary
```

```
Status      Count
-----
Active      0
Ready       3
Partial     0
```

The following sample output displays summarized information for the FRR database with the role as midpoint:

```
RP/0/0/CPU0:router# show mpls traffic-eng fast-reroute database role midpoint summary
```

```
Status      Count
-----
Active      0
Ready       2
```

Partial 0

This table describes the significant fields shown in the display.

Table 25: show mpls traffic-eng fast-reroute database Command Field Descriptions

Field	Description
Tunnel	Short form of tunnel interface name.
Out intf/label	Out interface Short name of the physical interface through which traffic goes to the protected link. Out label At a tunnel head, this is the label that the tunnel destination device advertises. The value “Unlabeled” indicates that no such label is advertised. At a tunnel midpoint, this is the label selected by the next hop device. The value “Pop Label” indicates that the next hop is the final hop for the tunnel.
FRR intf/label	Fast reroute interface Backup tunnel interface. Fast reroute label At a tunnel head, this is the label that the tunnel tail selected to indicate the destination network. The value “Unlabeled” indicates that no label is advertised. At a tunnel midpoint, this has the same value as the Out label.

Field	Description
Status	State of the rewrite: partial, ready, or active.

Related Commands

Command	Description
show mpls traffic-eng fast-reroute log, on page 142	Displays the contents of the FRR event log.

show mpls traffic-eng fast-reroute log

To display a history of fast reroute (FRR) events, use the **show mpls traffic-eng fast-reroute log** command in EXEC mode.

show mpls traffic-eng fast-reroute log [*interface* *type* *interface-path-id* | *location* *node-id*]

Syntax Description

interface	(Optional) Displays all FRR events for the selected protected interface.
<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
location <i>node-id</i>	(Optional) Displays all FRR events that occurred on the selected node.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was introduced.
Release 3.9.0	Sample output was modified.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	read

Examples

The following shows a sample output from the **show mpls traffic-eng fast-reroute log** command:

```
RP/0/0/CPU0:router# show mpls traffic-eng fast-reroute log
```

Node	Protected Interface	LSPs	Rewrites	When	Switching Time (usec)
0/0/CPU0	PO0/1/0/1	1	1	Feb 27 19:12:29.064000	147

This table describes the significant fields shown in the display.

Table 26: show mpls traffic-eng fast-reroute log Field Descriptions

Field	Description
Node	Node address.
Protected Interface	Type and interface-path-id that is being protected.
LSPs	LSP ¹⁷ associated with each interface being protected.
Rewrites	Number of rewrites initiated on the LSP.
When	Date the interface was protected.
Switching Time	Time required to switch the protected interface in microseconds.

¹⁷ LSP = Link-state Packet.

Related Commands

Command	Description
show mpls traffic-eng fast-reroute database, on page 137	Displays the contents of the FRR database.

 `show mpls traffic-eng fast-reroute log`



MPLS Traffic Engineering Commands

This module describes the commands used to configure Multiprotocol Label Switching (MPLS) Traffic Engineering (TE) on the Cisco IOS XR Software.

Your network must support the following Cisco features before you can enable MPLS-TE:

- MPLS
- IP Cisco Express Forwarding (CEF)
- Intermediate System-to-Intermediate System (IS-IS) or Open Shortest Path First (OSPF) routing protocol
- Resource Reservation Protocol (RSVP)

MPLS Label Distribution Protocol (LDP), Resource Reservation Protocol (RSVP), and Universal Control Plane (UCP) command descriptions are documented separately.

For detailed information about MPLS concepts, configuration tasks, and examples, see *Cisco IOS XR MPLS Configuration Guide for the Cisco XR 12000 Series Router*.

- [adjustment-threshold \(MPLS-TE\), page 150](#)
- [admin-weight, page 152](#)
- [affinity, page 154](#)
- [affinity-map, page 158](#)
- [application \(MPLS-TE\), page 160](#)
- [attribute-flags, page 162](#)
- [attribute-names, page 164](#)
- [auto-bw \(MPLS-TE\), page 166](#)
- [auto-bw collect frequency \(MPLS-TE\), page 168](#)
- [autoroute announce, page 170](#)
- [autoroute metric, page 172](#)
- [auto-tunnel backup \(MPLS-TE\), page 174](#)
- [backup-bw, page 176](#)
- [backup-path tunnel-te, page 179](#)

- [bw-limit \(MPLS-TE\), page 181](#)
- [clear mpls lmp, page 183](#)
- [clear mpls traffic-eng auto-bw \(MPLS-TE EXEC\), page 184](#)
- [clear mpls traffic-eng auto-tunnel backup unused, page 186](#)
- [clear mpls traffic-eng auto-tunnel mesh, page 188](#)
- [clear mpls traffic-eng counters auto-tunnel mesh, page 189](#)
- [clear mpls traffic-eng counters auto-tunnel backup, page 190](#)
- [clear mpls traffic-eng counters global, page 191](#)
- [clear mpls traffic-eng counters signaling, page 192](#)
- [clear mpls traffic-eng counters soft-preemption, page 194](#)
- [clear mpls traffic-eng fast-reroute log, page 196](#)
- [clear mpls traffic-eng link-management statistics, page 197](#)
- [clear mpls traffic-eng pce, page 198](#)
- [collect-bw-only \(MPLS-TE\), page 199](#)
- [destination \(MPLS-TE\), page 201](#)
- [direction \(GMPLS\), page 203](#)
- [disable \(explicit-path\), page 205](#)
- [ds-te bc-model, page 207](#)
- [ds-te mode, page 209](#)
- [ds-te te-classes, page 211](#)
- [exclude srlg \(auto-tunnel backup\), page 214](#)
- [explicit-path, page 216](#)
- [fast-reroute, page 218](#)
- [fast-reroute protect, page 220](#)
- [fast-reroute timers promotion, page 222](#)
- [flooding-igp \(GMPLS\), page 224](#)
- [flooding thresholds, page 226](#)
- [forwarding-adjacency, page 228](#)
- [index exclude-address, page 230](#)
- [index exclude-srlg, page 232](#)
- [index next-address, page 234](#)
- [interface \(MPLS-TE\), page 236](#)
- [interface \(SRLG\), page 238](#)

- [interface tunnel-gte, page 240](#)
- [interface tunnel-te, page 242](#)
- [ipcc interface \(MPLS-TE\), page 244](#)
- [ipcc routed \(MPLS-TE\), page 246](#)
- [ipv4 unnumbered \(MPLS\), page 248](#)
- [link-management timers bandwidth-hold, page 250](#)
- [link-management timers periodic-flooding, page 252](#)
- [link-management timers preemption-delay, page 254](#)
- [lmp hello \(GMPLS\), page 255](#)
- [lmp neighbor \(MPLS-TE\), page 257](#)
- [lmp router-id \(MPLS-TE\), page 259](#)
- [match \(GMPLS\), page 261](#)
- [maxabs \(MPLS-TE\), page 263](#)
- [mpls traffic-eng, page 265](#)
- [mpls traffic-eng auto-bw apply \(MPLS-TE\), page 266](#)
- [mpls traffic-eng fast-reroute promote, page 268](#)
- [mpls traffic-eng level, page 269](#)
- [mpls traffic-eng link-management flood, page 271](#)
- [mpls traffic-eng path-protection switchover gmpls, page 273](#)
- [mpls traffic-eng pce activate-pcep, page 275](#)
- [mpls traffic-eng pce reoptimize, page 277](#)
- [mpls traffic-eng reoptimize \(EXEC\), page 279](#)
- [mpls traffic-eng router-id \(MPLS-TE router\), page 281](#)
- [mpls traffic-eng repotimize mesh group, page 283](#)
- [nhop-only \(auto-tunnel backup\), page 284](#)
- [overflow threshold \(MPLS-TE\), page 286](#)
- [passive \(GMPLS\), page 288](#)
- [path-option \(MPLS-TE\), page 290](#)
- [path-selection ignore overload \(MPLS-TE\), page 293](#)
- [path-selection loose-expansion affinity \(MPLS-TE\), page 295](#)
- [path-selection loose-expansion metric \(MPLS-TE\), page 297](#)
- [path-selection metric \(MPLS-TE\), page 299](#)
- [path-selection metric \(interface\), page 301](#)

- [pce address \(MPLS-TE\), page 303](#)
- [pce deadtimer \(MPLS-TE\), page 305](#)
- [pce keepalive \(MPLS-TE\), page 307](#)
- [pce peer \(MPLS-TE\), page 309](#)
- [pce reoptimize \(MPLS-TE\), page 311](#)
- [pce request-timeout \(MPLS-TE\), page 313](#)
- [pce tolerance keepalive \(MPLS-TE\), page 315](#)
- [policy-class, page 317](#)
- [priority \(MPLS-TE\), page 319](#)
- [record-route, page 321](#)
- [remote \(GMPLS\), page 323](#)
- [reoptimize \(MPLS-TE\), page 325](#)
- [reoptimize timers delay \(MPLS-TE\), page 327](#)
- [router-id secondary \(MPLS-TE\), page 330](#)
- [show explicit-paths, page 332](#)
- [show mpls traffic-eng affinity-map, page 334](#)
- [show mpls traffic-eng autoroute, page 336](#)
- [show mpls traffic-eng auto-tunnel backup, page 338](#)
- [show mpls traffic-eng auto-tunnel mesh, page 341](#)
- [show mpls traffic-eng collaborator-timers, page 343](#)
- [show mpls traffic-eng counters signaling, page 345](#)
- [show mpls traffic-eng ds-te te-class, page 350](#)
- [show mpls traffic-eng forwarding, page 352](#)
- [show mpls traffic-eng forwarding-adjacency, page 355](#)
- [show mpls traffic-eng igp-areas, page 356](#)
- [show mpls traffic-eng link-management admission-control, page 358](#)
- [show mpls traffic-eng link-management advertisements, page 362](#)
- [show mpls traffic-eng link-management bandwidth-allocation, page 365](#)
- [show mpls traffic-eng link-management bfd-neighbors, page 368](#)
- [show mpls traffic-eng link-management igp-neighbors, page 370](#)
- [show mpls traffic-eng link-management interfaces, page 372](#)
- [show mpls traffic-eng link-management statistics, page 375](#)
- [show mpls traffic-eng link-management summary, page 377](#)

- [show mpls traffic-eng lmp](#), page 379
- [show mpls traffic-eng maximum tunnels](#), page 383
- [show mpls traffic-eng pce peer](#), page 386
- [show mpls traffic-eng pce tunnels](#), page 388
- [show mpls traffic-eng preemption log](#), page 390
- [show mpls traffic-eng topology](#), page 391
- [show mpls traffic-eng tunnels](#), page 401
- [show mpls traffic-eng tunnels auto-bw brief](#), page 427
- [show srlg](#), page 429
- [signalled-name](#), page 432
- [signalling advertise explicit-null \(MPLS-TE\)](#), page 433
- [snmp traps mpls traffic-eng](#), page 435
- [srlg](#), page 437
- [switching \(GMPLS\)](#), page 439
- [switching endpoint \(GMPLS\)](#), page 441
- [switching transit \(GMPLS\)](#), page 443
- [timers loose-path \(MPLS-TE\)](#), page 445
- [timers removal unused \(auto-tunnel backup\)](#), page 447
- [topology holddown sigerr \(MPLS-TE\)](#), page 449
- [tunnel-id \(auto-tunnel backup\)](#), page 451

adjustment-threshold (MPLS-TE)

To configure the tunnel bandwidth change threshold to trigger an adjustment, use the **adjustment-threshold** command in MPLS-TE automatic bandwidth interface configuration mode. To disable this feature, use the **no** form of this command.

adjustment-threshold *percentage* [**min** *minimum bandwidth*]

no adjustment-threshold *percentage* [**min** *minimum bandwidth*]

Syntax Description

<i>percentage</i>	Bandwidth change percent threshold to trigger an adjustment if the largest sample percentage is higher or lower than the current tunnel bandwidth. The range is from 1 to 100. The default is 5.
min <i>minimum bandwidth</i>	(Optional) Configures the bandwidth change value to trigger an adjustment. The tunnel bandwidth is changed only if the largest sample is higher or lower than the current tunnel bandwidth, in kbps. The range is from 10 to 4294967295. The default is 10.

Command Default

percentage: 5
minimum bandwidth: 10

Command Modes

MPLS-TE automatic bandwidth interface configuration

Command History

Release	Modification
Release 3.8.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

If you configure or modify the adjustment threshold while the automatic bandwidth is already running, the next bandwidth application is impacted for that tunnel. The new adjustment threshold determines if an actual bandwidth takes place.

Examples

The following example configures the tunnel bandwidth change threshold to trigger an adjustment:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-te 1
RP/0/0/CPU0:router(config-if)# auto-bw
```

```
RP/0/0/CPU0:router(config-if-tunte-autobw)# adjustment-threshold 20 min 500
```

Related Commands

Command	Description
application (MPLS-TE), on page 160	Configures the application frequency, in minutes, for the applicable tunnel.
auto-bw (MPLS-TE), on page 166	Configures automatic bandwidth on a tunnel interface and enters MPLS-TE automatic bandwidth interface configuration mode.
bw-limit (MPLS-TE), on page 181	Configures the minimum and maximum automatic bandwidth to set on a tunnel.
collect-bw-only (MPLS-TE), on page 199	Enables only the bandwidth collection without adjusting the automatic bandwidth.
overflow threshold (MPLS-TE), on page 286	Configures tunnel overflow detection.
show mpls traffic-eng tunnels, on page 401	Displays information about MPLS-TE tunnels.

admin-weight

To override the Interior Gateway Protocol (IGP) administrative weight (cost) of the link, use the **admin-weight** command in MPLS-TE interface configuration mode. To return to the default behavior, use the **no** form of this command.

admin-weight *weight*

no admin-weight *weight*

Syntax Description

<i>weight</i>	Administrative weight (cost) of the link. Range is 0 to 4294967295.

Command Default

weight: IGP Weight (default OSPF 1, ISIS 10)

Command Modes

MPLS-TE interface configuration

Command History

Release	Modification
Release 3.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

To use MPLS the **admin-weight** command for MPLS LSP path computations, path-selection metric must be configured to TE.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to override the IGP cost of the link and set the cost to 20:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# interface POS 0/7/0/0
RP/0/0/CPU0:router(config-mpls-te-if)# admin-weight 20
```

Related Commands

Command	Description
interface (MPLS-TE), on page 236	Enables MPLS-TE on an interface and enters MPLS-TE interface configuration mode.
mpls traffic-eng, on page 265	Enters MPLS-TE configuration mode.
path-selection metric (interface), on page 301	Specifies an MPLS-TE tunnel path-selection metric type.

affinity

To configure an affinity (the properties the tunnel requires in its links) for an MPLS-TE tunnel, use the **affinity** command in interface configuration mode. To disable this behavior, use the **no** form of this command.

affinity {*affinity-value* **mask** *mask-value* | **exclude** *name* | **exclude-all** | **include** *name* | **include-strict** *name*}
no affinity {*affinity-value* **mask** *mask-value* | **exclude** *name* | **exclude-all** | **include** *name* | **include-strict** *name*}

Syntax Description

<i>affinity-value</i>	Attribute values that are required for links to carry this tunnel. A 32-bit decimal number. Range is from 0x0 to 0xFFFFFFFF, representing 32 attributes (bits), where the value of an attribute is 0 or 1.
mask <i>mask-value</i>	Checks the link attribute. A 32-bit decimal number. Range is 0x0 to 0xFFFFFFFF, representing 32 attributes (bits), where the value of an attribute mask is 0 or 1.
exclude <i>name</i>	Configures a particular affinity to exclude.
exclude-all	Excludes all affinities.
include <i>name</i>	Configures the affinity to include in the loose sense.
include-strict <i>name</i>	Configures the affinity to include in the strict sense.

Command Default

affinity-value: 0X00000000
mask-value: 0xFFFFFFFF

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.2	This command was supported.
Release 3.4.0	Support was added for the Name-Based Affinity Constraint scheme.
Release 3.7.0	Affinity colors definition for MPLS-TE was added.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Affinity determines the link attributes of the tunnel (that is, the attributes for which the tunnel has an affinity). The attribute mask determines which link attribute the router should check. If a bit in the mask is 0, the attribute value of a link or that bit is irrelevant. If a bit in the mask is 1, the attribute value of that link and the required affinity of the tunnel for that bit must match.

A tunnel can use a link if the tunnel affinity equals the link attributes and the tunnel affinity mask.

Any properties set to 1 in the affinity should be 1 in the mask. The affinity and mask should be set as follows:

```
tunnel_affinity=tunnel_affinity and tunnel_affinity_mask
```

You can configure up to 16 affinity constraints under a given tunnel. These constraints are used to configure affinity constraints for the tunnel:

Include constraint

Specifies that a link is considered for CSPF if it contains all affinities associated with the include constraint. An acceptable link contains more affinity attributes than those associated with the include statement. You can have multiple include statements under a tunnel configuration.

Include-strict constraint

Specifies that a link is considered for CSPF if it contains only the colors associated with the include-strict statement. The link cannot have any additional colors. In addition, a link without a color is rejected.

Exclude constraint

Specifies that a link satisfies an exclude constraint if it does not have all the colors associated with the constraint. In addition, a link that does not have any attribute satisfies an exclude constraint.

Exclude-all constraint

Specifies that only the links without any attribute are considered for CSPF. An exclude-all constraint is not associated with any color; whereas, all other constraint types are associated with up to 10 colors.

You set one bit for each color; however, the sample output shows multiple bits at the same time. For example, you can configure red and black colors on GigabitEthernet0/4/1/3 from the **interface** command. The sample output from the [show mpls traffic-eng link-management interfaces](#), [on page 372](#) command shows that the Attributes field is set to 0x21, which means that there are 0x20 and 0x1 bits on the link.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

This example shows how to configure the tunnel affinity and mask:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-te 1
RP/0/0/CPU0:router(config-if)# affinity 0101 mask 303
```

This example shows that a link is eligible for CSPF if the color is red.. The link can have any additional colors.

```
RP/0/0/CPU0:router# configure
```

```
RP/0/0/CPU0:router(config)# interface tunnel-te 1
RP/0/0/CPU0:router(config-if)# affinity include red
```

This example shows that a link is eligible for CSPF if it has at least red and black colors. The link can have any additional colors.

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-te 1
RP/0/0/CPU0:router(config-if)# affinity include red black
```

This sample output shows that the include constraint from the **show mpls traffic-eng tunnels** command is 0x20 and 0x1:

```
Name: tunnel-tel Destination: 0.0.0.0
Status:
  Admin:      up Oper: down  Path: not valid  Signalling: Down
  G-PID: 0x0800 (internally specified)

Config Parameters:
  Bandwidth:      0 kbps (CT0) Priority:  7  7
  Number of configured name based affinity constraints: 1
  Name based affinity constraints in use:
    Include bit map      : 0x21
  Metric Type: TE (default)
  AutoRoute: disabled LockDown: disabled
  Loadshare:      0 equal loadshares
  Auto-bw: disabled(0/0) 0 Bandwidth Requested:      0
  Direction: unidirectional
  Endpoint switching capability: unknown, encoding type: unassigned
  Transit switching capability: unknown, encoding type: unassigned

Reason for the tunnel being down: No destination is configured
History:
```

This example shows that a tunnel can go over a link that contains red or black affinity. A link is eligible for CSPF if it has a red color or a black color. Thus, a link with red and any other colors and a link with black and other additional colors must meet the constraint.

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-te 1
RP/0/0/CPU0:router(config-if)# affinity include red
RP/0/0/CPU0:router(config-if)# affinity include black
```

This sample output shows that the include constraint from the **show mpls traffic-eng tunnels** command is 0x20 or 0x1:

```
Name: tunnel-tel Destination: 0.0.0.0
Status:
  Admin:      up Oper: down  Path: not valid  Signalling: Down
  G-PID: 0x0800 (internally specified)

Config Parameters:
  Bandwidth:      0 kbps (CT0) Priority:  7  7
  Number of configured name based affinity constraints: 2
  Name based affinity constraints in use:
    Include bit map      : 0x1
    Include bit map      : 0x20
  Metric Type: TE (default)
  AutoRoute: disabled LockDown: disabled
  Loadshare:      0 equal loadshares
  Auto-bw: disabled(0/0) 0 Bandwidth Requested:      0
  Direction: unidirectional
  Endpoint switching capability: unknown, encoding type: unassigned
  Transit switching capability: unknown, encoding type: unassigned
```


Reason for the tunnel being down: No destination is configured
History:

This example shows that a link is eligible for CSPF if it has only red color. The link must not have any additional colors.

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-te 1
RP/0/0/CPU0:router(config-if)# affinity include-strict red
```

This example shows that a link is eligible for CSPF if it does not have the red attribute:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-te 1
RP/0/0/CPU0:router(config-if)# affinity exclude red
```

This example shows that a link is eligible for CSPF if it does not have red and blue attributes. Thus, a link that has only a red attribute or only a blue attribute is eligible for CSPF.

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-te 1
RP/0/0/CPU0:router(config-if)# affinity exclude red blue
```

This example shows that a link is eligible for CSPF if it does not have either a red or a blue attribute:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-te 1
RP/0/0/CPU0:router(config-if)# affinity exclude red
RP/0/0/CPU0:router(config-if)# affinity exclude blue
```

Related Commands

Command	Description
affinity-map, on page 158	Assigns a numerical value to each affinity name.
attribute-names, on page 164	Configures attribute names for the interface.
interface tunnel-te, on page 242	Configures an MPLS-TE tunnel interface.
show mpls traffic-eng affinity-map, on page 334	Displays the color name-to-value mappings configured on the router.
show mpls traffic-eng tunnels, on page 401	Displays information about MPLS-TE tunnels.

affinity-map

To assign a numerical value to each affinity name, use the **affinity-map** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

affinity-map *affinity name* {*affinity value*| **bit-position** *value*}

no affinity-map *affinity name* {*affinity value*| **bit-position** *value*}

Syntax Description

<i>affinity name</i>	Affinity map name-to-value designator (in hexadecimal, <i>0-ffffff</i>).
<i>affinity value</i>	Affinity map value designator. Range is from 1 to 80000000.
bit-position	Configures the value of an affinity map for the bit position of the 32-bit number.
<i>value</i>	Bit position value. Range is from 0 to 31.

Command Default

No default behavior or values

Command Modes

MPLS-TE configuration

Command History

Release	Modification
Release 3.4.0	This command was introduced.
Release 3.9.0	The following command syntax was enhanced: • The <i>affinity value</i> argument range was changed to 1 to 80000000. • The bit-position keyword and <i>value</i> argument were added. • Sample output was added to show how to configure the value for the bit position.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note

The name-to-value mapping must represent a single bit of a 32-bit value.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to assign a numerical value to each affinity name:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# affinity-map red 1
RP/0/0/CPU0:router(config-mpls-te)# affinity-map blue 2
```

The following example shows how to configure the value of 15 for an affinity map by bit position:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# affinity-map red2 bit-position 15
```

Related Commands

Command	Description
affinity, on page 154	Configures affinity (the properties that the tunnel requires in its links) for an MPLS-TE tunnel.
mpls traffic-eng, on page 265	Enters MPLS-TE configuration mode.
show mpls traffic-eng affinity-map, on page 334	Displays the color name-to-value mappings configured on the router.

application (MPLS-TE)

To configure the application frequency, in minutes, for the applicable tunnel, use the **application** command in MPLS-TE automatic bandwidth interface configuration mode. To disable this feature, use the **no** form of this command.

application *minutes*

no application *minutes*

Syntax Description

<i>minutes</i>	Frequency, in minutes, for the automatic bandwidth application. The range is from 5 to 10080 (7 days). The default is 1440.

Command Default

minutes : 1440 (24 hours)

Command Modes

MPLS-TE automatic bandwidth interface configuration

Command History

Release	Modification
Release 3.8.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

If you configure and modify the application frequency, the application period can reset and restart for that tunnel. The next bandwidth application for the tunnel happens within the specified minutes.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to configure application frequency to 1000 minutes for MPLS-TE interface 1:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-te 1
RP/0/0/CPU0:router(config-if)# auto-bw
RP/0/0/CPU0:router(config-if-tunte-autobw)# application 1000
```

Related Commands

Command	Description
adjustment-threshold (MPLS-TE), on page 150	Configures the tunnel-bandwidth change threshold to trigger an adjustment.
auto-bw (MPLS-TE), on page 166	Configures automatic bandwidth on a tunnel interface and enters MPLS-TE automatic bandwidth configuration mode.
bw-limit (MPLS-TE), on page 181	Configures the minimum and maximum automatic bandwidth to set on a tunnel.
collect-bw-only (MPLS-TE), on page 199	Enables only the bandwidth collection without adjusting the automatic bandwidth.
interface tunnel-te, on page 242	Configures an MPLS-TE tunnel interface.
overflow threshold (MPLS-TE), on page 286	Configures tunnel overflow detection.
show mpls traffic-eng tunnels, on page 401	Displays information about MPLS-TE tunnels.

attribute-flags

To configure attribute flags for an interface, use the **attribute-flags** command in MPLS-TE interface configuration mode. To return to the default behavior, use the **no** form of this command.

attribute-flags *attribute-flags*

no attribute-flags *attribute-flags*

Syntax Description

<i>attribute -flags</i>	Links attributes that are compared to the affinity bits of a tunnel during selection of a path. Range is 0x0 to 0xFFFFFFFF, representing 32 attributes (bits) where the value of an attribute is 0 or 1.

Command Default

attributes : 0x0

Command Modes

MPLS-TE interface configuration

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **attribute-flags** command assigns attributes to a link so that tunnels with matching attributes (represented by their affinity bits) prefer this link instead of others that do not match.

The interface attribute is flooded globally so that it can be used as a tunnel headend path selection criterion.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to set attribute flags to 0x0101:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# interface POS 0/7/0/0
RP/0/0/CPU0:router(config-mpls-te-if)# attribute-flags 0x0101
```

Related Commands

Command	Description
admin-weight, on page 152	Overrides the IGP administrative weight of the link.
affinity, on page 154	Configures affinity (the properties that the tunnel requires in its links) for an MPLS-TE tunnel.
attribute-names, on page 164	Configures the attribute names for the interface.
interface (MPLS-TE), on page 236	Enables MPLS-TE on an interface and enters MPLS-TE interface configuration mode.
mpls traffic-eng, on page 265	Enters MPLS-TE configuration mode.

attribute-names

To configure attributes for the interface, use the **attribute-names** command in MPLS-TE interface configuration mode. To return to the default behavior, use the **no** form of this command.

attribute-names *attribute name*

no attribute-names *attribute name*

Syntax Description

<i>attribute name</i>	Attribute name expressed using alphanumeric or hexadecimal characters.

Command Default

No default behavior or values

Command Modes

MPLS-TE interface configuration

Command History

Release	Modification
Release 3.4.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note

The name-to-value mapping must represent a single bit of a 32-bit value.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to assign an attribute name (in this case, red) to a TE link:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# interface pos 0/2/0/1
RP/0/0/CPU0:router(config-mpls-te-if)# attribute-name red
```


Related Commands

Command	Description
affinity , on page 154	Configures affinity (the properties that the tunnel requires in its links) for an MPLS-TE tunnel.
attribute-flags , on page 162	Configures attribute flags for the interface.
interface (MPLS-TE) , on page 236	Enables MPLS-TE on an interface and enters MPLS-TE interface configuration mode.
mpls traffic-eng , on page 265	Enters MPLS-TE configuration mode.

auto-bw (MPLS-TE)

To configure automatic bandwidth on a tunnel interface and to enter MPLS-TE automatic bandwidth interface configuration mode, use the **auto-bw** command in MPLS-TE interface configuration mode. To disable the automatic bandwidth on that tunnel, use the **no** form of this command.

auto-bw

no auto-bw

Syntax Description This command has no arguments or keywords.

Command Default By default, automatic bandwidth is not enabled.

Command Modes MPLS-TE interface configuration

Command History	Release	Modification
	Release 3.8.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **auto-bw** command to enter MPLS-TE automatic bandwidth interface configuration mode.

The **auto-bw** and **load-share unequal** commands should not be used together.

The **load-share unequal** command determines the load-share for a tunnel based on the bandwidth. However, the MPLS-TE automatic bandwidth feature changes the bandwidth around. If you are configuring both the **load-share unequal** command and the MPLS-TE automatic bandwidth feature, we recommend that you specify an explicit load-share value configuration under each MPLS-TE automatic bandwidth tunnel.

The following automatic bandwidth scenarios are described:

- If you configure the automatic bandwidth on a tunnel, the automatic bandwidth is enabled on that tunnel. If no other configuration is specified, defaults for the various parameters are used, the operation stops.
- The automatic operation (for example, output rate collection) starts as soon as the automatic bandwidth is enabled on one tunnel. If automatic bandwidth is disabled from all tunnels, the operation stops.
- If the output rate collection is already active when the automatic bandwidth is configured on a tunnel, the statistics collection for that tunnel starts at the next collection configuration.

**Note**

Because the collection timer is already running, the first collection event for that tunnel happens in less than C minutes (for example, on an average of C/2 minutes).

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to enter MPLS-TE automatic bandwidth interface configuration mode:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router# interface tunnel-te 1
RP/0/0/CPU0:router(config-if)# auto-bw
RP/0/0/CPU0:router(config-if-tunte-autobw)#
```

Related Commands

Command	Description
adjustment-threshold (MPLS-TE), on page 150	Configures the tunnel-bandwidth change threshold to trigger an adjustment.
application (MPLS-TE), on page 160	Configures the application frequency, in minutes, for the applicable tunnel.
bw-limit (MPLS-TE), on page 181	Configures the minimum and maximum automatic bandwidth to set on a tunnel.
collect-bw-only (MPLS-TE), on page 199	Enables only the bandwidth collection without adjusting the automatic bandwidth.
interface tunnel-te, on page 242	Configures an MPLS-TE tunnel interface.
overflow threshold (MPLS-TE), on page 286	Configures tunnel overflow detection.
show mpls traffic-eng tunnels, on page 401	Displays information about MPLS-TE tunnels.

auto-bw collect frequency (MPLS-TE)

To configure the automatic bandwidth collection frequency, use the **auto-bw collect frequency** command in MPLS-TE configuration mode. To reset the automatic bandwidth frequency to its default value, use the **no** form of this command.

auto-bw collect frequency *minutes*

no auto-bw collect frequency *minutes*

Syntax Description

<i>minutes</i>	Interval between automatic bandwidth adjustments, in minutes. The range is from 1 to 10080. The default is 5.

Command Default

minutes: 5

In addition, the **no** form of this command resets to the default.

Command Modes

MPLS-TE configuration

Command History

Release	Modification
Release 3.8.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **auto-bw collect frequency** command configures the automatic bandwidth collection frequency for all the tunnels.

Modifying the global collection frequency does not restart the tunnel for the current application period. The application period continues with the modified collection frequency.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example configures a tunnel for an automatic bandwidth adjustment of 100 minutes:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
```

```
RP/0/0/CPU0:router(config-mpls-te)# auto-bw collect frequency 100
```

Related Commands

Command	Description
mpls traffic-eng, on page 265	Enters MPLS-TE configuration mode.
mpls traffic-eng auto-bw apply (MPLS-TE), on page 266	Configures the highest bandwidth available on a tunnel without waiting for the current application period to end.
show mpls traffic-eng tunnels, on page 401	Displays information about MPLS-TE tunnels.

autoroute announce

To specify that the Interior Gateway Protocol (IGP) should use the tunnel (if the tunnel is up) in its enhanced shortest path first (SPF) calculation, use the **autoroute announce** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

autoroute announce

no autoroute announce

Syntax Description	This command has no arguments or keywords.

Command Default	No default behavior or values

Command Modes	Interface configuration

Command History	Release	Modification
	Release 3.2	This command was supported.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples	The following example shows how to configure IGP to use the tunnel in its enhanced SPF calculation when the tunnel is up:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-te 1
```

```
RP/0/0/CPU0:router(config-if)# autoroute announce
```

Related Commands

Command	Description
interface tunnel-te, on page 242	Configures an MPLS-TE tunnel interface.

autoroute metric

To specify the MPLS-TE tunnel metric that the Interior Gateway Protocol (IGP) enhanced Shortest Path First (SPF) calculation uses, use the **autoroute metric** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

autoroute metric {**absolute**|**relative**} *value*

no autoroute metric {**absolute**|**relative**} *value*

Syntax Description

absolute	Displays the absolute metric mode; you can enter a positive metric value.
relative	Displays the relative metric mode; you can enter a positive, negative, or zero value.
<i>value</i>	Metric that the IGP enhanced SPF calculation uses. Relative value range is –10 to 10. Absolute value is 1 to 2147483647.

Command Default

relative *value* : 0

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.2	This command was supported.
Release 3.9.0	The absolute value range is from 1 to 2147483647.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **autoroute metric** command overwrites the default tunnel route metric of the shortest IGP path to the destination.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to configure the IGP enhanced SPF calculation using MPLS-TE tunnel metric as relative negative 1:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-te 1
RP/0/0/CPU0:router(config-if)# autoroute metric relative -1
```

Related Commands

Command	Description
autoroute announce , on page 170	Instructs the IGP to use the tunnel (if it is up) in its enhanced SPF calculation.
interface tunnel-te , on page 242	Configures an MPLS-TE tunnel interface.
show mpls traffic-eng autoroute , on page 336	Displays the tunnels announced to the IGP, including interface, destination, and bandwidth.

auto-tunnel backup (MPLS-TE)

To automatically build next-hop (NHOP) and next-next-hop (NNHOP) backup tunnels, and to enter auto-tunnel backup configuration mode, use the **auto-tunnel backup** command in MPLS-TE configuration mode. To clear the NHOP and NNHOP backup tunnels, use the **no** form of this command.

auto-tunnel backup

no auto-tunnel backup

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes MPLS-TE configuration

Command History	Release	Modification
	Release 4.0.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The range of *tunnel-ID* is required to be mentioned for the auto-tunnel backup tunnels; otherwise, none of the tunnels are created.

The **no** form of this command deletes both NHOP and NNHOP backup tunnels that are configured using either the **auto-tunnel backup** command or the **nhop-only** command.

Task ID	Task ID	Operation
	mpls-te	read, write

Examples The following example automatically builds NHOP and NNHOP backup tunnels:

```
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# auto-tunnel backup
```

Related Commands

Command	Description
clear mpls traffic-eng auto-tunnel backup unused, on page 186	Clears the unused automatic backup tunnels.
<code>mpls traffic-eng <i>interface-path-id</i> auto-tunnel backup</code>	Configures the automatic backup tunnel for a specific interface.
show mpls traffic-eng tunnels, on page 401	Displays information about MPLS-TE tunnels.
tunnel-id (auto-tunnel backup), on page 451	Configures range of tunnel interface numbers for automatic backup tunnels.

backup-bw

To configure the backup bandwidth for an MPLS-TE backup tunnel (that is used to protect a physical interface), use the **backup-bw** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

backup-bw {*backup bandwidth* {**any-class-type**| **class-type ct**}| **global-pool** {*bandwidth*| **unlimited**}| **sub-pool** {*bandwidth*| **unlimited**}| **unlimited** {**any-class-type**| **class-type ct**} }

no backup-bw {*backup bandwidth* {**any-class-type**| **class-type ct**}| **global-pool** {*bandwidth*| **unlimited**}| **sub-pool** {*bandwidth*| **unlimited**}| **unlimited** {**any-class-type**| **class-type ct**} }

Syntax Description

<i>backup bandwidth</i>	Backup bandwidth in any-pool provided by an MPLS-TE backup tunnel. Bandwidth is specified in kilobits per second (kbps). Range is 1 to 4294967295.
any-class-type	Displays the backup bandwidth assigned to any class-type protected tunnels.
class-type ct	Displays the class type of the backup bandwidth. Range is 0 to 1.
global-pool <i>bandwidth</i>	(In Prestandard DS-TE with RDM) Displays the backup bandwidth in global pool provided by an MPLS-TE backup tunnel. Bandwidth is specified in kilobits per second. Range is 1 to 4294967295.
unlimited	Displays the unlimited bandwidth.
sub-pool <i>bandwidth</i>	(In Prestandard DS-TE with RDM) Displays the backup bandwidth in sub-pool provided by an MPLS-TE backup tunnel. Bandwidth is specified in kilobits per second. Range bandwidth is 1 to 4294967295. Only label switched paths (LSPs) using bandwidth from the sub-pool can use the backup tunnel.

Command Default

Any class-type unlimited.

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Backup bandwidth can be limited or unlimited or specific to a global pool, sub-pool, or non-specific any-pool. Backup with backup-bw in global-pool protects global-pool LSPs only; backup-bw in sub-pool protects sub-pool LSPs only.

Backup tunnels configured with limited backup bandwidth (from any/global/sub pool) are not assigned to protect LSPs configured with zero signaled bandwidth.

Backup bandwidth provides bandwidth protection for fast reroute (FRR). Bandwidth protection for FRR supports DiffServ-TE with two bandwidth pools (class-types).

Class-type 0 is strictly equivalent to global-pool; class-type 1 is strictly equivalent to sub-pool bandwidth using the Russian Doll Model (RDM).

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to configure backup tunnel 1 for use only by LSPs that take their bandwidth from the global pool (class-type 0 tunnels). Backup tunnel 1 does not provide bandwidth protection.

```
RP/0/0/CPU0:router(config)# interface tunnel-te 1
RP/0/0/CPU0:router(config-if)# backup-bw global-pool unlimited
```

or

```
RP/0/0/CPU0:router(config)# interface tunnel-te 1
RP/0/0/CPU0:router(config-if)# backup-bw unlimited class-type 0
```

In the following example, backup tunnel 2 is used by LSPs that take their bandwidth from the sub-pool (class-type 1 tunnels) only. Backup tunnel 2 provides bandwidth protection for up to 1000 units.

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-te 2
RP/0/0/CPU0:router(config-if)# backup-bw sub-pool 1000
```

or

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-te 2
RP/0/0/CPU0:router(config-if)# backup-bw 1000 class-type 1
```

Related Commands

Commands	Description
backup-path tunnel-te, on page 179	Assigns one or more backup tunnels to a protected interface.
fast-reroute, on page 218	Enables FRR protection for an MPLS-TE tunnel.
interface tunnel-te, on page 242	Configures an MPLS-TE tunnel interface.

backup-path tunnel-te

To set an MPLS-TE tunnel to protect a physical interface against failure, use the **backup-path tunnel-te** command in MPLS-TE interface configuration mode. To return to the default behavior, use the **no** form of this command.

backup-path tunnel-te *tunnel-number*

no backup-path tunnel-te *tunnel-number*

Syntax Description

<i>tunnel-number</i>	Number of the tunnel protecting the interface. Range is 0 to 65535.

Command Default

No default behavior or values

Command Modes

MPLS-TE interface configuration

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

When the protected interface is down (shut down or removed), the traffic it was carrying (for the other label switched paths [LSPs], referred to as the protected LSPs) is rerouted, using fast reroute (FRR) onto the backup tunnels.

The following guidelines pertain to the FRR process:

- Multiple (backup) tunnels can protect the same interface by entering this command multiple times for different tunnels. The same (backup) tunnel can protect multiple interfaces by entering this command for each interface.
- The backup tunnel used to protect a physical interface must have a valid IP address configured.
- The backup tunnel cannot pass through the same interface that it is protecting.
- TE tunnels that are configured with the FRR option, cannot be used as backup tunnels.
- For the backup tunnel to provide protection to the protected LSP, the backup tunnel must have a terminating-end node in the path of a protected LSP.
- The source IP address of the backup tunnel and the merge point (MP) address (the terminating-end address of the backup tunnel) must be reachable.

**Note**

You must configure record-route on TE tunnels that are protected by multiple backup tunnels merging at a single node.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to protect PoS interface 0/7/0/0 using tunnel 100 and tunnel 150:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# interface POS 0/7/0/0
RP/0/0/CPU0:router(config-mpls-te-if)# backup-path tunnel-te 100
RP/0/0/CPU0:router(config-mpls-te-if)# backup-path tunnel-te 150
```

Related Commands

Command	Description
backup-bw, on page 176	Configures backup bandwidth for bandwidth protection.
fast-reroute, on page 218	Enables FRR protection for an MPLS-TE tunnel.
interface (MPLS-TE), on page 236	Enables MPLS-TE on an interface and enters MPLS-TE interface configuration mode.
mpls traffic-eng, on page 265	Enters MPLS-TE configuration mode.
show mpls traffic-eng tunnels, on page 401	Displays information about MPLS-TE tunnels.

bw-limit (MPLS-TE)

To configure the minimum and maximum automatic bandwidth to be set on a tunnel, use the **bw-limit** command in MPLS-TE automatic bandwidth interface configuration mode. To disable this feature, use the **no** form of this command.

bw-limit **min** *bandwidth* [**max** *bandwidth*]

no bw-limit

Syntax Description

min <i>bandwidth</i>	Configures the minimum automatic bandwidth, in kbps, on a tunnel. The range is from 0 to 4294967295. The default is 0.
max <i>bandwidth</i>	Configures the maximum automatic bandwidth, in kbps, on a tunnel. The range is from 0 to 4294967295. The default is 4294967295.

Command Default

min: 0

max: 4294967295

Command Modes

MPLS-TE automatic bandwidth interface configuration

Command History

Release	Modification
Release 3.8.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Both the **min** and **max** keywords must be configured.

The **bw-limit** command automatically sets the minimum bandwidth to the default value of 0, or the **bw-limit** command automatically sets the maximum to the default value of 4294967295 kbps.

If the value of the **min** keyword is greater than the **max** keyword, the **bw-limit** command is rejected. If you configure and modify the minimum or maximum bandwidth while the automatic bandwidth is already running, the next bandwidth application for that tunnel is impacted. For example, if the current tunnel requested bandwidth is 30 Mbps and the minimum bandwidth is modified to 50 Mbps, the next application sets the tunnel bandwidth to 50 Mbps.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to configure the minimum and maximum bandwidth for the tunnel:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-te 1
RP/0/0/CPU0:router(config-if)# auto-bw
RP/0/0/CPU0:router(config-if-tunte-autobw)# bw-limit min 30 max 80
```

Related Commands

Command	Description
adjustment-threshold (MPLS-TE), on page 150	Configures the tunnel-bandwidth change threshold to trigger an adjustment.
application (MPLS-TE), on page 160	Configures the application frequency, in minutes, for the applicable tunnel.
auto-bw (MPLS-TE), on page 166	Configures automatic bandwidth on a tunnel interface and enters MPLS-TE automatic bandwidth interface configuration mode.
collect-bw-only (MPLS-TE), on page 199	Enables only the bandwidth collection without adjusting the automatic bandwidth.
interface tunnel-te, on page 242	Configures an MPLS-TE tunnel interface.
overflow threshold (MPLS-TE), on page 286	Configures tunnel overflow detection.
show mpls traffic-eng tunnels, on page 401	Displays information about MPLS-TE tunnels.

clear mpls lmp

To clear Link Management Protocol (LMP) management hello settings, use the **clear mpls lmp** command in EXEC mode.

clear mpls lmp

Syntax Description

This command has no arguments or keywords.

Command Modes

EXEC

Command History

Release	Modification
Release 3.3.0	This command was introduced
Release 3.8.0	This command was moved under Cisco support.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note

The LMP and GMPLS-NNI features are not supported on x86 RPs.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to clear all LMP management hello settings:

```
RP/0/0/CPU0:router# clear mpls lmp
```

clear mpls traffic-eng auto-bw (MPLS-TE EXEC)

To clear automatic bandwidth sampled output rates and to restart the application period for the specified tunnel, use the **clear mpls traffic-eng auto-bw** command in EXEC mode.

clear mpls traffic-eng auto-bw {all | internal | tunnel-te *tunnel-number*}

Syntax Description

all	Clears the automatic bandwidth sampled output rates for all tunnels.
internal	Clears all the automatic bandwidth internal data structures.
tunnel-te <i>tunnel-number</i>	Clears the automatic bandwidth sampled output rates for a specific tunnel. The <i>tunnel-number</i> argument is the tunnel ID used to clear the sampled output rates.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.8.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

If no tunnel is specified, the **clear mpls traffic-eng auto-bw** command clears all the automatic bandwidth enabled tunnels.

For each tunnel in which the automatic bandwidth adjustment is enabled, information is maintained about the sampled output rates and the time remaining until the next bandwidth adjustment. The application period is restarted and values such as the largest collected bandwidth get reset. The tunnel continues to use the current bandwidth until the next application.

Task ID

Task ID	Operations
mpls-te	execute

Examples

The following example displays the information for the automatic bandwidth for tunnel number 0 from the **show mpls traffic-eng tunnels auto-bw brief** command:

```
RP/0/0/CPU0:router# show mpls traffic-eng tunnels 0 auto-bw brief
```

Tunnel	LSP Name	Last appl ID	Requested BW (kbps)	Signalled BW (kbps)	Highest BW (kbps)	Application BW (kbps)	Time Left
tunnel-te0		278	100	100	100	150	12m 38s

The following example shows how to clear the automatic bandwidth sampled output rates for tunnel number 0:

```
RP/0/0/CPU0:router# clear mpls traffic-eng auto-bw tunnel-te 0
```

```
RP/0/0/CPU0:router# show mpls traffic-eng tunnels 0 auto-bw brief
```

Tunnel	LSP Name	Last appl ID	Requested BW (kbps)	Signalled BW (kbps)	Highest BW (kbps)	Application BW (kbps)	Time Left
tunnel-te0		278	100	100	100	0	24m 0s

Related Commands

Command	Description
clear mpls traffic-eng counters signaling, on page 192	Clears the automatic bandwidth configuration in a tunnel.
show mpls traffic-eng tunnels auto-bw brief, on page 427	Displays the list of automatic-bandwidth-enabled tunnels, and indicates if the current signaled bandwidth of the tunnel is identical to the bandwidth that is applied by the automatic bandwidth.

clear mpls traffic-eng auto-tunnel backup unused

To remove unused automatic backup tunnels, use the **clear mpls traffic-eng auto-tunnel backup unused** command in global configuration mode.

clear mpls traffic-eng auto-tunnel backup unused [**all** | **tunnel-te** *tunnel-number*]

Syntax Description

all	Clears all the unused automatic backup tunnels.
tunnel-te <i>tunnel-number</i>	Clears a specific unused automatic backup tunnel.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 4.0.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **unused** auto-tunnel backup tunnel is the tunnel that is not assigned to protect any FRR tunnel.

The behavior of this command is the same as the expiration of the **timers removal unused** command in which, when the timeout value is reached, the automatic backup tunnel is removed.

Task ID

Task ID	Operation
mpls-te	execute

Examples

The following example displays the information for the unused backup automatic tunnels from the **show mpls traffic-eng tunnels unused** command:

```
RP/0/0/CPU0:router# show mpls traffic-eng tunnels unused
```

The following example shows how to clear the unused backup automatic tunnels:

```
RP/0/0/CPU0:router# clear mpls traffic-eng auto-tunnel backup unused all
RP/0/0/CPU0:router# show mpls traffic-eng tunnels unused
```

Related Commands

Command	Description
show mpls traffic-eng tunnels , on page 401	Displays information about MPLS-TE tunnels.

clear mpls traffic-eng auto-tunnel mesh

To clear all unused auto-tunnel mesh destinations, use the **clear mpls traffic-eng auto-tunnel mesh** command in EXEC mode.

clear mpls traffic-eng auto-tunnel mesh unused {all| tunnel-te}

Syntax Description

all	Clears all applicable unused auto-tunnel destinations.
tunnel-te <i>id</i>	Clears an unused auto-tunnel destinations identified by a tunnel identifier.

Command Default

None

Command Modes

EXEC

Command History

Release	Modification
Release 4.1.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	execute

Examples

This is sample output from the **clear mpls traffic-eng auto-tunnel mesh** command:

```
clear mpls traffic-eng auto-tunnel mesh
```


clear mpls traffic-eng counters auto-tunnel mesh

To clear all auto-tunnel mesh counters, use the **clear mpls traffic-eng counters auto-tunnel mesh** command in EXEC mode.

clear mpls traffic-eng counters auto-tunnel mesh

This command has no arguments or keywords.

Command Default

None

Command Modes

EXEC

Command History

Release	Modification
Release 4.1.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	execute

Examples

This is sample output from the **clear mpls traffic-eng counters auto-tunnel mesh** command:

```
RP/0/0/CPU0:routerclear mpls traffic-eng counters auto-tunnel mesh
```

clear mpls traffic-eng counters auto-tunnel backup

To clear MPLS-TE automatic tunnel backup counters, use the **clear mpls traffic-eng counters auto-tunnel backup** command in EXEC mode.

clear mpls traffic-eng counters auto-tunnel backup

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes EXEC

Command History	Release	Modification
	Release 4.0.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	mpls-te	execute

Examples The following example removes all counters for the automatic backup tunnels:

```
RP/0/0/CPU0:router# clear mpls traffic-eng counters auto-tunnel backup
```

Related Commands	Command	Description
	show mpls traffic-eng counters auto-tunnel backup	Displays the MPLS-TE automatic tunnel backup counters.
	show mpls traffic-eng tunnels, on page 401	Displays information about MPLS-TE tunnels.

clear mpls traffic-eng counters global

To clear the internal MPLS-TE tunnel counters, use the **clear mpls traffic-eng counters global** command in EXEC mode.

clear mpls traffic-eng counters global

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes EXEC

Command History	Release	Modification
	Release 3.8.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	mpls-te	execute

Examples The following example shows how to clear the internal MPLS-TE tunnel counters:

```
RP/0/0/CPU0:router# clear mpls traffic-eng counters global
```

clear mpls traffic-eng counters signaling

To clear (set to zero) the MPLS tunnel signaling counters, use the **clear mpls traffic-eng counters signaling** command in EXEC mode.

clear mpls traffic-eng counters signaling {**all** | [**heads** | **mids** | **tails**]} [**name** *name* | **summary**]

Syntax Description

all	Clears counters for all MPLS-TE tunnels.
heads	(Optional) Displays tunnels with their heads at this router.
mids	(Optional) Displays tunnels with their midpoints at this router.
tails	(Optional) Displays tunnels with their tails at this router.
name <i>name</i>	Clears counters for an MPLS-TE tunnel with the specified name.
summary	Clears the counter's summary.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was supported.
Release 3.5.0	Support was added for the middles keyword.
Release 3.8.0	The clear mpls traffic-eng counters tunnels command was replaced by clear mpls traffic-eng counters signaling command.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **clear mpls traffic-eng counters signaling** command to set all MPLS counters to zero so that changes can be seen easily.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to clear all counters:

```
RP/0/0/CPU0:router# clear mpls traffic-eng counters signaling all
```

Related Commands

Command	Description
show mpls traffic-eng counters signaling, on page 345	Displays tunnel signaling statistics.

clear mpls traffic-eng counters soft-preemption

To clear (set to zero) the counters for soft-preemption statistics, use the **clear mpls traffic-eng counters soft-preemption** command in EXEC mode.

clear mpls traffic-eng counters {all| soft-preemption}

Syntax Description

all	Clears counters for all MPLS-TE tunnels.
soft-preemption	Clears the statistics for soft preemption counters.

Command Default

None

Command Modes

EXEC

Command History

Release	Modification
Release 4.2.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

When all counters are cleared using the **clear mpls traffic-eng counters all** command, the counters for soft-preemption statistics are automatically cleared.

Task ID

Task ID	Operations
mpls-te	execute

Examples

This example shows how to clear all counters:

```
RP/0/0/CPU0:router# clear mpls traffic-eng counters signaling all
```

Related Commands

Command	Description
show mpls traffic-eng counters signaling , on page 345	Displays tunnel signaling statistics.

clear mpls traffic-eng fast-reroute log

To clear the log of MPLS fast reroute (FRR) events, use the **clear mpls traffic-eng fast-reroute log** command in EXEC mode.

clear mpls traffic-eng fast-reroute log

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes EXEC

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows sample output before clearing the log of FRR events:

```
RP/0/0/CPU0:router# show mpls traffic-eng fast-reroute log
```

Node	Protected Interface	LSPs	Rewrites	When	Switching Time (usec)
0/0/CPU0	PO0/1/0/1	1	1	Feb 27 19:12:29.064000	147
0/1/CPU0	PO0/1/0/1	1	1	Feb 27 19:12:29.060093	165
0/2/CPU0	PO0/1/0/1	1	1	Feb 27 19:12:29.063814	129
0/3/CPU0	PO0/1/0/1	1	1	Feb 27 19:12:29.062861	128

```
RP/0/0/CPU0:router# clear mpls traffic-eng fast-reroute log
```


clear mpls traffic-eng link-management statistics

To clear all the MPLS-TE admission control statistics, use the **clear mpls traffic-eng link-management statistics** command in EXEC mode.

clear mpls traffic-eng link-management statistics

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes EXEC

Command History	Release	Modification
	Release 3.2	This command was supported.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples The following example shows how to clear all the MPLS-TE statistics for admission control:

```
RP/0/0/CPU0:router# clear mpls traffic-eng link-management statistics
```

clear mpls traffic-eng pce

To clear the path computation element (PCE) statistics, use the **clear mpls traffic-eng pce** command in EXEC mode.

clear mpls traffic-eng pce [**peer ipv4 address**]

Syntax Description

peer	(Optional) Clears the statistics for one peer.
ipv4 address	(Optional) Configures the IPv4 address for PCE.

Command Default

Clears statistics for all the PCE peers.

Command Modes

EXEC

Command History

Release	Modification
Release 3.8.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	execute

Examples

The following example shows how to clear the statistics for the PCE:

```
RP/0/0/CPU0:router# clear mpls traffic-eng pce
```

Related Commands

Command	Description
show mpls traffic-eng pce peer , on page 386	Displays the status of the PCE peer address and state.

collect-bw-only (MPLS-TE)

To configure only the bandwidth collection without adjusting the bandwidth automatically, use the **collect-bw-only** command in MPLS-TE automatic bandwidth interface configuration mode. To disable this feature, use the **no** form of this command.

collect-bw-only

no collect-bw-only

Syntax Description This command has no arguments or keywords.

Command Default Bandwidth collection is either enabled or disabled.

Command Modes MPLS-TE automatic bandwidth interface configuration

Command History	Release	Modification
	Release 3.8.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

If you enable the **collect-bw-only** command while the automatic bandwidth is already running on a tunnel, the bandwidth application is disabled from that moment. Before you enable the actual bandwidth application, you can get the status of the automatic bandwidth behavior.

If you disable the **collect-bw-only** command on a tunnel from which the automatic bandwidth is already running, the actual bandwidth application takes place on the tunnel at the next application period.

It is also possible to manually activate a bandwidth application regardless of the collect bandwidth only flag that is being specified on a tunnel. To activate the bandwidth application, use the [mpls traffic-eng auto-bw apply \(MPLS-TE\)](#), on page 266 command in EXEC mode.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples

The following example shows how to enable only the bandwidth collection without adjusting the automatic bandwidth:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-te 1
RP/0/0/CPU0:router(config-if)# auto-bw
RP/0/0/CPU0:router(config-if-tunte-autobw)# collect-bw-only
```

Related Commands

Command	Description
adjustment-threshold (MPLS-TE), on page 150	Configures the tunnel-bandwidth change threshold to trigger an adjustment.
application (MPLS-TE), on page 160	Configures the application frequency, in minutes, for the applicable tunnel.
auto-bw (MPLS-TE), on page 166	Configures automatic bandwidth on a tunnel interface and enters MPLS-TE automatic bandwidth interface configuration mode.
bw-limit (MPLS-TE), on page 181	Configures the minimum and maximum automatic bandwidth to set on a tunnel.
interface tunnel-te, on page 242	Configures an MPLS-TE tunnel interface.
overflow threshold (MPLS-TE), on page 286	Configures tunnel overflow detection.
show mpls traffic-eng tunnels, on page 401	Displays information about MPLS-TE tunnels.

destination (MPLS-TE)

To configure the destination address of a TE tunnel, use the **destination** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

destination *ip-address*

no destination *ip-address*

Syntax Description	<i>ip-address</i>	Destination address of the MPLS-TE router ID.

Command Default	No default behavior or values

Command Modes	Interface configuration

Command History	Release	Modification
	Release 3.2	This command was supported.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

**Note**

The tunnel destination address must be a unique MPLS-TE router ID; it cannot be an MPLS-TE link address on a node.

For Point-to-Point (P2P) tunnels, the **destination** command is used as a single-line command.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples	The following example shows how to set the destination address for tunnel-te1 to 10.10.10.10:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-te1
RP/0/0/CPU0:router(config-if)# destination 10.10.10.10
```

Related Commands

Command	Description
interface tunnel-te, on page 242	Configures an MPLS-TE tunnel interface.
show mpls traffic-eng tunnels, on page 401	Displays information about MPLS-TE tunnels.

direction (GMPLS)

To configure a bidirectional optical tunnel for GMPLS, use the **direction** command in interface tunnel-gte configuration mode. To return to the default behavior, use the **no** form of this command.

direction bidirectional

no direction bidirectional

Syntax Description

bidirectional	Enables bidirectional tunneling.

Command Default

Default is unidirectional.

Command Modes

Interface tunnel-gte configuration

Command History

Release	Modification
Release 3.3.0	This command was introduced.
Release 3.8.0	GMPLS interfaces were supported under the tunnel-gte interface type.
Release 3.9.0	This command was removed.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note

The LMP and GMPLS-NNI features are not supported on x86 RPs.

There are two types of MPLS-TE tunnels:

- Generic packet MPLS-TE tunnels
- Optical MPLS-TE tunnel (GMPLS tunnel)

At the configuration level, you cannot tell the difference between a packet MPLS or a GMPLS-TE tunnel. The packet TE tunnels are unidirectional, whereas GMPLS tunnels are bidirectional; therefore, you can identify the optical GMPLS tunnel by identifying the bidirectional configuration.

The GMPLS-TE tunnel requires that you specify the endpoint and transit switching capability so that the path computation module can determine the links that the tunnel can traverse.

The transit switching capability describes the switching capability of the LSP region that the tunnel crosses. The endpoint switching capability describes the switching capability and encoding required for the tunnel interface associated with the two ends of the bidirectional tunnel (namely, active, and passive side).

Finally, for GMPLS functionality to work, you must configure the **direction** and **switching** commands.

**Note**

Bidirectional tunnel support is available on optical (GMPLS) tunnels only.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to change the tunnel direction from the default (unidirectional) to bidirectional:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-gte 99
RP/0/0/CPU0:router(config-if)# direction bidirectional
```

Related Commands

Command	Description
flooding-igp (GMPLS), on page 224	Floods selected GMPLS Traffic Engineering links.
interface tunnel-gte, on page 240	Configures an MPLS-TE tunnel interface for GMPLS interfaces.
lmp hello (GMPLS), on page 255	Configures LMP IPCC management hello settings.
match (GMPLS), on page 261	Configures or matches active and passive tunnels.
passive (GMPLS), on page 288	Configures passive GMPLS tunnels.
remote (GMPLS), on page 323	Configures remote TE links.
switching (GMPLS), on page 439	Configures TE-link switching attributes.

disable (explicit-path)

To prevent the path from being used by MPLS-TE tunnels while it is configured, use the **disable** command in explicit path configuration mode. To return to the default behavior, use the **no** form of this command.

disable

no disable

Syntax Description This command has no arguments or keywords.

Command Default Explicit path is enabled.

Command Modes Explicit path configuration

Command History	Release	Modification
	Release 3.2	This command was supported.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples The following example shows how to disable explicit path 200:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# explicit-path identifier 200
RP/0/0/CPU0:router(config-expl-path)# disable
```

Related Commands	Command	Description
	index exclude-address, on page 230	Specifies the next IP address to exclude from the explicit path.
	index next-address, on page 234	Specifies path entries at a specific index.

 disable (explicit-path)

Command	Description
show explicit-paths , on page 332	Displays the configured IP explicit paths.

ds-te bc-model

To enable a specific bandwidth constraint model (Maximum Allocation Model or Russian Doll Model) on the entire label switched router (LSR), use the **ds-te bc-model** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

ds-te bc-model mam

no ds-te bc-model mam

Syntax Description

mam	Enables the Maximum Allocation Model (MAM) bandwidth constraints model.

Command Default

RDM is the default bandwidth constraint model.

Command Modes

MPLS-TE configuration

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

You can configure both the MAM and RDM bandwidth values on a single interface before swapping to an alternate global MPLS-TE BC model.

If you configure bandwidth constraints without configuring the corresponding bandwidth constraint values, the router uses default bandwidth constraint values.

MAM is not supported in prestandard DS-TE mode. MAM and RDM are supported in IETF DS-TE mode; RDM is supported in prestandard DS-TE mode.



Note

Changing the bandwidth constraints model affects the entire router and may have a major impact on system performance as nonzero-bandwidth tunnels are torn down.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to enable the MAM bandwidth constraints model:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# ds-te bc-model mam
```

Related Commands

Command	Description
ds-te mode, on page 209	Configures standard DS-TE mode.
ds-te te-classes, on page 211	Enters DS-TE te-class map configuration mode.
mpls traffic-eng, on page 265	Enters MPLS-TE configuration mode.
show mpls traffic-eng ds-te te-class, on page 350	Displays the Diff-Serv TE-class map in use.

ds-te mode

To configure standard differentiated-service TE mode (DS-TE), use the **ds-te mode** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

ds-te mode ietf

no ds-te mode ietf

Syntax Description

ietf	Enables IETF standard mode.

Command Default

Prestandard DS-TE is the default differentiated service mode.

Command Modes

MPLS-TE configuration

Command History

Release	Modification
Release 3.3.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The following two DS-TE modes are supported:

- Prestandard mode
 - The Cisco proprietary mechanism for IGPs and RSVP signalling are used and DS-TE does not interoperate with third-party vendor equipment.
- IETF mode
 - Standard defined extensions are used for IGPs and RSVP signalling and DS-TE in this mode interoperates with third-party equipment.
 - IETF mode supports two bandwidth constraint models: the Russian Doll Model (RDM) and Maximum Allocation Model (MAM).
 - RDM is the default model.
 - Router advertises variable-length bandwidth constraints, max-reservable- bandwidth, and unreserved bandwidths in TE-classes.
 - tunnels must have valid class-type and priority configured as per TE-class map in use; otherwise, tunnels remain down.

- TE-class map (a set of tunnel priority and class-type values) is enabled to interpret unreserved bandwidth values advertised in IGP; therefore, TE-class map must be identical on all nodes for TE tunnels to be successfully established

For DS-TE to function properly, DS-TE modes must be configured identically on all MPLS-TE nodes. If you need to change the DS-TE mode, you must bring down all tunnel interfaces and after the change, you should flood the updated bandwidth values through the network.

**Note**

Changing the DS-TE mode affects the entire LSR and can have a major impact on system performance when tunnels are torn down.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to enable IETF standard mode:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# ds-te mode ietf
```

Related Commands

Command	Description
ds-te bc-model, on page 207	Enables a specific bandwidth constraint model (Maximum Allocation Model or Russian Doll Model) on the LSR.
ds-te te-classes, on page 211	Configures MPLS DS-TE TE-class maps.
mpls traffic-eng, on page 265	Enters MPLS-TE configuration mode.
mpls traffic-eng fast-reroute promote, on page 268	Configures the router to assign new or more efficient backup MPLS-TE tunnels to protected MPLS-TE tunnels.
show mpls traffic-eng ds-te te-class, on page 350	Displays the Diff-Serv TE-class map in use.

ds-te te-classes

To enter DS-TE te-class map configuration mode, use the **ds-te te-classes** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

ds-te te-classes te-class *te_class_index* {**class-type** *class_type_number* {**priority** *pri_number*}| **unused**}

no ds-te te-classes te-class *te_class_index* {**class-type** *class_type_number* {**priority** *pri_number*}| **unused**}

Syntax Description

te-class	Configures the te-class map.
<i>te_class_index</i>	TE class-map index. Range is 0 to 7.
class-type	Configures the class type.
<i>class_type_number</i>	Class type value in the te-class map. Range is 0 to 1.
priority	Configures the TE tunnel priority.
<i>pri_number</i>	TE tunnel priority value. Range is 0 to 7.
unused	Marks the TE-class as unused.

Command Default

The following default te-class maps are used in IETF DS-TE mode:

te-class index	class-type	priority
0	0	7
1	1	7
2	UNUSED	—
3	UNUSED	—
4	0	0
5	1	0
6	UNUSED	—
7	UNUSED	—

**Note**

The default mapping has 4 TE-classes used with 2 class-types and, 4 TE-classes are unused. TE-class map is not used in prestandard DS-TE mode.

Command Modes

MPLS-TE configuration

Command History

Release	Modification
Release 3.3.0	This command was introduced.
Release 3.8.0	The unused keyword was added.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

In IETF DS-TE mode, modified semantic of the unreserved bandwidth TLV is used. Each of the eight available bandwidth values advertised in the IGP corresponds to a TE class. Because IGP advertises only eight bandwidth values, only eight TE-Classes can be supported in a IETF DS-TE network. The TE-Class mapping must be configured the same way on every router in a DS-TE domain. There is, however, no method to automatically detect or enforce this required consistency.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to configure a TE-class 7 parameter:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# ds-te te-classes te-class 7 class-type 0 priority 4
```

Related Commands

Command	Description
ds-te bc-model, on page 207	Enables a specific bandwidth constraint model (Maximum Allocation Model or Russian Doll Model) on the LSR.
ds-te mode, on page 209	Configures standard DS-TE mode.
mpls traffic-eng, on page 265	Enters MPLS-TE configuration mode.

Command	Description
show mpls traffic-eng ds-te te-class, on page 350	Displays the Diff-Serv TE-class map in use.

exclude srlg (auto-tunnel backup)

To specify that automatic backup tunnels should avoid Shared Risk Link Groups (SRLGs) of protected interface, use the **exclude srlg** command in auto-tunnel backup configuration mode. To disable this feature, use the **no** form of this command.

exclude srlg [preferred]

no exclude srlg [preferred]

Syntax Description

preferred	(Optional) Causes the backup tunnel to avoid SRLGs of its protected interface(s); however, the backup tunnel is created if SRLGs are not avoided.

Command Default

Strict SRLG

Command Modes

Auto-tunnel backup configuration

Command History

Release	Modification
Release 4.0.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Strict SRLG configuration of this command means that the path computed for the backup tunnel that is automatically created, must not contain any links that are part of the excluded SRLG groups. If such a path cannot be found, the backup tunnel does not come up.

Configuration of the preferred option allows the automatic backup tunnel to come up even if a path that excludes SRLGs can not be found.

Task ID

Task ID	Operation
mpls-te	read, write

Examples

In the following example, automatic backup tunnels must avoid SRLGs of the protected interface.

```
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# interface pos 0/1/0/1
```

```
RP/0/0/CPU0:router(config-mpls-te-if)# auto-tunnel backup  
RP/0/0/CPU0:router(config-mpls-te-if-auto-backup)# exclude srlg preferred
```

Related Commands

Command	Description
auto-tunnel backup (MPLS-TE), on page 174	Builds automatic next-hop and next-next-hop tunnels, and enters auto-tunnel configuration mode.

explicit-path

To configure an explicit path for an MPLS-TE tunnel, use the **explicit-path** command in global configuration mode. To return to the default behavior, use the **no** form of this command.

explicit-path {*identifier number* | *name pathname*}

no explicit-path

Syntax Description

identifier <i>number</i>	Configures an explicit path using a number.
name <i>pathname</i>	Configures an explicit path using a pathname.

Command Default

No default behavior or values

Command Modes

Global configuration

Command History

Release	Modification
Release 3.3.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to configure an explicit path for an MPLS-TE tunnel:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# explicit-path identifier 200
```

Related Commands

Command	Description
disable (explicit-path) , on page 205	Prevents a path from being used by MPLS-TE tunnels.

Command	Description
show explicit-paths, on page 332	Displays the configured IP explicit paths.

fast-reroute

To enable fast-reroute (FRR) protection for an MPLS-TE tunnel, use the **fast-reroute** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

fast-reroute

no fast-reroute

Syntax Description This command has no arguments or keywords.

Command Default FRR is disabled.

Command Modes Interface configuration

Command History	Release	Modification
	Release 3.2	This command was supported.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

When a protected link used by the fast-reroutable label switched path (LSP) fails, the traffic is rerouted to a previously assigned backup tunnel. Configuring FRR on the tunnel informs all the nodes that the LSP is traversing that this LSP desires link/node/bandwidth protection.

You must allow sufficient time after an RP switchover before triggering FRR on standby RPs to synchronize with the active RP (verified using the **show redundancy** command). All TE tunnels must be in the recovered state and the database must be in the ready state for all ingress and egress line cards. To verify this information, use the **show mpls traffic-eng tunnels** and **show mpls traffic-eng fast-reroute database** commands.



Note Wait approximately 60 seconds before triggering FRR after verifying the database state.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples

The following example shows how to enable FRR on an MPLS-TE tunnel:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-te 1
RP/0/0/CPU0:router(config-if)# fast-reroute
```

Related Commands

Command	Description
fast-reroute protect , on page 220	Configures node and bandwidth protection for an MPLS-TE tunnel.
interface tunnel-te , on page 242	Configures an MPLS-TE tunnel interface.
show mpls traffic-eng forwarding , on page 352	Displays the contents of the FRR database.
show mpls traffic-eng tunnels , on page 401	Displays information about MPLS-TE tunnels.

fast-reroute protect

To enable node and bandwidth protection for an MPLS-TE tunnel, use the **fast-reroute protect** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

fast-reroute protect {bandwidth | node}

no fast-reroute protect

Syntax Description

bandwidth	Enables bandwidth protection request.
node	Enables node protection request.

Command Default

FRR is disabled.

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.6.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to enable bandwidth protection for a specified TE tunnel:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-te 1
RP/0/0/CPU0:router(config-if)# fast-reroute protect bandwidth
```


Related Commands

Command	Description
fast-reroute , on page 218	Enables FRR protection for an MPLS-TE tunnel.
interface tunnel-te , on page 242	Configures an MPLS-TE tunnel interface.
show mpls traffic-eng tunnels , on page 401	Displays information about MPLS-TE tunnels.

fast-reroute timers promotion

To configure how often the router considers switching a protected MPLS-TE tunnel to a new backup tunnel if additional backup-bandwidth or a better backup tunnel becomes available, use the **fast-reroute timers promotion** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

fast-reroute timers promotion *interval*

no fast-reroute timers promotion

Syntax Description

<i>interval</i>	Interval, in seconds, between scans to determine if a label switched path (LSP) should use a new, better backup tunnel. Range is 0 to 604800. A value of 0 disables backup tunnel promotions.

Command Default

interval: 300

Command Modes

MPLS-TE configuration

Command History

Release	Modification
Release 3.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Setting the interval to a low value puts more load on the CPU because it has to scan all protected LSPs more frequently. It is not recommended that the timer be configured below the default value of 300 seconds.

Pacing mechanisms have been implemented to distribute the load on the CPU when backup promotion is active. Because of this, when a large number of protected LSPs are promoted, some delay is noticeable in backup promotion. If the promotion timer is configured to a very low value (depending on the number of protected LSPs) some protected LSPs may never get promoted.

To disable the timer, set the value to zero.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to specify that LSPs are scanned every 600 seconds (10 minutes) to determine if they should be promoted to a better backup tunnel:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# fast-reroute timers promotion 600
```

Related Commands

Command	Description
mpls traffic-eng, on page 265	Enters MPLS-TE configuration mode.
mpls traffic-eng fast-reroute promote, on page 268	Configures the router to use a new or more efficient backup MPLS-TE tunnel when a current tunnel is overloaded.

flooding-igp (GMPLS)

To flood the GMPLS Traffic Engineering link into a specific OSPF area and instance, use the **flooding-igp** command in MPLS-TE interface configuration mode. To return to the default behavior, use the **no** form of this command.

flooding-igp ospf *instance area area*

no flooding-igp ospf *instance area area*

Syntax Description

ospf	Floods the interface into an OSPF instance
<i>instance</i>	Name of the OSPF instance into which the GMPLS link is to be flooded.
area <i>area</i>	Displays the area into which the GMPLS link is to be flooded (where TE is configured).

Command Default

No default behavior or values

Command Modes

MPLS-TE interface configuration

Command History

Release	Modification
Release 3.3.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note

The LMP and GMPLS-NNI features are not supported on x86 RPs.

A GMPLS link won't be flooded into any IGP topology unless this command is used.



Note

The **flooding-igp** command is valid for GMPLS-TE only.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to flood the optical GMPLS link on POS 0/1/0/0 into area 0 of OSPF instance “optical”:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# interface pos0/1/0/0
RP/0/0/CPU0:router(config-mpls-te-if)# flooding-igp ospf optical area 0
```

Related Commands

Command	Description
destination (MPLS-TE), on page 201	Configures bidirectional optical tunnels.
interface (MPLS-TE), on page 236	Enables MPLS-TE on an interface and enters MPLS-TE interface configuration mode.
lmp hello (GMPLS), on page 255	Configures LMP IPCC management hello settings.
match (GMPLS), on page 261	Configures or matches active and passive tunnels.
mpls traffic-eng, on page 265	Enters MPLS-TE configuration mode.
passive (GMPLS), on page 288	Configures passive GMPLS tunnels.
remote (GMPLS), on page 323	Configures remote TE links.
switching (GMPLS), on page 439	Configures TE-link switching attributes.

flooding thresholds

To set the reserved bandwidth thresholds for a link, use the **flooding thresholds** command in MPLS-TE interface configuration mode. To return to the default behavior, use the **no** form of this command.

flooding thresholds {**down** | **up**} *percent* [*percent1* | *percent2* | *percent3* | ... *percent 15*]

no flooding thresholds {**down** | **up**}

Syntax Description

down	Configures the threshold for decreased resource availability.
up	Configures the threshold for increased resource availability.
<i>percent</i> [<i>percent</i>]	Bandwidth threshold level. Range is 0 to 100 for all 16 levels.

Command Default

down: 100, 99, 98, 97, 96, 95, 90, 85 , 80, 75 , 60, 45, 30, 15

up: 5, 30, 45, 60, 75, 80, 85, 90, 95, 97 , 98, 99, 100

Command Modes

MPLS-TE interface configuration

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

You can configure up to 16 flooding threshold values. The first value is mandatory; the next 15 are optional.

When a threshold is crossed, MPLS-TE link management advertises updated link information. If no thresholds are crossed, changes can be flooded periodically unless periodic flooding was disabled.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to set the reserved bandwidth threshold for the link for decreased resource availability (down) and for increased resource availability (up) thresholds:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# interface POS 0/7/0/0
RP/0/0/CPU0:router(config-mpls-te-if)# flooding thresholds down 100 75 25
RP/0/0/CPU0:router(config-mpls-te-if)# flooding thresholds up 25 50 100
```

Related Commands

Command	Description
interface (MPLS-TE), on page 236	Enables MPLS-TE on an interface and enters MPLS-TE interface configuration mode.
mpls traffic-eng, on page 265	Enters MPLS-TE configuration mode.
link-management timers periodic-flooding, on page 252	Sets the length of the interval used for periodic flooding.
show mpls traffic-eng link-management advertisements, on page 362	Displays local link information currently being flooded by MPLS-TE link management into the global TE topology.
show mpls traffic-eng link-management bandwidth-allocation, on page 365	Displays current local link information.

forwarding-adjacency

To configure an MPLS-TE forwarding adjacency, use the **forwarding-adjacency** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

forwarding-adjacency [**holdtime** *time*]

no forwarding-adjacency [**holdtime** *time*]

Syntax Description

holdtime <i>time</i>	(Optional) Configures the holdtime value, in milliseconds, that is associated with each forwarding-adjacency LSP. The default is 0.

Command Default

holdtime *time*: 0

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.4.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

If you do not specify a **holdtime** *time* value, a delay is introduced with the following results:

- When forwarding-adjacency is configured on a tunnel that is up, TE notifies IGP without any additional delay.
- When forwarding-adjacency is not configured on a tunnel, TE notifies IGP without any additional delay.
- When forwarding-adjacency is configured on a tunnel that is down, TE does not notify IGP.
- When a tunnel on which forwarding-adjacency has been configured comes up, TE holds the notification to IGP for the period of holdtime (assuming nonzero holdtime). When the holdtime elapses, TE notifies IGP if the tunnel is still up.

The paths that traffic is taking to the destination can be manipulated by adjusting the forwarding adjacency link metric. To do that, use the **bandwidth** command. The unit of possible bandwidth values is in kbps.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to configure forwarding adjacency with a holdtime value of 60 milliseconds:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-te 888
RP/0/0/CPU0:router(config-if)# forwarding-adjacency holdtime 60
```

Related Commands

Command	Description
bandwidth (RSVP) , on page 458	Configures RSVP bandwidth on an interface using prestandard DS-TE mode.
interface tunnel-te , on page 242	Configures an MPLS-TE tunnel interface.
show mpls traffic-eng forwarding-adjacency , on page 355	Displays forwarding-adjacency information.

index exclude-address

To exclude an address from a tunnel path entry at a specific index, use the **index exclude-address** command in explicit path configuration mode. To return to the default behavior, use the **no** form of this command.

index *index-id* **exclude-address** { **ipv4 unicast** *IP address* }

no **index** *index-id*

Syntax Description

<i>index-id</i>	Index number at which the path entry is inserted or modified. Range is 1 to 65535.
ipv4 unicast <i>IP address</i>	Excludes the IPv4 unicast address.

Command Default

No default behavior or values

Command Modes

Explicit path configuration

Command History

Release	Modification
Release 3.2	Support for the ipv4 unicast keyword was added.
Release 3.4.0	The index (explicit path) command was modified to create two separate commands: index exclude-address and index next-address .

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

You cannot include or exclude addresses from an IP explicit path unless explicitly configured using the **exclude-address** keyword.

Use the **exclude-address** keyword only after entering the explicit path configuration mode.

If you use the **exclude-address** keyword and specify the IP address of a link, the constraint-based routine does not consider that link when it sets up MPLS-TE paths. If the excluded address is a flooded MPLS-TE router ID, the constraint-based shortest path first (SPF) routine does not consider that entire node.



Note

The person who performs the configuration must know the IDs of the routers, as it may not be apparent if the value refers to the link or to the node.

MPLS-TE accepts IP explicit paths composed of all excluded addresses configured using the **exclude-address** keyword.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to exclude address 192.168.3.2 at index 3 of the explicit path 200:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# explicit-path identifier 200
RP/0/0/CPU0:router(config-expl-path)# index 3 exclude-address ipv4 unicast 192.168.3.2
```

Related Commands

Command	Description
index next-address, on page 234	Specifies path entries at a specific index.
show explicit-paths, on page 332	Displays the configured IP explicit paths.

index exclude-srlg

To exclude an address to get SRLGs from a tunnel path entry at a specific index, use the **index exclude-srlg** command in explicit path configuration mode. To return to the default behavior, use the **no** form of this command.

index *index-id* **exclude-srlg** **ipv4 unicast** *IP address*

no **index** *index-id*

Syntax Description

<i>index-id</i>	Index number at which the path entry is inserted or modified. Range is 1 to 65535.
exclude-srlg	Specifies an IP address to get SRLG values from for exclusion.
ipv4 unicast <i>IP address</i>	Excludes the IPv4 unicast address.

Command Default

No default behavior or values

Command Modes

Explicit path configuration

Command History

Release	Modification
Release 4.0.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operation
mpls-te	read, write

Examples

The following example shows how to exclude the SRLG values from the IP address 192.168.3.2 at index 1 of the explicit path 100:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# explicit-path identifier 100
RP/0/0/CPU0:router(config-expl-path)# index 1 exclude-srlg ipv4 unicast 192.168.3.2
```

index next-address

To include a path entry at a specific index, use the **index next-address** command in explicit path configuration mode. To return to the default behavior, use the **no** form of this command.

index *index-id* **next-address** [**loose** | **strict**] **ipv4 unicast** *IP-address*

no **index** *index-id*

Syntax Description

<i>index-id</i>	Index number at which the path entry is inserted or modified. Range is 1 to 65535.
ipv4 unicast <i>IP-address</i>	Includes the IPv4 unicast address (strict address).
loose ipv4 unicast <i>IP-address</i>	(Optional) Specifies the next unicast address in the path as a loose hop.
strict ipv4 unicast <i>IP-address</i>	(Optional) Specifies the next unicast address in the path as a strict hop.

Command Default

No default behavior or values

Command Modes

Explicit path configuration

Command History

Release	Modification
Release 3.2	Support for the ipv4 unicast keyword was added.
Release 3.4.0	The index (explicit path) command was added to create two separate commands: index exclude-address and index next-address . Support was added for loose and strict keywords for the index next-address command.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

You cannot include addresses from an IP explicit path unless explicitly configured using the **next-address** keyword.

Use the **next-address** keyword only after entering the explicit path configuration mode.

**Note**

The person who performs the configuration must know the IDs of the routers, as it may not be apparent if the value refers to the link or to the node.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to insert the **next-address** 192.168.3.2 at index 3 of the explicit path 200:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# explicit-path identifier 200
RP/0/0/CPU0:router(config-expl-path)# index 3 next-address ipv4 unicast 192.168.3.2
```

Related Commands

Command	Description
index exclude-address, on page 230	Specifies the next IP address to exclude from the explicit path.
show explicit-paths, on page 332	Displays the configured IP explicit paths.

interface (MPLS-TE)

To enable MPLS-TE on an interface and to enter MPLS-TE interface configuration mode, use the **interface** command in global configuration mode. To return to the default behavior, use the **no** form of this command.

interface *type interface-path-id*

no interface *type interface-path-id*

Syntax Description

<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.

Command Default

No default behavior or values

Command Modes

Global configuration

Command History

Release	Modification
Release 3.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

You must enter MPLS-TE interface mode to configure specific interface parameters on physical interfaces. Configuring MPLS-TE links or a tunnel TE interface begins the TE-control process on RP.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to enter the MPLS-TE interface configuration mode:

```
RP/0/0/CPU0:router# configure  
RP/0/0/CPU0:router(config)# mpls traffic-eng  
RP/0/0/CPU0:router(config-mpls-te)# interface POS 0/7/0/1
```

The following example shows how to remove an interface from the MPLS-TE domain:

```
RP/0/0/CPU0:router# configure  
RP/0/0/CPU0:router(config)# mpls traffic-eng  
RP/0/0/CPU0:router(config-mpls-te)# no interface POS 0/7/0/1
```

interface (SRLG)

To enable Shared Risk Link Groups (SRLGs) on an interface and to enter SRLG interface configuration mode, use the **interface** command in SRLG configuration mode. To return to the previous configuration mode, use the **no** form of this command.

interface *type interface-path-id*

no interface *type interface-path-id*

Syntax Description

<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface.
Note	Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.

Command Default

No default behavior or values

Command Modes

SRLG configuration

Command History

Release	Modification
Release 4.0.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operation
mpls-te	read, write

Examples

The following example shows how to enter SRLG interface configuration mode:

```
RP/0/0/CPU0:router(config)# srlg
RP/0/0/CPU0:router(config-srlg)# interface POS 0/1/0/1
```

```
RP/0/0/CPU0:router(config-srlg-if)# value 10  
RP/0/0/CPU0:router(config-srlg-if)#value 50
```

Related Commands

Command	Description
interface (MPLS-TE), on page 236	Enables MPLS-TE on an interface and enters MPLS-TE interface configuration mode.
mpls traffic-eng, on page 265	Enters MPLS-TE configuration mode.

interface tunnel-gte

To configure an MPLS-TE tunnel interface for GMPLS interfaces, use the **interface tunnel-gte** command in global configuration mode. To return to the default behavior, use the **no** form of this command.

interface tunnel-gte *tunnel-id*

no interface tunnel-gte *tunnel-id*

Syntax Description

<i>tunnel-id</i>	Tunnel number. Range is 0 to 65535.

Command Default

Tunnel interfaces are disabled.

Command Modes

Global configuration

Command History

Release	Modification
Release 3.8.0	This command was introduced .

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note

The LMP and GMPLS-NNI features are not supported on x86 RPs.

You cannot have two tunnels using the same encapsulation mode with exactly the same source and destination address. The workaround is to create a loopback interface and use the loopback interface address as the source address of the tunnel.

Configuring MPLS-TE links or a tunnel TE interface begins the TE-control process on RP.

The **interface tunnel-gte** command indicates that the tunnel interface is for an MPLS-TE tunnel and enables the various tunnel MPLS-TE GMPLS tunnel interface options.

Task ID

Task ID	Operations
interface	read, write

Examples

The following example shows how to configure tunnel-gte interface 1:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-gte 1
```

Related Commands

Command	Description
match (GMPLS), on page 261	Matches an active tunnel to a passive tunnel.
passive (GMPLS), on page 288	Configures passive GMPLS tunnels.
switching endpoint (GMPLS), on page 441	Specifies the switching capability and encoding types for all endpoint TE links used to signal the optical tunnel that is mandatory to set up the GMPLS LSP.
switching transit (GMPLS), on page 443	Specifies the switching capability and encoding types for all transit TE links used to signal the optical tunnel to configure an optical LSP.

interface tunnel-te

To configure an MPLS-TE tunnel interface, use the **interface tunnel-te** command in global configuration mode. To return to the default behavior, use the **no** form of this command.

interface tunnel-te *tunnel-id*

no interface tunnel-te *tunnel-id*

Syntax Description

<i>tunnel-id</i>	Tunnel number. Range is 0 to 65535.

Command Default

Tunnel interfaces are disabled.

Command Modes

Global configuration

Command History

Release	Modification
Release 3.2	This command was supported.
Release 3.7.0	Policy-based tunnel selection example was added.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

You cannot have two tunnels using the same encapsulation mode with exactly the same source and destination address. The workaround is to create a loopback interface and to use the loopback interface address as the source address of the tunnel.

Configuring MPLS-TE links or Tunnel-TE interface begins the TE-control process on RP.

The **interface tunnel-te** command indicates that the tunnel interface is for an MPLS-TE tunnel and enables the various tunnel MPLS configuration options.



Note

You must configure record-route on TE tunnels that are protected by multiple backup tunnels merging at a single node.

Task ID

Task ID	Operations
interface	read, write

Examples

The following example shows how to configure tunnel interface 1:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-te 1
RP/0/0/CPU0:router(config-if)# ipv4 unnumbered loopback0
```

The following example shows how to set the tunnel-class attribute to map the correct traffic class to the tunnel:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-te 1
RP/0/0/CPU0:router(config-if)# policy-class 1
```

Related Commands

Command	Description
affinity, on page 154	Configures affinity (the properties that the tunnel requires in its links) for an MPLS-TE tunnel.
autoroute metric, on page 172	Instructs the IGP to use the tunnel in its enhanced SPF calculation, if the tunnel is in an up state.
backup-bw, on page 176	Configures backup bandwidth for FRR.
fast-reroute, on page 218	Enables FRR protection for an MPLS-TE tunnel.
path-option (MPLS-TE), on page 290	Configures a path option for an MPLS tunnel.
path-selection metric (interface), on page 301	Configures a path selection metric—TE or IGP.
policy-class, on page 317	Configures PBTS to direct traffic into specific TE tunnels.
priority (MPLS-TE), on page 319	Configures setup and reservation priority for an MPLS-TE tunnel.
record-route, on page 321	Configures record-route on an MPLS-TE tunnel.

ipcc interface (MPLS-TE)

To configure an interface-bound IP based control channel to a specific LMP neighbor with the option to specify a custom destination address that is useful for GigabitEthernet interfaces, use the **ipcc interface** command in MPLS-TE neighbor configuration mode. To disable this feature, use the **no** form of this command.

ipcc interface *type interface-path-id* [**dest** **ipv4 address**]

no ipcc interface *type interface-path-id* [**dest** **ipv4 address**]

Syntax Description

<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface. Note Use the show interfaces command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
dest	(Optional) Configures the remote endpoint address.
ipv4 address	(Optional) Configures the IPv4 address.

Command Default

No default behavior or values

Command Modes

MPLS-TE neighbor configuration

Command History

Release	Modification
Release 3.8.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to configure the IPCC interface for Loopback0:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# lmp neighbor OXC1
RP/0/0/CPU0:router(config-mpls-te-nbr-OXC1)# ipcc interface Loopback0
```

Related Commands

Command	Description
ipcc routed (MPLS-TE), on page 246	Configures an IPCC that is routable.
lmp neighbor (MPLS-TE), on page 257	Configures or updates an LMP neighbor and its associated parameters and enters MPLS-TE neighbor configuration mode.
mpls traffic-eng, on page 265	Enters MPLS-TE configuration mode.
show mpls traffic-eng lmp, on page 379	Displays information about the LMP.

ipcc routed (MPLS-TE)

To configure a routed IP-based control channel for a specific LMP neighbor, use the **ipcc routed** command in MPLS-TE neighbor configuration mode. To return to the default behavior, use the **no** form of this command.

ipcc routed

no ipcc routed

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes MPLS-TE neighbor configuration

Command History	Release	Modification
	Release 3.8.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples The following example shows how to configure a routed IPCC for neighbor router1 in which the destination IP address is the node ID of the neighbor router1 on an interface determined dynamically by an IP routing protocol:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# lmp neighbor router1
RP/0/0/CPU0:router(config-mpls-te-nbr-router1)# ipcc routed
```

Related Commands	Command	Description
	ipcc interface (MPLS-TE), on page 244	Configures an IPCC.

Command	Description
lmp neighbor (MPLS-TE), on page 257	Configures or updates an LMP neighbor and its associated parameters and enters MPLS-TE neighbor configuration mode.
mpls traffic-eng, on page 265	Enters MPLS-TE configuration mode.
show mpls traffic-eng lmp, on page 379	Displays information about the LMP.

ipv4 unnumbered (MPLS)

To specify the MPLS-TE tunnel Internet Protocol Version 4 (IPv4) address, use the **ipv4 unnumbered** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

ipv4 unnumbered *type interface-path-id*

no ipv4 unnumbered *type interface-path-id*

Syntax Description

<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface. Note Use the show interfaces command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.

Command Default

No IP address is set.

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Tunnel-te is not signaled until an IP address is configured on the tunnel interface; therefore, the tunnel state stays down without IP address configuration.

Loopback is commonly used as the interface type.

Task ID

Task ID	Operations
network	read, write

Examples

The following example shows how to configure the MPLS-TE tunnel to use the IPv4 address used on loopback interface 0:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-te 1
RP/0/0/CPU0:router(config-if)# ipv4 unnumbered loopback0
```

link-management timers bandwidth-hold

To set the length of time that bandwidth is held for a Resource Reservation Protocol (RSVP) Path (setup) message to wait for the corresponding RSVP Resv message to return, use the **link-management timers bandwidth-hold** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

link-management timers bandwidth-hold *holdtime*

no link-management timers bandwidth-hold *holdtime*

Syntax Description

<i>holdtime</i>	Number of seconds that bandwidth can be held. Range is 1 to 300. Default is 15.

Command Default

holdtime: 15

Command Modes

MPLS-TE configuration

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **link-management timers bandwidth-hold** command determines the time allowed for an RSVP message to return from a neighbor RSVP node.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to set the bandwidth to be held for 10 seconds:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# link-management timers bandwidth-hold 10
```

Related Commands

Command	Description
link-management timers periodic-flooding, on page 252	Sets the length of the interval used for periodic flooding.
mpls traffic-eng, on page 265	Enters MPLS-TE configuration mode.
show mpls traffic-eng link-management bandwidth-allocation, on page 365	Displays current local link information and bandwidth hold time.

link-management timers periodic-flooding

To set the length of the interval for periodic flooding, use the **link-management timers periodic-flooding** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

link-management timers periodic-flooding *interval*

no link-management timers periodic-flooding

Syntax Description	<i>interval</i>	Length of the interval, in seconds, for periodic flooding. Range is 0 to 3600. A value of 0 turns off periodic flooding. The minimum value is 30.

Command Default	<i>interval</i> : 180

Command Modes	MPLS-TE configuration

Command History	Release	Modification
	Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **link-management timers periodic-flooding** command advertises the link state information changes that do not trigger immediate action, such as a change to the allocated bandwidth that does not cross a threshold.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples

The following example shows how to set the interval length for periodic flooding to 120 seconds:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# link-management timers periodic-flooding 120
```


Related Commands

Command	Description
flooding thresholds, on page 226	Sets the reserved bandwidth flooding thresholds for a link.
link-management timers bandwidth-hold, on page 250	Sets the length of time that bandwidth is held for a RSVP Path (setup) message to wait for the corresponding RSVP Resv message to return.
mpls traffic-eng, on page 265	Enters MPLS-TE configuration mode.
show mpls traffic-eng link-management summary, on page 377	Displays the current periodic flooding interval.

link-management timers preemption-delay

To set the length of the interval for delaying LSP preemption, use the **link-management timers preemption-delay** command in MPLS-TE configuration mode. To disable this behavior, use the **no** form of this command.

link-management timers preemption-delay bundle-capacity *sec*

Syntax Description	bundle-capacity <i>sec</i>	Specifies the bundle-capacity preemption timer value in seconds.

Command Default	None

Command Modes	MPLS-TE configuration

Command History	Release	Modification
	Release 4.2.0	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The value *0* as bundle-capacity value in the **link-management timers preemption-delay** command disables this timer. This means there is no delay before preemption sets in when the bundle capacity goes down.

Task ID	Task ID	Operation
	mpls-te	read, write

Examples	This example shows how to set the interval length for preemption-delay:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# link-management timers preemption-delay bundle-capacity
180
```

Imp hello (GMPLS)

To configure Link Management Protocol (LMP) IPCC management hello settings, use the **imp hello** command in global MPLS-TE neighbor imp configuration mode. To return to the default behavior, use the **no** form of this command.

imp hello *hello-send -interval hello-dead-interval*

no imp hello *hello-send-interval hello-dead-interval*

Syntax Description

<i>hello-send-interval</i>	Time, in milliseconds, between sending hello keep alive message. Range is 100 to 21845.
<i>hello-dead-interval</i>	Time, in milliseconds, to wait without receiving a hello from the neighbor before declaring the IPCC down again. Range is 100 to 21845.

Command Default

No default behavior or values

Command Modes

MPLS-TE neighbor imp configuration mode

Command History

Release	Modification
Release 3.3.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

You can disable hellos using the **imp static** command.



Note

The LMP and GMPLS-NNI features are not supported on x86 RPs.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to configure Link Management Protocol (LMP) IPCC management hello settings:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# lmp neighbor lmp
RP/0/0/CPU0:router(config-mpls-te-nbr-lmp)# lmp hello 400 1200
```

Related Commands

Command	Description
destination (MPLS-TE), on page 201	Configures bidirectional optical tunnels.
lmp neighbor (MPLS-TE), on page 257	Configures or updates an LMP neighbor and its associated parameters and enters MPLS-TE neighbor configuration mode.
match (GMPLS), on page 261	Configures or matches active and passive tunnels.
mpls traffic-eng, on page 265	Enters MPLS-TE configuration mode.
passive (GMPLS), on page 288	Configures passive GMPLS tunnels.
remote (GMPLS), on page 323	Configures remote TE links.
switching (GMPLS), on page 439	Configures TE-link switching attributes.

Imp neighbor (MPLS-TE)

To configure or update an LMP neighbor with its associated identifier and enter MPLS-TE neighbor configuration mode, use the **imp neighbor** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

imp neighbor *name*

no imp neighbor *name*

Syntax Description

<i>name</i>	Text string representing the name of the LMP neighbor.

Command Default

No default behavior or values

Command Modes

MPLS-TE configuration

Command History

Release	Modification
Release 3.8.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note

The LMP and GMPLS-NNI features are not supported on x86 RPs.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to enter MPLS-TE neighbor configuration mode for router1:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# imp neighbor router1
RP/0/0/CPU0:router(config-mpls-te-nbr-router1)#
```

Related Commands

Command	Description
imp hello (GMPLS), on page 255	Configures LMP management hello settings.
mpls traffic-eng, on page 265	Enters MPLS-TE configuration mode.
show mpls traffic-eng imp, on page 379	Displays information about the LMP.

Imp router-id (MPLS-TE)

To configure the router ID for the optical instance using the LMP protocol, use the **imp router-id** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

Imp router-id {*ipv4 address* | *type interface-path-id*}

no Imp router-id {*ipv4 address* | *type interface-path-id*}

Syntax Description

<i>ipv4 address</i>	Router ID expressed as an IPv4 address.
<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface. Note Use the show interfaces command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.

Command Default

No default behavior or values

Command Modes

MPLS-TE configuration

Command History

Release	Modification
Release 3.3.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note

The LMP and GMPLS-NNI features are not supported on x86 RPs.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how configure the LMP router ID for IPv4 address 172.24.20.164:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# lmp router-id router 127.0.0.1
```

Related Commands

Command	Description
clear mpls lmp , on page 183	Clears LMP management hello settings.
mpls traffic-eng , on page 265	Enters MPLS-TE configuration mode.

match (GMPLS)

To match an active tunnel to a passive tunnel, use the **match** command in interface tunnel-gte configuration mode. To return to the default behavior, use the **no** form of this command.

match identifier *tunnel-number*

no match identifier *tunnel-number*

Syntax Description

identifier	Configures the identifier of the active tunnel to match with this passive tunnel.
<i>tunnel-number</i>	Tunnel number. Range is 0 to 65535.

Command Default

No default behavior or values

Command Modes

Interface tunnel-gte configuration

Command History

Release	Modification
Release 3.3.0	This command was introduced.
Release 3.8.0	GMPLS interfaces were supported under the tunnel-gte interface type.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note

The LMP and GMPLS-NNI features are not supported on x86 RPs.

GMPLS interfaces are used under the tunnel-gte interface type.

You must enter the hostname for the head router then underscore **_t**, and the tunnel number for the head router. If tunnel-gte1 is configured on the head router with a hostname of gmpls1, CLI is **match identifier gmpls1_t1**.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to match the active tunnel ID to the passive tunnel:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-gte 1
RP/0/0/CPU0:router(config-if)# match identifier gmpls1_t1
```

Related Commands

Command	Description
destination (MPLS-TE), on page 201	Configures bidirectional optical tunnels.
interface tunnel-gte, on page 240	Configures an MPLS-TE tunnel interface for GMPLS interfaces.
lmp hello (GMPLS), on page 255	Configures LMP IPCC management hello settings.
passive (GMPLS), on page 288	Configures passive GMPLS tunnels.
remote (GMPLS), on page 323	Configures remote TE links.
switching (GMPLS), on page 439	Configures TE-link switching attributes.

maxabs (MPLS-TE)

To specify the maximum number of MPLS-TE tunnels that can be configured, use the **maxabs** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

maxabs tunnels *tunnel-limit* **destinations** *dest-limit*

no maxabs tunnels *tunnel-limit* **destinations** *dest-limit*

Syntax Description

tunnels	Configures all tunnels for MPLS-TE.
<i>tunnel-limit</i>	Maximum number of tunnel TE interfaces. Range is 1 to 65536.
destinations	Configures all destinations for MPLS-TE.
<i>dest-limit</i>	Maximum total number of destinations that can be configured. Range is 1 to 65536.

Command Default

tunnel-limit: 4096

dest-limit: 4096

Command Modes

MPLS-TE configuration

Command History

Release	Modification
Release 3.8.0	This command was introduced.
Release 3.9.0	This command was removed.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to set the tunnel-te configuration limit to 1000:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# maxabs tunnels 1000 destinations 1000
```

Related Commands

Command	Description
show mpls traffic-eng maximum tunnels, on page 383	Displays the configuration of the maximum tunnel-te interfaces allowed.

mpls traffic-eng

To enter MPLS-TE configuration mode, use the **mpls traffic-eng** command in global configuration mode.

mpls traffic-eng

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes Global configuration

Command History	Release	Modification
	Release 3.3.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples The following example shows how to enter MPLS-TE configuration mode:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)#
```

mpls traffic-eng auto-bw apply (MPLS-TE)

To apply the highest bandwidth collected on a tunnel without waiting for the current application period to end, use the **mpls traffic-eng auto-bw apply** command in EXEC mode.

mpls traffic-eng auto-bw apply {**all**| **tunnel-te** *tunnel-number*}

Syntax Description

all	Applies the highest bandwidth collected instantly on all the automatic bandwidth-enabled tunnels.
tunnel-te <i>tunnel-number</i>	Applies the highest bandwidth instantly to the specified tunnel. The range is from 0 to 65535.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.8.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **mpls traffic-eng auto-bw apply** command can forcefully expire the current application period on a specified tunnel and immediately apply the highest bandwidth recorded so far instead of waiting for the application period to end on its own.



Note

The predefined threshold check still applies to the configuration, and if the delta is not significant enough, the automatic bandwidth functionality overrides this command.

The bandwidth application is performed only if at least one output rate sample has been collected for the current application period.

To guarantee the application of a specific signaled bandwidth value when triggering a manual bandwidth application, follow these steps:

- 1 Configure the minimum and maximum automatic bandwidth to the bandwidth value that you want to apply by using the **bw-limit (MPLS-TE)**, [on page 181](#) command.
- 2 Trigger a manual bandwidth application by using the **mpls traffic-eng auto-bw apply** command.

- 3 Revert the minimum and maximum automatic bandwidth value back to their original value.

Task ID

Task ID	Operations
mpls-te	execute

Examples

The following example applies the highest bandwidth to a specified tunnel:

```
RP/0/0/CPU0:router# mpls traffic-eng auto-bw apply tunnel-te 1
```

Related Commands

Command	Description
auto-bw collect frequency (MPLS-TE), on page 168	Configures the automatic bandwidth collection frequency and controls the manner in which the bandwidth for a tunnel collects output rate information, but does not adjust the tunnel bandwidth.
show mpls traffic-eng tunnels auto-bw brief, on page 427	Displays the list of automatic-bandwidth-enabled tunnels, and indicates if the current signaled bandwidth of the tunnel is identical to the bandwidth that is applied by the automatic bandwidth.

mpls traffic-eng fast-reroute promote

To configure the router to assign new or more efficient backup MPLS-TE tunnels to protected MPLS-TE tunnels, use the **mpls traffic-eng fast-reroute promote** command in EXEC mode. To return to the default behavior, use the **no** form of this command.

mpls traffic-eng fast-reroute promote

no mpls traffic-eng fast-reroute promote

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes EXEC

Command History	Release	Modification
	Release 3.2	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples The following example shows how to initiate backup tunnel promote and assignment:

```
RP/0/0/CPU0:router# mpls traffic-eng fast-reroute promote
```

Related Commands	Command	Description
	fast-reroute , on page 218	Enables FRR protection for an MPLS-TE tunnel.

mpls traffic-eng level

To configure a router running Intermediate System-to-System (IS-IS) MPLS-TE at IS-IS Level 1 and Level 2, use the **mpls traffic-eng level** command in router configuration mode. To return to the default behavior, use the **no** form of this command.

mpls traffic-eng level *isis-level*

no mpls traffic-eng level *isis-level*

Syntax Description

<i>isis-level</i>	IS-IS level (1, 2, or both) where MPLS-TE is enabled.

Command Default

No default behavior or values

Command Modes

Router configuration

Command History

Release	Modification
Release 3.2	This command was introduced.
Release 3.4.0	Support was added to enable MPLS Traffic Engineering in both IS-IS Level 1 and Level 2.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **mpls traffic-eng level** command is supported for IS-IS and affects the operation of MPLS-TE only if MPLS-TE is enabled for that routing protocol instance.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure a router running IS-IS MPLS to flood TE for IS-IS level 1:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# router isis 1
RP/0/0/CPU0:router(config-isis)# address-family ipv4 unicast
RP/0/0/CPU0:router(config-isis-af)# mpls traffic-eng level 1
```

```
RP/0/0/CPU0:router(config-isis-af)# metric-style wide
```

Related Commands

Command	Description
mpls traffic-eng router-id (MPLS-TE router), on page 281	Specifies that the TE router identifier for the node is the IP address associated with a given interface.

mpls traffic-eng link-management flood

To enable immediate flooding of all the local MPLS-TE links, use the **mpls traffic-eng link-management flood** command in EXEC mode. To return to the default behavior, use the **no** form of this command.

mpls traffic-eng link-management flood

no mpls traffic-eng link-management flood

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes EXEC

Command History	Release	Modification
	Release 3.2	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note

If there is no change in the LSA since last flooding, IGP may dampen the advertisement.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples The following example shows how to initiate flooding of the local MPLS-TE links:

```
RP/0/0/CPU0:router# mpls traffic-eng link-management flood
```

Related Commands

Command	Description
show mpls traffic-eng link-management advertisements , on page 362	Displays MPLS-TE link-management advertisements.

mpls traffic-eng path-protection switchover gmpls

To trigger a manual switchover for path protection for a GMPLS optical LSP, use the **mpls traffic-eng path-protection switchover gmpls** command in EXEC mode. To disable this feature, use the **no** form of this command.

mpls traffic-eng path-protection switchover gmpls *tunnel name*

no mpls traffic-eng path-protection switchover gmpls *tunnel name*

Syntax Description

<i>tunnel name</i>	Name of the tunnel that is used for a switchover.

Command Default

No manual path protection is invoked on either the head or tail router.

Command Modes

EXEC

Command History

Release	Modification
Release 3.9.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **mpls traffic-eng path-protection switchover gmpls** command is used for the following functions:

- Runs on both tunnel head and tunnel tail at the same time.
- Configures both head and tail router of the GMPLS LSP to achieve the complete path switchover at both ends.



Note

The LMP and GMPLS-NNI features are not supported on x86 RPs.

Task ID

Task ID	Operations
mpls-te	execute

Examples

The following example triggers the switchover for path-protection for GMPLS:

```
RP/0/0/CPU0:router# mpls traffic-eng path-protection switchover gmpls
```

Related Commands

Command	Description
path-option (MPLS-TE), on page 290	Configures a path option for an MPLS-TE tunnel.

mpls traffic-eng pce activate-pcep

To force idle peers to be reestablished without waiting for a timer, use the **mpls traffic-eng pce activate-pcep** command in EXEC mode. To return to the default behavior, use the **no** form of this command.

mpls traffic-eng pce activate-pcep {*address* | **all**}

no mpls traffic-eng pce activate-pcep {*address* | **all**}

Syntax Description

<i>address</i>	Address of the idle peer.
all	Activates all the idle peers.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.5.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	read, write, execute

Examples

The following example shows how to trigger a path computation client (PCC) or PCE to activate an idle path computation element protocol (PCEP) session:

```
RP/0/0/CPU0:router# mpls traffic-eng pce activate-pcep all
```

Related Commands

Command	Description
mpls traffic-eng pce reoptimize, on page 277	Triggers reoptimization manually either for all tunnels or a specific PCE-based tunnel.

mpls traffic-eng pce reoptimize

To trigger reoptimization manually either for all or a specific PCE-based tunnel, use the **mpls traffic-eng pce reoptimize** command in EXEC mode. To disable this feature, use the **no** form of this command.

mpls traffic-eng pce reoptimize [*tunnel ID*] [force]

no mpls traffic-eng pce reoptimize [*tunnel ID*] [force]

Syntax Description

<i>tunnel ID</i>	(Optional) Tunnel ID to be reoptimized. Range is from 0 to 65535.
force	(Optional) Forces the router to start using the newly calculated route even if the used path has a better metric.

Command Default

Reoptimizes all the PCE tunnels.

Command Modes

EXEC

Command History

Release	Modification
Release 3.5.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

If you do not run the **mpls traffic-eng pce reoptimize** command, the system tries to reoptimize at an interval of 3600 seconds.

Task ID

Task ID	Operations
mpls-te	read, write, execute

Examples

The following example shows how to trigger reoptimization for all PCE-based tunnels:

```
RP/0/0/CPU0:router# mpls traffic-eng pce reoptimize
```

Related Commands

Command	Description
mpls traffic-eng pce activate-pcep, on page 275	Forces idle peers to be re-established without waiting for a timer.

mpls traffic-eng reoptimize (EXEC)

To trigger the reoptimization interval of all TE tunnels, use the **mpls traffic-eng reoptimize** command in EXEC mode.

mpls traffic-eng reoptimize [*tunnel-id*] [*tunnel-name*] [**p2p** { **all** | *tunnel-id* }]

Syntax Description

<i>tunnel-id</i>	(Optional) MPLS-TE tunnel identification expressed as a number. Range is from 0 to 65535.
<i>tunnel-name</i>	(Optional) TE tunnel identification expressed as a name.
p2p	(Optional) Forces an immediate reoptimization of all P2P TE tunnels.
all	(Optional) Forces an immediate reoptimization for all P2P tunnels.
<i>tunnel-id</i>	P2P TE tunnel identification to be reoptimized. Range is from 0 to 65535.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was supported.
Release 3.9.0	The following keywords and arguments were added to support the P2P feature: • all keyword • p2p keyword, all keyword, and <i>tunnel-id</i> argument

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	execute

Examples

The following example shows how to immediately reoptimize all TE tunnels:

```
RP/0/0/CPU0:router# mpls traffic-eng reoptimize
```

The following example shows how to immediately reoptimize TE tunnel-te90:

```
RP/0/0/CPU0:router# mpls traffic-eng reoptimize tunnel-te90
```

The following example shows how to immediately reoptimize all P2P TE tunnels:

```
RP/0/0/CPU0:router# mpls traffic-eng reoptimize p2p all
```

Related Commands

Command	Description
reoptimize (MPLS-TE), on page 325	Forces immediate re-optimization of all TE tunnels.

mpls traffic-eng router-id (MPLS-TE router)

To specify that the TE router identifier for the node is the IP address associated with a given interface, use the **mpls traffic-eng router-id** command in the appropriate mode. To return to the default behavior, use the **no** form of this command.

mpls traffic-eng router-id *type interface-path-id*

no mpls traffic-eng router-id *type interface-path-id*

Syntax Description

<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface. Note Use the show interfaces command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.

Command Default

No default behavior or values

Command Modes

OSPF configuration
IS-IS address family configuration

Command History

Release	Modification
Release 3.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

A routers identifier acts as a stable IP address for the TE configuration. This IP address is flooded to all nodes. You must set the destination on the destination node TE router identifier for all affected tunnels. This router ID is the address that the TE topology database at the tunnel head uses for its path calculation.



Note

When the **mpls traffic-eng router-id** command is not configured, global router ID is used by MPLS-TE if there is one configured.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following examples show how to specify the TE router identifier as the IP address associated with loopback interface:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# router ospf CORE_AS
RP/0/0/CPU0:router(config-ospf)# mpls traffic-eng router-id 7.7.7.7

RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# router isis 811
RP/0/0/CPU0:router(config-isis)# address-family ipv4 unicast
RP/0/0/CPU0:router(config-isis-af)# mpls traffic-eng router-id 8.8.8.8
```

Related Commands

Command	Description
mpls traffic-eng level, on page 269	Configures a router running OSPF MPLS so that it floods TE for the indicated IS-IS level.

mpls traffic-eng reoptimize mesh group

To reoptimize all tunnels of a mesh group, use the **mpls traffic-eng reoptimize mesh group** command in EXEC mode.

mpls traffic-eng reoptimize auto-tunnel mesh group *group_id*

Syntax Description

<i>group_id</i>	Defines auto-tunnel mesh group ID that is to be reoptimized. Range is 0 to 4294967295.

Command Default

None

Command Modes

MPLS Transport profile configuration

Command History

Release	Modification
Release 4.1.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	execute

Examples

This is sample out from the **mpls traffic-eng reoptimize mesh group** command:

```
RP/0/0/CPU0:router mpls traffic-eng reoptimize mesh group 10
```

nhop-only (auto-tunnel backup)

To configure only a next-hop automatic backup tunnel with only link protection, use the **nhop-only** command in MPLS-TE auto-tunnel backup interface configuration mode. To return to the default configuration setting for automatic backup tunnels, use the **no** form of this command.

nhop-only

no nhop-only

Syntax Description This command has no arguments or keywords.

Command Default Both NHOP and NNHOP protection are enabled.

Command Modes Auto-tunnel backup configuration

Command History	Release	Modification
	Release 4.0.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

If you configure the **nhop-only** command, you destroy any next-next-hop (NNHOP) tunnel created to provide node protection for tunnels running over the specified interface.

If you unconfigure the **nhop-only** command, you trigger a backup assignment on primary tunnels running over that link. The automatic backup tunnel feature attempts to create NNHOP backup tunnels to provide node protection for the specified tunnels.

Task ID	Task ID	Operation
	mpls-te	read, write

Examples In the following example, NNHOP automatic backup tunnels are destroyed and only NHOP tunnels with link protection is configured:

```
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# interface pos 0/1/0/1
RP/0/0/CPU0:router(config-mpls-te-if)# auto-tunnel backup
RP/0/0/CPU0:router(config-mpls-te-if-auto-backup)# nhop-only
```


Related Commands

Command	Description
auto-tunnel backup (MPLS-TE), on page 174	Builds automatic NHOP and NNHOP backup tunnels.

overflow threshold (MPLS-TE)

To configure the tunnel overflow detection, use the **overflow threshold** command in MPLS-TE automatic bandwidth interface configuration mode. To disable the overflow detection feature, use the **no** form of this command.

overflow threshold *percentage* [*min bandwidth*] **limit** *limit*

no overflow threshold

Syntax Description

<i>percentage</i>	Bandwidth change percent to trigger an overflow. The range is from 1 to 100.
min <i>bandwidth</i>	(Optional) Configures the bandwidth change value, in kbps, to trigger an overflow. The range is from 10 to 4294967295. The default is 10.
limit <i>limit</i>	Configures the number of consecutive collection intervals that exceeds the threshold. The bandwidth overflow triggers an early tunnel bandwidth update. The range is from 1 to 10. The default is none.

Command Default

The default value is disabled.

Command Modes

MPLS-TE automatic bandwidth interface configuration

Command History

Release	Modification
Release 3.8.0	This command was introduced.
Release 3.9.0	The Usage Guidelines was updated to describe overflow detection.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

If you modify the **limit** keyword, the consecutive overflows counter for the tunnel is also reset.

If you enable or modify the minimum value, the current consecutive overflows counter for the tunnel is also reset, which effectively restarts the overflow detection from scratch.

Several number of consecutive bandwidth samples are greater than the overflow threshold (bandwidth percentage) and the minimum bandwidth configured, then a bandwidth application is updated immediately instead of waiting for the end of the application period.

Overflow detection applies only to bandwidth increase. For example, an overflow can not be triggered even if bandwidth decreases by more than the configured overflow threshold.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to configure the tunnel overflow detection for tunnel-te 1:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-te 1
RP/0/0/CPU0:router(config-if)# auto-bw
RP/0/0/CPU0:router(config-if-tunte-autobw)# overflow threshold 50 limit 3
```

Related Commands

Command	Description
adjustment-threshold (MPLS-TE), on page 150	Configures the tunnel bandwidth change threshold to trigger an adjustment.
application (MPLS-TE), on page 160	Configures the application frequency in minutes for the applicable tunnel.
auto-bw (MPLS-TE), on page 166	Configures automatic bandwidth on a tunnel interface and enters MPLS-TE automatic bandwidth interface configuration mode.
bw-limit (MPLS-TE), on page 181	Configures the minimum and maximum automatic bandwidth to set on a tunnel.
collect-bw-only (MPLS-TE), on page 199	Enables only the bandwidth collection without adjusting the automatic bandwidth.
show mpls traffic-eng tunnels, on page 401	Displays information about MPLS-TE tunnels.

passive (GMPLS)

To configure a passive GMPLS tunnel, use the **passive** command in interface tunnel-gte configuration mode. To return to the default behavior, use the **no** form of this command.

passive

no passive

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes Interface tunnel-gte configuration

Command History	Release	Modification
	Release 3.3.0	This command was introduced.
	Release 3.8.0	GMPLS interfaces were supported under the tunnel-gte interface type.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

GMPLS interfaces are used under the tunnel-gte interface type.



Note

The LMP and GMPLS-NNI features are not supported on x86 RPs.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples The following example shows how to configure a passive GMPLS virtual interface tunnel:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-gte 99
RP/0/0/CPU0:router(config-if)# passive
```

Related Commands

Command	Description
destination (MPLS-TE), on page 201	Configures bidirectional optical tunnels.
interface tunnel-gte, on page 240	Configures an MPLS-TE tunnel interface for GMPLS interfaces.
lmp hello (GMPLS), on page 255	Configures LMP IPCC management hello settings.
match (GMPLS), on page 261	Configures or matches active and passive tunnels.
remote (GMPLS), on page 323	Configures remote TE links.
switching (GMPLS), on page 439	Configures TE-link switching attributes.

path-option (MPLS-TE)

To configure a path option for an MPLS-TE tunnel, use the **path-option** command in tunnel-te interface configuration mode. To return to the default behavior, use the **no** form of this command.

path-option *preference-priority* [**protecting** *number*] {**dynamic** [**pce** [**address** **ipv4** *address*]]| **explicit** {**name** *path-name*| **identifier** *path-number*}} [**attribute-set** *name*] [**isis** *instance-name* **level** *level*] [**lockdown**] [**ospf** *instance-name* **area** {*value* | *address*}] [**verbatim**]

no path-option *preference-priority* {**dynamic** [**pce** [**address** **ipv4** *address*]]| **explicit** {**name** *path-name*| **identifier** *path-number*}} [**isis** *instance-name* **level** *level*] [**lockdown**] [**ospf** *instance-name* **area** {*value* | *address*}] [**verbatim**]

Syntax Description

<i>preference-priority</i>	Path option number. Range is from 1 to 1000.
protecting <i>number</i>	Specifies a path setup option to protect a path. The range is from 1 to 1000.
dynamic	Specifies that label switched paths (LSP) are dynamically calculated.
pce	(Optional) Specifies that the LSP is computed by a Path Computation Element (PCE).
address	(Optional) Configures the address for the PCE.
ipv4 <i>address</i>	Configures the IPv4 address for the PCE.
explicit	Specifies that LSP paths are IP explicit paths.
name <i>path-name</i>	Specifies the path name of the IP explicit path.
identifier <i>path-number</i>	Specifies a path number of the IP explicit path.
isis <i>instance-name</i>	(Optional) Limits CSPF to a single IS-IS instance and area.
attribute-set <i>name</i>	(Optional) Specifies the attribute set for the LSP.
level <i>level</i>	Configures the level for IS-IS. The range is from 1 to 2.
lockdown	(Optional) Specifies that the LSP cannot be reoptimized.
ospf <i>instance-name</i>	(Optional) Limits CSPF to a single OSPF instance and area.
area	Configures the area for OSPF.
<i>value</i>	Decimal value for the OSPF area ID.
<i>address</i>	IP address for the OSPF area ID.
verbatim	(Optional) Bypasses the Topology/CSPF check for explicit paths.

Command Default No default behavior or values

Command Modes Tunnel-te interface configuration

Command History	Release	Modification
	Release 3.2	This command was supported.
	Release 3.3.2	The protecting keyword was added to support GMPLS protection and restoration.
	Release 3.4.1	Both the verbatim and lockdown keywords can be used together.
	Release 3.7.0	An IGP-area was specified with the path-option command. Both the isis and the ospf keywords were added.
	Release 3.8.0	The pce , address , and ipv4 keywords were added. The <i>address</i> argument was added.
	Release 4.2.0	The attribute-set keyword was added.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

You can configure several path options for a single tunnel. For example, there can be several explicit path options and a dynamic option for one tunnel. The path setup preference is for lower (not higher) numbers, so option 1 is preferred.

When the lower number path option fails, the next path option is used to set up a tunnel automatically (unless using the lockdown option).

The **protecting** keyword specifies that you can configure path-protection for the primary LSP. The **protecting** keyword is available only for tunnel-gte interfaces.

You specify the backup path for the **path-option** command in case of the primary path failure.

CSPF areas are configured on a per-path-option basis.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples

The following example shows how to configure the tunnel to use a named IPv4 explicit path as verbatim and lockdown options for the tunnel. This tunnel cannot reoptimize when the FRR event goes away, unless you manually reoptimize it:

```
RP/0/0/CPU0:router(config)# interface tunnel-te 1
RP/0/0/CPU0:router(config-if)# path-option 1 explicit name test verbatim lockdown
```

The following example shows how to enable path protection on a tunnel to configure an explicit path:

```
RP/0/0/CPU0:router(config)# interface tunnel-te 1
RP/0/0/CPU0:router(config-if)# path-option 1 explicit name po4
RP/0/0/CPU0:router(config-if)# path-option protecting 1 explicit name po6
```

The following example shows how to limit CSPF to a single OSPF instance and area:

```
RP/0/0/CPU0:router(config)# interface tunnel-te 1
RP/0/0/CPU0:router(config-if)# path-option 1 explicit name router1 ospf 3 area 7 verbatim
```

The following example shows how to limit CSPF to a single IS-IS instance and area:

```
RP/0/0/CPU0:router(config)# interface tunnel-te 1
RP/0/0/CPU0:router(config-if)# path-option 1 dynamic isis mtbf level 1 lockdown
```

Related Commands

Command	Description
mpls traffic-eng path-protection switchover gmpls, on page 273	Specifies a switchover for path protection.
show explicit-paths, on page 332	Displays the configured IP explicit paths.
show mpls traffic-eng tunnels, on page 401	Displays information about MPLS-TE tunnels.

path-selection ignore overload (MPLS-TE)

To ignore the Intermediate System-to-Intermediate System (IS-IS) overload bit setting for MPLS-TE, use the **path-selection ignore overload** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

path-selection ignore overload {head | mid | tail}

no path-selection ignore overload {head | mid | tail}

Syntax Description

head	The tunnel stays up if set-overload-bit is set by ISIS on the head router. Ignores overload node during CSPF for the head node.
mid	The tunnel stays up if set-overload-bit is set by ISIS on the mid router. Ignores overload node during CSPF for the mid node.
tail	The tunnel stays up if set-overload-bit is set by ISIS on the tail router. Ignores overload node during CSPF for the tail node.

Command Default

None

Command Modes

MPLS-TE configuration

Command History

Release	Modification
Release 3.4.0	This command was introduced.
Release 4.1.0	The head , mid , and tail keywords were added.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **path-selection ignore overload** command to ensure that label switched paths (LSPs) are not broken because of routers that have IS-IS overload bit as enabled.

When the IS-IS overload bit avoidance (OLA) feature is activated, all nodes with the overload bit set, which includes head nodes, mid nodes, and tail nodes, are ignored. This means that they are still available for use with label switched paths (LSPs). This feature allows you to include an overloaded node in constraint-based shortest path first (CSPF).

Task ID

Task ID	Operations
mpls-te	read, write

Examples

This example shows how to use the **path-selection ignore overload head** command:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# path-selection ignore overload
RP/0/0/CPU0:router(config-mpls-te)# path-selection ignore overload head
```

path-selection loose-expansion affinity (MPLS-TE)

To specify the affinity value to be used to expand a path to the next loose hop for a tunnel on an area border router, use the **path-selection loose-expansion affinity** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

path-selection loose-expansion affinity *affinity-value* **mask** *affinity-mask* [**class-type** *type*]

no path-selection loose-expansion affinity *affinity-value* **mask** *affinity-mask* [**class-type** *type*]

Syntax Description

<i>affinity-value</i>	Attribute values required for links carrying this tunnel. A 32-bit decimal number. Range is 0x0 to 0xFFFFFFFF, representing 32 attributes (bits), where the value of an attribute is 0 or 1.
mask <i>affinity-mask</i>	Checks the link attribute, a 32-bit decimal number. Range is 0x0 to 0xFFFFFFFF, representing 32 attributes (bits), where the value of an attribute mask is 0 or 1.
class-type <i>type</i>	(Optional) Requests the class-type of the tunnel bandwidth. Range is 0 to 1.

Command Default

affinity-value : 0X00000000
mask-value : 0xFFFFFFFF

Command Modes

MPLS-TE configuration

Command History

Release	Modification
Release 3.4.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note

The new affinity scheme (based on names) is not supported for loose-hop expansion. New configuration does not affect the already up tunnels.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to configure affinity 0x55 with mask 0xFFFFFFFF:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# path-selection loose-expansion affinity 55 mask FFFFFFFF
```

Related Commands

Command	Description
path-selection loose-expansion metric (MPLS-TE), on page 297	Configures a metric type to be used to expand a path to the next loose hop for a tunnel on an area border router.
path-selection metric (MPLS-TE), on page 299	Configures the MPLS-TE tunnel path-selection metric.

path-selection loose-expansion metric (MPLS-TE)

To configure a metric type to be used to expand a path to the next loose hop for a tunnel on an area border router, use the **path-selection loose-expansion metric** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

path-selection loose-expansion metric {igp| te} [**class-type** *type*]

no path-selection loose-expansion metric {igp| te} [**class-type** *type*]

Syntax Description

igp	Configures an Interior Gateway Protocol (IGP) metric.
te	Configures a TE metric. This is the default.
class-type <i>type</i>	(Optional) Requests the class type of the tunnel bandwidth. Range is 0 to 1.

Command Default

The default is TE metric.

Command Modes

MPLS-TE configuration

Command History

Release	Modification
Release 3.4.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note

New configurations do not affect tunnels that are already up.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to set the path-selection metric to use the IGP metric overwriting default:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# path-selection loose-expansion metric igp
```

Related Commands

Command	Description
path-selection loose-expansion affinity (MPLS-TE), on page 295	Specifies the affinity value to be used to expand a path to the next loose hop for a tunnel on an area border router.

path-selection metric (MPLS-TE)

To specify the MPLS-TE tunnel path-selection metric, use the **path-selection metric** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

path-selection metric {igp| te}

no path-selection metric {igp| te}

Syntax Description

igp	Configures an Interior Gateway Protocol (IGP) metric.
te	Configures a TE metric.

Command Default

The default is TE metric.

Command Modes

MPLS-TE configuration

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The metric type to be used for path calculation for a given tunnel is determined as follows:

- If the **path-selection metric** command was entered to specify a metric type for the tunnel, use that metric type.
- Otherwise, use the default (TE) metric.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to set the path-selection metric to use the IGP metric overwriting default:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
```

```
RP/0/0/CPU0:router(config-mpls-te)# path-selection metric igp
```

Related Commands

Command	Description
path-selection loose-expansion affinity (MPLS-TE), on page 295	Specifies the affinity value to be used to expand a path to the next loose hop for a tunnel on an area border router.

path-selection metric (interface)

To configure an MPLS-TE tunnel path-selection metric type, use the **path-selection metric** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

path-selection metric {igp | te}

no path-selection metric {igp | te}

Syntax Description

igp	Configures Interior Gateway Protocol (IGP) metrics.
te	Configures TE metrics. This is the default.

Command Default

The default is TE metrics.

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The metric type to be used for path calculation for a given tunnel is determined as follows:

- If the **path-selection metric** command was entered to either a metric type for the tunnel or only a metric type, use that metric type.
- Otherwise, use the default (TE) metric.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to set the path-selection metric to use the IGP metric overwriting default:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-te 1
```

path-selection metric (interface)

```
RP/0/0/CPU0:router(config-if)# path-selection metric igp
```

Related Commands

Command	Description
show mpls traffic-eng topology, on page 391	Displays the tunnel path used.

pce address (MPLS-TE)

To configure the IPv4 self address for Path Computation Element (PCE), use the **pce address** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

pce address *ipv4 address*

no pce address *ipv4 address*

Syntax Description

ipv4 address	Configures the IPv4 address for PCE.

Command Default

No default behavior or values

Command Modes

MPLS-TE configuration

Command History

Release	Modification
Release 3.5.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The IP address is used in the TCP communication with the other PCEs or PCCs. In addition, this address is advertised using IGP.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to configure the IPv4 self address for PCE:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# pce address ipv4 10.10.10.10
```

Related Commands

Command	Description
pce keepalive (MPLS-TE), on page 307	Configures a PCEP keepalive interval.
path-option (MPLS-TE), on page 290	Configures a path option for an MPLS-TE tunnel.
pce peer (MPLS-TE), on page 309	Configures an IPv4 self address for a PCE peer.
pce reoptimize (MPLS-TE), on page 311	Configures a periodic reoptimization timer.
pce request-timeout (MPLS-TE), on page 313	Configures a PCE request-timeout.
pce tolerance keepalive (MPLS-TE), on page 315	Configures a PCE tolerance keepalive (which is the minimum acceptable peer proposed keepalive).

pce deadtimer (MPLS-TE)

To configure a path computation element (PCE) deadtimer, use the **pce deadtimer** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

pce deadtimer *value*

no pce deadtimer *value*

Syntax Description

<i>value</i>	Keepalive dead interval, in seconds. The range is 0 to 255.

Command Default

value: 120

Command Modes

MPLS-TE configuration

Command History

Release	Modification
Release 3.8.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

When the dead interval is 0, the LSR does not time out a PCEP session to a remote peer.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to configure a PCE deadtimer:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# pce deadtimer 50
```

Related Commands

Command	Description
mpls traffic-eng , on page 265	Enters MPLS-TE configuration mode.

Command	Description
path-option (MPLS-TE), on page 290	Configures a path option for an MPLS-TE tunnel.
pce address (MPLS-TE), on page 303	Configures the IPv4 self address for a PCE.
pce keepalive (MPLS-TE), on page 307	Configures a PCEP keepalive interval.
pce peer (MPLS-TE), on page 309	Configures an IPv4 self address for a PCE peer.
pce reoptimize (MPLS-TE), on page 311	Configures a periodic reoptimization timer.
pce request-timeout (MPLS-TE), on page 313	Configures a PCE request-timeout.
pce tolerance keepalive (MPLS-TE), on page 315	Configures a PCE tolerance keepalive (which is the minimum acceptable peer proposed keepalive).

pce keepalive (MPLS-TE)

To configure a path computation element protocol (PCEP) keepalive interval, use the **pce keepalive** command in MPLS-TE configuration mode. To disable this command, use the **no** form of this command.

pce keepalive *interval*

no pce keepalive *interval*

Syntax Description

<i>interval</i>	Keepalive interval, in seconds. The range is 0 to 255.

Command Default

interval: 30

Command Modes

MPLS-TE configuration

Command History

Release	Modification
Release 3.8.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

When the keepalive interval is 0, the LSR does not send keepalive messages.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to configure PCEP keepalive interval for 10 seconds:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router#(config-mpls-te) pce keepalive 10
```

Related Commands

Command	Description
mpls traffic-eng , on page 265	Enters MPLS-TE configuration mode.

Command	Description
path-option (MPLS-TE) , on page 290	Configures a path option for an MPLS-TE tunnel.
pce address (MPLS-TE) , on page 303	Configures the IPv4 self address for a PCE.
pce deadtimer (MPLS-TE) , on page 305	Configures a PCE deadtimer.
pce peer (MPLS-TE) , on page 309	Configures an IPv4 self address for a PCE peer.
pce reoptimize (MPLS-TE) , on page 311	Configures a periodic reoptimization timer.
pce request-timeout (MPLS-TE) , on page 313	Configures a PCE request-timeout.
pce tolerance keepalive (MPLS-TE) , on page 315	Configures a PCE tolerance keepalive (which is the minimum acceptable peer proposed keepalive).

pce peer (MPLS-TE)

To configure an IPv4 self address for a path computation element (PCE) peer, use the **pce peer** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

pce peer *ipv4 address*

no pce peer *ipv4 address*

Syntax Description	ipv4 address	Configures the IPv4 address for PCE.

Command Default	TE metric

Command Modes	MPLS-TE configuration

Command History	Release	Modification
	Release 3.5.0	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples	The following example shows how to configure an IPv4 self address for a PCE peer:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# pce peer ipv4 11.11.11.11
```

Related Commands	Command	Description
	mpls traffic-eng , on page 265	Enters MPLS-TE configuration mode.

Command	Description
path-option (MPLS-TE) , on page 290	Configures a path option for an MPLS-TE tunnel.
pce address (MPLS-TE) , on page 303	Configures the IPv4 self address for a PCE.
pce deadtimer (MPLS-TE) , on page 305	Configures a PCE deadtimer.
pce keepalive (MPLS-TE) , on page 307	Configures a PCEP keepalive interval.
pce reoptimize (MPLS-TE) , on page 311	Configures a periodic reoptimization timer.
pce request-timeout (MPLS-TE) , on page 313	Configures a PCE request-timeout.
pce tolerance keepalive (MPLS-TE) , on page 315	Configures a PCE tolerance keepalive (which is the minimum acceptable peer proposed keepalive).

pce reoptimize (MPLS-TE)

To configure a periodic reoptimization timer, use the **pce reoptimize** command in MPLS-TE configuration mode. To disable this feature, use the **no** form of this command.

pce reoptimize *value*

no pce reoptimize *value*

Syntax Description

<i>value</i>	Periodic reoptimization timer value, in seconds. The range is 60 to 604800.

Command Default

value: 3600

Command Modes

MPLS-TE configuration

Command History

Release	Modification
Release 3.8.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

When the dead interval is 0, the LSR does not time out a path computation element protocol (PCEP) session to a remote peer.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to configure a periodic reoptimization timer for 200 seconds:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# pce reoptimize 200
```

Related Commands

Command	Description
mpls traffic-eng , on page 265	Enters MPLS-TE configuration mode.
path-option (MPLS-TE) , on page 290	Configures a path option for an MPLS-TE tunnel.
pce address (MPLS-TE) , on page 303	Configures the IPv4 self address for a PCE.
pce deadtimer (MPLS-TE) , on page 305	Configures a PCE deadtimer.
pce keepalive (MPLS-TE) , on page 307	Configures a PCEP keepalive interval.
pce peer (MPLS-TE) , on page 309	Configures an IPv4 self address for a PCE peer.
pce request-timeout (MPLS-TE) , on page 313	Configures a PCE request-timeout.
pce tolerance keepalive (MPLS-TE) , on page 315	Configures a PCE tolerance keepalive (which is the minimum acceptable peer proposed keepalive).

pce request-timeout (MPLS-TE)

To configure a path computation element (PCE) request-timeout, use the **pce request-timeout** command in MPLS-TE configuration mode. To disable this feature, use the **no** form of this command.

pce request-timeout *value*

no pce request-timeout *value*

Syntax Description

<i>value</i>	PCE request-timeout, in seconds. The range is 5 to 100.

Command Default

value: 10

Command Modes

MPLS-TE configuration

Command History

Release	Modification
Release 3.8.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

PCC or PCE keeps a pending path request only for the request-timeout period.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to configure a PCE request-timeout for 10 seconds:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# pce request-timeout 10
```

Related Commands

Command	Description
mpls traffic-eng , on page 265	Enters MPLS-TE configuration mode.

Command	Description
path-option (MPLS-TE) , on page 290	Configures a path option for an MPLS-TE tunnel.
pce address (MPLS-TE) , on page 303	Configures the IPv4 self address for a PCE.
pce deadtimer (MPLS-TE) , on page 305	Configures a PCE deadtimer.
pce keepalive (MPLS-TE) , on page 307	Configures a PCEP keepalive interval.
pce peer (MPLS-TE) , on page 309	Configures an IPv4 self address for a PCE peer
pce reoptimize (MPLS-TE) , on page 311	Configures a periodic reoptimization timer.
pce tolerance keepalive (MPLS-TE) , on page 315	Configures a PCE tolerance keepalive (which is the minimum acceptable peer proposed keepalive).

pce tolerance keepalive (MPLS-TE)

To configure a path computation element (PCE) tolerance keepalive (which is the minimum acceptable peer proposed keepalive), use the **pce tolerance keepalive** command in MPLS-TE configuration mode. To disable this feature, use the **no** form of this command.

pce tolerance keepalive *value*

no pce tolerance keepalive *value*

Syntax Description

<i>value</i>	PCE tolerance keepalive value, in seconds. The range is 0 to 255.

Command Default

value: 10

Command Modes

MPLS-TE configuration

Command History

Release	Modification
Release 3.8.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to configure a PCE tolerance keepalive for 10 seconds:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# pce tolerance keepalive 10
```

Related Commands

Command	Description
mpls traffic-eng , on page 265	Enters MPLS-TE configuration mode.

Command	Description
path-option (MPLS-TE) , on page 290	Configures a path option for an MPLS-TE tunnel.
pce address (MPLS-TE) , on page 303	Configures the IPv4 self-address for a PCE.
pce deadtimer (MPLS-TE) , on page 305	Configures a PCE deadtimer.
pce keepalive (MPLS-TE) , on page 307	Configures a PCEP keepalive interval.
pce peer (MPLS-TE) , on page 309	Configures an IPv4 self address for a PCE peer
pce reoptimize (MPLS-TE) , on page 311	Configures a periodic reoptimization timer.
pce request-timeout (MPLS-TE) , on page 313	Configures a PCE request-timeout.

policy-class

To configure policy-based tunnel selection (PBTS) to direct traffic into specific TE tunnels, use the **policy-class** command in interface configuration mode. To disable this feature, use the **no** form of this command.

policy-class {*1 - 7* | **default**}

no policy-class

Syntax Description

<i>1 - 7</i>	Policy-class attribute to map the correct traffic class to this policy.
default	Default tunnel policy class.

Command Default

The lowest class tunnels are assigned to carry default traffic only if no default tunnel is available for forwarding.

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.7.0	This command was supported.
Release 4.0.1	The new keyword default added to the command for defining the default tunnel on the router.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **policy-class** command to enable policy-based tunnel selection (PBTS). See *Cisco IOS XR MPLS Configuration Guide for the Cisco XR 12000 Series Router* for more information on PBTS.

To display the configured PBTS policy-class value, use the **show mpls traffic-eng tunnels** command.

To display information about PBTS configuration, use the **show cef** and **show cef hardware** commands in *Cisco IOS XR IP Addresses and Services Command Reference for the Cisco XR 12000 Series Router*.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to configure a policy class:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-te 1
RP/0/0/CPU0:router(config-if)# policy-class 7
```

The following example shows how to configure a default policy-class tunnel:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-te 1
RP/0/0/CPU0:router(config-if)# policy-class default
RP/0/0/CPU0:router(config-if)# commit
```

Related Commands

Command	Description
interface tunnel-te, on page 242	Configures an MPLS-TE tunnel interface.
show cef	Displays the IPv4 or IPv6 Cisco Express Forwarding table.
show cef hardware	Displays Cisco Express Forwarding IPv4 or IPv6 hardware status and configuration information.
show mpls traffic-eng tunnels, on page 401	Displays information about MPLS-TE tunnels.

priority (MPLS-TE)

To configure the setup and reservation priority for an MPLS-TE tunnel, use the **priority** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

priority *setup-priority hold-priority*

no priority *setup-priority hold-priority*

Syntax Description

<i>setup-priority</i>	Priority used when signaling a label switched path (LSP) for this tunnel to determine which existing tunnels can be preempted. Range is 0 to 7 (in which a lower number indicates a higher priority). Therefore, an LSP with a setup priority of 0 can preempt any LSP with a non-0 priority.
<i>hold-priority</i>	Priority associated with an LSP for this tunnel to determine if it should be preempted by other LSPs that are being signaled. Range is 0 to 7 (in which a lower number indicates a higher priority).

Command Default

setup-priority: 7

hold-priority: 7

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

When an LSP is signaled and an interface does not currently have enough bandwidth available for that LSP, the call admission software (if necessary) preempts lower-priority LSPs to admit the new LSP. Accordingly, the new LSP priority is the setup priority and the existing LSP priority is the hold priority. The two priorities make it possible to signal an LSP with a low setup priority (so that the LSP does not preempt other LSPs on setup) and a high hold priority (so that the LSP is not preempted after it is established). Setup priority and hold priority are typically configured to be equal, and setup priority cannot be numerically smaller than the hold priority.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to configure a tunnel with a setup and hold priority of 1:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-te 1
RP/0/0/CPU0:router(config-if)# priority 1 1
```

Related Commands

Command	Description
interface tunnel-te, on page 242	Configures an MPLS-TE tunnel interface.

record-route

To record the route used by a tunnel, use the **record-route** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

record-route

no record-route

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes Interface configuration

Command History	Release	Modification
	Release 3.2	This command was supported.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note

You must configure record-route on TE tunnels that are protected by multiple backup tunnels merging at a single node.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples The following example shows how to enable record-route on the TE tunnel:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-te 1
RP/0/0/CPU0:router(config-if)# record-route
```

Related Commands

Command	Description
show mpls traffic-eng tunnels, on page 401	Displays information about MPLS-TE tunnels.

remote (GMPLS)

To configure Link Management Protocol (LMP) Neighbor remote Traffic Engineering (TE) links, use the **remote** command in MPLS-TE interface LMP data link adjacency configuration mode. To return to the default behavior, use the **no** form of this command.

remote {**interface-id** **unnum** *identifier* | **switching capability** | {**fsc** | **lsc** | **psc1**} | **te-link-id** | {**ipv4** *address* | **unnum** *identifier*}}

no remote {**interface-id** **unnum** *identifier* | **switching capability** | {**fsc** | **lsc** | **psc1**} | **te-link-id** | {**ipv4** *address* | **unnum** *identifier*}}

Syntax Description

interface-id	Configures the LMP neighbor remote interface identifier.
unnum <i>identifier</i>	Configures the unnumbered interface identifier. Range is 1 to 4294967295.
switching-capability	Configures the remote LMP MPLS-TE interface switching capability.
fsc lsc psc1	Configures the capability types: Fiber-Switch Capable, Lambda-Switch Capable, and Packet-Switch Capable.
te-link-id	Configures the remote LMP MPLS-TE link ID address.
ipv4 <i>address</i>	Configures the IPv4 address.
unnum <i>identifier</i>	Configures the unnumbered interface and identifier.

Command Default

No default behavior or values

Command Modes

MPLS-TE interface LMP data link adjacency configuration

Command History

Release	Modification
Release 3.3.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

**Note**

The LMP and GMPLS-NNI features are not supported on x86 RPs.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to configure LMP Neighbor remote TE links for unnumber interface-id 1066:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# interface POS 0/1/0/0
RP/0/0/CPU0:router(config-mpls-te-if)# lmp data-link adjacency
RP/0/0/CPU0:router(config-mpls-te-if-adj)# remote interface-id unnum 1066
```

Related Commands

Command	Description
destination (MPLS-TE), on page 201	Configures bidirectional optical tunnels.
lmp hello (GMPLS), on page 255	Configures LMP IPCC management hello settings.
match (GMPLS), on page 261	Configures or matches active and passive tunnels.
passive (GMPLS), on page 288	Configures passive GMPLS tunnels.
switching (GMPLS), on page 439	Configures TE-link switching attributes.

reoptimize (MPLS-TE)

To force the reoptimization interval for all TE tunnels, use the **reoptimize** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

reoptimize *frequency*

no reoptimize *frequency*

Syntax Description

frequency

Timer frequency range, in seconds. Range is from 0 to 604800.

Note:

- A value of 0 disables periodic reoptimization.
- Any value in the range from 1 to 60 results in periodic reoptimization that occurs every 60 seconds.

Command Default

frequency: 3600

Command Modes

MPLS-TE configuration

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to force the reoptimization interval to 60 seconds:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# reoptimize 60
```

Related Commands

Command	Description
mpls traffic-eng reoptimize (EXEC), on page 279	Triggers the reoptimization interval of all TE tunnels.

reoptimize timers delay (MPLS-TE)

To delay removal or relabeling of the old label switched paths (LSPs) (reoptimized LSP from the forwarding plane) after tunnel reoptimization, use the **reoptimize timers delay** command in MPLS-TE configuration mode. To restore the default value, use the **no** form of this command.

reoptimize timers delay {**after-frr** *seconds*| **cleanup** *delay-time*| **installation** *delay-time*| **path-protection** *seconds*}

no reoptimize timers delay {**after-frr** *seconds*| **cleanup** *delay-time*| **installation** *delay-time*| **path-protection** *seconds*}

Syntax Description

after-frr	Delays the LSP reoptimization in the event of the FRR.
<i>seconds</i>	Reoptimization initiation delay time of the tunnel, in seconds, after an FRR event. Range is from 0 to 120.
cleanup	Delays removal of the old LSPs after tunnel reoptimization.
<i>delay-time</i>	Reoptimization delay time, in seconds. A value of 0 disables delay. The valid range is from 0 to 300 for cleanup time.
installation	Delays installation of a new label after tunnel reoptimization.
<i>delay-time</i>	Reoptimization delay time, in seconds. A value of 0 disables delay. The valid range is 0 to 3600 for installation time.
path-protection	Delays the time between path protection switchover event and tunnel reoptimization.
<i>seconds</i>	Time, in seconds, between path protection switchover event and tunnel reoptimization. A value of 0 disables delay. Range is from 0 to 604800.

Command Default

after-frr *delay*: 0

cleanup delay: 20
delay-time: 20
installation delay: 20
path-protection: 180

Command Modes MPLS-TE configuration

Command History

Release	Modification
Release 3.2	This command was supported.
Release 3.9.0	The after-frr and path-protection keywords were added.

Usage Guidelines

A device with Multiprotocol Label Switching traffic engineering (MPLS-TE) tunnels periodically examines tunnels with established LSPs to discover whether more efficient LSPs (paths) are available. If a better LSP is available, the device signals the more efficient LSP; if the signaling is successful, the device replaces the older LSP with the new, more efficient LSP.

Sometimes the slower router-point nodes may not yet utilize the new label's forwarding plane. In this case, if the headend node replaces the labels quickly, it can result in brief packet loss. By delaying the cleanup of the old LSP using the **reoptimize timers delay cleanup** command, packet loss is avoided.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to set the reoptimization cleanup delay time to 1 minute:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# reoptimize timers delay cleanup 60
```

The following example shows how to set the reoptimization installation delay time to 40 seconds:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# reoptimize timers delay installation 40
```

The following example shows how to set the reoptimization delay time after the event of the FRR to 50 seconds:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# reoptimize timers delay after-frr 50
```

The following example shows how to set the reoptimization delay time between path protection switchover event and tunnel reoptimization to 80:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# reoptimize timers delay path-protection 80
```

Related Commands

Command	Description
reoptimize (MPLS-TE), on page 325	Reoptimizes all traffic engineering tunnels immediately.
mpls traffic-eng reoptimize (EXEC), on page 279	Configures the reoptimization interval of all TE tunnels.

router-id secondary (MPLS-TE)

To configure a secondary TE router identifier in MPLS-TE to be used locally (not advertised through IGP), use the **router-id secondary** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

router-id secondary *IP address*

no router-id secondary *IP address*

Syntax Description

<i>IP address</i>	IPv4 address to be used as secondary TE router ID.

Command Default

No default behavior or values

Command Modes

MPLS-TE configuration

Command History

Release	Modification
Release 3.4.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **router-id secondary** command on tail end nodes to terminate verbatim tunnels to secondary TE RIDs as destinations.

You can configure up to 32 IPv4 addresses as TE secondary router IDs.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to configure a secondary TE router identifier in MPLS-TE:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# router-id secondary 1.1.1.1
RP/0/0/CPU0:router(config-mpls-te)# router-id secondary 2.2.2.2
```

Related Commands

Command	Description
mpls traffic-eng router-id (MPLS-TE router), on page 281	Specifies that the TE router identifier for the node is the IP address associated with a given interface.

show explicit-paths

To display the configured IP explicit paths, use the **show explicit-paths** command in EXEC mode.

show explicit-paths [*name path-name*] *identifier number*

Syntax Description

name <i>path-name</i>	(Optional) Displays the name of the explicit path.
identifier <i>number</i>	(Optional) Displays the number of the explicit path. Range is 1 to 65535.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

An IP explicit path is a list of IP addresses that represent a node or link in the explicit path.

Task ID

Task ID	Operations
mpls-te	read

Examples

The following shows a sample output from the **show explicit-paths** command:

```
RP/0/0/CPU0:router# show explicit-paths

Path ToR2      status enabled
               0x1: next-address 192.168.1.2
               0x2: next-address 10.20.20.20
Path ToR3      status enabled
               0x1: next-address 192.168.1.2
               0x2: next-address 192.168.2.2
               0x3: next-address 10.30.30.30
Path 100       status enabled
               0x1: next-address 192.168.1.2
```



```

      0x2: next-address 10.20.20.20
Path 200    status enabled
      0x1: next-address 192.168.1.2
      0x2: next-address 192.168.2.2
      0x3: next-address 10.30.30.30

```

This table describes the significant fields shown in the display.

Table 27: show explicit-paths Command Field Descriptions

Field	Description
Path	Pathname or number, followed by the path status.
1: next-address	First IP address in the path.
2: next-address	Second IP address in the path.

The following shows a sample output from the **show explicit-paths** command using a specific path name:

```

RP/0/0/CPU0:router# show explicit-paths name ToR3

Path ToR3    status enabled
      0x1:  next-address 192.168.1.2
      0x2:  next-address 192.168.2.2
      0x3:  next-address 10.30.30.30

```

The following shows a sample output from the **show explicit-paths** command using a specific path number:

```

RP/0/0/CPU0:router# show explicit-paths identifier 200

Path 200    status enabled
      0x1:  next-address 192.168.1.2
      0x2:  next-address 192.168.2.2
      0x3:  next-address 10.30.30.30

```

Related Commands

Command	Description
index exclude-address, on page 230	Specifies the next IP address to exclude from the explicit path.
index next-address, on page 234	Specifies path entries at a specific index.

show mpls traffic-eng affinity-map

To display the color name-to-value mappings configured on the router, use the **show mpls traffic-eng affinity-map** command in EXEC mode.

show mpls traffic-eng affinity-map

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes EXEC

Command History	Release	Modification
	Release 3.4.0	This command was introduced.
	Release 3.9.0	The Bit Position field was added to the sample output.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

If the affinity value of an affinity associated with an affinity constraint is unknown, the **show mpls traffic-eng affinity-map** command output displays: "(refers to undefined affinity name)"

Task ID	Task ID	Operations
	mpls-te	read

Examples The following shows a sample output from the **show mpls traffic-eng affinity-map** command:

RP/0/0/CPU0:router# **show mpls traffic-eng affinity-map**

Affinity Name	Bit-position	Affinity Value
bcdefghabdefghabdefghabdefgha	0	1
red1	1	2
red2	2	4
red3	3	8
red4	4	10
red5	5	20
red6	6	40
red7	7	80

```

red8      8      100
red9      9      200
red10     10     400
red11     11     800
red12     12    1000
red13     13    2000
red14     14   4000
red15     15   8000
red16     16  10000
cdefghabcdefghabcdefghabcdefghab 17 20000
red18     18  40000
red19     19  80000
red20     20 100000
red21     21 200000
red22     22 400000
red23     23 800000
red24     24 1000000
red25     25 2000000
red26     26 4000000
red27     27 8000000
black28   28 10000000
red28     29 20000000
red30     30 40000000
abcdefghabcdefghabcdefghabcdefgh 31 80000000

```

Table 28: [show mpls traffic-eng affinity-map Field Descriptions, on page 335](#) describes the significant fields shown in the display.

Table 28: show mpls traffic-eng affinity-map Field Descriptions

Field	Description
Affinity Name	Affinity name associated with the tunnel affinity constraints.
Bit-position	Bit position set in the 32-bit affinity value
Affinity Value	Affinity value associated with the affinity name.

Related Commands

Command	Description
affinity, on page 154	Configures an affinity (the properties the tunnel requires in its links) for an MPLS-TE tunnel.
affinity-map, on page 158	Assigns a numerical value to each affinity name.

show mpls traffic-eng autoroute

To display tunnels that are announced to the Interior Gateway Protocol (IGP), including information about next hop and destinations, use the **show mpls traffic-eng autoroute** command in EXEC mode.

show mpls traffic-eng autoroute [*IP-address*]

Syntax Description	
<i>IP-address</i>	(Optional) Tunnel leading to this address.

Command Default	No default behavior or values

Command Modes	EXEC

Command History	Release	Modification
	Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The enhanced shortest path first (SPF) calculation of the IGP has been modified so that it uses traffic-engineering tunnels. The **show mpls traffic-eng autoroute** command displays those tunnels IGP is currently using in its enhanced SPF calculation (that is, which tunnels are up and have autoroute configured).

Tunnels are organized by destination. All tunnels to a destination carry a share of the traffic tunneled to that destination.

Task ID	Task ID	Operations
	mpls-te	read

Examples

The following shows a sample output from the **show mpls traffic-eng autoroute** command:

```
RP/0/0/CPU0:router# show mpls traffic-eng autoroute
Destination 103.0.0.3 has 2 tunnels in OSPF 0 area 0
tunnel-te1 (traffic share 1, nexthop 103.0.0.3)
tunnel-te2 (traffic share 1, nexthop 103.0.0.3)
```

This table describes the significant fields shown in the display.

Table 29: show mpls traffic-eng autoroute Command Field Descriptions

Field	Description
Destination	Multiprotocol Label Switching (MPLS) TE tail-end router ID.
traffic share	A factor based on bandwidth, indicating how much traffic this tunnel should carry, relative to other tunnels, to the same destination. If two tunnels go to a single destination, one with a traffic share of 200 and the other with a traffic share of 100, the first tunnel carries two-thirds of the traffic.
Nexthop	Next-hop router ID of the MPLS-TE tunnel.
absolute metric	Metric with mode absolute for the MPLS-TE tunnel.
relative metric	Metric with mode relative for the MPLS-TE tunnel.

Related Commands

Command	Description
autoroute metric, on page 172	Specifies the MPLS-TE tunnel metric that the IGP-enhanced SPF calculation will use.
show mpls traffic-eng tunnels, on page 401	Displays information about MPLS-TE tunnels.
topology holddown sigerr (MPLS-TE), on page 449	Specifies the time that a router should ignore a link in its TE topology database in tunnel path CSPF computations following a TE tunnel signalling error on the link.

show mpls traffic-eng auto-tunnel backup

To display information about automatically build MPLS-TE backup tunnels, use the **show mpls traffic-eng auto-tunnel backup** command in EXEC mode.

show mpls traffic-eng auto-tunnel {backup [private|summary|unused]}

Syntax Description

backup	Displays information about auto-tunnel backup.
private	(Optional) Displays private information about the automatically build MPLS-TE backup tunnels.
summary	(Optional) Displays the automatically build MPLS-TE backup tunnels summary information.
unused	(Optional) Displays only unused MPLS-TE backup tunnels.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 4.0.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operation
mpls-te	read

Examples

This is sample output from the **show mpls traffic-eng auto-tunnel backup** command:

```
AutoTunnel Backup Configuration:
  Interfaces count: 4
  Unused removal timeout: 1h 0m 0s
  Configured tunnel number range: 2000-2500
```

```

AutoTunnel Backup Summary:
  AutoTunnel Backups:
    1 created, 1 up, 0 down, 0 unused
    1 NHOP, 0 NNHOP, 0 SRLG strict, 0 SRLG preferred
  Protected LSPs:
    1 NHOP, 0 NHOP+SRLG
    0 NNHOP, 0 NNHOP+SRLG
  Protected S2L Sharing Families:
    0 NHOP, 0 NHOP+SRLG
    0 NNHOP, 0 NNHOP+SRLG
  Protected S2Ls:
    0 NHOP, 0 NHOP+SRLG
    0 NNHOP, 0 NNHOP+SRLG

Cumulative Counters (last cleared 05:17:19 ago):
      Total    NHOP    NNHOP
Created:         1         1         0
Connected:       1         1         0
Removed (down):  0         0         0
Removed (unused): 0         0         0
Removed (in use): 0         0         0
Range exceeded:  0         0         0

AutoTunnel Backups:
      Tunnel   State   Protection   Prot.   Protected   Protected
      Name                                Offered  Flows*   Interface   Node
-----
tunnel-te2000      up NHOP                                1      Gi0/2/0/2   N/A

*Prot. Flows = Total Protected LSPs, S2Ls and S2L Sharing Families

```

This is sample output from the **show mpls traffic-eng auto-tunnel mesh** command:

```

RP/0/0/CPU0:router#show mpls traffic-eng auto-tunnel mesh

Auto-tunnel Mesh Global Configuration:
  Unused removal timeout: 2h
  Configured tunnel number range: 10000-12000

Auto-tunnel Mesh Groups Summary:
  Mesh Groups count: 5
  Mesh Groups Destinations count: 50

Mesh Group 40 (2 Destinations, 1 Up, 1 Down):
  Destination-list: dl-40
  Attribute-set: ta_name
  Destination: 40.40.40.40, tunnel-id: 10000, State: Up
  Destination: 10.10.10.10, tunnel-id: 10001, State: Down
Mesh Group 41 (3 Destinations, 2 Up, 1 Down):
  Destination-list: dl-40
  Attribute-set: ta_name
  Destination: 4.4.4.4, tunnel-id: 10005, State: Up
  Destination: 3.3.3.3, tunnel-id: 10006, State: Up
  Destination: 1.1.1.1, tunnel-id: 10007, State: Down
Mesh Group 51 (0 Destinations, 0 Up, 0 Down):
  Destination-list: Not configured
  Attribute-set: Not configured
Mesh Group 52 (0 Destinations, 0 Up, 0 Down):
  Destination-list: NAME1 (Not defined)
  Attribute-set: NAME2 (Not defined)
Mesh Group 53 (2 Destinations, 1 Up, 1 Down):
  Destination-list: dl-53
  Attribute-set: Not configured
  Destination: 40.40.40.40, tunnel-id: 10000, State: Up
  Destination: 10.10.10.10, tunnel-id: 10001, State: Down

Cumulative Counters (last cleared 7h ago):
      Total
Created:      100
Connected:    50
Removed (unused): 50

```

```
Removed (in use):      0
Range exceeded:        0
```

This is sample output from the **show mpls traffic-eng auto-tunnel private** command:

```
Auto-tunnel Mesh Private Information:
ID allocator overall maximum ID: 4096
ID allocator last allocated ID: 50999
ID allocator number IDs allocated: 1000
```


show mpls traffic-eng auto-tunnel mesh

To display information about automatically built MPLS-TE mesh tunnels, use the **show mpls traffic-eng auto-tunnel mesh** command in EXEC mode.

show mpls traffic-eng auto-tunnel mesh {*mesh-value*| **unused**| **summary**| **attribute-set** *name*| **destination** *address*| **destination-list** *name*| **down**| **up**| **tunnel** {**created**| **not-created**}}

Syntax Description

mesh <i>mesh-value</i>	Displays the tunnels that belong to the specified auto-tunnel mesh group. The range of mesh group ID is from 0 to 4294967295.
attribute-set <i>name</i>	Displays mesh-groups configured with a specific attribute set.
destination <i>address</i>	Displays only the destinations with a specified address.
destination-list <i>name</i>	Displays mesh-groups configured with a specified prefix-list.
down	Displays only those tunnels that are down.
up	Displays only those tunnels that are up.
summary	Displays auto-tunnel mesh summary information.
unused	Displays only the down tunnels with no destination in the topology.
tunnel created not-created	Specifies either created destinations with tunnels, or not-created destinations without tunnels.

Command Default

None

Command Modes

EXEC

Command History

Release	Modification
Release 4.1.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operation
MPLS-TE	read

Examples

This is sample output from the **show mpls traffic-eng auto-tunnel mesh** command:

```
RP/0/0/CPU0:router show mpls traffic-eng auto-tunnel mesh
```

```
Auto-tunnel Mesh Global Configuration:
  Unused removal timeout: 1h 0m 0s
  Configured tunnel number range: 1000-1200
```

```
Auto-tunnel Mesh Groups Summary:
  Mesh Groups count: 1
  Mesh Groups Destinations count: 3
  Mesh Groups Tunnels count:
    3 created, 0 up, 3 down, 0 FRR enabled
```

```
Mesh Group: 65 (3 Destinations)
  Status: Enabled
  Attribute-set: am-65
  Destination-list: dl-65 (Not a prefix-list)
  Recreate timer: Not running
  -----
  Destination      Tunnel ID      State      Unused timer
  -----
    192.168.0.2      1000         up      Not running
    192.168.0.3      1001         up      Not running
    192.168.0.4      1002         up      Not running
  Displayed 3 tunnels, 0 up, 3 down, 0 FRR enabled
```

```
Auto-mesh Cumulative Counters:
  Last cleared: Wed Nov  9 12:56:37 2011 (02:39:07 ago)
  -----
  Created:          3
  Connected:        0
  Removed (unused): 0
  Removed (in use): 0
  Range exceeded:   0
```

This shows how to configure the **auto-tunnel mesh** command with **destination-list** and **attribute-set** keywords:

```
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# auto-tunnel mesh
RP/0/0/CPU0:router(config-te-auto-mesh)# group 65
RP/0/0/CPU0:router(config-te-mesh-group)# disable
RP/0/0/CPU0:router(config-te-mesh-group)# destination-list dl-65
RP/0/0/CPU0:router(config-te-mesh-group)# attribute-set am-65
```



Note

This **attribute-set** is an optional configuration. Without this configuration, all tunnels use default tunnel attribute values. If you configure a non-existent attribute-set, this mesh group does not create any tunnel.



Note

This **destination-list** configuration is mandatory. If there is no IPv4 prefix-list by this name on the router, this mesh group creates tunnels with all routers in the network.

show mpls traffic-eng collaborator-timers

To display the current status of the MPLS-TE collaborator timers, use the **show mpls traffic-eng collaborator-timers** command in EXEC mode.

show mpls traffic-eng collaborator-timers

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes EXEC

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The MPLS-TE process maintains the timers for all of the collaborators such as RSVP, LSD, and so forth. The **show mpls traffic-eng collaborator-timers** command shows the status of these timers.

Task ID	Task ID	Operations
	mpls-te	read

Examples The following sample output shows the current status of the collaborator timers:

```
RP/0/0/CPU0:router# show mpls traffic-eng collaborator-timers

Collaborator Timers
-----
Timer Name: [LMRIB Restart] Index:[0]
  Duration: [60] Is running: NO
  Last start time: 02/09/2009 11:57:59
  Last stop time: 02/09/2009 11:58:00
  Last expiry time: Never expired
Timer Name: [LMRIB Recovery] Index:[1]
  Duration: [60] Is running: YES
  Last start time: 02/09/2009 11:58:00
  Last stop time: Never Stopped
  Last expiry time: 19/08/2009 17:45:24
Timer Name: [RSVP Restart] Index:[2]
```

```

Duration: [180] Is running: NO
Last start time: 26/08/2009 18:59:18
Last stop time: 26/08/2009 18:59:20
Last expiry time: Never expired
Timer Name: [RSVP Recovery] Index:[3]
Duration: [1800] Is running: NO
Last start time: 26/08/2009 18:59:20
Last stop time: 26/08/2009 19:03:19
Last expiry time: 19/08/2009 18:12:39
Timer Name: [LSD Restart] Index:[4]
Duration: [60] Is running: NO
Last start time: 19/08/2009 17:44:26
Last stop time: 19/08/2009 17:44:26
Last expiry time: Never expired
Timer Name: [LSD Recovery] Index:[5]
Duration: [600] Is running: NO
Last start time: 19/08/2009 17:44:26
Last stop time: Never Stopped
Last expiry time: 19/08/2009 17:53:44
Timer Name: [Clearing in progress BW for the whole topology] Index:[6]
Duration: [60] Is running: YES
Last start time: 02/09/2009 11:57:50
Last stop time: Never Stopped
Last expiry time: 02/09/2009 11:57:50

```

This table describes the significant fields shown in the display.

Table 30: show mpls traffic-eng collaborator-timers Command Field Descriptions

Field	Description
Timer Name	Timer name that is associated to a collaborator.
Index	Identification number of the timer.
Duration	Expiry delay of the timer, in seconds. For example, the duration indicates the timer interval.
Is running	Timer is running low or not.
Last start time	Last time that the collaborator process for MPLS LSD was restarted.
Last stop time	Time TE was able to reconnect to the MPLS LSD process.
Last expiry time	Time that timer expired.

show mpls traffic-eng counters signaling

To display tunnel signaling statistics, use the **show mpls traffic-eng counters signaling** command in EXEC mode.

```
show mpls traffic-eng counters {signaling} {tunnel-number|all} [heads | mids | tails] [name tunnel-name] summary
```

Syntax Description

signaling	Displays signaling counters.
<i>tunnel-number</i>	Statistics for the input tunnel number. The range is from 0 to 65535.
all	Displays statistics for all tunnels.
heads	(Optional) Displays statistics for all tunnel heads.
mids	(Optional) Displays statistics for all tunnel midpoints.
tails	(Optional) Displays statistics for all tunnel tails.
name	Displays statistics for a specified tunnel.
<i>tunnel-name</i>	Name of the specified tunnel.
summary	Displays a summary of signaling statistics.

Command Default

None

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was supported.
Release 3.5.0	Support was added for the middles keyword.

Release	Modification
Release 3.8.0	The <i>tunnel-name</i> argument was added and the middles keyword was replaced with the mids keyword.
Release 3.9.0	The sample output for the all keyword was modified to display the tunnel signaling statistics for all tunnels that includes the tunnel-mte interface.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	read

Examples

This is a sample output from the **show mpls traffic-eng counters signaling** command, using the **all** keyword, which displays tunnel signaling statistics for all tunnels:

```
RP/0/0/CPU0:router# show mpls traffic-eng counters signaling all
```

```
Tunnel Head: tunnel-te100
Cumulative Tunnel Counters:
  Signalling Events      Recv      Xmit      ResvCreate      Recv      Xmit
    PathCreate           1          1      ResvCreate       1          0
    PathChange           0          0      ResvChange       0          0
    PathError             0          0      ResvError        0          0
    PathTear              0         18      ResvTear         0          0
    BackupAssign          0          1      BackupError      0          0
    PathQuery             0          0      Unknown          0          0

Destination 100.0.0.4
Cumulative counters
  Signalling Events      Recv      Xmit      ResvCreate      Recv      Xmit
    PathCreate           1          1      ResvCreate       1          0
    PathChange           0          0      ResvChange       0          0
    PathError             0          0      ResvError        0          0
    PathTear              0         18      ResvTear         0          0
    BackupAssign          0          1      BackupError      0          0
    PathQuery             0          0      Unknown          0          0
S2L LSP ID: 2 Sub-Grp ID: 0 Destination: 100.0.0.4
  Signalling Events      Recv      Xmit      ResvCreate      Recv      Xmit
    PathCreate           1          1      ResvCreate       1          0
    PathChange           0          0      ResvChange       0          0
    PathError             0          0      ResvError        0          0
    PathTear              0          0      ResvTear         0          0
    BackupAssign          0          1      BackupError      0          0
    PathQuery             0          0      Unknown          0          0

Tunnel Head: tunnel-mte200
Cumulative Tunnel Counters:
  Signalling Events      Recv      Xmit      ResvCreate      Recv      Xmit
    PathCreate           2          2      ResvCreate       2          0
    PathChange           0          0      ResvChange       0          0
    PathError             0          0      ResvError        0          0
```

```

PathTear          0      20      ResvTear          0      0
BackupAssign      0      2      BackupError      0      0
PathQuery         0      0      Unknown          0      0

Destination 100.0.0.4
Cumulative counters
Signalling Events      Recv      Xmit          Recv      Xmit
PathCreate           2        2      ResvCreate       2        0
PathChange           0        0      ResvChange       0        0
PathError            0        0      ResvError        0        0
PathTear             0       20      ResvTear         0        0
BackupAssign         0        2      BackupError      0        0
PathQuery            0        0      Unknown          0        0

S2L LSP ID: 10021 Sub-Grp ID: 1 Destination: 100.0.0.4
Signalling Events      Recv      Xmit          Recv      Xmit
PathCreate           1        1      ResvCreate       1        0
PathChange           0        0      ResvChange       0        0
PathError            0        0      ResvError        0        0
PathTear             0        0      ResvTear         0        0
BackupAssign         0        1      BackupError      0        0
PathQuery            0        0      Unknown          0        0

Tunnel Mid/Tail: router Source: 100.0.0.1 P2MP ID: 1677721603 Tunnel ID: 1 LSP ID: 21
Cumulative LSP Counters:
Signalling Events      Recv      Xmit          Recv      Xmit
PathCreate           2        1      ResvCreate       2        1
PathChange           0        0      ResvChange       0        0
PathError            0        0      ResvError        0        0
PathTear             0        0      ResvTear         0        0
BackupAssign         0        0      BackupError      0        0
PathQuery            0        0      Unknown          0        0

S2L LSP ID: 21 Sub-Grp ID: 0 Destination: 100.0.0.3
Signalling Events      Recv      Xmit          Recv      Xmit
PathCreate           2        1      ResvCreate       2        1
PathChange           0        0      ResvChange       0        0
PathError            0        0      ResvError        0        0
PathTear             0        0      ResvTear         0        0
BackupAssign         0        0      BackupError      0        0
PathQuery            0        0      Unknown          0        0

Tunnel Mid/Tail: router Source: 100.0.0.1 P2MP ID: 1677721603 Tunnel ID: 2 LSP ID: 21
Cumulative LSP Counters:
Signalling Events      Recv      Xmit          Recv      Xmit
PathCreate           2        1      ResvCreate       2        1
PathChange           0        0      ResvChange       0        0
PathError            0        0      ResvError        0        0
PathTear             0        0      ResvTear         0        0
BackupAssign         0        0      BackupError      0        0
PathQuery            0        0      Unknown          0        0

S2L LSP ID: 21 Sub-Grp ID: 0 Destination: 100.0.0.3
Signalling Events      Recv      Xmit          Recv      Xmit
PathCreate           2        1      ResvCreate       2        1
PathChange           0        0      ResvChange       0        0
PathError            0        0      ResvError        0        0
PathTear             0        0      ResvTear         0        0
BackupAssign         0        0      BackupError      0        0
PathQuery            0        0      Unknown          0        0

Tunnel Mid/Tail: router-1_t3 Source: 100.0.0.1 P2MP ID: 1677721603 Tunnel ID: 3 LSP ID:
18
Cumulative LSP Counters:
Signalling Events      Recv      Xmit          Recv      Xmit
PathCreate           2        1      ResvCreate       2        1
PathChange           0        0      ResvChange       0        0
PathError            0        0      ResvError        0        0
PathTear             0        0      ResvTear         0        0
BackupAssign         0        0      BackupError      0        0
PathQuery            0        0      Unknown          0        0

S2L LSP ID: 18 Sub-Grp ID: 0 Destination: 100.0.0.3
Signalling Events      Recv      Xmit          Recv      Xmit
PathCreate           2        1      ResvCreate       2        1
PathChange           0        0      ResvChange       0        0
PathError            0        0      ResvError        0        0

```

show mpls traffic-eng counters signaling

```

      PathTear          0          0      ResvTear          0          0
      BackupAssign      0          0      BackupError       0          0
      PathQuery         0          0      Unknown           0          0

Tunnel Mid/Tail: router-3_t33 Source: 100.0.0.3 P2MP ID: 1677721605 Tunnel ID: 33 LSP ID:
2
Cumulative LSP Counters:
  Signalling Events      Recv      Xmit          Recv      Xmit
  PathCreate             2          1      ResvCreate       2          1
  PathChange             0          0      ResvChange       0          0
  PathError              0          0      ResvError        0          0
  PathTear               0          0      ResvTear         0          0
  BackupAssign           0          0      BackupError      0          0
  PathQuery              0          0      Unknown          0          0
S2L LSP ID: 2 Sub-Grp ID: 0 Destination: 100.0.0.5
  Signalling Events      Recv      Xmit          Recv      Xmit
  PathCreate             2          1      ResvCreate       2          1
  PathChange             0          0      ResvChange       0          0
  PathError              0          0      ResvError        0          0
  PathTear               0          0      ResvTear         0          0
  BackupAssign           0          0      BackupError      0          0
  PathQuery              0          0      Unknown          0          0

Signaling Counter Summary:
  Signalling Events      Recv      Xmit          Recv      Xmit
  PathCreate            11          7      ResvCreate      11          4
  PathChange            0          0      ResvChange       0          0
  PathError             0          0      ResvError        0          0
  PathTear              0         38      ResvTear         0          0
  BackupAssign          0          3      BackupError      0          0
  PathQuery             0          0      Unknown          0          0

```

This is a sample output from the **show mpls traffic-eng counters signaling** command using the *tunnel number* argument, which displays statistics for the input tunnel number:

RP/0/0/CPU0:router# **show mpls traffic-eng counters signaling 200**

```

Tunnel Head: tunnel-te200
Cumulative Tunnel Counters:
  Signalling Events      Recv      Xmit          Recv      Xmit
  PathCreate             4          4      ResvCreate       4          0
  PathChange             0          0      ResvChange       0          0
  PathError              0          0      ResvError        0          0
  PathTear               0          1      ResvTear         0          0
  BackupAssign           0          4      BackupError      0          0
  PathQuery              0          0      Unknown          0          0

Destination 3.3.3.3
Cumulative counters
  Signalling Events      Recv      Xmit          Recv      Xmit
  PathCreate             4          4      ResvCreate       4          0
  PathChange             0          0      ResvChange       0          0
  PathError              0          0      ResvError        0          0
  PathTear               0          1      ResvTear         0          0
  BackupAssign           0          4      BackupError      0          0
  PathQuery              0          0      Unknown          0          0
S2L LSP ID: 3 Sub-Grp ID: 0 Destination: 3.3.3.3
  Signalling Events      Recv      Xmit          Recv      Xmit
  PathCreate             3          3      ResvCreate       3          0
  PathChange             0          0      ResvChange       0          0
  PathError              0          0      ResvError        0          0
  PathTear               0          0      ResvTear         0          0
  BackupAssign           0          3      BackupError      0          0
  PathQuery              0          0      Unknown          0          0

```

This table describes the significant fields shown in the display.

Table 31: show mpls traffic-eng counters signaling Command Field Descriptions

Field	Description
Tunnel Head	Tunnel head identifier.
Match Resv Create	Number of RSVP Reservation create messages received.
Sender Create	Number of Sender Create messages sent by TE to RSVP.
Path Error	Number of RSVP Path Error messages received.
Match Resv Change	Number of RSVP Reservation change messages received.
Sender Modify	Number of Sender Modify messages sent by TE to RSVP.
Path Change	Number of RSVP Path Change messages received.
Match Resv Delete	Number of RSVP Reservation delete messages received.
Sender Delete	Number of Sender Delete messages sent by TE to RSVP.
Path Delete	Number of RSVP Path Delete messages received.
Total	Total signaling messages received from RSVP.
Unknown	Unknown messages include fast reroute events and internal messages related to process restart.

Related Commands

Command	Description
clear mpls traffic-eng counters signaling, on page 192	Clears the counters for MPLS-TE tunnels.
clear mpls traffic-eng fast-reroute log, on page 196	Clears the counters for MPLS-TE tunnels.

show mpls traffic-eng ds-te te-class

To display the Diff-Serv TE-class map in use, use the **show mpls traffic-eng ds-te te-class** command in EXEC mode.

show show mpls traffic-eng ds-te te-class

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes EXEC

Command History	Release	Modification
	Release 3.3.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note TE-class is used only in IETF DS-TE mode.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples The following shows a sample output from the **show mpls traffic-eng ds-te te-class** command:

```
RP/0/0/CPU0:router# show mpls traffic-eng ds-te te-class

te-class 0: class-type 0 priority 7 status default
te-class 1: class-type 1 priority 7 status default
te-class 2: unused
te-class 3: unused
te-class 4: class-type 0 priority 0 status default
te-class 5: class-type 1 priority 0 status default
te-class 6: unused
te-class 7: unused
```

This table describes the significant fields shown in the display.

Table 32: show mpls traffic-eng ds-te te-class Command Field Descriptions

Field	Description
te-class	TE-class map, pair of class-type, and priority.
class-type	class-type of the tunnel.
status	Source of the TE-class map, either default or user configured.

show mpls traffic-eng forwarding

To display forwarding information on tunnels that were admitted locally, use the **show mpls traffic-eng forwarding** command in EXEC mode.

show mpls traffic-eng forwarding [**backup-name** *tunnel-name*] [**signalled-name** *tunnel-name*] [**source** *source-address*][**tunnel-id** *tunnel-id*] [**interface** {**in** | **inout** | **out**} *type interface-path-id*] {**p2p**} [**detail**]

Syntax Description

backup-name <i>tunnel-name</i>	(Optional) Restricts tunnels with this backup tunnel name.
signalled-name <i>tunnel-name</i>	(Optional) Restricts tunnels with this signalled tunnel name.
source <i>source-address</i>	(Optional) Restricts tunnels for this specified tunnel source IPv4 address.
tunnel-id <i>tunnel-id</i>	(Optional) Restricts tunnels for this tunnel identifier. Range for the <i>tunnel-id</i> argument is from 0 to 65535.
interface	(Optional) Displays information on the specified interface.
<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
in	Displays information for the input interface.
inout	Displays information for either the input or output interface.
out	Displays information for the output interface.
p2p	(Optional) Displays only Point-to-Point (P2P) information.
detail	(Optional) Displays detailed forwarding information.

Command Default No default behavior or values

Command Modes EXEC

Command History	Release	Modification
	Release 3.2	This command was supported.
	Release 3.8.0	The following keywords were added: • detail • p2p
	Release 3.9.0	The following keywords and arguments were added: • backup-name keyword and <i>tunnel-name</i> argument. • signalled-name keyword and <i>tunnel-name</i> argument. • source keyword and <i>source-address</i> argument. • tunnel-id keyword and <i>tunnel-id</i> argument. • in keyword. • inout keyword. • out keyword.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	mpls-te	read

Examples The following shows a sample output from the **show mpls traffic-eng forwarding** command:

```
RP/0/0/CPU0:router# show mpls traffic-eng forwarding
Tue Sep 15 14:22:39.609 UTC P2P tunnels
Tunnel ID      Ingress IF    Egress IF     In lbl    Out lbl    Backup tunnel
-----
```

```

2.2.2.2 2 2          Gi0/0/0/3   Gi0/0/0/4   16004   16020   unknown
6.6.6.6 1_23        -           Gi0/0/0/3   16000    3       tt1300
6.6.6.6 1100_9      -           Gi0/0/0/3   16002   16001   unknown
6.6.6.6 1200_9      -           Gi0/0/0/3   16001   16000   unknown
6.6.6.6 1300_2      -           Gi0/0/0/4   16005   16021   unknown
6.6.6.6 1400_9      -           Gi0/0/0/3   16003   16002   unknown

```

This table describes the significant fields shown in the display.

Table 33: show mpls traffic-eng forwarding Field Descriptions

Field	Description
TUNNEL ID	Tunnel identification.
Ingress IF	Ingress interface of the tunnel.
Egress IF	Egress interface of the tunnel.
In lbl	Incoming label associated with the tunnel.
Out lbl	Outgoing label associated with the tunnel.
Backup tunnel	Fast Reroute backup tunnel

show mpls traffic-eng forwarding-adjacency

To display forwarding-adjacency information for an IPv4 address, use the **show mpls traffic-eng forwarding-adjacency** command in EXEC mode.

show mpls traffic-eng forwarding-adjacency [*IP-address*]

Syntax Description	<i>IP-address</i>	(Optional) Destination IPv4 address for forwarding adjacency.

Command Default No default behavior or values

Command Modes EXEC

Command History	Release	Modification
	Release 3.4.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	mpls-te	read

Examples The following shows a sample output from the **show mpls traffic-eng forwarding-adjacency** command:

```
RP/0/0/CPU0:router# show mpls traffic-eng forwarding-adjacency
destination 3.3.3.3 has 1 tunnels
tunnel-te1      (traffic share 0, next-hop 3.3.3.3)
(Adjacency Announced: yes, holdtime 0)
```

Related Commands	Command	Description
	forwarding-adjacency , on page 228	Configures an MPLS-TE forwarding adjacency.

show mpls traffic-eng igp-areas

To display MPLS-TE internal area storage, use the **show mpls traffic-eng igp-areas** command in EXEC mode.

show mpls traffic-eng igp-areas [detail]

Syntax Description

detail	(Optional) Displays detailed information about the configured MPLS-TE igp-areas and communication statistics with IGP.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.4.0	This command was introduced.
Release 3.7.0	Sample output was modified so that the tunnels and links are not displayed in each area.
Release 3.9.0	The detail keyword was added. Sample output was modified to support the P2MP TE feature.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	read

Examples

The following shows a sample output from the **show mpls traffic-eng igp-areas** command:

```
RP/0/0/CPU0:router# show mpls traffic-eng igp-areas

MPLS-TE IGP Areas

Global router-id:          10.144.144.144
Global optical router-id:  Not available
```



```

IS-IS 100

  IGP ID: 0000.0000.0044
  TE router ID configured: 10.144.144.144
    in use: 10.144.144.144
  Link connection: up
  Topology/tunnel connection: up

  level 2
    TE index: 1
    IGP config for TE: complete
    Local links flooded in this IGP level: 1
    Flooding beacon sent and received
    P2P tunnel heads running over this IGP level: 1
      1 AA, 0 FA
    P2MP destinations running over this IGP level: 0
    Tunnel loose-hops expanded over this IGP level: 0

OSPF 100

  IGP ID: 10.144.144.144
  TE router ID configured: 10.144.144.144
    in use: 10.144.144.144
  Link connection: up
  Topology/tunnel connection: up

  area 0
    TE index: 0
    IGP config for TE: complete
    Local links flooded in this IGP area: 2
    Flooding beacon sent and received
    P2P tunnel heads running over this IGP area: 3
      1 AA, 0 FA
    P2MP destinations running over this IGP area: 0
    Tunnel loose-hops expanded over this IGP area: 0

```

This table describes the significant fields shown in the display.

Table 34: show mpls traffic-eng igp-areas Command Field Descriptions

Field	Description
Global router-id	Global router ID on this node.
IGP ID	IGP System ID.
area	IGP area.
TE index	Internal index in the IGP area table.
IGP config for TE	Whether the IGP configuration is complete or missing.

show mpls traffic-eng link-management admission-control

To display which tunnels were admitted locally and their parameters, use the **show mpls traffic-eng link-management admission-control** command in EXEC mode.

show mpls traffic-eng link-management admission-control [*interface type interface-path-id*]

Syntax Description

interface	(Optional) Displays information on the specified interface.
<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was supported.
Release 3.4.0	Support was added for the Name-Based Affinity Constraint scheme.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	read

Examples

The following shows a sample output from the **show mpls traffic-eng link-management admission-control** command:

```
RP/0/0/CPU0:router# show mpls traffic-eng link-management admission-control

S System Information:
  Tunnels Count      : 2
  Tunnels Selected   : 2
  Bandwidth descriptor legend:
    B0 = bw from pool 0, B1 = bw from pool 1, R = bw locked, H = bw held

TUNNEL ID          UP IF      DOWN IF      PRI STATE      BW (kbits/sec)
-----
10.10.10.10 1_34    -            PO0/2/0/1    7/7 Resv Admitted 100      RB0
10.10.10.10 15_2    -            PO0/2/0/2    7/7 Resv Admitted 0        B0
```

This table describes the significant fields shown in the display.

Table 35: show mpls traffic-eng link-management admission-control Command Field Descriptions

Field	Description
Tunnels Count	Total number of tunnels admitted.
Tunnels Selected	Number of tunnels displayed.
Bandwidth descriptor legend	BW pool type and status displayed with the tunnel entry. Shown as RG (Locked BW in global pool) in the preceding sample output.
TUNNEL ID	Tunnel identification.
UP IF	Upstream interface used by the tunnel.
DOWN IF	Downstream interface used by the tunnel.
PRI	Tunnel setup priority and hold priority.
STATE	Tunnel admission status.
BW (kbps)	Tunnel bandwidth in kilobits per second. If an R follows the bandwidth number, the bandwidth is reserved. If an H follows the bandwidth number, the bandwidth is temporarily being held for a Path message. If a G follows the bandwidth number, the bandwidth is from the global pool. If an S follows the bandwidth number the bandwidth is from the sub-pool.

The following shows a sample output from the **show mpls traffic-eng link-management interface** command:

```
RP/0/0/CPU0:router# show mpls traffic-eng link-management interface pos 0/2/0/1
```

```

System Information::
  Links Count          : 1

Link ID:: POS0/2/0/1 (35.0.0.5)
  Local Intf ID: 7
  Link Status:

    Link Label Type      : PSC (inactive)
    Physical BW          : 155520 kbits/sec
    BCID                 : RDM
    Max Reservable BW    : 0 kbits/sec (reserved: 100% in, 100% out)
    BC0 (Res. Global BW): 0 kbits/sec (reserved: 100% in, 100% out)
    BC1 (Res. Sub BW)   : 0 kbits/sec (reserved: 100% in, 100% out)
    MPLS-TE Link State   : MPLS-TE on, RSVP on
    Inbound Admission    : allow-all
    Outbound Admission   : allow-if-room
    IGP Neighbor Count   : 0
    Max Res BW (RDM)     : 0 kbits/sec
    BC0 (RDM)            : 0 kbits/sec
    BC1 (RDM)            : 0 kbits/sec
    Max Res BW (MAM)     : 0 kbits/sec
    BC0 (MAM)            : 0 kbits/sec
    BC1 (MAM)            : 0 kbits/sec
    Admin Weight         : 1 (OSPF), 10 (ISIS)
    Attributes           : 0x5 (name-based)
    Flooding Status: (1 area)
      IGP Area[1]: ospf 100 area 0, not flooded
                  (Reason: Interface has been administratively disabled)

```

This table describes the significant fields shown in the display.

Table 36: show mpls traffic-eng link-management interface Command Field Descriptions

Field	Description
Links Count	Number of links configured for MPLS-TE.
Link ID	Index of the link described.
Local Intf ID	Local interface ID.
Link Label Type	Label type of the link, for instance: PSC ¹⁸ , TDM ¹⁹ , FSC ²⁰ .
Physical BW	Link bandwidth capacity (in kilobits per second).
BCID	Bandwidth constraint model ID (RDM or MAM).
Max Reservable BW	Maximum reservable bandwidth on this link.
BC0 (Res. Global BW)	Bandwidth constraint value for class-type 0.
BC1 (Res. Sub BW)	Bandwidth constraint value for class-type 1.
MPLS-TE Link State	Status of the link MPLS-TE-related functions.
Inbound Admission	Link admission policy for incoming tunnels.
Outbound Admission	Link admission policy for outgoing tunnels.

Field	Description
IGP Neighbor Count	IGP neighbors directly reachable over this link.
Max Res BW (RDM)	Maximum reservable bandwidth on this link for RDM.
BC0 (RDM)	Bandwidth constraint value for RDM.
BC1 (RDM)	Bandwidth constraint value for RDM.
Admin Weight	Administrative weight associated with this link.
Attributes	Interface attributes referring to one or more affinity names.
IGP Area[1]	IGP type and area and level used for TE flooding.

¹⁸ PSC = Packet switch capable.

¹⁹ TDM = Time-division multiplexing.

²⁰ FSC = Fiber switch capable.

show mpls traffic-eng link-management advertisements

To display local link information that MPLS-TE link management is currently flooding into the global TE topology, use the **show mpls traffic-eng link-management advertisements** command in EXEC mode.

show mpls traffic-eng link-management advertisements

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes EXEC

Command History	Release	Modification
	Release 3.2	This command was supported.
	Release 3.8.0	This command was modified to include information specific to MPLS Shared Risk Link Groups (SRLG).
	Release 3.9.0	Sample output was modified to display the Attribute Names field.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show mpls traffic-eng link-management advertisements** command has two output formats depending on the Diff-Serv TE Mode: one for prestandard mode and one for IETF mode.

The SRLG values are advertised for the link.

Task ID	Task ID	Operations
	mpls-te	read

Examples The following shows a sample output from the **show mpls traffic-eng link-management advertisements** command:

```
RP/0/0/CPU0:router# show mpls traffic-eng link-management advertisements
Link ID:: 0 (GigabitEthernet0/2/0/1)
          Link IP Address      : 12.9.0.1
```

```

O/G Intf ID      : 28
Designated Router : 12.9.0.2
TE Metric        : 1
IGP Metric       : 1
Physical BW      : 1000000 kbits/sec
BCID            : RDM
Max Reservable BW : 10000 kbits/sec
Res Global BW    : 10000 kbits/sec
Res Sub BW       : 0 kbits/sec
SRLGs           : 10, 20

Downstream::
Global Pool      Sub Pool
-----
Reservable BW[0]: 10000 0 kbits/sec
Reservable BW[1]: 10000 0 kbits/sec
Reservable BW[2]: 9800 0 kbits/sec
Reservable BW[3]: 9800 0 kbits/sec
Reservable BW[4]: 9800 0 kbits/sec
Reservable BW[5]: 9800 0 kbits/sec
Reservable BW[6]: 9800 0 kbits/sec
Reservable BW[7]: 9800 0 kbits/sec

Attribute Flags: 0x00000004
Attribute Names: red2

Link ID:: 1 (GigabitEthernet0/2/0/2)
Link IP Address : 14.9.0.1
O/G Intf ID     : 29
Designated Router : 14.9.0.4
TE Metric       : 1
IGP Metric      : 1
Physical BW     : 1000000 kbits/sec
BCID           : RDM
Max Reservable BW : 750000 kbits/sec
Res Global BW    : 750000 kbits/sec
Res Sub BW       : 0 kbits/sec

Downstream::
Global Pool      Sub Pool
-----
Reservable BW[0]: 750000 0 kbits/sec
Reservable BW[1]: 750000 0 kbits/sec
Reservable BW[2]: 750000 0 kbits/sec
Reservable BW[3]: 750000 0 kbits/sec
Reservable BW[4]: 750000 0 kbits/sec
Reservable BW[5]: 750000 0 kbits/sec
Reservable BW[6]: 750000 0 kbits/sec
Reservable BW[7]: 750000 0 kbits/sec

Attribute Flags: 0x00000000
Attribute Names:

```

This table describes the significant fields shown in the display.

Table 37: show mpls traffic-eng link-management advertisements Command Field Descriptions

Field	Description
Link ID	Index of the link described.
Link IP Address	Local IP address of the link.
TE Metric	Metric value for the TE link configured under MPLS-TE.

Field	Description
IGP Metric	Metric value for the TE link configured under IGP.
Physical BW	Link bandwidth capacity (in kilobits per second).
BCID	Bandwidth constraint model ID (RDM or MAM).
Max Reservable BW	Maximum reservable bandwidth on this link.
Res Global BW	Maximum reservable of global pool/BC0 bandwidth on this link.
Res Sub BW	Reservable sub-bandwidth for sub-pool /BC1 bandwidth on this link.
SRLGs ²¹	Links that share a common fiber or a common physical attribute. If one link fails, other links in the group may also fail. Links in the group have a shared risk.
Downstream	Direction of the LSP path message.
Reservable BW[x]	Bandwidth available for reservations in the global TE topology and subpools.
Attribute Flags	Link attribute flags being flooded.
Attribute Names	Name of the affinity attribute of a link.
BC0	Bandwidth constraint value for class-type 0
BC1	Bandwidth constraint value for class-type 1
TE-class [index]	TE-class configured on this router at given index (mapping of class-type and priority), shows available bandwidth in that class.

²¹ SRLGs = Shared Risk Link Groups.

show mpls traffic-eng link-management bandwidth-allocation

To display current local link information, use the **show mpls traffic-eng link-management bandwidth-allocation** command in EXEC mode.

show mpls traffic-eng link-management bandwidth-allocation [*interface type interface-path-id*]

Syntax Description

interface	(Optional) Displays information on the specified interface.
<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Advertised and current information may differ depending on how flooding is configured.

Task ID

Task ID	Operations
mpls-te	read

Examples

The following shows a sample output from the **show mpls traffic-eng link-management bandwidth-allocation** command:

```
RP/0/0/CPU0:router# show mpls traffic-eng link bandwidth-allocation interface POS 0/2/0/1
```

```
System Information::
  Links Count          : 4
  Bandwidth Hold time  : 15 seconds

Link ID:: POS0/2/0/1 (7.2.2.1)
Local Intf ID: 4
Link Status:
  Link Label Type      : PSC
  Physical BW          : 155520 kbits/sec
  BCID                 : MAM
  Max Reservable BW    : 1000 kbits/sec (reserved: 0% in, 0% out)
  BC0                  : 600 kbits/sec (reserved: 2% in, 2% out)
  BC1                  : 400 kbits/sec (reserved: 0% in, 0% out)
  MPLS-TE Link State   : MPLS-TE on, RSVP on, admin-up, flooded
  Inbound Admission    : allow-all
  Outbound Admission   : allow-if-room
  IGP Neighbor Count   : 2
  BW Descriptors       : 1 (including 0 BC1 descriptors)
  Admin Weight         : 1 (OSPF), 10 (ISIS)
Up Thresholds         : 15 30 45 60 75 80 85 90 95 96 97 98 99 100 (default)
Down Thresholds       : 100 99 98 97 96 95 90 85 80 75 60 45 30 15 (default)
```

Bandwidth Information::

Downstream BC0 (kbits/sec):

KEEP	PRIORITY	BW HELD	BW TOTAL HELD	BW LOCKED	BW TOTAL LOCKED
0		0	0	0	0
1		0	0	0	0
2		0	0	0	0
3		0	0	0	0
4		0	0	0	0
5		0	0	0	0
6		0	0	0	0
7		0	0	10	10

Downstream BC1 (kbits/sec):

KEEP	PRIORITY	BW HELD	BW TOTAL HELD	BW LOCKED	BW TOTAL LOCKED
0		0	0	0	0
1		0	0	0	0
2		0	0	0	0
3		0	0	0	0
4		0	0	0	0
5		0	0	0	0
6		0	0	0	0

This table describes the significant fields shown in the display.

Table 38: show mpls traffic-eng link-management bandwidth-allocation Command Field Descriptions

Field	Description
Links Count	Number of links configured for MPLS-TE.
Bandwidth Hold Time	Time, in seconds, that bandwidth can be held.

Field	Description
Link ID	Interface name and IP address of the link.
Link Label type	Label type of the link, for example: • PSC²² • TDM²³ • FSC²⁴
Physical BW	Link bandwidth capacity (in bits per second).
BCID	Bandwidth constraint model ID (RDM or MAM).
Max Reservable BW	Maximum reservable bandwidth on this link.
BC0	Maximum RSVP bandwidth in BC0.
BC1	Maximum RSVP bandwidth in BC1.
BW Descriptors	Number of bandwidth allocations on this link.
MPLS-TE Link State	Status of the link MPLS-TE-related functions.
Inbound Admission	Link admission policy for incoming tunnels.
Outbound Admission	Link admission policy for outgoing tunnels.
IGP Neighbor Count	IGP neighbors directly reachable over this link.
BW Descriptors	Internal bandwidth descriptors created when tunnels are admitted.
Admin Weight	Administrative weight associated with this link.
Up Thresholds	Threshold values used to determine link advertisement when available bandwidth increases.
Down Thresholds	Threshold values used to determine link advertisement when available bandwidth decreases.

²² PSC = Packet switch capable.

²³ TDM = Time-division multiplexing.

²⁴ FSC = Fiber switch capable.

show mpls traffic-eng link-management bfd-neighbors

To display TE-enabled Bidirectional Forwarding Detection (BFD) neighbors, use the **show mpls traffic-eng link-management bfd-neighbors** command in EXEC mode.

show mpls traffic-eng link-management bfd-neighbors [*interface type interface-path-id*]

Syntax Description

interface	(Optional) Displays information about the specified interface.
<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.8.0	The interface keyword was added.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	read

Examples

The following shows a sample output from the **show mpls traffic-eng link-management bfd-neighbors** command:

```
RP/0/0/CPU0:router# show mpls traffic-eng link-management bfd-neighbors
```

```
Link ID:: POS0/6/0/0  
BFD Neighbor Address: 7.3.3.1, State: Up  
Link ID:: POS0/6/0/1  
No BFD Neighbor  
Link ID:: POS0/6/0/2  
BFD Neighbor Address: 7.4.4.1, State: Down
```

This table describes the significant fields shown in the display.

Table 39: show mpls traffic-eng link-management bfd Command Field Descriptions

Field	Description
Link ID	Link by which the neighbor is reached.
BFD Neighbor Address	Neighbor address and Up/Down state.

Related Commands

Command	Description
bfd fast-detect (MPLS-TE)	Enables BFD for communication failure detection.
bfd minimum-interval (MPLS-TE)	Sets the BFD interval.
bfd multiplier (MPLS-TE)	Sets the BFD multiplier.

show mpls traffic-eng link-management igp-neighbors

To display Interior Gateway Protocol (IGP) neighbors, use the **show mpls traffic-eng link-management igp-neighbors** command in EXEC mode.

show mpls traffic-eng link-management igp-neighbors [**igp-id** {**isis** *isis-address*| **ospf** *ospf-id*} [**interface** *type interface-path-id*| *IP-address*]]

Syntax Description

igp-id	(Optional) Displays the IGP neighbors that are using a specified IGP identification.
isis <i>isis-address</i>	Displays the specified Intermediate System-to-Intermediate System (IS-IS) neighbor system ID when neighbors are displayed by IGP ID.
ospf <i>ospf-id</i>	Displays the specified Open Shortest Path first (OSPF) neighbor OSPF router ID when neighbors are displayed by IGP ID.
interface	(Optional) Displays information on the specified interface.
<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
<i>IP-address</i>	(Optional) IGP neighbors that are using a specified IGP IP address.

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	read

Examples

The following shows a sample output from the **show mpls traffic-eng link-management igp-neighbors** command:

```
RP/0/0/CPU0:router# show mpls traffic-eng link igp-neighbors
Link ID: POS0/7/0/0
  No Neighbors
Link ID: POS0/7/0/1
  Neighbor ID: 10.90.90.90 (area: ospf   area 0, IP: 10.15.12.2)
```

This table describes the significant fields shown in the display.

Table 40: show mpls traffic-eng link-management igp-neighbors Command Field Descriptions

Field	Description
Link ID	Link by which the neighbor is reached.
Neighbor ID	IGP identification information for the neighbor.

show mpls traffic-eng link-management interfaces

To display interface resources, or a summary of link management information, use the **show mpls traffic-eng link-management interfaces** command in EXEC mode.

show mpls traffic-eng link-management interfaces [*type interface-path-id*]

Syntax Description

<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was supported.
Release 3.4.1	No more than 100 links can be configured under MPLS-TE/fast reroute (FRR).
Release 3.8.0	This command was modified to include information specific to Multiprotocol Label Switching (MPLS) Shared Risk Link Groups (SRLG).
Release 3.9.0	The following modifications are included: • Sample output was modified to add the Attribute Names field. • More than 250 links can be configured under MPLS-TE.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

You cannot configure more than 250 links under MPLS-TE.

SRLG values can be configured for the link.

Task ID

Task ID	Operations
mpls-te	read

Examples

The following sample output is from the **show mpls traffic-eng link-management interfaces** command:

```
RP/0/0/CPU0:router# show mpls traffic-eng link-management interfaces GigabitEthernet0/2/0/1
```

```
System Information::
  Links Count          : 7 (Maximum Links Supported 250)

Link ID:: GigabitEthernet0/2/0/1 (12.9.0.1)
  Local Intf ID: 28
  Link Status:

    Link Label Type      : PSC
    Physical BW          : 1000000 kbits/sec
    BCID                 : RDM
    Max Reservable BW    : 10000 kbits/sec (reserved: 2% in, 2% out)
    BC0 (Res. Global BW) : 10000 kbits/sec (reserved: 2% in, 2% out)
    BC1 (Res. Sub BW)    : 0 kbits/sec (reserved: 100% in, 100% out)
    MPLS TE Link State   : MPLS TE on, RSVP on, admin-up
    Inbound Admission    : reject-huge
    Outbound Admission   : allow-if-room
    IGP Neighbor Count   : 1
    Max Res BW (RDM)     : 10000 kbits/sec
    BC0 (RDM)            : 10000 kbits/sec
    BC1 (RDM)            : 0 kbits/sec
    Max Res BW (MAM)     : 0 kbits/sec
    BC0 (MAM)            : 0 kbits/sec
    BC1 (MAM)            : 0 kbits/sec
    Attributes           : 0x4
    Attribute Names      : red2
    Flooding Status: (1 area)
      IGP Area[1]: OSPF 100 area 0, flooded
      Nbr: ID 12.9.0.2, IP 0.0.0.0 (Up)
      Admin weight: not set (TE), 1 (IGP)
```

This table describes the significant fields shown in the display.

Table 41: show mpls traffic-eng link-management interfaces Command Field Descriptions

Field	Description
Links Count	Number of links configured for MPLS-TE. Maximum number of links supported is 100.
Link ID	Link identification index.
Link Label Type	Label type assigned to the link.
Physical Bandwidth	Link bandwidth capacity (in kilobits per second).
BCID	Bandwidth constraint model ID (RDM or MAM).

Field	Description
Max Reservable BW	Maximum reservable bandwidth on this link.
BC0	Reservable bandwidth (in kbps) on this link in BC0.
BC1	Reservable bandwidth (in kbps) on this link in BC1.
Attributes	TE link attribute in hexadecimal.
Attribute Names	Name of the affinity attribute of a link.
SRLGs ²⁵ .	Links that share a common fiber or a common physical attribute. If one link fails, other links in the group may also fail. Links in the group have a shared risk.
MPLS-TE Link State	Status of the MPLS link.
Inbound Admission	Link admission policy for inbound tunnels.
Outbound Admission	Link admission policy for outbound tunnels.
IGP Neighbor Count	IGP ²⁶ neighbors directly reachable over this link.
Admin. Weight	Administrative weight associated with this link.
Flooding Status	Status for each configured area or Flooding status for the configured area.
IGP Area	IGP type and area and level used for TE flooding.

²⁵ SRLGs = Shared Risk Link Groups.

²⁶ IGP = Interior Gateway Protocol .

show mpls traffic-eng link-management statistics

To display interface resources or a summary of link management information, use the **show mpls traffic-eng link-management statistics** command in EXEC mode.

show mpls traffic-eng link-management statistics [**summary** | **interface** *type interface-path-id*]

Syntax Description

summary	(Optional) Displays the statistics summary.
interface	(Optional) Displays the interface for which information is requested.
<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show mpls traffic-eng link-management statistics** command displays resource and configuration information for all configured interfaces.

Task ID

Task ID	Operations
mpls-te	read

Examples

The following shows a sample output from the **show mpls traffic-eng link-management statistics** command using the **summary** keyword:

```
RP/0/0/CPU0:router# show mpls traffic-eng link-management statistics summary
```

LSP Admission Statistics:

	Setup Requests	Setup Admits	Setup Rejects	Setup Errors	Tear Requests	Tear Preempts	Tear Errors
Path	13	12	1	0	10	0	0
Resv	8	8	0	0	5	0	0

[Table 42: show mpls traffic-eng link-management statistics summary Command Field Descriptions](#), on page 376 describes the significant fields shown in the display.

Table 42: show mpls traffic-eng link-management statistics summary Command Field Descriptions

Field	Description
Path	Path information.
Resv	Reservation information.
Setup Requests	Number of requests for a setup.
Setup Admits	Number of admitted setups.
Setup Rejects	Number of rejected setups.
Setup Errors	Number of setup errors.
Tear Requests	Number of tear requests.
Tear Preempts	Number of paths torn down due to preemption.
Tear Errors	Number of tear errors.

show mpls traffic-eng link-management summary

To display a summary of link management information, use the **show mpls traffic-eng link-management summary** command in EXEC mode.

show mpls traffic-eng link-management summary

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes EXEC

Command History	Release	Modification
	Release 3.2	This command was supported.
	Release 3.4.1	No more than 100 links can be configured for MPLS-TE fast reroute (FRR).
	Release 3.9.0	No more than 250 links can be configured under MPLS-TE.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

You cannot configure more than 250 links for MPLS-TE/FRR.

Task ID	Task ID	Operations
	mpls-te	read

Examples The following sample output is from the **show mpls traffic-eng link-management summary** command:

```
RP/0/0/CPU0:router# show mpls traffic-eng link-management summary

System Information::
  Links Count           : 6 (Maximum Links Supported 100)
  Flooding System       : enabled
  IGP Areas Count       : 2

IGP Areas
-----
```

show mpls traffic-eng link-management summary

```

IGP Area[1]:: isis    level-2
  Flooding Protocol   : ISIS
  Flooding Status     : flooded
  Periodic Flooding   : enabled (every 180 seconds)
  Flooded Links       : 4
  IGP System ID       : 0000.0000.0002.00
  MPLS-TE Router ID   : 20.20.20.20
  IGP Neighbors       : 8

IGP Area[2]:: ospf    area 0
  Flooding Protocol   : OSPF
  Flooding Status     : flooded
  Periodic Flooding   : enabled (every 180 seconds)
  Flooded Links       : 4
  IGP System ID       : 20.20.20.20
  MPLS-TE Router ID   : 20.20.20.20
  IGP Neighbors       : 8

```

This table describes the significant fields shown in the display.

Table 43: show mpls traffic-eng link-management summary Command Field Descriptions

Field	Description
Links Count	Number of links configured for MPLS-TE. Maximum number of links supported is 100.
Flooding System	Enable status of the MPLS-TE flooding system.
IGP Areas Count	Number of IGP ²⁷ areas described.
IGP Area	IGP type and area and level used for TE flooding.
Flooding Protocol	IGP flooding information for this area.
Flooding Status	Status of flooding for this area.
Periodic Flooding	Status of periodic flooding for this area.
Flooded Links	Links that were flooded.
IGP System ID	IGP for the node associated with this area.
MPLS-TE Router ID	MPLS-TE router ID for this node.
IGP Neighbors	Number of reachable IGP neighbors associated with this area.

²⁷ IGP = Interior Gateway Protocol.

show mpls traffic-eng lmp

To display operation details about the status of the Link Management Protocol (LMP) instance and neighbor, IPCC, and MPLS-TE links, use the **show mpls traffic-eng lmp** command in EXEC mode.

show mpls traffic-eng lmp [*interface type interface-path-id*] **ipcc** | **neighbor** [*name*] | **statistics**]

Syntax Description

interface	(Optional) Displays information on the specified interface.
<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface. Note Use the show interfaces command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
ipcc	(Optional) Displays information for LMP Internet Protocol Control Channel (IPCC).
neighbor [<i>name</i>]	(Optional) Displays information for the LMP neighbor.
statistics	(Optional) Displays information for the statistics.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.8.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note

The LMP and GMPLS-NNI features are not supported on x86 RPs.

Task ID

Task ID	Operations
mpls-te	read

Examples

The following sample output shows summary information for the local LMP protocol. One remote LMP neighbor named gmpls4 with the node ID 44.44.44.44. The neighbor has one MPLS-TE link (GigabitEthernet0/5/0/1) that has a local MPLS-TE link ID of 10.5.1.4, and data link ID of 21. The data link LMP state is "Up Allocated", which means that the LMP state is up and is being used by the GMPLS protocol as part of an optical tunnel.

```
RP/0/0/CPU0:router# show mpls traffic-eng lmp
```

```
MPLS TE LMP Node ID: 11.11.11.11
```

```
LMP Neighbor
Name: gmpls4, IP: 44.44.44.44, Owner: MPLS TE
LMP: Enabled
LMP Hellos: Enabled by configuration
IPCC ID: 1, State Up
LMP UDP port: 701
  Known via      : Configuration
  Type           : Routed
  Destination IP  : 44.44.44.44
  Source IP      : 11.11.11.11
```

```

      Data Link I/F      | Lcl Data Link ID | Lcl TE Link ID | Data Link LMP state
-----+-----+-----+-----
GigabitEthernet0/5/0/1 |                21 |        10.5.1.4 | Up Allocated

```

The following sample output shows that one routed IPCC to LMP neighbor, gmpls4, is in the up state and has ID of 1:

```
RP/0/0/CPU0:router# show mpls traffic-eng lmp ipcc
```

```

IPCC      |      | Neighbor
ID | Type | IP | Status | Name
-----+-----+-----+-----+-----
1   | Routed | 44.44.44.44 | Up | gmpls4

```

The following sample output shows the IPCC and MPLS-TE link information for all the configured LMP neighbors:

```
RP/0/0/CPU0:router# show mpls traffic-eng lmp neighbor
```

```
LMP Neighbor
Name: gmpls4, IP: 44.44.44.44, Owner: MPLS TE
LMP: Enabled
LMP Hellos: Enabled by configuration
IPCC ID: 1, State Up
LMP UDP port: 701
  Known via      : Configuration
  Type           : Routed
  Destination IP  : 44.44.44.44
  Source IP      : 11.11.11.11
```

```

      Data Link I/F      | Lcl Data Link ID | Lcl TE Link ID | Data Link LMP state
-----+-----+-----+-----
GigabitEthernet0/5/0/1 |                21 |        10.5.1.4 | Up Allocated

```


The following sample output shows IPCC and MPLS-TE link information for a specified LMP neighbor, gmpls4:

```
RP/0/0/CPU0:router# show mpls traffic-eng lmp neighbor gmpls4
```

```
LMP Neighbor
Name: gmpls4, IP: 44.44.44.44, Owner: MPLS TE
LMP: Enabled
LMP Hellos: Enabled by configuration
IPCC ID: 1, State Up
LMP UDP port: 701
  Known via      : Configuration
  Type           : Routed
  Destination IP  : 44.44.44.44
  Source IP       : 11.11.11.11

-----+-----+-----+-----
Data Link I/F | Lcl Data Link ID | Lcl TE Link ID | Data Link LMP state
-----+-----+-----+-----
GigabitEthernet0/5/0/1 | 21 | 10.5.1.4 | Up Allocated
```

The following sample output shows detailed information for MPLS-TE, data link, and IPCC properties for a specified local interface that is configured as an LMP MPLS-TE link:

```
RP/0/0/CPU0:router# show mpls traffic-eng lmp interface gigabitEthernet 0/5/0/1
```

```
Interface: GigabitEthernet0/5/0/1
  Owner: MPLS TE
  LMP for TE Link: Enabled
  LMP Link Summary Last Error(s): None
  Local data link ID type: Unnumbered
  Local data link ID: Dec = 21, Hex = 0x15
  Local TE link ID type: IPv4
  Local TE link ID: 10.5.1.4
  Local TE link switching capability: Packet-Switch Capable-1 (PSC-1)
  Remote neighbor name: gmpls4
  Remote neighbor node ID: 44.44.44.44
  Remote TE link ID type: IPv4
  Remote TE link ID: 10.5.1.1
  Remote data link ID type: Unnumbered
  Remote data link ID: Dec = 13, Hex = 0xd
  Remote TE link switching capability: Packet-Switch Capable-1 (PSC-1)
  Data link I/F state: Up
  Data link LMP state: Up/Allocated
  TE link LMP state: Up
  Data link allocation status: Allocated
  IPCC ID: 1
  IPCC type: Routed
  IPCC destination IP address: 44.44.44.44
  Local Min Reservable Bandwidth: 125000000 bytes/sec
  Local Max Reservable Bandwidth: 125000000 bytes/sec
  Nbr Min Reservable Bandwidth: 125000000 bytes/sec
  Nbr Max Reservable Bandwidth: 125000000 bytes/sec
  Local Link Encoding Type: Ethernet
  Nbr Link Encoding Type: Ethernet
  VRF ID: Default [0x60000000] (Supported)
```

The following sample output shows detailed LMP protocol signaling statistics per neighbor and for all MPLS-TE links if LMP is running in nonstatic mode:

```
RP/0/0/CPU0:router# show mpls traffic-eng lmp statistics
```

```
LMP Neighbor
Name: gmpls4, IP: 44.44.44.44, Owner: MPLS TE
Transmit Msg Id: 33
Receive Msg Id: 33
Link Summ msgs Transmitted: 32
Link Summ msgs Received: 33
```

show mpls traffic-eng lmp

```

IPCC ID: 1, State Up
Hello Interval: 2000 (msec)
Minimum Acceptable Hello Interval: 100 (msec)
Maximum Acceptable Hello Interval: 21845 (msec)
Hello Dead Interval: 6000 (msec)
Minimum Acceptable Hello Dead Interval: 300 (msec)
Maximum Acceptable Hello Dead Interval: 65535 (msec)
No. of packets transmitted: 380
No. of packets Received: 377
Tx Seq No.: 374
Rx Seq No.: 374
Transmit Msg Id: 1
Receive Msg Id: 1
Link Summ msgs Transmitted: 32
Link Summ msgs Received: 33

```

```

      Data Link I/F      | Lcl Data Link ID | Lcl TE Link ID | Rcvd_Msg_Id Xmt_Msg_Id
-----+-----+-----+-----+-----
GigabitEthernet0/5/0/1 |          21      |      10.5.1.4   |          33      33

```

Related Commands

Command	Description
ipcc interface (MPLS-TE), on page 244	Configures an IPCC.
lmp neighbor (MPLS-TE), on page 257	Configure or updates a LMP neighbor and its associated parameters and enters MPLS-TE neighbor configuration mode.

show mpls traffic-eng maximum tunnels

To display the maximum number of MPLS-TE tunnels that you can configure, use the **show mpls traffic-eng maximum tunnels** command in EXEC mode.

show mpls traffic-eng maximum tunnels

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 3.2	This command was supported.
	Release 3.8.0	Sample output was modified.
	Release 3.9.0	Sample output was modified to support the Point-to-Multipoint (P2MP) feature.
	Release 4.0.0	Sample output was modified to support the maximum number of allowed automatic backup tunnels.
	Release 4.1.1	Sample output was modified to support the maximum number of allowed automatic mesh tunnels.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	mpls-te	read

Examples This is sample output from the **show mpls traffic-eng maximum tunnels** command:

```
RP/0/0/CPU0:router# show mpls traffic-eng maximum tunnels
Maximum Global Tunnel Count:
```

show mpls traffic-eng maximum tunnels

Maximum	Current Count
-----	-----
4096	2

Maximum P2MP Tunnel Count:

Maximum	Current Count
-----	-----
500	

Maximum Global Destination Count:

Maximum	Current Count
-----	-----
4096	2

Maximum AutoTunnel Backup Count:

Maximum	Current Count
-----	-----
200	122

This is sample output of the automatic mesh tunnels from the **show mpls traffic-eng maximum tunnels** command:

RP/0/0/CPU0:router# **show mpls traffic-eng maximum tunnels**

Maximum Global Tunnel Count:

Maximum	Current Count
-----	-----
4096	12

Maximum Static Tunnel Count:

Maximum	Current Count
-----	-----
4096	8

Maximum Auto-tunnel Mesh Count:

Maximum	Current Count
-----	-----
201	3

Maximum P2MP Tunnel Count:

Maximum	Current Count
-----	-----
500	1

Maximum Global Destination Count:

Maximum	Current Count
-----	-----
4096	13

Maximum GMPLS-UNI Tunnel Count:

Maximum	Current Count
-----	-----
500	39

Table 44: [show mpls traffic-eng maximum tunnels Command Field Descriptions](#), on page 385 describes the significant fields shown in the display.

Table 44: show mpls traffic-eng maximum tunnels Command Field Descriptions

Field	Description
Maximum Global Tunnel Count	Maximum number of tunnel interfaces (all TE tunnel types, tunnel-te, tunnel-mte, and tunnel-gte) that can be configured.
Maximum P2MP Tunnel Count	Maximum number of P2MP tunnels that can be configured.
Maximum Global Destination Count	Maximum number of tunnel destinations that can be configured.
Maximum	Table heading for the maximum number in each category.
Current Count	Table heading for the current count in each category.
Maximum AutoTunnel Backup Count	Maximum number of automatic backup tunnels that can be configured.
Maximum GMPLS UNI Tunnel Count	Maximum number of Generalized Multiprotocol Label Switching (GMPLS) User-Network Interface (UNI) tunnels that can be configured and the current tunnel count.
Maximum AutoTunnel Mesh Count	Maximum number of automatic mesh tunnels that can be configured.

Related Commands

Command	Description
maxabs (MPLS-TE) , on page 263	Specifies the maximum number of tunnel TE interfaces that can be configured.
tunnel-id (auto-tunnel backup) , on page 451	Configures the range of tunnel interface numbers used for automatic backup tunnels.

show mpls traffic-eng pce peer

To display the status of the path computation element (PCE) peer address and state, use the **show mpls traffic-eng pce peer** command in EXEC mode.

show mpls traffic-eng pce peer [*address* | **all**]

Syntax Description

<i>address</i>	(Optional) IPv4 peer address for the PCE.
all	(Optional) Displays all the peers for the PCE.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.8.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	read

Examples

The following sample output shows the status of both the PCE peer and state:

```
RP/0/0/CPU0:router# show mpls traffic-eng pce peer
```

```
PCE Address 202.202.88.8
State Up
  PCEP has been up for: 04:18:31
Learned through:
  OSPF 1
Sending KA every 30 s
Time out peer if no KA received for 120 s
Tolerance: Minimum KA 10 s
KA messages rxed 518 txed 517
PCEReq messages rxed 0, txed 0
PCERep messages rxed 0, txed 0
```

```

PCEErr messages rxed 0, txed 0
  Last error received: None
  Last error sent: None
PCE OPEN messages: rxed 1, txed 2
PCEP session ID: local 0, remote 0

Average reply time from peer: 0 ms
Minimum reply time from peer: 0 ms
Maximum reply time from peer: 0 ms
0 requests timed out with this peer
Transmit TCP buffer: Current 0, Maximum 12
Receive TCP buffer: Current 0, Maximum 12

```

This table describes the significant fields shown in the display.

Table 45: show mpls traffic-eng pce peer Field Descriptions

Field	Description
KA	PCEP keepalive.
Learned through	Learned through is how the peer was learned which is either through a static configuration or an IGP.
Average reply time from peer	Average reply time for the peer to respond to PCEReq request messages with PCERep response messages.
Minimum reply time from peer	Minimum reply time for the peer to respond to PCEReq request messages with PCERep response messages.
Maximum reply time from peer	Maximum reply for the peer to respond to PCEReq request messages with PCERep response messages.
Transmit TCP buffer Receive TCP Buffer	Number of messages that are in the TCP buffer with the peer waiting to be sent or processed locally.
0 requests timed out with this peer	Number of PCEReq messages that timed out waiting for a response from this peer.

Related Commands

Command	Description
clear mpls traffic-eng pce , on page 198	Clears the PCE statistics.
pce address (MPLS-TE) , on page 303	Configures the IPv4 self address for a PCE.
pce peer (MPLS-TE) , on page 309	Configures an IPv4 self address for a PCE peer.

show mpls traffic-eng pce tunnels

To display the status of the path computation element (PCE) tunnels, use the **show mpls traffic-eng pce tunnels** command in EXEC mode.

show mpls traffic-eng pce tunnels [*tunnel-id*]

Syntax Description

<i>tunnel-id</i>	(Optional) Tunnel identifier. The range is 0 to 4294967295.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.8.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	read

Examples

The following sample output shows the status of the PCE tunnels:

```
RP/0/0/CPU0:router# show mpls traffic-eng pce tunnels
```

```
Tunnel : tunnel-te10
  Destination : 205.205.10.10
  State : down, PCE failed to find path

Tunnel : tunnel-te30
  Destination : 3.3.3.3
  State : up
  Current path option: 10, path obtained from dynamically learned PCE 1.2.3.4
  Admin weight : 15
  Hop Count : 3
```

This table describes the significant fields shown in the display.

Table 46: show mpls traffic-eng pce tunnels Command Field Descriptions

Field	Description
Tunnel	Tunnel number for the MPLS-TE tunnel interface.
Destination	IP address of the destination of the tunnel.
State	State of the tunnel. Values are up, down, or admin-down.
Admin weight	Administrative weight (cost) of the link.

Related Commands

Command	Description
pce address (MPLS-TE), on page 303	Configures the IPv4 self address for a PCE.

show mpls traffic-eng preemption log

To display the log of preemption events, use the **show mpls traffic-eng preemption log** command in EXEC mode.

show mpls traffic-eng preemption log

Syntax Description	log	Displays a log of preemption events.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 4.2.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	mpls-te	read

Examples This is sample output from the **show mpls traffic-eng preemption log** command displaying the log of preemption events:

```
RP/0/0/CPU0:router# show mpls traffic-eng preemption log
Bandwidth Change on GigabitEthernet0/0/0/0
Old BW (BC0/BC1): 200000/100000, New BW (BC0/BC1): 1000/500 kbps
BW Overshoot (BC0/BC1): 1000/0 kbps
Preempted BW (BC0/BC1): 35000/0 kbps; Soft 30000/0 kbps; Hard 5000/0 kbps;
Preempted 2 tunnels; Soft 1 tunnel; Hard 1 tunnel
```

TunID	LSP ID	Source	Destination	Preempt Type	Pri S/H	Bandwidth (in kbps)	BW Type
1	10002	192.168.0.1	1.0.0.0	Hard	7/7	5000	BC0
1	2	192.168.0.1	192.168.0.4	Soft	7/7	30000	BC0

show mpls traffic-eng topology

To display the current MPLS-TE network topology for the node, use the **show mpls traffic-eng topology** command in EXEC mode.

show mpls traffic-eng topology [*IP-address*] [**affinity**] [**brief**] [**link-only**] [**bandwidth** *number*] **exclude-srlg** *exclude-srlg-interface-address* | **explicit-path** { **identifier** *explicit-path-id-number* | **name** *explicit-path-name* } | **priority** *level*] [**isis** *nsap-address* | **ospf** *ospf-address*] [**path** { **destination** *IP-address* | **tunnel** *P2P-tunnel-number* }] [{ **router** | **network** }] [**model-type** { **rdm** | **mam** }]

Syntax Description

<i>IP-address</i>	(Optional) Node IP address (router identifier to interface address).
destination <i>IP-address</i>	Displays the LSP destination IPv4 address.
exclude-srlg	Specifies an IP address to get SRLG values from for exclusion.
explicit-path	Displays the explicit LSP path.
tunnel	Displays the topology path that is based on the Point-to-Point (P2P) tunnel number.
<i>P2P -tunnel-number</i>	P2P tunnel number. Range is 0 to 65535.
affinity	(Optional) Displays the attribute values that are required for links carrying this tunnel. A 32-bit decimal number. Range is 0x0 to 0xFFFFFFFF, representing 32 attributes (bits), where the value of an attribute is 0 or 1.
bandwidth <i>number</i>	(Optional) Displays the bandwidth value that is required by this label switched path (LSP).
priority <i>level</i>	(Optional) Displays the priority used when signaling a LSP for this tunnel, to determine which existing tunnels can be preempted.
isis <i>nsap-address</i>	(Optional) Displays the node router identification, if Intermediate System-to-Intermediate System (IS-IS) is enabled.

ospf <i>ospf-address</i>	(Optional) Displays the node router identifier, if Open Shortest Path First (OSPF) is enabled.
path	(Optional) Displays the path to a destination from this router.
router	Displays the given OSPF address type of the router node.
network	Displays the given OSPF address type of the network node.
brief	(Optional) Displays the brief form of the output that provides a less detailed version of the topology.
link-only	(Optional) Displays the MPLS-TE topology that is filtered by the given neighbor address.
model-type { rdm mam }	(Optional) Displays the bandwidth constraints model type, RDM or MAM.

Command Default No default behavior or values

Command Modes EXEC

Command History	Release	Modification
	Release 3.2	This command was supported.
	Release 3.8.0	This command was modified to include information specific to MPLS Shared Risk Link Groups (SRLG).
	Release 3.9.0	These enhancements are listed:
		• The tunnel keyword and <i>P2P tunnel-number</i> argument were added. • The destination keyword and <i>IP-address</i> argument were added. • The link-only keyword was added. • The affinity keyword was modified. • Sample output was modified to display the Attribute Names field.

Release	Modification
Release 4.0.0	These enhancements are listed: • The exclude-srlg keyword and <i>exclude-srlg-interface-address</i> argument were added. • explicit-path keyword and <i>explicit-path-id-number</i> argument were added. • Sample output was added to support the additional keywords and arguments. • Sample output was added to show the SRLG interfaces.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following shows a sample output from the **show mpls traffic-eng topology** command specifying the tunnel number in brief form:

```
RP/0/0/CPU0:router# show mpls traffic-eng topology path tunnel 160

Tunnell60 Path Setup to 10.10.10.10: FULL_PATH
bw 100 (CT0), min_bw 0, metric: 10
setup_pri 7, hold_pri 7
affinity_bits 0x0, affinity_mask 0xfffff
Hop0:10.2.2.1
Hop1:10.10.10.10
```

The following shows a sample output from the **show mpls traffic-eng topology** command specifying the destination IP address:

```
RP/0/0/CPU0:router# show mpls traffic-eng topology path destination 10.10.10.10

Path Setup to 10.10.10.10:
bw 0 (CT0), min_bw 999900, metric: 10
setup_pri 7, hold_pri 7
affinity_bits 0x0, affinity_mask 0xfffffffff
Hop0:10.2.2.1
Hop1:10.10.10.10
```

The following sample output shows the MPLS-TE network topology with the name of the affinity attribute of the link:

```
RP/0/0/CPU0:router# show mpls traffic-eng topology

Link[1]:Point-to-Point, Nbr IGP Id:3.3.3.3, Nbr Node Id:9, gen:23
Frag Id:25, Intf Address:13.9.1.1, Intf Id:0
Nbr Intf Address:13.9.1.3, Nbr Intf Id:0
```

show mpls traffic-eng topology

```

TE Metric:1, IGP Metric:1, Attribute Flags:0x0
Attribute Names:
Switching Capability:, Encoding:
BC Model ID:RDM
Physical BW:155520 (kbps), Max Reservable BW Global:116640 (kbps)
Max Reservable BW Sub:0 (kbps)

```

	Total Allocated BW (kbps)	Global Pool Reservable BW (kbps)	Sub Pool Reservable BW (kbps)
	-----	-----	-----
bw[0]:	0	116640	0
bw[1]:	0	116640	0
bw[2]:	0	116640	0
bw[3]:	0	116640	0
bw[4]:	0	116640	0
bw[5]:	0	116640	0
bw[6]:	0	116640	0
bw[7]:	0	116640	0

```

Link[2]:Broadcast, DR:12.9.0.2, Nbr Node Id:1, gen:23
Frag Id:28, Intf Address:12.9.0.1, Intf Id:0
Nbr Intf Address:0.0.0.0, Nbr Intf Id:0
TE Metric:1, IGP Metric:1, Attribute Flags:0x4
Attribute Names: red2
Switching Capability:, Encoding:
BC Model ID:RDM
Physical BW:1000000 (kbps), Max Reservable BW Global:10000 (kbps)
Max Reservable BW Sub:0 (kbps)

```

	Total Allocated BW (kbps)	Global Pool Reservable BW (kbps)	Sub Pool Reservable BW (kbps)
	-----	-----	-----
bw[0]:	0	10000	0
bw[1]:	0	10000	0
bw[2]:	0	10000	0
bw[3]:	0	10000	0
bw[4]:	0	10000	0
bw[5]:	0	10000	0
bw[6]:	0	10000	0
bw[7]:	0	10000	0

The following shows a sample output from the **show mpls traffic-eng topology** command in detail form in prestandard DS-TE mode:

```
RP/0/0/CPU0:router# show mpls traffic-eng topology
```

```

My_System_id: 0000.0000.0002.00 (isis level-2)
My_System_id: 20.20.20.20 (ospf area 0)
My_BC_Model_Type: RDM

```

```
Signalling error holddown: 10 sec Global Link Generation 36
```

```
IGP Id: 0000.0000.0002.00, MPLS-TE Id: 20.20.20.20 Router Node (isis level-2)
```

```
Link[0]:Point-to-Point, Nbr IGP Id:0000.0000.0003.00, Nbr Node Id:3, gen:36
```

```

Frag Id:0, Intf Address:7.3.3.1, Intf Id:0
Nbr Intf Address:7.3.3.2, Nbr Intf Id:0
TE Metric:10, IGP Metric:10, Attribute Flags:0x0
SRLGs: 10, 20
Switching Capability:, Encoding:

```

```
BC Model ID:RDM
```

```
Physical BW:155520 (kbps), Max Reservable BW Global:100000 (kbps)
```

```
Max Reservable BW Sub:50000 (kbps)
```

	Total Allocated BW (kbps)	Global Pool Reservable BW (kbps)	Sub Pool Reservable BW (kbps)
	-----	-----	-----
bw[0]:	0	100000	50000
bw[1]:	0	100000	50000
bw[2]:	0	100000	50000
bw[3]:	0	100000	50000

```

bw[4]:          0          100000          50000
bw[5]:          0          100000          50000
bw[6]:          0          100000          50000
bw[7]:          0          100000          50000

```

The following shows a sample output from the **show mpls traffic-eng topology** command in detail form in IETF DS-TE mode.

```
RP/0/0/CPU0:router# show mpls traffic-eng topology
```

```

My_System_id: 0000.0000.0001.00 (isis 1 level-2)
My_System_id: 10.10.10.10 (ospf 100 area 0)
My_BC_Model_Type: MAM

Signalling error holddown: 10 sec Global Link Generation 84

IGP Id: 0000.0000.0001.00, MPLS-TE Id: 10.10.10.10 Router Node (isis 1 level-2)

Link[0]:Point-to-Point, Nbr IGP Id:0000.0000.0002.00, Nbr Node Id:6, gen:84
  Frag Id:0, Intf Address:7.2.2.1, Intf Id:0
  Nbr Intf Address:7.2.2.2, Nbr Intf Id:0
  TE Metric:10, IGP Metric:10, Attribute Flags:0x0
  SRLGs: 10, 20
  Switching Capability:, Encoding:
BC Model ID:MAM
  Physical BW:155520 (kbps), Max Reservable BW:1000 (kbps)
  BC0:600 (kbps) BC1:400 (kbps)
    Total Allocated  Reservable
    BW (kbps)        BW (kbps)
    -----
  TE-class[0]:          10          590
  TE-class[1]:           0          400
  TE-class[2]:           0           0
  TE-class[3]:           0           0
  TE-class[4]:           0          600
  TE-class[5]:           0          400
Link[1]:Point-to-Point, Nbr IGP Id:0000.0000.0002.00, Nbr Node Id:6, gen:84
  Frag Id:0, Intf Address:7.1.1.1, Intf Id:0
  Nbr Intf Address:7.1.1.2, Nbr Intf Id:0
  TE Metric:10, IGP Metric:10, Attribute Flags:0x0
  SRLGs: 10, 20
  Switching Capability:, Encoding:
BC Model ID:MAM
  Physical BW:155520 (kbps), Max Reservable BW:1000 (kbps) BC0:600 (kbps) BC1:400
(kbps)
    Total Allocated  Reservable
    BW (kbps)        BW (kbps)
    -----
  TE-class[0]:          10          590
  TE-class[1]:           0          400
  TE-class[2]:           0           0
  TE-class[3]:           0           0
  TE-class[4]:           0          600
  TE-class[5]:           0          400
  TE-class[6]:           0           0
  TE-class[7]:           0           0

```

The following shows a sample output for the **show mpls traffic-eng topology** command in brief form:

```
RP/0/0/CPU0:router# show mpls traffic-eng topology 192.168.0.145 brief
```

```

IGP Id: 0000.0000.0010.00, MPLS TE Id: 192.168.0.145 Router Node (ISIS test level-1)
Link[0]:Point-to-Point, Nbr IGP Id:0000.0000.0234.00, Nbr Node Id:4, gen:5
  Frag Id:0, Intf Address:10.3.11.145, Intf Id:0
  Nbr Intf Address:10.3.11.143, Nbr Intf Id:0
  TE Metric:10, IGP Metric:10, Attribute Flags:0x0
  SRLGs: 10, 20
  Attribute Names: red2
  Switching Capability:, Encoding:
BC Model ID:RDM

```

Physical BW:155520 (kbps), Max Reservable BW Global:0 (kbps)
Max Reservable BW Sub:0 (kbps)

The following sample output shows a brief topology for the affinity attributes:

```
RP/0/0/CPU0:router# show mpls traffic-eng topology affinity

affinity
Mon Mar 23 13:25:47.236 EST EST
My_System_id: 1.1.1.1 (OSPF 100 area 0)
My_System_id: 0000.0000.0001.00 (IS-IS 100 level-2)
My_BC_Model_Type: RDM

Signalling error holddown: 10 sec Global Link Generation 233

IGP Id: 0000.0000.0001.00, MPLS TE Id: 11.11.1.1 Router Node (IS-IS 100 level-2)

IGP Id: 1.1.1.1, MPLS TE Id: 1.1.1.1 Router Node (OSPF 100 area 0)
  Link[0]:      Intf Address: 12.9.1.1, Nbr Intf Address: 12.9.1.2
              Attribute Flags: 0x0
              Attribute Names:
  Link[1]:      Intf Address: 13.9.1.1, Nbr Intf Address: 13.9.1.3
              Attribute Flags: 0x0
              Attribute Names:
  Link[2]:      Intf Address: 12.9.0.1, DR: 12.9.0.2
              Attribute Flags: 0x4
              Attribute Names: red2
  Link[3]:      Intf Address: 14.9.0.1, DR: 14.9.0.4
              Attribute Flags: 0x0
              Attribute Names:
  Link[4]:      Intf Address: 13.9.0.1, DR: 13.9.0.3
              Attribute Flags: 0x0
              Attribute Names:

IGP Id: 4.4.4.4, MPLS TE Id: 4.4.4.4 Router Node (OSPF 100 area 0)
  Link[0]:      Intf Address: 34.9.1.4, Nbr Intf Address: 34.9.1.3
              Attribute Flags: 0x0
              Attribute Names:
  Link[1]:      Intf Address: 14.9.0.4, DR: 14.9.0.4
              Attribute Flags: 0x1e
              Attribute Names: red1 red2 red3 red4
  Link[2]:      Intf Address: 24.9.0.4, DR: 24.9.0.4
              Attribute Flags: 0x0
              Attribute Names:
  Link[3]:      Intf Address: 34.9.0.4, DR: 34.9.0.3
              Attribute Flags: 0x0
              Attribute Names:
  Link[4]:      Intf Address: 24.9.1.4, Nbr Intf Address: 24.9.1.2
              Attribute Flags: 0x0
              Attribute Names:
```

The following sample output for the **show mpls traffic-eng topology** command that shows the output to a single link:

```
RP/0/0/CPU0:router# show mpls traffic-eng topology 12.9.1.1 link-only

Wed Sep 2 13:24:48.821 EST

IGP Id: 0000.0000.0002.00, MPLS TE Id: 2.2.2.2 Router Node (IS-IS 100 level-2)

Link[0]:Point-to-Point, Nbr IGP Id:0000.0000.0001.00, Nbr Node Id:-1, gen:277740
  Frag Id:0, Intf Address:12.9.1.2, Intf Id:0
  Nbr Intf Address:12.9.1.1, Nbr Intf Id:0
  TE Metric:10, IGP Metric:10, Attribute Flags:0x0
  Attribute Names:
  Switching Capability:, Encoding:
  BC Model ID:RDM
  Physical BW:155520 (kbps), Max Reservable BW Global:116640 (kbps)
  Max Reservable BW Sub:0 (kbps)
```


	Total Allocated BW (kbps)	Global Pool Reservable BW (kbps)	Sub Pool Reservable BW (kbps)
bw[0]:	0	116640	0
bw[1]:	0	116640	0
bw[2]:	0	116640	0
bw[3]:	0	116640	0
bw[4]:	0	116640	0
bw[5]:	0	116640	0
bw[6]:	0	116640	0
bw[7]:	0	116640	0

IGP Id: 2.2.2.2, MPLS TE Id: 2.2.2.2 Router Node (OSPF 100 area 0)

Link[3]:Point-to-Point, Nbr IGP Id:1.1.1.1, Nbr Node Id:-1, gen:277737
 Frag Id:29, Intf Address:12.9.1.2, Intf Id:0
 Nbr Intf Address:12.9.1.1, Nbr Intf Id:0
 TE Metric:1, IGP Metric:1, Attribute Flags:0x0
 Attribute Names:
 Switching Capability:, Encoding:
 BC Model ID:RDM
 Physical BW:155520 (kbps), Max Reservable BW Global:116640 (kbps)
 Max Reservable BW Sub:0 (kbps)

	Total Allocated BW (kbps)	Global Pool Reservable BW (kbps)	Sub Pool Reservable BW (kbps)
bw[0]:	0	116640	0
bw[1]:	0	116640	0
bw[2]:	0	116640	0
bw[3]:	0	116640	0
bw[4]:	0	116640	0
bw[5]:	0	116640	0
bw[6]:	0	116640	0
bw[7]:	0	116640	0

The following shows a sample output for the **show mpls traffic-eng topology model-type mam** command:

```
RP/0/0/CPU0:router# show mpls traffic-eng topology model-type mam

IGP Id: 0000.0000.0001.00, MPLS-TE Id: 10.10.10.10 Router Node (isis 1 level-2)
Link[0]:      Intf Address:7.2.2.1, Nbr Intf Address:7.2.2.2
Link[1]:      Intf Address:7.1.1.1, Nbr Intf Address:7.1.1.2

IGP Id: 0000.0000.0002.00, MPLS-TE Id: 20.20.20.20 Router Node (isis 1 level-2)
Link[0]:      Intf Address:7.2.2.2, Nbr Intf Address:7.2.2.1
Link[1]:      Intf Address:7.1.1.2, Nbr Intf Address:7.1.1.1
Link[2]:      Intf Address:7.3.3.1, Nbr Intf Address:7.3.3.2

IGP Id: 0000.0000.0003.00, MPLS-TE Id: 30.30.30.30 Router Node (isis 1 level-2)
Link[0]:      Intf Address:7.3.3.2, Nbr Intf Address:7.3.3.1
```

The following shows a sample output from the **show mpls traffic-eng topology** command specifying the topology for the SRLG interfaces:

```
RP/0/0/CPU0:router# show mpls traffic-eng topology srlg
```

```
Tue Oct 6 13:10:30.342 UTC
My_System_id: 0000.0000.0005.00 (IS-IS 1 level-2)
```

SRLG	Interface Addr	TE Router ID	IGP Area ID
1	51.1.2.1	100.0.0.1	IS-IS 1 level-2
2	51.1.2.1	100.0.0.1	IS-IS 1 level-2
3	51.1.2.1	100.0.0.1	IS-IS 1 level-2
4	51.1.2.1	100.0.0.1	IS-IS 1 level-2
5	51.1.2.1	100.0.0.1	IS-IS 1 level-2
6	51.1.2.1	100.0.0.1	IS-IS 1 level-2
7	51.1.2.1	100.0.0.1	IS-IS 1 level-2

show mpls traffic-eng topology

```

      8      51.1.2.1      100.0.0.1      IS-IS 1 level-2
     10      50.4.5.5      100.0.0.5      IS-IS 1 level-2
     30      50.4.5.5      100.0.0.5      IS-IS 1 level-2
     77      50.4.5.5      100.0.0.5      IS-IS 1 level-2
     88      50.4.5.5      100.0.0.5      IS-IS 1 level-2
    1500      50.4.5.5      100.0.0.5      IS-IS 1 level-2
10000000      50.4.5.5      100.0.0.5      IS-IS 1 level-2
4294967290      50.4.5.5      100.0.0.5      IS-IS 1 level-2
4294967295      50.4.5.5      100.0.0.5      IS-IS 1 level-2

```

The following shows a sample output from the **show mpls traffic-eng topology path destination** command specifying the topological path with SRLG exclusion:

```
RP/0/0/CPU0:router# show mpls traffic-eng topology path destination 100.0.0.2 exclude-srlg
50.4.5.5 isis 1 level 2
```

```

Tue Oct  6 13:13:44.053 UTC
Path Setup to 100.0.0.2:
bw 0 (CT0), min_bw 0, metric: 20
setup_pri 7, hold_pri 7
affinity_bits 0x0, affinity_mask 0xffff
Exclude SRLG Intf Addr : 50.4.5.5
SRLGs Excluded: 10, 30, 77, 88, 1500, 10000000
                  4294967290, 4294967295
Hop0:50.5.1.5
Hop1:50.5.1.1
Hop2:51.1.2.1
Hop3:51.1.2.2
Hop4:100.0.0.2

```

The following shows a sample output from the **show mpls traffic-eng topology path destination** command specifying the topological path based on a given explicit path:

```
RP/0/0/CPU0:router# show mpls traffic-eng topology path destination 100.0.0.2 explicit-path
name exclude-srlg isis 1 level 2
```

```

Tue Oct  6 13:16:44.233 UTC
Path Setup to 100.0.0.2:
bw 0 (CT0), min_bw 0, metric: 20
setup_pri 7, hold_pri 7
affinity_bits 0x0, affinity_mask 0xffff
SRLGs Excluded: 10, 30, 77, 88, 1500, 10000000
                  4294967290, 4294967295, 1, 2, 3, 4
                  5, 6, 7, 8
Hop0:50.5.1.5
Hop1:50.5.1.1
Hop2:50.1.2.1
Hop3:50.1.2.2
Hop4:100.0.0.2

```

This table describes the significant fields shown in the display.

Table 47: show mpls traffic-eng topology Field Descriptions

Field	Description
My_System_id	IGP ²⁸ system or IGP router ID.
Signalling error holddown	Link hold-down timer configured to handle path error events to exclude link from topology.
IGP Id	Identification of the advertising router.
Link	MPLS-TE link.

Field	Description
Frag Id	GP LSA ²⁹ fragment identifier.
Nbr Intf Address	Neighbor Interface address of this link.
TE Metric	TE cost of link.
SRLGs	SRLG ³⁰ values that are flooded by IGP to TE.
Switching Capability	Switching capability: packet, optical, lambda.
Physical BW	Physical line rate.
BC Model ID	Bandwidth constraint model ID (RDM or MAM).
Max Reservable BW	Maximum bandwidth (in kilobits per second) that you can reserve on a link.
Max Reservable BW Global	Maximum bandwidth (in kilobits per second) that you can reserve on a link in global-pool (prestandard and RDM).
Max Reservable BW Sub	Maximum bandwidth (in kilobits per second) that you can reserve on a link in subpool (prestandard and RDM).
BC0	Maximum bandwidth (in kilobits per second) that you can reserve on a link in BC0.
BC1	Maximum bandwidth (in kilobits per second) that you can reserve on a link in BC1.
TE-class[index]	Available bandwidth in TE-class (map of class-type and priority) at given index.
Total Allocated BW	Bandwidth (in Kbps) allocated at that priority.
Global Pool Reservable BW	Available bandwidth (in kbps) reservable at that priority in global pool (prestandard RDM).
Sub Pool Reservable BW	Available bandwidth (in kbps) reservable at that priority in sub-pool (prestandard RDM).
Attribute Names	Brief topology and the associated affinity attributes. The names of the affinity attribute of the link are displayed.

²⁸ IGP = Interior Gateway Protocol.

²⁹ LSA = link-state advertisement.

 show mpls traffic-eng topology

³⁰ SRLG = shared-risk link group.

Related Commands

Command	Description
show mpls traffic-eng tunnels , on page 401	Displays information about MPLS-TE tunnels.
interface (SRLG) , on page 238	Enables SRLG on an interface and enters SRLG interface configuration mode.
srlg , on page 437	Configures an MPLS traffic engineering SRLG values for a link on an interface.
show srlg , on page 429	Displays the SRLG interface and configuration information.

show mpls traffic-eng tunnels

To display information about MPLS-TE tunnels, use the **show mpls traffic-eng tunnels** command in EXEC mode.

```
show mpls traffic-eng tunnels [ tunnel-number ] [affinity] [all] [auto-bw] [auto-tunnel] [backup
[tunnel-number | auto-tunnel [mesh ] mesh-value] [ name tunnel-name]] [promotion-timer promotion-timer]
protected-interface type interface-path-id | {static| auto} ]] [brief] [destination destination-address] [detail]
[down] [gmpls] [interface {in | out | inout} type interface-path-id] [name tunnel-name] [p2p] [property {
backup-tunnel | fast-reroute}] [protection [unused]] [reoptimized within-last interval][role {all | head
| tail | middle}] [source source-address] [suboptimal constraints {current | max | none}] [summary]
[tabular] [unused][up] [class-type ct] [igp {isis | ospf}] [within-last interval]
```

Syntax Description

<i>tunnel-number</i>	(Optional) Number of the tunnel. Range is from 0 to 65535.
attribute-set	(Optional) Restricts the display of tunnels with an attribute set.
affinity	(Optional) Displays the affinity attributes for all outgoing links. The links, which are used by the tunnel, display color information.
all	(Optional) Displays all MPLS-TE tunnels.
auto-bw	(Optional) Restricts the display to tunnels when the automatic bandwidth is enabled.
auto-tunnel	(Optional) Restricts the display of automatically created tunnels.
mesh <i>mesh-value</i>	Displays the tunnels that belong to the specified auto-tunnel mesh group.
backup	(Optional) Displays FRR ³¹ backup tunnels information. The information includes the physical interface protected by the tunnel, the number of TE LSPs ³² protected, and the bandwidth protected. (Optional) Displays backup information for automatic tunnels and FRR tunnels.
name <i>tunnel-name</i>	(Optional) Displays the tunnel with given name.
promotion-timer <i>promotion-timer</i>	(Optional) Displays the configured FRR backup tunnel promotion timer value, in seconds.
protected-interface	(Optional) Displays FRR protected interfaces.

static	(Optional) Displays static backup tunnels.
auto-tunnel	(Optional) Displays protected automatic backup tunnels.
brief	(Optional) Displays the brief form of this command.
destination <i>destination-address</i>	(Optional) Restricts the display to tunnels destined for the specified IP address.
detail	(Optional) Displays detail information about headend tunnels.
down	(Optional) Displays tunnels that are down.
gmpls	(Optional) Restricts the display to GMPLS tunnels.
interface in	(Optional) Displays tunnels that use the specified input interface.
interface out	(Optional) Displays tunnels that use the specified output interface.
interface inout	(Optional) Displays tunnels that use the specified interface as an input or output interface.
<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
p2p	(Optional) Displays only P2P tunnels.
property backup-tunnel	(Optional) Displays tunnels with property of backup tunnel. Selects MPLS-TE tunnels used to protect physical interfaces on this router. A tunnel configured to protect a link against failure is a backup tunnel and has the backup tunnel property.
property fast-reroute	(Optional) Displays tunnels with property of fast-reroute configured. Selects FRR-protected MPLS-TE tunnels originating on (head), transmitting (router), or terminating (tail) on this router.

protection	(Optional) Displays all protected tunnels (configured as fast-reroutable). Displays information about the protection provided to each tunnel selected by other options specified with this command. The information includes whether protection is configured for the tunnel, the protection (if any) provided to the tunnel by this router, and the tunnel bandwidth protected.
reoptimized within-last <i>interval</i>	(Optional) Displays tunnels reoptimized within the last given time interval.
role all	(Optional) Displays all tunnels.
role head	(Optional) Displays tunnels with their heads at this router.
role middle	(Optional) Displays tunnels at the middle of this router.
role tail	(Optional) Displays tunnels with their tails at this router.
source <i>source-address</i>	(Optional) Restricts the display to tunnels with a matching source IP address.
suboptimal constraints current	(Optional) Displays tunnels whose path metric is greater than the current shortest path constrained by the tunnel's configured options.
suboptimal constraints max	(Optional) Displays tunnels whose path metric is greater than the current shortest path, constrained by the configured options for the tunnel, and taking into consideration only the network capacity.
suboptimal constraints none	(Optional) Displays tunnels whose path metric is greater than the shortest unconstrained path.
summary	(Optional) Displays summary of configured tunnels.
tabular	(Optional) Displays a table showing TE LSPs, with one entry per line.
unused	(Optional) Displays only unused backup tunnels.
up	(Optional) Displays tunnels when the tunnel interface is up.
class-type <i>ct</i>	(Optional) Displays tunnels using the given class-type value configuration.

igp <i>isis</i>	(Optional) Displays tunnels with the path calculated as the IS-IS type for IGP.
igp <i>ospf</i>	(Optional) Displays tunnels with the path calculated as the OSPF type for IGP.
within-last <i>interval</i>	(Optional) Displays tunnels that has come up within the last given time interval.

³¹ FRR = Fast Reroute.

³² LSPs = Label Switched Paths.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 3.2	This command was introduced.
	Release 3.3.0	The tabular keyword was added.
	Release 3.5.0	The command output was updated to support unequal load-balancing parameters.
	Release 3.7.0	If specified, sample output was modified to display the area on its own line after the existing path-option information.
	Release 3.8.0	These items were added: • To support the Automatic Bandwidth feature: ◦ The auto-bw keyword was added. ◦ Sample output and automatic bandwidth fields were added. • The <i>tunnel-number</i> argument, gmpls keyword, and p2p keyword were added.

Release	Modification
Release 3.9.0	These items were added: • The p2p keyword was added. • The affinity keyword was added. • Sample output was added to support the affinity keyword. • Sample output was added to support the brief keyword. • Sample output was added to support the summary keyword. • Sample output was added to support the tabular keyword.
Release 4.0.0	These items were added to support the MPLS-TE automatic backup tunnel feature: • The auto-tunnel keyword was added. • The unused keyword was added.
Release 4.1.1	The mesh keyword was added.

Usage Guidelines

You must be in a user group associated with a task group that includes the proper task IDs. The command reference guides include the task IDs required for each command. If you suspect user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **brief** form of the **show mpls traffic-eng tunnels** command to display information specific to a tunnel interface. Use the command without the **brief** keyword to display information that includes the destination address, source ID, role, name, suboptimal constraints, and interface.

The **affinity** keyword is available for only the source router.

Selected tunnels would have a shorter path if they were reoptimized immediately.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

This sample output is not changed when no area is specified for the active path-option. If the area is specified, it is added on a line of its own after the existing path-option information.

```
RP/0/0/CPU0:router# show mpls traffic-eng tunnels 20 detail
```

Signalling Summary:

```

    LSP Tunnels Process:  running
    RSVP Process:        running
    Forwarding:           enabled
    Periodic reoptimization: every 3600 seconds, next in 2400 seconds
```

show mpls traffic-eng tunnels

```

        Periodic FRR Promotion: every 300 seconds, next in 16 seconds
        Auto-bw enabled tunnels: 6

Name: tunnel-te20 Destination: 130.130.130.130
Status:
  Admin:      up Oper:      up Path: valid Signalling: connected

  path option 1, type explicit rlr2r3gig_path (Basis for Setup, path weight 200)
  G-PID: 0x0800 (derived from egress interface properties)
  Bandwidth Requested: 113 kbps CT0

Config Parameters:
  Bandwidth:      100 kbps (CT0) Priority: 7 7 Affinity: 0x0/0xffff
  Metric Type: TE (interface)
  AutoRoute: enabled LockDown: disabled Policy class: not set
  Forwarding-Adjacency: disabled
  Loadshare:      0 equal loadshares
  Auto-bw: enabled
    Last BW Applied: 113 kbps CT0 BW Applications: 1
    Last Application Trigger: Periodic Application
    Bandwidth Min/Max: 0-4294967295 kbps
    Application Frequency: 5 min Jitter: 0s Time Left: 4m 19s
    Collection Frequency: 1 min
    Samples Collected: 0 Next: 14s
    Highest BW: 0 kbps Underflow BW: 0 kbps
    Adjustment Threshold: 10% 10 kbps
    Overflow Detection disabled
    Underflow Detection disabled
    Fast Reroute: Disabled, Protection Desired: None
    Path Protection: Not Enabled
History:
  Tunnel has been up for: 00:18:54 (since Sun Mar 14 23:48:23 UTC 2010)
  Current LSP:
    Uptime: 00:05:41 (since Mon Mar 15 00:01:36 UTC 2010)
  Prior LSP:
    ID: path option 1 [3]
    Removal Trigger: reoptimization completed
Current LSP Info:
  Instance: 4, Signaling Area: IS-IS 1 level-2
  Uptime: 00:05:41 (since Mon Mar 15 00:01:36 UTC 2010)
  Outgoing Interface: GigabitEthernet0/5/0/21, Outgoing Label: 16009
  Router-IDs: local 110.110.110.110
               downstream 120.120.120.120
Path Info:
  Outgoing:
  Explicit Route:
    Strict, 61.10.1.2
    Strict, 61.15.1.1
    Strict, 61.15.1.2
    Strict, 130.130.130.130
  Record Route: Disabled
  Tspec: avg rate=113 kbits, burst=1000 bytes, peak rate=113 kbits
  Session Attributes: Local Prot: Not Set, Node Prot: Not Set, BW Prot: Not Set
Resv Info: None
  Record Route: Disabled
  Fspec: avg rate=113 kbits, burst=1000 bytes, peak rate=113 kbits
  Displayed 1 (of 6) heads, 0 (of 0) midpoints, 0 (of 0) tails
  Displayed 1 up, 0 down, 0 recovering, 0 recovered heads

```

This is a sample output from the **show mpls traffic-eng tunnels** command using the **property** keyword:

```
RP/0/0/CPU0:router# show mpls traffic-eng tunnels property backup interface out pos 0/6/0/0
```

```

Signalling Summary:
  LSP Tunnels Process: running, not registered with RSVP
  RSVP Process:      not running
  Forwarding:         enabled
  Periodic reoptimization: every 3600 seconds, next in 3595 seconds
  Periodic FRR Promotion: every 300 seconds, next in 295 seconds
  Periodic auto-bw collection: disabled

```

```

Name: tunnel-tel Destination: 1.1.1.1
Status:
  Admin:    up Oper:    up Path: valid Signalling: connected

  path option 1, type dynamic (Basis for Setup, path weight 1)
  G-PID: 0x0800 (derived from egress interface properties)

Config Parameters:
  Bandwidth:      1000 kbps (CT0) Priority:  7  7 Affinity: 0x0/0xffff
  Metric Type: TE (default)
  AutoRoute: disabled LockDown: disabled
  Loadshare:      10000 bandwidth-based
  Auto-bw: disabled(0/0) 0 Bandwidth Requested:      0
  Direction: unidirectional
  Endpoint switching capability: unknown, encoding type: unassigned
  Transit switching capability: unknown, encoding type: unassigned
  Backup FRR EXP Demotion: 1 ' 7, 2 ' 1
  Class-Attributes: 1, 2, 7
  Bandwidth-Policer: off

History:
  Tunnel has been up for: 00:00:08
  Current LSP:
    Uptime: 00:00:08

  Path info (ospf 0 area 0):
    Hop0: 10.0.0.2
    Hop1: 102.0.0.2
  Displayed 1 (of 1) heads, 0 (of 0) midpoints, 0 (of 0) tails
  Displayed 0 up, 1 down, 0 recovering, 0 recovered heads

```

This table describes the significant fields shown in the display.

Table 48: show mpls traffic-eng tunnels Command Field Descriptions

Field	Description
LSP Tunnels Process	Status of the LSP ³³ tunnels process.
RSVP Process	Status of the RSVP process.
Forwarding	Status of forwarding (enabled or disabled).
Periodic reoptimization	Time, in seconds, until the next periodic reoptimization.
Periodic FRR Promotion	Time, in seconds, till the next periodic FRR ³⁴ promotion.
Periodic auto-bw collection	Time, in seconds, till the next periodic auto-bw collection.
Name	Interface configured at the tunnel head.
Destination	Tail-end router identifier.
Admin/STATUS	Configured up or down.
Oper/STATE	Operationally up or down.

Field	Description
Signalling	Signaling connected or down or proceeding.
Config Parameters	Configuration parameters provided by tunnel mode MPLS traffic-eng, including those specific to unequal load-balancing functionality (bandwidth, load-share, backup FRR EXP demotion, class-attributes, and bandwidth-policer).
History: Current LSP: Uptime	Time LSP has been up.
Path Info	Hop list of current LSP.

³³ LSP = Link-State Packet.

³⁴ FRR = Fast Reroute.

This sample output shows the link attributes of links that are traversed by the tunnel (color information):

```
RP/0/0/CPU0:router# show mpls traffic-eng tunnels 11 affinity

Signalling Summary:
    LSP Tunnels Process:  running
    RSVP Process:        running
    Forwarding:           enabled
    Periodic reoptimization: every 3600 seconds, next in 2710 seconds
    Periodic FRR Promotion: every 300 seconds, next in 27 seconds

    Auto-bw enabled tunnels: 0 (disabled)

Name: tunnel-tell1 Destination: 3.3.3.3
Status:
  Admin:    up Oper:    up Path:  valid Signalling: connected

  path option 1, type explicit gige_1_2_3 (Basis for Setup, path weight 2)
  G-PID: 0x0800 (derived from egress interface properties)
  Bandwidth Requested: 200 kbps CT0

Config Parameters:
  Bandwidth:      200 kbps (CT0) Priority:  2 2
  Number of affinity constraints: 1
    Include bit map      : 0x4
    Include name         : red2

  Metric Type: TE (default)
  AutoRoute: disabled LockDown: disabled Policy class: not set
  Forwarding-Adjacency: disabled
  Loadshare:      0 equal loadshares
  Auto-bw: disabled
  Fast Reroute: Enabled, Protection Desired: Any
  Path Protection: Not Enabled

History:
  Tunnel has been up for: 02:55:27
  Current LSP:
    Uptime: 02:02:19
  Prior LSP:
    ID: path option 1 [8]
    Removal Trigger: reoptimization completed

Path info (OSPF 100 area 0):
  Link0: 12.9.0.1
  Attribute flags: 0x4
```

```

Attribute names: red2
Link1: 23.9.0.2
Attribute flags: 0x4
Attribute names: red2

```

```

Displayed 1 (of 8) heads, 0 (of 0) midpoints, 0 (of 0) tails
Displayed 1 up, 0 down, 0 recovering, 0 recovered heads

```

This sample output shows the brief summary of the tunnel status and configuration:

```
RP/0/0/CPU0:router# show mpls traffic-eng tunnels brief
```

```

Signalling Summary:
  LSP Tunnels Process: running
  RSVP Process: running
  Forwarding: enabled
  Periodic reoptimization: every 3600 seconds, next in 2538 seconds
  Periodic FRR Promotion: every 300 seconds, next in 38 seconds
  Auto-bw enabled tunnels: 0 (disabled)

```

TUNNEL NAME	DESTINATION	STATUS	STATE
tunnel-te1060	10.6.6.6	up	up
PE6_C12406_t607	10.7.7.7	up	up
PE6_C12406_t608	10.8.8.8	up	up
PE6_C12406_t609	10.9.9.9	up	up
PE6_C12406_t610	10.10.10.10	up	up
PE6_C12406_t621	10.21.21.21	up	up
PE7_C12406_t706	10.6.6.6	up	up
PE7_C12406_t721	10.21.21.21	up	up
Tunnel PE8-PE6	10.6.6.6	up	up
Tunnel PE8-PE21	10.21.21.21	up	up
Tunnel PE9-PE6	10.6.6.6	up	up
Tunnel PE9-PE21	10.21.21.21	up	up
Tunnel PE10-PE6	10.6.6.6	up	up
Tunnel PE10-PE21	10.21.21.21	up	up
PE21_C12406_t2106	10.6.6.6	up	up
PE21_C12406_t2107	10.7.7.7	up	up
PE21_C12406_t2108	10.8.8.8	up	up
PE21_C12406_t2109	10.9.9.9	up	up
PE21_C12406_t2110	10.10.10.10	up	up
PE6_C12406_t6070	10.7.7.7	up	up
PE7_C12406_t7060	10.6.6.6	up	up
tunnel-te1	200.0.0.3	up	up
OUNI POS0/1/0/1	100.0.0.1	up	up
OUNI POS0/1/0/2	200.0.0.1	up	up

```

Displayed 1 (of 1) heads, 20 (of 20) midpoints, 0 (of 0) tails
Displayed 1 up, 0 down, 0 recovering, 0 recovered heads

```

This section shows a sample output that results when automatic backup tunnels are created:

```
RP/0/0/CPU0:router# show mpls traffic-eng tunnels brief
```

```

.
.
.
TUNNEL NAME      DESTINATION      STATUS  STATE
tunnel-te0       200.0.0.3        up      up
tunnel-te1       200.0.0.3        up      up
tunnel-te2       200.0.0.3        up      up
*tunnel-te50     200.0.0.3        up      up
*tunnel-te60     200.0.0.3        up      up
*tunnel-te70     200.0.0.3        up      up
*tunnel-te80     200.0.0.3        up      up

```

```
* = automatically created backup tunnel
```

This is sample output that shows a summary of configured tunnels by using the **summary** keyword:

```
RP/0/0/CPU0:router# show mpls traffic-eng tunnels summary
```

```
LSP Tunnels Process: not running, disabled
                    RSVP Process: running
                    Forwarding: enabled
                    Periodic reoptimization: every 3600 seconds, next in 2706 seconds
                    Periodic FRR Promotion: every 300 seconds, next in 81 seconds
                    Periodic auto-bw collection: disabled
```

Signalling Summary:

```
Head: 1 interfaces, 1 active signalling attempts, 1 established
      0 explicit, 1 dynamic
      1 activations, 0 deactivations
      0 recovering, 0 recovered
Mids: 0
Tails: 0
```

Fast ReRoute Summary:

```
Head: 0 FRR tunnels, 0 protected, 0 rerouted
Mid: 0 FRR tunnels, 0 protected, 0 rerouted
Summary: 0 protected, 0 link protected, 0 node protected, 0 bw protected
```

AutoTunnel Backup Summary:

```
AutoTunnel Backups:
    50 created, 50 up, 0 down, 8 unused
    25 NHOP, 25 NNHOP, 10 SRLG strict, 10 SRLG pref
Protected LSPs:
    10 NHOP, 20 NHOP+SRLG
    15 NNHOP, 5 NNHOP+SRLG
Protected S2L Sharing Families:
    10 NHOP, 20 NHOP+SRLG
    15 NNHOP, 5 NNHOP+SRLG
Protected S2Ls:
    10 NHOP, 20 NHOP+SRLG
    15 NNHOP, 5 NNHOP+SRLG
```

This table describes the significant fields shown in the display.

Table 49: show mpls traffic-eng tunnels protection Command Field Descriptions

Field	Description
Tunnel#	Number of the MPLS-TE backup tunnel.
LSP Head/router	Node is either head or router for this LSP ³⁵ .
Instance	LSP ID.
Backup tunnel	Backup tunnel protection for NHOP/NNHOP.
out if	Backup tunnel's outgoing interface
Original	Outgoing interface, label, and next-hop of the LSP when not using backup.
With FRR	Outgoing interface and label when using backup tunnel.

Field	Description
LSP BW	Signaled bandwidth of the LSP.
Backup level	Type of bandwidth protection provided—pool type and limited/unlimited bandwidth.
LSP Tunnels Process	Status of the TE process 36 .

³⁵ LSP = Link-State Packet.

³⁶ LSP = Label Switched Path

This is sample output from the **show mpls traffic-eng tunnels** command using the **backup** keyword. This command selects every MPLS-TE tunnel known to the router, and displays information about the FRR protection that each selected tunnel provides for interfaces on this route. The command does not generate output for tunnels that do not provide FRR protection of interfaces on this router:

```
RP/0/0/CPU0:router# show mpls traffic-eng tunnels backup

tunnel160
  Admin: up, Oper: up
  Src: 10.20.20.20, Dest: 10.10.10.10, Instance: 28
  Fast Reroute Backup Provided:
    Protected I/fs: POS0/7/0/0
    Protected lsp: 0
    Backup BW: any-class unlimited, Inuse: 0 kbps
```

This table describes the significant fields shown in the display.

Table 50: show mpls traffic-eng tunnels backup Command Field Descriptions

Field	Description
Tunnel#	MPLS-TE backup tunnel number.
Dest	IP address of backup tunnel destination.
State	State of the backup tunnel. Values are up, down, or admin-down.
Instance	LSP ID of the tunnel.
Protected I/fs	List of interfaces protected by the backup tunnel.
Protected lsp	Number of LSPs currently protected by the backup tunnel.
Backup BW	Configured backup bandwidth type and amount. Pool from which bandwidth is acquired. Values are any-class, CT0, and CT1. Amount is either unlimited or a configured limit in kbps.

Field	Description
Inuse	Backup bandwidth currently in use on the backup tunnel.

This shows a sample output from the **show mpls traffic-eng tunnels** command using the **backup** and **protected-interface** keywords:

```
RP/0/0/CPU0:router# show mpls traffic-eng tunnels backup protected-interface
```

```
Interface: POS0/5/0/1
Tunnel100  UNUSED : out I/f:                Admin: down Oper: down

Interface: POS0/7/0/0
Tunnel160   NHOP : out I/f: POS0/6/0/0  Admin:   up Oper:   up
```

This table describes the significant fields shown in the display.

Table 51: show mpls traffic-eng tunnels backup protected-interface Command Field Descriptions

Field	Description
Interface	MPLS-TE-enabled FRR protected interface.
Tunnel#	FRR protected tunnel on the interface.
NHOP/NNHOP/UNUSED	State of Protected tunnel. Values are unused, next hop, next-next hop.
out I/f	Outgoing interface of the backup tunnel providing the protection.

This shows a sample output from the **show mpls traffic-eng tunnels up** command using the **igp ospf** keywords:

```
RP/0/0/CPU0:router# show mpls traffic-eng tunnels up igp ospf
```

```
Signalling Summary:
  LSP Tunnels Process: running
  RSVP Process:       running
  Forwarding:         enabled
  Periodic reoptimization: every 3600 seconds, next in 3381 seconds
  Periodic FRR Promotion:  every 300 seconds, next in 81 seconds
  Periodic auto-bw collection: disabled

Name: tunnel-tell Destination: 30.30.30.30
Status:
  Admin:   up Oper:   up Path: valid Signalling: connected

  path option 1, type explicit back (Basis for Setup, path weight 1)
  G-PID: 0x0800 (derived from egress interface properties)

Config Parameters:
  Bandwidth:      0 kbps (CT0) Priority:  7 7 Affinity: 0x0/0xffff
  Number of configured name based affinities: 2
  Name based affinity constraints in use:
    Include bit map      : 0x4 (refers to undefined affinity name)
    Include-strict bit map: 0x4
```



```

Metric Type: TE (default)
AutoRoute: disabled LockDown: disabled Loadshare: 0 bw-based
Auto-bw: disabled(0/0) 0 Bandwidth Requested: 0
Direction: unidirectional
Endpoint switching capability: unknown, encoding type: unassigned
Transit switching capability: unknown, encoding type: unassigned

History:
Tunnel has been up for: 00:00:21
Current LSP:
  Uptime: 00:00:21
Prior LSP:
  ID: path option 1 [4]
  Removal Trigger: tunnel shutdown

Path info (ospf area 0):
Hop0: 7.4.4.2
Hop1: 30.30.30.30

Displayed 1 (of 3) heads, 0 (of 0) midpoints, 0 (of 0) tails
Displayed 1 up, 0 down, 0 recovering, 0 recovered heads

```

This shows a sample output from the **show mpls traffic-eng tunnels** command using the **up within-last** keywords:

```

RP/0/0/CPU0:router# show mpls traffic-eng tunnels up within-last 200

Signalling Summary:
  LSP Tunnels Process: running
  RSVP Process: running
  Forwarding: enabled
  Periodic reoptimization: every 3600 seconds, next in 3381 seconds
  Periodic FRR Promotion: every 300 seconds, next in 81 seconds
  Periodic auto-bw collection: disabled

Name: tunnel-tell Destination: 30.30.30.30
Status:
  Admin: up Oper: up Path: valid Signalling: connected

  path option 1, type explicit back (Basis for Setup, path weight 1)
G-PID: 0x0800 (derived from egress interface properties)

Config Parameters:
  Bandwidth: 0 kbps (CT0) Priority: 7 7 Affinity: 0x0/0xffff
  Number of configured name based affinities: 2
  Name based affinity constraints in use:
    Include bit map: 0x4 (refers to undefined affinity name)
    Include-strict bit map: 0x4
Metric Type: TE (default)
AutoRoute: disabled LockDown: disabled Loadshare: 0 bw-based
Auto-bw: disabled(0/0) 0 Bandwidth Requested: 0
Direction: unidirectional
Endpoint switching capability: unknown, encoding type: unassigned
Transit switching capability: unknown, encoding type: unassigned

History:
Tunnel has been up for: 00:00:21
Current LSP:
  Uptime: 00:00:21
Prior LSP:
  ID: path option 1 [4]
  Removal Trigger: tunnel shutdown

Path info (ospf area 0):
Hop0: 7.4.4.2
Hop1: 30.30.30.30

Displayed 1 (of 3) heads, 0 (of 0) midpoints, 0 (of 0) tails
Displayed 1 up, 0 down, 0 recovering, 0 recovered heads

```

This shows a sample output from the **show mpls traffic-eng tunnels** command using the **reoptimized within-last** keywords:

```
RP/0/0/CPU0:router# show mpls traffic-eng tunnels reoptimized within-last 600

Signalling Summary:
    LSP Tunnels Process: running
    RSVP Process: running
    Forwarding: enabled
    Periodic reoptimization: every 60000 seconds, next in 41137 seconds
    Periodic FRR Promotion: every 300 seconds, next in 37 seconds
    Periodic auto-bw collection: disabled

Name: tunnel-te1 Destination: 30.30.30.30
Status:
    Admin: up Oper: up Path: valid Signalling: connected

    path option 1, type explicit prot1 (Basis for Setup, path weight 1)
G-PID: 0x0800 (derived from egress interface properties)

Config Parameters:
    Bandwidth: 66 kbps (CT0) Priority: 7 7 Affinity: 0x0/0xffff
    Metric Type: IGP (global)
    AutoRoute: enabled LockDown: disabled Loadshare: 66 bw-based
    Auto-bw: disabled(0/0) 0 Bandwidth Requested: 66
    Direction: unidirectional
Endpoint switching capability: unknown, encoding type: unassigned
Transit switching capability: unknown, encoding type: unassigned

History:
    Tunnel has been up for: 00:14:04
    Current LSP:
        Uptime: 00:03:52
        Selection: reoptimization
    Prior LSP:
        ID: path option 1 [2013]
        Removal Trigger: reoptimization completed

Path info (ospf area 0):
Hop0: 7.2.2.2
Hop1: 7.3.3.2
Hop2: 30.30.30.30
Displayed 1 (of 1) heads, 0 (of 0) midpoints, 0 (of 0) tails
Displayed 1 up, 0 down, 0 recovering, 0 recovered heads
```

This is a sample output from the **show mpls traffic-eng tunnels** command using the **detail** keyword:

```
RP/0/0/CPU0:router# show mpls traffic-eng tunnels 100 detail

Name: tunnel-te1 Destination: 24.24.24.24
Status:
    Admin: up Oper: up

    Working Path: valid Signalling: connected
    Protecting Path: valid Protect Signalling: connected
    Working LSP is carrying traffic

    path option 1, type explicit po4 (Basis for Setup, path weight 1)
    (Basis for Standby, path weight 2)
G-PID: 0x001d (derived from egress interface properties)
Path protect LSP is present.

    path option 1, type explicit po6 (Basis for Setup, path weight 1)

Config Parameters:
    Bandwidth: 10 kbps (CT0) Priority: 7 7 Affinity: 0x0/0xffff
    Metric Type: TE (default)
    AutoRoute: enabled LockDown: disabled Loadshare: 10 bw-based
    Auto-bw: disabled(0/0) 0 Bandwidth Requested: 10
    Direction: unidirectional
```

```

Endpoint switching capability: unknown, encoding type: unassigned
Transit switching capability: unknown, encoding type: unassigned

History:
Tunnel has been up for: 00:04:06
Current LSP:
  Uptime: 00:04:06
Prior LSP:
  ID: path option 1 [5452]
  Removal Trigger: path verification failed
Current LSP Info:
  Instance: 71, Signaling Area: ospf optical area 0
  Uptime: 00:10:41
  Incoming Label: explicit-null
  Outgoing Interface: POS0/4/0/0, Outgoing Label: implicit-null
  Path Info:
    Explicit Route:
      Strict, 100.0.0.3
      Strict, 24.24.24.24
    Record Route: None
    Tspec: avg rate=2488320 kbits, burst=1000 bytes, peak rate=2488320 kbits
Resv Info:
  Record Route:
    IPv4 100.0.0.3, flags 0x0
    Fspec: avg rate=2488320 kbits, burst=1000 bytes, peak rate=2488320 kbits
Protecting LSP Info:
  Instance: 72, Signaling Area: ospf optical area 0
  Incoming Label: explicit-null
  Outgoing Interface: POS0/6/0/0, Outgoing Label: implicit-null
  Path Info:
    Explicit Route:
      Strict, 101.0.0.3
      Strict, 24.24.24.24
    Record Route: None
    Tspec: avg rate=2488320 kbits, burst=1000 bytes, peak rate=2488320 kbits
Resv Info:
  Record Route:
    IPv4 101.0.0.3, flags 0x0
    Fspec: avg rate=2488320 kbits, burst=1000 bytes, peak rate=2488320 kbits

```

This is a sample output from the **show mpls traffic-eng tunnels** command using the **role mid** keyword:

```

RP/0/0/CPU0:router# show mpls traffic-eng tunnels role mid

Signalling Summary:
  LSP Tunnels Process: running
  RSVP Process: running
  Forwarding: enabled
  Periodic reoptimization: every 3600 seconds, next in 1166 seconds
  Periodic FRR Promotion: every 300 seconds, next in 90 seconds
  Periodic auto-bw collection: disabled
LSP Tunnel 10.10.10.10 1 [5508] is signalled, connection is up
Tunnel Name: FRR1 t1 Tunnel Role: Mid
InLabel: POS0/2/0/1, 33
OutLabel: POS0/3/0/0, implicit-null
Signalling Info:
  Src 10.10.10.10 Dst 30.30.30.30, Tunnel ID 1, Tunnel Instance 5508
  Path Info:1
    Incoming Address: 7.3.3.1
Incoming Explicit Route:
  Strict, 7.3.3.1
  Loose, 30.30.30.30
ERO Expansion Info:
  ospf 100 area 0, Metric 1 (TE), Affinity 0x0, Mask 0xffff, Queries 0
  Outgoing Explicit Route:
    Strict, 7.2.2.1
    Strict, 30.30.30.30
Record Route: None
Tspec: avg rate=10 kbits, burst=1000 bytes, peak rate=10 kbits
Resv Info:
  Record Route:

```

show mpls traffic-eng tunnels

```

IPv4 30.30.30.30, flags 0x20
Label 3, flags 0x1
IPv4 7.3.3.2, flags 0x0
Label 3, flags 0x1
Fspec: avg rate=10 kbits, burst=1000 bytes, peak rate=10 kbits
Displayed 0 (of 1) heads, 1 (of 1) midpoints, 0 (of 1) tails
Displayed 0 up, 0 down, 0 recovering, 0 recovered heads

```

This sample output shows a tabular table for TE LSPs by using the **tabular** keyword:

```
RP/0/0/CPU0:router# show mpls traffic-eng tunnels tabular
```

Tunnel Name	LSP ID	Destination Address	Source Address	Tun State	FRR State	LSP Role
tunnel-te1060	2	10.6.6.6	10.1.1.1	up	Inact	Head
PE6_C12406_t607	2	10.7.7.7	10.6.6.6	up	Inact	Mid
PE6_C12406_t608	2	10.8.8.8	10.6.6.6	up	Inact	Mid
PE6_C12406_t609	2	10.9.9.9	10.6.6.6	up	Inact	Mid
PE6_C12406_t610	2	10.10.10.10	10.6.6.6	up	Inact	Mid
PE6_C12406_t621	2	10.21.21.21	10.6.6.6	up	Inact	Mid
PE7_C12406_t706	835	10.6.6.6	10.7.7.7	up	Inact	Mid
PE7_C12406_t721	603	10.21.21.21	10.7.7.7	up	Inact	Mid
Tunnel_PE8-PE6	4062	10.6.6.6	10.8.8.8	up	Inact	Mid
Tunnel_PE8-PE21	6798	10.21.21.21	10.8.8.8	up	Inact	Mid
Tunnel_PE9-PE6	4062	10.6.6.6	10.9.9.9	up	Inact	Mid
Tunnel_PE9-PE21	6795	10.21.21.21	10.9.9.9	up	Inact	Mid
Tunnel_PE10-PE6	4091	10.6.6.6	10.10.10.10	up	Inact	Mid
Tunnel_PE10-PE21	6821	10.21.21.21	10.10.10.10	up	Inact	Mid
PE21_C12406_t2106	2	10.6.6.6	10.21.21.21	up	Ready	Mid
PE21_C12406_t2107	2	10.7.7.7	10.21.21.21	up	Inact	Mid
PE21_C12406_t2108	2	10.8.8.8	10.21.21.21	up	Inact	Mid
PE21_C12406_t2109	2	10.9.9.9	10.21.21.21	up	Inact	Mid
PE21_C12406_t2110	2	10.10.10.10	10.21.21.21	up	Inact	Mid
PE6_C12406_t6070	2	10.7.7.7	10.6.6.6	up	Inact	Mid
PE7_C12406_t7060	626	10.6.6.6	10.7.7.7	up	Inact	Mid
tunnel-te1	1	200.0.0.3	200.0.0.1	up	Inact	Head InAct
tunnel-te100	1	200.0.0.3	200.0.0.1	up	Ready	Head InAct
OUNI POS0/1/0/1	2	100.0.0.1	200.0.0.1	up	Inact	Head InAct
OUNI POS0/1/0/2	6	200.0.0.1	100.0.0.1	up	Inact	Tail InAct

This sample output shows a tabular table indicating automatic backup tunnels when using the **tabular** keyword:

```
RP/0/0/CPU0:router# show mpls traffic-eng tunnels tabular
```

Tunnel Name	LSP ID	Destination Address	Source Address	State	FRR State	LSP Role	Path Prot
tunnel-te0	549	200.0.0.3	200.0.0.1	up	Inact	Head	InAct
tunnel-te1	546	200.0.0.3	200.0.0.1	up	Inact	Head	InAct
tunnel-te2	6	200.0.0.3	200.0.0.1	up	Inact	Head	InAct
*tunnel-te50	6	200.0.0.3	200.0.0.1	up	Active	Head	InAct
*tunnel-te60	4	200.0.0.3	200.0.0.1	up	Active	Head	InAct
*tunnel-te70	4	200.0.0.3	200.0.0.1	up	Active	Head	InAct
*tunnel-te80	3	200.0.0.3	200.0.0.1	up	Active	Head	InAct

* = automatically created backup tunnel

This table describes the significant fields shown in the display.

Table 52: show mpls traffic-eng tunnels tabular Command Field Descriptions

Field	Description
Tunnel Name	MPLS-TE tunnel name.

Field	Description
LSP ID	LSP ID of the tunnel.
Destination Address	Destination address of the TE tunnel (identified in Tunnel Name).
Source Address	Source address for the filtered tunnels.
Tunnel State	State of the tunnel. Values are up, down, or admin-down.
FRR State	FRR state identifier.
LSP Role	Role identifier. Values are All, Head, or Tail.

This sample output shows the MPLS-TE tunnel information only for tunnels in which the automatic bandwidth is enabled using the **auto-bw** keyword:

```
RP/0/0/CPU0:router# show mpls traffic-eng tunnels auto-bw
```

```

Signalling Summary:
    LSP Tunnels Process:  running
    RSVP Process:         running
    Forwarding:           enabled
    Periodic reoptimization: every 3600 seconds, next in 636 seconds
    Periodic FRR Promotion: every 300 seconds, next in 276 seconds
    Auto-bw enabled tunnels: 1

Name: tunnel-tel  Destination: 0.0.0.0
Status:
    Admin:      up Oper: down  Path: not valid  Signalling: Down
    G-PID: 0x0800 (internally specified)
    Bandwidth Requested: 0 kbps  CT0

Config Parameters:
    Bandwidth:      0 kbps (CT0) Priority:  7  7 Affinity: 0x0/0xffff
    Metric Type: TE (default)
    AutoRoute: disabled  LockDown: disabled  Policy class: not set
    Loadshare:      0 equal loadshares

Auto-bw: (collect bw only)
    Last BW Applied: 500 kbps (CT0)  BW Applications: 25
    Last Application Trigger: Periodic Application
    Bandwidth Min/Max: 10-10900 kbps
    Application Frequency: 10 min (Cfg: 10 min)  Time Left: 5m 34s
    Collection Frequency: 2 min
    Samples Collected: 2  Highest BW: 450 kbps  Next: 1m 34s
    Adjustment Threshold: 5%
    Overflow Threshold: 15%  Limit: 1/4  Early BW Applications: 0
    Direction: unidirectional
    Endpoint switching capability: unknown, encoding type: unassigned
    Transit switching capability: unknown, encoding type: unassigned
    Fast Reroute: Disabled, Protection Desired: None

Reason for the tunnel being down: No destination is configured
History:
    Displayed 1 (of 1) heads, 0 (of 0) midpoints, 0 (of 0) tails
    Displayed 0 up, 1 down, 0 recovering, 0 recovered heads

```

This table describes the significant fields shown in the display.

Table 53: show mpls traffic-eng tunnels auto-bw Command Field Descriptions

Field	Description
collect bw only	Field is displayed only if the bandwidth collection is configured in the tunnel automatic bandwidth configuration.
Last BW Applied	Last bandwidth change that is requested by the automatic bandwidth for the tunnel. In addition, this field indicates which pool is used for the bandwidth.
BW Applications	Total number of bandwidth applications that is requested by the automatic bandwidth, which includes the applications triggered by an overflow condition.
Last Application Trigger	These last application options are displayed: • Periodic Application • Overflow Detected • Manual Application
Bandwidth Min/Max	Bandwidth configured is either minimum or maximum.
Application Frequency	Configured application frequency. The Time Left field indicates the time left before the next application executes.
Collection Frequency	Globally configured collection frequency, which is the same value for all the tunnels.
Samples Collected	Number of samples that are collected during the current application period. This field is replaced by the Collection Disabled field if Collection Frequency is not currently configured.
Highest BW	Highest bandwidth that is collected for the application period.
Next	Time left before the next collection event.
Overflow Threshold	Overflow threshold that is configured. The Overflow field appears only if the overflow detection is configured in the tunnel automatic bandwidth configuration.
Limit	Consecutive overflow detected or configured limit.

Field	Description
Early BW Applications	Number of early bandwidth applications that are triggered by an overflow condition.

This is sample output from the **show mpls traffic-eng tunnels** command after the NNHOP SRLG preferred automatic backup tunnel is configured:

```
RP/0/0/CPU0:router# show mpls traffic-eng tunnels 1
```

Signalling Summary:

```

    LSP Tunnels Process:  running
    RSVP Process:        running
    Forwarding:           enabled
    Periodic reoptimization: every 3600 seconds, next in 2524 seconds
    Periodic FRR Promotion: every 300 seconds, next in 49 seconds
    Auto-bw enabled tunnels: 1

```

Name: tunnel-tel Destination: 200.0.0.3 (auto backup)

Status:

```
Admin:    up Oper:    up Path:  valid Signalling: connected
```

path option 10, type explicit (autob_nnhop_srlg_tunnel1) (Basis for Setup, path weight 11)

path option 20, type explicit (autob_nnhop_tunnel1)

G-PID: 0x0800 (derived from egress interface properties)

Bandwidth Requested: 0 kbps CT0

Creation Time: Fri Jul 10 01:53:25.581 PST (1h 25m 17s ago)

Config Parameters:

Bandwidth: 0 kbps (CT0) Priority: 7 7 Affinity: 0x0/0xffff

Metric Type: TE (default)

AutoRoute: disabled LockDown: disabled Policy class: not set

Forwarding-Adjacency: disabled

Loadshare: 0 equal loadshares

Auto-bw: disabled

Fast Reroute: Disabled, Protection Desired: None

Path Protection: Not Enabled

Auto Backup:

Protected LSPs: 4

Protected S2L Sharing Families: 0

Protected S2Ls: 0

Protected i/f: Gi0/1/0/0 Protected node: 20.0.0.2

Protection: NNHOP+SRLG

Unused removal timeout: not running

History:

Tunnel has been up for: 00:00:08

Current LSP:

Uptime: 00:00:08

Prior LSP:

ID: path option 1 [545]

Removal Trigger: configuration changed

Path info (OSPF 0 area 0):

Hop0: 10.0.0.2

Hop1: 100.0.0.2

Hop2: 100.0.0.3

Hop3: 200.0.0.3

This table describes the significant fields shown in the display.

Table 54: show mpls traffic-eng tunnels Command Field Descriptions

Field	Description
Auto Backup	Auto backup section header.
Creation Time	Time when the tunnel was created and for what period was the tunnel created.
Protected LSPs	Number of ready and active LSPs protected by this backup.
Protected S2L Sharing Families	Number of ready and active sharing families protected by this backup.
Protected S2Ls	Number of ready and active primary tunnels protected by this backup.
Protected i/f Protected node	Interface and NNHOP node protected by this backup.
Protection: NNHOP+SRLG	Type of protection provided by this backup. Note Protection can be different when a preferred SRLG is configured and an SRLG path is not found.
Example when backup is in use: Unused removal timeout: not running Example when backup is unused: Unused removal timeout: 1h26m	Amount of time left before the unused removal timeout expires. This timer only runs when the backup is in the unused state. After the timer expires, the automatic backup tunnel is removed.

This is sample output from the **show mpls traffic-eng tunnels** command using the **detail** keyword:

```
RP/0/0/CPU0:router# show mpls traffic-eng tunnels 999 detail
```

```
Name: tunnel-te999 Destination: 1.1.1.1
Status:
  Admin:      up Oper:      up Path:  valid Signalling: connected

  path option 1, type dynamic (Basis for Setup, path weight 2)
  Path-option attribute: po
    Number of affinity constraints: 2
      Include bit map      : 0x4
      Include name         : blue
      Exclude bit map      : 0x2
      Exclude name         : red

    Bandwidth: 300 (CT0)
    G-PID: 0x0800 (derived from egress interface properties)
    Bandwidth Requested: 300 kbps CT0
    Creation Time: Tue Aug 14 23:35:58 2012 (00:00:42 ago)
  Config Parameters:
    Bandwidth:      100 kbps (CT0) Priority:  7 7 Affinity: 0x0/0xffff
    Metric Type: TE (default)
    Hop-limit: disabled
```



```

AutoRoute: disabled LockDown: disabled Policy class: not set
Forwarding-Adjacency: disabled
Loadshare: 0 equal loadshares
Auto-bw: disabled
Fast Reroute: Enabled, Protection Desired: Any
Path Protection: Not Enabled
Soft Preemption: Disabled
SNMP Index: 42
History:
  Tunnel has been up for: 00:00:30 (since Tue Aug 14 23:36:10 EST 2012)
  Current LSP:
    Uptime: 00:00:30 (since Tue Aug 14 23:36:10 EST 2012)
  Current LSP Info:
    Instance: 2, Signaling Area: OSPF 100 area 16909060
    Uptime: 00:00:30 (since Tue Aug 14 23:36:10 EST 2012)
    Outgoing Interface: GigabitEthernet0/2/0/2, Outgoing Label: 16005
    Router-IDs: local 3.3.3.3
                downstream 2.2.2.2
  Soft Preemption: None
  Path Info:
    Outgoing:
      Explicit Route:
        Strict, 23.9.0.2
        Strict, 12.9.0.2
        Strict, 12.9.0.1
        Strict, 1.1.1.1

    Record Route: Disabled
    Tspec: avg rate=300 kbits, burst=1000 bytes, peak rate=300 kbits
    Session Attributes: Local Prot: Set, Node Prot: Not Set, BW Prot: Not Set
                      Soft Preemption Desired: Not Set

  Resv Info:
    Record Route:
      IPv4 2.2.2.2, flags 0x20
      Label 16005, flags 0x1
      IPv4 23.9.0.2, flags 0x0
      Label 16005, flags 0x1
      IPv4 1.1.1.1, flags 0x20
      Label 3, flags 0x1
      IPv4 12.9.0.1, flags 0x0
      Label 3, flags 0x1
    Fspec: avg rate=300 kbits, burst=1000 bytes, peak rate=300 kbits Displayed 1 (of 8)
heads, 0 (of 3) midpoints, 0 (of 0) tails Displayed 1 up, 0 down, 0 recovering, 0 recovered
heads

```

This is sample output from the **show mpls traffic-eng tunnels** command using the **auto-tunnel backup** keywords:

```
RP/0/0/CPU0:router# show mpls traffic-eng tunnels auto-tunnel backup
```

```

AutoTunnel Backup Configuration:
  Interfaces count: 30
  Unused removal timeout: 2h
  Configured tunnel number range: 0-100
AutoTunnel Backup Summary:
  50 created, 50 up, 0 down, 8 unused
  25 NHOP, 25 NNHOP, 10 SRLG strict, 10 SRLG pref
Protected LSPs:
  10 NHOP, 20 NHOP+SRLG
  15 NNHOP, 5 NNHOP+SRLG
Protected S2L Sharing Families:
  10 NHOP, 20 NHOP+SRLG
  15 NNHOP, 5 NNHOP+SRLG
Protected S2Ls:
  10 NHOP, 20 NHOP+SRLG
  15 NNHOP, 5 NNHOP+SRLG

Cumulative Counters (last cleared 1h ago):
      Total      NHOP      NNHOP
Created:      550       300       250
Connected:    500       250       250
Removed (down): 0         0         0

```

```

Removed (unused):    200      100      100
Removed (in use):    0        0        0
Range exceeded:      0        0        0

```

This table describes the significant fields shown in the display.

Table 55: show mpls traffic-eng tunnels auto-tunnel backup Command Field Descriptions

Field	Description
AutoTunnel Backup Configuration	Header for the automatic tunnel backup configuration.
Interfaces count	Number of interfaces that have automatic tunnel backup enabled.
Unused removal timeout	Configured value and time left before expiration of the unused removal timeout attribute.
Configured tunnel number range	Configured tunnel number range.
AutoTunnel Backup Summary	Header for the automatic tunnel backup summary information.
50 created	Number of automatic backup tunnels created.
50 up	Number of automatic backup tunnels in the up state.
0 down	Number of automatic backup tunnels in the down state.
8 unused	Number of automatic backup tunnels in the unused state.
25 NHOP	Number of automatic backup tunnels created for NHOP protection.
25 NNHOP	Number of automatic backup tunnels created for NNHOP protection.
10 SRLG strict	Number of automatic backup tunnels created with the SRLG preferred attribute.
10 SRLG pref	Number of automatic backup tunnels created with the SRLG preferred attribute.
Protected LSPs Protected S2L Sharing Families Protected S2Ls	Headings for summary information showing current status of LSPs, S2L Sharing Families, and S2Ls that are protected by the automatic tunnel backups. Numbers include primary tunnels in FRR ready and active state.
10 NHOP	Number of automatic backup tunnels that are link protected.

Field	Description
20 NHOP+SRLG	Number of automatic backup tunnels that are link protected and using an SRLG diverse backup path.
15 NNHOP	Number of automatic backup tunnels that are node protected.
20 NNHOP+SRLG	Number of automatic backup tunnels that are node protected and use an SRLG diverse backup path.
Cumulative Counters (last cleared 1h ago):	Cumulative counters for automatic backup tunnels.
Headers: Total, NHOP, NNHOP	Total number of counters and breakdown of NHOP and NNHOP counters.
Created:	Cumulative number of created automatic backup tunnels since the last counter was cleared.
Connected:	Cumulative number of the connected automatic backup tunnels since the last counter was cleared. Note Counter increments only the first time that a tunnel connects.
Removed (down/unused/in use)	Number of automatic backup tunnels that are removed based on state.
Range exceeded	Number of automatic backup tunnels attempted and later rejected when the total number exceeds the configured range.

This is sample output from the **show mpls traffic-eng tunnels** command with the **mesh** keyword:

```
RP/0/0/CPU0:router# show mpls traffic-eng tunnels auto-tunnel
Signalling Summary:
    LSP Tunnels Process:  running
    RSVP Process:        running
    Forwarding:           enabled
    Periodic reoptimization: every 3600 seconds, next in 3098 seconds
    Periodic FRR Promotion: every 300 seconds, next in 238 seconds
    Auto-bw enabled tunnels: 1000

Name: tunnel-te9000  Destination: 20.20.20.20 (auto-tunnel mesh)
Status:
  Admin:    up Oper:    up  Path:  valid  Signalling: connected
  path option 10, type dynamic (Basis for Setup, path weight 11)
  G-PID: 0x0800 (derived from egress interface properties)
  Bandwidth Requested: 0 kbps CT0
  Creation Time: Thu Jan 14 09:09:31 2010 (01:41:20 ago)
Config Parameters:
  Bandwidth: 0 kbps (CT0) Priority: 7 7 Affinity: 0x0/0xffff
  Metric Type: TE (default)
  AutoRoute: disabled LockDown: disabled Policy class: not set
  Forwarding-Adjacency: disabled
  Loadshare: 0 equal loadshares
  Auto-bw: disabled
  Fast Reroute: Disabled, Protection Desired: None
  Path Protection: Not Enabled
```

```

Attribute-set: TA-NAME (type auto-mesh)
Auto-tunnel Mesh:
Group 40: Destination-list dl-40
Unused removal timeout: not running
History:
Tunnel has been up for: 01:40:53 (since Thu Jan 14 09:09:58 EST 2010)
Current LSP:
Uptime: 01:41:00 (since Thu Jan 14 09:09:51 EST 2010)
Reopt. LSP:
Last Failure:
LSP not signalled, identical to the [CURRENT] LSP
Date/Time: Thu Jan 14 09:42:30 EST 2010 [01:08:21 ago]

Path info (OSPF 100 area 0):
Hop0: 7.0.15.1
Hop1: 20.20.20.20

```

This shows an auto-tunnel mesh summary sample output from the **show mpls traffic-eng tunnels** command using the **summary** keyword:

```

RP/0/0/CPU0:router# show mpls traffic-eng tunnels summary
Thu Jan 14 10:46:34.677 EST

```

```

LSP Tunnels Process: running
RSVP Process: running
Forwarding: enabled
Periodic reoptimization: every 3600 seconds, next in 3354 seconds
Periodic FRR Promotion: every 300 seconds, next in 193 seconds
Periodic auto-bw collection: 1000

Signalling Summary:
Head: 2000 interfaces, 2000 active signalling attempts, 2000 established
      2000 explicit, 0 dynamic
      9250 activations, 7250 deactivations
      0 recovering, 2000 recovered
Mids: 0
Tails: 0

Fast ReRoute Summary:
Head: 1000 FRR tunnels, 1000 protected, 0 rerouted
Mid: 0 FRR tunnels, 0 protected, 0 rerouted
Summary: 1000 protected, 500 link protected, 500 node protected, 0 bw protected

P2MP Summary:
Tunnel Head: 250 total, 250 connected
Destination Head: 500 total, 500 connected
S2L Head: 500 established, 0 proceeding
S2L Mid: 0 established, 0 proceeding
S2L Tail: 0 established

P2MP Fast ReRoute Summary:
Tunnel Head: 250 FRR enabled
S2L Head: 500 FRR, 500 protected, 0 rerouted
S2L Mid: 0 FRR, 0 protected, 0 rerouted
Summary: 500 protected, 500 link protected, 0 node protected, 0 bw protected

<snip>

Auto-tunnel Mesh Summary:
Auto-mesh Tunnels:
50 created, 50 up, 0 down, 25 FRR, 20 FRR enabled
Mesh Groups:
4 groups, 50 destinations

```

This shows an auto-tunnel mesh summary sample output from the **show mpls traffic-eng tunnels** command using the **auto-mesh** keyword:

```

RP/0/0/CPU0:router# show mpls traffic-eng tunnels auto-tunnel
Signalling Summary:
LSP Tunnels Process: running
RSVP Process: running

```

```

        Forwarding: enabled
        Periodic reoptimization: every 3600 seconds, next in 3098 seconds
        Periodic FRR Promotion: every 300 seconds, next in 238 seconds
        Auto-bw enabled tunnels: 1000

Name: tunnel-te9000 Destination: 20.20.20.20 (auto-tunnel mesh)
Status:
  Admin: up Oper: up Path: valid Signalling: connected
  path option 10, type dynamic (Basis for Setup, path weight 11)
  G-PID: 0x0800 (derived from egress interface properties)
  Bandwidth Requested: 0 kbps CT0
  Creation Time: Thu Jan 14 09:09:31 2010 (01:41:20 ago)
Config Parameters:
  Bandwidth: 0 kbps (CT0) Priority: 7 7 Affinity: 0x0/0xffff
  Metric Type: TE (default)
  AutoRoute: disabled LockDown: disabled Policy class: not set
  Forwarding-Adjacency: disabled
  Loadshare: 0 equal loadshares
  Auto-bw: disabled
  Fast Reroute: Disabled, Protection Desired: None
  Path Protection: Not Enabled
  Attribute-set: TA-NAME (type auto-mesh)
Auto-tunnel Mesh:
  Group 40: Destination-list dl-40
  Unused removal timeout: not running
History:
  Tunnel has been up for: 01:40:53 (since Thu Jan 14 09:09:58 EST 2010)
  Current LSP:
    Uptime: 01:41:00 (since Thu Jan 14 09:09:51 EST 2010)
  Reopt. LSP:
    Last Failure:
      LSP not signalled, identical to the [CURRENT] LSP
      Date/Time: Thu Jan 14 09:42:30 EST 2010 [01:08:21 ago]

Path info (OSPF 100 area 0):
Hop0: 7.0.15.1
Hop1: 20.20.20.20

```

This example includes output for Generalized Multiprotocol Label Switching (GMPLS) User-Network Interface (UNI) configuration for the **show mpls traffic-eng tunnels** command using the **summary** keyword:

```

RP/0/0/CPU0:router#show mpls traffic-eng tunnels auto-tunnel
Thu Jan 14 10:46:34.677 EST

        LSP Tunnels Process: running
        RSVP Process: running
        Forwarding: enabled
        Periodic reoptimization: every 3600 seconds, next in 3354 seconds
        Periodic FRR Promotion: every 300 seconds, next in 193 seconds
        Periodic auto-bw collection: 1000

Signalling Summary:
  Head: 2000 interfaces, 2000 active signalling attempts, 2000 established
        2000 explicit, 0 dynamic
        9250 activations, 7250 deactivations
        0 recovering, 2000 recovered
  Mids: 0
  Tails: 0

Fast ReRoute Summary:
  Head: 1000 FRR tunnels, 1000 protected, 0 rerouted
  Mid: 0 FRR tunnels, 0 protected, 0 rerouted
  Summary: 1000 protected, 500 link protected, 500 node protected, 0 bw protected

P2MP Summary:
  Tunnel Head: 250 total, 250 connected
  Destination Head: 500 total, 500 connected
  S2L Head: 500 established, 0 proceeding
  S2L Mid: 0 established, 0 proceeding
  S2L Tail: 0 established

```

```
P2MP Fast ReRoute Summary:
  Tunnel Head: 250 FRR enabled
  S2L Head: 500 FRR, 500 protected, 0 rerouted
  S2L Mid: 0 FRR, 0 protected, 0 rerouted
  Summary: 500 protected, 500 link protected, 0 node protected, 0 bw protected

<snip>
GMPLS UNI Summary:
  Heads: 23 up, 4 down
  Tails: 13 up, 2 down
```

Related Commands

Command	Description
auto-tunnel backup (MPLS-TE)	Builds automatic NHOP and NNHOP backup tunnels.
backup-bw	Specifies the bandwidth type that LSPs can use for a backup tunnel, whether the backup tunnel should provide bandwidth protection, and if yes, how much and in which bandwidth pool.
srlg	Configures an SRLG membership for a link on a given interface.

show mpls traffic-eng tunnels auto-bw brief

To display the list of automatic bandwidth enabled tunnels, and to indicate if the current signaled bandwidth of the tunnel is identical to the bandwidth that is applied by the automatic bandwidth, use the **show mpls traffic-eng tunnels auto-bw brief** command in EXEC mode.

show mpls traffic-eng tunnels auto-bw brief

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes EXEC

Command History	Release	Modification
	Release 3.8.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show mpls traffic-eng tunnels auto-bw brief** command to determine if the automatic bandwidth application has been applied on a specified tunnel. If a single tunnel is specified, only the information for that tunnel is displayed.

Task ID	Task ID	Operations
	mpls-te	read

Examples The following sample output shows the list of automatic bandwidth enabled tunnels:

RP/0/0/CPU0:router# **show mpls traffic-eng tunnels auto-bw brief**

Tunnel Name	LSP ID	Last appl BW (kbps)	Requested BW (kbps)	Signalled BW (kbps)	Highest BW (kbps)	Application Time Left
tunnel-te0	1		10	10	50	2h 5m
tunnel-te1	5		500	300	420	1h 10m

This table describes the significant fields shown in the display.

Table 56: show mpls traffic-eng tunnels auto-bw brief Field Descriptions

Field	Description
Tunnel Name	Name for the tunnel.
LSP ID	ID of the Label Switched Path that is used by the tunnel.
Last appl BW (kbps)	Last bandwidth applied (for example, requested) by the automatic-bandwidth feature for the tunnel.
Requested BW (kbps)	Bandwidth that is requested for the tunnel.
Signalled BW (kbps)	Bandwidth that is actually signalled for the tunnel.
Highest BW (kbps)	Highest bandwidth measured since the last start of the application interval.
Application Time Left	Time left until the application period ends for this tunnel.

Related Commands

Command	Description
show mpls traffic-eng tunnels, on page 401	Displays information about MPLS-TE tunnels.

show srlg

To show the SRLG interface and configuration information, use the **show srlg** command in EXEC mode.

```
show srlg [interface type interface-path-id] [location {node-id| all| mgmt-nodes}] [value value-number]
[trace{file filename original| hexdump | last entries| reverse | stats| tailf | unique | verbose | wrapping}]
```

Syntax Description

interface <i>type</i>	(Optional) Displays information on the specific interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface. Note Use the show interfaces command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
location	(Optional) Specifies a node.
<i>node-id</i>	Node ID. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
all	Specifies all locations.
mgmt-nodes	Specifies all management nodes.
value <i>value-number</i>	(Optional) Displays SRLG value numbers.
trace	(Optional) Displays trace information for SRLG.
file <i>filename</i>	(Optional) Displays trace information for a specific file name.
original	Displays the original location of the file.
hexdump	(Optional) Displays traces in hexadecimal format.
last	(Optional) Displays trace information for a specific number of entries.
<i>entries</i>	Number of entries. Replace entries with the number of entries you want to display. For example, if you enter 5, the display shows the last 5 entries in the trace data. Range is 1 to 4294967295.
reverse	(Optional) Displays the latest traces first.

stats	(Optional) Displays the statistics in the command output.
tailf	(Optional) Displays the new traces as they are added in the command output.
unique	(Optional) Displays the unique entries with counts in the command output.
verbose	(Optional) Displays the information for internal debugging in the command output.
wrapping	(Optional) Displays the wrapping entries in the command output.

Command Default No default behavior or values

Command Modes EXEC

Command History	Release	Modification
	Release 4.0.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	ip-services	read

Examples The following sample output is from the **show srlg value** command.

```

System Information::
Interface Count    : 2 (Maximum Interfaces Supported 250)

Interface   : POS0/1/0/0, Value Count : 2
SRLG Values : 10,20

Interface   : POS0/1/0/1, Value Count : 2
SRLG Values : 10,30

Interface   : POS0/1/0/2, Value Count : 2

```

```
SRLG Values : 10,40  
Interface   : POS0/2/0/0, Value Count : 1  
SRLG Values : 100
```

Related Commands

Command	Description
interface (MPLS-TE), on page 236	Enables MPLS-TE on an interface and enters MPLS-TE interface configuration mode.
mpls traffic-eng, on page 265	Enters MPLS-TE configuration mode.

signalled-name

To configure the name of the tunnel required for an MPLS-TE tunnel, use the **signalled-name** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

signalled-name *name*

no signalled-bandwidth *name*

Syntax Description

<i>name</i>	Name used to signal the tunnel.

Command Default

Default name is the hostname_tID, where ID is the tunnel interface number.

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.3.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to set the tunnel name:

```
RP/0/0/CPU0:router(config)# interface tunnel-te 1
RP/0/0/CPU0:router(config-if)# signalled-name tunnel-from-NY-to-NJ
```

Related Commands

Command	Description
show mpls traffic-eng tunnels , on page 401	Displays information about MPLS-TE tunnels.

signalling advertise explicit-null (MPLS-TE)

To specify that tunnels terminating on a router use explicit-null labels, use the **signalling advertise explicit-null** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

signalling advertise explicit-null

no signalling advertise explicit-null

Syntax Description This command has no arguments or keywords.

Command Default Implicit-null labels are advertised.

Command Modes MPLS-TE configuration

Command History	Release	Modification
	Release 3.2	This command was supported.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **signalling advertise explicit-null** command to specify that tunnels terminating on this router use explicit-null labels. This command applies to tunnel labels advertised to next to last (penultimate) hop.

The explicit label is used to carry quality-of-service (QoS) information up to the terminating-end router of the label switched path (LSP).

Task ID	Task ID	Operations
	mpls-te	read, write

Examples The following example shows how to configure explicit null tunnel labels:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# signalling advertise explicit-null
```

Related Commands

Command	Description
mpls traffic-eng , on page 265	Enters MPLS-TE configuration mode.
path-selection loose-expansion metric (MPLS-TE) , on page 297	Configures a metric type to be used to expand a path to the next loose hop for a tunnel on an area border router.

snmp traps mpls traffic-eng

To enable the router to send Multiprotocol Label Switching traffic engineering (MPLS-TE) Simple Network Management Protocol (SNMP) notifications or informs, use the **snmp traps mpls traffic-eng** command in global configuration mode. To disable this behavior, use the **no** form of this command.

snmp traps mpls traffic-eng [*notification-option*]

no snmp traps mpls traffic-eng [*notification-option*]

Syntax Description

<i>notification-option</i>	(Optional) Notification option to enable the sending of notifications to indicate changes in the status of MPLS-TE tunnels. Use one of these values: • up • down • reoptimize • reroute • cisco-ext

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

If the command is entered without the *notification-option* argument, all MPLS-TE notification types are enabled.

SNMP notifications can be sent as either traps or inform requests.

The **snmp-server enable traps mpls traffic-eng** command enables both traps and inform requests for the specified notification types. To specify whether the notifications should be sent as traps or informs, use the **snmp-server host** command and specify the keyword **trap** or **informs**.

If you do not enter the **snmp traps mpls traffic-eng** command, no MPLS-TE notifications controlled by this command are sent. To configure the router to send these MPLS-TE SNMP notifications, you must enter at

least one **snmp enable traps mpls traffic-eng** command. If you enter the command with no keywords, all MPLS-TE notification types are enabled. If you enter the command with a keyword, only the notification type related to that keyword is enabled. To enable multiple types of MPLS-TE notifications, you must issue a separate **snmp traps mpls traffic-eng** command for each notification type and notification option.

The **snmp traps mpls traffic-eng** command is used in conjunction with the **snmp host** command. Use the **snmp host** command to specify which host or hosts receive MPLS-TE SNMP notifications. To send notifications, you must configure at least one **snmp host** command.

For a host to receive an MPLS-TE notification controlled by this command, both the **snmp traps mpls traffic-eng** command and the **snmp host** command for that host must be enabled.

Task ID

Task ID	Operations
mpls-te	read/write

Examples

This example shows how to configure a router to send MPLS-TE tunnel up SNMP notifications when a configured MPLS-TE tunnel leaves the down state and enters the up state:

```
RP/0/0/CPU0:router(config)# snmp traps mpls traffic-eng up
```

Related Commands

Command	Description
snmp-server host	Specifies the recipient of a SNMP notification operation.

srlg

To configure an MPLS traffic engineering shared-risk link group (SRLG) value for a link on a given interface, use the **srlg** command in global configuration mode. To disable this configuration, use the **no** form of this command.

srlg *value*

no srlg *value*

Syntax Description

<i>value</i>	Value number that identifies the SRLG. Range is 0 to 4294967295.

Command Default

Shared Risk Link Group memberships are not configured.

Command Modes

Global configuration

Command History

Release	Modification
Release 3.8.0	This command was introduced.
Release 4.0.0	The value argument was added. Command mode was changed to the global configuration mode.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

You can enter up to 30 SRLG entries on the ingress and egress ports of the interface. SRLG entries configured over 30 are silently dropped.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to configure an SRLG with 10 member links:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router# (config)# srlg
RP/0/0/CPU0:router# (config-srlg)# interface POS 0/3/0/2
RP/0/0/CPU0:router# (config-srlg-if)# value 10
```

Related Commands

Command	Description
interface (MPLS-TE), on page 236	Enables MPLS-TE on an interface and enters MPLS-TE interface configuration mode.
mpls traffic-eng, on page 265	Enters MPLS-TE configuration mode.

switching (GMPLS)

To configure TE-link switching attributes, use the **switching** command in MPLS-TE interface configuration mode. To return to the default behavior, use the **no** form of this command.

switching {*key value*| *link*} [*capability switching*| **encoding** *encoding type*]

no switching {*key value*| *link*} [*capability switching*| **encoding** *encoding type*]

Syntax Description

key	Configures the Interface Switching Capability Key.
<i>value</i>	Local interface switching capability key value. Range is 1 to 99.
link	Enables link switching.
capability <i>switching</i>	(Optional) Configures switching capability type.
encoding <i>encoding type</i>	(Optional) Enables local encoding. Range is 1 to 99.

Command Default

No default behavior or values

Command Modes

MPLS-TE interface configuration

Command History

Release	Modification
Release 3.3.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note

The LMP and GMPLS-NNI features are not supported on x86 RPs.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to configure interface switching key on Packet-over-SONET/SDH (POS) interface 0/7/0/1:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# interface POS 0/7/0/1
RP/0/0/CPU0:router(config-mpls-te-if)# switching key 66
```

Related Commands

Command	Description
lmp hello (GMPLS), on page 255	Configures LMP IPCC management hello settings.
match (GMPLS), on page 261	Configures or matches active and passive tunnels.
passive (GMPLS), on page 288	Configures passive GMPLS tunnels.
remote (GMPLS), on page 323	Configures remote TE links.

switching endpoint (GMPLS)

To specify the switching capability and encoding types for all endpoint TE links used to signal the optical tunnel that is mandatory to set up the GMPLS LSP, use the **switching endpoint** command in interface tunnel-gte configuration mode. To disable this feature, use the **no** form of this command.

switching endpoint *capability switching type* [**encoding** *encoding type*]

no switching endpoint *capability switching type* [**encoding** *encoding type*]

Syntax Description

capability switching type Capability switching type is the optical LSP switching capability descriptor. The following types are used:

pscl

Specifies Packet-Switch Capable-1 that is equivalent to numeric 1.

lsc

Specifies Lambda-Switch Capable that is equivalent to numeric 150.

fsc

Specifies Fiber-Switch Capable that is equivalent to numeric 200.

encoding *encoding type* (Optional) Specifies the transport capability of the TE link over which the GMPLS LSP is established. For SONET links, the encoding is specified as sonetsdh. For Ethernet links, the encoding is specified as ethernet.

Command Default

No default behavior or values

Command Modes

Interface tunnel-gte configuration

Command History

Release	Modification
Release 3.3.2	This command was introduced.
Release 3.8.0	GMPLS interfaces are used under the tunnel-gte interface type.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

GMPLS interfaces are used under the tunnel-gte interface type.

Use the **switching endpoint** command to configure the optical LSP.

The switching and encoding types must match with the configured values at the termination point of the LSP.

**Note**

The LMP and GMPLS-NNI features are not supported on x86 RPs.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to configure switching capability as psc1 and the encoding type as sonetsdh for the **switching endpoint** command:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-gte 1
RP/0/0/CPU0:router(config-if)# ipv4 address 99.99.99.2 255.255.255.254
RP/0/0/CPU0:router(config-if)# signalled-name tunnel-gte1
RP/0/0/CPU0:router(config-if)# switching endpoint psc1 encoding sonetsdh
RP/0/0/CPU0:router(config-if)# priority 2 2
RP/0/0/CPU0:router(config-if)# signalled-bandwidth 2488320
RP/0/0/CPU0:router(config-if)# destination 109.109.109.109
RP/0/0/CPU0:router(config-if)# path-option 1 explicit name g1-p1-p2
RP/0/0/CPU0:router(config-if)# path-option protecting 1 explicit name g2-p1-p2
```

Related Commands

Command	Description
interface tunnel-gte , on page 240	Configures an MPLS-TE tunnel interface for GMPLS interfaces.
switching transit (GMPLS) , on page 443	Specifies the switching capability and encoding types for all transit TE links used to signal the optical tunnel.

switching transit (GMPLS)

To specify the switching capability and encoding types for all transit TE links used to signal the optical tunnel to configure an optical LSP, use the **switching transit** command in interface tunnel-gte configuration mode. To disable this feature, use the **no** form of this command.

switching transit *capability switching type* [**encoding** *encoding type*]

no switching transit *capability switching type* [**encoding** *encoding type*]

Syntax Description

capability switching type Capability switching type is the optical LSP switching capability descriptor. The following types are used:

pscl

Specifies Packet-Switch Capable-1 that is equivalent to numeric 1.

lsc

Specifies Lambda-Switch Capable that is equivalent to numeric 150.

fsc

Specifies Fiber-Switch Capable that is equivalent to numeric 200.

encoding *encoding type* (Optional) Specifies the transport capability of the TE link over which the GMPLS LSP is established. For SONET links, the encoding is specified as sonetsdh. For Ethernet links, the encoding is specified as ethernet.

Command Default

No default behavior or values

Command Modes

Interface tunnel-gte configuration

Command History

Release	Modification
Release 3.3.2	This command was introduced.
Release 3.8.0	GMPLS interfaces are used under the tunnel-gte interface type.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

GMPLS interfaces are used under the tunnel-gte interface type.

Use the **switching transit** command to configure the optical LSP.

The switching and encoding types must match with the configured values at the termination point of the LSP.

**Note**

The LMP and GMPLS-NNI features are not supported on x86 RPs.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to configure switching capability as lsc and the encoding type as sonetsdh for the **switching transit** command:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface tunnel-gte1
RP/0/0/CPU0:router(config-if)# ipv4 address 99.99.99.2 255.255.255.254
RP/0/0/CPU0:router(config-if)# signalled-name tunnel-gte1
RP/0/0/CPU0:router(config-if)# switching transit lsc encoding sonetsdh
RP/0/0/CPU0:router(config-if)# priority 2 2
RP/0/0/CPU0:router(config-if)# signalled-bandwidth 2488320
RP/0/0/CPU0:router(config-if)# destination 109.109.109.109
RP/0/0/CPU0:router(config-if)# path-option 1 explicit name g1-p1-p2
RP/0/0/CPU0:router(config-if)# path-option protecting 1 explicit name g2-p1-p2
```

Related Commands

Command	Description
interface tunnel-gte , on page 240	Configures an MPLS-TE tunnel interface for GMPLS interfaces.
switching endpoint (GMPLS) , on page 441	Specifies the switching capability and encoding types for all endpoint TE links used to signal the optical tunnel.

timers loose-path (MPLS-TE)

To configure the period between the headend retries after path errors, use the **timers loose-path** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

timers loose-path retry-period *value*

no timers loose-path retry-period *value*

Syntax Description

retry-period <i>value</i>	Configures the time, in seconds, between retries upon a path error. Range is 30 to 600.

Command Default

value: 120

Command Modes

MPLS-TE configuration

Command History

Release	Modification
Release 3.4.0	This command was introduced .

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to the period between retries after path errors to 300 seconds:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# timers loose-path retry-period 300
```

Related Commands

Command	Description
mpls traffic-eng , on page 265	Enters MPLS-TE configuration mode.

Command	Description
path-selection loose-expansion affinity (MPLS-TE), on page 295	Specifies the affinity value to be used to expand a path to the next loose hop for a tunnel on an area border router.

timers removal unused (auto-tunnel backup)

To configure the frequency at which a timer scans backup autotunnels and removes tunnels that are not in use, use the **timers removal unused (auto-tunnel backup)** command in auto-tunnel backup configuration mode. To return to the default behavior, use the **no** form of this command.

timers removal unused *frequency*

no timers removal unused *frequency*

Syntax Description

<i>frequency</i>	Frequency, in minutes, between backup autotunnel scans to remove tunnels that are not used. Range is 0; 5 to 10080 minutes (7 days). A value of 0 disables the scanning and removal of tunnels.

Command Default

frequency: 60

Command Modes

auto-tunnel backup configuration

Command History

Release	Modification
Release 4.0.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **unused** auto-tunnel backup tunnel is the tunnel that is not assigned to protect any FRR tunnel.

Task ID

Task ID	Operation
mpls-te	read, write

Examples

The following example shows that unused automatic backup tunnels are removed after the 10 minute timer scan is reached.

```
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# auto-tunnel backup
RP/0/0/CPU0:router(config-te-auto-bk)# timers removal unused 10
```

Related Commands

Command	Description
show mpls traffic-eng auto-tunnel backup unused	Displays the unused backup tunnels only.
auto-tunnel backup (MPLS-TE), on page 174	Builds automatic next-hop and next-next-hop tunnels, and enters auto-tunnel configuration mode.

topology holddown sigerr (MPLS-TE)

To specify the time that a router should ignore a link in its TE topology database in tunnel path constrained shortest path first (CSPF) computations following a TE tunnel signaling error on the link, use the **topology holddown sigerr** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

topology holddown sigerr *seconds*

no topology holddown sigerr *seconds*

Syntax Description

<i>seconds</i>	Time that the router ignores a link during tunnel path calculations, following a TE tunnel error on the link, specified in seconds. Range is 0 to 300. Default is 10.

Command Default

seconds: 10

Command Modes

MPLS-TE configuration

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

A router at the headend for TE tunnels can receive a Resource Reservation Protocol (RSVP) No Route error message before the router receives a topology update from the IGP routing protocol announcing that the link is down. When this happens, the headend router ignores the link in subsequent tunnel path calculations to avoid generating paths that include the link and are likely to fail when signaled. The link is ignored until the router receives a topology update from its IGP or a link holddown timeout occurs. Use the **topology holddown sigerr** command to change the link holddown time from its 10-second default value.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to set the link holddown time for signaling errors at 15 seconds:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# topology holddown sigerr 15
```

Related Commands

Command	Description
mpls traffic-eng , on page 265	Enters MPLS-TE configuration mode.
show mpls traffic-eng topology , on page 391	Displays the current MPLS-TE global topology of this node as well as the signaling error holddown time.

tunnel-id (auto-tunnel backup)

To configure the range of tunnel interface numbers to be used for automatic backup tunnels, use the **tunnel-id** command in auto-tunnel backup configuration mode. To delete the automatic backup tunnels, use the **no** form of this command.

tunnel-id *min number max number*
no tunnel-id

Syntax Description

min	(Optional) Minimum number for automatic backup tunnels.
<i>number</i>	Valid values are from 0 to 65535.
max	(Optional) Maximum number for automatic backup tunnels.

Command Default

No default behavior or values

Command Modes

Auto-tunnel backup configuration

Command History

Release	Modification
Release 4.0.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

If you increase the tunnel ID range, the automatic backup tunnels that failed earlier will get created the next time automatic backup assignments are processed.

Restrictions:

- Command is rejected if the **max** value minus **min** value is $\geq 1K$.
- Command is rejected if **min** value $>$ **max** value.
- Command is rejected if **min** value is greater than the tunnel ID of an existing automatic backup tunnel.
- Command is rejected if **max** value is smaller than the tunnel ID of an existing automatic backup tunnel.
- Command is rejected if a statically configured tunnel ID matches with the configured **min** and **max** range of values.
- Command is rejected if a static backup assignment is already configured to a tunnel with an ID within the **min** value / **max** value range.

Task ID

Task ID	Operation
mple-te	read, write

Examples

The following example allows 800 automatic backup tunnels to be created:

```
RP/0/0/CPU0:router(config)# mpls traffic-eng
RP/0/0/CPU0:router(config-mpls-te)# auto-tunnel backup
RP/0/0/CPU0:router(config-te-auto-bk)# tunnel-id min 1200 max 2000
```

Related Commands

Command	Description
auto-tunnel backup (MPLS-TE), on page 174	Builds automatic next-hop and next-next-hop tunnels, and enters auto-tunnel configuration mode.



RSVP Infrastructure Commands

This module describes the commands to configure and use Resource Reservation Protocol (RSVP). RSVP is a signaling protocol used to set up, maintain, and control end-to-end quality-of-service (QoS) reservations over IP. RSVP is specified in Internet Engineering Task Force (IETF) RFC 2205 (<ftp://ftp.isi.edu/in-notes/rfc2205.txt>).

The protocol has been extended to signal Multiprotocol Label Switching traffic engineering (MPLS-TE) tunnels, as specified in the IETF RFC 3209, *RSVP-TE: Extensions to RSVP for LSP Tunnels* and Optical UNI tunnels, as specified in the Optical Internetworking Forum (OIF) document OIF2000.125.7, *User Network Interface (UNI) 1.0, Signalling Specification*. The RSVP implementation supports fault handling as specified in IETF RFC 3473, *Generalized Multiprotocol Label Switching (GMPLS) Signaling RSVP-TE extensions*. The RSVP implementation also supports cryptographic authentication and refresh overhead reduction as specified in the RFC2747, *RSVP Cryptographic Authentication* and RFC2961, *RSVP Refresh Overhead Reduction Extensions* respectively.

For detailed information about MPLS concepts, configuration tasks, and examples, see *Cisco IOS XR MPLS Configuration Guide for the Cisco XR 12000 Series Router*.

Disable or Enable RSVP Message Checksum

Starting from Cisco IOS XR Release 4.0 RSVP computes and sets the checksum field on all outgoing RSVP messages, by default. RSVP also verifies the received checksum on all RSVP received messages to ensure its integrity.

A CLI is provided to override this default behavior and revert to the behavior exhibited in prior releases, whereby RSVP neither computes or sets the RSVP checksum field on outgoing RSVP messages, nor does it verify the checksum on received RSVP messages. This CLI is :

```
RP/0/0/CPU0:router(config)#rsvp signalling checksum disable
```



Note

When the **rsvp signalling checksum disable** command is configured, RSVP sets a zero checksum on all outgoing RSVP messages and ignores the checksum on all received RSVP incoming messages.

- [authentication \(RSVP\)](#), page 456
- [bandwidth \(RSVP\)](#), page 458
- [bandwidth mam \(RSVP\)](#), page 460

- [bandwidth rdm \(RSVP\), page 462](#)
- [clear rsvp authentication, page 464](#)
- [clear rsvp counters authentication, page 466](#)
- [clear rsvp counters all, page 468](#)
- [clear rsvp counters chkpt, page 470](#)
- [clear rsvp counters events, page 472](#)
- [clear rsvp counters messages, page 474](#)
- [clear rsvp counters oor, page 476](#)
- [clear rsvp counters prefix-filtering, page 478](#)
- [key-source key-chain \(RSVP\), page 480](#)
- [life-time \(RSVP\), page 482](#)
- [rsvp , page 484](#)
- [rsvp interface, page 485](#)
- [rsvp neighbor, page 487](#)
- [show rsvp authentication, page 489](#)
- [show rsvp counters, page 495](#)
- [show rsvp counters oor, page 499](#)
- [show rsvp counters prefix-filtering, page 501](#)
- [show rsvp fast-reroute, page 504](#)
- [show rsvp graceful-restart, page 507](#)
- [show rsvp hello instance, page 511](#)
- [show rsvp hello instance interface-based, page 514](#)
- [show rsvp interface, page 516](#)
- [show rsvp request, page 519](#)
- [show rsvp reservation, page 521](#)
- [show rsvp sender, page 524](#)
- [show rsvp session, page 527](#)
- [signalling dscp \(RSVP\), page 530](#)
- [signalling graceful-restart, page 532](#)
- [signalling hello graceful-restart refresh interval, page 534](#)
- [signalling hello graceful-restart refresh misses, page 536](#)
- [signalling prefix-filtering access-list, page 538](#)
- [signalling prefix-filtering default-deny-action, page 540](#)

- [signalling rate-limit, page 542](#)
- [signalling refresh interval, page 544](#)
- [signalling refresh missed, page 546](#)
- [signalling refresh reduction bundle-max-size, page 548](#)
- [signalling refresh reduction disable, page 550](#)
- [signalling refresh reduction reliable, page 552](#)
- [signalling refresh reduction summary, page 555](#)
- [window-size \(RSVP\), page 557](#)

authentication (RSVP)

To enter RSVP authentication mode, use the **authentication** command in global configuration mode, RSVP interface configuration mode, or RSVP neighbor configuration mode. To remove authentication parameters in the applicable mode, use the **no** form of this command.

authentication

no authentication

Syntax Description This command has no arguments or keywords.

Command Default The default value is no authentication, which means that the feature is disabled.

Command Modes

- Global configuration
- RSVP interface configuration
- RSVP neighbor configuration

Command History	Release	Modification
	Release 3.4.1	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	mpls-te	read, write
	ouni	read, write

Examples The following example shows how to enter RSVP authentication configuration mode from global configuration mode:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp authentication
RP/0/0/CPU0:router(config-rsvp-auth)#
```

The following example shows how to activate the RSVP on an interface and enter RSVP authentication configuration mode:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp interface pos 0/2/1/0
RP/0/0/CPU0:router(config-rsvp-if)# authentication
RP/0/0/CPU0:router(config-rsvp-if-auth)#
```

The following example shows how to configure the RSVP neighbor with IP address 1.1.1.1 and enter neighbor authentication configuration mode:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp neighbor 1.1.1.1 authentication
RP/0/0/CPU0:router(config-rsvp-nbor-auth)#
```

Related Commands

Command	Description
key-source key-chain (RSVP) , on page 480	Specifies the source of the key information to authenticate RSVP signaling messages.
life-time (RSVP) , on page 482	Controls how long RSVP maintains idle security associations with trusted neighbors.
window-size (RSVP) , on page 557	Specifies the tolerance to accept out-of-sequence messages.

bandwidth (RSVP)

To configure RSVP bandwidth on an interface using prestandard DS-TE mode, use the **bandwidth** command in RSVP interface configuration mode. To reset the RSVP bandwidth on that interface to its default value, use the **no** form of this command.

bandwidth [*total-reservable-bandwidth* [*largest-reservable-flow*] [**sub-pool** *reservable-bw*]] [**global-pool** *bandwidth* [**sub-pool** *reservable-bw*]] [**bc0** *bandwidth* [**bc1** *reservable-bw*]]

no bandwidth

Syntax Description

<i>total-reservable-bandwidth</i>	(Optional) Total reservable bandwidth (in Kbps, Mbps or Gbps) that RSVP accepts for reservations on this interface. Range is 0 to 4294967295.
<i>largest-reservable-flow</i>	(Optional) Largest reservable flow (in Kbps, Mbps or Gbps) that RSVP accepts for reservations on this interface. Range is 0 to 4294967295.
sub-pool <i>reservable-bw</i>	(Optional) Configures the total reservable bandwidth in the sub-pool (in Kbps, Mbps, or Gbps). Range is 0 to 4294967295.
bc0 <i>bandwidth</i>	(Optional) Configures the total reservable bandwidth in the bc0 pool (in Kbps, Mbps or Gbps). The default is Kbps. Range is 0 to 4294967295.
bc1 <i>reservable-bw</i>	(Optional) Configures the total reservable bandwidth in the bc1 pool (in Kbps, Mbps or Gbps).
global-pool <i>bandwidth</i>	(Optional) Configures the total reservable bandwidth in the global-pool. Range is 0 to 4294967295 Kbps.

Command Default

sub-pool-bw: 0



Note

If the command is entered without the optional arguments, the total bandwidth is set to 75 percent of the intrinsic bandwidth of the interface. (If the interface has zero intrinsic bandwidth, none are reserved.)

Command Modes

RSVP interface configuration

Command History

Release	Modification
Release 3.2	This command was supported.
Release 3.7.0	The sub-pool keyword was added.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

RSVP is enabled either using the **rsvp interface** command or when MPLS is configured on the interface. In addition, there are other instances in which RSVP is enabled automatically; for example, when an RSVP message is received on an interface that is not configured under RSVP or MPLS (such as out-of-band signaling for an Optical User Network Interface application).

If RSVP reservation messages are received on an interface different from the one through which the corresponding Path message was sent out, the interfaces are adjusted such that all resource reservations, such as bandwidth, are done on the outgoing interface of the Path message.

Prestandard DS-TE uses the Cisco proprietary mechanisms for RSVP signaling and IGP advertisements. This DS-TE mode does not interoperate with third-party vendor equipment. Note that prestandard DS-TE is enabled only after configuring the sub-pool bandwidth values on MPLS-enabled interfaces.

**Note**

You can also configure RSVP bandwidth on an interface using IETF DS-TE mode. This mode supports multiple bandwidth constraint models, including the Russian Doll Model (RDM) and the Maximum Allocation Model (MAM) both with two bandwidth pools.

Task ID

Task ID	Operations
mpls-te	read, write
ouni	read, write

Examples

The following example shows how to limit the total of all RSVP reservations on POS interface 0/3/0/0 to 5000 Kbps:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp interface pos 0/3/0/0
RP/0/0/CPU0:router(config-rsvp-if)# bandwidth 5000
```

Related Commands

Command	Description
bandwidth mam (RSVP), on page 460	Configures RSVP bandwidth on an interface using the MAM bandwidth constraints model.
bandwidth rdm (RSVP), on page 462	Configures RSVP bandwidth on an interface using the RDM bandwidth constraints model.

bandwidth mam (RSVP)

To configure RSVP bandwidth on an interface using the Maximum Allocation Model (MAM) bandwidth constraints model, use the **bandwidth mam** command in RSVP interface configuration mode. To return to the default behavior, use the **no** form of this command.

bandwidth mam {*total-reservable-bandwidth*| **max-reservable-bw** *maximum-reservable-bw*}
[*largest-reservable-flow* [**bc0** *reservable-bandwidth*] [**bc1** *reservable-bw*]]

no bandwidth mam

Syntax Description

<i>total-reservable- bandwidth</i>	Total reservable bandwidth (in Kbps, Mbps or Gbps) that RSVP accepts for reservations on this interface. Range is 0 to 4294967295.
max-reservable-bw <i>maximum-reservable-bw</i>	Configures the maximum reservable bandwidth (in Kbps, Mbps or Gbps) that RSVP accepts for reservations on this interface. Range is 0 to 4294967295.
<i>largest-reservable-flow</i>	(Optional) Largest reservable flow (in Kbps, Mbps or Gbps) that RSVP accepts for reservations on this interface. Range is 0 to 4294967295.
bc0 <i>reservable-bandwidth</i>	(Optional) Configures the total reservable bandwidth in the bc0 pool (in Kbps, Mbps or Gbps).
bc1 <i>reservable-bw</i>	(Optional) Configures the total reservable bandwidth in the bc1 pool (in Kbps, Mbps or Gbps).

Command Default

No default behavior or values.

Command Modes

RSVP interface configuration

Command History

Release	Modification
Release 3.3.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Both the MAM and RDM models can be configured on a single interface to allow switching between each model.

**Note**

Non-stop forwarding (NSF) is not guaranteed when the bandwidth constraint model is changed.

Task ID

Task ID	Operations
mpls-te	read, write
ouni	read, write

Examples

The following example shows how to limit the total of all RSVP reservations on POS interface 0/3/0/0 to 7500 kbps:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp interface pos 0/3/0/0
RP/0/0/CPU0:router(config-rsvp-if)# bandwidth mam 7500
```

Related Commands

Command	Description
bandwidth (RSVP), on page 458	Configures RSVP bandwidth on an interface using prestandard DS-TE mode.
bandwidth rdm (RSVP), on page 462	Configures RSVP bandwidth on an interface using the RDM bandwidth constraints model.

bandwidth rdm (RSVP)

To configure RSVP bandwidth on an interface using the Russian Doll Model (RDM) bandwidth constraints model, use the **bandwidth rdm** command in RSVP interface configuration mode. To return to the default behavior, use the **no** form of this command.

bandwidth rdm {*total-reservable-bw*| **bc0** *total-reservable-bw*| **global-pool** *total-reservable-bw*}
[*largest-reservable-flow*] [**bc1** *reservable-bw*] [**sub-pool** *reservable-bw*]

no bandwidth rdm

Syntax Description

<i>total-reservable-bw</i>	Total reservable bandwidth (in Kbps, Mbps or Gbps). The default value is expressed in Kbps.
bc0 <i>total-reservable-bw</i>	Reserves bandwidth in the bc0 pool (in Kbps, Mbps or Gbps).
global-pool	Reserves bandwidth in the global pool.
<i>largest-reservable-flow</i>	(Optional) Largest reservable flow (in Kbps, Mbps or Gbps). The default value is expressed in Kbps.
bc1	(Optional) Reserves bandwidth in the bc1 pool (in Kbps, Mbps or Gbps).
sub-pool	(Optional) Reserves bandwidth in the sub-pool.
<i>reservable-bandwidth</i>	Reservable bandwidth in the sub- and bc1 pools (in Kbps, Mbps or Gbps). The default value is expressed in Kbps.

Command Default

No default behavior or values.

Command Modes

RSVP interface configuration

Command History

Release	Modification
Release 3.3.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Both the MAM and RDM bandwidth constraint models support up to two bandwidth pools.

Cisco IOS XR software provides global configuration when switching between bandwidth constraint models. Both models are configured on a single interface to allow switching between models.

**Note**

Non-stop forwarding (NSF) is not guaranteed when the bandwidth constraint model is changed.

The **global pool** and **sub-pool** keywords are included in this command for backward compatibility with prestandard DS-TE. The **global pool** keyword is equivalent to the **bc0** keyword. The **sub-pool** keyword is equivalent to the **bc1** keyword.

RDM is the default bandwidth constraint model used in both pre-standard and IETF mode.

Task ID

Task ID	Operations
mpls-te	read, write
ouni	read, write

Examples

The following example shows how to limit the total of all RSVP reservations on POS interface 0/3/0/0 to 7500 kbps, and allows each single flow to reserve no more than 1000 kbps:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp interface pos 0/3/0/0
RP/0/0/CPU0:router(config-rsvp-if)# bandwidth rdm 7500 1000
```

Related Commands

Command	Description
bandwidth (RSVP), on page 458	Configures RSVP bandwidth on an interface using prestandard DS-TE mode.
bandwidth mam (RSVP), on page 460	Configures RSVP bandwidth on an interface using the MAM bandwidth constraints model.

clear rsvp authentication

To eliminate RSVP security association (SA) before the lifetime expires, use the **clear rsvp authentication** command in EXEC mode.

clear rsvp authentication [*type interface-path-id*] [**destination** *IP address*] [**source** *IP address*]

Syntax Description

<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
destination <i>IP address</i>	(Optional) Eliminates the RSVP security associations (SA) before their lifetimes expire. All SAs with this destination IP address are cleared.
source <i>IP address</i>	(Optional) Eliminates the RSVP security associations (SA) before their lifetimes expire. All SAs with this source IP address are cleared.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.4.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **clear rsvp authentication** command for the following reasons:

- To eliminate security associations before their lifetimes expire
- To free up memory
- To resolve a problem with a security association being in an indeterminate state

You can delete all RSVP security associations if you do not enter an optional filter (interface, source, or destination IP address).

If you delete a security association, it is recreated as needed.

Task ID

Task ID	Operations
mpls-te	execute
ouni	execute

Examples

The following example shows how to clear each SA:

```
RP/0/0/CPU0:router# clear rsvp authentication
```

The following example shows how to clear each SA with the destination address 1.1.1.1:

```
RP/0/0/CPU0:router# clear rsvp authentication destination 1.1.1.1
```

The following example shows how to clear each SA with the source address 2.2.2.2:

```
RP/0/0/CPU0:router# clear rsvp authentication source 2.2.2.2
```

The following example shows how to clear each SA with the POS interface 0/2/1/0:

```
RP/0/0/CPU0:router# clear rsvp authentication POS 0/2/1/0
```

The following example shows how to clear each SA on the POS interface 0/2/1/0, destination address 1.1.1.1, and source address 2.2.2.2:

```
RP/0/0/CPU0:router# clear rsvp authentication POS 0/2/1/0 destination 1.1.1.1 source 2.2.2.2
```

Related Commands

Command	Description
life-time (RSVP), on page 482	Controls how long RSVP maintains idle security associations with other trusted RSVP neighbors.

clear rsvp counters authentication

To eliminate RSVP counters for each security association (SA), use the **clear rsvp counters authentication** command in EXEC mode.

clear rsvp counters authentication [*type interface-path-id*] [**destination** *IP address*][**source** *IP address*]

Syntax Description

<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
destination <i>IP address</i>	(Optional) Eliminates authentication-related statistics for each security association (SA) with this destination IP address.
source <i>IP address</i>	(Optional) Eliminates authentication-related statistics for each security association (SA) with this source IP address.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.4.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	execute
ouni	execute

Examples

The following example shows how to clear authentication counters for each SA:

```
RP/0/0/CPU0:router# clear rsvp counters authentication
```

The following example shows how to clear authentication counters for each SA with the destination address 1.1.1.1:

```
RP/0/0/CPU0:router# clear rsvp counters authentication destination 1.1.1.1
```

The following example shows how to clear authentication counters for each SA with the source address 2.2.2.2:

```
RP/0/0/CPU0:router# clear rsvp counters authentication source 2.2.2.2
```

The following example shows how to clear authentication counters for each SA with the POS interface 0/2/1/0:

```
RP/0/0/CPU0:router# clear rsvp counters authentication POS 0/2/1/0
```

The following example shows how to clear authentication counters for each SA on the POS interface 0/2/1/0, destination address 1.1.1.1, and source address 2.2.2.2:

```
RP/0/0/CPU0:router# clear rsvp counters authentication POS 0/2/1/0 destination 1.1.1.1  
source 2.2.2.2
```

clear rsvp counters all

To clear (set to zero) all RSVP message and event counters that are being maintained by the router, use the **clear rsvp counters all** command in EXEC mode.

clear rsvp counters all [*type interface-path-id*]

Syntax Description

<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	read, write
ouni	read, write

Examples

The following example shows how to clear all message and event counters:

```
RP/0/0/CPU0:router# clear rsvp counters all
```


Related Commands

Command	Description
clear rsvp counters events, on page 472	Clears all RSVP event counters that are being maintained by the router.
clear rsvp counters messages, on page 474	Clears all RSVP message counters that are being maintained by the router.
show rsvp counters, on page 495	Shows all RSVP message/event counters that are being maintained by the router.

clear rsvp counters chkpt

To clear RSVP checkpoint counters, use the **clear rsvp counters chkpt** command in EXEC mode.

clear rsvp counters chkpt

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes EXEC

Command History	Release	Modification
	Release 3.2	This command was supported.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	mpls-te	read, write
	ouni	read, write

Examples The following example shows how to clear all message and event counters:

```
RP/0/0/CPU0:router# clear rsvp counters chkpt
```

Related Commands	Command	Description
	clear rsvp counters events, on page 472	Clears all RSVP event counters that are being maintained by the router.
	clear rsvp counters messages, on page 474	Clears all RSVP message counters that are being maintained by the router.

Command	Description
show rsvp counters , on page 495	Shows all RSVP message/event counters that are being maintained by the router.

clear rsvp counters events

To clear (set to zero) all RSVP event counters that are being maintained by the router, use the **clear rsvp counters events** command in EXEC mode.

clear rsvp counters events [*type interface-path-id*]

Syntax Description

<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **clear rsvp counters events** command to set all RSVP event counters to zero.

Task ID

Task ID	Operations
mpls-te	read, write
ouni	read, write

Examples

The following example shows how to clear all event counters:

```
RP/0/0/CPU0:router# clear rsvp counters events
```

Related Commands

Command	Description
clear rsvp counters messages, on page 474	Clears all RSVP message counters that are being maintained by the router.
show rsvp counters, on page 495	Shows RSVP event counters that are being maintained by the router when the <i>events</i> option is specified.

clear rsvp counters messages

To clear (set to zero) all RSVP message counters that are being maintained by the router, use the **clear rsvp counters messages** command in EXEC mode.

clear rsvp counters messages [*type interface-path-id*]

Syntax Description

<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **clear rsvp counters messages** command to set all RSVP message counters to zero.

Task ID

Task ID	Operations
mpls-te	read, write
ouni	read, write

Examples

The following example shows how to set all RSVP message counters for POS interface 0/3/0/2 to zero:

```
RP/0/0/CPU0:router# clear rsvp counters messages pos0/3/0/2
```

Related Commands

Command	Description
show rsvp counters, on page 495	Displays the number of RSVP messages sent and received.

clear rsvp counters oor

To clear internal RSVP counters on out of resources (OOR) events, use the **clear rsvp counters oor** command in EXEC mode.

clear rsvp counters oor [*type interface-path-id*]

Syntax Description

<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **clear rsvp counters oor** command to set RSVP OOR counters to zero.

Task ID

Task ID	Operations
mpls-te	read, write
ouni	read, write

Examples

The following example show how to clear all RSVP message counters for POS interface 0/3/0/2 to zero:

```
RP/0/0/CPU0:router# clear rsvp counters oor pos0/3/0/2
```

Related Commands

Command	Description
show rsvp counters oor, on page 499	Displays the internal RSVP counters on OOR events.

clear rsvp counters prefix-filtering

To clear internal prefix-filtering related RSVP counters, use the **clear rsvp counters prefix-filtering** command in EXEC mode.

clear rsvp counters prefix-filtering {**interface** [*type interface-path-id*]| **access-list** [*aclname*]}

Syntax Description

interface	Clears RSVP prefix-filtering counters for all interfaces.
<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
access-list	Clears RSVP prefix-filtering counters for access control list.
<i>aclname</i>	(Optional) Name of the access list.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **clear rsvp counters prefix-filtering** command to set RSVP prefix-filtering related RSVP counters to zero.

Task ID

Task ID	Operations
mpls-te	read, write

Task ID	Operations
ouni	read, write

Examples

The following example shows how to set all RSVP message counters for POS interface 0/3/0/2 to zero:

```
RP/0/0/CPU0:router# clear rsvp counters prefix-filtering interface pos0/3/0/2
```

The following example shows how to set all RSVP prefix-filtering counters for access-list banks to zero:

```
RP/0/0/CPU0:router# clear rsvp counters prefix-filtering access-list banks
```

Related Commands

Command	Description
show rsvp counters prefix-filtering , on page 501	Displays the internal prefix-filtering related RSVP counters.

key-source key-chain (RSVP)

To specify the source of the key information to authenticate RSVP messages, use the **key-source key-chain** command in the appropriate RSVP authentication configuration mode. To remove the key source from the appropriate RSVP authentication configuration mode, use the **no** form of this command.

key-source key-chain *key-chain-name*

no key-source key-chain *key-chain-name*

Syntax Description

<i>key-chain-name</i>	Name of the keychain. The maximum number of characters is 32.

Command Default

The default value is none, which means that the key source is not specified.

Command Modes

RSVP authentication configuration
 RSVP interface authentication configuration
 RSVP neighbor authentication configuration

Command History

Release	Modification
Release 3.4.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note

- RSVP authentication is enabled regardless of whether or not the specified keychain exists or has no available keys to use. If the specified keychain does not exist or there are no available keys in the keychain, RSVP authentication processing fails.
- The **key-source key-chain** command does not create a keychain but just specifies which keychain to use. You must configure a keychain first. For an example of how a key chain is configured, see *Cisco IOS XR System Security Configuration Guide for the Cisco XR 12000 Series Router*.
- The **no key-source key-chain** command does not necessarily disable the authentication.
- RSVP authentication supports only keyed-hash message authentication code (HMAC)-type algorithms.

For inheritance procedures, see *Cisco IOS XR MPLS Configuration Guide for the Cisco XR 12000 Series Router*.

Task ID

Task ID	Operations
mpls-te	read, write
ouni	read, write

Examples

The following example shows that the source of the key information is specified for the keychain mpls-keys in RSVP authentication configuration mode:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp authentication
RP/0/0/CPU0:router(config-rsvp-auth)# key-source key-chain mpls-keys
```

The following example shows that the source of the key information is specified for the keychain mpls-keys for a POS interface in RSVP authentication configuration mode:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp interface POS 0/2/1/0
RP/0/0/CPU0:router(config-rsvp-if)# authentication
RP/0/0/CPU0:router(config-rsvp-if-auth)# key-source key-chain mpls-keys
```

The following example shows that the source of the key information is specified for the keychain mpls-keys in RSVP neighbor authentication configuration mode:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp neighbor 1.1.1.1 authentication
RP/0/0/CPU0:router(config-rsvp-nbor-auth)# key-source key-chain mpls-keys
```

Related Commands

Command	Description
life-time (RSVP) , on page 482	Controls how long RSVP maintains idle security associations with other trusted RSVP neighbors.
window-size (RSVP) , on page 557	Specifies the tolerance to accept out-of-sequence messages.

life-time (RSVP)

To control how long RSVP maintains idle security associations with other trusted RSVP neighbors, use the **life-time** command in the appropriate RSVP authentication configuration mode. To disable the lifetime setting, use the **no** form of this command.

life-time *seconds*

no life-time *seconds*

Syntax Description

<i>seconds</i>	Length of time, in seconds, that RSVP maintains security associations with other trusted RSVP neighbors. Range is 30 to 86400.

Command Default

seconds: 1800 (30 minutes)

Command Modes

RSVP authentication configuration
 RSVP interface authentication configuration
 RSVP neighbor authentication configuration

Command History

Release	Modification
Release 3.4.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

For inheritance procedures, see *Cisco IOS XR MPLS Configuration Guide for the Cisco XR 12000 Series Router*.

Use the **life-time (RSVP)** command to indicate when to end idle security associations with RSVP trusted neighbors.

By setting a larger lifetime, the router remembers the state for a long period time which provides better protection against a replay attack.

Use the **clear rsvp authentication** command to free security associations before their lifetimes expire.

Task ID

Task ID	Operations
mpls-te	read, write

Task ID	Operations
ouni	read, write

Examples

The following example shows how to configure a lifetime of 2000 seconds for each SA in RSVP authentication configuration mode:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp authentication
RP/0/0/CPU0:router(config-rsvp-auth)# life-time 2000
```

The following example shows how to configure a lifetime of 2000 seconds for each SA in RSVP neighbor authentication configuration mode:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp neighbor 1.1.1.1 authentication
RP/0/0/CPU0:router(config-rsvp-nbor-auth)# life-time 2000
```

The following example shows how to configure a lifetime of 2000 seconds for each SA in RSVP interface authentication configuration mode:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp interface POS 0/2/1/0
RP/0/0/CPU0:router(config-rsvp-if)# authentication
RP/0/0/CPU0:router(config-rsvp-if-auth)# life-time 2000
```

Related Commands

Command	Description
clear rsvp authentication , on page 464	Clears out RSVP security associations.
key-source key-chain (RSVP) , on page 480	Specifies the source of the key information to authenticate RSVP signaling messages.
window-size (RSVP) , on page 557	Specifies the tolerance to accept out-of-sequence messages.

rsvp

To enable functionality for Resource Reservation Protocol (RSVP) and enter RSVP configuration commands, use the **rsvp** command in global configuration mode. To return to the default behavior, use the **no** form of this command.

rsvp

no rsvp

Syntax Description	This command has no keywords or arguments.

Command Default	No default behavior or values

Command Modes	Global configuration

Command History	Release	Modification
	Release 3.2	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples	The following example shows how to enable RSVP functionality and enter the sub-mode for RSVP configuration commands:

```
RP/0/0/CPU0:router(config)# rsvp  
RP/0/0/CPU0:router(config-rsvp)#
```


rsvp interface

To configure RSVP on an interface, use the **rsvp interface** command in global configuration mode. To disable RSVP on that interface, use the **no** form of this command.

rsvp interface *type interface-path-id*

no rsvp interface *type interface-path-id*

Syntax Description

<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.

Command Default

RSVP is enabled by default on an interface under the following conditions. (Enabling RSVP on an interface means that interface can be used by RSVP to send and receive RSVP messages).

- RSVP is configured on that interface using the **rsvp interface** command.
- MPLS is configured on that interface.
- Automatically enabled as in the case of out-of-band signaling for the Optical User Network Interface (O-UNI) application, where an RSVP message could be received on an interface which is not configured under RSVP or MPLS.

Command Modes

Global configuration

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

When RSVP is enabled on an interface by any of the three methods mentioned in the above section, the default bandwidth is 0. Use the bandwidth command in RSVP interface configuration mode to configure the bandwidth on an interface.

If the interface bandwidth is 0, RSVP can be used only to signal flows that do not require bandwidth on this interface. In the case of O-UNI, 0 bandwidth is not an issue, because O-UNI does not use bandwidth as a resource.

The **rsvp interface** command enables the RSVP interface configuration mode.

Task ID

Task ID	Operations
mpls-te	read, write
ouni	read, write

Examples

The following example shows how to enable the RSVP interface configuration mode and to enable RSVP on this interface with 0 bandwidth:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp interface pos 0/3/0/0
```

Related Commands

Command	Description
bandwidth (RSVP), on page 458	Configures RSVP bandwidth on an interface using prestandard DS-TE mode.
signalling dscp (RSVP), on page 530	Gives all RSVP packets sent out on a specific interface higher priority in the network by marking them with a particular DSCP.

rsvp neighbor

To specify an RSVP neighbor, use the **rsvp neighbor** command in global configuration mode. To deactivate authentication for a neighbor, use the **no** form of this command.

rsvp neighbor *IP-address* **authentication**

no rsvp neighbor *IP-address* **authentication**

Syntax Description

<i>IP-address</i>	IP address of the neighbor. A single IP address of a specific neighbor; usually one of the neighbor's physical or logical (loopback) interfaces.
authentication	Configures RSVP authentication parameters.

Command Default

No default values or behaviors

Command Modes

Global configuration

Command History

Release	Modification
Release 3.4.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note

RSVP neighbor configuration mode can be used only if you want to configure authentication for a particular neighbor.

Task ID

Task ID	Operations
mpls-te	read, write
ouni	read, write

Examples

The following example shows how to enter RSVP neighbor authentication configuration mode for IP address 1.1.1.1:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp neighbor 1.1.1.1 authentication
RP/0/0/CPU0:router(config-rsvp-nbor-auth)#
```

Related Commands

Command	Description
key-source key-chain (RSVP) , on page 480	Specifies the source of the key information to authenticate RSVP signaling messages.
life-time (RSVP) , on page 482	Controls how long RSVP maintains idle security associations with other trusted RSVP neighbors.
window-size (RSVP) , on page 557	Specifies the tolerance to accept out-of-sequence messages.

show rsvp authentication

To display the database for the security association that RSVP has established with other RSVP neighbors, use the **show rsvp authentication** command in EXEC mode.

show rsvp authentication [*type interface-path-id*] [**destination** *IP-address*] [**detail**] [**mode** {**receive** | **send**}] [**neighbor** *IP-address*] [**source** *IP-address*]

Syntax Description

<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
destination <i>IP-address</i>	(Optional) Displays the database for the security association (SA) for the destination IP address. The <i>IP address</i> argument is the IP address of the destination address.
detail	(Optional) Displays additional information about RSVP security SAs.
mode	(Optional) Specifies the SA type. An SA is used to authenticate either incoming (receive) or outgoing (send) messages.
receive	Displays SAs for incoming messages.
send	Displays SAs for outgoing messages.
neighbor <i>IP-address</i>	(Optional) Displays the RSVP authentication information for the neighbor IP address. The <i>IP-address</i> argument is the IP address of the neighbor. For the send SA, the neighbor address is the destination address. For receive, the neighbor address is the source address.
source <i>IP-address</i>	(Optional) Displays the database for the SA for the source IP address. The <i>IP-address</i> argument is the IP address of the source address.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.4.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	read
ouni	read

Examples

The following sample output displays information for RSVP authentication:

```
RP/0/0/CPU0:router# show rsvp authentication
```

Codes: S - static, G - global, N - neighbor, I -interface, C - chain

Source Address	Dest Address	Interface	Mode	Key-Source	Key-ID	Code
3.0.0.1	3.0.0.2	PO0/7/0/2	Send	mpls-keys	1	SGC
3.0.0.2	3.0.0.1	PO0/7/0/2	Recv	mpls-keys	1	SGC

This table describes the significant fields shown in the display.

Table 57: show rsvp authentication Command Field Descriptions

Field	Description
Source Address	IP address of the sender. For Send mode, this is the local address (either the address of the Interface field or the local router ID). For Recv mode, this is the address of the RSVP neighbor.
Dest Address	IP address of the receiver. For Send mode, this is the address of the RSVP neighbor. For Recv mode, this is the local address (either the address of the Interface field or the local router ID).
Interface	Name of the interface over which the security association is being maintained.

Field	Description
Mode	Direction of the association for the following mode types: Send Authenticates messages that you forward. Recv Authenticates messages that you receive.
Key-Source	Key source identification string that is currently set to the configured keychain name.
Key-ID	The last successful key ID that is used for authentication and maps to the keychain ID configuration. If the value is too large to fit into the column, it is truncated and a (..) suffix is appended. Use the detail mode to see the non-truncated key ID.
Code	Code field has the following terms: Static Key is static and configured. Global Key is global-based. Neighbor Key is neighbor-based. Interface Key is interface-based. Chain Key is part of a keychain.

The following sample output shows detailed information about a Send mode SA that is followed by a Receive mode SA:

```
RP/0/0/CPU0:router# show rsvp authentication detail
```

```

RSVP Authentication Information:
  Source Address:      3.0.0.1
  Destination Address: 3.0.0.2
  Neighbour Address:   3.0.0.2
  Interface:           POS0/7/0/2
  Direction:           Send

```

```

LifeTime:                1800 (sec)
LifeTime left:           1305 (sec)
KeyType:                  Static Global KeyChain
Key Source:               name1
Key Status:               No error
KeyID:                    1
Digest:                   HMAC MD5 (16)
Challenge:                Not supported
TX Sequence:              5023969459702858020 (0x45b8b99b00000124)
Messages successfully authenticated: 245
Messages failed authentication: 0

Receive Errors:
  Incomplete security association: 0
  Missing INTEGRITY object: 0
  Incorrect digest: 0
  Digest type mismatch: 0
  Duplicate sequence number: 0
  Out-of-range sequence number: 0
  Invalid message format: 0

```

This table describes the significant fields shown in the display.

Table 58: show rsvp authentication detail Command Field Descriptions

Field	Description
Source Address	IP address of the sender. For Send mode, this is the local address (either the address of the Interface field or the local router ID). For Recv mode, this is the address of the RSVP neighbor.
Destination Address	IP address of the receiver. For Send mode, this is the address of the RSVP neighbor. For Recv mode, this is the local address (either the address of the Interface field or the local router ID).
Neighbor Address	IP address of the RSVP neighbor with which the security association is being maintained.
Interface	Name of the interface over which the security association is being maintained.
Direction	Direction of the association for the following mode types: Send Authenticates messages that you forward. Recv Authenticates messages that you receive.
LifeTime	Configured expiration timer value.
LifeTime left	Number of seconds until the expiration timer expires.

Field	Description
KeyType	Keys that are used: Static Key is static and configured. Global Key is global-based. Neighbor Key is neighbor-based. Interface Key is interface-based. Chain Key is part of a keychain.
Key-Source	Key source identification string that is currently set to the configured keychain name.
Key Status	Last status reported from the key source.
Key-ID	Last successful key ID that is used for authentication and that maps to the keychain ID configuration. If the value is too large to fit into the column, it is truncated and a (..) suffix is appended. (Use the detail mode to see the non-truncated key ID.)
Digest	Digest algorithm that is used. The algorithms are either HMAC-MD5 or HMAC-SHA1.
Challenge	Current challenge status (always not supported) reported.
Tx Sequence	Last sequence number that was sent.
Messages successfully authenticated	Number of messages authenticated by using this SA.
Messages failed authentication	Number of messages that failed authentication using this SA.
Sequence Window Size	Maximum configured RX sequence number window.
Sequence Window Count	Currently used size of the RX sequence number window.

Field	Description
Incomplete security association	Number of messages that are dropped due to a key failure.
Incorrect digest	Number of messages that are dropped due to an incorrect digest.
Digest type mismatch	Number of messages that are dropped due to an incorrect digest length, which implies an algorithm mismatch.
Duplicate sequence number	Number of messages that are dropped due to a duplicate sequence number.
Out-of-range sequence number	Number of messages that are dropped due to a sequence number range (window-size) checking.
Invalid message format	Number of messages that are dropped due to formatting errors, such as incorrect objects.

show rsvp counters

To display internal RSVP counters, use the **show rsvp counters** command in EXEC mode.

show rsvp counters {**messages** [*type interface-path-id*] **summary** || **events** | **database**}

Syntax Description

messages	Displays a historical count of the number of messages RSVP has received and sent on each interface along with a summation.
<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
summary	(Optional) Displays the aggregate counts of all interfaces.
events	Displays the number of states expired for lack of refresh and a count of received No Acknowledgements (NACKs).
database	Displays counters on RSVP database, including number of paths, session, and so on.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was supported on the Cisco XR 12000 Series Router. The database keyword was added.
Release 3.9.0	The summary keyword was added.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

In message counters, bundle messages are counted as single bundle messages. The component messages are not counted separately.

The **messages** keyword shows the counters for all the interfaces. In addition, the aggregate summary is shown by using both the **messages** and **summary** keywords.

Task ID

Task ID	Operations
mpls-te	read, write
ouni	read, write

Examples

The following is sample output from the **show rsvp counters messages** command for POS0/3/0/0:

```
RP/0/0/CPU0:router# show rsvp counters messages POS 0/3/0/0
```

POS0/3/0/0	Recv	Xmit		Recv	Xmit
Path	24	1	Resv	0	0
PathError	0	0	ResvError	0	0
PathTear	5	1	ResvTear	0	0
ResvConfirm	0	0	Ack	34	0
Bundle	0		Hello	0	0
SRefresh	10118	0	OutOfOrder	0	
Retransmit		0	Rate Limited		0

This table describes the significant fields shown in the display.

Table 59: show rsvp counters messages Command Field Descriptions

Field	Description
Path	Number of Path messages sent downstream or received from an upstream node.
PathError	Number of PathError messages received from a downstream neighbor or sent to an upstream neighbor.
PathTear	Number of PathTear messages sent downstream, or messages received, from upstream neighbors.
ResvConfirm	Number of ResvConfirm messages received from an upstream neighbor or sent to a downstream neighbor.
Bundle	Number of Bundle messages containing RSVP messages sent and received by the neighbor.
SRefresh	Number of Summary Refresh messages sent to and received by a neighbor to refresh the path and reservation states.
Retransmit	Number of messages retransmitted to ensure reliable messaging (related to refresh reduction).

Field	Description
Resv	Number of Reservation messages received from a downstream neighbor or sent to an upstream neighbor to reserve resources.
ResvError	Number of Reservation Error messages received from a upstream neighbor or sent to a downstream neighbor.
ResvTear	Number of Reservation Tear messages received from a downstream neighbor or sent to an upstream neighbor to tear down RSVP flows.
Ack	Number of Acknowledgement messages sent and received by a neighbor acknowledging receipt of a message.
Hello	Number of Hello messages sent to and received by a neighbor.
OutOfOrder	Number of messages received that are out of order.
Rate Limited	Number of RSVP packets affected by rate limiting.

The following is sample output from the **show rsvp counters events** command:

```
RP/0/0/CPU0:router# show rsvp counters events

Ethernet0/0/0/0                                tunnel1
  Expired Path states                          0          Expired Path states          0
  Expired Resv states                          0          Expired Resv states          0
  NACKs received                              0          NACKs received              0
POS0/3/0/1                                     POS0/3/0/2
  Expired Path states                          0          Expired Path states          0
  Expired Resv states                          0          Expired Resv states          0
  NACKs received                              0          NACKs received              0
POS0/3/0/3                                     All RSVP Interfaces
  Expired Path states                          0          Expired Path states          0
  Expired Resv states                          0          Expired Resv states          0
  NACKs received                              0          NACKs received              0
```

This table describes the significant fields shown in the display.

Table 60: show rsvp counters events Command Field Descriptions

Field	Description
Expired Path states	Number of Path states expired for lack of refresh.
Expired Reserve states	Number of Resv states expired for lack of refresh.
NACKS received	Number of NACKS received.

The following is sample output from the **show rsvp counters database** command:

```
RP/0/0/CPU0:router# show rsvp counters database

Sessions: 0
Locally created and incoming paths: 0
Outgoing paths: 0
Locally created and incoming Reservations: 0
Outgoing Reservations: 0
Interfaces: 4
```

This table describes the significant fields shown in the display.

Table 61: show rsvp counters database Command Field Descriptions

Field	Description
Sessions	RSVP sessions.
Locally created and incoming paths	Path states created by a: • Local application on the node. • Path message received from the network.
Outgoing paths	Outgoing path states.
Locally created and incoming Reservations	Reservations created by a: • Local application on the node. • Path message received from the network.
Outgoing Reservations	Outgoing reservation (request) states.
Interfaces	Known RSVP interfaces.

show rsvp counters oor

To display internal RSVP counters on out of resources (OOR) events, use the **show rsvp counters oor** command in EXEC mode.

show rsvp counters oor [*type interface-path-id*] **summary**

Syntax Description

<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
summary	(Optional) Displays a summary of OOR events.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	read, write
ouni	read, write

Examples

The following is sample output from the **show rsvp counters oor** command:

```
RP/0/0/CPU0:router# show rsvp counters oor
```

```
POS 0/3/0/0          Rejected
  Path                24
POS 0/3/0/2          Rejected
  Path                31
All RSVP Interfaces  Rejected
  Path                55
```

This table describes the significant fields shown in the display.

Table 62: show rsvp counters oor Command Field Descriptions

Field	Description
Path	Number of Path messages received on the interface that were rejected due to oor conditions.

show rsvp counters prefix-filtering

To display internal prefix-filtering related RSVP counters, use the **show rsvp counters prefix-filtering** command in EXEC mode.

show rsvp counters prefix-filtering interface [*type interface-path-id*] **summary**] **access-list** [*aclname*]

Syntax Description

interface	Displays RSVP prefix-filtering counters for all interfaces.
<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
summary	(Optional) Displays a summary of RSVP prefix-filtering counters on all interfaces.
access-list	Displays RSVP prefix-filtering counters for the access control list.
<i>aclname</i>	(Optional) Name of the access control list.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note

Counters do not increment if you have not configured an access control list for prefix-filtering.

Task ID

Task ID	Operations
mpls-te	read, write
ouni	read, write

Examples

The following is sample output from the **show rsvp counters prefix-filtering** command:

RP/0/0/CPU0:router# **show rsvp counters prefix-filtering interface**

Routed	Fwd	Local	Drop	Def-Drop	Def-Proc	Total
Path	4					4
PathTear	0					0
ResvConfirm	0					0
Total	4					4
POS0/5/0/1	Fwd	Local	Drop	Def-Drop	Def-Proc	Total
Path		1	0	219	2	222
PathTear		0	0	31	0	31
ResvConfirm		0	0	0	0	0
Total		1	0	219	2	253
POS0/5/0/2	Fwd	Local	Drop	Def-Drop	Def-Proc	Total
Path		0	0	0	1	1
PathTear		0	0	0	0	0
ResvConfirm		0	0	0	0	0
Total		0	0	0	1	1
ALL RSVP						
Interfaces	Fwd	Local	Drop	Def-Drop	Def-Proc	Total
Path	4	1	0	219	3	227
PathTear	0	0	0	31	0	31
ResvConfirm	0	0	0	0	0	0
Total	4	1	0	250	3	258

The following is sample output from the **show rsvp counters prefix-filtering interface type interface-path-id** command:

RP/0/0/CPU0:router# **show rsvp counters prefix-filtering interface POS 0/5/0/1**

POS0/5/0/1	Fwd	Local	Drop	Def-Drop	Def-Proc	Total
Path		1	0	219	2	222
PathTear		0	0	31	0	31
ResvConfirm		0	0	0	0	0
Total		1	0	250	2	253

The following is sample output from the **show rsvp counters prefix-filtering interface summary** command:

RP/0/0/CPU0:router# **show rsvp counters prefix-filtering interface summary**

ALL RSVP						
Interfaces	Fwd	Local	Drop	Def-Drop	Def-Proc	Total
Path	4	1	0	219	3	227
PathTear	0	0	0	31	0	31
ResvConfirm	0	0	0	0	0	0
Total	4	1	0	250	3	258

The following is sample output from the **show rsvp counters prefix-filtering access-list banks** command:

RP/0/0/CPU0:router# **show rsvp counters prefix-filtering access-list banks**

```

ACL: banks          Forward      Local      Drop      Total
Path                0          0          0          0
PathTear            0          0          0          0
ResvConfirm          0          0          0          0
Total               0          0          0          0

```

This table describes the significant fields shown in the display.

Table 63: show rsvp counters prefix-filtering interface and summary CommandField Descriptions

Field	Description
Fwd	Number of messages forwarded to the next router. Note The messages are counted against the <i>routed</i> interface only because RSVP has no record of what interface the messages will be forwarded to.
Local	Number of messages not forwarded (because they are locally destined).
Drop	Number of messages dropped.
Def-Drop	Number of messages dropped when an access control list match returns an implicit deny. (Results when RSVP is configured to drop implicit deny messages.)
Def-Proc	Number of messages processed by RSVP when an access control list match returns an implicit deny.
Path	Number of Path messages.
PathTear	Number of Path Tear messages.
ResvConfirm	Number of ResvConfirm messages.

show rsvp fast-reroute

To display RSVP Fast-Reroute (FRR) information, use the **show rsvp fast-reroute** command in EXEC mode.

show rsvp fast-reroute [**destination** *IP-address*] [**dst-port** *port*] [**source** *IP-address*] [**src-port** *source-port*] [**summary**]

Syntax Description

destination <i>IP-address</i>	(Optional) Displays the entries that match the specified address.
dst-port <i>port</i>	(Optional) Displays the port address of the destination router.
source <i>IP-address</i>	(Optional) Displays the IP address of the source network.
src-port <i>source-port</i>	(Optional) Displays the port number of the source router.
summary	(Optional) Displays summarized information about the FRR database.

Command Default

None

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	read, write
ouni	read, write

Examples

This is sample output from the **show rsvp fast-reroute** command:

```
RP/0/0/CPU0:router# show rsvp fast-reroute
```

Type	Destination	TunID	Source	PSBs	RSBs
LSP4	70.70.70.70	1	50.50.50.50	Ready	Ready

This table describes the significant fields shown in the display.

Table 64: show rsvp fast-reroute Command Field Descriptions

Field	Description
Type	Type of session.
Destination	Destination address of session.
TunID	Tunnel ID number.
Source	Source address of session.
PSBs	PSB FRR ³⁷ state.
RSBs	RSB FRR state.

³⁷ Fast reroute.

This is sample output from the **show rsvp fast-reroute summary** command:

```
RP/0/0/CPU0:router# show rsvp fast-reroute summary
```

States	Total	Ready	Act-Wait	Active
PSBs	1	1	0	0
RSBs	1	1	0	0

This table describes the significant fields shown in the display.

Table 65: show rsvp fast-reroute summary Command Field Descriptions

Field	Description
States	FRR ³⁸ state.
Total	Total number of path and reservation states.
Ready	Number of states in FRR ready state. No FRR processing has been done on these states.
Act-Wait	Number of states in “Active Wait” FRR state. • For PSBs, this indicates that after FRR the path message has not yet been sent. • For RSBs, this indicates that after FRR, the reservation message has not yet been received.

show rsvp fast-reroute

Field	Description
Active	Number of states in “Active” FRR state. • For PSBs, this indicates that after FRR the path message has been sent. • For RSBs, this indicates that after FRR, the reservation message has been received.

38 Fast reroute.

Related Commands

Command	Description
show mrrib mpls traffic-eng fast-reroute	Configures the multicast routing information base MPLS traffic engineering fast reroute information.

show rsvp graceful-restart

To display the local graceful-restart information for RSVP, use the **show rsvp graceful-restart** command in EXEC mode.

show rsvp graceful-restart [**neighbors**] [*IP-address*] [**detail**]

Syntax Description

neighbors	(Optional) Displays single-line status for each neighbor. If this keyword is not specified, only a multiline table entry is displayed showing local graceful-restart information.
<i>IP-address</i>	(Optional) Address of the neighbor you are displaying. Displays a specific neighbor with that destination address only. If this keyword is not specified, all neighbors are displayed.
detail	(Optional) Displays multiline status for each neighbor. If this keyword is not specified, only a single-line table entry is displayed.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Graceful-restart neighbors are displayed in ascending order of neighbor IP address.

Task ID

Task ID	Operations
mpls-te	read, write
ouni	read, write

Examples

The following is sample output from the **show rsvp graceful-restart** command:

```
RP/0/0/CPU0:router# show rsvp graceful-restart

Graceful restart: enabled  Number of global neighbors: 1
Local MPLS router id: 192.168.55.55
Restart time: 60 seconds  Recovery time: 120 seconds
Recovery timer: Not running
Hello interval: 5000 milliseconds Maximum Hello miss-count: 4
```

This table describes the significant fields shown in the display.

Table 66: show rsvp graceful-restart Command Field Descriptions

Field	Description
Graceful restart	Indicates whether graceful restart is configured locally.
Number of global neighbors	Number of neighbors identified by a unique router ID.
Local MPLS router id	Local router ID used for the MPLS or OUNI applications.
Restart time	Amount of time after a loss in hello messages within which RSVP hello session is reestablished. This setting is manually configurable.
Recovery time	Local recovery time advertised to neighbors. This is dynamically computed based on the number of LSPs established and is the time used by neighbors to refresh states in the event of a failure.
Recovery timer	Countdown timer which, upon expiry, causes un-refreshed data forwarding states to be deleted (usually beginning with a value that is equivalent to the sum of the restart and recovery times).
Hello interval	Interval at which hello messages are sent to neighbors.
Maximum hello miss-count	Number of hellos from a neighbor that can be missed before declaring hellos down.

The following is sample output from the **show rsvp graceful-restart neighbors** command, which displays information about graceful restart neighbors in the router:

```
RP/0/0/CPU0:router# show rsvp graceful-restart neighbors

Neighbor      App  State Recovery      Reason      Since      LostCnt
-----
```



```
192.168.77.77 MPLS      UP      DONE      N/A  19/12/2002 17:02:25      0
```

This table describes the significant fields shown in the display.

Table 67: show rsvp graceful-restart neighbors Command Field Descriptions

Field	Description
Neighbor	Router ID of a global neighbor.
App	Application type of a global neighbor (MPLS or OUNI).
State	State of the hello session to a global neighbor (up, down, INIT).
Recovery	State at which the local node is recovering a global neighbor.
Reason	Last reason for which communication has been lost for a global neighbor. If none has occurred, this field is marked as N/A.
Since	Time at which the current hello state for a global neighbor has been established.
LostCnt	Number of times hello communication has been lost with a global neighbor.

The following is sample output from the **show rsvp graceful-restart neighbors detail** command, which displays detailed information about all graceful restart neighbors:

```
RP/0/0/CPU0:router# show rsvp graceful-restart neighbors detail

Neighbor: 192.168.77.77 Source: 192.168.55.55 (MPLS)
  Hello instance for application MPLS
    Hello State: UP      (for 00:20:52)
    Number of times communications with neighbor lost: 0
    Reason: N/A
  Recovery State: DONE
  Number of Interface neighbors: 1
    address: 192.168.55.0
  Restart time: 120 seconds  Recovery time: 120 seconds
  Restart timer: Not running
  Recovery timer: Not running
  Hello interval: 5000 milliseconds  Maximum allowed missed Hello messages: 4
```

This table describes the significant fields shown in the display.

Table 68: show rsvp graceful-restart neighbors detail Command Field Descriptions

Field	Description
Neighbor	Router ID of a global neighbor.

Field	Description
Source	Local router ID and application type.
Hello State	State of the hello instance for the global neighbor (up, down, or init) and duration of the current state.
Number of times communications with neighbor lost	Number of times hello communication has been lost with a global neighbor.
Reason	Last reason indicating why communication was lost for a global neighbor. If none has occurred, this field is marked as N/A.
Recovery State	State at which the local node is recovering a global neighbor.
Number of Interface neighbors	Number of interfaces belonging to a global neighbor.
Address	IP address of the interface neighbor.
Recovery timer	Remote recovery time for a global neighbor.
Hello interval	Interval at which hello messages are sent by the remote global neighbor.
Maximum allowed missed Hello messages	Number of hellos that can be missed by the remote global neighbor before declaring hellos down.

show rsvp hello instance

To display the RSVP hello instances, use the **show rsvp hello instance** command in EXEC mode.

show rsvp hello instance [*Hostname or IP-address*] [**detail**]

Syntax Description

<i>Hostname or IP-address</i>	(Optional) Address of the neighbor you are displaying. If this argument is not specified, all neighbors are displayed.
detail	(Optional) Displays multiline status for each hello instance. If this keyword is not specified, only a single-line table entry is displayed.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Hello instances are displayed in ascending order of neighbor IP address.

Task ID

Task ID	Operations
mpls-te	read, write
ouni	read, write

Examples

The following is sample output from the **show rsvp hello instance** command, which displays brief information about all hello instances in the router:

```
RP/0/0/CPU0:router# show rsvp hello instance
```

Neighbor	Type	State	Interface	LostCnt
192.168.77.77	ACTIVE	UP	None	0

This table describes the significant fields shown in the display.

Table 69: show rsvp hello instance Command Field Descriptions

Field	Description
Neighbor	Router ID of a global neighbor hosting the hello instance.
Type	Hello instance type (active or passive). Active type indicates that a node is sending hello requests and passive indicates that a node is sending hello acknowledgements.
State	State of the hello session to a global neighbor (up, down, or init).
Interface	Interface for interface bound hello's used for FRR ³⁹ . Hello instances bound to a global neighbor show Interface as None. Hellos used for FRR are currently not supported.
LostCnt	Number of times hello communication has been lost with a global neighbor.

³⁹ Fast reroute.

The following is sample output from the **show rsvp hello instance** command, which displays detailed information about all hello instances in the router:

```
RP/0/0/CPU0:router# show rsvp hello instance detail

Neighbor: 192.168.77.77 Source: 192.168.55.55 (MPLS)
State: UP (for 00:07:14)
Type: ACTIVE (sending requests)
I/F: None
Hello interval (msec) (used when ACTIVE)
Configured: 5000
Src_instance 0x484b01, Dst_instance 0x4d4247
Counters:
Communication with neighbor lost:
  Num of times: 0   Reasons:
    Missed acks: 0
    New Src_Inst received: 0
    New Dst_Inst received: 0
    I/f went down: 0
    Neighbor disabled Hello: 0
Msgs Received: 93
Sent: 92
Suppressed: 87
```

This table describes the significant fields shown in the display.

Table 70: show rsvp hello instance detail Command Field Descriptions

Field	Description
Neighbor	Router ID of a global neighbor.
Source	Local router ID and application type.
State	State of the hello instance for the global neighbor (up, down or init) and duration of the current state.
Type	Hello instance type (active or passive). Active type indicates that a node is sending hello requests and passive indicates that a node is sending hello acks.
I/F	Interface for interface bound hellos. Hello instances for Graceful restart show interface as None.

show rsvp hello instance interface-based

To display the RSVP hello instances on a specific interface, use the **show rsvp hello instance interface-based** command in EXEC mode.

show rsvp hello instance interface-based [*IP-address*] [detail]

Syntax Description

<i>IP-address</i>	(Optional) Address of the neighboring interface. you are displaying. If this argument is not specified, all neighbors are displayed.
detail	(Optional) Displays detailed information for the specified interface.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Hello instances are displayed in ascending order of neighbor IP address.

Task ID

Task ID	Operations
mpls-te	read, write
ouni	read, write

Examples

The following is sample output from the **show rsvp hello instance interface-based** command, which displays detailed information about hello instances on a specific interface:

```
RP/0/0/CPU0:router# show rsvp hello instance interface-based 10.10.10.10
```

```
Neighbor      Type      State      Interface      LostCnt
-----
```

```
10.10.10.10      ACTIVE  UP      None      0
```

This table describes the significant fields shown in the display.

Table 71: show rsvp hello instance interface-based Command Field Descriptions

Field	Description
Neighbor	Router ID of a global neighbor hosting the hello instance.
Type	Hello instance type (active or passive). Active type indicates that a node is sending hello requests and passive indicates that a node is sending hello acknowledgements.
State	State of the hello session to a global neighbor (up, down, or init).
Interface	Interface for interface bound hello's used for FRR ⁴⁰ . Hello instances bound to a global neighbor show interface as none. Hellos used for FRR are currently not supported.
LostCnt	Number of times hello communication has been lost with a global neighbor.

⁴⁰ Fast reroute.

show rsvp interface

To display information about all interfaces with RSVP enabled, use the **show rsvp interface** command in EXEC mode.

show rsvp interface [*type interface-path-id*] [**detail**]

Syntax Description

<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
detail	(Optional) Displays multiline status for each interface. If this keyword is not specified, only a single-line table entry is displayed.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was supported.
Release 3.9.0	Sample output was modified.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show rsvp interface** command to display various configuration settings such as the list of neighbors and their refresh reduction capabilities.

Task ID

Task ID	Operations
mpls-te	read, write
ouni	read, write

Examples

The following is sample output from the **show rsvp interface** command, which displays brief information about the RSVP-configured interfaces running in prestandard DS-TE mode:

```
RP/0/0/CPU0:router# show rsvp interface gigabitEthernet 0/3/0/0

Thu Oct 22 20:35:07.737 UTC
INTERFACE: GigabitEthernet0/3/0/0 (ifh=0x4000300).
  BW (bits/sec): Max=750M. MaxFlow=750M.
                Allocated=0 (0%).
                BC0=750M. BC1=0.
```

The following is sample output from the **show rsvp interface** command, which displays brief information about the RSVP-configured interfaces for the GigabitEthernet interface type:

```
RP/0/0/CPU0:router# show rsvp interface gigabitEthernet 0/3/0/0

Thu Oct 22 20:35:42.323 UTC
Interface      MaxBW (bps) MaxFlow (bps) Allocated (bps)      MaxSub (bps)
-----
Gi0/3/0/0      750M        750M          0 ( 0%)              0
```

This following is sample output from the **show rsvp interfaces detail** command running in standard DS-TE mode:

```
RP/0/0/CPU0:router# show rsvp interface gigabitEthernet 0/3/0/0 detail

Thu Oct 22 20:35:11.638 UTC
INTERFACE: GigabitEthernet0/3/0/0 (ifh=0x4000300).
VRF ID: 0x60000000 (Default).
  BW (bits/sec): Max=750M. MaxFlow=750M.
                Allocated=0 (0%).
                BC0=750M. BC1=0.
  Signalling: No DSCP marking. No rate limiting.
  States in: 0. Max missed msgs: 4.
  Expiry timer: Not running. Refresh interval: 45s.
  Normal Refresh timer: Not running. Summary refresh timer: Running.
  Refresh reduction local: Enabled. Summary Refresh: Enabled (1472 bytes max).
  Reliable summary refresh: Disabled. Bundling: Enabled. (1500 bytes max).
  Ack hold: 400 ms, Ack max size: 1500 bytes. Retransmit: 900ms.
  Neighbor information:
    Neighbor-IP      Nbor-MsgIds States-out Refresh-Reduction Expiry(min::sec)
    -----
           9.0.0.1           0           6           Enabled 14::56
          10.10.10.10         0           0           Enabled 14::33
```

This table describes the significant fields shown in the display.

Table 72: show rsvp interface detail Command Field Descriptions

Field	Description
Bandwidth	Configured values on the interface and currently allocated bandwidth.
Ack hold	Time, in milliseconds, before RSVP responds with an acknowledgment.

Field	Description
Neighbor-IP	Address of peer that RSVP is exchanging messages on that interface.
Nbor-msglds	Message IDs received from the neighbor (corresponding to the number of LSPs with reliable messaging).
States-out	States (including paths or reservations) sent on this interface to the neighbor.
Refresh Reduction	Neighbor Refresh Reduction capability.
Expiry	Time a neighbor entry in the interface database expires if there is no activity on this interface with the corresponding neighbor.

Related Commands

Commands	Description
show rsvp counters, on page 495	Displays internal RSVP counters.

show rsvp request

To list all the requests that RSVP knows about on a router, use the **show rsvp request** command in EXEC mode.

show rsvp request [**destination** *IP-address*] [**detail**] [**dst-port** *port-num*] [**source** *IP-address*] [**src-port** *port-num*]

Syntax Description

detail	(Optional) Displays multiline status for each path. If this keyword is not specified, only a single-line table entry is displayed.
destination <i>IP-address</i>	(Optional) Displays the entries that match the specified address.
dst-port <i>port-num</i>	(Optional) Displays destination port and tunnel information.
source <i>IP-address</i>	(Optional) Displays source address information.
src-port <i>port-num</i>	(Optional) Displays port and LSP ID information.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

This command displays information about upstream reservations only; that is, reservations being sent to upstream hops. Information about downstream reservations (that is, incoming or locally created reservations) is available using the **show rsvp reservation** command.

Reservations are displayed in ascending order of destination IP address, destination port, source IP address, and source port.

Task ID

Task ID	Operations
mpls-te	read, write

Task ID	Operations
ouni	read, write

Examples

The following is sample output from the **show rsvp request** command:

```
RP/0/0/CPU0:router# show rsvp request
```

```

-----
Dest Addr DPort      Source Addr SPort Pro   OutputIF Sty Serv Rate Burst
-----
192.168.40.40 2001      192.168.67.68    2    0   PO0/7/0/1 SE LOAD    0    1K
-----
```

The following is sample output from the **show rsvp request detail** command, which displays detailed information about all requests in the router. Requests are reservation states for the reservation messages sent upstream:

```
RP/0/0/CPU0:router# show rsvp request detail
```

```

REQ:  IPv4-LSP Session addr: 192.168.40.40. TunID: 2001. LSPId: 2.
      Source addr: 192.168.67.68. ExtID: 192.168.67.68.
      Output interface: POS0/7/0/1. Next hop: 192.168.67.68 (lih: 0x19700001).
      Flags: Local Receiver.
      Style: Shared-Explicit. Service: Controlled-Load.
      Rate: 0 bits/sec. Burst: 1K bytes. Peak: 0 bits/sec.
      MTU min: 0, max: 500 bytes.
      Policy: Forwarding. Policy source(s): MPLS/TE.
      Number of supporting PSBs: 1
      Destination Add DPort      Source Add SPort Pro   Input IF Rate Burst Prot
      192.168.40.40 2001      192.168.67.68 2    0   PO0/7/0/1    0    1K    Off
      Number of supporting RSBs: 1
      Destination Add DPort      Source Add SPort Pro   Input IF Sty Serv Rate Burst
      192.168.40.40 2001      65.66.67.68 2    0   None SE LOAD    0    1K
-----
```

This table describes the significant fields shown in the display.

Table 73: show rsvp request detail Command Field Descriptions

Field	Description
Number of supporting PSBs	Number of senders for this session (typically, 1).
Number of supporting RSBs	Number of reservations per session (typically, 1).
Policy	Admission control status.
Policy source	Entity performing the admission control (MPLS-TE or COPS).

Related Commands

Commands	Description
show rsvp reservation , on page 521	Displays internal RSVP reservation counters.

show rsvp reservation

To display all reservations that RSVP knows about on a router, use the **show rsvp reservation** command in EXEC mode.

show rsvp reservation [*destination IP address*] [**detail**] [**dst-port** *port-num*] [**source** *IP-address*] [**src-port** *port-num*]

Syntax Description

detail	(Optional) Displays multiline status for each reservation. If the detail keyword is not specified, only a single-line table entry is displayed.
destination <i>IP-address</i>	(Optional) Displays the entries that match the specified address.
dst-port <i>port-num</i>	(Optional) Displays destination port and tunnel ID information.
source <i>IP-address</i>	(Optional) Displays source address information.
src-port <i>port-num</i>	(Optional) Displays source port and LSP ID information.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show rsvp reservation** command displays information about downstream reservations only (that is, reservations received on this device or created by application program interface (API) calls). Upstream reservations or requests are displayed using the **show rsvp request** command.

Task ID

Task ID	Operations
mpls-te	read, write
ouni	read, write

Examples

The following is sample output from the **show rsvp reservation** command:

```
RP/0/0/CPU0:router# show rsvp reservation
```

Dest Addr	DPort	Source Addr	SPort	Pro	Input IF	Sty	Serv	Rate	Burst
192.168.40.40	2001	192.168.67.68	2	0	None	SE	LOAD	0	1K
192.168.67.68	2000	10.40.40.40	15	0	PO0/7/0/1	SE	LOAD	0	1K

The following example displays detailed information about all reservations in the router:

```
RP/0/0/CPU0:router# show rsvp reservation detail
```

```
RESV: IPv4-LSP Session addr: 192.168.40.40. TunID: 2001. LSPId: 2.
Source addr: 192.168.67.68. ExtID: 192.168.67.68.
Input adjusted interface: None. Input physical interface: None.
Next hop: 0.0.0.0 (lih: 0x0).
Style: Shared-Explicit. Service: Controlled-Load.
Rate: 0 bits/sec. Burst: 1K bytes. Peak: 0 bits/sec.
MTU min: 40, max: 500 bytes.
Flags: Local Receiver.
State expires in 0.000 sec.
Policy: Accepted. Policy source(s): MPLS/TE.
Header info: RSVP TTL=255. IP TTL=255. Flags: 0x0. TOS=0xff.
Resource:
  Labels: Local downstream: 3.

RESV: IPv4-LSP Session addr: 192.168.67.68. TunID: 2000. LSPId: 15.
Source addr: 192.168.40.40. ExtID: 10.10.40.40.
Input adjusted interface: PO0/7/0/1. Input physical interface: PO0/7/0/1.
Next hop: 10.66.67.68 (lih: 0x8DE00002).
Style: Shared-Explicit. Service: Controlled-Load.
Rate: 0 bits/sec. Burst: 1K bytes. Peak: 0 bits/sec.
MTU min: 0, max: 500 bytes.
Flags: None.
State expires in 361.184 sec.
Policy: Accepted. Policy source(s): MPLS/TE.
Header info: RSVP TTL=254. IP TTL=254. Flags: 0x1. TOS=0xff.
Resource:
  Labels: Outgoing downstream: 3.
```

This table describes the significant fields shown in the display.

Table 74: show rsvp reservation detail Command Field Descriptions

Field	Description
Input adjusted interface	Interface to reflect the path's outgoing interface.
Input physical interface	Interface where the reservation was received.
Next hop	Address of the downstream node that sent the reservation to this node.
Lih	Logical interface handle sent in the hop object of path returned to us in the reservation to figure out what interface the path was sent on.
Flags	Indicates path state, including as Local Repair, Local Sender (LSP ⁴¹ ingress node), and others.

Field	Description
Policy	Admission control status.
Policy source	Entity performing the admission control on the LSP.
Header info	RSVP header information as described in RFC 2205.

⁴¹ Link-state packet

Related Commands

Command	Description
show rsvp request, on page 519	Lists all the requests that RSVP knows about on a router.

show rsvp sender

To display all path states that RSVP knows about on this router, use the **show rsvp sender** command in EXEC mode.

show rsvp sender [*destination IP-address*] [**detail**] [**dst-port** *port-num*] [**source** *IP-address*] [**src-port** *port-num*]

Syntax Description

detail	(Optional) Displays multiline status for each path. If the detail keyword is not specified, only a single-line table entry is displayed.
destination <i>IP-address</i>	(Optional) Displays the entries that match the specified address.
dst-port <i>port-num</i>	(Optional) Displays destination port and tunnel ID information.
source <i>IP-address</i>	(Optional) Displays source address information.
src-port <i>port-num</i>	(Optional) Displays source port and LSP ID information.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show rsvp sender** command displays information about path states.

Task ID

Task ID	Operations
mpls-te	read, write
ouni	read, write

Examples

The following is sample output from the **show rsvp sender** command:

```
RP/0/0/CPU0:router# show rsvp sender
```

Dest Addr	DPort	Source Addr	SPort	Pro	Input IF	Rate	Burst	Prot
10.40.40.40	2001	10.66.67.68	2	0	PO0/7/0/1	0	1K	Off
10.66.67.68	2000	10.40.40.40	15	0	None	0	1K	Off

This table describes the significant fields shown in the display.

Table 75: show rsvp sender Command Field Descriptions

Field	Description
DPort	Destination port number and tunnel-id.
Dest Address	Destination and session address of LSP ⁴² .
SPort	Source port and LSP ID.
Source Addr	Address of the ingress node of the LSP.
Input IF	Interface on which the Path message was received.

⁴² Link-state packet

The following example displays detailed information about all paths in the system:

```
RP/0/0/CPU0:router# show rsvp sender detail
```

```

PATH: IPv4-LSP Session addr: 65.66.67.68. TunID: 1. LSPId: 25.
Source addr: 40.40.40.40. ExtID: 40.40.40.40.
Prot: Off. Backup tunnel: None.
Setup Priority: 7, Reservation Priority: 0
Rate: 0 bits/sec. Burst: 1K bytes. Peak: 0 bits/sec.
Min unit: 40 bytes, Max unit: 500 bytes
Flags: Bidirectional.
State expires in 370.154 sec.
Policy: Accepted. Policy source(s): Default.
Header info: RSVP TTL=254. IP TTL=254. Flags: 0x1. TOS=0xc0.
Input interface: PO0/3/0/0. Previous hop: 40.40.40.40 (lih: 0x40600001).
Resource:
  Labels: Outgoing upstream: 3.
  Class-Type: None.
  Explicit Route (Incoming):
    Strict, 65.66.67.68(interface-path-id 5)
    Strict, 65.66.67.68/32

```

This table describes the significant fields shown in the display.

Table 76: show rsvp sender detail Command Field Descriptions

Field	Description
Prot	LSP configured as a protected tunnel.

Field	Description
Backup tunnel	Name of the backup tunnel assigned to protect this LSP ⁴³ .
Flags	Path state, including as local repair, local sender (LSP ingress node), and others.
Policy	Admission control status for Path message in the incoming direction.
Policy source	Entity doing the admission control, such as COPS or MPLS-TE ⁴⁴ .
Header info	RSVP header information as described in RFC 2205.
Input interface	Interface on which the path was received. At ingress mode, it is None.
Previous hop	Address of the upstream peer who sent us the Path message. May be the interface address or node-id depending on LSP (packet or optical).
Lih	Logical interface handle received in the hop object of the path.
Output interface	Interface on which the path was forwarded to the downstream neighbor
Policy	Admission control status for the path in the outgoing direction.
Explicit route	Explicit route specified in the explicit-route object of the Path message.

⁴³ Link-state packet

⁴⁴ MPLS-Traffic Engineering

show rsvp session

To list all sessions that RSVP knows about on this router, use the **show rsvp session** command in EXEC mode.

show rsvp session [**destination** *IP-address*] [**detail**] [**dst-port** *port-num*] [**tunnel-name** *tunnel-name*]

Syntax Description

detail	(Optional) Displays multiline status for each path. If the detail keyword is not specified, only a single-line table entry is displayed.
destination <i>IP-address</i>	(Optional) Displays the entries that match the specified address.
dst-port <i>port-num</i>	(Optional) Displays destination port and tunnel ID information.
tunnel-name <i>tunnel-name</i>	(Optional) Displays status for the session matching the specified tunnel-name.

Command Modes

EXEC

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Sessions are displayed in ascending order of destination IP address, destination port, and source IP address.

Task ID

Task ID	Operations
mpls-te	read, write
ouni	read, write

Examples

The following is sample output from the **show rsvp session** command:

```
RP/0/0/CPU0:router# show rsvp session
```

```
Type      Session Addr  Port  Proto/ExtTunID  PSBs  RSBs  Reqs
-----
```

```

LSP4      10.40.40.40  2001      10.66.67.68      1      1      1
LSP4      10.66.67.68  2000      10.40.40.40      1      1      0

```

This table describes the significant fields shown in the display.

Table 77: show rsvp session Command Field Descriptions

Field	Description
Type	Type of data flow (Traffic-Engineering LSP (LSP4), OUNI, or IPV4 session).
Session Addr	Destination address of the data packets and also tail of the LSP.
Port	Destination port or tunnel ID in case of TE and OUNI tunnels.
Proto/ExtTunID	Source address of TE and OUNI tunnels or protocol as in the case of IPV4 sessions.
PSBs	Number of path state blocks for this session.
RSBs	Number of reservation state blocks pertaining to incoming or local reservations for this session.
Reqs	Number of requests. State data structure representing reservations sent up-stream.

The following is sample output for the **show rsvp session detail** command:

```

RP/0/0/CPU0:router# show rsvp session detail

SESSION: IPv4-LSP Addr: 65.66.67.68, TunID: 1, ExtID: 40.40.40.40
PSBs: 1, RSBs: 1, Requests: 0
LSPId: 1
Tunnel Name: newhead_t1
RSVP Path Info:
  InLabel: No intf, No label
  Incoming Address: Unknown
  Explicit Route:
    Strict, 65.66.67.68(interface-path-id 5)
    Strict, 65.66.67.68/32
  Record Route: None
  Tspec: avg rate=0, burst=1K, peak rate=0
RSVP Resv Info:
  OutLabel: POS0/7/0/1, 5
  FRR OutLabel: No intf, No label
  Record Route:
    Node-id 65.66.67.68, interface index 5
  Tspec: avg rate=0, burst=1K, peak rate=0

```

This table describes the significant fields shown in the display.

Table 78: show rsvp session detail Command Field Descriptions

Field	Description
TunID	Tunnel identifier and the destination port of the LSP ⁴⁵ .
ExtID	Ingress node address of LSP.
Tunnel Instance	Source port of the LSP (with the ExtId forming the source parameters).
Tunnel Name	Name of the tunnel and LSP.
InLabel	Incoming interface and label info for the LSP in the upstream direction. At the egress node, using penultimate hop popping at the egress node, (implicit-null) appears as <i>No Label</i> .
Incoming Address	Address of the ingress interface.
Explicit Route	Explicit route specified in the explicit-route object of the Path message.
Record Route	Record route object in either the path or reservation message.
Tspec	Traffic parameters.
OutLabel	Outgoing interface and label sent downstream.
FRR OutLabel	For FRR ⁴⁶ , displays the backup tunnel and Merge-point label.
Fspec	Flow spec parameters for specified QoS.

⁴⁵ Link-state packet.

⁴⁶ Fast reroute.

signalling dscp (RSVP)

To give all RSVP signaling packets sent out on a specific interface higher priority in the network by marking them with a particular Differentiated Service Code Point (DSCP), use the **signalling dscp** command in RSVP interface configuration submode. To return to the default behavior, use the **no** form of this command.

signalling dscp *dscp*

no signalling dscp

Syntax Description

<i>dscp</i>	DSCP priority number. Range is 0 to 63.

Command Default

No default behavior or values

Command Modes

RSVP interface configuration

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

DSCP marking improves signaling setup and teardown times.

Ordinarily, when a router receives Path messages for a particular state marked with a DSCP value, it sends out Path messages for that state marked with the same DSCP value. This command overrides that DSCP persistence and ensures that all messages sent out a particular interface are marked with a specified DSCP.

Though this command controls RSVP signaling packets, it has no effect on ordinary IP or MPLS data packets traveling along the path created or reserved by this RSVP session.

DSCP persistence operates on a per-state basis, but this command operates on a per-interface basis. So, if some incoming message (for example, multicast Path) with DSCP 10 causes two outgoing messages on interfaces A and B, ordinarily both are sent with DSCP 10. If **signalling dscp 5** is configured for RSVP on interface A, the Path messages being sent out interface A is marked with DSCP 5, but the Path messages being sent out interface B are marked with DSCP 10.

There is a difference between the **signalling dscp 0** and **no signalling dscp** commands. The first command instructs RSVP to explicitly set to 0 the DSCP on all packets sent out this interface. The second command removes any override on the packets being sent out this interface, and allows the DSCP of received packets that created this state to persist on packets forwarded out this interface.

The RFC specifies a standard mapping from the eight IP precedence values to eight values in the 64-value DSCP space. You can use those special DSCP values to specify IP precedence bits only.

Task ID

Task ID	Operations
mpls-te	read, write
ouni	read, write

Examples

The following example shows how to mark all RSVP packets going out on POS interface 0/1/0/1 as DSCP 20:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp interface pos 0/1/0/1
RP/0/0/CPU0:router(config-rsvp-if)# signalling dscp 20
```

The following example shows how to disable DSCP marking of signaling packets going out POS interface 0/1/0/1:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp interface pos 0/1/0/1
RP/0/0/CPU0:router(config-rsvp-if)# interface pos 0/1/0/1
RP/0/0/CPU0:router(config-rsvp-if)# no signalling dscp
```

signalling graceful-restart

To enable or disable RSVP signaling graceful restart, use the **signalling graceful-restart** command in RSVP configuration mode. To return to the default behavior, use the **no** form of this command.

signalling graceful-restart [**recovery-time** *time*] **restart-time** *time*]

no signalling graceful-restart

Syntax Description

recovery-time	(Optional) Configures the recovery time that is advertised in the Restart Cap object in the Hello messages.
<i>time</i>	Time, in seconds, for the neighbor to wait for the node to recover (replay) existing states after the Hello session is reestablished before initiating TEARs. Range is 0 to 3600.
restart-time	(Optional) Configures the restart time that is advertised in the Restart Cap object in hello messages.
<i>time</i>	Time, in seconds, after a control-plane restart that RSVP can start exchanging hello messages. Range is 60 to 3600. Default is 120.

Command Default

RSVP signaling graceful restart is disabled.

Command Modes

RSVP configuration

Command History

Release	Modification
Release 3.2	This command was supported.
Release 3.9.0	The recovery-time keyword was added.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **signalling graceful-restart** command provides a mechanism that helps minimize the negative effects on MPLS and Optical User Network Interface (O-UNI) traffic for the following types of faults. This is an implementation of the fault handling section of the IETF standard RFC 3473:

Control-channel-failure

Disruption of communication channels between 2 nodes when the communication channels are separated from the data channels.

Node-failure

Control plane of a node fails, but the node preserves its data forwarding states.

The **signalling graceful-restart** command instigates the exchange of RSVP hello messages between the router and its neighbor nodes. After the hello messages are established with a given neighbor, RSVP can detect these types of faults when they occur.

If no hello messages are received from a neighbor within a certain number of hello intervals, a node assumes that communication with the neighbor has been lost. The node waits the amount of time advertised by the last restart time communicated by the neighbor, before invoking procedures for recovery from communication loss.

The configured restart time is important in case of recovery from failure. The configured value should accurately reflect the amount of time within which, after a control-plane restart, RSVP can start exchanging hello messages.

Task ID

Task ID	Operations
mpls-te	read, write
ouni	read, write

Examples

The following example shows how to enable RSVP signalling graceful restart:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp
RP/0/0/CPU0:router(config-rsvp)# signalling graceful-restart
```

The following example shows how to set the restart time:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp
RP/0/0/CPU0:router(config-rsvp)# signalling graceful-restart restart-time 200
```

The following example shows how to reset the restart time to the default of 120 seconds:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp
RP/0/0/CPU0:router(config-rsvp)# no signalling graceful-restart restart-time
```

signalling hello graceful-restart refresh interval

To configure the interval at which RSVP graceful-restart hello messages are sent to each neighbor, use the **signalling hello graceful-restart refresh interval** command in RSVP configuration mode. To return to the default behavior, use the **no** form of this command.

signalling hello graceful-restart refresh interval *refresh-interval*

no signalling hello graceful-restart refresh interval

Syntax Description

<i>refresh-interval</i>	Interval, in milliseconds, at which RSVP graceful-restart hello messages are sent to each neighbor. Range is 3000 to 30000.

Command Default

refresh interval: 5000

Command Modes

RSVP configuration

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **signalling hello graceful-restart refresh interval** command determines how often hello messages are sent to each neighbor. If the interval is made short, the hello messages are sent more frequently. Although a short interval may help detect failures quickly, it also results in increased network traffic. Optimizations in the RSVP hello mechanism exist to reduce the number of hello messages traveling over the network.

When an RSVP hello message is received, the receiving node acknowledges the hello and restarts its hello timer to the neighbor. By doing this, a hello is transmitted to the neighbor only if a hello is not received before the hello refresh interval has expired.

If two neighboring nodes do not have the same hello interval, the node with the larger hello interval has to acknowledge its neighbor's (more frequent) hellos. For instance, if node A has a hello interval of 5 seconds, and node B has a hello interval of 10 seconds, node B still has to send hello messages every 5 seconds.

The hello backoff mechanism is an optimization that is tailored to minimize the number of hello messages from a neighbor that either does not have graceful restart enabled, or that fails to come back up during the restart interval. The restart interval is provided by the neighbor in the restart cap object.

Task ID

Task ID	Operations
mpls-te	read, write
ouni	read, write

Examples

The following example sets the hello graceful-restart refresh interval to 4000 msec:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp
RP/0/0/CPU0:router(config-rsvp)# signalling hello graceful-restart refresh interval 4000
```

Related Commands

Command	Description
signalling hello graceful-restart refresh misses, on page 536	Configures the number of consecutive missed RSVP hello messages before a neighbor is declared down or unreachable.

signalling hello graceful-restart refresh misses

To configure the number of consecutive missed RSVP hello messages before a neighbor is declared down or unreachable, use the **signalling hello graceful-restart refresh misses** command in RSVP configuration mode. To return to the default behavior, use the **no** form of this command.

signalling hello graceful-restart refresh misses *refresh-misses*

no signalling hello graceful-restart refresh misses

Syntax Description

refresh-misses

Number of misses for hello messages before a neighbor is declared down or unreachable. Range is 1 to 10. Default is 3.

Command Default

refresh-misses: 3

Command Modes

RSVP configuration

Command History

Release

Release 3.2

Modification

This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

If no hello messages (request or ACK) are received from a neighbor within the configured number of refresh misses, the node assumes that communication with the neighbor has been lost.

Task ID

Task ID

mpls-te

ouni

Operations

read, write

read, write

Examples

The following example shows how to set hello graceful-restart refresh misses to 4:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp
RP/0/0/CPU0:router(config-rsvp)# signalling hello graceful-restart refresh misses 4
```

Related Commands

Command	Description
signalling hello graceful-restart refresh interval, on page 534	Configures the interval at which RSVP graceful restart hello messages are sent per neighbor.

signalling prefix-filtering access-list

To specify the extended access control list to use for prefix filtering of RSVP Router Alert messages, use the **signalling prefix-filtering access-list** command in RSVP configuration mode. To return to the default behavior, use the **no** form of this command.

signalling prefix-filtering access-list *access list name*

no signalling prefix-filtering access-list *access list name*

Syntax Description

<i>access list name</i>	Extended access-list name as a string (maximum 32 characters).

Command Default

No default behavior or values

Command Modes

RSVP configuration

Command History

Release	Modification
Release 3.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note

The extended access control list containing the source and destination prefixes used for packet filtering is configured separately.

Task ID

Task ID	Operations
mpls-te	read, write
ouni	read, write

Examples

The following example shows how to configure the access control list name banks for prefix-filtering of RSVP Router Alert messages:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp
RP/0/0/CPU0:router(config-rsvp)# signalling prefix-filtering access-list banks
```

The following example shows how to disable RSVP prefix-filtering of RSVP Router Alert messages:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp
RP/0/0/CPU0:router(config-rsvp)# no signalling prefix-filtering access-list banks
```

Related Commands

Command	Description
signalling prefix-filtering default-deny-action, on page 540	Configures RSVP to drop messages when an access control list match yields an implicit deny.

signalling prefix-filtering default-deny-action

To configure RSVP to drop RSVP Router Alert messages when an access control list match returns an implicit deny, use the **signalling prefix-filtering default-deny-action** command in RSVP configuration mode. To return to the default behavior, use the **no** form of this command.

signalling prefix-filtering default-deny-action drop

no signalling prefix-filtering default-deny-action drop

Syntax Description	drop Specifies when RSVP router alert messages are dropped.	
Command Default	Performs normal RSVP processing of Path, Path Tear, and ResvConfirm message packets.	
Command Modes	RSVP configuration	
Command History	Release	Modification
	Release 3.2	This command was introduced
Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.	
Task ID	Task ID	Operations
	mpls-te	read, write
	ouni	read, write

Examples

The following example shows how to configure RSVP Router Alert messages when an access control list match returns an implicit deny:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp
RP/0/0/CPU0:router(config-rsvp)# signalling prefix-filtering default-deny-action drop
```


Related Commands

Command	Description
signalling prefix-filtering access-list, on page 538	Configures extended access control lists for prefix-filtering of an RSVP Router Alert messages.

signalling rate-limit

To limit the rate of RSVP signaling messages being sent out a particular interface, use the **signalling rate-limit** command in RSVP interface configuration mode. To return to the default behavior, use the **no** form of this command.

signalling rate-limit[*rate messages*] [*interval interval-length*]

no signalling rate-limit [*rate messages*] [*interval interval-length*]

Syntax Description

rate <i>messages</i>	(Optional) Configures the number of messages sent per scheduling interval. Range is 1 to 500 messages.
interval <i>interval-length</i>	(Optional) Specifies the length, in milliseconds, between scheduling intervals. Range is 250 to 2000.

Command Default

messages: 100

interval-length: 1,000 (1 second)

Command Modes

RSVP interface configuration

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the rate-limiting feature with caution. Limiting the rate of RSVP signaling has the advantage of avoiding an overload of the next hop router's input queue, because such overloads would cause the next hop router to drop RSVP messages. However, reliable messaging and rapid retransmit usually enable the router to recover very rapidly from message drops; so rate limiting might not be necessary.

If the rate is set too low, it causes slower convergence times. This command limits all RSVP messages except acknowledgments (ACK) and SRefresh messages. The command does not let you make a router generate messages faster than its inherent limit. (That limit differs among router models.)

Task ID

Task ID	Operations
mpls-te	read, write

Task ID	Operations
ouni	read, write

Examples

The following example shows how to enable rate-limiting:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp interface POS0/3/0/0
RP/0/0/CPU0:router(config-rsvp-if)# signalling rate-limit
```

The following example shows how to limit the rate to 50 messages per second:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp interface pos 0/3/0/0
RP/0/0/CPU0:router(config-rsvp-if)# signalling rate-limit rate 50
```

The following example shows how to set a limit at 40 messages for every 250 milliseconds:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp interface pos 0/3/0/0
RP/0/0/CPU0:router(config-rsvp-if)# signalling rate-limit rate 40 interval 250
```

The following example shows how to restore the rate to the default of 100 messages per second:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp interface pos 0/3/0/0
RP/0/0/CPU0:router(config-rsvp-if)# no signalling rate-limit rate
```

The following example shows how to disable rate-limiting:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp interface pos 0/3/0/0
RP/0/0/CPU0:router(config-rsvp-if)# no signalling rate-limit
```

Related Commands

Command	Description
signalling refresh reduction bundle-max-size , on page 548	Specifies the maximum bundle size of maximum size of single RSVP bundle message.

signalling refresh interval

To change the frequency with which a router updates the network about the RSVP state of a particular interface, use the **signalling refresh interval** command in RSVP interface configuration mode. To return to the default behavior, use the **no** form of this command.

signalling refresh interval *seconds*

no signalling refresh interval

Syntax Description

<i>seconds</i>	Number of seconds the router waits to update the network about the RSVP state of an interface, in seconds. Range is 10 to 180. Default is 45.

Command Default

seconds: 45

Command Modes

RSVP interface configuration

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

RSVP relies on a soft-state mechanism to maintain state consistency in the face of network losses. That mechanism is based on continuous refresh messages to keep a state current. Each RSVP router is responsible for sending periodic refresh messages to its neighbors.

The router attempts to randomize network traffic and reduce metronomic burstiness by jittering the actual interval between refreshes by as much as 50 percent. As a result, refreshes may not be sent at exactly the interval specified. However, the average rate of refreshes are within the specified refresh interval.

Lengthening the interval reduces the refresh load of RSVP on the network but causes downstream nodes to hold state longer. This reduces the responsiveness of the network to failure scenarios. Shortening the interval improves network responsiveness but expands the messaging load on the network.

The reliable messaging extension, implemented through the **signalling refresh reduction reliable** command, may cause new or changed messages to be temporarily refreshed at a more rapid rate than specified to improve network responsiveness.

The use of reliable messaging with rapid retransmit substantially improves network responsiveness in case of transient message loss; if the refresh interval is changed when using the reliable messaging feature, it is more useful to lengthen the interval than to shorten it.

The summary refresh extension, implemented through the **signalling refresh reduction summary** command, provides a lower-cost mechanism to refresh RSVP state. The router uses the same refresh interval between successive refreshes of a single state when using summary refresh and when using ordinary message-based refresh.

Task ID

Task ID	Operations
mpls-te	read, write
ouni	read, write

Examples

The following example shows how to specify a refresh interval of 30 seconds:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp interface tunnel-te 2
RP/0/0/CPU0:router(config-rsvp-if)# signalling refresh interval 30
```

The following example shows how to restore the refresh interval to the default value of 45 seconds:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp interface tunnel-te 2
RP/0/0/CPU0:router(config-rsvp-if)# no signalling refresh interval
```

Related Commands

Command	Description
signalling refresh missed, on page 546	Specifies the number of successive missed refresh messages before RSVP deems the state expired and tears it down.
signalling refresh reduction reliable, on page 552	Customizes acknowledgment message size and hold interval, and the RSVP message retransmit interval.
signalling refresh reduction summary, on page 555	Enables and configures the maximum size of the SRefresh message.

signalling refresh missed

To specify the number of successive refresh messages that can be missed before the RSVP deems a state to be expired (resulting in the state to be torn down), use the **signalling refresh missed** command in RSVP interface configuration mode. To return to the default behavior, use the **no** form of this command.

signalling refresh missed*number*

no signalling refresh missed

Syntax Description	<i>number</i>	Number of successive missed refresh messages. Range is 1 to 8. Default is 4.

Command Default	<i>number</i> : 4

Command Modes	RSVP interface configuration

Command History	Release	Modification
	Release 3.2	This command was supported.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
	Decreasing the missed-message number improves RSVP responsiveness to major failures like router failure or link faults, but decreases the resilience of RSVP resulting in packet drops or temporary network congestion. The latter condition makes RSVP too sensitive.
	Increasing the missed-message number increases the resilience of RSVP to such transient packet loss, but decreases the RSVP responsiveness to more intransient network failures such as router failure or link fault.
	The default value of 4 provides a balance of resilience and responsiveness factors.

Task ID	Task ID	Operations
	mpls-te	read, write
	ouni	read, write

Examples

The following example shows how to specify a missed refresh limit of six (6) messages:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp interface tunnel-te 2
RP/0/0/CPU0:router(config-rsvp-if)# signalling refresh missed 6
```

The following example shows how to return the missed refresh limit to the default value of four (4):

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp interface tunnel-te 2
RP/0/0/CPU0:router(config-rsvp-if)# no signalling refresh missed
```

Related Commands

Command	Description
signalling refresh interval, on page 544	Changes the frequency with which a router updates the network about the RSVP state of an interface.
signalling refresh reduction reliable, on page 552	Customizes acknowledgment message size and hold interval, and the RSVP message retransmit interval.
signalling refresh reduction summary, on page 555	Enables and configures the maximum size of the SRefresh message.

signalling refresh reduction bundle-max-size

To configure the maximum size of a single RSVP bundle message, use the **signalling refresh reduction bundle-max-size** command in RSVP interface configuration mode.

signalling refresh reduction bundle-max-size *size*

Syntax Description

<i>size</i>	Maximum size, in bytes, of a single RSVP bundle message. Range is 512 to 65000.

Command Default

size: 4096

Command Modes

RSVP interface configuration

Command History

Release	Modification
Release 3.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	read, write
ouni	read, write

Examples

The following example shows how to set the maximum bundle size of a single RSVP bundle message to 4000:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp interface tunnel-te 2
RP/0/0/CPU0:router(config-rsvp-if)# signalling refresh reduction bundle-max-size 4000
```

Related Commands

Command	Description
show rsvp interface , on page 516	Displays information about all interfaces with RSVP enabled.

signalling refresh reduction disable

To disable RSVP refresh reduction on an interface, use the **signalling refresh reduction disable** command in RSVP interface configuration mode. To return to the default behavior, use the **no** form of this command.

signalling refresh reduction disable

no signalling refresh reduction disable

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes RSVP interface configuration

Command History	Release	Modification
	Release 3.2	This command was supported.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The following features of the IETF refresh reduction standard RFC 2961 are enabled with this command:

- Setting the refresh-reduction-capable bit in message headers
- Message-ID usage
- Reliable messaging with rapid retransmit, acknowledgment (ACK), and NACK messages
- Summary refresh extension

Because refresh reduction relies on cooperation of the neighbor, the neighbor must also support the standard. If the router detects that a neighbor is not supporting the refresh reduction standard (either through observing the refresh-reduction-enabled bit in messages received from the next hop, or by sending a Message-ID object to the next hop and receiving an error), refresh reduction is not used on this link. That information is obtained through use of the **show rsvp interface detail** command.

Task ID	Task ID	Operations
	mpls-te	read, write
	ouni	read, write

Examples

The following example shows how to disable RSVP refresh reduction on an interface:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp interface tunnel-te 2
RP/0/0/CPU0:router(config-rsvp-if)# signalling refresh reduction disable
```

The following example shows how to enable RSVP refresh reduction on the interface:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp interface tunnel-te 2
RP/0/0/CPU0:router(config-rsvp-if)# no signalling refresh reduction disable
```

Related Commands

Command	Description
show rsvp interface, on page 516	Displays information about all interfaces with RSVP enabled.
signalling refresh interval, on page 544	Changes the frequency with which a router updates the network about the RSVP state of an interface.
signalling refresh reduction reliable, on page 552	Customizes acknowledgment message size and hold interval, and the RSVP message retransmit interval.
signalling refresh reduction summary, on page 555	Enables and configures the maximum size of the signalling refresh message.

signalling refresh reduction reliable

To configure the parameters of reliable messaging, use the **signalling refresh reduction reliable** command in RSVP interface configuration mode. To return to the default behavior, use the **no** form of this command.

signalling refresh reduction reliable {**ack-max-size** *bytes*| **ack-hold-time** *milliseconds*| **retransmit-time** *milliseconds*| **summary-refresh**}

no signalling refresh reduction reliable {**ack-max-size** *bytes*| **ack-hold-time** *milliseconds*| **retransmit-time** *milliseconds*| **summary-refresh**}

Syntax Description

ack-max-size	Specifies the maximum size of the RSVP component within a single acknowledgment message.
<i>bytes</i>	Number of bytes that define the maximum size of an RSVP component. Range is 20 to 65000.
ack-hold-time	Specifies the maximum amount of time a router holds an acknowledgment before sending it, in an attempt to bundle several acknowledgments into a single acknowledgment message.
<i>milliseconds</i>	Number of milliseconds that define the acknowledgment hold time. Range is 100 to 5000.
retransmit-time	Specifies the amount of time the router initially waits for an acknowledgment message before resending the RSVP message.
<i>milliseconds</i>	Number of milliseconds that define the retransmit time. Range is 100 to 10000.
summary-refresh	Enables the use of reliable transmission for RSVP summary refresh messages.

Command Default

ack-max-size *bytes*: 4096
ack-hold-time *milliseconds*: 400 (0.4 seconds)
retransmit-time *milliseconds*: 900 (0.9 seconds)

Command Modes

RSVP interface configuration

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

For reliable messaging to work properly, configure the retransmit time on the send router (A) and acknowledgment hold time on the peer router (B). (Vice versa for messages in reverse direction.)

The retransmit time must be greater than the acknowledgment hold time, so that the acknowledgment message has time to get back to the sender before the message retransmits. We recommend that the retransmit-time interval be at least twice the acknowledgment hold-time interval. If the retransmit-time value is smaller than the acknowledgment hold-time value, then router A retransmits the message even though router B may have received the message and is waiting for an acknowledgment hold time to time out to send the acknowledgment. This causes unnecessary network traffic.

Reducing the value of **ack-max-size** causes more acknowledgment messages to be issued, with fewer acknowledgments contained within each acknowledgment message. However, reducing the acknowledgment-max-size does not speed up the rate at which acknowledgment messages are issued because their frequency is still controlled by the time values (acknowledgment hold time and retransmit time).

To use reliable messaging for summary refresh messages, use the **rsvp interface interface-name** and **signalling refresh reduction summary** commands.

Task ID

Task ID	Operations
mpls-te	read, write
ouni	read, write

Examples

The following example shows how to set the maximum acknowledgment message size to 4096 bytes on POS interface 0/4/0/1:

```
RP/0/0/CPU0:router(config)# rsvp interface pos 0/4/0/1
RP/0/0/CPU0:router(config-rsvp-if)# signalling refresh reduction reliable ack-max-size 4096
```

The following example shows how to return the maximum acknowledgment message size to the default of 1000 bytes on POS interface 0/4/0/1:

```
RP/0/0/CPU0:router(config)# rsvp interface pos 0/4/0/1
RP/0/0/CPU0:router(config-rsvp-if)# no rsvp signalling refresh reduction reliable
```

The following example shows how to set the acknowledgment hold time to 1 second:

```
RP/0/0/CPU0:router(config)# rsvp interface pos 0/4/0/1
RP/0/0/CPU0:router(config-rsvp-if)# signalling refresh reduction reliable ack-hold-time 1000
```

The following example shows how to return the acknowledgment hold time to the default of 0.4 second:

```
RP/0/0/CPU0:router(config)# rsvp interface pos 0/4/0/1
RP/0/0/CPU0:router(config-rsvp-if)# no signalling refresh reduction reliable ack-hold-time
```

The following example shows how to set the retransmit timer to 2 seconds:

```
RP/0/0/CPU0:router(config)# rsvp interface pos 0/4/0/1  
RP/0/0/CPU0:router(config-rsvp-if)# signalling refresh reduction reliable retransmit-time  
2000
```

The following example shows how to return the retransmit timer to the default of 0.9 seconds:

```
RP/0/0/CPU0:router(config)# rsvp interface pos 0/4/0/1  
RP/0/0/CPU0:router(config-rsvp-if)# no signalling refresh reduction reliable
```

The following example shows how to enable the use of reliable transmission for RSVP summary refresh messages:

```
RP/0/0/CPU0:router(config-rsvp-if)# signalling refresh reduction reliable summary-refresh
```

The following example shows how to disable the use of reliable transmission for RSVP summary refresh messages:

```
RP/0/0/CPU0:router(config-rsvp-if)# no signalling refresh reduction reliable summary-refresh
```

Related Commands

Command	Description
signalling refresh reduction disable, on page 550	Disables RSVP refresh reduction on an interface.

signalling refresh reduction summary

To configure RSVP summary refresh message size on an interface, use the **signalling refresh reduction summary** command in RSVP interface configuration mode. To return to the default behavior, use the **no** form of this command.

signalling refresh reduction summary*max-size**bytes*

no signalling refresh reduction summary *max-size**bytes*

Syntax Description

max-size <i>bytes</i>	Specifies the maximum size, in bytes, of a single RSVP summary refresh message. Range is 20 to 65000.

Command Default

bytes: 4096

Command Modes

RSVP interface configuration

Command History

Release	Modification
Release 3.2	This command was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **signalling refresh reduction summary** command to specify the maximum size of the summary refresh messages sent. Message size is verified using the **show rsvp interface detail** command.

Task ID

Task ID	Operations
mpls-te	read, write
ouni	read, write

Examples

The following example shows how to change the summary message maximum size on an interface:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp interface tunnel-te 2
RP/0/0/CPU0:router(config-rsvp-if)# signalling refresh reduction summary max-size 6000
```

The following example shows how to return the summary message maximum size to the default value on an interface:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp interface tunnel-te 2
RP/0/0/CPU0:router(config-rsvp-if)# no signalling refresh reduction summary max-size 6000
```

Related Commands

Command	Description
show rsvp interface, on page 516	Displays information about all interfaces with RSVP enabled.
signalling refresh interval, on page 544	Changes the frequency with which a router updates the network about the RSVP state of an interface.

window-size (RSVP)

To specify the maximum number of RSVP authenticated messages that can be received out of sequence, use the **window-size** command in RSVP authentication configuration mode, RSVP interface authentication configuration mode, or RSVP neighbor authentication configuration mode. To disable the window size, use the **no** form of this command.

window-size *N*

no window-size

Syntax Description

<i>N</i>	Size of the window to restrict out-of-sequence messages. Range is 1 to 64. Default is 1. All out-of-sequence messages are dropped.

Command Default

N: 1

Command Modes

RSVP authentication configuration
RSVP interface authentication configuration
RSVP neighbor authentication configuration

Command History

Release	Modification
Release 3.4.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **window-size** command to specify the maximum number of authenticated messages that are received out of sequence. All RSVP authenticated messages include a sequence number that is used to prevent replays of RSVP messages.

With a default window size of one message, RSVP rejects any out-of-order or out-of-sequence authenticated messages because they are assumed to be replay attacks. However, sometimes bursts of RSVP messages become reordered between RSVP neighbors. If this occurs on a regular basis, and you can verify that the node sending the burst of messages is trusted, you can use the window-size option to adjust the burst size such that RSVP does not discard such reordered bursts. RSVP checks for duplicate messages within these bursts.

Task ID

Task ID	Operations
mpls-te	read, write

Task ID	Operations
ouni	read, write

Examples

The following example shows how to configure the size of the window to 33 in RSVP neighbor authentication configuration mode:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp neighbor 1.1.1.1 authentication
RP/0/0/CPU0:router(config-rsvp-nbor-auth)# window-size 33
```

The following example shows how to configure the size of the window to 33 in RSVP authentication configuration mode:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp authentication
RP/0/0/CPU0:router(config-rsvp-auth)# window-size 33
```

The following example shows how to configure the size of the window to 33 in RSVP interface authentication configuration mode by using the **rsvp interface** command:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# rsvp interface POS 0/2/1/0
RP/0/0/CPU0:router(config-rsvp-if)# authentication
RP/0/0/CPU0:router(config-rsvp-if-auth)# window-size 33
```

Related Commands

Command	Description
key-source key-chain (RSVP) , on page 480	Specifies the source of the key information to authenticate RSVP signaling messages.
life-time (RSVP) , on page 482	Controls how long RSVP maintains idle security associations with other trusted RSVP neighbors.



MPLS OAM Commands

This module describes Multiprotocol Label Switching (MPLS) label switched path (LSP) verification commands. These commands provide a means to detect and diagnose data plane failures and are the first set of commands in the MPLS Operations, Administration, and Maintenance (OAM) solution.

For detailed information about MPLS concepts, configuration tasks, and examples, see *Cisco IOS XR MPLS Configuration Guide for the Cisco XR 12000 Series Router*.

- [clear mpls oam counters, page 560](#)
- [echo disable-vendor-extension, page 562](#)
- [echo revision, page 563](#)
- [mpls oam, page 565](#)
- [ping mpls ipv4, page 566](#)
- [ping mpls traffic-eng, page 571](#)
- [ping pseudowire \(AToM\), page 575](#)
- [ping mpls mldp \(P2MP\), page 579](#)
- [ping mpls mldp \(MP2MP\), page 586](#)
- [show mpls oam, page 593](#)
- [show mpls oam database, page 595](#)
- [traceroute mpls ipv4, page 597](#)
- [traceroute mpls multipath, page 601](#)
- [traceroute mpls traffic-eng, page 605](#)
- [traceroute mpls mldp \(P2MP\), page 608](#)
- [traceroute mpls mldp \(MP2MP\), page 614](#)

clear mpls oam counters

To clear MPLS OAM counters, use the **clear mpls oam counters** command in EXEC mode.

clear mpls oam counters {**global**| **interface** [*type interface-path-id*]} **packet**}

Syntax Description

global	Clears global counters.
interface	Clears counters on a specified interface.
<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface. Note Use the show interfaces command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
packet	Clears global packet counters.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.3.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	execute
mpls-ldp	execute
mpls-static	execute

Examples

The following example shows how to clear all global MPLS OAM counters:

```
RP/0/0/CPU0:router# clear mpls oam counters global
```

echo disable-vendor-extension

To disable sending the vendor extension type length and value (TLV) in the echo request, use the **echo disable-vendor extension** command in MPLS OAM configuration mode. To return to the default behavior, use the **no** form of this command.

echo disable-vendor-extension

no echo disable-vendor-extension

Syntax Description This command has no arguments or keywords.

Command Default The default value is 4.

Command Modes MPLS OAM configuration mode

Release	Modification
Release 3.3.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Operations
mpls-te	read, write
mpls-ldp	read, write
mpls-static	read, write

Examples The following example shows how to disable inclusion of the vendor extensions TLV in the echo requests:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls oam
RP/0/0/CPU0:router(config-oam)# echo disable-vendor-extension
```

echo revision

To set the echo packet revision, use the **echo revision** command in MPLS OAM configuration mode. To return to the default behavior, use the **no** form of this command.

echo revision {1 | 2 | 3 | 4 }

no echo revision

Syntax Description

1 | 2 | 3 | 4

Draft revision number:

- 1: draft-ietf-mpls-lsp-ping-03 (initial)
- 2: draft-ietf-mpls-lsp-ping-03 (rev 1)
- 3: draft-ietf-mpls-lsp-ping-03 (rev 2)
- 4: draft-ietf-mpls-lsp-ping-09 (initial)

Command Default

The default echo revision is 4 (in draft 9).

Command Modes

MPLS OAM configuration mode

Command History

Release	Modification
Release 3.3.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	read, write
mpls-ldp	read, write
mpls-static	read, write

Examples

The following example shows how to set the echo packet default revision:

```
RP/0/0/CPU0:router# configure  
RP/0/0/CPU0:router(config)# mpls oam  
RP/0/0/CPU0:router(config-oam)# echo revision 1
```


mpls oam

To enable MPLS OAM LSP verification, use the **mpls oam** command in global configuration mode. To return to the default behavior, use the **no** form of this command.

mpls oam

no mpls oam

Syntax Description This command has no arguments or keywords.

Command Default By default, MPLS OAM functionality is disabled.

Command Modes Global configuration

Release	Modification
Release 3.3.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **mpls oam** command and OAM functionality is described in the IETF LSP ping draft.

Task ID	Operations
mpls-te	read, write
mpls-ldp	read, write
mpls-static	read, write

Examples The following example shows how to enable MPLS OAM:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# mpls oam
RP/0/0/CPU0:router(config-oam)#
```

ping mpls ipv4

To check MPLS host reachability and network connectivity by specifying the destination type as a Label Distribution Protocol (LDP) IPv4 address, use the **ping mpls ipv4** command in EXEC mode.

ping mpls ipv4 *address/mask* [**destination** *start-address end-address increment*] [**dsmap**] [**exp** *exp-bits*] [**force-explicit-null**] [**interval** *min-send-delay*] [**output interface** *type interface-path-id*] [**nexthop** *nexthop-address*][**pad** *pattern*][**repeat** *count*] [**reply** {**dscp** *dscp-value* | **reply mode** {**ipv4** | **no-reply** | **router-alert**} | **reply pad-tlv**}] [**revision** *version*] [**size** *packet-size*] [**source** *source-address*] [**sweep** *min value max value increment*] [**timeout** *timeout*] [**ttl** *value*] [**verbose**] [**fec-type** {**bgp** | **generic** | **ldp**}]

Syntax Description

<i>address/mask</i>	Address prefix of the target and number of bits in the target address network mask.
destination <i>start address end address address increment</i>	(Optional) Specifies a network 127/8 address to be used as the destination address in the echo request packet. <i>start address</i> Start of the network address. <i>end address</i> Start of the ending network address. <i>address increment</i> Incremental value of the network address, which is expressed as a decimal number value or IP address.
dsmap	(Optional) Indicates that a downstream mapping (DSMAP) type length and value should be included in the LSP echo request.
exp <i>exp-bits</i>	(Optional) Specifies the MPLS experimental field value in the MPLS header for echo replies. Range is 0 to 7. Default is 0.
force-explicit-null	(Optional) Forces an unsolicited explicit null label to be added to the MPLS label stack and allows LSP ping to be used to detect LSP breakages at the penultimate hop.
interval <i>min-send-delay</i>	(Optional) Specifies a send interval, in milliseconds, between requests. Range is 0 to 3600000. Default is 0.

output interface	(Optional) Specifies the output interface where echo request packets are sent.
<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface. Note Use the show interfaces command to see a list of all interfaces currently configured on the router. For more information, use the question mark (?) online help function.
nexthop	(Optional) Specifies the nextop as an IP address.
<i>nexthop-iaddress</i>	(Optional) IP address for the next hop.
pad pattern	(Optional) Specifies the pad pattern for an echo request.
repeat count	(Optional) Specifies the number of times to resend a packet. Range is 1 to 2147483647. Default is 5.
reply dscp dscp-value	Specifies the differentiated service codepoint value for an MPLS echo reply.
reply mode [ipv4 router-alert no-reply]	Specifies the reply mode for the echo request packet. no-reply Do not reply ipv4 Reply with an IPv4 UDP packet (this is the default) router-alert Reply with an IPv4 UDP packet with the IP router alert set
reply pad-tlv	Indicates that a pad TLV should be included.

revision <i>version</i>	(Optional) Specifies the Cisco extension TLV versioning field: • 1 draft-ietf-mpls-lsp-ping-03 (initial) • 2 draft-ietf-mpls-lsp-ping-03 (rev 1) • 3 draft-ietf-mpls-lsp-ping-03 (rev 2) • 4 draft-ietf-mpls-lsp-ping-09 (initial)
size <i>packet size</i>	(Optional) Specifies the packet size or number of bytes in each MPLS echo request packet. Range is 100 to 17986. Default is 100.
source <i>source-address</i>	(Optional) Specifies the source address used in the echo request packet.
sweep <i>min value max value interval</i>	(Optional) Specifies a range of sizes for the echo packets sent. <i>min value</i> Minimum or start size for an echo packet (range is 100 to 17986) <i>max value</i> Maximum or end size for an echo packet (range is 100 to 17986) <i>interval</i> Number used to increment an echo packet size (range is 1 to 8993)
timeout <i>timeout</i>	(Optional) Specifies the timeout interval, in seconds. Range is 0 to 3600. Default is 2.
ttl <i>value</i>	(Optional) Specifies the TTL value to be used in the MPLS labels (range is 1 to 255).
verbose	(Optional) Enables verbose output information, including MPLS echo reply, sender address of the packet, and return codes.

Command Default

exp *exp bits*: 0

interval *min-send-delay*: 0

repeat *count* : 5

reply-mode: IPv4

timeout *timeout* : 2

Command Modes EXEC

Command History	Release	Modification
	Release 3.3.0	This command was introduced.
	Release 3.4.1	Sample output was modified.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **output interface** keyword specifies the output interface on which the MPLS echo request packets are sent. If the specified output interface is not part of the LSP, the packets are not transmitted.

In cases where the sweep keyword is used, values larger than the outgoing interface's MTU are not transmitted.

The **ping** command sends an echo request packet to an address, and then awaits a reply. Ping output can help you evaluate path-to-host reliability, delays over the path, and whether the host can be reached or is functioning.



Note

The **ping mpls** command is not supported on optical LSPs. If an optical LSP is encountered along the LSP's path, it is treated as a physical interface.

For detailed configuration information about the MPLS **ping** command, see *Cisco IOS XR System Monitoring Configuration Guide for the Cisco XR 12000 Series Router*.

Task ID	Task ID	Operations
	mpls-te	read, write
	mpls-ldp	read, write

Examples The following example shows the destination type as a label distribution protocol (LDP) prefix and specifies a range of sizes for the echo packets sent:

```
RP/0/0/CPU0:router# ping mpls ipv4 140.140.140/32 verbose sweep 100 200 15 repeat 1
```

```
Sending 1, [100..200]-byte MPLS Echos to 140.140.140.140/32,
timeout is 2 seconds, send interval is 0 msec:
```

```
Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
'L' - labeled output interface, 'B' - unlabeled output interface,
'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
'P' - no rx intf label prot, 'p' - premature termination of LSP,
```

'R' - transit router, 'I' - unknown upstream index,
 'X' - unknown return code, 'x' - return code 0

Type escape sequence to abort.

```
! size 100, reply addr 196.100.1.26, return code 3
! size 115, reply addr 196.100.1.26, return code 3
! size 130, reply addr 196.100.1.26, return code 3
! size 145, reply addr 196.100.1.26, return code 3
! size 160, reply addr 196.100.1.26, return code 3
! size 175, reply addr 196.100.1.26, return code 3
! size 190, reply addr 196.100.1.26, return code 3
```

Success rate is 100 percent (7/7), round-trip min/avg/max = 5/6/8 ms

The following example shows the destination type as a label distribution protocol (LDP) prefix and specifies FEC type as generic and verbose option:

```
RP/0/0/CPU0:router# ping mpls ipv4 11.11.11.11/32 fec-type generic output interface
gigabitEthernet 0/0/0/3
nexthop 172.40.103.2 verbose
```

Sending 5, 100-byte MPLS Echos to 11.11.11.11/32,
 timeout is 2 seconds, send interval is 0 msec:

Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
 'L' - labeled output interface, 'B' - unlabeled output interface,
 'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
 'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
 'P' - no rx intf label prot, 'p' - premature termination of LSP,
 'R' - transit router, 'I' - unknown upstream index,
 'X' - unknown return code, 'x' - return code 0

Type escape sequence to abort.

```
! size 100, reply addr 11.101.11.11, return code 3
! size 100, reply addr 11.101.11.11, return code 3
! size 100, reply addr 11.101.11.11, return code 3
! size 100, reply addr 11.101.11.11, return code 3
! size 100, reply addr 11.101.11.11, return code 3
```

Success rate is 100 percent (5/5), round-trip min/avg/max = 3/4/6 ms

ping mpls traffic-eng

To specify the destination type as an MPLS-TE tunnel and tunnel interface, use the **ping mpls traffic-eng** command in EXEC mode.

ping mpls traffic-eng tunnel *tunnel-ID* [**dsmap**] [**exp** *exp-bits*] [**force-explicit-null**] [**interval** *min-send-delay*] [**pad** *pattern*] [**repeat** *count*] [**reply** {**dscp** *dscp-value* | **reply mode** {**ipv4** | **no-reply** | **router-alert**} | **reply pad-tlv**}] [**revision** *version*] [**size** *packet-size*] [**source** *source-address*] [**sweep** *min-value max-value increment*] [**timeout** *timeout*] [**ttl** *value*] [**verbose**]

Syntax Description

tunnel <i>tunnel-ID</i>	Specifies the destination type as an MPLS traffic engineering (TE) tunnel and the tunnel interface number. The range for the tunnel interface number is from 0 to 65535.
dsmap	(Optional) Indicates that a downstream mapping (DSMAP) type length and value should be included in the LSP echo request.
exp <i>exp-bits</i>	(Optional) Specifies the MPLS experimental field value in the MPLS header for echo replies. Range is 0 to 7. Default is 0.
force-explicit-null	(Optional) Forces an unsolicited explicit null label to be added to the MPLS label stack and allows LSP ping to be used to detect LSP breakages at the penultimate hop.
interval <i>min-send-delay</i>	(Optional) Specifies a send interval, in milliseconds, between requests. Range is 0 to 3600000. Default is 0.
pad <i>pattern</i>	(Optional) Specifies the pad pattern for an echo request.
repeat <i>count</i>	(Optional) Specifies the number of times to resend a packet. Range is 1 to 2147483647. Default is 5.
reply dscp <i>dscp-value</i>	(Optional) Specifies the differentiated service codepoint value for an MPLS echo reply.
reply mode [ipv4 router-alert no-reply]	(Optional) Specifies the reply mode for the echo request packet. no-reply Do not reply ipv4 Reply with an IPv4 UDP packet (this is the default) router-alert Reply with an IPv4 UDP packet with the IP router alert set
reply pad-tlv	(Optional) Indicates that a pad TLV should be included.

revision <i>version</i>	(Optional) Specifies the Cisco extension TLV versioning field: • 1 draft-ietf-mpls-lsp-ping-03 (initial) • 2 draft-ietf-mpls-lsp-ping-03 (rev 1) • 3 draft-ietf-mpls-lsp-ping-03 (rev 2) • 4 draft-ietf-mpls-lsp-ping-09 (initial)
size <i>packet-size</i>	(Optional) Specifies the packet size or number of bytes in each MPLS echo request packet. Range is 100 to 17986. Default is 100.
source <i>source-address</i>	(Optional) Specifies the source address used in the echo request packet.
sweep <i>min-value max-value interval</i>	(Optional) Specifies a range of sizes for the echo packets sent. <i>min-value</i> Minimum or start size for an echo packet (range is 100 to 17986) <i>max-value</i> Maximum or end size for an echo packet(range is 100 to 17986) <i>interval</i> Number used to increment an echo packet size(range is 1 to 8993)
timeout <i>timeout</i>	(Optional) Specifies the timeout interval, in seconds. Range is 0 to 3600. Default is 2.
ttl <i>value</i>	(Optional) Specifies the TTL value to be used in the MPLS labels (range is 1 to 255).
verbose	(Optional) Enables verbose output information, including MPLS echo reply, sender address of the packet, and return codes.

Command Default

exp *exp-bits*: 0

interval *min-send-delay*: 0

repeat *count*: 5

reply-mode: IPv4

timeout *timeout* : 2

Command Modes

EXEC

Command History

Release	Modification
Release 3.3.0	This command was introduced.
Release 3.4.1	Sample output was modified.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **output interface** keyword specifies the output interface on which the MPLS echo request packets are sent. If the specified output interface is not part of the LSP, the packets are not transmitted.

In cases where the **sweep** keyword is used, values larger than the outgoing interface's MTU are not transmitted.

The **ping** command sends an echo request packet to an address, and then awaits a reply. Ping output can help you evaluate path-to-host reliability, delays over the path, and whether the host can be reached or is functioning.

**Note**

The **ping mpls traffic-eng** command is not supported on optical LSPs. If an optical LSP is encountered along the LSP's path, it is treated as a physical interface.

Task ID

Task ID	Operations
mpls-te	read, write
mpls-ldp	read, write

Examples

The following example shows how to check connectivity by using the **ping mpls traffic-eng** command when a TE tunnel 10 is present. Return code, reply address, and packet size are displayed due to the **verbose** keyword.

```
RP/0/0/CPU0:router# ping mpls traffic-eng tunnel 10 repeat 1 verbose

Sending 1, 100-byte MPLS Echos to tunnel-te10,
    timeout is 2 seconds, send interval is 0 msec:

Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
       'L' - labeled output interface, 'B' - unlabeled output interface,
       'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
       'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
       'P' - no rx intf label prot, 'p' - premature termination of LSP,
       'R' - transit router, 'X' - unknown return code, 'x' - return code 0

Type escape sequence to abort.
!    size 100, reply addr 196.100.1.18, return code 3

Success rate is 100 percent (1/1), round-trip min/avg/max = 15/15/15 ms
```

Related Commands

Command	Description
show mpls traffic-eng tunnels	Displays information about MPLS-TE tunnels.
ping mpls traffic-eng tunnel-te (P2P)	Verifies the connectivity of the LSP path for the MPLS-TE tunnel.

ping pseudowire (AToM)

To verify connectivity between provider edge (PE) LSRs in an Any Transport over MPLS (AToM) setup, use the **ping pseudowire** command in EXEC mode.

ping [**mpls**] **pseudowire** *remote-PE -address pw-id* [**exp** *exp-bits*] [**interval** *min-send-delay*] [**pad** *pattern*] [**repeat** *count*] [**reply** {**dscp** *dscp-value* | **reply mode** {**ipv4** | **no-reply** | **router-alert** | **control-channel**} | **reply pad-flv**}] [**size** *packet-size*] [**source** *source-address*] [**sweep** *min-value max-value increment*] [**timeout** *timeout*] [**ttl** *value*] [**verbose**]

Syntax Description

mpls	(Optional) Verifies the Labeled Switch Path (LSP).
<i>remote-PE address</i>	IP address of the remote PE LSR.
<i>pw-id</i>	Pseudowire ID that identifies the pseudowire in which MPLS connectivity is being verified. The pseudowire is used to send the echo request packets. The range is from 1 to 4294967295.
exp <i>exp-bits</i>	(Optional) Specifies the MPLS experimental field value in the MPLS header for echo replies. Range is 0 to 7. Default is 0.
interval <i>min-send-delay</i>	(Optional) Specifies a send interval, in milliseconds, between requests. Range is 0 to 3600000. Default is 0.
pad <i>pattern</i>	(Optional) Specifies the pad pattern for an echo request.
repeat <i>count</i>	(Optional) Specifies the number of times to resend a packet. Range is 1 to 2147483647. Default is 5.
reply dscp <i>dscp-value</i>	(Optional) Specifies the differentiated service codepoint value for an MPLS echo reply.

reply mode { ipv4 router-alert no-reply control-channel }	(Optional) Specifies the reply mode for the echo request packet.
no-reply	Do not reply
ipv4	Reply with an IPv4 UDP packet (the default)
router-alert	Reply with an IPv4 UDP packet with the IP router alert set
control-channel	Force the use of a VCCV control channel. Reply using an application for a defined control channel. This applies only to pseudowires in which VCCV is used in the reply path. This is the default choice for pseudowire ping.
reply pad-tlv	(Optional) Indicates that a reply pad TLV should be included.
size <i>packet-size</i>	(Optional) Specifies the packet size or number of bytes in each MPLS echo request packet. Range is 100 to 17986. Default is 100.
source <i>source-address</i>	(Optional) Specifies the source address used in the echo request packet.
sweep <i>min-value max-value interval</i>	Specifies a range of sizes for the echo packets sent. <i>min-value</i> Minimum or start size for an echo packet (range is 100 to 17986) <i>max-value</i> Maximum or end size for an echo packet (range is 100 to 17986) <i>interval</i> Number used to increment an echo packet size (range is 1 to 8993)
timeout <i>timeout</i>	(Optional) Specifies the timeout interval in seconds. Range is 0 to 3600. Default is 2 seconds.
ttl <i>value</i>	(Optional) Specifies the TTL value to be used in the MPLS labels (range is 1 to 255).

verbose	(Optional) Enables verbose output information, including MPLS echo reply, sender address of the packet, and return codes.

Command Default

exp *exp bits*: 0
interval *min-send-delay*: 0
repeat *count*: 5
reply-mode: IPv4
timeout *timeout* : 2

Command Modes

EXEC

Command History

Release	Modification
Release 3.4.1	This command was introduced.
Release 3.9.0	The following keywords and arguments were added: • force-control-channel, control-word, ra-label and ttl-expiry keywords were added.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

In cases in which the **sweep** keyword is used, values larger than the outgoing interface's MTU are not transmitted.

The **ping** command sends an echo request packet to an address, and then awaits a reply. Ping output can help you evaluate path-to-host reliability, delays over the path, and whether the host can be reached or is functioning.

**Note**

The **ping mpls** command is not supported on optical LSPs. If an optical LSP is encountered along the LSP's path, it is treated as a physical interface.

AToM VCCV allows the sending of control packets inband of an AToM pseudowire (PW) from the originating provider edge (PE) router. The transmission is intercepted at the destination PE router, instead of being forwarded to the customer edge (CE) router. This lets you use MPLS LSP ping to test the pseudowire section of AToM virtual circuits (VCs).

The no interactive version of the **ping pseudowire (AToM)** command is supported.

The control word setting is either enabled along the entire path between the Terminating-Provider Edge (T-PE) or it is completely disabled. If the control word configuration is enabled on one segment and disabled on another segment, the multisegment pseudowire does not come up.

Task ID

Task ID	Operations
mpls-te	read, write
mpls-ldp	read, write

Examples

The following example shows how the **ping mpls pseudowire** command is used to verify PE to PE connectivity in which the remote PE address is 150.150.150.150. Only one echo request packet is sent and the remote PE is to answer using IPv4 instead of the control channel.

```
RP/0/0/CPU0:router# ping mpls pseudowire 150.150.150.150 21 repeat 1 reply mode ipv4

Sending 1, 100-byte MPLS Echos to 150.150.150.150 VC: 21,
    timeout is 2 seconds, send interval is 0 msec:

Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
       'L' - labeled output interface, 'B' - unlabeled output interface,
       'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
       'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
       'P' - no rx intf label prot, 'p' - premature termination of LSP,
       'R' - transit router, 'I' - unknown upstream index,
       'X' - unknown return code, 'x' - return code 0

Type escape sequence to abort.
!
Success rate is 100 percent (1/1), round-trip min/avg/max = 23/23/23 ms
```

ping mpls mldp (P2MP)

To check data plane and control plane of MPLS for the Point-to-Multipoint (P2MP) label switch path, use the **ping mpls mldp p2mp** command in EXEC mode.

ping mpls mldp p2mp *root-address* { **IPv4** *source-ipv4-address group-ipv4-address* | **IPv6** *source-ipv6-address group-ipv6-address* | **vpn***vpn4 AS-number [source-ipv4-address group-ipv4-address]* | **vpn***vpn6 AS-number [source-ipv6-address group-ipv6-address]* } **mdt** *oui:vpn-index mdt-number* | **global-id** *lsp-id* } [**options**]

Syntax Description

mldp	Verifies the ping capability for multicast label distribution protocol (mldp).
p2mp	Indicates the Point-to-Multipoint (P2MP) label switch path.
<i>root-address</i>	Specifies the root address.
IPv4 <i>ipv4-address</i>	Defines IPv4 opaque encoding.
IPv6 <i>ipv6-address</i>	Defines IPv6 opaque encoding.
vpn <i>vpn4 AS-number [source-ipv4-address group-ipv4-address]</i>	Defines VPNv4 opaque encoding.
vpn <i>vpn6 AS-number [source-ipv6-address group-ipv6-address]</i>	Defines VPNv6 opaque encoding.
mdt <i>oui:vpn-index mdt number</i>	Defines VPN ID opaque encoding. Range of 3-byte OUI is 0 to 16777215. Range of <i>mdt-number</i> is 0 to 4294967295.
global-id <i>lsp-id</i>	Defines 4 byte global LSP ID opaque encoding.
<i>source-address</i>	Specifies the source address of target multicast address.
<i>group-address</i>	Specifies the target address of target multicast address.
<i>AS-number</i>	Specifies the Autonomous system number as follows: • 4-byte AS-number with asdot (X.Y) : aa.bb:cc format (for example, 11.22:33) • 2-byte AS-number or 4-byte AS-number: aa.bb format (for example, 11:22) • IPv4 address and index:aa.bb.cc.dd:ee format (for example, 11.22.33.44:55)

options

Specifies a set of various options:

ddmap

(Optional) Indicates that a downstream detailed mapping TLV (ddmap) should be included in the LSP echo request.

destination

(Optional) Specifies a network 127/8 address to be used as the destination address in the echo request packet.

start-address: Start of the network address.

end-address: End of the network address.

address increment: Incremental value of the network address, which is expressed as a decimal number value or IP address.

expexp-bits

(Optional) Specifies the MPLS experimental field value in the MPLS header for echo replies. Range is 0 to 7. Default is 0.

flags

fec: (Optional) Specifies that forwarding equivalent class (FEC) stack checking is to be performed at transit routers.

no-ttl: (Optional) Specifies not to add TTL expired flag in echo request.

force-explicit-null

(Optional) Forces an unsolicited explicit null label to be added to the MPLS label stack and allows LSP ping to be used to detect LSP breakages at the penultimate hop.

interval *min-send-delay*

(Optional) Specifies a send interval, in milliseconds, between requests. Range is 0 to 3600000. Default is 0.

jitter

(Optional) Specifies a jitter value for a corresponding echo request, in milliseconds.

Range is 0 to 2147483647. Default is 200.

pad *pattern*

(Optional) Specifies the pad pattern for an echo request.

repeat *count*

(Optional) Specifies the number of times to resend a packet. Range is 1 to 2147483647. Default is 5.

reply dscp *dscp-value*

(Optional) Specifies the differentiated service codepoint value for an MPLS echo reply.

mode [ipv4 | router-alert]

(Optional) Specifies the reply mode for the echo request packet.

ipv4

Reply with an IPv4 UDP packet (this is the default)

router-alert

Reply with an IPv4 UDP packet with the IP router alert set

responder-id *ipv4-address*

(Optional) Adds responder identifier into corresponding echo request.

size *packet size*

(Optional) Specifies the packet size or number of bytes in each MPLS echo request packet. Range is 100 to 17986. Default is 100.

source *ipv4-address*

(Optional) Specifies the source address used in the echo request packet.

sweep

(Optional)

timeout *timeout*

(Optional) Specifies the timeout interval, in seconds. Range is 0 to 3600. Default is 2.

ttl

(Optional) Specifies the TTL value to be used in the MPLS labels (range is 1 to 255). Default is 255.

verbose

(Optional) Enables verbose output information, including MPLS echo reply, sender address of the packet, and return codes.

Command Default No default behavior or values

Command Modes EXEC

Command History	Release	Modification
	Release 4.1.1	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	basic-services	execute
	mpls-te	read
	mpls-ldp	read

Examples The following examples show how to check connectivity for P2MP by using the **ping mpls mldp p2mp** command.

```
RP/0/0/CPU0:router#ping mpls mldp p2mp 192.168.0.1 ipv4 2.2.2.2 232.1.1.1
```

```
Sending 1, 100-byte MPLS Echos to mldp p2mp 192.168.0.1 ipv4 (2.2.2.2, 232.1.1.1),
    timeout is 2.2 seconds, send interval is 0 msec, jitter value is 200 msec:
```

```
Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
        'L' - labeled output interface, 'B' - unlabeled output interface,
        'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
        'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
        'P' - no rx intf label prot, 'p' - premature termination of LSP,
        'R' - transit router, 'I' - unknown upstream index,
        'X' - unknown return code, 'x' - return code 0, 'd' - DDMAP
```

Type escape sequence to abort.

```
Request #1
! reply addr 11.11.11.3
! reply addr 12.12.12.4
```

Round-trip min/avg/max = 17/27/38 ms

```
RP/0/0/CPU0:router#ping mpls mldp p2mp 192.168.0.1 ipv4 2.2.2.2 232.1.1.1 ddmapp ttl 1
```

```
Sending 1, 100-byte MPLS Echos to mldp p2mp 192.168.0.1 ipv4 (2.2.2.2, 232.1.1.1),
    timeout is 2.2 seconds, send interval is 0 msec, jitter value is 200 msec:
```

```
Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
        'L' - labeled output interface, 'B' - unlabeled output interface,
        'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
        'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
        'P' - no rx intf label prot, 'p' - premature termination of LSP,
        'R' - transit router, 'I' - unknown upstream index,
        'X' - unknown return code, 'x' - return code 0, 'd' - DDMAP
```

Type escape sequence to abort.

```
Request #1
d reply addr 10.10.10.2
  [L] DDMAP 0: 11.11.11.3 11.11.11.3 MRU 1500 [Labels: 16016 Exp: 0]
  [L] DDMAP 1: 12.12.12.4 12.12.12.4 MRU 1500 [Labels: 16016 Exp: 0]
```

This table describes the significant fields shown in the display:

Opaque Type	Opaque Value	Supported Multicast Application	Signaling
IPv4	S, G	PIM-SSM transit of IPv4	In-Band
IPv6	S, G	PIM-SSM transit of IPv6	In-Band
MDT	VPN-ID, MDT#	mVPN Default-MDT (MDT# = 0) mVPN Data-MDT (MDT# > 0)	In-Band
Global ID	4 byte value	BGP Assigned LSPs	Out-of-Band
VPNv4	(S,G), VPN-ID	VPNv4	In-Band
VPNv6	(S,G), VPN-ID	VPNv6	In-Band

Related Commands

Command	Description
ping mpls mldp (MP2MP), on page 586	Verifies data plane and control plane for the Multipoint-to-Multipoint (MP2MP) label switch path.
traceroute mpls mldp (P2MP), on page 608	Verifies hop-by-hop fault localization and path tracing for the point-to-multipoint path.
traceroute mpls mldp (MP2MP), on page 614	Verifies hop-by-hop fault localization and path tracing for the multipoint-to-multipoint path.

ping mpls mldp (MP2MP)

To check data plane and control plane of MPLS for the Multipoint-to-Multipoint (MP2MP) label switch path, use the **ping mpls mldp mp2mp** command in exec mode.

ping mpls mldp mp2mp *root-address* { **IPv4** *source-ipv4-address group-ipv4-address* | **IPv6** *source-ipv6-address group-ipv6-address* | **vpn4** *AS-number* [*source-ipv4-address group-ipv4-address*] | **vpn6** *AS-number* [*source-ipv6-address group-ipv6-address*] | **mdt** *oui:vpn-index mdt-number* | **global-id** *lsp-id* } [**options**]

Syntax Description

mldp	Verifies the ping capability for multicast label distribution protocol (mldp).
mp2mp	Indicates the Multipoint-to-Multipoint (MP2MP) label switch path.
<i>root-address</i>	Specifies the root address.
IPv4 <i>ipv4-address</i>	Defines IPv4 opaque encoding.
IPv6 <i>ipv6-address</i>	Defines IPv6 opaque encoding.
vpn4 <i>AS-number</i> [<i>source-ipv4-address group-ipv4-address</i>]	Defines VPNv4 opaque encoding.
vpn6 <i>AS-number</i> [<i>source-ipv6-address group-ipv6-address</i>]	Defines VPNv6 opaque encoding.
mdt <i>oui:vpn-index mdt number</i>	Defines VPN ID opaque encoding. Range of 3-byte OUI is 0 to 16777215. Range of <i>mdt-number</i> is 0 to 4294967295.
global-id <i>lsp-id</i>	Defines 4 byte global LSP ID opaque encoding.
<i>source-address</i>	Specifies the source address of target multicast address.
<i>group-address</i>	Specifies the target address of target multicast address.
<i>AS-number</i>	Specifies the Autonomous system number as follows: 4-byte AS-number with asdot (X.Y) : aa.bb.cc format (for example, 11.22:33) 2-byte AS-number or 4-byte AS-number: aa.bb format (for example, 11:22) - IPv4 address and index:aa.bb.cc.dd:ee format (for example, 11.22.33.44:55)

options

Specifies a set of various options:

ddmap

(Optional) Indicates that a downstream detailed mapping TLV (ddmap) should be included in the LSP echo request.

destination

(Optional) Specifies a network 127/8 address to be used as the destination address in the echo request packet.

start-address: Start of the network address.

end-address: End of the network address.

address increment: Incremental value of the network address, which is expressed as a decimal number value or IP address.

expexp-bits

(Optional) Specifies the MPLS experimental field value in the MPLS header for echo replies. Range is 0 to 7. Default is 0.

flags

fec: (Optional) Specifies that forwarding equivalent class (FEC) stack checking is to be performed at transit routers.

no-ttl: (Optional) Specifies not to add TTL expired flag in echo request.

force-explicit-null

(Optional) Forces an unsolicited explicit null label to be added to the MPLS label stack and allows LSP ping to be used to detect LSP breakages at the penultimate hop.

interval *min-send-delay*

(Optional) Specifies a send interval, in milliseconds, between requests. Range is 0 to 3600000. Default is 0.

jitter

(Optional) Specifies a jitter value for a corresponding echo request, in milliseconds.

Range is 0 to 2147483647. Default is 200.

pad *pattern*

(Optional) Specifies the pad pattern for an echo request.

repeat *count*

(Optional) Specifies the number of times to resend a packet. Range is 1 to 2147483647. Default is 5.

reply dscp *dscp-value*

(Optional) Specifies the differentiated service codepoint value for an MPLS echo reply.

mode [*ipv4* | *router-alert*]

(Optional) Specifies the reply mode for the echo request packet.

ipv4

Reply with an IPv4 UDP packet (this is the default)

router-alert

Reply with an IPv4 UDP packet with the IP router alert set

responder-id *ipv4-address*

(Optional) Adds responder identifier into corresponding echo request.

size *packet size*

(Optional) Specifies the packet size or number of bytes in each MPLS echo request packet. Range is 100 to 17986. Default is 100.

source *ipv4-address*

(Optional) Specifies the source address used in the echo request packet.

sweep

(Optional)

timeout *timeout*

(Optional) Specifies the timeout interval, in seconds. Range is 0 to 3600. Default is 2.

ttl

(Optional) Specifies the TTL value to be used in the MPLS labels (range is 1 to 255). Default is 255.

verbose

(Optional) Enables verbose output information, including MPLS echo reply, sender address of the packet, and return codes.

Command Default No default behavior or values

Command Modes EXEC

Command History	Release	Modification
	Release 4.1.1	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	basic-services	execute
	mpls-te	read
	mpls-ldp	read

Examples The following example shows how to check connectivity by using the **ping mpls mldp** command when a root address is present.

```
RP/0/0/CPU0:router#ping mpls mldp mp2mp 192.168.0.1 global-id 1
```

Mon Jul 11 15:35:50.294 JST

Sending 1, 100-byte MPLS Echos to mldp mp2mp 192.168.0.1 global-id 1,
timeout is 2.2 seconds, send interval is 0 msec, jitter value is 200 msec:

Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
'L' - labeled output interface, 'B' - unlabeled output interface,
'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
'P' - no rx intf label prot, 'p' - premature termination of LSP,
'R' - transit router, 'I' - unknown upstream index,
'X' - unknown return code, 'x' - return code 0, 'd' - DDMAP

Type escape sequence to abort.

Request #1
! reply addr 10.10.10.2
! reply addr 12.12.12.4
! reply addr 11.11.11.3

Round-trip min/avg/max = 72/112/135 ms

RP/0/0/CPU0:router#ping mpls mldp mp2mp 192.168.0.1 global-id 1 responder-id 11.11.11.3
Mon Jul 11 15:36:16.038 JST

Sending 1, 100-byte MPLS Echos to mldp mp2mp 192.168.0.1 global-id 1,
timeout is 2.2 seconds, send interval is 0 msec, jitter value is 200 msec:

Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
'L' - labeled output interface, 'B' - unlabeled output interface,
'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
'P' - no rx intf label prot, 'p' - premature termination of LSP,
'R' - transit router, 'I' - unknown upstream index,
'X' - unknown return code, 'x' - return code 0, 'd' - DDMAP

Type escape sequence to abort.

Request #1
! reply addr 11.11.11.3

Round-trip min/avg/max = 163/163/163 ms

This table describes the significant fields shown in the display:

Opaque Type	Opaque Value	Supported Multicast Application	Signaling
IPv4	S, G	PIM-SSM transit of IPv4	In-Band
IPv6	S, G	PIM-SSM transit of IPv6	In-Band
MDT	VPN-ID, MDT#	mVPN Default-MDT (MDT# = 0) mVPN Data-MDT (MDT# > 0)	In-Band
Global ID	4 byte value	BGP Assigned LSPs	Out-of-Band
VPNv4	(S,G), VPN-ID	VPNv4	In-Band
VPNv6	(S,G), VPN-ID	VPNv6	In-Band

Related Commands

Command	Description
ping mpls mldp (P2MP), on page 579	Verifies data plane and control plane for the point-to-multipoint (P2MP) label switch path.
traceroute mpls mldp (P2MP), on page 608	Verifies hop-by-hop fault localization and path tracing for the point-to-multipoint path.
traceroute mpls mldp (MP2MP), on page 614	Verifies hop-by-hop fault localization and path tracing for the multipoint-to-multipoint path.

show mpls oam

To display MPLS OAM information, use the **show mpls oam** command in EXEC mode.

show mpls oam {**client**| **counters** {**global**| **packet**}| **interface** *type interface-path-id*}

Syntax Description

client	Displays clients registered with LSPV server.
counters global	Displays LSP verification global counters.
counters packet	Displays LSP verification packet counters.
counters interface	Displays LSP verification information for a specific interface.
<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface. Note Use the show interfaces command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.5.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	read
mpls-ldp	read

Task ID	Operations
mpls-static	read

Examples

The following example shows how to display MPLS OAM client information:

```
RP/0/0/CPU0:router# show mpls oam client
Client Process: l2vpn_mgr Node: 0/0/SP Pid: 418014
Client Process: te_control Node: 0/0/SP Pid: 639227
```

This table describes the significant fields shown in the display.

Table 79: show mpls oam client Command Field Descriptions

Field	Description
Client Process	Process of client.

show mpls oam database

To display MPLS OAM database information, use the **show mpls oam database** command in EXEC mode.

show mpls oam database { **requests** | **tt-requests** } [**detail**] [**handle** *handle-value*]

Syntax Description

requests	Displays request database
tt-requests	Displays tree trace request database
detail	(Optional) Displays displayed information.
handle	(Optional) Displays handle information.
<i>handle-value</i>	Generic handle value. Range is from 0 to 4294967295.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.5.0	This command was introduced.
Release 3.9.0	The <i>handle-value</i> argument was added.
Release 4.0.0	The replies keyword was removed.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
mpls-te	read
mpls-ldp	read
mpls-static	read

Examples

The following example shows how to display detailed MPLS OAM database information:

```
RP/0/0/CPU0:router# show mpls oam database request detail
```


traceroute mpls ipv4

To learn the routes that packets follow when traveling to their Label Distribution Protocol (LDP) IPv4 destination, use the **traceroute mpls** command in EXEC mode.

traceroute mpls ipv4*address/mask* [**destination** *start-address end-address address-increment*] [**exp** *exp-bits*] [**flags** *fec*] [**force-explicit-null**] [**output interface** *type interface-path-id*] [**nexthop** *nexthop-address*] [**reply** {*dscp dscp-value* | **reply mode** {*ipv4* | *router-alert*} }] [**revision** *version*] [**source** *source-address*] [**timeout** *timeout*] [**ttl** *value*] [**verbose**] [**fec-type** {*bgp* | *generic* | *ldp*}]

Syntax Description

<i>address/mask</i>	Specifies the destination type as a label distribution protocol (LDP) prefix. Address prefix of the target and number of bits in the target address network mask.
destination <i>start-address end-address address-increment</i>	Specifies a network 127 address to be used as the destination address in the echo request packet. <i>start address</i> Start of the network address. <i>end address</i> End of the network address. <i>address increment</i> Incremental value of the network address.
exp <i>exp-bits</i>	(Optional) Specifies the MPLS experimental field value in the MPLS header for echo replies. Range is 0 to 7. Default is 0.
flags <i>fec</i>	(Optional) Specifies that forwarding equivalent class (FEC) stack checking is to be performed at transit routers.
force-explicit-null	(Optional) Forces an unsolicited explicit null label to be added to the MPLS label stack and allows LSP ping to be used to detect LSP breakages at the penultimate hop.
output interface	(Optional) Specifies the output interface in which echo request packets are sent.
<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface. Note Use the show interfaces command to see a list of all interfaces currently configured on the router. For more information, use the question mark (?) online help function.

nexthop	(Optional) Specifies the IP address for the next hop.
<i>nexthop-address</i>	(Optional) IP address for the next hop.
reply dscp <i>dscp-value</i>	(Optional) Specifies the differentiated service codepoint value for an MPLS echo reply.
reply mode { ipv4 router-alert }	(Optional) Specifies the reply mode for the echo request packet. ipv4 Reply with IPv4 UDP packet (this is the default) router-alert Reply with IPv4 UDP packet with router alert
revision <i>version</i>	(Optional) Specifies the Cisco extension TLV versioning field: • 1 draft-ietf-mpls-lsp-ping-03 (initial) • 2 draft-ietf-mpls-lsp-ping-03 (rev 1) • 3 draft-ietf-mpls-lsp-ping-03 (rev 2) • 4 draft-ietf-mpls-lsp-ping-09 (initial)
source <i>source-address</i>	(Optional) Specifies the source address used in the echo request packet.
timeout <i>timeoutt</i>	(Optional) Specifies the timeout interval, in seconds. Range is from 0 to 3600. Default is 2.
ttl <i>value</i>	(Optional) Specifies the maximum number of hops (range is 1 to 255).
verbose	(Optional) Enables verbose output information, including MPLS echo reply, sender address of the packet, and return codes.

Command Default

exp *exp-bits*: 0
reply mode: IPv4
timeout *timeout*: 2

Command Modes

EXEC

Command History

Release	Modification
Release 3.3.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

**Note**

The **traceroute mpls** command is not supported on optical LSPs. If an optical LSP is encountered along the LSPs path, it is treated as a physical interface.

For detailed configuration information about MPLS LSP trace operations, see *Cisco IOS XR System Monitoring Configuration Guide for the Cisco XR 12000 Series Router*.

Task ID

Task ID	Operations
mpls-te	read, write
mpls-ldp	read, write

Examples

The following example shows how to trace a destination:

```
RP/0/0/CPU0:router# traceroute mpls ipv4 140.140.140.140/32
destination 127.0.0.10 127.0.0.15.1
```

Tracing MPLS Label Switched Path to 140.140.140.140/32, timeout is 2 seconds

```
Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
'L' - labeled output interface, 'B' - unlabeled output interface,
'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
'P' - no rx intf label prot, 'p' - premature termination of LSP,
'R' - transit router, 'I' - unknown upstream index,
'X' - unknown return code, 'x' - return code 0
```

Type escape sequence to abort.

Destination address 127.0.0.10

```
0 196.100.1.41 MRU 4470 [Labels: 19 Exp: 0]
L 1 196.100.1.42 MRU 4470 [Labels: 86 Exp: 0] 360 ms
2 196.100.1.50 MRU 4470 [Labels: implicit-null Exp: 0] 8 ms
! 3 196.100.1.18 9 ms
```

The following example shows how to trace a destination with FEC type specified as generic and verbose option:

```
RP/0/0/CPU0:router# traceroute mpls ipv4 11.11.11.11/32 fec-type generic output interface
gigabitEthernet 0/0/0/3
nexthop 172.40.103.2 verbose
```

Tracing MPLS Label Switched Path to 11.11.11.11/32, timeout is 2 seconds

```
Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
'L' - labeled output interface, 'B' - unlabeled output interface,
'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
```

'P' - no rx intf label prot, 'p' - premature termination of LSP,
'R' - transit router, 'I' - unknown upstream index,
'X' - unknown return code, 'x' - return code 0

Type escape sequence to abort.

```
0 172.40.103.1 172.40.103.2 MRU 1500 [Labels: 16038 Exp: 0]
L 1 172.40.103.2 173.101.103.1 MRU 1500 [Labels: 16037 Exp: 0] 6 ms, ret code 8
L 2 173.101.103.1 11.101.11.11 MRU 1500 [Labels: implicit-null Exp: 0] 4 ms, ret code 8
! 3 11.101.11.11 6 ms, ret code 3
```

traceroute mpls multipath

To discover all possible paths of an LSP between the ingress and egress routers, use the **traceroute mpls multipath** command in EXEC mode.

traceroute mpls multipath ipv4 *address/mask* [**destination** *start-address end-address address-increment*] [**exp** *exp-bits*] [**flags** *fec*] [**force-explicit-null**] [**hashkey** **ipv4** **bitmap** *bit-size*] [**interval** *min-send-delay*] [**output interface** *type interface-path-id*] [**nexthop** *nexthop-address*] [**reply** {**dscp** *dscp-value* | **reply mode**{**ipv4** | **router-alert**} }] [**retry-count** *count*] [**revision** *version*] [**source** *source-address*] [**timeout** *timeout*] [**ttl** *value*] [**verbose**] [**fec-type** {**bgp** | **generic** | **ldp**}]

Syntax Description

ipv4	Specifies the destination type as a Label Distribution Protocol (LDP) IPv4 address.
<i>address/mask</i>	Address prefix of the target and number of bits in the target address network mask.
destination <i>start-address end-address address-increment</i>	(Optional) Specifies a network 127 address to be used as the destination address in the echo request packet. start-address Start of the network address. end-address End of the network address. address-increment Incremental value of the network address.
exp <i>exp-bits</i>	(Optional) Specifies the MPLS experimental field value in the MPLS header for echo replies. Range is 0 to 7. Default is 0.
flags <i>fec</i>	(Optional) Specifies that forwarding equivalent class (FEC) stack checking is to be performed at transit routers.
force-explicit-null	(Optional) Forces an unsolicited explicit null label to be added to the MPLS label stack and allows LSP ping to be used to detect LSP breakages at the penultimate hop.
hashkey ipv4 bitmap <i>bit-size</i>	(Optional) Allows user control of the hash key/multipath settings. Range is 0 to 256. The default is 32.
interval <i>min-send-delay</i>	(Optional) Specifies a send interval, in milliseconds, between requests. Range is 0 to 3600000. Default is 0.
output interface	(Optional) Specifies the output interface where echo request packets are sent.

<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface. Note Use the show interfaces command to see a list of all interfaces currently configured on the router. For more information, use the question mark (?) online help function.
nexthop	(Optional) Specifies the IP address for the next hop.
<i>nexthop-address</i>	(Optional) IP address for the next hop.
reply dscp <i>dscp-value</i>	(Optional) Specifies the differentiated service codepoint value for an MPLS echo reply.
reply mode [ipv4 router-alert]	(Optional) Specifies the reply mode for the echo request packet. ipv4 Reply with IPv4 UDP packet (this is the default) router-alert Reply with IPv4 UDP packet with router alert
retry-count <i>count</i>	(Optional) Specifies the number of retry attempts during multipath LSP traceroute. A retry is attempted if an outstanding echo request • times out waiting for the corresponding echo reply. • fails to find a valid destination address set to exercise a specific outgoing path. Range is 0 to 10. Default is 3.
revision <i>version</i>	(Optional) Specifies the Cisco extension TLV versioning field: • 1 draft-ietf-mpls-lsp-ping-03 (initial) • 2 draft-ietf-mpls-lsp-ping-03 (rev 1) • 3 draft-ietf-mpls-lsp-ping-03 (rev 2) • 4 draft-ietf-mpls-lsp-ping-09 (initial)
source <i>source-address</i>	(Optional) Specifies the source address used in the echo request packet.
timeout <i>timeout</i>	(Optional) Specifies the timeout interval, in seconds. Range is from 0 to 3600. Default is 2.
ttl <i>value</i>	(Optional) Specifies the maximum number of hops (range is 1 to 255).
verbose	(Optional) Enables verbose output information, including MPLS echo reply, sender address of the packet, and return codes.

Command Default

exp *exp-bits* : 0
hashkey ipv4 bitmap *bit-size*: 4
interval *min-send-delay*: 0
reply mode: IPv4
retry-count: 3
timeout *timeout* : 2

Command Modes

EXEC

Command History

Release	Modification
Release 3.3.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **hashkey ipv4 bitmap** keyword and *bit-size* value control how many addresses are encoded in the DSMAP multipath field. Larger values allow more coverage of equal cost multiple paths throughout the network, but with more processing at the head, mid, and tail routers.

Task ID

Task ID	Operations
mpls-te	read, write
mpls-ldp	read, write

Examples

The following example shows how to specify the destination type as an LDP IPv4 prefix:

```
RP/0/0/CPU0:router# traceroute mpls multi ipv4 140.140.140.140/32 verbose
force-explicit-null
```

```
Starting LSP Path Discovery for 140.140.140.140/32
```

```
Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
'L' - labeled output interface, 'B' - unlabeled output interface,
'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
'P' - no rx intf label prot, 'p' - premature termination of LSP,
'R' - transit router, 'I' - unknown upstream index,
'X' - unknown return code, 'x' - return code 0
```

```
Type escape sequence to abort.
```

```
LL!
```

```

Path 0 found,
output interface POS0/2/0/3 source 196.100.1.61 destination 127.0.0.1
0 196.100.1.61 196.100.1.62 MRU 4470 [Labels: 18/explicit-null Exp: 0/0] multipaths 0
L 1 196.100.1.62 196.100.1.10 MRU 4470 [Labels: 17/explicit-null Exp: 0/0] ret code 8
multipaths 1
L 2 196.100.1.10 196.100.1.18 MRU 4470 [Labels: implicit-null/explicit-null Exp: 0/0] ret
code 8 multipaths 1
! 3 196.100.1.1018, ret code 3 multipaths 0
LL!
Path 1 found,
output interface GigabitEthernet0/3/0/0 source 196.100.1.5 destination 127.0.0.1
0 196.100.1.5 196.100.1.37 6 MRU 1500 [Labels: 18/explicit-null Exp: 0/0] multipaths 0
L 1 196.100.1.6 196.100.1.10 MRU 4470 [Labels: 17/explicit-null Exp: 0/0] ret code 8
multipaths 1
L 2 10196.0100.21.5 1010 196.0100.21.10 18 MRU 4470 [Labels: implicit-null/explicit-null
Exp: 0/0] ret code 8 multipaths 1
! 3 10196.0100.21.1018, ret code 3 multipaths 0

Paths (found/broken/unexplored) (2/0/0)
Echo Request (sent/fail) (6/0)
Echo Reply (received/timeout) (6/0)
Total Time Elapsed 80 ms

```

The following example shows how to specify the FEC type as LDP with verbose option:

```

RP/0/0/CPU0:router# traceroute mpls multipath ipv4 11.11.11.11/32 fec-type ldp output
interface gigabitEthernet 0/0/0/3
nextthop 172.40.103.2 verbose

```

Starting LSP Path Discovery for 11.11.11.11/32

```

Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
'L' - labeled output interface, 'B' - unlabeled output interface,
'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
'P' - no rx intf label prot, 'p' - premature termination of LSP,
'R' - transit router, 'I' - unknown upstream index,
'X' - unknown return code, 'x' - return code 0

```

Type escape sequence to abort.

```

LL!
Path 0 found,
output interface GigabitEthernet0/0/0/3 nexthop 172.40.103.2
source 172.40.103.1 destination 127.0.0.0
0 172.40.103.1 172.40.103.2 MRU 1500 [Labels: 16038 Exp: 0] multipaths 0
L 1 172.40.103.2 173.101.103.1 MRU 1500 [Labels: 16037 Exp: 0] ret code 8 multipaths 1
L 2 173.101.103.1 11.101.11.11 MRU 1500 [Labels: implicit-null Exp: 0] ret code 8 multipaths
1
! 3 11.101.11.11, ret code 3 multipaths 0

Paths (found/broken/unexplored) (1/0/0)
Echo Request (sent/fail) (3/0)
Echo Reply (received/timeout) (3/0)
Total Time Elapsed 21 ms

```


traceroute mpls traffic-eng

To specify the destination type as an MPLS traffic engineering (TE) tunnel, use the **traceroute mpls traffic-eng** command in EXEC mode.

traceroute mpls traffic-eng tunnel *tunnel-ID* [**destination** *start-address end-address address-increment increment-mask*] [**exp** *exp-bits*] [**flags fec**] [**force-explicit-null**] [**reply** {**dscp** *dscp-value* | **reply mode** {**ipv4** | **router-alert**} }] [**revision** *version*] [**source** *source-address*] [**timeout** *timeout*] [**ttl** *value*] [**verbose**]

Syntax Description

tunnel	Specifies the MPLS-TE tunnel type.
<i>tunnel-ID</i>	Tunnel interface.
destination <i>start-address end-address address-increment increment-mask</i>	(Optional) Specifies a network 127 address to be used as the destination address in the echo request packet. <i>start-address</i> Start of the network address. <i>end-address</i> End of the network address. <i>address-increment</i> Incremental value of the network address. <i>increment-mask</i> Incremental mask of the network address.
exp <i>exp-bits</i>	(Optional) Specifies the MPLS experimental field value in the MPLS header for echo replies. Range is 0 to 7. Default is 0.
flags fec	(Optional) Specifies that forwarding equivalent class (FEC) stack checking is to be performed at transit routers.
force-explicit-null	(Optional) Forces an unsolicited explicit null label to be added to the MPLS label stack and allows LSP ping to be used to detect LSP breakages at the penultimate hop.
reply dscp <i>dscp-value</i>	(Optional) Specifies the differentiated service codepoint value for an MPLS echo reply.

reply mode [ipv4 router-alert]	(Optional) Specifies the reply mode for the echo request packet. ipv4 Reply with IPv4 UDP packet (this is the default) router-alert Reply with IPv4 UDP packet with router alert
revision <i>version</i>	(Optional) Specifies the Cisco extension TLV versioning field: • 1 draft-ietf-mpls-lsp-ping-03 (initial) • 2 draft-ietf-mpls-lsp-ping-03 (rev 1) • 3 draft-ietf-mpls-lsp-ping-03 (rev 2) • 4 draft-ietf-mpls-lsp-ping-09 (initial)
source <i>source-address</i>	(Optional) Specifies the source address used in the echo request packet.
timeout <i>timeout</i>	(Optional) Specifies the timeout interval, in seconds. Range is from 0 to 3600. Default is 2.
ttl <i>value</i>	(Optional) Specifies the maximum number of hops (range is 1 to 255).
verbose	(Optional) Enables verbose output information, including MPLS echo reply, sender address of the packet, and return codes.

Command Default

exp *exp-bits* : 0
reply mode: IPv4
timeout *timeout* : 2

Command Modes

EXEC

Command History

Release	Modification
Release 3.9.0	This command was introduced.
Release 4.0.0	This command was replaced by the traceroute mpls traffic-eng tunnel-te (P2P) command.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operation
mpls-te	read
mpls-ldp	read

Examples

The following example shows how to specify the destination as a MPLS-TE tunnel:

```
RP/0/0/CPU0:router#  traceroute mpls traffic-eng tunnel 13

Tracing MPLS TE Label Switched Path on tunnel-te13, timeout is 2 seconds

Codes: '.' - success, 'Q' - request not sent, '.' - timeout,
       'L' - labeled output interface, 'B' - unlabeled output interface,
       'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
       'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
       'P' - no rx intf label prot, 'p' - premature termination of LSP,
       'R' - transit router, 'I' - unknown upstream index,
       'X' - unknown return code, 'x' - return code 0

Type escape sequence to abort.

0 0.0.0.0 11.0.0.1 MRU 1500 [Labels: 16003 Exp: 0]
L 1 192.168.200.2 192.168.170.1 MRU 1500 [Labels: implicit-null Exp: 0] 110 ms
! 2 192.168.170.1 0.0.0.0 MRU 0 [No Label] 169 ms
```

Related Commands

Command	Description
ping mpls traffic-eng tunnel-te (P2P)	Displays information about MPLS-TE tunnel for a point-to-point connection.

traceroute mpls mldp (P2MP)

To verify hop-by-hop fault localization and path tracing for the point-to-multipoint path, use the **traceroute mpls mldp p2mp** command in EXEC mode.

traceroute mpls mldp p2mp *root-address* {**IPv4** *source-ipv4-address group-ipv4-address*| **IPv6** *source-ipv6-address group-ipv6-address*| **vpn4** *AS-number* [*source-ipv4-address group-ipv4-address*]| **vpn6** *AS-number* [*source-ipv6-address group-ipv6-address*]| **mdt** *oui:vpn-index mdt-number*| **global-id** *lsp-id*} [**options**]

Syntax Description

mldp	Verifies the ping capability for multicast label distribution protocol (mldp).
p2mp	Indicates the Point-to-Multipoint (P2MP) label switch path.
<i>root-address</i>	Specifies the root address.
IPv4 <i>ipv4-address</i>	Defines IPv4 opaque encoding.
IPv6 <i>ipv6-address</i>	Defines IPv6 opaque encoding.
vpn4 <i>AS-number</i> [<i>source-ipv4-address group-ipv4-address</i>]	Defines VPNv4 opaque encoding.
vpn6 <i>AS-number</i> [<i>source-ipv6-address group-ipv6-address</i>]	Defines VPNv6 opaque encoding.
mdt <i>oui:vpn-index mdt number</i>	Defines VPN ID opaque encoding. Range of 3-byte OUI is 0 to 16777215. Range of <i>mdt-number</i> is 0 to 4294967295.
global-id <i>lsp-id</i>	Defines 4 byte global LSP ID opaque encoding.
<i>source-address</i>	Specifies the source address of target multicast address.
<i>group-address</i>	Specifies the target address of target multicast address.
<i>AS-number</i>	Specifies the Autonomous system number as follows: • 4-byte AS-number with asdot (X.Y) : aa.bb.cc format (for example, 11.22:33) • 2-byte AS-number or 4-byte AS-number: aa.bb format (for example, 11:22) • IPv4 address and index:aa.bb.cc.dd:ee format (for example, 11.22.33.44:55)

options

Specifies a set of various options:

destination

(Optional) Specifies a network 127/8 address to be used as the destination address in the echo request packet.

start-address: Start of the network address.

end-address: End of the network address.

address increment: Incremental value of the network address, which is expressed as a decimal number value or IP address.

expexp-bits

(Optional) Specifies the MPLS experimental field value in the MPLS header for echo replies. Range is 0 to 7. Default is 0.

flags

fec: (Optional) Specifies that forwarding equivalent class (FEC) stack checking is to be performed at transit routers.

no-ttl: (Optional) Specifies not to add TTL expired flag in echo request.

force-explicit-null

(Optional) Forces an unsolicited explicit null label to be added to the MPLS label stack and allows LSP ping to be used to detect LSP breakages at the penultimate hop.

jitter

(Optional) Specifies a jitter value for a corresponding echo request, in milliseconds. Range is 0 to 2147483647. Default is 200.

reply dscp dscp-value

(Optional) Specifies the differentiated service codepoint value for an MPLS echo reply.

mode [ipv4 | router-alert]

(Optional) Specifies the reply mode for the echo request packet.

ipv4

Reply with an IPv4 UDP packet (this is the default)

router-alert

Reply with an IPv4 UDP packet with the IP router alert set

responder-id *ipv4-address*

(Optional) Adds responder identifier into corresponding echo request.

source *ipv4-address*

(Optional) Specifies the source address used in the echo request packet.

timeout *timeout*

(Optional) Specifies the timeout interval, in seconds. Range is 0 to 3600. Default is 2.

ttl

(Optional) Specifies the TTL value to be used in the MPLS labels (range is 1 to 255). Default is 255.

verbose

(Optional) Enables verbose output information, including MPLS echo reply, sender address of the packet, and return codes.

Command Default	No default behavior or values

Command Modes	EXEC

Command History	Release	Modification
	Release 4.1.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operation
basic-services	execute
mpls-te or mpls-ldp	read

Examples

The following examples show how to verify path tracing for P2MP by using the **traceroute mpls mldp p2mp** command.

```
RP/0/0/CPU0:router#traceroute mpls mldp p2mp 192.168.0.1 ipv4 2.2.2.2 232.1.1.1 ttl 4
Mon Jul 11 15:36:42.299 JST
```

```
Tracing MPLS Label Switched Path to mldp p2mp 192.168.0.1 ipv4 (2.2.2.2, 232.1.1.1),
  timeout is 2.2 seconds, jitter value is 200 msec
```

```
Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
'L' - labeled output interface, 'B' - unlabeled output interface,
'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
'P' - no rx intf label prot, 'p' - premature termination of LSP,
'R' - transit router, 'I' - unknown upstream index,
'X' - unknown return code, 'x' - return code 0, 'd' - DDMAP
```

Type escape sequence to abort.

```
d 1 10.10.10.2 54 ms [Estimated Role: Branch]
  [L] DDMAP 0: 11.11.11.3 11.11.11.3 MRU 1500 [Labels: 16016 Exp: 0]
  [L] DDMAP 1: 12.12.12.4 12.12.12.4 MRU 1500 [Labels: 16016 Exp: 0]

! 2 11.11.11.3 47 ms [Estimated Role: Egress]
! 2 12.12.12.4 68 ms [Estimated Role: Egress]
. 3 *
. 4 *
```

```
RP/0/0/CPU0:router#traceroute mpls mldp p2mp 192.168.0.1 ipv4 2.2.2.2 232.1.1.1 ttl 4 jitter
300
Mon Jul 11 15:37:18.976 JST
```

```
Tracing MPLS Label Switched Path to mldp p2mp 192.168.0.1 ipv4 (2.2.2.2, 232.1.1.1),
  timeout is 2.3 seconds, jitter value is 300 msec
```

```
Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
'L' - labeled output interface, 'B' - unlabeled output interface,
'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
'P' - no rx intf label prot, 'p' - premature termination of LSP,
'R' - transit router, 'I' - unknown upstream index,
'X' - unknown return code, 'x' - return code 0, 'd' - DDMAP
```

Type escape sequence to abort.

```
d 1 10.10.10.2 77 ms [Estimated Role: Branch]
  [L] DDMAP 0: 11.11.11.3 11.11.11.3 MRU 1500 [Labels: 16016 Exp: 0]
  [L] DDMAP 1: 12.12.12.4 12.12.12.4 MRU 1500 [Labels: 16016 Exp: 0]

! 2 12.12.12.4 15 ms [Estimated Role: Egress]
```



```
! 2 11.11.11.3 114 ms [Estimated Role: Egress]
. 3 *
. 4 *
```

Related Commands

Command	Description
ping mpls mldp (P2MP), on page 579	Verifies data plane and control plane for the point-to-multipoint (P2MP) label switch path.
traceroute mpls mldp (MP2MP), on page 614	Verifies hop-by-hop fault localization and path tracing for the multipoint-to-multipoint path.

traceroute mpls mldp (MP2MP)

To verify hop-by-hop fault localization and path tracing for the multipoint-to-multipoint path (MP2MP), use the **traceroute mpls mldp mp2mp** command in EXEC mode.

traceroute mpls mldp mp2mp *root-address* {**IPv4** *source-ipv4-address group-ipv4-address*| **IPv6** *source-ipv6-address group-ipv6-address*| **vpn4** *AS-number* [*source-ipv4-address group-ipv4-address*]| **vpn6** *AS-number* [*source-ipv6-address group-ipv6-address*]| **mdt** *oui:vpn-index mdt-number*| **global-id** *lsp-id*} [**options**]

Syntax Description

mldp	Verifies the ping capability for multicast label distribution protocol (mldp).
mp2mp	Indicates the Multipoint-to-Multipoint (MP2MP) label switch path.
<i>root-address</i>	Specifies the root address.
IPv4 <i>ipv4-address</i>	Defines IPv4 opaque encoding.
IPv6 <i>ipv6-address</i>	Defines IPv6 opaque encoding.
vpn4 <i>AS-number</i> [<i>source-ipv4-address group-ipv4-address</i>]	Defines VPNv4 opaque encoding.
vpn6 <i>AS-number</i> [<i>source-ipv6-address group-ipv6-address</i>]	Defines VPNv6 opaque encoding.
mdt <i>oui:vpn-index mdt number</i>	Defines VPN ID opaque encoding. Range of 3-byte OUI is 0 to 16777215. Range of <i>mdt-number</i> is 0 to 4294967295.
global-id / <i>lsp-id</i>	Defines 4 byte global LSP ID opaque encoding.
<i>source-address</i>	Specifies the source address of target multicast address.
<i>group-address</i>	Specifies the target address of target multicast address.
<i>AS-number</i>	Specifies the Autonomous system number as follows: • 4-byte AS-number with asdot (X.Y) : aa.bb.cc format (for example, 11.22:33) • 2-byte AS-number or 4-byte AS-number: aa.bb format (for example, 11:22) • IPv4 address and index:aa.bb.cc.dd:ee format (for example, 11.22.33.44:55)

options

Specifies a set of various options:

destination

(Optional) Specifies a network 127/8 address to be used as the destination address in the echo request packet.

start-address: Start of the network address.

end-address: End of the network address.

address increment: Incremental value of the network address, which is expressed as a decimal number value or IP address.

expexp-bits

(Optional) Specifies the MPLS experimental field value in the MPLS header for echo replies. Range is 0 to 7. Default is 0.

flags

fec: (Optional) Specifies that forwarding equivalent class (FEC) stack checking is to be performed at transit routers.

no-ttl: (Optional) Specifies not to add TTL expired flag in echo request.

force-explicit-null

(Optional) Forces an unsolicited explicit null label to be added to the MPLS label stack and allows LSP ping to be used to detect LSP breakages at the penultimate hop.

jitter

(Optional) Specifies a jitter value for a corresponding echo request, in milliseconds. Range is 0 to 2147483647. Default is 200.

reply dscp-value

(Optional) Specifies the differentiated service codepoint value for an MPLS echo reply.

mode [ipv4 | router-alert]

(Optional) Specifies the reply mode for the echo request packet.

ipv4

Reply with an IPv4 UDP packet (this is the default)

router-alert

Reply with an IPv4 UDP packet with the IP router alert set

responder-id *ipv4-address*

(Optional) Adds responder identifier into corresponding echo request.

source *ipv4-address*

(Optional) Specifies the source address used in the echo request packet.

timeout *timeout*

(Optional) Specifies the timeout interval, in seconds. Range is 0 to 3600. Default is 2.

ttl

(Optional) Specifies the TTL value to be used in the MPLS labels (range is 1 to 255). Default is 255.

verbose

(Optional) Enables verbose output information, including MPLS echo reply, sender address of the packet, and return codes.

Command Default	ttl255 jitter200

Command Modes	EXEC

Command History	Release	Modification
	Release 4.1.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operation
basic-services	execute
mpls-te or mpls-ldp	read

Examples

The following examples show how to verify path tracing for MP2MP by using the **traceroute mpls mldp mp2mp** command.

```
RP/0/0/CPU0:router#traceroute mpls mldp mp2mp 192.168.0.1 global-id 1 ttl 4
```

```
Tracing MPLS Label Switched Path to mldp mp2mp 192.168.0.1 global-id 1,
    timeout is 2.2 seconds, jitter value is 200 msec
```

```
Codes: '.' - success, 'Q' - request not sent, '.' - timeout,
        'L' - labeled output interface, 'B' - unlabeled output interface,
        'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
        'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
        'P' - no rx intf label prot, 'p' - premature termination of LSP,
        'R' - transit router, 'I' - unknown upstream index,
        'X' - unknown return code, 'x' - return code 0, 'd' - DDMAP
```

Type escape sequence to abort.

```
! 1 10.10.10.2 41 ms [Estimated Role: Bud]
    [L] DDMAP 0: 11.11.11.3 11.11.11.3 MRU 1500 [Labels: 16020 Exp: 0]
    [L] DDMAP 1: 12.12.12.4 12.12.12.4 MRU 1500 [Labels: 16020 Exp: 0]

! 2 11.11.11.3 16 ms [Estimated Role: Egress]
! 2 12.12.12.4 17 ms [Estimated Role: Egress]
. 3 *
. 4 *
```

Related Commands

Command	Description
ping mpls mldp (MP2MP), on page 586	Verifies data plane and control plane for the multipoint-to-multipoint (MP2MP) label switch path.
traceroute mpls mldp (P2MP), on page 608	Verifies hop-by-hop fault localization and path tracing for the point-to-multipoint path.



INDEX

A

adjustment-threshold (MPLS-TE) command [150](#)
 admin-weight command [152](#)
 affinity command [154](#)
 affinity-map command [158](#)
 application (MPLS-TE) command [160](#)
 attribute-flags command [162](#)
 attribute-names command [164](#)
 authentication (RSVP) command [456](#)
 auto-bw (MPLS-TE) command [166](#)
 auto-bw collect frequency (MPLS-TE) command [168](#)
 auto-tunnel backup (MPLS-TE) [174](#)
 autoroute announce command [170](#)
 autoroute metric command [172](#)

B

backoff command [3](#)
 backup-bw command [176](#)
 backup-path tunnel-te command [179](#)
 bandwidth (RSVP) command [458](#)
 bandwidth mam (RSVP) command [460](#)
 bandwidth rdm (RSVP) command [462](#)
 bw-limit (MPLS-TE) command [181](#)

C

clear command [189](#)
 clear mpls ldp forwarding command [8](#)
 clear mpls ldp msg-counters neighbor command [5](#)
 clear mpls ldp neighbor command [7](#)
 clear mpls lmp command [183](#)
 clear mpls oam counters command [560](#)
 clear mpls traffic-eng auto-bw (MPLS-TE EXEC) command [184](#)
 clear mpls traffic-eng auto-tunnel backup unused [186](#)
 clear mpls traffic-eng counters auto-tunnel backup command [190](#)
 clear mpls traffic-eng counters global command [191](#)
 clear mpls traffic-eng counters signaling command [192](#)
 clear mpls traffic-eng fast-reroute log command [196](#)

clear mpls traffic-eng link-management statistics command [197](#)
 clear mpls traffic-eng pce command [198](#)
 clear rsvp authentication command [464](#)
 clear rsvp counters all command [468](#)
 clear rsvp counters authentication command [466](#)
 clear rsvp counters chkpt command [470](#)
 clear rsvp counters events command [472](#)
 clear rsvp counters messages command [474](#)
 clear rsvp counters oor command [476](#)
 clear rsvp counters prefix-filtering command [478](#)
 clear unused command [188](#)
 collect-bw-only (MPLS-TE) command [199](#)

D

default-route command [10](#)
 destination (MPLS-TE) command [201](#)
 direction (GMPLS) command [203](#)
 disable (explicit-path) command [205](#)
 discovery hello command [12](#)
 discovery instance-tlv disable command [14](#)
 discovery targeted-hello command [15](#)
 discovery transport-address command [17](#)
 downstream-on-demand command [19](#)
 ds-te bc-model command [207](#)
 ds-te mode command [209](#)
 ds-te te-classes command [211](#)

E

echo disable-vendor-extension command [562](#)
 echo revision command [563](#)
 exclude srlg (autotunnel backup) [214](#)
 explicit-null command [21](#)
 explicit-path command [216](#)

F

fast-reroute command [218](#)
 fast-reroute protect command [220](#)
 fast-reroute timers promotion command [222](#)
 flooding thresholds command [226](#)
 flooding-igp (GMPLS) command [224](#)
 forwarding-adjacency command [228](#)

G

graceful-restart (MPLS LDP) command [23](#)

H

holdtime (MPLS LDP) command [26](#)

I

igp auto-config disable command [28](#)
 igp sync delay command [30](#)
 igp sync delay on-proc-restart command [32](#)
 index exclude-address command [230](#)
 index exclude-srlg [232](#)
 index next-address command [234](#)
 interface (MPLS LDP) command [34](#)
 interface (MPLS-TE) command [236](#)
 interface (SRLG) command [238](#)
 interface tunnel-gte command [240](#)
 interface tunnel-te command [242](#)
 ipcc interface (MPLS-TE) command [244](#)
 ipcc routed (MPLS-TE) command [246](#)
 ipv4 unnumbered (MPLS) command [248](#)

K

key-source key-chain (RSVP) command [480](#)

L

label accept command [36](#)
 label advertise command [38](#)
 label allocate command [41](#)
 life-time (RSVP) command [482](#)
 link-management timers bandwidth-hold command [250](#)
 link-management timers periodic-flooding command [252](#)
 link-management timers preemption-delay command [254](#)
 lmp hello (GMPLS) command [255](#)

lmp neighbor (MPLS-TE) command [257](#)
 lmp router-id (MPLS-TE) command [259](#)
 log graceful-restart command [43](#)
 log neighbor command [45](#)
 log nsr command [47](#)
 log session-protection command [48](#)

M

match (GMPLS) command [261](#)
 maxabs (MPLS-TE) command [263](#)
 maximum interfaces (MPLS LDP) command [50](#)
 mpls command [283](#)
 mpls ip-ttl-propagate command [110](#)
 mpls label range command [112](#)
 mpls ldp command [52](#)
 mpls mtu command [114](#)
 mpls oam command [565](#)
 mpls traffic-eng auto-bw apply (MPLS-TE) command [266](#)
 mpls traffic-eng command [265](#)
 mpls traffic-eng fast-reroute promote command [268](#)
 mpls traffic-eng level command [269](#)
 mpls traffic-eng link-management flood command [271](#)
 mpls traffic-eng path-protection switchover gmpls command [273](#)
 mpls traffic-eng pce activate-pcep command [275](#)
 mpls traffic-eng reoptimize (EXEC) command [279](#)
 mpls traffic-eng router-id (MPLS-TE router) command [281](#)

N

neighbor password command [53](#)
 neighbor password disable command [55](#)
 neighbor targeted command [56](#)
 nhop-only (auto-tunnel backup) [284](#)
 nsr (MPLS-LDP) command [58](#)

O

overflow threshold (MPLS-TE) command [286](#)

P

passive (GMPLS) command [288](#)
 path-option (MPLS-TE) command [290](#)
 path-selection ignore overload (MPLS-TE) command [293](#)
 path-selection loose-expansion affinity (MPLS-TE) command [295](#)
 path-selection loose-expansion metric (MPLS-TE) command [297](#)
 path-selection metric (interface) command [301](#)
 path-selection metric (MPLS-TE) command [299](#)

pce address (MPLS-TE) command [303](#)
 pce deadtimer (MPLS-TE) command [305](#)
 pce keepalive (MPLS-TE) command [307](#)
 pce peer (MPLS-TE) command [309](#)
 pce reoptimize (MPLS-TE) command [311](#)
 pce request-timeout (MPLS-TE) command [313](#)
 pce tolerance keepalive (MPLS-TE) command [315](#)
 ping mpls ipv4 command [566](#)
 ping mpls mldp (MP2MP) command [586](#)
 ping mpls mldp command [579](#)
 ping mpls traffic-eng command [571](#)
 ping pseudowire (AToM) command [575](#)
 policy-class command [317](#)
 priority (MPLS-TE) command [319](#)

R

record-route command [321](#)
 remote (GMPLS) command [323](#)
 reoptimize (MPLS-TE) command [325](#)
 reoptimize timers delay (MPLS-TE) command [327](#)
 router-id (MPLS LDP) command [60](#)
 router-id secondary (MPLS-TE) command [330](#)
 RSVP [453](#)
 rsvp command [484](#)
 rsvp interface command [485](#)
 rsvp neighbor command [487](#)

S

session protection command [62](#)
 show explicit-paths command [332](#)
 show mpls forwarding command [116](#)
 show mpls forwarding exact-route command [121](#)
 show mpls interfaces command [125](#)
 show mpls label range command [128](#)
 show mpls label table command [130](#)
 show mpls ldp backoff command [64](#)
 show mpls ldp bindings command [66](#)
 show mpls ldp discovery command [72](#)
 show mpls ldp forwarding command [77](#)
 show mpls ldp graceful-restart command [82](#)
 show mpls ldp igp sync command [84](#)
 show mpls ldp interface command [87](#)
 show mpls ldp neighbor command [90](#)
 show mpls ldp parameters command [96](#)
 show mpls ldp statistics msg-counters command [99](#)
 show mpls ldp summary command [101](#)
 show mpls lsd applications command [133](#)
 show mpls lsd clients command [135](#)
 show mpls oam command [593](#)

show mpls oam database command [595](#)
 show mpls traffic-eng affinity-map command [334](#)
 show mpls traffic-eng auto-tunnel backup [338](#)
 show mpls traffic-eng auto-tunnel mesh command [341](#)
 show mpls traffic-eng autoroute command [336](#)
 show mpls traffic-eng collaborator-timers command [343](#)
 show mpls traffic-eng counters signaling command [345](#)
 show mpls traffic-eng ds-te te-class command [350](#)
 show mpls traffic-eng fast-reroute database command [137](#)
 show mpls traffic-eng fast-reroute log command [142](#)
 show mpls traffic-eng forwarding command [352](#)
 show mpls traffic-eng forwarding-adjacency command [355](#)
 show mpls traffic-eng igp-areas command [356](#)
 show mpls traffic-eng link-management admission-control command [358](#)
 show mpls traffic-eng link-management advertisements command [362](#)
 show mpls traffic-eng link-management bandwidth-allocation command [365](#)
 show mpls traffic-eng link-management bfd-neighbors command [368](#)
 show mpls traffic-eng link-management interfaces command [372](#)
 show mpls traffic-eng link-management statistics command [375](#)
 show mpls traffic-eng link-management summary command [377](#)
 show mpls traffic-eng lmp command [379](#)
 show mpls traffic-eng maximum tunnels command [383](#)
 show mpls traffic-eng pce peer command [386](#)
 show mpls traffic-eng pce tunnels command [388](#)
 show mpls traffic-eng preemption log command [390](#)
 show mpls traffic-eng topology command [391](#)
 show mpls traffic-eng tunnels auto-bw brief command [427](#)
 show mpls traffic-eng tunnels command [401](#)
 show rsvp authentication command [489](#)
 show rsvp counters command [495](#)
 show rsvp counters oor command [499](#)
 show rsvp counters prefix-filtering command [501](#)
 show rsvp fast-reroute command [504](#)
 show rsvp graceful-restart command [507](#)
 show rsvp hello instance command [511](#)
 show rsvp hello instance interface-based command [514](#)
 show rsvp interface command [516](#)
 show rsvp request command [519](#)
 show rsvp reservation command [521](#)
 show rsvp sender command [524](#)
 show rsvp session command [527](#)
 show srlg command [429](#)
 signalled-name command [432](#)
 signalling advertise explicit-null (MPLS-TE) command [433](#)
 signalling dscp (LDP) command [104](#)
 signalling dscp (RSVP) command [530](#)
 signalling graceful-restart command [532](#)
 signalling hello graceful-restart refresh interval command [534](#)
 signalling hello graceful-restart refresh misses command [536](#)
 signalling prefix-filtering access-list command [538](#)

signalling prefix-filtering default-deny-action command [540](#)
signalling rate-limit command [542](#)
signalling refresh interval command [544](#)
signalling refresh missed command [546](#)
signalling refresh reduction bundle-max-size command [548](#)
signalling refresh reduction disable command [550](#)
signalling refresh reduction reliable command [552](#)
signalling refresh reduction summary command [555](#)
snmp traps mpls traffic-eng command [435](#)
snmp-server traps mpls ldp command [106](#)
srlg command [437](#)
switching (GMPLS) command [439](#)
switching endpoint (GMPLS) command [441](#)
switching transit (GMPLS) command [443](#)

T

timers loose-path (MPLS-TE) command [445](#)
timers removal unused (autotunnel backup) command [447](#)
topology holddown sigerr (MPLS-TE) command [449](#)
traceroute mpls ipv4 command [597](#)
traceroute mpls mldp (MP2MP) command [614](#)
traceroute mpls mldp (P2MP) command [608](#)
traceroute mpls multipath command [601](#)
traceroute mpls traffic-eng command [605](#)

W

window-size (RSVP) command [557](#)