



Cisco IOS XR Virtual Private Network Command Reference for the Cisco XR 12000 Series Router, Release 4.2.x

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

Text Part Number: OL-26118-02

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <http://www.cisco.com/go/trademarks>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

Any Internet Protocol (IP) addresses used in this document are not intended to be actual addresses. Any examples, command display output, and figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses in illustrative content is unintentional and coincidental.

© 2013 Cisco Systems, Inc. All rights reserved.



CONTENTS

Preface

Preface vii

Changes to This Document vii

Obtaining Documentation and Submitting a Service Request vii

CHAPTER 1

Virtual Private Network Commands 1

authentication (L2TP) 4

backup (L2VPN) 6

backup disable (L2VPN) 8

clear l2tp counters control session 10

clear l2tp counters control tunnel 12

clear l2tp tunnel 14

clear l2vpn collaborators 16

clear l2vpn counters l2tp 17

clear l2vpn counters bridge mac-withdrawal 19

clear l2vpn forwarding counters 20

clear l2vpn forwarding mac-address-table 21

clear l2vpn forwarding message counters 23

clear l2vpn forwarding table 24

description (GLOBAL) 25

description (XCONNECT) 26

digest (L2TP) 27

hello-interval (L2TP) 29

hidden (L2TP) 31

hostname (L2TP) 33

interface (p2p) 35

interworking ipv4 37

interworking ethernet 38

l2tp-class	40
l2tp-class configuration	41
l2transport	43
l2transport cell-packing	45
l2transport l2protocol	47
l2transport propagate	49
l2transport service-policy	51
l2vpn	53
l2vpn switchover	55
logging (l2vpn)	57
mpls static label (L2VPN)	59
neighbor (L2VPN)	61
password (L2TP)	63
pw-class (L2VPN)	65
pw-class encapsulation l2tpv3	67
pw-class encapsulation mpls	69
pw-ether	71
p2p	73
receive-window (L2TP)	75
retransmit (L2TP)	77
rollover (L3VPN)	79
sequencing (L2VPN)	81
show l2tp class	83
show l2tp counters forwarding session	85
show l2tp session	87
show l2tp tunnel	89
show l2vpn atom-db	91
show l2vpn collaborators	94
show l2vpn forwarding	96
show l2vpn forwarding l2tp	101
show l2vpn generic-interface-list	103
show l2vpn index	105
show l2vpn pw-class	107
show l2vpn pwhe	109
show l2vpn resource	111

[show l2vpn xconnect](#) 112
[show tunnel-template](#) 121
[switching-tlv \(L2VPN\)](#) 123
[tag-impose](#) 125
[tag-rewrite](#) 127
[timeout setup \(L2TP\)](#) 129
[transport mode \(L2VPN\)](#) 131
[tunnel-template](#) 133
[xconnect group](#) 134

CHAPTER 2

Virtual Private LAN Services Commands 137

[action \(VPLS\)](#) 139
[aging \(VPLS\)](#) 141
[bridge-domain \(VPLS\)](#) 143
[bridge group \(VPLS\)](#) 145
[clear l2vpn bridge-domain \(VPLS\)](#) 147
[flooding disable](#) 149
[flooding unknown-unicast disable \(VPLS\)](#) 151
[interface \(VPLS\)](#) 153
[learning disable \(VPLS\)](#) 155
[limit \(VPLS\)](#) 157
[mac \(VPLS\)](#) 159
[maximum \(VPLS\)](#) 161
[mpls static label \(VPLS\)](#) 163
[mtu \(VPLS\)](#) 165
[neighbor \(VPLS\)](#) 167
[notification \(VPLS\)](#) 169
[port-down flush disable \(VPLS\)](#) 171
[pw-class \(VFI\)](#) 173
[pw-status \(L2VPN\)](#) 175
[show l2vpn bridge-domain \(VPLS\)](#) 177
[show l2vpn forwarding bridge-domain \(VPLS\)](#) 184
[show l2vpn forwarding bridge-domain mac-address \(VPLS\)](#) 189
[shutdown \(Bridge Domain\)](#) 193
[shutdown \(VFI\)](#) 195

static-address (VPLS)	197
static-mac-address (VPLS)	199
time (VPLS)	201
type (VPLS)	203
vfi (VPLS)	205
withdraw (VPLS)	207



Preface

The *Cisco IOS XR Virtual Private Network Command Reference for the Cisco XR 12000 Series Router* preface contains these sections:

- [Changes to This Document](#), page vii
- [Obtaining Documentation and Submitting a Service Request](#), page vii

Changes to This Document

This table lists the technical changes made to this document since it was first printed.

Revision	Date	Change Summary
OL-26118-02	June 2012	Republished with documentation updates for Cisco IOS XR Release 4.2.1
OL-26118-01	December 2011	Initial release of this document.

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS version 2.0.



Virtual Private Network Commands

For detailed information about virtual private network concepts, configuration tasks, and examples, refer to the *Cisco IOS XR Virtual Private Network Configuration Guide for the Cisco XR 12000 Series Router*

- [authentication \(L2TP\), page 4](#)
- [backup \(L2VPN\), page 6](#)
- [backup disable \(L2VPN\), page 8](#)
- [clear l2tp counters control session, page 10](#)
- [clear l2tp counters control tunnel, page 12](#)
- [clear l2tp tunnel, page 14](#)
- [clear l2vpn collaborators, page 16](#)
- [clear l2vpn counters l2tp, page 17](#)
- [clear l2vpn counters bridge mac-withdrawal, page 19](#)
- [clear l2vpn forwarding counters, page 20](#)
- [clear l2vpn forwarding mac-address-table, page 21](#)
- [clear l2vpn forwarding message counters, page 23](#)
- [clear l2vpn forwarding table, page 24](#)
- [description \(GLOBAL\), page 25](#)
- [description \(XCONNECT\), page 26](#)
- [digest \(L2TP\), page 27](#)
- [hello-interval \(L2TP\), page 29](#)
- [hidden \(L2TP\), page 31](#)
- [hostname \(L2TP\), page 33](#)
- [interface \(p2p\), page 35](#)
- [interworking ipv4, page 37](#)
- [interworking ethernet, page 38](#)

- [l2tp-class](#), page 40
- [l2tp-class configuration](#), page 41
- [l2transport](#), page 43
- [l2transport cell-packing](#), page 45
- [l2transport l2protocol](#), page 47
- [l2transport propagate](#), page 49
- [l2transport service-policy](#), page 51
- [l2vpn](#), page 53
- [l2vpn switchover](#), page 55
- [logging \(l2vpn\)](#), page 57
- [mpls static label \(L2VPN\)](#), page 59
- [neighbor \(L2VPN\)](#), page 61
- [password \(L2TP\)](#), page 63
- [pw-class \(L2VPN\)](#), page 65
- [pw-class encapsulation l2tpv3](#), page 67
- [pw-class encapsulation mpls](#), page 69
- [pw-ether](#), page 71
- [p2p](#), page 73
- [receive-window \(L2TP\)](#), page 75
- [retransmit \(L2TP\)](#), page 77
- [rollover \(L3VPN\)](#), page 79
- [sequencing \(L2VPN\)](#), page 81
- [show l2tp class](#), page 83
- [show l2tp counters forwarding session](#), page 85
- [show l2tp session](#), page 87
- [show l2tp tunnel](#), page 89
- [show l2vpn atom-db](#), page 91
- [show l2vpn collaborators](#), page 94
- [show l2vpn forwarding](#), page 96
- [show l2vpn forwarding l2tp](#), page 101
- [show l2vpn generic-interface-list](#), page 103
- [show l2vpn index](#), page 105
- [show l2vpn pw-class](#), page 107

- [show l2vpn pwhe](#), page 109
- [show l2vpn resource](#), page 111
- [show l2vpn xconnect](#), page 112
- [show tunnel-template](#), page 121
- [switching-tlv \(L2VPN\)](#), page 123
- [tag-impose](#), page 125
- [tag-rewrite](#), page 127
- [timeout setup \(L2TP\)](#), page 129
- [transport mode \(L2VPN\)](#), page 131
- [tunnel-template](#), page 133
- [xconnect group](#), page 134

authentication (L2TP)

To enable L2TP authentication for a specified L2TP class name, use the **authentication** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

authentication

no authentication

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes L2TP class configuration

Command History	Release	Modification
	Release 3.7.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note

You can also enable L2TP authentication for a specified class name from L2TP class configuration submode. To enter this submode, enter the **l2tp-class** command followed by the class name.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples The following example shows how to configure L2TP authentication for the specified L2TP class name "cisco":

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2tp-class cisco
RP/0/0/CPU0:router(config-l2tp-class)# authentication
```

Related Commands

Command	Description
hello-interval (L2TP), on page 29	Configures the hello-interval value for L2TP (duration between control channel hello packets).
hidden (L2TP), on page 31	Enables hidden attribute-value pairs (AVPs).
hostname (L2TP), on page 33	Defines the name used in the L2TP hostname AVP.
l2tp-class, on page 40	Enters L2TP class configuration mode where you can define an L2TP signaling template.
password (L2TP), on page 63	Defines the password and password encryption type for control channel authentication.
receive-window (L2TP), on page 75	Configures the receive window size for the L2TP server.
retransmit (L2TP), on page 77	Configures retransmit retry and timeout values.

backup (L2VPN)

To configure the backup pseudowire for the cross-connect, use the **backup** command in L2VPN xconnect p2p pseudowire configuration mode. To disable this feature, use the **no** form of this command.

backup neighbor *IP-address* **pw-id** *value*

no backup neighbor *IP-address* **pw-id** *value*

Syntax Description

neighbor <i>IP-address</i>	Specifies the peer to cross connect. The <i>IP-address</i> argument is the IPv4 address of the peer.
pw-id <i>value</i>	Configures the pseudowire ID. The range is from 1 to 4294967295.

Command Default

None

Command Modes

L2VPN xconnect p2p pseudowire configuration

Command History

Release	Modification
Release 3.8.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **backup** command to enter L2VPN xconnect p2p pseudowire backup configuration mode.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to configure backup pseudowires:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# xconnect group gr1
RP/0/0/CPU0:router(config-l2vpn-xc)# p2p p001
RP/0/0/CPU0:router(config-l2vpn-xc-p2p)# neighbor 10.1.1.1 pw-id 2
RP/0/0/CPU0:router(config-l2vpn-xc-p2p-pw)# backup neighbor 10.2.2.2 pw-id 5
RP/0/0/CPU0:router(config-l2vpn-xc-p2p-pw-backup)#
```

Related Commands

Command	Description
backup disable (L2VPN), on page 8	Specifies how long a backup pseudowire should wait before resuming operation after the primary pseudowire goes down.
l2vpn, on page 53	Enters L2VPN configuration mode.
neighbor (L2VPN), on page 61	Configures a pseudowire for a cross-connect.
p2p, on page 73	Enters p2p configuration submode to configure point-to-point cross-connects.
xconnect group, on page 134	Configures cross-connect groups.

backup disable (L2VPN)

To specify how long a backup pseudowire should wait before resuming operation after the primary pseudowire goes down, use the **backup disable** command in L2VPN pseudowire class configuration mode. To disable this feature, use the **no** form of this command.

backup disable {*delay value*| **never**}

no backup disable {*delay value*| **never**}

Syntax Description

delay <i>value</i>	Specifies the number of seconds that elapse after the primary pseudowire becomes nonfunctional before the Cisco IOS XR software attempts to activate the secondary pseudowire. The range, in seconds, is from 0 to 180. The default is 0.
never	Specifies that the secondary pseudowire does not fall back to the primary pseudowire if the primary pseudowire becomes available again, unless the secondary pseudowire fails.

Command Default

The default disable delay is the value of 0, which means that the primary pseudowire is activated immediately when it comes back up.

Command Modes

L2VPN pseudowire class configuration

Command History

Release	Modification
Release 3.8.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how a backup delay is configured for point-to-point pseudowire in which the backup disable delay is set to 50 seconds:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# pw-class class1
RP/0/0/CPU0:router(config-l2vpn-pwc)# backup disable delay 50
RP/0/0/CPU0:router(config-l2vpn-pwc)# exit
RP/0/0/CPU0:router(config-l2vpn)# xconnect group A
RP/0/0/CPU0:router(config-l2vpn-xc)# p2p rtrx
RP/0/0/CPU0:router(config-l2vpn-xc-p2p)# neighbor 10.1.1.1 pw-id 2
RP/0/0/CPU0:router(config-l2vpn-xc-p2p-pw)# pw-class class1
RP/0/0/CPU0:router(config-l2vpn-xc-p2p-pw)# backup neighbor 10.2.2.2 pw-id 5
RP/0/0/CPU0:router(config-l2vpn-xc-p2p-pw-backup)#
```

Related Commands

Command	Description
l2vpn , on page 53	Enters L2VPN configuration mode.
neighbor (L2VPN) , on page 61	Configures a pseudowire for a cross-connect.
p2p , on page 73	Enters p2p configuration submode to configure point-to-point cross-connects.
pw-class (L2VPN) , on page 65	Enters pseudowire class submode to define a pseudowire class template.
xconnect group , on page 134	Configures cross-connect groups.

clear l2tp counters control session

To clear L2TP control counters for a session, use the **clear l2tp counters control session** command in EXEC mode.

clear l2tp counters control session fsm [event| state transition]

Syntax Description

fsm	(Optional) Clears finite state machine counters.
event	(Optional) Clears state machine event counters.
state	(Optional) Clears state machine state counters.
transition	(Optional) Clears state machine transition counters.

Command Default

None

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to clear all L2TP state machine transition counters:

```
RP/0/0/CPU0:router(config-l2vpn-xc-p2p-pw-backup)## clear l2tp counters control session fsm
state transition
```

Related Commands

Command	Description
clear l2tp counters control tunnel, on page 12	Clears L2TP control counters for a tunnel.
clear l2vpn counters l2tp, on page 17	Clears L2VPN statistical information, such as, packets dropped.

clear l2tp counters control tunnel

To clear L2TP control counters for a tunnel, use the **clear l2tp counters control tunnel** command in EXEC mode.

clear l2tp counters control tunnel {all| authentication| id *tunnel id*}

Syntax Description

all	Clears all L2TP counters, except authentication counters
authentication	Clears tunnel authentication counters.
id <i>tunnel id</i>	Clears a specified counter. Range is 1 to 4294967295.

Command Default

None

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to clear all L2TP control tunnel counters:

```
RP/0/0/CPU0:router# clear l2tp counters control tunnel all
```

Related Commands

Command	Description
clear l2tp counters control session, on page 10	Clears L2TP control counters for a session.

Command	Description
clear l2vpn counters l2tp, on page 17	Clears L2VPN statistical information, such as, packets dropped.

clear l2tp tunnel

To clear L2TP tunnels, use the **clear l2tp tunnel** command in EXEC mode.

clear l2tp tunnel {**all**| **id** *tunnel id*| **l2tp-class** *class name*| **local ipv4** *ipv4 address*| **remote ipv4** *ipv4 address*}

Syntax Description

all	Clears all L2TP tunnels.
id <i>tunnel id</i>	Clears a specified tunnel.
l2tp-class <i>class name</i>	Clears all L2TP tunnels based on L2TP class name.
local ipv4 <i>ipv4 address</i>	Clears all local tunnels based on the specified local IPv4 address.
remote ipv4 <i>ipv4 address</i>	Clears all remote tunnels based on the specified local IPv4 address.

Command Default

None

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to clear all L2TP tunnels:

```
RP/0/0/CPU0:router# clear l2tp tunnel all
```

Related Commands

Command	Description
clear l2tp counters control session, on page 10	Clears L2TP control counters for a session.
clear l2tp counters control tunnel, on page 12	Clears L2TP control counters for a tunnel.

clear l2vpn collaborators

To clear the state change counters for L2VPN collaborators, use the **clear l2vpn collaborators** command in EXEC mode.

clear l2vpn collaborators

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 3.4.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples The following example shows how to clear change counters for L2VPN collaborators:

```
RP/0/0/CPU0:router# clear l2vpn collaborators
```

Related Commands	Command	Description
	show l2vpn collaborators , on page 94	Displays information about the state of the interprocess communications connections between l2vpn_mgr and other processes.

clear l2vpn counters l2tp

To clear L2VPN statistical information, such as, packets dropped, use the **clear l2vpn counters l2tp** command in EXEC mode.

clear l2vpn counters l2tp [**neighbor** *ip-address* [**pw-id** *value*]]

Syntax Description

l2tp	Clears all L2TP counters.
neighbor <i>ip-address</i>	(Optional) Clears all L2TP counters for the specified neighbor.
pw-id <i>value</i>	(Optional) Configures the pseudowire ID. The range is from 1 to 4294967295.

Command Default

None

Command Modes

EXEC

Command History

Release	Modification
Release 3.4.0	This command was introduced.
Release 3.7.0	The pw-id keyword was added.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to clear all L2TP counters:

```
RP/0/0/CPU0:router# clear l2vpn counters l2tp
```

Related Commands

Command	Description
show l2vpn collaborators, on page 94	Displays information about the state of the interprocess communications connections between l2vpn_mgr and other processes.

clear l2vpn counters bridge mac-withdrawal

To clear the MAC withdrawal statistics for the counters of the bridge domain, use the **clear l2vpn counters bridge mac-withdrawal** command in EXEC mode.

clear l2vpn counters bridge mac-withdrawal {**all**| **group** *group-name* **bd-name** *bd-name*| **neighbor** *ip-address* **pw-id** *value*}

Syntax Description

all	Clears the MAC withdrawal statistics over all the bridges.
group <i>group-name</i>	Clears the MAC withdrawal statistics over the specified group.
bd-name <i>bd-name</i>	Clears the MAC withdrawal statistics over the specified bridge.
neighbor <i>ip-address</i>	Clears the MAC withdrawal statistics over the specified neighbor.
pw-id <i>value</i>	Clears the MAC withdrawal statistics over the specified pseudowire. The range is from 1 to 4294967295.

Command Default

None

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to clear the MAC withdrawal statistics over all the bridges:

```
RP/0/0/CPU0:router# clear l2vpn counters bridge mac-withdrawal all
```

clear l2vpn forwarding counters

To clear L2VPN forwarding counters, use the **clear l2vpn forwarding counters** command in EXEC mode.

clear l2vpn forwarding counters

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 3.4.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples The following example shows how to clear L2VPN forwarding counters:

```
RP/0/0/CPU0:router# clear l2vpn forwarding counters
```

Related Commands	Command	Description
	show l2vpn forwarding , on page 96	Displays forwarding information from the layer2_fib manager on the line card.

clear l2vpn forwarding mac-address-table

To clear L2VPN forwarding MAC address tables, use the **clear l2vpn forwarding mac-address-table** command in EXEC mode.

clear l2vpn forwarding mac-address-table {*address address*| *bridge-domain name*| *interface type interface-path-id*| **location** *node-id*}

Syntax Description

<i>address</i>	Clears a specified MAC address.
bridge-domain <i>name</i>	Clears bridge domains learned from a MAC address table.
<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface. Note Use the show interfaces command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
location <i>node-id</i>	Clears L2VPN forwarding message counters for the specified location. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

Command Default

None

Command Modes

EXEC

Command History

Release	Modification
Release 3.5.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read, write, execute

Examples

The following example shows how to clear L2VPN forwarding MAC address tables on a specified node:

```
RP/0/0/CPU0:router# clear l2vpn forwarding mac-address location 1/1/1
```

Related Commands

Command	Description
show l2vpn forwarding , on page 96	Displays forwarding information from the layer2_fib manager on the line card.

clear l2vpn forwarding message counters

To clear L2VPN forwarding message counters, use the **clear l2vpn forwarding message counters** command in EXEC mode.

clear l2vpn forwarding message counters location *node-id*

Syntax Description	location <i>node-id</i>	Clears L2VPN forwarding message counters for the specified location.
---------------------------	--------------------------------	--

Command Default	None
------------------------	------

Command Modes	EXEC
----------------------	------

Command History	Release	Modification
	Release 3.5.0	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

Task ID	Task ID	Operations
	l2vpn	read, write

Examples	The following example shows how to clear L2VPN forwarding message counters on a specified node:
-----------------	---

```
RP/0/0/CPU0:router# clear l2vpn forwarding message counters location 0/6/CPU0
```

Related Commands	Command	Description
	show l2vpn forwarding , on page 96	Displays forwarding information from the layer2_fib manager on the line card.

clear l2vpn forwarding table

To clear an L2VPN forwarding table at a specified location, use the **clear l2vpn forwarding table** command in EXEC mode.

clear l2vpn forwarding table location *node-id*

Syntax Description	<div><div>location <i>node-id</i></div><div>Clears L2VPN forwarding tables for the specified location.</div></div>					
Command Default	None					
Command Modes	EXEC					
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>Release 3.4.0</td><td>This command was introduced.</td></tr></table>		Release	Modification	Release 3.4.0	This command was introduced.
Release	Modification					
Release 3.4.0	This command was introduced.					
Usage Guidelines	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p>					
Task ID	<table><tr><th>Task ID</th><th>Operations</th></tr><tr><td>l2vpn</td><td>read, write</td></tr></table>		Task ID	Operations	l2vpn	read, write
Task ID	Operations					
l2vpn	read, write					
Examples	<p>The following example shows how to clear an L2VPN forwarding table from a specified location:</p> <pre>RP/0/0/CPU0:router# clear l2vpn forwarding table location 1/2/3/5</pre>					
Related Commands	<table><tr><th>Command</th><th>Description</th></tr><tr><td>show l2vpn forwarding, on page 96</td><td>Displays forwarding information from the layer2_fib manager on the line card.</td></tr></table>		Command	Description	show l2vpn forwarding , on page 96	Displays forwarding information from the layer2_fib manager on the line card.
Command	Description					
show l2vpn forwarding , on page 96	Displays forwarding information from the layer2_fib manager on the line card.					

description (GLOBAL)

To specify the description of a multisegment pseudowire globally, use the **description** command in l2vpn configuration mode. To revert, use the **no** form of the command.

description *description-name*

no description

Syntax Description	<i>description-name</i>	Name of the description of the multisegment pseudowire.
Command Default	None	
Command Modes	l2vpn	
Command History	Release	Modification
	Release 4.1.1	This command was introduced.
Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.	
Task ID	Task ID	Operation
	l2vpn	read, write
Examples	The example shows how to specify the description of a multisegment pseudowire: RP/0/0/CPU0:router# configure RP/0/0/CPU0:router(config)# l2vpn RP/0/0/CPU0:router(config-l2vpn)# description S-PE1	
Related Commands	Command	Description
	description (XCONNECT), on page 26	Specifies the description of an l2vpn cross connect.

description (XCONNECT)

To specify the description of an l2vpn xconnect such as attachment circuit (AC) AC-AC, AC-PW, and multisegment pseudowire (MS-PW), use the **description** command in L2VPN xconnect mode. To revert, use the **no** form of the command.

description *description-name*

no description

Syntax Description

<i>description-name</i>	Name of the description of the cross connect.
-------------------------	---

Command Default

None

Command Modes

L2VPN xconnect

Command History

Release	Modification
Release 4.1.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operation
l2vpn	read, write

Examples

The example shows how to specify the description of a cross connect:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# xconnect group MS-PW1
RP/0/0/CPU0:router(config-l2vpn-xc)# p2p ms-pw1
RP/0/0/CPU0:router(config-l2vpn-xc-p2p)# description MS-PW from T-PE1 to T-PE2
```

Related Commands

Command	Description
description (GLOBAL) , on page 25	Specifies multisegment pseudowire global description.

digest (L2TP)

To configure digest options, use the **digest** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

digest {**check disable**| **hash** {**MD5**| **SHA1**}}| **secret** {**0**| **7**| *word*}}

no digest {**check disable**| **hash** {**MD5**| **SHA1**}}| **secret** {**0**| **7**| *word*}}

Syntax Description

check disable	Disables digest checking.
hash { MD5 SHA1 }	Configures the digest hash method (MD5 or SHA1). Default is MD5.
secret { 0 7 <i>word</i> }	Configures a shared secret for message digest.

Command Default

check disable: Digest checking is enabled by default.

hash: Default is MD5 if the **digest** command is issued without the secret keyword option and L2TPv3 integrity checking is enabled.

Command Modes

L2TP class configuration

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The digest secret and hash algorithm can be configured in the l2tp-class configuration for authentication of the control channel. For control channel authentication to work correctly, however, both sides of the L2TP control channel connection must share a common secret and hash algorithm.

To update of digest secret without network disruption, Cisco supports a maximum to two digest secrets. You can configure a new secret while keeping the old secret valid. You can safely remove the old secret after you update all affected peer nodes with a new secret,

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to configure digest options for L2TP:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2tp-class cisco
RP/0/0/CPU0:router(config-l2tp-class)# digest check disable
RP/0/0/CPU0:router(config-l2tp-class)# digest secret cisco hash md5
```

Related Commands

Command	Description
authentication (L2TP), on page 4	Enables L2TP authentication for a specified L2TP class name.
hello-interval (L2TP), on page 29	Configures the hello-interval value for L2TP (duration between control channel hello packets).
hidden (L2TP), on page 31	Enables hidden attribute-value pairs (AVPs).
hostname (L2TP), on page 33	Defines the name used in the L2TP hostname AVP.
l2tp-class, on page 40	Enters L2TP class configuration mode where you can define an L2TP signaling template.
password (L2TP), on page 63	Defines the password and password encryption type for control channel authentication.
receive-window (L2TP), on page 75	Configures the receive window size for the L2TP server.
retransmit (L2TP), on page 77	Configures retransmit retry and timeout values.

hello-interval (L2TP)

To configure the hello-interval value for L2TP (duration between control channel hello packets), use the **hello interval (L2TP)** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

hello-interval *interval*

no hello-interval *interval*

Syntax Description	<i>interval</i>	Interval (in seconds) between control channel hello packets. The range is from 0 to 1000. Default is 60 seconds.
--------------------	-----------------	--

Command Default	<i>interval</i> : 60 seconds
-----------------	------------------------------

Command Modes	L2TP class configuration
---------------	--------------------------

Command History	Release	Modification
	Release 3.7.0	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
------------------	---

Task ID	Task ID	Operations
	l2vpn	read, write

Examples	The following example shows how to configure the hello-interval value for L2TP to 22 seconds:
----------	---

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2tp-class cisco
RP/0/0/CPU0:router(config-l2tp-class)# hello-interval 22
```

Related Commands	Command	Description
	authentication (L2TP) , on page 4	Enables L2TP authentication for a specified L2TP class name.

Command	Description
hidden (L2TP), on page 31	Enables hidden attribute-value pairs (AVPs).
hostname (L2TP), on page 33	Defines the name used in the L2TP hostname AVP.
l2tp-class, on page 40	Enters L2TP class configuration mode where you can define an L2TP signaling template.
password (L2TP), on page 63	Defines the password and password encryption type for control channel authentication.
receive-window (L2TP), on page 75	Configures the receive window size for the L2TP server.
retransmit (L2TP), on page 77	Configures retransmit retry and timeout values.

hidden (L2TP)

To enable hidden attribute-value pairs (AVPs), use the **hidden** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

hidden

no hidden

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes L2TP class configuration

Command History	Release	Modification
	Release 3.7.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples The following example shows how to enable hidden AVPs:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2tp-class cisco
RP/0/0/CPU0:router(config-l2tp-class)# hidden
```

Related Commands	Command	Description
	authentication (L2TP) , on page 4	Enables L2TP authentication for a specified L2TP class name.
	hello-interval (L2TP) , on page 29	Configures the hello-interval value for L2TP (duration between control channel hello packets).
	hostname (L2TP) , on page 33	Defines the name used in the L2TP hostname AVP.

Command	Description
l2tp-class , on page 40	Enters L2TP class configuration mode where you can define an L2TP signaling template.
password (L2TP) , on page 63	Defines the password and password encryption type for control channel authentication.
receive-window (L2TP) , on page 75	Configures the receive window size for the L2TP server.
retransmit (L2TP) , on page 77	Configures retransmit retry and timeout values.

hostname (L2TP)

To define the name used in the L2TP hostname AVP, use the **hostname** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

hostname *name*

no hostname *name*

Syntax Description

<i>name</i>	Hostname used to identify the router during L2TP control channel authentication.
-------------	--

Command Default

None

Command Modes

L2TP class configuration

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to configure a hostname using the word “cisco”:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2tp-class cisco
RP/0/0/CPU0:router(config-l2tp-class)# hostname cisco
```

Related Commands

Command	Description
authentication (L2TP), on page 4	Enables L2TP authentication for a specified L2TP class name.
hello-interval (L2TP), on page 29	Configures the hello-interval value for L2TP (duration between control channel hello packets).

Command	Description
hidden (L2TP), on page 31	Enables hidden attribute-value pairs (AVPs).
l2tp-class, on page 40	Enters L2TP class configuration mode where you can define an L2TP signaling template.
password (L2TP), on page 63	Defines the password and password encryption type for control channel authentication.
receive-window (L2TP), on page 75	Configures the receive window size for the L2TP server.
retransmit (L2TP), on page 77	Configures retransmit retry and timeout values.

interface (p2p)

To configure an attachment circuit, use the **interface** command in p2p configuration submenu. To return to the default behavior, use the **no** form of this command.

interface *type interface-path-id* [**PW-Ether** | **PW-IW**]

no interface *type interface-path-id* [**PW-Ether** | **PW-IW**]

Syntax Description

<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
PW-Ether	(Optional) Configures an Ethernet Interface.
PW-IW	(Optional) Configures an IP Interworking Interface.

Command Default

None

Command Modes

p2p configuration submenu

Command History

Release	Modification
Release 3.4.0	This command was introduced.
Release 4.2.1	The following keywords were added: • PW-Ether • PW-IW

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to configure an attachment circuit on a TenGigE interface:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# xconnect group gr1
RP/0/0/CPU0:router(config-l2vpn-xc)# p2p p001
RP/0/0/CPU0:router(config-l2vpn-xc-p2p)# interface TenGigE 1/1/1/1
```

Related Commands

Command	Description
p2p, on page 73	Enters p2p configuration submode to configure point-to-point cross-connects.

interworking ipv4

To configure IPv4 interworking, use the **interworking ipv4** command in the p2p configuration submode. To return to the default behavior, use the **no** form of this command.

interworking ipv4

no interworking ipv4

Syntax Description	<div>ipv4</div> <div>Sets IPv4 interworking.</div>					
Command Default	None					
Command Modes	p2p configuration submode					
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>Release 4.2.0</td><td>This command was introduced.</td></tr></table>		Release	Modification	Release 4.2.0	This command was introduced.
Release	Modification					
Release 4.2.0	This command was introduced.					
Usage Guidelines	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p>					
Task ID	<table><tr><th>Task ID</th><th>Operations</th></tr><tr><td>l2vpn</td><td>read, write</td></tr></table>		Task ID	Operations	l2vpn	read, write
Task ID	Operations					
l2vpn	read, write					
Examples	<p>The following example shows how to configure an attachment circuit on a TenGigE interface:</p> <pre>RP/0/0/CPU0:router# configure RP/0/0/CPU0:router(config)# l2vpn RP/0/0/CPU0:router(config-l2vpn)# xconnect group gr1 RP/0/0/CPU0:router(config-l2vpn-xc)# p2p gr1 RP/0/0/CPU0:router(config-l2vpn-xc-p2p)# interworking ipv4 RP/0/0/CPU0:router(config-l2vpn-xc-p2p)#</pre>					
Related Commands	<table><tr><th>Command</th><th>Description</th></tr><tr><td>p2p, on page 73</td><td>Enters p2p configuration submode to configure point-to-point cross-connects.</td></tr></table>		Command	Description	p2p , on page 73	Enters p2p configuration submode to configure point-to-point cross-connects.
Command	Description					
p2p , on page 73	Enters p2p configuration submode to configure point-to-point cross-connects.					

interworking ethernet

To configure ethernet interworking across a pseudowire that enables delivery of Ethernet frames, use the **interworking ethernet** command in p2p configuration submode. To undo the configuration, use the **no** form of this command.

interworking ethernet

no interworking ethernet

Syntax Description

ethernet	Specifies the type of pseudowire and the type of traffic that can flow across it.
-----------------	---

Command Default

None

Command Modes

p2p configuration submode

Command History

Release	Modification
Release 4.2.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operation
l2vpn	read, write

Examples

This example shows how to configure an ethernet interface:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# Xconnect group grp1
RP/0/0/CPU0:router(config-l2vpn-xc)# p2p AC1_to_PW1
RP/0/0/CPU0:router(config-l2vpn-xc-p2p)# interworking ethernet
RP/0/0/CPU0:router(config-l2vpn-xc-p2p)#
```

Related Commands

Command	Description
p2p , on page 73	Enters p2p configuration submode to configure point-to-point cross-connects.
interworking ipv4 , on page 37	Configures IPv4 interworking.

l2tp-class

To enter L2TP class configuration mode where you can define an L2TP signaling template, use the **l2tp-class** command in global configuration mode. To delete the L2TP class, use the **no** form of this command.

l2tp-class *l2tp-class-name*

no l2tp-class *l2tp-class-name*

Syntax Description

l2tp-class-name	L2TP class name.
-----------------	------------------

Command Default

No L2TP classes are defined.

Command Modes

Global configuration

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note

An L2TP class name must be defined before configuring L2TP control plane configuration settings.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to enter L2TP configuration mode to create a template of L2TP control plane configuration settings that can be inherited by different pseudowire classes (in this case, the word “cisco” is used):

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2tp-class cisco
RP/0/0/CPU0:router(config-l2tp-class)#
```


l2tp-class configuration

To enter L2TP class configuration mode in which an L2TP signaling template is not defined, use the **l2tp-class configuration** command in global configuration mode. To delete the L2TP class configuration, use the **no** form of this command.

l2tp-class configuration

no l2tp-class configuration

Syntax Description This command has no arguments or keywords.

Command Default No L2TP classes are defined.

Command Modes Global configuration

Command History	Release	Modification
	Release 3.8.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples The following example shows how to enter L2TP configuration mode:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2tp-class configuration
RP/0/0/CPU0:router(config-l2tp-class)#
```

Related Commands	Command	Description
	authentication (L2TP), on page 4	Enables L2TP authentication for a specified L2TP class name.
	hello-interval (L2TP), on page 29	Configures the hello-interval value for L2TP (duration between control channel hello packets).

Command	Description
hidden (L2TP), on page 31	Enables hidden attribute-value pairs (AVPs).
hostname (L2TP), on page 33	Defines the name used in the L2TP hostname AVP.
password (L2TP), on page 63	Defines the password and password encryption type for control channel authentication.
receive-window (L2TP), on page 75	Configures the receive window size for the L2TP server.
retransmit (L2TP), on page 77	Configures retransmit retry and timeout values.

l2transport

To configure a physical interface to operate in Layer 2 transport mode, use the **l2transport** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

l2transport

no l2transport

This command has no arguments or keywords.

Command Default

None

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.4.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The l2transport command and these configuration items are mutually exclusive:

- IPv4 address and feature (for example, ACL) configuration
- IPv4 enable, address and feature (for example, ACL) configuration
- Bundle-enabling configuration
- L3 subinterfaces
- Layer 3 QoS Policy



Note

After an interface or connection is set to Layer 2 switched, commands such as **ipv4 address** are not usable. If you configure routing commands on the interface, **l2transport** is rejected.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to configure an interface or connection as Layer 2 switched under several different modes:

Ethernet Port Mode:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface GigabitEthernet 0/0/0/0
RP/0/0/CPU0:router(config-if)# l2transport
```

Ethernet VLAN Mode:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface GigabitEthernet 0/0/0/0.900 l2transport
RP/0/0/CPU0:router(config-if)# encapsulation dot1q 100dot1q vlan 999
```

Ethernet VLAN Mode (QinQ):

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface GigabitEthernet 0/0/0/0.900 l2transport
RP/0/0/CPU0:router(config-if)# encapsulation dot1q 20 second-dot1q 10vlan 999 888
```

Ethernet VLAN Mode (QinAny):

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface GigabitEthernet 0/0/0/0.900 l2transport
RP/0/0/CPU0:router(config-if)# encapsulation dot1q 30 second-dot1q dot1q vlan 999 any
```

Related Commands

Command	Description
show l2vpn forwarding , on page 96	Displays forwarding information from the layer2_fib manager on the line card.

l2transport cell-packing

To configure L2VPN cell packing parameters, use the **l2transport cell-packing** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

l2transport cell-packing *maximum timer*

no l2transport cell-packing *maximum timer*

Syntax Description

<i>maximum</i>	Maximum number of cells to be packed in a packet. Range is 2 to 86.
<i>timer</i>	Cell packing timer (1, 2, or 3).

Command Default

No default behavior or values

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.5.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read, write
atm	read, write

Examples

The following example shows how to configure L2VPN cell packing parameters:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface GigabitEthernet 0/0/0/0
RP/0/0/CPU0:router(config-if)# l2transport cell-packing 33 2
```

Related Commands

Command	Description
show l2vpn forwarding, on page 96	Displays forwarding information from the layer2_fib manager on the line card.

l2transport l2protocol

To configure Layer 2 protocol handling, use the **l2transport l2protocol** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

l2transport l2protocol {cdp| pvst| stp| vtp} {drop| experimental *bits*| tunnel experimental *bits*}

no l2transport l2protocol {cdp| pvst| stp| vtp} {drop| experimental *bits*| tunnel experimental *bits*}

Syntax Description

cdp	Configures Cisco Discovery Protocol (CDP).
pvst	Configures Per VLAN Spanning Tree protocol (PVST).
stp	Configures Spanning Tree Protocol (STP).
vtp	Configures VLAN Trunk Protocol (VTP).
drop	Drops the selected protocol packets.
experimental <i>bits</i>	Modifies the MPLS experimental bits.
tunnel experimental <i>bits</i>	Configures tunnel protocol packets.

Command Default

None

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.5.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

These L2 protocols are available:

- Cisco Discovery Protocol (CDP)—CDP is protocol-independent and is used to obtain protocol addresses, platform information, and other data about neighboring devices.
- PVST maintains a spanning tree instance for each VLAN configured in the network and permits a VLAN trunk to be forwarding for some VLANs and not for others. It can also load balance Layer 2 traffic by forwarding some VLANs on one trunk and other VLANs on others.

- Spanning-Tree Protocol (STP)—STP is a link management protocol that provides path redundancy in the network. For Ethernet networks to function properly, only one active path can exist between two stations.
- VLAN Trunk Protocol (VTP)—VTP is a Cisco-proprietary protocol that reduces administration in a switched network. When you configure a new VLAN on one VTP server, the VLAN is distributed through all switches in the domain.

Task ID

Task ID	Operations
l2vpn	read, write
atm	read, write

Examples

The following example shows how to configure Layer 2 protocol handling:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface GigabitEthernet 0/0/0/0
RP/0/0/CPU0:router(config-if)# l2transport l2protocol cpsv reverse-tunnelstp drop
```

Related Commands

Command	Description
show l2vpn forwarding , on page 96	Displays forwarding information from the layer2_fib manager on the line card.

l2transport propagate

To propagate Layer 2 transport events, use the **l2transport propagate** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

l2transport propagate remote-status

no l2transport propagate remote-status

Syntax Description	remote-status	
	Propagates remote link status changes.	
Command Default	None	
Command Modes	Interface configuration	
Command History	Release	Modification
	Release 3.9.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **l2transport propagate** command provides a mechanism for the detection and propagation of remote link failure for port mode EoMPLS.

To display the state of l2transport events, use the **show controller internal** command in

To display the state of l2transport events, use the show controller internal command in *Cisco IOS XR Interface and Hardware Component Configuration Guide for the Cisco XR 12000 Series Router*

For more information about the Ethernet remote port shutdown feature, see *Cisco IOS XR MPLS Configuration Guide for the Cisco XR 12000 Series Router*.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows how to propagate remote link status changes:

```
RP/0/0/CPU0:router# configure
```

```
RP/0/0/CPU0:router(config)# interface GigabitEthernet 0/0/0/0  
RP/0/0/CPU0:router(config-if)# l2transport propagate remote remote-status
```

Related Commands

Command	Description
show l2vpn forwarding, on page 96	Displays forwarding information from the layer2_fib manager on the line card.

l2transport service-policy

To configure a Layer 2 transport quality of service (QoS) policy, use the **l2transport service-policy** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

l2transport service-policy {**input** *policy-name*| **output** *policy-name*}

no l2transport service-policy {**input** *policy-name*| **output** *policy-name*}

Syntax Description

input <i>policy-name</i>	Configures the direction of service policy application: input.
output <i>policy-name</i>	Configures the direction of service policy application: output.

Command Default

None

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.5.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read, write
atm	read, write

Examples

The following example shows how configure an L2 transport quality of service (QoS) policy:

```
RP/0/RSP0RP00/CPU0:router# configure
RP/0/RSP0RP00/CPU0:router(config)# interface GigabitEthernet 0/0/0/0
RP/0/RSP0RP00/CPU0:router(config-if)# l2transport service-policy input sp_0001
```

Related Commands

Command	Description
show l2vpn forwarding, on page 96	Displays forwarding information from the layer2_fib manager on the line card.

l2vpn

To enter L2VPN configuration mode, use the **l2vpn** command in global configuration mode. To return to the default behavior, use the **no** form of this command.

l2vpn

no l2vpn

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Global configuration

Command History	Release	Modification
	Release 3.4.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note

All L2VPN configuration can be deleted using the **no l2vpn** command.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples The following example shows how to enter L2VPN configuration mode:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)#
```

Related Commands

Command	Description
show l2vpn forwarding, on page 96	Displays forwarding information from the layer2_fib manager on the line card.

l2vpn switchover

To force a manual pseudowire switchover, use the **l2vpn switchover** command in EXEC mode.

l2vpn switchover xconnect neighbor *IP-address* **pw-id** *value*

Syntax Description

xconnect	Configures the switchover for the cross-connect.
neighbor <i>IP-address</i>	Configures the peer for the cross-connect.
pw-id <i>value</i>	Configures the pseudowire ID. The range is from 1 to 4294967295.

Command Default

None

Command Modes

EXEC

Command History

Release	Modification
Release 4.1.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

If the backup exists, you can switch a primary router over to the backup router. You can use the **l2vpn switchover** command to reactivate the primary router.

Task ID

Task ID	Operations
l2vpn	read, write, execute

Examples

The following example shows how to switch a primary pseudowire to a backup pseudowire:

```
RP/0/0/CPU0:router# l2vpn switchover xconnect neighbor 10.1.1.1 pw-id 2
```

Related Commands

Command	Description
backup disable (L2VPN), on page 8	Specifies how long a backup pseudowire should wait before resuming operation after the primary pseudowire goes down.

logging (l2vpn)

To enable cross-connect logging, use the **logging** command in L2VPN configuration submode. To return to the default behavior, use the **no** form of this command.

logging pseudowire status

no logging pseudowire status

Syntax Description

pseudowire status	Enables pseudowire state change logging.
-------------------	--

Command Default

None

Command Modes

L2VPN configuration submode

Command History

Release	Modification
Release 3.5.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note

All L2VPN configuration can be deleted using the **no l2vpn** command.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to enable cross-connect logging:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# logging pseudowire status
```

Related Commands

Command	Description
l2vpn , on page 53	Enters L2VPN configuration mode.

mpls static label (L2VPN)

To configure static labels for MPLS L2VPN, use the **mpls static label** command in L2VPN cross-connect P2P pseudowire configuration mode. To have MPLS assign a label dynamically, use the **no** form of this command.

mpls static label *local label* *remote value*

no mpls static label *local label* *remote value*

Syntax Description

local <i>label</i>	Configures a local pseudowire label. Range is 16 to 15999.
remote <i>value</i>	Configures a remote pseudowire label. Range is 16 to 15999.

Command Default

The default behavior is a dynamic label assignment.

Command Modes

L2VPN cross-connect P2P pseudowire configuration

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to configure static labels for MPLS L2VPN:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn xconnect group l2vpn
RP/0/0/CPU0:router(config-l2vpn-xc)# p2p rtrA_to_rtrB
RP/0/0/CPU0:router(config-xc-p2p)# neighbor 10.1.1.2 pw-id 1000
RP/0/0/CPU0:router(config-l2vpn-xc-p2p-pw)# mpls static label local 800 remote 500
```

Related Commands

Command	Description
l2vpn, on page 53	Enters L2VPN configuration mode.
neighbor (L2VPN), on page 61	Configures a pseudowire for a cross-connect.
p2p, on page 73	Enters p2p configuration submode to configure point-to-point cross-connects.
xconnect group, on page 134	Configures cross-connect groups.

neighbor (L2VPN)

To configure a pseudowire for a cross-connect, use the **neighbor** command in p2p configuration submode. To return to the default behavior, use the **no** form of this command.

neighbor *A.B.C.D* **pw-id** *value* [**backup** | **mpls** | **pw-class** | **tag-impose**]

no neighbor *A.B.C.D* **pw-id** *value* [**backup** | **mpls** | **pw-class** | **tag-impose**]

Syntax Description

<i>A.B.C.D</i>	IP address of the cross-connect peer.
pw-id <i>value</i>	Configures the pseudowire ID and ID value. Range is 1 to 4294967295.
tag-impose	Optional Specifies a tag during a VLAN ID configuration.

Command Default

None

Command Modes

p2p configuration submode

Command History

Release	Modification
Release 3.4.0	This command was introduced.
Release 3.4.1	The vccv disable keyword was added.
Release 3.7.0	The following keywords were removed: <ul style="list-style-type: none"> • control-word • pw-static-label local • remote • vccv • transport-mode
Release 4.2.1	The keyword tag-impose was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

A cross-connect may have two segments:

- 1 An Attachment Circuit (AC)
- 2 An second AC or a pseudowire

**Note**

The pseudowire is identified by two keys: neighbor and pseudowire ID. There may be multiple pseudowires going to the same neighbor. It is not possible to configure a neighbor only.

All L2VPN configurations can be deleted using the **no l2vpn** command.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows a point-to-point cross-connect configuration (including pseudowire configuration):

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn xconnect group l2vpn
RP/0/0/CPU0:router(config-l2vpn-xc)# p2p rtrA_to_rtrB
RP/0/0/CPU0:router(config-xc-p2p)# neighbor 10.1.1.2 pw-id 1000 pw-class class12
RP/0/0/CPU0:router(config-xc-p2p)# neighbor 10.1.1.3 pw-id 1001 pw-class class13
RP/0/0/CPU0:router(config-xc)# p2p rtrC_to_rtrD
RP/0/0/CPU0:router(config-xc-p2p)# neighbor 10.2.2.3 pw-id 200 pw-class class23
RP/0/0/CPU0:router(config-xc-p2p)# neighbor 10.2.2.4 pw-id 201 pw-class class24
```

The following example shows a point-to-point cross-connect configuration (including pseudowire configuration):

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn xconnect group l2vpn
RP/0/0/CPU0:router(config-l2vpn-xc)# p2p rtrA_to_rtrB
RP/0/0/CPU0:router(config-xc-p2p)# neighbor 10.1.1.2 pw-id 1000 pw-class foo
RP/0/0/CPU0:router(config-xc)# p2p rtrC_to_rtrD
RP/0/0/CPU0:router(config-xc-p2p)# neighbor 20.2.2.3 pw-id 200 pw-class bar1
```

Related Commands

Command	Description
l2vpn , on page 53	Enters L2VPN configuration mode.
p2p , on page 73	Enters p2p configuration submode to configure point-to-point cross-connects.
pw-class (L2VPN) , on page 65	Enters pseudowire class submode to define a pseudowire class template.
xconnect group , on page 134	Configures cross-connect groups.

password (L2TP)

To define the password and password encryption type for control channel authentication, use the **password** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

password [**0**| **7**] *password*

no password

Syntax Description

0	(Optional) Specifies that an unencrypted password will follow.
7	(Optional) Specifies that an encrypted password will follow.
<i>password</i>	Unencrypted or clear text user password.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to define an unencrypted password using the word “cisco” for control channel authentication:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2tp-class sanjose
RP/0/0/CPU0:router(config-l2tp-class)# password 0 cisco
```

Related Commands

Command	Description
authentication (L2TP), on page 4	Enables L2TP authentication for a specified L2TP class name.
hello-interval (L2TP), on page 29	Configures the hello-interval value for L2TP (duration between control channel hello packets).
hidden (L2TP), on page 31	Enables hidden attribute-value pairs (AVPs).
hostname (L2TP), on page 33	Defines the name used in the L2TP hostname AVP.
l2tp-class, on page 40	Enters L2TP class configuration mode where you can define an L2TP signaling template.
receive-window (L2TP), on page 75	Configures the receive window size for the L2TP server.
retransmit (L2TP), on page 77	Configures retransmit retry and timeout values.

pw-class (L2VPN)

To enter pseudowire class submode to define a pseudowire class template, use the **pw-class** command in L2VPN configuration submode. To delete the pseudowire class, use the **no** form of this command.

pw-class *class-name*

no pw-class *class-name*

Syntax Description	<div> <div><i>class-name</i></div> <div>Pseudowire class name.</div> </div>	
Command Default	None	
Command Modes	L2VPN configuration submode	
Command History	Release	Modification
	Release 3.5.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note

All L2VPN configurations can be deleted using the **no l2vpn** command.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows how to define a simple pseudowire class template:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# xconnect group l1vpn
RP/0/0/CPU0:router(config-l2vpn-xc)# p2p rtrA_to_rtrB
RP/0/0/CPU0:router(config-l2vpn-xc-p2p)# neighbor 10.1.1.2 pw-id 1000
RP/0/0/CPU0:router(config-l2vpn-xc-p2p-pw)# pw-class kanata01
```

Related Commands

Command	Description
p2p , on page 73	Enters p2p configuration submode to configure point-to-point cross-connects.

pw-class encapsulation l2tpv3

To configure L2TPv3 pseudowire encapsulation, use the **pw-class encapsulation l2tpv3** command in L2VPN pseudowire class configuration mode. To return to the default behavior, use the **no** form of this command.

pw-class class name encapsulation l2tpv3 [**cookie size** {0 | 4 | 8}| **ipv4 source** *address*| **pmtu max** 68-65535| **protocol l2tpv3 class name**| **tos** {reflect **value** 0-255| **value** 0-255}| **ttl** *value*]

pw-class class name encapsulation l2tpv3 [**cookie size** {0 | 4 | 8}| **ipv4 source** *address*| **pmtu max** 68-65535| **protocol l2tpv3 class name**| **tos** {reflect **value** 0-255| **value** 0-255}| **ttl** *value*]

Syntax Description

class name	Configures an encapsulation class name.
cookie size {0 4 8}	(Optional) Configures the L2TPv3 cookie size setting: <ul style="list-style-type: none"> • 0—Cookie size is 0 bytes. • 4—Cookie size is 4 bytes. • 8—Cookie size is 8 bytes.
ipv4 source <i>address</i>	(Optional) Configures the local source IPv4 address.
pmtu max 68-65535	(Optional) Configures the value of the maximum allowable session MTU.
protocol l2tpv3 class name	(Optional) Configures L2TPv3 as the signaling protocol for the pseudowire class.
tos {reflect value 0-255 value 0-255}	(Optional) Configures TOS and the TOS value. Range is 0 to 255.
ttl <i>value</i>	Configures the Time-to-live (TTL) value. Range is 1 to 255.

Command Default

None

Command Modes

L2VPN pseudowire class configuration

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

**Note**

All L2VPN configurations can be deleted using the **no l2vpn** command.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to define L2TPV3 pseudowire encapsulation:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# pw-class kanata01
RP/0/0/CPU0:router(config-l2vpn-pwc)# encapsulation l2tpv3
```

Related Commands

Command	Description
pw-class (L2VPN), on page 65	Enters pseudowire class submode to define a pseudowire class template.
pw-class encapsulation mpls, on page 69	Configures MPLS pseudowire encapsulation.

pw-class encapsulation mpls

To configure MPLS pseudowire encapsulation, use the **pw-class encapsulation mpls** command in L2VPN pseudowire class configuration mode. To undo the configuration, use the **no** form of this command.

pw-class *class-name* **encapsulation mpls** {**control word**| **ipv4**| **load-balancing**| **preferred-path**| **protocol ldp**| **sequencing**| **tag-rewrite**| **transport-mode**| **vccv verification-type none**}

no pw-class *class-name* **encapsulation mpls** {**control word**| **ipv4**| **load-balancing**| **preferred-path**| **protocol ldp**| **sequencing**| **tag-rewrite**| **transport-mode**| **vccv verification-type none**}

Syntax Description

<i>class-name</i>	Encapsulation class name.
control word	Disables control word for MPLS encapsulation. Disabled by default.
ipv4	Sets the local source IPv4 address.
load-balancing	Sets flow label-based load balancing.
preferred-path	Configures the preferred path tunnel settings.
protocol ldp	Configures LDP as the signaling protocol for this pseudowire class.
sequencing	Configures sequencing on receive or transmit.
tag-rewrite	Configures VLAN tag rewrite.
transport-mode	Configures transport mode to be either Ethernet or VLAN.
vccv none	Enables or disables the VCCV verification type.

Command Default

None

Command Modes

L2VPN pseudowire class configuration

Command History

Release	Modification
Release 3.5.0	This command was introduced.
Release 3.8.0	The keywords control word disable and vccv none were replaced by the keywords control word and vccv verification-type none .
Release 3.9.0	The following keywords were added: <ul style="list-style-type: none"> • preferred-path • sequencing • tag-rewrite • transport-mode

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

**Note**

All L2VPN configurations can be deleted using the **no l2vpn** command.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

This example shows how to define MPLS pseudowire encapsulation:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# pw-class kanata01
RP/0/0/CPU0:router(config-l2vpn-pwc)# encapsulation mpls
```

Related Commands

Command	Description
pw-class (L2VPN), on page 65	Enters pseudowire class submode to define a pseudowire class template.
pw-class encapsulation l2tpv3, on page 67	Configures L2TPv3 pseudowire encapsulation.

pw-ether

To configure a PWHE Ethernet interface, use the **pw-ether** command in global configuration mode or in p2p configuration submenu. To return to the default behavior, use the **no** form of this command.

pw-ether *value*

no pw-ether *value*

Syntax Description

<i>value</i>	Value of the PWHE Ethernet interface. The range is from 1 to 32768.
--------------	---

Command Default

None

Command Modes

Global configuration
p2p configuration

Command History

Release	Modification
Release 4.2.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operation
interface (global configuration)	read, write
l2vpn (p2p configuration)	read, write

Examples

This example shows the sample output of a PWHE Ethernet interface configuration in global configuration mode:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface pw-ether 78
RP/0/0/CPU0:router(config-if)# attach generic-interface-list interfacelist1
```

This example shows the sample output of a PWHE Ethernet interface configuration in p2p configuration submode:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# xconnect group xc1
RP/0/0/CPU0:router(config-l2vpn-xc)# p2p grp1
RP/0/0/CPU0:router(config-l2vpn-xc-p2p)# interface pw-ether 78
```

This example shows the sample output of L2 overhead configuration for the PW-HE interface:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface pw-ether 78
RP/0/0/CPU0:router(config-if)# l2overhead 32
```

This example shows the sample output of Load-interval configuration for the PW-HE interface:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface pw-ether 78
RP/0/0/CPU0:router(config-if)# load-interval 60
```

This example shows the sample output of how to set logging of interface state change for the PW-HE interface:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface pw-ether 78
RP/0/0/CPU0:router(config-if)# logging events link-status
```

This example shows the sample output of MAC address configuration for the PW-HE interface:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface pw-ether 78
RP/0/0/CPU0:router(config-if)# mac-address 44-37-E6-89-C3-93
```

This example shows the sample output of MTU configuration for the PW-HE interface:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface pw-ether 78
RP/0/0/CPU0:router(config-if)# mtu 128
```

This example shows the sample output of bandwidth configuration for the PW-HE interface:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface pw-ether 78
RP/0/0/CPU0:router(config-if)# bandwidth 256
```

Related Commands

Command	Description
p2p, on page 73	Enters p2p configuration submode to configure point-to-point cross-connects.

p2p

To enter p2p configuration submode to configure point-to-point cross-connects, use the **p2p** command in L2VPN xconnect mode. To return to the default behavior, use the **no** form of this command.

p2p *xconnect-name*

no p2p *xconnect-name*

Syntax Description	
<i>xconnect-name</i>	(Optional) Configures the name of the point-to-point cross- connect.

Command Default	None
-----------------	------

Command Modes	L2VPN xconnect
---------------	----------------

Command History	Release	Modification
	Release 3.4.0	This command was introduced.

Usage Guidelines	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>The name of the point-to-point cross-connect string is a free format description string.</p>
------------------	---

Task ID	Task ID	Operations
	l2vpn	read, write

Examples	The following example shows a point-to-point cross-connect configuration (including pseudowire configuration):
----------	--

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# xconnect group group 1
RP/0/0/CPU0:router(config-l2vpn-xc)# p2p xc1
```

Related Commands

Command	Description
interface (p2p), on page 35	Configures an attachment circuit.

receive-window (L2TP)

To configure the receive window size for the L2TP server, use the **receive-window** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

receive-window *size*

no receive-window *size*

Syntax Description

<i>size</i>	Maximum number of packets that are received from a peer before back-off is applied. Default is 512.
-------------	---

Command Default

size: 512

Command Modes

L2TP class configuration

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to configure the receive window size for the L2TP server to 10 packets:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2tp-class cisco
RP/0/0/CPU0:router(config-l2tp-class)# receive-window 10
```

Related Commands

Command	Description
authentication (L2TP) , on page 4	Enables L2TP authentication for a specified L2TP class name.

Command	Description
hello-interval (L2TP), on page 29	Configures the hello-interval value for L2TP (duration between control channel hello packets).
hidden (L2TP), on page 31	Enables hidden attribute-value pairs (AVPs).
hostname (L2TP), on page 33	Defines the name used in the L2TP hostname AVP.
l2tp-class, on page 40	Enters L2TP class configuration mode where you can define an L2TP signaling template.
password (L2TP), on page 63	Defines the password and password encryption type for control channel authentication.
retransmit (L2TP), on page 77	Configures retransmit retry and timeout values.

retransmit (L2TP)

To configure retransmit retry and timeout values, use the **retransmit** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

retransmit {**initial** *initial-retries*| **retries** *retries*| **timeout** {**max**| **min**} *timeout*}

no retransmit {**initial** *initial-retries*| **retries** *retries*| **timeout** {**max**| **min**} *timeout*}

Syntax Description

initial <i>initial-retries</i>	Configures the number of SCCRP messages resent before giving up on a particular control channel. Range is 1 to 1000. Default is 2.
retries <i>retries</i>	Configures the maximum number of retransmissions before determining that peer router does not respond. Range is 5 to 1000. Default is 15.
timeout { max min } <i>timeout</i>	Configures the maximum and minimum retransmission interval in seconds for control packets. Range is 1 to 8. Maximum timeout default is 8 seconds. Minimum timeout default is 1 second.

Command Default

initial retries: 2
retries: 15
min timeout: 1
max timeout: 8

Command Modes

L2TP class configuration

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to configure a retransmit retry value to 1:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2tp-class cisco
RP/0/0/CPU0:router(config-l2tp-class)# retransmit initial retries 1
```

Related Commands

Command	Description
authentication (L2TP), on page 4	Enables L2TP authentication for a specified L2TP class name.
hello-interval (L2TP), on page 29	Configures the hello-interval value for L2TP (duration between control channel hello packets).
hidden (L2TP), on page 31	Enables hidden attribute-value pairs (AVPs).
hostname (L2TP), on page 33	Defines the name used in the L2TP hostname AVP.
l2tp-class, on page 40	Enters L2TP class configuration mode where you can define an L2TP signaling template.
password (L2TP), on page 63	Defines the password and password encryption type for control channel authentication.
receive-window (L2TP), on page 75	Configures the receive window size for the L2TP server.

rollover (L3VPN)

To configure rollover times for a tunnel-template, use the **rollover** command in tunnel encapsulation l2tp configuration mode. To return to the default behavior, use the **no** form of this command.

rollover *periodic time holdown time*

no rollover *periodic time holdown time*

Syntax Description

periodic <i>time</i>	Configures the periodic rollover time in seconds. Range is 60 to 31536000.
holddown <i>time</i>	Configures the holddown time for old session cookie values.

Command Default

None

Command Modes

tunnel encapsulation l2tp configuration

Command History

Release	Modification
Release 3.5.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The name of the point-to-point cross-connect string is a free format description string.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to configure rollover times for a tunnel-template:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# tunnel-template kanata_9
RP/0/0/CPU0:router(config-tuntem) encapsulation l2tp
RP/0/0/CPU0:router(config-tunencap-l2tp) # rollover
```

Related Commands

Command	Description
interface (p2p), on page 35	Configures an attachment circuit.

sequencing (L2VPN)

To configure L2VPN pseudowire class sequencing, use the **pw-class sequencing** command in L2VPN pseudowire class encapsulation mode. To return to the default behavior, use the **no** form of this command.

sequencing {both| receive| transmit {resynch 5-65535}}

no sequencing {both| receive| transmit {resynch 5-65535}}

Syntax Description

both	Configures transmit and receive side sequencing.
receive	Configures receive side sequencing.
transmit	Configures transmit side sequencing.
resynch 5-65535	Configures the threshold for out-of-sequence packets before resynchronization. Range is 5 to 65535.

Command Default

None

Command Modes

L2VPN pseudowire class encapsulation mode

Command History

Release	Modification
Release 3.5.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Do not configure **sequence resynch** on high speed circuits. On low speed circuits, do not configure a threshold lower than 10 to 20 seconds of traffic.



Note

All L2VPN configurations can be deleted using the **no l2vpn** command.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to configure L2VPN pseudowire class sequencing:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# pw-class kanata01
RP/0/0/CPU0:router(config-l2vpn-pw)# encapsulation mpls
RP/0/0/CPU0:router(config-l2vpn-encap-mpls)# sequencing both
```

Related Commands

Command	Description
pw-class (L2VPN), on page 65	Enters pseudowire class submode to define a pseudowire class template.

show l2tp class

To display information about an L2TP class, use the **show l2tp class** command in EXEC mode.

show l2tp class name *name*

Syntax Description	name <i>name</i> Configures an L2TP class name.
--------------------	--

Command Default	None
-----------------	------

Command Modes	EXEC
---------------	------

Command History	Release	Modification
	Release 3.7.0	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
------------------	---

Task ID	Task ID	Operations
	l2vpn	read, write

Examples	The following example shows sample output for the show l2vtp session class command:
----------	--

```
RP/0/0/CPU0:router# show l2tp class name kanata_02

l2tp-class kanata_02
  manually configured class
  configuration parameters:
    (not) hidden
    (no) authentication
    (no) digest
    digest check enable
    hello 60
    (no) hostname
    (no) password
    (no) accounting
    (no) security crypto-profile
    (no) ip vrf
    receive-window 888
    retransmit retries 15
```

show l2tp class

```

retransmit timeout max 8
retransmit timeout min 1
retransmit initial retries 2
retransmit initial timeout max 8
retransmit initial timeout min 1
timeout setup 300

```

This table describes the significant fields shown in the display.

Table 1: show l2tp class brief Field Descriptions

Field	Description
l2tp-class	Shows the L2TP class name and the manner of its creation. For example, manually configured class.
configuration parameters	Displays a complete list and state of all configuration parameters.

Related Commands

Command	Description
l2tp-class , on page 40	Enters L2TP class configuration mode where you can define an L2TP signaling template.

show l2tp counters forwarding session

To display L2TP forward session counters, use the **show l2tp counter forwarding session** command in EXEC mode.

show l2tp counters forwarding session [*id identifier*] **name** *local-name remote-name*]

Syntax Description

id <i>identifier</i>	(Optional) Configures the session counter identifier.
name <i>local-name remote name</i>	(Optional) Configures the local and remote names for a session counter.

Command Default

None

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows sample output for the **show l2tp counters forwarding session** command:

```
RP/0/RP00/CPU0:router(config-l2vpn) # pw-class kanata01show l2tp counters forwarding session
```

```
LocID      RemID      TunID      Pkts-In    Pkts-Out   Bytes-In   Bytes-Out
22112      15584      14332      0           0           0           0
```

This table describes the significant fields shown in the display.

Table 2: show l2tp counters forwarding session Field Descriptions

Field	Description
LocID	Local session ID.
RemID	Remote session ID.
TunID	Local Tunnel ID for this session.
Pkts-In	Number of packets input in the session.
Pkts-Out	Number of packets output in the session.
Bytes-In	Number of bytes input in the session.
Bytes-Out	Number of bytes output in the session.

Related Commands

Command	Description
show l2tp tunnel, on page 89	Displays information about L2TP tunnels.

show l2tp session

To display information about L2TP sessions, use the **show l2tp session** command in EXEC mode.

show l2tp session [**detail**| **brief**| **interworking**| **circuit**| **sequence**| **state**] {**id** *id*| **name** *name*}

Syntax Description

brief	(Optional) Displays summary output for a session.
circuit	(Optional) Displays attachment circuit information for a session.
detail	(Optional) Displays detailed output for a session.
interworking	(Optional) Displays interworking information for a session.
sequence	(Optional) Displays data packet sequencing information for a session.
state	(Optional) Displays control plane state information for a session.
id <i>id</i>	Configures the local tunnel ID. Range is 0 to 4294967295.
name <i>name</i>	Configures the tunnel name.

Command Default

None

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following sample output is from the **show l2vtp session brief** command:

```
RP/0/RP00/CPU0:router(config-l2vpn-pw) # encapsulation mpls show l2tp session brief
```

```
L2TP Session Information Total tunnels 1 sessions 6
```

LocID	TunID	Peer-address	State	Vcid
			sess/cir	
26093	43554	13.0.0.2	est,UP	60
26094	43554	13.0.0.2	est,UP	40
26095	43554	13.0.0.2	est,UP	50
26096	43554	13.0.0.2	est,UP	70
26097	43554	13.0.0.2	est,UP	20
26098	43554	13.0.0.2	est,UP	30

This table describes the significant fields shown in the display.

Table 3: show l2tp session brief Field Descriptions

Field	Description
LocID	Local session ID.
TunID	Local tunnel ID for this session.
Peer-address	The IP address of the other end of the session.
State	The state of the session.
Vcid	The Virtual Circuit ID of the session. This is the same value of the pseudowire ID for l2vpn.

Related Commands

Command	Description
show l2tp tunnel , on page 89	Displays information about L2TP tunnels.

show l2tp tunnel

To display information about L2TP tunnels, use the **show l2tp tunnel** command in EXEC mode.

show l2tp tunnel {**detail**|**brief**|**state**|**transport**} {**id** *identifier*|**name** *local-name remote-name*}

Syntax Description

detail	Displays detailed output for L2TP tunnels.
brief	Displays summary information for the tunnel.
state	Displays control plane state information.
transport	Displays transport information (IP) for each selected control channel.
id <i>identifier</i>	Displays local control channel identifiers.
name <i>local-name remote-name</i>	Displays the local and remote names of a control channel.

Command Default

None

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following sample output is from the **show l2tp tunnel** command:

```
RP/0/0/CPU0:router(config-l2vpn-encap-mp1s)# sequencing bothshow l2tp tunnel
L2TP Tunnel Information Total tunnels 1 sessions 6
```

show l2tp tunnel

```

LocID RemID Remote Name   State Remote Address Port Sessions L2TP Class
43554 6220  PE2             est  13.0.0.2      0      6      foo

```

This table describes the significant fields shown in the display.

Table 4: show l2tp tunnel Field Descriptions

Field	Description
LocID	Local session ID.
RemID	Remote session ID.
Remote Name	Remote name of the session.
State	State of the session.
Remote Address	Remote address of the session.
Port	Session port.
Sessions	Number of sessions.
L2TP	L2TP class name.

Related Commands

Command	Description
show l2tp session, on page 87	Displays information about L2TP sessions.

show l2vpn atom-db

To display AToM database information, use the **show l2vpn atom-db** command in EXEC mode.

show l2vpn atom-db [**detail**| **l2-rid**| **ldp-rid**| **local-gid**| **neighbor**| **preferred-path**| **remote-gid**| **source**]

Syntax Description

detail	Specifies the details of the database.
l2-rid	Specifies the AToM database walking the L2 RID thread.
ldp-rid	Specifies the AToM database walking the LDP RID thread.
local-gid	Specifies the AToM database walking the Local GID thread.
neighbor	Specifies the details of the neighbor database.
preferred-path	Specifies the preferred path (tunnel) of the database
remote-gid	Specifies the AToM database walking the Remote GID thread.
source	Specifies the details of the source database.

Command Default

None

Command Modes

EXEC

Command History

Release	Modification
Release 4.2.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read

Examples

This example shows the sample output of the **show l2vpn atom-db source 1.1.1.1** command:

```
RP/0/0/CPU0:router# show l2vpn atom-db source 1.1.1.1
Peer ID      Source      VC ID      Encap      Signaling    FEC      Discovery
2.2.2.2      1.1.1.1      1          MPLS        LDP          128      none
```

This example shows the sample output of the **show l2vpn atom-db source 1.1.1.1 detail** command:

```
RP/0/0/CPU0:router# show l2vpn atom-db source 1.1.1.1 detail
PW: neighbor 2.2.2.2, PW ID 1, state is down ( provisioned )
  PW class class1, XC ID 0x1
  Encapsulation MPLS, protocol LDP
  Source address 1.1.1.1
  PW type Ethernet, control word disabled, interworking none
  PW backup disable delay 0 sec
  Sequencing not set

      MPLS          Local          Remote
      -----
Label          16000          unknown
Group ID       0x200000060      0x0
Interface      GigabitEthernet0/0/0/1.1  unknown
MTU            1504          unknown
Control word   disabled       unknown
PW type        Ethernet    unknown
VCCV CV type   0x2           0x0
                (none)
                (LSP ping verification)
VCCV CC type   0x6           0x0
                (none)
                (router alert label)
                (TTL expiry)
      -----
MIB cpwVcIndex: 4278194081
Create time: 13/12/2010 15:28:26 (20:32:27 ago)
Last time status changed: 13/12/2010 15:28:26 (20:32:27 ago)
Configuration info:
  PW class: class1
  Peer ID = 2.2.2.2, pseudowire ID = 1
  Control word is not set
  Transport mode: not set
    Configured (Static) Encapsulation: not set
    Provisioned Encapsulation: MPLS
  Static tag rewrite: not set
  MTU: 1504
  Tunnel interface: None
  IW type: 0
  PW type: Dynamic
  Pref path configured: No
  Bridge port: No
  BP learning disabled: No
  BP ucast flooding disabled: No
  BP bcast flooding disabled: No
  CW is mandatory: No
  Label: local unassigned, remote unassigned
  L2 Router-ID: 0.0.0.0
  LDP Router-ID: 0.0.0.0
  GR stale: No
  LDP Status: local established, remote unknown
  LDP tag rewrite: not set
  Force switchover: inactive
  MAC trigger: inactive
  VC sane: Yes
  Use PW Status: No
  Local PW Status: Up(0x0); Remote PW Status: Up(0x0)
  Peer FEC Failed: No
  LSP: Down
  Operational state:
    LDP session state: down
    TE tunnel transport: No
    VC in gr mode: No
```

```
Peer state: up
Transport LSP down: Yes
Advertised label to LDP: No
Received a label from LSD: Yes
Need to send standby bit: No
VC created from rbinding: No
PW redundancy dampening on : No
Notified up : No
Detailed segment state: down
PW event trace history [Total events: 8]
-----
Time          Event          Value
=====
12/13/2010 15:28:26 LSP Down      0
12/13/2010 15:28:26 Provision    0
12/13/2010 15:28:26 LSP Down      0
12/13/2010 15:28:26 Connect Req    0
12/13/2010 15:28:26 Rewrite create 0x100000
12/13/2010 15:28:26 Got label      0x3e80
12/13/2010 15:28:26 Local Mtu      0x5e0
12/13/2010 15:28:26 Peer Up        0
```

show l2vpn collaborators

To display information about the state of the interprocess communications connections between l2vpn_mgr and other processes, use the **show l2vpn collaborators** command in EXEC mode.

show l2vpn collaborators

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes EXEC

Release	Modification
Release 3.4.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Operations
l2vpn	read, write

Examples The following example shows sample output for the **show l2vpn collaborators** command:

```
RP/0/0/CPU0:router# show l2vpn collaborators
L2VPN Collaborator stats:
Name                State      Up Cnts    Down Cnts
-----
IMC                  Down       0          0
LSD                  Up         1          0
```

This table describes the significant fields shown in the display.

Table 5: show l2vpn collaborators Field Descriptions

Field	Description
Name	Abbreviated name of the task interacting with l2vpn_mgr.

Field	Description
State	Indicates if l2vpn_mgr has a working connection with the other process.
Up Cnts	Number of times the connection between l2vpn_mgr and the other process has been successfully established.
Down Cnts	Number of times that the connection between l2vpn_mgr and the other process has failed or been terminated.

Related Commands

Command	Description
clear l2vpn collaborators , on page 16	Clears the state change counters for L2VPN collaborators.

show l2vpn forwarding

To display forwarding information from the layer2_fib manager on the line card, use the **show l2vpn forwarding** command in EXEC mode.

show l2vpn forwarding {**bridge-domain**| **counter**| **detail**| **hardware**| **inconsistent**| **interface**| **l2tp**| **location** [*node-id*]| **message**| **mstp**| **resource**| **retry-list**| **summary**| **unresolved**}

Syntax Description

bridge-domain	Displays bridge domain related forwarding information.
counter	Displays the cross-connect counters.
detail	Displays detailed information from the layer2_fib manager.
hardware	Displays hardware-related layer2_fib manager information.
inconsistent	Displays inconsistent entries only.
interface	Displays the match AC subinterface.
l2tp	Displays L2TPv3 related forwarding information.
location <i>node-id</i>	Displays layer2_fib manager information for the specified location. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
message	Displays messages exchanged with collaborators.
mstp	Displays multi-spanning tree related forwarding information.
resource	Displays resource availability information in the layer2_fib manager.
retry-list	Displays retry list related information.
summary	Displays summary information about cross-connects in the layer2_fib manager.
unresolved	Displays unresolved entries only.

Command Default

None

Command Modes

EXEC

Command History

Release	Modification
Release 3.4.0	This command was introduced.
Release 3.7.0	Sample output was updated to add MAC information for the layer2_fib manager summary.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read

Examples

The following sample output is from the **show l2vpn forwarding bridge detail location** command:

```
RP/0/0/CPU0:router# show l2vpn forwarding location 0/2/cpu0
Bridge-domain name: bgl:bd1, id: 0, state: up
MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: no
Security: disabled
DHCPv4 snooping: profile not known on this node
IGMP snooping: disabled, flooding: disabled
Bridge MTU: 1500 bytes
Number of bridge ports: 1
Number of MAC addresses: 0
Multi-spanning tree instance: 0

GigabitEthernet0/1/0/1.2, state: oper up
Number of MAC: 0
Statistics:
  packets: received 0, sent 0
  bytes: received 0, sent 0
Storm control drop counters:
  packets: broadcast 0, multicast 0, unknown unicast 0
  bytes: broadcast 0, multicast 0, unknown unicast 0

Bridge-domain name: bgl:bd2, id: 1, state: up
Type: pbb-edge, I-SID: 1234
Core-bridge: pbb-bd2
MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: no
Security: disabled
```

```

DHCPv4 snooping: profile not known on this node
IGMP snooping: disabled, flooding: disabled
Bridge MTU: 1500 bytes
Number of bridge ports: 0
Number of MAC addresses: 0
Multi-spanning tree instance: 0

PBB Edge, state: up
  Number of MAC: 0
GigabitEthernet0/1/0/1.3, state: oper up
  Number of MAC: 0
  Storm control drop counters:
    packets: broadcast 0, multicast 0, unknown unicast 0
    bytes: broadcast 0, multicast 0, unknown unicast 0

Bridge-domain name: bg1:bd3, id: 2, state: up
  Type: pbb-core
  Number of associated pbb-edge BDs: 1

MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: no
Security: disabled
DHCPv4 snooping: profile not known on this node
IGMP snooping: disabled, flooding: disabled
Bridge MTU: 1500 bytes
Number of bridge ports: 0
Number of MAC addresses: 0
Multi-spanning tree instance: 0

PBB Core, state: up
Vlan-id: 1

GigabitEthernet0/1/0/1.4, state: oper up
  Number of MAC: 0
  Storm control drop counters:
    packets: broadcast 0, multicast 0, unknown unicast 0
    bytes: broadcast 0, multicast 0, unknown unicast 0

```

The following sample outputs shows the backup pseudowire information:

```

RP/0/0/CPU0:router#show l2vpn forwarding detail location 0/2/CPU0
Local interface: GigabitEthernet0/2/0/0.1, Xconnect id: 0x3000001, Status: up
  Segment 1
    AC, GigabitEthernet0/2/0/0.1, Ethernet VLAN mode, status: Bound
    RG-ID 1, active
    Statistics:
      packets: received 0, sent 0
      bytes: received 0, sent 0
  Segment 2
    MPLS, Destination address: 101.101.101.101, pw-id: 1000, status: Bound
    Pseudowire label: 16000
    Statistics:
      packets: received 0, sent 0
      bytes: received 0, sent 0
  Backup PW
    MPLS, Destination address: 102.102.102.102, pw-id: 1000, status: Bound
    Pseudowire label: 16001
    Statistics:
      packets: received 0, sent 0
      bytes: received 0, sent 0

RP/0/0/CPU0:router#show l2vpn forwarding bridge-domain detail location 0/2/CPU0
Bridge-domain name: bg1:bd1, id: 0, state: up
...
  GigabitEthernet0/2/0/0.4, state: oper up
    RG-ID 1, active
    Number of MAC: 0
    ...

```

```
Nbor 101.101.101.101 pw-id 5000
Backup Nbor 101.101.101.101 pw-id 5000
Number of MAC: 0
...
```

The following sample outputs displays the SPAN segment information of the xconnect:

```
RP/0/0/CPU0:router# show l2vpn forwarding counter location 0/7/CPU0
Legend: ST = State, DN = Down
```

Segment 1	Segment 2	ST	Byte	Switched
pw-span-test (Monitor-Session) mpls	2.2.2.2 UP	0		

```
RP/0/0/CPU0:router #Show l2vpn forwarding monitor-session location 0/7/CPU0
```

Segment 1	Segment 2	State
pw-span-test(monitor-session) mpls	2.2.2.2	UP
pw-span-sess(monitor-session) mpls	3.3.3.3	UP

```
RP/0/0/CPU0:router #Show l2vpn forwarding monitor-session pw-span-test location 0/7/CPU0
```

Segment 1	Segment 2	State
pw-span-test(Monitor-Session) mpls	2.2.2.2	UP

Example 4:

```
RP/0/0/CPU0:router #show l2vpn forwarding detail location 0/7/CPU0
Xconnect id: 0xc000001, Status: up
```

Segment 1

Monitor-Session, pw-span-test, status: Bound

Segment 2

MPLS, Destination address: 2.2.2.2, pw-id: 1, status: Bound

Pseudowire label: 16001

Statistics:

packets: received 0, sent 11799730

bytes: received 0, sent 707983800

Example 5:

```
show l2vpn forwarding private location 0/11/CPU0
```

Xconnect ID 0xc000001

Xconnect info:

Base info: version=0xaabbcc13, flags=0x0, type=2, reserved=0
xcon_bound=TRUE, switching_type=0, data_type=3

AC info:

Base info: version=0xaabbcc11, flags=0x0, type=3, reserved=0
xcon_id=0xc000001, ifh= none, subifh= none, ac_id=0, ac_type=SPAN,
ac_mtu=1500, iw_mode=none, adj_valid=FALSE, adj_addr none

PW info:

Base info: version=0xaabbcc12, flags=0x0, type=4, reserved=0
pw_id=1, nh_valid=TRUE, sig_cap_flags=0x20, context=0x0,
MPLS, pw_label=16001

Statistics:

packets: received 0, sent 11799730

bytes: received 0, sent 707983800

Object: NHOP

Event Trace History [Total events: 5]

Time	Event	Flags
=====	=====	=====

Nexthop info:

Base info: version=0xaabbcc14, flags=0x10000, type=5, reserved=0

show l2vpn forwarding

```
nh_addr=2.2.2.2, plat_data_valid=TRUE, plat_data_len=128, child_count=1
```

```
Object: XCON
```

```
Event Trace History [Total events: 16]
```

```
-----
Time          Event          Flags
====          =====
-----
RP/0/0/CPU0:router #show l2vpn forwarding summary location 0/7/CPU0
Major version num:1, minor version num:0
Shared memory timestamp:0x31333944cf
Number of forwarding xconnect entries:2
  Up:2   Down:0
  AC-PW:1 (1 mpls)  AC-AC:0  AC-BP:0  AC-Unknown:0
  PW-BP:0  PW-Unknown:0  Monitor-Session-PW:1
Number of xconnects down due to:
  AIB:0  L2VPN:0  L3FIB:0
Number of p2p xconnects: 2
Number of bridge-port xconnects: 0
Number of nexthops:1
  MPLS:   Bound:1  Unbound:0  Pending Registration:0
Number of bridge-domains: 0
Number of static macs: 0
Number of locally learned macs: 0
Number of remotely learned macs: 0
Number of total macs: 0
```

The following sample output is from the **show l2vpn forwarding** command:

```
RP/0/0/CPU0:router# show l2vpn forwarding location 0/2/cpu0
```

```
ID   Segment 1      Segment 2
-----
1    Gi0/2/0/0 1    1.1.1.1  9)
```

The following sample output shows the MAC information in the layer2_fib manager summary:

```
RP/0/0/CPU0:router# show l2vpn forwarding summary location 0/3/CPU0
```

```
Major version num:1, minor version num:0
Shared memory timestamp:0x66ff58e894
Number of forwarding xconnect entries:2
  Up:1   Down:0
  AC-PW:0  AC-AC:0  AC-BP:1  PW-BP:1
Number of xconnects down due to:
  AIB:0  L2VPN:0  L3FIB:0
Number of nexthops:1
Number of static macs: 5
Number of locally learned macs: 5
Number of remotely learned macs: 0
Number of total macs: 10
```

Related Commands

Command	Description
clear l2vpn forwarding counters , on page 20	Clears L2VPN forwarding counters.

show l2vpn forwarding l2tp

To display L2VPN forwarding information, use the **show l2vpn forwarding l2tp** command in EXEC mode.

show l2vpn forwarding l2tp disposition {**local session id** *session-ID*| **hardware**| **location** *node-id*} **location** *node-id*

Syntax Description

disposition	Displays forwarding disposition information.
<i>session-ID</i>	Displays L2TPv3-related forwarding information for the specified local session ID. Range is 1-4294967295.
hardware	Displays L2TPv3-related forwarding information read from hardware.
location	Displays L2TPv3-related forwarding information for the specified location.

Command Default

None

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID


Task ID	Operations
l2vpn	read

Examples

The following example shows sample output for the **show l2vpn forwarding l2tp** command:

```
RP/0/0/CPU0:router# show l2vpn forwarding l2tp disposition hardware location 0/3/1
```

```
ID      Segment 1      Segment 2
-----
1      Gi0/2/0/0 1      1.1.1.1  9)
```

 show l2vpn forwarding l2tp**Related Commands**

Command	Description
clear l2vpn forwarding counters, on page 20	Clears L2VPN forwarding counters.

show l2vpn generic-interface-list

To display all the L2VPN virtual interfaces, use the **show l2vpn generic-interface-list** command in EXEC mode.

show l2vpn generic-interface-list {detail| name| private| summary}

Syntax Description

detail	Specifies the details of the interface.
name	Specifies the name of the interface.
private	Specifies the private details of the interface.
summary	Specifies the summary information of the interface.

Command Default

None

Command Modes

EXEC

Command History

Release	Modification
Release 4.2.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read

Examples

This example shows the sample output of the **show l2vpn generic-interface-list** command:

```
RP/0/0/CPU0:router# show l2vpn generic-interface-list
generic-interface-list: 11 (ID: 2, interfaces: 2)  Number of items: 20
generic-interface-list: 12 (ID: 3, interfaces: 4)  Number of items: 15
```

This example shows the sample output of the **show l2vpn generic-interface-list detail** command:

```
RP/0/0/CPU0:router# show l2vpn generic-interface-list detail
generic-interface-list: 11 (ID: 2, interfaces: 2)
```

show l2vpn generic-interface-list

```

GigabitEthernet0/1/0/0 - items pending 2
GigabitEthernet0/1/0/1 - items pending 4
Number of items: 27
  PW-Ether: 1-10, 12-21
  PW-IW: 1-7

generic-interface-list: l2 (ID: 3, interfaces: 4)
  GigabitEthernet0/1/0/0 - items pending 2
  GigabitEthernet0/1/0/1 - items pending 4
  GigabitEthernet0/1/0/2 - items pending 1
  GigabitEthernet0/1/0/3 - items pending 0
Number of items: 20
  PW-Ether: 1-15
  PW-IW: 1-7

```

This example shows the sample output of the **show l2vpn generic-interface-list name | detail** command:

```

RP/0/0/CPU0:router# show l2vpn generic-interface-list name l1 detail
generic-interface-list: l1 (ID: 2, interfaces: 2)
  GigabitEthernet0/1/0/0 - items pending 2
  GigabitEthernet0/1/0/1 - items pending 4
Number of items: 20
  PW-Ether 1-10, 12-21

```


show l2vpn index

To display statistics about the index manager, use the **show l2vpn index** command in EXEC mode.

show l2vpn index private

Syntax Description	private	(Optional) Detailed information about all indexes allocated for each pool.
--------------------	----------------	--

Command Default	None
-----------------	------

Command Modes	EXEC
---------------	------

Command History	Release	Modification
	Release 4.2.1	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
------------------	---

Task ID	Task ID	Operations
	l2vpn	read

Examples	This example shows the sample output of the show l2vpn index command:
----------	--

```
RP/0/0/CPU0:router# show l2vpn index
Pool id: 0x4, App: RD
Pool size: 32767
zombied IDs: 0
allocated IDs: 0

Pool id: 0x5, App: IFLIST
Pool size: 65535
zombied IDs: 0
allocated IDs: 2

Pool id: 0xff000001, App: PW/PBB/Virtual AC
Pool size: 40960
zombied IDs: 0
```

```
allocated IDs: 1
```

```
Pool id: 0xff000002, App: BD  
Pool size: 4095  
zombied IDs: 0  
allocated IDs: 2
```

```
Pool id: 0xff000003, App: MP2MP  
Pool size: 65535  
zombied IDs: 0  
allocated IDs: 1
```

show l2vpn pw-class

To display L2VPN pseudowire class information, use the **show l2vpn pw-class** command in EXEC mode.

show l2vpn pw-class [**detail**] **name** *class name*]

Syntax Description

detail	(Optional) Displays detailed information.
name <i>class-name</i>	(Optional) Displays information about a specific pseudowire class name.

Command Default

None

Command Modes

EXEC

Command History

Release	Modification
Release 3.5.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read

Examples

The following example shows sample output for the **show l2vpn pw-class** command:

```
RP/0/0/CPU0:router# show l2vpn pw-class
```

Name	Encapsulation	Protocol
mplsclass_75	MPLS	LDP
l2tp-dynamic	L2TPv3	L2TPv3

This example shows sample output for the **show l2vpn pw-class detail** command:

```
RP/0/0/CPU0:router# show l2vpn pw-class detail
Encapsulation MPLS, protocol LDP
Transport mode not set, control word unset (default)
Sequencing not set
Static tag rewrite not set
```

```

PW Backup disable delay: 0 sec
MAC withdraw message is sent over PW: no
IPv4 source address 1.1.1.1

```

This table describes the significant fields shown in the display.

Table 6: show l2vpn pw-class Command Field Descriptions

Field	Description
Name	Displays the name of the pseudowire class.
Encapsulation	Displays the encapsulation type.
Protocol	Displays the protocol type.

Related Commands

Command	Description
clear l2vpn forwarding counters, on page 20	Clears L2VPN forwarding counters.

show l2vpn pwhe

To display the pseudowire headend (PWHE) information, use the **show l2vpn pwhe** command in EXEC mode.

show l2vpn pwhe {detail| interface| summary}

Syntax Description

detail	Specifies the details of the interface.
interface	Specifies the name of the interface.
summary	Specifies the summary information of the interface.

Command Default

None

Command Modes

EXEC

Command History

Release	Modification
Release 4.2.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read

Examples

This example show the sample output for **show l2vpn pwhe detail** command:

```
RP/0/0/CPU0:router# show l2vpn pwhe detail
Interface: PW-Ether1   Interface State: Down, Admin state: Up
Interface handle 0x20000070
MTU: 1514
BW: 10000 Kbit
Interface MAC addresses: 0279.96e9.8205
Label: 16000
L2-overhead: 0
VC-type: 5
CW: N
```

```

Generic-interface-list: ifl1 (id: 1)
  Gi0/2/0/1, in bundle BE3, state: Up, replication: success
  Gi0/2/0/0, in bundle BE5, state: Up, replication: success
  Gi0/2/0/2, in bundle BE5, state: Up, replication: success
  Gi0/2/0/3, state: Up, replication: success

Interface: PW-IW1   Interface State: Up, Admin state: Up
Interface handle 0x20000070
MTU: 1514
BW: 10000 Kbit
VC-type: 11
CW: N
Generic-interface-list: ifl2 (id: 2)
  Gi0/3/0/1, in bundle BE6, state: Up, replication: success
  Gi0/3/0/0, in bundle BE6, state: Up, replication: success
  Gi0/3/0/2, state: Up, replication: success
  Gi0/3/0/3, state: Up, replication: success

```

This example show the sample output for **show l2vpn pwhe summary** command:

```

RP/0/0/CPU0:router# show l2vpn pwhe summary
Number of PW-HE interface: 1600
Up: 1300 Down: 300 Admindown: 0
Number of PW-Ether interfaces: 900
Up: 700 Down: 200 Admindown: 0
Number of PW-IW interfaces: 700
Up: 600 Down: 100 Admindown: 0

```

show l2vpn resource

To display the memory state in the L2VPN process, use the **show l2vpn resource** command in EXEC mode.

show l2vpn resource

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 3.4.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read

Examples The following example shows sample output for the **show l2vpn resource** command:

```
RP/0/0/CPU0:router# show l2vpn resource
```

Memory: Normal

describes the significant fields shown in the display. [Table 7: show l2vpn resource Command Field Descriptions, on page 111](#)

Table 7: show l2vpn resource Command Field Descriptions

Field	Description
Memory	Displays memory status.

show l2vpn xconnect

To display brief information on configured cross-connects, use the **show l2vpn connect** command in EXEC mode.

show l2vpn xconnect [**detail**| **group**| **interface**| **neighbor**| **state**| **summary**| **type**| **state unresolved**]

Syntax Description

detail	(Optional) Displays detailed information.
group	(Optional) Displays all cross-connects in a specified group.
interface	(Optional) Filters the interface and subinterface.
neighbor	(Optional) Filters the neighbor.
state	(Optional) Filters the following xconnect state types: <ul style="list-style-type: none"> • up • down
summary	(Optional) Displays AC information from the AC Manager database.
type	(Optional) Filters the following xconnect types: <ul style="list-style-type: none"> • ac-pw • locally switched
state unresolved	(Optional) Displays information about unresolved cross-connects.

Command Default

None

Command Modes

EXEC

Command History

Release	Modification
Release 3.4.0	This command was introduced.
Release 3.4.1	VCCV-related show command output was added.
Release 3.6.0	Preferred-path-related show command output was added.

Release	Modification
Release 3.7.0	Sample output was updated to display the backup pseudowire information.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

If a specific cross-connect is specified in the command (for instance, AC_to_PW1) then only that cross-connect will be displayed; otherwise, all cross-connects are displayed.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows sample output for the **show l2vpn xconnect** command:

```
RP/0/0/CPU0:router# show l2vpn xconnect
```

Legend: ST = State, UP = Up, DN = Down, AD = Admin Down, UR = Unresolved,
LU = Local Up, RU = Remote Up, CO = Connected

XConnect Group	Name	ST	Segment 1 Description	ST	Segment 2 Description	ST
g1	x1	UP	pw-span-test	UP	2.2.2.2	1 UP
siva_xc	siva_p2p	UP	Gi0/4/0/1	UP	10.1.1.1	1 UP
					Backup	
					10.2.2.2	2 UP

The following sample output shows that the backup is in standby mode for the **show l2vpn xconnect detail** command:

```
RP/0/0/CPU0:router# show l2vpn xconnect detail
```

```
Group siva_xc, XC siva_p2p, state is up; Interworking none
Monitor-Session: pw-span-test, state is configured
AC: GigabitEthernet0/4/0/1, state is up
  Type Ethernet
  MTU 1500; XC ID 0x5000001; interworking none; MSTi 0
  Statistics:
    packet totals: send 90
    byte totals: send 19056
PW: neighbor 10.1.1.1, PW ID 1, state is up ( established )
PW class not set, XC ID 0x5000001
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word enabled, interworking none
PW backup disable delay 0 sec
Sequencing not set
  MPLS          Local          Remote
  -----
  Label         30005          16003
  Group ID      0x5000300      0x5000400
  Interface     GigabitEthernet0/4/0/1  GigabitEthernet0/4/0/2
```

show l2vpn xconnect

```

      Interface  pw-span-test                      GigabitEthernet0/3/0/1
      MTU        1500                            1500
      Control word enabled                      enabled
      PW type    Ethernet                      Ethernet
      VCCV CV type 0x2                          0x2
                  (LSP ping verification)      (LSP ping verification)
      VCCV CC type 0x3                          0x3
                  (control word)                (control word)
                  (router alert label)          (router alert label)
-----
Create time: 20/11/2007 21:45:07 (00:49:18 ago)
Last time status changed: 20/11/2007 21:45:11 (00:49:14 ago)
Statistics:
  packet totals: receive 0
  byte totals: receive 0

Backup PW:
PW: neighbor 2.2.2.2, PW ID 2, state is up ( established )
  Backup for neighbor 1.1.1.1 PW ID 1 ( standby )
  PW class not set, XC ID 0x0
  Encapsulation MPLS, protocol LDP
  PW type Ethernet, control word enabled, interworking none
  PW backup disable delay 0 sec
  Sequencing not set
      MPLS      Local                      Remote
      -----
      Label     30006                      16003
      Group ID  unassigned                  0x5000400
      Interface unknown                  GigabitEthernet0/4/0/2
      MTU        1500                      1500
      Control word enabled                enabled
      PW type    Ethernet                  Ethernet
      VCCV CV type 0x2                      0x2
                  (LSP ping verification)  (LSP ping verification)
      VCCV CC type 0x3                      0x3
                  (control word)            (control word)
                  (router alert label)      (router alert label)
      -----
Backup PW for neighbor 10.1.1.1 PW ID 1
Create time: 20/11/2007 21:45:45 (00:48:40 ago)
Last time status changed: 20/11/2007 21:45:49 (00:48:36 ago)
Statistics:
  packet totals: receive 0
  byte totals: receive 0

```

The following sample output shows that the backup is active for the **show l2vpn xconnect detail** command:

RP/0/0/CPU0:router# **show l2vpn xconnect detail**

```

Group siva xc, XC siva_p2p, state is down; Interworking none
Monitor-Session: pw-span-test, state is configured
AC: GigabitEthernet0/4/0/1, state is up
  Type Ethernet
  MTU 1500; XC ID 0x5000001; interworking none; MSTi 0
  Statistics:
    packet totals: send 98
    byte totals: send 20798
PW: neighbor 10.1.1.1, PW ID 1, state is down ( local ready )
  PW class not set, XC ID 0x5000001
  Encapsulation MPLS, protocol LDP
  PW type Ethernet, control word enabled, interworking none
  PW backup disable delay 0 sec
  Sequencing not set
      MPLS      Local                      Remote
      -----
      Label     30005                      unknown
      Group ID  0x5000300                  0x0
      Interface GigabitEthernet0/4/0/1      unknown
      Interface pw-span-test                GigabitEthernet0/3/0/1
      MTU        1500                      unknown
      Control word enabled                  unknown

```

```

PW type          Ethernet          unknown
VCCV CV type 0x2          0x0
                        (none)
                        (LSP ping verification)
VCCV CC type 0x3          0x0
                        (none)
                        (control word)
                        (router alert label)
-----
Create time: 20/11/2007 21:45:06 (00:53:31 ago)
Last time status changed: 20/11/2007 22:38:14 (00:00:23 ago)
Statistics:
  packet totals: receive 0
  byte totals: receive 0

Backup PW:
PW: neighbor 10.2.2.2, PW ID 2, state is up ( established )
Backup for neighbor 10.1.1.1 PW ID 1 ( active )
PW class not set, XC ID 0x0
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word enabled, interworking none
PW backup disable delay 0 sec
Sequencing not set
  MPLS          Local          Remote
-----
Label          30006          16003
Group ID        unassigned      0x5000400
Interface        unknown      GigabitEthernet0/4/0/2
MTU             1500          1500
Control word    enabled         enabled
PW type         Ethernet      Ethernet
VCCV CV type 0x2          0x2
                        (LSP ping verification)
                        (LSP ping verification)
VCCV CC type 0x3          0x3
                        (control word)
                        (control word)
                        (router alert label)
                        (router alert label)
-----
Backup PW for neighbor 10.1.1.1 PW ID 1
Create time: 20/11/2007 21:45:44 (00:52:54 ago)
Last time status changed: 20/11/2007 21:45:48 (00:52:49 ago)
Statistics:
  packet totals: receive 0
  byte totals: receive 0

```

The following sample output displays the xconnects with switch port analyzer (SPAN) as one of the segments:

```

Show l2vpn xconnect type minotor-session-pw
Legend: ST = State, UP = Up, DN = Down, AD = Admin Down, UR = Unresolved,
       LU = Local Up, RU = Remote Up, CO = Connected

```

XConnect Group	Name	ST	Segment 1 Description	ST	Segment 2 Description	ST
g1	x1	UP	pw-span-test	UP	2.2.2.2 1	UP

The following sample output shows that one-way redundancy is enabled:

```

Group g1, XC x2, state is up; Interworking none
AC: GigabitEthernet0/2/0/0.2, state is up, active in RG-ID 1
Type VLAN; Num Ranges: 1
VLAN ranges: [2, 2]
MTU 1500; XC ID 0x3000002; interworking none
Statistics:
  packets: received 103, sent 103
  bytes: received 7348, sent 7348
  drops: illegal VLAN 0, illegal length 0
PW: neighbor 101.101.101.101, PW ID 2000, state is up ( established )
PW class class1, XC ID 0x3000002
Encapsulation MPLS, protocol LDP
PW type Ethernet VLAN, control word disabled, interworking none
PW backup disable delay 0 sec
One-way PW redundancy mode is enabled

```

show l2vpn xconnect

```

Sequencing not set
....
Incoming Status (PW Status TLV):
  Status code: 0x0 (Up) in Notification message
Outgoing Status (PW Status TLV):
  Status code: 0x0 (Up) in Notification message
....
Backup PW:
PW: neighbor 102.102.102.102, PW ID 3000, state is standby ( all ready )
Backup for neighbor 101.101.101.101 PW ID 2000 ( inactive )
PW class class1, XC ID 0x30000002
Encapsulation MPLS, protocol LDP
PW type Ethernet VLAN, control word disabled, interworking none
Sequencing not set
....
Incoming Status (PW Status TLV):
  Status code: 0x26 (Standby, AC Down) in Notification message
Outgoing Status (PW Status TLV):
  Status code: 0x0 (Up) in Notification message

```

The following example shows sample output for the **show l2vpn xconnect** command:

```
RP/0/0/CPU0:router# show l2vpn xconnect
```

Legend: ST = State, UP = Up, DN = Down, AD = Admin Down, UR = Unresolved,
LU = Local Up, RU = Remote Up, CO = Connected

XConnect Group	Name	ST	Segment 1 Description	ST	Segment 2 Description	ST
siva_xc	siva_p2p	UP	Gi0/4/0/1	UP	1.1.1.1	UP
					Backup	
					2.2.2.2	UP

The following sample output shows that the backup is in standby mode for the **show l2vpn xconnect detail** command:

```
RP/0/0/CPU0:router# show l2vpn xconnect detail
```

```

Group siva_xc, XC siva_p2p, state is up; Interworking none
AC: GigabitEthernet0/4/0/1, state is up
Type Ethernet
MTU 1500; XC ID 0x50000001; interworking none; MSTi 0
Statistics:
  packet totals: received 90, sent 90
  byte totals: received 19056, sent 19056
PW: neighbor 1.1.1.1, PW ID 1, state is up ( established )
PW class not set, XC ID 0x50000001
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word enabled, interworking none
PW backup disable delay 0 sec
Sequencing not set

```

MPLS	Local	Remote
Label	30005	16003
Group ID	0x5000300	0x5000400
Interface	GigabitEthernet0/4/0/1	GigabitEthernet0/4/0/2
MTU	1500	1500
Control word	enabled	enabled
PW type	Ethernet	Ethernet
VCCV CV type	0x2	0x2
	(LSP ping verification)	(LSP ping verification)
VCCV CC type	0x3	0x3
	(control word)	(control word)
	(router alert label)	(router alert label)

```

Create time: 20/11/2007 21:45:07 (00:49:18 ago)
Last time status changed: 20/11/2007 21:45:11 (00:49:14 ago)
Statistics:
  packet totals: received 0, sent 0
  byte totals: received 0, sent 0

```

```

Backup PW:
PW: neighbor 2.2.2.2, PW ID 2, state is up ( established )
Backup for neighbor 1.1.1.1 PW ID 1 ( standby )
PW class not set, XC ID 0x0
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word enabled, interworking none
PW backup disable delay 0 sec
Sequencing not set
  MPLS          Local          Remote
  -----
Label          30006          16003
Group ID       unassigned      0x5000400
Interface      unknown          GigabitEthernet0/4/0/2
MTU            1500          1500
Control word   enabled          enabled
PW type        Ethernet      Ethernet
VCCV CV type   0x2          0x2
                (LSP ping verification)    (LSP ping verification)
VCCV CC type   0x3          0x3
                (control word)              (control word)
                (router alert label)        (router alert label)
  -----
Backup PW for neighbor 1.1.1.1 PW ID 1
Create time: 20/11/2007 21:45:45 (00:48:40 ago)
Last time status changed: 20/11/2007 21:45:49 (00:48:36 ago)
Statistics:
  packet totals: received 0, sent 0
  byte totals: received 0, sent 0

```

The following sample output shows that the backup is active for the **show l2vpn xconnect detail** command:

```

RP/0/0/CPU0:router# show l2vpn xconnect detail

Group siva_xc, XC siva_p2p, state is down; Interworking none
AC: GigabitEthernet0/4/0/1, state is up
  Type Ethernet
  MTU 1500; XC ID 0x5000001; interworking none; MSTi 0
  Statistics:
    packet totals: send 98
    byte totals: send 20798
PW: neighbor 1.1.1.1, PW ID 1, state is down ( local ready )
PW class not set, XC ID 0x5000001
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word enabled, interworking none
PW backup disable delay 0 sec
Sequencing not set
  MPLS          Local          Remote
  -----
Label          30005          unknown
Group ID       0x5000300        0x0
Interface      GigabitEthernet0/4/0/1    unknown
MTU            1500          unknown
Control word   enabled          unknown
PW type        Ethernet      unknown
VCCV CV type   0x2          0x0
                (none)
                (LSP ping verification)
VCCV CC type   0x3          0x0
                (none)
                (control word)
                (router alert label)
  -----
Create time: 20/11/2007 21:45:06 (00:53:31 ago)
Last time status changed: 20/11/2007 22:38:14 (00:00:23 ago)
Statistics:
  packet totals: received 0, sent 0
  byte totals: received 0, sent 0

Backup PW:
PW: neighbor 2.2.2.2, PW ID 2, state is up ( established )

```

```

Backup for neighbor 1.1.1.1 PW ID 1 ( active )
PW class not set, XC ID 0x0
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word enabled, interworking none
PW backup disable delay 0 sec
Sequencing not set

```

MPLS	Local	Remote
Label	30006	16003
Group ID	unassigned	0x5000400
Interface	unknown	GigabitEthernet0/4/0/2
MTU	1500	1500
Control word	enabled	enabled
PW type	Ethernet	Ethernet
VCCV CV type	0x2	0x2
	(LSP ping verification)	(LSP ping verification)
VCCV CC type	0x3	0x3
	(control word)	(control word)
	(router alert label)	(router alert label)

```

Backup PW for neighbor 1.1.1.1 PW ID 1
Create time: 20/11/2007 21:45:44 (00:52:54 ago)
Last time status changed: 20/11/2007 21:45:48 (00:52:49 ago)
Statistics:
  packet totals: received 0, sent 0
  byte totals: received 0, sent 0

```

This example shows that the PW type changes to Ethernet, which is Virtual Circuit (VC) type 5, on the interface when a double tag rewrite option is used.

```
RP/0/0/CPU0:router# show l2vpn xconnect pw-class pw-class1 detail
```

```

Group VPWS, XC ac3, state is up; Interworking none
AC: GigabitEthernet0/7/0/5.3, state is up
Type VLAN; Num Ranges: 1
VLAN ranges: [12, 12]
MTU 1508; XC ID 0x2440096; interworking none
Statistics:
  packets: received 26392092, sent 1336
  bytes: received 1583525520, sent 297928
  drops: illegal VLAN 0, illegal length 0
PW: neighbor 3.3.3.3, PW ID 3, state is up ( established )
PW class VPWS1, XC ID 0x2440096
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word disabled, interworking none
PW backup disable delay 0 sec
Sequencing not set

```

MPLS	Local	Remote
Label	16147	21355
Group ID	0x120001c0	0x120001c0
Interface	GigabitEthernet0/7/0/5.3	GigabitEthernet0/7/0/5.3
MTU	1508	1508
Control word	disabled	disabled
PW type	Ethernet	Ethernet
VCCV CV type	0x2	0x2
	(LSP ping verification)	(LSP ping verification)
VCCV CC type	0x6	0x6
	(router alert label)	(router alert label)
	(TTL expiry)	(TTL expiry)

```

Incoming Status (PW Status TLV):
Status code: 0x0 (Up) in Notification message
Outgoing Status (PW Status TLV):
Status code: 0x0 (Up) in Notification message
MIB cpwVcIndex: 4294705365
Create time: 21/09/2011 08:05:01 (00:14:01 ago)
Last time status changed: 21/09/2011 08:07:01 (00:12:01 ago)
Statistics:
  packets: received 1336, sent 26392092

```

bytes: received 297928, sent 1583525520

This example shows the sample output of a pseudowire headend (PWHE) cross connect:

```
RP/0/0/CPU0:router# show l2vpn xconnect interface pw-ether 67 detail
Group g1, XC xcl, state is down; Interworking none
AC:PW-Ether1, state is up
  Type PW-Ether
  Interface-list: interfacelist1
  Replicate status:
    Gi0/2/0/1: success
    Gi0/3/0/1: pending
    Gi0/4/0/1: failed
  MTU 1500; interworking none
  Statistics:
    packets: received 0, sent 0
    bytes: received 0, sent 0
PW: neighbor 130.130.130.130, PW ID 1234, state is down ( provisioned )
PW class not set
Encapsulation MPLS, protocol LDP
PW type Ethernet VLAN, control word disabled, interworking none
Sequencing not set
Internal label: 16008
VLAN id imposed: 101

      MPLS          Local                      Remote
      -----
Label          16001                          unknown
Group ID       0x2000600                        0x0
Interface      PW-Ether1                      unknown
MTU            1500                          unknown
Control word   disabled                      unknown
PW type        Ethernet VLAN                  unknown
VCCV CV type   0x2                          0x0
                                   (none)
                                   (LSP ping verification)
VCCV CC type   0x6                          0x0
                                   (none)
                                   (router alert label)
                                   (TTL expiry)
      -----
MIB cpwVcIndex: 2
Create time: 19/02/2010 23:13:01 (1w2d ago)
Last time status changed: 19/02/2010 23:13:16 (1w2d ago)
Statistics:
  packets: received 0, sent 0
  bytes: received 0, sent 0
```

This table describes the significant fields shown in the display.

Table 8: show l2vpn xconnect Command Field Descriptions

Field	Description
XConnect Group	Displays a list of all configured cross-connect groups.
Group	Displays the cross-connect group number.
Name	Displays the cross-connect group name.
Description	Displays the cross-connect group description. If no description is configured, the interface type is displayed.

Field	Description
ST	State of the cross-connect group: up (UP) or down (DN).

Related Commands

Command	Description
xconnect group , on page 134	Configures cross-connect groups.

show tunnel-template

To display tunnel template information, use the **show tunnel-template** command in the EXEC mode.

show tunnel-template *template-name*

Syntax Description	<i>template-name</i>	Name of the tunnel template.
--------------------	----------------------	------------------------------

Command Default	None
-----------------	------

Command Modes	EXEC
---------------	------

Command History	Release	Modification
	Release 3.5.0	This command was introduced.

Usage Guidelines

Task ID	Task ID	Operation
	tunnel	read

Examples

The following example shows the output of the **show tunnel-template test** command for Local PE Tunnel:

```
RP/0/0/CPU0:router# show tunnel-template test
Fri Jan 30 06:22:46.428 UTC

Tunnel template
-----
Name:      test (ifhandle: 0x00080030)
MTU:       1464
TTL:       255
TOS:       0
Tunnel ID: 1
Source:    25.25.25.25
Session ID: 0x1D174108 Cookie: 8 bytes [0x24FD3ADAA4485333] being rolled into
           Session ID: 0x15A86E93 Cookie: 8 bytes [0xF486195660CCD522]
Next Session-id/Cookie rollover happens in 1 minute 49 seconds
Transmit:   14213298 pkts  1250770344 bytes
Cookie Mismatch: 0 pkts
MTU Violation: 0 pkts
```

The following example shows the output of the **show tunnel-template test** command for Remote PE Tunnel:

```
RP/0/0/CPU0:router# show tunnel-template test
```

show tunnel-template

Fri Jan 30 06:04:29.800 UTC

Tunnel template

```

-----
Name:      test (ifhandle: 0x00080030)
MTU:       600
TTL:       255
TOS:       0
Tunnel ID: 1
Source:    35.35.35.35      Address Pool: 36.36.36.0/28
Session ID: 0x111F4312 Cookie: 8 bytes [0xB95A806145BE9BE7]
Transmit:  122168722 pkts  10750845295 bytes
Cookie Mismatch: 0 pkts
MTU Violation: 0 pkts

```

Related Commands

Command	Description
tunnel-template, on page 133	Enters tunnel-template configuration submode.

switching-tlv (L2VPN)

To advertise the switching point type-length variable (TLV) in the label binding, use the **switching-tlv** command in the pseudowire class configuration mode. To disable the display of the TLV, use the **no** form of this command.

switching tlv hide

no switching tlv

Syntax Description

hide	Hides TLV.
-------------	------------

Command Default

Switching point TLV data is advertised to peers.

Command Modes

L2VPN pseudowire class encapsulation mode

Command History

Release	Modification
Release 4.1.1	This command was introduced.

Usage Guidelines

The pseudowire switching point TLV information includes the following information:

- Pseudowire ID of the last pseudowire segment traversed
- Pseudowire switching point description
- Local IP address of the pseudowire switching point
- Remote IP address of the last pseudowire switching point that was crossed or the T-PE router

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to configure a timeout value for L2TP session setup of 400 seconds:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# pw-class cisco
RP/0/0/CPU0:router(config-l2vpn-pwc)# encapsulation mpls
RP/0/0/CPU0:router(config-l2vpn-pwc-mpls)# switching-tlv hide
RP/0/0/CPU0:router(config-l2vpn-pwc-mpls)#
```

Related Commands

Command	Description
pw-class (L2VPN), on page 65	Enters pseudowire class submode to define a pseudowire class template.

tag-impose

To specify a tag for a VLAN ID configuration, use the **tag-impose** command in l2vpn configuration submode. To remove the tag, use the **no** form of this command.

tag-impose *vlan value*

no tag-impose *vlan value*

Syntax Description

vlan	VLAN in tagged mode.
<i>value</i>	Tag value. The range is from 1 to 4094. The default value is 0.

Command Default

None

Command Modes

L2VPN configuration

Command History

Release	Modification
Release 4.2.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

This example shows how to specify a tag for a VLAN:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# xconnect group xc1
RP/0/0/CPU0:router(config-l2vpn-xc)# p2p grp1
RP/0/0/CPU0:router(config-l2vpn-xc-p2p)# neighbor 10.1.1.2 pw-id 78
RP/0/0/CPU0:router(config-l2vpn-xc-p2p-pw)# tag-impose vlan 8
```

Related Commands

Command	Description
pw-class (L2VPN), on page 65	Enters pseudowire class submode to define a pseudowire class template.

tag-rewrite

To configure VLAN tag rewrite, use the **tag-rewrite** command in Encapsulation MPLS configuration mode. To disable VLAN tag rewrite, use the **no** form of this command.

tag-rewrite ingress vlan *vlan-id*

no tag-rewrite ingress vlan *vlan-id*

Syntax Description	ingress	Configures ingress mode.
	vlan	Configures VLAN tagged mode
	<i>vlan-id</i>	Specifies the value of the ID of the VLAN.

Command Default None

Command Modes Encapsulation MPLS configuration

Command History	Release	Modification
	Release 3.7.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **tag-rewrite** command is applicable only to pseudowires with MPLS encapsulation.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples The following example shows how to configure preferred-path tunnel settings:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# pw-class kanata01
RP/0/0/CPU0:router(config-l2vpn-pwc)# encapsulation mpls
RP/0/0/CPU0:router(config-l2vpn-pwc-encap-mpls)# tag-rewrite vlan 2000
RP/0/0/CPU0:router(config-l2vpn-pwc-encap-mpls)#
```

Related Commands

Command	Description
show l2vpn xconnect , on page 112	Displays brief information on configured cross-connects.

timeout setup (L2TP)

To configure timeout definitions for L2TP session setup, use the **timeout setup** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

timeout setup *seconds*

no timeout setup *seconds*

Syntax Description

<i>seconds</i>	Time, in seconds, to setup a control channel. Range is 60 to 6000 seconds. Default is 300 seconds.
----------------	--

Command Default

seconds: 300

Command Modes

L2TP class configuration

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to configure a timeout value for L2TP session setup of 400 seconds:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2tp-class cisco
RP/0/0/CPU0:router(config-l2tp-class)# timeout setup 400
```

Related Commands

Command	Description
authentication (L2TP) , on page 4	Enables L2TP authentication for a specified L2TP class name.

Command	Description
hello-interval (L2TP), on page 29	Configures the hello-interval value for L2TP (duration between control channel hello packets).
hidden (L2TP), on page 31	Enables hidden attribute-value pairs (AVPs).
hostname (L2TP), on page 33	Defines the name used in the L2TP hostname AVP.
l2tp-class, on page 40	Enters L2TP class configuration mode where you can define an L2TP signaling template.
password (L2TP), on page 63	Defines the password and password encryption type for control channel authentication.
receive-window (L2TP), on page 75	Configures the receive window size for the L2TP server.
retransmit (L2TP), on page 77	Configures retransmit retry and timeout values.
show l2tp session, on page 87	Displays information about L2TP sessions.
show l2tp tunnel, on page 89	Displays information about L2TP tunnels.

transport mode (L2VPN)

To configure L2VPN pseudowire class transport mode, use the **transport mode** command in L2VPN pseudowire class MPLS encapsulation mode. To return to the default behavior, use the **no** form of this command.

transport mode {ethernet| vlan }

no transport mode {ethernet| vlan }

Syntax Description

ethernet	Configures Ethernet port mode.
vlan	Configures VLAN tagged mode.

Command Default

None

Command Modes

L2VPN pseudowire class MPLS encapsulation

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note

All L2VPN configurations can be deleted using the **no l2vpn** command.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to configure Ethernet transport mode:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# pw-class kanata01
```

```
RP/0/0/CPU0:router(config-l2vpn-pw)# encapsulation mpls  
RP/0/0/CPU0:router(config-l2vpn-encap-mpls)# transport-mode ethernet
```

Related Commands

Command	Description
pw-class (L2VPN), on page 65	Enters pseudowire class submode to define a pseudowire class template.

tunnel-template

To enter tunnel-template configuration submode, use the **tunnel-template** command in global configuration mode.

tunnel-template *template name*

no tunnel-template *template-name*

Syntax Description	<i>template-name</i>	Configures a name for the tunnel template.
--------------------	----------------------	--

Command Default	None
-----------------	------

Command Modes	Global configuration
---------------	----------------------

Command History	Release	Modification
	Release 3.5.0	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
------------------	---

Task ID	Task ID	Operations
	tunnel	read, write

Examples	The following example shows how to enter tunnel-template configuration submode:
----------	---

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# tunnel-template template_01
```

Related Commands	Command	Description
	xconnect group , on page 134	Configures cross-connect groups.

xconnect group

To configure cross-connect groups, use the **xconnect group** command in L2VPN configuration mode. To return to the default behavior, use the **no** form of this command.

xconnect group *group-name*

no xconnect group *group-name*

Syntax Description

<i>group-name</i>	Configures a cross-connect group name using a free-format 32-character string.
-------------------	--

Command Default

None

Command Modes

L2VPN configuration

Command History

Release	Modification
Release 3.4.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note

You can configure up to a maximum of 16K cross-connects per box.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to group all cross -connects for customer_atlantic:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# xconnect group customer_atlantic
```

Related Commands

Command	Description
show l2vpn xconnect, on page 112	Displays brief information on configured cross-connects.



Virtual Private LAN Services Commands

This module describes the commands used to configure, monitor, and troubleshoot Virtual Private LAN Services (VPLS).

For detailed information about virtual private network concepts, configuration tasks, and examples, refer to the *Virtual Private Configuration Guide*.

- [action \(VPLS\), page 139](#)
- [aging \(VPLS\), page 141](#)
- [bridge-domain \(VPLS\), page 143](#)
- [bridge group \(VPLS\), page 145](#)
- [clear l2vpn bridge-domain \(VPLS\), page 147](#)
- [flooding disable, page 149](#)
- [flooding unknown-unicast disable \(VPLS\), page 151](#)
- [interface \(VPLS\), page 153](#)
- [learning disable \(VPLS\), page 155](#)
- [limit \(VPLS\), page 157](#)
- [mac \(VPLS\), page 159](#)
- [maximum \(VPLS\), page 161](#)
- [mpls static label \(VPLS\), page 163](#)
- [mtu \(VPLS\), page 165](#)
- [neighbor \(VPLS\), page 167](#)
- [notification \(VPLS\), page 169](#)
- [port-down flush disable \(VPLS\), page 171](#)
- [pw-class \(VFI\), page 173](#)
- [pw-status \(L2VPN\), page 175](#)
- [show l2vpn bridge-domain \(VPLS\), page 177](#)
- [show l2vpn forwarding bridge-domain \(VPLS\), page 184](#)

- [show l2vpn forwarding bridge-domain mac-address \(VPLS\), page 189](#)
- [shutdown \(Bridge Domain\), page 193](#)
- [shutdown \(VFI\), page 195](#)
- [static-address \(VPLS\), page 197](#)
- [static-mac-address \(VPLS\), page 199](#)
- [time \(VPLS\), page 201](#)
- [type \(VPLS\), page 203](#)
- [vfi \(VPLS\), page 205](#)
- [withdraw \(VPLS\), page 207](#)

action (VPLS)

To configure the bridge behavior when the number of learned MAC addresses reaches the MAC limit configured, use the **action** command in L2VPN bridge group bridge domain MAC limit configuration mode. To disable this feature, use the **no** form of this command.

action {**flood**| **no-flood**| **shutdown**}

no action {**flood**| **no-flood**| **shutdown**}

Syntax Description

flood	Configures the action to flood all unknown unicast packets when the MAC limit is reached. If the action is set to flood, all unknown unicast packets, with unknown destinations addresses, are flooded over the bridge.
no-flood	Configures the action to no-flood so all unknown unicast packets are dropped when the MAC limit is reached. If the action is set to no-flood, all unknown unicast packets, with unknown destination addresses, are dropped.
shutdown	Stops forwarding when the MAC limit is reached. If the action is set to shutdown, all packets are dropped.

Command Default

No action is taken when the MAC address limit is reached.

Command Modes

L2VPN bridge group bridge domain MAC limit configuration

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **action** command to specify the type of action to be taken when the action is violated.

The configured action has no impact if the MAC limit has not been reached.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to configure the bridge bar to flood all unknown unicast packets when the number of MAC addresses learned by the bridge reaches 10:

```
RP/0/0/CPU0:router#configure
RP/0/0/CPU0:router(config)#l2vpn
RP/0/0/CPU0:router(config-l2vpn)#bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)#bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)#mac
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac)#limit
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac-limit)#action flood
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac-limit)#maximum 10
```

Related Commands

Command	Description
bridge-domain (VPLS), on page 143	Establishes a bridge domain and enters L2VPN bridge group bridge domain configuration mode.
bridge group (VPLS), on page 145	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
limit (VPLS), on page 157	Sets the MAC address limit for action, maximum, and notification and enters L2VPN bridge group bridge domain MAC limit configuration mode.
l2vpn, on page 53	Enters L2VPN configuration mode.
mac (VPLS), on page 159	Enters L2VPN bridge group bridge domain MAC configuration mode.
maximum (VPLS), on page 161	Configures the specified action when the number of MAC addresses learned on a bridge is reached.
notification (VPLS), on page 169	Specifies the type of notification that is sent when the number of learned MAC addresses exceeds the configured limit.

aging (VPLS)

To enter the MAC aging configuration submode to set the aging parameters such as time and type, use the **aging** command in L2VPN bridge group bridge domain configuration mode. To return to the default value for all parameters that are attached to this configuration submode, use the **no** form of this command.

aging

no aging

Syntax Description

This command has no keywords or arguments.

Command Default

No defaults are attached to this parameter since it is used as a configuration submode. See defaults that are assigned to the [time \(VPLS\)](#), [on page 201](#) and the [type \(VPLS\)](#), [on page 203](#) parameters.

Command Modes

L2VPN bridge group bridge domain MAC configuration

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **aging** command to enter L2VPN bridge group bridge domain MAC aging configuration mode.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to enter MAC aging configuration submode and to set the MAC aging time to 120 seconds:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac)# aging
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac-aging)# time 120
```

Related Commands

Commands	Description
bridge-domain (VPLS) , on page 143	Establishes a bridge domain and enters L2VPN bridge group bridge domain configuration mode.
bridge group (VPLS) , on page 145	Creates a bridge group so that it can contain bridge domains and then assigns network interfaces to the bridge domain.
l2vpn , on page 53	Enters L2VPN configuration mode.
mac (VPLS) , on page 159	Enters L2VPN bridge group bridge domain MAC configuration mode.
time (VPLS) , on page 201	Configures the maximum aging time.
type (VPLS) , on page 203	Configures the type for MAC address aging.

bridge-domain (VPLS)

To establish a bridge domain and to enter L2VPN bridge group bridge domain configuration mode, use the **bridge-domain** command in L2VPN bridge group configuration mode. To return to a single bridge domain, use the **no** form of this command.

bridge-domain *bridge-domain-name*

no bridge-domain *bridge-domain-name*

Syntax Description

<i>bridge-domain-name</i>	Name of the bridge domain.
Note	The maximum number of characters that can be specified in the bridge domain name is 27.

Command Default

The default value is a single bridge domain.

Command Modes

L2VPN bridge group configuration

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **bridge-domain** command to enter L2VPN bridge group bridge domain configuration mode.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to configure a bridge domain:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)#
```

Related Commands

Command	Description
bridge group (VPLS), on page 145	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
l2vpn, on page 53	Enters L2VPN configuration mode.

bridge group (VPLS)

To create a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain, use the **bridge group** command in L2VPN configuration mode. To remove all the bridge domains that are created under this bridge group and to remove all network interfaces that are assigned under this bridge group, use the **no** form of this command.

bridge group *bridge-group-name*

no bridge-group *bridge-group-name*

Syntax Description	
<i>bridge-group-name</i>	Number of the bridge group to which the interface belongs.

Command Default No bridge group is created.

Command Modes L2VPN configuration

Command History	Release	Modification
	Release 3.7.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **bridge group** command to enter L2VPN bridge group configuration mode.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples The following example shows that bridge group 1 is assigned:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)#
```

Related Commands

Command	Description
bridge-domain (VPLS) , on page 143	Establishes a bridge domain and enters L2VPN bridge group bridge domain configuration mode.
l2vpn , on page 53	Enters L2VPN configuration mode.

clear l2vpn bridge-domain (VPLS)

To clear the MAC addresses and to restart the bridge domains on the router, use the **clear l2vpn bridge-domain** command in EXEC mode.

clear l2vpn bridge-domain {**all**| **bd-name** *name*| **group** *group*}

Syntax Description

all	Clears and restarts all the bridge domains on the router.
bd-name <i>name</i>	Clears and restarts the specified bridge domain. The <i>name</i> argument specifies the name of the bridge-domain.
group <i>group</i>	Clears and restarts all the bridge domains that are part of the bridge group.

Command Default

None

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

This is the method that allows a bridge to forward again after it was put in Shutdown state as a result of exceeding the configured MAC limit.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to clear all the MAC addresses and to restart all the bridge domains on the router:

```
RP/0/0/CPU0:router# clear l2vpn bridge-domain all
```

Related Commands

Command	Description
show l2vpn bridge-domain (VPLS), on page 177	Display information for the bridge ports such as attachment circuits and pseudowires for the specific bridge domains.

flooding disable

To configure flooding for traffic at the bridge domain level or at the bridge port level, use the **flooding disable** command in L2VPN bridge group bridge domain configuration mode. To return the bridge to normal flooding behavior when all unknown unicast packets, all broadcast packets, and all multicast packets are flooded over all other bridge domain network interfaces, use the **no** form of this command.

flooding disable

no flooding disable

This command has no keywords or arguments.

Command Default

The default behavior is that packets are flooded when their destination MAC address is not found.

Command Modes

L2VPN bridge group bridge domain configuration

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **flooding disable** command to override the parent bridge configuration.

By default, bridge ports inherit the flooding behavior of the bridge domain.

When flooding is disabled, all unknown unicast packets, all broadcast packets, and all multicast packets are discarded.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to disable flooding on the bridge domain called bar:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# flooding disable
```

Related Commands

Command	Description
bridge-domain (VPLS), on page 143	Establishes a bridge domain and enters L2VPN bridge group bridge domain configuration mode.
bridge group (VPLS), on page 145	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
l2vpn, on page 53	Enters L2VPN configuration mode.
mtu (VPLS), on page 165	Adjusts the maximum packet size or maximum transmission unit (MTU) size for the bridge domain.

flooding unknown-unicast disable (VPLS)

To disable flooding of unknown unicast traffic at the bridge domain level or at the bridge port level, use the **flooding unknown-unicast disable** command in L2VPN bridge group bridge domain configuration mode. To return the bridge to normal flooding behavior, use the **no** form of this command.

flooding unknown-unicast disable

no flooding unknown-unicast disable

Syntax Description This command has no keywords or arguments.

Command Default The default behavior is that packets are flooded when their destination MAC address is not found.

Command Modes L2VPN bridge group bridge domain configuration

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **flooding unknown-unicast disable** command to override the parent bridge configuration.

By default, bridge ports inherit the flooding behavior of the bridge domain.

When flooding is disabled, all unknown unicast packets are discarded.

Use this command on Layer 2 interfaces. This command is not applicable on BVI interfaces.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples The following example shows how to disable flooding on the bridge domain called bar:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# flooding unknown-unicast disable
```

Related Commands

Command	Description
bridge-domain (VPLS), on page 143	Establishes a bridge domain and enters L2VPN bridge group bridge domain configuration mode.
bridge group (VPLS), on page 145	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
l2vpn, on page 53	Enters L2VPN configuration mode.
mtu (VPLS), on page 165	Adjusts the maximum packet size or maximum transmission unit (MTU) size for the bridge domain.

interface (VPLS)

To add an interface to a bridge domain that allows packets to be forwarded and received from other interfaces that are part of the same bridge domain, use the **interface** command in L2VPN bridge group bridge domain configuration mode. To remove an interface from a bridge domain, use the **no** form of this command.

interface *type interface-path-id*

no interface *type interface-path-id*

Syntax Description

<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface. Note Use the show interfaces command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.

Command Default

None

Command Modes

L2VPN bridge group bridge domain configuration

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **interface** command to enter L2VPN bridge group bridge domain attachment circuit configuration mode. In addition, the **interface** command enters the interface configuration submode to configure parameters specific to the interface.

By default, an interface is not part of a bridge.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to configure the bundle Ethernet interface as an attachment circuit:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# interface gigabitethernet 0/1/0/9
RP/0/0/CPU0:router(config-l2vpn-bg-bd-ac)#
```

Related Commands

Command	Description
bridge-domain (VPLS), on page 143	Establishes a bridge domain and enters L2VPN bridge group bridge domain configuration mode.
bridge group (VPLS), on page 145	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
l2vpn, on page 53	Enters L2VPN configuration mode.

learning disable (VPLS)

To override the MAC learning configuration of a parent bridge or to set the MAC learning configuration of a bridge, use the **learning disable** command in L2VPN bridge group bridge domain MAC configuration mode. To disable this feature, use the **no** form of this command.

learning disable

no learning disable

Syntax Description

This command has no keywords or arguments.

Command Default

By default, learning is enabled on all bridge domains and all interfaces on that bridge inherits this behavior.

Command Modes

L2VPN bridge group bridge domain MAC configuration

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

When set, the **learning disable** command stops all MAC learning either on the specified interface or the bridge domain.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

In the following example, MAC learning is disabled on all ports in the bridge domain called bar, which is applied to all interfaces in the bridge unless the interface has its own MAC learning enable command.

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac)# learning disable
```

Related Commands

Command	Description
bridge-domain (VPLS), on page 143	Establishes a bridge domain and enters L2VPN bridge group bridge domain configuration mode.
bridge group (VPLS), on page 145	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
l2vpn, on page 53	Enters L2VPN configuration mode.
mac (VPLS), on page 159	Enters L2VPN bridge group bridge domain MAC configuration mode.

limit (VPLS)

To set the MAC address limit for action, maximum, and notification and to enter L2VPN bridge group bridge domain MAC limit configuration mode, use the **limit** command in L2VPN bridge group bridge domain MAC configuration mode. To remove all limits that were previously configured under the MAC configuration submodes, use the **no** form of this command.

limit

no limit

Syntax Description	This command has no keywords or arguments.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	L2VPN bridge group bridge domain MAC configuration
----------------------	--

Command History	Release	Modification
	Release 3.7.0	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

Use the limit command to enter L2VPN bridge group bridge domain MAC limit configuration mode. The limit command specifies that one syslog message is sent or a corresponding trap is generated with the MAC limit when the action is violated.
--

Task ID	Task ID	Operations
	l2vpn	read, write

Examples	The following example shows how the MAC limit for the bridge bar is set to 100 with an action of shutdown. After the configuration, the bridge stops all forwarding after 100 MAC addresses are learned. When this happens, a syslog message and an SNMP trap are created.
-----------------	--

<pre>RP/0/0/CPU0:router# configure RP/0/0/CPU0:router(config)# l2vpn RP/0/0/CPU0:router(config-l2vpn)# bridge group 1 RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar RP/0/0/CPU0:router(config-l2vpn-bg-bd)# mac</pre>
--

```

RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac)# limit
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac-limit)# maximum 100
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac-limit)# action shutdown
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac-limit)# notification both

```

Related Commands

Command	Description
action (VPLS), on page 139	Configures bridge behavior when the number of learned MAC addresses reaches the MAC limit configured.
bridge-domain (VPLS), on page 143	Establishes a bridge domain and enters L2VPN bridge group bridge domain configuration mode.
bridge group (VPLS), on page 145	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
l2vpn, on page 53	Enters L2VPN configuration mode.
mac (VPLS), on page 159	Enters L2VPN bridge group bridge domain MAC configuration mode.
maximum (VPLS), on page 161	Configures the specified action when the number of MAC addresses learned on a bridge is reached.
notification (VPLS), on page 169	Specifies the type of notification that is sent when the number of learned MAC addresses exceeds the configured limit.

mac (VPLS)

To enter L2VPN bridge group bridge domain MAC configuration mode, use the **mac** command in L2VPN bridge group bridge domain configuration mode. To disable all configurations added under the MAC configuration submodes, use the **no** form of this command.

mac

no mac

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes L2VPN bridge group bridge domain configuration

Command History	Release	Modification
	Release 3.7.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **mac** command to enter L2VPN bridge group bridge domain MAC configuration mode.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples The following example shows how to enter L2VPN bridge group bridge domain MAC configuration mode:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac)#
```

Related Commands

Command	Description
aging (VPLS), on page 141	Enters the MAC aging configuration submode to set the aging parameters such as time and type.
bridge-domain (VPLS), on page 143	Establishes a bridge domain and enters L2VPN bridge group bridge domain configuration mode.
bridge group (VPLS), on page 145	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
l2vpn, on page 53	Enters L2VPN configuration mode.
learning disable (VPLS), on page 155	Overrides the MAC learning configuration of a parent bridge or sets the MAC learning configuration of a bridge.
limit (VPLS), on page 157	Sets the MAC address limit for action, maximum, and notification and enters L2VPN bridge group bridge domain MAC limit configuration mode.
static-address (VPLS), on page 197	Adds static entries to the MAC address for filtering.
withdraw (VPLS), on page 207	Disables MAC address withdrawal for a specified bridge domain

maximum (VPLS)

To configure the specified action when the number of MAC addresses learned on a bridge is reached, use the **maximum** command in L2VPN bridge group bridge domain MAC limit configuration mode. To disable this feature, use the **no** form of this command.

maximum *value*

no maximum *value*

Syntax Description

<i>value</i>	Maximum number of learned MAC addresses. The range is from 5 to 512000.
--------------	---

Command Default

The default maximum value is 4000.

Command Modes

L2VPN bridge group bridge domain MAC limit configuration

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The action can either be flood, no flood, or shutdown. Depending on the configuration, a syslog, an SNMP trap notification, or both are issued.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows when the number of MAC address learned on the bridge reaches 5000 and the bridge stops learning but continues flooding:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac)# limit
```

```
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac-limit)# maximum 5000
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac-limit)# action no-flood
```

Related Commands

Command	Description
action (VPLS), on page 139	Configures bridge behavior when the number of learned MAC addresses reaches the MAC limit configured.
bridge-domain (VPLS), on page 143	Establishes a bridge domain and enters L2VPN bridge group bridge domain configuration mode.
bridge group (VPLS), on page 145	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
l2vpn, on page 53	Enters L2VPN configuration mode.
limit (VPLS), on page 157	Sets the MAC address limit for action, maximum, and notification and enters L2VPN bridge group bridge domain MAC limit configuration mode.
mac (VPLS), on page 159	Enters L2VPN bridge group bridge domain MAC configuration mode.
notification (VPLS), on page 169	Specifies the type of notification that is sent when the number of learned MAC addresses exceeds the configured limit.

mpls static label (VPLS)

To configure the MPLS static labels and the static labels for the access pseudowire configuration, use the **mpls static label** command in L2VPN bridge group bridge domain VFI pseudowire configuration mode. To assign the dynamic MPLS labels to either the virtual forwarding interface (VFI) pseudowire or the access pseudowire, use the **no** form of this command.

mpls static label *local value value remote value*

no mpls static label *local value value remote value*

Syntax Description

local <i>value</i>	Configures the local pseudowire label.
Note	Use the show mpls label range command to obtain the range for the local labels.
remote <i>value</i>	Configures the remote pseudowire label.
Note	The range of values for the remote labels depends on the label allocator of the remote router.

Command Default

By default, the router attempts to assign dynamic labels to the pseudowire.

Command Modes

L2VPN bridge group bridge domain Access/VFI pseudowire configuration

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Ensure that both ends of the pseudowire have matching static labels.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to configure the VFI pseudowire 10.1.1.2 with pseudowire ID of 1000 to use MPLS label 800 and remote MPLS label 500:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# vfi model
RP/0/0/CPU0:router(config-l2vpn-bg-bd-vfi)# neighbor 10.1.1.2 pw-id 1000
RP/0/0/CPU0:router(config-l2vpn-bg-bd-vfi-pw)# mpls static label local 800 remote 500
```

Related Commands

Command	Description
bridge-domain (VPLS), on page 143	Establishes a bridge domain and enters L2VPN bridge group bridge domain configuration mode.
bridge group (VPLS), on page 145	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
l2vpn, on page 53	Enters L2VPN configuration mode.
neighbor (VPLS), on page 167	Adds an access pseudowire port to a bridge domain or a pseudowire to a bridge virtual forwarding interface (VFI).
pw-class (VFI), on page 173	Configures the pseudowire class template name to use for the pseudowire.
vfi (VPLS), on page 205	Configures virtual forwarding interface (VFI) parameters.

mtu (VPLS)

To adjust the maximum packet size or maximum transmission unit (MTU) size for the bridge domain, use the **mtu** command in L2VPN bridge group bridge domain configuration mode. To disable this feature, use the **no** form of this command.

mtu *bytes*

no mtu

Syntax Description

<i>bytes</i>	MTU size, in bytes. The range is from 46 to 65535.
--------------	--

Command Default

The default MTU value is 1500.

Command Modes

L2VPN bridge group bridge domain configuration

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Each interface has a default maximum packet size or MTU size. This number generally defaults to the largest size possible for that interface type. On serial interfaces, the MTU size varies, but cannot be set smaller than 64 bytes.

The MTU for the bridge domain includes only the payload of the packet. For example, a configured bridge MTU of 1500 allows tagged packets of 1518 bytes (6 bytes DA, 6 bytes SA, 2 bytes ethertype, or 4 bytes qtag).

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example specifies an MTU of 1000 bytes:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
```

```
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# mtu 1000
```

Related Commands

Command	Description
bridge-domain (VPLS), on page 143	Establishes a bridge domain and enters L2VPN bridge group bridge domain configuration mode.
bridge group (VPLS), on page 145	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
flooding disable, on page 149	Configures flooding for traffic at the bridge domain level or at the bridge port level.
l2vpn, on page 53	Enters L2VPN configuration mode.

neighbor (VPLS)

To add an access pseudowire port to a bridge domain or a pseudowire to a bridge virtual forwarding interface (VFI), use the **neighbor** command in the appropriate L2VPN bridge group bridge domain configuration submode. To remove the pseudowire either from the bridge or from the VFI, use the **no** form of this command.

neighbor *A.B.C.D* **pw-id** *value*

no neighbor *A.B.C.D* **pw-id** *value*

Syntax Description

<i>A.B.C.D</i>	IP address of the cross-connect peer.
pw-id <i>value</i>	Configures the pseudowire ID and ID value. Range is 1 to 4294967295.

Command Default

None

Command Modes

L2VPN bridge group bridge domain configuration
L2VPN bridge group bridge domain VFI configuration

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **neighbor** command to enter L2VPN bridge group bridge domain VFI pseudowire configuration mode. Alternatively, use the **neighbor** command to enter L2VPN bridge group bridge domain access pseudowire configuration mode.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to configure an access pseudowire directly under a bridge domain in L2VPN bridge group bridge domain configuration mode:

```
RP/0/0/CPU0:router# configure
```

```
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# neighbor 10.1.1.2 pw-id 1000
RP/0/0/CPU0:router(config-l2vpn-bg-bd-pw)#
```

The following example shows how to configure the parameters for any pseudowire in L2VPN bridge group bridge domain VFI configuration mode:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# vfi vl
RP/0/0/CPU0:router(config-l2vpn-bg-bd-vfi)# neighbor 10.1.1.2 pw-id 1000
RP/0/0/CPU0:router(config-l2vpn-bg-bd-vfi-pw)#
```

Related Commands

Command	Description
bridge-domain (VPLS), on page 143	Establishes a bridge domain and enters L2VPN bridge group bridge domain configuration mode.
bridge group (VPLS), on page 145	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
l2vpn, on page 53	Enters L2VPN configuration mode.
mpls static label (VPLS), on page 163	Configures the MPLS static labels and the static labels for the access pseudowire configuration.
pw-class (VFI), on page 173	Configures the pseudowire class template name to use for the pseudowire.
static-mac-address (VPLS), on page 199	Configures the static MAC address to associate a remote MAC address with a pseudowire or any other bridge interface.
vfi (VPLS), on page 205	Configures virtual forwarding interface (VFI) parameters.

notification (VPLS)

To specify the type of notification that is sent when the number of learned MAC addresses exceeds the configured limit, use the **notification** command in L2VPN bridge group bridge domain MAC limit configuration mode. To use the notification as only a syslog entry, use the **no** form of this command.

notification {both| none| trap}

no notification {both| none| trap}

Syntax Description

both	Sends syslog and trap notifications when the action is violated.
none	Specifies no notification.
trap	Sends trap notifications when the action is violated.

Command Default

By default, only a syslog message is sent when the number of learned MAC addresses reaches the maximum configured.

Command Modes

L2VPN bridge group bridge domain MAC limit configuration

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

A syslog message and an SNMP trap is generated. Alternatively, an SNMP trap is generated. Finally, no notification is generated.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how both a syslog message and an SNMP trap are generated with the bridge bar and learns more MAC addresses than the configured limit:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac)# limit
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac-limit)# notification both
```

Related Commands

Command	Description
action (VPLS) , on page 139	Configures bridge behavior when the number of learned MAC addresses reaches the MAC limit configured.
bridge-domain (VPLS) , on page 143	Establishes a bridge domain and enters L2VPN bridge group bridge domain configuration mode.
bridge group (VPLS) , on page 145	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
l2vpn , on page 53	Enters L2VPN configuration mode.
mac (VPLS) , on page 159	Enters L2VPN bridge group bridge domain MAC configuration mode.
maximum (VPLS) , on page 161	Configures the specified action when the number of MAC addresses learned on a bridge is reached.

port-down flush disable (VPLS)

To disable MAC flush when the bridge port is nonfunctional, use the **port-down flush disable** command in the L2VPN bridge group bridge domain MAC configuration mode. Use the **no** form of this command to enable the MAC flush when the bridge port is nonfunctional.

port-down flush disable

no port-down flush disable

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes L2VPN bridge group bridge domain MAC configuration

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **port-down flush disable** command disables the MAC flush when the bridge port is nonfunctional.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples The following example shows how to disable MAC flush when the bridge port is nonfunctional:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac)# port-down flush disable
```

Related Commands

Command	Description
action (VPLS), on page 139	Configures bridge behavior when the number of learned MAC addresses reaches the MAC limit configured.
bridge-domain (VPLS), on page 143	Establishes a bridge domain and enters L2VPN bridge group bridge domain configuration mode.
bridge group (VPLS), on page 145	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
l2vpn, on page 53	Enters L2VPN configuration mode.
mac (VPLS), on page 159	Enters L2VPN bridge group bridge domain MAC configuration mode.
maximum (VPLS), on page 161	Configures the specified action when the number of MAC addresses learned on a bridge is reached.
notification (VPLS), on page 169	Specifies the type of notification that is sent when the number of learned MAC addresses exceeds the configured limit.

pw-class (VFI)

To configure the pseudowire class template name to use for the pseudowire, use the **pw-class** command in L2VPN bridge group bridge domain VFI pseudowire configuration mode. To delete the pseudowire class, use the **no** form of this command.

pw-class *class-name*

no pw-class *class-name*

Syntax Description

<i>class-name</i>	Pseudowire class name.
-------------------	------------------------

Command Default

None

Command Modes

L2VPN bridge group bridge domain VFI pseudowire configuration

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to attach the pseudowire class to the pseudowire:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# vfi v1
RP/0/0/CPU0:router(config-l2vpn-bg-bd-vfi)# neighbor 10.1.1.2 pw-id 1000
RP/0/0/CPU0:router(config-l2vpn-bg-bd-vfi-pw)# pw-class canada
```

Related Commands

Command	Description
bridge-domain (VPLS), on page 143	Establishes a bridge domain and enters L2VPN bridge group bridge domain configuration mode.
bridge group (VPLS), on page 145	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
l2vpn, on page 53	Enters L2VPN configuration mode.
mpls static label (VPLS), on page 163	Configures the MPLS static labels and the static labels for the access pseudowire configuration.
neighbor (VPLS), on page 167	Adds an access pseudowire port to a bridge domain or a pseudowire to a bridge virtual forwarding interface (VFI).
vfi (VPLS), on page 205	Configures virtual forwarding interface (VFI) parameters.

pw-status (L2VPN)

To enable status signaling on a pseudowire, use the **pw-status** command in L2VPN configuration submode. To disable the pseudowire status signaling, use the **no** form of this command.

pw-status

no pw-status

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes L2VPN configuration submode

Command History	Release	Modification
	Release 4.1.1	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Cisco IOS XR software provides two methods for signaling pseudowires (PW) status:

- Using Label Withdraw Message
The provider edge routers (PEs) send Label Mapping Message to their peers as soon as the pseudowire is configured and administratively enabled. The pseudowire label should not be withdrawn unless the pseudowire is administratively disabled or deleted.
- Using PW status TLV
The PEs use LDP pseudowire status TLV to indicate pseudowire status to their peers. The LDP pseudowire status TLV contains additional information compared to the Label Withdraw Message.



Note Unless pseudowire status TLV is explicitly enabled under L2VPN configuration, the default signaling method is Label Withdrawal.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows how to enable pseudowire status signaling on configured pseudowires:

```
RP/0/0/CPU0:router# configure  
RP/0/0/CPU0:router(config)# l2vpn  
RP/0/0/CPU0:router(config-l2vpn)# pw-status  
RP/0/0/CPU0:router(config-l2vpn)#
```

Related Commands

Command	Description
l2vpn , on page 53	Enters L2VPN configuration mode.

show l2vpn bridge-domain (VPLS)

To display information for the bridge ports such as attachment circuits and pseudowires for the specific bridge domains, use the **show l2vpn bridge-domain** command in EXEC mode.

show l2vpn bridge-domain [**bd-name** *bridge-domain-name*| **brief**| **detail**| **group** *bridge-domain-group-name*| **interface** *type* *interface-path-id*]**neighbor** *IP-address* [**pw-id** *value*| **summary**]

Syntax Description

bd-name <i>bridge-domain-name</i>	(Optional) Displays the bridges by the bridge ID. The <i>bridge-domain-name</i> argument is used to name a bridge domain.
brief	(Optional) Displays brief information about the bridges.
detail	(Optional) Displays the output for the Layer 2 VPN (L2VPN) to indicate whether or not the MAC withdrawal feature is enabled and the number of MAC withdrawal messages that are sent or received from the pseudowire.
group <i>bridge-domain-group-name</i>	(Optional) Displays filter information on the bridge-domain group name. The <i>bridge-domain-group-name</i> argument is used to name the bridge domain group.
interface	(Optional) Displays the filter information for the interface on the bridge domain.
<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface. Note Use the show interfaces command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
neighbor <i>IP-address</i>	(Optional) Displays only the bridge domain that contains the pseudowires to match the filter for the neighbor. The <i>IP-address</i> argument is used to configure IP address of the neighbor.
pw-id <i>value</i>	(Optional) Displays the filter for the pseudowire ID. The range is from 1 to 4294967295.
summary	(Optional) Displays the summary information for the bridge domain.

Command Default

None

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **interface** keyword to display only the bridge domain that contains the specified interface as an attachment circuit. In the sample output, only the attachment circuit matches the filter that is displayed. No pseudowires are displayed.

Task ID

Task ID	Operations
l2vpn	read

Examples

This table describes the significant fields shown in the display.

The following sample output shows information for the bridge ports such as attachment circuits and pseudowires for the specific bridge domains:

```
RP/0/0/CPU0:router# show l2vpn bridge-domain
```

```
Bridge group: g1, bridge-domain: bd1, id: 0, state: up, ShgId: 0, MSTi: 0
Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
Filter MAC addresses: 0
ACs: 1 (1 up), VFIs: 1, PWs: 1 (1 up)
List of ACs:
  Gi0/1/0/0, state: up, Static MAC addresses: 2, MSTi: 0 (unprotected)
List of Access PWs:
List of VFIs:
  VFI 1
    Neighbor 10.1.1.1 pw-id 1, state: up, Static MAC addresses: 0
```

This table describes the significant fields shown in the display.

Table 9: show l2vpn bridge-domain Command Field Descriptions

Field	Description
Bridge group	Name of bridge domain group is displayed.
bridge-domain	Name of bridge domain is displayed.
id	ID assigned to this bridge domain is displayed.
state	Current state of the bridge domain is displayed.

The following example shows sample output for a bridge named bd1:

```
RP/0/0/CPU0:router# show l2vpn bridge-domain bd-name bd1

Bridge group: g1, bridge-domain: bd1, id: 0, state: up, ShgId: 0, MSTi: 0
Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
Filter MAC addresses: 0
ACs: 1 (1 up), VFIs: 1, PWs: 1 (1 up)
List of ACs:
  Gi0/1/0/0, state: up, Static MAC addresses: 2, MSTi: 0 (unprotected)
List of Access PWs:
List of VFIs:
  VFI 1
    Neighbor 10.1.1.1 pw-id 1, state: up, Static MAC addresses: 0
```

The following sample output shows brief information about the bridges:

```
RP/0/0/CPU0:router# show l2vpn bridge-domain brief

Bridge Group/Bridge-Domain Name  ID      State      Num ACs/up  Num PWs/up
-----
g1/bd1                          0       up         1/1         1/1
```

This table describes the significant fields shown in the display.

Table 10: show l2vpn bridge-domain brief Command Field Descriptions

Field	Description
Bridge Group/Bridge-Domain Name	Bridge domain group name followed by the bridge domain name are displayed.
ID	ID assigned to this bridge domain is displayed.
State	Current state of the bridge domain is displayed.
Num ACs/up	Total number of attachment circuits that are up in this bridge domain is displayed.
Num PWs/up	Total number of pseudowires that are up in this bridge domain is displayed. The count includes both VFI pseudowires and access pseudowires.

The following sample output shows detailed information:

```
RP/0/0/CPU0:router# show l2vpn bridge-domain detail

Bridge group: g1, bridge-domain: bd1, id: 0, state: up, ShgId: 0, MSTi: 0
MAC learning: enabled
MAC withdraw: disabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: yes
Security: disabled
DHCPv4 snooping: disabled
MTU: 1500
Filter MAC addresses:
ACs: 1 (1 up), VFIs: 1, PWs: 1 (1 up)
List of ACs:
```

show l2vpn bridge-domain (VPLS)

```

AC: GigabitEthernet0/1/0/0, state is up
Type Ethernet
MTU 1500; XC ID 0x2000001; interworking none; MSTi 0 (unprotected)
MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: yes
Security: disabled
DHCPv4 snooping: disabled
Static MAC addresses:
  0000.0000.0000
  0001.0002.0003
Statistics:
  packet totals: receive 3919680, send 9328
  byte totals: receive 305735040, send 15022146
List of Access PWs:
List of VFIs:
  VFI 1
    PW: neighbor 1.1.1.1, PW ID 1, state is up ( established )
    PW class mpls, XC ID 0xff000001
    Encapsulation MPLS, protocol LDP
    PW type Ethernet, control word disabled, interworking none
    PW backup disable delay 0 sec
    Sequencing not set
      MPLS          Local          Remote
      -----
      Label         16003          16003
      Group ID      0x0            0x0
      Interface     1              1
      MTU           1500           1500
      Control word   disabled        disabled
      PW type       Ethernet       Ethernet
      VCCV CV type  0x2            0x2
                   (LSP ping verification)
                   (LSP ping verification)
      VCCV CC type  0x2            0x2
                   (router alert label)
                   (router alert label)
      -----
    Create time: 12/03/2008 14:03:00 (17:17:30 ago)
    Last time status changed: 13/03/2008 05:57:58 (01:22:31 ago)
    MAC withdraw message: send 0 receive 0
    Static MAC addresses:
    Statistics:
      packet totals: receive 3918814, send 3918024
      byte totals: receive 305667492, send 321277968
  VFI Statistics:
    drops: illegal VLAN 0, illegal length 0

```

The following sample output shows that when a bridge operates in VPWS mode, the irrelevant information for MAC learning is suppressed:

```

RP/0/0/CPU0:router# show l2vpn bridge-domain detail

Bridge group: foo_group, bridge-domain: foo_bd, id: 0, state: up, ShgId: 0
VPWS Mode
MTU: 1500
ACs: 1 (0 up), VFIs: 1, PWs: 2 (2 up)
List of ACs:
  AC: GigabitEthernet0/5/1/4, state is admin down
  Type Ethernet      MTU 1500; XC ID 1; interworking none
  Static MAC addresses:
  Statistics:
    packet totals: receive 0, send 0
    byte totals: receive 0, send 0
List of VFIs:
  VFI foo_vfi
    PW: neighbor 1.1.1.1, PW ID 1, state is up ( established )
    PW class not set
    Encapsulation MPLS, protocol LDP
    PW type Ethernet, control word enabled, interworking none

```

```

Sequencing not set
MPLS          Local                               Remote
-----
Label          16001                               16001
Group ID       unassigned                           unknown
Interface      siva/vfi                             siva/vfi
MTU            1500                               1500
Control word   enabled                               enabled
PW type        Ethernet                         Ethernet
VCCV CV type   0x2                               0x2
                (LSP ping verification)         (LSP ping verification)
VCCV CC type   0x3                               0x3
                (control word)                     (control word)
                (router alert label)                 (router alert label)
-----
Create time: 25/06/2007 05:29:42 (2w0d ago)
Last time status changed: 27/06/2007 06:50:35 (1w5d ago)
Static MAC addresses:
PW: neighbor 1.1.1.1, PW ID 2, state is up ( established )
PW class not set
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word enabled, interworking none
Sequencing not set
MPLS          Local                               Remote
-----
Label          16002                               16002
Group ID       unassigned                           unknown
Interface      siva/vfi                             siva/vfi
MTU            1500                               1500
Control word   enabled                               enabled
PW type        Ethernet                         Ethernet
VCCV CV type   0x2                               0x2
                (LSP ping verification)         (LSP ping verification)
VCCV CC type   0x3                               0x3
                (control word)                     (control word)
                (router alert label)                 (router alert label)
-----
Create time: 25/06/2007 05:29:42 (2w0d ago)
Last time status changed: 27/06/2007 06:50:35 (1w5d ago)
Static MAC addresses:
Statistics:
drops: illegal VLAN 0, illegal length 0

```

This table describes the significant fields shown in the display.

Table 11: show l2vpn bridge-domain detail Command Field Descriptions

Field	Description
Bridge group	Name of bridge domain group is displayed.
bridge-domain	Name of bridge domain is displayed.
ID	ID assigned to this bridge domain is displayed.
state	Current state of the bridge domain is displayed.
MSTi	ID for the Multiple Spanning Tree.

The following sample output shows filter information about the bridge-domain group named g1:

```

RP/0/0/CPU0:router# show l2vpn bridge-domain group g1
Bridge group: g1, bridge-domain: bd1, id: 0, state: up, ShgId: 0, MSTi: 0

```

show l2vpn bridge-domain (VPLS)

```

Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
Filter MAC addresses: 0
ACs: 1 (1 up), VFIs: 1, PWs: 1 (1 up)
List of ACs:
  Gi0/1/0/0, state: up, Static MAC addresses: 2, MSTi: 0 (unprotected)
List of Access PWs:
List of VFIs:
  VFI 1
    Neighbor 1.1.1.1 pw-id 1, state: up, Static MAC addresses: 0

```

The following sample output shows display the filter information for the interface on the bridge domain:

```
RP/0/0/CPU0:router# show l2vpn bridge-domain interface gigabitEthernet 0/1/0/0
```

```

Bridge group: g1, bridge-domain: bdl, id: 0, state: up, ShgId: 0, MSTi: 0
Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
Filter MAC addresses: 0
ACs: 1 (1 up), VFIs: 1, PWs: 1 (1 up)
List of ACs:
  Gi0/1/0/0, state: up, Static MAC addresses: 2, MSTi: 0 (unprotected)

```

The following sample output shows that the bridge domain contains the pseudowires to match the filter for the neighbor:

```
RP/0/0/CPU0:router# show l2vpn bridge-domain neighbor 1.1.1.1
```

```

Bridge group: g1, bridge-domain: bdl, id: 0, state: up, ShgId: 0, MSTi: 0
Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
Filter MAC addresses: 0
ACs: 1 (1 up), VFIs: 1, PWs: 1 (1 up)
List of Access PWs:
List of VFIs:
  VFI 1
    Neighbor 1.1.1.1 pw-id 1, state: up, Static MAC addresses: 0

```

The following sample output shows the summary information for the bridge domain:

```
RP/0/0/CPU0:router# show l2vpn bridge-domain summary
```

```

Number of groups: 1, bridge-domains: 1, Up: 1, Shutdown: 0
Number of ACs: 1 Up: 1, Down: 0
Number of PWs: 1 Up: 1, Down: 0

```

This table describes the significant fields shown in the display.

Table 12: show l2vpn bridge-domain summary Command Field Descriptions

Field	Description
Number of groups	Number of configured bridge domain groups is displayed.
bridge-domains	Number of configured bridge domains is displayed.
Shutdown	Number of bridge domains that are in Shutdown state is displayed.
Number of ACs	Number of attachment circuits that are in Up state and Down state are displayed.
Number of PWs	Number of pseudowires that are in Up state and Down state are displayed. This includes the VFI pseudowire and the access pseudowire.

Related Commands

Command	Description
clear l2vpn bridge-domain (VPLS), on page 147	Clears the MAC addresses and restarts the bridge domains on the router.

show l2vpn forwarding bridge-domain (VPLS)

To display information on the bridge that is used by the forwarding layer, use the **show l2vpn forwarding bridge-domain** command in EXEC mode.

show l2vpn forwarding bridge-domain [*bridge-domain-name*] {**detail**|**hardware** {**egress**|**ingress**}}
location *node-id*

Syntax Description

<i>bridge-domain-name</i>	(Optional) Name of a bridge domain.
detail	Displays all the detailed information on the attachment circuits and pseudowires.
hardware	Displays the hardware location entry.
egress	Reads information from the egress PSE.
ingress	Reads information from the ingress PSE.
location <i>node-id</i>	Displays the bridge-domain information for the specified location. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

Command Default

None

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

For each bridge, you can display summary information about the number of bridge ports, number of MAC addresses, and so forth.

The **detail** keyword displays detailed information on the attachment circuits and pseudowires, and is meant for field investigation by a specialized Cisco engineer.

**Note**

All bridge ports in the bridge domain on that line card are displayed. Therefore, if the bridge domain contains non-local bridge ports, those are displayed as well.

Task ID

Task ID	Operations
l2vpn	read

Examples

The following sample output shows bridge-domain information for location 0/1/CPU0:

```
RP/0/0/CPU0:router# show l2vpn forwarding bridge-domain location 0/1/CPU0
```

```
Bridge-Domain Name          ID      Ports addr  Flooding Learning State
-----
g1:bd1

Bridge-domain name: g1:bd1, id: 0, state: up
MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: yes
Security: disabled
DHCPv4 snooping: profile not known on this node
Bridge MTU: 1500 bytes
Number of bridge ports: 2
Number of MAC addresses: 65536
Multi-spanning tree instance: 0

GigabitEthernet0/1/0/0, state: oper up
Number of MAC: 32770
Sent(Packets/Bytes): 0/21838568
Received(Packets/Bytes): 5704781/444972918

Nbor 1.1.1.1 pw-id 1
Number of MAC: 32766
Sent(Packets/Bytes): 0/0
Received(Packets/Bytes): 5703987/444910986
0      2      65536 Enabled Enabled UP
```

The following sample output shows detailed information for hardware location 0/1/CPU0 from the egress pse:

```
RP/0/0/CPU0:router
```

```
Bridge-domain name: g1:bd1, id: 0, state: up
MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: yes
Security: disabled
DHCPv4 snooping: profile not known on this node
Bridge MTU: 1500 bytes
Number of bridge ports: 2
Number of MAC addresses: 65536
Multi-spanning tree instance: 0
```

show l2vpn forwarding bridge-domain (VPLS)

```

===== GSR HW Information =====

-----
SHG-TX rewrite details
-----
HW Rewrite 0 Detail :
-----
Rewrite HW Address : 0x00060000
packets 0 bytes 0
Raw data:
[ 0x04018180 04018190 040181a0 040181b0 ]
[ 0x04018170 00000000 80360000 000bfff4 ]
[ 0x00000000 00000000 00000000 00000000 ]

-----
SHG-TX encap details
-----
outer_etype:          0
outer_vlan_id:        0
gather_profile:       0
inner_vlan_id:        0
so_l2_len_adjust:    0

-----
SHG-TX mgid details
-----
Base MGIDs for default mgid
base_mgid[0]:         0x0003ffff
base_mgid[1]:         0x0003ffff
base_mgid[2]:         0x0003ffff
base_mgid[3]:         0x0003ffff
base_mgid[4]:         0x0003ffff
base_mgid[5]:         0x0003ffff
base_mgid[6]:         0x0003ffff
base_mgid[7]:         0x0003ffff
MGID Entries for default mgid
oi[0]:                0
oq[0]:                16384
xc_id[0]:              1
mgid_idx[0]:           0x00000000
next_mgid[0]:          0x00000000

-----
VMR 0 Details
-----
vmrid: 0x5f002010
Value: 0xc0 0x00 0x1f 0xff 0xff 0xff 0xff 0xff 0xff 0xfd
Mask : 0x00 0x00 0x1f 0xff 0xff 0xff 0xff 0xff 0xff 0xe0
Result 0x32003000

=====

GigabitEthernet0/1/0/0, state: oper up
Number of MAC: 32770
Sent(Packets/Bytes): 749/22989834
Received(Packets/Bytes): 5732104/447104112

===== GSR HW Information =====

-----
BP-TX-AC rewrite details
-----

BP is local

-----
BP L2 Uidb Details
-----
l2fwd_enabled:        true
plim_enabled:         true
l2fwd_type:           4
l2_ac_type:           0
xconn_id:             0

```

```

bridge_id:                                0
shg id:                                   0
unicast flooding enabled:                  0
multicast flooding enabled:                0
broadcast flooding enabled:                0
mac learning enabled:                      0
Is AC Port mode?:                          0
-----
HW Rewrite 0 Detail :
-----
Rewrite HW Address : 0x59eff314
packets 0 bytes 0
HFA Bits 0x0 gp 0 mtu 1580 (REW)
OI 0x3fffc OutputQ 0 Output-port 0x36 local_outputq 0x0
Raw data:
[ 0x00000000 0036062c 0003fffc 00000000 ]
[ 0x00000000 00000000 0d103600 00000010 ]
[ 0x00000000 00000000 00000000 00000000 ]
-----
BP OI/OQ Details
-----
oi[0]:      0x00000000      oq[0]      16384
oi[1]:      0x00000000      oq[1]      65535
oi[2]:      0x00000000      oq[2]      65535
oi[3]:      0x00000000      oq[3]      65535
oi[4]:      0x00000000      oq[4]      65535
oi[5]:      0x00000000      oq[5]      65535
oi[6]:      0x00000000      oq[6]      65535
oi[7]:      0x00000000      oq[7]      65535
-----
Sram table entry details
-----
sram_data: 0xa000400c
=====

Nbor 1.1.1.1 pw-id 1
Number of MAC: 32766
Sent(Packets/Bytes): 0/0
Received(Packets/Bytes): 5731250/447037500

===== GSR HW Information =====

-----
BP-TX-AC rewrite details
-----
BP OI/OQ Details
-----
oi[0]:      0x00000000      oq[0]      65535
oi[1]:      0x00000000      oq[1]      65535
oi[2]:      0x00000000      oq[2]      65535
oi[3]:      0x00000000      oq[3]      65535
oi[4]:      0x00000000      oq[4]      65535
oi[5]:      0x00000000      oq[5]      65535
oi[6]:      0x00000000      oq[6]      65535
oi[7]:      0x00000000      oq[7]      65535
-----
BP Encap Info
-----
mac_length: 0
mac_string:
egress_slot: 2
num_tags: 1
tags: {16001, }
if_handle: 0x03000500
=====

```

The following sample output shows the bridge-domain information for the specified location:

```
RP/0/0/CPU0:router# show l2vpn forwarding bridge-domain g1:bd1 location 0/1/CPU0
```

```
Bridge-Domain Name      ID      Ports addr      Flooding Learning State
```

```
-----
gl:bd1                                0      2      65536  Enabled  Enabled  UP
-----
```

This table describes the significant fields shown in the display.

Table 13: show l2vpn forwarding bridge-domain Command Field Descriptions

Field	Description
Bridge-Domain Name	Name of bridge domain is displayed.
Bridge ID	ID assigned to this bridge domain is displayed.
Ports	Number of ports that are part of this bridge domain is displayed.
MAC Addr	Number of MAC addresses that are learned on this bridge domain is displayed.
Flooding	Flooding of packets are displayed if they are enabled on this bridge domain.
Learning	Learning of MAC addresses are displayed if they are enabled on this bridge domain.
State	Current state of the bridge domain is displayed.

Related Commands

Command	Description
clear l2vpn bridge-domain (VPLS) , on page 147	Clears the MAC addresses and restarts the bridge domains on the router.

show l2vpn forwarding bridge-domain mac-address (VPLS)

To display the summary information for the MAC address, use the **show l2vpn forwarding bridge-domain mac-address** command in EXEC mode.

show l2vpn forwarding bridge-domain [*bridge-domain-name*] **mac-address** {*MAC-address*} **detail** | **hardware** {*egress* | *ingress*} | **interface** *type interface-path-id* | **neighbor** *address* **pw-id** *pw-id* | **location** *node-id*

Syntax Description

<i>bridge-domain-name</i>	(Optional) Name of a bridge domain.
<i>MAC-address</i>	MAC address.
detail	Displays detailed information for the MAC address.
hardware	Reads information from the hardware.
egress	Reads information from the egress PSE.
ingress	Reads information from the ingress PSE.
interface	Displays the match for the attachment circuit subinterface.
<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface. Note Use the show interfaces command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
neighbor <i>address</i>	Displays the match for the neighbor IP address.
pw-id <i>pw-id</i>	Displays the match for the pseudowire ID.
location <i>node-id</i>	Displays the bridge-domain information for the MAC address of the specified location. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

Command Default

None

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.0	This command was introduced.
Release 3.7.2	This command was introduced.
Release 3.8.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read

Examples

The following sample output shows the specified location of the bridge-domain name g1:bd1 for the MAC address:

```
RP/0/0/CPU0:router# show l2vpn forwarding bridge-domain g1:bd1 location 0/1/CPU0
```

Bridge-Domain Name	Bridge ID	Ports	MAC addr	Flooding	Learning	State
g1:bd1	0	2	65536	Enabled	Enabled	UP

The following sample output shows the list of MAC addresses that are learned on a specified bridge and summary information for the addresses:

```
RP/0/0/CPU0:router# show l2vpn forwarding bridge-domain mac-address location 0/1/CPU0
```

Mac Address	Type	Learned from/Filtered on	LC learned	Age
0000.0000.0000	static	Gi0/1/0/0	N/A	N/A
0000.0001.0101	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.0102	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.0103	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.0104	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.0105	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.0106	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.0107	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.0108	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.0109	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.010a	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.010b	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.010c	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.010d	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.010e	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.010f	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.0110	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.0111	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.0112	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
....				

The following sample output shows the MAC address on a specified interface on a specified bridge:

```
RP/0/0/CPU0:router# show l2vpn forwarding bridge-domain g1:bd1 mac-address 1.2.3 location 0/1/CPU0
```

Mac Address	Type	Learned from/Filtered on	LC learned	Age
0001.0002.0003	static	Gi0/1/0/0	N/A	N/A

The following sample output shows the hardware information from the egress pse:

```
RP/0/0/CPU0:router# show l2vpn forwarding bridge-domain g1:bd1 mac-address hardware egress location 0/1/CPU0
```

Mac Address	Type	Learned from/Filtered on	LC learned	Age
0000.0000.0000	static	Gi0/1/0/0	N/A	N/A
0000.0001.0101	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0102	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0103	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0104	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0105	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0106	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0107	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0108	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0109	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.010a	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.010b	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.010c	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.010d	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.010e	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.010f	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0110	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0111	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0112	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0113	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0114	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
...				

The following sample output shows the MAC addresses that are learned on a specified pseudowire on a specified bridge:

```
RP/0/0/CPU0:router# show l2vpn forwarding bridge-domain mac-address neighbor 1.1.1.1 pw-id 1 location 0/1/CPU0
```

Mac Address	Type	Learned from/Filtered on	LC learned	Age
0000.0003.0101	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0102	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0103	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0104	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0105	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0106	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0107	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0108	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0109	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.010a	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.010b	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.010c	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.010d	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.010e	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.010f	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0110	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0111	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0112	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0113	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0114	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0115	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
...				

show l2vpn forwarding bridge-domain mac-address (VPLS)

The following sample output shows the detailed information for MAC addresses that are learned on a specified interface and on specified bridge of a specified interface card. The sample output lists all the MAC addresses, the learned location, and the current age.

```
RP/0/0/CPU0:router# show l2vpn forwarding bridge-domain g1:bd1 mac-address interface
gigabitEthernet 0/1/0/0 location 0/1/CPU0
```

Mac Address	Type	Learned from/Filtered on	LC learned	Age
0000.0000.0000	static	Gi0/1/0/0	N/A	N/A
0000.0001.0101	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0102	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0103	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0104	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0105	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0106	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0107	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0108	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0109	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.010a	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.010b	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.010c	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.010d	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.010e	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.010f	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0110	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0111	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0112	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0113	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0114	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s

Related Commands

Command	Description
show l2vpn forwarding bridge-domain (VPLS) , on page 184	Displays information on the bridge that is used by the forwarding layer.

shutdown (Bridge Domain)

To shut down a bridge domain to bring the bridge and all attachment circuits and pseudowires under it to admin down state, use the **shutdown** command in L2VPN bridge group bridge domain configuration mode. To re-enable the bridge domain, use the **no** form of this command.

shutdown

no shutdown

Syntax Description This command has no keywords or arguments.

Command Default By default, the bridge is not shutdown.

Command Modes L2VPN bridge group bridge domain configuration

Command History	Release	Modification
	Release 3.7.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

When a bridge domain is disabled, all VFI's associated with the bridge domain are disabled. You can still attach or detach members to or from the bridge domain as well as the VFI's associated with the bridge domain.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples The following example shows how to disable the bridge domain named bar:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# shutdown
```

Related Commands

Command	Description
bridge-domain (VPLS), on page 143	Establishes a bridge domain and enters L2VPN bridge group bridge domain configuration mode.
bridge group (VPLS), on page 145	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
l2vpn, on page 53	Enters L2VPN configuration mode.

shutdown (VFI)

To disable virtual forwarding interface (VFI), use the **shutdown** command in L2VPN bridge group bridge domain VFI configuration mode. To re-enable VFI, use the **no** form of this command.

shutdown

no shutdown

Syntax Description This command has no keywords or arguments.

Command Default By default, the VFI is not shutdown.

Command Modes L2VPN bridge group bridge domain VFI configuration

Command History	Release	Modification
	Release 3.7.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples The following example shows how to disable VFI:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# vfi v1
RP/0/0/CPU0:router(config-l2vpn-bg-bd-vfi)# shutdown
```

Related Commands	Command	Description
	bridge-domain (VPLS) , on page 143	Establishes a bridge domain and enters L2VPN bridge group bridge domain configuration mode.

Command	Description
bridge group (VPLS), on page 145	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
l2vpn, on page 53	Enters L2VPN configuration mode.
mpls static label (VPLS), on page 163	Configures the MPLS static labels and the static labels for the access pseudowire configuration.
neighbor (VPLS), on page 167	Adds an access pseudowire port to a bridge domain or a pseudowire to a bridge virtual forwarding interface (VFI).

static-address (VPLS)

To add static entries to the MAC address for filtering, use the **static-address** command in L2VPN bridge group bridge domain MAC configuration mode. To remove entries profiled by the combination of a specified entry information, use the **no** form of this command.

static-address *MAC-address* **drop**

no static-address *MAC-address* **drop**

Syntax Description

<i>MAC-address</i>	Static MAC address that is used to filter on the bridge domain.
drop	Drops all traffic that is going to the configured MAC address.

Command Default

No static MAC address is configured.

Command Modes

L2VPN bridge group bridge domain MAC configuration

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to add static MAC entries in L2VPN bridge group bridge domain MAC configuration mode. This entry causes all packets with destination MAC address 1.1.1 to be dropped.

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac)# static-address 1.1.1 drop
```

Related Commands

Command	Description
bridge-domain (VPLS), on page 143	Establishes a bridge domain and enters L2VPN bridge group bridge domain configuration mode.
bridge group (VPLS), on page 145	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
l2vpn, on page 53	Enters L2VPN configuration mode.
mac (VPLS), on page 159	Enters L2VPN bridge group bridge domain MAC configuration mode.

static-mac-address (VPLS)

To configure the static MAC address to associate a remote MAC address with a pseudowire or any other bridge interface, use the **static-mac-address** command in the appropriate L2VPN bridge group bridge domain configuration submode. To disable this feature, use the **no** form of this command.

static-mac-address *MAC-address*

no static-mac-address *MAC-address*

Syntax Description	<i>MAC-address</i> Static address to add to the MAC address.	
Command Default	None	
Command Modes	L2VPN bridge group bridge domain VFI pseudowire configuration L2VPN bridge group bridge domain attachment circuit configuration	
Command History	Release	Modification
	Release 3.7.0	This command was introduced.
Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.	
Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows how to associate a remote MAC address with a pseudowire:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# vfi model
RP/0/0/CPU0:router(config-l2vpn-bg-bd-vfi)# neighbor 10.1.1.2 pw-id 1000
RP/0/0/CPU0:router(config-l2vpn-bg-bd-vfi-pw)# static-mac-address 1.1.1
```

The following example shows how to associate a GigabitEthernet interface from a bridge domain to static MAC address 1.1.1:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# interface GigabitEthernet 0/1/0/0
RP/0/0/CPU0:router(config-l2vpn-bg-bd-ac)# static-mac-address 1.1.1
```

The following example shows how to associate an access pseudowire to static MAC address 2.2.2:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# neighbor 10.1.1.2 pw-id 2000
RP/0/0/CPU0:router(config-l2vpn-bg-bd-pw)# static-mac-address 2.2.2
```

Related Commands

Command	Description
bridge-domain (VPLS), on page 143	Establishes a bridge domain and enters L2VPN bridge group bridge domain configuration mode.
bridge group (VPLS), on page 145	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
l2vpn, on page 53	Enters L2VPN configuration mode.
mpls static label (VPLS), on page 163	Configures the MPLS static labels and the static labels for the access pseudowire configuration.
neighbor (VPLS), on page 167	Adds an access pseudowire port to a bridge domain or a pseudowire to a bridge virtual forwarding interface (VFI).
vfi (VPLS), on page 205	Configures virtual forwarding interface (VFI) parameters.

time (VPLS)

To configure the maximum aging time, use the **time** command in L2VPN bridge group bridge domain MAC aging configuration mode. To disable this feature, use the **no** form of this command.

time *seconds*

no time *seconds*

Syntax Description

<i>seconds</i>	MAC address table entry maximum age. The range is from 300 to 30000 seconds. Aging time is counted from the last time that the switch saw the MAC address. The default value is 300 seconds.
----------------	--

Command Default

seconds: 300

Command Modes

L2VPN bridge group bridge domain MAC aging configuration

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

If no packets are received from the MAC address for the duration of the maximum aging time, the dynamic MAC entry previously learned is removed from the forwarding table.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to increase the maximum aging time to 600 seconds. After 600 seconds of inactivity from a MAC address, the MAC address is removed from the forwarding table.

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# mac
```

```
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac)# aging
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac-aging)# time 600
```

Related Commands

Command	Description
aging (VPLS), on page 141	Enters the MAC aging configuration submode to set the aging parameters such as time and type.
bridge-domain (VPLS), on page 143	Establishes a bridge domain and enters L2VPN bridge group bridge domain configuration mode.
bridge group (VPLS), on page 145	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
l2vpn, on page 53	Enters L2VPN configuration mode.
mac (VPLS), on page 159	Enters L2VPN bridge group bridge domain MAC configuration mode.
type (VPLS), on page 203	Configures the type for MAC address aging.

type (VPLS)

To configure the type for MAC address aging, use the **type** command in L2VPN bridge group bridge domain MAC aging configuration mode. To disable this feature, use the **no** form of this command.

type {absolute| inactivity}

no type {absolute| inactivity}

Syntax Description

absolute	Configures the absolute aging type.
inactivity	Configures the inactivity aging type.

Command Default

By default, the inactivity type is configured.

Command Modes

L2VPN bridge group bridge domain MAC aging configuration

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

In general, the type is set to inactivity. With an inactivity type configuration, a MAC address is removed from the forwarding table after the MAC address is inactive for the configured aging time.

With an absolute type configuration, a MAC address is always removed from the forwarding table after the aging time has elapsed once it is initially learned.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to configure the MAC address aging type to absolute for every member of the bridge domain named bar:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
```

```

RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac)# aging
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac-aging)# type absolute

```

Related Commands

Command	Description
aging (VPLS), on page 141	Enters the MAC aging configuration submode to set the aging parameters such as time and type.
bridge-domain (VPLS), on page 143	Establishes a bridge domain and enters L2VPN bridge group bridge domain configuration mode.
bridge group (VPLS), on page 145	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
l2vpn, on page 53	Enters L2VPN configuration mode.
mac (VPLS), on page 159	Enters L2VPN bridge group bridge domain MAC configuration mode.
time (VPLS), on page 201	Configures the maximum aging time.

vfi (VPLS)

To configure virtual forwarding interface (VFI) parameters and to enter L2VPN bridge group bridge domain VFI configuration mode, use the **vfi** command in L2VPN bridge group bridge domain configuration mode. To remove all configurations that are made under the specified VFI, use the **no** form of this command.

vfi *vfi-name*

no vfi *vfi-name*

Syntax Description

<i>vfi-name</i>	Name of the specified virtual forwarding interface.
-----------------	---

Command Default

None

Command Modes

L2VPN bridge group bridge domain configuration

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **vfi** command to enter L2VPN bridge group bridge domain VFI configuration mode.

You cannot configure a pseudowire directly under a bridge domain. Therefore, a pseudowire must be configured under a VFI, which is configured under a bridge domain.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to create a VFI:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# vfi v1
RP/0/0/CPU0:router(config-l2vpn-bg-bd-vfi)#
```

Related Commands

Command	Description
bridge-domain (VPLS), on page 143	Establishes a bridge domain and enters L2VPN bridge group bridge domain configuration mode.
bridge group (VPLS), on page 145	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
l2vpn, on page 53	Enters L2VPN configuration mode.
mpls static label (VPLS), on page 163	Configures the MPLS static labels and the static labels for the access pseudowire configuration.
neighbor (VPLS), on page 167	Adds an access pseudowire port to a bridge domain or a pseudowire to a bridge virtual forwarding interface (VFI).

withdraw (VPLS)

To enable MAC address withdrawal for a specified bridge domain, use the **withdraw** command in L2VPN bridge group bridge domain MAC configuration mode. To disable this feature, use the **no** form of this command

withdraw { disable }

no withdraw { disable }

Syntax Description

disable	Disables MAC address withdrawal.
----------------	----------------------------------

Command Default

By default, MAC address withdrawal is enabled.

Command Modes

L2VPN bridge group bridge domain MAC configuration

Command History

Release	Modification
Release 3.7.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to enable disable MAC withdrawal:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac)# withdraw disable
```

The following example shows how to disable sending MAC withdrawal messages to access pseudowires:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
```

```
RP/0/0/CPU0:router(config-l2vpn-bg-bd) # mac
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac) # withdraw access-pw disable
```

Related Commands

Command	Description
bridge-domain (VPLS), on page 143	Establishes a bridge domain and enters L2VPN bridge group bridge domain configuration mode.
bridge group (VPLS), on page 145	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
l2vpn, on page 53	Enters L2VPN configuration mode.
mac (VPLS), on page 159	Enters L2VPN bridge group bridge domain MAC configuration mode.



INDEX

A

action (VPLS) command [139](#)
aging (VPLS) command [141](#)
authentication (L2TP) command [4](#)

B

backup (L2VPN) command [6](#)
backup disable (L2VPN) command [8](#)
bridge group (VPLS) command [145](#)
bridge-domain (VPLS) command [143](#)

C

clear l2tp counters control session command [10](#)
clear l2tp counters control tunnel command [12](#)
clear l2tp tunnel command [14](#)
clear l2vpn bridge-domain (VPLS) command [147](#)
clear l2vpn collaborators command [16](#)
clear l2vpn counters bridge mac-withdrawal command [19](#)
clear l2vpn counters l2tp command [17](#)
clear l2vpn forwarding counters command [20](#)
clear l2vpn forwarding mac-address-table command [21](#)
clear l2vpn forwarding message counters command [23](#)
clear l2vpn forwarding table command [24](#)

D

description (GLOBAL) command [25](#)
description (XCONNECT) command [26](#)
digest (L2TP) command [27](#)

F

flooding disable command [149](#)
flooding unknown-unicast disable (VPLS) command [151](#)

H

hello-interval (L2TP) command [29](#)
hidden (L2TP) command [31](#)
hostname (L2TP) command [33](#)

I

interface (p2p) command [35](#)
interface (VPLS) command [153](#)
interworking ethernet command [38](#)
interworking ipv4 command [37](#)

L

l2tp-class command [40](#)
l2tp-class configuration command [41](#)
l2transport cell-packing command [45](#)
l2transport command [43](#)
l2transport l2protocol command [47](#)
l2transport propagate command [49](#)
l2transport service-policy command [51](#)
l2vpn command [53](#)
l2vpn switchover command [55](#)
learning disable (VPLS) command [155](#)
limit (VPLS) command [157](#)
logging (l2vpn) command [57](#)

M

mac (VPLS) command [159](#)
maximum (VPLS) command [161](#)
mpls static label (L2VPN) command [59](#)
mpls static label (VPLS) command [163](#)
mtu (VPLS) command [165](#)

N

neighbor (L2VPN) command [61](#)
 neighbor (VPLS) command [167](#)
 notification (VPLS) command [169](#)

P

p2p command [73](#)
 password (L2TP) command [63](#)
 port-down flush disable (VPLS) command [171](#)
 pw-class (L2VPN) command [65](#)
 pw-class (VFI) command [173](#)
 pw-class encapsulation l2tpv3 command [67](#)
 pw-class encapsulation mpls command [69](#)
 pw-status (L2VPN) command [175](#)

R

receive-window (L2TP) command [75](#)
 retransmit (L2TP) command [77](#)
 rollover (L3VPN) command [79](#)

S

sequencing (L2VPN) command [81](#)
 show l2tp class command [83](#)
 show l2tp counters forwarding session command [85](#)
 show l2tp session command [87](#)
 show l2tp tunnel command [89](#)
 show l2vpn atom-db command [91](#)
 show l2vpn bridge-domain (VPLS) command [177](#)
 show l2vpn collaborators command [94](#)
 show l2vpn forwarding bridge-domain (VPLS) command [184](#)
 show l2vpn forwarding bridge-domain mac-address (VPLS) command [189](#)
 show l2vpn forwarding command [96](#)

show l2vpn forwarding l2tp command [101](#)
 show l2vpn generic-interface-list command [103](#)
 show l2vpn index command [105](#)
 show l2vpn pw-class command [107](#)
 show l2vpn pwhe command [109](#)
 show l2vpn resource command [111](#)
 show l2vpn xconnect command [112](#)
 show tunnel-template command [121](#)
 shutdown (Bridge Domain) command [193](#)
 shutdown (VFI) command [195](#)
 static-address (VPLS) command [197](#)
 static-mac-address (VPLS) command [199](#)
 switching-tlv (L2VPN) command [123](#)

T

tag-impose command [125](#)
 tag-rewrite command [127](#)
 time (VPLS) command [201](#)
 timeout setup (L2TP) command [129](#)
 transport mode (L2VPN) command [131](#)
 tunnel-template command [133](#)
 type (VPLS) command [203](#)

V

vfi (VPLS) command [205](#)

W

withdraw (VPLS) command [207](#)

X

xconnect group command [134](#)