



## CHAPTER 26

### **show ddns update interface through show ipv6 traffic Commands**

---

# show ddns update interface

To display the DDNS methods assigned to security appliance interfaces, use the **show ddns update interface** command in privileged EXEC mode.

**show ddns update interface** [*interface-name*]

## Syntax Description

*interface-name* (Optional) The name of a network interface.

## Defaults

Omitting the *interface-name* string displays the DDNS method assigned to each interface.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Privileged EXEC	•	—	•	•	—

## Command History

Release	Modification
7.2(1)	This command was introduced.

## Examples

The following example displays the DDNS method assigned to the inside interface:

```
hostname# show ddns update interface inside
Dynamic DNS Update on inside:
  Update Method Name      Update Destination
  ddns-2                  not available
hostname#
```

## Related Commands

Command	Description
<b>ddns (DDNS-update-method mode)</b>	Specifies a DDNS update method type for a created DDNS method.
<b>ddns update (interface config mode)</b>	Associates a security appliance interface with a DDNS update method or a DDNS update hostname.
<b>ddns update method (global config mode)</b>	Creates a method for dynamically updating DNS resource records.
<b>show ddns update method</b>	Displays the type and interval for each configured DDNS method. a DHCP server to perform DDNS updates.
<b>show running-config ddns</b>	Displays the type and interval of all configured DDNS methods in the running configuration.

# show ddns update method

To display the DDNS update methods in the running configuration, use the **show ddns update method** command in privileged EXEC mode.

**show ddns update method** [*method-name*]

<b>Syntax Description</b>	<i>method-name</i> (Optional) The name of a configured DDNS update method.
---------------------------	--

<b>Defaults</b>	Omitting the <i>method-name</i> string displays all configured DDNS update methods.
-----------------	---

<b>Command Modes</b>	The following table shows the modes in which you can enter the command:
----------------------	---

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Privileged EXEC	•	—	•	•	—

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	7.2(1)	This command was introduced.

<b>Examples</b>	The following example displays the DDNS method named ddns-2:
-----------------	--

```
hostname(config)# show ddns update method ddns-2
```

```
Dynamic DNS Update Method: ddns-2
  IETF standardized Dynamic DNS 'A' and 'PTR' records update
  Maximum update interval: 0 days 0 hours 10 minutes 0 seconds
hostname(config)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>ddns (DDNS-update-method mode)</b>	Specifies a DDNS update method type for a created DDNS method.
	<b>ddns update (interface config mode)</b>	Associates a security appliance interface with a Dynamic DNS (DDNS) update method or a DDNS update hostname.
	<b>ddns update method (global config mode)</b>	Creates a method for dynamically updating DNS resource records.
	<b>show ddns update interface</b>	Displays the interfaces associated with each configured DDNS method.
	<b>show running-config ddns</b>	Displays the type and interval of all configured DDNS methods in the running configuration.

# show debug

To show the current debugging configuration, use the **show debug** command.

**show debug** [*command* [*keywords*]]

## Syntax Description

*command* (Optional) Specifies the debug command whose current configuration you want to view. For each *command*, the syntax following *command* is identical to the syntax supported by the associated **debug** command. For example, valid *keywords* following **show debug aaa** are the same as the valid keywords for the **debug aaa** command. Thus, **show debug aaa** supports an **accounting** keyword, which allows you to specify that you want to see the debugging configuration for that portion of AAA debugging.

## Defaults

This command has no default settings.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Privileged EXEC	•	•	•	•	•

## Command History

Release	Modification
Preexisting	This command was preexisting.
8.0(2)	The <b>eigrp</b> keyword was added to the list of possible command values.

**Usage Guidelines**

The valid *command* values follow. For each *command*, the syntax following *command* is identical to the syntax supported by the associated **debug** command. Refer to the associated **debug** command for information about the supported syntax.

**Note**

The availability of each *command* value depends upon the command modes that support the applicable **debug** command.

- aaa
- appfw
- arp
- asdm
- context
- crypto
- ctiqbe
- ctm
- dhcpc
- dhcpd
- dhcprelay
- disk
- dns
- eigrp
- email
- entity
- fixup
- fover
- fsm
- ftp
- generic
- gtp
- h323
- http
- http-map
- icmp
- igmp
- ils
- imagemgr
- ipsec-over-tcp
- ipv6
- iua-proxy

- **kerberos**
- **ldap**
- **mfib**
- **mgcp**
- **mrib**
- **ntdomain**
- **ntp**
- **ospf**
- **parser**
- **pim**
- **pix**
- **pptp**
- **radius**
- **rip**
- **rtsp**
- **sdi**
- **sequence**
- **sip**
- **skinny**
- **smtp**
- **sqlnet**
- **ssh**
- **ssl**
- **sunrpc**
- **tacacs**
- **timestamps**
- **vpn-sessiondb**
- **webvpn**
- **xdmcp**
- **xml**

## Examples

The following commands enable debugging for authentication, accounting, and Flash memory. The **show debug** command is used in three ways to demonstrate how you can use it to view all debugging configuration, debugging configuration for a specific feature, and even debugging configuration for a subset of a feature.

```
hostname# debug aaa authentication
debug aaa authentication enabled at level 1
hostname# debug aaa accounting
debug aaa accounting enabled at level 1
hostname# debug disk filesystem
```

```
debug disk filesystem enabled at level 1
hostname# show debug
debug aaa authentication enabled at level 1
debug aaa accounting enabled at level 1
debug disk filesystem enabled at level 1
hostname# show debug aaa
debug aaa authentication enabled at level 1
debug aaa authorization is disabled.
debug aaa accounting enabled at level 1
debug aaa internal is disabled.
debug aaa vpn is disabled.
hostname# show debug aaa accounting
debug aaa accounting enabled at level 1
hostname#
```

### Related Commands

Command	Description
<b>debug</b>	See all <b>debug</b> commands.

# show dhcpd

To view DHCP binding, state, and statistical information, use the **show dhcpd** command in privileged EXEC or global configuration mode.

**show dhcpd {binding [*IP\_address*] | state | statistics}**

## Syntax Description

<b>binding</b>	Displays binding information for a given server IP address and its associated client hardware address and lease length.
<i>IP_address</i>	Shows the binding information for the specified IP address.
<b>state</b>	Displays the state of the DHCP server, such as whether it is enabled in the current context and whether it is enabled on each of the interfaces.
<b>statistics</b>	Displays statistical information, such as the number of address pools, bindings, expired bindings, malformed messages, sent messages, and received messages.

## Defaults

No default behavior or values.

## Command Modes

The following table shows the modes in which you can enter the command:

	Firewall Mode		Security Context		
				Multiple	
Command Mode	Routed	Transparent	Single	Context	System
Privileged EXEC	•	•	•	•	—

## Command History

Release	Modification
Preexisting	This command was preexisting.

## Usage Guidelines

If you include the optional IP address in the **show dhcpd binding** command, only the binding for that IP address is shown.

The **show dhcpd binding | state | statistics** commands are also available in global configuration mode.

## Examples

The following is sample output from the **show dhcpd binding** command:

```
hostname# show dhcpd binding
IP Address Hardware Address Lease Expiration Type
10.0.1.100 0100.a0c9.868e.43 84985 seconds automatic
```

The following is sample output from the **show dhcpd state** command:

```
hostname# show dhcpd state
Context Not Configured for DHCP
Interface outside, Not Configured for DHCP
```



Interface inside, Not Configured for DHCP

The following is sample output from the **show dhcpd statistics** command:

```
hostname# show dhcpd statistics
```

```
DHCP UDP Unreachable Errors: 0
```

```
DHCP Other UDP Errors: 0
```

```
Address pools          1
```

```
Automatic bindings     1
```

```
Expired bindings       1
```

```
Malformed messages    0
```

```
Message                Received
```

```
BOOTREQUEST           0
```

```
DHCPDISCOVER          1
```

```
DHCPREQUEST           2
```

```
DHCPDECLINE           0
```

```
DHCPRELEASE           0
```

```
DHCPINFORM            0
```

```
Message                Sent
```

```
BOOTREPLY             0
```

```
DHCPOFFER             1
```

```
DHCPACK               1
```

```
DHCPNAK               1
```

## Related Commands

Command	Description
<b>clear configure dhcpd</b>	Removes all DHCP server settings.
<b>clear dhcpd</b>	Clears the DHCP server bindings and statistic counters.
<b>dhcpd lease</b>	Defines the lease length for DHCP information granted to clients.
<b>show running-config dhcpd</b>	Displays the current DHCP server configuration.

# show dhcprelay state

To view the state of the DHCP relay agent, use the **show dhcprelay state** command in privileged EXEC or global configuration mode.

## show dhcprelay state

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Privileged EXEC	•	—	•	•	—

Release	Modification
Preexisting	This command was preexisting.

**Usage Guidelines** This command displays the DHCP relay agent state information for the current context and each interface.

**Examples** The following is sample output from the **show dhcprelay state** command:

```
hostname# show dhcprelay state

Context   Configured as DHCP Relay
Interface outside, Not Configured for DHCP
Interface infrastructure, Configured for DHCP RELAY SERVER
Interface inside, Configured for DHCP RELAY
```

Related Commands	Command	Description
	<b>show dhcpd</b>	Displays DHCP server statistics and state information.
	<b>show dhcprelay statistics</b>	Displays the DHCP relay statistics.
	<b>show running-config dhcprelay</b>	Displays the current DHCP relay agent configuration.

# show disk

To display the contents of the flash memory, use the **show disk** command in privileged EXEC mode.

**show disk**[0 | 1] [filesystem | all] controller

Syntax Description	0   1	Specifies the internal flash memory (0, the default) or the external flash memory (1).
	all	Shows the contents of flash memory and the file system information,
	controller	Specifies the flash model number.
	filesystem	Shows information about the compact flash card.

**Defaults** This command shows the internal flash memory by default.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Privileged EXEC	•	•	•	—	•

Command History	Release	Modification
	7.0(1)	This command was introduced.

**Examples** The following is sample output from the **show disk** command:

```
hostname# show disk
-#- --length-- ----date/time----- path
11 1301      Feb 21 2005 18:01:34 test.cfg
12 1949      Feb 21 2005 20:13:36 test1.cfg
13 2551      Jan 06 2005 10:07:36 test2.cfg
14 609223    Jan 21 2005 07:14:18 test3.cfg
15 1619      Jul 16 2004 16:06:48 test4.cfg
16 3184      Aug 03 2004 07:07:00 old_running.cfg
17 4787      Mar 04 2005 12:32:18 test5.cfg
20 1792      Jan 21 2005 07:29:24 test6.cfg
21 7765184   Mar 07 2005 19:38:30 test7.cfg
22 1674      Nov 11 2004 02:47:52 test8.cfg
23 1863      Jan 21 2005 07:29:18 test9.cfg
24 1197      Jan 19 2005 08:17:48 test10.cfg
25 608554    Jan 13 2005 06:20:54 backupconfig.cfg
26 5124096   Feb 20 2005 08:49:28 cdisk1
27 5124096   Mar 01 2005 17:59:56 cdisk2
28 2074      Jan 13 2005 08:13:26 test11.cfg
29 5124096   Mar 07 2005 19:56:58 cdisk3
30 1276      Jan 28 2005 08:31:58 lead
```

```

31 7756788      Feb 24 2005 12:59:46 asdmfile.dbg
32 7579792      Mar 08 2005 11:06:56 asdmfile1.dbg
33 7764344      Mar 04 2005 12:17:46 asdmfile2.dbg
34 5124096      Feb 24 2005 11:50:50 cdisk4
35 15322        Mar 04 2005 12:30:24 hs_err.log

```

10170368 bytes available (52711424 bytes used)

The following is sample output from the **show disk filesystems** command:

```

hostname# show disk filesystems
***** Flash Card Geometry/Format Info *****

COMPACT FLASH CARD GEOMETRY
  Number of Heads:          4
  Number of Cylinders       978
  Sectors per Cylinder      32
  Sector Size               512
  Total Sectors             125184

COMPACT FLASH CARD FORMAT
  Number of FAT Sectors     61
  Sectors Per Cluster       8
  Number of Clusters        15352
  Number of Data Sectors    122976
  Base Root Sector          123
  Base FAT Sector           1
  Base Data Sector          155

```

The following is sample output from the **show disk controller** command:

```

hostname# show disk:0 controller
Flash Model: STI Flash 8.4.0

```

## Related Commands

Command	Description
<b>dir</b>	Displays the directory contents.
<b>show flash</b>	Displays the contents of the internal Flash memory in the PIX security appliance only.

# show disk

To display the contents of the flash memory, use the **show disk** command in privileged EXEC mode.

**show disk**[0 | 1] [fileys | all]

Syntax Description	0   1	Specifies the internal flash memory (0, the default) or the external flash memory (1).
	all	Shows the contents of flash memory and the file system information,
	fileys	Shows information about the compact flash card.

**Defaults** This command shows the internal flash memory by default.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Privileged EXEC	•	•	•	—	•

Command History	Release	Modification
	7.0(1)	This command was introduced.

**Examples** The following is sample output from the **show disk** command:

```
hostname# show disk
#- --length-- -----date/time----- path
11 1301      Feb 21 2005 18:01:34 test.cfg
12 1949      Feb 21 2005 20:13:36 test1.cfg
13 2551      Jan 06 2005 10:07:36 test2.cfg
14 609223    Jan 21 2005 07:14:18 test3.cfg
15 1619      Jul 16 2004 16:06:48 test4.cfg
16 3184      Aug 03 2004 07:07:00 old_running.cfg
17 4787      Mar 04 2005 12:32:18 test5.cfg
20 1792      Jan 21 2005 07:29:24 test6.cfg
21 7765184   Mar 07 2005 19:38:30 test7.cfg
22 1674      Nov 11 2004 02:47:52 test8.cfg
23 1863      Jan 21 2005 07:29:18 test9.cfg
24 1197      Jan 19 2005 08:17:48 test10.cfg
25 608554    Jan 13 2005 06:20:54 backupconfig.cfg
26 5124096   Feb 20 2005 08:49:28 cdisk1
27 5124096   Mar 01 2005 17:59:56 cdisk2
28 2074      Jan 13 2005 08:13:26 test11.cfg
29 5124096   Mar 07 2005 19:56:58 cdisk3
30 1276      Jan 28 2005 08:31:58 lead
31 7756788   Feb 24 2005 12:59:46 asdmfile.dbg
32 7579792   Mar 08 2005 11:06:56 asdmfile1.dbg
```

**show disk**

```

33 7764344    Mar 04 2005 12:17:46 asdmfile2.dbg
34 5124096    Feb 24 2005 11:50:50 cdisk4
35 15322      Mar 04 2005 12:30:24 hs_err.log

```

10170368 bytes available (52711424 bytes used)

The following is sample output from the **show disk filesystems** command:

```

hostname# show disk filesystems
***** Flash Card Geometry/Format Info *****

COMPACT FLASH CARD GEOMETRY
  Number of Heads:           4
  Number of Cylinders        978
  Sectors per Cylinder       32
  Sector Size                 512
  Total Sectors              125184

COMPACT FLASH CARD FORMAT
  Number of FAT Sectors      61
  Sectors Per Cluster        8
  Number of Clusters         15352
  Number of Data Sectors    122976
  Base Root Sector          123
  Base FAT Sector            1
  Base Data Sector          155

```

**Related Commands**

Command	Description
<b>dir</b>	Displays the directory contents.
<b>show flash</b>	Displays the contents of the internal Flash memory in the PIX security appliance only.

# show dns-hosts

To show the DNS cache, use the **show dns-hosts** command in privileged EXEC mode. The DNS cache includes dynamically learned entries from a DNS server as well as manually entered name and IP addresses using the **name** command.

**show dns-hosts**

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Privileged EXEC	•	•	•	•	—

Command History	Release	Modification
	7.0(1)	This command was introduced.

**Examples** The following is sample output from the **show dns-hosts** command:

```
hostname# show dns-hosts
Host                               Flags      Age Type  Address(es)
ns2.example.com                   (temp, OK) 0    IP    10.102.255.44
ns1.example.com                   (temp, OK) 0    IP    192.168.241.185
snowmass.example.com              (temp, OK) 0    IP    10.94.146.101
server.example.com                (temp, OK) 0    IP    10.94.146.80
```

Table 11 shows each field description.

**Table 26-1** *show dns-hosts Fields*

Field	Description
Host	Shows the hostname.
Flags	Shows the entry status, as a combination of the following: <ul style="list-style-type: none"> <li>temp—This entry is temporary because it comes from a DNS server. The security appliance removes this entry after 72 hours of inactivity.</li> <li>perm—This entry is permanent because it was added with the <b>name</b> command.</li> <li>OK—This entry is valid.</li> <li>??—This entry is suspect and needs to be revalidated.</li> <li>EX—This entry is expired.</li> </ul>
Age	Shows the number of hours since this entry was last referenced.
Type	Shows the type of DNS record; this value is always IP.
Address(es)	The IP addresses.

#### Related Commands

Command	Description
<b>clear dns-hosts</b>	Clears the DNS cache.
<b>dns domain-lookup</b>	Enables the security appliance to perform a name lookup.
<b>dns name-server</b>	Configures a DNS server address.
<b>dns retries</b>	Specifies the number of times to retry the list of DNS servers when the security appliance does not receive a response.
<b>dns timeout</b>	Specifies the amount of time to wait before trying the next DNS server.



# show eigrp events

To display the EIGRP event log, use the **show eigrp events** command in privileged EXEC mode.

**show eigrp** [*as-number*] **events** [{*start end*} | **type**]

<b>Syntax Description</b>	<i>as-number</i>	(Optional) Specifies the autonomous system number of the EIGRP process for which you are viewing the event log. Because the security appliance only supports one EIGRP routing process, you do not need to specify the autonomous system number.
	<i>end</i>	(Optional) Limits the output to the entries with starting with the <i>start</i> index number and ending with the <i>end</i> index number.
	<i>start</i>	(Optional) A number specifying the log entry index number. Specifying a start number causes the output to start with the specified event and end with the event specified by the <i>end</i> argument. Valid values are from 1 to 4294967295.
	<b>type</b>	(Optional) Displays the events that are being logged.

**Defaults** If a *start* and *end* is not specified, all log entries are shown.

**Command Modes** The following table shows the modes in which you can enter the command:

	Firewall Mode		Security Context		
				Multiple	
Command Mode	Routed	Transparent	Single	Context	System
Privileged EXEC	•	—	•	—	—

<b>Command History</b>	Release	Modification
	8.0(2)	This command was introduced.

**Usage Guidelines** The **show eigrp events** output displays up to 500 events. Once the maximum number of events has been reached, new events are added to the bottom of the output and old events are removed from the top of the output.

You can use the **clear eigrp events** command to clear the EIGRP event log.

The **show eigrp events type** command displays the logging status of EIGRP events. By default, neighbor changes, neighbor warning, and DUAL FSM messages are logged. You can disable neighbor change event logging using the **no eigrp log-neighbor-changes** command. You can disable neighbor warning event logging using the **no eigrp log-neighbor-warnings** command. You cannot disable the logging of DUAL FSM events.

**Examples**

The following is sample output from the **show eigrp events** command:

```
hostname# show eigrp events
```

```
Event information for AS 100:
```

```
1 12:11:23.500 Change queue emptied, entries: 4
2 12:11:23.500 Metric set: 10.1.0.0/16 53760
3 12:11:23.500 Update reason, delay: new if 4294967295
4 12:11:23.500 Update sent, RD: 10.1.0.0/16 4294967295
5 12:11:23.500 Update reason, delay: metric chg 4294967295
6 12:11:23.500 Update sent, RD: 10.1.0.0/16 4294967295
7 12:11:23.500 Route install: 10.1.0.0/16 10.130.60.248
8 12:11:23.500 Find FS: 10.1.0.0/16 4294967295
9 12:11:23.500 Rcv update met/succmet: 53760 28160
10 12:11:23.500 Rcv update dest/nh: 10.1.0.0/16 10.130.60.248
11 12:11:23.500 Metric set: 10.1.0.0/16 4294967295
```

The following is sample output from the **show eigrp events** command with a start and stop number defined:

```
hostname# show eigrp events 3 8
```

```
Event information for AS 100:
```

```
3 12:11:23.500 Update reason, delay: new if 4294967295
4 12:11:23.500 Update sent, RD: 10.1.0.0/16 4294967295
5 12:11:23.500 Update reason, delay: metric chg 4294967295
6 12:11:23.500 Update sent, RD: 10.1.0.0/16 4294967295
7 12:11:23.500 Route install: 10.1.0.0/16 10.130.60.248
8 12:11:23.500 Find FS: 10.1.0.0/16 4294967295
```

The following is sample output from the **show eigrp events** command when there are no entries in the EIGRP event log:

```
hostname# show eigrp events
```

```
Event information for AS 100: Event log is empty.
```

The following is sample output from the **show eigrp events type** command:

```
hostname# show eigrp events type
```

```
EIGRP-IPv4 Event Logging for AS 100:
```

```
Log Size          500
Neighbor Changes  Enable
Neighbor Warnings Enable
Dual FSM          Enable
```

**Related Commands**

Command	Description
<b>clear eigrp events</b>	Clears the EIGRP event logging buffer.
<b>eigrp log-neighbor-changes</b>	Enables the logging of neighbor change events.
<b>eigrp log-neighbor-warnings</b>	Enables the logging of neighbor warning events.

# show eigrp interfaces

To display the interfaces participating in EIGRP routing, use the **show eigrp interfaces** command in privileged EXEC mode.

**show eigrp** [*as-number*] **interfaces** [*if-name*] [**detail**]

## Syntax Description

<i>as-number</i>	(Optional) Specifies the autonomous system number of the EIGRP process for which you are displaying active interfaces. Because the security appliance only supports one EIGRP routing process, you do not need to specify the autonomous system number.
<b>detail</b>	(Optional) Displays detail information.
<i>if-name</i>	(Optional) The name of an interface as specified by the <b>nameif</b> command. Specifying an interface name limits the display to the specified interface.

## Defaults

If you do not specify an interface name, information for all EIGRP interfaces is displayed.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Privileged EXEC	•	—	•	—	—

## Command History

Release	Modification
8.0(2)	This command was introduced.

## Usage Guidelines

Use the **show eigrp interfaces** command to determine on which interfaces EIGRP is active, and to learn information about EIGRP relating to those interfaces.

If an interface is specified, only that interface is displayed. Otherwise, all interfaces on which EIGRP is running are displayed.

If an autonomous system is specified, only the routing process for the specified autonomous system is displayed. Otherwise, all EIGRP processes are displayed.

## Examples

The following is sample output from the **show eigrp interfaces** command:

```
hostname# show eigrp interfaces
```

```
EIGRP-IPv4 interfaces for process 100
```

Interface	Peers	Xmit Queue Un/Reliable	Mean SRTT	Pacing Time Un/Reliable	Multicast Flow Timer	Pending Routes
-----------	-------	---------------------------	--------------	----------------------------	-------------------------	-------------------

## ■ show eigrp interfaces

```

mgmt          0          0/0          0          11/434          0          0
outside       1          0/0          337         0/10           0          0
inside        1          0/0          10          1/63          103         0

```

Table 26-2 describes the significant fields shown in the display.

**Table 26-2** *show eigrp interfaces Field Descriptions*

Field	Description
process	Autonomous system number for the EIGRP routing process.
Peers	Number of directly-connected peers.
Xmit Queue Un/Reliable	Number of packets remaining in the Unreliable and Reliable transmit queues.
Mean SRTT	Mean smooth round-trip time interval (in seconds).
Pacing Time Un/Reliable	Pacing time (in seconds) used to determine when EIGRP packets should be sent out the interface (unreliable and reliable packets).
Multicast Flow Timer	Maximum number of seconds in which the security appliance will send multicast EIGRP packets.
Pending Routes	Number of routes in the packets in the transmit queue waiting to be sent.

#### Related Commands

Command	Description
<b>network</b>	Defines the networks and interfaces that participate in the EIGRP routing process.

# show eigrp neighbors

To display the EIGRP neighbor table, use the **show eigrp neighbors** command in privileged EXEC mode.

**show eigrp** [*as-number*] **neighbors** [**detail** | **static**] [*if-name*]

## Syntax Description

<i>as-number</i>	(Optional) Specifies the autonomous system number of the EIGRP process for which you are deleting neighbor entries. Because the security appliance only supports one EIGRP routing process, you do not need to specify the autonomous system number.
<b>detail</b>	(Optional) Displays detail neighbor information.
<i>if-name</i>	(Optional) The name of an interface as specified by the <b>nameif</b> command. Specifying an interface name displays all neighbor table entries that were learned through that interface.
<b>static</b>	(Optional) Displays EIGRP neighbors that are statically defined using the <b>neighbor</b> command.

## Defaults

If you do not specify an interface name, the neighbors learned through all interfaces are displayed.

## Command Modes

The following table shows the modes in which you can enter the command:

	Firewall Mode		Security Context		
				Multiple	
Command Mode	Routed	Transparent	Single	Context	System
Privileged EXEC	•	—	•	—	—

## Command History

Release	Modification
8.0(2)	This command was introduced.

## Usage Guidelines

You can use the **clear eigrp neighbors** command to clear the dynamically-learned neighbors from the EIGRP neighbor table.

Static neighbors are not included in the output unless you use the **static** keyword.

## Examples

The following is sample output from the **show eigrp neighbors** command:

```
hostname# show eigrp neighbors
```

```
EIGRP-IPv4 Neighbors for process 100
Address                Interface    Holdtime  Uptime    Q      Seq  SRTT  RTO
                   (secs)    (h:m:s)  Count   Num   (ms)  (ms)
172.16.81.28           Ethernet1    13        0:00:41   0       11    4     20
```

## ■ show eigrp neighbors

```

172.16.80.28      Ethernet0      14      0:02:01  0      10      12      24
172.16.80.31      Ethernet0      12      0:02:02  0       4       5       20

```

Table 26-2 describes the significant fields shown in the display.

**Table 26-3**      *show eigrp neighbors Field Descriptions*

Field	Description
process	Autonomous system number for the EIGRP routing process.
Address	IP address of the EIGRP neighbor.
Interface	Interface on which the security appliance receives hello packets from the neighbor.
Holdtime	<p>Length of time (in seconds) that the security appliance waits to hear from the neighbor before declaring it down. This hold time is received from the neighbor in the hello packet, and begins decreasing until another hello packet is received from the neighbor.</p> <p>If the neighbor is using the default hold time, this number will be less than 15. If the peer configures a non-default hold time, the non-default hold time will be displayed.</p> <p>If this value reaches 0, the security appliance considers the neighbor unreachable.</p>
Uptime	Elapsed time (in hours:minutes: seconds) since the security appliance first heard from this neighbor.
Q Count	Number of EIGRP packets (update, query, and reply) that the security appliance is waiting to send.
Seq Num	Sequence number of the last update, query, or reply packet that was received from the neighbor.
SRTT	Smooth round-trip time. This is the number of milliseconds required for an EIGRP packet to be sent to this neighbor and for the security appliance to receive an acknowledgment of that packet.
RTO	Retransmission timeout (in milliseconds). This is the amount of time the security appliance waits before resending a packet from the retransmission queue to a neighbor.

The following is sample output from the **show eigrp neighbors static** command:

```

hostname# show eigrp neighbors static

EIGRP-IPv4 neighbors for process 100
Static Address      Interface
192.168.1.5         management

```

Table 26-4 describes the significant fields shown in the display.

**Table 26-4**      *show ip eigrp neighbors static Field Descriptions*

Field	Description
process	Autonomous system number for the EIGRP routing process.

**Table 26-4** *show ip eigrp neighbors static Field Descriptions*

Field	Description
Static Address	IP address of the EIGRP neighbor.
Interface	Interface on which the security appliance receives hello packets from the neighbor.

The following is sample output from the **show eigrp neighbors detail** command:

```
hostname# show eigrp neighbors detail
```

```
EIGRP-IPv4 neighbors for process 100
H   Address                Interface      Hold Uptime    SRTT   RTO   Q  Seq Tye
      (sec)                (ms)          Cnt  Num
3   1.1.1.3                Et0/0         12 00:04:48 1832   5000   0   14
    Version 12.2/1.2, Retrans: 0, Retries: 0
    Restart time 00:01:05
0   10.4.9.5                Fa0/0         11 00:04:07   768   4608   0   4   S
    Version 12.2/1.2, Retrans: 0, Retries: 0
2   10.4.9.10              Fa0/0         13 1w0d           1   3000   0   6   S
    Version 12.2/1.2, Retrans: 1, Retries: 0
1   10.4.9.6                Fa0/0         12 1w0d           1   3000   0   4   S
    Version 12.2/1.2, Retrans: 1, Retries: 0
```

Table 26-5 describes the significant fields shown in the display.

**Table 26-5** *show ip eigrp neighbors details Field Descriptions*

Field	Description
process	Autonomous system number for the EIGRP routing process.
H	This column lists the order in which a peering session was established with the specified neighbor. The order is specified with sequential numbering starting with 0.
Address	IP address of the EIGRP neighbor.
Interface	Interface on which the security appliance receives hello packets from the neighbor.
Holdtime	Length of time (in seconds) that the security appliance waits to hear from the neighbor before declaring it down. This hold time is received from the neighbor in the hello packet, and begins decreasing until another hello packet is received from the neighbor.  If the neighbor is using the default hold time, this number will be less than 15. If the peer configures a non-default hold time, the non-default hold time will be displayed.  If this value reaches 0, the security appliance considers the neighbor unreachable.
Uptime	Elapsed time (in hours:minutes: seconds) since the security appliance first heard from this neighbor.
SRTT	Smooth round-trip time. This is the number of milliseconds required for an EIGRP packet to be sent to this neighbor and for the security appliance to receive an acknowledgment of that packet.

**Table 26-5** *show ip eigrp neighbors details Field Descriptions*

Field	Description
RTO	Retransmission timeout (in milliseconds). This is the amount of time the security appliance waits before resending a packet from the retransmission queue to a neighbor.
Q Count	Number of EIGRP packets (update, query, and reply) that the security appliance is waiting to send.
Seq Num	Sequence number of the last update, query, or reply packet that was received from the neighbor.
Version	The software version that the specified peer is running.
Retrans	The number of times that a packet has been retransmitted.
Retries	The number of times an attempt was made to retransmit a packet.
Restart time	Elapsed time (in hours:minutes: seconds) since the specified neighbor has restarted.

**Related Commands**

Command	Description
<b>clear eigrp neighbors</b>	Clear the EIGRP neighbor table.
<b>debug eigrp neighbors</b>	Display EIGRP neighbor debug messages.
<b>debug ip eigrp</b>	Display EIGRP packet debug messages.



# show eigrp topology

To display the EIGRP topology table, use the **show eigrp topology** command in privileged EXEC mode.

**show eigrp** [*as-number*] **topology** [*ip-addr* [*mask*] | **active** | **all-links** | **pending** | **summary** | **zero-successors**]

## Syntax Description

<b>active</b>	(Optional) Displays only active entries in the EIGRP topology table.
<b>all-links</b>	(Optional) Displays all routes in the EIGRP topology table, even those that are not feasible successors.
<i>as-number</i>	(Optional) Specifies the autonomous system number of the EIGRP process. Because the security appliance only supports one EIGRP routing process, you do not need to specify the autonomous system number.
<i>ip-addr</i>	(Optional) The IP address from the topology table to display. When specified with a mask, a detailed description of the entry is provided.
<i>mask</i>	(Optional) The network mask to apply to the <i>ip-addr</i> argument.
<b>pending</b>	(Optional) Displays all entries in the EIGRP topology table that are waiting for an update from a neighbor or are waiting to reply to a neighbor.
<b>summary</b>	(Optional) Displays a summary of the EIGRP topology table.
<b>zero-successors</b>	(Optional) Displays available routes in the EIGRP topology table.

## Defaults

Only routes that are feasible successors are displayed. Use the **all-links** keyword to display all routes, including those that are not feasible successors.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Privileged EXEC	•	—	•	—	—

## Command History

Release	Modification
8.0(2)	This command was introduced.

## Usage Guidelines

You can use the **clear eigrp topology** command to remove the dynamic entries from the topology table.

## Examples

The following is sample output from the **show eigrp topology** command:

```
hostname# show eigrp topology
```

```
EIGRP-IPv4 Topology Table for AS(100)/ID(192.168.1.1)
```

Codes: P - Passive, A - Active, U - Update, Q - Query, R - Reply,  
r - Reply status

```
P 10.16.90.0 255.255.255.0, 2 successors, FD is 0
    via 10.16.80.28 (46251776/46226176), Ethernet0
    via 10.16.81.28 (46251776/46226176), Ethernet1
P 10.16.81.0 255.255.255.0, 1 successors, FD is 307200
    via Connected, Ethernet1
    via 10.16.81.28 (307200/281600), Ethernet1
    via 10.16.80.28 (307200/281600), Ethernet0
```

Table 26-6 describes the significant fields shown in the displays.

**Table 26-6** show eigrp topology Field Information

Field	Description
Codes	State of this topology table entry. Passive and Active refer to the EIGRP state with respect to this destination; Update, Query, and Reply refer to the type of packet that is being sent.
P - Passive	The route is known to be good and no EIGRP computations are being performed for this destination.
A - Active	EIGRP computations are being performed for this destination.
U - Update	Indicates that an update packet was sent to this destination.
Q - Query	Indicates that a query packet was sent to this destination.
R - Reply	Indicates that a reply packet was sent to this destination.
r - Reply status	Flag that is set after the software has sent a query and is waiting for a reply.
address mask	Destination IP address and mask.
successors	Number of successors. This number corresponds to the number of next hops in the IP routing table. If “successors” is capitalized, then the route or next hop is in a transition state.
FD	Feasible distance. The feasible distance is the best metric to reach the destination or the best metric that was known when the route went active. This value is used in the feasibility condition check. If the reported distance of the router (the metric after the slash) is less than the feasible distance, the feasibility condition is met and that path is a feasible successor. Once the software determines it has a feasible successor, it need not send a query for that destination.
via	IP address of the peer that told the software about this destination. The first <i>n</i> of these entries, where <i>n</i> is the number of successors, is the current successors. The remaining entries on the list are feasible successors.
(cost/adv_cost)	The first number is the EIGRP metric that represents the cost to the destination. The second number is the EIGRP metric that this peer advertised.
interface	The interface from which the information was learned.

The following is sample output from the **show eigrp topology** used with an IP address. The output shown is for an internal route.

```
hostname# show eigrp topology 10.2.1.0 255.255.255.0
```

```
EIGRP-IPv4 (AS 100): Topology Default-IP-Routing-Table(0) entry for entry for 10.2.1.0
255.255.255.0
```

```

State is Passive, Query origin flag is 1, 1 Successor(s), FD is 281600
Routing Descriptor Blocks:
  0.0.0.0 (Ethernet0/0), from Connected, Send flag is 0x0
    Composite metric is (281600/0), Route is Internal
    Vector metric:
      Minimum bandwidth is 10000 Kbit
      Total delay is 1000 microseconds
      Reliability is 255/255
      Load is 1/255
      Minimum MTU is 1500
      Hop count is 0

```

The following is sample output from the **show eigrp topology** used with an IP address. The output shown is for an external route.

```

hostname# show eigrp topology 10.4.80.0 255.255.255.0

```

```

EIGRP-IPv4 (AS 100): Topology Default-IP-Routing-Table(0) entry for entry for 10.4.80.0
255.255.255.0

```

```

State is Passive, Query origin flag is 1, 1 Successor(s), FD is 409600
Routing Descriptor Blocks:
  10.2.1.1 (Ethernet0/0), from 10.2.1.1, Send flag is 0x0
    Composite metric is (409600/128256), Route is External
    Vector metric:
      Minimum bandwidth is 10000 Kbit
      Total delay is 6000 microseconds
      Reliability is 255/255
      Load is 1/255
      Minimum MTU is 1500
      Hop count is 1
    External data:
      Originating router is 10.89.245.1
      AS number of route is 0
      External protocol is Connected, external metric is 0
      Administrator tag is 0 (0x00000000)

```

## Related Commands

Command	Description
<b>clear eigrp topology</b>	Clears the dynamically discovered entries from the EIGRP topology table.

# show eigrp traffic

To display the number of EIGRP packets sent and received, use the **show eigrp traffic** command in privileged EXEC mode.

**show eigrp** [*as-number*] **traffic**

## Syntax Description

<i>as-number</i>	(Optional) Specifies the autonomous system number of the EIGRP process for which you are viewing the event log. Because the security appliance only supports one EIGRP routing process, you do not need to specify the autonomous system number.
------------------	--

## Defaults

No default behaviors or values.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Privileged EXEC	•	—	•	—	—

## Command History

Release	Modification
8.0(2)	This command was introduced.

## Usage Guidelines

You can use the **clear eigrp traffic** command to clear the EIGRP traffic statistics.

## Examples

The following is sample output from the **show eigrp traffic** command:

```
hostname# show eigrp traffic

EIGRP-IPv4 Traffic Statistics for AS 100
  Hellos sent/received: 218/205
  Updates sent/received: 7/23
  Queries sent/received: 2/0
  Replies sent/received: 0/2
  Acks sent/received: 21/14
  Input queue high water mark 0, 0 drops
  SIA-Queries sent/received: 0/0
  SIA-Replies sent/received: 0/0
  Hello Process ID: 1719439416
  PDM Process ID: 1719439824
```

[Table 26-4](#) describes the significant fields shown in the display.

**Table 26-7** *show eigrp traffic Field Descriptions*

Field	Description
process	Autonomous system number for the EIGRP routing process.
Hellos sent/received	Number of hello packets sent and received.
Updates sent/received	Number of update packets sent and received.
Queries sent/received	Number of query packets sent and received.
Replies sent/received	Number of reply packets sent and received.
Acks sent/received	Number of acknowledgment packets sent and received.
Input queue high water mark/drops	Number of received packets that are approaching the maximum receive threshold and number of dropped packets.
SIA-Queries sent/received	Stuck in active queries sent and received.
SIA-Replies sent/received	Stuck in active replies sent and received.

**Related Commands**

Command	Description
<b>debug eigrp packets</b>	Displays debug information for EIGRP packets sent and received.
<b>debug eigrp transmit</b>	Displays debug information for EIGRP messages sent.

# show environment

To display system environment information for system components, use the **show environment** command in privileged EXEC mode.

**show environment** [**driver** | **fans** | **power-supply** | **temperature** [**chassis** | **cpu**]]

## Syntax Description

<b>chassis</b>	(Optional) Limits the temperature display to the chassis.
<b>cpu</b>	(Optional) Limits the temperature display to the processors. The ASA 5580-40 displays information for 4 processors. The ASA 5580-20 displays information for 2 processors.
<b>driver</b>	(Optional) Display the environment monitoring (IPMI) driver status. The driver status can be one of the following: <ul style="list-style-type: none"> <li>RUNNING—the driver is operational.</li> <li>STOPPED—an error has caused the driver to stop.</li> </ul>
<b>fans</b>	(Optional) Displays the operational status of the cooling fans. The status is one of the following: <ul style="list-style-type: none"> <li>OK—The fan is operating normally.</li> <li>Failed—The fan has failed and should be replaced.</li> </ul>
<b>power-supply</b>	(Optional) Displays the operational status of the power supplies. The status for each power supply is one of the following: <ul style="list-style-type: none"> <li>OK—The power supply is operating normally.</li> <li>Failed—The power supply has failed and should be replaced.</li> <li>Not Present—The specified power supply is not installed.</li> </ul> <p>The power supply redundancy status also displays. The redundancy status is one of the following:</p> <ul style="list-style-type: none"> <li>OK—The unit is operating normally with full resources.</li> <li>Lost—The unit has lost redundancy but is operating normally with minimum resources. Any further failures will result in a system shutdown.</li> <li>N/A—The unit is not configured for power supply redundancy.</li> </ul>
<b>temperature</b>	(Optional) Displays the temperature and status of the processors and chassis. The temperature is given in celsius. The status is one of the following: <ul style="list-style-type: none"> <li>OK—The temperature is within normal operating range.</li> <li>Critical—The temperature is outside of normal operating range.</li> </ul>

## Defaults

All operational information, except driver, is displayed if no keywords are specified.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Privileged EXEC	•	•	•	—	•

### Command History

Release	Modification
8.1(1)	This command was introduced.

### Usage Guidelines

You can display operating environment information on the ASA 5580 security appliance. This information includes the operational status of the fans and power supplies, and temperature and status of the CPUs and chassis. The 5580-40 displays information for 4 CPUs; the 5580-20 displays information for 2 CPUs.

### Examples

The following is sample output of the **show environment** command:

```
hostname# show environment

Cooling Fans:
-----
Cooling Fan 1: OK
Cooling Fan 2: OK
Cooling Fan 3: OK
Cooling Fan 4: OK
Cooling Fan 5: OK
Cooling Fan 6: OK

Power Supplies:
-----
Power Supply Unit Redundancy: N/A

Power Supply 1: OK
Power Supply 2: Not Present

Temperature:
-----

Processors:
-----
Processor 1: 30 C - OK
Processor 2: 29 C - OK

Chassis:
-----
Ambient 1: 29 C - OK
Ambient 2: 31 C - OK
Ambient 3: 34 C - OK
Ambient 4: 36 C - OK
```

The following is sample output from the **show environment driver** command when there are no errors:

```
hostname# show environment driver

Driver Information:
```

## show environment

```

-----
Status : RUNNING

Driver Error Statistics:
-----
Timeout I/O Errors      : 0
Try Again I/O Errors    : 0
Invalid Addr I/O Errors : 0
Message Size I/O Errors : 0
Memory I/O Errors       : 0
Unknown I/O Errors      : 0
Receive Msg ID Errors   : 0
Receive Type Errors     : 0
Sensor Update Failures  : 0

Last 5 Errors:
-----

```

The following is sample output from the **show environment driver** command when there is a driver error:

```

hostname# show environment driver

Driver Information:
-----
Status : STOPPED

Driver Error Statistics:
-----
Timeout I/O Errors      : 0
Try Again I/O Errors    : 0
Invalid Addr I/O Errors : 0
Message Size I/O Errors : 0
Memory I/O Errors       : 0
Unknown I/O Errors      : 0
Receive Msg ID Errors   : 0
Receive Type Errors     : 0
Sensor Update Failures  : 1

Last 5 Errors:
-----
1.) IPMI driver stopped responding
   Time: 03:27:21 UTC Apr 16 2007

```

### Related Commands

Command	Description
<b>show version</b>	Displays the hardware and software versions.



# show failover

To display information about the failover status of the unit, use the **show failover** command in privileged EXEC mode.

**show failover** [**group** *num* | **history** | **interface** | **state** | **statistics**]

## Syntax Description

<b>group</b>	Displays the running state of the specified failover group.
<b>history</b>	Displays failover history. The failover history displays past failover state changes and the reason for the state change. History information is cleared with the device is rebooted.
<b>interface</b>	Displays failover command and stateful link information.
<i>num</i>	Failover group number.
<b>state</b>	Displays the failover state of both failover units. The information displayed includes the primary or secondary status of the unit, the Active/Standby status of the unit, and the last reported reason for failover. The fail reason remains in the output even when the reason for failure is cleared.
<b>statistics</b>	Displays transmit and receive packet count of failover command interface.

## Defaults

No default behavior or values.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Privileged EXEC	•	•	•	•	•

## Command History

Release	Modification
7.0(1)	This command was modified. The output includes additional information.

## Usage Guidelines

The **show failover** command displays the dynamic failover information, interface status, and Stateful Failover statistics. The Stateful Failover Logical Update Statistics output appears only when Stateful Failover is enabled. The “xerr” and “rerr” values do not indicate errors in failover, but rather the number of packet transmit or receive errors.



### Note

Stateful Failover, and therefore Stateful Failover statistics output, is not available on the ASA 5505 adaptive security appliance.

In the **show failover** command output, the stateful failover fields have the following values:

- Stateful Obj has these values:
  - xmit—Indicates the number of packets transmitted.
  - xerr—Indicates the number of transmit errors.
  - rcv—Indicates the number of packets received.
  - rerr—Indicates the number of receive errors.
- Each row is for a particular object static count as follows:
  - General—Indicates the sum of all stateful objects.
  - sys cmd—Refers to the logical update system commands, such as **login** or **stay alive**.
  - up time—Indicates the value for the security appliance up time, which the active security appliance passes on to the standby security appliance.
  - RPC services—Remote Procedure Call connection information.
  - TCP conn—Dynamic TCP connection information.
  - UDP conn—Dynamic UDP connection information.
  - ARP tbl—Dynamic ARP table information.
  - Xlate\_Timeout—Indicates connection translation timeout information.
  - VPN IKE upd—IKE connection information.
  - VPN IPSEC upd—IPSec connection information.
  - VPN CTCP upd—cTCP tunnel connection information.
  - VPN SDI upd—SDI AAA connection information.
  - VPN DHCP upd—Tunneled DHCP connection information.
  - SIP Sesson—SIP signalling session information.

If you do not enter a failover IP address, the **show failover** command displays 0.0.0.0 for the IP address, and monitoring of the interfaces remain in a “waiting” state. You must set a failover IP address for failover to work.

Table 26-8 describes the interface states for failover.

**Table 26-8 Failover Interface States**

State	Description
Normal	The interface is up and receiving hello packets from the corresponding interface on the peer unit.
Normal (Waiting)	The interface is up but has not yet received a hello packet from the corresponding interface on the peer unit. Verify that a standby IP address has been configured for the interface and that there is connectivity between the two interfaces.
Normal (Not-Monitored)	The interface is up but is not monitored by the failover process. The failure of an interface that is not monitored does not trigger failover.
No Link	The physical link is down.
No Link (Waiting)	The physical link is down and the interface has not yet received a hello packet from the corresponding interface on the peer unit. After restoring the link, verify that a standby IP address has been configured for the interface and that there is connectivity between the two interfaces.

**Table 26-8** Failover Interface States (continued)

State	Description
No Link (Not-Monitored)	The physical link is down but is not monitored by the failover process. The failure of an interface that is not monitored does not trigger failover.
Link Down	The physical link is up, but the interface is administratively down.
Link Down (Waiting)	The physical link is up, but the interface is administratively down and the interface has not yet received a hello packet from the corresponding interface on the peer unit. After bringing the interface up (using the <b>no shutdown</b> command in interface configuration mode), verify that a standby IP address has been configured for the interface and that there is connectivity between the two interfaces.
Link Down (Not-Monitored)	The physical link is up, but the interface is administratively down but is not monitored by the failover process. The failure of an interface that is not monitored does not trigger failover.
Testing	The interface is in testing mode due to missed hello packets from the corresponding interface on the peer unit.
Failed	Interface testing has failed and the interface is marked as failed. If the interface failure causes the failover criteria to be met, then the interface failure causes a failover to the secondary unit or failover group.

In multiple configuration mode, only the **show failover** command is available in a security context; you cannot enter the optional keywords.

## Examples

The following is sample output from the **show failover** command for Active/Standby Failover. The security appliances are ASA 5500 series adaptive security appliances, each equipped with a CSC SSM as shown in the details for slot 1 of each security appliance.

```
hostname# show failover

Failover On
Cable status: N/A - LAN-based failover enabled
Failover unit Primary
Failover LAN Interface: fover Ethernet2 (up)
Unit Poll frequency 1 seconds, holdtime 3 seconds
Interface Poll frequency 15 seconds
Interface Policy 1
Monitored Interfaces 2 of 250 maximum
failover replication http
Last Failover at: 22:44:03 UTC Dec 8 2004
  This host: Primary - Active
    Active time: 13434 (sec)
    slot 0: ASA5520 hw/sw rev (1.0/7.1(0)10) status (Up Sys)
      Interface inside (10.130.9.3): Normal
      Interface outside (10.132.9.3): Normal
    slot 1: ASA-SSM-20 hw/sw rev (1.0/CSC-SSM 5.0 (Build#1176)) status (Up/Up)
      Logging port IP: 10.0.0.3/24
      CSC-SSM, 5.0 (Build#1176)
  Other host: Secondary - Standby Ready
    Active time: 0 (sec)
    slot 0: ASA5520 hw/sw rev (1.0/7.1(0)10) status (Up Sys)
      Interface inside (10.130.9.4): Normal
      Interface outside (10.132.9.4): Normal
    slot 1: ASA-SSM-20 hw/sw rev (1.0/CSC-SSM 5.0 (Build#1176)) status (Up/Up)
```

Logging port IP: 10.0.0.4/24  
CSC-SSM, 5.0 (Build#1176)

```
Stateful Failover Logical Update Statistics
Link : fover Ethernet2 (up)
Stateful Obj   xmit      xerr      rcv      rerr
General        0          0          0          0
sys cmd        1733        0         1733        0
up time        0          0          0          0
RPC services    0          0          0          0
TCP conn       6          0          0          0
UDP conn       0          0          0          0
ARP tbl       106          0          0          0
Xlate_Timeout  0          0          0          0
VPN IKE upd    15          0          0          0
VPN IPSEC upd  90          0          0          0
VPN CTCP upd   0          0          0          0
VPN SDI upd    0          0          0          0
VPN DHCP upd   0          0          0          0
SIP Session    0          0          0          0

Logical Update Queue Information
          Cur      Max      Total
Recv Q:   0        2       1733
Xmit Q:   0        2      15225
```

The following is sample output from the **show failover** command for Active/Active Failover:

```
hostname# show failover

Failover On
Failover unit Primary
Failover LAN Interface: third GigabitEthernet0/2 (up)
Unit Poll frequency 1 seconds, holdtime 15 seconds
Interface Poll frequency 4 seconds
Interface Policy 1
Monitored Interfaces 8 of 250 maximum
failover replication http
Group 1 last failover at: 13:40:18 UTC Dec 9 2004
Group 2 last failover at: 13:40:06 UTC Dec 9 2004

This host:   Primary
Group 1      State:           Active
             Active time:    2896 (sec)
Group 2      State:           Standby Ready
             Active time:    0 (sec)

slot 0: ASA-5530 hw/sw rev (1.0/7.0(0)79) status (Up Sys)
slot 1: SSM-IDS-20 hw/sw rev (1.0/5.0(0.11)S91(0.11)) status (Up)
admin Interface outside (10.132.8.5): Normal
admin Interface third (10.132.9.5): Normal
admin Interface inside (10.130.8.5): Normal
admin Interface fourth (10.130.9.5): Normal
ctx1 Interface outside (10.1.1.1): Normal
ctx1 Interface inside (10.2.2.1): Normal
ctx2 Interface outside (10.3.3.2): Normal
ctx2 Interface inside (10.4.4.2): Normal

Other host:  Secondary
Group 1      State:           Standby Ready
             Active time:    190 (sec)
Group 2      State:           Active
             Active time:    3322 (sec)
```

```

slot 0: ASA-5530 hw/sw rev (1.0/7.0(0)79) status (Up Sys)
slot 1: SSM-IDS-20 hw/sw rev (1.0/5.0(0.1)S91(0.1)) status (Up)
admin Interface outside (10.132.8.6): Normal
admin Interface third (10.132.9.6): Normal
admin Interface inside (10.130.8.6): Normal
admin Interface fourth (10.130.9.6): Normal
ctx1 Interface outside (10.1.1.2): Normal
ctx1 Interface inside (10.2.2.2): Normal
ctx2 Interface outside (10.3.3.1): Normal
ctx2 Interface inside (10.4.4.1): Normal

```

#### Stateful Failover Logical Update Statistics

```

Link : third GigabitEthernet0/2 (up)
Stateful Obj  xmit      xerr      rcv      rerr
General       0          0          0          0
sys cmd       380          0        380          0
up time        0          0          0          0
RPC services   0          0          0          0
TCP conn     1435          0       1450          0
UDP conn        0          0          0          0
ARP tbl       124          0         65          0
Xlate_Timeout  0          0          0          0
VPN IKE upd    15          0          0          0
VPN IPSEC upd  90          0          0          0
VPN CTCP upd   0          0          0          0
VPN SDI upd    0          0          0          0
VPN DHCP upd   0          0          0          0
SIP Session    0          0          0          0

```

#### Logical Update Queue Information

```

          Cur      Max      Total
Recv Q:      0         1      1895
Xmit Q:       0         0      1940

```

The following is sample output from the **show failover** command on the ASA 5505 series adaptive security appliance:

```

Failover On
Failover unit Primary
Failover LAN Interface: fover Vlan150 (up)
Unit Poll frequency 1 seconds, holdtime 15 seconds
Interface Poll frequency 5 seconds, holdtime 25 seconds
Interface Policy 1
Monitored Interfaces 4 of 250 maximum
Version: Ours 7.2(0)55, Mate 7.2(0)55
Last Failover at: 19:59:58 PST Apr 6 2006

```

#### This host: Primary - Active

```

Active time: 34 (sec)
slot 0: ASA5505 hw/sw rev (1.0/7.2(0)55) status (Up Sys)
  Interface inside (192.168.1.1): Normal
  Interface outside (192.168.2.201): Normal
  Interface dmz (172.16.0.1): Normal
  Interface test (172.23.62.138): Normal
slot 1: empty

```

#### Other host: Secondary - Standby Ready

```

Active time: 0 (sec)
slot 0: ASA5505 hw/sw rev (1.0/7.2(0)55) status (Up Sys)
  Interface inside (192.168.1.2): Normal
  Interface outside (192.168.2.211): Normal
  Interface dmz (172.16.0.2): Normal
  Interface test (172.23.62.137): Normal
slot 1: empty

```

The following is sample output from the **show failover state** command for an active-active setup:

```
hostname(config)# show failover state
```

	State	Last Failure Reason	Date/Time
This host -	Secondary		
Group 1	Failed	Backplane Failure	03:42:29 UTC Apr 17 2009
Group 2	Failed	Backplane Failure	03:42:29 UTC Apr 17 2009
Other host -	Primary		
Group 1	Active	Comm Failure	03:41:12 UTC Apr 17 2009
Group 2	Active	Comm Failure	03:41:12 UTC Apr 17 2009

```

====Configuration State====
    Sync Done
====Communication State====
    Mac set

```

The following is sample output from the **show failover state** command for an active-standby setup:

```
hostname(config)# show failover state
```

	State	Last Failure Reason	Date/Time
This host -	Primary		
	Negotiation	Backplane Failure	15:44:56 UTC Jun 20 2009
Other host -	Secondary		
	Not Detected	Comm Failure	15:36:30 UTC Jun 20 2009

```

====Configuration State====
    Sync Done
====Communication State====
    Mac set

```

Table 26-9 describes the output of the **show failover state** command.

**Table 26-9** *show failover state Output Description*

Field	Description
Configuration State	<p>Displays the state of configuration synchronization.</p> <p>The following are possible configuration states for the standby unit:</p> <ul style="list-style-type: none"> <li>• <b>Config Syncing - STANDBY</b>—Set while the synchronized configuration is being executed.</li> <li>• <b>Interface Config Syncing - STANDBY</b></li> <li>• <b>Sync Done - STANDBY</b>—Set when the standby unit has completed a configuration synchronization from the active unit.</li> </ul> <p>The following are possible configuration states for the active unit:</p> <ul style="list-style-type: none"> <li>• <b>Config Syncing</b>—Set on the active unit when it is performing a configuration synchronization to the standby unit.</li> <li>• <b>Interface Config Syncing</b></li> <li>• <b>Sync Done</b>—Set when the active unit has completed a successful configuration synchronization to the standby unit.</li> <li>• <b>Ready for Config Sync</b>—Set on the active unit when the standby unit signals that it is ready to receive a configuration synchronization.</li> </ul>
Communication State	<p>Displays the status of the MAC address synchronization.</p> <ul style="list-style-type: none"> <li>• <b>Mac set</b>—The MAC addresses have been synchronized from the peer unit to this unit.</li> <li>• <b>Updated Mac</b>—Used when a MAC address is updated and needs to be synchronized to the other unit. Also used during the transition period where the unit is updating the local MAC addresses synchronized from the peer unit.</li> </ul>
Date/Time	Displays a date and timestamp for the failure.
Last Failure Reason	<p>Displays the reason for the last reported failure. This information is not cleared, even if the failure condition is cleared. This information changes only when a failover occurs.</p> <p>The following are possible fail reasons:</p> <ul style="list-style-type: none"> <li>• <b>Ifc Failure</b>—The number of interfaces that failed met the failover criteria and caused failover.</li> <li>• <b>Comm Failure</b>—The failover link failed or peer is down.</li> <li>• <b>Backplane Failure</b></li> </ul>
State	Displays the Primary/Secondary and Active/Standby status for the unit.
This host/Other host	This host indicates information for the device upon which the command was executed. Other host indicates information for the other device in the failover pair.

The following is sample output from the **show failover history** command:

```
hostname# show failover history
```

```

=====
From State          To State          Reason
=====
At 16:28:50 UTC Sep 9 2006
Not Detected        Negotiation        No Error

At 16:29:18 UTC Sep 9 2006
Negotiation         Cold Standby       Detected an Active mate

At 16:29:19 UTC Sep 9 2006
Cold Standby        Sync Config        Detected an Active mate

At 16:29:31 UTC Sep 9 2006
Sync Config         Sync File System   Detected an Active mate

At 16:29:31 UTC Sep 9 2006
Sync File System    Bulk Sync          Detected an Active mate

At 16:29:36 UTC Sep 9 2006
Bulk Sync           Standby Ready      Detected an Active mate

At 16:30:52 UTC Sep 9 2006
Standby Ready       Just Active        Set by the CI config cmd

At 16:30:52 UTC Sep 9 2006
Just Active         Active Drain       Set by the CI config cmd

At 16:30:52 UTC Sep 9 2006
Active Drain        Active Applying Config Set by the CI config cmd

At 16:30:52 UTC Sep 9 2006
Active Applying Config Active Config Applied Set by the CI config cmd

At 16:30:52 UTC Sep 9 2006
Active Config Applied Active              Set by the CI config cmd

At 16:30:55 UTC Sep 9 2006
Active              Disabled           Set by the CI config cmd
=====

```

Each entry provides the time and date the state change occurred, the beginning state, the resulting state, and the reason for the state change. The newest entries are located at the bottom of the display. Older entries appear at the top. A maximum of 60 entries can be displayed. Once the maximum number of entries has been reached, the oldest entries are removed from the top of the output as new entries are added to the bottom.

[Table 26-10](#) shows the failover states. There are two types of states—stable and transient. Stable states are states that the unit can remain in until some occurrence, such as a failure, causes a state change. A transient state is a state that the unit passes through while reaching a stable state.

**Table 26-10 Failover States**

State	Description
Initialization	The unit checks platform capabilities and configuration and prepares the failover communication channels. This is a transient state.
Disabled	Failover is disabled. This is a stable state.



**Table 26-10 Failover States**

State	Description
Negotiation	The unit establishes the connection with peer and negotiates with peer to determine software version compatibility and Active/Standby role. Depending upon the role that is negotiated, the unit will go through the Standby Unit States or the Active Unit States or enter the failed state. This is a transient state.
Failed	The unit is in the failed state. This is a stable state.
<b>Standby Unit States</b>	
Cold Standby	The unit waits for the peer to reach the Active state. When the peer unit reaches the Active state, this unit progresses to the Standby Config state. This is a transient state.
Sync Config	The unit requests the running configuration from the peer unit. If an error occurs during the configuration synchronization, the unit returns to the Initialization state. This is a transient state.
Sync File System	The unit synchronizes the file system with the peer unit. This is a transient state.
Bulk Sync	The unit receives state information from the peer. This state only occurs when Stateful Failover is enabled. This is a transient state.
Standby Ready	The unit is ready to take over if the active unit fails. This is a stable state.
<b>Active Unit States</b>	
Just Active	The first state the unit enters when becoming the active unit. During this state a message is sent to the peer alerting the peer that the unit is becoming active and the IP and MAC addresses are set for the interfaces. This is a transient state.
Active Drain	Queues messages from the peer are discarded. This is a transient state.
Active Applying Config	The unit is applying the system configuration. This is a transient state.
Active Config Applied	The unit has finished applying the system configuration. This is a transient state.
Active	The unit is active and processing traffic. This is a stable state.

Each state change is followed by a reason for the state change. The reason typically remains the same as the unit progresses through the transient states to the stable state. The following are the possible state change reasons:

- No Error
- Set by the CI config cmd
- Failover state check
- Failover interface become OK
- HELLO not heard from mate
- Other unit has different software version
- Other unit operating mode is different
- Other unit license is different

- Other unit chassis configuration is different
- Other unit card configuration is different
- Other unit want me Active
- Other unit want me Standby
- Other unit reports that I am failed
- Other unit reports that it is failed
- Configuration mismatch
- Detected an Active mate
- No Active unit found
- Configuration synchronization done
- Recovered from communication failure
- Other unit has different set of vlans configured
- Unable to verify vlan configuration
- Incomplete configuration synchronization
- Configuration synchronization failed
- Interface check
- My communication failed
- ACK not received for failover message
- Other unit got stuck in learn state after sync
- No power detected from peer
- No failover cable
- HA state progression failed
- Detect service card failure
- Service card in other unit has failed
- My service card is as good as peer
- LAN Interface become un-configured
- Peer unit just reloaded
- Switch from Serial Cable to LAN-Based fover
- Unable to verify state of config sync
- Auto-update request
- Unknown reason

---

**Related Commands**

Command	Description
<b>show running-config failover</b>	Displays the <b>failover</b> commands in the current configuration.

---

# show failover exec

To display the **failover exec** command mode for the specified unit, use the **show failover exec** command in privileged EXEC mode.

**show failover exec {active | standby | mate}**

## Syntax Description

<b>active</b>	Displays the <b>failover exec</b> command mode for the active unit.
<b>mate</b>	Displays the <b>failover exec</b> command mode for the peer unit.
<b>standby</b>	Displays the <b>failover exec</b> command mode for the standby unit.

## Defaults

No default behavior or values.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Privileged EXEC	•	•	•	•	•

## Command History

Release	Modification
8.0(2)	This command was introduced.

## Usage Guidelines

The **failover exec** command creates a session with the specified device. By default, that session is in global configuration mode. You can change the command mode of that session by sending the appropriate command (such as the **interface** command) using the **failover exec** command. Changing **failover exec** command modes for the specified device does not change the command mode for the session you are using to access the device. Changing commands modes for your current session to the device does not affect the command mode used by the **failover exec** command.

The **show failover exec** command displays the command mode on the specified device in which commands sent with the **failover exec** command are executed.

## Examples

The following is sample output from the **show failover exec** command. This example demonstrates that the command mode for the unit where the **failover exec** commands are being entered does not have to be the same as the **failover exec** command mode where the commands are being executed.

In this example, an administrator logged into the standby unit adds a name to an interface on the active unit. The second time the **show failover exec mate** command is entered in this example shows the peer device in interface configuration mode. Commands sent to the device with the **failover exec** command are executed in that mode.

```
hostname(config)# show failover exec mate
```

**show failover exec**

Active unit Failover EXEC is at config mode

*! The following command changes the standby unit failover exec mode  
! to interface configuration mode.*

```
hostname(config)# failover exec mate interface GigabitEthernet0/1  
hostname(config)# show failover exec mate
```

Active unit Failover EXEC is at interface sub-command mode

*! Because the following command is sent to the active unit, it is replicated  
! back to the standby unit.*

```
hostname(config)# failover exec mate nameif test
```

**Related Commands**

Command	Description
<b>failover exec</b>	Executes the supplied command on the designated unit in a failover pair.

# show file

To display information about the file system, use the **show file** command in privileged EXEC mode.

**show file descriptors | system | information** *filename*

## Syntax Description

<b>descriptors</b>	Displays all open file descriptors.
<i>filename</i>	Specifies the filename.
<b>information</b>	Displays information about a specific file.
<b>system</b>	Displays the size, bytes available, type of media, flags, and prefix information about the disk file system.

## Defaults

No default behavior or values.

## Command Modes

The following table shows the modes in which you can enter the command:

	Firewall Mode		Security Context		
				Multiple	
Command Mode	Routed	Transparent	Single	Context	System
Privileged EXEC	•	•	•	•	•

## Command History

Release	Modification
7.0(1)	This command was introduced.

## Examples

The following example shows how to display file system information:

```
hostname# show file descriptors
No open file descriptors
hostname# show file system
File Systems:
  Size(b)    Free(b)    Type  Flags  Prefixes
* 60985344   60973056   disk   rw     disk:
```

## Related Commands

Command	Description
<b>dir</b>	Displays the directory contents.
<b>pwd</b>	Displays the current working directory.

# show firewall

To show the current firewall mode (routed or transparent), use the **show firewall** command in privileged EXEC mode.

**show firewall**

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Privileged EXEC	•	•	•	•	•

Release	Modification
7.0(1)	This command was introduced.

**Examples** The following is sample output from the **show firewall** command:

```
hostname# show firewall
Firewall mode: Router
```

Command	Description
<b>firewall transparent</b>	Sets the firewall mode.
<b>show mode</b>	Shows the current context mode, either single or multiple.

# show flash

To display the contents of the internal Flash memory, use the **show flash:** command in privileged EXEC mode.

**show flash:**



## Note

In the ASA 5500 series, the **flash** keyword is aliased to **disk0**.

## Syntax Description

This command has no arguments or keywords.

## Defaults

No default behavior or values.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Privileged EXEC	•	•	•	•	•

## Command History

Release	Modification
Preexisting	This command was preexisting.

## Examples

The following example shows how to display the contents of the internal Flash memory:

```
hostname# show flash:
-#- --length-- -----date/time----- path
11 1301      Feb 21 2005 18:01:34 test.cfg
12 1949      Feb 21 2005 20:13:36 pepsi.cfg
13 2551      Jan 06 2005 10:07:36 Leo.cfg
14 609223    Jan 21 2005 07:14:18 rr.cfg
15 1619      Jul 16 2004 16:06:48 hackers.cfg
16 3184      Aug 03 2004 07:07:00 old_running.cfg
17 4787      Mar 04 2005 12:32:18 admin.cfg
20 1792      Jan 21 2005 07:29:24 Marketing.cfg
21 7765184   Mar 07 2005 19:38:30 asdmfile-RLK
22 1674      Nov 11 2004 02:47:52 potts.cfg
23 1863      Jan 21 2005 07:29:18 r.cfg
24 1197      Jan 19 2005 08:17:48 tst.cfg
25 608554    Jan 13 2005 06:20:54 500kconfig
26 5124096   Feb 20 2005 08:49:28 cdisk70102
27 5124096   Mar 01 2005 17:59:56 cdisk70104
28 2074      Jan 13 2005 08:13:26 negateACL
29 5124096   Mar 07 2005 19:56:58 cdisk70105
30 1276      Jan 28 2005 08:31:58 steel
31 7756788   Feb 24 2005 12:59:46 asdmfile.50074.dbg
```

## ■ show flash

```

32 7579792    Mar 08 2005 11:06:56 asdmfile.gusingh
33 7764344    Mar 04 2005 12:17:46 asdmfile.50075.dbg
34 5124096    Feb 24 2005 11:50:50 cdisk70103
35 15322      Mar 04 2005 12:30:24 hs_err_pid2240.log

```

10170368 bytes available (52711424 bytes used)

**Related Commands**

Command	Description
<b>dir</b>	Displays the directory contents.
<b>show disk0</b>	Displays the contents of the internal Flash memory.
<b>show disk1</b>	Displays the contents of the external Flash memory card.



# show flow-export counters

To display runtime counters associated with NetFlow data, use the **show flow-export counters** command in privileged EXEC mode.

## show flow-export counters

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Privileged EXEC	•	•	•	•	—

Command History	Release	Modification
	8.1(1)	This command was introduced.

**Usage Guidelines** The runtime counters include statistical data as well as error data.

**Examples** The following is sample output from the **show flow-export counters** command that shows runtime counters that are associated with NetFlow data:

```
hostname# show flow-export counters

destination: inside 209.165.200.224 2055
Statistics:
  packets sent                      1000
Errors:
  block allocation failure          0
  invalid interface                 0
  template send failure             0
```

Related Commands	Commands	Description
	<b>clear flow-export counters</b>	Resets all runtime counters in NetFlow to zero.
	<b>flow-export destination</b> <i>interface-name</i> <i>ipv4-address</i>   <i>hostname</i> <i>udp-port</i>	Specifies the IP address or hostname of the NetFlow collector, and the UDP port on which the NetFlow collector is listening.
	<b>flow-export template</b> <b>timeout-rate</b> <i>minutes</i>	Controls the interval at which the template information is sent to the NetFlow collector.
	<b>logging</b> <b>flow-export-syslogs enable</b>	Enables syslog messages after you have entered the <b>logging</b> <b>flow-export-syslogs disable</b> command, and the syslog messages that are associated with NetFlow data.

# show fragment

To display the operational data of the IP fragment reassembly module, enter the **show fragment** command in privileged EXEC mode.

**show fragment** [*interface*]

## Syntax Description

*interface* (Optional) Specifies the security appliance interface.

## Defaults

If an *interface* is not specified, the command applies to all interfaces.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Privileged EXEC mode	•	•	•	•	•

## Command History

Release	Modification
7.0(1)	The command was separated into two commands, <b>show fragment</b> and <b>show running-config fragment</b> , to separate the configuration data from the operational data.

## Examples

This example shows how to display the operational data of the IP fragment reassembly module:

```
hostname# show fragment
Interface: inside
  Size: 200, Chain: 24, Timeout: 5, Threshold: 133
  Queue: 0, Assembled: 0, Fail: 0, Overflow: 0
Interface: outside1
  Size: 200, Chain: 24, Timeout: 5, Threshold: 133
  Queue: 0, Assembled: 0, Fail: 0, Overflow: 0
Interface: test1
  Size: 200, Chain: 24, Timeout: 5, Threshold: 133
  Queue: 0, Assembled: 0, Fail: 0, Overflow: 0
Interface: test2
  Size: 200, Chain: 24, Timeout: 5, Threshold: 133
  Queue: 0, Assembled: 0, Fail: 0, Overflow: 0
```

## Related Commands

Command	Description
<b>clear configure fragment</b>	Clears the IP fragment reassembly configuration and resets the defaults.
<b>clear fragment</b>	Clears the operational data of the IP fragment reassembly module.

Command	Description
<b>fragment</b>	Provides additional management of packet fragmentation and improves compatibility with NFS.
<b>show running-config fragment</b>	Displays the IP fragment reassembly configuration.

# show gc

To display the garbage collection process statistics, use the **show gc** command in privileged EXEC mode.

**show gc**

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behaviors or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Privileged EXEC	•	•	•	•	•

Command History	Release	Modification
	Preexisting	This command was preexisting.

**Examples** The following is sample output from the **show gc** command:

```
hostname# show gc
```

```
Garbage collection process stats:
Total tcp conn delete response      :          0
Total udp conn delete response      :          0
Total number of zombie cleaned      :          0
Total number of embryonic conn cleaned :          0
Total error response                 :          0
Total queries generated              :          0
Total queries with conn present response :          0
Total number of sweeps               :         946
Total number of invalid vcid         :          0
Total number of zombie vcid          :          0
```

Related Commands	Command	Description
	<b>clear gc</b>	Removes the garbage collection process statistics.

# show h225

To display information for H.225 sessions established across the security appliance, use the **show h225** command in privileged EXEC mode.

## show h225

### Syntax Description

This command has no arguments or keywords.

### Defaults

No default behavior or values.

### Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Privileged EXEC	•	•	•	•	•

### Command History

Release	Modification
Preexisting	This command was preexisting.

### Usage Guidelines

The **show h225** command displays information for H.225 sessions established across the security appliance. Along with the **debug h323 h225 event**, **debug h323 h245 event**, and **show local-host** commands, this command is used for troubleshooting H.323 inspection engine issues.

Before using the **show h225**, **show h245**, or **show h323-ras** commands, we recommend that you configure the **pager** command. If there are a lot of session records and the **pager** command is not configured, it may take a while for the **show** output to reach its end. If there is an abnormally large number of connections, check that the sessions are timing out based on the default timeout values or the values set by you. If they are not, then there is a problem that needs to be investigated.

### Examples

The following is sample output from the **show h225** command:

```
hostname# show h225
Total H.323 Calls: 1
1 Concurrent Call(s) for
| Local: | 10.130.56.3/1040 | Foreign: 172.30.254.203/1720
| 1. CRV 9861
| Local: | 10.130.56.3/1040 | Foreign: 172.30.254.203/1720
0 Concurrent Call(s) for
| Local: | 10.130.56.4/1050 | Foreign: 172.30.254.205/1720
```

This output indicates that there is currently 1 active H.323 call going through the security appliance between the local endpoint 10.130.56.3 and foreign host 172.30.254.203, and for these particular endpoints, there is 1 concurrent call between them, with a CRV (Call Reference Value) for that call of 9861.

For the local endpoint 10.130.56.4 and foreign host 172.30.254.205, there are 0 concurrent Calls. This means that there is no active call between the endpoints even though the H.225 session still exists. This could happen if, at the time of the **show h225** command, the call has already ended but the H.225 session has not yet been deleted. Alternately, it could mean that the two endpoints still have a TCP connection opened between them because they set “maintainConnection” to TRUE, so the session is kept open until they set it to FALSE again, or until the session times out based on the H.225 timeout value in your configuration.

**Related Commands**

Commands	Description
<b>debug h323</b>	Enables the display of debug information for H.323.
<b>inspect h323</b>	Enables H.323 application inspection.
<b>show h245</b>	Displays information for H.245 sessions established across the security appliance by endpoints using slow start.
<b>show h323-ras</b>	Displays information for H.323 RAS sessions established across the security appliance.
<b>timeout h225   h323</b>	Configures idle time after which an H.225 signalling connection or an H.323 control connection will be closed.

# show h245

To display information for H.245 sessions established across the security appliance by endpoints using slow start, use the **show h245** command in privileged EXEC mode.

**show h245**

## Syntax Description

This command has no arguments or keywords.

## Defaults

No default behavior or values.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Privileged EXEC	•	•	•	•	•

## Command History

Release	Modification
Preexisting	This command was preexisting.

## Usage Guidelines

The **show h245** command displays information for H.245 sessions established across the security appliance by endpoints using slow start. (Slow start is when the two endpoints of a call open another TCP control channel for H.245. Fast start is where the H.245 messages are exchanged as part of the H.225 messages on the H.225 control channel.) Along with the **debug h323 h245 event**, **debug h323 h225 event**, and **show local-host** commands, this command is used for troubleshooting H.323 inspection engine issues.

## Examples

The following is sample output from the **show h245** command:

```
hostname# show h245
Total: 1
| LOCAL | TPKT | FOREIGN | TPKT
1 | 10.130.56.3/1041 | 0 | 172.30.254.203/1245 | 0
| MEDIA: LCN 258 Foreign 172.30.254.203 RTP 49608 RTCP 49609
| Local | 10.130.56.3 RTP 49608 RTCP 49609
| MEDIA: LCN 259 Foreign 172.30.254.203 RTP 49606 RTCP 49607
| Local | 10.130.56.3 RTP 49606 RTCP 49607
```

There is currently one H.245 control session active across the security appliance. The local endpoint is 10.130.56.3, and we are expecting the next packet from this endpoint to have a TPKT header because the TPKT value is 0. (The TKTP header is a 4-byte header preceding each H.225/H.245 message. It gives



the length of the message, including the 4-byte header.) The foreign host endpoint is 172.30.254.203, and we are expecting the next packet from this endpoint to have a TPKT header because the TPKT value is 0.

The media negotiated between these endpoints have a LCN (logical channel number) of 258 with the foreign RTP IP address/port pair of 172.30.254.203/49608 and a RTCP IP address/port of 172.30.254.203/49609 with a local RTP IP address/port pair of 10.130.56.3/49608 and a RTCP port of 49609.

The second LCN of 259 has a foreign RTP IP address/port pair of 172.30.254.203/49606 and a RTCP IP address/port pair of 172.30.254.203/49607 with a local RTP IP address/port pair of 10.130.56.3/49606 and RTCP port of 49607.

**Related Commands**

Commands	Description
<b>debug h323</b>	Enables the display of debug information for H.323.
<b>inspect h323</b>	Enables H.323 application inspection.
<b>show h245</b>	Displays information for H.245 sessions established across the security appliance by endpoints using slow start.
<b>show h323-ras</b>	Displays information for H.323 RAS sessions established across the security appliance.
<b>timeout h225   h323</b>	Configures idle time after which an H.225 signalling connection or an H.323 control connection will be closed.

# show h323-ras

To display information for H.323 RAS sessions established across the security appliance between a gatekeeper and its H.323 endpoint, use the **show h323-ras** command in privileged EXEC mode.

**show h323-ras**

## Syntax Description

This command has no arguments or keywords.

## Defaults

No default behavior or values.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Privileged EXEC	•	•	•	•	•

## Command History

Release	Modification
Preexisting	This command was preexisting.

## Usage Guidelines

The **show h323-ras** command displays information for H.323 RAS sessions established across the security appliance between a gatekeeper and its H.323 endpoint. Along with the **debug h323 ras event** and **show local-host** commands, this command is used for troubleshooting H.323 RAS inspection engine issues.

The **show h323-ras** command displays connection information for troubleshooting H.323 inspection engine issues, and is described in the **inspect protocol h323 {h225 | ras}** command page.

## Examples

The following is sample output from the **show h323-ras** command:

```
hostname# show h323-ras
Total: 1
| GK | Caller
| 172.30.254.214 10.130.56.14
hostname#
```

This output shows that there is one active registration between the gatekeeper 172.30.254.214 and its client 10.130.56.14.

## Related Commands

Commands	Description
<b>debug h323</b>	Enables the display of debug information for H.323.
<b>inspect h323</b>	Enables H.323 application inspection.
<b>show h245</b>	Displays information for H.245 sessions established across the security appliance by endpoints using slow start.
<b>show h323-ras</b>	Displays information for H.323 RAS sessions established across the security appliance.
<b>timeout h225   h323</b>	Configures idle time after which an H.225 signalling connection or an H.323 control connection will be closed.

# show history

To display previously entered commands, use the **show history** command in user EXEC mode.

## show history

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
User EXEC	•	•	•	•	•

Release	Modification
Preexisting	This command was preexisting.

**Command History**

**Usage Guidelines** The **show history** command lets you display previously entered commands. You can examine commands individually with the up and down arrows, enter **^p** to display previously entered lines, or enter **^n** to display the next line.

**Examples** The following example shows how to display previously entered commands when you are in user EXEC mode:

```
hostname> show history
show history
help
show history
```

The following example shows how to display previously entered commands in privileged EXEC mode:

```
hostname# show history
show history
help
show history
enable
show history
```

This example shows how to display previously entered commands in global configuration mode:

```
hostname(config)# show history
show history
help
```

```
show history
enable
show history
config t
show history
```

#### Related Commands

Command	Description
<b>help</b>	Displays help information for the command specified.

# show idb

To display information about the status of interface descriptor blocks, use the **show idb** command in privileged EXEC mode.

## show idb

### Syntax Description

This command has no arguments or keywords.

### Defaults

No default behavior or values.

### Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
User EXEC	•	•	•	—	•

### Command History

Release	Modification
7.0(1)	This command was introduced.

### Usage Guidelines

IDBs are the internal data structure representing interface resources. See the “[Examples](#)” section for a description of the display output.

### Examples

The following is sample output from the **show idb** command:

```
hostname# show idb
Maximum number of Software IDBs 280. In use 23.

              HWIDBs      SWIDBs
              Active 6      21
              Inactive 1      2
              Total IDBs 7      23
Size each (bytes) 116      212
Total bytes 812      4876

HWIDB# 1 0xbb68ebc Control0/0
HWIDB# 2 0xcd47d84 GigabitEthernet0/0
HWIDB# 3 0xcd4c1dc GigabitEthernet0/1
HWIDB# 4 0xcd5063c GigabitEthernet0/2
HWIDB# 5 0xcd54a9c GigabitEthernet0/3
HWIDB# 6 0xcd58f04 Management0/0

SWIDB# 1 0x0bb68f54 0x01010001 Control0/0
SWIDB# 2 0x0cd47e1c 0xffffffff GigabitEthernet0/0
SWIDB# 3 0x0cd772b4 0xffffffff GigabitEthernet0/0.1
```

```

PEER IDB# 1 0x0d44109c 0xffffffff 3 GigabitEthernet0/0.1
PEER IDB# 2 0x0d2c0674 0x00020002 2 GigabitEthernet0/0.1
PEER IDB# 3 0x0d05a084 0x00010001 1 GigabitEthernet0/0.1
SWIDB# 4 0x0bb7501c 0xffffffff GigabitEthernet0/0.2
SWIDB# 5 0x0cd4c274 0xffffffff GigabitEthernet0/1
SWIDB# 6 0x0bb75704 0xffffffff GigabitEthernet0/1.1
PEER IDB# 1 0x0cf8686c 0x00020003 2 GigabitEthernet0/1.1
SWIDB# 7 0x0bb75dec 0xffffffff GigabitEthernet0/1.2
PEER IDB# 1 0x0d2c08ac 0xffffffff 2 GigabitEthernet0/1.2
SWIDB# 8 0x0bb764d4 0xffffffff GigabitEthernet0/1.3
PEER IDB# 1 0x0d441294 0x00030001 3 GigabitEthernet0/1.3
SWIDB# 9 0x0cd506d4 0x01010002 GigabitEthernet0/2
SWIDB# 10 0x0cd54b34 0xffffffff GigabitEthernet0/3
PEER IDB# 1 0x0d3291ec 0x00030002 3 GigabitEthernet0/3
PEER IDB# 2 0x0d2c0aa4 0x00020001 2 GigabitEthernet0/3
PEER IDB# 3 0x0d05a474 0x00010002 1 GigabitEthernet0/3
SWIDB# 11 0x0cd58f9c 0xffffffff Management0/0
PEER IDB# 1 0x0d05a65c 0x00010003 1 Management0/0

```

Table 26-1 shows each field description.

**Table 26-1** show idb stats Fields

Field	Description
HWIDBs	Shows the statistics for all HWIDBs. HWIDBs are created for each hardware port in the system.
SWIDBs	Shows the statistics for all SWIDBs. SWIDBs are created for each main and subinterface in the system, and for each interface that is allocated to a context. Some other internal software modules also create IDBs.
HWIDB#	Specifies a hardware interface entry. The IDB sequence number, address, and interface name is displayed in each line.
SWIDB#	Specifies a software interface entry. The IDB sequence number, address, corresponding vPif id, and interface name are displayed in each line.
PEER IDB#	Specifies an interface allocated to a context. The IDB sequence number, address, corresponding vPif id, context id and interface name are displayed in each line.

#### Related Commands

Command	Description
<b>interface</b>	Configures an interface and enters interface configuration mode.
<b>show interface</b>	Displays the runtime status and statistics of interfaces.

# show igmp groups

To display the multicast groups with receivers that are directly connected to the security appliance and that were learned through IGMP, use the **show igmp groups** command in privileged EXEC mode.

**show igmp groups** [[**reserved** | *group*] [*if\_name*] [**detail**]] | **summary**

## Syntax Description

<b>detail</b>	(Optional) Provides a detailed description of the sources.
<i>group</i>	(Optional) The address of an IGMP group. Including this optional argument limits the display to the specified group.
<i>if_name</i>	(Optional) Displays group information for the specified interface.
<b>reserved</b>	(Optional) Displays information about reserved groups.
<b>summary</b>	(Optional) Displays group joins summary information.

## Defaults

No default behavior or values.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Privileged EXEC	•	—	•	—	—

## Command History

Release	Modification
7.0(1)	This command was introduced.

## Usage Guidelines

If you omit all optional arguments and keywords, the **show igmp groups** command displays all directly connected multicast groups by group address, interface type, and interface number.



---

**Examples**

The following is sample output from the **show igmp groups** command:

```
hostname#show igmp groups
```

```
IGMP Connected Group Membership
Group Address      Interface      Uptime      Expires      Last Reporter
224.1.1.1          inside        00:00:53    00:03:26    192.168.1.6
```

---

**Related Commands**

Command	Description
<b>show igmp interface</b>	Displays multicast information for an interface.

# show igmp interface

To display multicast information for an interface, use the **show igmp interface** command in privileged EXEC mode.

**show igmp interface** [*if\_name*]

## Syntax Description

*if\_name* (Optional) Displays IGMP group information for the selected interface.

## Defaults

No default behavior or values.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Privileged EXEC	•	—	•	—	—

## Command History

Release	Modification
7.0(1)	This command was modified. The <b>detail</b> keyword was removed.

## Usage Guidelines

If you omit the optional *if\_name* argument, the **show igmp interface** command displays information about all interfaces.

## Examples

The following is sample output from the **show igmp interface** command:

```
hostname# show igmp interface inside

inside is up, line protocol is up
Internet address is 192.168.37.6, subnet mask is 255.255.255.0
IGMP is enabled on interface
IGMP query interval is 60 seconds
Inbound IGMP access group is not set
Multicast routing is enabled on interface
Multicast TTL threshold is 0
Multicast designated router (DR) is 192.168.37.33
No multicast groups joined
```

## Related Commands

Command	Description
<b>show igmp groups</b>	Displays the multicast groups with receivers that are directly connected to the security appliance and that were learned through IGMP.

# show igmp traffic

To display IGMP traffic statistics, use the **show igmp traffic** command in privileged EXEC mode.

**show igmp traffic**

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Privileged EXEC	•	—	•	—	—

Command History	Release	Modification
	7.0(1)	This command was introduced.

**Examples** The following is sample output from the **show igmp traffic** command:

```
hostname# show igmp traffic

IGMP Traffic Counters
Elapsed time since counters cleared: 00:02:30
Received      Sent
Valid IGMP Packets      3         6
Queries                  2         6
Reports                  1         0
Leaves                   0         0
Mtrace packets          0         0
DVMRP packets           0         0
PIM packets              0         0

Errors:
Malformed Packets       0
Martian source           0
Bad Checksums            0
```

Related Commands	Command	Description
	<b>clear igmp counters</b>	Clears all IGMP statistic counters.
	<b>clear igmp traffic</b>	Clear the IGMP traffic counters.

# show import webvpn

To list the WebVPN custom data and plug-ins that currently are present in flash memory on the security appliance, enter the **show import webvpn** (*option*) command in privileged EXEC mode.

**show import webvpn | customization | plug-in | plug-in detail | translation-table | url-list | webcontent**

## Syntax Description

This command has no arguments or keywords.

## Defaults

No default behavior or values.

## Command Modes

The following table shows the modes in which you can enter the command:

	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Privileged EXEC mode	•	—	•	—	—

## Command History

Release	Modification
8.0(2)	This command was introduced.

## Usage Guidelines

Use the **show import webvpn** command to identify the custom data and the Java-based client applications available to WebVPN users. The displayed list itemizes all of the requested data types that are in flash memory on the security appliance.

Each of the show import webvpn command displays the following currently loaded WebVPN data:

- Customization - customization object (file names base64 decoded)
- Plug-in - Third-party Java-based client applications (SSH, VNC, and RDP)
- Plug-in detail - The hash and date information for each plug-in.
- Translation Table - Localization/internationalization dictionary tables
- URL-list - URL list objects (file names base64 decoded)
- Web content - disk0:/cisco\_config/htms recursively (all files full names)

## Example

The following illustrates the WebVPN data displayed by various **show import webvpn** command:

```
hostname# show import webvpn plug-in
ssh
rdp
vnc
hostname#
```

```

hostname# show import webvpn customization
Template
DfltCustomization
hostname#

hostname# show import webvpn translation-table
Translation Tables' Templates:
  AnyConnect
  PortForwarder
  banners
  csd
  customization
  url-list
  webvpn
Translation Tables:
  ru                                customization
  ua                                customization
hostname#

hostname# show import webvpn url-list
Template
No bookmarks are currently defined
hostname#

hostname# show import webvpn webcontent
No custom webcontent is loaded
hostname#

```

## Related Commands

Command	Description
<b>revert webvpn all</b>	Removes all WebVPN data and plug-in current on the security appliance.

# show interface

To view interface statistics, use the **show interface** command in privileged EXEC mode.

```
show interface [{physical_interface | redundantnumber}[.subinterface] | mapped_name |  
interface_name] [stats | detail]
```

## Syntax Description

<b>detail</b>	(Optional) Shows detailed interface information, including the order in which the interface was added, the configured state, the actual state, and asymmetrical routing statistics, if enabled by the <b>asr-group</b> command.
<i>interface_name</i>	(Optional) Identifies the interface name set with the <b>nameif</b> command.
<i>mapped_name</i>	(Optional) In multiple context mode, identifies the mapped name if it was assigned using the <b>allocate-interface</b> command.
<i>physical_interface</i>	(Optional) Identifies the interface ID, such as <b>gigabitethernet 3/1</b> . See the <b>interface</b> command for accepted values.
<b>redundantnumber</b>	(Optional) Identifies the redundant interface ID, such as <b>redundant1</b> .
<b>stats</b>	(Default) Shows interface information and statistics. This keyword is the default, so this keyword is optional.
<i>subinterface</i>	(Optional) Identifies an integer between 1 and 4294967293 designating a logical subinterface.

## Defaults

If you do not identify any options, this command shows basic statistics for all interfaces.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Privileged EXEC	•	•	•	•	•

## Command History

Release	Modification
7.0(1)	This command was modified to include the new interface numbering scheme, and to add the <b>stats</b> keyword for clarity, and the <b>detail</b> keyword.
7.0(4)	This command added support for the 4GE SSM interfaces.
7.2(1)	This command added support for switch interfaces.
8.0(2)	This command added support for redundant interfaces. Also, the delay is added for subinterfaces. Two new counters were added: input reset drops and output reset drops.
8.1(1)	This command added support for the TenGigabitEthernet interface.

**Usage Guidelines**

If an interface is shared among contexts, and you enter this command within a context, the security appliance shows only statistics for the current context. When you enter this command in the system execution space for a physical interface, the security appliance shows the combined statistics for all contexts.

The number of statistics shown for subinterfaces is a subset of the number of statistics shown for a physical interface.

You cannot use the interface name in the system execution space, because the **nameif** command is only available within a context. Similarly, if you mapped the interface ID to a mapped name using the **allocate-interface** command, you can only use the mapped name in a context. If you set the **visible** keyword in the **allocate-interface** command, the security appliance shows the interface ID in the output of the **show interface** command.

**Note**

The number of bytes transmitted or received in the Hardware count and the Traffic Statistics count are different.

In the hardware count, the amount is retrieved directly from hardware, and reflects the Layer 2 packet size. While in traffic statistics, it reflects the Layer 3 packet size.

The count difference is varied based upon the design of the interface card hardware.

For example, for a Fast Ethernet card, the Layer 2 count is 14 bytes greater than the traffic count, because it includes the Ethernet header. On the Gigabit Ethernet card, the Layer 2 count is 18 bytes greater than the traffic count, because it includes both the Ethernet header and the CRC.

See the “[Examples](#)” section for a description of the display output.

**Examples**

The following is sample output from the **show interface** command:

```
hostname# show interface
Interface Management0/0 "mgmt", is up, line protocol is up
  Hardware is bcm5706C rev02, BW 1000 Mbps, DLY 10 usec
    Auto-Duplex(Full-duplex), Auto-Speed(1000 Mbps)
    MAC address 0016.3582.1e28, MTU 1500
    IP address 10.0.8.112, subnet mask 255.255.255.0
    108032 packets input, 11376344 bytes, 0 no buffer
    Received 92710 broadcasts, 0 runts, 0 giants
    0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
    0 L2 decode drops
    28128 packets output, 20012287 bytes, 0 underruns
    0 output errors, 0 collisions, 0 interface resets
    0 late collisions, 0 deferred
    0 input reset drops, 0 output reset drops
    input queue (curr/max packets): hardware (11/52)
    output queue (curr/max packets): hardware (12/26)
  Traffic Statistics for "mgmt":
    108032 packets input, 9347396 bytes
    28128 packets output, 19496565 bytes
    45611 packets dropped
    1 minute input rate 0 pkts/sec, 121 bytes/sec
    1 minute output rate 0 pkts/sec, 0 bytes/sec
    1 minute drop rate, 0 pkts/sec
    5 minute input rate 0 pkts/sec, 52 bytes/sec
    5 minute output rate 0 pkts/sec, 0 bytes/sec
    5 minute drop rate, 0 pkts/sec
```

```

Interface Management0/1 "", is administratively down, line protocol is down
  Hardware is bcm5706C rev02, BW 1000 Mbps, DLY 10 usec
    Auto-Duplex, Auto-Speed
    Available but not configured via nameif
    MAC address 0016.3582.1e2a, MTU not set
    IP address unassigned
    0 packets input, 0 bytes, 0 no buffer
    Received 0 broadcasts, 0 runts, 0 giants
    0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
    0 L2 decode drops
    0 packets output, 0 bytes, 0 underruns
    0 output errors, 0 collisions, 0 interface resets
    0 late collisions, 0 deferred
    0 input reset drops, 0 output reset drops
    input queue (curr/max packets): hardware (0/0)
    output queue (curr/max packets): hardware (0/0)
Interface GigabitEthernet3/0 "", is administratively down, line protocol is up
  Hardware is i82571EB 4CU rev06, BW 1000 Mbps, DLY 10 usec
    Auto-Duplex(Full-duplex), Auto-Speed(1000 Mbps)
    Available but not configured via nameif
    MAC address 0015.1715.592c, MTU not set
    IP address 10.12.135.96, subnet mask 255.255.255.0
    920 packets input, 58880 bytes, 409 no buffer
    Received 920 broadcasts, 0 runts, 0 giants
    0 input errors, 0 CRC, 0 frame, 5728 overrun, 0 ignored, 0 abort
    0 L2 decode drops
    0 packets output, 0 bytes, 0 underruns
    0 output errors, 0 collisions, 0 interface resets
    0 late collisions, 0 deferred
    0 input reset drops, 0 output reset drops
    input queue (curr/max packets): hardware (0/511)
    output queue (curr/max packets): hardware (0/0)
Interface GigabitEthernet3/1 "inside", is up, line protocol is up
  Hardware is i82571EB 4CU rev06, BW 1000 Mbps, DLY 10 usec
    Auto-Duplex(Full-duplex), Auto-Speed(1000 Mbps)
    MAC address 0015.1715.592d, MTU 1500
    IP address 10.0.72.96, subnet mask 255.255.255.0
    137291 packets input, 9832141 bytes, 0 no buffer
    Received 137283 broadcasts, 0 runts, 0 giants
    0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
    0 L2 decode drops
    13 packets output, 832 bytes, 0 underruns
    0 output errors, 0 collisions, 0 interface resets
    0 late collisions, 0 deferred
    0 input reset drops, 0 output reset drops
    input queue (curr/max packets): hardware (41/511)
    output queue (curr/max packets): hardware (13/13)
  Traffic Statistics for "inside":
    137291 packets input, 7360903 bytes
    13 packets output, 364 bytes
    21092 packets dropped
    1 minute input rate 0 pkts/sec, 47 bytes/sec
    1 minute output rate 0 pkts/sec, 0 bytes/sec
    1 minute drop rate, 0 pkts/sec
    5 minute input rate 0 pkts/sec, 43 bytes/sec
    5 minute output rate 0 pkts/sec, 0 bytes/sec
    5 minute drop rate, 0 pkts/sec
Interface GigabitEthernet3/2 "", is up, line protocol is up
  Hardware is i82571EB 4CU rev06, BW 1000 Mbps, DLY 10 usec
    Auto-Duplex(Full-duplex), Auto-Speed(1000 Mbps)
    Available but not configured via nameif
    MAC address 0015.1715.592e, MTU not set
    IP address 10.0.73.96, subnet mask 255.255.255.0
    0 packets input, 0 bytes, 0 no buffer

```



```

Received 0 broadcasts, 0 runts, 0 giants
0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
0 L2 decode drops
0 packets output, 0 bytes, 0 underruns
0 output errors, 0 collisions, 0 interface resets
0 late collisions, 0 deferred
0 input reset drops, 0 output reset drops
input queue (curr/max packets): hardware (0/511)
output queue (curr/max packets): hardware (0/0)
Interface GigabitEthernet3/3 "", is up, line protocol is up
Hardware is i82571EB 4CU rev06, BW 1000 Mbps, DLY 10 usec
Auto-Duplex(Full-duplex), Auto-Speed(1000 Mbps)
Available but not configured via nameif
MAC address 0015.1715.592f, MTU not set
IP address 10.0.74.96, subnet mask 255.255.255.0
23 packets input, 1472 bytes, 0 no buffer
Received 23 broadcasts, 0 runts, 0 giants
0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
23 L2 decode drops
0 packets output, 0 bytes, 0 underruns
0 output errors, 0 collisions, 0 interface resets
0 late collisions, 0 deferred
0 input reset drops, 0 output reset drops
input queue (curr/max packets): hardware (23/511)
output queue (curr/max packets): hardware (0/0)
Interface TenGigabitEthernet5/0 "", is administratively down, line
protocol is down
# Attention: This interface is located in a PCIe x4 slot. For #
# optimal throughput, install the interface in a PCIe x8 slot #
# if one is available. #
Hardware is i82598af rev00, BW 10000 Mbps, DLY 10 usec
Auto-Duplex(Full-duplex), Auto-Speed(10000 Mbps)
Available but not configured via nameif
MAC address 001b.2100.10d3, MTU not set
IP address unassigned
0 packets input, 0 bytes, 0 no buffer
Received 0 broadcasts, 0 runts, 0 giants
0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
0 L2 decode drops
0 packets output, 0 bytes, 0 underruns
0 output errors, 0 collisions, 0 interface resets
0 late collisions, 0 deferred
0 input reset drops, 0 output reset drops
Interface Redundant1 "", is down, line protocol is down
Redundancy Information:
Members unassigned
Interface Redundant5 "redundant", is administratively down, line protocol is down
Hardware is i82546GB rev03, BW 1000 Mbps, DLY 1000 usec
Auto-Duplex, Auto-Speed
MAC address 000b.fcf8.c451, MTU 1500
IP address 10.2.3.5, subnet mask 255.255.255.0
0 packets input, 0 bytes, 0 no buffer
Received 0 broadcasts, 0 runts, 0 giants
0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
0 L2 decode drops
0 packets output, 0 bytes, 0 underruns
0 output errors, 0 collisions
0 late collisions, 0 deferred
0 input reset drops, 0 output reset drops
input queue (curr/max packets): hardware (0/0)
output queue (curr/max packets): hardware (0/0)
Traffic Statistics for "redundant":
0 packets input, 0 bytes
0 packets output, 0 bytes

```

```

0 packets dropped
1 minute input rate 0 pkts/sec,  0 bytes/sec
1 minute output rate 0 pkts/sec,  0 bytes/sec
1 minute drop rate, 0 pkts/sec
5 minute input rate 0 pkts/sec,  0 bytes/sec
5 minute output rate 0 pkts/sec,  0 bytes/sec
5 minute drop rate, 0 pkts/sec
Redundancy Information:
  Member GigabitEthernet0/3(Active), GigabitEthernet0/2
  Last switchover at 15:15:26 UTC Oct 24 2006
Interface Redundant5.1 "", is down, line protocol is down
  VLAN identifier none
  Available but not configured with VLAN or via nameif

```

Table 26-1 shows each field description.

**Table 26-12** show interface Fields

Field	Description
Interface <i>ID</i>	The interface ID. Within a context, the security appliance shows the mapped name (if configured), unless you set the <b>allocate-interface</b> command <b>visible</b> keyword.
<i>“interface_name”</i>	The interface name set with the <b>nameif</b> command. In the system execution space, this field is blank because you cannot set the name in the system. If you do not configure a name, the following message appears after the Hardware line:  Available but not configured via nameif
is <i>state</i>	The administrative state, as follows: <ul style="list-style-type: none"> <li>up—The interface is not shut down.</li> <li>administratively down—The interface is shut down with the <b>shutdown</b> command.</li> </ul>
Line protocol is <i>state</i>	The line status, as follows: <ul style="list-style-type: none"> <li>up—A working cable is plugged into the network interface.</li> <li>down—Either the cable is incorrect or not plugged into the interface connector.</li> </ul>
VLAN identifier	For subinterfaces, the VLAN ID.
Hardware	The interface type, maximum bandwidth, delay, duplex, and speed. When the link is down, the duplex and speed show the configured values. When the link is up, these fields show the configured values with the actual settings in parentheses.
<i>message area</i>	A message might be displayed in some circumstances. See the following examples: <ul style="list-style-type: none"> <li>In the system execution space, you might see the following message: Available for allocation to a context</li> <li>If you do not configure a name, you see the following message: Available but not configured via nameif</li> <li>If an interface is a member of a redundant interface, you see the following message: Active member of Redundant5</li> </ul>
MAC address	The interface MAC address.

**Table 26-12** *show interface Fields (continued)*

Field	Description
MTU	The maximum size, in bytes, of packets allowed on this interface. If you do not set the interface name, this field shows “MTU not set.”
IP address	The interface IP address set using the <b>ip address</b> command or received from a DHCP server. In the system execution space, this field shows “IP address unassigned” because you cannot set the IP address in the system.
Subnet mask	The subnet mask for the IP address.
Packets input	The number of packets received on this interface.
Bytes	The number of bytes received on this interface.
No buffer	The number of received packets discarded because there was no buffer space in the main system. Compare this with the ignored count. Broadcast storms on Ethernet networks are often responsible for no input buffer events.
Received:	
Broadcasts	The number of broadcasts received.
Input errors	The number of total input errors, including the types listed below. Other input-related errors can also cause the input error count to increase, and some datagrams might have more than one error; therefore, this sum might exceed the number of errors listed for the types below.
Runts	The number of packets that are discarded because they are smaller than the minimum packet size, which is 64 bytes. Runts are usually caused by collisions. They might also be caused by poor wiring and electrical interference.
Giants	The number of packets that are discarded because they exceed the maximum packet size. For example, any Ethernet packet that is greater than 1518 bytes is considered a giant.
CRC	The number of Cyclical Redundancy Check errors. When a station sends a frame, it appends a CRC to the end of the frame. This CRC is generated from an algorithm based on the data in the frame. If the frame is altered between the source and destination, the security appliance notes that the CRC does not match. A high number of CRCs is usually the result of collisions or a station transmitting bad data.
Frame	The number of frame errors. Bad frames include packets with an incorrect length or bad frame checksums. This error is usually the result of collisions or a malfunctioning Ethernet device.
Overrun	The number of times that the security appliance was incapable of handing received data to a hardware buffer because the input rate exceeded the security appliance capability to handle the data.
Ignored	This field is not used. The value is always 0.
Abort	This field is not used. The value is always 0.
L2 decode drops	The number of packets dropped because the name is not configured ( <b>nameif</b> command) or a frame with an invalid VLAN id is received.
Packets output	The number of packets sent on this interface.
Bytes	The number of bytes sent on this interface.

**Table 26-12** *show interface Fields (continued)*

Field	Description
Underruns	The number of times that the transmitter ran faster than the security appliance could handle.
Output Errors	The number of frames not transmitted because the configured maximum number of collisions was exceeded. This counter should only increment during heavy network traffic.
Collisions	The number of messages retransmitted due to an Ethernet collision (single and multiple collisions). This usually occurs on an overextended LAN (Ethernet or transceiver cable too long, more than two repeaters between stations, or too many cascaded multiport transceivers). A packet that collides is counted only once by the output packets.
Interface resets	The number of times an interface has been reset. If an interface is unable to transmit for three seconds, the security appliance resets the interface to restart transmission. During this interval, connection state is maintained. An interface reset can also happen when an interface is looped back or shut down.
Babbles	Unused. (“babble” means that the transmitter has been on the interface longer than the time taken to transmit the largest frame.)
Late collisions	<p>The number of frames that were not transmitted because a collision occurred outside the normal collision window. A late collision is a collision that is detected late in the transmission of the packet. Normally, these should never happen. When two Ethernet hosts try to talk at once, they should collide early in the packet and both back off, or the second host should see that the first one is talking and wait.</p> <p>If you get a late collision, a device is jumping in and trying to send the packet on the Ethernet while the security appliance is partly finished sending the packet. The security appliance does not resend the packet, because it may have freed the buffers that held the first part of the packet. This is not a real problem because networking protocols are designed to cope with collisions by resending packets. However, late collisions indicate a problem exists in your network. Common problems are large repeated networks and Ethernet networks running beyond the specification.</p>
Deferred	The number of frames that were deferred before transmission due to activity on the link.
input reset drops	Counts the number of packets dropped in the RX ring when a reset occurs.
output reset drops	Counts the number of packets dropped in the TX ring when a reset occurs.
Lost carrier	The number of times the carrier signal was lost during transmission.
No carrier	Unused.
Input queue (curr/max packets): Hardware	<p>(Gigabit Ethernet only). The number of packets in the input queue, the current and the maximum.</p> <p>For 10-Gigabit Ethernet interfaces, which have multiple queues, see the <b>show interface detail</b> command.</p>
Output queue (curr/max packets): Hardware	<p>(Gigabit Ethernet only). The number of packets in the output queue, the current and the maximum.</p> <p>For 10-Gigabit Ethernet interfaces, which have multiple queues, see the <b>show interface detail</b> command.</p>

**Table 26-12** show interface Fields (continued)

Field	Description
Traffic Statistics:	The number of packets received, transmitted, or dropped.
Packets input	The number of packets received and the number of bytes.
Packets output	The number of packets transmitted and the number of bytes.
Packets dropped	The number of packets dropped. Typically this counter increments for packets dropped on the accelerated security path (ASP), for example, if a packet is dropped due to an access list deny.  See the <b>show asp drop</b> command for reasons for potential drops on an interface.
1 minute input rate	The number of packets received in packets/sec and bytes/sec over the last minute.
1 minute output rate	The number of packets transmitted in packets/sec and bytes/sec over the last minute.
1 minute drop rate	The number of packets dropped in packets/sec over the last minute.
5 minute input rate	The number of packets received in packets/sec and bytes/sec over the last 5 minutes.
5 minute output rate	The number of packets transmitted in packets/sec and bytes/sec over the last 5 minutes.
5 minute drop rate	The number of packets dropped in packets/sec over the last 5 minutes.
Redundancy Information:	For redundant interfaces, shows the member physical interfaces. The active interface has “(Active)” after the interface ID.  If you have not yet assigned members, you see the following output:  Members unassigned
Last switchover	For redundant interfaces, shows the last time the active interface failed over to the standby interface.

The following is sample output from the **show interface detail** command. The following example shows detailed interface statistics for all interfaces, including asymmetrical routing statistics, if enabled by the **asr-group** command:

```
hostname# show interface detail
Interface TenGigabitEthernet5/0 "", is administratively down, line
protocol is up
  Hardware is i82598af rev01, BW 10000 Mbps, DLY 10 usec
    (Full-duplex), (10000 Mbps)
    Available but not configured via nameif
    MAC address 001b.2103.c9d5, MTU not set
    IP address unassigned
    0 packets input, 0 bytes, 0 no buffer
    Received 0 broadcasts, 0 runts, 0 giants
    0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
    0 L2 decode drops
    0 packets output, 0 bytes, 0 underruns
    0 output errors, 0 collisions, 0 interface resets
    0 late collisions, 0 deferred
    0 input reset drops, 0 output reset drops
    Queue stats:
```

```

RX[00]: 0 packets, 0 bytes
      curr/min packets: 511/511
RX[01]: 0 packets, 0 bytes
      curr/min packets: 511/511
RX[02]: 0 packets, 0 bytes
      curr/min packets: 511/511
RX[03]: 0 packets, 0 bytes
      curr/min packets: 511/511
TX[00]: 0 packets, 0 bytes, 0 underruns
      curr/max packets: 0/0
TX[01]: 0 packets, 0 bytes, 0 underruns
      curr/max packets: 0/0
TX[02]: 0 packets, 0 bytes, 0 underruns
      curr/max packets: 0/0
TX[03]: 0 packets, 0 bytes, 0 underruns
      curr/max packets: 0/0
Control Point Interface States:
Interface number is unassigned
...

```

Table 26-13 shows each field description for the **show interface detail** command. See Table 26-1 for fields that are also shown for the **show interface** command.

**Table 26-13** show interface detail Fields

Field	Description
Queue Stats	<p>(10-Gigabit Ethernet only). Shows the queue statistics.</p> <p>For example, the following lines:</p> <pre> RX[00]: 2866177 packets, 189167682 bytes       curr/min blocks: 511/408 </pre> <p>indicate that on receive queue 0, 2866177 packets and 189167682 bytes were received. Currently there are 511 blocks in hardware queue 0, and the minimum blocks were 408.</p> <p>Similarly for transmit, the following lines:</p> <pre> TX[00]: 2820355 packets, 186143390 bytes, 0 underruns       curr/max blocks: 43/250 </pre> <p>indicate that on transmit queue 0, 2820355 packets and 186143390 bytes were sent. There have been 0 underruns. Currently there are 43 blocks on transmit queue 0 and the maximum blocks were 250.</p> <p>The “packets input” and “bytes” displayed prior to “Queue stats” is the sum of packets and bytes on all RX queues respectively.</p> <p>Similarly, the “packets output” and “bytes” is the sum of packets and bytes on all TX queues.</p>
Control Point Interface States:	
Interface number	A number used for debugging that indicates in what order this interface was created, starting with 0.
Interface config status	<p>The administrative state, as follows:</p> <ul style="list-style-type: none"> <li>• active—The interface is not shut down.</li> <li>• not active—The interface is shut down with the <b>shutdown</b> command.</li> </ul>

**Table 26-13** show interface detail Fields (continued)

Field	Description
Interface state	The actual state of the interface. In most cases, this state matches the config status above. If you configure high availability, it is possible there can be a mismatch because the security appliance brings the interfaces up or down as needed.
Asymmetrical Routing Statistics:	
Received X1 packets	Number of ASR packets received on this interface.
Transmitted X2 packets	Number of ASR packets sent on this interfaces.
Dropped X3 packets	Number of ASR packets dropped on this interface. The packets might be dropped if the interface is down when trying to forward the packet.

Related Commands	Command	Description
	<b>allocate-interface</b>	Assigns interfaces and subinterfaces to a security context.
	<b>clear interface</b>	Clears counters for the <b>show interface</b> command.
	<b>delay</b>	Changes the delay metric for an interface.
	<b>interface</b>	Configures an interface and enters interface configuration mode.
	<b>nameif</b>	Sets the interface name.
	<b>show interface ip brief</b>	Shows the interface IP address and status.



# show interface ip brief

To view interface IP addresses and status, use the **show interface ip brief** command in privileged EXEC mode.

**show interface** [*physical\_interface* [, *subinterface*] | *mapped\_name* | *interface\_name* | **vlan number**]  
**ip brief**

Syntax Description	
<i>interface_name</i>	(Optional) Identifies the interface name set with the <b>nameif</b> command.
<i>mapped_name</i>	(Optional) In multiple context mode, identifies the mapped name if it was assigned using the <b>allocate-interface</b> command.
<i>physical_interface</i>	(Optional) Identifies the interface ID, such as <b>gigabitethernet0/1</b> . See the <b>interface</b> command for accepted values.
<i>subinterface</i>	(Optional) Identifies an integer between 1 and 4294967293 designating a logical subinterface.
<b>vlan number</b>	(Optional) For models with a built-in switch, such as the ASA 5505 adaptive security appliance, specifies the VLAN interface.

## Defaults

If you do not specify an interface, the security appliance shows all interfaces.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent <sup>1</sup>	Single	Multiple	
				Context	System
Privileged EXEC	•	•	•	•	—

1. Available for the Management 0/0 interface or subinterface only.

## Command History

Release	Modification
7.0(1)	This command was introduced.
7.2(1)	This command added support for VLAN interfaces, and for the Management 0/0 interface or subinterface in transparent mode.

## Usage Guidelines

In multiple context mode, if you mapped the interface ID in the **allocate-interface** command, you can only specify the mapped name or the interface name in a context.

See the “[Examples](#)” section for a description of the display output.

## Examples

The following is sample output from the **show ip brief** command:

```
hostname# show interface ip brief
```

Interface	IP-Address	OK?	Method	Status	Protocol
Control0/0	127.0.1.1	YES	CONFIG	up	up
GigabitEthernet0/0	209.165.200.226	YES	CONFIG	up	up
GigabitEthernet0/1	unassigned	YES	unset	administratively down	down
GigabitEthernet0/2	10.1.1.50	YES	manual	administratively down	down
GigabitEthernet0/3	192.168.2.6	YES	DHCP	administratively down	down
Management0/0	209.165.201.3	YES	CONFIG	up	

Table 26-13 shows each field description.

**Table 26-14** show interface ip brief Fields

Field	Description
Interface	The interface ID or, in multiple context mode, the mapped name if you configured it using the <b>allocate-interface</b> command. If you show all interfaces, then information about the internal interface for the AIP SSM displays, if installed on the ASA adaptive security appliance. The internal interface is not user-configurable, and the information is for debugging purposes only.
IP-Address	The interface IP address.
OK?	This column is not currently used, and always shows “Yes.”
Method	The method by which the interface received the IP address. Values include the following: <ul style="list-style-type: none"> <li>unset—No IP address configured.</li> <li>manual—Configured the running configuration.</li> <li>CONFIG—Loaded from the startup configuration.</li> <li>DHCP—Received from a DHCP server.</li> </ul>
Status	The administrative state, as follows: <ul style="list-style-type: none"> <li>up—The interface is not shut down.</li> <li>administratively down—The interface is shut down with the <b>shutdown</b> command.</li> </ul>
Protocol	The line status, as follows: <ul style="list-style-type: none"> <li>up—A working cable is plugged into the network interface.</li> <li>down—Either the cable is incorrect or not plugged into the interface connector.</li> </ul>

**Related Commands**

Command	Description
<b>allocate-interface</b>	Assigns interfaces and subinterfaces to a security context.
<b>interface</b>	Configures an interface and enters interface configuration mode.
<b>ip address</b>	Sets the IP address for the interface or sets the management IP address for a transparent firewall.
<b>nameif</b>	Sets the interface name.
<b>show interface</b>	Displays the runtime status and statistics of interfaces.

# show inventory

To display information about all of the Cisco products installed in the networking device that are assigned a product identifier (PID), version identifier (VID), and serial number (SN), use the **show inventory** command in user EXEC or privileged EXEC mode. If a Cisco entity is not assigned a PID, that entity is not retrieved or displayed.

**show inventory** [**slot**]

## Syntax Description

**slot** (Optional) Specifies the SSM slot number (the system is slot 0)

## Defaults

If you do not specify a slot to show inventory for:

- Show inventory information of all SSMs (including for power supply)

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	—	—	•

## Command History

Release	Modification
7.0	Minor semantic changes.

## Usage Guidelines

The **show inventory** command retrieves and displays inventory information about each Cisco product in the form of a UDI. The UDI is a combination of three separate data elements: a product identifier (PID), a version identifier (VID), and the serial number (SN).

The PID is the name by which the product can be ordered; it has been historically called the “Product Name” or “Part Number.” This is the identifier that one would use to order an exact replacement part.

The VID is the version of the product. Whenever a product has been revised, the VID will be incremented. The VID is incremented according to a rigorous process derived from Telcordia GR-209-CORE, an industry guideline that governs product change notices.

The SN is the vendor-unique serialization of the product. Each manufactured product will carry a unique serial number assigned at the factory, which cannot be changed in the field. This is the means by which to identify an individual, specific instance of a product.

The UDI refers to each product as an entity. Some entities, such as a chassis, will have subentities like slots. Each entity will display on a separate line in a logically ordered presentation that is arranged hierarchically by Cisco entities.

Use the **show inventory** command without options to display a list of Cisco entities installed in the networking device that are assigned a PID.

**Examples**

The following is sample output from the **show inventory** command without any keywords or arguments. This sample output displays a list of Cisco entities installed in a router that are assigned a PID.

```
ciscoasa# show inventory
Name:"Chassis", DESCR:"ASA 5540 Adaptive Security Appliance"
PID:ASA5540 , VID:V01 , SN:P3000000998

Name:"slot 1", DESCR:"ASA 5500 Series Security Services Module-20"
PID:ASA-SSM-20 , VID:V01 , SN:P0000000999

Name:"power supply", DESCR:"ASA 5500 Series 180W AC Power Supply"
PID:ASA-180W-PWR-AC , VID:V01 , SN:123456789AB

ciscoasa# show inventory 0
Name:"Chassis", DESCR:"ASA 5540 Adaptive Security Appliance"
PID:ASA5540 , VID:V01 , SN:P3000000998

ciscoasa# show inventory 1
Name:"slot 1", DESCR:"ASA 5500 Series Security Services Module-20"
PID:ASA-SSM-20 , VID:V01 , SN:P0000000999

ciscoasa# show inventory
Chassis, DESCR: ASA 5580-40 Adaptive Security Appliance
PID: ASA5580-40 , VID: V01 , SN: USE646N20M
```

Table 26-15 describes the fields shown in the display.

**Table 26-15** *show inventory Field Descriptions*

Field	Description
Name	Physical name (text string) assigned to the Cisco entity. For example, console or a simple component number (port or module number), such as "1," depending on the physical component naming syntax of the device. Equivalent to the entPhysicalName MIB variable in RFC 2737.
DESCR	Physical description of the Cisco entity that characterizes the object. Equivalent to the entPhysicalDesc MIB variable in RFC 2737.
PID	Entity product identifier. Equivalent to the entPhysicalModelName MIB variable in RFC 2737.
VID	Entity version identifier. Equivalent to the entPhysicalHardwareRev MIB variable in RFC 2737.
SN	Entity serial number. Equivalent to the entPhysicalSerialNum MIB variable in RFC 2737.

**Related Commands**

Command	Description
<b>show diag</b>	Displays diagnostic information about the controller, interface processor, and port adapters for a networking device.
<b>show tech-support</b>	Displays general information about the router when it reports a problem.

■ show inventory

# show ip address

To view interface IP addresses or, for transparent mode, the management IP address, use the **show ip address** command in privileged EXEC mode.

```
show ip address [physical_interface [.subinterface] | mapped_name | interface_name |  
                vlan number]
```

Syntax Description	
<i>interface_name</i>	(Optional) Identifies the interface name set with the <b>nameif</b> command.
<i>mapped_name</i>	(Optional) In multiple context mode, identifies the mapped name if it was assigned using the <b>allocate-interface</b> command.
<i>physical_interface</i>	(Optional) Identifies the interface ID, such as <b>gigabitethernet0/1</b> . See the <b>interface</b> command for accepted values.
<i>subinterface</i>	(Optional) Identifies an integer between 1 and 4294967293 designating a logical subinterface.
<b>vlan number</b>	(Optional) For models with a built-in switch, such as the ASA 5505 adaptive security appliance, specifies the VLAN interface.

**Defaults** If you do not specify an interface, the security appliance shows all interface IP addresses.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Privileged EXEC	•	•	•	•	—

Command History	Release	Modification
	7.2(1)	This command added support for VLAN interfaces.

**Usage Guidelines** This command shows the primary IP addresses (called “System” in the display) for when you configure high availability as well as the current IP addresses. If the unit is active, then the system and current IP addresses match. If the unit is standby, then the current IP addresses show the standby addresses.

**Examples** The following is sample output from the **show ip address** command:

```
hostname# show ip address
System IP Addresses:
Interface          Name      IP address    Subnet mask    Method
GigabitEthernet0/0 mgmt      10.7.12.100   255.255.255.0  CONFIG
GigabitEthernet0/1 inside    10.1.1.100    255.255.255.0  CONFIG
GigabitEthernet0/2.40 outside   209.165.201.2 255.255.255.224 DHCP
```

```

GigabitEthernet0/3      dmz      209.165.200.225 255.255.255.224 manual
Current IP Addresses:
Interface              Name      IP address      Subnet mask      Method
GigabitEthernet0/0     mgmt     10.7.12.100     255.255.255.0    CONFIG
GigabitEthernet0/1     inside   10.1.1.100      255.255.255.0    CONFIG
GigabitEthernet0/2.40  outside  209.165.201.2   255.255.255.224  DHCP
GigabitEthernet0/3     dmz      209.165.200.225 255.255.255.224 manual

```

Table 26-13 shows each field description.

**Table 26-16** show ip address Fields

Field	Description
Interface	The interface ID or, in multiple context mode, the mapped name if you configured it using the <b>allocate-interface</b> command.
Name	The interface name set with the <b>nameif</b> command.
IP address	The interface IP address.
Subnet mask	The IP address subnet mask.
Method	The method by which the interface received the IP address. Values include the following: <ul style="list-style-type: none"> <li>unset—No IP address configured.</li> <li>manual—Configured the running configuration.</li> <li>CONFIG—Loaded from the startup configuration.</li> <li>DHCP—Received from a DHCP server.</li> </ul>

#### Related Commands

Command	Description
<b>allocate-interface</b>	Assigns interfaces and subinterfaces to a security context.
<b>interface</b>	Configures an interface and enters interface configuration mode.
<b>nameif</b>	Sets the interface name.
<b>show interface</b>	Displays the runtime status and statistics of interfaces.
<b>show interface ip brief</b>	Shows the interface IP address and status.



# show ip address dhcp

To view detailed information about the DHCP lease or server for an interface, use the **show ip address dhcp** command in privileged EXEC mode.

**show ip address** {*physical\_interface*[*.subinterface*] | *mapped\_name* | *interface\_name*} **dhcp**  
{**lease** | **server**}

Syntax Description	
<i>interface_name</i>	Identifies the interface name set with the <b>nameif</b> command.
<b>lease</b>	Shows information about the DHCP lease.
<i>mapped_name</i>	In multiple context mode, identifies the mapped name if it was assigned using the <b>allocate-interface</b> command.
<i>physical_interface</i>	Identifies the interface ID, such as <b>gigabitethernet0/1</b> . See the <b>interface</b> command for accepted values.
<b>server</b>	Shows information about the DHCP server.
<i>subinterface</i>	Identifies an integer between 1 and 4294967293 designating a logical subinterface.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent <sup>1</sup>	Single	Multiple Context	System
Privileged EXEC	•	—	•	•	—

1. Available for the Management 0/0 interface or subinterface only.

Command History	Release	Modification
	7.0(1)	This command was changed to include the <b>lease</b> and <b>server</b> keywords to accommodate the new server functionality.
	7.2(1)	This command added support for VLAN interfaces, and for the Management 0/0 interface or subinterface in transparent mode.

**Usage Guidelines** See the “[Examples](#)” section for a description of the display output.

**Examples** The following is sample output from the **show ip address dhcp lease** command:

```
hostname# show ip address outside dhcp lease
Temp IP Addr:209.165.201.57 for peer on interface:outside
Temp sub net mask:255.255.255.224
```

```

DHCP Lease server:209.165.200.225, state:3 Bound
DHCP Transaction id:0x4123
Lease:259200 secs, Renewal:129600 secs, Rebind:226800 secs
Temp default-gateway addr:209.165.201.1
Temp ip static route0: dest 10.9.0.0 router 10.7.12.255
Next timer fires after:111797 secs
Retry count:0, Client-ID:cisco-0000.0000.0000-outside
Proxy: TRUE Proxy Network: 10.1.1.1
Hostname: device1

```

Table 26-13 shows each field description.

**Table 26-17** show ip address dhcp lease Fields

Field	Description
Temp IP Addr	The IP address assigned to the interface.
Temp sub net mask	The subnet mask assigned to the interface.
DHCP Lease server	The DHCP server address.
state	<p>The state of the DHCP lease, as follows:</p> <ul style="list-style-type: none"> <li>Initial—The initialization state, where the security appliance begins the process of acquiring a lease. This state is also shown when a lease ends or when a lease negotiation fails.</li> <li>Selecting—The security appliance is waiting to receive DHCPOFFER messages from one or more DHCP servers, so it can choose one.</li> <li>Requesting—The security appliance is waiting to hear back from the server to which it sent its request.</li> <li>Purging—The security appliance is removing the lease because the client has released the IP address or there was some other error.</li> <li>Bound—The security appliance has a valid lease and is operating normally.</li> <li>Renewing—The security appliance is trying to renew the lease. It regularly sends DHCPREQUEST messages to the current DHCP server, and waits for a reply.</li> <li>Rebinding—The security appliance failed to renew the lease with the original server, and now sends DHCPREQUEST messages until it gets a reply from any server or the lease ends.</li> <li>Holdddown—The security appliance started the process to remove the lease.</li> <li>Releasing—The security appliance sends release messages to the server indicating that the IP address is no longer needed.</li> </ul>
DHCP transaction id	A random number chosen by the client, used by the client and server to associate the request messages.
Lease	The length of time, specified by the DHCP server, that the interface can use this IP address.
Renewal	The length of time until the interface automatically attempts to renew this lease.

**Table 26-17** show ip address dhcp lease Fields (continued)

Field	Description
Rebind	The length of time until the security appliance attempts to rebind to a DHCP server. Rebinding occurs if the security appliance cannot communicate with the original DHCP server, and 87.5 percent of the lease time has expired. The security appliance then attempts to contact any available DHCP server by broadcasting DHCP requests.
Temp default-gateway addr	The default gateway address supplied by the DHCP server.
Temp ip static route0	The default static route.
Next timer fires after	The number of seconds until the internal timer triggers.
Retry count	If the security appliance is attempting to establish a lease, this field shows the number of times the security appliance tried sending a DHCP message. For example, if the security appliance is in the Selecting state, this value shows the number of times the security appliance sent discover messages. If the security appliance is in the Requesting state, this value shows the number of times the security appliance sent request messages.
Client-ID	The client ID used in all communication with the server.
Proxy	Specifies if this interface is a proxy DHCP client for VPN clients, True or False.
Proxy Network	The requested network.
Hostname	The client hostname.

The following is sample output from the **show ip address dhcp server** command:

```
hostname# show ip address outside dhcp server

DHCP server: ANY (255.255.255.255)
Leases:      0
Offers:      0      Requests: 0      Acks: 0      Naks: 0
Declines:    0      Releases: 0      Bad: 0

DHCP server: 40.7.12.6
Leases:      1
Offers:      1      Requests: 17     Acks: 17     Naks: 0
Declines:    0      Releases: 0      Bad: 0
DNS0: 171.69.161.23, DNS1: 171.69.161.24
WINS0: 172.69.161.23, WINS1: 172.69.161.23
Subnet: 255.255.0.0   DNS Domain: cisco.com
```

Table 26-18 shows each field description.

**Table 26-18** show ip address dhcp server Fields

Field	Description
DHCP server	The DHCP server address from which this interface obtained a lease. The top entry ("ANY") is the default server and is always present.
Leases	The number of leases obtained from the server. For an interface, the number of leases is typically 1. If the server is providing address for an interface that is running proxy for VPN, there will be several leases.

**Table 26-18** *show ip address dhcp server Fields (continued)*

Field	Description
Offers	The number of offers from the server.
Requests	The number of requests sent to the server.
Acks	The number of acknowledgements received from the server.
Naks	The number of negative acknowledgements received from the server.
Declines	The number of declines received from the server.
Releases	The number of releases sent to the server.
Bad	The number of bad packets received from the server.
DNS0	The primary DNS server address obtained from the DHCP server.
DNS1	The secondary DNS server address obtained from the DHCP server.
WINS0	The primary WINS server address obtained from the DHCP server.
WINS1	The secondary WINS server address obtained from the DHCP server.
Subnet	The subnet address obtained from the DHCP server.
DNS Domain	The domain obtained from the DHCP server.

**Related Commands**

Command	Description
<b>interface</b>	Configures an interface and enters interface configuration mode.
<b>ip address dhcp</b>	Sets the interface to obtain an IP address from a DHCP server.
<b>nameif</b>	Sets the interface name.
<b>show interface ip brief</b>	Shows the interface IP address and status.
<b>show ip address</b>	Displays the IP addresses of interfaces.

# show ip address pppoe

To view detailed information about the PPPoE connection, use the **show ip address pppoe** command in privileged EXEC mode.

**show ip address** {*physical\_interface*[*.subinterface*] | *mapped\_name* | *interface\_name* | *vlan number*} **pppoe**

Syntax Description	
<i>interface_name</i>	Identifies the interface name set with the <b>nameif</b> command.
<i>mapped_name</i>	In multiple context mode, identifies the mapped name if it was assigned using the <b>allocate-interface</b> command.
<i>physical_interface</i>	Identifies the interface ID, such as <b>gigabitethernet0/1</b> . See the <b>interface</b> command for accepted values.
<i>subinterface</i>	Identifies an integer between 1 and 4294967293 designating a logical subinterface.
<b>vlan number</b>	(Optional) For models with a built-in switch, such as the ASA 5505 adaptive security appliance, specifies the VLAN interface.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent <sup>1</sup>	Single	Multiple	
				Context	System
Privileged EXEC	•	•	•	•	—

1. Available for the Management 0/0 interface or subinterface only.

Command History	Release	Modification
	7.2(1)	This command was introduced.

**Usage Guidelines** See the “[Examples](#)” section for a description of the display output.

**Examples** The following is sample output from the **show ip address pppoe** command:

```
hostname# show ip address outside pppoe
```

**Related Commands**

Command	Description
<b>interface</b>	Configures an interface and enters interface configuration mode.
<b>ip address ppoe</b>	Sets the interface to obtain an IP address from a PPPoE server.
<b>nameif</b>	Sets the interface name.
<b>show interface ip brief</b>	Shows the interface IP address and status.
<b>show ip address</b>	Displays the IP addresses of interfaces.

# show ip audit count

To show the number of signature matches when you apply an audit policy to an interface, use the **show ip audit count** command in privileged EXEC mode.

**show ip audit count** [**global** | **interface** *interface\_name*]

## Syntax Description

<b>global</b>	(Default) Shows the number of matches for all interfaces.
<b>interface</b> <i>interface_name</i>	(Optional) Shows the number of matches for the specified interface.

## Defaults

If you do not specify a keyword, this command shows the matches for all interfaces (**global**).

## Command Modes

The following table shows the modes in which you can enter the command:

	Firewall Mode		Security Context		
				Multiple	
Command Mode	Routed	Transparent	Single	Context	System
Privileged EXEC	•	•	•	•	—

## Command History

Release	Modification
Preexisting	This command was preexisting.

## Usage Guidelines

To create an audit policy, use the **ip audit name** command, and to apply the policy, use the **ip audit interface** command.

## Examples

The following is sample output from the **show ip audit count** command:

```
hostname# show ip audit count
IP AUDIT GLOBAL COUNTERS

1000 I Bad IP Options List      0
1001 I Record Packet Route     0
1002 I Timestamp                0
1003 I Provide s,c,h,tcc       0
1004 I Loose Source Route       0
1005 I SATNET ID                0
1006 I Strict Source Route      0
1100 A IP Fragment Attack      0
1102 A Impossible IP Packet    0
1103 A IP Teardrop              0
2000 I ICMP Echo Reply          0
2001 I ICMP Unreachable        0
2002 I ICMP Source Quench      0
2003 I ICMP Redirect            0
```

## show ip audit count

```

2004 I ICMP Echo Request      10
2005 I ICMP Time Exceed       0
2006 I ICMP Parameter Problem 0
2007 I ICMP Time Request      0
2008 I ICMP Time Reply        0
2009 I ICMP Info Request      0
2010 I ICMP Info Reply        0
2011 I ICMP Address Mask Request 0
2012 I ICMP Address Mask Reply 0
2150 A Fragmented ICMP       0
2151 A Large ICMP             0
2154 A Ping of Death          0
3040 A TCP No Flags           0
3041 A TCP SYN & FIN Flags Only 0
3042 A TCP FIN Flag Only      0
3153 A FTP Improper Address    0
3154 A FTP Improper Port      0
4050 A Bomb                    0
4051 A Snork                   0
4052 A Chargen                 0
6050 I DNS Host Info           0
6051 I DNS Zone Xfer           0
6052 I DNS Zone Xfer High Port 0
6053 I DNS All Records         0
6100 I RPC Port Registration   0
6101 I RPC Port Unregistration 0
6102 I RPC Dump                0
6103 A Proxied RPC             0
6150 I ypserv Portmap Request  0
6151 I ypbind Portmap Request  0
6152 I yppasswdd Portmap Request 0
6153 I ypuddated Portmap Request 0
6154 I ypxfrd Portmap Request  0
6155 I mountd Portmap Request  0
6175 I rexd Portmap Request    0
6180 I rexd Attempt            0
6190 A statd Buffer Overflow   0

```

```

IP AUDIT INTERFACE COUNTERS: inside
...

```

### Related Commands

Command	Description
<b>clear ip audit count</b>	Clears the count of signature matches for an audit policy.
<b>ip audit interface</b>	Assigns an audit policy to an interface.
<b>ip audit name</b>	Creates a named audit policy that identifies the actions to take when a packet matches an attack signature or an informational signature.
<b>show running-config ip audit attack</b>	Shows the configuration for the <b>ip audit attack</b> command.



# show ip verify statistics

To show the number of packets dropped because of the Unicast RPF feature, use the **show ip verify statistics** command in privileged EXEC mode. Use the **ip verify reverse-path** command to enable Unicast RPF.

**show ip verify statistics** [*interface interface\_name*]

## Syntax Description

**interface** (Optional) Shows statistics for the specified interface.  
*interface\_name*

## Defaults

This command shows statistics for all interfaces.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Privileged EXEC	•	—	•	•	—

## Command History

Release	Modification
Preexisting	This command was preexisting.

## Examples

The following is sample output from the **show ip verify statistics** command:

```
hostname# show ip verify statistics
interface outside: 2 unicast rpf drops
interface inside: 1 unicast rpf drops
interface intf2: 3 unicast rpf drops
```

## Related Commands

Command	Description
<b>clear configure ip verify reverse-path</b>	Clears the <b>ip verify reverse-path</b> configuration.
<b>clear ip verify statistics</b>	Clears the Unicast RPF statistics.
<b>ip verify reverse-path</b>	Enables the Unicast Reverse Path Forwarding feature to prevent IP spoofing.
<b>show running-config ip verify reverse-path</b>	Shows the <b>ip verify reverse-path</b> configuration.

# show ips

To show all available IPS virtual sensors that are configured on the AIP SSM, use the **show ips** command in privileged EXEC mode.

**show ips [detail]**

## Syntax Description

**detail** (Optional) Shows the sensor ID number as well as the name.

## Defaults

No default behavior or values.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Privileged EXEC	•	•	•	•	•

## Command History

Release	Modification
8.0(2)	This command was introduced.

## Usage Guidelines

In multiple context mode, this command shows all virtual sensors when entered in the system execution space, but only shows the virtual sensors assigned to the context in the context execution space. See the **allocate-ips** command to assign virtual sensors to contexts.

Virtual sensors are available in IPS Version 6.0 and above.

---

**Examples**

The following is sample output from the **show ips** command:

```
hostname# show ips
Sensor name
-----
ips1
ips2
```

The following is sample output from the **show ips detail** command:

```
hostname# show ips detail
Sensor name          Sensor ID
-----
ips1                  1
ips2                  2
```

---

**Related Commands**

Command	Description
<b>allocate-ips</b>	Assigns a virtual sensor to a security context.
<b>ips</b>	Diverts traffic to the AIP SSM.

# show ipsec sa

To display a list of IPSec SAs, use the **show ipsec sa** command in global configuration mode or privileged EXEC mode. You can also use the alternate form of this command: **show crypto ipsec sa**.

**show ipsec sa** [**entry** | **identity** | **map** *map-name* | **peer** *peer-addr*] [**detail**]

## Syntax Description

<b>detail</b>	(Optional) Displays detailed error information on what is displayed.
<b>entry</b>	(Optional) Displays IPSec SAs sorted by peer address
<b>identity</b>	(Optional) Displays IPSec SAs for sorted by identity, not including ESPs. This is a condensed form.
<b>map</b> <i>map-name</i>	(Optional) Displays IPSec SAs for the specified crypto map.
<b>peer</b> <i>peer-addr</i>	(Optional) Displays IPSec SAs for specified peer IP addresses.

## Defaults

No default behavior or values.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	—	—
Privileged EXEC	•	•	•	—	—

## Command History

Release	Modification
Preexisting	This command was preexisting.

## Examples

The following example, entered in global configuration mode, displays IPSec SAs.

```
hostname(config)# show ipsec sa
interface: outside2
  Crypto map tag: def, local addr: 10.132.0.17

  local ident (addr/mask/prot/port): (0.0.0.0/0.0.0.0/0/0)
  remote ident (addr/mask/prot/port): (172.20.0.21/255.255.255.255/0/0)
  current_peer: 172.20.0.21
  dynamic allocated peer ip: 10.135.1.5

  #pkts encaps: 0, #pkts encrypt: 0, #pkts digest: 0
  #pkts decaps: 1145, #pkts decrypt: 1145, #pkts verify: 1145
  #pkts compressed: 0, #pkts decompressed: 0
  #pkts not compressed: 0, #pkts comp failed: 0, #pkts decomp failed: 0
  #pre-frag successes: 2, #pre-frag failures: 1, #fragments created: 10
  #PMTUs sent: 5, #PMTUs rcvd: 2, #decapstulated frags needing reassembly: 1
  #send errors: 0, #recv errors: 0
```

```

local crypto endpt.: 10.132.0.17, remote crypto endpt.: 172.20.0.21

path mtu 1500, ipsec overhead 60, media mtu 1500
current outbound spi: DC15BF68

inbound esp sas:
  spi: 0x1E8246FC (511854332)
    transform: esp-3des esp-md5-hmac
    in use settings = {RA, Tunnel, }
    slot: 0, conn_id: 3, crypto-map: def
    sa timing: remaining key lifetime (sec): 548
    IV size: 8 bytes
    replay detection support: Y
outbound esp sas:
  spi: 0xDC15BF68 (3692412776)
    transform: esp-3des esp-md5-hmac
    in use settings = {RA, Tunnel, }
    slot: 0, conn_id: 3, crypto-map: def
    sa timing: remaining key lifetime (sec): 548
    IV size: 8 bytes
    replay detection support: Y

Crypto map tag: def, local addr: 10.132.0.17

local ident (addr/mask/prot/port): (0.0.0.0/0.0.0.0/0/0)
hostname(config)#

```

**Note**

Fragmentation statistics are pre-fragmentation statistics if the IPSec SA policy states that fragmentation occurs before IPSec processing. Post-fragmentation statistics appear if the SA policy states that fragmentation occurs after IPSec processing.

The following example, entered in global configuration mode, displays IPSec SAs for a crypto map named def.

```

hostname(config)# show ipsec sa map def
cryptomap: def
  Crypto map tag: def, local addr: 172.20.0.17

    local ident (addr/mask/prot/port): (0.0.0.0/0.0.0.0/0/0)
    remote ident (addr/mask/prot/port): (10.132.0.21/255.255.255.255/0/0)
    current_peer: 10.132.0.21
    dynamic allocated peer ip: 90.135.1.5

    #pkts encaps: 0, #pkts encrypt: 0, #pkts digest: 0
    #pkts decaps: 1146, #pkts decrypt: 1146, #pkts verify: 1146
    #pkts compressed: 0, #pkts decompressed: 0
    #pkts not compressed: 0, #pkts comp failed: 0, #pkts decomp failed: 0
    #send errors: 0, #recv errors: 0

    local crypto endpt.: 172.20.0.17, remote crypto endpt.: 10.132.0.21

    path mtu 1500, ipsec overhead 60, media mtu 1500
    current outbound spi: DC15BF68

inbound esp sas:
  spi: 0x1E8246FC (511854332)
    transform: esp-3des esp-md5-hmac
    in use settings = {RA, Tunnel, }
    slot: 0, conn_id: 3, crypto-map: def
    sa timing: remaining key lifetime (sec): 480

```

```

    IV size: 8 bytes
    replay detection support: Y
outbound esp sas:
  spi: 0xDC15BF68 (3692412776)
    transform: esp-3des esp-md5-hmac
    in use settings = {RA, Tunnel, }
    slot: 0, conn_id: 3, crypto-map: def
    sa timing: remaining key lifetime (sec): 480
    IV size: 8 bytes
    replay detection support: Y

Crypto map tag: def, local addr: 172.20.0.17

local ident (addr/mask/prot/port): (0.0.0.0/0.0.0.0/0/0)
remote ident (addr/mask/prot/port): (192.168.132.0/255.255.255.0/0/0)
current_peer: 10.135.1.8
dynamic allocated peer ip: 0.0.0.0

#pkts encaps: 73672, #pkts encrypt: 73672, #pkts digest: 73672
#pkts decaps: 78824, #pkts decrypt: 78824, #pkts verify: 78824
#pkts compressed: 0, #pkts decompressed: 0
#pkts not compressed: 73672, #pkts comp failed: 0, #pkts decomp failed: 0
#send errors: 0, #recv errors: 0

local crypto endpt.: 172.20.0.17, remote crypto endpt.: 10.135.1.8

path mtu 1500, ipsec overhead 60, media mtu 1500
current outbound spi: 3B6F6A35

inbound esp sas:
  spi: 0xB32CF0BD (3006066877)
    transform: esp-3des esp-md5-hmac
    in use settings = {RA, Tunnel, }
    slot: 0, conn_id: 4, crypto-map: def
    sa timing: remaining key lifetime (sec): 263
    IV size: 8 bytes
    replay detection support: Y
outbound esp sas:
  spi: 0x3B6F6A35 (997157429)
    transform: esp-3des esp-md5-hmac
    in use settings = {RA, Tunnel, }
    slot: 0, conn_id: 4, crypto-map: def
    sa timing: remaining key lifetime (sec): 263
    IV size: 8 bytes
    replay detection support: Y
hostname(config)#

```

The following example, entered in global configuration mode, shows IPSec SAs for the keyword **entry**.

```

hostname(config)# show ipsec sa entry
peer address: 10.132.0.21
  Crypto map tag: def, local addr: 172.20.0.17

local ident (addr/mask/prot/port): (0.0.0.0/0.0.0.0/0/0)
remote ident (addr/mask/prot/port): (10.132.0.21/255.255.255.0/0/0)
current_peer: 10.132.0.21
dynamic allocated peer ip: 90.135.1.5

#pkts encaps: 0, #pkts encrypt: 0, #pkts digest: 0
#pkts decaps: 1147, #pkts decrypt: 1147, #pkts verify: 1147
#pkts compressed: 0, #pkts decompressed: 0
#pkts not compressed: 0, #pkts comp failed: 0, #pkts decomp failed: 0
#send errors: 0, #recv errors: 0

```

```

local crypto endpt.: 172.20.0.17, remote crypto endpt.: 10.132.0.21

path mtu 1500, ipsec overhead 60, media mtu 1500
current outbound spi: DC15BF68

inbound esp sas:
  spi: 0x1E8246FC (511854332)
    transform: esp-3des esp-md5-hmac
    in use settings = {RA, Tunnel, }
    slot: 0, conn_id: 3, crypto-map: def
    sa timing: remaining key lifetime (sec): 429
    IV size: 8 bytes
    replay detection support: Y
outbound esp sas:
  spi: 0xDC15BF68 (3692412776)
    transform: esp-3des esp-md5-hmac
    in use settings = {RA, Tunnel, }
    slot: 0, conn_id: 3, crypto-map: def
    sa timing: remaining key lifetime (sec): 429
    IV size: 8 bytes
    replay detection support: Y

peer address: 10.135.1.8
Crypto map tag: def, local addr: 172.20.0.17

local ident (addr/mask/prot/port): (0.0.0.0/0.0.0.0/0/0)
remote ident (addr/mask/prot/port): (192.168.132.0/255.255.255.0/0/0)
current_peer: 10.135.1.8
dynamic allocated peer ip: 0.0.0.0

#pkts encaps: 73723, #pkts encrypt: 73723, #pkts digest: 73723
#pkts decaps: 78878, #pkts decrypt: 78878, #pkts verify: 78878
#pkts compressed: 0, #pkts decompressed: 0
#pkts not compressed: 73723, #pkts comp failed: 0, #pkts decomp failed: 0
#send errors: 0, #recv errors: 0

local crypto endpt.: 172.20.0.17, remote crypto endpt.: 10.135.1.8

path mtu 1500, ipsec overhead 60, media mtu 1500
current outbound spi: 3B6F6A35

inbound esp sas:
  spi: 0xB32CF0BD (3006066877)
    transform: esp-3des esp-md5-hmac
    in use settings = {RA, Tunnel, }
    slot: 0, conn_id: 4, crypto-map: def
    sa timing: remaining key lifetime (sec): 212
    IV size: 8 bytes
    replay detection support: Y
outbound esp sas:
  spi: 0x3B6F6A35 (997157429)
    transform: esp-3des esp-md5-hmac
    in use settings = {RA, Tunnel, }
    slot: 0, conn_id: 4, crypto-map: def
    sa timing: remaining key lifetime (sec): 212
    IV size: 8 bytes
    replay detection support: Y
hostname(config)#

```

The following example, entered in global configuration mode, shows IPSec SAs with the keywords **entry detail**.

```
hostname(config)# show ipsec sa entry detail
peer address: 10.132.0.21
  Crypto map tag: def, local addr: 172.20.0.17

    local ident (addr/mask/prot/port): (0.0.0.0/0.0.0.0/0/0)
    remote ident (addr/mask/prot/port): (10.132.0.21/255.255.255.0/0/0)
    current_peer: 10.132.0.21
    dynamic allocated peer ip: 90.135.1.5

    #pkts encaps: 0, #pkts encrypt: 0, #pkts digest: 0
    #pkts decaps: 1148, #pkts decrypt: 1148, #pkts verify: 1148
    #pkts compressed: 0, #pkts decompressed: 0
    #pkts not compressed: 0, #pkts comp failed: 0, #pkts decomp failed: 0
    #pkts no sa (send): 0, #pkts invalid sa (rcv): 0
    #pkts encaps failed (send): 0, #pkts decaps failed (rcv): 0
    #pkts invalid prot (rcv): 0, #pkts verify failed: 0
    #pkts invalid identity (rcv): 0, #pkts invalid len (rcv): 0
    #pkts replay rollover (send): 0, #pkts replay rollover (rcv): 0
    #pkts replay failed (rcv): 0
    #pkts internal err (send): 0, #pkts internal err (rcv): 0

    local crypto endpt.: 172.20.0.17, remote crypto endpt.: 10.132.0.21

    path mtu 1500, ipsec overhead 60, media mtu 1500
    current outbound spi: DC15BF68

inbound esp sas:
  spi: 0x1E8246FC (511854332)
    transform: esp-3des esp-md5-hmac
    in use settings ={RA, Tunnel, }
    slot: 0, conn_id: 3, crypto-map: def
    sa timing: remaining key lifetime (sec): 322
    IV size: 8 bytes
    replay detection support: Y
outbound esp sas:
  spi: 0xDC15BF68 (3692412776)
    transform: esp-3des esp-md5-hmac
    in use settings ={RA, Tunnel, }
    slot: 0, conn_id: 3, crypto-map: def
    sa timing: remaining key lifetime (sec): 322
    IV size: 8 bytes
    replay detection support: Y

peer address: 10.135.1.8
  Crypto map tag: def, local addr: 172.20.0.17

    local ident (addr/mask/prot/port): (0.0.0.0/0.0.0.0/0/0)
    remote ident (addr/mask/prot/port): (192.168.132.0/255.255.255.0/0/0)
    current_peer: 10.135.1.8
    dynamic allocated peer ip: 0.0.0.0

    #pkts encaps: 73831, #pkts encrypt: 73831, #pkts digest: 73831
    #pkts decaps: 78989, #pkts decrypt: 78989, #pkts verify: 78989
    #pkts compressed: 0, #pkts decompressed: 0
    #pkts not compressed: 73831, #pkts comp failed: 0, #pkts decomp failed: 0
    #pkts no sa (send): 0, #pkts invalid sa (rcv): 0
    #pkts encaps failed (send): 0, #pkts decaps failed (rcv): 0
    #pkts invalid prot (rcv): 0, #pkts verify failed: 0
    #pkts invalid identity (rcv): 0, #pkts invalid len (rcv): 0
    #pkts replay rollover (send): 0, #pkts replay rollover (rcv): 0
    #pkts replay failed (rcv): 0
```



```

#pkts internal err (send): 0, #pkts internal err (rcv): 0

local crypto endpt.: 172.20.0.17, remote crypto endpt.: 10.135.1.8

path mtu 1500, ipsec overhead 60, media mtu 1500
current outbound spi: 3B6F6A35

inbound esp sas:
  spi: 0xB32CF0BD (3006066877)
    transform: esp-3des esp-md5-hmac
    in use settings = {RA, Tunnel, }
    slot: 0, conn_id: 4, crypto-map: def
    sa timing: remaining key lifetime (sec): 104
    IV size: 8 bytes
    replay detection support: Y
outbound esp sas:
  spi: 0x3B6F6A35 (997157429)
    transform: esp-3des esp-md5-hmac
    in use settings = {RA, Tunnel, }
    slot: 0, conn_id: 4, crypto-map: def
    sa timing: remaining key lifetime (sec): 104
    IV size: 8 bytes
    replay detection support: Y
hostname(config)#

```

The following example shows IPSec SAs with the keyword **identity**.

```

hostname(config)# show ipsec sa identity
interface: outside2
  Crypto map tag: def, local addr: 172.20.0.17

    local ident (addr/mask/prot/port): (0.0.0.0/0.0.0.0/0/0)
    remote ident (addr/mask/prot/port): (10.132.0.21/255.255.255.255/0/0)
    current_peer: 10.132.0.21
    dynamic allocated peer ip: 90.135.1.5

    #pkts encaps: 0, #pkts encrypt: 0, #pkts digest: 0
    #pkts decaps: 1147, #pkts decrypt: 1147, #pkts verify: 1147
    #pkts compressed: 0, #pkts decompressed: 0
    #pkts not compressed: 0, #pkts comp failed: 0, #pkts decomp failed: 0
    #send errors: 0, #recv errors: 0

    local crypto endpt.: 172.20.0.17, remote crypto endpt.: 10.132.0.21

    path mtu 1500, ipsec overhead 60, media mtu 1500
    current outbound spi: DC15BF68

  Crypto map tag: def, local addr: 172.20.0.17

    local ident (addr/mask/prot/port): (0.0.0.0/0.0.0.0/0/0)
    remote ident (addr/mask/prot/port): (192.168.132.0/255.255.255.0/0/0)
    current_peer: 10.135.1.8
    dynamic allocated peer ip: 0.0.0.0

    #pkts encaps: 73756, #pkts encrypt: 73756, #pkts digest: 73756
    #pkts decaps: 78911, #pkts decrypt: 78911, #pkts verify: 78911
    #pkts compressed: 0, #pkts decompressed: 0
    #pkts not compressed: 73756, #pkts comp failed: 0, #pkts decomp failed: 0
    #send errors: 0, #recv errors: 0

    local crypto endpt.: 172.20.0.17, remote crypto endpt.: 10.135.1.8

    path mtu 1500, ipsec overhead 60, media mtu 1500
    current outbound spi: 3B6F6A35

```

The following example shows IPSec SAs with the keywords **identity** and **detail**.

```
hostname(config)# show ipsec sa identity detail
interface: outside2
  Crypto map tag: def, local addr: 172.20.0.17

    local ident (addr/mask/prot/port): (0.0.0.0/0.0.0.0/0/0)
    remote ident (addr/mask/prot/port): (10.132.0.21/255.255.255.255/0/0)
    current_peer: 10.132.0.21
    dynamic allocated peer ip: 90.135.1.5

    #pkts encaps: 0, #pkts encrypt: 0, #pkts digest: 0
    #pkts decaps: 1147, #pkts decrypt: 1147, #pkts verify: 1147
    #pkts compressed: 0, #pkts decompressed: 0
    #pkts not compressed: 0, #pkts comp failed: 0, #pkts decomp failed: 0
    #pkts no sa (send): 0, #pkts invalid sa (rcv): 0
    #pkts encaps failed (send): 0, #pkts decaps failed (rcv): 0
    #pkts invalid prot (rcv): 0, #pkts verify failed: 0
    #pkts invalid identity (rcv): 0, #pkts invalid len (rcv): 0
    #pkts replay rollover (send): 0, #pkts replay rollover (rcv): 0
    #pkts replay failed (rcv): 0
    #pkts internal err (send): 0, #pkts internal err (rcv): 0

    local crypto endpt.: 172.20.0.17, remote crypto endpt.: 10.132.0.21

    path mtu 1500, ipsec overhead 60, media mtu 1500
    current outbound spi: DC15BF68

  Crypto map tag: def, local addr: 172.20.0.17

    local ident (addr/mask/prot/port): (0.0.0.0/0.0.0.0/0/0)
    remote ident (addr/mask/prot/port): (192.168.132.0/255.255.255.0/0/0)
    current_peer: 10.135.1.8
    dynamic allocated peer ip: 0.0.0.0

    #pkts encaps: 73771, #pkts encrypt: 73771, #pkts digest: 73771
    #pkts decaps: 78926, #pkts decrypt: 78926, #pkts verify: 78926
    #pkts compressed: 0, #pkts decompressed: 0
    #pkts not compressed: 73771, #pkts comp failed: 0, #pkts decomp failed: 0
    #pkts no sa (send): 0, #pkts invalid sa (rcv): 0
    #pkts encaps failed (send): 0, #pkts decaps failed (rcv): 0
    #pkts invalid prot (rcv): 0, #pkts verify failed: 0
    #pkts invalid identity (rcv): 0, #pkts invalid len (rcv): 0
    #pkts replay rollover (send): 0, #pkts replay rollover (rcv): 0
    #pkts replay failed (rcv): 0
    #pkts internal err (send): 0, #pkts internal err (rcv): 0

    local crypto endpt.: 172.20.0.17, remote crypto endpt.: 10.135.1.8

    path mtu 1500, ipsec overhead 60, media mtu 1500
    current outbound spi: 3B6F6A35
```

## Related Commands

Command	Description
<b>clear configure isakmp</b>	Clears all the ISAKMP configuration.
<b>clear configure isakmp policy</b>	Clears all ISAKMP policy configuration.
<b>clear isakmp sa</b>	Clears the IKE runtime SA database.

Command	Description
<b>isakmp enable</b>	Enables ISAKMP negotiation on the interface on which the IPSec peer communicates with the security appliance.
<b>show running-config isakmp</b>	Displays all the active ISAKMP configuration.

# show ipsec sa summary

To display a summary of IPSec SAs, use the **show ipsec sa summary** command in global configuration mode or privileged EXEC mode.

## show ipsec sa summary

**Syntax Description** This command has no arguments or variables.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	—	—
Privileged EXEC	•	•	•	—	—

Command History	Release	Modification
	7.0(1)	This command was introduced.

**Examples** The following example, entered in global configuration mode, displays a summary of IPSec SAs by the following connection types:

- IPSec
- IPSec over UDP
- IPSec over NAT-T
- IPSec over TCP
- IPSec VPN load balancing

```
hostname(config)# show ipsec sa summary
```

```
Current IPSec SA's:          Peak IPSec SA's:
IPSec           :           2      Peak Concurrent SA   :       14
IPSec over UDP   :           2      Peak Concurrent L2L  :        0
IPSec over NAT-T :           4      Peak Concurrent RA   :       14
IPSec over TCP   :           6
IPSec VPN LB     :           0
Total           :          14
hostname(config)#
```

## Related Commands

Command	Description
<b>clear ipsec sa</b>	Removes IPSec SAs entirely or based on specific parameters.
<b>show ipsec sa</b>	Displays a list of IPSec SAs.
<b>show ipsec stats</b>	Displays a list of IPSec statistics.

# show ipsec stats

To display a list of IPSec statistics, use the **show ipsec stats** command in global configuration mode or privileged EXEC mode.

## show ipsec stats

**Syntax Description** This command has no keywords or variables.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	—	—
Privileged EXEC	•	•	•	—	—

Command History	Release	Modification
	7.0(1)	This command was introduced.

**Examples** The following example, entered in global configuration mode, displays IPSec statistics:

```
hostname(config)# show ipsec stats
```

```
IPsec Global Statistics
```

```
-----
```

```
Active tunnels: 2
```

```
Previous tunnels: 9
```

```
Inbound
```

```
Bytes: 4933013
```

```
Decompressed bytes: 4933013
```

```
Packets: 80348
```

```
Dropped packets: 0
```

```
Replay failures: 0
```

```
Authentications: 80348
```

```
Authentication failures: 0
```

```
Decryptions: 80348
```

```
Decryption failures: 0
```

```
Decapsulated fragments needing reassembly: 0
```

```
Outbound
```

```
Bytes: 4441740
```

```
Uncompressed bytes: 4441740
```

```
Packets: 74029
```

```
Dropped packets: 0
```

```
Authentications: 74029
```

```
Authentication failures: 0
```

```
Encryptions: 74029
```

```

Encryption failures: 0
Fragmentation successes: 3
    Pre-fragmentation successes:2
    Post-fragmentation successes: 1
Fragmentation failures: 2
    Pre-fragmentation failures:1
    Post-fragmentation failures: 1
Fragments created: 10
PMTUs sent: 1
PMTUs recvd: 2
Protocol failures: 0
Missing SA failures: 0
System capacity failures: 0
hostname(config)#

```

**Related Commands**

Command	Description
<b>clear ipsec sa</b>	Clears IPSec SAs or counters based on specified parameters.
<b>crypto ipsec transform-set</b>	Defines a transform set.
<b>show ipsec sa</b>	Displays IPSec SAs based on specified parameters.
<b>show ipsec sa summary</b>	Displays a summary of IPSec SAs.

# show ipv6 access-list

To display the IPv6 access list, use the **show ipv6 access-list** command in privileged EXEC mode. The IPv6 access list determines what IPv6 traffic can pass through the security appliance.

**show ipv6 access-list** [*id* [*source-ipv6-prefix/prefix-length* | **any** | **host** *source-ipv6-address*]]

## Syntax Description

<b>any</b>	(Optional) An abbreviation for the IPv6 prefix <code>::/0</code> .
<b>host</b> <i>source-ipv6-address</i>	(Optional) IPv6 address of a specific host. When provided, only the access rules for the specified host are displayed.
<i>id</i>	(Optional) The access list name. When provided, only the specified access list is displayed.
<i>source-ipv6-prefix</i> <i>/prefix-length</i>	(Optional) IPv6 network address and prefix. When provided, only the access rules for the specified IPv6 network are displayed.

## Defaults

Displays all IPv6 access lists.

## Command Modes

The following table shows the modes in which you can enter the command:

	Firewall Mode		Security Context		
				Multiple	
Command Mode	Routed	Transparent	Single	Context	System
Privileged EXEC	•	—	•	•	—

## Command History

Release	Modification
7.0(1)	This command was introduced.

## Usage Guidelines

The **show ipv6 access-list** command provides output similar to the **show ip access-list** command, except that it is IPv6-specific.

## Examples

The following is sample output from the **show ipv6 access-list** command. It shows IPv6 access lists named inbound, tcptraffic, and outbound.

```
hostname# show ipv6 access-list
IPv6 access list inbound
  permit tcp any any eq bgp reflect tcptraffic (8 matches) sequence 10
  permit tcp any any eq telnet reflect tcptraffic (15 matches) sequence 20
  permit udp any any reflect udptraffic sequence 30
IPv6 access list tcptraffic (reflexive) (per-user)
  permit tcp host 2001:0DB8:1::1 eq bgp host 2001:0DB8:1::2 eq 11000 timeout 300 (time
    left 243) sequence 1
  permit tcp host 2001:0DB8:1::1 eq telnet host 2001:0DB8:1::2 eq 11001 timeout 300
    (time left 296) sequence 2
```



```
IPv6 access list outbound
  evaluate udptraffic
  evaluate tcptraffic
```

#### Related Commands

Command	Description
<b>ipv6 access-list</b>	Creates an IPv6 access list.

# show ipv6 interface

To display the status of interfaces configured for IPv6, use the **show ipv6 interface** command in privileged EXEC mode.

**show ipv6 interface** [**brief**] [*if\_name*] [**prefix**]

## Syntax Description

<b>brief</b>	Displays a brief summary of IPv6 status and configuration for each interface.
<i>if_name</i>	(Optional) The internal or external interface name, as designated by the <b>nameif</b> command. The status and configuration for only the designated interface is shown.
<b>prefix</b>	(Optional) Prefix generated from a local IPv6 prefix pool. The prefix is the network portion of the IPv6 address.

## Defaults

Displays all IPv6 interfaces.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Privileged EXEC	•	—	•	•	—

## Command History

Release	Modification
7.0(1)	This command was introduced.

## Usage Guidelines

The **show ipv6 interface** command provides output similar to the **show interface** command, except that it is IPv6-specific. If the interface hardware is usable, the interface is marked *up*. If the interface can provide two-way communication, the line protocol is marked *up*.

When an interface name is not specified, information on all IPv6 interfaces is displayed. Specifying an interface name displays information about the specified interface.

## Examples

The following is sample output from the **show ipv6 interface** command:

```
hostname# show ipv6 interface outside
interface ethernet0 "outside" is up, line protocol is up
  IPv6 is enabled, link-local address is 2001:0DB8::/29 [TENTATIVE]
  Global unicast address(es):
    2000::2, subnet is 2000::/64
  Joined group address(es):
    FF02::1
```

```
FF02::1:FF11:6770
MTU is 1500 bytes
ND DAD is enabled, number of DAD attempts: 1
ND reachable time is 30000 milliseconds
ND advertised reachable time is 0 milliseconds
ND advertised retransmit interval is 0 milliseconds
ND router advertisements are sent every 200 seconds
ND router advertisements live for 1800 seconds
```

The following is sample output from the **show ipv6 interface** command when entered with the **brief** keyword:

```
hostname# show ipv6 interface brief
outside [up/up]
    unassigned
inside [up/up]
    fe80::20d:29ff:fe1d:69f0
    fec0::a:0:0:a0a:a70
vlan101 [up/up]
    fe80::20d:29ff:fe1d:69f0
    fec0::65:0:0:a0a:6570
dmz-ca [up/up]
    unassigned
```

The following is sample output from the **show ipv6 interface** command. It shows the characteristics of an interface which has generated a prefix from an address.

```
hostname# show ipv6 interface inside prefix
IPv6 Prefix Advertisements inside
Codes: A - Address, P - Prefix-Advertisement, O - Pool
        U - Per-user prefix, D - Default        N - Not advertised, C - Calendar

AD      fec0:0:0:a::/64 [LA] Valid lifetime 2592000, preferred lifetime 604800
```

# show ipv6 neighbor

To display the IPv6 neighbor discovery cache information, use the **show ipv6 neighbor** command in privileged EXEC mode.

**show ipv6 neighbor** [*if\_name* | *address*]

## Syntax Description

<i>address</i>	(Optional) Displays neighbor discovery cache information for the supplied IPv6 address only.
<i>if_name</i>	(Optional) Displays cache information for the supplied interface name, as configure by the <b>nameif</b> command, only.

## Defaults

No default behavior or values.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Privileged EXEC	•	—	•	•	—

## Command History

Release	Modification
7.0(1)	This command was introduced.

## Usage Guidelines

The following information is provided by the **show ipv6 neighbor** command:

- **IPv6 Address**—the IPv6 address of the neighbor or interface.
- **Age**—the time (in minutes) since the address was confirmed to be reachable. A hyphen (-) indicates a static entry.
- **Link-layer Addr**—MAC address. If the address is unknown, a hyphen (-) is displayed.
- **State**—The state of the neighbor cache entry.



### Note

Reachability detection is not applied to static entries in the IPv6 neighbor discovery cache; therefore, the descriptions for the **INCMP** (Incomplete) and **REACH** (Reachable) states are different for dynamic and static cache entries.

The following are possible states for dynamic entries in the IPv6 neighbor discovery cache:

- **INCMP**—(Incomplete) Address resolution is being performed on the entry. A neighbor solicitation message has been sent to the solicited-node multicast address of the target, but the corresponding neighbor advertisement message has not yet been received.

- **REACH**—(Reachable) Positive confirmation was received within the last ReachableTime milliseconds that the forward path to the neighbor was functioning properly. While in **REACH** state, the device takes no special action as packets are sent.
- **STALE**—More than ReachableTime milliseconds have elapsed since the last positive confirmation was received that the forward path was functioning properly. While in **STALE** state, the device takes no action until a packet is sent.
- **DELAY**—More than ReachableTime milliseconds have elapsed since the last positive confirmation was received that the forward path was functioning properly. A packet was sent within the last DELAY\_FIRST\_PROBE\_TIME seconds. If no reachability confirmation is received within DELAY\_FIRST\_PROBE\_TIME seconds of entering the **DELAY** state, send a neighbor solicitation message and change the state to **PROBE**.
- **PROBE**—A reachability confirmation is actively sought by resending neighbor solicitation messages every RetransTimer milliseconds until a reachability confirmation is received.
- **????**—Unknown state.

The following are possible states for static entries in the IPv6 neighbor discovery cache:

- **INCOMP**—(Incomplete) The interface for this entry is down.
- **REACH**—(Reachable) The interface for this entry is up.

- **Interface**

Interface from which the address was reachable.

## Examples

The following is sample output from the **show ipv6 neighbor** command when entered with an interface:

```
hostname# show ipv6 neighbor inside
IPv6 Address                               Age Link-layer Addr State Interface
2000:0:0:4::2                             0 0003.a0d6.141e REACH inside
FE80::203:A0FF:FED6:141E                   0 0003.a0d6.141e REACH inside
3001:1::45a                               - 0002.7d1a.9472 REACH inside
```

The following is sample output from the **show ipv6 neighbor** command when entered with an IPv6 address:

```
hostname# show ipv6 neighbor 2000:0:0:4::2
IPv6 Address                               Age Link-layer Addr State Interface
2000:0:0:4::2                             0 0003.a0d6.141e REACH inside
```

## Related Commands

Command	Description
<b>clear ipv6 neighbors</b>	Deletes all entries in the IPv6 neighbor discovery cache, except static entries.
<b>ipv6 neighbor</b>	Configures a static entry in the IPv6 neighbor discovery cache.

# show ipv6 route

To display the contents of the IPv6 routing table, use the **show ipv6 route** command in privileged EXEC mode.

## show ipv6 route

### Syntax Description

This command has no arguments or keywords.

### Defaults

No default behavior or values.

### Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Privileged EXEC	•	—	•	•	—

### Command History

Release	Modification
7.0(1)	This command was introduced.

### Usage Guidelines

The **show ipv6 route** command provides output similar to the **show route** command, except that the information is IPv6-specific.

The following information appears in the IPv6 routing table:

- **Codes**—Indicates the protocol that derived the route. Values are as follows:
  - **C**—Connected
  - **L**—Local
  - **S**—Static
  - **R**—RIP derived
  - **B**—BGP derived
  - **I1**—ISIS L1—Integrated IS-IS Level 1 derived
  - **I2**—ISIS L2—Integrated IS-IS Level 2 derived
  - **IA**—ISIS interarea—Integrated IS-IS interarea derived
- **fe80::/10**—Indicates the IPv6 prefix of the remote network.
- **[0/0]**—The first number in the brackets is the administrative distance of the information source; the second number is the metric for the route.
- **via ::**—Specifies the address of the next router to the remote network.

- **inside**—Specifies the interface through which the next router to the specified network can be reached.

### Examples

The following is sample output from the **show ipv6 route** command:

```
hostname# show ipv6 route

IPv6 Routing Table - 7 entries
Codes: C - Connected, L - Local, S - Static, R - RIP, B - BGP
       U - Per-user Static route
       I1 - ISIS L1, I2 - ISIS L2, IA - ISIS interarea
       O - OSPF intra, OI - OSPF inter, OE1 - OSPF ext 1, OE2 - OSPF ext 2
L   fe80::/10 [0/0]
    via ::, inside
    via ::, vlan101
L   fec0::a:0:0:a0a:a70/128 [0/0]
    via ::, inside
C   fec0:0:0:a::/64 [0/0]
    via ::, inside
L   fec0::65:0:0:a0a:6570/128 [0/0]
    via ::, vlan101
C   fec0:0:0:65::/64 [0/0]
    via ::, vlan101
L   ff00::/8 [0/0]
    via ::, inside
    via ::, vlan101
S   ::/0 [0/0]
    via fec0::65:0:0:a0a:6575, vlan101
```

### Related Commands

Command	Description
<b>debug ipv6 route</b>	Displays debug messages for IPv6 routing table updates and route cache updates.
<b>ipv6 route</b>	Adds a static entry to the IPv6 routing table.

# show ipv6 routers

To display IPv6 router advertisement information received from on-link routers, use the **show ipv6 routers** command in privileged EXEC mode.

**show ipv6 routers** [*if\_name*]

## Syntax Description

*if\_name* (Optional) The internal or external interface name, as designated by the **nameif** command, that you want to display information about.

## Defaults

No default behavior or values.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Privileged EXEC	•	—	•	•	—

## Command History

Release	Modification
7.0(1)	This command was introduced.

## Usage Guidelines

When an interface name is not specified, information on all IPv6 interfaces is displayed. Specifying an interface name displays information about the specified interface.

## Examples

The following is sample output from the **show ipv6 routers** command when entered without an interface name:

```
hostname# show ipv6 routers
Router FE80::83B3:60A4 on outside, last update 3 min
  Hops 0, Lifetime 6000 sec, AddrFlag=0, OtherFlag=0
  Reachable time 0 msec, Retransmit time 0 msec
  Prefix 3FFE:C00:8007::800:207C:4E37/96 autoconfig
  Valid lifetime -1, preferred lifetime -1
Router FE80::290:27FF:FE8C:B709 on inside, last update 0 min
  Hops 64, Lifetime 1800 sec, AddrFlag=0, OtherFlag=0
  Reachable time 0 msec, Retransmit time 0 msec
```

## Related Commands

Command	Description
<b>ipv6 route</b>	Adds a static entry to the IPv6 routing table.



# show ipv6 traffic

To display statistics about IPv6 traffic, use the **show ipv6 traffic** command in privileged EXEC mode.

## show ipv6 traffic

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Privileged EXEC	•	—	•	•	—

Command History	Release	Modification
	7.0(1)	This command was introduced.

**Usage Guidelines** Use the **clear ipv6 traffic** command to clear the traffic counters.

**Examples** The following is sample output from the **show ipv6 traffic** command:

```
hostname# show ipv6 traffic
IPv6 statistics:
  Rcvd:  545 total, 545 local destination
         0 source-routed, 0 truncated
         0 format errors, 0 hop count exceeded
         0 bad header, 0 unknown option, 0 bad source
         0 unknown protocol, 0 not a router
         218 fragments, 109 total reassembled
         0 reassembly timeouts, 0 reassembly failures
  Sent:  228 generated, 0 forwarded
         1 fragmented into 2 fragments, 0 failed
         0 encapsulation failed, 0 no route, 0 too big
  Mcast: 168 received, 70 sent

ICMP statistics:
  Rcvd: 116 input, 0 checksum errors, 0 too short
         0 unknown info type, 0 unknown error type
  unreachable: 0 routing, 0 admin, 0 neighbor, 0 address, 0 port
  parameter: 0 error, 0 header, 0 option
         0 hopcount expired, 0 reassembly timeout, 0 too big
         0 echo request, 0 echo reply
         0 group query, 0 group report, 0 group reduce
```

## ■ show ipv6 traffic

```

0 router solicit, 60 router advert, 0 redirects
31 neighbor solicit, 25 neighbor advert
Sent: 85 output, 0 rate-limited
unreach: 0 routing, 0 admin, 0 neighbor, 0 address, 0 port
parameter: 0 error, 0 header, 0 option
0 hopcount expired, 0 reassembly timeout, 0 too big
0 echo request, 0 echo reply
0 group query, 0 group report, 0 group reduce
0 router solicit, 18 router advert, 0 redirects
33 neighbor solicit, 34 neighbor advert

UDP statistics:
Rcvd: 109 input, 0 checksum errors, 0 length errors
      0 no port, 0 dropped
Sent: 37 output

TCP statistics:
Rcvd: 85 input, 0 checksum errors
Sent: 103 output, 0 retransmitted

```

**Related Commands**

Command	Description
<b>clear ipv6 traffic</b>	Clears ipv6 traffic counters.



