



CHAPTER 10

default through dynamic-filter whitelist Commands

default (crl configure)

To return all CRL parameters to their system default values, use the **default** command in **crl configure** configuration mode. The **crl configure** configuration mode is accessible from the **crypto ca trustpoint** configuration mode. These parameters are used only when the LDAP server requires them.

default

Syntax Description This command has no arguments or keywords.

Defaults No default behaviors or values.

Command Modes The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Crl configure configuration	•		•		

Release	Modification
7.0	This command was introduced.

Usage Guidelines Invocations of this command do not become part of the active configuration.

Examples The following example enters **ca-crl** configuration mode, and returns CRL command values to their defaults:

```
hostname(config)# crypto ca trustpoint central
hostname(ca-trustpoint)# crl configure
hostname(ca-crl)# default
hostname(ca-crl)#
```

Command	Description
crl configure	Enters crl configure configuration mode.
crypto ca trustpoint	Enters trustpoint configuration mode.
protocol ldap	Specifies LDAP as a retrieval method for CRLs.

default (interface)

To return an interface command to its system default value, use the **default** command in interface configuration mode.

default *command*

Syntax Description

command Specifies the command that you want to set to the default. For example:

default activation key

Defaults

No default behaviors or values.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Interface configuration	•	•	•	•	—

Command History

Release	Modification
7.0(1)	This command was introduced.

Usage Guidelines

This command is a run-time command; when you enter it, it does not become part of the active configuration.

Examples

The following example enters interface configuration mode, and returns the security level to its default:

```
hostname(config)# interface gigabitethernet 0/0
hostname(config-if)# default security-level
```

Related Commands

Command	Description
interface	Enters interface configuration mode.

default (time-range)

To restore default settings for the **absolute** and **periodic** commands, use the **default** command in time-range configuration mode.

```
default { absolute | periodic days-of-the-week time to [days-of-the-week] time }
```

Syntax Description

absolute	Defines an absolute time when a time range is in effect.
days-of-the-week	<p>The first occurrence of this argument is the starting day or day of the week that the associated time range is in effect. The second occurrence is the ending day or day of the week the associated statement is in effect.</p> <p>This argument is any single day or combinations of days: Monday, Tuesday, Wednesday, Thursday, Friday, Saturday, and Sunday. Other possible values are:</p> <ul style="list-style-type: none"> daily—Monday through Sunday weekdays—Monday through Friday weekend—Saturday and Sunday <p>If the ending days of the week are the same as the starting days of the week, you can omit them.</p>
periodic	Specifies a recurring (weekly) time range for functions that support the time-range feature.
time	Specifies the time in the format HH:MM. For example, 8:00 is 8:00 a.m. and 20:00 is 8:00 p.m.
to	Entry of the to keyword is required to complete the range “from start-time to end-time.”

Defaults

There are no default settings for this command.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Time-range configuration	•	•	•	•	

Command History

Release	Modification
7.0	This command was introduced.

Usage Guidelines

If the end days-of-the-week value is the same as the start value, you can omit them.

If a **time-range** command has both **absolute** and **periodic** values specified, then the **periodic** commands are evaluated only after the **absolute start** time is reached, and are not further evaluated after the **absolute end** time is reached.

The time-range feature relies on the system clock of the adaptive security appliance; however, the feature works best with NTP synchronization.

Examples

The following example shows how to restore the default behavior of the **absolute** keyword:

```
hostname(config-time-range) # default absolute
```

Related Commands

Command	Description
absolute	Defines an absolute time when a time range is in effect.
periodic	Specifies a recurring (weekly) time range for functions that support the time-range feature.
time-range	Defines access control to the adaptive security appliance based on time.

default-acl

To specify the ACL to be used as the default ACL for NAC Framework sessions that fail posture validation, use the **default-acl** command in nac-policy-nac-framework configuration mode. To remove the command from the NAC policy, use the **no** form of the command.

[no] **default-acl** *acl-name*

Syntax Description	<i>acl-name</i>	Names the access control list to be applied to the session.
--------------------	-----------------	---

Defaults	No default behavior or values.
----------	--------------------------------

Command Modes	The following table shows the modes in which you can enter the command:
---------------	---

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
nac-policy-nac-framework configuration	•	—	•	—	—

Command History	Release	Modification
	7.3(0)	“nac-” removed from command name. Command moved from group-policy configuration mode to nac-policy-nac-framework configuration mode.
	7.2(1)	This command was introduced.

Usage Guidelines	<p>Each group policy points to a default ACL to be applied to hosts that match the policy and are eligible for NAC. The adaptive security appliance applies the NAC default ACL before posture validation. Following posture validation, the adaptive security appliance replaces the default ACL with the one obtained from the Access Control Server for the remote host. It retains the default ACL if posture validation fails.</p> <p>The adaptive security appliance also applies the NAC default ACL if clientless authentication is enabled (which is the default setting).</p>
------------------	---

Examples	<p>The following example identifies acl-1 as the ACL to be applied before posture validation succeeds:</p> <pre>hostname(config-group-policy)# default-acl acl-1 hostname(config-group-policy)</pre> <p>The following example inherits the ACL from the default group policy.</p> <pre>hostname(config-group-policy)# no default-acl hostname(config-group-policy)</pre>
----------	--

Related Commands

Command	Description
<code>nac-policy</code>	Creates and accesses a Cisco NAC policy, and specifies its type.
<code>nac-settings</code>	Assigns a NAC policy to a group policy.
<code>debug nac</code>	Enables logging of NAC Framework events
<code>show vpn-session_summary.db</code>	Displays the number IPSec, WebVPN, and NAC sessions.
<code>show vpn-session.db</code>	Displays information about VPN sessions, including NAC results.

default enrollment

To return all enrollment parameters to their system default values, use the **default enrollment** command in crypto ca trustpoint configuration mode.

default enrollment

Syntax Description

This command has no arguments or keywords.

Defaults

No default behavior or values.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Crypto ca trustpoint configuration	•	•	•	•	•

Command History

Release	Modification
7.0	This command was introduced.

Usage Guidelines

Invocations of this command do not become part of the active configuration.

Examples

The following example enters crypto ca trustpoint configuration mode for trustpoint central, and returns all enrollment parameters to their default values within trustpoint central:

```
hostname<config># crypto ca trustpoint central
hostname<ca-trustpoint># default enrollment
hostname<ca-trustpoint>#
```

Related Commands

Command	Description
clear configure crypto ca trustpoint	Removes all trustpoints.
crl configure	Enters crl configuration mode.
crypto ca trustpoint	Enters trustpoint configuration mode.

default-domain

To set a default domain name for users of the group policy, use the **default-domain** command in group-policy configuration mode. To delete a domain name, use the **no** form of this command.

To delete all default domain names, use the **no default-domain** command without arguments. This deletes all configured default domain names, including a null list created by issuing the **default-domain none** command.

default-domain { *value domain-name* | **none** }

no default-domain [*domain-name*]

Syntax Description

none	Indicates that there is no default domain name. Sets a default domain name with a null value, thereby disallowing a default domain name. Prevents inheriting a default domain name from a default or specified group policy.
value <i>domain-name</i>	Identifies the default domain name for the group.

Defaults

No default behavior or values.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Group-policy configuration	•	—	•	—	—

Command History

Release	Modification
7.0(1)	This command was introduced.

Usage Guidelines

To prevent users from inheriting a domain name, use the **default-domain none** command.

The adaptive security appliance passes the default domain name to the legacy VPN client (connecting with IPsec/IKEv1) or the AnyConnect VPN client (connecting with SSL) to append to DNS queries that omit the domain field. This domain name applies only to tunneled packets. When there are no default domain names, users inherit the default domain name in the default group policy.

You can use only alphanumeric characters, hyphens (-), and periods (.) in default domain names.

Examples

The following example shows how to set a default domain name of FirstDomain for the group policy named FirstGroup:

```
hostname(config)# group-policy FirstGroup attributes
hostname(config-group-policy)# default-domain value FirstDomain
```

Related Commands

Command	Description
split-dns	Provides a list of domains to be resolved through the split tunnel.
split-tunnel-network-list	Identifies the access list the adaptive security appliance uses to distinguish networks that require tunneling and those that do not.
split-tunnel-policy	Lets an IPSec client conditionally direct packets over an IPSec tunnel in encrypted form, or to a network interface in cleartext form.

default-group-policy

To specify the set of attributes that the user inherits by default, use the **default-group-policy** command in tunnel-group general-attributes configuration mode. To eliminate a default group policy name, use the **no** form of this command.

default-group-policy *group-name*

no default-group-policy *group-name*

Syntax Description

group-name Specifies the name of the default group.

Defaults

The default group name is DfltGrpPolicy.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Tunnel-group general-attributes configuration	•	—	•	—	—

Command History

Version	Modification
7.0(1)	This command was introduced.
7.1(1)	The default-group-policy command in webvpn configuration mode was deprecated. The default-group-policy command in tunnel-group general-attributes mode replaces it.

Usage Guidelines

In Version 7.1(1), if you enter this command in webvpn configuration mode, it is transformed to the same command in tunnel-group general-attributes mode.

The default group policy DfltGrpPolicy comes with the initial configuration of the adaptive security appliance. You can apply this attribute to all tunnel-group types.

Examples

The following example entered in config-general configuration mode, specifies a set of attributes for users to inherit by default for an IPSec LAN-to-LAN tunnel group named “standard-policy”. This set of commands defines the accounting server, the authentication server, the authorization server and the address pools.

```
hostname(config)# tunnel-group standard-policy type ipsec-ra
hostname(config)# tunnel-group standard-policy general-attributes
hostname(config-tunnel-general)# default-group-policy first-policy
hostname(config-tunnel-general)# accounting-server-group aaa-server123
hostname(config-tunnel-general)# address-pool (inside) addrpool1 addrpool2 addrpool3
hostname(config-tunnel-general)# authentication-server-group aaa-server456
```

```
hostname(config-tunnel-general)# authorization-server-group aaa-server78  
hostname(config-tunnel-general)#
```

Related Commands

Command	Description
clear-configure tunnel-group	Clears all configured tunnel groups.
group-policy	Creates or edits a group policy
show running-config tunnel group	Shows the tunnel group configuration for all tunnel groups or for a particular tunnel group.
tunnel-group general-attributes	Specifies the general attributes for the named tunnel-group.

default-group-policy (webvpn)

To specify the name of the group policy to use when the WebVPN or e-mail proxy configuration does not specify a group policy, use the **default-group-policy** command in various configuration modes. To remove the attribute from the configuration, use the **no** version of this command.

default-group-policy *groupname*

no default-group-policy

Syntax Description

groupname	Identifies the previously configured group policy to use as the default group policy. Use the group-policy command to configure a group policy.
-----------	--

Defaults

A default group policy, named *DfltGrpPolicy*, always exists on the adaptive security appliance. This **default-group-policy** command lets you substitute a group policy that you create as the default group policy for WebVPN and e-mail proxy sessions. An alternative is to edit the *DfltGrpPolicy*.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Webvpn configuration	•	—	•	—	—
Imap4s configuration	•	—	•	—	—
Pop3s configuration	•	—	•	—	—
Smtps configuration	•	—	•	—	—

Command History

Version	Modification
7.0(1)	This command was introduced.
7.1(1)	This command was deprecated in webvpn configuration mode and moved to tunnel-group general-attributes configuration mode.

Usage Guidelines

WebVPN, IMAP4S, POP3S, and SMTPS sessions require either a specified or a default group policy. For WebVPN, use this command in webvpn mode. For e-mail proxy, use this command in the applicable e-mail proxy mode.

In Version 7.1(1), if you enter this command in webvpn configuration mode, it is transformed to the same command in tunnel-group general-attributes mode.

You can edit, but not delete the system DefaultGroupPolicy. It has the following AVPs:

Attribute	Default Value
wins-server	none
dns-server	none
dhcp-network-scope	none
vpn-access-hours	unrestricted
vpn-simultaneous-logins	3
vpn-idle-timeout	30 minutes
vpn-session-timeout	none
vpn-filter	none
vpn-tunnel-protocol	WebVPN
ip-comp	disable
re-xauth	disable
group-lock	none
pfs	disable
client-access-rules	none
banner	none
password-storage	disabled
ipsec-udp	disabled
ipsec-udp-port	0
backup-servers	keep-client-config
split-tunnel-policy	tunnelall
split-tunnel-network-list	none
default-domain	none
split-dns	none
intercept-dhcp	disable
client-firewall	none
secure-unit-authentication	disabled
user-authentication	disabled
user-authentication-idle-timeout	none
ip-phone-bypass	disabled
leap-bypass	disabled
nem	disabled
webvpn attributes:	
filter	none
functions	disabled
homepage	none
html-content-filter	none
port-forward	disabled
port-forward-name	none
url-list	none

Examples

The following example shows how to specify a default group policy called WebVPN7 for WebVPN:

```
hostname(config)# webvpn  
hostname(config-webvpn)# default-group-policy WebVPN7
```

default-idle-timeout

To set a default idle timeout value for WebVPN users, use the **default-idle-timeout** command in webvpn configuration mode. To remove the default idle timeout value from the configuration and reset the default, use the **no** form of this command.

The default idle timeout prevents stale sessions.

default-idle-timeout *seconds*

no default-idle-timeout

Syntax Description	seconds	Specifies the number of seconds for the idle time out. The minimum is 60 seconds, maximum is 1 day (86400 seconds).
--------------------	---------	---

Defaults	1800 seconds (30 minutes).
----------	----------------------------

Command Modes	The following table shows the modes in which you can enter the command:
---------------	---

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Webvpn configuration	•	—	•	—	—

Command History	Release	Modification
	7.0	This command was introduced.

Usage Guidelines	<p>The adaptive security appliance uses the value you set here if there is no idle timeout defined for a user, if the value is 0, or if the value does not fall into the valid range.</p> <p>We recommend that you set this command to a short time period. This is because a browser set to disable cookies (or one that prompts for cookies and then denies them) can result in a user not connecting but nevertheless appearing in the sessions database. If the maximum number of connections permitted is set to one (vpn-simultaneous-logins command), the user cannot log back in because the database indicates that the maximum number of connections already exists. Setting a low idle timeout removes such phantom sessions quickly, and lets a user log in again.</p>
------------------	---

Examples	<p>The following example shows how to set the default idle timeout to 1200 seconds (20 minutes):</p> <pre>hostname(config)# webvpn hostname(config-webvpn)# default-idle-timeout 1200</pre>
----------	---

Related Commands	Command	Description
	vpn-simultaneous-logins	Sets the maximum number of simultaneous VPN sessions permitted. Use in group-policy or username mode.

default-information (EIGRP)

To control the candidate default route information for the EIGRP routing process, use the **default-information** command in router configuration mode. To suppress EIGRP candidate default route information in incoming or outbound updates, use the **no** form of this command.

default-information {in | out} [*acl-name*]

no default-information {in | out}

Syntax Description

<i>acl-name</i>	(Optional) Named standard access list.
in	Configures EIGRP to accept exterior default routing information.
out	Configures EIGRP to advertise external routing information.

Defaults

Exterior routes are accepted and sent.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Router configuration	•	—	•	—	—

Command History

Release	Modification
8.0(2)	This command was introduced.

Usage Guidelines

Only the **no** form of the command or **default-information** commands with an access list specified will appear in the running configuration because, by default, the candidate default routing information is accepted and sent. The **no** form of the command does not take an *acl-name* argument.

Examples

The following example disables the receipt of exterior or candidate default route information:

```
hostname(config)# router eigrp 100
hostname(config-router)# no default-information in
```

Related Commands

Command	Description
router eigrp	Creates an EIGRP routing process and enters configuration mode for that process.

default-information originate (OSPF)

To generate a default external route into an OSPF routing domain, use the **default-information originate** command in router configuration mode. To disable this feature, use the **no** form of this command.

default-information originate [**always**] [**metric** *value*] [**metric-type** {**1** | **2**}] [**route-map** *name*]

no default-information originate [[**always**] [**metric** *value*] [**metric-type** {**1** | **2**}] [**route-map** *name*]]

Syntax Description

always	(Optional) Always advertises the default route regardless of whether the software has a default route.
metric <i>value</i>	(Optional) Specifies the OSPF default metric value from 0 to 16777214.
metric-type { 1 2 }	(Optional) External link type associated with the default route advertised into the OSPF routing domain. Valid values are as follows: <ul style="list-style-type: none"> 1—Type 1 external route. 2—Type 2 external route.
route-map <i>name</i>	(Optional) Name of the route map to apply.

Defaults

The default values are as follows:

- metric** *value* is 1.
- metric-type** is 2.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Router configuration	•	—	•	—	—

Command History

Release	Modification
Preexisting	This command was preexisting.

Usage Guidelines

Using the **no** form of this command with optional keywords and arguments only removes the optional information from the command. For example, entering **no default-information originate metric 3** removes the **metric 3** option from the command in the running configuration. To remove the complete command from the running configuration, use the **no** form of the command without any options: **no default-information originate**.

Examples

The following example shows how to use the **default-information originate** command with an optional metric and metric type:

```
hostname(config-router)# default-information originate always metric 3 metric-type 2
hostname(config-router)#
```

Related Commands

Command	Description
router ospf	Enters router configuration mode.
show running-config router	Displays the commands in the global router configuration.

default-information originate (RIP)

To generate a default route into RIP, use the **default-information originate** command in router configuration mode. To disable this feature, use the **no** form of this command.

default-information originate [**route-map** *name*]

no default-information originate [**route-map** *name*]

Syntax Description

route-map *name* (Optional) Name of the route map to apply. The routing process generates the default route if the route map is satisfied.

Defaults

This command is disabled by default.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Router configuration	•	—	•	—	—

Command History

Release	Modification
7.2(1)	This command was introduced.

Usage Guidelines

The route map referenced in the **default-information originate** command cannot use an extended access list; it can use a standard access list.

Examples

The following example shows how generate a default route into RIP:

```
hostname(config)# router rip
hostname(config-router)# network 10.0.0.0
hostname(config-router)# default-information originate
```

Related Commands

Command	Description
router rip	Enters router configuration mode for the RIP routing process.
show running-config router	Displays the commands in the global router configuration.

default-language

To set the default language displayed on the Clientless SSL VPN pages, use the **default-language** command from webvpn configuration mode.

default-language *language*

Syntax Description

language Specifies the name of a previously-imported translation table.

Defaults

The default language is en-us (English spoken in the United States).

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
webvpn configuration	•	—	•	—	—

Command History

Release	Modification
8.0(2)	This command was introduced.

Usage Guidelines

The adaptive security appliance provides language translation for the portal and screens displayed to users that initiate browser-based, clientless SSL VPN connections, as well as the user interface displayed to AnyConnect VPN Client users.

The default language is displayed to the Clientless SSL VPN user when they initially connect to the adaptive security appliance, before logging in. Thereafter, the language displayed is affected by the tunnel group or group policy settings and any customization that they reference.

Examples

The following example changes the default language to Chinese:with the name *Sales*:

```
hostname(config-webvpn)# default-language zh
```

Related Commands

Command	Description
import webvpn translation-table	Imports a translation table.
revert	Removes translation tables from cache memory.
show import webvpn translation-table	Displays information about imported translation tables.

default-metric

To specify the EIGRP metrics for redistributed routes, use the **default-metric** command in router configuration mode. To restore the default values, use the **no** form of this command.

default-metric *bandwidth delay reliability loading mtu*

no default-metric *bandwidth delay reliability loading mtu*

Syntax Description		
<i>bandwidth</i>		The minimum bandwidth of the route in kilobytes per second. Valid values are from 1 to 4294967295.
<i>delay</i>		The route delay in tens of microseconds. Valid values are 1 to 4294967295.
<i>reliability</i>		The likelihood of successful packet transmission expressed as a number from 0 through 255. The value 255 means 100 percent reliability; 0 means no reliability.
<i>loading</i>		The effective bandwidth of the route expressed as a number from 1 to 255 (255 is 100 percent loading).
<i>mtu</i>		The smallest allowed value for the MTU, expressed in bytes. Valid values are from 1 to 65535.

Defaults

Only connected routes can be redistributed without a default metric. The metric of redistributed connected routes is set to 0.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Router configuration	•	—	•	—	—

Command History

Release	Modification
8.0(2)	This command was introduced.

Usage Guidelines

You must use a default metric to redistribute a protocol into EIGRP unless you use the **metric** keyword and attributes in the **redistribute** command. Metric defaults have been carefully set to work for a wide variety of networks. Take great care when changing these values. Keeping the same metrics is supported only when you are redistributing from static routes.

Examples

The following example shows how the redistributed RIP route metrics are translated into EIGRP metrics with values as follows: bandwidth = 1000, delay = 100, reliability = 250, loading = 100, and MTU = 1500.

```
hostname(config)# router eigrp 100
hostname(config-router)# network 172.16.0.0
hostname(config-router)# redistribute rip
hostname(config-router)# default-metric 1000 100 250 100 1500
```

Related Commands

Command	Description
router eigrp	Creates an EIGRP routing process and enters router configuration mode for that process.
redistribute (EIGRP)	Redistributes routes into the EIGRP routing process.

delay

To set a delay value for an interface, use the **delay** command in interface configuration mode. To restore the default delay value, use the **no** form of this command.

delay *delay-time*

no delay

Syntax Description

delay-time The delay time in tens of microseconds. Valid values are from 1 to 16777215.

Defaults

The default delay depends upon the interface type. Use the **show interface** command to see the delay value for an interface.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Interface configuration	•	—	•	—	—

Command History

Release	Modification
8.0(2)	This command was introduced.

Usage Guidelines

The value entered is in tens of microseconds. The delay value displayed in the **show interface** output is in microseconds.

Examples

The following example changes the delay on an interface from the default 1000 to 2000. Truncated **show interface** command output is included before and after the **delay** command to show how the command affects the delay values. The delay value is noted in the second line of the **show interface** output, after the DLY label.

Notice that the command entered to change the delay value to 2000 is **delay 200**, not **delay 2000**. This is because the value entered with the **delay** command is in tens of microseconds, and the **show interface** output displays microseconds.

```
hostname(config)# interface Ethernet0/0
hostname(config-if)# show interface Ethernet0/0

Interface Ethernet0/0 "outside", is up, line protocol is up
  Hardware is i82546GB rev03, BW 100 Mbps, DLY 1000 usec
    Auto-Duplex(Half-duplex), Auto-Speed(100 Mbps)
    MAC address 0013.c480.7e16, MTU 1500
```

delay

```

        IP address 10.86.194.224, subnet mask 255.255.254.0
! Remainder of the output removed

```

```

hostname(config-if)# delay 200
hostname(config-if)# show interface Ethernet0/0

```

```

Interface Ethernet0/0 "outside", is up, line protocol is up
  Hardware is i82546GB rev03, BW 100 Mbps, DLY 2000 usec
    Auto-Duplex(Half-duplex), Auto-Speed(100 Mbps)
    MAC address 0013.c480.7e16, MTU 1500
    IP address 10.86.194.224, subnet mask 255.255.254.0
! Remainder of the output removed

```

Related Commands

Command	Description
show interface	Displays interface statistics and settings.

delete

To delete a file from Flash memory, use the **delete** command in privileged EXEC mode.

delete [/noconfirm] [/recursive] [disk0: | disk1: | flash:][path/]filename

Syntax Description	/noconfirm	(Optional) Does not prompt for confirmation.
	/recursive	(Optional) Deletes the specified file recursively in all subdirectories.
	disk0:	(Optional) Specifies the internal Flash memory.
	disk1:	(Optional) Specifies the external Flash memory card.
	<i>filename</i>	Specifies the name of the file to delete.
	flash:	(Optional) Specifies the internal Flash memory. This keyword is the same as disk0 .
	<i>path/</i>	(Optional) Specifies to the path to the file.

Defaults If you do not specify a directory, the directory is the current working directory by default.

Command Modes The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Privileged EXEC	•	•	•	•	•

Command History	Release	Modification
	7.0(1)	This command was introduced.

Usage Guidelines The file is deleted from the current working directory if a path is not specified. Wildcards are supported when deleting files. When deleting files, you are prompted with the filename and must confirm the deletion.

Examples The following example shows how to delete a file named test.cfg in the current working directory:

```
hostname# delete test.cfg
```

Related Commands	Command	Description
	cd	Changes the current working directory to the one specified.

Command	Description
rmdir	Removes a file or directory.
show file	Displays the specified file.

deny-message (group-policy webvpn configuration mode)

To change the message delivered to a remote user who logs into WebVPN successfully, but has no VPN privileges, use the **deny-message value** command in group-webvpn configuration mode. To remove the string so that the remote user does not receive a message, use the **no** form of this command.

deny-message value "*string*"

no deny-message value

Syntax Description

<i>string</i>	Up to 491 alphanumeric characters, including special characters, spaces, and punctuation.
---------------	---

Defaults

The default deny message is: "Login was successful, but because certain criteria have not been met or due to some specific group policy, you do not have permission to use any of the VPN features. Contact your IT administrator for more information."

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Group-webvpn configuration	•	—	•	—	—

Command History

Release	Modification
7.0(1)	This command was introduced.
7.1(1)	This command moved from tunnel-group webvpn configuration mode to group-webvpn configuration mode.

Usage Guidelines

Before entering this command, you must enter the **group-policy name attributes** in global configuration mode, then the **webvpn** command. (This assumes you already have created the policy *name*.)

The **no deny-message none** command removes the attribute from the group-webvpn configuration. The policy inherits the attribute value.

When typing the string in the **deny-message value** command, continue typing even if the command wraps.

The text appears on the remote user's browser upon login, independent of the tunnel policy used for the VPN session.

Examples

The following example shows the first command that creates an internal group policy named group2. The subsequent commands modify the deny message associated with that policy.

deny-message (group-policy webvpn configuration mode)

```
hostname(config)# group-policy group2 internal
hostname(config)# group-policy group2 attributes
hostname(config-group-policy)# webvpn
hostname(config-group-webvpn)# deny-message value "Your login credentials are OK. However,
you have not been granted rights to use the VPN features. Contact your administrator for
more information."
hostname(config-group-webvpn)
```

Related Commands

Command	Description
clear configure group-policy	Removes all group-policy configuration.
group-policy	Creates a group policy.
group-policy attributes	Enters the group-policy attribute configuration mode.
show running-config group-policy [<i>name</i>]	Displays the running group policy configuration for the policy named.
webvpn (group-policy or username configuration mode)	Enters group-policy webvpn configuration mode.

deny version

To deny a specific version of SNMP traffic, use the **deny version** command in snmp-map configuration mode, which is accessible by entering the **snmp-map** command in global configuration mode. To disable this command, use the **no** form of this command.

deny version *version*

no deny version *version*

Syntax Description

<i>version</i>	Specifies the version of SNMP traffic that the adaptive security appliance drops. The permitted values are 1 , 2 , 2c , and 3 .
----------------	---

Defaults

No default behavior or values.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Snmp-map configuration	•	•	•	•	—

Command History

Release	Modification
7.0(1)	This command was introduced.

Usage Guidelines

Use the **deny version** command to restrict SNMP traffic to specific versions of SNMP. Earlier versions of SNMP were less secure, so restricting SNMP traffic to Version 2 may be specified by your security policy. You use the **deny version** command within an SNMP map, which you configure using the **snmp-map** command. After creating the SNMP map, you enable the map using the **inspect snmp** command and then apply it to one or more interfaces using the **service-policy** command.

Examples

The following example shows how to identify SNMP traffic, define a SNMP map, define a policy, and apply the policy to the outside interface:

```
hostname(config)# access-list snmp-acl permit tcp any any eq 161
hostname(config)# access-list snmp-acl permit tcp any any eq 162
hostname(config)# class-map snmp-port
hostname(config-cmap)# match access-list snmp-acl
hostname(config-cmap)# exit
hostname(config)# snmp-map inbound_snmp
hostname(config-snmp-map)# deny version 1
hostname(config-snmp-map)# exit
hostname(config)# policy-map inbound_policy
hostname(config-pmap)# class snmp-port
```

```
hostname(config-pmap-c)# inspect snmp inbound_snmp
hostname(config-pmap-c)# exit
hostname(config-pmap)# exit
hostname(config)# service-policy inbound_policy interface outside
```

Related Commands

Commands	Description
class-map	Defines the traffic class to which to apply security actions.
inspect snmp	Enables SNMP application inspection.
policy-map	Associates a class map with specific security actions.
snmp-map	Defines an SNMP map and enables SNMP map configuration mode.
service-policy	Applies a policy map to one or more interfaces.

description

To add a description for a named configuration unit (for example, for a context or for an object group, or for a DAP record), use the **description** command in various configuration modes. The description adds helpful notes in your configuration. To remove the description, use the **no** form of this command.

description *text*

no description

Syntax Description

text

Sets the description as a text string up to 200 characters in length. For dynamic-access-policy-record mode the maximum length is 80 characters.

If you want to include a question mark (?) in the string, you must type **Ctrl-V** before typing the question mark so you do not inadvertently invoke CLI help.

Defaults

No default behavior or values.

Command Modes

This command is available in various configuration modes.

Command History

Release

Modification

Preexisting

This command was preexisting.

8.0(2)

Support added for dynamic-access-policy-record mode.

Examples

The following example adds a description to the “Administration” context configuration:

```
hostname(config)# context administrator
hostname(config-context)# description This is the admin context.
hostname(config-context)# allocate-interface gigabitethernet0/0.1
hostname(config-context)# allocate-interface gigabitethernet0/1.1
hostname(config-context)# config-url flash://admin.cfg
```

Related Commands

Command

Description

class-map

Identifies traffic to which you apply actions in the **policy-map** command.

context

Creates a security context in the system configuration and enters context configuration mode.

gtp-map

Controls parameters for the GTP inspection engine.

interface

Configures an interface and enters interface configuration mode.

object-group

Identifies traffic to include in the **access-list** command.

policy-map

Identifies actions to apply to traffic identified by the **class-map** command.

dhcp client route distance

To configure an administrative distance for routes learned through DHCP, use the **dhcp client route distance** command in interface configuration mode. To restore the default setting, use the **no** form of this command.

```

dhcp client route distance distance

no dhcp client route distance distance
    
```

Syntax Description	<i>distance</i>	The administrative distance to apply to routes learned through DHCP. Valid values are from 1 to 255.
--------------------	-----------------	--

Defaults	Routes learned through DHCP are given an administrative distance of 1 by default.
----------	---

Command Modes	The following table shows the modes in which you can enter the command:
---------------	---

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Interface configuration	•	—	•	—	—

Command History	Release	Modification
	7.2(1)	This command was introduced.

The **dhcp client route distance** command is checked only when a route is learned from DHCP. If the **dhcp client route distance** command is entered after a route is learned from DHCP, the administrative distance specified does not affect the existing learned route. Only routes learned after the command was entered have the specified administrative distance.

You must specify the **setroute** option on the **ip address dhcp** command to obtain routes through DHCP.

If DHCP is configured on multiple interfaces, you must use the **dhcp client route distance** command on each of the interfaces to indicate the priority of the installed routes.

Examples

The following example obtains the default route through DHCP on GigabitEthernet0/2. The route is tracked by tracking entry object 1. The SLA operation monitors the availability of the 10.1.1.1 gateway off of the outside interface. If the SLA operation fails, then the backup route obtained through DHCP on GigabitEthernet0/3 is used. The backup route is assigned an administrative distance of 254.

```

hostname(config)# sla monitor 123
hostname(config-sla-monitor)# type echo protocol ipIcmpEcho 10.1.1.1 interface outside
hostname(config-sla-monitor-echo)# timeout 1000
hostname(config-sla-monitor-echo)# frequency 3
    
```

```
hostname(config)# sla monitor schedule 123 life forever start-time now
hostname(config)# track 1 rtr 123 reachability
hostname(config)# interface GigabitEthernet0/2
hostname(config-if)# dhcp client route track 1
hostname(config-if)# ip address dhcp setroute
hostname(config)# interface GigabitEthernet0/3
hostname(config-if)# dhcp client route track 1
hostname(config-if)# dhcp client route distance 254
hostname(config-if)# ip address dhcp setroute
```

Related Commands

Command	Description
dhcp client route track	Associates routes learned through DHCP with a tracking entry object.
ip address dhcp	Configures the specified interface with an IP address obtained through DHCP.
sla monitor	Defines an SLA monitoring operation.
track rtr	Creates a tracking entry to poll the SLA.

dhcp client route track

To configure the DHCP client to associate added routes with a specified tracked object number, use the **dhcp client route track** command in interface configuration mode. To disable DHCP client route tracking, use the **no** form of this command.

dhcp client route track *number*

no dhcp client route track

Syntax Description	<i>number</i>	The tracking entry object ID. Valid values are from 1 to 500.
--------------------	---------------	---

Defaults	No default behaviors or values.
----------	---------------------------------

Command Modes	The following table shows the modes in which you can enter the command:
---------------	---

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Interface configuration	•	—	•	—	—

Command History	Release	Modification
	7.2(1)	This command was introduced.

The **dhcp client route track** command is checked only when a route is learned from DHCP. If the **dhcp client route track** command is entered after a route is learned from DHCP, the existing learned routes are not associated with a tracking object. ou must put the following two commands in the correct order. Make sure that you always enter the **dhcp client route track** command first, followed by the **ip address dhcp setroute** command, If you have already entered the **ip address dhcp setroute** command, then remove it and re-enter it in the order previously described. Only routes learned after the command was entered are associated with the specified tracking object.

You must specify the **setroute** option on the **ip address dhcp** command to obtain routes through DHCP.

If DHCP is configured on multiple interfaces, you must use the **dhcp client route distance** command on each of the interfaces to indicate the priority of the installed routes.

The following example obtains the default route through DHCP on GigabitEthernet0/2. The route is tracked by tracking entry object 1. The SLA operation monitors the availability of the 10.1.1.1 gateway off of the outside interface. If the SLA operation fails, then the backup route obtained through DHCP on GigabitEthernet0/3 is used. The backup route is assigned an administrative distance of 254.

```
hostname(config)# sla monitor 123
hostname(config-sla-monitor)# type echo protocol ipIcmpEcho 10.1.1.1 interface outside
```

```
hostname(config-sla-monitor-echo)# timeout 1000
hostname(config-sla-monitor-echo)# frequency 3
hostname(config)# sla monitor schedule 123 life forever start-time now
hostname(config)# track 1 rtr 123 reachability
hostname(config)# interface GigabitEthernet0/2
hostname(config-if)# dhcp client route track 1
hostname(config-if)# ip address dhcp setroute
hostname(config)# interface GigabitEthernet0/3
hostname(config-if)# dhcp client route distance 254
hostname(config-if)# ip address dhcp setroute
```

Related Commands

Command	Description
dhcp client route distance	Assigns an administrative distance to routes learned through DHCP.
ip address dhcp	Configures the specified interface with an IP address obtained through DHCP.
sla monitor	Defines an SLA monitoring operation.
track rtr	Creates a tracking entry to poll the SLA.

dhcp-client broadcast-flag

To allow the adaptive security appliance to set the broadcast flag in the DHCP client packet, use the **dhcp-client broadcast-flag** command in global configuration mode. To disallow the broadcast flag, use the **no** form of this command.

- dhcp-client broadcast-flag**
- no dhcp-client broadcast-flag**

Syntax Description This command has no arguments or keywords.

Defaults By default, the broadcast flag is disabled.

Command Modes The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	—

Command History	Release	Modification
	8.0(2)	This command was introduced.

Usage Guidelines

If you enable the DHCP client for an interface using the **ip address dhcp** command, then you can use this command to set the broadcast flag to 1 in the DHCP packet header when the DHCP client sends a discover requesting an IP address. The DHCP server listens to this broadcast flag and broadcasts the reply packet if the flag is set to 1.

If you enter the **no dhcp-client broadcast-flag** command, the broadcast flag is set to 0, and the DHCP server unicasts the reply packets to the client with the offered IP address.

The DHCP client can receive both broadcast and unicast offers from the DHCP server.

Examples The following example enables the broadcast flag:

```
hostname(config)# dhcp-client broadcast-flag
```

Related Commands	Command	Description
	ip address dhcp	Enables the DHCP client for an interface.
	interface	Enters interface configuration mode so you can set the IP address.

dhcp-client client-id	Sets DHCP request packet option 61 to include the interface MAC address.
dhcp-client update dns	Enables DNS updates for the DHCP client.

dhcp-client client-id

To force a MAC address to be stored inside a DHCP request packet for option 61 instead of the default internally-generated string, use the **dhcp-client client-id** command in global configuration mode. To disallow the MAC address, use the **no** form of this command.

dhcp-client client-id interface *interface_name*

no dhcp-client client-id interface *interface_name*

Syntax Description

interface <i>interface_name</i>	Specifies the interface on which you want to enable the MAC address for option 61.
---	--

Defaults

By default, an internally-generated ASCII string is used for option 61.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	—

Command History

Release	Modification
8.0(2)	This command was introduced.

Usage Guidelines

If you enable the DHCP client for an interface using the **ip address dhcp** command, some ISPs expect option 61 to be the interface MAC address. If the MAC address is not included in the DHCP request packet, then an IP address will not be assigned. Use the **dhcp-client client-id** command to include the interface MAC address for option 61.

Examples

The following example enables the MAC address for option 61 for the outside interface:

```
hostname(config)# dhcp-client client-id interface outside
```

Related Commands

Command	Description
ip address dhcp	Enables the DHCP client for an interface.
interface	Enters interface configuration mode so you can set the IP address.

dhcp-client broadcast-flag	Sets the broadcast flag in the DHCP client packet.
dhcp-client update dns	Enables DNS updates for the DHCP client.

dhcp-client update dns

To configure the update parameters that the DHCP client passes to the DHCP server, use the **dhcp-client update dns** command in global configuration mode. To remove the parameters that the DHCP client passes to the DHCP server, use the **no** form of this command.

dhcp-client update dns [server {both | none}]

no dhcp-client update dns [server {both | none}]

Syntax Description

both	The client requests that the DHCP server update both the DNS A and PTR resource records.
none	The client requests that the DHCP server perform no DDNS updates.
server	Specifies the DHCP server to receive the client requests.

Defaults

By default, the adaptive security appliance requests that the DHCP server perform PTR RR updates only. The client does not send the FQDN option to the server.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	—	•	•	—

Command History

Release	Modification
7.2(1)	This command was introduced.

Usage Guidelines

This command can also be entered in interface configuration mode, but it is not hyphenated. See **dhcp client update dns**. When entered in interface mode, the **dhcp client update dns** command overrides settings configured by this command in global configuration mode.

Examples

The following example configures the client to request that the DHCP server update neither the A and the PTR RRs:

```
hostname(config)# dhcp-client update dns server none
```

The following example configures the client to request that the server update both the A and PTR RRs:

```
hostname(config)# dhcp-client update dns server both
```

Related Commands

Command	Description
ddns (DDNS-update-method mode)	Specifies a DDNS update method type for a created DDNS method.
ddns update (interface config mode)	Associates a dynamic DNS (DDNS) update method with a adaptive security appliance interface or a DDNS update hostname.
ddns update method (global config mode)	Creates a method for dynamically updating DNS resource records.
dhcp client update dns	
dhcpd update dns	Enables a DHCP server to perform DDNS updates.
interval maximum	Configures the maximum interval between update attempts by a DDNS update method.

dhcp-network-scope

To specify the range of IP addresses the adaptive security appliance DHCP server should use to assign addresses to users of this group policy, use the **dhcp-network-scope** command in group-policy configuration mode. To remove the attribute from the running configuration, use the **no** form of this command. This option allows inheritance of a value from another group policy. To prevent inheriting a value, use the **dhcp-network-scope none** command.

dhcp-network-scope {*ip_address*} | none

no dhcp-network-scope

Syntax Description

<i>ip_address</i>	Specifies the IP subnetwork the DHCP server should use to assign IP addresses to users of this group policy.
none	Sets the DHCP subnetwork to a null value, thereby allowing no IP addresses. Prevents inheriting a value from a default or specified group policy.

Defaults

No default behavior or values.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Group-policy	•	—	•	—	—

Command History

Release	Modification
7.0(1)	This command was introduced.

Examples

The following example shows how to set an IP subnetwork of 10.10.85.1 for the group policy named First Group:

```
hostname(config)# group-policy FirstGroup attributes
hostname(config-group-policy)# dhcp-network-scope 10.10.85.1
```

dhcp-server

To configure support for DHCP servers that assign IP addresses to clients as a VPN tunnel is established, use the **dhcp-server** command in tunnel-group general-attributes configuration mode. To return this command to the default, use the **no** form of this command.

dhcp-server [*link-selection* | *subnet-selection*] *hostname1* [...*hostname10*]

no dhcp-server [*link-selection* | *subnet-selection*] *hostname*

Syntax Description

<i>hostname1</i> ... <i>hostname10</i>	Specifies the IP address of the DHCP server. You can specify up to 10 DHCP servers.
<i>link-selection</i>	(Optional) Supports DHCP suboption 5, link selection for the relay agent information option 82, defined in RFC 3527. Use this option only with DHCP servers that support this RFC standard.
<i>subnet-selection</i>	(Optional) Supports DHCP option 118, the IPv4 subnet selection option, defined in RFC 3011. Use this option only with DHCP servers that support this RFC standard.

Defaults

No default behavior or values.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Tunnel-group general attributes configuration	•	—	•	—	—

Command History

Release	Modification
7.0(1)	This command was introduced.
8.2(2)	Support for RFC 3011 and RFC 3527 was added.

Usage Guidelines

You can apply this attribute to remote access tunnel-group types only.

Examples

The following commands entered in configuration mode add three DHCP servers (dhcp1, dhcp2, and dhcp3) to the IPsec remote-access tunnel group, “remotegrp”:

```
hostname(config)# tunnel-group remotegrp type remote-access
hostname(config)# tunnel-group remotegrp general
hostname(config-tunnel-general)# default-group-policy remotegrp
hostname(config-tunnel-general)# dhcp-server dhcp1 dhcp2 dhcp3
```

Related Commands	Command	Description
	clear-configure tunnel-group	Clears all configured tunnel groups.
	show running-config tunnel group	Shows the tunnel group configuration for all tunnel groups or for a particular tunnel group.
	tunnel-group general-attributes	Specifies the general attributes for the named tunnel-group.

dhcpd address

To define the IP address pool used by the DHCP server, use the **dhcpd address** command in global configuration mode. To remove an existing DHCP address pool, use the **no** form of this command.

dhcpd address *IP_address1*[-*IP_address2*] *interface_name*

no dhcpd address *interface_name*

Syntax Description

<i>interface_name</i>	Interface the address pool is assigned to.
<i>IP_address1</i>	Start address of the DHCP address pool.
<i>IP_address2</i>	End address of the DHCP address pool.

Defaults

No default behavior or values.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	—

Command History

Release	Modification
Preexisting	This command was preexisting.

Usage Guidelines

The **dhcpd address** *ip1*[-*ip2*] *interface_name* command specifies the DHCP server address pool. The address pool of a adaptive security appliance DHCP server must be within the same subnet of the adaptive security appliance interface on which it is enabled, and you must specify the associated adaptive security appliance interface using *interface_name*.

The size of the address pool is limited to 256 addresses per pool on the adaptive security appliance. If the address pool range is larger than 253 addresses, the netmask of the adaptive security appliance interface cannot be a Class C address (for example, 255.255.255.0) and needs to be something larger, for example, 255.255.254.0.

DHCP clients must be physically connected to the subnet of the adaptive security appliance DHCP server interface.

The **dhcpd address** command cannot use interface names with a “-” (dash) character because the “-” character is interpreted as a range specifier instead of as part of the object name.

The **no dhcpd address** *interface_name* command removes the DHCP server address pool that you configured for the specified interface.

Refer to the *Cisco ASA 5500 Series Configuration Guide using the CLI* for information on how to implement the DHCP server feature into the adaptive security appliance.

Examples

The following example shows how to use the **dhcpd address**, **dhcpd dns**, and **dhcpd enable interface_name** commands to configure an address pool and DNS server for the DHCP clients on the **dmz** interface of the adaptive security appliance:

```
hostname(config)# dhcpd address 10.0.1.100-10.0.1.108 dmz
hostname(config)# dhcpd dns 209.165.200.226
hostname(config)# dhcpd enable dmz
```

The following example shows how to configure a DHCP server on the inside interface. It uses the **dhcpd address** command to assign a pool of 10 IP addresses to the DHCP server on that interface.

```
hostname(config)# dhcpd address 10.0.1.101-10.0.1.110 inside
hostname(config)# dhcpd dns 198.162.1.2 198.162.1.3
hostname(config)# dhcpd wins 198.162.1.4
hostname(config)# dhcpd lease 3000
hostname(config)# dhcpd ping_timeout 1000
hostname(config)# dhcpd domain example.com
hostname(config)# dhcpd enable inside
```

Related Commands

Command	Description
clear configure dhcpd	Removes all DHCP server settings.
dhcpd enable	Enables the DHCP server on the specified interface.
show dhcpd	Displays DHCP binding, statistic, or state information.
show running-config dhcpd	Displays the current DHCP server configuration.

dhcpcd auto_config

To enable the adaptive security appliance to automatically configure DNS, WINS and domain name values for the DHCP server based on the values obtained from an interface running a DHCP or PPPoE client, or from a vpn server, use the **dhcpcd auto_config** command in global configuration mode. To discontinue the automatic configuration of DHCP parameters, use the **no** form of this command.

dhcpcd auto_config *client_if_name* [[**vpnclient-wins-override**] **interface** *if_name*]

no dhcpcd auto_config *client_if_name* [[**vpnclient-wins-override**] **interface** *if_name*]

Syntax Description

<i>client_if_name</i>	Specifies the interface running the DHCP client that supplies the DNS, WINS, and domain name parameters.
interface <i>if_name</i>	Specifies the interface to which the action will apply.
vpnclient-wins-override	Overrides interface DHCP or PPPoE client WINS parameter with vpnclient parameter.

Defaults

No default behavior or values.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	—	•	•	—

Command History

Release	Modification
Preexisting	This command was preexisting.

Usage Guidelines

If you specify DNS, WINS, or domain name parameters using the CLI commands, then the CLI-configured parameters overwrite the parameters obtained by automatic configuration.

Examples

The following example shows how to configure DHCP on the inside interface. The **dhcpcd auto_config** command is used to pass DNS, WINS, and domain information obtained from the DHCP client on the outside interface to the DHCP clients on the inside interface.

```
hostname(config)# dhcpcd address 10.0.1.101-10.0.1.110 inside
hostname(config)# dhcpcd auto_config outside
hostname(config)# dhcpcd enable inside
```

Related Commands

Command	Description
clear configure dhcpd	Removes all DHCP server settings.
dhcpd enable	Enables the DHCP server on the specified interface.
show ip address dhcp server	Displays detailed information about the DHCP options provided by a DHCP server to an interface acting as a DHCP client.
show running-config dhcpd	Displays the current DHCP server configuration.

dhcpd dns

To define the DNS servers for DHCP clients, use the **dhcpd dns** command in global configuration mode. To clear defined servers, use the **no** form of this command.

dhcpd dns *dnsip1* [*dnsip2*] [**interface** *if_name*]

no dhcpd dns [*dnsip1* [*dnsip2*]] [**interface** *if_name*]

Syntax Description

<i>dnsip1</i>	IP address of the primary DNS server for the DHCP client.
<i>dnsip2</i>	(Optional) IP address of the alternate DNS server for the DHCP client.
interface <i>if_name</i>	Specifies the interface to which values entered to the server apply. If no interface is specified, values are applied to all servers.

Defaults

No default behavior or values.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	—

Command History

Release	Modification
Preexisting	This command was preexisting.

Usage Guidelines

The **dhcpd dns** command lets you specify the IP address or addresses of the DNS server(s) for the DHCP client. You can specify two DNS servers. The **no dhcpd dns** command lets you remove the DNS IP address(es) from the configuration.

Examples

The following example shows how to use the **dhcpd address**, **dhcpd dns**, and **dhcpd enable interface_name** commands to configure an address pool and DNS server for the DHCP clients on the **dmz** interface of the adaptive security appliance.

```
hostname(config)# dhcpd address 10.0.1.100-10.0.1.108 dmz
hostname(config)# dhcpd dns 192.168.1.2
hostname(config)# dhcpd enable dmz
```

Related Commands

Command	Description
clear configure dhcpd	Removes all DHCP server settings.
dhcpd address	Specifies the address pool used by the DHCP server on the specified interface.
dhcpd enable	Enables the DHCP server on the specified interface.
dhcpd wins	Defines the WINS servers for DHCP clients.
show running-config dhcpd	Displays the current DHCP server configuration.

dhcpd domain

To define the DNS domain name for DHCP clients, use the **dhcpd domain** command in global configuration mode. To clear the DNS domain name, use the **no** form of this command.

dhcpd domain *domain_name* [**interface** *if_name*]

no dhcpd domain [*domain_name*] [**interface** *if_name*]

Syntax Description

<i>domain_name</i>	The DNS domain name, for example example.com.
interface <i>if_name</i>	Specifies the interface to which values entered to the server apply. If no interface is specified, values are applied to all servers.

Defaults

No default behavior or values.

Command Modes

The following table shows the modes in which you can enter the command:

	Firewall Mode		Security Context		
				Multiple	
Command Mode	Routed	Transparent	Single	Context	System
Global configuration	•	•	•	•	—

Command History

Release	Modification
Preexisting	This command was preexisting.

Usage Guidelines

The **dhcpd domain** command lets you specify the DNS domain name for the DHCP client. The **no dhcpd domain** command lets you remove the DNS domain server from the configuration.

Examples

The following example shows how to use the **dhcpd domain** command to configure the domain name supplied to DHCP clients by the DHCP server on the adaptive security appliance:

```
hostname(config)# dhcpd address 10.0.1.101-10.0.1.110 inside
hostname(config)# dhcpd dns 198.162.1.2 198.162.1.3
hostname(config)# dhcpd wins 198.162.1.4
hostname(config)# dhcpd lease 3000
hostname(config)# dhcpd ping_timeout 1000
hostname(config)# dhcpd domain example.com
hostname(config)# dhcpd enable inside
```

Related Commands

Command	Description
clear configure dhcpd	Removes all DHCP server settings.
show running-config dhcpd	Displays the current DHCP server configuration.

dhcpd enable

To enable the DHCP server, use the **dhcpd enable** command in global configuration mode. To disable the DHCP server, use the **no** form of this command. The DHCP server provides network configuration parameters to DHCP clients. Support for the DHCP server within the adaptive security appliance means that the adaptive security appliance can use DHCP to configure connected clients.

dhcpd enable *interface*

no dhcpd enable *interface*

Syntax Description

interface Specifies the interface on which to enable the DHCP server.

Defaults

No default behavior or values.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	—

Command History

Release	Modification
Preexisting	This command was preexisting.

Usage Guidelines

The **dhcpd enable interface** command lets you enable the DHCP daemon to listen for the DHCP client requests on the DHCP-enabled interface. The **no dhcpd enable** command disables the DHCP server feature on the specified interface.



Note

For multiple context mode, you cannot enable the DHCP server on an interface that is used by more than one context (a shared VLAN).

When the adaptive security appliance responds to a DHCP client request, it uses the IP address and subnet mask of the interface where the request was received as the IP address and subnet mask of the default gateway in the response.



Note

The adaptive security appliance DHCP server daemon does not support clients that are not directly connected to a adaptive security appliance interface.

Refer to the *Cisco ASA 5500 Series Configuration Guide using the CLI* for information on how to implement the DHCP server feature into the adaptive security appliance.

Examples

The following example shows how to use the **dhcpd enable** command to enable the DHCP server on the inside interface:

```
hostname(config)# dhcpd address 10.0.1.101-10.0.1.110 inside
hostname(config)# dhcpd dns 198.162.1.2 198.162.1.3
hostname(config)# dhcpd wins 198.162.1.4
hostname(config)# dhcpd lease 3000
hostname(config)# dhcpd ping_timeout 1000
hostname(config)# dhcpd domain example.com
hostname(config)# dhcpd enable inside
```

Related Commands

Command	Description
debug dhcpd	Displays debug information for the DHCP server.
dhcpd address	Specifies the address pool used by the DHCP server on the specified interface.
show dhcpd	Displays DHCP binding, statistic, or state information.
show running-config dhcpd	Displays the current DHCP server configuration.

dhcpd lease

To specify the DHCP lease length, use the **dhcpd lease** command in global configuration mode. To restore the default value for the lease, use the **no** form of this command.

dhcpd lease *lease_length* [**interface** *if_name*]

no dhcpd lease [*lease_length*] [**interface** *if_name*]

Syntax Description

interface <i>if_name</i>	Specifies the interface to which values entered to the server apply. If no interface is specified, values are applied to all servers.
<i>lease_length</i>	Length of the IP address lease, in seconds, granted to the DHCP client from the DHCP server; valid values are from 300 to 1048575 seconds.

Defaults

The default *lease_length* is 3600 seconds.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	—

Command History

Release	Modification
Preexisting	This command was preexisting.

Usage Guidelines

The **dhcpd lease** command lets you specify the length of the lease, in seconds, that is granted to the DHCP client. This lease indicates how long the DHCP client can use the assigned IP address that the DHCP server granted.

The **no dhcpd lease** command lets you remove the lease length that you specified from the configuration and replaces this value with the default value of 3600 seconds.

Examples

The following example shows how to use the **dhcpd lease** command to specify the length of the lease of DHCP information for DHCP clients:

```
hostname(config)# dhcpd address 10.0.1.101-10.0.1.110 inside
hostname(config)# dhcpd dns 198.162.1.2 198.162.1.3
hostname(config)# dhcpd wins 198.162.1.4
hostname(config)# dhcpd lease 3000
hostname(config)# dhcpd ping_timeout 1000
hostname(config)# dhcpd domain example.com
hostname(config)# dhcpd enable inside
```

Related Commands

Command	Description
clear configure dhcpd	Removes all DHCP server settings.
show running-config dhcpd	Displays the current DHCP server configuration.

dhcpd option

To configure DHCP options, use the **dhcpd option** command in global configuration mode. To clear the option, use the **no** form of this command.

dhcpd option *code* {**ascii** *string*} | {**ip** *IP_address* [*IP_address*]} | {**hex** *hex_string*} [**interface** *if_name*]

no dhcpd option *code* [**interface** *if_name*]

Syntax Description

ascii	Specifies that the option parameter is an ASCII character string.
<i>code</i>	A number representing the DHCP option being set. Valid values are 0 to 255 with several exceptions. See the “ Usage Guidelines ” section, below, for the list of DHCP option codes that are not supported.
hex	Specifies that the option parameter is a hexadecimal string.
<i>hex_string</i>	Specifies a hexadecimal string with an even number of digits and no spaces. You do not need to use a 0x prefix.
interface <i>if_name</i>	Specifies the interface to which values entered to the server apply. If no interface is specified, values are applied to all servers.
ip	Specifies that the option parameter is an IP address. You can specify a maximum of two IP addresses with the ip keyword.
<i>IP_address</i>	Specifies a dotted-decimal IP address.
<i>string</i>	Specifies an ASCII character string without spaces.

Defaults

No default behavior or values.

Command Modes

The following table shows the modes in which you can enter the command:

	Firewall Mode		Security Context		
				Multiple	
Command Mode	Routed	Transparent	Single	Context	System
Global configuration	•	•	•	•	—

Command History

Release	Modification
Preexisting	This command was preexisting.

Usage Guidelines

You can use the **dhcpd option** command to provide TFTP server information to Cisco IP Phones and routers.

When a DHCP option request arrives at the adaptive security appliance DHCP server, the adaptive security appliance places the value or values that are specified by the **dhcpd option** command in the response to the client.

The **dhcpd option 66** and **dhcpd option 150** commands specify TFTP servers that Cisco IP Phones and routers can use to download configuration files. Use the commands as follows:

- **dhcpd option 66** *ascii string*, where *string* is either the IP address or hostname of the TFTP server. Only one TFTP server can be specified for option 66.
- **dhcpd option 150 ip** *IP_address [IP_address]*, where *IP_address* is the IP address of the TFTP server. You can specify a maximum of two IP addresses for option 150.

**Note**

The **dhcpd option 66** command only takes an **ascii** parameter, and the **dhcpd option 150** only takes an **ip** parameter.

Use the following guidelines when specifying an IP address for the **dhcpd option 66 | 150** commands:

- If the TFTP server is located on the DHCP server interface, use the local IP address of the TFTP server.
- If the TFTP server is located on a less secure interface than the DHCP server interface, then general outbound rules apply. Create a group of NAT, global, and **access-list** entries for the DHCP clients, and use the actual IP address of the TFTP server.
- If the TFTP server is located on a more secure interface, then general inbound rules apply. Create a group of static and **access-list** statements for the TFTP server and use the global IP address of the TFTP server.

For information about other DHCP options, refer to RFC2132.

**Note**

The security appliance does not verify that the option type and value that you provide match the expected type and value for the option code as defined in RFC 2132. For example, you can enter **dhcpd option 46 ascii hello**, and the security appliance accepts the configuration although option 46 is defined in RFC 2132 as expecting a single-digit, hexadecimal value.

You cannot configure the following DHCP options with the **dhcpd option** command:

Option Code	Description
0	DHCPOPT_PAD
1	HCPOPT_SUBNET_MASK
12	DHCPOPT_HOST_NAME
50	DHCPOPT_REQUESTED_ADDRESS
51	DHCPOPT_LEASE_TIME
52	DHCPOPT_OPTION_OVERLOAD
53	DHCPOPT_MESSAGE_TYPE
54	DHCPOPT_SERVER_IDENTIFIER
58	DHCPOPT_RENEWAL_TIME
59	DHCPOPT_REBINDING_TIME
61	DHCPOPT_CLIENT_IDENTIFIER
67	DHCPOPT_BOOT_FILE_NAME

Option Code	Description
82	DHCPOPT_RELAY_INFORMATION
255	DHCPOPT_END

Examples

The following example shows how to specify a TFTP server for DHCP option 66:

```
hostname(config)# dhcpd option 66 ascii MyTftpServer
```

Related Commands

Command	Description
clear configure dhcpd	Removes all DHCP server settings.
show running-config dhcpd	Displays the current DHCP server configuration.

dhcpd ping_timeout

To change the default timeout for DHCP ping, use the **dhcpd ping_timeout** command in global configuration mode. To return to the default value, use the **no** form of this command. To avoid address conflicts, the DHCP server sends two ICMP ping packets to an address before assigning that address to a DHCP client. This command specifies the ping timeout in milliseconds.

```

dhcpd ping_timeout number [interface if_name]

no dhcpd ping_timeout [interface if_name]
    
```

Syntax Description

interface <i>if_name</i>	Specifies the interface to which values entered to the server apply. If no interface is specified, values are applied to all servers.
<i>number</i>	The timeout value of the ping, in milliseconds. The minimum value is 10, the maximum is 10000. The default is 50.

Defaults

The default number of milliseconds for *number* is 50.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	—

Command History

Release	Modification
Preexisting	This command was preexisting.

Usage Guidelines

The adaptive security appliance waits for both ICMP ping packets to time out before assigning an IP address to a DHCP client. For example, if the default value is used, the adaptive security appliance waits for 1500 milliseconds (750 milliseconds for each ICMP ping packet) before assigning an IP address. A long ping timeout value can adversely affect the performance of the DHCP server.

Examples

The following example shows how to use the **dhcpd ping_timeout** command to change the ping timeout value for the DHCP server:

```

hostname(config)# dhcpd address 10.0.1.101-10.0.1.110 inside
hostname(config)# dhcpd dns 198.162.1.2 198.162.1.3
hostname(config)# dhcpd wins 198.162.1.4
hostname(config)# dhcpd lease 3000
hostname(config)# dhcpd ping_timeout 1000
hostname(config)# dhcpd domain example.com
hostname(config)# dhcpd enable inside
    
```

Related Commands

Command	Description
clear configure dhcpd	Removes all DHCP server settings.
show running-config dhcpd	Displays the current DHCP server configuration.

dhcpd update dns

To enable a DHCP server to perform Dynamic DNS updates, use the **dhcpd update dns** command in global configuration mode. To disable DDNS by a DHCP server, use the **no** form of this command.

```

dhcpd update dns [both] [override] [interface srv_ifc_name]

no dhcpd update dns [both] [override] [interface srv_ifc_name]
    
```

Syntax Description

both	Specifies that the DHCP server updates both A and PTR DNS RRs.
interface	Specifies the adaptive security appliance interface to which the DDNS updates apply.
override	Specifies that the DHCP server overrides DHCP client requests.
<i>srv_ifc_name</i>	Specifies an interface to apply this option to.

Defaults

By default, the DHCP server performs PTR RR updates only.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	—	•	•	—

Command History

Release	Modification
7.2(1)	This command was introduced.

Usage Guidelines

DDNS updates the name to address and address to name mappings maintained by DNS. Updates are performed in conjunction with a DHCP server. The **dhcpd update dns** command enables updates by the server.

Name and address mappings are contained in two types of RRs:

- The A resource record contains domain name to IP address mappings.
- The PTR resource record contains IP address to domain name mappings.

DDNS updates can be used to maintain consistent information between the A and PTR RR types.

Using the **dhcpd update dns** command, the DHCP server can be configured to perform both A and PRT RR updates or PTR RR updates only. It can also be configured to override update requests from the DHCP client.

Examples

The following example configures the DDNS server to perform both A and PTR updates while also overriding requests from the DHCP client:

```
hostname(config)# dhcpcd update dns both override
```

Related Commands

Command	Description
ddns (DDNS-update-method mode)	Specifies a DDNS update method type for a created DDNS method.
ddns update (interface config mode)	Associates a DDNS update method with a adaptive security appliance interface or a DDNS update hostname.
ddns update method (global config mode)	Creates a method for dynamically updating DNS resource records.
dhcp-client update dns	Configures the update parameters that the DHCP client passes to the DHCP server.
interval maximum	Configures the maximum interval between update attempts by a DDNS update method.

dhcpd wins

To define the WINS servers for DHCP clients, use the **dhcpd wins** command in global configuration mode. To remove the WINS servers from the DHCP server, use the **no** form of this command.

dhcpd wins *server1* [*server2*] [**interface** *if_name*]

no dhcpd wins [*server1* [*server2*]] [**interface** *if_name*]

Syntax Description

interface <i>if_name</i>	Specifies the interface to which values entered to the server apply. If no interface is specified, values are applied to all servers.
<i>server1</i>	Specifies the IP address of the primary Microsoft NetBIOS name server (WINS server).
<i>server2</i>	(Optional) Specifies the IP address of the alternate Microsoft NetBIOS name server (WINS server).

Defaults

No default behavior or values.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	—

Command History

Release	Modification
Preexisting	This command was preexisting.

Usage Guidelines

The **dhcpd wins** command lets you specify the addresses of the WINS servers for the DHCP client. The **no dhcpd wins** command removes the WINS server IP addresses from the configuration.

Examples

The following example shows how to use the dhcpd wins command to specify WINS server information that is sent to DHCP clients:

```
hostname(config)# dhcpd address 10.0.1.101-10.0.1.110 inside
hostname(config)# dhcpd dns 198.162.1.2 198.162.1.3
hostname(config)# dhcpd wins 198.162.1.4
hostname(config)# dhcpd lease 3000
hostname(config)# dhcpd ping_timeout 1000
hostname(config)# dhcpd domain example.com
hostname(config)# dhcpd enable inside
```

Related Commands

Command	Description
clear configure dhcpd	Removes all DHCP server settings.
dhcpd address	Specifies the address pool used by the DHCP server on the specified interface.
dhcpd dns	Defines the DNS servers for DHCP clients.
show dhcpd	Displays DHCP binding, statistic, or state information.
show running-config dhcpd	Displays the current DHCP server configuration.

dhcprelay enable

To enable the DHCP relay agent, use the **dhcprelay enable** command in global configuration mode. To disable DHCP relay agent, use the **no** form of this command. The DHCP relay agent allows DHCP requests to be forwarded from a specified adaptive security appliance interface to a specified DHCP server.

```
dhcprelay enable interface_name

no dhcprelay enable interface_name
```

Syntax Description	interface_name	Name of the interface on which the DHCP relay agent accepts client requests.
--------------------	----------------	--

Defaults	The DHCP relay agent is disabled.
----------	-----------------------------------

Command Modes	The following table shows the modes in which you can enter the command:
---------------	---

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	—	•	•	—

Release	Modification
Preexisting	This command was preexisting.

Usage Guidelines

For the adaptive security appliance to start the DHCP relay agent with the **dhcprelay enable interface_name** command, you must have a **dhcprelay server** command already in the configuration. Otherwise, the adaptive security appliance displays an error message similar to the following:

```
DHCPRA: Warning - There are no DHCP servers configured!
No relaying can be done without a server!
Use the 'dhcprelay server <server_ip> <server_interface>' command
```

- You cannot enable DHCP relay under the following conditions:
- You cannot enable DHCP relay and the DHCP relay server on the same interface.
 - You cannot enable DCHP relay and a DHCP server (**dhcprd enable**) on the same interface.
 - You cannot enable DHCP relay in a context at the same time as the DHCP server.
 - For multiple context mode, you cannot enable DHCP relay on an interface that is used by more than one context (a shared VLAN).
- The **no dhcprelay enable interface_name** command removes the DHCP relay agent configuration for the interface that is specified by *interface_name* only.

Examples

The following example shows how to configure the DHCP relay agent for a DHCP server with an IP address of 10.1.1.1 on the outside interface of the adaptive security appliance, client requests on the inside interface of the adaptive security appliance, and a timeout value up to 90 seconds:

```
hostname(config)# dhcprelay server 10.1.1.1 outside
hostname(config)# dhcprelay timeout 90
hostname(config)# dhcprelay enable inside
hostname(config)# show running-config dhcprelay
dhcprelay server 10.1.1.1 outside
dhcprelay enable inside
dhcprelay timeout 90
```

The following example shows how to disable the DHCP relay agent:

```
hostname(config)# no dhcprelay enable inside
hostname(config)# show running-config dhcprelay
dhcprelay server 10.1.1.1 outside
dhcprelay timeout 90
```

Related Commands

Command	Description
clear configure dhcprelay	Removes all DHCP relay agent settings.
debug dhcp relay	Displays debug information for the DHCP relay agent.
dhcprelay server	Specifies the DHCP server that the DHCP relay agent forwards DHCP requests to.
dhcprelay setroute	Defines IP address that the DHCP relay agent uses as the default router address in DHCP replies.
show running-config dhcprelay	Displays the current DHCP relay agent configuration.

dhcprelay server

To specify the DHCP server that DHCP requests are forwarded to, use the **dhcprelay server** command in global configuration mode. To remove the DHCP server from the DHCP relay configuration, use the **no** form of this command. The DHCP relay agent allows DHCP requests to be forwarded from a specified adaptive security appliance interface to a specified DHCP server.

```
dhcprelay server IP_address interface_name

no dhcprelay server IP_address [interface_name]
```

Syntax Description

<i>interface_name</i>	Name of the adaptive security appliance interface on which the DHCP server resides.
<i>IP_address</i>	The IP address of the DHCP server to which the DHCP relay agent forwards client DHCP requests.

Defaults

No default behavior or values.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	—	•	•	—

Command History

Release	Modification
Preexisting	This command was preexisting.

Usage Guidelines

You can add up to four DHCP relay servers per interface; however, there is a limit of ten DHCP relay servers total that can be configured on the adaptive security appliance. You must add at least one **dhcprelay server** command to the adaptive security appliance configuration before you can enter the **dhcprelay enable** command. You cannot configure a DHCP client on an interface that has a DHCP relay server configured.

The **dhcprelay server** command opens UDP port 67 on the specified interface and starts the DHCP relay task as soon as the **dhcprelay enable** command is added to the configuration.

When you use the **no dhcprelay server IP_address [interface_name]** command, the interface stops forwarding DHCP packets to that server.

The **no dhcprelay server IP_address [interface_name]** command removes the DHCP relay agent configuration for the DHCP server that is specified by *IP_address [interface_name]* only.

Examples

The following example shows how to configure the DHCP relay agent for a DHCP server with an IP address of 10.1.1.1 on the outside interface of the adaptive security appliance, client requests on the inside interface of the adaptive security appliance, and a timeout value up to 90 seconds:

```
hostname(config)# dhcprelay server 10.1.1.1 outside
hostname(config)# dhcprelay timeout 90
hostname(config)# dhcprelay enable inside
hostname(config)# show running-config dhcprelay
dhcprelay server 10.1.1.1 outside
dhcprelay enable inside
dhcprelay timeout 90
```

Related Commands

Command	Description
clear configure dhcprelay	Removes all DHCP relay agent settings.
dhcprelay enable	Enables the DHCP relay agent on the specified interface.
dhcprelay setroute	Defines IP address that the DHCP relay agent uses as the default router address in DHCP replies.
dhcprelay timeout	Specifies the timeout value for the DHCP relay agent.
show running-config dhcprelay	Displays the current DHCP relay agent configuration.

dhcprelay setroute

To set the default gateway address in the DHCP reply, use the **dhcprelay setroute** command in global configuration mode. To remove the default router, use the **no** form of this command. This command causes the default IP address of the DHCP reply to be substituted with the address of the specified adaptive security appliance interface.

```
dhcprelay setroute interface
no dhcprelay setroute interface
```

Syntax Description	interface	Configures the DHCP relay agent to change the first default IP address (in the packet sent from the DHCP server) to the address of <i>interface</i> .
--------------------	-----------	---

Defaults	No default behavior or values.
----------	--------------------------------

Command Modes	The following table shows the modes in which you can enter the command:
---------------	---

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	—	•	•	—

Command History	Release	Modification
	Preexisting	This command was preexisting.

The **dhcprelay setroute interface** command lets you enable the DHCP relay agent to change the first default router address (in the packet sent from the DHCP server) to the address of *interface*.

If there is no default router option in the packet, the adaptive security appliance adds one containing the address of *interface*. This action allows the client to set its default route to point to the adaptive security appliance.

When you do not configure the **dhcprelay setroute interface** command (and there is a default router option in the packet), it passes through the adaptive security appliance with the router address unaltered.

Examples

The following example shows how to use the **dhcprelay setroute** command to set the default gateway in the DHCP reply from the external DHCP server to the inside interface of the adaptive security appliance:

```
hostname(config)# dhcprelay server 10.1.1.1 outside
hostname(config)# dhcprelay timeout 90
hostname(config)# dhcprelay setroute inside
hostname(config)# dhcprelay enable inside
```


Related Commands	Command	Description
	clear configure dhcprelay	Removes all DHCP relay agent settings.
	dhcprelay enable	Enables the DHCP relay agent on the specified interface.
	dhcprelay server	Specifies the DHCP server that the DHCP relay agent forwards DHCP requests to.
	dhcprelay timeout	Specifies the timeout value for the DHCP relay agent.
	show running-config dhcprelay	Displays the current DHCP relay agent configuration.

dhcprelay timeout

To set the DHCP relay agent timeout value, use the **dhcprelay timeout** command in global configuration mode. To restore the timeout value to its default value, use the **no** form of this command.

```

dhcprelay timeout seconds

no dhcprelay timeout
    
```

Syntax Description

<i>seconds</i>	Specifies the number of seconds that are allowed for DHCP relay address negotiation.
----------------	--

Defaults

The default value for the dhcprelay timeout is 60 seconds.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	—	•	•	—

Command History

Release	Modification
Preexisting	This command was preexisting.

Usage Guidelines

The **dhcprelay timeout** command lets you set the amount of time, in seconds, allowed for responses from the DHCP server to pass to the DHCP client through the relay binding structure.

Examples

```

The following example shows how to configure the DHCP relay agent for a DHCP server with an IP address of 10.1.1.1 on the outside interface of the adaptive security appliance, client requests on the inside interface of the adaptive security appliance, and a timeout value up to 90 seconds:

hostname(config)# dhcprelay server 10.1.1.1 outside
hostname(config)# dhcprelay timeout 90
hostname(config)# dhcprelay enable inside
hostname(config)# show running-config dhcprelay
dhcprelay server 10.1.1.1 outside
dhcprelay enable inside
dhcprelay timeout 90
    
```

Related Commands

Command	Description
clear configure dhcprelay	Removes all DHCP relay agent settings.
dhcprelay enable	Enables the DHCP relay agent on the specified interface.
dhcprelay server	Specifies the DHCP server that the DHCP relay agent forwards DHCP requests to.
dhcprelay setroute	Defines IP address that the DHCP relay agent uses as the default router address in DHCP replies.
show running-config dhcprelay	Displays the current DHCP relay agent configuration.

dialog

To customize dialog messages displayed to WebVPN users, use the **dialog** command in webvpn customization configuration mode. To remove the command from the configuration and cause the value to be inherited, use the **no** form of this command.

```

dialog { title | message | border } style value
no dialog { title | message | border } style value
    
```

Syntax Description

border	Specifies you are changing the border.
message	Specifies you are changing the message.
style	Specifies you are changing the style.
title	Specifies you are changing the title.
<i>value</i>	The actual text to display (maximum 256 characters), or CSS parameters (maximum 256 characters).

Defaults

The default title style is background-color:#669999;color:white.
 The default message style is background-color:#99CCCC;color:black.
 The default border style is border:1px solid black;border-collapse:collapse.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Webvpn customization configuration	•	—	•	—	—

Command History

Release	Modification
7.1(1)	This command was introduced.

Usage Guidelines

The **style** option is expressed as any valid CSS parameters. Describing these parameters is beyond the scope of this document. For more information about CSS parameters, consult CSS specifications at the World Wide Web Consortium website at www.w3.org. Appendix F of the CSS 2.1 Specification contains a convenient list of CSS parameters, and is available at www.w3.org/TR/CSS21/propidx.html.

Here are some tips for making the most common changes to the WebVPN pages—the page colors:

- You can use a comma-separated RGB value, an HTML color value, or the name of the color if recognized in HTML.
- RGB format is 0,0,0, a range of decimal numbers from 0 to 255 for each color (red, green, blue); the comma separated entry indicates the level of intensity of each color to combine with the others.

- HTML format is #000000, six digits in hexadecimal format; the first and second represent red, the third and fourth green, and the fifth and sixth represent blue.

**Note**

To easily customize the WebVPN pages, we recommend that you use ASDM, which has convenient features for configuring style elements, including color swatches and preview capabilities.

Examples

The following example customizes the dialog message, changing the foreground color to blue:

```
F1-asal(config)# webvpn
F1-asal(config-webvpn)# customization cisco
F1-asal(config-webvpn-custom)# dialog message style color:blue
```

Related Commands

Command	Description
application-access	Customizes the Application Access box of the WebVPN Home page.
browse-networks	Customizes the Browse Networks box of the WebVPN Home page.
web-bookmarks	Customizes the Web Bookmarks title or links on the WebVPN Home page.
file-bookmarks	Customizes the File Bookmarks title or links on the WebVPN Home page.

dir

To display the directory contents, use the **dir** command in privileged EXEC mode.

dir [/all] [all-file systems] [/recursive] [flash: | system:] [path]

Syntax Description

/all	(Optional) Displays all files.
/recursive	(Optional) Displays the directory contents recursively.
all-file systems	(Optional) Displays the files of all file systems.
disk0:	(Optional) Specifies the internal Flash memory, followed by a colon.
disk1:	(Optional) Specifies the external Flash memory card, followed by a colon.
flash:	(Optional) Displays the directory contents of the default flash partition.
path	(Optional) Specifies a specific path.
system:	(Optional) Displays the directory contents of the file system.

Defaults

If you do not specify a directory, the directory is the current working directory by default.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Privileged EXEC	•	•	•	—	•

Command History

Release	Modification
7.0(1)	This command was introduced.

Usage Guidelines

The **dir** command without keywords or arguments displays the directory contents of the current directory.

Examples

The following example shows how to display the directory contents:

```
hostname# dir
Directory of disk0:/

1      -rw-  1519      10:03:50 Jul 14 2003    my_context.cfg
2      -rw-  1516      10:04:02 Jul 14 2003    my_context.cfg
3      -rw-  1516      10:01:34 Jul 14 2003    admin.cfg
60985344 bytes total (60973056 bytes free)
```

The following example shows how to display recursively the contents of the entire file system:

```
hostname# dir /recursive disk0:
Directory of disk0:/*
 1      -rw-   1519          10:03:50 Jul 14 2003    my_context.cfg
 2      -rw-   1516          10:04:02 Jul 14 2003    my_context.cfg
 3      -rw-   1516          10:01:34 Jul 14 2003    admin.cfg
60985344 bytes total (60973056 bytes free)
```

Related Commands

Command	Description
cd	Changes the current working directory to the one specified.
pwd	Displays the current working directory.
mkdir	Creates a directory.
rmdir	Removes a directory.

disable

To exit privileged EXEC mode and return to unprivileged EXEC mode, use the **disable** command in privileged EXEC mode.

disable

Syntax Description

This command has no arguments or keywords.

Defaults

No default behaviors or values.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Privileged EXEC	•	•	•	•	•

Command History

Release	Modification
Preexisting	This command was preexisting.

Usage Guidelines

Use the **enable** command to enter privileged mode. The **disable** command allows you to exit privileged mode and returns you to an unprivileged mode.

Examples

The following example shows how to enter privileged mode:

```
hostname> enable
hostname#
```

The following example shows how to exit privileged mode:

```
hostname# disable
hostname>
```

Related Commands

Command	Description
enable	Enables privileged EXEC mode.

disable (cache)

To disable caching for WebVPN, use the **disable** command in cache configuration mode. To reenabling caching, use the **no** version of this command.

disable

no disable

Defaults

Caching is enabled with default settings for each cache attribute.

Command Modes

The following table shows the modes in which you enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Cache configuration	•	—	•	—	—

Command History

Release	Modification
7.1(1)	This command was introduced.

Usage Guidelines

Caching stores frequently reused objects in the system cache, which reduces the need to perform repeated rewriting and compressing of content. It reduces traffic between WebVPN and both the remote servers and end-user browsers, with the result that many applications run much more efficiently.


Examples

The following example shows how to disable caching, and how to then reenabling it.

```
hostname(config)# webvpn
hostname(config-webvpn)# cache
hostname(config-webvpn-cache)# disable
hostname(config-webvpn-cache)# no disable
hostname(config-webvpn-cache)#
```

Related Commands

Command	Description
cache	Enters WebVPN Cache mode.
cache-compressed	Configures WebVPN cache compression.
expiry-time	Configures the expiration time for caching objects without revalidating them.
lmfactor	Sets a revalidation policy for caching objects that have only the last-modified timestamp.

 **disable (cache)**

Command	Description
max-object-size	Defines the maximum size of an object to cache.
min-object-size	Defines the minimum size of an object to cache.

disable service-settings

To disable the service settings on IP phones when using the Phone Proxy feature, use the **disable service-settings** command in phone-proxy configuration mode. To preserve the settings on the IP phones, use the **no** form of this command.

disable service-settings

no disable service-settings

Syntax Description

There are no arguments or keywords for this command.

Defaults

The service settings are disabled by default.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Phone-proxy configuration	•	—	•	—	—

Command History

Release	Modification
8.0(4)	This command was introduced.

Usage Guidelines

By default, the following settings are disabled on the IP phones:


- PC Port
- Gratuitous ARP
- Voice VLAN access
- Web Access
- Span to PC Port

To preserve the settings configured on the CUCM for each IP phone configured, configure the **no disable service-settings** command.

Examples

The following example shows the use of the **disable service-settings** command to preserve the settings of the IP phones that use the Phone Proxy feature on the ASA:

```
hostname(config-phone-proxy)# no disable service-settings
```

 disable service-settings**Related Commands**

Command	Description
phone-proxy	Configures the Phone Proxy instance.
show phone-proxy	Displays Phone Proxy specific information.

display

To display attribute value pairs that the adaptive security appliance writes to the DAP attribute database, enter the **display** command in dap test attributes mode.

display

Command Default

No default value or behaviors.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
dap test attributes	•	•	•	—	—

Command History

Release	Modification
8.0(2)	This command was introduced.

Usage Guidelines

Normally the adaptive security appliance retrieves user authorization attributes from the AAA server and retrieves endpoint attributes from Cisco Secure Desktop, Host Scan, CNA or NAC. For the test command, you specify the user authorization and endpoint attributes in this attributes mode. The adaptive security appliance writes them to an attribute database that the DAP subsystem references when evaluating the AAA selection attributes and endpoint select attributes for a DAP record. The **display** command lets you display these attributes to the console.

Related Commands

Command	Description
attributes	Enters attributes mode, in which you can set attribute value pairs.
dynamic-access-policy-record	Creates a DAP record.
test dynamic-access-policy attributes	Enters attributes submode.
test dynamic-access-policy execute	Executes the logic that generates the DAP and displays the resulting access policies to the console.

distance eigrp

To configure the administrative distances of internal and external EIGRP routes, use the **distance eigrp** command in router configuration mode. To restore the default values, use the **no** form of this command.

```
distance eigrp internal-distance external-distance

no distance eigrp
```

Syntax Description

<i>external-distance</i>	Administrative distance for EIGRP external routes. External routes are those for which the best path is learned from a neighbor external to the autonomous system. Valid values are from 1 to 255.
<i>internal-distance</i>	Administrative distance for EIGRP internal routes. Internal routes are those that are learned from another entity within the same autonomous system. Valid values are from 1 to 255.

Defaults

- The default values are as follows:
- external-distance* is 170
 - internal-distance* is 90

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Router configuration	•	—	•	—	—

Command History

Release	Modification
8.0(2)	This command was introduced.

Usage Guidelines

Because every routing protocol has metrics based on algorithms that are different from the other routing protocols, it is not always possible to determine the “best path” for two routes to the same destination that were generated by different routing protocols. Administrative distance is a route parameter that the adaptive security appliance uses to select the best path when there are two or more different routes to the same destination from two different routing protocols.

If you have more than one routing protocol running on the adaptive security appliance, you can use the **distance eigrp** command to adjust the default administrative distances of routes discovered by the EIGRP routing protocol in relation to the other routing protocols. [Table 10-1](#) lists the default administrative distances for the routing protocols supported by the adaptive security appliance.

Table 10-1 **Default Administrative Distances**

Route Source	Default Administrative Distance
Connected interface	0
Static route	1
EIGRP summary route	5
Internal EIGRP	90
OSPF	110
RIP	120
EIGRP external route	170
Unknown	255

The **no** form of the command does not take any keywords or arguments. Using the **no** form of the command restores the default administrative distance for both internal and external EIGRP routes.

Examples

The following example uses the **distance eigrp** command set the administrative distance of all EIGRP internal routes to 80 and all EIGRP external routes to 115. Setting the EIGRP external route administrative distance to 115 would give routes discovered by EIGRP to a specific destination preference over the same routes discovered by RIP but not by OSPF.

```
hostname(config)# router eigrp 100
hostname(config-router)# network 192.168.7.0
hostname(config-router)# network 172.16.0.0
hostname(config-router)# distance eigrp 90 115
```

Related Commands

Command	Description
router eigrp	Creates an EIGRP routing process and enters configuration mode for that process.

distance ospf

To define OSPF route administrative distances based on route type, use the **distance ospf** command in router configuration mode. To restore the default values, use the **no** form of this command.

distance ospf [*intra-area d1*] [*inter-area d2*] [*external d3*]

no distance ospf

Syntax Description

<i>d1</i> , <i>d2</i> , and <i>d3</i>	Distance for each route types. Valid values range from 1 to 255.
external	(Optional) Sets the distance for routes from other routing domains that are learned by redistribution.
inter-area	(Optional) Sets the distance for all routes from one area to another area.
intra-area	(Optional) Sets the distance for all routes within an area.

Defaults

The default values for *d1*, *d2*, and *d3* are 110.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Router configuration	•	—	•	—	—

Command History

Release	Modification
Preexisting	This command was preexisting.

Usage Guidelines

You must specify at least one keyword and argument. You can enter the commands for each type of administrative distance separately, however they appear as a single command in the configuration. If you reenter an administrative distance, the administrative distance for only that route type changes; the administrative distances for any other route types remain unaffected.

The **no** form of the command does not take any keywords or arguments. Using the **no** form of the command restores the default administrative distance for all of the route types. If you want to restore the default administrative distance for a single route type when you have multiple route types configured, you can do one of the following:

- Manually set that route type to the default value.
- Use the **no** form of the command to remove the entire configuration and then re-enter the configurations for the route types you want to keep.

Examples

The following example sets the administrative distance of external routes to 150:

```
hostname(config-router)# distance ospf external 105
hostname(config-router)#
```

The following example shows how entering separate commands for each route type appears as a single command in the router configuration:

```
hostname(config-router)# distance ospf intra-area 105 inter-area 105
hostname(config-router)# distance ospf intra-area 105
hostname(config-router)# distance ospf external 105
hostname(config-router)# exit
hostname(config)# show running-config router ospf 1
!
router ospf 1
  distance ospf intra-area 105 inter-area 105 external 105
!
hostname(config)#
```

The following example shows how to set each administrative distance to 105, and then change only the external administrative distance to 150. The **show running-config router ospf** command shows how only the external route type value changed, while the other route types retained the value previously set.

```
hostname(config-router)# distance ospf external 105 intra-area 105 inter-area 105
hostname(config-router)# distance ospf external 150
hostname(config-router)# exit
hostname(config)# show running-config router ospf 1
!
router ospf 1
  distance ospf intra-area 105 inter-area 105 external 150
!
hostname(config)#
```

Related Commands

Command	Description
router ospf	Enters router configuration mode.
show running-config router	Displays the commands in the global router configuration.

distribute-list in

To filter the networks received in routing updates, use the **distribute-list in** command in router configuration mode. To remove the filtering, use the **no** form of this command.

distribute-list *acl* **in** [**interface** *if_name*]

no distribute-list *acl* **in** [**interface** *if_name*]

Syntax Description

<i>acl</i>	Name of a standard access list.
<i>if_name</i>	(Optional) The interface name as specified by the nameif command. Specifying an interface causes the access list to be applied only to routing updates received on that interface.

Defaults

Networks are not filtered in incoming updates.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Router configuration	•	—	•	—	—

Command History

Release	Modification
7.2(1)	This command was introduced.

Usage Guidelines

If no interface is specified, the access list will be applied to all incoming updates.

Examples

The following example filters RIP routing updates received on the outside interface. It accepts routes in the 10.0.0.0 network and discards all others.

```
hostname(config)# access-list ripfilter permit 10.0.0.0
hostname(config)# access-list ripfilter deny any
hostname(config)# router rip
hostname(config-router)# network 10.0.0.0
hostname(config-router)# distribute-list ripfilter in interface outside
```

The following example filters EIGRP routing updates received on the outside interface. It accepts routes in the 10.0.0.0 network and discards all others.

```
hostname(config)# access-list eigrp_filter permit 10.0.0.0
hostname(config)# access-list eigrp_filter deny any
hostname(config)# router eigrp 100
hostname(config-router)# network 10.0.0.0
```

```
hostname(config-router)# distribute-list eigrp_filter in interface outside
```

Related Commands

Command	Description
distribute-list out	Filters networks from being advertised in routing updates.
router eigrp	Enters router configuration mode for the EIGRP routing process.
router rip	Enters router configuration mode for the RIP routing process.
show running-config router	Displays the commands in the global router configuration.

distribute-list out

To filter specific networks from being sent in routing updates, use the **distribute-list out** command in router configuration mode. To remove the filtering, use the **no** form of this command.

```
distribute-list acl out [interface if_name | eigrp as_number | rip | ospf pid | static | connected]

no distribute-list acl out [interface if_name | eigrp as_number | rip | ospf pid | static | connected]
```

Syntax Description

<i>acl</i>	Name of a standard access list.
connected	(Optional) Filters only connected routes.
eigrp <i>as_number</i>	(Optional) Filters only EIGRP routes from the specified autonomous system number. The <i>as_number</i> is the autonomous system number of the EIGRP routing process on the adaptive security appliance.
interface <i>if_name</i>	(Optional) The interface name as specified by the nameif command. Specifying an interface causes the access list to be applied only to routing updates sent on the specified interface.
ospf <i>pid</i>	(Optional) Filters only OSPF routes discovered by the specified OSPF process.
rip	(Optional) Filters only RIP routes.
static	(Optional) Filters only static routes

Defaults

Networks are not filtered in sent updates.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Router configuration	•	—	•	—	—

Command History

Release	Modification
7.2(1)	This command was introduced.
8.0(2)	The eigrp keyword was added.

Usage Guidelines

If no interface is specified, the access list will be applied to all outgoing updates.

Examples

The following example prevents the 10.0.0.0 network from being advertised in RIP updates sent out of any interface:

```
hostname(config)# access-list ripfilter deny 10.0.0.0
hostname(config)# access-list ripfilter permit any
```

```
hostname(config)# router rip
hostname(config-router)# network 10.0.0.0
hostname(config-router)# distribute-list ripfilter out
```

The following example prevents the EIGRP routing process from advertising the 10.0.0.0 network on the outside interface:

```
hostname(config)# access-list eigrp_filter deny 10.0.0.0
hostname(config)# access-list eigrp_filter permit any
hostname(config)# router eigrp 100
hostname(config-router)# network 10.0.0.0
hostname(config-router)# distribute-list eigrp_filter out interface outside
```

Related Commands

Command	Description
distribute-list in	Filters networks received in routing updates.
router eigrp	Enters router configuration mode for the EIGRP routing process.
router rip	Enters router configuration mode for the RIP routing process.
show running-config router	Displays the commands in the global router configuration.

dns domain-lookup

To enable the adaptive security appliance to send DNS requests to a DNS server to perform a name lookup for supported commands, use the **dns domain-lookup** command in global configuration mode. To disable DNS lookup, use the **no** form of this command.

dns domain-lookup *interface_name*

no dns domain-lookup *interface_name*

Syntax Description

<i>interface_name</i>	Specifies the interface on which you want to enable DNS lookup. If you enter this command multiple times to enable DNS lookup on multiple interfaces, the adaptive security appliance tries each interface in order until it receives a response.
-----------------------	---

Defaults

DNS lookup is disabled by default.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	—

Command History

Release	Modification
7.0(1)	This command was introduced.

Usage Guidelines

Use the **dns name-server** command to configure the DNS server addresses to which you want to send DNS requests. See the **dns name-server** command for a list of commands that support DNS lookup.

The adaptive security appliance maintains a cache of name resolutions that consists of dynamically learned entries. Instead of making queries to external DNS servers each time an hostname-to-IP-address translation is needed, the adaptive security appliance caches information returned from external DNS requests. The adaptive security appliance only makes requests for names that are not in the cache. The cache entries time out automatically according to the DNS record expiration, or after 72 hours, whichever comes first.

Examples

The following example enables DNS lookup on the inside interface:

```
hostname(config)# dns domain-lookup inside
```

Related Commands

Command	Description
dns name-server	Configures a DNS server address.
dns retries	Specifies the number of times to retry the list of DNS servers when the adaptive security appliance does not receive a response.
dns timeout	Specifies the amount of time to wait before trying the next DNS server.
domain-name	Sets the default domain name.
show dns-hosts	Shows the DNS cache.

dns-group (tunnel-group webvpn configuration mode)

To specify the DNS server to use for a WebVPN tunnel-group, use the **dns-group** command in tunnel-group webvpn configuration mode. To restore the default DNS group, use the **no** form of this command.

dns-group *name*

no dns-group

Syntax Description	<i>name</i>	Specifies the name of the DNS server group configuration to use for the tunnel group.
--------------------	-------------	---

Defaults	The default value is DefaultDNS.
----------	----------------------------------

Command Modes	The following table shows the modes in which you can enter the command:
---------------	---

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Tunnel-group webvpn-attributes configuration	•	—	•	—	—

Command History	Release	Modification
	7.1(1)	This command was introduced.

Usage Guidelines	<p>The name can specify any DNS group. The dns-group command resolves the hostname to the appropriate DNS server for the tunnel group.</p> <p>You configure the DNS group using the dns server-group command.</p>
------------------	--

Examples	<p>The following example shows a customization command that specifies the use of the DNS group named “dnsgroup1”:</p> <pre>hostname(config)# tunnel-group test type webvpn hostname(config)# tunnel-group test webvpn-attributes hostname(config-tunnel-webvpn)# dns-group dnsgroup1 hostname(config-tunnel-webvpn)#</pre>
----------	--

Related Commands	Command	Description
	clear configure dns	Removes all DNS commands.
	dns server-group	Enters DNS-server-group mode, in which you can configure a DNS server group.
	show running-config dns-server group	Shows one or all the existing DNS server-group configurations.
	tunnel-group webvpn-attributes	Enters the config-webvpn mode for configuring WebVPN tunnel-group attributes.

dns-guard

To enable the DNS guard function, which enforces one DNS response per query, use the **dns-guard** command in parameters configuration mode. To disable this feature, use the **no** form of this command.

dns-guard

no dns-guard

Syntax Description

This command has no arguments or keywords.

Defaults

DNS guard is enabled by default. This feature can be enabled when **inspect dns** is configured even if a **policy-map type inspect dns** is not defined. To disable, **no dns-guard** must explicitly be stated in the policy map configuration. If **inspect dns** is not configured, the behavior is determined by the **global dns-guard** command.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Parameters configuration	•	•	•	•	—

Command History

Release	Modification
7.2(1)	This command was introduced.

Usage Guidelines

The identification field in the DNS header is used to match the DNS response with the DNS header. One response per query is allowed through the security appliance.

Examples

The following example shows how to enable DNS guard in a DNS inspection policy map:

```
hostname(config)# policy-map type inspect dns preset_dns_map
hostname(config-pmap)# parameters
hostname(config-pmap-p)# dns-guard
```

Related Commands

Command	Description
class	Identifies a class map name in the policy map.
class-map type inspect	Creates an inspection class map to match traffic specific to an application.

Command	Description
policy-map	Creates a Layer 3/4 policy map.
show running-config policy-map	Display all current policy map configurations.

dns-server

To set the IP address of the primary and secondary DNS servers, use the **dns-server** command in group-policy configuration mode. To remove the attribute from the running configuration, use the **no** form of this command.

dns-server { **value** *ip_address* [*ip_address*] | **none** }

no dns-server

Syntax Description

none	Sets dns-servers to a null value, thereby allowing no DNS servers. Prevents inheriting a value from a default or specified group policy.
value <i>ip_address</i>	Specifies the IP address of the primary and secondary DNS servers.

Defaults

No default behavior or values.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Group-policy configuration	•	—	•	—	—

Command History

Release	Modification
7.0(1)	This command was introduced.

Usage Guidelines

This option allows inheritance of a DNS server from another group policy. To prevent inheriting a server, use the **dns-server none** command.

Every time you issue the **dns-server** command you overwrite the existing setting. For example, if you configure DNS server x.x.x.x and then configure DNS server y.y.y.y, the second command overwrites the first, and y.y.y.y becomes the sole DNS server. The same holds true for multiple servers. To add a DNS server rather than overwrite previously configured servers, include the IP addresses of all DNS servers when you enter this command.

Examples

The following example shows how to configure DNS servers with the IP addresses 10.10.10.15, 10.10.10.30, and 10.10.10.45 for the group policy named FirstGroup.

```
hostname(config)# group-policy FirstGroup attributes
hostname(config-group-policy)# dns-server value 10.10.10.15 10.10.10.30 10.10.10.45
```

dns server-group

To enter the dns server-group mode, in which you can specify the domain-name, name-server, number of retries, and timeout values for a DNS server to use for a tunnel-group, use the **dns server-group** command in global configuration mode. To remove a particular DNS server group, use the **no** form of this command.

dns server -group *name*

no dns server-group

Syntax Description

<i>name</i>	Specifies the name of the DNS server group configuration to use for the tunnel group.
-------------	---

Defaults

The default value is DefaultDNS.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	—	•	—	—

Command History

Release	Modification
7.0(1)	This command was introduced.

Usage Guidelines

The name can specify any DNS group. You configure the DNS group using the **dns server-group** command.

Examples

The following example configures a DNS server group named “eval”:

```
hostname(config)# dns server-group eval
hostname(config-dns-server-group)# domain-name cisco.com
hostname(config-dns-server-group)# name-server 192.168.10.10
hostname(config-dns-server-group)# retries 5
hostname(config-dns-server-group)# timeout 7
hostname(config-dns-server-group)#
```

Related Commands	Command	Description
	clear configure dns	Removes all DNS commands.
	show running-config dns server-group	Shows the current running DNS server-group configuration.

domain-name

To set the default domain name, use the **domain-name** command in global configuration mode. To remove the domain name, use the **no** form of this command. The adaptive security appliance appends the domain name as a suffix to unqualified names. For example, if you set the domain name to “example.com,” and specify a syslog server by the unqualified name of “jupiter,” then the security appliance qualifies the name to “jupiter.example.com.”

domain-name *name*

no domain-name [*name*]

Syntax Description

<i>name</i>	Sets the domain name, up to 63 characters.
-------------	--

Defaults

The default domain name is default.domain.invalid.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	•

Command History

Release	Modification
Preexisting	This command was preexisting.

Usage Guidelines

For multiple context mode, you can set the domain name for each context, as well as within the system execution space.

Examples

The following example sets the domain as example.com:

```
hostname(config)# domain-name example.com
```

Related Commands

Command	Description
dns domain-lookup	Enables the adaptive security appliance to perform a name lookup.
dns name-server	Configures a DNS server address.

■ domain-name

Command	Description
hostname	Sets the adaptive security appliance hostname.
show running-config domain-name	Shows the domain name configuration.

domain-name (dns server-group)

To set the default domain name, use the **domain-name** command in dns server-group configuration mode. To remove the domain name, use the **no** form of this command. The adaptive security appliance appends the domain name as a suffix to unqualified names. For example, if you set the domain name to “example.com,” and specify a syslog server by the unqualified name of “jupiter,” then the security appliance qualifies the name to “jupiter.example.com.”

domain-name *name*

no domain-name [*name*]

Syntax Description

<i>name</i>	Sets the domain name, up to 63 characters.
-------------	--

Defaults

The default domain name is default.domain.invalid.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
dns server-group configuration	•	•	•	•	•

Command History

Release	Modification
7.1(1)	This command replaces the dns domain-lookup command, which is deprecated.

Usage Guidelines

For multiple context mode, you can set the domain name for each context, as well as within the system execution space.

Examples

The following example sets the domain as “example.com” for “dnsgroup1”:

```
hostname(config)# dns server-group dnsgroup1
hostname(config-dns-server-group)# domain-name example.com
hostname(config-dns-server-group)#
```

Related Commands

Command	Description
clear configure dns	Removes all DNS commands.
dns server-group	Enters DNS-server-group mode, in which you can configure a DNS server group.

Command	Description
domain-name	Sets the default domain name globally.
show running-config dns-server group	Shows one or all the current DNS server-group configurations.

download-max-size

To specify the maximum size allowed for an object to download, use the **download-max-size** command in group-policy webvpn configuration mode. To remove this object from the configuration, use the **no** version of this command.

download-max-size <size>

no download-max-size

Syntax Description

size Specifies the maximum size allowed for a downloaded object. The range is 0 through 2147483647.

Defaults

The default size is 2147483647.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Group-policy webvpn configuration mode	•	—	•	—	—

Command History

Release	Modification
8.0(2)	This command was introduced.

Usage Guidelines

Setting the size to 0 effectively disallows object downloading.

Examples

The following example sets the maximum size for a downloaded object to 1500 bytes:

```
hostname(config)# group-policy test attributes
hostname(config-group-policy)# webvpn
hostname(config-group-webvpn)# download-max-size 1500
```

Related Commands

Command	Description
post-max-size	Specifies the maximum size of an object to post.
upload-max-size	Specifies the maximum size of an object to upload.

Command	Description
webvpn	Use in group-policy configuration mode or in username configuration mode. Lets you enter webvpn mode to configure parameters that apply to group policies or usernames.
webvpn	Use in global configuration mode. Lets you configure global settings for WebVPN.

drop

To drop all packets that match the **match** command or **class** command, use the drop command in match or class configuration mode. To disable this action, use the **no** form of this command.

drop [send-protocol-error] [log]

no drop [send-protocol-error] [log]

Syntax Description

send-protocol-error	Sends a protocol error message.
log	Logs the match. The system log message number depends on the application.

Defaults

No default behaviors or values.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Match and class configuration	•	•	•	•	—

Command History

Release	Modification
7.2(1)	This command was introduced.

Usage Guidelines

When using the Modular Policy Framework, drop packets that match a **match** command or class map by using the **drop** command in match or class configuration mode. This drop action is available in an inspection policy map (the **policy-map type inspect** command) for application traffic; however, not all applications allow this action.

An inspection policy map consists of one or more **match** and **class** commands. The exact commands available for an inspection policy map depends on the application. After you enter the **match** or **class** command to identify application traffic (the **class** command refers to an existing **class-map type inspect** command that in turn includes **match** commands), you can enter the **drop** command to drop all packets that match the **match** command or **class** command.

If you drop a packet, then no further actions are performed in the inspection policy map. For example, if the first action is to drop the packet, then it will never match any further **match** or **class** commands. If the first action is to log the packet, then a second action, such as dropping the packet, can occur. You can configure both the **drop** and the **log** action for the same **match** or **class** command, in which case the packet is logged before it is dropped for a given match.

When you enable application inspection using the **inspect** command in a Layer 3/4 policy map (the **policy-map** command), you can enable the inspection policy map that contains this action, for example, enter the **inspect http http_policy_map** command where http_policy_map is the name of the inspection policy map.

Examples

The following example drops packets and sends a log when they match the http-traffic class map. If the same packet also matches the second **match** command, it will not be processed because it was already dropped.

```
hostname(config-cmap)# policy-map type inspect http http-map1
hostname(config-pmap)# class http-traffic
hostname(config-pmap-c)# drop log
hostname(config-pmap-c)# match req-resp content-type mismatch
hostname(config-pmap-c)# reset log
```

Related Commands

Commands	Description
class	Identifies a class map name in the policy map.
class-map type inspect	Creates an inspection class map to match traffic specific to an application.
policy-map	Creates a Layer 3/4 policy map.
policy-map type inspect	Defines special actions for application inspection.
show running-config policy-map	Display all current policy map configurations.

drop-connection

When using the Modular Policy Framework, drop packets and close the connection for traffic that matches a **match** command or class map by using the **drop-connection** command in match or class configuration mode. The connection will be removed from the connection database on the adaptive security appliance. Any subsequent packets entering the adaptive security appliance for the dropped connection will be discarded. This drop-connection action is available in an inspection policy map (the **policy-map type inspect** command) for application traffic; however, not all applications allow this action. To disable this action, use the **no** form of this command.

drop-connection [**send-protocol-error**] [**log**]

no drop-connection [**send-protocol-error**] [**log**]

Syntax Description

send-protocol-error	Sends a protocol error message.
log	Logs the match. The system log message number depends on the application.

Defaults

No default behaviors or values.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Match and class configuration	•	•	•	•	—

Command History

Release	Modification
7.2(1)	This command was introduced.

Usage Guidelines

An inspection policy map consists of one or more **match** and **class** commands. The exact commands available for an inspection policy map depends on the application. After you enter the **match** or **class** command to identify application traffic (the **class** command refers to an existing **class-map type inspect** command that in turn includes **match** commands), you can enter the **drop-connection** command to drop packets and close the connection for traffic that matches the **match** command or **class** command.

If you drop a packet or close a connection, then no further actions are performed in the inspection policy map. For example, if the first action is to drop the packet and close the connection, then it will never match any further **match** or **class** commands. If the first action is to log the packet, then a second action, such as dropping the packet, can occur. You can configure both the **drop-connection** and the **log** action for the same **match** or **class** command, in which case the packet is logged before it is dropped for a given match.

When you enable application inspection using the **inspect** command in a Layer 3/4 policy map (the **policy-map** command), you can enable the inspection policy map that contains this action, for example, enter the **inspect http http_policy_map** command where http_policy_map is the name of the inspection policy map.

Examples

The following example drops packets, closes the connection, and sends a log when they match the http-traffic class map. If the same packet also matches the second **match** command, it will not be processed because it was already dropped.

```
hostname(config-cmap)# policy-map type inspect http http-map1
hostname(config-pmap)# class http-traffic
hostname(config-pmap-c)# drop-connection log
hostname(config-pmap-c)# match req-resp content-type mismatch
hostname(config-pmap-c)# reset log
```

Related Commands

Commands	Description
class	Identifies a class map name in the policy map.
class-map type inspect	Creates an inspection class map to match traffic specific to an application.
policy-map	Creates a Layer 3/4 policy map.
policy-map type inspect	Defines special actions for application inspection.
show running-config policy-map	Display all current policy map configurations.

dtls port

To specify a port for DTLS connections, use the **dtls port** command from webvpn configuration mode. To remove the command from the configuration, use the **no** form of this command:

dtls port *number*

no dtls port *number*

Syntax Description

number The UDP port number, from 1 to 65535.

Defaults

The default port number is 443.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Webvpn configuration	•	—	•	—	—

Command History

Release	Modification
8.0(2)	This command was introduced.

Usage Guidelines

This command specifies the UDP port to be used for SSL VPN connections using DTLS.

DTLS avoids latency and bandwidth problems associated with some SSL connections and improves the performance of real-time applications that are sensitive to packet delays.

Examples

The following example enters webvpn configuration mode and specifies port 444 for DTLS:

```
hostname(config)# webvpn
hostname(config-webvpn)# dtls port 444
```

Related Commands

Command	Description
dtls enable	Enables DTLS on an interface.
svc dtls	Enables DTLS for groups or users establishing SSL VPN connections.
vpn-tunnel-protocol	Specifies VPN protocols that the adaptive security appliance allows for remote access, including SSL.

duplex

To set the duplex of a copper (RJ-45) Ethernet interface, use the **duplex** command in interface configuration mode. To restore the duplex setting to the default, use the **no** form of this command.

```
duplex { auto | full | half }

no duplex
```

Syntax Description

auto	Auto-detects the duplex mode.
full	Sets the duplex mode to full duplex.
half	Sets the duplex mode to half duplex.

Defaults

The default is auto detect.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Interface configuration	•	•	•	—	•

Command History

Release	Modification
7.0(1)	This command was moved from a keyword of the interface command to an interface configuration mode command.

Usage Guidelines

Set the duplex mode on the physical interface only.

The **duplex** command is not available for fiber media.

If your network does not support auto detection, set the duplex mode to a specific value.

For RJ-45 interfaces on the ASA 5500 series adaptive security appliance, the default auto-negotiation setting also includes the Auto-MDI/MDIX feature. Auto-MDI/MDIX eliminates the need for crossover cabling by performing an internal crossover when a straight cable is detected during the auto-negotiation phase. Either the speed or duplex must be set to auto-negotiate to enable Auto-MDI/MDIX for the interface. If you explicitly set both the speed and duplex to a fixed value, thus disabling auto-negotiation for both settings, then Auto-MDI/MDIX is also disabled.

If you set the duplex to anything other than **auto** on PoE ports, if available, then Cisco IP phones and Cisco wireless access points that do not support IEEE 802.3af will not be detected and supplied with power.

Examples

The following example sets the duplex mode to full duplex:

```
hostname(config)# interface gigabitethernet0/1
hostname(config-if)# speed 1000
hostname(config-if)# duplex full
hostname(config-if)# nameif inside
hostname(config-if)# security-level 100
hostname(config-if)# ip address 10.1.1.1 255.255.255.0
hostname(config-if)# no shutdown
```

Related Commands

Command	Description
clear configure interface	Clears all configuration for an interface.
interface	Configures an interface and enters interface configuration mode.
show interface	Displays the runtime status and statistics of interfaces.
show running-config interface	Shows the interface configuration.
speed	Sets the interface speed.

dynamic-access-policy-config

To configure a DAP record and the access policy attributes associated with it, use the **dynamic-access-policy-config** command in global configuration mode. To remove an existing DAP configuration, use the **no** form of this command.

To activate a DAP selection configuration file, use the **dynamic-access-policy-config** command with the activate argument.

```
dynamic-access-policy-config name | activate

no dynamic-access-policy-config
```

name	Specifies the name of the DAP record. The name can be up to 64 characters long and cannot contain spaces.
activate	Activates the DAP selection configuration file

Defaults

No default behavior or values.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Name - Global configuration	•	•	•	—	—
Activeate - Privileged EXEC					

Release	Modification
8.0(2)	This command was introduced.

Usage Guidelines

Use the dynamic-access-policy-config command in global configuration mode to create one or more DAP records. When you use this command you enter dynamic-access-policy-record mode, in which you can set attributes for the named DAP record. The commands you can use in dynamic-access-policy-record mode include the following:

- action
- description
- network-acl
- priority
- user-message
- webvpn

Examples

The following example shows how to configure the DAP record named user1.

```
hostname(config)# dynamic-access-policy-config user1  
hostname(config-dynamic-access-policy-record)#
```

Related Commands

Command	Description
dynamic-access-policy-record	Populates the DAP record with access policy attributes.
show running-config dynamic-access-policy-record <i>[name]</i>	Displays the running configuration for all DAP records, or for the named DAP record.

dynamic-access-policy-record

To create a DAP record and populate it with access policy attributes, use the **dynamic-access-policy-record** command in global configuration mode. To remove an existing DAP record, use the **no** form of this command.

- dynamic-access-policy-record** *name*
- no dynamic-access-policy-record** *name*

Syntax Description	<i>name</i>	Specifies the name of the DAP record. The name can be up to 64 characters long and cannot contain spaces.
--------------------	-------------	---

Defaults	No default behavior or values.
----------	--------------------------------

Command Modes	The following table shows the modes in which you can enter the command:
---------------	---

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	—	—

Command History	Release	Modification
	8.0(2)	This command was introduced.

Usage Guidelines

Use the dynamic-access-policy-record command in global configuration mode to create one or more DAP records. When you use this command you enter dynamic-access-policy-record mode, in which you can set attributes for the named DAP record. The commands you can use in dynamic-access-policy-record mode include the following:

- action
- description
- network-acl
- priority
- user-message
- webvpn

Examples

The following example shows how to create a DAP record named Finance.

```
hostname(config)# dynamic-access-policy-record Finance
hostname(config-dynamic-access-policy-record)#
```

Related Commands	Command	Description
	clear config	Removes all DAP records or the named DAP record.
	dynamic-access-policy-record <i>[name]</i>	
	dynamic-access-policy-config url	Configures the DAP Selection Configuration file.
	show running-config dynamic-access-policy-record <i>[name]</i>	Displays the running configuration for all DAP records, or for the named DAP record.

dynamic-filter ambiguous-is-black

To treat Botnet Traffic Filter greylisted traffic as blacklisted traffic for dropping purposes, use the **dynamic-filter ambiguous-is-black** command in global configuration mode. To allow greylisted traffic, use the **no** form of this command.

```
dynamic-filter ambiguous-is-black

no dynamic-filter ambiguous-is-black
```

Syntax Description This command has no arguments or keywords.

Defaults This command is disabled by default.

Command Modes The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	—

Release	Modification
8.2(2)	This command was introduced.

Usage Guidelines If you configured the **dynamic-filter enable** command and then the **dynamic-filter drop blacklist** command, this command treats greylisted traffic as blacklisted traffic for dropping purposes. If you do not enable this command, greylisted traffic will not be dropped.

Ambiguous addresses are associated with multiple domain names, but not all of these domain names are on the blacklist. These addresses are on the *greylist*.

Examples The following example monitors all port 80 traffic on the outside interface, and then drops blacklisted and greylisted traffic at a threat level of moderate or greater:

```
hostname(config)# access-list dynamic-filter_acl extended permit tcp any any eq 80
hostname(config)# dynamic-filter enable interface outside classify-list dynamic-filter_acl
hostname(config)# dynamic-filter drop blacklist interface outside
hostname(config)# dynamic-filter ambiguous-is-black
```


Related Commands

Command	Description
address	Adds an IP address to the blacklist or whitelist.
clear configure dynamic-filter	Clears the running Botnet Traffic Filter configuration.
clear dynamic-filter dns-snoop	Clears Botnet Traffic Filter DNS snooping data.
clear dynamic-filter reports	Clears Botnet Traffic filter report data.
clear dynamic-filter statistics	Clears Botnet Traffic filter statistics.
dns domain-lookup	Enables the adaptive security appliance to send DNS requests to a DNS server to perform a name lookup for supported commands.
dns server-group	Identifies a DNS server for the adaptive security appliance.
dynamic-filter blacklist	Edits the Botnet Traffic Filter blacklist.
dynamic-filter database fetch	Manually retrieves the Botnet Traffic Filter dynamic database.
dynamic-filter database find	Searches the dynamic database for a domain name or IP address.
dynamic-filter database purge	Manually deletes the Botnet Traffic Filter dynamic database.
dynamic-filter drop blacklist	Automatically drops blacklisted traffic.
dynamic-filter enable	Enables the Botnet Traffic Filter for a class of traffic or for all traffic if you do not specify an access list.
dynamic-filter updater-client enable	Enables downloading of the dynamic database.
dynamic-filter use-database	Enables use of the dynamic database.
dynamic-filter whitelist	Edits the Botnet Traffic Filter whitelist.
inspect dns dynamic-filter-snoop	Enables DNS inspection with Botnet Traffic Filter snooping.
name	Adds a name to the blacklist or whitelist.
show asp table dynamic-filter	Shows the Botnet Traffic Filter rules that are installed in the accelerated security path.
show dynamic-filter data	Shows information about the dynamic database, including when the dynamic database was last downloaded, the version of the database, how many entries the database contains, and 10 sample entries.
show dynamic-filter dns-snoop	Shows the Botnet Traffic Filter DNS snooping summary, or with the detail keyword, the actual IP addresses and names.
show dynamic-filter reports	Generates reports of the top 10 botnet sites, ports, and infected hosts.
show dynamic-filter statistics	Shows how many connections were monitored with the Botnet Traffic Filter, and how many of those connections match the whitelist, blacklist, and greylist.
show dynamic-filter updater-client	Shows information about the updater server, including the server IP address, the next time the adaptive security appliance will connect with the server, and the database version last installed.
show running-config dynamic-filter	Shows the Botnet Traffic Filter running configuration.

dynamic-filter blacklist

To edit the Botnet Traffic Filter blacklist, use the **dynamic-filter blacklist** command in global configuration mode. To remove the blacklist, use the **no** form of this command. The static database lets you augment the dynamic database with domain names or IP addresses that you want to blacklist.

dynamic-filter blacklist

no dynamic-filter blacklist

Syntax Description

This command has no arguments or keywords.

Defaults

No default behavior or values.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	—

Command History

Release	Modification
8.2(1)	This command was introduced.

Usage Guidelines

After you enter the dynamic-filter blacklist configuration mode, you can manually enter domain names or IP addresses (host or subnet) that you want to tag as bad names in a blacklist using the **address** and **name** commands. You can also enter names or IP addresses in a whitelist (see the **dynamic-filter whitelist** command), so that names or addresses that appear on both the dynamic blacklist and whitelist are identified only as whitelist addresses in syslog messages and reports. Note that you see syslog messages for whitelisted addresses even if the address is not also in the dynamic blacklist.

Static blacklist entries are always designated with a Very High threat level.

When you add a domain name to the static database, the adaptive security appliance waits 1 minute, and then sends a DNS request for that domain name and adds the domain name/IP address pairing to the *DNS host cache*. (This action is a background process, and does not affect your ability to continue configuring the adaptive security appliance). We recommend also enabling DNS packet inspection with Botnet Traffic Filter snooping (see the **inspect dns dynamic-filter-snooping** command). The adaptive security appliance uses Botnet Traffic Filter snooping instead of the regular DNS lookup to resolve static blacklist domain names in the following circumstances:

- The adaptive security appliance DNS server is unavailable.
- A connection is initiated during the 1 minute waiting period before the adaptive security appliance sends the regular DNS request.

If DNS snooping is used, when an infected host sends a DNS request for a name on the static database, the adaptive security appliance looks inside the DNS packets for the domain name and associated IP address and adds the name and IP address to the DNS reverse lookup cache.

If you do not enable Botnet Traffic Filter snooping, and one of the above circumstances occurs, then that traffic will not be monitored by the Botnet Traffic Filter.

**Note**

This command requires adaptive security appliance use of a DNS server; see the **dns domain-lookup** and **dns server-group** commands.

Examples

The following example creates entries for the blacklist and whitelist:

```
hostname(config)# dynamic-filter blacklist
hostname(config-l1ist)# name bad1.example.com
hostname(config-l1ist)# name bad2.example.com
hostname(config-l1ist)# address 10.1.1.1 255.255.255.0

hostname(config-l1ist)# dynamic-filter whitelist
hostname(config-l1ist)# name good.example.com
hostname(config-l1ist)# name great.example.com
hostname(config-l1ist)# name awesome.example.com
hostname(config-l1ist)# address 10.1.1.2 255.255.255.255
```

Related Commands

Command	Description
address	Adds an IP address to the blacklist or whitelist.
clear configure dynamic-filter	Clears the running Botnet Traffic Filter configuration.
clear dynamic-filter dns-snoop	Clears Botnet Traffic Filter DNS snooping data.
clear dynamic-filter reports	Clears Botnet Traffic filter report data.
clear dynamic-filter statistics	Clears Botnet Traffic filter statistics.
dns domain-lookup	Enables the adaptive security appliance to send DNS requests to a DNS server to perform a name lookup for supported commands.
dns server-group	Identifies a DNS server for the adaptive security appliance.
dynamic-filter ambiguous-is-black	Treats greylisted traffic as blacklisted traffic for action purposes.
dynamic-filter database fetch	Manually retrieves the Botnet Traffic Filter dynamic database.
dynamic-filter database find	Searches the dynamic database for a domain name or IP address.
dynamic-filter database purge	Manually deletes the Botnet Traffic Filter dynamic database.
dynamic-filter drop blacklist	Automatically drops blacklisted traffic.
dynamic-filter enable	Enables the Botnet Traffic Filter for a class of traffic or for all traffic if you do not specify an access list.
dynamic-filter updater-client enable	Enables downloading of the dynamic database.
dynamic-filter use-database	Enables use of the dynamic database.
dynamic-filter whitelist	Edits the Botnet Traffic Filter whitelist.
inspect dns	Enables DNS inspection with Botnet Traffic Filter snooping.
dynamic-filter-snoop	

Command	Description
name	Adds a name to the blacklist or whitelist.
show asp table dynamic-filter	Shows the Botnet Traffic Filter rules that are installed in the accelerated security path.
show dynamic-filter data	Shows information about the dynamic database, including when the dynamic database was last downloaded, the version of the database, how many entries the database contains, and 10 sample entries.
show dynamic-filter dns-snoop	Shows the Botnet Traffic Filter DNS snooping summary, or with the detail keyword, the actual IP addresses and names.
show dynamic-filter reports	Generates reports of the top 10 botnet sites, ports, and infected hosts.
show dynamic-filter statistics	Shows how many connections were monitored with the Botnet Traffic Filter, and how many of those connections match the whitelist, blacklist, and greylist.
show dynamic-filter updater-client	Shows information about the updater server, including the server IP address, the next time the adaptive security appliance will connect with the server, and the database version last installed.
show running-config dynamic-filter	Shows the Botnet Traffic Filter running configuration.

dynamic-filter database fetch

To test the download of the dynamic database for the Botnet Traffic Filter, use the **dynamic-filter database fetch** command in privileged EXEC mode.

dynamic-filter database fetch

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values.

Command Modes The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Privileged EXEC	•	•	•	•	•

Release	Modification
8.2(1)	This command was introduced.

Usage Guidelines The actual database is not stored on the adaptive security appliance;it is downloaded and then discarded. Use this command for testing purposes only.

Examples The following example tests the download of the dynamic database:

```
hostname# dynamic-filter database fetch
```

Related Commands	Command	Description
	address	Adds an IP address to the blacklist or whitelist.
	clear configure dynamic-filter	Clears the running Botnet Traffic Filter configuration.
	clear dynamic-filter dns-snoop	Clears Botnet Traffic Filter DNS snooping data.
	clear dynamic-filter reports	Clears Botnet Traffic filter report data.
	clear dynamic-filter statistics	Clears Botnet Traffic filter statistics.
	dns domain-lookup	Enables the adaptive security appliance to send DNS requests to a DNS server to perform a name lookup for supported commands.
	dns server-group	Identifies a DNS server for the adaptive security appliance.

Command	Description
dynamic-filter ambiguous-is-black	Treats greylisted traffic as blacklisted traffic for action purposes.
dynamic-filter blacklist	Edits the Botnet Traffic Filter blacklist.
dynamic-filter database find	Searches the dynamic database for a domain name or IP address.
dynamic-filter database purge	Manually deletes the Botnet Traffic Filter dynamic database.
dynamic-filter drop blacklist	Automatically drops blacklisted traffic.
dynamic-filter enable	Enables the Botnet Traffic Filter for a class of traffic or for all traffic if you do not specify an access list.
dynamic-filter updater-client enable	Enables downloading of the dynamic database.
dynamic-filter use-database	Enables use of the dynamic database.
dynamic-filter whitelist	Edits the Botnet Traffic Filter whitelist.
inspect dns dynamic-filter-snoop	Enables DNS inspection with Botnet Traffic Filter snooping.
name	Adds a name to the blacklist or whitelist.
show asp table dynamic-filter	Shows the Botnet Traffic Filter rules that are installed in the accelerated security path.
show dynamic-filter data	Shows information about the dynamic database, including when the dynamic database was last downloaded, the version of the database, how many entries the database contains, and 10 sample entries.
show dynamic-filter dns-snoop	Shows the Botnet Traffic Filter DNS snooping summary, or with the detail keyword, the actual IP addresses and names.
show dynamic-filter reports	Generates reports of the top 10 botnet sites, ports, and infected hosts.
show dynamic-filter statistics	Shows how many connections were monitored with the Botnet Traffic Filter, and how many of those connections match the whitelist, blacklist, and greylist.
show dynamic-filter updater-client	Shows information about the updater server, including the server IP address, the next time the adaptive security appliance will connect with the server, and the database version last installed.
show running-config dynamic-filter	Shows the Botnet Traffic Filter running configuration.

dynamic-filter database find

To check if a domain name or IP address is included in the dynamic database for the Botnet Traffic Filter, use the **dynamic-filter database find** command in privileged EXEC mode.

dynamic-filter database find *string*

Syntax Description

string The *string* can be the complete domain name or IP address, or you can enter part of the name or address, with a minimum search string of 3 characters. Regular expressions are not supported for the database search.

Defaults

No default behavior or values.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Privileged EXEC	•	•	•	•	•

Command History

Release	Modification
8.2(1)	This command was introduced.

Usage Guidelines

If there are multiple matches, the first two matches are shown. To refine your search for a more specific match, enter a longer string.

Examples

The following example searches on the string “example.com”, and finds 1 match:

```
hostname# dynamic-filter database find bad.example.com

bad.example.com
Found 1 matches
```

The following example searches on the string “bad”, and finds more than 2 matches:

```
hostname# dynamic-filter database find bad

bad.example.com
bad.example.net
Found more than 2 matches, enter a more specific string to find an exact
match
```

Related Commands

Command	Description
dynamic-filter ambiguous-is-black	Treats greylisted traffic as blacklisted traffic for action purposes.
dynamic-filter drop blacklist address	Automatically drops blacklisted traffic.
dynamic-filter drop blacklist address	Adds an IP address to the blacklist or whitelist.
clear configure dynamic-filter	Clears the running Botnet Traffic Filter configuration.
clear dynamic-filter dns-snoop	Clears Botnet Traffic Filter DNS snooping data.
clear dynamic-filter reports	Clears Botnet Traffic filter report data.
clear dynamic-filter statistics	Clears Botnet Traffic filter statistics.
dns domain-lookup	Enables the adaptive security appliance to send DNS requests to a DNS server to perform a name lookup for supported commands.
dns server-group	Identifies a DNS server for the adaptive security appliance.
dynamic-filter blacklist	Edits the Botnet Traffic Filter blacklist.
dynamic-filter database fetch	Manually retrieves the Botnet Traffic Filter dynamic database.
dynamic-filter database purge	Manually deletes the Botnet Traffic Filter dynamic database.
dynamic-filter enable	Enables the Botnet Traffic Filter for a class of traffic or for all traffic if you do not specify an access list.
dynamic-filter updater-client enable	Enables downloading of the dynamic database.
dynamic-filter use-database	Enables use of the dynamic database.
dynamic-filter whitelist	Edits the Botnet Traffic Filter whitelist.
inspect dns dynamic-filter-snoop	Enables DNS inspection with Botnet Traffic Filter snooping.
name	Adds a name to the blacklist or whitelist.
show asp table dynamic-filter	Shows the Botnet Traffic Filter rules that are installed in the accelerated security path.
show dynamic-filter data	Shows information about the dynamic database, including when the dynamic database was last downloaded, the version of the database, how many entries the database contains, and 10 sample entries.
show dynamic-filter dns-snoop	Shows the Botnet Traffic Filter DNS snooping summary, or with the detail keyword, the actual IP addresses and names.
show dynamic-filter reports	Generates reports of the top 10 botnet sites, ports, and infected hosts.
show dynamic-filter statistics	Shows how many connections were monitored with the Botnet Traffic Filter, and how many of those connections match the whitelist, blacklist, and greylist.
show dynamic-filter updater-client	Shows information about the updater server, including the server IP address, the next time the adaptive security appliance will connect with the server, and the database version last installed.
show running-config dynamic-filter	Shows the Botnet Traffic Filter running configuration.

dynamic-filter database purge

To manually delete the Botnet Traffic Filter dynamic database from running memory, use the **dynamic-filter database purge** command in privileged EXEC mode.

dynamic-filter database purge

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values.

Command Modes The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Privileged EXEC	•	•	•	•	•

Command History	Release	Modification
	8.2(1)	This command was introduced.

Usage Guidelines The database files are stored in running memory; they are not stored in Flash memory. If you need to delete the database, use the **dynamic-filter database purge** command.

Before you can purge the database files, disable use of the database using the **no dynamic-filter use-database** command.

Examples The following example disables use of the database, and then purges the database:

```
hostname(config)# no dynamic-filter use-database
hostname(config)# dynamic-filter database purge
```

Related Commands	Command	Description
	address	Adds an IP address to the blacklist or whitelist.
	clear configure dynamic-filter	Clears the running Botnet Traffic Filter configuration.
	clear dynamic-filter dns-snoop	Clears Botnet Traffic Filter DNS snooping data.
	clear dynamic-filter reports	Clears Botnet Traffic filter report data.
	clear dynamic-filter statistics	Clears Botnet Traffic filter statistics.

Command	Description
dns domain-lookup	Enables the adaptive security appliance to send DNS requests to a DNS server to perform a name lookup for supported commands.
dns server-group	Identifies a DNS server for the adaptive security appliance.
dynamic-filter ambiguous-is-black	Treats greylisted traffic as blacklisted traffic for action purposes.
dynamic-filter blacklist	Edits the Botnet Traffic Filter blacklist.
dynamic-filter database fetch	Manually retrieves the Botnet Traffic Filter dynamic database.
dynamic-filter database find	Searches the dynamic database for a domain name or IP address.
dynamic-filter drop blacklist	Automatically drops blacklisted traffic.
dynamic-filter enable	Enables the Botnet Traffic Filter for a class of traffic or for all traffic if you do not specify an access list.
dynamic-filter updater-client enable	Enables downloading of the dynamic database.
dynamic-filter use-database	Enables use of the dynamic database.
dynamic-filter whitelist	Edits the Botnet Traffic Filter whitelist.
inspect dns dynamic-filter-snoop	Enables DNS inspection with Botnet Traffic Filter snooping.
name	Adds a name to the blacklist or whitelist.
show asp table dynamic-filter	Shows the Botnet Traffic Filter rules that are installed in the accelerated security path.
show dynamic-filter data	Shows information about the dynamic database, including when the dynamic database was last downloaded, the version of the database, how many entries the database contains, and 10 sample entries.
show dynamic-filter dns-snoop	Shows the Botnet Traffic Filter DNS snooping summary, or with the detail keyword, the actual IP addresses and names.
show dynamic-filter reports	Generates reports of the top 10 botnet sites, ports, and infected hosts.
show dynamic-filter statistics	Shows how many connections were monitored with the Botnet Traffic Filter, and how many of those connections match the whitelist, blacklist, and greylist.
show dynamic-filter updater-client	Shows information about the updater server, including the server IP address, the next time the adaptive security appliance will connect with the server, and the database version last installed.
show running-config dynamic-filter	Shows the Botnet Traffic Filter running configuration.

dynamic-filter drop blacklist

To automatically drop blacklisted traffic using the Botnet Traffic Filter, use the **dynamic-filter drop blacklist** command in global configuration mode. To disable the automatic dropping, use the **no** form of this command.

```
dynamic-filter drop blacklist [interface name] [action-classify-list subset_access_list]
[threat-level {eq level | range min max}]
```

```
no dynamic-filter drop blacklist [interface name] [action-classify-list subset_access_list]
[threat-level {eq level | range min max}]
```

Syntax Description

action-classify-list <i>sub_access_list</i>	<p>(Optional) Identifies a subset of traffic that you want to drop . See the access-list extended command to create the access list.</p> <p>The dropped traffic must always be equal to or a subset of the monitored traffic identified by the dynamic-filter enable command. For example, if you specify an access list for the dynamic-filter enable command, and you specify the action-classify-list for this command, then it must be a subset of the dynamic-filter enable access list.</p>
interface <i>name</i>	<p>(Optional) Limits monitoring to a specific interface. The dropped traffic must always be equal to or a subset of the monitored traffic identified by the dynamic-filter enable command.</p> <p>Any interface-specific commands take precedence over the global command.</p>
threat-level { eq <i>level</i> range <i>min max</i> }	<p>(Optional) Limits the traffic dropped by setting the threat level. If you do not explicitly set a threat level, the level used is threat-level range moderate very-high.</p> <p>Note We highly recommend using the default setting unless you have strong reasons for changing the setting.</p> <p>The <i>level</i> and <i>min</i> and <i>max</i> options are:</p> <ul style="list-style-type: none"> • very-low • low • moderate • high • very-high <p>Note Static blacklist entries are always designated with a Very High threat level.</p>

Defaults

This command is disabled by default.

The default threat level is **threat-level range moderate very-high**.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	—

Command History

Release	Modification
8.2(2)	This command was introduced.

Usage Guidelines

Be sure to first configure a **dynamic-filter enable** command for any traffic you want to drop; the dropped traffic must always be equal to or a subset of the monitored traffic.

You can enter this command multiple times for each interface and global policy. Make sure you do not specify overlapping traffic in multiple commands for a given interface/global policy. Because you cannot control the exact order that commands are matched, overlapping traffic means you do not know which command will be matched. For example, do not specify both a command that matches all traffic (without the **action-classify-list** keyword) as well as a command with the **action-classify-list** keyword for a given interface. In this case, the traffic might never match the command with the **action-classify-list** keyword. Similarly, if you specify multiple commands with the **action-classify-list** keyword, make sure each access list is unique, and that the networks do not overlap.

Examples

The following example monitors all port 80 traffic on the outside interface, and then drops traffic at a threat level of moderate or greater:

```
hostname(config)# access-list dynamic-filter_acl extended permit tcp any any eq 80
hostname(config)# dynamic-filter enable interface outside classify-list dynamic-filter_acl
hostname(config)# dynamic-filter drop blacklist interface outside
```

Related Commands

Command	Description
address	Adds an IP address to the blacklist or whitelist.
clear configure dynamic-filter	Clears the running Botnet Traffic Filter configuration.
clear dynamic-filter dns-snoop	Clears Botnet Traffic Filter DNS snooping data.
clear dynamic-filter reports	Clears Botnet Traffic filter report data.
clear dynamic-filter statistics	Clears Botnet Traffic filter statistics.
dns domain-lookup	Enables the adaptive security appliance to send DNS requests to a DNS server to perform a name lookup for supported commands.
dns server-group	Identifies a DNS server for the adaptive security appliance.
dynamic-filter ambiguous-is-black	Treats greylisted traffic as blacklisted traffic for action purposes.
dynamic-filter blacklist	Edits the Botnet Traffic Filter blacklist.
dynamic-filter database fetch	Manually retrieves the Botnet Traffic Filter dynamic database.

Command	Description
dynamic-filter database find	Searches the dynamic database for a domain name or IP address.
dynamic-filter database purge	Manually deletes the Botnet Traffic Filter dynamic database.
dynamic-filter enable	Enables the Botnet Traffic Filter for a class of traffic or for all traffic if you do not specify an access list.
dynamic-filter updater-client enable	Enables downloading of the dynamic database.
dynamic-filter use-database	Enables use of the dynamic database.
dynamic-filter whitelist	Edits the Botnet Traffic Filter whitelist.
inspect dns dynamic-filter-snoop	Enables DNS inspection with Botnet Traffic Filter snooping.
name	Adds a name to the blacklist or whitelist.
show asp table dynamic-filter	Shows the Botnet Traffic Filter rules that are installed in the accelerated security path.
show dynamic-filter data	Shows information about the dynamic database, including when the dynamic database was last downloaded, the version of the database, how many entries the database contains, and 10 sample entries.
show dynamic-filter dns-snoop	Shows the Botnet Traffic Filter DNS snooping summary, or with the detail keyword, the actual IP addresses and names.
show dynamic-filter reports	Generates reports of the top 10 botnet sites, ports, and infected hosts.
show dynamic-filter statistics	Shows how many connections were monitored with the Botnet Traffic Filter, and how many of those connections match the whitelist, blacklist, and greylist.
show dynamic-filter updater-client	Shows information about the updater server, including the server IP address, the next time the adaptive security appliance will connect with the server, and the database version last installed.
show running-config dynamic-filter	Shows the Botnet Traffic Filter running configuration.

dynamic-filter enable

To enable the Botnet Traffic Filter, use the **dynamic-filter enable** command in global configuration mode. To disable the Botnet Traffic Filter, use the **no** form of this command. The Botnet Traffic Filter compares the source and destination IP address in each initial connection packet to the IP addresses in the dynamic database, static database, DNS reverse lookup cache, and DNS host cache, and sends a syslog message or drops any matching traffic.

dynamic-filter enable [*interface name*] [**classify-list** *access_list*]

no dynamic-filter enable [*interface name*] [**classify-list** *access_list*]

Syntax Description

classify-list <i>access_list</i>	Identifies the traffic that you want to monitor using an extended access list (see the access-list extended command). If you do not create an access list, by default you monitor all traffic.
interface <i>name</i>	Limits monitoring to a specific interface.

Defaults

The Botnet Traffic Filter is disabled by default.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	—

Command History

Release	Modification
8.2(1)	This command was introduced.

Usage Guidelines

Malware is malicious software that is installed on an unknowing host. Malware that attempts network activity such as sending private data (passwords, credit card numbers, key strokes, or proprietary data) can be detected by the Botnet Traffic Filter when the malware starts a connection to a known bad IP address. The Botnet Traffic Filter checks incoming and outgoing connections against a dynamic database of known bad domain names and IP addresses, and then logs any suspicious activity. You can also supplement the dynamic database with a static database by entering IP addresses or domain names in a local “blacklist” or “whitelist.”

The DNS snooping is enabled separately (see the **inspect dns dynamic-filter-snoop** command). Typically, for maximum use of the Botnet Traffic Filter, you need to enable DNS snooping, but you can use Botnet Traffic Filter logging independently if desired. Without DNS snooping for the dynamic database, the Botnet Traffic Filter uses only the static database entries, plus any IP addresses in the dynamic database; domain names in the dynamic database are not used.

Botnet Traffic Filter Address Categories

Addresses monitored by the Botnet Traffic Filter include:

- Known malware addresses—These addresses are on the “blacklist.”
- Known allowed addresses—These addresses are on the “whitelist.”
- Ambiguous addresses—These addresses are associated with multiple domain names, but not all of these domain names are on the blacklist. These addresses are on the “greylist.”
- Unlisted addresses—These addresses are unknown, and not included on any list.

Botnet Traffic Filter Actions for Known Addresses

You can configure the Botnet Traffic Filter to log suspicious activity using the **dynamic-filter enable** command, and you can optionally configure it to block suspicious traffic automatically using the **dynamic-filter drop blacklist** command.

Unlisted addresses do not generate any syslog messages, but addresses on the blacklist, whitelist, and greylist generate syslog messages differentiated by type. The Botnet Traffic Filter generates detailed syslog messages numbered 338nnn. Messages differentiate between incoming and outgoing connections, blacklist, whitelist, or greylist addresses, and many other variables. (The greylist includes addresses that are associated with multiple domain names, but not all of these domain names are on the blacklist.)

See the *Cisco ASA 5500 Series System Log Messages* for detailed information about syslog messages.

Examples

The following example monitors all port 80 traffic on the outside interface, and then drops traffic at a threat level of moderate or greater:

```
hostname(config)# access-list dynamic-filter_acl extended permit tcp any any eq 80
hostname(config)# dynamic-filter enable interface outside classify-list dynamic-filter_acl
hostname(config)# dynamic-filter drop blacklist interface outside
```

Related Commands

Command	Description
address	Adds an IP address to the blacklist or whitelist.
clear configure dynamic-filter	Clears the running Botnet Traffic Filter configuration.
clear dynamic-filter dns-snoop	Clears Botnet Traffic Filter DNS snooping data.
clear dynamic-filter reports	Clears Botnet Traffic filter report data.
clear dynamic-filter statistics	Clears Botnet Traffic filter statistics.
dns domain-lookup	Enables the adaptive security appliance to send DNS requests to a DNS server to perform a name lookup for supported commands.
dns server-group	Identifies a DNS server for the adaptive security appliance.
dynamic-filter ambiguous-is-black	Treats greylisted traffic as blacklisted traffic for action purposes.
dynamic-filter blacklist	Edits the Botnet Traffic Filter blacklist.
dynamic-filter database fetch	Manually retrieves the Botnet Traffic Filter dynamic database.
dynamic-filter database find	Searches the dynamic database for a domain name or IP address.
dynamic-filter database purge	Manually deletes the Botnet Traffic Filter dynamic database.
dynamic-filter drop blacklist	Automatically drops blacklisted traffic.

Command	Description
dynamic-filter updater-client enable	Enables downloading of the dynamic database.
dynamic-filter use-database	Enables use of the dynamic database.
dynamic-filter whitelist	Edits the Botnet Traffic Filter whitelist.
inspect dns dynamic-filter-snoop	Enables DNS inspection with Botnet Traffic Filter snooping.
name	Adds a name to the blacklist or whitelist.
show asp table dynamic-filter	Shows the Botnet Traffic Filter rules that are installed in the accelerated security path.
show dynamic-filter data	Shows information about the dynamic database, including when the dynamic database was last downloaded, the version of the database, how many entries the database contains, and 10 sample entries.
show dynamic-filter dns-snoop	Shows the Botnet Traffic Filter DNS snooping summary, or with the detail keyword, the actual IP addresses and names.
show dynamic-filter reports	Generates reports of the top 10 botnet sites, ports, and infected hosts.
show dynamic-filter statistics	Shows how many connections were monitored with the Botnet Traffic Filter, and how many of those connections match the whitelist, blacklist, and greylist.
show dynamic-filter updater-client	Shows information about the updater server, including the server IP address, the next time the adaptive security appliance will connect with the server, and the database version last installed.
show running-config dynamic-filter	Shows the Botnet Traffic Filter running configuration.

dynamic-filter updater-client enable

To enable downloading of the dynamic database from the Cisco update server for the Botnet Traffic Filter, use the **dynamic-filter updater-client enable** command in global configuration mode. To disable downloading of the dynamic database, use the **no** form of this command.

dynamic-filter updater-client enable

no dynamic-filter updater-client enable

Syntax Description

This command has no arguments or keywords.

Defaults

Downloading is disabled by default.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	—	•

Command History

Release	Modification
8.2(1)	This command was introduced.

Usage Guidelines

If you do not have a database already installed on the adaptive security appliance, it downloads the database after approximately 2 minutes. The update server determines how often the adaptive security appliance polls the server for future updates, typically every hour.

The Botnet Traffic Filter can receive periodic updates for the dynamic database from the Cisco update server.

This database lists thousands of known bad domain names and IP addresses. When the domain name in a DNS reply matches a name in the dynamic database, the Botnet Traffic Filter adds the name and IP address to the *DNS reverse lookup cache*. When the infected host starts a connection to the IP address of the malware site, then the adaptive security appliance sends a syslog message informing you of the suspicious activity.

To use the database, be sure to configure a domain name server for the adaptive security appliance so that it can access the URL. To use the domain names in the dynamic database, you need to enable DNS packet inspection with Botnet Traffic Filter snooping; the adaptive security appliance looks inside the DNS packets for the domain name and associated IP address.

In some cases, the IP address itself is supplied in the dynamic database, and the Botnet Traffic Filter logs any traffic to that IP address without having to inspect DNS requests.

The database files are stored in running memory; they are not stored in Flash memory. If you need to delete the database, use the **dynamic-filter database purge** command.

**Note**

This command requires adaptive security appliance use of a DNS server; see the **dns domain-lookup** and **dns server-group** commands.

Examples

The following multiple mode example enables downloading of the dynamic database, and enables use of the database in context1 and context2:

```
hostname(config)# dynamic-filter updater-client enable
hostname(config)# changeto context context1
hostname/context1(config)# dynamic-filter use-database
hostname/context1(config)# changeto context context2
hostname/context2(config)# dynamic-filter use-database
```

The following single mode example enables downloading of the dynamic database, and enables use of the database:

```
hostname(config)# dynamic-filter updater-client enable
hostname(config)# dynamic-filter use-database
```

Related Commands

Command	Description
address	Adds an IP address to the blacklist or whitelist.
clear configure dynamic-filter	Clears the running Botnet Traffic Filter configuration.
clear dynamic-filter dns-snoop	Clears Botnet Traffic Filter DNS snooping data.
clear dynamic-filter reports	Clears Botnet Traffic filter report data.
clear dynamic-filter statistics	Clears Botnet Traffic filter statistics.
dns domain-lookup	Enables the adaptive security appliance to send DNS requests to a DNS server to perform a name lookup for supported commands.
dns name-server	Identifies a DNS server for the adaptive security appliance.
dynamic-filter ambiguous-is-black	Treats greylisted traffic as blacklisted traffic for action purposes.
dynamic-filter blacklist	Edits the Botnet Traffic Filter blacklist.
dynamic-filter database fetch	Manually retrieves the Botnet Traffic Filter dynamic database.
dynamic-filter database find	Searches the dynamic database for a domain name or IP address.
dynamic-filter database purge	Manually deletes the Botnet Traffic Filter dynamic database.
dynamic-filter drop blacklist	Automatically drops blacklisted traffic.
dynamic-filter enable	Enables the Botnet Traffic Filter for a class of traffic or for all traffic if you do not specify an access list.
dynamic-filter use-database	Enables use of the dynamic database.
dynamic-filter whitelist	Edits the Botnet Traffic Filter whitelist.
inspect dns dynamic-filter-snoop	Enables DNS inspection with Botnet Traffic Filter snooping.
name	Adds a name to the blacklist or whitelist.

Command	Description
show asp table dynamic-filter	Shows the Botnet Traffic Filter rules that are installed in the accelerated security path.
show dynamic-filter data	Shows information about the dynamic database, including when the dynamic database was last downloaded, the version of the database, how many entries the database contains, and 10 sample entries.
show dynamic-filter dns-snoop	Shows the Botnet Traffic Filter DNS snooping summary, or with the detail keyword, the actual IP addresses and names.
show dynamic-filter reports	Generates reports of the top 10 botnet sites, ports, and infected hosts.
show dynamic-filter statistics	Shows how many connections were monitored with the Botnet Traffic Filter, and how many of those connections match the whitelist, blacklist, and greylist.
show dynamic-filter updater-client	Shows information about the updater server, including the server IP address, the next time the adaptive security appliance will connect with the server, and the database version last installed.
show running-config dynamic-filter	Shows the Botnet Traffic Filter running configuration.

dynamic-filter use-database

To enable use of the dynamic database for the Botnet Traffic Filter, use the **dynamic-filter use-database** command in global configuration mode. To disable use of the dynamic database, use the **no** form of this command. Disabling use of the downloaded database is useful in multiple context mode so you can configure use of the database on a per-context basis.

- dynamic-filter use-database
- no dynamic-filter use-database

Syntax Description

This command has no arguments or keywords.

Defaults

Use of the database is disabled by default.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	—

Release	Modification
8.2(1)	This command was introduced.

Usage Guidelines

To enable downloading of the dynamic database, see the **dynamic-filter updater-client enable** command.

Examples

The following multiple mode example enables downloading of the dynamic database, and enables use of the database in context1 and context2:

```
hostname(config)# dynamic-filter updater-client enable
hostname(config)# changeto context context1
hostname/context1(config)# dynamic-filter use-database
hostname/context1(config)# changeto context context2
hostname/context2(config)# dynamic-filter use-database
```

The following single mode example enables downloading of the dynamic database, and enables use of the database:

```
hostname(config)# dynamic-filter updater-client enable
hostname(config)# dynamic-filter use-database
```

Related Commands

Command	Description
address	Adds an IP address to the blacklist or whitelist.
clear configure dynamic-filter	Clears the running Botnet Traffic Filter configuration.
clear dynamic-filter dns-snoop	Clears Botnet Traffic Filter DNS snooping data.
clear dynamic-filter reports	Clears Botnet Traffic filter report data.
clear dynamic-filter statistics	Clears Botnet Traffic filter statistics.
dns domain-lookup	Enables the adaptive security appliance to send DNS requests to a DNS server to perform a name lookup for supported commands.
dns server-group	Identifies a DNS server for the adaptive security appliance.
dynamic-filter ambiguous-is-black	Treats greylisted traffic as blacklisted traffic for action purposes.
dynamic-filter blacklist	Edits the Botnet Traffic Filter blacklist.
dynamic-filter database fetch	Manually retrieves the Botnet Traffic Filter dynamic database.
dynamic-filter database find	Searches the dynamic database for a domain name or IP address.
dynamic-filter database purge	Manually deletes the Botnet Traffic Filter dynamic database.
dynamic-filter drop blacklist	Automatically drops blacklisted traffic.
dynamic-filter enable	Enables the Botnet Traffic Filter for a class of traffic or for all traffic if you do not specify an access list.
dynamic-filter updater-client enable	Enables downloading of the dynamic database.
dynamic-filter whitelist	Edits the Botnet Traffic Filter whitelist.
inspect dns dynamic-filter-snoop	Enables DNS inspection with Botnet Traffic Filter snooping.
name	Adds a name to the blacklist or whitelist.
show asp table dynamic-filter	Shows the Botnet Traffic Filter rules that are installed in the accelerated security path.
show dynamic-filter data	Shows information about the dynamic database, including when the dynamic database was last downloaded, the version of the database, how many entries the database contains, and 10 sample entries.
show dynamic-filter dns-snoop	Shows the Botnet Traffic Filter DNS snooping summary, or with the detail keyword, the actual IP addresses and names.
show dynamic-filter reports	Generates reports of the top 10 botnet sites, ports, and infected hosts.
show dynamic-filter statistics	Shows how many connections were monitored with the Botnet Traffic Filter, and how many of those connections match the whitelist, blacklist, and greylist.
show dynamic-filter updater-client	Shows information about the updater server, including the server IP address, the next time the adaptive security appliance will connect with the server, and the database version last installed.
show running-config dynamic-filter	Shows the Botnet Traffic Filter running configuration.

dynamic-filter whitelist

To edit the Botnet Traffic Filter whitelist, use the **dynamic-filter whitelist** command in global configuration mode. To remove the whitelist, use the **no** form of this command. The static database lets you augment the dynamic database with domain names or IP addresses that you want to whitelist.

dynamic-filter whitelist

no dynamic-filter whitelist

Syntax Description

This command has no arguments or keywords.

Defaults

No default behavior or values.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	—

Command History

Release	Modification
8.2(1)	This command was introduced.

Usage Guidelines

After you enter the dynamic-filter whitelist configuration mode, you can manually enter domain names or IP addresses (host or subnet) that you want to tag as good names in a whitelist using the **address** and **name** commands. Names or addresses that appear on both the dynamic blacklist and static whitelist are identified only as whitelist addresses in syslog messages and reports. Note that you see syslog messages for whitelisted addresses even if the address is not also in the dynamic blacklist. You can enter names or IP addresses in the static blacklist using the **dynamic-filter blacklist** command.

When you add a domain name to the static database, the adaptive security appliance waits 1 minute, and then sends a DNS request for that domain name and adds the domain name/IP address pairing to the *DNS host cache*. (This action is a background process, and does not affect your ability to continue configuring the adaptive security appliance). We recommend also enabling DNS packet inspection with Botnet Traffic Filter snooping (see the **inspect dns dynamic-filter-snooping** command). The adaptive security appliance uses Botnet Traffic Filter snooping instead of the regular DNS lookup to resolve static blacklist domain names in the following circumstances:

- The adaptive security appliance DNS server is unavailable.
- A connection is initiated during the 1 minute waiting period before the adaptive security appliance sends the regular DNS request.

If DNS snooping is used, when an infected host sends a DNS request for a name on the static database, the adaptive security appliance looks inside the DNS packets for the domain name and associated IP address and adds the name and IP address to the DNS reverse lookup cache.

If you do not enable Botnet Traffic Filter snooping, and one of the above circumstances occurs, then that traffic will not be monitored by the Botnet Traffic Filter.

**Note**

This command requires adaptive security appliance use of a DNS server; see the **dns domain-lookup** and **dns server-group** commands.

Examples

The following example creates entries for the blacklist and whitelist:

```
hostname(config)# dynamic-filter blacklist
hostname(config-l1ist)# name bad1.example.com
hostname(config-l1ist)# name bad2.example.com
hostname(config-l1ist)# address 10.1.1.1 255.255.255.0

hostname(config-l1ist)# dynamic-filter whitelist
hostname(config-l1ist)# name good.example.com
hostname(config-l1ist)# name great.example.com
hostname(config-l1ist)# name awesome.example.com
hostname(config-l1ist)# address 10.1.1.2 255.255.255.255
```

Related Commands

Command	Description
address	Adds an IP address to the blacklist or whitelist.
clear configure dynamic-filter	Clears the running Botnet Traffic Filter configuration.
clear dynamic-filter dns-snoop	Clears Botnet Traffic Filter DNS snooping data.
clear dynamic-filter reports	Clears Botnet Traffic filter report data.
clear dynamic-filter statistics	Clears Botnet Traffic filter statistics.
dns domain-lookup	Enables the adaptive security appliance to send DNS requests to a DNS server to perform a name lookup for supported commands.
dns server-group	Identifies a DNS server for the adaptive security appliance.
dynamic-filter ambiguous-is-black	Treats greylisted traffic as blacklisted traffic for action purposes.
dynamic-filter blacklist	Edits the Botnet Traffic Filter blacklist.
dynamic-filter database fetch	Manually retrieves the Botnet Traffic Filter dynamic database.
dynamic-filter database find	Searches the dynamic database for a domain name or IP address.
dynamic-filter database purge	Manually deletes the Botnet Traffic Filter dynamic database.
dynamic-filter drop blacklist	Automatically drops blacklisted traffic.
dynamic-filter enable	Enables the Botnet Traffic Filter for a class of traffic or for all traffic if you do not specify an access list.
dynamic-filter updater-client enable	Enables downloading of the dynamic database.
dynamic-filter use-database	Enables use of the dynamic database.
inspect dns	Enables DNS inspection with Botnet Traffic Filter snooping.
dynamic-filter-snoop	

Command	Description
name	Adds a name to the blacklist or whitelist.
show asp table dynamic-filter	Shows the Botnet Traffic Filter rules that are installed in the accelerated security path.
show dynamic-filter data	Shows information about the dynamic database, including when the dynamic database was last downloaded, the version of the database, how many entries the database contains, and 10 sample entries.
show dynamic-filter dns-snoop	Shows the Botnet Traffic Filter DNS snooping summary, or with the detail keyword, the actual IP addresses and names.
show dynamic-filter reports	Generates reports of the top 10 botnet sites, ports, and infected hosts.
show dynamic-filter statistics	Shows how many connections were monitored with the Botnet Traffic Filter, and how many of those connections match the whitelist, blacklist, and greylist.
show dynamic-filter updater-client	Shows information about the updater server, including the server IP address, the next time the adaptive security appliance will connect with the server, and the database version last installed.
show running-config dynamic-filter	Shows the Botnet Traffic Filter running configuration.