



Administering Trend Micro InterScan for Cisco CSC SSM


This chapter describes tasks you might perform infrequently, such as installing a patch, and includes the following sections:

- [Configuring Connection Settings, page 6-1](#)
- [Managing Admin Email and Notification Settings, page 6-2](#)
- [Performing Configuration Backup, page 6-2](#)
- [Configuring Failover Settings, page 6-3](#)
- [Installing Product Upgrades, page 6-5](#)
- [Viewing the Product License, page 6-5](#)

Configuring Connection Settings

To view your network connection settings, select **Administration > Device Settings > Connection Settings**. The **Connection Settings** window (shown in [Figure 6-1](#)) displays selections you made during installation.

Figure 6-1 Connection Settings Window



■ Managing Admin Email and Notification Settings

The **Primary DNS** and **Secondary DNS** IP address fields can be changed on this screen. To change your other connection settings, such as host name, domain name, or IP address, go to **Configuration > Trend Micro Content Security** and select **CSC Setup** from the menu.

You can also change these settings using the command-line interface (CLI). Log in to the CLI, and issue a **session 1** command. If this is your first time logging in to the CLI, use the default user name (cisco) and password (cisco). You are prompted to change your password.


After you log in, select option **1**, Network Settings, from the Trend Micro InterScan for Cisco CSC SSM Setup Wizard menu. Follow the prompts to change the settings. See the “[Reimaging the CSC SSM](#)” section on page A-4, for more information.

Managing Admin Email and Notification Settings

The **Notification Settings** window (shown in [Figure 6-2](#)) allows you to:

- View and/or change the administrator email address you selected during installation (on the **Host Configuration** window)
- View the SMTP server IP and port you selected during installation (on the **Host Configuration** window)
- Configure the maximum number of administrator notifications per hour

Figure 6-2 Notification Settings Window



To make changes on this window, enter the new information and click **Save**.

You can also make these changes in the ASDM by selecting **Configuration > Trend Micro Content Security**, then select **CSC Setup** from the menu.

Performing Configuration Backup

Trend Micro InterScan for Cisco CSC SSM provides the ability to back up your device configuration and save it in a compressed file. You can import the saved configuration and thus restore your system to the settings configured at the time of the save.

**Note**

A configuration backup is essential for recovery in case you lose your ASDM/Web GUI password. See [Recovering a Lost Password, page 8-5](#) for more information.

As soon as you finish configuring Trend Micro InterScan for Cisco CSC SSM as described in previous chapters, perform a configuration backup. Go to **Administration > Configuration Backup** to display the **Configuration Backup** window, shown in [Figure 6-3](#).

Figure 6-3 Configuration Backup Window



Export (Save) Configuration

Click **Export** to save your configuration settings. A **File Download** dialog box displays. You can open the file, which is named config.tgz by default, or save the file to your computer.

Import Configuration

To restore a saved configuration file, on the **Backup Configuration** window, click **Browse**. Locate the config.tgz file and click **Import**. The file name displays in the **Select a configuration file** field. The saved configuration settings are restored to the appliance.

Importing a saved configuration file restarts scanning service. You should notice, for example, that the counters on the **Summary** window reset.

Configuring Failover Settings

Trend Micro InterScan for Cisco CSC SSM provides capability to replicate configuration to a peer unit in supporting the device failover feature on the ASA. Before you configure the peer device, or the CSC SSM on the failover device, finish configuring the primary device first, that is, enable spyware/grayware scanning, customize your notifications if you plan to do so, and so on.

When you have fully configured the primary device to perform as you want it, follow the steps exactly as described in the checklist below to configure the failover peer. Print a copy of the checklist that you can use to record your steps as you progress.

Configuring Failover Settings

Step	Configure Failover Checklist	Checkoff
1	<p>Decide which appliance should act as the primary device, and which should act as the secondary device. Record the IP address of each here:</p> <p>Notes: _____</p>	<input type="checkbox"/> <input type="checkbox"/>
2	<p>Open a browser window and enter the following URL in the Address field: http://<primary device IP address>:8443. The Logon window displays. Log on, and navigate to Administration > Device Settings > Device Failover Settings.</p>	<input type="checkbox"/>
3	<p>Open a second browser window and enter the following URL in the Address field: http://<secondary device IP address>:8443. As in step 2, log on, and navigate to the Device Failover Settings window.</p>	<input type="checkbox"/>
4	<p>On the Device Failover Settings window for the primary device, enter the IP address of the secondary device in the Peer IP address field. Enter an encryption key of 1-8 alphanumeric characters in the Encryption key field. Click Save, and then click Enable. The following message displays under the window title:</p> <p>InterScan for CSC SSM could not establish a connection because the failover peer device is not yet configured. Please configure the failover peer device, then try again.</p> <p>This message is normal and appears because the peer is not yet configured. Do not be concerned about this message at this time.</p>	<input type="checkbox"/>
5	<p>On the Device Failover Settings window for the secondary device, enter the IP address of the primary device in the Peer IP address field. Enter the encryption key of 1-8 alphanumeric characters in the Encryption key field. The encryption key must be identical to the key entered for the primary device. Click Save, and then click Enable. The following message displays under the window title:</p> <p>InterScan for CSC SSM has successfully connected with the failover peer device.</p> <p><i>Do not click anything else</i> at this time for the secondary device.</p>	<input type="checkbox"/>
6	<p>Go back to the Device Failover Settings window for the primary device and click Synchronize with peer.</p>	<input type="checkbox"/>
7	<p>The message in the Status field at the bottom of the windows should now state the date and time of the synchronization, for example:</p> <p>Status: Last synchronized with peer on: 09/29/2005 15:20:11</p>	<input type="checkbox"/>



Caution

Be sure you do not click **Synchronize with peer** at the end of Step 5 while you are still on the **Device Failover Settings** window for the secondary device. If you do, the configuration you have already set up on the primary device is erased. You must perform manual synchronization from the primary device as described in Step 6.

When you complete the steps on the checklist, the failover relationship is successfully configured.

If at a future time you want to make a change to the configuration, for example, you change the spam filtering threshold from Low to Medium, you should modify the configuration on the primary device only. Trend Micro InterScan for Cisco CSC SSM detects the configuration mismatch, and updates the peer with the configuration change you made on the first device.

The exception to the auto-synchronization feature is uploading a system patch. A patch must be applied on both the primary and secondary devices. See the “[Installing Product Upgrades](#)” section on page 6-5 for more information.

If for some reason the peer device becomes unavailable, an email notification is sent to the administrator. The message continues to be sent periodically until the problem with the peer is resolved.

Installing Product Upgrades

From time to time, a product upgrade becomes available that fixes a known issues or offers new functionality. First download the system patch from the Web site or CD provided, then go to **Administration > Product Upgrades** to display the **Upgrade** window, shown in [Figure 6-4](#).

Figure 6-4 Product Upgrades Window



Upgrades may restart system services and interrupt system operation. Upgrading the system while the device is in operation may allow traffic containing viruses and malware through the network.

See the online help for this window for information about installing and removing upgrades.

Viewing the Product License


The **Product License** window (shown in [Figure 6-5](#)) allows you to view the status of your product license, including:

- Which license(s) are activated (Base License only, or Base License and Plus License)
- License version, which should state “Full” unless you are temporarily using an “Evaluation” copy
- Activation Code for your license
- Number of licensed seats (users)—this information displays only for the Base License, even if you purchased the Plus License

Viewing the Product License

- Status, which should be “Activated”
- License expiration date—if you have both the Base and Plus Licenses, the expiration dates can be different

Figure 6-5 Product License Window




153663

If your license is not renewed, antivirus scanning continues with the version of the pattern file and scan engine that was valid at the time of expiration plus a short grace period. However, other features may become unavailable. See the [License Expiration](#) section for more information.

License Expiration

As you approach and even pass the expiration date, a message displays in the **Summary** window under the window header, similar to the example shown in [Figure 6-6](#).

Figure 6-6 License Expiration Message



148816

When your product license expires, you can continue using Trend Micro InterScan for Cisco CSC SSM, but you are no longer eligible to receive updates (to the virus pattern file, scan engine, and so on). Your network may no longer be protected against new security threats.

If your Plus license expires, content-filtering and URL-filtering are no longer available. In this case, traffic is passed without filtering content or URLs.

If you purchased the Plus License at a later time after you purchased and installed the Base License, the expiration dates are different. You can renew each license at different times as the renewal date approaches.

License Information Links

The Product License window contains some helpful links. These are:

- View detailed license online
- Check Status Online

The View detailed license online link takes you to the Trend Micro online registration Web site where you can view information about your license, and find instructions for renewing. **Check Status Online** displays a message below the **Product License** window title that describes the status of your license, similar to the example in the previous figure.

View the online help for the **Product License** window for additional information.

■ Viewing the Product License