



## CHAPTER

# 6

## **clear configure through clear configure xlate-bypass Commands**

---

# clear configure

To clear the running configuration, use the **clear configure** command in global configuration mode.

**clear configure** { **primary** | **secondary** | **all** | *command* }

## Syntax Description

<b>all</b>	Clears the entire running configuration.
<i>command</i>	Clears the configuration for a specified command. For more information, see individual entries in this guide for each <b>clear configure</b> <i>command</i> command.
<b>primary</b>	Clears commands related to connectivity, including the following commands: <ul style="list-style-type: none"> <li>• <b>tftp-server</b></li> <li>• <b>shun</b></li> <li>• <b>route</b></li> <li>• <b>ip address</b></li> <li>• <b>mtu</b></li> <li>• <b>failover</b></li> <li>• <b>monitor-interface</b></li> <li>• <b>boot</b></li> </ul>
<b>secondary</b>	Clears commands not related to connectivity (that are cleared using the <b>primary</b> keyword).

## Defaults

No default behavior or values.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	•

## Command History

Release	Modification
1.1(1)	This command was introduced.
3.1(1)	This command was modified to allow you to clear the configuration for each command.

### Usage Guidelines

When you enter this command in a security context, you clear only the context configuration. If you enter this command in the system execution space, you clear the system running configuration as well as all context running configurations. Because you cleared all context entries in the system configuration (see the **context** command), the contexts are no longer running, and you cannot change to a context execution space.

Before clearing the configuration, make sure you save any changes to the **boot config** command (which specifies the startup configuration location) to the startup configuration; if you changed the startup configuration location only in the running configuration, then when you restart, the configuration loads from the default location.

### Examples

The following example clears the entire running configuration:

```
hostname(config)# clear configure all
```

### Related Commands

Command	Description
<b>configure http</b>	Merges a configuration file from the specified HTTP(S) URL with the running configuration.
<b>configure memory</b>	Merges the startup configuration with the running configuration.
<b>configure net</b>	Merges a configuration file from the specified TFTP URL with the running configuration.
<b>show running-config</b>	Shows the running configuration.

# clear configure aaa

To clear the AAA configuration, use the **clear configure aaa** command in global configuration mode. The **clear configure aaa** command removes the AAA command statements from the configuration.

**clear configure aaa**

## Syntax Description

This command has no arguments or keywords.

## Defaults

No default behavior or values.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	—

## Command History

Release	Modification
1.1(1)	The <b>clear aaa</b> command was introduced.
3.1(1)	This command was changed from <b>clear aaa</b> .

## Usage Guidelines

This command also resets the AAA parameters to their default values, if any.

## Examples

```
hostname(config)# clear configure aaa
```

## Related Commands

Command	Description
<b>aaa accounting</b>	Enables or disables accounting.
<b>aaa authentication</b>	Enables or disables user authentication.
<b>aaa authorization</b>	Enables or disables user authorization.
<b>show running-config aaa</b>	Displays the AAA configuration.

# clear configure aaa-server

To remove all AAA server groups or to clear the specified group, use the **clear configure aaa-server** command in global configuration mode.

**clear configure aaa-server** [*server-tag*]

**clear configure aaa-server** [*server-tag*] **host** *server-ip*

## Syntax Description

<i>server-ip</i>	The IP address of the AAA server.
<i>server-tag</i>	(Optional) Symbolic name of the server group to be cleared.

## Defaults

Remove all AAA server groups.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	—	—	•

## Command History

Release	Modification
1.1(1)	The <b>clear aaa-server</b> command was introduced.
3.1(1)	This command was changed from <b>clear aaa-server</b> .

## Usage Guidelines

You can specify a particular AAA server group or, by default, all AAA server groups.

Use the **host** keyword to specify a particular server within a server group.

This command also resets the AAA server parameters to their default values, if any.

## Examples

The following example shows how to remove server groups:

```
hostname(config)# aaa-server svrgrp1 protocol sdi
hostname(config)# aaa-server svrgrp1 host 1.2.3.4
hostname(config-aaa-server)# timeout 9
hostname(config-aaa-server)# retry 7
hostname(config-aaa-server)# sdi-version sdi-5
hostname(config-aaa-server)# exit
```

The following command shows how to remove a specific server from a group:

```
hostname(config)# clear config aaa-server svrgrp1 host 1.2.3.4
```

The following command shows how to remove a server group:

```
hostname(config)# clear config aaa-server svrgrp1
```

The following command shows how to remove all server groups:

```
hostname(config)# clear config aaa-server
```

**Related Commands**

Command	Description
<b>aaa-server host</b>	Specifies and manages host-specific AAA server connection data.
<b>aaa-server protocol</b>	Lets you configure AAA server parameters that are group-specific and common to all hosts.
<b>show running-config aaa</b>	Displays the current maximum number of concurrent proxy connections allowed per user, along with other AAA configuration values.

# clear configure access-group

To remove access groups from all the interfaces, use the **clear configure access-group** command in global configuration mode.

## clear configure access-group

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	—

Command History	Release	Modification
	1.1(1)	This command was introduced.
	3.1(1)	This command was changed from <b>clear access-group</b> .

**Examples** The following example shows how to remove all access groups:

```
hostname(config)# clear configure access-group
```

Related Commands	Command	Description
	<b>access-group</b>	Binds an access list to an interface.
	<b>show running-config access-group</b>	Displays the current access group configuration.

# clear configure access-list

To clear an access list from the running configuration, use the **clear configure access list** command in global configuration mode.

**clear configure access-list** [*id*]

<b>Syntax Description</b>	<i>id</i> (Optional) Name or number of an access list.
---------------------------	--

<b>Defaults</b>	All the access lists are cleared from the running configuration.
-----------------	--

<b>Command Modes</b>	The following table shows the modes in which you can enter the command:
----------------------	---

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	—

Command History	Release	Modification
	3.1(1)	This command was introduced.

<b>Examples</b>	This example shows how to clear the access lists from the running configuration:
-----------------	--

```
hostname(config)# clear configure access-list
```

Related Commands	Command	Description
	<b>access-list extended</b>	Adds an access list to the configuration and configures policy for IP traffic through the firewall.
	<b>access-list standard</b>	Adds an access list to identify the destination IP addresses of OSPF routes, which can be used in a route map for OSPF redistribution.
	<b>clear access-list</b>	Clears access list counters.
	<b>show access-list</b>	Displays counters for an access list.
	<b>show running-config access-list</b>	Displays the access list configuration running on the FWSM.



# clear configure alias

To remove all **alias** commands from the configuration, use the **clear configure alias** command in global configuration mode.

**clear configure alias**

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	—	•	•	•

Command History	Release	Modification
	1.1(1)	This command was introduced.
	3.1(1)	This command was changed from <b>clear alias</b> .

**Examples** The following example shows how to remove all **alias** commands from the configuration:

```
hostname(config)# clear configure alias
```

Related Commands	Command	Description
	<b>alias</b>	Translates one address into another.
	<b>show running-config alias</b>	Displays the overlapping addresses with dual NAT commands in the configuration.

# clear configure arp

To clear static ARP entries added by the **arp** command, use the **clear configure arp** command in global configuration mode.

## clear configure arp

### Syntax Description

This command has no arguments or keywords.

### Defaults

No default behavior or values.

### Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	—	•	•	•	—

### Command History

Release	Modification
2.2(1)	This command was introduced.
3.1(1)	The <b>configure</b> keyword was added.

### Examples

The following example clears static ARP entries from the configuration:

```
hostname# clear configure arp
```

### Related Commands

Command	Description
<b>arp</b>	Adds a static ARP entry.
<b>arp-inspection</b>	For transparent firewall mode, inspects ARP packets to prevent ARP spoofing.
<b>firewall transparent</b>	Sets the firewall mode to transparent.
<b>show arp statistics</b>	Shows ARP statistics.
<b>show running-config arp</b>	Shows the current configuration of the ARP timeout.

# clear configure arp-inspection

To clear the ARP inspection configuration, use the **clear configure arp-inspection** command in global configuration mode.

## clear configure arp-inspection

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	—	•	•	•	—

Command History	Release	Modification
	2.2(1)	This command was introduced.
	3.1(1)	This command was changed from <b>clear arp-inspection</b> .

**Examples** The following example clears the ARP inspection configuration:

```
hostname# clear configure arp-inspection
```

Related Commands	Command	Description
	<b>arp</b>	Adds a static ARP entry.
	<b>arp-inspection</b>	For transparent firewall mode, inspects ARP packets to prevent ARP spoofing.
	<b>firewall transparent</b>	Sets the firewall mode to transparent.
	<b>show arp statistics</b>	Shows ARP statistics.
	<b>show running-config arp</b>	Shows the current configuration of the ARP timeout.

# clear configure asdm

To remove all **asdm** commands from the running configuration, use the **clear configure asdm** command in global configuration mode.

**clear configure asdm** [**location** | **group**]

## Syntax Description

<b>group</b>	(Optional) Clears only the <b>asdm group</b> commands from the running configuration.
<b>location</b>	(Optional) Clears only the <b>asdm location</b> commands from the running configuration.

## Defaults

No default behavior or values.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	•

## Command History

Release	Modification
1.1(1)	This command was introduced (as the <b>clear pdm</b> command).
3.1(1)	This command was changed from the <b>clear pdm</b> command to the <b>clear configure asdm</b> command.

## Usage Guidelines

To view the **asdm** commands in the running configuration, use the **show running-config asdm** command.

Clearing the **asdm location** and **asdm group** commands from the configuration causes ASDM to regenerate those commands the next time ASDM is accessed, but may disrupt active ASDM sessions.



### Note

On FWSMs running in multiple context mode, the **clear configure asdm group** and **clear configure asdm location** commands are only available in the user contexts.

## Examples

The following example clears the **asdm group** commands from the running configuration:

```
hostname(config)# clear configure asdm group
hostname(config)#
```

Related Commands	Command	Description
	<b>asdm group</b>	Used by ASDM to associate object group names with interfaces.
	<b>asdm location</b>	Used by ASDM to record IP address to interface associations.
	<b>show running-config asdm</b>	Displays the <b>asdm</b> commands in the running configuration.

# clear configure auth-prompt

To remove the previously specified authentication prompt challenge text and revert to the default value, if any, use the **clear configure auth-prompt** command in global configuration mode.

## clear configure auth-prompt

### Syntax Description

This command has no arguments or keywords.

### Defaults

No default behavior or values.

### Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	—	—	•

### Command History

Release	Modification
1.1(1)	The <b>clear auth-prompt</b> command was introduced.
3.1(1)	This command was changed from <b>clear auth-prompt</b> .

### Usage Guidelines

After you clear the authentication prompt, the prompt users see when they log in depends on the protocol they use:

- Users who log in using HTTP see the following prompt: `HTTP Authentication`.
- Users who log in using FTP see the following prompt: `FTP Authentication`.
- Users who log in using Telnet see no prompt.

### Examples

The following example shows how to clear the auth-prompt:

```
hostname(config)# clear configure auth-prompt
```

### Related Commands

<b>auth-prompt</b>	Sets the user authorization prompts.
<b>show running-config auth-prompt</b>	Displays the user authorization prompts.

# clear configure auto-update

To clear the Auto Update Server configuration, use the **clear configure auto-update** command in global configuration mode.

**clear configure auto-update**

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	—	—

Release	Modification
3.1(1)	This command was introduced.

**Command History**

**Examples** The following example clears the ARP inspection configuration:

```
hostname# clear configure auto-update
```

Related Commands	Command	Description
	<b>auto-update device-id</b>	Sets the FWSM device ID for use with an Auto Update Server.
	<b>auto-update poll-period</b>	Sets how often the FWSM checks for updates from an Auto Update Server.
	<b>auto-update server</b>	Identifies the Auto Update Server.
	<b>auto-update timeout</b>	Stops traffic from passing through the FWSM if the Auto Update Server is not contacted within the timeout period.
	<b>show running-config auto-update</b>	Shows the Auto Update Server configuration.

# clear configure banner

To remove all the banners, use the **clear configure banner** command in global configuration mode.

**clear configure banner**

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	•

Release	Modification
2.2(1)	The <b>clear banner</b> command was introduced.
3.1(1)	This command was changed to <b>clear configure banner</b> .

**Examples** The following example shows how to clear banners:

```
hostname(config)# clear configure banner
```

Command	Description
<b>banner</b>	Configures the session, login, or message-of-the-day banner.
<b>show running-config banner</b>	Displays all banners.



# clear configure ca certificate map

To remove all certificate map entries or to remove a specified certificate map entry, use the **clear configure ca configurate map** command in global configuration mode.

**clear configure ca certificate map** [*sequence-number*]

<b>Syntax Description</b>	<i>sequence-number</i>	(Optional) Specifies a number for the certificate map rule you are removing. The range is 1 through 65535.
---------------------------	------------------------	--

<b>Defaults</b>	No default behavior or values.
-----------------	--------------------------------

<b>Command Modes</b>	The following table shows the modes in which you can enter the command:
----------------------	---

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	—

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	3.1(1)	This command was introduced.

<b>Examples</b>	<p>The following example removes all certificate map entries.</p> <pre>hostname(config)# clear configure ca certificate map hostname(config)#</pre>
-----------------	---

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>crypto ca certificate map</b>	Enters ca certificate map mode.

# clear configure class

To clear the class configuration, use the **clear configure class** command in global configuration mode.

## clear configure class

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	N/A	N/A	—	—	•

Release	Modification
2.2(1)	This command was introduced.
3.1(1)	This command was changed from <b>clear class</b> .

**Examples** The following example clears the class configuration:

```
hostname(config)# clear configure class
```

Related Commands	Command	Description
	<b>class</b>	Configures a resource class.
	<b>context</b>	Configures a security context.
	<b>limit-resource</b>	Sets the resource limit for a class.
	<b>member</b>	Assigns a context to a resource class.
	<b>show class</b>	Shows the contexts assigned to a class.

# clear configure class-map

To remove all class maps, use the **clear configure class-map** command in global configuration mode.

**clear configure class-map** [**type** { **regex** | **inspect** [*protocol*] }]

<b>Syntax Description</b>	<b>inspect</b>	(Optional) Clears inspection class maps.
	<i>protocol</i>	(Optional) Specifies the type of application map you want to clear. Available types include: <ul style="list-style-type: none"> <li>• <b>http</b></li> <li>• <b>sip</b></li> </ul>
	<b>regex</b>	(Optional) Clears regular expression class maps.
	<b>type</b>	(Optional) Specifies the type of class map you want to clear. To clear Layer 3/4 class maps, to not specify the type.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	—

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	3.1(1)	This command was introduced.
	4.0(1)	The <b>type</b> keyword was added.

**Usage Guidelines** To clear the class map for a specific class map name, use the **no** form of the **class-map** command.

**Examples** The following example shows how to clear all configured class maps:

```
hostname(config)# clear configure class-map
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>class-map</b>	Applies a traffic class to an interface.
	<b>show running-config class-map</b>	Displays the information about the class map configuration.

# clear configure command-alias

To remove all non-default command aliases, use the **clear configure command-alias** command in global configuration mode.

## clear configure command-alias

### Syntax Description

This command has no arguments or keywords.

### Defaults

No default behavior or values.

### Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	•

### Command History

Release	Modification
3.1(1)	This command was introduced.

### Examples

The following example shows how to remove all non-default command aliases:

```
hostname(config)# clear configure command-alias
```

### Related Commands

Command	Description
<b>command-alias</b>	Creates a command alias.
<b>show running-config command-alias</b>	Displays all non-default command aliases.

# clear configure console

To reset the console connection settings to defaults, use the **clear configure console** command in global configuration mode.

## clear configure console

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	•

Command History	Release	Modification
	3.1(1)	This command was introduced.

**Examples** The following example shows how to reset the console connection settings to defaults:

```
hostname(config)# clear configure console
```

Related Commands	Command	Description
	<b>console timeout</b>	Sets the idle timeout for a console connection to the FWSM.
	<b>show running-config console timeout</b>	Displays the idle timeout for a console connection to the FWSM.

# clear configure context

To clear all context configurations in the system configuration, use the **clear configure context** command in global configuration mode.

**clear configure context [noconfirm]**

## Syntax Description

**noconfirm** (Optional) Removes all contexts without prompting you for confirmation. This option is useful for automated scripts.

## Defaults

No default behavior or values.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	N/A	N/A	—	—	•

## Command History

Release	Modification
2.2(1)	This command was introduced.
3.1(1)	This command was changed from <b>clear context</b> .

## Usage Guidelines

This command lets you remove all contexts, including the admin context. The admin context cannot be removed using the **no context** command, but can be removed using the **clear configure context** command.

## Examples

The following example removes all contexts from the system configuration, and does not confirm the deletion:

```
hostname(config)# clear configure context noconfirm
```

## Related Commands

Command	Description
<b>admin-context</b>	Sets the admin context.
<b>changeto</b>	Changes between contexts or the system execution space.
<b>context</b>	Creates a security context in the system configuration and enters context configuration mode.

Command	Description
<b>mode</b>	Sets the context mode to single or multiple.
<b>show context</b>	Shows a list of contexts (system execution space) or information about the current context.

# clear configure crypto

To remove the entire crypto configuration, including IPSec, crypto maps, dynamic crypto maps, CA trustpoints, all certificates, certificate map configurations, and ISAKMP, use the **clear configure crypto** command in global configuration mode. To remove specific configurations, use this command with keywords as shown in the syntax. Take caution when using this command.

**clear configure crypto** [**ca** | **dynamic-map** | **ipsec** | **isakmp** | **map**]

## Syntax Description

<b>ca</b>	Removes certification authority policy.
<b>dynamic-map</b>	Removes dynamic crypto map configuration.
<b>ipsec</b>	Removes IPSec configuration.
<b>isakmp</b>	Removes ISAKMP configuration.
<b>map</b>	Removes crypto map configuration.

## Defaults

No default behavior or values.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	—

## Command History

Release	Modification
3.1(1)	This command was introduced.

## Examples

The following example issued in global configuration mode, removes all of the crypto configuration from the FWSM:

```
hostname(config)# clear configure crypto
hostname(config)#
```

## Related Commands

Command	Description
<b>clear configure crypto</b>	Clears all or specified crypto dynamic maps from the configuration.
<b>clear configure crypto map</b>	Clears all or specified crypto maps from the configuration.
<b>clear configure isakmp policy</b>	Clears all ISAKMP policy configuration.
<b>show running-config crypto</b>	Displays the entire crypto configuration, including IPSec, crypto maps, dynamic crypto maps, and ISAKMP.



# clear configure crypto ca trustpoint

To remove all trustpoints from the configuration, use the **clear configure crypto ca trustpoint** command in global configuration mode.

## clear configure crypto ca trustpoint

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	—

Command History	Release	Modification
	3.1(1)	This command was introduced.

**Examples** The following example entered in global configuration mode, removes all trustpoints from the configuration:

```
hostname(config)# clear configure crypto ca trustpoint
hostname(config)#
```

Related Commands	Command	Description
	<b>crypto ca trustpoint</b>	Enters the trustpoint subconfiguration level for the indicated trustpoint.

# clear configure crypto dynamic-map

To remove all or specified crypto dynamic maps from the configuration, use the **clear configure crypto dynamic-map** command in global configuration mode.

**clear configure crypto dynamic-map** *dynamic-map-name* *dynamic-seq-num*

## Syntax Description

<i>dynamic-map-name</i>	Specifies the name of a specific crypto dynamic map.
<i>dynamic-seq-num</i>	Specifies the sequence number of the crypto dynamic map.

## Defaults

No default behavior or values.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	—	•	•	—

## Command History

Release	Modification
1.1(1)	This command was introduced.
3.1(1)	This command was changed from <b>clear crypto dynamic-map</b> .

## Examples

The following example entered in global configuration mode, removes the crypto dynamic map mymaps with sequence number 3 from the configuration:

```
hostname(config)# clear configure crypto dynamic-map mymaps 3
hostname(config)#
```

## Related Commands

Command	Description
<b>clear configure crypto map</b>	Clears the configuration of all or specified crypto maps.
<b>show running-config crypto dynamic-map</b>	Displays all the active configuration for all dynamic crypto maps.
<b>show running-config crypto map</b>	Displays all the active configuration for all crypto maps.

# clear configure crypto map

To remove all or specified crypto maps from the configuration, use the **clear configure crypto map** command in global configuration mode.

**clear configure crypto map** *map-name seq-num*

## Syntax Description

<i>map-name</i>	Specifies the name of a specific crypto map.
<i>seq-num</i>	Specifies the sequence number of the crypto map.

## Defaults

No default behavior or values.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	—

## Command History

Release	Modification
3.1(1)	This command was introduced.

## Examples

The following example entered in global configuration mode, removes the crypto map mymaps with sequence number 3 from the configuration:

```
hostname(config)# clear configure crypto map mymaps 3
hostname(config)#
```

## Related Commands

Command	Description
<b>clear configure crypto dynamic-map</b>	Clears the configuration of all or specified crypto dynamic maps.
<b>crypto map interface</b>	Applies a crypto map to an interface.
<b>show running-config crypto map</b>	Displays the active configuration for all crypto maps.
<b>show running-config crypto dynamic-map</b>	Displays the active configuration for all dynamic crypto maps.

# clear configure dhcpd

To clear all of the DHCP server commands, binding, and statistics, use the **clear configure dhcpd** command in global configuration mode.

## clear configure dhcpd

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	—

Release	Modification
3.1(1)	This command was introduced.

**Usage Guidelines** The **clear configure dhcpd** command clears all of the **dhcpd** commands, bindings, and statistical information. To clear only the statistic counters or binding information, use the **clear dhcpd** command.

**Examples** The following example shows how to clear all **dhcpd** commands:

```
hostname(config)# clear configure dhcpd
```

Command	Description
<b>clear dhcpd</b>	Clears the DHCP server bindings and statistic counters.
<b>show running-config dhcpd</b>	Displays the current DHCP server configuration.

# clear configure dhcprelay

To clear all of the DHCP relay configuration, use the **clear configure dhcprelay** command in global configuration mode.

**clear configure dhcprelay**

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	—	•	•	—

Release	Modification
3.1(1)	This command was introduced.

**Usage Guidelines** The **clear configure dhcprelay** command clears the DHCP relay statistics and configuration. To clear only the DHCP statistic counters, use the **clear dhcprelay statistics** command.

**Examples** The following example shows how to clear the DHCP relay configuration:

```
hostname(config)# clear configure dhcprelay
```

Related Commands	Command	Description
	<b>clear dhcprelay statistics</b>	Clears the DHCP relay agent statistic counters.
	<b>debug dhcprelay</b>	Displays debug information for the DHCP relay agent.
	<b>show dhcprelay statistics</b>	Displays DHCP relay agent statistic information.
	<b>show running-config dhcprelay</b>	Displays the current DHCP relay agent configuration.

# clear configure dns

To clear all DNS commands, use the **clear configure dns** command in global configuration mode.

**clear configure dns**

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	—

Release	Modification
3.1(1)	This command was introduced.

**Command History**

**Examples** The following example clears all DNS commands:

```
hostname(config)# clear configure dns
```

Related Commands	Command	Description
	<b>dns domain-lookup</b>	Enables the FWSM to perform a name lookup.
	<b>dns name-server</b>	Configures a DNS server address.
	<b>dns retries</b>	Specifies the number of times to retry the list of DNS servers when the FWSM does not receive a response.
	<b>dns timeout</b>	Specifies the amount of time to wait before trying the next DNS server.
	<b>show dns-hosts</b>	Shows the DNS cache.

# clear configure established

To remove all established commands, use the **clear configure established** command in global configuration mode.

## clear configure established

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	•

Command History	Release	Modification
	1.1(1)	This command was introduced.
	3.1(1)	This command was changed from <b>clear established</b> .

**Usage Guidelines** To remove an established connection created by the **established** command, enter the **clear local-hosts** command.

**Examples** The following example shows how to remove established commands:

```
hostname(config)# clear configure established
```

Related Commands	Command	Description
	<b>established</b>	Permits return connections on ports that are based on an established connection.
	<b>show running-config established</b>	Displays the allowed inbound connections that are based on established connections.
	<b>clear local-hosts</b>	Clears the current connections.

# clear configure failover

To remove **failover** commands from the configuration and restore the defaults, use the **clear configure failover** command in global configuration mode.

**clear configure failover**

## Syntax Description

This command has no arguments or keywords.

## Defaults

No default behavior or values.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	•

## Command History

Release	Modification
1.1(1)	This command was introduced (as <b>clear failover</b> ).
3.1(1)	Command was changed from <b>clear failover</b> to <b>clear configure failover</b> .

## Usage Guidelines

This command clears all **failover** commands from the running configuration and restores the defaults. If you use the **all** keyword with the **show running-config failover** command, you will see the default failover configuration.

The **clear configure failover** command is not available in a security context in multiple configuration mode; you must enter the command in the system execution space.

## Examples

The following example clears all failover commands from the configuration:

```
hostname(config)# clear configure failover
hostname(config)# show running-configuration failover
no failover
```

## Related Commands

Command	Description
<b>show running-config failover</b>	Displays the <b>failover</b> commands in the running configuration.



# clear configure filter

To clear URL, FTP, and HTTPS filtering configuration, use the **clear configure filter** command in global configuration mode.

## clear configure filter

### Defaults

No default behavior or values.

### Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	•

### Command History

Release	Modification
1.1(1)	This command was introduced.
3.1(1)	This command was changed from <b>clear filter</b> .

### Usage Guidelines

The **clear configure filter** command clears the URL, FTP, and HTTPS filtering configuration.

### Examples

The following example clears the URL, FTP, and HTTPS filtering configuration:

```
hostname# clear configure filter
```

### Related Commands

Commands	Description
<b>filter ftp</b>	Identifies the FTP traffic to be filtered by a URL filtering server.
<b>filter https</b>	Identifies the HTTPS traffic to be filtered by a Websense server.
<b>filter url</b>	Directs traffic to a URL filtering server.
<b>show running-config filter</b>	Displays the filtering configuration.
<b>url-server</b>	Identifies an N2H2 or Websense server for use with the <b>filter</b> command.

# clear configure firewall

To set the firewall mode to the default routed mode, use the **clear configure firewall** command in global configuration mode.

## clear configure firewall

### Syntax Description

This command has no arguments or keywords.

### Defaults

No default behavior or values.

### Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	—

### Command History

Release	Modification
2.2(1)	This command was introduced.
3.1(1)	In multiple context mode, you can enter this command within a context only. Previously, you entered it in the system execution space. This command was also changed from <b>clear firewall</b> .

### Examples

The following example sets the firewall mode to the default:

```
hostname(config)# clear configure firewall
```

### Related Commands

Command	Description
<b>arp</b>	Adds a static ARP entry.
<b>firewall transparent</b>	Sets the firewall mode to transparent.
<b>show arp statistics</b>	Shows ARP statistics.
<b>show running-config arp</b>	Shows the current configuration of the ARP timeout.

# clear configure fixup

To clear the fixup configuration, use the **clear configure fixup** command in global configuration mode.

## clear configure fixup

### Defaults

No default behavior or values.

### Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	•

### Command History

Release	Modification
1.1(1)	The <b>clear fixup</b> command was introduced.
3.1(1)	This command was changed from <b>clear fixup</b> .

### Usage Guidelines

The **clear configure fixup** command removes the fixup configuration.

### Examples

The following example clears the fixup configuration:

```
hostname# clear configure fixup
```

### Related Commands

Commands	Description
<b>class-map</b>	Defines the traffic class to which to apply security actions.
<b>policy-map</b>	Associates a class map with specific security actions.

# clear configure fragment

To reset all the IP fragment reassembly configurations to defaults, use the **clear configure fragment** command in global configuration mode.

**clear configure fragment** [*interface*]

## Syntax Description

*interface* (Optional) Specifies the FWSM interface.

## Defaults

If an *interface* is not specified, the command applies to all interfaces.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	—

## Command History

Release	Modification
1.1(1)	The <b>clear fragment</b> command was introduced.
3.1(1)	The <b>configure</b> keyword and optional <i>interface</i> argument were added. The command was also separated into two commands, <b>clear fragment</b> and <b>clear configure fragment</b> , to separate clearing of the configuration data from the operational data.

## Usage Guidelines

The **clear configure fragment** command resets all the IP fragment reassembly configurations to defaults. In addition, the the **chain**, **size**, and **timeout** keywords are reset to their default values, which are as follows:

- **chain** is 24 packets
- **size** is 200
- **timeout** is 5 seconds

**Examples**

The following example shows how to reset all the IP fragment reassembly configurations to defaults:

```
hostname(config)# clear configure fragment
```

**Related Commands**

Command	Description
<b>clear fragment</b>	Clears the operational data of the IP fragment reassembly module.
<b>fragment</b>	Provides additional management of packet fragmentation and improves compatibility with NFS.
<b>show fragment</b>	Displays the operational data of the IP fragment reassembly module.
<b>show running-config fragment</b>	Displays the IP fragment reassembly configuration.

# clear configure ftp

To clear the FTP configuration, use the **clear configure ftp** command in global configuration mode.

**clear configure ftp**

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	•

Release	Modification
3.1(1)	This command was introduced.

**Usage Guidelines** The **clear configure ftp** command clears the FTP configuration.

**Examples** The following example clears the FTP configuration:

```
hostname# clear configure filter
```

Commands	Description
<b>filter ftp</b>	Identifies the FTP traffic to be filtered by a URL filtering server.
<b>filter https</b>	Identifies the HTTPS traffic to be filtered by a Websense server.
<b>filter url</b>	Directs traffic to a URL filtering server.
<b>show running-config filter</b>	Displays the filtering configuration.
<b>url-server</b>	Identifies an N2H2 or Websense server for use with the <b>filter</b> command.

# clear configure ftp-map

To clear the FTP map configuration, use the **clear configure ftp-map** command in global configuration mode.

## clear configure ftp-map

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	•

Release	Modification
3.1(1)	This command was introduced.

**Usage Guidelines** The **clear configure ftp-map** command removes the FTP map configuration.

**Examples** The following example clears the FTP map configuration:

```
hostname# clear configure ftp-map
```

Related Commands	Commands	Description
	<b>class-map</b>	Defines the traffic class to which to apply security actions.
	<b>ftp-map</b>	Defines an FTP map and enables ftp map configuration mode.
	<b>inspect ftp</b>	Applies a specific FTP map to use for application inspection.
	<b>request-command deny</b>	Specifies FTP commands to disallow.

# clear configure global

To remove the **global** commands from the configuration, use the **clear configure global** command in global configuration mode.

**clear configure global**

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	—	•	•	—

Release	Modification
1.1(1)	This command was introduced.
3.1(1)	This command was changed from <b>clear global</b> .

**Examples** The following example shows how to remove the **global** commands from the configuration:

```
hostname(config)# clear configure global
```

Command	Description
<b>global</b>	Creates entries from a pool of global addresses.
<b>show running-config global</b>	Displays the <b>global</b> commands in the configuration.



# clear configure group-policy

To remove the configuration for a particular group policy, use the **clear configure group-policy** command in global configuration mode, and append the name of the group policy. To remove all group-policy commands from the configuration except the default group policy, use this command without arguments.

**clear configure group-policy** [*name*]

## Syntax Description

*name* Specifies the name of the group policy.

## Defaults

Remove all group-policy commands from the configuration, except the default group policy.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	—	•	—	—

## Command History

Release	Modification
3.1(1)	This command was introduced.

## Examples

The following example shows how to clear the configuration for the group policy named FirstGroup.

```
hostname(config)# clear configure group-policy FirstGroup
```

## Related Commands

Command	Description
<b>group-policy</b>	Creates, edits, or removes a group policy.
<b>group-policy attributes</b>	Enters group-policy attributes mode, which lets you configure AVPs for a specified group policy.
<b>show running-config group-policy</b>	Displays the running configuration for a particular group policy or for all group policies.

# clear configure gtp-map

To clear GTP map configuration, use the **clear configure gtp-map** command in global configuration mode.

## clear configure gtp-map

### Defaults

No default behavior or values.

### Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	•

### Command History

Release	Modification
3.1(1)	This command was introduced.

### Usage Guidelines

The **clear configure gtp-map** command removes the GTP map configuration.

### Examples

The following example clears GTP map configuration:

```
hostname# clear configure gtp-map
```

### Related Commands

Commands	Description
<b>clear service-policy inspect gtp</b>	Clears global GTP statistics.
<b>debug gtp</b>	Displays detailed information about GTP inspection.
<b>gtp-map</b>	Defines a GTP map and enables GTP map configuration mode.
<b>inspect gtp</b>	Applies a specific GTP map to use for application inspection.
<b>show service-policy inspect gtp</b>	Displays the GTP configuration.

# clear configure hostname

To reset the hostname to the default, use the **clear configure hostname** command in global configuration mode.

## clear configure hostname

### Syntax Description

This command has no arguments or keywords.

### Defaults

The default hostname is FWSM.

### Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	—

### Command History

Release	Modification
1.1(1)	This command was introduced.
3.1(1)	The <b>configure</b> keyword was added.

### Examples

The following example clears the hostname:

```
hostname(config)# clear configure hostname
```

### Related Commands

Command	Description
<b>banner</b>	Sets a login, message of the day, or enable banner.
<b>domain-name</b>	Sets the default domain name.
<b>hostname</b>	Sets the hostname for the FWSM.

# clear configure http

To disable the HTTP server and to remove configured hosts that can access the HTTP server, use the **clear configure http** command in global configuration mode.

**clear configure http**

## Defaults

No default behavior or values.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	—	•	—	—

## Command History

Release	Modification
Preexisting	This command was preexisting.

## Examples

The following example shows how to clear the HTTP configuration.

```
hostname(config)# clear configure http
```

## Related Commands

Command	Description
<b>http</b>	Specifies hosts that can access the HTTP server by IP address and subnet mask. Specifies the FWSM interface through which the host accesses the HTTP server.
<b>http authentication-certificate</b>	Requires authentication via certificate from users who are establishing HTTPS connections to the FWSM.
<b>http server enable</b>	Enables the HTTP server.
<b>show running-config http</b>	Displays the hosts that can access the HTTP server, and whether or not the HTTP server is enabled.

# clear configure http-map

To clear HTTP map configuration, use the **clear configure http-map** command in global configuration mode.

## clear configure http-map

### Defaults

No default behavior or values.

### Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	•

### Command History

Release	Modification
3.1(1)	This command was introduced.

### Usage Guidelines

The **clear configure http-map** command removes the HTTP map configuration.

### Examples

The following example clears the HTTP map configuration:

```
hostname# clear configure http-map
```

### Related Commands

Commands	Description
<b>class-map</b>	Defines the traffic class to which to apply security actions.
<b>debug http-map</b>	Displays detailed information about traffic associated with an HTTP map.
<b>http-map</b>	Defines an HTTP map for configuring enhanced HTTP inspection.
<b>inspect http</b>	Applies a specific HTTP map to use for application inspection.
<b>policy-map</b>	Associates a class map with specific security actions.

# clear configure icmp

To clear the configured access rules for ICMP traffic, use the **clear configure icmp** command in global configuration mode.

## clear configure icmp

### Defaults

No default behavior or values.

### Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	•

### Command History

Release	Modification
3.1(1)	Support for this command was introduced.

### Usage Guidelines

The **clear configure icmp** command clears the configured access rules for ICMP traffic.

### Examples

The following example clears the clear configured access rules for ICMP traffic:

```
hostname# clear configure icmp
```

### Related Commands

Commands	Description
<b>clear configure icmp</b>	Clears the ICMP configuration.
<b>debug icmp</b>	Enables the display of debug information for ICMP.
<b>show icmp</b>	Displays ICMP configuration.
<b>timeout icmp</b>	Configures the idle timeout for ICMP.

# clear configure interface

To clear the interface configuration, use the **clear configure interface** command in global configuration mode.

**clear configure interface**[*mapped\_name* | *interface\_name*]

## Syntax Description

<i>interface_name</i>	(Optional) Identifies the interface name set with the <b>nameif</b> command.
<i>mapped_name</i>	(Optional) In multiple context mode, identifies the mapped name if it was assigned using the <b>allocate-interface</b> command.

## Defaults

If you do not specify an interface, the FWSM clears all interface configuration.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	•

## Command History

Release	Modification
3.1(1)	This command was introduced.

## Usage Guidelines

You cannot use the interface name in the system execution space, because the **nameif** command is only available within a context. Similarly, if you mapped the interface ID to a mapped name using the **allocate-interface** command, you can only use the mapped name in a context.

## Examples

The following example clears the interface configuration:

```
hostname(config)# clear configure interface
```

The following example clears the inside interface configuration:

```
hostname(config)# clear configure interface inside
```

The following example clears the int1 interface configuration in a context. “int1” is a mapped name.

```
hostname/contexta(config)# clear configure interface int1
```

The following example clears all interface configuration.

```
hostname(config)# clear configure interface
```

Related Commands	Command	Description
	<b>allocate-interface</b>	Assigns interfaces and subinterfaces to a security context.
	<b>clear interface</b>	Clears counters for the <b>show interface</b> command.
	<b>interface</b>	Configures an interface and enters interface configuration mode.
	<b>show interface</b>	Displays the runtime status and statistics of interfaces.



# clear configure interface bvi

To clear the bridge virtual interface configuration, use the **clear configure interface bvi** command in global configuration mode.

**clear configure interface bvi** *bridge\_group\_number*

## Syntax Description

*bridge\_group\_number* Specifies the bridge group number as an integer between 1 and 100.

## Defaults

No default behavior or values.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	—	•	•	•	—

## Command History

Release	Modification
3.1(1)	This command was introduced.

## Examples

The following example clears the interface configuration for bridge group 1:

```
hostname(config)# clear configure interface bvi 1
```

## Related Commands

Command	Description
<b>bridge-group</b>	Groups two transparent firewall interfaces into a bridge group.
<b>interface</b>	Configures an interface.
<b>interface bvi</b>	Enters the interface configuration mode for a bridge group so you can set the management IP address.
<b>ip address</b>	Sets the management IP address for a bridge group.
<b>show running-config interface bvi</b>	Shows the bridge group interface configuration.

# clear configure ip

To clear all IP addresses set by the **ip address** command, use the **clear configure ip** command in global configuration mode.

## clear configure ip

### Syntax Description

This command has no arguments or keywords.

### Defaults

No default behavior or values.

### Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	—

### Command History

Release	Modification
3.1(1)	This command was introduced.

### Usage Guidelines

In transparent firewall mode, this command clears the management IP address for the bridge groups.

If you want to stop all current connections that use the old IP addresses, enter the **clear local-hosts** command. Otherwise, the connections time out as usual.

### Examples

The following example clears all IP addresses:

```
hostname(config)# clear configure ip
```

### Related Commands

Command	Description
<b>allocate-interface</b>	Assigns interfaces and subinterfaces to a security context.
<b>clear configure interface</b>	Clears all configuration for an interface.
<b>interface</b>	Configures an interface and enters interface configuration mode.
<b>ip address</b>	Sets the IP address for the interface.
<b>show running-config interface</b>	Displays the interface configuration.

# clear configure ip local pool

To remove IP address pools, use the **clear configure ip local pool** command in global configuration mode.

**clear ip local pool** [*poolname*]

## Syntax Description

*poolname* (Optional) Specifies the name of the IP address pool.

## Defaults

No default behavior or values.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	—	•	—	—

## Command History

Release	Modification
3.1(1)	Support for this command was introduced.

## Examples

The following example removes all IP address pools from the running configuration:

```
hostname(config)# clear config ip local pool
hostname(config)#
```

## Related Commands

Command	Description
<b>clear configure ip local pool</b>	Removes all ip local pools.
<b>ip local pool</b>	Configures an IP address pool.

# clear configure ip verify reverse-path

To clear the **ip verify reverse-path** configuration, use the **clear configure ip verify reverse-path** command in global configuration mode.

## clear configure ip verify reverse-path

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	—	•	•	—

Release	Modification
1.1(1)	The <b>clear ip verify reverse-path</b> command was introduced.
3.1(1)	This command was changed to <b>clear configure ip verify reverse-path</b> .

**Examples** The following example clears the **ip verify reverse-path** configuration for all interfaces:

```
hostname(config)# clear configure ip verify reverse-path
```

Command	Description
<b>clear ip verify statistics</b>	Clears the Unicast RPF statistics.
<b>ip verify reverse-path</b>	Enables the Unicast Reverse Path Forwarding feature to prevent IP spoofing.
<b>show ip verify statistics</b>	Shows the Unicast RPF statistics.
<b>show running-config ip verify reverse-path</b>	Shows the <b>ip verify reverse-path</b> configuration.

# clear configure ipv6

To clear the global IPv6 commands from the running configuration, use the **clear configure ipv6** command in global configuration mode.

**clear configure ipv6** [**route** | **access-list**]

## Syntax Description

<b>route</b>	(Optional) Clears the commands that statically define routes in the IPv6 routing table from the running configuration.
<b>access-list</b>	(Optional) Clears the IPv6 access list commands from the running configuration.

## Defaults

Without keywords, this command clears all IPv6 commands from the running configuration.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	—	•	•	—

## Command History

Release	Modification
3.1(1)	This command was introduced.

## Usage Guidelines

This command only clears the global IPv6 commands from the running configuration; it does not clear the IPv6 commands entered in interface configuration mode.

## Examples

The following example shows how to clear statically defined IPv6 routes from the IPv6 routing table:

```
hostname(config)# clear configure ipv6 route
hostname(config)#
```

## Related Commands

Command	Description
<b>ipv6 route</b>	Defines a static route in the IPv6 routing table.
<b>show ipv6 route</b>	Displays the contents of the IPv6 routing table.
<b>show running-config ipv6</b>	Displays the IPv6 commands in the running configuration.

# clear configure isakmp

To remove all of the ISAKMP configuration, use the **clear configure isakmp** command in global configuration mode.

**clear configure isakmp**

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	—

Release	Modification
3.1(1)	This command was introduced.

**Examples** The following example issued in global configuration mode, removes all of the ISAKMP configuration from the FWSM:

```
hostname(config)# clear configure isakmp
hostname(config)#
```

Related Commands	Command	Description
	<b>clear configure isakmp policy</b>	Clears all ISAKMP policy configuration.
	<b>isakmp enable</b>	Enables ISAKMP negotiation on the interface on which the IPSec peer communicates with the FWSM.
	<b>show isakmp stats</b>	Displays runtime statistics.
	<b>show isakmp sa</b>	Displays IKE runtime SA database with additional information.
	<b>show running-config isakmp</b>	Displays all the active configuration.

# clear configure isakmp policy

To remove all of the ISAKMP policy configuration, use the **clear configure isakmp policy** command in global configuration mode.

**clear configure isakmp policy** *priority*

## Syntax Description

*priority* Specifies the priority of the ISAKMP priority to be cleared.

## Defaults

No default behavior or values.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	—

## Command History

Release	Modification
3.1(1)	This command was introduced.

## Examples

The following example removes the ISAKMP policy with priority 3 from the configuration:

```
hostname(config)# clear configure isakmp policy 3
hostname(config)#
```

## Related Commands

Command	Description
<b>isakmp enable</b>	Enables ISAKMP negotiation on the interface on which the IPSec peer communicates with the FWSM.
<b>show isakmp stats</b>	Displays runtime statistics.
<b>show isakmp sa</b>	Displays IKE runtime SA database with additional information.
<b>show running-config isakmp</b>	Displays all the active configuration.

# clear configure logging

To clear the logging configuration, use the **clear configure logging** command in global configuration mode.

**clear configure logging** [**disabled** | **level**]

## Syntax Description

<b>disabled</b>	(Optional) Indicates that all disabled system log messages should be reenabled. When you use this option, no other logging configuration is cleared.
<b>level</b>	(Optional) Indicates that the severity level assignments for system log messages should be reset to their default values. When you use this option, no other logging configuration is cleared.

## Defaults

No default behavior or values.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	•

## Command History

Release	Modification
3.1(1)	This command was introduced.

## Usage Guidelines

You can use the **show running-config logging** command to view all logging configuration settings. If you use the **clear configure logging** command without either the **disabled** or **level** keyword, all logging configuration settings are cleared.

## Examples

The following example shows how to clear logging configuration. The output of the **show logging** command indicates that all logging features are disabled.

```
hostname(config)# clear configure logging
hostname(config)# show logging
Syslog logging: disabled
  Facility: 20
  Timestamp logging: disabled
  Standby logging: disabled
  Deny Conn when Queue Full: disabled
  Console logging: disabled
  Monitor logging: disabled
  Buffer logging: disabled
  Trap logging: disabled
```



```
History logging: disabled
Device ID: disabled
Mail logging: disabled
ASDM logging: disabled
```

**Related Commands**

Command	Description
<b>show logging</b>	Displays the enabled logging options.
<b>show running-config logging</b>	Displays the logging-related portion of the running configuration.

# clear configure logging rate-limit

To reset the logging rate limit, use the **clear configure logging rate-limit** command in global configuration mode.

**clear configure logging rate-limit**

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	—

Release	Modification
3.1(1)	This command was introduced.

**Examples** The following example shows how to reset the logging rate limit:

```
hostname(config)# clear configure logging rate-limit
```

After the information is cleared, nothing more displays until the hosts reestablish their connections.

Related Commands	Command	Description
	<b>logging rate limit</b>	Limits the rate at which system log messages are generated.
	<b>show running config logging rate-limit</b>	Shows the current logging rate limit setting.

# clear configure mac-address-table

To clear the **mac-address-table static** and **mac-address-table aging-time** configuration, use the **clear configure mac-address-table** command in global configuration mode.

**clear configure mac-address-table**

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	—	•	•	•	—

Command History	Release	Modification
	3.1(1)	This command was introduced.

**Examples** The following example clears the **mac-address-table static** and **mac-address-table aging-time** configuration:

```
hostname# clear configure mac-address-table
```

Related Commands	Command	Description
	<b>firewall transparent</b>	Sets the firewall mode to transparent.
	<b>mac-address-table aging-time</b>	Sets the timeout for dynamic MAC address entries.
	<b>mac-address-table static</b>	Adds static MAC address entries to the MAC address table.
	<b>mac-learn</b>	Disables MAC address learning for an interface.
	<b>show mac-address-table</b>	Shows the MAC address table, including dynamic and static entries.

# clear configure mac-learn

To clear the **mac-learn** configuration, use the **clear configure mac-learn** command in global configuration mode.

**clear configure mac-learn**

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	—	•	•	•	—

Release	Modification
2.2(1)	This command was introduced.
3.1(1)	This command was changed from <b>clear mac-learn</b> .

**Examples** The following example clears the **mac-learn** configuration:

```
hostname# clear configure mac-learn
```

Command	Description
<b>firewall transparent</b>	Sets the firewall mode to transparent.
<b>mac-address-table static</b>	Adds static MAC address entries to the MAC address table.
<b>mac-learn</b>	Disables MAC address learning for an interface.
<b>show mac-address-table</b>	Shows the MAC address table, including dynamic and static entries.

# clear configure mac-list

To remove the indicated list of MAC addresses, previously specified the **mac-list** command, use the **clear configure mac-list** command in global configuration mode:

**clear configure mac-list** *id*

## Syntax Description

*id* A MAC address list name.

## Defaults

No default behaviors or values.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	—	—	•

## Command History

Release	Modification
3.1(1)	This command was introduced.

## Usage Guidelines

To remove a list of MAC addresses, use the **clear mac-list** command.

## Examples

The following example shows how to clear a MAC address list:

```
hostname(config)# clear configure mac-list firstmaclist
```

## Related Commands

Command	Description
<b>mac-list</b>	Adds a list of MAC addresses using a first-match search.
<b>show running-config mac-list</b>	Displays the MAC addresses in the MAC address list indicated by the <i>id</i> value.

# clear configure management-access

To remove the configuration of an internal interface for management access of the FWSM, use the **clear configure management-access** command in global configuration mode.

**clear configure management-access**

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	•

Release	Modification
3.1(1)	The keyword <b>configure</b> was added.

**Usage Guidelines** The **management-access** command lets you define an internal management interface using the IP address of the firewall interface specified in *mgmt\_if*. (The interface names are defined by the **nameif** command and displayed in quotes, “ ”, in the output of the **show interface** command.) The **clear configure management-access** command removes the configuration of the internal management interface specified with the **management-access** command.

**Examples** The following example removes the configuration of an internal interface for management access of the FWSM:

```
hostname(config)# clear configure management-access
```

Command	Description
<b>management-access</b>	Configures an internal interface for management access.
<b>show running-config management-access</b>	Displays the name of the internal interface configured for management access.

# clear configure mgcp-map

To clear the MGCP map configuration, use the **clear configure mgcp-map** command in global configuration mode.

## clear configure mgcp-map

### Defaults

No default behavior or values.

### Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	•

### Command History

Release	Modification
3.1(1)	This command was introduced.

### Usage Guidelines

The **clear configure mgcp-map** clears the MGCP map configuration.

### Examples

The following example clears clear the MGCP map configuration:

```
hostname# clear configure mgcp-map
```

### Related Commands

Commands	Description
<b>debug mgcp</b>	Enables MGCP debug information.
<b>mgcp-map</b>	Defines an MGCP map and enables MGCP map configuration mode.
<b>show conn</b>	Displays the connection state for different connection types.
<b>show mgcp</b>	Displays information about MGCP sessions established through the FWSM.

# clear configure monitor-interface

To remove all **monitor-interface** commands from the running configuration and restore the default interface health monitoring, use the **clear configure monitor-interface** command in global configuration mode.

## clear configure monitor-interface

### Syntax Description

This command has no arguments or keywords.

### Defaults

No default behavior or values.

### Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	—

### Command History

Release	Modification
2.2(1)	This command was introduced.

### Usage Guidelines

By default, virtual interfaces are not monitored for failover. Using the **clear monitor-interface** command clears the **monitor-interface** commands from the running configuration. To view the **monitor-interface** commands in the running configuration, use the **show running-config monitor-interface** command.

### Examples

The following example clears the **monitor-interface** commands from the running configuration:

```
hostname(config)# clear configure monitor-interface
hostname(config)#
```

### Related Commands

Command	Description
<b>monitor-interface</b>	Enables health monitoring of a designated interface for failover purposes.
<b>show running-config monitor-interface</b>	Displays the <b>monitor-interface</b> commands in the running configuration.



# clear configure mroute

To remove the **mroute** commands from the running configuration, use the **clear configure mroute** command in global configuration mode.

## clear configure mroute

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	—

Release	Modification
3.1(1)	This command was introduced.

**Examples** The following example shows how to remove the **mroute** commands from the configuration:

```
hostname(config)# clear configure mroute
hostname(config)#
```

Command	Description
<b>mroute</b>	Configures a static multicast route.
<b>show mroute</b>	Displays IPv4 multicast routing table.
<b>show running-config mroute</b>	Displays configured multicast routes.

# clear configure mtu

To clear the configured maximum transmission unit values on all interfaces, use the **clear configure mtu** command in global configuration mode.

## clear configure mtu

### Syntax Description

This command has no arguments or keywords.

### Defaults

Using the **clear configure mtu command** sets the maximum transmission unit to the default of 1500 for all Ethernet interfaces.

### Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	—	•	•	•	—

### Command History

Release	Modification
3.1(1)	This command was introduced.

### Examples

The following example clears the current maximum transmission unit values on all interfaces:

```
hostname(config)# clear configure mtu
```

### Related Commands

Command	Description
<b>mtu</b>	Specifies the maximum transmission unit for an interface.
<b>show running-config mtu</b>	Displays the current maximum transmission unit block size.

# clear configure multicast-routing

To remove the **multicast-routing** command from the running configuration, use the **clear configure multicast-routing** command in global configuration mode.

## clear configure multicast-routing

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	—	•	—	—

Command History	Release	Modification
	3.1(1)	This command was introduced.

**Usage Guidelines** The **clear configure multicast-routing** command removes the **multicast-routing** from the running configuration. The **no multicast-routing** command also removes the multicast-routing command from the running configuration.

**Examples** The following example shows how to remove the **multicast-routing** command from the running configuration:

```
hostname(config)# clear configure multicast-routing
```

Related Commands	Command	Description
	<b>multicast-routing</b>	Enables multicast routing on the FWSM.

# clear configure name

To clear the list of names from the configuration, use the **clear configure name** command in global configuration mode.

## clear configure name

### Syntax Description

This command has no arguments or keywords.

### Defaults

No default behavior or values.

### Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	—

### Command History

Release	Modification
1.1(1)	The <b>clear name</b> command was introduced.
3.1(1)	This command was changed to <b>clear configure name</b> .

### Examples

The following example shows how to clear the name list:

```
hostname(config)# clear configure name
```

### Related Commands

Command	Description
<b>name</b>	Associates a name with an IP address.
<b>show running-config name</b>	Displays the list of names associated with IP addresses.

# clear configure nat

To remove the NAT configuration, use the **clear configure nat** command in privileged EXEC mode.

## clear configure nat

### Syntax Description

This command has no arguments or keywords.

### Defaults

No default behavior or values.

### Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Privileged EXEC	•	—	•	•	—

### Command History

Release	Modification
1.1(1)	This command was introduced.
2.2(1)	This command was modified to support UDP maximum connections for local hosts.
3.1(1)	This command was changed from <b>clear nat</b> .

### Usage Guidelines

The following applies to transparent firewall mode:



#### Note

In transparent firewall mode, only NAT id 0 is valid.

### Examples

The following example shows how to remove the NAT configuration:

```
hostname(config)# clear configure nat
```

### Related Commands

Command	Description
<b>nat</b>	Associates a network with a pool of global IP addresses.
<b>show running-config nat</b>	Displays a pool of global IP addresses that are associated with the network.

# clear configure nat-control

To disable the NAT configuration requirement, use the **clear configure nat-control** command in global configuration mode.

## clear configure nat-control

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	—	•	•	—

Release	Modification
3.1(1)	This command was introduced.

**Examples** The following example disables the NAT configuration requirement:

```
hostname(config)# clear configure nat-control
```

Related Commands	Command	Description
	<b>nat</b>	Defines an address on one interface that is translated to a global address on another interface.
	<b>nat-control</b>	Enforces NAT control. Disabling NAT control allows inside hosts to communicate with outside networks without configuring a NAT rule.
	<b>show running-config nat-control</b>	Displays the NAT configuration requirement.

# clear configure object-group

To remove all the **object group** commands from the configuration, use the **clear configure object-group** command in global configuration mode.

**clear configure object-group** [{**protocol** | **service** | **icmp-type** | **network**}]

## Syntax Description

<b>icmp-type</b>	(Optional) Clears all ICMP groups.
<b>network</b>	(Optional) Clears all network groups.
<b>protocol</b>	(Optional) Clears all protocol groups.
<b>service</b>	(Optional) Clears all service groups.

## Defaults

No default behavior or values.

## Command Modes

The following table shows the modes in which you can enter the command:

	Firewall Mode		Security Context		
				Multiple	
Command Mode	Routed	Transparent	Single	Context	System
Global configuration	•	•	•	•	—

## Command History

Release	Modification
1.1(1)	This command was introduced.
3.1(1)	This command was changed from <b>clear object-group</b> .

## Examples

The following example shows how to remove all the **object-group** commands from the configuration:

```
hostname(config)# clear configure object-group
```

## Related Commands

Command	Description
<b>group-object</b>	Adds network object groups.
<b>network-object</b>	Adds a network object to a network object group.
<b>object-group</b>	Defines object groups to optimize your configuration.
<b>port-object</b>	Adds a port object to a service object group.
<b>show running-config object-group</b>	Displays the current object groups.

# clear configure pager

To remove the number of lines set to display in a Telnet session before the “---More---” prompt appears from the running configuration, use the **clear configure pager** command in global configuration mode.

## clear configure pager

### Syntax Description

This command has no arguments or keywords.

### Defaults

No default behavior or values.

### Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	—

### Command History

Release	Modification
4.0(1)	This command was introduced.

### Examples

The following example shows how to remove the number of lines set to display in a Telnet session before the “---More---” prompt appears from the running configuration:

```
hostname(config)# clear configure pager
hostname(config)#
```

### Related Commands

Command	Description
<b>show pager</b>	Displays the default number of lines set to display in a Telnet session before the “---More---” prompt appears.
<b>show running-config pager</b>	Displays the number of lines set to display in a Telnet session before the “---More---” prompt appears in the running configuration.
<b>terminal pager</b>	Sets the number of lines to display in a Telnet session before the “---More---” prompt appears. This command is not saved to the running configuration.



# clear configure passwd

To clear the login password configuration and restore the default setting of “cisco,” use the **clear configure passwd** command in global configuration mode.

**clear configure {passwd | password}**

## Syntax Description

**passwd | password** You can enter either command; they are aliased to each other.

## Defaults

No default behavior or values.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	•

## Command History

Release	Modification
1.1(1)	The <b>clear passwd</b> command was introduced.
3.1(1)	This command was changed to <b>clear configure passwd</b> .

## Examples

The following example clears the login password and restores it to the default of “cisco”:

```
hostname(config)# clear configure passwd
```

## Related Commands

Command	Description
<b>enable</b>	Enters privileged EXEC mode.
<b>enable password</b>	Sets the enable password.
<b>passwd</b>	Sets the login password.
<b>show curpriv</b>	Shows the currently logged in username and the user privilege level.
<b>show running-config passwd</b>	Shows the login password in encrypted form.

# clear configure pim

To clear all of the global **pim** commands from the running configuration, use the **clear configure pim** command in global configuration mode.

## clear configure pim

### Syntax Description

This command has no arguments or keywords.

### Defaults

No default behavior or values.

### Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	—	•	—	—

### Command History

Release	Modification
3.1(1)	This command was introduced.

### Usage Guidelines

The **clear configure pim** command clears all of the **pim** commands from the running configuration. To clear PIM traffic counters and topology information, use the **clear pim counters** and the **clear pim topology** commands.

The **clear configure pim** command only clears the **pim** commands entered in global configuration mode; it does not clear the interface-specific **pim** commands.

### Examples

The following example shows how to clear all **pim** commands from the running configuration:

```
hostname(config)# clear configure pim
```

### Related Commands

Command	Description
<b>clear pim topology</b>	Clears the PIM topology table.
<b>clear pim counters</b>	Clears the PIM traffic counters.
<b>show running-config pim</b>	Displays the <b>pim</b> commands in the running configuration.

# clear configure policy-map

To remove all **policy-map** commands, use the **clear configure policy-map** command in global configuration mode.

**clear configure policy-map** [**type inspect** [*protocol*]]

<b>Syntax Description</b>	<i>protocol</i>	(Optional) Specifies the type of inspection policy map you want to clear. Available types include: <ul style="list-style-type: none"> <li>• <b>dcerpc</b></li> <li>• <b>esmtplib</b></li> <li>• <b>http</b></li> <li>• <b>sip</b></li> </ul>
	<b>type inspect</b>	(Optional) Clears inspection policy maps.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	—

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	3.1(1)	This command was introduced.
	4.0(1)	The <b>type</b> keyword was added.

**Usage Guidelines** To clear the policy map for a specific policy map name, use the **no** form of the **policy-map** command.

**Examples** The following example shows the **clear configure policy-map** command:

```
hostname(config)# clear configure policy-map
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>

<b>policy-map</b>	Configures a policy; that is, an association of a traffic class and one or more actions.
<b>show running-config policy-map</b>	Displays the entire policy configuration.

# clear configure prefix-list

To remove the **prefix-list** commands from the running configuration, use the **clear configure prefix-list** command in global configuration mode.

**clear configure prefix-list** [*prefix-list-name*]

## Syntax Description

*prefix-list-name* (Optional) The name of a prefix list. When a prefix list name is specified, only the commands for that prefix list are removed from the configuration.

## Defaults

No default behavior or values.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	—	•	—	—

## Command History

Release	Modification
1.1(1)	This command was introduced (as <b>clear prefix-list</b> ).
3.1(1)	This command was changed from <b>clear prefix-list</b> to <b>clear configure prefix-list</b> .

## Usage Guidelines

The **clear configure prefix-list** command removes the **prefix-list** commands and the **prefix-list description** commands from the running configuration. If a prefix list name is specified, then the **prefix-list** command and **prefix-list description** command, if present, for that prefix list only are removed from the running configuration.

This command does not remove the **no prefix-list sequence** command from the running configuration.

## Examples

The following example removes all **prefix-list** commands from the running configuration for a prefix list named MyPrefixList:

```
hostname# clear configure prefix-list MyPrefixList
```

## Related Commands

Command	Description
<b>show running-config prefix-list</b>	Displays the <b>prefix-list</b> commands in the running configuration.

# clear configure privilege

To remove the configured privilege levels for commands, use the **clear configure privilege** command in global configuration mode.

## clear configure privilege

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	—

Release	Modification
1.1(1)	The <b>clear privilege</b> command was introduced.
3.1(1)	This command was changed from <b>clear privilege</b> .

**Usage Guidelines** There is no undo.

**Examples** The following example shows how to reset the configured privilege levels for the commands:

```
hostname(config)# clear configure privilege
```

Command	Description
<b>privilege</b>	Configures the command privilege levels.
<b>show curpriv</b>	Displays current privilege level
<b>show running-config privilege</b>	Displays privilege levels for commands.

# clear configure prompt

To clear the customized prompt, use the **clear configure prompt** command in global configuration mode.

## clear configure prompt

### Syntax Description

This command has no arguments or keywords.

### Defaults

The default prompt is the hostname. In multiple context mode, the hostname is followed by the current context name (*hostname/context*).

### Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	—	•

### Command History

Release	Modification
3.1(1)	This command was introduced.

### Examples

The following example clears the customized prompt:

```
hostname(config)# clear configure prompt
```

### Related Commands

Command	Description
<b>prompt</b>	Creates a customized prompt.
<b>show running-config prompt</b>	Displays the configured prompt.

# clear configure regex

To remove all regular expressions, use the **clear configure regex** command in global configuration mode.

## clear configure regex

### Syntax Description

This command has no arguments or keywords.

### Defaults

No default behavior or values.

### Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	—

### Command History

Release	Modification
4.0(1)	This command was introduced.

### Usage Guidelines

To clear the regular expression for a specific regular expression name, use the **no** form of the **regex** command.

### Examples

The following example shows how to clear all configured regular expressions:

```
hostname(config)# clear configure regex
```

### Related Commands

Command	Description
<b>class-map type regex</b>	Creates a regular expression class map.
<b>regex</b>	Creates a regular expression.
<b>show running-config regex</b>	Shows all regular expressions.
<b>test regex</b>	Tests a regular expression.



# clear configure resource partition

To clear the memory partition configuration, use the **clear configure resource partition** command in global configuration mode.

**clear configure resource partition** [*number*]

## Syntax Description

*number* (Optional) Specifies the partition number, between 0 and 11 by default. If you changed the number of partitions using the **resource acl-partition** command, the partition numbering starts with 0. So if you have 10 partitions, the partition numbers are 0 through 9.

## Defaults

Clears the configuration for all partitions if you do not specify a number.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	—	—	•

## Command History

Release	Modification
4.0(1)	This command was introduced.

## Examples

The following example clears the configuration for partition 0:

```
hostname(config)# clear configure resource partition 0
```

## Related Commands

Command	Description
<b>allocate-acl-partition</b>	Assigns a context to a specific memory partition.
<b>resource acl-partition</b>	Sets the total number of memory partitions.
<b>resource partition</b>	Customizes a memory partition.
<b>resource rule</b>	Reallocates rules between features globally for all partitions.
<b>rules</b>	Reallocates rules between features for a specific partition.
<b>show resource acl-partition</b>	Shows the current memory partition characteristics, including the sizes and allocated contexts.
<b>show resource partition</b>	Shows the memory partition sizes.
<b>show resource rule</b>	Shows the current allocation of rules.

Command	Description
<b>show running-config resource partition</b>	Shows the current memory partition configuration.
<b>size</b>	Changes the size of a memory partition.

# clear configure rip

To clear the **rip** commands from the running configuration, use the **clear configure rip** command in global configuration mode.

## clear configure rip

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	—	•	—	—

Command History	Release	Modification
	1.1(1)	This command was introduced (as <b>clear rip</b> ).
	3.1(1)	This command was changed from <b>clear rip</b> to <b>clear configure rip</b> .

**Usage Guidelines** The **clear configure rip** command removes all **rip** commands from the configuration. Use the **no** form of the commands to clear specific commands.

**Examples** The following example clears all RIP commands from the running configuration:

```
hostname(config)# clear configure rip
```

Related Commands	Command	Description
	<b>debug rip</b>	Displays debug information for RIP.
	<b>rip</b>	Configures RIP on the specified interface.
	<b>show running-config rip</b>	Displays the RIP commands in the running configuration.

# clear configure route-inject

To remove all the route-inject configurations, use the **clear configure route-inject** command in global configuration mode. The associated connected and static routes and NAT pools that were injected into the MSFC routing tables are also removed. You can remove the redistribute and route-inject configuration for the user context if you are in multi-mode or system context if you are in single routed mode.

## clear configure route-inject

### Syntax Description

This command has no arguments or keywords.

### Defaults

No default behavior or values.

### Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	—	•	• —	—

### Command History

Release	Modification
4.0(1)	This command was introduced.

### Usage Guidelines

Use the **clear configure route-inject** command in global configuration mode remove all the route-inject configurations. The associated connected and static routes and NAT pools that were injected into the MSFC routing tables are also removed.

The **route-inject** command is used to inject the connected and static routes and NAT pools configured on FWSM into the MSFC routing table.

### Examples

The following example shows how to remove the conditions for the route injection:

```
hostname(config)# clear configure route-inject
```

### Related Commands

Command	Description
<b>debug route-inject</b>	Enables debugging of the route-injections that have been configured on FWSM.
<b>route-inject</b>	Injects the connected and static routes and NAT pools configured on FWSM into the MSFC routing table.

Command	Description
<b>show route-inject</b>	Displays the routes and NAT pools that have been injected.
<b>show running-config route-inject</b>	Displays the route-injection running configuration.

# clear configure route-map

To remove all of the route maps, use the **clear configure route-map** command in global configuration mode.

## clear configure route-map

### Syntax Description

This command has no arguments or keywords.

### Defaults

No default behavior or values.

### Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	—	•	—	—

### Command History

Release	Modification
1.1(1)	This command was introduced (as <b>clear route-map</b> ).
3.1(1)	This command was changed from <b>clear route-map</b> to <b>clear configure route-map</b> .

### Usage Guidelines

Use the **clear configure route-map** command in global configuration mode to remove all **route-map** commands in the configuration. The **route-map** command is used to configure conditions of redistributing the routes from one routing protocol into another routing protocol.

To remove individual **route-map** commands, use the **no route-map** command.

### Examples

The following example shows how to remove the conditions of redistributing routes from one routing protocol into another routing protocol:

```
hostname(config)# clear configure route-map
```

### Related Commands

Command	Description
<b>route-map</b>	Defines the conditions for redistributing routes from one routing protocol into another.
<b>show running-config route-map</b>	Displays the information about the route map configuration.

# clear configure router

To clear all router commands from the running configuration, use the **clear configure router** command in global configuration mode.

**clear configure router** [**ospf** [*id*] | **bgp** [*as-num*]]

## Syntax Description

<i>as-num</i>	(Optional) The BGP autonomous system number.
<b>bgp</b> <i>as-num</i>	(Optional) Specifies that only BGP commands are removed from the configuration.
<i>id</i>	(Optional) The OSPF process ID.
<b>ospf</b>	(Optional) Specifies that only OSPF commands are removed from the configuration.

## Defaults

If no keywords are specified, all **router** and associated router configuration mode commands are cleared from the configuration.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	—	•	—	—

## Command History

Release	Modification
1.1(1)	This command was introduced (as <b>clear router</b> ).
3.1(1)	This command was changed from <b>clear router</b> to <b>clear configure router</b> .
3.2(1)	The <b>bgp</b> keyword was added.


## Examples

The following example clears all OSPF commands associated with OSPF process 1 from the running configuration:

```
hostname(config)# clear configure router ospf 1
hostname(config)#
```

The following example clears all BGP commands associated with the BGP routing process with the autonomous system number of 100:

```
hostname(config)# clear configure router bgp 100
hostname(config)#
```

 clear configure router

Related Commands	Command	Description
	show running-config router	Displays the commands in the global router configuration.



# clear configure service-policy

To clear the service policy configuration, use the **clear configure service-policy** command in global configuration mode.

## clear configure service-policy

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	—

Command History	Release	Modification
	3.1(1)	This command was introduced.

**Examples** The following is an example of the **clear configure service-policy** command:

```
hostname(config)# clear configure service-policy
```

Related Commands	Command	Description
	<b>show service-policy</b>	Displays the service policy.
	<b>show running-config service-policy</b>	Displays the service policies configured in the running configuration.
	<b>service-policy</b>	Configures the service policy.
	<b>clear service-policy</b>	Clears service policy statistics.

# clear configure snmp-map

To clear the SNMP map configuration, use the **clear configure snmp-map** command in global configuration mode.

## clear configure snmp-map

### Defaults

No default behavior or values.

### Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	•

### Command History

Release	Modification
3.1(1)	This command was introduced.

### Usage Guidelines

The **clear configure snmp-map** command removes the SNMP map configuration.

### Examples

The following example clears the SNMP map configuration:

```
hostname# clear configure snmp-map
```

### Related Commands

Commands	Description
<b>class-map</b>	Defines the traffic class to which to apply security actions.
<b>deny version</b>	Disallows traffic using a specific version of SNMP.
<b>inspect snmp</b>	Enable SNMP application inspection.
<b>snmp-map</b>	Defines an SNMP map and enables SNMP map configuration mode.

# clear configure snmp-server

To disable the Simple Network Management Protocol (SNMP) server, use the **clear configure snmp-server** command in global configuration mode.

**clear configure snmp-server**

**Syntax Description** This command has no arguments or keywords.

**Defaults** This command has no default settings.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	•

Command History	Release	Modification
	3.1(1)	This command was introduced.

**Examples** The following example shows how to disable the SNMP server:

```
hostname #clear snmp-server
```

Related Commands	Command	Description
	<b>snmp-server</b>	Provides the security appliance event information through SNMP.
	<b>show snmp-server statistics</b>	Displays information about the SNMP server configuration.

# clear configure ssh

To clear all SSH commands from the running configuration, use the **clear configure ssh** command in global configuration mode.

## clear configure ssh

### Syntax Description

This command has no arguments or keywords.

### Defaults

No default behavior or values.

### Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	—

### Command History

Release	Modification
3.1(1)	This command was changed from the <b>clear ssh</b> command to the <b>clear configure ssh</b> command.

### Usage Guidelines

This command clears all SSH commands from the configuration. To clear specific commands, use the **no** form of those commands.

### Examples

The following example clears all SSH commands from the configuration:

```
hostname(config)# clear configure ssh
```

### Related Commands

Command	Description
<b>show running-config ssh</b>	Displays the current SSH commands in the running configuration.
<b>ssh</b>	Allows SSH connectivity to the FWSM from the specified client or network.
<b>ssh scopy enable</b>	Enables a secure copy server on the FWSM.
<b>ssh timeout</b>	Sets the timeout value for idle SSH sessions.
<b>ssh version</b>	Restricts the FWSM to using either SSH Version 1 or SSH Version 2.

# clear configure static

To remove all the **static** commands from the configuration, use the **clear configure static** command in global configuration mode.

## clear configure static

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	—

Command History	Release	Modification
	1.1(1)	This command was introduced.
	2.2(1)	This command was modified to support UDP maximum connections for local hosts.
	3.1(1)	This command was changed from <b>clear static</b> .

**Examples** The following example shows how to remove all the **static** commands from the configuration:

```
hostname(config)# clear configure static
```

Related Commands	Command	Description
	<b>show running-config static</b>	Displays all <b>static</b> commands in the configuration.
	<b>static</b>	Configures a persistent one-to-one address translation rule by mapping a local IP address to a global IP address.

# clear configure sunrpc-server

To clear the remote processor call services from the FWSM, use the **clear configure sunrpc-server** command in global configuration mode.

**clear configure sunrpc-server [active]**

## Syntax Description

**active** (Optional) Identifies the SunRPC services that are currently active on the FWSM.

## Defaults

No default behavior or values.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	•

## Command History

Release	Modification
3.1(1)	This command was introduced.

## Usage Guidelines

The **sunrpc-server** command displays the configured **router ospf** commands.



### Note

If the highest-level IP address on the FWSM is a private address, this address is sent in hello packets and database definitions. To prevent this action, set the **router-id** *ip\_address* to a global address.

## Examples

The following example shows how to clear the SunRPC services from the FWSM:

```
hostname(config)# clear configure sunrpc-server active
```

## Related Commands

Command	Description
<b>sunrpc-server</b>	Creates the SunRPC services table.
<b>show running-config sunrpc-server</b>	Displays the information about the SunRPC configuration.

# clear configure sysopt

To clear the configuration for all **sysopt** commands, use the **clear configure sysopt** command in global configuration mode.

**clear configure sysopt**

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	—

Command History	Release	Modification
	1.1(1)	This command was introduced.
	3.1(1)	This command was changed from <b>clear sysopt</b> .

**Examples** The following example clears all **sysopt** command configuration:

```
hostname(config)# clear configure sysopt
```

Related Commands	Command	Description
	<b>show running-config sysopt</b>	Shows the <b>sysopt</b> command configuration.
	<b>sysopt connection permit-ipsec</b>	Permits any packets that come from an IPSec tunnel without checking any access lists for interfaces.
	<b>sysopt connection tcpmss</b>	Overrides the maximum TCP segment size or ensures that the maximum is not less than a specified size.
	<b>sysopt connection timewait</b>	Forces each TCP connection to linger in a shortened TIME_WAIT state after the final normal TCP close-down sequence.
	<b>sysopt nodnsalias</b>	Disables alteration of the DNS A record address when you use the <b>alias</b> command.

# clear configure telnet

To remove the Telnet connection and idle timeout from the configuration, use the **clear configure telnet** command in global configuration mode.

## clear configure telnet

### Syntax Description

This command has no arguments or keywords.

### Defaults

No default behavior or values.

### Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	—

### Command History

Release	Modification
3.1(1)	The keyword <b>configure</b> was added.

### Examples

The following example shows how to remove the Telnet connection and the idle timeout from the FWSM configuration:

```
hostname(config)# clear configure telnet
```

### Related Commands

Command	Description
<b>show running-config telnet</b>	Displays the current list of IP addresses that are authorized to use Telnet connections to the FWSM.
<b>telnet</b>	Adds Telnet access to the console and sets the idle timeout.



# clear configure terminal

To clear the terminal display width setting, use the **clear configure terminal** command in global configuration mode.

## clear configure terminal

**Syntax Description** This command has no keywords or arguments.

**Defaults** The default display width is 80 columns.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	•

Command History	Release	Modification
	2.2(1)	The <b>clear terminal</b> command was introduced.
	3.1(1)	This command was changed to <b>clear configure terminal</b> .

**Examples** The following example clears the display width:

```
hostname# clear configure terminal
```

Related Commands	Command	Description
	<b>terminal</b>	Sets the terminal line parameters.
	<b>terminal width</b>	Sets the terminal display width.
	<b>show running-config terminal</b>	Displays the current terminal settings.

# clear configure timeout

To restore the default idle time durations in the configuration, use the **clear configure timeout** command in global configuration mode.

## clear configure timeout

### Syntax Description

This command has no arguments or keywords.

### Defaults

No default behavior or values.

### Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	—

### Command History

Release	Modification
1.1(1)	This command was introduced.
3.1(1)	This command was changed from <b>clear timeout</b> .

### Examples

This example shows how to remove the maximum idle time durations from the configuration:

```
hostname(config)# clear configure timeout
```

### Related Commands

Command	Description
<b>show running-config timeout</b>	Displays the timeout value of the designated protocol.
<b>timeout</b>	Sets the maximum idle time duration.

# clear configure tunnel-group

To remove all or specified tunnel groups from the configuration, use the **clear config tunnel-group** command in global configuration.

**clear config tunnel-group** [*name*]

## Syntax Description

*name* (Optional) Specifies the name of a tunnel group.

## Defaults

No default behavior or values.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	—

## Command History

Release	Modification
3.1(1)	This command was introduced.

## Examples

The following example entered in global configuration mode, removes the toengineering tunnel group from the configuration:

```
hostname(config)# clear config tunnel-group toengineering
hostname(config)#
```

## Related Commands

Command	Description
<b>show running-config tunnel-group</b>	Displays information about all or selected tunnel-groups.
<b>tunnel-group</b>	Enters tunnel-group subconfiguration mode for the specified type.

# clear configure url-block

To clear clears URL pending block buffer and long URL support configuration, use the **clear configure url-block** command in global configuration mode.

## clear configure url-block

### Defaults

No default behavior or values.

### Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	•

### Command History

Release	Modification
1.1(1)	This command was introduced.
3.1(1)	This command was changed from <b>clear url-block</b> .

### Usage Guidelines

The **clear configure url-block** command clears URL pending block buffer and long URL support configuration.

### Examples

The following example clears URL pending block buffer and long URL support configuration:

```
hostname# clear configure url-block
```

### Related Commands

Commands	Description
<b>clear url-block block statistics</b>	Clears the block buffer usage counters.
<b>show url-block</b>	Displays information about the URL cache, which is used for buffering URLs while waiting for responses from an N2H2 or Websense filtering server.
<b>url-block</b>	Manage the URL buffers used for web server responses.
<b>url-cache</b>	Enables URL caching while pending responses from an N2H2 or Websense server and sets the size of the cache.
<b>url-server</b>	Identifies an N2H2 or Websense server for use with the <b>filter</b> command.

# clear configure url-cache

To clear the URL cache, use the **clear configure url-cache** command in global configuration mode.

## clear configure url-cache

### Defaults

No default behavior or values.

### Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	•

### Command History

Release	Modification
1.1(1)	This command was introduced.
3.1(1)	This command was changed from <b>clear url-cache</b> .

### Usage Guidelines

The **clear configure url-cache** command clears the URL cache.

### Examples

The following example clears the URL cache:

```
hostname# clear configure url-cache
```

### Related Commands

Commands	Description
<b>clear url-cache statistics</b>	Removes <b>url-cache</b> command statements from the configuration.
<b>filter url</b>	Directs traffic to a URL filtering server.
<b>show url-cache statistics</b>	Displays information about the URL cache, which is used for buffering URLs while waiting for responses from an N2H2 or Websense filtering server.
<b>url-cache</b>	Enables URL caching while pending responses from an N2H2 or Websense server and sets the size of the cache.
<b>url-server</b>	Identifies an N2H2 or Websense server for use with the <b>filter</b> command.

# clear configure url-server

To clear the URL filtering server configuration, use the **clear configure url-server** command in global configuration mode.

## clear configure url-server

### Defaults

No default behavior or values.

### Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	•	•	•	•

### Command History

Release	Modification
1.1(1)	This command was introduced.
3.1(1)	This command was changed from <b>clear url-server</b> .

### Usage Guidelines

The **clear configure url-server** command clears the URL filtering server configuration.

### Examples

The following example URL filtering server configuration:

```
hostname# clear configure url-server
```

### Related Commands

Commands	Description
<b>clear url-server</b>	Clears the URL filtering server statistics.
<b>show url-server</b>	Displays information about the URL cache, which is used for buffering URLs while waiting for responses from an N2H2 or Websense filtering server.
<b>url-cache</b>	Enables URL caching while pending responses from an N2H2 or Websense server and sets the size of the cache.
<b>url-block</b>	Manages the URL buffers used for web server responses while waiting for a filtering decision from the filtering server.
<b>url-server</b>	Identifies an N2H2 or Websense server for use with the <b>filter</b> command.

# clear configure username

To clear the username database, use the **clear configure username** command in global configuration mode. To clear the configuration for a particular user, use this command and append the username.

**clear configure username** [*name*]

## Syntax Description

*name* (Optional) Specifies the username to be deleted.

## Defaults

No default behavior or values.

## Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Global configuration	•	—	•	—	—

## Command History

Release	Modification
1.1(1)	The <b>clear username</b> command was introduced.
3.1(1)	This command was changed from <b>clear username</b> .

## Usage Guidelines

The internal user authentication database consists of the users entered with the **username** command. The **login** command uses this database for authentication.

## Examples

The following example shows how to clear the configuration for the user named anyuser:

```
hostname(config)# clear configure username anyuser
```

## Related Commands

Command	Description
<b>show running-config username</b>	Displays the running configuration for a particular user or for all users.
<b>username</b>	Adds a user to the FWSM database.
<b>username attributes</b>	Lets you configure AVPs for specific users.

# clear configure virtual

To remove the authentication virtual server from the configuration, use the **clear configure virtual** command in global configuration mode.

## clear configure virtual

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	—	—	•

Release	Modification
1.1(1)	The <b>clear virtual</b> command was introduced.
3.1(1)	This command was changed from <b>clear virtual</b> .

**Usage Guidelines** There is no undo.

**Examples** The following example shows the **clear configure virtual** command:

```
hostname(config)# clear configure virtual
```

Command	Description
<b>show running-config virtual</b>	Displays the IP address for the authentication virtual server.
<b>virtual http</b>	Allows separate authentication with the FWSM and with the HTTP server.
<b>virtual telnet</b>	Authenticates users with the virtual Telnet server for traffic types for which the FWSM does not supply an authentication prompt.



# clear configure xlate-bypass

To set the xlate bypass configuration to the default (disabled), use the **clear configure xlate-bypass** command in global configuration mode.

## clear configure xlate-bypass

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default behavior or values.

**Command Modes** The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Global configuration	•	•	•	•	—

**Command History**

Release	Modification
3.2(1)	This command was introduced.

**Examples** The following example clears the xlate bypass configuration:

```
hostname(config)# clear configure xlate-bypass
```

**Related Commands**

Command	Description
<b>nat</b>	Configures NAT.
<b>nat-control</b>	Enables NAT control.
<b>same-security-traffic inter-interface</b>	Allows interfaces on the same security level to communicate.
<b>show xlate</b>	Shows current translation and connection information.
<b>xlate-bypass</b>	Enables xlate bypass.

