



# Newer Cisco SBA Guides Available

This guide is part of an older series of Cisco Smart Business Architecture designs. To access the latest Cisco SBA Guides, go to <http://www.cisco.com/go/sba>

Cisco strives to update and enhance SBA guides on a regular basis. As we develop a new series of SBA guides, we test them together, as a complete system. To ensure the mutual compatibility of designs in Cisco SBA guides, you should use guides that belong to the same series.





SBA

BORDERLESS  
NETWORKS

DEPLOYMENT  
GUIDE

# Application Optimization Deployment Guide

● ● ● SMART BUSINESS ARCHITECTURE

August 2012 Series

# Preface

## Who Should Read This Guide

This Cisco® Smart Business Architecture (SBA) guide is for people who fill a variety of roles:

- Systems engineers who need standard procedures for implementing solutions
- Project managers who create statements of work for Cisco SBA implementations
- Sales partners who sell new technology or who create implementation documentation
- Trainers who need material for classroom instruction or on-the-job training

In general, you can also use Cisco SBA guides to improve consistency among engineers and deployments, as well as to improve scoping and costing of deployment jobs.

## Release Series

Cisco strives to update and enhance SBA guides on a regular basis. As we develop a series of SBA guides, we test them together, as a complete system. To ensure the mutual compatibility of designs in Cisco SBA guides, you should use guides that belong to the same series.

The Release Notes for a series provides a summary of additions and changes made in the series.

All Cisco SBA guides include the series name on the cover and at the bottom left of each page. We name the series for the month and year that we release them, as follows:

**month year** Series

For example, the series of guides that we released in August 2012 are the “August 2012 Series”.

You can find the most recent series of SBA guides at the following sites:

Customer access: <http://www.cisco.com/go/sba>

Partner access: <http://www.cisco.com/go/sbachannel>

## How to Read Commands

Many Cisco SBA guides provide specific details about how to configure Cisco network devices that run Cisco IOS, Cisco NX-OS, or other operating systems that you configure at a command-line interface (CLI). This section describes the conventions used to specify commands that you must enter.

Commands to enter at a CLI appear as follows:

```
configure terminal
```

Commands that specify a value for a variable appear as follows:

```
ntp server 10.10.48.17
```

Commands with variables that you must define appear as follows:

```
class-map [highest class name]
```

Commands shown in an interactive example, such as a script or when the command prompt is included, appear as follows:

```
Router# enable
```

Long commands that line wrap are underlined. Enter them as one command:

```
wrr-queue random-detect max-threshold 1 100 100 100 100 100  
100 100 100
```

Noteworthy parts of system output or device configuration files appear highlighted, as follows:

```
interface Vlan64  
ip address 10.5.204.5 255.255.255.0
```

## Comments and Questions

If you would like to comment on a guide or ask questions, please use the [SBA feedback form](#).

If you would like to be notified when new comments are posted, an RSS feed is available from the SBA customer and partner pages.

# Table of Contents

<b>What's In This SBA Guide</b> .....	1	<b>Appendix A: Product List</b> .....	28
Cisco SBA Borderless Networks.....	1	<b>Appendix B: Changes</b> .....	33
Route to Success .....	1		
About This Guide .....	1		
<b>Introduction</b> .....	2		
Business Overview.....	2		
Technology Overview.....	2		
Deployment Details .....	5		
Configuring the WAAS Central Manager.....	6		
Configuring the WAVE Appliance .....	11		
Configuring WAAS on the Services Ready Engine.....	18		
Configuring WAAS Express.....	24		

# What's In This SBA Guide

## Cisco SBA Borderless Networks

Cisco SBA helps you design and quickly deploy a full-service business network. A Cisco SBA deployment is prescriptive, out-of-the-box, scalable, and flexible.

Cisco SBA incorporates LAN, WAN, wireless, security, data center, application optimization, and unified communication technologies—tested together as a complete system. This component-level approach simplifies system integration of multiple technologies, allowing you to select solutions that solve your organization's problems—without worrying about the technical complexity.

Cisco SBA Borderless Networks is a comprehensive network design targeted at organizations with up to 10,000 connected users. The SBA Borderless Network architecture incorporates wired and wireless local area network (LAN) access, wide-area network (WAN) connectivity, WAN application optimization, and Internet edge security infrastructure.

## Route to Success

To ensure your success when implementing the designs in this guide, you should first read any guides that this guide depends upon—shown to the left of this guide on the route below. As you read this guide, specific prerequisites are cited where they are applicable.

## About This Guide


This *deployment guide* contains one or more deployment chapters, which each include the following sections:

- **Business Overview**—Describes the business use case for the design. Business decision makers may find this section especially useful.
- **Technology Overview**—Describes the technical design for the business use case, including an introduction to the Cisco products that make up the design. Technical decision makers can use this section to understand how the design works.
- **Deployment Details**—Provides step-by-step instructions for deploying and configuring the design. Systems engineers can use this section to get the design up and running quickly and reliably.

You can find the most recent series of Cisco SBA guides at the following sites:

Customer access: <http://www.cisco.com/go/sba>

Partner access: <http://www.cisco.com/go/sbachannel>





# Introduction

## Business Overview

The number of remote work sites is increasing, so network administrators need tools to help them ensure solid application performance in remote locations. Recent trends show that a majority of new hires are located at remote sites. These trends are tied to global expansion, employee attraction and retention, mergers and acquisitions, cost savings, and environmental concerns.

In the meantime, remote-site communications requirements are evolving to embrace collaborative applications, video, and Web 2.0 technologies. These developments are also placing greater performance demands on the remote sites and the WAN.

The enterprise trend toward data-center consolidation also continues. The consolidation efforts move most remote-site assets into data centers, largely to comply with regulatory mandates for centralized security and stronger control over corporate data assets.

Consolidating data centers while growing the remote-site population means that increasing numbers of remote employees access LAN-based business applications across comparatively slow WANs. With these applications growing increasingly multimedia-centric and latency-sensitive, IT and networking staffs are further challenged to keep remote-application response times on par with the experiences of users situated locally to the company's application servers in the data center. These local users enjoy multimegabit LAN speeds and are not affected by any distance-induced delay, unlike their counterparts at the other end of a WAN connection.

Application optimization can boost network performance along with enhancing security and improving application delivery. Cisco WAN Optimization is an architectural solution comprising a set of tools and techniques that work together in a strategic systems approach to provide best-in-class WAN optimization performance while minimizing its total cost of ownership.

## Technology Overview

### Central Manager

Every Cisco Wide Area Application Services (Cisco WAAS) network must have one primary WAAS Central Manager device that is responsible for managing the other WAAS devices in the network. The WAAS Central Manager devices host the WAAS Central Manager GUI, a web-based interface that allows you to configure, manage, and monitor the WAAS devices in your network. The WAAS Central Manager resides on a dedicated Cisco Wide Area Virtualization Engine (Cisco WAVE) device.

Detail on the Cisco WAVE sizing is provided in the following table.

*Table 1 - Central Manager Cisco WAVE options*

Device	Number of managed devices (Cisco WAAS and Cisco WAAS Express)
WAVE-294-4GB	250
WAVE-594-8GB	1000
WAVE-694-16GB	2000
vCM-100N	100
vCM-2000N	2000

### WAN Aggregation

The WAN-aggregation site uses a cluster of two or more Cisco WAVE devices to provide Cisco WAAS capabilities. The WAVE appliances connect to the distribution-layer switch. The connections use EtherChannel both for increased throughput and for resiliency. The WAVEs connect to the WAN services network that is configured on the distribution switch.

The total number of devices required is a minimum of two (for N+1 redundancy). The following table provides details on the Cisco WAVE sizing. The fan-out numbers correspond to the total number of remote-peer WAVE devices.

Table 2 - WAN-aggregation Cisco WAVE options

Device	Max optimized TCP connections	Max recommended WAN link [Mbps]	Max optimized throughput [Mbps]	Max core fan-out [Peers]
WAVE-594-8GB	750	50	250	50
WAVE-594-12GB	1300	100	300	100
WAVE-694-16GB	2500	200	450	150
WAVE-694-24GB	6000	200	500	300
WAVE-7541	18000	500	1000	700
WAVE-7571	60000	1000	2000	1400
WAVE-8541	150000	2000	4000	2800

A more comprehensive, interactive Cisco WAAS sizing tool is available for registered users of cisco.com:

<http://tools.cisco.com/WAAS/sizing>

The Web Cache Communication Protocol (WCCP) is a protocol developed by Cisco. Its purpose is to transparently intercept and redirect traffic from a network device to a WCCP appliance such as a Cisco WAVE running Cisco WAAS.

WCCP is enabled on the Multiprotocol Label Switching (MPLS) CE and Dynamic Multipoint VPN (DMVPN) routers. The WCCP redirect uses service groups 61 and 62 to match traffic for redirection. These service groups must be used in pairs:


- Service group 61 uses the source address to redirect traffic
- Service group 62 uses the destination address to redirect traffic

This design uses WCCP 61 inbound on LAN-facing interfaces to match unoptimized data sourced from the data center that is destined for clients at the WAN remote sites. WCCP 62 is used inbound on WAN-facing interfaces, matching optimized data sourced from the WAN remote sites. WCCP 62 is used outbound on LAN interfaces for DMVPN hub routers.

The connections from the distribution switch to the WAN aggregation

routers are routed point-to-point links. This design mandates the use of a negotiated-return generic routing encapsulation (GRE) tunnel from Cisco WAVE to router. When a design uses a GRE negotiated return, it is not required that the Cisco WAVE appliances and the WAN aggregation routers are Layer 2 adjacent.

Figure 1 - WAN aggregation—Cisco WAAS topology



## Remote Sites

The WAN optimization design for the remote sites can vary somewhat based on site-specific characteristics. Single router sites use a single (nonredundant) Cisco WAVE. Similarly, all dual-router sites use dual WAVEs. The specifics of the WAVE sizing and form factor primarily depend on the number of end users and bandwidth of the WAN links. Low bandwidth (< 2 Mbps) single-router, single-link sites can also use the embedded Cisco WAASx capability of the router.

There are many factors to consider in the selection of the WAN remote-site WAN optimization platform. The primary parameter of interest is the bandwidth of the WAN link. After the bandwidth requirement has been met, the next item under consideration is the maximum number of concurrent, optimized TCP connections. Additional detail on the Cisco WAVE sizing is provided in the following table. The optimized throughput numbers correspond to the apparent bandwidth available after successful optimization by Cisco WAAS.

Table 3 - WAN remote-site Cisco WAVE options

Device	Max optimized TCP connections	Max recommended WAN link [Mbps]	Max optimized throughput [Mbps]
Cisco1941/WAASX <sup>1</sup>	150	4	8
SRE-710-S	200	20	200
SRE-710-M	500	20	500
SRE-910-S	200	50	200
SRE-910-M	500	50	500
SRE-910-L	1000	50	1000
WAVE-294-4GB	200	10	100
WAVE-294-8GB	400	20	150
WAVE-594-8GB	750	50	250
WAVE-594-12GB	1300	100	300
WAVE-694-16GB	2500	200	450
WAVE-694-24GB	6000	200	500

Notes:


1. Single link design only

A more comprehensive, interactive WAAS sizing tool is available for registered users of cisco.com:

<http://tools.cisco.com/WAAS/sizing>

The embedded router WAASx provides a subset of the full set of WAAS capabilities available on the WAVE platforms. The current WAASx software release is compatible with single-link WAN designs, cost-effective, and easy to deploy. No design or architecture changes are required to enable this functionality on the router.

Figure 2 - WAN remote-site - WAASx topology



The WAVE form factors previously discussed include a router Service Ready Engine (SRE) and an external appliance. These variants all run the same WAAS software and are functionally equivalent. The primary difference is the method of LAN attachment for these devices:

- SRE: One internal interface (router connect only), one external interface
- Appliance: Two interfaces (both external)


The approach for connecting the WAVE devices to the LAN is to be consistent regardless of the chosen hardware form-factor. All WAVE connections are made using the external interfaces. The benefit of this method is that it is not necessary to create a dedicated network specifically to attach the WAVE devices, and the SRE and appliance devices can use an identical design. The internal interface of the SRE is not used for this design, except for the initial bootstrapping of the device configurations.

You must connect an external Ethernet cable from each SRE module for this solution.




You should connect the WAVE devices to the data VLAN of the access switch in all flat Layer 2 designs.

Figure 3 - WAN remote-site—WAAS topology (access layer connection)



When the deployment uses a distribution-layer design, the WAVE devices should connect to the primary data VLAN on the distribution switch.

Figure 4 - WAN remote-site—WAAS topology (distribution layer connection)



Where possible, connect the WAVE appliances through both interfaces using EtherChannel for performance and resiliency.

WCCP Version 2 is enabled on the WAN routers to redirect traffic to the WAAS appliances.

The WCCP redirect uses service groups 61 and 62 to match traffic for redirection. These services groups must be used in pairs:

- Service group 61 uses the source address to redirect traffic
- Service group 62 uses the destination address to redirect traffic

This design uses WCCP 61 inbound on LAN-facing VLAN subinterfaces to match unoptimized data sourced from the clients destined for the data center (or other remote sites). In all cases, WCCP 62 is used inbound on WAN-facing interfaces to match optimized data sourced from the data center (or other remote sites).

Because the WAVE is connected to the data VLAN, this design requires the use of a negotiated-return GRE tunnel from the WAVE to the router. When using a GRE-negotiated return, you are not required to create a new network on the routers specifically to attach the WAVEs.

### Deployment Details

This deployment guide uses certain standard design parameters and references various network infrastructure services that are not located within this solution. These parameters are listed in the following table.

Table 4 - Universal design parameters

Network service	Cisco SBA values	Site specific values
Domain name	cisco.local	
Active Directory, DNS server, DHCP server	10.4.48.10	
Cisco ACS (Optional)	10.4.48.15	
Network Time Protocol (NTP) server	10.4.48.17	
SNMP read only community	cisco	
SNMP read write community	cisco123	

## Process

### Configuring the WAAS Central Manager

1. Configure switch for Central Manager
2. Install the vWAAS virtual machine
3. Configure the WAAS Central Manager
4. Enable centralized AAA

## Configuration Checklist

This table specifies the parameters and data, in addition to the universal design parameters that you need to set up and configure the Cisco WAAS Central Manager. For your convenience, you can enter your values in the table and refer to it when configuring the appliance. The values you enter will differ from those in this example, which are provided for demonstration purposes only.

Table 5 - Cisco WAAS network system parameters checklist

Parameter	Cisco SBA values	Site specific values
Switch interface number	1/0/10	
VLAN number	148	
Time zone	PST -8 0	
IP address	10.4.48.100/24	
Default gateway	10.4.48.1	
Host name	waas-wcm-1	
Management network (optional)	10.4.48.0/24	
TACACS shared key (optional)	SecretKey	

## Procedure 1

### Configure switch for Central Manager

This guide assumes that the switches have already been configured. The following steps contain only the information required to complete the connection of the switch to the Cisco WAVE appliances. For full details on switch configuration, see *Cisco SBA —Server Room Deployment Guide* or *Cisco SBA —Data Center Deployment Guide*.

#### Option 1. Configure the server room switch

**Step 1:** Connect the Cisco WAVE's external Ethernet port to an Ethernet port on the switch, and then return the switchport configuration to the default.

```
default interface GigabitEthernet1/0/10
```

**Step 2:** Define the switchport as an access port, and then apply quality-of-service (QoS) configuration.

```
interface GigabitEthernet1/0/10
description Link to WAAS-CM
switchport access vlan 148
switchport host
logging event link-status
macro apply EgressQoS
no shutdown
```

## Option 2. Configure the data center switch

**Step 1:** Connect the single-homed appliance to a dual-homed Cisco Fabric Extender (FEX), Define the switchport as an access port, and then apply quality-of-service (QoS) configuration.

```
interface Ethernet102/1/1
  switchport access vlan 148
  spanning-tree port type edge
  service-policy type qos input DC-FCOE+1P4Q_INTERFACE-DSCP-QOS
```



### Tech Tip

You must assign the Ethernet interface configuration on both data center core Cisco Nexus 5500UP switches as the appliance is dual homed because it is on a dual-homed Cisco FEX.

## Procedure 2

### Install the vWAAS virtual machine

#### (Optional)

This procedure is only required if you are using a Cisco Virtual WAAS (Cisco vWAAS).

Cisco vWAAS is provided as an open virtual appliance (OVA). The OVA is prepackaged with disk, memory, CPU, network interface cards (NICs), and other virtual machine related configuration parameters. This is an industry standard and many virtual appliances are available in this format. Cisco provides a different OVA file for each vWAAS model.



### Tech Tip

The OVA files are available only in DVD media format and are not available for download on [www.cisco.com](http://www.cisco.com) at this time.

**Step 1:** Deploy the OVF template with the VMWare vSphere client.

**Step 2:** Before you configure Cisco vWAAS, install the vWAAS OVA on the VMware ESX/ESXi server by using vSphere.

**Step 3:** Configure the device by using the VMware console.

The procedures and steps for configuring the Cisco vWAAS Central Manager and vWAAS Application Accelerator devices are identical to those for the Cisco WAVE appliance and SRE form factors. Select the appropriate following procedure to complete the vWAAS configuration.

## Procedure 3

### Configure the WAAS Central Manager

Use a Cisco WAVE-594 or WAVE-294 device for the Cisco Central Manager function at the primary location to provide graphical management, configuration, and reporting for the Cisco WAAS network. This device resides in the server farm because it is not directly in the forwarding path of the WAN optimization, but provides management and monitoring services. In order to initially configure the Central Manager, you must have terminal access to the console port for basic configuration options and IP address assignment. For all Cisco WAVE devices, the factory default username is admin and the factory default password is default.

**Step 1:** Start the initial setup utility from the command line by entering the **setup** command.

Parameter	Default Value
1. Device Mode	Application Accelerator
2. Interception Method	WCCP
3. Time Zone	UTC 0 0
4. Management Interface	GigabitEthernet 1/0
5. Autosense	Enabled
6. DHCP	Enabled
ESC Quit ? Help	WAAS Default Configuration

Press 'y' to select above defaults, 'n' to configure all, <1-6> to change specific default [y]: **n**

## Step 2: Configure as Central Manager.

1. Application Accelerator
  2. Central Manager
- Select device mode [1]: **2**

## Step 3: Configure the time zone.

Enter Time Zone <Time Zone Hours(-23 to 23) Minutes(0-59)>  
[UTC 0 0]: **PST -8 0**

## Step 4: Configure the management interface, IP address, and default gateway.

No.	Interface Name	IP Address	Network Mask
1.	GigabitEthernet 1/0	dhcp	
2.	GigabitEthernet 2/0	dhcp	

Select Management Interface [1]: **1**  
Enable Autosense for Management Interface? (y/n) [y]: **y**  
Enable DHCP for Management Interface? (y/n) [y]: **n**  
Enter Management Interface IP Address  
<a.b.c.d or a.b.c.d/X(optional mask bits)> [Not configured]:  
**10.4.48.100/24**  
Enter Default Gateway IP Address [Not configured]: **10.4.48.1**

## Step 5: Configure the Domain Name System (DNS), host, and NTP settings.

Enter Domain Name Server IP Address [Not configured]:  
**10.4.48.10**  
Enter Domain Name(s) (Not configured): **cisco.local**  
Enter Host Name (None): **WAAS-WCM-1**  
Enter NTP Server IP Address [None]: **10.4.48.17**

## Step 6: Select the appropriate license.

The product supports the following licenses:  
1. Enterprise  
Enter the license(s) you purchased [1]: **1**

## Step 7: Verify the configuration settings, and then initiate reload.

Parameter	Configured Value
1. Device Mode	Central Manager
2. Time Zone	PST -8 0
3. Management Interface	GigabitEthernet 1/0
4. Autosense	Enabled
5. DHCP	Disabled
6. IP Address	10.4.48.100
7. IP Network Mask	255.255.255.0
8. IP Default Gateway	10.4.48.1
9. DNS IP Address	10.4.48.10
10. Domain Name(s)	cisco.local
11. Host Name	WAAS-WCM-1
12. NTP Server Address	10.4.48.17
13. License	Enterprise

ESC Quit ? Help ! CLI \_\_\_\_\_ WAAS Final Configuration

Press 'y' to select configuration, 'd' to toggle defaults display, <1-13> to change specific parameter [y]: **y**  
Apply WAAS Configuration: Device Mode changed in SETUP; New configuration takes effect after a reload. If applicable, registration with CM, CM IP address, WAAS WCCP configuration etc, are applied after the reboot. Initiate system reload?  
<y/n> [n] **y**  
Are you sure? <y/n> [n]: **y**

Next, configure the device management protocols.

## Step 8: Reboot, and then log in to the Cisco WAAS Central Manager.

## Step 9: Enable Secure Shell Protocol (SSH) by generating the RSA key, and then enabling the sshd service.

```
ssh-key-generate key-length 2048
sshd version 2
sshd enable
no telnet enable
```

**Step 10:** Enable Simple Network Management Protocol (SNMP), which allows the network infrastructure devices to be managed by a Network Management System (NMS), and then configure SNMPv2c for a read-only and a read-write community string.

```
snmp-server community cisco
snmp-server community cisco123 RW
```

**Step 11:** If you want to limit access to the appliance, configure management access control lists (ACLs).

In networks where network operational support is centralized, you can increase network security by using an access list to limit the networks that can access your device. In this example, only devices on the 10.4.48.0/24 network are able to access the device via SSH or SNMP.

```
ip access-list extended 155
  permit tcp 10.4.48.0 0.0.0.255 any eq ssh
  deny tcp any any eq ssh
  permit ip any any
  exit
interface GigabitEthernet 1/0
  ip access-group 155 in
!
ip access-list standard 55
  permit 10.4.48.0 0.0.0.255
  exit
snmp-server access-list 55
```

**Step 12:** After you make configuration changes, save the configuration.

```
copy running-config startup-config
```

**Step 13:** Reboot. The Cisco WAAS Central Manager device should be up and running after the reload completes, and be accessible to a web browser at the IP address assigned during setup, or at the associated host name if it has been configured in DNS.

## Procedure 4

## Enable centralized AAA

### (Optional)

This guide assumes that Cisco Access Control System (Cisco ACS) has already been configured. Only the procedures required to support the integration of Cisco WAAS into the deployment are included. For details on how to configure Cisco ACS, see the *Cisco SBA—Borderless Networks Device Management Using ACS Deployment Guide*.

**Step 1:** Log in to the Cisco WAAS Central Manager through the web interface (for example, <https://waas-wcm-1.cisco.local:8443>) by using the default user name of **admin** and password of **default**.


Next, configure the Network-Admins user group. The web interface for the Cisco WAAS Central Manager requires a user group with the proper role assigned to authorize users from an external AAA database. This step must be completed before enabling authentication, authorization, and accounting (AAA) and can only be performed by using the web interface.

**Step 2:** In Admin > AAA > User Groups, click **Create**.


**Step 3:** In the Name field, type a name. This name must match exactly (case sensitive) the group name used on the AAA server. For example, “Network Admins” in this implementation.



**Step 4:** After you create the group, click the **Role Management** tab, click the **X** to assign the role, and then click **Submit**.



After you properly assign the role, a large, green check mark appears next to the icon.



Next, configure secure user authentication. AAA controls all management access to the Cisco WAAS and Cisco WAVE devices (SSH and HTTPS).

A local admin user was created on the Cisco WAAS/WAVE during setup. This user account provides the ability to manage the device in case the centralized TACACS+ server is unavailable or in case you do not have a TACACS+ server in your organization.

i

### Tech Tip

The AAA configuration details shown are for the Cisco WAAS devices only. Additional configuration is required on the AAA server for successful user authentication. Do not proceed with configuring secure user authentication until you have completed the relevant steps in the *Cisco SBA—Borderless Networks Device Management Using ACS Deployment Guide*.

**Step 5:** Enable AAA authentication for access control. The following configures TACACS+ as the primary method for user authentication (login) and user authorization (configuration).

```
tacacs key SecretKey
tacacs password ascii
tacacs host 10.4.48.15 primary
!
authentication login local enable secondary
authentication login tacacs enable primary
authentication configuration local enable secondary
authentication configuration tacacs enable primary
authentication fail-over server-unreachable
```

**Step 6:** After you make configuration changes, save the configuration.

```
copy running-config startup-config
```

## Process

Configuring the WAVE Appliance

1. Configure switch for WAVE appliances
2. Configure the WAVE appliance
3. Configure WCCPv2 on routers

### Configuration Checklist

This table specifies the parameters and data, in addition to the universal design parameters, that you need to set up and configure the Cisco WAAS network. For your convenience, you can enter your values in the table and refer to it when configuring the WAAS network. The values you enter will differ from those in this example, which are provided for demonstration purposes only.

Table 6 - Cisco WAAS network system parameters checklist

Parameter	Cisco SBA values primary WAVE	Cisco SBA values secondary WAVE	Site specific values
Switch inter- face Numbers	1/0/2 2/0/2	1/0/2 2/0/2	
VLAN number	350	350	
VLAN name (optional)	WAN_Service_Net	WAN_Service_Net	
Time zone	PST -8 0	PST -8 0	
IP address	10.4.32.161/26	10.4.32.162/26	
Default gateway	10.4.32.129/26	10.4.32.129/26	
WAAS Central Manager	10.4.48.100	10.4.48.100	
Hostname	WAVE-1	WAVE-2	
IP addresses of routers inter- cepting traffic with WCCP	10.4.32.241 10.4.32.242 10.4.32.243	10.4.32.241 10.4.32.242 10.4.32.243	
WCCP password	c1sco123	c1sco123	
Management network (optional)	10.4.48.0/24	10.4.48.0/24	
TACACS shared key (optional)	SecretKey	SecretKey	

## Procedure 1 Configure switch for WAVE appliances

There are three options for where to connect Cisco WAVE appliances. The distribution switch is the appropriate location to physically connect WAVE appliances at the WAN-aggregation site and two-tier remote sites. The access switch is the appropriate location to physically connect WAVE appliances at single-tier remote sites.

- **Distribution layer switch**— This device type requires a resilient connection but does not require a routing protocol. This type of connection can use a Layer 2 EtherChannel link.
- **Remote site access layer switch stack or modular switch**— This type of connection can use a Layer 2 EtherChannel link.
- **Remote site access layer switch**— This type of connection can use a Layer 2 access interface.

This guide assumes that the switches have already been configured so it includes only the procedures required to complete the connection of the switch to the Cisco WAVE appliances. For details on how to configure a distribution layer switch, see *Cisco SBA—Borderless Networks LAN Deployment Guide*.

### Option 1. Connect a distribution layer switch

**Step 1:** If a VLAN does not already exist on the distribution layer switch, configure it now.

```
vlan 350
name WAN_Service_Net
```

**Step 2:** Configure Layer 3. Be sure to configure a VLAN interface (SVI) for every new VLAN added so devices in the VLAN can communicate with the rest of the network.

```
interface Vlan350
ip address 10.4.32.129 255.255.255.192
no shutdown
```

Next, configure EtherChannel member interfaces.



### Tech Tip

EtherChannel is a logical interface that bundles multiple physical LAN links into a single logical link.

**Step 3:** Connect the WAVE appliance EtherChannel uplinks in order to separate switches in the distribution layer switches or stack (for the Cisco Catalyst 4507R+E distribution layer, this separates redundant modules for additional resiliency), and then configure two or more physical interfaces to be members of the EtherChannel. It is recommended that the physical interfaces are added in multiples of two. Also, apply the egress QoS macro that was defined in the platform configuration procedure. This ensures traffic is prioritized appropriately.



### Tech Tip

Configure the physical interfaces that are members of a Layer 2 EtherChannel prior to configuring the logical port-channel interface. Doing the configuration in this order allows for minimal configuration and reduces errors because most of the commands entered to a port-channel interface are copied to its members interfaces and do not require manual replication.

```
interface GigabitEthernet 1/0/2
description Link to WAVE port 1
interface GigabitEthernet 2/0/2
description Link to WAVE port 2
!
interface range GigabitEthernet 1/0/2, GigabitEthernet 2/0/2
switchport
macro apply EgressQoS
channel-group 7 mode on
logging event link-status
logging event bundle-status
```

Next, configure the EtherChannel. An access mode interface is used for the connection to the Cisco WAVE appliance.

**Step 4:** Assign the VLAN created at the beginning of the procedure to the interface. When using EtherChannel, the port channel number must match the channel group configured in Step 3.

```
interface Port-channel 7
description EtherChannel link to WAVE
switchport access vlan 350
logging event link-status
no shutdown
```

## Option 2. Connect a remote site access layer switch stack or modular switch

Next, configure EtherChannel member interfaces. The physical interfaces that are members of a Layer 2 EtherChannel are configured prior to configuring the logical port-channel interface. Doing the configuration in this order allows for minimal configuration and reduces errors because most of the commands entered to a port-channel interface are copied to its members' interfaces and do not require manual replication.



### Tech Tip

EtherChannel is a logical interface which bundles multiple physical LAN links into a single logical link.

**Step 1:** Connect the WAVE appliance EtherChannel uplinks to separate switches in the stack, and in the case of the Cisco Catalyst 4507R+E access layer, to separate redundant modules for additional resiliency, and then configure two or more physical interfaces to be members of the EtherChannel and return their switchport configuration to the default. It is recommended that they are added in multiples of two. Also, apply the egress QoS macro that was defined in the platform configuration procedure. This ensures traffic is prioritized appropriately.

```
default interface GigabitEthernet 1/0/2
default interface GigabitEthernet 2/0/2
!
interface GigabitEthernet 1/0/2
description Link to WAVE port 1
interface GigabitEthernet 2/0/2
```

```
description Link to WAVE port 2
!
interface range GigabitEthernet 1/0/2, GigabitEthernet 2/0/2
switchport
macro apply EgressQoS
channel-group 7 mode on
logging event link-status
logging event bundle-status
```

Next, configure the EtherChannel. You use an access mode interface for the connection to the Cisco WAVE appliance.

**Step 2:** Assign the data VLAN to the interface. When using EtherChannel, the port channel number must match the channel group configured in the previous step.

```
interface Port-channel 7
description EtherChannel link to WAVE
switchport access vlan 64
ip arp inspection trust
logging event link-status
no shutdown
```

## Option 3. Connect a remote site access layer switch

**Step 1:** Connect the Cisco WAVE's external Ethernet port to an Ethernet port on the remote site's access switch, and then return the switchport configuration to the default.

```
default interface GigabitEthernet1/0/3
```

**Step 2:** Define the switchport in the remote-site access switch as an access port for the data VLAN, and then apply port-security and QoS configuration.

```
interface GigabitEthernet1/0/3
description Link to WAVE
switchport access vlan 64
switchport host
ip arp inspection trust
logging event link-status
macro apply EgressQoS
no shutdown
```

## Procedure 2

## Configure the WAVE appliance

You can deploy a cluster of Cisco WAVE appliances at the WAN-aggregation site in order to provide the headend termination for Cisco WAAS traffic to and from the remote sites across the WAN. You then connect these devices directly to the distribution-layer switch, using GRE-negotiated return to communicate with the WCCP routers. If you don't want resiliency for application acceleration at the WAN-aggregation site, you can deploy an appliance individually, instead of in a cluster.

You can also deploy Cisco WAVE appliances at WAN remote sites, either individually or as part of a WAVE cluster. You should use this procedure to configure WAN remote-site WAVE appliances. You use the same setup utility that you used in the initial configuration of the Cisco WAAS Central Manager to set up WAVE appliance devices. These devices require only basic setup through their console port to assign initial settings. After you complete this setup, you can perform all management of the WAAS network through the WAAS Central Manager console.

Initial configuration of the Cisco WAVE application accelerators requires terminal access to the console port for basic configuration options and IP address assignment. For all Cisco WAVE devices, the factory default user name is **admin** and the factory default password is **default**.

The setup utility configuration steps for the application accelerator Cisco WAVEs are similar to the setup of the Cisco WAAS Central Manager, but the steps begin to differ after you choose application-accelerator as the device mode. After you choose this mode, the setup script changes to allow you to register the WAVE with the existing Central Manager, and to define the traffic interception method as WCCP.

For all Cisco WAVE devices, the factory default username is admin and the factory default password is default.

**Step 1:** Run setup. You can start the initial setup utility from the command line by entering the **setup** command.

Parameter	Default Value
1. Device Mode	Application Accelerator
2. Interception Method	WCCP
3. Time Zone	UTC 0 0
4. Management Interface	GigabitEthernet 1/0
5. Autosense	Enabled
6. DHCP	Enabled
ESC Quit ? Help	WAAS Default Configuration

Press 'y' to select above defaults, 'n' to configure all, <1-6> to change specific default [y]: n

**Step 2:** Configure the appliance as an application accelerator.

1. Application Accelerator
  2. AppNav Controller
  3. Central Manager
- Select device mode [1]: **1**

**Step 3:** Configure the interception method.

1. WCCP
  2. Other
- Select Interception Method [1]: **1**

**Step 4:** Configure the time zone.

Enter Time Zone <Time Zone Hours(-23 to 23) Minutes(0-59)>  
[UTC 0 0]: **PST -8 0**



**Step 5:** Configure the management interface, IP address, and default gateway.

```
No.      Interface Name      IP Address      Network Mask
  1. GigabitEthernet 1/0          dhcp
  2. GigabitEthernet 2/0          dhcp
Select Management Interface [1]: 1
Enable Autosense for Management Interface? (y/n)[y]: y
Enable DHCP for Management Interface? (y/n)[y]: n
Enter Management Interface IP Address
<a.b.c.d or a.b.c.d/X(optional mask bits)> [Not configured]:
10.4.32.161/26
Enter Default Gateway IP Address [Not configured]: 10.4.32.129
Enter Central Manager IP Address (WARNING: An invalid entry
will cause SETUP to take a long time when applying WAAS
configuration) [None]: 10.4.48.100
```

**Step 6:** Configure the DNS, host, and NTP settings.

```
Enter Domain Name Server IP Address [Not configured]:
10.4.48.10
Enter Domain Name(s) (Not configured): cisco.local
Enter Host Name (None): WAVE-1
Enter NTP Server IP Address [None]: 10.4.48.17
```

**Step 7:** Configure the WCCP router list.

```
Enter WCCP Router (max 4) IP Address list (ip1 ip2 ...) []:
10.4.32.241 10.4.32.242 10.4.32.243
```

**Step 8:** Select the appropriate license.

```
The product supports the following licenses:
  1. Transport
  2. Enterprise
  3. Enterprise & Video
  4. Enterprise & Virtual-Blade
  5. Enterprise, Video & Virtual-Blade
Enter the license(s) you purchased [2]: 2
```

**Step 9:** Verify the configuration settings.

Parameter	Configured Value
1. Device Mode	Application Accelerator
2. Interception Method	WCCP
3. Time Zone	PST -8 0
4. Management Interface	GigabitEthernet 1/0
5. Autosense	Enabled
6. DHCP	Disabled
7. IP Address	10.4.32.161
8. IP Network Mask	255.255.255.192
9. IP Default Gateway	10.4.32.129
10. CM IP Address	10.4.48.100
11. DNS IP Address	10.4.48.10
12. Domain Name(s)	cisco.local
13. Host Name	WAVE-1
14. NTP Server Address	10.4.48.17
15. WCCP Router List	10.4.32.241 10.4.32.242 10.4.32.243
16. License	Enterprise

```
ESC Quit ? Help ! CLI _____ WAAS Final Configuration
_____

Press 'y' to select configuration, <F2> to see all
configuration, 'd' to toggle defaults display, <1-16> to
change specific parameter [y]: y
Applying WAAS configuration on WAE ...
May take a few seconds to complete ...
```

**Step 10:** In the EXEC mode, enable the propagation of local configuration changes to the WAAS Central Manager.

```
cms lcm enable
```

**Step 11:** If you are connecting the Cisco WAAS to a distribution switch or switch stack, configure the port-channel connection and register it to the Cisco WAAS Central Manager.

```
interface GigabitEthernet 1/0
  no ip address 10.4.32.161 255.255.255.192
  exit
!
primary-interface PortChannel 1
!
interface PortChannel 1
  ip address 10.4.32.161 255.255.255.192
  exit
!
interface GigabitEthernet 1/0
  channel-group 1
  exit
interface GigabitEthernet 2/0
  channel-group 1
  no shutdown
  exit
```

There are several additional, non-default settings that you can enable on the Cisco WAVE devices in order to complete the configuration. These settings are configured in the next steps.

**Step 12:** Configure the GRE negotiated return. All Cisco WAVE devices use GRE-negotiated return with their respective WCCP routers.

```
no wccp tcp-promiscuous service-pair 1 2
wccp tcp-promiscuous service-pair 61 62 redirect-method gre
wccp tcp-promiscuous service-pair 61 62 egress-method wccp-gre
```

**Step 13:** Configure WCCP router list. This design uses authentication between the routers and WAVE.

If any of the WCCP routers are Cisco ASR1000 Series routers, then change the default setting of hash-source-ip to mask-assign. This change must be made for WCCP to operate properly and is made on the WAVES, not on the routers.

```
wccp tcp-promiscuous service-pair 61 62 router-list-num 7
wccp tcp-promiscuous service-pair 61 62 assignment-method mask
```

```
wccp tcp-promiscuous service-pair 61 62 password cisco123
wccp tcp-promiscuous service-pair 61 62 enable
```

All other router platforms can use the default setting:

```
wccp tcp-promiscuous service-pair 61 62 router-list-num 7
wccp tcp-promiscuous service-pair 61 62 password cisco123
wccp tcp-promiscuous service-pair 61 62 enable
```

Next, configure device management protocols.

**Step 14:** Log in to the Cisco WAVE, and then enable SSH by generating the RSA key and enabling the sshd service.

```
ssh-key-generate key-length 2048
sshd version 2
sshd enable
no telnet enable
```

**Step 15:** Enable Simple Network Management Protocol (SNMP). This allows the network infrastructure devices to be managed by a Network Management System (NMS). Configure SNMPv2c for both a read-only and a read-write community string.

```
snmp-server community cisco
snmp-server community cisco123 RW
```

**Step 16:** If you want to limit access to the appliance, configure management ACLs.

In networks where network operational support is centralized you can increase network security by using an access list to limit the networks that can access your device. In this example, only devices on the 10.4.48.0/24 network are able to access the device via SSH or SNMP.

```
ip access-list extended 155
  permit tcp 10.4.48.0 0.0.0.255 any eq ssh
  deny tcp any any eq ssh
  permit ip any any
  exit
interface PortChannel 1
  ip access-group 155 in
!
ip access-list standard 55
  permit 10.4.48.0 0.0.0.255
  exit
snmp-server access-list 55
```

**Step 17:** If you have a centralized TACACS+ server, configure secure user authentication as the primary method for user authentication (login) and user authorization (configuration) by enabling AAA authentication for access control. AAA controls all management access to the Cisco WAAS and Cisco WAVE devices (SSH and HTTPS).



### Tech Tip

A factory default local admin user was created on the Cisco WAAS/Cisco WAVE during setup. This user account provides the ability to manage the device in case the centralized TACACS+ server is unavailable, or if you do not have a TACACS+ server in your organization.

```
tacacs key SecretKey
tacacs password ascii
tacacs host 10.4.48.15 primary
!
authentication login local enable secondary
authentication login tacacs enable primary
authentication configuration local enable secondary
authentication configuration tacacs enable primary
authentication fail-over server-unreachable
```

**Step 18:** After you make configuration changes, in the EXEC mode save the configuration.

```
copy running-config startup-config
```

**Step 19:** If you are deploying a cluster of Cisco WAVE appliances, repeat Procedure 10 through Procedure 2 for the resilient appliance.

## Procedure 3 Configure WCCPv2 on routers

This guide assumes that the router has already been configured. Only the procedures required to support the integration of Cisco WAAS into the deployment are included. For details on how to configure a WAN router, see the *Cisco SBA—Borderless Networks MPLS WAN Deployment Guide*, *VPN WAN Deployment Guide*, or *Layer 2 WAN Deployment Guide*.

In this design, WCCP diverts network traffic destined for the WAN to the Cisco WAAS system for optimization. This method provides for a clean deployment with minimal additional cabling, and requires both the WAN-aggregation and remote-site routers to be configured for WCCP.

**Step 1:** Configure global WCCP parameters and enable services 61 and 62, and then configure a group-list and password. Permit only the on-site WAVE appliances in the group-list to prevent unauthorized Cisco WAVE devices from joining the WAAS cluster.

You must enable services 61 and 62 for WCCP redirect for Cisco WAAS. As a best practice, exempt certain critical traffic types from WCCP redirect by using a redirect list.

```
ip wccp 61 redirect-list WAAS-REDIRECT-LIST group-list WAVE
password clisco123
ip wccp 62 redirect-list WAAS-REDIRECT-LIST group-list WAVE
password clisco123
!
ip access-list standard WAVE
  permit 10.4.32.161
  permit 10.4.32.162
ip access-list extended WAAS-REDIRECT-LIST
  remark WAAS WCCP Redirect List
  deny    tcp any any eq 22
  deny    tcp any eq 22 any
  deny    tcp any eq telnet any
  deny    tcp any any eq telnet
  deny    tcp any eq tacacs any
  deny    tcp any any eq tacacs
  deny    tcp any eq bgp any
  deny    tcp any any eq bgp
  deny    tcp any any eq 123
  deny    tcp any eq 123 any
  permit  tcp any any
```

**Step 2:** Configure WCCP redirection for traffic from the LAN. Be sure to identify specific interfaces where traffic to and from the WAN are intercepted.

Traffic from the LAN is intercepted with service 61 inbound on all LAN interfaces. It is not necessary to configure WCCP interception on voice interfaces and voice VLANs.

If the LAN interface is a Layer 3 interface, define WCCP redirection on the interface directly.

```
interface Port-Channel 1
ip wccp 61 redirect in
```

If the LAN interface is a VLAN trunk, define WCCP redirection on the data VLAN subinterface.

```
interface GigabitEthernet0/2.64
ip wccp 61 redirect in
```

Next, configure WCCP redirection for traffic from the WAN.

**Step 3:** If you want to configure a Cisco WAN router, except a DMVPN hub router, do the following.

Traffic from the WAN is intercepted with service 62 inbound on all WAN interfaces, including DMVPN tunnel interfaces (but not their underlying physical interfaces).

```
interface GigabitEthernet 0/3
ip wccp 62 redirect in
```

**Step 4:** If you want to configure DMVPN hub routers, do the following.

DMVPN hub routers require WCCP 62 outbound on the LAN interface to support dynamic creation of spoke to spoke tunnels. Traffic from the WAN is intercepted with service 62 outbound on the LAN interfaces.

```
interface PortChannel 1
ip wccp 62 redirect out
```

**Step 5:** If LAN interfaces are VLAN trunks, define WCCP redirection on the data VLAN subinterface.

```
interface GigabitEthernet0/2.64
ip wccp 61 redirect out
```

**Step 6:** After you make configuration changes, save the configuration.

```
copy running-config startup-config
```

**Step 7:** If you have multiple WAN routers at the site or multiple WAN interfaces on a single router, repeat the steps in this procedure for each WAN facing interface.

## Process

Configuring WAAS on the Services Ready Engine

1. Configure remote switch for WAVE SRE
2. Configure the WAVE SRE
3. Configure WCCPv2 on Routers

## Configuration Checklist

This table specifies the parameters and data, in addition to the universal design parameters that you need to set up and configure the Cisco WAAS SRE. For your convenience, you can enter your values in the table and refer to it when configuring the SRE. The values you enter will differ from those in this example, which are provided for demonstration purposes only.

Table 7 - Cisco WAAS network system parameters checklist

Parameter	Cisco SBA values primary WAVE	Cisco SBA values secondary WAVE	Site specific values
Switch interface number	1/0/3	1/0/4	
VLAN number	64	64	
Time zone	PST -8 0	PST -8 0	
IP address	10.5.52.8/24	10.5.52.9/24	
Default gateway	10.5.52.1/24	10.5.52.1/24	
WAAS central manager	10.4.48.100	10.4.48.100	
Hostname	WAVE-sre-1	WAVE-sre-2	
IP addresses of routers intercepting traffic with WCCP	10.255.251.203 (r1) 10.255.253.203 (r2)	10.255.251.203 (r1) 10.255.253.203 (r2)	
WCCP password	c1sco123	c1sco123	
Management network (optional)	10.4.48.0/24	10.4.48.0/24	
TACACS shared key (optional)	SecretKey	SecretKey	

## Procedure 1 Configure remote switch for WAVE SRE

The access switch is the appropriate location to physically connect Cisco WAVE SREs at single-tier remote sites. Regardless of the switch type—single switch, switch stack, or modular—this type of connection must use a Layer 2 access interface.

This guide assumes that the LAN switch has already been configured. Only the procedures required to complete the connection of the switch to the Cisco WAVE appliances are included. For details on how to configure switches, see *Cisco SBA—Borderless Networks LAN Deployment Guide*.

**Step 1:** Connect the Cisco WAVE's external Ethernet port to an Ethernet port on the remote site's access switch, and then return the switchport configuration to the default.

```
default interface GigabitEthernet1/0/3
```

**Step 2:** Define the switchport in the remote-site access switch as an access port for the data VLAN, and then apply port-security and QoS configuration.

```
interface GigabitEthernet1/0/3
description Link to WAVE
switchport access vlan 64
switchport host
ip arp inspection trust
logging event link-status
macro apply EgressQoS
no shutdown
```

## Procedure 2 Configure the WAVE SRE

This guide assumes that the router has already been configured. Only the procedures required to support the integration of Cisco WAAS into the deployment are included. For details on how to configure the WAN router, see the *Cisco SBA—Borderless Networks MPLS WAN Deployment Guide*, *VPN WAN Deployment Guide*, or *Layer 2 WAN Deployment Guide*.

You can use a variety of Cisco WAVE appliances or SRE form-factors for the remote-site Cisco WAAS equipment in this design, depending on the performance requirements.

You can insert the SRE modules directly into a corresponding module slot in the remote-site router and configure them somewhat differently from the appliances. If you are using an appliance, you can follow the WAN-Aggregation Cisco WAVE device set of procedures with remote-site addressing parameters.

Although the remote-site router can potentially communicate directly with the SRE by using the router backplane, this design uses the external interfaces on the modules, which allows for a consistent design implementation regardless of the chosen Cisco WAVE device. You must enable the SM interface and assign an arbitrary (locally significant only) IP address in order for the SM interface to be accessed through a console session from the host router.

You must connect the external interface to the data network on the access or distribution switch for this configuration to work properly.



**Step 1:** Configure console access and SRE IP addresses on the host router by entering the following commands on the host router. This permits console access to the SRE modules.

```
interface SM1/0
ip address 192.0.2.2 255.255.255.252
service-module external ip address 10.5.52.8 255.255.255.0
service-module ip default-gateway 10.5.52.1
no shutdown
```



### Tech Tip

The IP address assigned 192.0.2.2 to SM/0 is arbitrary in this design and only locally significant to the host router.

Next, if AAA has been enabled on the router, configure an AAA exemption for SRE devices.

Configuring an exemption on the router is required because when AAA is enabled on the router, you will be prompted for both a router login and a Cisco WAAS login; which can be confusing. Disabling the initial router authentication requires you to create an AAA method, which you then apply to the specific line configuration on the router associated with the SRE.

**Step 2:** Create the AAA login method.

```
aaa authentication login MODULE none
```

**Step 3:** Determine which line number is assigned to SRE. The example output below shows line 67.

```
RS203-2921-1# show run | begin line con 0
line con 0
logging synchronous
line aux 0
line 67
no activation-character
no exec
transport preferred none
transport input all
transport output pad telnet rlogin lapb-ta mop udptn v120 ssh
stopbits 1
```

```
flowcontrol software
line vty 0 4
transport preferred none
transport input ssh
```

**Step 4:** Restrict access to the SRE console by creating an access-list. The access-list number is arbitrary, but the IP address must match the address assigned to the SM interface in Step 1.

```
access-list 67 permit 192.0.2.2
```

**Step 5:** Assign the method to the appropriate line.

```
line 67
login authentication MODULE
access-class 67 in
transport output none
```

**Step 6:** Connect to the Cisco WAVE console by using a session from the host router.

After the IP address is assigned, and the interface is enabled, it is possible to open a session on the Cisco WAVE and run the setup script. For all WAVE devices, the factory default username is **admin** and the factory default password is default.

Note that if you are using secure user authentication on the router and have not created a AAA exemption, you must first authenticate with a valid router login credential before logging into the Cisco WAVE console session.

```
RS203-2921-1# service-module sm 1/0 session
```

**Step 7:** Run setup. You can start the initial setup utility from the command line by entering the setup command.

Parameter	Default Value
Device Mode	Application Accelerator
1. Interception Method	WCCP
2. Time Zone	UTC 0 0
3. Management Interface	GigabitEthernet 1/0
(internal)	
Autosense	Disabled
DHCP	Disabled
ESC Quit ? Help	WAAS Default Configuration

Press 'y' to select above defaults, 'n' to configure all, <1-3> to changespecific default [y]: **n**

**Step 8:** Configure the interception method.

1. WCCP
  2. Other
- Select Interception Method [1]: **1**

**Step 9:** Configure the time zone.

Enter Time Zone <Time Zone Hours(-23 to 23) Minutes(0-59)>  
[UTC 0 0]: **PST -8 0**

**Step 10:** Configure the management interface, IP address, and default gateway.

This design uses the external interface as the management interface.

No.	Interface Name	IP Address	Network Mask
1.	GigabitEthernet 1/0 (internal)	unassigned	unassigned
2.	GigabitEthernet 2/0 (external)	dhcp	

Select Management Interface [1]: **2**

Enable Autosense for Management Interface? (y/n) [y]: **y**

Enable DHCP for Management Interface? (y/n) [y]: **n**



**Tech Tip**

If you receive the following warning, you may disregard it because the IP address configuration was provided previously.

```
*** You have chosen to disable DHCP! Any network
configuration learnt from DHCP server will be
unlearnt! SETUP will indicate failure as the
management interface cannot be brought up - Please
make sure WAVE Management Interface IP address and
Default Gateway are configured from the Router;
Press ENTER to continue:
```

**Step 11:** Configure the Cisco WAAS Central Manager address.

Enter Central Manager IP Address (WARNING: An invalid entry will cause SETUP to take a long time when applying WAAS configuration) [None]: **10.4.48.100**

**Step 12:** Configure DNS, host, and NTP settings.

Enter Domain Name Server IP Address [Not configured]:  
**10.4.48.10**

Enter Domain Name(s) (Not configured): **cisco.local**

Enter Host Name (None): **WAVE-SRE-1**

Enter NTP Server IP Address [None]: **10.4.48.17**

**Step 13:** Configure the WCCP router list.

Enter WCCP Router (max 4) IP Address list (ip1 ip2 ...) []:  
**10.255.251.203 10.255.253.203**

**Step 14:** Select the appropriate license.

The product supports the following licenses:

1. Transport
2. Enterprise
3. Enterprise & Video

Enter the license(s) you purchased [2]: **2**

**Step 15:** Verify the configuration settings.

Parameter	Configured Value
1. Interception Method	WCCP
2. Time Zone	PST -8 0
3. Management Interface	GigabitEthernet 2/0 (external)
4. Autosense	Enabled
5. DHCP	Disabled
IP Address	10.5.52.8
IP Network Mask	255.255.255.0
IP Default Gateway	10.5.52.1
6. CM IP Address	10.4.48.100
7. DNS IP Address	10.4.48.10
8. Domain Name(s)	cisco.local
9. Host Name	WAVE-SRE-1

```

10. NTP Server Address      10.4.48.17
11. WCCP Router List       10.255.251.203 10.255.253.203
12. License                 Enterprise
ESC Quit ? Help ! CLI ----- WAAS Final Configuration

```

Press 'y' to select configuration, <F2> to see all configuration, 'd' to toggle defaults display, <1-12> to change specific parameter [y]: **y**

Router WCCP configuration

First WCCP router IP in the WCCP router list seems to be an external address; WCCP configuration on external routers is not allowed through SETUP. Please press ENTER to apply WAAS configuration on WAVE ...

Applying WAAS configuration on WAE ...

May take a few seconds to complete ...

WAAS configuration applied successfully!!

Saved configuration to memory.

Press ENTER to continue ...

**Step 16:** When you are prompted with a recommended router WCCP configuration template, you don't have to retain the information. This router configuration is covered in depth in a following procedure.

**Step 17:** In the EXEC mode, enable the propagation of local configuration changes to the WAAS Central Manager.

```
cms lcm enable
```

**Step 18:** Configure the GRE negotiated return. All Cisco WAVE devices use GRE-negotiated return with their respective WCCP routers.

```

no wccp tcp-promiscuous service-pair 1 2
wccp tcp-promiscuous service-pair 61 62 redirect-method gre
wccp tcp-promiscuous service-pair 61 62 egress-method wccp-gre

```

**Step 19:** Configure WCCP router list. This design uses authentication between the routers and WAVE.

If any of the WCCP routers are Cisco ASR1000 Series routers, then change the default setting of hash-source-ip to mask-assign. This change must be made for WCCP to operate properly and is made on the WAVES, not on the routers.

```

wccp tcp-promiscuous service-pair 61 62 router-list-num 7
wccp tcp-promiscuous service-pair 61 62 assignment-method mask

```

```

wccp tcp-promiscuous service-pair 61 62 password c1sco123
wccp tcp-promiscuous service-pair 61 62 enable

```

All other router platforms can use the default setting:

```

wccp tcp-promiscuous service-pair 61 62 router-list-num 7
wccp tcp-promiscuous service-pair 61 62 password c1sco123
wccp tcp-promiscuous service-pair 61 62 enable

```

Next, configure device management protocols.

**Step 20:** Log in to the Cisco WAVE, and then enable SSH by generating the RSA key and enabling the sshd service.

```

ssh-key-generate key-length 2048
sshd version 2
sshd enable
no telnet enable

```

**Step 21:** Enable Simple Network Management Protocol (SNMP) in order to allow the network infrastructure devices to be managed by a Network Management System (NMS), and then configure SNMPv2c both for a read-only and a read-write community string.

```

snmp-server community cisco
snmp-server community cisco123 RW

```

**Step 22:** If you want to limit access to the appliance, configure management ACLs.

In networks where network operational support is centralized, you can increase network security by using an access list to limit the networks that can access your device. In this example, only devices on the 10.4.48.0/24 network are able to access the device via SSH or SNMP.

```

ip access-list extended 155
permit tcp 10.4.48.0 0.0.0.255 any eq ssh
deny tcp any any eq ssh
permit ip any any
exit
interface GigabitEthernet 1/0
ip access-group 155 in
!
ip access-list standard 55
permit 10.4.48.0 0.0.0.255
exit
snmp-server access-list 55

```

**Step 23:** If you have a centralized TACACS+ server, configure secure user authentication as the primary method for user authentication (login) and user authorization (configuration) by enabling AAA authentication for access control. AAA controls all management access to the Cisco WAAS and Cisco WAVE devices (SSH and HTTPS).



### Tech Tip

A factory default local admin user was created on the Cisco WAAS/Cisco WAVE during setup. This user account provides the ability to manage the device in case the centralized TACACS+ server is unavailable, or if you do not have a TACACS+ server in your organization.

```
tacacs key SecretKey
tacacs password ascii
tacacs host 10.4.48.15 primary
!
authentication login local enable secondary
authentication login tacacs enable primary
authentication configuration local enable secondary
authentication configuration tacacs enable primary
authentication fail-over server-unreachable
```

**Step 24:** After you make configuration changes, in the EXEC mode save the configuration.

```
copy running-config startup-config
```

Each Cisco WAVE registers with the Cisco WAAS Central Manager as it becomes active on the network.

**Step 25:** If you want to verify the Cisco WAVE registration, you can use the **show cms info** command on the respective WAVE or via the web interface to the Cisco WAAS Central Manager.

**Step 26:** When this configuration is complete, you can return the session to the command line of the host router by entering the escape sequence **Ctrl-Shift-6, 6** again, then **x**.

**Step 27:** If you are deploying a cluster of Cisco WAVE appliances, repeat Procedure 1 through Procedure 2 for the resilient appliance.

## Procedure 3

## Configure WCCPv2 on Routers

In this design, WCCP diverts network traffic destined for the WAN to the Cisco WAAS system for optimization. This method provides for a clean deployment with minimal additional cabling, and requires both the WAN-aggregation and remote-site routers to be configured for WCCP.

This guide assumes that the router has already been configured. Only the procedures required to support the integration of Cisco WAAS into the deployment are included. Full details on WAN router configuration are included in the *Cisco SBA—Borderless Networks MPLS WAN Deployment Guide*, *VPN WAN Deployment Guide*, or *Layer 2 WAN Deployment Guide*.

**Step 1:** Configure global WCCP parameters, enable services 61 and 62, and then configure a group-list and password. Permit only the on-site WAVE appliances in the group-list to prevent unauthorized Cisco WAVE devices from joining the WAAS cluster.

You must enable services 61 and 62 for WCCP redirect for Cisco WAAS. These services should be using WCCP Version 2. As a best practice, exempt certain critical traffic types from WCCP redirect by using a redirect list.

```
ip wccp 61 redirect-list WAAS-REDIRECT-LIST group-list WAVE
password clisco123
ip wccp 62 redirect-list WAAS-REDIRECT-LIST group-list WAVE
password clisco123
!
ip access-list standard WAVE
permit 10.5.52.8
permit 10.5.52.9
ip access-list extended WAAS-REDIRECT-LIST
remark WAAS WCCP Redirect List
deny tcp any any eq 22
deny tcp any eq 22 any
deny tcp any eq telnet any
deny tcp any any eq telnet
deny tcp any eq tacacs any
deny tcp any any eq tacacs
deny tcp any eq bgp any
deny tcp any any eq bgp
deny tcp any any eq 123
deny tcp any eq 123 any
permit tcp any any
```

## Step 2: Configure WCCP redirection for traffic from the LAN.

Specific interfaces must be identified where traffic to and from the WAN are intercepted.

Traffic from the LAN is intercepted with service 61 inbound on all LAN interfaces. It is not necessary to configure WCCP interception on voice interfaces and voice VLANs.

If the LAN interface is a Layer 3 interface, define WCCP redirection on the interface directly.

```
interface Port-Channel 1
  ip wccp 61 redirect in
```

If the LAN interface is a VLAN trunk, define WCCP redirection on the data VLAN subinterface.

```
interface GigabitEthernet0/2.64
  ip wccp 61 redirect in
```

## Step 3: Configure WCCP redirection for traffic from the WAN.

Traffic from the WAN is intercepted with service 62 inbound on all WAN interfaces, including DMVPN tunnel interfaces (but not their underlying physical interfaces).

```
interface GigabitEthernet 0/3
  ip wccp 62 redirect in
```

## Step 4: After you make configuration changes, save the configuration.

```
copy running-config startup-config
```

## Step 5: If you have multiple WAN routers at the site, repeat Step 1 through Step 4 for each WAN router.

## Process

### Configuring WAAS Express

1. Configure the Central Manager for WAASx
2. Create WAAS Express user
3. Configure WAAS Express routers

## Configuration Checklist

This table specifies the parameters and data, in addition to the universal design parameters that you need to set up and configure Cisco WAAS Express. For your convenience, you can enter your values in the table and refer to it when configuring the router. The values you enter will differ from those in this example, which are provided for demonstration purposes only.

Table 8 - Cisco WAAS network system parameters checklist

Parameter	Cisco SBA values Primary WAVE	Site specific values
WAAS Central Manager	10.4.48.100	
WAASx username	waasx	
WAASx password	c1sco123	

## Procedure 1

### Configure the Central Manager for WAASx

You can use the Cisco WAAS Central Manager to centrally manage WAASx routers, similar to a Cisco WAVE appliance. You must define a user name and password for the WAAS Central Manager to use to access the WAASx routers for monitoring and management. You secure these communications by using HTTPS, which requires the use of digital certificates.

First, configure login and password credentials for the Cisco WAASx router by using the Cisco WAAS Central Manager web interface (<https://waas-wcm-1.cisco.local:8443>). You can do this by editing the WAASx global credentials.



Step 1: Click Admin > Security > WAAS Express > Global Credentials.

**Step 2:** Enter the appropriate user name and password that you also plan to configure on the Cisco WAASx router or on the central AAA server. The screenshot above shows user name **waasx** and password **c1sco123**.

**Step 3:** Export the trusted digital certificate from Cisco WAAS Central Manager.

To enable secure communications between the Cisco WAAS Central Manager and the router requires that you install the digital certificate from the WAAS Central Manager on each of the WAASx routers. The certificate can be exported in privacy enhanced mail (PEM) base64 format. This command is available through the device command line interface.

```
WAAS-WCM-1#show crypto certificate-detail admin | begin BEGIN
...skipping
-----BEGIN CERTIFICATE-----
<certificate data deleted>
-----END CERTIFICATE-----
```

**Step 4:** Because this information is required for all Cisco WAASx routers, copy and paste this certificate, and then save it to a secure file.

## Procedure 2

## Create WAAS Express user

There are two options when you are creating the Cisco WAAS Express account. You can create the account locally on each WAAS Express router, or you can create it once on the central AAA server.

As networks scale in the number of devices to maintain, there is an operational burden to maintain local user accounts on every device. A centralized authentication, authorization and accounting (AAA) service reduces operational tasks per device and provides an audit log of user access for security compliance and root cause analysis.

### Option 1. Create a local user account

**Step 1:** Create a local user on the remote-site router.

```
username waasx privilege 15 password c1sco123
```

### Option 2. Create a centralized AAA

The Cisco Secure ACS internal identity store can contain all the network administrator accounts or just accounts that require a policy exception if an external identity store (such as Microsoft Active Directory) is available. A common example of an account that would require an exception is one associated with a network management system that allows the account to perform automated configuration and monitoring.

**Step 1:** Navigate and log in to the ACS Administration Page. (Example: <https://acs.cisco.local>)

**Step 2:** Navigate to **Users and Identity Stores > Internal Identity Stores > Users**.

**Step 3:** Click **Create**.

**Step 4:** Enter a name, description, and password for the user account. The example shows user name **waasx** and password **c1sco123**.

Users and Identity Stores > Internal Identity Stores > Users > Create

**General**

Name:  Status:

Description:

Identity Group:

**Password Information**

Password must:

- Contain 4 - 32 characters

Enable Password Information

Password must:

- Contain 4 - 32 characters

Password Type:

Enable Password:

Password:

Confirm Password:

☐ Change password on next login

**User Information**

There are no additional identity attributes defined for user records

= Required fields

**Step 5:** To the right of Identity Group, click **Select**.

**Step 6:** Select the radio button next to the **Network Admins** group.

Identity Groups

Filter:  Match if:

Name	Description
<input type="radio"/> All Groups	Identity Group Root
<input type="radio"/> Helpdesk	Users who are allowed to login to a device but not make changes
<input checked="" type="radio"/> Network Admins	Users who are allowed to login to a device and make changes

**Step 7:** Click **OK**, and then click **Submit**.

### Procedure 3

### Configure WAAS Express routers

This guide assumes that the router has already been configured. Only the procedures required to support the integration of Cisco WAAS into the deployment are included. Full details on WAN router configuration are included in the *Cisco SBA—Borderless Networks MPLS WAN Deployment Guide*, *VPN WAN Deployment Guide*, or *Layer 2 WAN Deployment Guide*.

If you want to turn on the embedded WAN optimization, you must enable Cisco WAAS optimization on the router's WAN interface. WAASx can also be centrally managed by the same WAAS Central Manager used with Cisco WAVE devices. The router must also be properly configured to communicate securely with the WAAS Central Manager.

Note the following:

- Cisco WAASx is a specially licensed feature. This license must be installed on a router with sufficient DRAM to support the WAASx functionality.
- Cisco WAASx routers must be configured with maximum DRAM.
- WCCP redirection is not used for a Cisco WAASx implementation. There is no need to redirect traffic to an external device, because all traffic optimization is performed on the router.

**Step 1:** Enable Cisco WAAS on a remote-site router with WAN interface GigabitEthernet0/0.

```
interface GigabitEthernet0/0
  waas enable
```

**Step 2:** Configure self-signed trustpoint, and then generate a digital certificate.

This step is necessary even if you already have a self-signed trustpoint that is auto-generated from HTTPS that was enabled previously. Be sure to match the host name and domain name that are already configured on the router for the subject-alt-name field.

```
crypto pki trustpoint SELF-SIGNED-TRUSTPOINT
  enrollment selfsigned
  subject-alt-name RS204-1941.cisco.local
  revocation-check none
  rsakeypair SELF-SIGNED-RSAKEYPAIR 2048
  exit
```

```
crypto pki enroll SELF-SIGNED-TRUSTPOINT
```

The router has already generated a Self Signed Certificate for trustpoint TP-self-signed-xxxxxx.

If you continue the existing trustpoint and Self Signed Certificate will be deleted.

Do you want to continue generating a new Self Signed Certificate? [yes/no]: **yes**

% Include the router serial number in the subject name? [yes/no]: **no**

% Include an IP address in the subject name? [no]: **no**

Generate Self Signed Router Certificate? [yes/no]: **yes**

Router Self Signed Certificate successfully created

**Step 3:** Configure the Cisco WAASx router to use a loopback interface as the source for any HTTP client communication.

```
ip http client source-interface Loopback0
```

**Step 4:** Enable the HTTPS secure server.

```
ip http secure-server
ip http secure-trustpoint SELF-SIGNED-TRUSTPOINT
```

**Step 5:** Create a trustpoint, and then import the Cisco WAAS Central Manager certificate.

```
crypto pki trustpoint WAAS-WCM
  revocation-check none
  enrollment terminal pem
  exit
crypto pki authenticate WAAS-WCM
Enter the base 64 encoded CA certificate.
End with a blank line or the word "quit" on a line by itself
```

**Step 6:** Paste the PEM certificate that was generated in the previous procedure from the Cisco WAAS Central Manager.

```
-----BEGIN CERTIFICATE-----
<certificate data deleted>
-----END CERTIFICATE-----
quit
```

Certificate has the following attributes:

```
Fingerprint MD5: 2EA6FF8F 38ABC32F 25168396 1A587F17
Fingerprint SHA1: 8DAB6185 7B95FC4C 34FDACDC A8F2B1A4 8074709B
% Do you accept this certificate? [yes/no]: yes
Trustpoint CA certificate accepted.
% Certificate successfully imported
```

**Step 7:** Register the Cisco WAASx router with the WAAS Central Manager.

After you have properly generated and installed the digital certificates, you can register the router with the WAAS Central Manager. In the EXEC mode, enter:

```
waas cm-register https://10.4.48.100:8443/wcm/register
```

The router appears as a managed device on the WAAS Central Manager.

**Step 8:** After you make configuration changes, save the configuration.

```
copy running-config startup-config
```

# Appendix A: Product List

## WAAS Central Manager

Functional Area	Product Description	Part Numbers	Software
Central Manager Appliance	Cisco Wide Area Virtualization Engine 694	WAVE-694-K9	5.0.1
	Cisco Wide Area Virtualization Engine 594	WAVE-594-K9	
	Cisco Wide Area Virtualization Engine 294	WAVE-294-K9	
Central Manager Virtual Appliance	Virtual WAAS Central Manager	WAAS-CM-VIRT-K9	5.0.1
	License to manage up to 2000 WAAS Nodes	LIC-VCM-2000N	
	License to manage up to 100 WAAS Nodes	LIC-VCM-100N	

## WAAS Aggregation

Functional Area	Product Description	Part Numbers	Software
WAVE Aggregation Appliance	Cisco Wide Area Virtualization Engine 8541	WAVE-8541-K9	5.0.1
	Cisco Wide Area Virtualization Engine 7571	WAVE-7571-K9	
	Cisco Wide Area Virtualization Engine 7541	WAVE-7541-K9	
	Cisco Wide Area Virtualization Engine 694	WAVE-694-K9	
	Cisco Wide Area Virtualization Engine 594	WAVE-594-K9	

## WAAS Remote Site

Functional Area	Product Description	Part Numbers	Software
Remote Site WAVE Appliance	Cisco Wide Area Virtualization Engine 694	WAVE-694-K9	5.0.1
	Cisco Wide Area Virtualization Engine 594	WAVE-594-K9	
	Cisco Wide Area Virtualization Engine 294	WAVE-294-K9	

Functional Area	Product Description	Part Numbers	Software
Remote-Site WAVE SRE	Cisco SRE 910 with 4-8 GB RAM, 2x 500 GB 7,200 rpm HDD, RAID 0/1, dual-core CPU configured with ISR G2	SM-SRE-910-K9	5.0.1
	WAAS software container for SRE SM 900	SM9-WAAS	
	WAAS Enterprise License for SRE Large deployment	WAAS-ENT-SM-L	
	WAAS Enterprise License for SRE Medium deployment	WAAS-ENT-SM-M	
	WAAS Enterprise License for SRE Small deployment	WAAS-ENT-SM-S	
Remote-Site WAVE SRE	Cisco SRE 710 with 4 GB RAM, 500 GB 7,200 rpm HDD, single-core CPU configured with Cisco ISR G2	SM-SRE-710-K9	5.0.1
	WAAS software container for SRE SM 700	SM7-WAAS	
	WAAS Enterprise License for SRE Medium deployment	WAAS-ENT-SM-M	
	WAAS Enterprise License for SRE Small deployment	WAAS-ENT-SM-S	
Remote-Site WAAS Express	1941 WAAS Express only Bundle	C1941-WAASX-SEC/K9	15.1(4)M4
	Data Paper PAK for Cisco 1900 series	SL-19-DATA-K9	securityk9, datak9

## WAN Aggregation

Functional Area	Product Description	Part Numbers	Software
WAN-aggregation Router	Aggregation Services 1002 Router	ASR1002-5G-VPN/K9	IOS-XE 15.2(2)S
	Aggregation Services 1001 Router	ASR1001-2.5G-VPNK9	Advanced Enterprise
WAN-aggregation Router	Cisco 3945 Security Bundle w/SEC license PAK	CISCO3945-SEC/K9	15.1(4)M4
	Cisco 3925 Security Bundle w/SEC license PAK	CISCO3925-SEC/K9	securityk9, datak9
	Data Paper PAK for Cisco 3900 series	SL-39-DATA-K9	

## WAN Remote Site

Functional Area	Product Description	Part Numbers	Software
Modular WAN Remote-site Router	Cisco 3945 Voice Sec. Bundle, PVDM3-64, UC and SEC License PAK	C3945-VSEC/K9	15.1(4)M4
	Cisco 3925 Voice Sec. Bundle, PVDM3-64, UC and SEC License PAK	C3925-VSEC/K9	securityk9, datak9
	Data Paper PAK for Cisco 3900 series	SL-39-DATA-K9	

Functional Area	Product Description	Part Numbers	Software
Modular WAN Remote-site Router	Cisco 2951 Voice Sec. Bundle, PVDM3-32, UC and SEC License PAK	C2951-VSEC/K9	15.1(4)M4
	Cisco 2921 Voice Sec. Bundle, PVDM3-32, UC and SEC License PAK	C2921-VSEC/K9	securityk9, datak9
	Cisco 2911 Voice Sec. Bundle, PVDM3-32, UC and SEC License PAK	C2911-VSEC/K9	
	Data Paper PAK for Cisco 2900 series	SL-29-DATA-K9	
Modular WAN Remote-site Router	1941 WAAS Express only Bundle	C1941-WAASX-SEC/K9	15.1(4)M4
	Data Paper PAK for Cisco 1900 series	SL-19-DATA-K9	securityk9, datak9
Fixed WAN Remote-site Router	Cisco 881 SRST Ethernet Security Router with FXS FXO 802.11n FCC Compliant	C881SRST-K9	15.1(4)M4 securityk9, datak9

## LAN Access Layer

Functional Area	Product Description	Part Numbers	Software
Modular Access Layer Switch	Cisco Catalyst 4507R+E 7-slot Chassis with 48Gbps per slot	WS-C4507R+E	3.3.0.SG(15.1-1SG)
	Cisco Catalyst 4500 E-Series Supervisor Engine 7L-E	WS-X45-SUP7L-E	IP Base
	Cisco Catalyst 4500 E-Series 48 Ethernet 10/100/1000 (RJ45) PoE+ ports	WS-X4648-RJ45V+E	
	Cisco Catalyst 4500 E-Series 48 Ethernet 10/100/1000 (RJ45) PoE+,UPoE ports	WS-X4748-UPOE+E	
Stackable Access Layer Switch	Cisco Catalyst 3750-X Series Stackable 48 Ethernet 10/100/1000 PoE+ ports	WS-C3750X-48PF-S	15.0(1)SE2
	Cisco Catalyst 3750-X Series Stackable 24 Ethernet 10/100/1000 PoE+ ports	WS-C3750X-24P-S	IP Base
	Cisco Catalyst 3750-X Series Two 10GbE SFP+ and Two GbE SFP ports network module	C3KX-NM-10G	
	Cisco Catalyst 3750-X Series Four GbE SFP ports network module	C3KX-NM-1G	
Standalone Access Layer Switch	Cisco Catalyst 3560-X Series Standalone 48 Ethernet 10/100/1000 PoE+ ports	WS-C3560X-48PF-S	15.0(1)SE2
	Cisco Catalyst 3560-X Series Standalone 24 Ethernet 10/100/1000 PoE+ ports	WS-C3560X-24P-S	IP Base
	Cisco Catalyst 3750-X Series Two 10GbE SFP+ and Two GbE SFP ports network module	C3KX-NM-10G	
	Cisco Catalyst 3750-X Series Four GbE SFP ports network module	C3KX-NM-1G	



Functional Area	Product Description	Part Numbers	Software
Stackable Access Layer Switch	Cisco Catalyst 2960-S Series 48 Ethernet 10/100/1000 PoE+ ports and Two 10GbE SFP+ Uplink ports	WS-C2960S-48FPD-L	15.0(1)SE2 LAN Base
	Cisco Catalyst 2960-S Series 48 Ethernet 10/100/1000 PoE+ ports and Four GbE SFP Uplink ports	WS-C2960S-48FPS-L	
	Cisco Catalyst 2960-S Series 24 Ethernet 10/100/1000 PoE+ ports and Two 10GbE SFP+ Uplink ports	WS-C2960S-24PD-L	
	Cisco Catalyst 2960-S Series 24 Ethernet 10/100/1000 PoE+ ports and Four GbE SFP Uplink ports	WS-C2960S-24PS-L	
	Cisco Catalyst 2960-S Series Flexstack Stack Module	C2960S-STACK	

## LAN Distribution Layer

Functional Area	Product Description	Part Numbers	Software
Modular Distribution Layer Virtual Switch Pair	Cisco Catalyst 6500 E-Series 6-Slot Chassis	WS-C6506-E	15.0(1)SY1 IP services
	Cisco Catalyst 6500 VSS Supervisor 2T with 2 ports 10GbE and PFC4	VS-S2T-10G	
	Cisco Catalyst 6500 16-port 10GbE Fiber Module w/DFC4	WS-X6816-10G-2T	
	Cisco Catalyst 6500 24-port GbE SFP Fiber Module w/DFC4	WS-X6824-SFP	
	Cisco Catalyst 6500 4-port 40GbE/16-port 10GbE Fiber Module w/DFC4	WS-X6904-40G-2T	
	Cisco Catalyst 6500 4-port 10GbE SFP+ adapter for WX-X6904-40G module	CVR-CFP-4SFP10G	
Modular Distribution Layer Switch	Cisco Catalyst 4507R+E 7-slot Chassis with 48Gbps per slot	WS-C4507R+E	3.3.0.SG(15.1-1SG) Enterprise Services
	Cisco Catalyst 4500 E-Series Supervisor Engine 7-E, 848Gbps	WS-X45-SUP7-E	
	Cisco Catalyst 4500 E-Series 24-port GbE SFP Fiber Module	WS-X4624-SFP-E	
	Cisco Catalyst 4500 E-Series 12-port 10GbE SFP+ Fiber Module	WS-X4712-SFP+E	
Stackable Distribution Layer Switch	Cisco Catalyst 3750-X Series Stackable 12 GbE SFP ports	WS-C3750X-12S-E	15.0(1)SE2 IP Services
	Cisco Catalyst 3750-X Series Two 10GbE SFP+ and Two GbE SFP ports network module	C3KX-NM-10G	
	Cisco Catalyst 3750-X Series Four GbE SFP ports network module	C3KX-NM-1G	

## Data Center Core

Functional Area	Product Description	Part Numbers	Software
Core Switch	Cisco Nexus 5596 up to 96-port 10GbE, FCoE, and Fibre Channel SFP+	N5K-C5596UP-FA	NX-OS 5.1(3)N1(1a) Layer 3 License
	Cisco Nexus 5596 Layer 3 Switching Module	N55-M160L30V2	
	Cisco Nexus 5548 up to 48-port 10GbE, FCoE, and Fibre Channel SFP+	N5K-C5548UP-FA	
	Cisco Nexus 5548 Layer 3 Switching Module	N55-D160L3	
Ethernet Extension	Cisco Nexus 2000 Series 48 Ethernet 100/1000BASE-T Fabric Extender	N2K-C2248TP-1GE	—
	Cisco Nexus 2000 Series 48 Ethernet 100/1000BASE-T (enhanced) Fabric Extender	N2K-C2248TP-E	
	Cisco Nexus 2000 Series 32 1/10 GbE SFP+, FCoE capable Fabric Extender	N2K-C2232PP-10GE	

# Appendix B: Changes

This appendix summarizes the changes to this guide since the previous Cisco SBA series.

- The deployment details have been restructured into three processes; deploying a central manager, deploying a WAVE appliance, and deploying WAAS on a SRE.
- In the deployment details, checklists have been added to make it easier to know what parameters you need before starting the processes.
- In the deployment details, propagation of local configuration changes to the central manager has been enabled.

## Notes

## Feedback

Click [here](#) to provide feedback to Cisco SBA.



## SMART BUSINESS ARCHITECTURE

ALL DESIGNS, SPECIFICATIONS, STATEMENTS, INFORMATION, AND RECOMMENDATIONS (COLLECTIVELY, "DESIGNS") IN THIS MANUAL ARE PRESENTED "AS IS," WITH ALL FAULTS. CISCO AND ITS SUPPLIERS DISCLAIM ALL WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE. IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THE DESIGNS, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. THE DESIGNS ARE SUBJECT TO CHANGE WITHOUT NOTICE. USERS ARE SOLELY RESPONSIBLE FOR THEIR APPLICATION OF THE DESIGNS. THE DESIGNS DO NOT CONSTITUTE THE TECHNICAL OR OTHER PROFESSIONAL ADVICE OF CISCO, ITS SUPPLIERS OR PARTNERS. USERS SHOULD CONSULT THEIR OWN TECHNICAL ADVISORS BEFORE IMPLEMENTING THE DESIGNS. RESULTS MAY VARY DEPENDING ON FACTORS NOT TESTED BY CISCO.

Any Internet Protocol (IP) addresses used in this document are not intended to be actual addresses. Any examples, command display output, and figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses in illustrative content is unintentional and coincidental.

© 2012 Cisco Systems, Inc. All rights reserved.



**Americas Headquarters**  
Cisco Systems, Inc.  
San Jose, CA

**Asia Pacific Headquarters**  
Cisco Systems (USA) Pte. Ltd.  
Singapore

**Europe Headquarters**  
Cisco Systems International BV Amsterdam,  
The Netherlands

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco Website at [www.cisco.com/go/offices](http://www.cisco.com/go/offices).

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: [www.cisco.com/go/trademarks](http://www.cisco.com/go/trademarks). Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)