



CHAPTER 16

N Commands

The commands in this chapter apply to the Cisco MDS 9000 Family of multilayer directors and fabric switches. All commands are shown here in alphabetical order regardless of command mode. See [“About the CLI Command Modes”](#) section on page 1-3 to determine the appropriate mode for each command.

Send documentation comments to mdsfeedback-doc@cisco.com

native-autonomous-fabric-num

To create an IVR persistent FC ID database entry, use the **native-autonomous-fabric-num** command in fcdomain database configuration submode. To delete all IVR persistent FC ID database entries for a given AFID and VSAN, use the **no** form of the command.

native-autonomous-fabric-num *afid-num* **native-vsan** *vsan-id* **domain** *domain-id*

no native-autonomous-fabric-num *afid-num* **native-vsan** *vsan-id* **domain** *domain-id*

Syntax Description

<i>afid-num</i>	Specifies the native AFID. The range is 1 to 64.
native-vsan <i>vsan-id</i>	Specifies the native VSAN ID. The range is 1 to 4093.
domain <i>domain-id</i>	Specifies the domain ID. The range is 1 to 239.

Defaults

None.

Command Modes

fcdomain database configuration submode.

Command History

Release	Modification
2.1(2)	This command was introduced.

Usage Guidelines

There is only one domain ID associated with an AFID and VSAN. If you change the domain ID, all the associated FC ID mapping records are also changed.

Examples

The following example shows how to create an entry for a native AFID, VSAN, and domain:

```
switch# config t
switch(config)# ivr fcdomain database autonomous-fabric-num 10 vsan 20
switch(config-fcdomain)# native-autonomous-fabric-num 20 native-vsan 30 domain 15
switch(config-fcdomain-fcid)#
```

The following example shows how to remove all entries for a native AFID and VSAN:

```
switch# config t
switch(config)# ivr fcdomain database autonomous-fabric-num 10 vsan 20
switch(config-fcdomain)# no native-autonomous-fabric-num 20 native-vsan 30
```

Related Commands

Command	Description
ivr fcdomain database autonomous-fabric-num	Creates IVR persistent FC IDs.
show ivr fcdomain database	Displays IVR fcdomain database entry information.

[Send documentation comments to mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)

node (Cisco IOA cluster node configuration submode)

To configure IOA switch, use the **node** command. To delete a node to the cluster, use the **no** form of the command.

node { **local** | *remote-node-name* **or** *ip-address* }

no node { **local** | *remote-node-name* **or** *ip-address* }

Syntax Description	local	Specifies local node as a part of the cluster.
	remote-node-name	Specifies either through the DNS name or IPV4/IPV6 address.

Defaults	None.
----------	-------

Command Modes	Cisco IOA cluster node configuration submode.
---------------	---

Command History	Release	Modification
	NX-OS 4.2(1)	This command was introduced.

Usage Guidelines	None.
------------------	-------

Examples	The following example shows how to configure the local switch:
----------	--

```
switch(config)# ioa cluster tape_vault
switch#(config-ioa-cl)# node local
switch(config-ioa-cl-node)# node 172.23.144.95
2009 May 19 21:06:57 sjc-sw2 %CLUSTER-2-CLUSTER_QUORUM_GAIN: Cluster 0x2143000dec3ee782
now has quorum with 1 nodes
2009 May 19 21:07:03 sjc-sw2 %CLUSTER-2-CLUSTER_QUORUM_GAIN: Cluster 0x2143000dec3ee782
now has quorum with 2 nodes
sjc-sw2(config-ioa-cl-node)# end
```

Related Commands	Command	Description
	interface ioa	Configures the IOA interface.

Send documentation comments to mdsfeedback-doc@cisco.com

node

To configure Cisco SME switch, use the **node** command. To disable this command, use the **no** form of the command.

node {**local** | {*A.B.C.D* | *X:X::X* /*n*| *DNS name*}}

no node {**local** | {*A.B.C.D* | *X:X::X* /*n*| *DNS name*}}

Syntax Description

local	Configures the local switch.
<i>A.B.C.D</i>	Specifies the IP address of the remote switch in IPv4 format.
<i>X:X::X/n</i>	Specifies the IP address of the remote switch in IPv6 format.
<i>DNS name</i>	Specifies the name of the remote database.

Defaults

None.

Command Modes

Cisco SME cluster configuration submode.

Command History

Release	Modification
3.2(2)	This command was introduced.

Usage Guidelines

None.

Examples

The following example adds the Cisco SME interface from a local switch:

```
switch# config t
switch(config)# sme cluster c1
switch(config-sme-cl)# node local
switch(config-sme-cl-node)#
```

The following example adds the Cisco SME interface from a remote switch:

```
switch# config t
switch(config)# sme cluster c1
switch(config-sme-cl)# node 171.71.23.33
switch(config-sme-cl-node)#
```

Related Commands

Command	Description
show sme cluster <i>cluster name</i> node	Displays Cisco SME node information about a local or remote switch.

Send documentation comments to mdsfeedback-doc@cisco.com

npiv enable

To enable N port identifier virtualization (NPIV) for all VSANs on a switch, use the **npiv enable** command in configuration mode. To disable NPIV, use the **no** form of the command.

npiv enable

no npiv enable

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Defaults	Disabled.
-----------------	-----------

Command Modes	Configuration mode.
----------------------	---------------------

Command History	Release	Modification
	3.0(1)	This command was introduced.

Usage Guidelines	NPIV provides a means to assign multiple port IDs to a single N Port. This feature allows multiple applications on the N port to use different identifiers and allows access control, zoning, and port security to be implemented at the application level.
-------------------------	---

You must globally enable NPIV for all VSANs on the MDS switch to allow the NPIV-enabled applications to use multiple N port identifiers.
--



Note	All of the N Port Identifiers are allocated in the same VSAN.
-------------	---

Examples	The following example enables NPIV for all VSANs on the switch:
-----------------	---

<pre>switch# config terminal switch(config)# npiv enable</pre>
--

	The following example disables NPIV for all VSANs on the switch:
--	--

<pre>switch(config)# no npiv enable</pre>
--

Related Commands	Command	Description
	show interface	Displays interface configurations.

Send documentation comments to mdsfeedback-doc@cisco.com

nport

To configure the site and VSAN ID of the N ports, use the **nport** command. To delete the N port from the IOA cluster, use the **no** form of the command.

nport {**pwwn** *pwwn* **site** *site name* **vsan** *vsan-id*}

no nport {**pwwn** *pwwn* **site** *site name* **vsan** *vsan-id*}

Syntax Description

pwwn	Specifies the N port.
<i>pwwn</i>	Specifies the N port PWWN. The format is hh:hh:hh:hh:hh:hh:hh:hh.
site	Specifies an IOA site.
<i>site name</i>	Specifies an IOA site name. The maximum length is 31 characters.
vsan	Specifies the VSAN where this flow is accelerated.
<i>vsan id</i>	Specifies the VSAN ID where this flow is accelerated. The range is from 1 to 4093.

Defaults

None.

Command Modes

Configuration mode.

Command History

Release	Modification
NX-OS 4.2(1)	This command was introduced.

Usage Guidelines

None.

Examples

The following example shows how to configure the site and VSAN ID of the N port:

```
switch(config-ioa-cl)# nport pwwn 10:0:0:0:0:0:1 site SJC vsan 100
switch(config-ioa-cl)# no nport pwwn 11:0:0:0:0:0:1 site SJC vsan 100
switch(config-ioa-cl)# end
```

Related Commands

Command	Description
show ioa cluster summary	Displays the summary of all the IOA clusters.

Send documentation comments to mdsfeedback-doc@cisco.com

nport pwwn

To configure the N Port pWWN for the SAN extension tuner, use the **nport pwwn** command in SAN extension configuration mode. To revert to the default value, use the **no** form of the command.

nport pwwn *pwwn-id* **vsan** *vsan-id* **interface** **gigabitethernet** *slot/port*

no nport pwwn *pwwn-id* **vsan** *vsan-id* **interface** **gigabitethernet** *slot/port*

Syntax Description

<i>pwwn-id</i>	Specifies the port WWN ID. The format is <i>hh:hh:hh:hh:hh:hh:hh:hh</i> , where <i>h</i> is a hexadecimal number.
<i>vsan vsan-id</i>	Specifies the VSAN ID. The range is 1 to 4093.
interface gigabitethernet <i>slot/port</i>	Specifies the Gigabit Ethernet interface slot and port.

Defaults

None.

Command Modes

SAN extension configuration mode.

Command History

Release	Modification
2.0(x)	This command was introduced.

Usage Guidelines

None.

Examples

The following example shows how to add an entry to the SAN extension tuner database:

```
switch# san-ext-tuner
switch(san-ext)# nport pwwn 11:22:33:44:55:66:77:88 vsan 1 interface gigabitethernet 1/1
```

Related Commands

Command	Description
san-ext-tuner	Enters SAN extension configuration mode.
show san-ext-tuner	Shows SAN extension tuner information.

Send documentation comments to mdsfeedback-doc@cisco.com

npv enable

To enable N port virtualization (NPV), use the **npv enable** command in configuration mode. To disable this feature, use the **no** form of the command.

npv enable

no npv enable

Syntax Description

This command has no other arguments or keywords.

Defaults

None.

Command Modes

Configuration mode.

Command History

Release	Modification
3.2(1)	This command was introduced.

Usage Guidelines

When NPV is enabled, all configurations are erased and the switch is rebooted. The switch restarts in the NPV mode. All configuration and verification commands for NPV are available only when NPV is enabled on the switch. When you disable this feature, all related configurations are automatically erased and the switch is rebooted.

Examples

The following example shows how to enable NPV:

```
switch# config
switch(config)# npv enable
```

Related Commands

Command	Description
show npv status	Displays the NPV current status.

Send documentation comments to mdsfeedback-doc@cisco.com

npv auto-load-balance disruptive

To enable autoloading balance disruptive, use the **npv auto-load-balance disruptive** command in configuration mode. To disable this feature, use the **no** form of the command.

npv auto load-balancing disruptive

no npv auto load-balancing disruptive

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Defaults	None.
-----------------	-------

Command Modes	Configuration mode.
----------------------	---------------------

Command History	Release	Modification
	3.3(1)	This command was introduced.

Usage Guidelines	None.
-------------------------	-------

Examples	The following example shows how to enable autoloading balance disruptive: <pre>switch(config)# npv auto-load-balance disruptive Enabling this feature may flap the server interfaces whenever load is not in a balanced state. This process may result in traffic disruption. Do you want to proceed? (y/n): Please enter y or n Y switch(config)#</pre>
-----------------	--

Related Commands	Command	Description
	npv traffic-map server interface	Configures server interface traffic engineering.

[Send documentation comments to mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)

npv traffic-map server-interface

To configure the server interface based traffic engineering, use the **npv traffic-map server-interface** command in configuration mode. To revert to the default value, use the **no** form of the command.

npv traffic-map server-interface *if-range* **external-interface** *if-range*

no npv traffic-map server-interface *if-range* **external-interface** *if-range*

Syntax Description	<i>if-range</i> Range may vary from 1 to 1.	
Defaults	None.	
Command Modes	Configuration mode.	
Command History	Release	Modification
	3.3(1a)	This command was introduced.
Usage Guidelines	None.	
Examples	The following example shows how to configure NPV traffic map server interface:	
	<pre>switch(config)# npv traffic-map server-interface fc1/1 external-interface fc1/2 switch(config)# npv traffic-map server-interface fc1/4-5 external-interface fc1/6-7 switch(config)# no npv traffic-map server-interface fc1/4-5 external-interface fc1/6-7 switch(config)# no npv traffic-map server-interface fc1/1 external-interface fc1/2 switch(config)#</pre>	
Related Commands	Command	Description
	show npv-traffic-map	Displays information about the NPV traffic map.

Send documentation comments to mdsfeedback-doc@cisco.com

ntp

To configure NTP settings on the switch, use the **ntp** command in configuration mode. To remove the settings on the switch, use the **no** form of this command.

ntp {**peer** | **server**} {*ip-address* | *ipv6-address* | *dns-name*} [**key** *key-id*] [**prefer**]

no ntp {**peer** | **server**} {*ip-address* | *ipv6-address* | *dns-name*} [**key** *key-id*] [**prefer**]

Syntax Description	
peer	Specify an NTP peer.
server	Specify an NTP server.
<i>ip-address</i>	IP address of NTP peer/server.
<i>ipv6-address</i>	IPv6 address of NTP peer/server.
<i>dns-name</i>	Domain Name Server (DNS) name of NTP peer/server. Maximum size is 80 characters.
key	(Optional) Specifies a key to be used for associating with a server.
<i>key-id</i>	Key ID. The range is from 1 to 65535.
prefer	(Optional) Specifies that the NTP peer/server be chosen for synchronisation from the set of servers that have survived the sanity checks and clock selection procedure.

Defaults None.

Command Modes Configuration mode.

Command History	Release	Modification
	NX-OS 5.0(1a)	key option added.
	1.0(2)	This command was introduced.

Usage Guidelines Use the **ntp server** command when the remote system is not expected to consider the time from the local MDS switch. If multiple NTP servers are configured, then the timing information is used for more than one server. The best server is determined by using a clock selection procedure and will be reported as the reference source.

Use the **ntp peer** command when the remote system is expected to consider the time from the local MDS switch. In a group of two peers, the more accurate peer is selected as the servers and the other peers act as a clients. If the selected server becomes invalid, another is chosen from remaining peers. Only peers at the same stratum are considered as actual peers.



Note

For the MDS switch, the default minimum polling interval is 16 seconds. As the client synchronisation with the server improves the poll interval increases to 64 seconds. If the synchronisation to the server is lost then the interval may return to the minimum polling interval.

Send documentation comments to mdsfeedback-doc@cisco.com

Examples

This example forms a server association with a server:

```
switch(config)# config t  
switch(config)# ntp server 10.10.10.10  
switch(config)#
```

This example forms a peer association with a peer :

```
switch# config t  
switch(config)# ntp peer 10.20.10.0  
switch(config)#
```

Related Commands

Command	Description
ntp distribute	Enables CFS distribution for NTP.
show ntp peers	Displays all the NTP peers.

Send documentation comments to mdsfeedback-doc@cisco.com

ntp abort

To discard the Network Time Protocol (NTP) Cisco Fabric Services (CFS) distribution session in progress, use the **ntp abort** command in configuration mode.

ntp abort

Syntax Description	This command has no other arguments or keywords.
---------------------------	--

Defaults	None.
-----------------	-------

Command Modes	Configuration mode.
----------------------	---------------------

Command History	Release	Modification
	2.0(x)	This command was introduced.

Usage Guidelines	None.
-------------------------	-------

Examples	The following example shows how to configure NTP CFS distribution session in progress:
-----------------	--

<pre>switch# config terminal switch(config)# ntp abort</pre>
--

Related Commands	Command	Description
	ntp distribute	Enables CFS distribution for NTP.
	show ntp	Displays NTP information.

Send documentation comments to mdsfeedback-doc@cisco.com

ntp commit

To apply the pending configuration pertaining to the Network Time Protocol (NTP) Cisco Fabric Services (CFS) distribution session in progress in the fabric, use the **ntp commit** command in configuration mode.

ntp commit

Syntax Description	This command has no other arguments or keywords.
---------------------------	--

Defaults	None.
-----------------	-------

Command Modes	Configuration mode.
----------------------	---------------------

Command History	Release	Modification
	2.0(x)	This command was introduced.

Usage Guidelines	None.
-------------------------	-------

Examples	The following example shows how to commit changes to the active NTP configuration:
-----------------	--

```
switch# config terminal  
switch(config)# ntp commit
```

Related Commands	Command	Description
	ntp distribute	Enables CFS distribution for NTP.
	show ntp	Displays NTP information.

Send documentation comments to mdsfeedback-doc@cisco.com

ntp distribute

To enable Cisco Fabric Services (CFS) distribution for Network Time Protocol (NTP), use the **ntp distribute** command. To disable this feature, use the **no** form of the command.

ntp distribute

no ntp distribute

Syntax Description	This command has no other arguments or keywords.
---------------------------	--

Defaults	Disabled.
-----------------	-----------

Command Modes	Configuration mode.
----------------------	---------------------

Command History	This command was introduced in Cisco MDS SAN-OS Release 1.0(2).
------------------------	---

Command History	Release	Modification
	2.0(x)	This command was introduced.

Usage Guidelines	Before distributing the Fibre Channel timer changes to the fabric, the temporary changes to the configuration must be committed to the active configuration using the ntp commit command.
-------------------------	--

Examples	The following example shows how to distribute the active NTP configuration to the fabric:
-----------------	---

```
switch# config terminal
switch(config)# ntp distribute
```

Related Commands	Command	Description
	ntp commit	Commits the NTP configuration changes to the active configuration.
	show ntp	Displays NTP information.

Send documentation comments to mdsfeedback-doc@cisco.com

ntp sync-retry

To retry synchronization with configured servers, use the **ntp sync-retry** command.

ntp sync-retry

Syntax Description This command has no arguments or keywords.

Defaults None.

Command Modes EXEC mode.

Command History	Release	Modification
	4.1(1b)	Added a note.
	3.3(1a)	This command was introduced.

Usage Guidelines None.



Note

If the user changes the mgmt0 ip address, NX-OS should conditionally do an internal **ntp synchronization-retry**.

Examples The following example displays the sup-fc0 message logs:

```
switch# ntp sync-retry
```

Related Commands	Command	Description
	ntp distribute	Enables CFS distribution for NTP.
	show ntp	Displays NTP information.

[Send documentation comments to mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)

nwwn (DPVM database configuration submode)

To add a device to a dynamic port VSAN membership (DPVM) database using the nWWN, use the **nwwn** command in DPVM database configuration submode. To remove a device from a DPVM database using the nWWN, use the **no** form of the command.

nwwn *nwwn-id* **vsan** *vsan-id*

no nwwn *nwwn-id* **vsan** *vsan-id*

Syntax Description

<i>nwwn-id</i>	Specifies the node WWN ID. The format is <i>hh:hh:hh:hh:hh:hh:hh</i> , where <i>h</i> is a hexadecimal number.
vsan <i>vsan-id</i>	Specifies the VSAN ID. The range is 1 to 4093.

Defaults

None.

Command Modes

DPVM database configuration submode.

Command History

Release	Modification
2.0(x)	This command was introduced.

Usage Guidelines

To use this command, DPVM must be enabled using the **dpvm enable** command.

Examples

The following example shows how to add an entry to the DPVM database:

```
switch# config terminal
switch(config)# dpvm database
switch(config-dpvm-db)# nwwn 11:22:33:44:55:66:77:88 vsan 1
```

The following example shows how to delete an entry from the DPVM database:

```
switch(config-dpvm-db)# no nwwn 11:22:33:44:55:66:77:88 vsan 1
```

Related Commands

Command	Description
dpvm database	Configures the DPVM database.
show dpvm	Displays DPVM database information.

[Send documentation comments to mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)

nwwn (SAN extension configuration mode)

To configure the nWWN for the SAN extension tuner, use the **nwwn** command in SAN extension configuration submode.

nwwn *nwwn-id*

Syntax Description

<i>nwwn-id</i>	Specifies the nWWN address. The format is <i>hh:hh:hh:hh:hh:hh:hh:hh</i> , where <i>h</i> is a hexadecimal number.
----------------	--

Defaults

None.

Command Modes

SAN extension configuration mode.

Command History

Release	Modification
2.0(x)	This command was introduced.

Usage Guidelines

None.

Examples

The following example shows how to add an entry to the SAN extension tuner database:

```
switch# san-ext-tuner
switch(san-ext)# nwwn 20:42:00:0b:46:79:f1:80
```

Related Commands

Command	Description
san-ext-tuner	Enters SAN extension configuration mode.
show san-ext-tuner	Shows SAN extension tuner information.