



C Commands

This chapter describes the Cisco Nexus 1000V commands that begin with the letter, C.

cache size

To specify a cache size for a Netflow flow monitor, use the **cache size** command. To remove the cache size for a flow monitor, use the **no** form of this command.

cache size *value*

no cache size *value*

Syntax Description	<i>value</i> Size in number of entries. The range is 256 to 16384 entries.				
Defaults	4096 entries				
Command Modes	Netflow Monitor Configuration (config-flow-monitor)				
Supported User Roles	network-admin				
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>4.0(4)SV1(1)</td><td>This command was introduced.</td></tr></table>	Release	Modification	4.0(4)SV1(1)	This command was introduced.
Release	Modification				
4.0(4)SV1(1)	This command was introduced.				
Usage Guidelines	Use the cache-size command to limit the impact of the Netflow flow monitor cache on memory and performance.				
Examples	This example shows how to configure the cache size for a Netflow flow monitor named MonitorTest, and then display the configuration:				

Send document comments to nexus1k-docfeedback@cisco.com.

```
n1000v# config t
n1000v(config)# flow monitor MonitorTest
n1000v(config-flow-monitor)# cache size 15000
n1000v(config-flow-monitor)# show flow monitor MonitorTestFlow
Monitor monitortest:
    Use count: 0
    Inactive timeout: 600
    Active timeout: 1800
    Cache Size: 15000
n1000v(config-flow-monitor)#
```

This example shows how to remove a cache size from a flow monitor:

```
n1000v# config t
n1000v(config)# flow monitor MonitorTest
n1000v(config-flow-monitor)# no cache size
n1000v(config-flow-monitor)# show flow monitor MonitorTestFlow
n1000v(config-flow-monitor)#
Monitor monitortest:
    Use count: 0
    Inactive timeout: 600
    Active timeout: 1800
    Cache Size: 4096
n1000v(config-flow-monitor)#
```

Related Commands

Command	Description
show flow monitor	Displays information about the flow monitor cache module.
flow monitor	Creates a flow monitor.
timeout	Specifies an aging timer and its value for aging entries from the cache.
record	Adds a flow record to the flow monitor.
exporter	Adds a flow exporter to the flow monitor.

Send document comments to nexus1k-docfeedback@cisco.com.

capability

To set a particular profile capability, use the **capability** command. To remove the profile capability, use the **no** form of this command.

capability {uplink | l3control}

no capability [uplink | l3control]

Syntax Description	uplink	Sets the uplink capability for this profile.
	l3control	Sets the L3AIPC capability for this profile. Used for configuring ERSPAN enabled port profiles for l3 control.

Defaults	None
----------	------

Command Modes	Port Profile Configuration (config-port-prof)
---------------	---

Supported User Roles	network-admin
----------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	This command allows the port to be used as an uplink port. In vCenter Server, the port groups with uplink port profiles can be selected and assigned to physical ports (a vmnic or a pnica).
------------------	--



Note

If a port profile is configured as an uplink, then it cannot be used to configure VMware virtual ports.

Examples	This example shows how to configure a particular port profile capability:
----------	---

```
n1000v(config-port-prof)# capability uplink
```

This example shows how to remove the port profile configuration:

```
n1000v(config)# no capability uplink
```

Related Commands

Send document comments to nexus1k-docfeedback@cisco.com.

Command	Description
port-profile	Places you into CLI Global Configuration mode for configuring the specified port profile.
show port-profile name	Displays information about the port profile(s).

Send document comments to nexus1k-docfeedback@cisco.com.

cd

To change to a different directory from the one you are currently working in, use the **cd** command.

```
cd [filesystem:[//directory] | directory]
```

Syntax Description	<i>filesystem:</i>	(Optional) Name of the file system. Valid file systems are bootflash and volatile .
	<i>//directory</i>	(Optional) Name of the directory. The directory name is case sensitive.

Defaults	bootflash
-----------------	------------------

Command Modes	Any
----------------------	-----

Supported User Roles	network-admin
-----------------------------	---------------

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	You can only change to the directories that are on the active supervisor module. Use the present working directory (pwd) command to verify the name of the directory you are currently working in.
-------------------------	---

Examples	This example shows how to change to a different directory on the current file system: <pre>n1000v# cd my-scripts</pre> This example shows how to change from the file system you are currently working in to a different file system: <pre>n1000v# cd volatile:</pre> This example shows how to revert back to the default directory, bootflash: <pre>n1000v# cd</pre>
-----------------	--

Related Commands	Command	Description
	pwd	Displays the name of the directory you are currently working in.

Send document comments to nexus1k-docfeedback@cisco.com.

cdp advertise

To specify the CDP version to advertise, use the **cdp advertise** command. To remove the cdp advertise configuration, use the **no** form of this command.

cdp advertise {v1 | v2}

no cdp advertise [v1 | v2]

Syntax Description	<table><tr><td>v1</td><td>CDP Version 1.</td></tr><tr><td>v2</td><td>CDP Version 2.</td></tr></table>		v1	CDP Version 1.	v2	CDP Version 2.
v1	CDP Version 1.					
v2	CDP Version 2.					
Defaults	CDP Version 2					
Command Modes	Global Configuration (config)					
SupportedUserRoles	network-admin					
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>4.0(4)SV1(1)</td><td>This command was introduced.</td></tr></table>		Release	Modification	4.0(4)SV1(1)	This command was introduced.
Release	Modification					
4.0(4)SV1(1)	This command was introduced.					
Usage Guidelines						
Examples	This example shows how to set CDP Version 1 as the version to advertise: <pre>n1000v(config)# cdp advertise v1</pre> This example shows how to remove CDP Version 1 as the configuration to advertise: <pre>n1000v(config)# no cdp advertise v1</pre>					
Related Commands	<table><tr><th>Command</th><th>Description</th></tr><tr><td>show cdp global</td><td>Displays the CDP configuration.</td></tr></table>		Command	Description	show cdp global	Displays the CDP configuration.
Command	Description					
show cdp global	Displays the CDP configuration.					

Send document comments to nexus1k-docfeedback@cisco.com.

cdp enable (global)

To enable Cisco Discovery Protocol (CDP) globally on all interfaces and port channels, use the **cdp enable** command. To disable CDP globally, use the **no** form of this command.

cdp enable

no cdp enable

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Defaults	None
-----------------	------

Command Modes	Global Configuration (config)
----------------------	-------------------------------

Supported User Roles	network-admin
-----------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	CDP can only be configured on physical interfaces and port channels.
-------------------------	--

Examples	This example shows how to enable CDP globally and then show the CDP configuration:
-----------------	--

```
n1000v# config t
n1000v(config)# cdp enable
n1000v(config)# show cdp global
Global CDP information:
  CDP enabled globally
  Refresh time is 60 seconds
  Hold time is 180 seconds
  CDPv2 advertisements is enabled
  DeviceID TLV in System-Name(Default) Format
```

This example shows how to disable CDP globally and then show the CDP configuration:

```
n1000v(config)# no cdp enable
n1000v# show cdp global
Global CDP information:
  CDP disabled globally
  Refresh time is 60 seconds
  Hold time is 180 seconds
  CDPv2 advertisements is enabled
  DeviceID TLV in System-Name(Default) Format
n1000v(config)#
```

■ cdp enable (global)

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands	Command	Description
	show cdp global	Displays the CDP configuration.
	cdp enable (interface or port channel)	Enables CDP on an interface or port channel.

Send document comments to nexus1k-docfeedback@cisco.com.

cdp enable (interface or port channel)

To enable Cisco Discovery Protocol (CDP) on an interface or port channel, use the **cdp enable** command. To disable it, use the **no** form of this command.

cdp enable

no cdp enable

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Defaults	None
-----------------	------

Command Modes	Interface Configuration (config-if)
----------------------	-------------------------------------

Supported User Roles	network-admin
-----------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	CDP must be enabled globally before you configure the device ID format. CDP can only be configured on physical interfaces and port channels.
-------------------------	--

Examples	This example shows how to enable CDP on port channel 2:
-----------------	---

```
n1000v# config t
n1000v(config)# interface port-channel2
n1000v(config-if)# cdp enable
n1000v(config-if)#
```

This example shows how to disable CDP on mgmt0:

```
n1000v# config t
n1000v(config)# interface mgmt0
n1000v(config-if)# no cdp enable
n1000v(config-if)# show cdp interface mgmt0
    mgmt0 is up
    CDP disabled on interface
    Sending CDP packets every 60 seconds
    Holdtime is 180 seconds
n1000v(config-if)#
```

 `cdp enable (interface or port channel)`

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands	Command	Description
	<code>show cdp interface</code>	Displays the CDP configuration for an interface.
	<code>show cdp neighbors</code>	Displays your device from the upstream device.
	<code>cdp advertise</code>	Assigns the CDP version the interface will advertise—CDP Version 1 or CDP Version 2.
	<code>cdp format device ID</code>	Assigns the CDP device ID
	<code>cdp holdtime</code>	Sets the maximum amount of time that CDP holds onto neighbor information before discarding it.

Send document comments to nexus1k-docfeedback@cisco.com.

cdp format device-id

To specify the device ID format for CDP, use the **cdp format device-id** command. To remove it, use the **no** form of this command.

cdp format device-id { **mac-address** | **serial-number** | **system-name** }

no cdp format device-id { **mac-address** | **serial-number** | **system-name** }

Syntax Description

mac-address	MAC address of the Chassis.
serial-number	Chassis serial number.
system-name	System name/Fully Qualified Domain Name (Default).

Defaults

System name/Fully Qualified Domain Name

Command Modes

Global Configuration (config)

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

CDP must be enabled globally before you configure the device ID format.
You can configure CDP on physical interfaces and port channels only.

Examples

This example shows how to configure the CDP device ID with the MAC address format and then display the configuration:

```
n1000v(config)# cdp format device-id mac-address
n1000v(config)# show cdp global
Global CDP information:
CDP enabled globally
  Sending CDP packets every 5 seconds
  Sending a holdtime value of 10 seconds
  Sending CDPv2 advertisements is disabled
  Sending DeviceID TLV in Mac Address Format
```

This example shows how to remove the CDP device ID MAC address format from the configuration:

```
n1000v(config)# no cdp format device-id mac-address
```

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands	Command	Description
	show cdp global	Displays CDP global configuration parameters.
	show cdp interface	Displays the CDP configuration for an interface.
	show cdp neighbors	Displays your device from the upstream device.
	cdp advertise	Assigns the CDP version the interface will advertise—CDP Version 1 or CDP Version 2.
	cdp enable interface	Enables CDP on an interface or port channel.
	cdp holdtime	Sets the maximum amount of time that CDP holds onto neighbor information before discarding it.

Send document comments to nexus1k-docfeedback@cisco.com.

cdp holdtime

To do set the maximum amount of time that CDP holds onto neighbor information before discarding it, use the **cdp holdtime** command. To remove the CDP holdtime configuration, use the **no** form of this command.

cdp holdtime *seconds*

no cdp holdtime *seconds*

Syntax Description	<i>seconds</i> The range is from 10 to 255 seconds.						
Defaults	180 seconds						
Command Modes	Global Configuration (config)						
Supported User Roles	network-admin						
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>4.0(4)SV1(1)</td><td>This command was introduced.</td></tr></table>	Release	Modification	4.0(4)SV1(1)	This command was introduced.		
Release	Modification						
4.0(4)SV1(1)	This command was introduced.						
Usage Guidelines	CDP must be enabled globally before you configure the device ID format. You can configure CDP on physical interfaces and port channels only.						
Examples	This example shows how to set the CDP holdtime to 10 second: <pre>n1000v(config)# cdp holdtime 10</pre> This example shows how to remove the CDP holdtime configuration: <pre>n1000v(config)# no cdp holdtime 10</pre>						
Related Commands	<table><tr><th>Command</th><th>Description</th></tr><tr><td>show cdp global</td><td>Displays CDP global configuration parameters.</td></tr><tr><td>show cdp neighbors</td><td>Displays the upstream device from your device.</td></tr></table>	Command	Description	show cdp global	Displays CDP global configuration parameters.	show cdp neighbors	Displays the upstream device from your device.
Command	Description						
show cdp global	Displays CDP global configuration parameters.						
show cdp neighbors	Displays the upstream device from your device.						

Send document comments to nexus1k-docfeedback@cisco.com.

cdp timer

To set the refresh time for CDP to send advertisements to neighbors, use the **cdp timer** command. To remove the CDP timer configuration, use the **no** form of this command.

cdp timer *seconds*

no cdp timer *seconds*

Syntax Description	<i>seconds</i>	The range is from 5 to 254 seconds.
---------------------------	----------------	-------------------------------------

Defaults	60 seconds
-----------------	------------

Command Modes	Global Configuration (config)
----------------------	-------------------------------

Supported User Roles	network-admin
-----------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to configure the CDP timer to 10 seconds:

```
n1000v(config)# cdp timer 10
```

This example shows how to remove the CDP timer configuration:

```
n1000v(config)# no cdp timer 10
```

Related Commands	Command	Description
	show cdp global	Displays CDP global configuration parameters.
	show cdp neighbors	Displays the upstream device from your device.

Send document comments to nexus1k-docfeedback@cisco.com.

channel-group auto (port profile)

To create and define a channel group for all interfaces belonging to a port profile, use the **channel-group auto** command. To remove the channel-group, use the **no** form of this command.

channel-group auto [*mode channel_mode*] [*sub-group cdp*]

no channel-group

Syntax Description	
mode <i>channel_mode</i>	(Optional) Specify a channeling mode: - on - active (uses LACP) - passive (uses LACP)
sub-group cdp	(Optional) Creates subgroups, using CDP, for managing the traffic flow when the port profile connects to two upstream switches, also called virtual port channel host mode (vPC-HM).

Defaults	None
----------	------

Command Modes	Port Profile Configuration (config-port-prof)
---------------	---

Supported User Roles	network-admin
----------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

The **channel-group auto** command creates a unique port channel for all interfaces belonging to the same module. The channel-group is automatically assigned when the port profile is assigned to the first interface. Each additional interface belonging to the same module is added to the same port-channel. In VMware environments, a different port channel is created for each module.

- The channel group mode must be set to **on**.
- When configuring a port channel for a port profile that connects to two upstream switches, also called virtual port channel host mode (vPC-HM):
 - You know whether CDP is configured in the upstream switches.

If so, then CDP creates a subgroup for each upstream switch to manage its traffic separately.

If CDP is not configured in the upstream switch, then you must manually configure subgroups to manage the traffic flow on the separate switches.

Send document comments to nexus1k-docfeedback@cisco.com.

- If vPC-HM is not configured when port channels connect to two different upstream switches, then the VMs behind the Cisco Nexus 1000V receive duplicate packets from the network for broadcast/unknown floods/multicast.

vPC-HM can also be configured on the interface. For more information, see the *Cisco Nexus 1000V Interface Configuration Guide, Release 4.0(4)SV1(1)*.

Examples

This example shows how to configure a port channel for a port profile that connects to a single upstream switch, and then display the configuration:

```
n1000v# config t
n1000v(config)# port-profile AccessProf
n1000v(config-port-prof)# channel-group auto mode on
n1000v(config-port-prof)# show port-profile name AccessProf
port-profile AccessProf
  description: allaccess4
  status: disabled
  capability uplink: yes
  port-group: AccessProf
  config attributes:
    switchport mode access
    channel-group auto mode on
  evaluated config attributes:
    switchport mode access
    channel-group auto mode on
  assigned interfaces:
n1000v(config-port-prof)#
```

This example shows how to remove the channel group configuration from the port profile and then display the configuration:

```
n1000v# config t
n1000v(config)# port-profile AccessProf
n1000v(config-port-prof)# no channel-group
n1000v(config-port-prof)# show port-profile name AccessProf
port-profile AccessProf
  description: allaccess4
  status: disabled
  capability uplink: yes
  port-group: AccessProf
  config attributes:
    switchport mode access
  evaluated config attributes:
    switchport mode access
  assigned interfaces:
n1000v(config-port-prof)#
```

This example shows how to configure an uplink port profile, to be used by the physical NICs in the VEM, in vPC-HM when the ports in the port channel connect to two different upstream switches:

```
n1000v# config t
n1000v(config)# port-profile uplinkProf
n1000v(config-port-prof)# channel-group auto mode on sub-group cdp
n1000v(config-port-prof)# show port-profile name uplinkProf
port-profile uplinkProf
  description:
  status: disabled
  capability uplink: no
  capability l3control: no
```

Send document comments to nexus1k-docfeedback@cisco.com.

```
system vlans: none
port-group:
max-ports: 32
inherit:
config attributes:
    channel-group auto mode on sub-group cdp
evaluated config attributes:
    channel-group auto mode on sub-group cdp
assigned interfaces:
n1000v(config-port-prof)#
```

Related Commands

Command	Description
show port-profile <i>name profile-name</i>	Displays the port profile configuration.
port-profile <i>profile-name</i>	Creates a port profile and places you into CLI Global Configuration mode for the named port profile.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

channel-group (interface)

To create a port channel group or to move an interface from one port channel group to another, use the **channel-group** command. To remove the channel group configuration from an interface, use the **no** form of this command.

channel-group *number* [**force**] [**mode** {**active** | **on** | **passive**}]

no channel-group [*number*]

Syntax Description

<i>number</i>	Number of the channel group. The maximum number of port channels that can be configured is 256. The allowable range of channel group numbers that can be assigned is from 1 to 4096.
force	Forces the interface to join the channel group, although some parameters are not compatible. See Usage Guidelines below for information about the compatibility parameters and which ones can be forced.
mode	Specifies the port channel mode of the interface.
on	This is the default channel mode. All port channels that are not running LACP remain in this mode. If you attempt to change the channel mode to active or passive before enabling LACP, the device returns an error message. After you enable LACP globally, you enable LACP on each channel by configuring the channel mode as either active or passive. An interface in this mode does not initiate or respond to LACP packets. When an LACP attempts to negotiate with an interface in the on state, it does not receive any LACP packets and becomes an individual link with that interface; it does not join the channel group.
active	Specifies that when you enable the Link Aggregation Control Protocol (LACP), this command enables LACP on the specified interface. Interface is in active negotiating state, in which the port initiates negotiations with other ports by sending LACP packets.
passive	Specifies that when you enable LACP, this command enables LACP only if an LACP device is detected. The interface is in a passive negotiation state, in which the port responds to LACP packets that it receives but does not initiate LACP negotiation.

Defaults

The default mode is **on**.

Command Modes

Interface Configuration (config-if)

Supported User Roles

network-admin

Send document comments to nexus1k-docfeedback@cisco.com.

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

A port channel in the **on** channel mode is a pure port channel and can aggregate a maximum of eight ports. It does not run LACP.

If an existing port channel is not running LACP you cannot change the mode for it or any of its interfaces. If you try to do so, the channel mode remains **on** and an error message is generated.

When you delete the last physical interface from a port channel, the port channel remains. To delete the port channel completely, use the **no** form of the **port-channel** command.

When an interface joins a port channel, the following attributes are removed and replaced with the those of the port channel:

- Bandwidth
- Delay
- Extended Authentication Protocol over UDP
- VRF
- IP address
- MAC address
- Spanning Tree Protocol
- NAC
- Service policy
- Quality of Service (QoS)
- ACLs

The following attributes remain unaffected when an interface joins or leaves a port channel:

- Beacon
- Description
- CDP
- LACP port priority
- Debounce
- UDLD
- MDIX
- Rate mode
- Shutdown
- SNMP trap

You do not have to create a port channel interface before you assign a physical interface to a channel group. A port channel interface is created automatically when the channel group gets its first physical interface, if it is not already created.

Send document comments to nexus1k-docfeedback@cisco.com.

Examples

This example shows how to add an interface to LACP channel group 5 in active mode:

```
n1000v(config-if)# channel-group 5 mode active
n1000v(config-if)#
```

Related Commands

Command	Description
show interface port-channel	Displays information about the traffic on the specified port channel interface.
show port-channel summary	Displays information on the port channels.
feature lacp	Enables the LACP feature globally
show lacp port-channel	Displays LACP information.
show port-channel compatibility-parameters	Displays the list of compatibility checks that the Cisco Nexus 1000V uses.

Send document comments to nexus1k-docfeedback@cisco.com.

check logflash

To check the compactFlash, use the **check logflash** command.

check logflash [bad-blocks]

Syntax Description	bad-blocks (Optional) Finds bad blocks in compactFlash.
--------------------	--

Defaults	None
----------	------

Command Modes	Any
---------------	-----

SupportedUserRoles	network-admin
--------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples	This example shows how to check compactFlash: n1000v# check logflash
----------	--

Send document comments to nexus1k-docfeedback@cisco.com.

class (policy map type qos)

To add an existing Quality of Service (QoS) class to a policy map, use the **class** command. To remove a QoS class from a policy map, use the **no** form of this command.

```
class [type qos] { class-map-name | class-default } [insert-before [type qos]
before-class-map-name]
```

```
no class { class-map-name | class-default }
```

Syntax Description	
type qos	(Optional) Specifies the class type to be QoS. QoS is the default class type.
<i>class-map-name</i>	Adds the specified name of an existing class to the policy map.
class-default	Adds the class-default to a policy map. The class-default matches all traffic not classified in other classes.
insert-before <i>before-class-map-name</i>	(Optional) Specifies the sequence of this class in the policy by identifying the class map it should precede. If not specified, the class is placed at the end of the list of classes in the policy. Policy actions in the first class that matches the traffic type are performed.

Defaults

type QoS

The default is to reference a new class map at the end of the policy map.

The class named class-default matches all traffic not classified in other classes.

Command Modes

Policy Map Configuration (**config-pmap**)

Supported User Roles

network-admin

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Policy actions in the first class that matches the traffic type are performed.

The class named class-default matches all traffic not classified in other classes.

Examples

This example shows how to add a class map in sequence to the end of a policy map:

```
n1000v(config)# policy-map my_policy1
n1000v(config-pmap)# class traffic_class2
n1000v(config-pmap-c-qos)#
```

Send document comments to nexus1k-docfeedback@cisco.com.

This example shows how to insert a class map in sequence before an existing class map in a policy map:

```
n1000v(config)# policy-map my_policy1
n1000v(config-pmap-qos)# class insert-before traffic_class2 traffic_class1
n1000v(config-pmap-c-qos)#
```

This example shows how to add the class-default class map to a policy map:

```
n1000v(config)# policy-map my_policy1
n1000v(config-pmap-qos)# class class-default
n1000v(config-pmap-c-qos)#
```

This example shows how to remove a class map reference from a policy map:

```
n1000v(config)# policy-map my_policy1
n1000v(config-pmap)# no class traffic_class1
n1000v(config-pmap)#
```

Related Commands

Command	Description
policy-map	Creates or modifies a policy map.
set cos	Assigns a CoS to a QoS policy map.
set dscp	Assigns a DSCP value for a traffic class in a QoS policy map.
set precedence	Assigns a precedence value for the IP headers in a specific traffic class in a QoS policy map.
set discard-class	Assigns a discard-class value for a class of traffic in a QoS policy map.
show class-map qos	Displays class maps.
show policy-map	Displays policy maps and statistics.

Send document comments to nexus1k-docfeedback@cisco.com.

class-map

To create or modify a QoS class map that defines a class of traffic, use the **class-map** command. To remove a class map, use the **no** form of this command.

class-map [**type qos**] [**match-any** | **match-all**] *class-map-name*

no class-map [**type qos**] [**match-any** | **match-all**] *class-map-name*

Syntax Description	type qos	(Optional) Specifies the component type QoS for the class map. By default, the class map type is QoS.
	match-any	(Optional) Specifies that if the packet matches any of the matching criteria configured for this class map, then this class map is applied to the packet.
	match-all	(Optional) Specifies that if the packet matches all the matching criteria configured for this class map, then this class map is applied to the packet. This is the default action if match-any is not specified.
	<i>class-map-name</i>	Name assigned to the class map. The name class-default is reserved.

Defaults	type QoS match-all
-----------------	-----------------------

Command Modes	Global configuration (config)
----------------------	-------------------------------

SupportedUserRoles	network-admin
---------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	Hyphen, underscore, and alphabetic characters are allowed in the class map name.
	Forty characters are the maximum allowed in the class map name.
	Characters in the class map name are case sensitive.

Examples	This example shows how to create a class map and enter the QoS class map configuration mode to configure the specified map:
-----------------	---

```
n1000v# configure terminal
n1000v(config)# class-map my_class1
n1000v(config-cmap-qos)#
```

This example shows how to remove the QoS class map named *my_class1*:

```
n1000v(config)# no class-map my_class1
```

Send document comments to nexus1k-docfeedback@cisco.com.

```
n1000v(config)#
```

Related Commands

Command	Description
show class-map qos	Displays class maps.
match class-map	Configures the traffic class by matching packets based on match criteria in another class map.
match packet length	Configures the traffic class by matching packets based on packet lengths.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

clear access-list counters

To clear the counters for IP and MAC access control list(s) (ACLs), use the **clear access-list counters** command.

clear access-list counters [*access-list-name*]

Syntax Description

<i>access-list-name</i>	(Optional) Name of the ACL whose counters the device clears. The name can be up to 64 alphanumeric, case-sensitive characters.
-------------------------	--

Defaults

None

Command Modes

Any

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

If you specify an ACL, the name can be up to 64 alphanumeric, case-sensitive characters.

Examples

This example shows how to clear counters for all IP and MAC ACLs:

```
n1000v# clear access-list counters
n1000v#
```

This example shows how to clear counters for an IP ACL named acl-ip-01:

```
n1000v# clear access-list counters acl-ip-01
n1000v#
```

Related Commands

Command	Description
clear ip access-list counters	Clears counters for IP ACLs.
clear mac access-list counters	Clears counters for MAC ACLs.
show access-lists	Displays information about one or all IP and MAC ACLs.

Send document comments to nexus1k-docfeedback@cisco.com.

clear cdp

To clear Cisco Discovery Protocol(CDP) information on an interface, use the **clear cdp** command.

clear cdp { **counters** [**interface** *slot/port*] | **table** [**interface** *slot/port*] }

Syntax Description	counters	Clear CDP counters on all interfaces.
	interface <i>slot/port</i>	(Optional) Clear CDP counters on a specified interface .
	table	Clear CDP cache on all interfaces.

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

Supported User Roles	network-admin network-operator
-----------------------------	-----------------------------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to clear CDP counters on all interfaces:

```
n1000V# clear cdp counters
```

This example shows how to clear CDP cache on all interfaces:

```
n1000V# clear cdp table
```

Related Commands	Command	Description
	show cdp all	Displays all interfaces that have CDP enabled.
	show cdp entry	Displays the CDP database entries
	show cdp global	Displays the CDP global parameters.
	show cdp interface <i>interface-type slot-port</i>	Displays the CDP interface status

■ clear cli history

Send document comments to nexus1k-docfeedback@cisco.com.

clear cli history

To clear the history of commands you have entered into the CLI, use the **clear cli history** command.

clear cli history

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

Supported User Roles	network-admin
-----------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	Use the show cli history command to display the history of the commands that you entered at the command-line interface (CLI).
-------------------------	--

Examples	This example shows how to clear the command history: <pre>n1000v# clear cli history</pre>
-----------------	--

Related Commands	Command	Description
	show cli history	Displays the command history.

Send document comments to nexus1k-docfeedback@cisco.com.

clear cores

To clear the core files, use the **clear cores** command.

clear cores [**archive**]

Syntax Description	archive (Optional) Clears the core file on the logflash filesystem.	
Defaults	None	
Command Modes	Any	
Supported User Roles	network-admin	
Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.
Usage Guidelines	Use the show system cores command to display information about the core files.	
Examples	This example shows how to clear the core file: n1000v# clear cores	
	This example shows how to clear the core on the logflash filesystem: n1000v# clear cores archive	
Related Commands	Command	Description
	show system cores	Displays the core filename.
	system cores	Configures the core filename.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

clear counters

To clear interface counters, use the **clear counters** command.

```
clear counters [ interface {all | ethernet slot/port | loopback virtual-interface-number | mgmt |  
                  port-channel port-channel-number | vethernet interface-number} ]
```

Syntax Description

interface	Clears interface counters.
all	Clears all interface counters.
ethernet <i>slot/port</i>	Clears Ethernet interface counters. The range is 1 to 66.
loopback <i>virtual-interface-number</i>	Clears loopback interface counters. The range is 0 to 1023.
mgmt	Clears the management interface (mgmt0).
port-channel <i>port-channel-number</i>	Clears port-channel interfaces. The range is 1 to 4096.
vethernet <i>interface-number</i>	Clears virtual Ethernet interfaces. The range is 1 to 1048575.

Defaults

None

Command Modes

Any

Supported User Roles

network-admin
network-operator

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples

This example shows how to clear the Ethernet interface counters:

```
n1000v(config)# clear counters ethernet 2/1
```

Related Commands

Command	Description
show interface counters	Displays the interface status, which includes the counters.

Send document comments to nexus1k-docfeedback@cisco.com.

clear debug-logfile

To clear the contents of the debug logfile, use the **clear debug-logfile** command.

clear debug-logfile *filename*

Syntax Description	<i>filename</i>	Name of the debug logfile to clear.
---------------------------	-----------------	-------------------------------------

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

Supported User Roles	network-admin
-----------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples	This example shows how to clear the debug logfile: n1000v# clear debug-logfile syslogd_debugs
-----------------	---

Related Commands	Command	Description
	debug logfile	Configures a debug logging file.
	debug logging	Enable debug logging.
	show debug logfile	Displays the contents of the debug logfile.

Send document comments to nexus1k-docfeedback@cisco.com.

clear flow exporter

To clear the statistics for a Flexible NetFlow flow exporter, use the **clear flow exporter** command in Any.

clear flow exporter { **name** *exporter-name* | *exporter-name* }

Syntax Description	name	Indicates that a flow exporter will be specified by name.
	<i>exporter-name</i>	Name of an existing flow exporter.

Command Default	None
------------------------	------

Command Modes	Any
----------------------	-----

Supported User Roles	network-admin
-----------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	You must have already enabled traffic monitoring with Flexible NetFlow using an exporter before you can use the clear flow exporter command.
-------------------------	---

Examples	The following example clears the statistics for the flow exporter named NFC-DC-PHOENIX:
-----------------	---

```
n1000v# clear flow exporter name NFC-DC-PHOENIX
n1000v#
```

Related Commands	Command	Description
	clear flow exporter	Clears the statistics for exporters.
	flow exporter	Creates a flow exporter.
	show flow exporter	Displays flow exporter status and statistics.

Send document comments to nexus1k-docfeedback@cisco.com.

clear ip access-list counters

To clear the counters for IP access control lists (ACLs), use the **clear ip access-list counters** command.

clear ip access-list counters [*access-list-name*]

Syntax Description	<i>access-list-name</i> (Optional) Name of the IP ACL whose counters you want cleared. The name can be up to 64 alphanumeric, case-sensitive characters.
--------------------	--

Defaults	None
----------	------

Command Modes	Any
---------------	-----

Supported User Roles	network-admin
----------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	If specifying an ACL by name, it can be up to 64 alphanumeric, case-sensitive characters.
------------------	---

Examples	This example shows how to clear counters for all IP ACLs:
----------	---

```
n1000v# clear ip access-list counters
n1000v#
```

This example shows how to clear counters for an IP ACL named acl-ip-101:

```
n1000v# clear ip access-list counters acl-ip-101
n1000v#
```

Related Commands	Command	Description
	clear access-list counters	Clears counters for IP and MAC ACLs.
	clear mac access-list counters	Clears counters for MAC ACLs.
	show access-lists	Displays information about one or all IP and MAC ACLs.
	show ip access-lists	Displays information about one or all IP ACLs.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

clear ip igmp interface statistics

To clear the IGMP statistics for an interface, use the **clear ip igmp interface statistics** command.

clear ip igmp interface statistics [*if-type if-number*]

Syntax Description	<i>if-type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
	<i>if-number</i>	(Optional) Interface number.

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

Supported User Roles	network-admin
	network-operator

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples	This example shows how to clear IGMP statistics for an interface:
	n1000v# clear ip igmp interface statistics ethernet 2/1
	n1000v#

Related Commands	Command	Description
	show ip igmp interface	Displays information about IGMP interfaces.

Send document comments to nexus1k-docfeedback@cisco.com.

clear ip igmp snooping statistics vlan

To clear the IGMP snooping statistics for VLANs, use the **clear ip igmp snooping statistics vlan** command.

clear ip igmp snooping statistics vlan {*vlan-id* | **all**}

Syntax Description

<i>vlan-id</i>	VLAN number. The range is from 1 to 3967 and 4048 to 4093.
all	Applies to all VLANs.

Defaults

None

Command Modes

Any

Supported User Roles

network-admin
network-operator

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples

This example shows how to clear IGMP snooping statistics for VLAN 1:

```
n1000v# clear ip igmp snooping statistics vlan 1
n1000v#
```

Related Commands

Command	Description
show ip igmp snooping statistics vlan	Displays IGMP snooping statistics by VLAN.

Send document comments to nexus1k-docfeedback@cisco.com.

clear lacp counters

To clear the statistics for all interfaces for Link Aggregation Control Protocol (LACP) groups, use the **clear lacp counters** command.

clear lacp counters [**interface port-channel** *channel-number*]

Syntax Description	<i>channel-number</i> (Optional) LACP port-channel number. The range of values is from 1 to 4096.
---------------------------	---

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

Supported User Roles	network-admin
-----------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	If you clear counters for a specific port channel, the allowable port channel numbers are from 1 to 4096. If you do not specify a channel number, the LACP counters for all LACP port groups are cleared. If you clear counters for a static port-channel group, without the aggregation protocol enabled, the device ignores the command.
-------------------------	---

Examples	This example shows how to clear all the LACP counters:
-----------------	--

```
n1000v(config)# clear lacp counters
n1000v(config) #
```

This example shows how to clear all LACP counters for the LACP port-channel group 20:

```
n1000v(config)# clear lacp counters interface port-channel 20
n1000v(config) #
```

Related Commands	Command	Description
	show lacp counters	Displays information about LACP statistics.

Send document comments to nexus1k-docfeedback@cisco.com.

clear license

To uninstall a license file from a VSM, or to uninstall an evaluation license before installing a permanent license, use the **clear license** command.

clear license *filename*

Syntax Description	<i>filename</i>	Name of the license file to be uninstalled.
---------------------------	-----------------	---

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

Supported User Roles	network-admin
-----------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	If a license is in use, you cannot uninstall it. Before uninstalling the license file, all licenses must first be transferred from the VEMs to the VSM license pool.
-------------------------	--



Caution

Service Disruption

When you uninstall a license file from a VSM, the vEthernet interfaces on the VEMs are removed from service and the traffic flowing to them from virtual machines is dropped. This traffic flow is not resumed until you add a new license file with licenses for the VEMs. We recommend notifying the server administrator that you are uninstalling a license and that this will cause the vEthernet interfaces to shut down.

Examples	This example shows how to remove the Enterprise.lic license file from a VSM:
-----------------	--

```
n1000v# clear license Enterprise.lic
Clearing license Enterprise.lic:
SERVER this_host ANY
VENDOR cisco

Do you want to continue? (y/n) y
Clearing license ..done
n1000v#
```

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands	Command	Description
	show license	Displays license information.
	install license	Installs a license file(s) on a VSM
	svs license transfer src-vem	Transfers licenses from a source VEM to another VEM, or to the VSM pool of available licenses.

Send document comments to nexus1k-docfeedback@cisco.com.

clear line

To end a session on a specified vty, use the **clear line** command.

clear line *word*

Syntax Description	<i>word</i> Specifies the vty name.
--------------------	-------------------------------------

Defaults	None
----------	------

Command Modes	Any
---------------	-----

Supported User Roles	network-admin network-operator
----------------------	-----------------------------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples	This example shows how to end a session on a specified vty: n1000v(config)# clear line
----------	--

Related Commands	Command	Description
	show users	Displays active user sessions.

Send document comments to nexus1k-docfeedback@cisco.com.

clear logging logfile

Use the **clear logging logfile** command to clear messages from the logging file.

clear logging logfile

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

SupportedUserRoles	Super user
---------------------------	------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples	This example shows how to clear messages from the logging file:
	<pre>n1000v# clear logging logfile n1000v#</pre>

Related Commands	Command	Description
	show logging logfile	Displays the logs in the local log file.

Send document comments to nexus1k-docfeedback@cisco.com.

clear logging session

Use the **clear logging session** command to clear the current logging session.

clear logging session

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

SupportedUserRoles	Super user
---------------------------	------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples	This example shows how to clear the current logging session:
-----------------	--

```
n1000v# clear logging session
n1000v#
```

Related Commands	Command	Description
	show logging session	Displays logging session status

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

clear mac access-list counters

To clear the counters for MAC access control lists (ACLs), use the **clear mac access-list counters** command.

clear mac access-list counters [*access-list-name*]

Syntax Description

<i>access-list-name</i>	(Optional) Name of the MAC ACL whose counters you want to clear. The name can be up to 64 alphanumeric, case-sensitive characters.
-------------------------	--

Defaults

None

Command Modes

Any

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

If you want counters cleared for a specific MAC ACL, the name can be up to 64 alphanumeric, case-sensitive characters.

Examples

This example shows how to clear counters for all MAC ACLs:

```
n1000v# clear mac access-list counters
n1000v#
```

This example shows how to clear counters for a MAC ACL named acl-mac-0060:

```
n1000v# clear mac access-list counters acl-mac-0060
n1000v#
```

Related Commands

Command	Description
clear access-list counters	Clears counters for IP and MAC ACLs.
clear ip access-list counters	Clears counters for IP ACLs.
show access-lists	Displays information about one or all IP and MAC ACLs.
show mac access-lists	Displays information about one or all MAC ACLs.

Send document comments to nexus1k-docfeedback@cisco.com.

clear mac address-table dynamic

To clear the dynamic address entries from the MAC address table in Layer 2, use the **clear mac address-table dynamic** command.

```
clear mac address-table dynamic [[address mac_addr] [vlan vlan-id] [interface {type slot/port | port-channel number}]]
```

Syntax Description	address	(Optional) Specifies the MAC address to remove from the table. Use the format XXXX.XXXX.XXXX.
	mac_addr	
	vlan <i>vlan-id</i>	(Optional) Specifies the VLAN from which the MAC address should be removed from the table. The range of valid values is from 1 to 4094.
	interface { <i>type slot/port</i> <i>port-channel number</i> }}	(Optional) Specifies the interface. Use either the type of interface, the slot number, and the port number, or the port-channel number.

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

Supported User Roles	network-admin
-----------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines Use the **clear mac address-table dynamic** command with no arguments to remove all dynamic entries from the table.

To clear static MAC addresses from the table, use the **no mac address-table static** command.

If the **clear mac address-table dynamic** command is entered with no options, all dynamic addresses are removed. If you specify an address but do not specify an interface, the address is deleted from all interfaces. If you specify an interface but do not specify an address, the device removes all addresses on the specified interfaces.

Examples This example shows how to clear all the dynamic Layer 2 entries from the MAC address table:

```
n1000v(config)# clear mac address-table dynamic
n1000v(config) #
```

This example shows how to clear all the dynamic Layer 2 entries from the MAC address table for VLAN 20 on port 2/20:

clear mac address-table dynamic

Send document comments to nexus1k-docfeedback@cisco.com.

```
n1000v(config)# clear mac address-table dynamic vlan 20 interface ethernet 2/20
n1000v(config)#
```

Related Commands

Command	Description
show mac address-table	Displays the information about the MAC address table.

Send document comments to nexus1k-docfeedback@cisco.com.

clear ntp statistics

To clear the Network Time Protocol statistics, use the **clear ntp statistics** command.

clear ntp statistics {**all-peers** | **io** | **local** | **memory**}

Syntax Description	all-peers	Clear statistics for all NTP peers.
	io	Clear IO statistics.
	local	Clear local statistics.
	memory	Clear memory statistics.

Defaults	None
----------	------

Command Modes	Any
---------------	-----

Supported User Roles	network-admin network-operator
----------------------	-----------------------------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to clear statistics for all NTP peers:

```
n1000v(config)# clear ntp statistics all-peers
```

Related Commands	Command	Description
	show ntp peers	Displays information about NTP peers.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

clear port-security

To clear dynamically-learned, secure MAC address(es), use the **clear port-security** command.

```
clear port-security {dynamic} {interface vethernet veth-number | address address} [vlan
vlan-id]
```

Syntax Description		
dynamic		Specifies that you want to clear dynamically-learned, secure MAC addresses.
interface vethernet veth-number		Specifies the interface of the dynamically learned, secure MAC addresses that you want to clear.
address address		Specifies a single MAC address to be cleared, where <i>address</i> is the MAC address.
vlan vlan-id		Specifies the VLAN of the secure MAC addresses to be cleared. Valid VLAN IDs are from 1 to 4096.

Defaults	dynamic
----------	----------------

Command Modes	Any
---------------	-----

SupportedUserRoles	network-admin
--------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to remove dynamically learned, secure MAC addresses from the veth1 interface:

```
n1000v# config t
n1000v(config)# clear port-security dynamic interface veth 1
```

This example shows how to remove the dynamically learned, secure MAC address 0019.D2D0.00AE:

```
n1000v# config t
n1000v(config)# clear port-security dynamic address 0019.D2D0.00AE
```

Related Commands

Send document comments to nexus1k-docfeedback@cisco.com.

Command	Description
debug port-security	Provides debugging information for port security.
show port-security	Shows information about port security.
switchport port-security	Enables port security on a Layer 2 interface.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

clear qos statistics

To clear the counters for QoS statistics, use the **clear qos statistics** command.

```
clear qos statistics {interface [ethernet type/slot | vethernet number | port-channel number] }
                    [input type qos | output type qos]}
```

Syntax Description

interface	(Optional) Identifies a specific interface for which to clear statistics.
input type qos	(Optional) Clears only input QoS statistics.
output type qos	(Optional) Clears only output QoS statistics.

Defaults

None

Command Modes

Any

Supported User Roles

network-admin
network-operator

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

If you do not specify an interface, the counters are cleared for all interfaces.

Examples

This example shows how to clear QoS statistics for all interfaces:

```
n1000v# clear qos statistics
n1000v#
```

This example shows how to clear all input QoS statistics for veth2:

```
n1000v# clear qos statistics veth2 input type qos
n1000v#
```

Related Commands

Command	Description
qos statistics	Enables or disables QoS statistics.
show qos statistics	Displays QoS statistics.

Send document comments to nexus1k-docfeedback@cisco.com.

clear ssh hosts

To clear the Secure Shell (SSH) host sessions, use the **clear ssh hosts** command.

clear ssh hosts

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

Supported User Roles	network-admin
-----------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples	This example shows how to clear all SSH host sessions: n1000v# clear ssh hosts
-----------------	--

Related Commands	Command	Description
	ssh server enable	Enables the SSH server.

Send document comments to nexus1k-docfeedback@cisco.com.

clear system reset-reason

To clear the device reset-reason history, use the **clear system reset-reason** command.

clear system reset-reason

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

Supported User Roles	network-admin
-----------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples	This example shows how to clear reset-reason history:
	n1000v# clear system reset-reason

Related Commands	Command	Description
	show system reset-reason	Displays the device reset-reason history.

Send document comments to nexus1k-docfeedback@cisco.com.

clear user

To clear a user session, use the **clear user** command.

clear user *user-id*

Syntax Description	<i>user-id</i>	User identifier.
Defaults	None	
Command Modes	Any	
Supported User Roles	network-admin	
Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.
Usage Guidelines	Use the show users command to display the current user sessions on the device.	
Examples	This example shows how to clear all SSH host sessions: n1000v# clear user user1	
Related Commands	Command	Description
	show users	Displays the user session information.

Send document comments to nexus1k-docfeedback@cisco.com.

cli var name

To define a command line interface (CLI) variable for a terminal session, use the **cli var name** command. To remove the CLI variable, use the **no** form of this command.

cli var name *variable-name variable-text*

cli no var name *variable-name*

Syntax Description	<i>variable-name</i>	Name of the variable. The name is alphanumeric, case sensitive, and has a maximum of 31 characters.
	<i>variable-text</i>	Variable text. The text is alphanumeric, can contain spaces, and has a maximum of 200 characters.

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

Supported User Roles	network-admin
-----------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	You can reference a CLI variable using the following syntax:
	<code>\$(variable-name)</code>
	Instances where you can use variables include the following:
	• Command scripts • Filenames
	You cannot reference a variable in the definition of another variable.
	You can use the predefined variable, <code>TIMESTAMP</code> , to insert the time of day. You cannot change or remove the <code>TIMESTAMP</code> CLI variable.
	You must remove a CLI variable before you can change its definition.

Examples	This example shows how to define a CLI variable: <pre>n1000v# cli var name testinterface interface 2/3</pre>
-----------------	---

Send document comments to nexus1k-docfeedback@cisco.com.

This example shows how to reference the `TIMESTAMP` variable:

```
n1000v# copy running-config > bootflash:run-config-$(TIMESTAMP).cnfg
```

This example shows how to remove a CLI variable:

```
n1000v# cli no var name testinterface interface 2/3
```

Related Commands

Command	Description
<code>show cli variables</code>	Displays the CLI variables.

Send document comments to nexus1k-docfeedback@cisco.com.

clock set

To manually set the clock, use the **clock set** command.

clock set *time day month year*

Syntax Description	<i>time</i>	Time of day. The format is <i>HH:MM:SS</i> .
	<i>day</i>	Day of the month. The range is from 1 to 31.
	<i>month</i>	Month of the year. The values are January, February, March, April, May, June, July, August, September, October, November, and December .
	<i>year</i>	Year. The range is from 2000 to 2030.

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

Supported User Roles	network-admin
-----------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	Use this command when you cannot synchronize your device with an outside clock source, such as NTP.
-------------------------	---

Examples	This example shows how to manually set the clock: n1000v# clock set 9:00:00 1 June 2008
-----------------	---

Related Commands	Command	Description
	show clock	Displays the clock time.

Send document comments to nexus1k-docfeedback@cisco.com.

clock summer-time

To configure the summer-time (daylight saving time) offset, use the **clock summer-time** command. To revert to the default, use the **no** form of this command.

clock summer-time *zone-name start-week start-day start-month start-time end-week end-day end-month end-time offset-minutes*

no clock summer-time

Syntax Description	
<i>zone-name</i>	Time zone string. The time zone string is a three-character string.
<i>start-week</i>	Week of the month to start the summer-time offset. The range is from 1 to 5.
<i>start-day</i>	Day of the month to start the summer-time offset. Valid values are Monday, Tuesday, Wednesday, Thursday, Friday, Saturday, or Sunday .
<i>start-month</i>	Month to start the summer-time offset. Valid values are January, February, March, April, May, June, July, August, September, October, November, and December .
<i>start-time</i>	Time to start the summer-time offset. The format is <i>hh:mm</i> .
<i>end-week</i>	Week of the month to end the summer-time offset. The range is from 1 to 5.
<i>end-day</i>	Day of the month to end the summer-time offset. Valid values are Monday, Tuesday, Wednesday, Thursday, Friday, Saturday, or Sunday .
<i>end-month</i>	Month to end the summer-time offset. Valid values are January, February, March, April, May, June, July, August, September, October, November, and December .
<i>end-time</i>	Time to end the summer-time offset. The format is <i>hh:mm</i> .
<i>offset-minutes</i>	Number of minutes to offset the clock. The range is from 1 to 1440.

Defaults None

Command Modes Global Configuration (config)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Send document comments to nexus1k-docfeedback@cisco.com.

Examples

This example shows how to configure the offset for summer-time or daylight saving time:

```
n1000v# configure terminal
n1000v(config)# clock summer-time PDT 1 Sunday March 02:00 1 Sunday November 02:00 60
```

This example shows how to remove the summer-time offset:

```
n1000v# configure terminal
n1000v(config)# no clock summer-time
```

Related Commands

Command	Description
show clock	Displays clock summer-time offset configuration.

Send document comments to nexus1k-docfeedback@cisco.com.

clock timezone

To configure the time zone offset from Coordinated Universal Time (UTC), use the **clock timezone** command. To revert to the default, use the **no** form of this command.

clock timezone *zone-name offset-hours offset-minutes*

no clock timezone

Syntax Description	<i>zone-name</i>	Zone name. The name is a 3-character string for the time zone acronym (for example, PST or EST).
	<i>offset-hours</i>	Number of hours offset from UTC. The range is from -23 to 23.
	<i>offset-minutes</i>	Number of minutes offset from UTC. The range is from 0 to 59.

Defaults	None
----------	------

Command Modes	Any
---------------	-----

Supported User Roles	network-admin
----------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to configure the time zone offset from UTC:

```
n1000v# clock timezone EST 5 0
```

This example shows how to remove the time zone offset:

```
n1000v# no clock timezone
```

Related Commands	Command	Description
	show clock	Displays the clock time.

Send document comments to nexus1k-docfeedback@cisco.com.

collect counter

To configure the number of bytes or packets in a flow as a non-key field and collect the number of bytes or packets seen for a Flexible NetFlow flow record, use the **collect counter** command. To disable the counters, use the **no** form of this command.

collect counter {bytes [long] | packets [long]}

no collect counter {bytes [long] | packets [long]}

Syntax Description	bytes	Configures the number of bytes or packets seen in a flow as a non-key field and enables collecting the total number of bytes from the flow.
	long	(Optional) Enables collecting the total number of bytes from the flow using a 64 bit counter.
	packets	Configures the number of bytes seen in a flow as a non-key field and enables collecting the total number of packets from the flow.

Command Default This command is not enabled by default.

Command Modes Flow Record Configuration

Supported User Roles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples The following example enables collecting the total number of bytes from the flows as a non-key field:

```
n1000v(config)# flow record FLOW-RECORD-1
n1000v(config-flow-record)# collect counter bytes
```

The following example enables collecting the total number of bytes from the flows as a non-key field using a 64 bit counter:

```
n1000v(config)# flow record FLOW-RECORD-1
n1000v(config-flow-record)# collect counter bytes long
```

The following example enables collecting the total number of packets from the flows as a non-key field:

```
n1000v(config)# flow record FLOW-RECORD-1
n1000v(config-flow-record)# collect counter packets
```

Send document comments to nexus1k-docfeedback@cisco.com.

The following example enables collecting the total number of packets from the flows as a non-key field using a 64 bit counter:

```
n1000v(config)# flow record FLOW-RECORD-1  
n1000v(config-flow-record)# collect counter packets long
```

Related Commands

Command	Description
collect counter	Configures the counters as a non-key field and collects the counter values.
flow record	Creates a flow record.
show flow record	Displays flow record status and statistics.

Send document comments to nexus1k-docfeedback@cisco.com.

collect timestamp sys-uptime

To collect the TIMESTAMP SYS-UPTIME for a NetFlow flow record, use the **collect timestamp sys-uptime** command. To disable the collection, use the **no** form of this command.

collect timestamp sys-uptime {first | last}

no collect timestamp sys-uptime {first | last}

Syntax Description	first	Configures the sys-uptime for the time the first packet was seen from the flows as a non-key field and enables collecting time stamps based on the sys-uptime for the time the first packet was seen from the flows.
	last	Configures the sys-uptime for the time the last packet was seen from the flows as a non-key field and enables collecting time stamps based on the sys-uptime for the time the most recent packet was seen from the flows.

Command Default This command is not enabled by default.

Command Modes Flow Record Configuration

Supported User Roles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples The following example enables collecting the sys-uptime for the time the first packet was seen from the flows:

```
n1000v(config)# flow record FLOW-RECORD-1
n1000v(config-flow-record)# collect timestamp sys-uptime first
```

The following example enables collecting the sys-uptime for the time the most recent packet was seen from the flows:

```
n1000v(config)# flow record FLOW-RECORD-1
n1000v(config-flow-record)# collect timestamp sys-uptime last
```

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands

Command	Description
flow record	Creates a flow record.
show flow record	Displays flow record status and statistics.

Send document comments to nexus1k-docfeedback@cisco.com.

collect transport tcp flags

To collect a Transmission Control Protocol (TCP) flags for a NetFlow flow record, use the **collect transport tcp flags** command. To disable the collection, use the **no** form of this command.

collect transport tcp flags

no collect transport tcp flags

Syntax Description	This command has no arguments or keywords
---------------------------	---

Command Default	This command is not enabled by default.
------------------------	---

Command Modes	Flow Record Configuration
----------------------	---------------------------

Supported User Roles	network-admin
-----------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples

The following example collects the TCP flags:

```
n1000v(config)# flow record FLOW-RECORD-1
n1000v(config-flow-record)# collect transport tcp flags
```

Related Commands	Command	Description
	flow record	Creates a flow record.
	show flow record	Displays flow record status and statistics.

Send document comments to nexus1k-docfeedback@cisco.com.

configure terminal

To access configuration commands in the CLI Global Configuration mode, use the **configure terminal** command.

configure terminal

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

SupportedUserRoles	network-admin
---------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	The configuration changes you make in the Global Configuration mode are saved in the running configuration file. To save these changes persistently across reboots and restarts, you must copy them to the startup configuration file using the copy running-config startup-config command.
-------------------------	--

Examples	This example shows how to access configuration commands in the CLI Global Configuration mode: n1000v# configure terminal n1000v(config)#
-----------------	---

Related Commands	Command	Description
	where	Displays the current configuration mode context.
	pwd	Displays the name of the present working directory.
	copy run start	Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration.

Send document comments to nexus1k-docfeedback@cisco.com.

connect

To initiate a connection with vCenter, use the **connect** command. To disconnect from vCenter, use the **no connect** form of this command.

connect

no connect

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Defaults	no connect
-----------------	------------

Command Modes	SVS Connect Configuration (config-svs-conn)
----------------------	---

SupportedUserRoles	network-admin
---------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	Upon connection to vCenter, if a username and password have not been configured for this connection, you are prompted to enter them. There can be only one active connection at a time. If a previously-defined connection is up, an error message displays and the connect command is rejected until the previous connection is closed by entering no connect.
-------------------------	---

Examples	This example shows how to connect to vCenter:
-----------------	---

```
n1000v(config#) svs connection vcWest
n1000v(config-svs-conn#) protocol vmware-vim
n1000v(config-svs-conn#) remote hostname vcMain
n1000v(config-svs-conn#) vmware dvs datacenter-name HamiltonDC
n1000v(config-svs-conn#) connect
```

This example shows how to disconnect from vCenter:

```
n1000v(config#) svs connection vcWest
n1000v(config-svs-conn#) no connect
```

Related Commands	Command	Description
	show svs connections	Displays the current connections to the Cisco Nexus 1000V.

Send document comments to nexus1k-docfeedback@cisco.com.

control vlan

To assign a control VLAN to the Cisco Nexus 1000V domain, use the **control vlan** command. To remove the control VLAN, use the **no** form of this command.

control vlan *number*

no control vlan

Syntax Description	<i>number</i>	control VLAN number.
--------------------	---------------	----------------------

Defaults	None
----------	------

Command Modes	SVS Domain Configuration (config-svs-domain)
---------------	---

Supported User Roles	network-admin
----------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	Newly-created VLANs remain unused until Layer 2 ports are assigned to them. If you enter a VLAN ID that is assigned to an internally allocated VLAN, the CLI returns an error message.
------------------	---

Examples	This example shows how to configure control VLAN 70 for domain ID 32:
----------	---

```
n1000v# config t
n1000v(config)# svs-domain
n1000v(config-svs-domain)# domain id 32
n1000v(config-svs-domain)# control vlan 70
n1000v(config-svs-domain)#
```

This example shows how to remove control VLAN 70 from domain ID 32:

```
n1000v# config t
n1000v(config)# svs-domain
n1000v(config-svs-domain)# domain id 32
n1000v(config-svs-domain)# no control vlan 70
n1000v(config-svs-domain)#
```

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands	Command	Description
	show vlan-id	Displays the configuration for the specified VLAN.
	svs-domain	Creates the domain and places you into CLI SVS Domain Configuration mode.
	domain id	Assigns a domain ID to the domain.
	packet vlan	Assigns a packet VLAN to the domain.
	show svs-domain	Displays the domain configuration.

Send document comments to nexus1k-docfeedback@cisco.com.

copy

To copy a file from a source to a destination, use the **copy** command.

copy *source-url destination-url*

Syntax Description

<i>source-url</i>	Location URL (or variable) of the source file or directory to be copied. The source can be either local or remote, depending upon whether the file is being downloaded or uploaded.
<i>destination-url</i>	Destination URL (or variable) of the copied file or directory. The destination can be either local or remote, depending upon whether the file is being downloaded or uploaded.

The format of the source and destination URLs varies according to the file or directory location. You may enter either a command-line interface (CLI) variable for a directory or a filename that follows the Cisco NX-OS file system syntax (*filesystem:[/directory]/[filename]*).

The following tables list URL prefix keywords by the file system type. If you do not specify a URL prefix keyword, the device looks for the file in the current directory.

[Table 1](#) lists URL prefix keywords for bootflash and remote writable storage file systems.

Table 1 URL Prefix Keywords for Storage File Systems

Keyword	Source or Destination
bootflash: <i>[/module/]</i>	Source or destination URL for boot flash memory. The <i>module</i> argument value is sup-active , sup-local , sup-remote , or sup-standby .
ftp:	Source or destination URL for a FTP network server. The syntax for this alias is as follows: ftp: <i>[/server]/[path]/filename</i>
scp:	Source or destination URL for a network server that supports Secure Shell (SSH) and accepts copies of files using the secure copy protocol (scp). The syntax for this alias is as follows: scp: <i>[/[username@]server]/[path]/filename</i>
sftp:	Source or destination URL for an SSH FTP (SFTP) network server. The syntax for this alias is as follows: sftp: <i>[/[username@]server]/[path]/filename</i>
tftp:	Source or destination URL for a TFTP network server. The syntax for this alias is as follows: tftp: <i>[/server[:port]]/[path]/filename</i>

Send document comments to nexus1k-docfeedback@cisco.com.

Table 2 lists the URL prefix keywords for nonwritable file systems.

Table 2 URL Prefix Keywords for Special File Systems

Keyword	Source or Destination
core:	Local memory for core files. You can copy core files from the core: file system.
debug:	Local memory for debug files. You can copy core files from the debug: file system.
log:	Local memory for log files. You can copy log files from the log: file system.
system:	Local system memory. You can copy the running configuration to or from the system: file system. The system: file system is optional when referencing the running-config file in a command.
volatile:	Local volatile memory. You can copy files to or from the volatile: file system. All files in the volatile: memory are lost when the physical device reloads.

Defaults

The default name for the destination file is the source filename.

Command Modes

Any

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

The entire copying process may take several minutes, depending on the network conditions and the size of the file, and differs from protocol to protocol and from network to network.

The colon character (:) is required after the file system URL prefix keywords (such as **bootflash**).

In the URL syntax for **ftp:**, **scp:**, **sftp:**, and **tftp:**, the server is either an IP address or a host name.

Examples

This example shows how to copy a file within the same directory:

```
n1000v# copy file1 file2
```

This example shows how to copy a file to another directory:

```
n1000v# copy file1 my_files:file2
```

This example shows how to copy a file to another supervisor module:

```
n1000v# copy file1 bootflash://sup-remote/file1.bak
```

Send document comments to nexus1k-docfeedback@cisco.com.

This example shows how to copy a file from a remote server:

```
n1000v# copy scp://10.10.1.1/image-file.bin bootflash:image-file.bin
```

Related Commands	Command	Description
	cd	Changes the current working directory.
	cli var name	Configures CLI variables for the session.
	dir	Displays the directory contents.
	move	Moves a file.
	pwd	Displays the name of the current working directory.

Send document comments to nexus1k-docfeedback@cisco.com.

copy running-config startup-config

To copy the running configuration to the startup configuration, use the **copy running-config startup-config** command.

copy running-config startup-config

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

SupportedUserRoles	network-admin
---------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	Use this command to save configuration changes in the running configuration to the startup configuration in persistent memory. When a device reload or switchover occurs, the saved configuration is applied.
-------------------------	---

Examples	This example shows how to save the running configuration to the startup configuration:
-----------------	--

```
n1000v# copy running-config startup-config
[#####] 100%
```

Related Commands	Command	Description
	show running-config	Displays the running configuration.
	show running-config diff	Displays the differences between the running configuration and the startup configuration.
	show startup-config	Displays the startup configuration.
	write erase	Erases the startup configuration in the persistent memory.