



F Commands

This chapter describes the Cisco Nexus 1000V commands that begin with the letter F.

find

To find filenames beginning with a specific character string, use the **find** command.

find *filename-prefix*

Syntax Description	<i>filename-prefix</i>	The beginning characters of a filename or the entire filename. The filename prefix is case sensitive.
Defaults	None	
Command Modes	Any	
Supported User Roles	network-admin	
Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.
Usage Guidelines	The find command searches all subdirectories under the current working directory. You can use the cd and pwd commands to navigate to the starting directory.	

Send document comments to nexus1k-docfeedback@cisco.com.

Examples

This example shows how to display filenames beginning with ospf:

```
n1000v# find ospf
/usr/bin/find: ./lost+found: Permission denied
./ospf-gr.cfg
./ospfgrconfig
./ospf-gr.conf
```

Related Commands

Command	Description
cd	Changes the current working directory.
pwd	Displays the name of the current working directory.

Send document comments to nexus1k-docfeedback@cisco.com.

flow exporter

To create or modify a NetFlow flow exporter defining where and how Flow Records are exported to the NetFlow Collector Server, use the **flow exporter** command. To remove a flow exporter, use the **no** form of this command.

flow exporter *exporter-name*

no flow exporter *exporter-name*

Syntax Description

<i>exporter-name</i>	Name of the flow exporter that is created or modified.
----------------------	--

Defaults

Flow exporters are not present in the configuration until you create them.

Command Modes

Global Configuration (config)

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples

The following example shows how to create and configure FLOW-EXPORTER-1:

```
n1000v(config)# flow exporter FLOW-EXPORTER-1
n1000v(config-flow-exporter)# description located in Pahrump, NV
n1000v(config-flow-exporter)# destination A.B.C.D
n1000v(config-flow-monitor)# dscp 32
n1000v(config-flow-monitor)# source mgmt0
n1000v(config-flow-monitor)# transport udp 59
n1000v(config-flow-monitor)# version 9
```

The following example shows how to remove FLOW-EXPORTER-1:

```
n1000v(config)# no flow exporter FLOW-EXPORTER-1
n1000v(config)#
```

Related Commands

Command	Description
clear flow exporter	Clears the flow monitor.
show flow exporter	Displays flow monitor status and statistics.
description	Adds a description to a flow record, flow monitor, or flow exporter.

Send document comments to nexus1k-docfeedback@cisco.com.

Command	Description
destination	Adds a destination IP address to a NetFlow flow exporter.
dscp	Adds a differentiated services codepoint (DSCP) to a flow exporter.
source mgmt	Adds the management interface to a flow exporter designating it as the source for NetFlow flow records.
transport udp	Adds a destination UDP port used to reach the NetFlow collector to a flow exporter.
version 9	Designates NetFlow export version 9 in the NetFlow exporter.

Send document comments to nexus1k-docfeedback@cisco.com.

flow monitor

To create a Flexible NetFlow flow monitor, or to modify an existing Flexible NetFlow flow monitor, and enter Flexible NetFlow flow monitor configuration mode, use the **flow monitor** command. To remove a Flexible NetFlow flow monitor, use the **no** form of this command.

flow monitor *monitor-name*

no flow monitor *monitor-name*

Syntax Description	<i>monitor-name</i>	Name of the flow monitor that is created or modified.
Defaults	Flow monitors are not present in the configuration until you create them.	
Command Modes	Global Configuration (config)	
Supported User Roles	network-admin	
Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Flow monitors are the Flexible NetFlow component that is applied to interfaces to perform network traffic monitoring. Flow monitors consist of a record that you add to the flow monitor after you create the flow monitor, and a cache that is automatically created at the time the flow monitor is applied to the first interface. Flow data is collected from the network traffic during the monitoring process based on the key and non-key fields in the record which is configured for the flow monitor and stored in the flow monitor cache.

Once you enter the flow monitor configuration mode, the prompt changes to the following:

```
n1000v(config-flow-monitor)#
```

Within the flow monitor configuration mode, the following keywords and arguments are available to configure the flow monitor:

- **cache**—Specifies the cache size, from 256 to 16384 entries.
- **description** *description*—Provides a description for this flow monitor; maximum of 63 characters.
- **exit**—Exits from the current configuration mode.
- **exporter** *name*—Specifies the name of an exporter to export records.
- **no**—Negates a command or sets its defaults.
- **record** { *record-name* | **netflow ipv4** *collection-type* | **netflow-original** }—Specifies a flow record to use as follows:
 - *record-name*—Name of a record.

Send document comments to nexus1k-docfeedback@cisco.com.

- **netflow ipv4 collection-type**—Specifies the traditional IPv4 NetFlow collection schemes as follows:
 - original-input**—Specifies the traditional IPv4 input NetFlow.
 - original-output**—Specifies the traditional IPv4 output NetFlow.
 - protocol-port**—Specifies the protocol and ports aggregation scheme.
- **netflow-original**—Specifies the traditional IPv4 input NetFlow with origin autonomous systems.
- **timeout {active | inactive}**—Specifies a flow timeout period as follows:
 - **active**—Specifies an active or long timeout in the range of 60 to 4092 seconds.
 - **inactive**—Specifies an inactive or normal timeout in the range of 15 to 4092 seconds.

The **netflow-original** and **original-input** keywords are the same and are equivalent to the following commands:

- **match ipv4 source address**
- **match ipv4 destination address**
- **match ip tos**
- **match ip protocol**
- **match transport source-port**
- **match transport destination-port**
- **match interface input**
- **collect counter bytes**
- **collect counter packet**
- **collect timestamp sys-uptime first**
- **collect timestamp sys-uptime last**
- **collect interface output**
- **collect transport tcp flags**

The **original-output** keywords are the same as **original-input** keywords except for the following:

- **match interface output** (instead of match interface input)
- **collect interface input** (instead of collect interface output)

Examples

The following examples creates and configures a flow monitor named FLOW-MONITOR-1:

```
n1000v(config)# flow monitor FLOW-MONITOR-1
n1000v(config-flow-monitor)# description monitor location las vegas, NV
n1000v(config-flow-monitor)# exporter exporter-name1
n1000v(config-flow-monitor)# record test-record
n1000v(config-flow-monitor)# netflow ipv4 original-input
```

Related Commands

Command	Description
clear flow monitor	Clears the flow monitor.
show flow monitor	Displays flow monitor status and statistics.

Send document comments to nexus1k-docfeedback@cisco.com.

flow record

To create a Flexible NetFlow flow record, or to modify an existing Flexible NetFlow flow record, and enter Flexible NetFlow flow record configuration mode, use the **flow record** command. To remove a Flexible NetFlow flow record, use the **no** form of this command.

flow record *record-name*

no flow record *record-name*

Syntax Description	<i>record-name</i>	Name of the flow record that is created or modified.
Defaults	Flow records are not present in the configuration until you create them.	
Command Modes	Global Configuration (config)	
Supported User Roles	network-admin	
Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Flexible NetFlow uses key and non-key fields just as original NetFlow does to create and populate flows in a cache. In Flexible NetFlow a combination of key and non-key fields is called a record. Original NetFlow and Flexible NetFlow both use the values in key fields in IP datagrams, such as the IP source or destination address and the source or destination transport protocol port, as the criteria for determining when a new flow must be created in the cache while network traffic is being monitored. A flow is defined as a stream of packets between a given source and a given destination. New flows are created whenever NetFlow analyzes a packet that has a unique value in one of the key fields.

Once you enter the flow record configuration mode, the prompt changes to the following:

```
n1000v(config-flow-record)#
```

Within the flow record configuration mode, the following keywords and arguments are available to configure the flow record:

- **collect**—Specifies a non-key field. See the **collect** command for additional information.
- **description** *description*—Provides a description for this flow record; maximum of 63 characters.
- **exit**—Exits from the current configuration mode.
- **match**—Specifies a key field. See the **match** command for additional information.
- **no**—Negates a command or sets its defaults.

Cisco NX-OS enables the following match fields by default when you create a flow record:

- **match interface input**

Send document comments to nexus1k-docfeedback@cisco.com.

- **match interface output**
- **match flow direction**

Examples

The following example creates a flow record named FLOW-RECORD-1, and enters Flexible NetFlow flow record configuration mode:

```
n1000v(config)# flow record FLOW-RECORD-1
n1000v(config-flow-record)#
```

Related Commands

Command	Description
clear flow monitor	Clears the flow monitor.
flow monitor	Creates a flow monitor.
show flow monitor	Displays flow monitor status and statistics.

Send document comments to nexus1k-docfeedback@cisco.com.

format

To format an external Flash device to erase the contents and restore it to its factory-shipped state, use the **format** command.

format *filesystem:*

Syntax Description	<i>filesystem:</i>	Name of the file system. The valid values are bootflash , logflash , slot0 , usb1 , or usb2 .
Defaults	None	
Command Modes	any	
Supported User Roles	network-admin	
Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.
Usage Guidelines	You can use this command only in the default virtual device context (VDC).	
Examples	This example shows how to format an external Flash device: n1000v# format slot0:	
Related Commands	Command	Description
	cd	Changes the current working directory.
	dir	Displays the directory contents.
	pwd	Displays the name of the current working directory.

Send document comments to nexus1k-docfeedback@cisco.com.

from (table map)

To specify a set of mappings of input field values to output field values in a table map, use the **from** command.

from *source-value to dest-value*

Syntax Description

<i>source-value</i>	Specifies the source value in the range from 0 to 63.
<i>dest-value</i>	Specifies the destination value in the range from 0 to 63.

Defaults

None

Command Modes

Table map configuration

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples

This example shows how to create a mapping from three source values to the corresponding destination values:

```
n1000v(config)# table-map cir-markdown-map
n1000v(config-tmap)# from 0 to 7
n1000v(config-tmap)# from 1 to 6
n1000v(config-tmap)# from 2 to 5
```

Related Commands

Command	Description
show table-map	Displays table maps.