

Send comments to nexus5k-docfeedback@cisco.com



L Commands

This chapter describes the Cisco NX-OS FabricPath commands that begin with L.

Send comments to nexus5k-docfeedback@cisco.com

log-adjacency-changes (FabricPath)

To configure the log changes in the adjacency state, use the **log-adjacency-changes** command. To return to the default setting, use the **no** form of this command.

log-adjacency-changes

no log-adjacency-changes

Syntax Description This command has no arguments or keywords.

Command Default ON

Command Modes FabricPath IS-IS configuration mode

Command History	Release	Modification
	5.1(3)N1(1)	This command was introduced.

Usage Guidelines This command requires an Enhanced Layer 2 license.

Examples This example shows how to configure the log changes in the adjacency state:

```
switch# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# fabricpath domain default
switch(config-fabricpath-isis)# log-adjacency-changes
switch(config-fabricpath-isis)#
```

Related Commands	Command	Description
	show fabricpath isis	Displays FabricPath IS-IS information.

Send comments to nexus5k-docfeedback@cisco.com

lsp-gen-interval (FabricPath)

To configure a link-state packet (LSP) generation interval, use the **lsp-gen-interval** command. To return to the default setting, use the **no** form of this command.

lsp-gen-interval { *lsp-max-wait* | *lsp-initial-wait* | *lsp-second-wait* }

no lsp-gen-interval { *lsp-max-wait* | *lsp-initial-wait* | *lsp-second-wait* }

Syntax Description		
<i>lsp-max-wait</i>		Maximum interval (in seconds) between two consecutive occurrences of an LSP being generated. The range is from 50 to 120000. The default is 8000.
<i>lsp-initial-wait</i>		Initial LSP generation delay (in milliseconds). The range is from 50 to 120000. The default is 50.
<i>lsp-second-wait</i>		Hold time between the first and second LSP generation (in milliseconds). The range is from 50 to 120000. The default is 50.

Command Default The defaults are as follows:

- lsp-max-wait: 8000
- lsp-initial-wait: 50
- lsp-second-wait: 50

Command Modes FabricPath IS-IS configuration mode

Command History	Release	Modification
	5.1(3)N1(1)	This command was introduced.

Usage Guidelines You can enter the **lsp-gen-interval** command to control the rate of LSP packets being generated, transmitted, and retransmitted.

This command requires an Enhanced Layer 2 license.

Examples This example shows how to configure an LSP-generation interval:

```
switch# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# fabricpath domain default
switch(config-fabricpath-isis)# lsp-gen-interval 9000 60 70
switch(config-fabricpath-isis)#
```

Related Commands	Command	Description
	show fabricpath isis	Displays FabricPath IS-IS information.

Send comments to nexus5k-docfeedback@cisco.com

lsp-mtu (FabricPath)

To configure a link-state packet (LSP) maximum transmission unit (MTU) that is generated by the Cisco NX-OS software, use the **lsp-mtu** command. To return to the default setting, use the **no** form of this command.

lsp-mtu *bytes*

no lsp-mtu *bytes*

Syntax Description	<i>bytes</i> Maximum LSP size in bytes. The range is from 128 to 4352.	
Command Default	1492 bytes	
Command Modes	FabricPath IS-IS configuration mode	
Command History	Release	Modification
	5.1(3)N1(1)	This command was introduced.
Usage Guidelines	This command requires an Enhanced Layer 2 license.	
Examples	<p>This example shows how to set the maximum LSP size to 1500 bytes:</p> <pre>switch# configure terminal Enter configuration commands, one per line. End with CNTL/Z. switch(config)# fabricpath domain default switch(config-fabricpath-isis)# lsp-mtu 1500 switch(config-fabricpath-isis)#</pre>	
Related Commands	Command	Description
	show fabricpath isis	Displays FabricPath Layer 2 IS-IS.