



Send comments to nexus5k-docfeedback@cisco.com



Cisco Nexus 5000 Series NX-OS Fabric Extender Command Reference

Cisco NX-OS Releases 4.x, 5.x

First Published: October 2008

Last Modified: July 2012

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

Text Part Number: OL-25839-01

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

Cisco Nexus 5000 Series NX-OS Fabric Extender Command Reference
© 2008-2012 Cisco Systems, Inc. All rights reserved.

Send comments to nexus5k-docfeedback@cisco.com



CONTENTS

Preface vii

Audience vii

Supported Switches vii

 Cisco Nexus 5000 Platform Switches vii

 Cisco Nexus 5500 Platform Switches viii

Organization viii

Document Conventions ix

Related Documentation x

 Release Notes x

 Configuration Guides x

 Maintain and Operate Guides xi

 Installation and Upgrade Guides xi

 Licensing Guide xi

 Command References xi

 Technical References xi

 Error and System Messages xi

 Troubleshooting Guide xii

Obtaining Documentation and Submitting a Service Request xii

xii

New and Changed Information xiii

New and Changed Information for Cisco NX-OS Releases xiii

 New and Changed Information for Cisco NX-OS Release 5.2(1)N1(1) xiii

 New and Changed Information for Cisco NX-OS Release 5.1(3)N1(1) xiii

 New and Changed Information for Cisco NX-OS Release 5.0(3)N2(1) xiv

 New and Changed Information for Cisco NX-OS Release 5.0(3)N1(1) xiv

 New and Changed Information for Cisco NX-OS Release 5.0(2)N2(1) xiv

 New and Changed Information for Cisco NX-OS Release 5.0(2)N1(1) xiv

 New and Changed Information for Cisco NX-OS Release 4.2(1)N2(1) xv

 New and Changed Information for Cisco NX-OS Release 4.2(1)N1(1) xv

 New and Changed Information for Cisco NX-OS Release 4.1(3)N1(1) xvi

 New and Changed Information for Cisco NX-OS Release 4.0(1a)N2(1) xvi

Send comments to nexus5k-docfeedback@cisco.com

A Commands FEX-1

attach fex FEX-2

D Commands FEX-3

description (fex) FEX-4

diagnostic bootup level FEX-5

F Commands FEX-7

fcoe FEX-8

feature fex FEX-10

fex FEX-11

fex associate FEX-13

fex pinning redistribute FEX-15

fex queue-limit FEX-16

H Commands FEX-17

hardware buffer-threshold FEX-18

hardware queue-limit FEX-20

hardware shared-buffer-size FEX-23

hardware uplink-pause-no-drop FEX-25

L Commands FEX-27

locator-led fex FEX-28

logging fex FEX-29

P Commands FEX-31

pinning max-links FEX-32

provision FEX-34

S Commands FEX-37

serial FEX-38

slot FEX-40

switchport mode fex-fabric FEX-41

Show Commands FEX-43

show diagnostic result fex FEX-44

show environment fex FEX-46

show fex FEX-48

show fex detail FEX-50

show fex transceiver FEX-53

Send comments to nexus5k-docfeedback@cisco.com

[show fex version](#) **FEX-55**
[show interface fex-fabric](#) **FEX-56**
[show interface fex-intf](#) **FEX-57**
[show interface transceiver fex-fabric](#) **FEX-58**
[show inventory fex](#) **FEX-60**
[show locator-led](#) **FEX-61**
[show module fex](#) **FEX-62**
[show provision](#) **FEX-64**
[show queuing interface](#) **FEX-65**
[show running-config exclude-provision](#) **FEX-68**
[show running-config fex](#) **FEX-70**
[show sprom fex](#) **FEX-72**
[show startup-config exclude-provision](#) **FEX-76**
[show system reset-reason fex](#) **FEX-77**
[show version fex](#) **FEX-78**

T Commands **FEX-79**

[type](#) **FEX-80**

Send comments to nexus5k-docfeedback@cisco.com



Preface

This preface describes the audience, organization, and conventions of the *Cisco Nexus 5000 Series NX-OS Fabric Extender Command Reference*. It also provides information on how to obtain related documentation.

This preface includes the following sections:

- [Audience, page vii](#)
- [Supported Switches, page vii](#)
- [Organization, page viii](#)
- [Document Conventions, page ix](#)
- [Related Documentation, page x](#)
- [Obtaining Documentation and Submitting a Service Request, page xii](#)

Audience

This publication is for experienced users who configure and maintain Cisco NX-OS devices.

Supported Switches

This section includes the following topics:

- [Cisco Nexus 5000 Platform Switches, page vii](#)
- [Cisco Nexus 5500 Platform Switches, page viii](#)

Cisco Nexus 5000 Platform Switches

[Table 1](#) lists the Cisco switches supported in the Cisco Nexus 5000 Platform.



Note

For more information on these switches, see the *Cisco Nexus 5500 Platform and Cisco Nexus 5000 Platform Hardware Installation Guide* available at the following URL:

http://www.cisco.com/en/US/products/ps9670/tsd_products_support_series_home.html

Send comments to nexus5k-docfeedback@cisco.com

Table 1 Supported Cisco Nexus 5000 Platform Switches

Switch	Description
Cisco Nexus 5010 Switch	The Cisco Nexus 5010 is a 1 rack unit (RU) switch. It delivers 500 Gbps of wire-speed switching capacity designed for traditional, virtualized, unified, and high-performance computing (HPC) environments.
Cisco Nexus 5020 Switch	The Cisco Nexus 5020 is a 2 rack unit (RU) switch. It delivers 1+ Tbps of wire-speed switching capacity designed for traditional, virtualized, unified, and HPC environments.



Note

The Cisco Nexus 5000 Platform switches only supports Internet Group Management Protocol (IGMP) snooping. IGMP, Protocol Independent Multicast (PIM), and Multicast Source Discovery Protocol (MSDP) are not supported on the Cisco Nexus 5000 Platform switches.

Cisco Nexus 5500 Platform Switches

Table 2 lists the Cisco switches supported in the Cisco Nexus 5500 Platform.



Note

For more information on these switches, see the *Cisco Nexus 5500 Platform and Cisco Nexus 5000 Platform Hardware Installation Guide* available at the following URL:
http://www.cisco.com/en/US/products/ps9670/tsd_products_support_series_home.html

Table 2 Supported Cisco Nexus 5500 Platform Switches

Switch	Description
Cisco Nexus 5548P Switch	The Cisco Nexus 5548P switch is the first switch in the Cisco Nexus 5500 Platform. It is a one-rack-unit (1 RU), 10-Gigabit Ethernet and Fibre Channel over Ethernet (FCoE) switch that offers up to 960-Gbps throughput and up to 48 ports.
Cisco Nexus 5596P Switch	The Cisco Nexus 5596P switch is a top-of-rack, 10-Gigabit Ethernet and FCoE switch offering up to 1920-Gigabit throughput and up to 96 ports.

Organization

This document is organized as follows:

Send comments to nexus5k-docfeedback@cisco.com

Chapter Title	Description
New and Changed Information	Describes the new and changed information for the new Cisco NX-OS software releases.
A Commands	Describes the Cisco NX-OS Fabric Extender commands that begin with A.
D Commands	Describes the Cisco NX-OS Fabric Extender commands that begin with D.
F Commands	Describes the Cisco NX-OS Fabric Extender commands that begin with F.
H Commands	Describes the Cisco NX-OS Fabric Extender commands that begin with H.
L Commands	Describes the Cisco NX-OS Fabric Extender commands that begin with L.
P Commands	Describes the Cisco NX-OS Fabric Extender commands that begin with P.
S Commands	Describes the Cisco NX-OS Fabric Extender commands that begin with S.
Show Commands	Describes the Cisco NX-OS Fabric Extender show commands.
T Commands	Describes the Cisco NX-OS Fabric Extender commands that begin with T.

Document Conventions

Command descriptions use these conventions:

Convention	Description
boldface font	Commands and keywords are in boldface.
<i>italic font</i>	Arguments for which you supply values are in italics.
[]	Elements in square brackets are optional.
{ x y z }	Alternative keywords are grouped in braces and separated by vertical bars.
[x y z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.

Screen examples use these conventions:

screen font	Terminal sessions and information that the switch displays are in screen font.
boldface screen font	Information you must enter is in boldface screen font.
<i>italic screen font</i>	Arguments for which you supply values are in italic screen font.
< >	Nonprinting characters, such as passwords, are in angle brackets.
[]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

Send comments to nexus5k-docfeedback@cisco.com

This document uses the following conventions:



Note

Means reader *take note*. Notes contain helpful suggestions or references to material not covered in the manual.



Caution

Means reader *be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

Related Documentation

Documentation for Cisco Nexus 5000 Series Switches and Cisco Nexus 2000 Series Fabric Extender is available at the following URL:

http://www.cisco.com/en/US/products/ps9670/tsd_products_support_series_home.html

The following are related Cisco Nexus 5000 Series and Cisco Nexus 2000 Series Fabric Extender documents:

Release Notes

Cisco Nexus 5000 Series and Cisco Nexus 2000 Series Release Notes

Cisco Nexus 5000 Series Switch Release Notes

Configuration Guides

Cisco Nexus 5000 Series Configuration Limits for Cisco NX-OS Release 5.0(2)N1(1)

Cisco Nexus 5000 Series Configuration Limits for Cisco NX-OS Release 4.2(1)N1(1) and Release 4.2(1)N2(1)

Cisco Nexus 5000 Series NX-OS Fibre Channel over Ethernet Configuration Guide

Cisco Nexus 5000 Series NX-OS Layer 2 Switching Configuration Guide

Cisco Nexus 5000 Series NX-OS Multicast Routing Configuration Guide

Cisco Nexus 5000 Series NX-OS Quality of Service Configuration Guide

Cisco Nexus 5000 Series NX-OS SAN Switching Configuration Guide

Cisco Nexus 5000 Series NX-OS Security Configuration Guide

Cisco Nexus 5000 Series NX-OS System Management Configuration Guide

Cisco Nexus 5000 Series NX-OS Unicast Routing Configuration Guide

Cisco Nexus 5000 Series Switch NX-OS Software Configuration Guide

Cisco Nexus 5000 Series Fabric Manager Configuration Guide, Release 3.4(1a)

Cisco Nexus 7000 Series NX-OS Fundamentals Configuration Guide, Release 6.x

Cisco Nexus 2000 Series Fabric Extender Software Configuration Guide

Send comments to nexus5k-docfeedback@cisco.com

Maintain and Operate Guides

Cisco Nexus 5000 Series NX-OS Operations Guide

Installation and Upgrade Guides

Cisco Nexus 5000 Series and Cisco Nexus 5500 Platform Hardware Installation Guide

Cisco Nexus 2000 Series Hardware Installation Guide

Cisco Nexus 5000 Series NX-OS Software Upgrade and Downgrade Guide, Release 4.2(1)N1(1)

Regulatory Compliance and Safety Information for the Cisco Nexus 5000 Series Switches and Cisco Nexus 2000 Series Fabric Extenders

Licensing Guide

Cisco NX-OS Licensing Guide

Command References

Cisco Nexus 5000 Series NX-OS FabricPath Command Reference

Cisco Nexus 5000 Series NX-OS Fabric Extender Command Reference

Cisco Nexus 5000 Series NX-OS Fibre Channel Command Reference

Cisco Nexus 5000 Series NX-OS Fundamentals Command Reference

Cisco Nexus 5000 Series NX-OS Layer 2 Interfaces Command Reference

Cisco Nexus 5000 Series NX-OS Multicast Routing Command Reference

Cisco Nexus 5000 Series NX-OS QoS Command Reference

Cisco Nexus 5000 Series NX-OS Security Command Reference

Cisco Nexus 5000 Series NX-OS System Management Command Reference

Cisco Nexus 5000 Series NX-OS TrustSec Command Reference

Cisco Nexus 5000 Series NX-OS Unicast Routing Command Reference

Cisco Nexus 5000 Series NX-OS vPC Command Reference

Technical References

Cisco Nexus 5000 Series and Cisco Nexus 2000 Series Fabric Extender MIBs Reference

Error and System Messages

Cisco NX-OS System Messages Reference

Send comments to nexus5k-docfeedback@cisco.com

Troubleshooting Guide

Cisco Nexus 5000 Troubleshooting Guide

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as an RSS feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service. Cisco currently supports RSS Version 2.0.

Send comments to nexus5k-docfeedback@cisco.com



New and Changed Information

This chapter provides release-specific information for each new and changed feature in the *Cisco Nexus 5000 Series NX-OS Fabric Extender Command Reference*. The latest version of this document is available at the following Cisco website:

http://www.cisco.com/en/US/products/ps9670/prod_command_reference_list.html

To check for additional information about this Cisco NX-OS Release, see the *Cisco Nexus 5000 Series Switch Release Notes* available at the following Cisco website:

http://www.cisco.com/en/US/products/ps9670/prod_release_notes_list.html

New and Changed Information for Cisco NX-OS Releases

This section includes the following topics:

- [New and Changed Information for Cisco NX-OS Release 5.2\(1\)N1\(1\), page xiii](#)
- [New and Changed Information for Cisco NX-OS Release 5.1\(3\)N1\(1\), page xiii](#)
- [New and Changed Information for Cisco NX-OS Release 5.0\(3\)N2\(1\), page xiv](#)
- [New and Changed Information for Cisco NX-OS Release 5.0\(3\)N1\(1\), page xiv](#)
- [New and Changed Information for Cisco NX-OS Release 5.0\(2\)N2\(1\), page xiv](#)
- [New and Changed Information for Cisco NX-OS Release 5.0\(2\)N1\(1\), page xiv](#)
- [New and Changed Information for Cisco NX-OS Release 4.2\(1\)N2\(1\), page xv](#)
- [New and Changed Information for Cisco NX-OS Release 4.2\(1\)N1\(1\), page xv](#)
- [New and Changed Information for Cisco NX-OS Release 4.1\(3\)N1\(1\), page xvi](#)
- [New and Changed Information for Cisco NX-OS Release 4.0\(1a\)N2\(1\), page xvi](#)

New and Changed Information for Cisco NX-OS Release 5.2(1)N1(1)

There are no new or changed commands for this release.

New and Changed Information for Cisco NX-OS Release 5.1(3)N1(1)

[Table 1](#) summarizes the new and changed features for Cisco NX-OS Release 5.1(3)N1(1) and tells you where they are documented.

Send comments to nexus5k-docfeedback@cisco.com

Table 1 *New and Changed Information for Release 5.1(3)N1(1)*

Feature	Description	Where Documented
FCoE over Adapter Fabric Extender (Adapter-FEX)	This feature was introduced. The following commands were updated to include support for Adapter-FEX: <ul style="list-style-type: none"> fcoe 	fcoe
Fabric Extender hardware enhancements	The The Cisco Nexus N2248TP-E Fabric Extender was introduced. The following commands were introduced on a 2248TP-E Fabric Extender: <ul style="list-style-type: none"> hardware shared-buffer-size hardware uplink-pause-no-drop The following commands were updated: <ul style="list-style-type: none"> hardware queue-limit 	hardware queue-limit hardware shared-buffer-size hardware uplink-pause-no-drop

New and Changed Information for Cisco NX-OS Release 5.0(3)N2(1)

There are no new and changed features for Cisco NX-OS Release 5.0(3)N2(1).

New and Changed Information for Cisco NX-OS Release 5.0(3)N1(1)

There are no new and changed features for Cisco NX-OS Release 5.0(3)N1(1).

New and Changed Information for Cisco NX-OS Release 5.0(2)N2(1)

There are no new and changed features for Cisco NX-OS Release 5.0(2)N2(1).

New and Changed Information for Cisco NX-OS Release 5.0(2)N1(1)

[Table 2](#) summarizes the new and changed features for Cisco NX-OS Release 5.0(2)N1(1) and tells you where they are documented.

Send comments to nexus5k-docfeedback@cisco.com

Table 2 *New and Changed Information for Release 5.0(2)N1(1)*

Feature	Description	Where Documented
Bootup diagnostic level	You can control the diagnostic level of all the Fabric Extenders connected to the switch.	diagnostic bootup level
Support for Fabric Extender preprovisioning	You can preprovision a module in a chassis slot of a Cisco Nexus 2000 Series Fabric Extender.	provision slot show provision show running-config exclude-provision show startup-config exclude-provision

New and Changed Information for Cisco NX-OS Release 4.2(1)N2(1)

[Table 3](#) summarizes the new and changed features for Cisco NX-OS Release 4.2(1)N2(1) and tells you where they are documented.

Table 3 *New and Changed Information for Release 4.2(1)N2(1)*

Feature	Description	Where Documented
Cisco Nexus 2000 Series Fabric Extender enhancements	<p>The following commands were updated:</p> <ul style="list-style-type: none"> diagnostic bootup level <p>The following commands were introduced:</p> <ul style="list-style-type: none"> hardware buffer-threshold hardware queue-limit 	diagnostic bootup level hardware buffer-threshold hardware queue-limit

New and Changed Information for Cisco NX-OS Release 4.2(1)N1(1)

[Table 4](#) summarizes the new and changed features for Cisco NX-OS Release 4.2(1)N1(1) and tells you where they are documented.

Table 4 *New and Changed Information for Release 4.2(1)N1(1)*

Feature	Description	Where Documented
Cisco Nexus 2000 Series Fabric Extender enhancements	<p>The following commands were introduced:</p> <ul style="list-style-type: none"> fex queue-limit type <p>The following commands were updated:</p> <ul style="list-style-type: none"> pinning max-links 	fex queue-limit pinning max-links type Show Commands

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

New and Changed Information for Cisco NX-OS Release 4.1(3)N1(1)

[Table 5](#) summarizes the new and changed features for Cisco NX-OS Release 4.1(3)N1(1) and tells you where they are documented.

Table 5 *New and Changed Information for Release 4.1(3)N1(1)*

Feature	Description	Where Documented
Cisco Nexus 2000 Series Fabric Extender enhancements	<p>The beacon command was deprecated and replaced with the locator-led command.</p> <p>The following commands were introduced:</p> <ul style="list-style-type: none"> show queuing interface 	locator-led fex show queuing interface

New and Changed Information for Cisco NX-OS Release 4.0(1a)N2(1)

[Table 6](#) summarizes the new and changed features for Cisco NX-OS Release 4.0(1a)N2(1) and tells you where they are documented.

Table 6 *New and Changed Information for Release 4.0(1a)N2(1)*

Feature	Description	Where Documented
Cisco Nexus 2000 Series Fabric Extender	This feature was introduced to manage a Cisco Nexus 2000 Series Fabric Extender from a Cisco Nexus 5000 Series switch.	attach fex beacon description (fex) feature fex fex fex associate fex pinning redistribute logging fex pinning max-links serial switchport mode fex-fabric Show Commands

Send comments to nexus5k-docfeedback@cisco.com



A Commands

This chapter describes the Cisco NX-OS commands that begin with A that are used to manage a Cisco Nexus 2000 Series Fabric Extender from a Cisco Nexus 5000 Series switch.

Send comments to nexus5k-docfeedback@cisco.com

attach fex

To access the command-line interface (CLI) of a connected Fabric Extender to run diagnostic commands, use the **attach fex** command.

attach fex *chassis_ID*

Syntax Description	<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
--------------------	-------------------	--

Command Default	None
-----------------	------

Command Modes	EXEC mode
---------------	-----------

Command History	Release	Modification
	4.0(1a)N2(1)	This command was introduced.

Usage Guidelines	Use the attach fex command to access the CLI on a connected Fabric Extender and performing diagnostic commands. We recommend that you use this command only following direction from Cisco technical support personnel.
------------------	--

Examples	This example shows how to access the CLI of a connected Fabric Extender to run diagnostic commands: switch# attach fex 101
----------	--

Related Commands	Command	Description
	show fex	Displays all configured Fabric Extender chassis connected to the switch.

Send comments to nexus5k-docfeedback@cisco.com



D Commands

This chapter describes the Cisco NX-OS commands that begin with D that are used to manage a Cisco Nexus 2000 Series Fabric Extender from a Cisco Nexus 5000 Series switch.

Send comments to nexus5k-docfeedback@cisco.com

description (fex)

To specify a description for a Fabric Extender, use the **description** command. To revert to the default description, use the **no** form of this command.

description *description*

no description

Syntax Description	<i>description</i> Description of a Fabric Extender. The default is the string FEXxxxx where xxxx is the chassis ID. For example, if the chassis ID is 123, the default description is FEX0123. The maximum length is 20 alphanumeric characters.							
Command Default	None							
Command Modes	Fabric extender configuration mode							
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>4.0(1a)N2(1)</td><td>This command was introduced.</td></tr></table>		Release	Modification	4.0(1a)N2(1)	This command was introduced.		
Release	Modification							
4.0(1a)N2(1)	This command was introduced.							
Examples	<p>This example shows how to specify a description for a Fabric Extender:</p> <pre>switch# configure terminal switch(config)# fex 101 switch(config-fex)# description Rack16_FEX101</pre> <p>This example shows how to revert to the default description for a Fabric Extender:</p> <pre>switch# configure terminal switch(config)# fex 101 switch(config-fex)# no description</pre>							
Related Commands	<table><tr><th>Command</th><th>Description</th></tr><tr><td>fex</td><td>Creates a Fabric Extender and enters Fabric Extender configuration mode.</td></tr><tr><td>show fex</td><td>Displays all configured Fabric Extender chassis connected to the switch.</td></tr></table>		Command	Description	fex	Creates a Fabric Extender and enters Fabric Extender configuration mode.	show fex	Displays all configured Fabric Extender chassis connected to the switch.
Command	Description							
fex	Creates a Fabric Extender and enters Fabric Extender configuration mode.							
show fex	Displays all configured Fabric Extender chassis connected to the switch.							

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

diagnostic bootup level

To configure the bootup diagnostic level to trigger diagnostics when the device boots, use the **diagnostic bootup level** command. To remove the bootup diagnostic level configuration, use the **no** form of this command.

diagnostic bootup level {bypass | complete}

no diagnostic bootup level {bypass | complete}

Syntax Description

bypass	Specifies that all bootup tests are skipped.
complete	Specifies that all bootup diagnostics are performed. This is the default value.

Command Default

Complete

Command Modes

Global configuration mode

Command History

Release	Modification
4.0(0)N1(1)	This command was introduced.
4.2(1)N2(1)	Support was added to control the diagnostic level of all the Fabric Extenders connected to the switch.

Examples

This example shows how to configure the bootup diagnostics level to trigger the complete diagnostics:

```
switch(config)# diagnostic bootup level complete  
switch(config)#
```

This example shows how to remove the bootup diagnostics level configuration:

```
switch(config)# no diagnostic bootup level complete  
switch(config)#
```

Related Commands

Command	Description
show diagnostic bootup level	Displays the bootup diagnostics level.
show diagnostic bootup result	Displays the results of the diagnostics tests.

Send comments to nexus5k-docfeedback@cisco.com

Send comments to nexus5k-docfeedback@cisco.com



F Commands

This chapter describes the Cisco NX-OS commands that begin with F that are used to manage a Cisco Nexus 2000 Series Fabric Extender from a Cisco Nexus 5000 Series switch.

Send comments to nexus5k-docfeedback@cisco.com

fcoe

To associate a Cisco Nexus 2000 Series Fabric Extender (FEX) to a switch for pinning Fibre Channel over Ethernet (FCoE) Initialization Protocol (FIP) and FCoE traffic, use the **fcoe** command. To remove the association, use the **no** form of this command.

fcoe [**vsan** *vsan-id*]

no fcoe [**vsan**]

Syntax Description	vsan <i>vsan-id</i>	Specifies the VSAN status. The VSAN ID range is from 1 to 4094.
Command Default	None	
Command Modes	FEX configuration mode VLAN configuration mode	
Command History	Release	Modification
	5.1(3)N1(1)	This command was introduced.

Usage Guidelines

Before you use this command, make sure that you enable the Fabric Extender (FEX) features on the switch by using the **feature fex** command.

You can use this command only on a Cisco Nexus 2232P Fabric Extender. When you bind an interface to a virtual Fibre Channel interface to enable FCoE traffic, you must use slot number 1. The port number can be from 1 to 32.

Examples

This example shows how to configure a FEX as FCoE enabled:

```
switch# configure terminal
switch(config)# feature fex
switch(config)# fex 100
switch(config-fex)# fcoe
switch(config-fex)#
```

This example shows how to configure a pair of FEXs to carry FCoE traffic in a fabric virtual port channel (vPC) topology, with the host uplink ports in the FEXs configured to the same port channel:

```
switch# configure terminal
switch(config)# feature lacp
switch(config)# feature fex
switch(config)# feature fcoe
switch(config)# fex 100
switch(config-fex)# fcoe
switch(config-fex)# exit
switch(config)# interface vfc 1
switch(config-if)# bind interface eth101/1/1
```


Send comments to nexus5k-docfeedback@cisco.com

```
switch(config)# interface eth101/1/1
switch(config-if)# channel-group 1
switch(config)# fex 102
switch(config-fex)# fcoe
switch(config)# interface vfc 1
switch(config-if)# bind interface eth102/1/1
switch(config)# interface eth102/1/1
switch(config-if)# channel-group 1
switch(config-if)#
```

This example shows how to configure FCoE traffic on a VLAN:

```
switch# configure terminal
switch(config)# vlan 5
switch(config-vlan)# fcoe vsan 1
switch(config-vlan)#
```

This example shows how to disable FCoE traffic on a FEX:

```
switch# configure terminal
switch(config)# fex 100
switch(config-fex)# no fcoe
switch(config-fex)#
```

Related Commands

Command	Description
feature fcoe	Enables the FCoE feature on the switch.
feature fex	Enables the FEX feature on the switch.
feature lacp	Enables the Link Aggregation Control Protocol (LACP).
show fex	Displays information about a specific FEX.

Send comments to nexus5k-docfeedback@cisco.com

feature fex

To enable Fabric Extender (FEX) features on the switch, use the **feature fex** command. To disable FEX, use the **no** form of this command.

feature fex

no feature fex

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	4.0(1a)N2(1)	This command was introduced.

Examples	This example shows how to enable FEX features on the switch:
	<pre>switch(config)# feature fex switch(config)#</pre>

Related Commands	Command	Description
	fex	Creates a Fabric Extender and enters fabric extender configuration mode.
	show feature	Displays the features enabled or disabled on the switch.

Send comments to nexus5k-docfeedback@cisco.com

fex

To create a Fabric Extender and enter fabric extender configuration mode, use the **fex** command. To delete the Fabric Extender configuration, use the **no** form of this command.

fex *chassis_ID*

no fex *chassis_ID*

Syntax Description	<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
--------------------	-------------------	--

Command Default	None
-----------------	------

Command Modes	Global configuration mode
---------------	---------------------------

Command History	Release	Modification
	4.0(1a)N2(1)	This command was introduced.

Usage Guidelines	You can create and configure the Fabric Extender before you connect and associate it to an interface on the parent switch. Once you associate the Fabric Extender to the switch, the configuration you created is transferred over to the Fabric Extender and applied.
------------------	--

Examples	This example shows how to enter Fabric Extender configuration mode:
----------	---

```
switch# configure terminal
switch(config)# fex 101
switch(config-fex)#
```

This example shows how to delete the Fabric Extender configuration:

```
switch(config-fex)# no fex 101
switch(config)#
```

Related Commands	Command	Description
	beacon	Turns on the locator beacon LED of a Fabric Extender.
	description (fex)	Specifies a description for a Fabric Extender.
	fex associate	Associates a Fabric Extender to an Ethernet or EtherChannel interface.
	pinning max-links	Specifies the number of statically pinned uplinks connected to a Fabric Extender.
	serial	Assigns a serial number to a Fabric Extender.

Send comments to nexus5k-docfeedback@cisco.com

Command	Description
show fex	Displays all configured Fabric Extender chassis connected to the switch.
type	Specifies the Fabric Extender card.

Send comments to nexus5k-docfeedback@cisco.com

fex associate

To associate a Fabric Extender to a fabric interface, use the **fex associate** command. To disassociate the Fabric Extender, use the **no** form of this command.

fex associate *chassis_ID*

no fex associate [*chassis_ID*]

Syntax Description	<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
--------------------	-------------------	--

Command Default	None
-----------------	------

Command Modes	Interface configuration mode
---------------	------------------------------

Command History	Release	Modification
	4.0(1a)N2(1)	This command was introduced.

Usage Guidelines	Before you can associate an interface on the parent switch to the Fabric Extender, you must first make the interface into a fabric interface by entering the switchport mode fex-fabric command.
------------------	---



Note

On a Cisco Nexus 5000 Series switch that runs a Cisco NX-OS release 4.2(1)N1(1), the **switchport mode fex-fabric** command is not supported on an Ethernet interface.

Examples	This example shows how to associate the Fabric Extender to an Ethernet interface:
----------	---

```
switch# configure terminal
switch(config)# interface ethernet 1/40
switch(config-if)# switchport mode fex-fabric
switch(config-if)# fex associate 101
```

This example shows how to associate the Fabric Extender to an EtherChannel interface:

```
switch# configure terminal
switch(config)# interface port-channel 4
switch(config-if)# switchport mode fex-fabric
switch(config-if)# fex associate 101
```

Send comments to nexus5k-docfeedback@cisco.com

Related Commands	Command	Description
	show fex	Displays all configured Fabric Extender chassis connected to the switch.
	switchport mode fex-fabric	Sets the interface to be an uplink port.

Send comments to nexus5k-docfeedback@cisco.com

fex pinning redistribute

To redistribute the host interfaces on a Fabric Extender, use the **fex pinning redistribute** command.

fex pinning redistribute *chassis_ID*

Syntax Description	<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
---------------------------	-------------------	--

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	4.0(1a)N2(1)	This command was introduced.

Usage Guidelines	<p>When you provision the Fabric Extender using the statically pinned mode (see the <i>Cisco Nexus 2000 Series Fabric Extender Software Configuration Guide</i>), the host interfaces on the Fabric Extender are pinned to the fabric interfaces in the order that they were initially configured. The next time that you reboot the Fabric Extender, the configured fabric interfaces are pinned to the host interfaces in an ascending order by the port number of the fabric interface.</p>
-------------------------	--

Use the **fex pinning redistribute** command if you want to configure the same fixed distribution of host interfaces without restarting the Fabric Extender after your initial configuration.



Caution

This command disrupts all the host interface ports of the Fabric Extender. However, the disruption is shorter than would be the case if you reboot the Fabric Extender.

Examples	This example shows how to redistribute the host interfaces on a Fabric Extender:
-----------------	--

```
switch# fex pinning redistribute 101
switch#
```

Related Commands	Command	Description
	pinning max-links	Defines the number of uplinks on a Fabric Extender.
	show fex	Displays all configured Fabric Extender chassis connected to the switch.
	show interface fex-intf	Displays the Fabric Extender ports pinned to a specific switch interface.

Send comments to nexus5k-docfeedback@cisco.com

fex queue-limit

To limit the amount of input buffer space (in bytes) allocated to each Fabric Extender port, use the **fex queue-limit** command. To disable the drop threshold and allow a Fabric Extender port to use all available buffer space, use the **no** form of this command.

fex queue-limit

no fex queue-limit

Syntax Description

This command has no arguments or keywords.

Command Default

Fabric Extender queue limit is available in the default configuration and is set on.

Command Modes

System QoS configuration mode

Command History

Release	Modification
4.2(1)N1(1)	This command was introduced.

Usage Guidelines

By default, the drop threshold applies to each Fabric Extender port to limit the amount of buffer being allocated for each port. To restore the default queue limit of each Fabric Extender port, use the **fex queue-limit** command.

Examples

This example shows how to set the queue limit for the input buffer for each Fabric Extender port:

```
switch(config)# system qos
switch(config-sys-qos)# fex queue-limit
switch(config-sys-qos)#
```

This example shows how to restore the default queue limit for each Fabric Extender port:

```
switch(config)# system qos
switch(config-sys-qos)# no fex queue-limit
switch(config-sys-qos)#
```

Related Commands

Command	Description
show fex	Displays all configured Fabric Extender chassis connected to the switch.

Send comments to nexus5k-docfeedback@cisco.com



H Commands

This chapter describes the Cisco NX-OS commands that begin with H that are used to manage a Cisco Nexus 2000 Series Fabric Extender from a Cisco Nexus 5000 Series switch.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

hardware buffer-threshold

To limit the amount of input hardware buffer usage for each Fabric Extender, use the **hardware buffer-threshold** command. To revert to the default and allow a Fabric Extender to use all available hardware buffer space, use the **no** form of this command.

hardware *fex_card_typ* **buffer-threshold** *buffer-limit*

no hardware *fex_card_typ* **buffer-threshold**

Syntax Description

<i>fex_card_type</i>	Fabric Extender card type. The following Fabric Extender card types are supported: <ul style="list-style-type: none"> N2148T—Fabric Extender 48x1G 4x10G SFP+ Module See the “Usage Guidelines” section for a description of this Fabric Extender.
<i>buffer-limit</i>	Buffer threshold limit in bytes. The range is from 81920 to 316160.

Command Default

None

Command Modes

Fabric extender configuration mode

Command History

Release	Modification
4.2(1)N2(1)	This command was introduced.

Usage Guidelines



Note

This command is supported only on a Cisco Nexus 2148T Fabric Extender.

The Cisco Nexus 2148T Fabric Extender has four 10-Gigabit Ethernet fabric interfaces for its uplink connection to the parent Cisco Nexus 5000 Series switch and 48 1000BASE-T (1-Gigabit) Ethernet host interfaces for its downlink connection to servers or hosts.

The **buffer-threshold** keyword sets the consumption level of input buffers before an indication is sent to the egress queue to start observing the tail drop threshold. If the buffer usage is lower than the configured buffer threshold, the tail drop threshold is ignored.

Examples

This example shows how to configure the hardware buffer threshold limit on a Cisco Nexus 2148T Fabric Extender:

```
switch(config)# fex 110
switch(config-fex)# hardware N2148T buffer-threshold 163840
switch(config-fex)#
```

Send comments to nexus5k-docfeedback@cisco.com

This example shows how to remove the hardware buffer threshold configured on a Cisco Nexus 2148T Fabric Extender:

```
switch(config)# fex 110  
switch(config-fex)# no hardware N2148T buffer-threshold  
switch(config-fex)#
```

Related Commands

Command	Description
fex	Creates a Fabric Extender and enters fabric extender configuration mode.
show fex	Displays all configured Fabric Extender chassis connected to the switch.
show queuing interface	Displays information about interface queuing parameters, including buffer threshold and queue limits.
show running-config fex	Displays the running configuration for Fabric Extenders.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

hardware queue-limit

To control the egress queue tail drop threshold level on a Fabric Extender, use the **hardware queue-limit** command. To disable the drop threshold and allow a Fabric Extender to use all available hardware buffer space, use the **no** form of this command.

hardware *fex_card_typ* **queue-limit** [*queue-limit*] [**rx** | **tx**]

no hardware *fex_card_typ* **queue-limit** [**rx** | **tx**]

Syntax Description		
<i>fex_card_type</i>		<p>Fabric Extender card type. The following Fabric Extender card types are supported:</p> <ul style="list-style-type: none"> • N2148T—Fabric Extender 48x1G 4x10G SFP+ Module • N2224TP—Fabric Extender 24x1G 2x10G SFP+ Module • N2232P—Fabric Extender 32x10G SFP+ 8x10G SFP+ Module • N2232TM—Fabric Extender 32x10GBase-T 8x10G SFP+ Module • N2248T—Fabric Extender 48x1G 4x10G SFP+ Module • N2248TP-E—Fabric Extender 48x1G 4x10G SFP+ Module <p>See the “Usage Guidelines” section for a description of these Fabric Extenders.</p>
<i>queue-limit</i>		<p>(Optional) Queue limit in bytes. The range is from 81920 to 652800 for a Cisco Nexus 2148T Fabric Extender, from 32768 to 33538048 for a on a Cisco Nexus 2248TP-E Fabric Extender, and from 5120 to 652800 for all other supported Fabric Extenders.</p>
rx		<p>(Optional) Specifies the default queue-limit for receiving (ingress).</p> <p>Note This keyword is supported only on a Cisco Nexus 2248TP-E Fabric Extender.</p>
tx		<p>(Optional) Specifies the default queue-limit for transmission (egress).</p> <p>Note This keyword is supported only on a Cisco Nexus 2248TP-E Fabric Extender.</p>

Command Default The default queue-limit for **rx** (ingress) on a Cisco Nexus 2248TP-E Fabric Extender is 1MB.
The default queue-limit for **tx** (egress) on a Cisco Nexus 2248TP-E Fabric Extender is 4MB.

Command Modes Fabric extender configuration mode

Send comments to nexus5k-docfeedback@cisco.com

Command History	Release	Modification
	4.2(1)N2(1)	This command was introduced.
	5.1(3)N1(1)	<p>The Cisco Nexus 2248TP-E Fabric Extender was introduced. The rx and tx keywords was introduced for this Fabric Extender.</p> <p>The queue limit is changed to 5120 to 652800 bytes for all Cisco Nexus 2000 Series Fabric Extender, except Cisco Nexus 2148T Fabric Extender and Cisco Nexus 2248TP-E Fabric Extender.</p> <p>Note On a Cisco Nexus 5000 Series switch that runs a Cisco NX-OS release prior to 5.1(3)N1(1), the queue limit range was from 2560 to 652800 bytes.</p>

Usage Guidelines

You can use a lower queue limit value on the Fabric Extender to prevent one blocked receiver from affecting traffic being sent to other noncongested receivers (head-of-line blocking); however, this will increase burst absorption on the ingress traffic. A higher queue limit value provides better burst absorption and less head-of-line blocking protection.

Supported Cisco Nexus 2000 Series Fabric Extender

The following Cisco Nexus 2000 Series Fabric Extenders are supported on a Cisco Nexus 5000 Series switch that runs a Cisco NX-OS release 4.2(1)N2(1):

- Cisco Nexus 2148T Fabric Extender—It has four 10-Gigabit Ethernet fabric interfaces for its uplink connection to the parent Cisco Nexus 5000 Series switch and 48 1000BASE-T (1-Gigabit) Ethernet host interfaces for its downlink connection to servers or hosts.
- Cisco Nexus N2224TP Fabric Extender—It has two 10-Gigabit Ethernet fabric interfaces with small form-factor pluggable (SFP+) interface adapters for its uplink connection to the parent Cisco Nexus 5000 Series switch and 24 1000BASE-T (1-Gigabit) Ethernet host interfaces for its downlink connection to servers or hosts. It does not support Fibre Channel over Ethernet (FCoE).
- Cisco Nexus 2232P Fabric Extender—It has eight 10-Gigabit Ethernet fabric interfaces with small form-factor pluggable (SFP+) interface adapters for its uplink connection to the parent Cisco Nexus 5000 Series switch and 32 10-Gigabit Ethernet fabric interfaces with SFP+ interface adapters for its downlink connection to servers or hosts.
- Cisco Nexus 2248T Fabric Extender—It has four 10-Gigabit Ethernet fabric interfaces with SFP+ interface adapters for its uplink connection to the parent Cisco Nexus 5000 Series switch and 48 1000BASE-T (1-Gigabit) Ethernet host interfaces for its downlink connection to servers or hosts.

The following Cisco Nexus 2000 Series Fabric Extenders are supported on a Cisco Nexus 5000 Series switch that runs a Cisco NX-OS release 5.0(3)N2(1):

- Cisco Nexus 2148T Fabric Extender—It has four 10-Gigabit Ethernet fabric interfaces for its uplink connection to the parent Cisco Nexus 5000 Series switch and 48 1000BASE-T (1-Gigabit) Ethernet host interfaces for its downlink connection to servers or hosts.
- Cisco Nexus N2224TP Fabric Extender—It has two 10-Gigabit Ethernet fabric interfaces with small form-factor pluggable (SFP+) interface adapters for its uplink connection to the parent Cisco Nexus 5000 Series switch and 24 1000BASE-T (1-Gigabit) Ethernet host interfaces for its downlink connection to servers or hosts. It does not support Fibre Channel over Ethernet (FCoE).
- Cisco Nexus 2232P Fabric Extender—It has eight 10-Gigabit Ethernet fabric interfaces with small form-factor pluggable (SFP+) interface adapters for its uplink connection to the parent Cisco Nexus 5000 Series switch and 32 10-Gigabit Ethernet fabric interfaces with SFP+ interface adapters for its downlink connection to servers or hosts.

Send comments to nexus5k-docfeedback@cisco.com

- Cisco Nexus 2232TM Fabric Extender—It has eight 10-Gigabit Ethernet fabric interfaces with small form-factor pluggable (SFP+) interface adapters for its uplink connection to the parent Cisco Nexus 5000 Series switch and 32 10-Gigabit BASE-T Ethernet fabric interfaces for its downlink connection to servers or hosts.
- Cisco Nexus 2248T Fabric Extender—It has four 10-Gigabit Ethernet fabric interfaces with SFP+ interface adapters for its uplink connection to the parent Cisco Nexus 5000 Series switch and 48 1000BASE-T (1-Gigabit) Ethernet host interfaces for its downlink connection to servers or hosts.

The following Cisco Nexus 2000 Series Fabric Extenders was introduced on a Cisco Nexus 5000 Series switch that runs a Cisco NX-OS release 5.1(3)N1(1):

- Cisco Nexus N2248TP-E Fabric Extender—It has four 10-Gigabit Ethernet fabric interfaces for its uplink connection to the parent Cisco Nexus 5000 Series switch and 48 1000BASE-T (1-Gigabit) Ethernet host interfaces with small form-factor pluggable (SFP+) interface adapters for its downlink connection to servers or hosts.

Examples

This example shows how to configure the hardware buffer queue limit on a Cisco Nexus 2248T Fabric Extender:

```
switch(config)# fex 110
switch(config-fex)# hardware N2248T queue-limit 327680
switch(config-fex)#
```

This example shows how to remove the hardware buffer queue limit configured on a Cisco Nexus 2248T Fabric Extender:

```
switch(config)# fex 110
switch(config-fex)# no hardware N2248T queue-limit
switch(config-fex)#
```

Related Commands

Command	Description
fex	Creates a Fabric Extender and enters fabric extender configuration mode.
show fex	Displays all configured Fabric Extender chassis connected to the switch.
show queuing interface	Displays information about interface queuing parameters, including buffer threshold and queue limits.
show running-config fex	Displays the running configuration for Fabric Extenders.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

hardware shared-buffer-size

To configure the shared buffer size for a Cisco Nexus 2000 Series Fabric Extender, use the **hardware shared-buffer-size** command. To revert to the default setting, use the **no** form of this command.

```
hardware fex_card_type shared-buffer-size [buffer-size]
```

```
no hardware fex_card_type shared-buffer-size [buffer-size]
```

Syntax Description

<i>fex_card_type</i>	Fabric Extender card type. The following Fabric Extender card types are supported: <ul style="list-style-type: none">• N2248TP-E—Fabric Extender 48x1G 4x10G SFP+ Module See the “Usage Guidelines” section for a description of this Fabric Extender.
<i>buffer-size</i>	(Optional) Shared buffer size (KB). The range is from 10800KB to 25392KB.

Command Default

The default size of the shared buffer is 25392KB.

Command Modes

Fabric Extender configuration mode

Command History

Release	Modification
5.1(3)N1(1)	This command was introduced.
	The Cisco Nexus N2248TP-E Fabric Extender was introduced.

Usage Guidelines



Note

This command is supported only on a Cisco Nexus 2248TP-E Fabric Extender.

The Cisco Nexus N2248TP-E Fabric Extender has four 10-Gigabit Ethernet fabric interfaces for its uplink connection to the parent Cisco Nexus 5000 Series switch and 48 1000BASE-T (1-Gigabit) Ethernet host interfaces with small form-factor pluggable (SFP+) interface adapters for its downlink connection to servers or hosts.

The total available buffer is 32MB which is shared in both direction (ingress, egress).

The default size of the shared buffer is 25392KB. However, when configuring an Ethernet-based pause no-drop class, the shared buffer size changes to 10800KB. This change is required to increase the dedicated buffer that supports the pause no-drop class. The pause no-drop class does not use buffer space from the shared-pool.

Send comments to nexus5k-docfeedback@cisco.com

Examples

This example shows how to configure the hardware buffer size on a Cisco Nexus 2248TP-E Fabric Extender:

```
switch# configure terminal
switch(config)# fex 100
switch(config-fex)# hardware N2248TTP-E shared-buffer-size 25000
switch(config-fex)#
```

This example shows how to remove the hardware pause no-drop configuration between a Cisco Nexus 2248TTP-E Fabric Extender and a switch:

```
switch# configure terminal
switch(config)# fex 100
switch(config-fex)# no hardware N2248TTP-E shared-buffer-size 25000
switch(config-fex)#
```

Related Commands

Command	Description
fex	Creates a Fabric Extender and enters fabric extender configuration mode.
show fex	Displays all configured Fabric Extender chassis connected to the switch.
show running-config fex	Displays the running configuration for Fabric Extenders.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

hardware uplink-pause-no-drop

To configure a pause no-drop class up to a distance of 3000 meters between the Cisco Nexus 2000 Series Fabric Extender and a Cisco Nexus 5000 Series switch, use the **hardware uplink-pause-no-drop** command. To revert to the default setting, use the **no** form of this command.

hardware *fex_card_type* **uplink-pause-no-drop distance** [*distance-value*]

no hardware *fex_card_type* **uplink-pause-no-drop distance** [*distance-value*]

Syntax Description

<i>fex_card_type</i>	Fabric Extender card type. The following Fabric Extender card types are supported: <ul style="list-style-type: none"> N2248TP-E—Fabric Extender 48x1G 4x10G SFP+ Module See the “Usage Guidelines” section for a description of this Fabric Extender.
distance	Specifies the distance between the Fabric Extender and switch.
<i>distance-value</i>	(Optional) Distance in meters. The range is from 300 to 3000.

Command Default

The default distance between a Fabric Extender and the switch is 300 meters.

Command Modes

Fabric Extender configuration mode

Command History

Release	Modification
5.1(3)N1(1)	This command was introduced.
	The Cisco Nexus N2248TP-E Fabric Extender was introduced.

Usage Guidelines



Note

This command is supported only on a Cisco Nexus 2248TP-E Fabric Extender.

The Cisco Nexus N2248TP-E Fabric Extender has four 10-Gigabit Ethernet fabric interfaces for its uplink connection to the parent Cisco Nexus 5000 Series switch and 48 1000BASE-T (1-Gigabit) Ethernet host interfaces with small form-factor pluggable (SFP+) interface adapters for its downlink connection to servers or hosts.

Examples

This example shows how to configure the hardware pause no-drop class up to a distance of 3000 meters between a Cisco Nexus 2248TTP-E Fabric Extender and a switch:

```
switch# configure terminal
switch(config)# fex 100
switch(config-fex)# hardware N2248TTP-E pause-no-drop distance 3000
switch(config-fex)#
```

Send comments to nexus5k-docfeedback@cisco.com

This example shows how to remove the hardware pause no-drop configuration between a Cisco Nexus 2248TTP-E Fabric Extender and a switch:

```
switch# configure terminal
switch(config)# fex 100
switch(config-fex)# no hardware N2248TTP-E pause-no-drop distance 3000
switch(config-fex)#
```

Related Commands

Command	Description
fex	Creates a Fabric Extender and enters fabric extender configuration mode.
show fex	Displays all configured Fabric Extender chassis connected to the switch.
show running-config fex	Displays the running configuration for Fabric Extenders.

Send comments to nexus5k-docfeedback@cisco.com



L Commands

This chapter describes the Cisco NX-OS commands that begin with L that are used to manage a Cisco Nexus 2000 Series Fabric Extender from a Cisco Nexus 5000 Series switch.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

locator-led fex

To turn on the locator LED of a Fabric Extender, use the **locator-led** command. To turn off the locator LED, use the **no** form of this command.

locator-led fex *chassis_ID*

no locator-led fex *chassis_ID*

Syntax Description	<i>chassis_ID</i>	Fabric Extender chassis ID. The range is from 100 to 199.
---------------------------	-------------------	---

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	4.1(3)N1(1)	This command was introduced.
	Note	On a Cisco Nexus 5000 Series switch that runs a Cisco NX-OS release prior to 4.1(3)N1(1), the locator beacon LED was toggled with the beacon command.

Usage Guidelines Use the **locator-led** command to toggle the locator LED of a Fabric Extender, which allows you to easily identify the machine in a busy data center.

The **locator-led** command replaces the following command, which is deprecated in Cisco NX-OS Release 4.1(3)N1(1) and later releases:

- **[no] beacon**

Examples This example shows how to turn on the locator LED for a specific Fabric Extender chassis:

```
switch# locator-led fex 100
switch#
```

This example shows how to turn off the locator beacon LED for a specific Fabric Extender chassis:

```
switch# no locator-led fex 100
switch#
```

Related Commands	Command	Description
	show fex	Displays all configured Fabric Extender chassis connected to the switch.
	show locator-led	Displays the status of the locator LED in Fabric Extender modules.

Send comments to nexus5k-docfeedback@cisco.com

logging fex

To set the logging alert level for Fabric Extender events, use the **logging fex** command. To reset the logging level, use the **no** form of this command.

logging fex [*severity-level*]

no logging fex [*severity-level*]

Syntax Description

severity-level (Optional) Number of the desired severity level at which messages should be logged. Messages at or numerically lower than the specified level are logged. Severity levels are as follows:

- 0—emergency: System unusable
- 1—alert: Immediate action needed
- 2—critical: Critical condition—default level
- 3—error: Error condition
- 4—warning: Warning condition
- 5—notification: Normal but significant condition
- 6—informational: Informational message only
- 7—debugging: Appears during debugging only

Command Default

None

Command Modes

Global configuration mode

Command History

Release	Modification
4.0(1a)N2(1)	This command was introduced.

Examples

This example shows how to set the logging alert level for Fabric Extender events:

```
switch(config)# logging fex 4
```

This example shows how to reset the logging level:

```
switch(config)# no logging fex
```

Related Commands

Command	Description
show fex	Displays all configured Fabric Extender chassis connected to the switch.

Send comments to nexus5k-docfeedback@cisco.com

Send comments to nexus5k-docfeedback@cisco.com



P Commands

This chapter describes the Cisco NX-OS commands that begin with P that are used to manage a Cisco Nexus 2000 Series Fabric Extender from a Cisco Nexus 5000 Series switch.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

pinning max-links

To specify the number of statically pinned uplinks, use the **pinning max-links** command. To reset to the default, use the **no** form of this command.

pinning max-links *uplinks*

no pinning max-links

Syntax Description	<i>uplinks</i>	Number of uplinks. The range is from 1 to 8. The default is 1. This command is applicable only if the Fabric Extender is connected to its parent switch using one or more statically pinned fabric interfaces.
---------------------------	----------------	---

Command Default	The default number of uplinks is 1.
------------------------	-------------------------------------

Command Modes	Fabric extender configuration mode
----------------------	------------------------------------

Command History	Release	Modification
	4.0(1a)N2(1)	This command was introduced.
	4.2(1)N1(1)	The number of uplinks is extended to 8.
	Note	In releases prior to Cisco NX-OS Release 4.2(1)N1(1), the maximum number of uplinks was 4.

Usage Guidelines	Use the pinning max-links command when you create a number of pinned fabric interface connections to enable the parent switch to determine a distribution of host interfaces. The host interfaces are divided by the number of <i>uplinks</i> and distributed accordingly.
-------------------------	---



Caution

Changing the value of *uplinks* is disruptive. All the host interfaces on the Fabric Extender are brought down and back up as the parent switch reassigns its static pinning.

Examples	This example shows how to specify the number of statically pinned uplinks for a Fabric Extender:
-----------------	--

```
switch# configure terminal
switch(config)# fex 101
switch(config-fex)# pinning max-links 4
```

This example shows how to revert to the uplink count to the default for a Fabric Extender:

```
switch# configure terminal
switch(config)# fex 101
switch(config-fex)# no pinning max-links
```


Send comments to nexus5k-docfeedback@cisco.com

Related Commands	Command	Description
	fex	Creates a Fabric Extender and enters fabric extender configuration mode.
	fex pinning redistribute	Redistributes the host interfaces on a Fabric Extender.
	show fex	Displays all configured Fabric Extender chassis connected to the switch.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

provision

To preprovision a module in a chassis slot, use the **provision** command. To remove a preprovisioned module from a slot, use the **no** form of this command.

provision model *model-name*

no provision model [*model-name*]

Syntax Description	
model	Specifies the type of module to be provisioned.
<i>model-name</i>	Module name. The supported modules are as follows: <ul style="list-style-type: none"> • N2K-C2148T—Cisco Nexus 2000 Series Fabric Extender 48x1G 4x10G Module • N2K-C2232P—Cisco Nexus 2000 Series Fabric Extender 32x10G Module • N2K-C2232TM—Cisco Nexus 2000 Series Fabric Extender 32x10G Module • N2K-C2248T—Cisco Nexus 2000 Series Fabric Extender 48x1G 4x10G Module • N2K-N2224TP—Cisco Nexus 2000 Series Fabric Extender 24x1G 2x10G SFP+ Module • N55-M16FP—Cisco 16 port Port Fiber Channel Expansion Module 16 x SFP • N55-M16P—Cisco 16x10-Gigabit Ethernet Expansion Module • N55-M16UP—Cisco 16x10-Gigabit Flexible Ethernet Expansion Module • N55-M8P8FP—Cisco 8 Port 1/2/4/8-Gigabit Fibre Channel + 8 Port 10-Gigabit Ethernet Expansion Module • N5K-M1008—Cisco 8 Port Fiber Channel Expansion Module 8 x SFP • N5K-M1060—Cisco 6 Port Fiber Channel Expansion Module 6 x SFP • N5K-M1404—Expansion Module 4 x 10GBase-T LAN, 4 x Fiber Channel • N5K-M1600—Cisco 6-port 10 Gigabit Ethernet SFP Module 6 x SFP

Command Default None

Command Modes Slot configuration mode
Switch profile configuration mode

Send comments to nexus5k-docfeedback@cisco.com

Command History

Release	Modification
5.0(2)N1(1)	This command was introduced.

Usage Guidelines

Use this command to define the modules (line card or Cisco Nexus 2000 Series Fabric Extender) to preprovision. If the card type does not match the card in the slot or the module is not compatible with the chassis, you see the following messages:

```
ERROR: The card type does not match the card in slot
```

or

```
ERROR: This module cannot be configured for this chassis
```

You can configure features or interfaces (Ethernet, Fibre Channel) on the modules before the modules are inserted in the switch chassis. You can also use this command to manage the configuration of these features or interfaces when the module is offline due to a failure or scheduled downtime. These configurations are applied when the module comes online.

When you preprovision a module by specifying the type of module, platform manager will allow only modules of matching type to come online. If you configure the interfaces for the module without specifying the module type, the configuration is applied when the module comes online, regardless of the module type.

You can preprovision modules and interfaces in a switch profile. The modules and interfaces are preprovisioned when you apply (commit) the switch profile. Once the module is inserted and interfaces are created, the preprovisioning module passes on the configuration to the respective applications before the interfaces come up.

Mutual exclusion is a mechanism where configuration outside the switch profile is not allowed in the switch profile and vice-versa. This requirement is to ensure that configuration in the switch profile is exactly the same on both switches. Preprovisioned configuration is the same as a configuration when the module is online, so mutual exclusion checks would continue to apply normally.

When you downgrade from Cisco NX-OS release 5.0(2)N1(1), which supports preprovisioning, to an earlier release of Cisco NX-OS that does not support module preprovisioning, you will be prompted to remove preprovisioning configuration that you configured on the switch.

Examples

This example shows how to preprovision a module in slot 2 of the chassis:

```
switch(config)# slot 2
switch(config-slot)# provision model N5K-M1404
switch(config-slot)#
```

This example shows how to remove a preprovisioned module from a chassis slot:

```
switch(config)# slot 2
switch(config-slot)# no provision model N5K-M1404
switch(config-slot)#
```

This example shows how to remove all preprovisioned modules or line cards from a chassis slot:

```
switch(config)# slot 2
switch(config-slot)# no provision model
switch(config-slot)#
```

Send comments to nexus5k-docfeedback@cisco.com

Related Commands

Command	Description
show module	Displays module information.
show provision	Displays provisioned modules.
show switch-profile	Displays switch profile information.
show running-config exclude-provision	Displays the running configuration excluding the preprovisioned features.
slot	Enables a slot for preprovisioning a module.
switch-profile	Configures a switch profile.

Send comments to nexus5k-docfeedback@cisco.com



S Commands

This chapter describes the Cisco NX-OS commands that begin with S that are used to manage a Cisco Nexus 2000 Series Fabric Extender from a Cisco Nexus 5000 Series switch.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

serial

To assign a serial number to a Fabric Extender, use the **serial** command. To remove the serial number, use the **no** form of this command.

```
serial serial_string

no serial
```

Syntax Description	serial_string	Serial number string for the Fabric Extender. The string is alphanumeric, case sensitive, and has a maximum length of 20 characters.
--------------------	---------------	--


Command Default	None
-----------------	------

Command Modes	Fabric extender configuration mode
---------------	------------------------------------

Command History	Release	Modification
	4.0(1a)N2(1)	This command was introduced.

Usage Guidelines

The serial number string you define with the **serial** command must match the serial number of the Fabric Extender. If you configure a serial number and then you use the **fex associate** command to associate the corresponding chassis ID to the switch, the association will succeed only if the Fabric Extender reports a matching serial number string.



Caution

Configuring a serial number other than that of the given Fabric Extender will force the Fabric Extender offline.

Examples

This example shows how to specify a serial number for a Fabric Extender:

```
switch# configure terminal
switch(config)# fex 101
switch(config-fex)# serial Rack16_FEX101
```

This example shows how to remove a serial number from a Fabric Extender:

```
switch# configure terminal
switch(config)# fex 101
switch(config-fex)# no serial
```

Send comments to nexus5k-docfeedback@cisco.com

Related Commands	Command	Description
	fex	Creates a Fabric Extender and enters fabric extender configuration mode.
	fex associate	Associates a Fabric Extender to an Ethernet or EtherChannel interface.
	show fex	Displays all configured Fabric Extender chassis connected to the switch.

Send comments to nexus5k-docfeedback@cisco.com

slot

To enable preprovisioning on a slot in a chassis, use the **slot** command. To disable the slot for preprovisioning, use the **no** form of this command.

slot *slot-number*

no slot *slot-number*

Syntax Description	<i>slot-number</i> Slot number in the chassis. The range is from 2 to 199.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Global configuration mode Configuration synchronization mode
----------------------	---

Command History	Release	Modification
	5.0(2)N1(1)	This command was introduced.

Usage Guidelines	Use this command to enable preprovisioning of features or interfaces of a module on a slot in a chassis. Preprovisioning allows you to configure features or interfaces (Ethernet, Fibre Channel) on modules before the modules are inserted in the switch chassis.
-------------------------	---

Examples	This example shows how to enable a chassis slot for preprovisioning of a module:
-----------------	--

```
switch(config)# slot 2
switch(config-slot)#
```

This example shows how to disable a chassis slot for preprovisioning of a module:

```
switch(config)# no slot 2
switch(config)#
```

Related Commands	Command	Description
	port	Configures ports as Ethernet, native Fibre Channel or Fibre Channel over Ethernet (FCoE) ports.
	provision	Preprovisions a module in a slot.
	show running-config exclude-provision	Displays the running configuration excluding the preprovisioned features.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

switchport mode fex-fabric

To set the interface type to be an uplink port for a Fabric Extender, use the **switchport mode fex-fabric** command.

switchport mode fex-fabric

no switchport mode fex-fabric

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Interface configuration mode
----------------------	------------------------------

Command History	Release	Modification
	4.0(1a)N2(1)	This command was introduced.

Examples	This example shows how to set an Ethernet interface to be an uplink port for a Fabric Extender:
-----------------	---

```
switch# configure terminal
switch(config)# interface ethernet 1/40
switch(config-if)# switchport mode fex-fabric
```

This example shows how to set an EtherChannel interface to be an uplink port for a Fabric Extender:

```
switch# configure terminal
switch(config)# interface port-channel 4
switch(config-if)# switchport mode fex-fabric
```

Related Commands	Command	Description
	fex associate	Associates a Fabric Extender to an Ethernet or EtherChannel interface.
	show fex	Displays all configured Fabric Extender chassis connected to the switch.

Send comments to nexus5k-docfeedback@cisco.com

Send comments to nexus5k-docfeedback@cisco.com



Show Commands

This chapter describes the Cisco NX-OS **show** commands used to manage a Cisco Nexus 2000 Series Fabric Extender from a Cisco Nexus 5000 Series switch.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

show diagnostic result fex

To display the results from the diagnostic tests for a Fabric Extender chassis, use the **show diagnostic result fex** command.

show diagnostic result fex *chassis_ID*

Syntax Description	<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
Command Default	None	
Command Modes	EXEC mode	
Command History	Release	Modification
	4.0(1a)N2(1)	This command was introduced.

Examples

This example shows how to display the results from the diagnostic tests for a Fabric Extender:

```
switch# show diagnostic result fex 100
FEX-100: 48x1GE/Supervisor SerialNo   : JAF1237ABSE
Overall Diagnostic Result for FEX-100  : OK

Test results: (. = Pass, F = Fail, U = Untested)
TestPlatform:
0)          SPROM: -----> .
1)          MV88E6095: -----> .
2)          Fan: -----> .
3)          Power Supply: -----> .
4) Temperature Sensor: -----> .

TestForwardingPorts:
Eth   1  2  3  4  5  6  7  8  9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24
Port -----
      .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .

Eth   25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48
Port -----
      .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .

TestFabricPorts:
Fabric 1  2  3  4
Port -----
      .  .  .  .

switch#
```

Send comments to nexus5k-docfeedback@cisco.com

Related Commands

Command	Description
show fex	Displays all configured Fabric Extender chassis connected to the switch.

Send comments to nexus5k-docfeedback@cisco.com

show environment fex

To display the environmental sensor status, use the **show environment fex** command.

show environment fex {**all** | *chassis_ID*} [**temperature** | **power** | **fan**]

Syntax Description		
all		Displays information for all Fabric Extender chassis.
<i>chassis_ID</i>		Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
temperature		(Optional) Displays temperature sensor information.
power		(Optional) Displays power capacity and power distribution information.
fan		(Optional) Displays fan information.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	4.0(1a)N2(1)	This command was introduced.

Examples This example shows how to display the environmental sensor status for a Fabric Extender:

```
switch# show environment fex 100
```

Temperature Fex 100:

Module	Sensor	MajorThresh (Celsius)	MinorThres (Celsius)	CurTemp (Celsius)	Status
1	Outlet-1	85	75	50	ok
1	Inlet-1	100	90	37	ok

Fan Fex: 100:

Fan	Model	Hw	Status
Chassis	N2K-C2148-FAN	--	ok
PS-1	N5K-PAC-200W	--	ok
PS-2	--	--	absent

Power Supply Fex 100:

Voltage: 12 Volts				
PS	Model	Power (Watts)	Power (Amp)	Status
1	N5K-PAC-200W	0.00	0.00	ok

Send comments to nexus5k-docfeedback@cisco.com

```

2  --          --          --          --

Mod Model          Power      Power      Power      Power      Status
Requested Requested Allocated Allocated
(Watts)   (Amp)    (Watts)   (Amp)
-----
1   N5K-C5110T-BF-1GE 24.00     2.00      24.00     2.00      powered-up

Power Usage Summary:
-----
Power Supply redundancy mode:          redundant

Total Power Capacity                  0.00 W

Power reserved for Supervisor(s)      24.00 W
Power currently used by Modules        0.00 W

Total Power Available                  -24.00 W
-----
switch#

```

Related Commands

Command	Description
show fex	Displays all configured Fabric Extender chassis connected to the switch.

Send comments to nexus5k-docfeedback@cisco.com

show fex

To display information about a specific Fabric Extender or all attached chassis, use the **show fex** command.

show fex [*chassis_ID* [*detail*]]

Syntax Description	<i>chassis_ID</i>	(Optional) Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
	detail	(Optional) Displays a detailed listing.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	4.0(1a)N2(1)	This command was introduced.

Examples

This example shows how to display information about all attached Fabric Extender chassis:

```
switch# show fex
FEX          FEX          FEX          FEX
Number      Description    State      Model          Serial
-----
100          FEX0100                Online    N5K-C5110T-BF-1GE  JAF1237ABSE
101          FEX0101                Online    N2K-C2248TP-1GE   JAF11223333
102          FEX0102                Online    N5K-C5110T-BF-1GE  JAF1241BLHQ
105          FEX0105                Online    N2K-C2232P-10GE   JAF1331AKBM
switch#
```

This example shows how to display information about a specific Fabric Extender chassis:

```
switch# show fex 101
FEX: 101 Description: FEX0101   state: Online
  FEX version: 4.2(1)N1(1) [Switch version: 4.2(1)N1(1)]
  Extender Model: N2K-C2248TP-1GE,  Extender Serial: JAF11223333
  Part No: 73-12748-01
pinning-mode: static    Max-links: 1
Fabric port for control traffic: Eth3/5
Fabric interface state:
  Po5 - Interface Up. State: Active
  Eth3/5 - Interface Up. State: Active
  Eth3/6 - Interface Up. State: Active
switch#
```

This example shows how to display the detailed information about all attached Fabric Extender chassis:

```
switch# show fex detail
FEX: 100 Description: FEX0100   state: Online
  FEX version: 4.2(1)N1(1) [Switch version: 4.2(1)N1(1)]
```


Send comments to nexus5k-docfeedback@cisco.com

```
FEX Interim version: 4.2(1)N1(0.309)
Switch Interim version: 4.2(1)N1(0.309)
Extender Model: N5K-C5110T-BF-1GE, Extender Serial: JAF1237ABSE
Part No: 73-12009-02
Card Id: 70, Mac Addr: 00:0d:ec:b1:13:02, Num Macs: 64
Module Sw Gen: 12594 [Switch Sw Gen: 21]
post level: complete
pinning-mode: static Max-links: 1
Fabric port for control traffic: Eth3/3
Fabric interface state:
  Po12 - Interface Up. State: Active
  Eth3/3 - Interface Up. State: Active
  Eth3/4 - Interface Up. State: Active
Fex Port      State Fabric Port Primary Fabric
  Eth100/1/1   Up      Po12      Po12
  Eth100/1/2   Up      Po12      Po12
  Eth100/1/3   Up      Po12      Po12
  Eth100/1/4   Up      Po12      Po12
  Eth100/1/5   Up      Po12      Po12
  Eth100/1/6   Up      Po12      Po12
  Eth100/1/7   Up      Po12      Po12
  Eth100/1/8   Up      Po12      Po12
  Eth100/1/9   Up      Po12      Po12
  Eth100/1/10  Up      Po12      Po12
  Eth100/1/11  Up      Po12      Po12
  Eth100/1/12  Up      Po12      Po12
  Eth100/1/13  Up      Po12      Po12
  Eth100/1/14  Up      Po12      Po12
  Eth100/1/15  Up      Po12      Po12
  Eth100/1/16  Up      Po12      Po12
  Eth100/1/17  Up      Po12      Po12
  Eth100/1/18  Up      Po12      Po12
  Eth100/1/19  Up      Po12      Po12
  Eth100/1/20  Up      Po12      Po12
  Eth100/1/21  Up      Po12      Po12
  Eth100/1/22  Up      Po12      Po12
  Eth100/1/23  Up      Po12      Po12
--More--
switch#
```

Related Commands

Command	Description
fex	Creates a Fabric Extender and enters fabric extender configuration mode.

Send comments to nexus5k-docfeedback@cisco.com

show fex detail

To display detailed information about a specific Fabric Extender or all attached chassis, use the **show fex detail** command.

show fex detail

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	4.2(1)N1(1)	This command was introduced.

Examples	This example shows how to display detailed information about all attached Fabric Extender chassis:
-----------------	--

```
switch# show fex detail
FEX: 100 Description: FEX0100   state: Online
  FEX version: 4.2(1)N1(1) [Switch version: 4.2(1)N1(1)]
  FEX Interim version: 4.2(1)N1(0.326)
  Switch Interim version: 4.2(1)N1(0.326)
  Extender Model: N5K-C5110T-BF-1GE,  Extender Serial: JAF1237ABSE
  Part No: 73-12009-02
  Card Id: 70, Mac Addr: 00:0d:ec:b1:13:02, Num Macs: 64
  Module Sw Gen: 12594  [Switch Sw Gen: 21]
  post level: complete
pinning-mode: static   Max-links: 1
Fabric port for control traffic: Eth3/4
Fabric interface state:
  Po12 - Interface Up. State: Active
  Eth3/3 - Interface Up. State: Active
  Eth3/4 - Interface Up. State: Active
Fex Port      State  Fabric Port  Primary Fabric
Eth100/1/1    Up      Po12         Po12
Eth100/1/2    Up      Po12         Po12
Eth100/1/3    Up      Po12         Po12
Eth100/1/4    Up      Po12         Po12
Eth100/1/5    Up      Po12         Po12
Eth100/1/6    Up      Po12         Po12
Eth100/1/7    Up      Po12         Po12
Eth100/1/8    Up      Po12         Po12
Eth100/1/9    Up      Po12         Po12
Eth100/1/10   Up      Po12         Po12
Eth100/1/11   Up      Po12         Po12
Eth100/1/12   Up      Po12         Po12
Eth100/1/13   Up      Po12         Po12
Eth100/1/14   Up      Po12         Po12
Eth100/1/15   Up      Po12         Po12
Eth100/1/16   Up      Po12         Po12
```

Send comments to nexus5k-docfeedback@cisco.com

Eth100/1/17	Up	Po12	Po12
Eth100/1/18	Up	Po12	Po12
Eth100/1/19	Up	Po12	Po12
Eth100/1/20	Up	Po12	Po12
Eth100/1/21	Up	Po12	Po12
Eth100/1/22	Up	Po12	Po12
Eth100/1/23	Up	Po12	Po12
Eth100/1/24	Up	Po12	Po12
Eth100/1/25	Up	Po12	Po12
Eth100/1/26	Up	Po12	Po12
Eth100/1/27	Up	Po12	Po12
Eth100/1/28	Up	Po12	Po12
Eth100/1/29	Up	Po12	Po12
Eth100/1/30	Up	Po12	Po12
Eth100/1/31	Up	Po12	Po12
Eth100/1/32	Up	Po12	Po12
Eth100/1/33	Down	Po12	Po12
Eth100/1/34	Down	Po12	Po12
Eth100/1/35	Down	Po12	Po12
Eth100/1/36	Down	Po12	Po12
Eth100/1/37	Down	Po12	Po12
Eth100/1/38	Down	Po12	Po12
Eth100/1/39	Down	Po12	Po12
Eth100/1/40	Up	Po12	Po12
Eth100/1/41	Up	Po12	Po12
Eth100/1/42	Up	Po12	Po12
Eth100/1/43	Up	Po12	Po12
Eth100/1/44	Up	Po12	Po12
Eth100/1/45	Up	Po12	Po12
Eth100/1/46	Up	Po12	Po12
Eth100/1/47	Up	Po12	Po12
Eth100/1/48	Up	Po12	Po12

Logs:

```

04/16/2010 05:05:23.441707: Module register received
04/16/2010 05:05:23.442886: Registration response sent
04/16/2010 05:05:23.551846: Module Online Sequence
04/16/2010 05:05:56.520856: Module Online
04/16/2010 05:29:38.526605: Deleting route to FEX
04/16/2010 05:29:38.536055: Module disconnected
04/16/2010 05:29:38.537686: Offlining Module
04/16/2010 05:29:38.538260: Module Offline Sequence
04/16/2010 05:29:53.646254: Module Offline
04/16/2010 05:29:54.178401: Deleting route to FEX
04/16/2010 05:29:54.184092: Module disconnected
04/16/2010 05:29:54.186230: Offlining Module
04/16/2010 05:31:13.784346: Module register received
04/16/2010 05:31:13.785410: Registration response sent
04/16/2010 05:31:15.676906: Module Online Sequence
04/16/2010 05:31:50.492714: Module Online
04/16/2010 05:32:18.388033: Deleting route to FEX
04/16/2010 05:32:18.393579: Module disconnected
04/16/2010 05:32:18.394845: Offlining Module
04/16/2010 05:32:18.395412: Module Offline Sequence
04/16/2010 05:32:30.336790: Module Offline
04/16/2010 05:32:30.683558: Deleting route to FEX
04/16/2010 05:32:30.690042: Module disconnected
04/16/2010 05:32:30.692101: Offlining Module
04/16/2010 05:33:42.781911: Module register received
04/16/2010 05:33:42.783432: Registration response sent
04/16/2010 05:33:52.542824: Module Online Sequence
04/16/2010 05:34:33.483417: Module Online
<---output truncated--->
switch#

```

Send comments to nexus5k-docfeedback@cisco.com

Related Commands	Command	Description
	fex	Creates a Fabric Extender and enters fabric extender configuration mode.
	show fex	Displays all configured Fabric Extender chassis connected to the switch.

Send comments to nexus5k-docfeedback@cisco.com

show fex transceiver

To display information about the transceiver connecting a Fabric Extender to the Cisco Nexus 5000 Series switch, use the **show fex transceiver** command.

show fex chassis_ID transceiver [calibration | detail]

Syntax Description	<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
	calibration	(Optional) Displays detailed calibration information about the transceiver.
	detail	(Optional) Displays detailed diagnostic information about the transceiver.

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	4.0(1a)N2(1)	This command was introduced.

Examples

This example shows how to display information about the transceiver that connects a Fabric Extender to the Cisco Nexus 5000 Series switch:

```
switch# show fex 101 transceiver
```

```
Fex Uplink: 1
Fabric Port: Ethernet3/5
  sfp is present
  name is CISCO-AVAGO
  part number is SFBR-7700SDZ
  revision is B4
  serial number is AGD113921ZR
  nominal bitrate is 10300 Mbits/sec
  Link length supported for 50/125mm fiber is 82 m(s)
  Link length supported for 62.5/125mm fiber is 26 m(s)
  cisco id is --
  cisco extended id number is 4
```

```
Fex Uplink: 2
Fabric Port: Ethernet3/6
  sfp is present
  name is CISCO-AVAGO
  part number is SFBR-7700SDZ
  revision is B4
  serial number is AGD113422LS
  nominal bitrate is 10300 Mbits/sec
  Link length supported for 50/125mm fiber is 82 m(s)
  Link length supported for 62.5/125mm fiber is 26 m(s)
  cisco id is --
  cisco extended id number is 4
```

Send comments to nexus5k-docfeedback@cisco.com

```
Fex Uplink: 3
Fabric Port: --
    sfp is present
    name is CISCO-AVAGO
    part number is SFBR-7700SDZ
    revision is B4
    serial number is AGD11392258
    nominal bitrate is 10300 MBits/sec
    Link length supported for 50/125mm fiber is 82 m(s)
    Link length supported for 62.5/125mm fiber is 26 m(s)
--More--
switch#
```

Related Commands

Command	Description
fex	Creates a Fabric Extender and enters fabric extender configuration mode.

Send comments to nexus5k-docfeedback@cisco.com

show fex version

To display the version information about a Fabric Extender, use the **show fex version** command.

show fex chassis_ID version

Syntax Description	<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
--------------------	-------------------	--

Command Default	None
-----------------	------

Command Modes	EXEC mode
---------------	-----------

Command History	Release	Modification
	4.0(1a)N2(1)	This command was introduced.

Examples This example shows how to display the version information about a Fabric Extender:

```
switch# show fex 101 version
Software
  Bootloader version:      0.2
  System boot mode:       primary
  System image version:    4.2(1)N1(1) [build 4.2(1)N1(0.309)]

Hardware
  Module:                  Fabric Extender 48x1GE + 4x10G Module
  CPU:                     Motorola, e300c4
  Serial number:           JAF11223333
  Bootflash:               locked

Kernel uptime is 0 day(s), 3 hour(s), 53 minutes(s), 43 second(s)

Last reset at Wed Mar 31 06:28:41 2010
  Reason: Kernel Reboot
  Service: Reload new image
switch#
```

Related Commands	Command	Description
	fex	Creates a Fabric Extender and enters fabric extender configuration mode.

Send comments to nexus5k-docfeedback@cisco.com

show interface fex-fabric

To display all Fabric Extender fabric interfaces, use the **show interface fex-fabric** command.

show interface fex-fabric

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	4.0(1a)N2(1)	This command was introduced.

Examples This example shows how to display all Fabric Extender fabric interfaces:

```
switch# show interface fex-fabric
Fabric      Fabric      Fex      FEX
Fex  Port      Port State      Uplink      Model      Serial
-----
105   Eth1/5      Active    5      N2K-C2232P-10GE  JAF1331AKBM
105   Eth1/6      Active    6      N2K-C2232P-10GE  JAF1331AKBM
105   Eth1/7      Active    8      N2K-C2232P-10GE  JAF1331AKBM
105   Eth1/8      Active    7      N2K-C2232P-10GE  JAF1331AKBM
102   Eth1/17     Active    1      N5K-C5110T-BF-1GE JAF1241BLHQ
102   Eth1/18     Configured 0
102   Eth1/19     Active    3      N5K-C5110T-BF-1GE JAF1241BLHQ
102   Eth1/20     Active    4      N5K-C5110T-BF-1GE JAF1241BLHQ
100   Eth3/3      Active    1      N5K-C5110T-BF-1GE JAF1237ABSE
100   Eth3/4      Active    2      N5K-C5110T-BF-1GE JAF1237ABSE
101   Eth3/5      Active    1      N2K-C2248TP-1GE   JAF11223333
101   Eth3/6      Active    2      N2K-C2248TP-1GE   JAF11223333
switch#
```

Related Commands	Command	Description
	show fex	Displays all configured Fabric Extender chassis connected to the switch.

Send comments to nexus5k-docfeedback@cisco.com

show interface fex-intf

To display the host interfaces pinned to a fabric interface, use the **show interface fex-intf** command.

show interface *interface* **fex-intf**

Syntax Description	<i>interface</i>	Ethernet or EtherChannel interface.
---------------------------	------------------	-------------------------------------

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	4.0(1a)N2(1)	This command was introduced.

Examples	This example shows how to display the host interfaces pinned to an Ethernet fabric interface on the parent switch: switch# show interface ethernet 1/1 fex-intf
	This example shows how to display the host interfaces pinned to an EtherChannel fabric interface on the parent switch: switch# show interface port-channel 1 fex-intf

Related Commands	Command	Description
	show fex	Displays all configured Fabric Extender chassis connected to the switch.

Send comments to nexus5k-docfeedback@cisco.com

show interface transceiver fex-fabric

To display information about all transceivers connected to fabric interfaces, use the **show interface transceiver fex-fabric** command.

show interface transceiver fex-fabric [**calibration** | **detail**]

Syntax Description	calibration	(Optional) Displays detailed calibration information about the transceiver.
	detail	(Optional) Displays detailed diagnostic information about the transceiver.

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	4.0(1a)N2(1)	This command was introduced.

Examples This example shows how to display information about all transceivers that connect to fabric interfaces:

```
switch# show interface transceiver fex-fabric
Ethernet1/5
  sfp is present
  name is CISCO-MOLEX INC
  part number is 74752-9025
  revision is A
  serial number is MOC12302468
  nominal bitrate is 12000 Mbits/sec
  Link length supported for 50/125mm fiber is 0 m(s)
  Link length supported for 62.5/125mm fiber is 0 m(s)
  cisco id is --
  cisco extended id number is 4

Ethernet1/6
  sfp is present
  name is CISCO-MOLEX INC
  part number is 74752-9025
  revision is A
  serial number is MOC12260214
  nominal bitrate is 12000 Mbits/sec
  Link length supported for 50/125mm fiber is 0 m(s)
  Link length supported for 62.5/125mm fiber is 0 m(s)
  cisco id is --
  cisco extended id number is 4

Ethernet1/7
  sfp is present
  name is CISCO-MOLEX INC
  part number is 74752-9025
  revision is A
  serial number is MOC12301888
```

Send comments to nexus5k-docfeedback@cisco.com

```
nominal bitrate is 12000 Mbits/sec
Link length supported for 50/125mm fiber is 0 m(s)
Link length supported for 62.5/125mm fiber is 0 m(s)
cisco id is --
cisco extended id number is 4

Ethernet1/8
    sfp is present
    name is CISCO-MOLEX INC
--More--
switch#
```

Related Commands

Command	Description
show fex	Displays all configured Fabric Extender chassis connected to the switch.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

show inventory fex

To display the physical inventory of a Fabric Extender, such as the name, description, and volume ID, use the **show inventory fex** command.

show inventory fex *chassis_ID*

Syntax Description	<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
--------------------	-------------------	--

Command Default	None
-----------------	------

Command Modes	EXEC mode
---------------	-----------

Command History	Release	Modification
	4.2(1)N1(1)	This command was introduced.

Examples This example shows how to display the physical inventory of a specific Fabric Extender chassis:

```
switch# show inventory fex 100
NAME: "FEX 100 CHASSIS", DESCR: "N5K-C5110T-BF-1GE CHASSIS"
PID: N5K-C5110T-BF-1GE , VID: V01 , SN: JAF1237ABSE

NAME: "FEX 100 Module 1", DESCR: "Fabric Extender Module: 48x1GE, 4X10GE Supervisor"
PID: N5K-C5110T-BF-1GE , VID: V00 , SN: JAF1237ABSE

NAME: "FEX 100 Fan 1", DESCR: "Fabric Extender Fan module"
PID: N2K-C2148-FAN , VID: N/A , SN: N/A

NAME: "FEX 100 Power Supply 1", DESCR: "Fabric Extender AC power supply"
PID: N5K-PAC-200W , VID: 00V0, SN: PAC12473L17

switch#
```

Related Commands	Command	Description
	show fex	Displays all configured Fabric Extender chassis connected to the switch.

Send comments to nexus5k-docfeedback@cisco.com

show locator-led

To display the status of the locator LED in a Fabric Extender, use the **show locator-led** command.

show locator-led status

Syntax Description	status	Displays the status of the locator LED in a Fabric Extender module.
--------------------	--------	---

Command Default	None
-----------------	------

Command Modes	EXEC mode
---------------	-----------

Command History	Release	Modification
	4.2(1)N1(1)	This command was introduced.

Usage Guidelines	Use the locator-led command to toggle the locator LED of a Fabric Extender.
------------------	--

Examples	This example shows how to display the modules that have the locator LED set to off or on:
----------	---

```
switch# show locator-led status
Component          Locator LED Status
-----
FEX 100            off
FEX 101            off
FEX 102            off
FEX 103            off
FEX 105            off
switch#
```

Related Commands	Command	Description
	locator-led	Turns on the locator LED of a Fabric Extender chassis.
	show fex	Displays all configured Fabric Extender chassis connected to the switch.

Send comments to nexus5k-docfeedback@cisco.com

show module fex

To display the module information for a Fabric Extender, use the **show module fex** command.

show module fex [**all** | *chassis_ID*]

Syntax Description	<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
	all	Displays information about all Fabric Extender modules.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	4.2(1)N1(1)	This command was introduced.

Examples

This example shows how to display the module information of Fabric Extenders:

```
switch# show module fex all
FEX Mod Ports Card Type                               Model                               Status.
-----
100 1    48      Fabric Extender 48x1GE Module                       N5K-C5110T-BF-1GE  present
101 1    48      Fabric Extender 48x1GE + 4x10G Mod N2K-C2248TP-1GE    present
102 1    48      Fabric Extender 48x1GE Module                       N5K-C5110T-BF-1GE  present
105 1    32      Fabric Extender 32x10GE + 8x10G Mo N2K-C2232P-10GE    present

FEX Mod Sw                Hw      World-Wide-Name(s) (WWN)
-----
100 1    4.2(1)N1(1)             0.0      --
101 1    4.2(1)N1(1)             0.103    --
102 1    4.2(1)N1(1)             0.2      --
105 1    4.2(1)N1(1)             1.0      --

FEX Mod  MAC-Address(es)                               Serial-Num
-----
100 1    000d.ecb1.1300 to 000d.ecb1.132f                       JAF1237ABSE
101 1    0022.bdd1.3cc0 to 0022.bdd1.3cef                       JAF11223333
102 1    000d.ecb1.25c0 to 000d.ecb1.25ef                       JAF1241BLHQ
105 1    000d.ecca.6f40 to 000d.ecca.6f5f                       JAF1331AKBM
switch#
```

This commands shows how to display the module information for a specific Fabric Extender:

```
switch# show module fex 100
FEX Mod Ports Card Type                               Model                               Status.
-----
100 1    48      Fabric Extender 48x1GE Module                       N5K-C5110T-BF-1GE  present

FEX Mod Sw                Hw      World-Wide-Name(s) (WWN)
-----
```

Send comments to nexus5k-docfeedback@cisco.com

```
100 1    4.2(1)N1(1)    0.0    --

FEX Mod  MAC-Address(es)                      Serial-Num
--- ---  -
100 1    000d.ecb1.1300 to 000d.ecb1.132f      JAF1237ABSE
switch#
```

Related Commands

Command	Description
show fex	Displays all configured Fabric Extender chassis connected to the switch.

Send comments to nexus5k-docfeedback@cisco.com

show provision

To display information about provision, use the **show provision** command.

show provision failed-config *slot-number*

Syntax Description	failed-config	Displays the configuration that failed to be applied to the slot.
	<i>slot-number</i>	Slot number in the chassis. The range is from 2 to 199.

Command Default	None
-----------------	------

Command Modes	EXEC mode Configuration synchronization mode
---------------	---

Command History	Release	Modification
	5.0(2)N1(1)	This command was introduced.

Examples	<p>This example shows how to display the preprovisioning configuration that failed to be applied to slot 2:</p> <pre>switch# show provision failed-config 2 Config has not been applied yet for this slot.</pre> <p>switch#</p>
----------	--

Related Commands	Command	Description
	provision	Preprovisions a module in a slot.
	show running-config exclude-provision	Displays the running configuration excluding the preprovisioned features.
	slot	Enables a slot for preprovisioning a module.

Send comments to nexus5k-docfeedback@cisco.com

show queuing interface

To display the queuing information of interfaces, use the **show queuing interface** command.

show queuing interface [**ethernet** *slot-chassis-no/port-slot-no/port-no*]

Syntax Description	ethernet	(Optional) Specifies that queuing information be displayed for an Ethernet interface or a Fabric Extender.
	<i>slot-chassis-no</i>	Slot number of the Ethernet interface or chassis ID of the Fabric Extender. The range is from 1 to 255.
	<i>port-slot-no</i>	Port number of the Ethernet interface or the remote slot ID of the Fabric Extender. The range is from 1 to 128.
	<i>port-no</i>	Port number of the Fabric Extender. The range is from 1 to 48.

Command Default Displays the queuing information for all interfaces.

Command Modes EXEC mode

Command History	Release	Modification
	4.1(3)N1(1)	This command was introduced.

Examples This example shows how to display the queuing information, including the buffer threshold and queue limit values, of a specified interface on a switch that runs Cisco NX-OS 4.2(1)N2(1):

```
switch# show queuing interface eth101/1/1
Ethernet101/1/1 queuing information:
  Input buffer allocation:
  Qos-group: 0 3 4 (shared)
  frh: 3
  drop-type: drop
  cos: 0 2 3 4 6 7
  xon      xoff      buffer-size
  -----+-----+-----
  11520    21760    44800

  Qos-group: 2
  frh: 2
  drop-type: no-drop
  cos: 1 5
  xon      xoff      buffer-size
  -----+-----+-----
  12800    23040    46080

  Queueing:
  queue    qos-group    cos                priority  bandwidth mtu
  -----+-----+-----+-----+-----+-----
  3         0 3 4        0 2 3 4 6        WRR      99        9280
  2         2          1 5              WRR      1         9280
```

Send comments to nexus5k-docfeedback@cisco.com

Buffer threshold: 163840 bytes

Queue limit: 327680 bytes

Queue Statistics:

queue rx

-----+-----

3 38557

2 0

Port Statistics:

tx queue drop

26374

Priority-flow-control enabled: no

Flow-control status:

cos	qos-group	rx pause	tx pause	masked rx pause
0	0	xon	xon	xon
1	2	xon	xon	xon
2	3	xon	xon	xon
3	0	xon	xon	xon
4	3	xon	xon	xon
5	2	xon	xon	xon
6	0	xon	xon	xon
7	n/a	xon	xon	xon

-----+-----+-----+-----+-----

0 0 xon xon xon

1 2 xon xon xon

2 3 xon xon xon

3 0 xon xon xon

4 3 xon xon xon

5 2 xon xon xon

6 0 xon xon xon

7 n/a xon xon xon

switch#

This example shows how to display the queuing information, including the buffer threshold and queue limit values, of a specified interface on a switch that runs Cisco NX-OS 5.0(2)N2(1):

switch# **show queuing interface ethernet 1/4**

Interface Ethernet1/4 TX Queuing

qos-group	sched-type	oper-bandwidth
0	WRR	50
1	WRR	50
5	priority	0

0 WRR 50

1 WRR 50

5 priority 0

Interface Ethernet1/4 RX Queuing

qos-group 0:

q-size: 102400, MTU: 1538

drop-type: drop, xon: 0, xoff: 640

Statistics:

Pkts received over the port : 1

Ucast pkts sent to the cross-bar : 0

Mcast pkts sent to the cross-bar : 1

Ucast pkts received from the cross-bar : 1577841

Pkts sent to the port : 1577841

Pkts discarded on ingress : 0

Per-priority-pause status : Rx (Inactive), Tx (Inactive)

qos-group 1:

q-size: 76800, MTU: 2240

drop-type: no-drop, xon: 128, xoff: 240

Statistics:

Pkts received over the port : 0

Ucast pkts sent to the cross-bar : 0

Mcast pkts sent to the cross-bar : 0

Ucast pkts received from the cross-bar : 0

Pkts sent to the port : 0

Pkts discarded on ingress : 0

Per-priority-pause status : Rx (Inactive), Tx (Inactive)

Send comments to nexus5k-docfeedback@cisco.com

```

qos-group 5:
  q-size: 122880, MTU: 1538
  drop-type: drop, xon: 0, xoff: 768
  Statistics:
    Pkts received over the port          : 0
    Ucast pkts sent to the cross-bar     : 0
    Mcast pkts sent to the cross-bar     : 0
    Ucast pkts received from the cross-bar : 0
    Pkts sent to the port                : 1
    Pkts discarded on ingress            : 0
    Per-priority-pause status           : Rx (Inactive), Tx (Inactive)
switch#

```

Table 1 describes the significant fields shown in the display.

Table 1 *show queuing interface Field Descriptions*

Field	Description
Ethernet ...	Ethernet interface information.
qoS-group	Information about QoS groups configured on the switch.
sched-type	Type of schedule.
WRR	Weighted round robin(WRR). Queue eight for scheduling.
Priority	Priority of the queue.
q-size	Queue size.
drop-type	Queue drop type can be either drop or no-drop.
MTU	Maximum transmit unit (MTU) for the queue.
Xon	Transmission on at this threshold.
Xoff	Transmission off at this threshold.
Buffer threshold	Buffer threshold value for the interface.
Queue limit	Queue limit value for the interface.

Related Commands

Command	Description
hardware buffer-threshold	Configures the hardware buffer threshold.
hardware queue-limit	Configures the hardware queue limit.
show fex	Displays all configured Fabric Extender chassis connected to the switch.

Send comments to nexus5k-docfeedback@cisco.com

show running-config exclude-provision

To display the running configuration without the configuration for offline preprovisioned interfaces, use the **show running-config exclude-provision** command.

show running-config exclude-provision

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	5.0(2)N1(1)	This command was introduced.

Examples	This example shows how to display the running configuration without the offline preprovisioned interfaces:
-----------------	--

```
switch# show running-config exclude-provision

!Command: show running-config exclude-provision
!Time: Mon Sep  6 08:10:16 2010

version 5.0(2)N1(1)
feature fcoe

feature telnet
feature tacacs+
cfs ipv4 distribute
cfs eth distribute
feature udd
feature interface-vlan
feature lacp
feature vpc
feature lldp
feature vtp
feature fex

username admin password 5 $1$wmFN7Wly$/pjqx1DfAkCCAg/KyxbUz/  role network-admin
username install password 5 !  role network-admin
username praveena password 5 !  role network-operator
no password strength-check
ip domain-lookup
ip domain-lookup
tacacs-server host 192.168.131.54 key 7 "wawy1234"
tacacs-server host 192.168.131.37
tacacs-server host 192.168.131.37 test username user1
aaa group server tacacs+ t1
    server 192.168.131.54
```

Send comments to nexus5k-docfeedback@cisco.com

```
aaa group server tacacs+ tacacs
radius-server host 192.168.128.5 key 7 "KkwyCet" authentication accounting
aaa group server radius r1
    server 192.168.128.5
hostname BEND-2
vlan dot1Q tag native
logging event link-status default
logging event trunk-status default
no service recover-errdisable
errdisable recovery interval 600
no errdisable detect cause link-flap
errdisable recovery cause link-flap
errdisable recovery cause udd
--More--
<--output truncated-->
switch#
```

Related Commands

Command	Description
copy running-config startup-config	Copies the running configuration to the startup configuration.
provision	Preprovisions a module in a slot.
show provision	Displays the preprovisioned module information.
show startup-config exclude-provision	Displays the startup configuration without the preprovisioning information for offline interfaces.
slot	Configures a chassis slot for a predefined module.

Send comments to nexus5k-docfeedback@cisco.com

show running-config fex

To display the running configuration for Fabric Extenders (FEXs), use the **show running-config fex** command.

show running-config fex [all]

Syntax Description	all (Optional) Displays FEX information including default settings.	
Command Default	None	
Command Modes	EXEC mode	
Command History	Release	Modification
	4.2(1)N2(1)	This command was introduced.

Examples

This example shows how to display information on the running FEX configuration, including the buffer threshold value and queue limit:

```
switch# show running-config fex

!Command: show running-config fex
!Time: Mon Jul 19 07:56:21 2010

version 4.2(1)N2(1)
feature fex

fex 100
  pinning max-links 1
  description "RedwoodFex100"
fex 101
  pinning max-links 1
  description "FEX0101"
fex 150
  pinning max-links 1
  description "PortolaFex150"
fex 151
  pinning max-links 1
  description "PortolaFex151"
fex 160
  pinning max-links 1
  description "FEX0160"
fex 198
  hardware N2232P queue-limit 50000
  pinning max-links 1
  description "WoodsideFex198"
fex 199
  hardware N2232P queue-limit 20000
  no hardware N2248T queue-limit
  hardware N2148T buffer-threshold 163840
```

Send comments to nexus5k-docfeedback@cisco.com

```
pinning max-links 1
description "WoodsideFex199"

interface port-channel100
  fex associate 100

interface port-channel150
--More--
switch#
```

Related Commands

Command	Description
hardware buffer-threshold	Configures the hardware buffer threshold.
hardware queue-limit	Configures the hardware queue limit.
show fex	Displays all configured Fabric Extender chassis connected to the switch.

Send comments to nexus5k-docfeedback@cisco.com

show sprom fex

To display information about the SPROM, use the **show sprom fex** command.

show sprom fex {all | *chassis_ID* {all | backplane | powersupply *module_no*}}

Syntax Description		
	<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
	all	Displays all SPROM content for a specific Fabric Extender.
	backplane	Displays the backplane SPROM content for a specific Fabric Extender.
	powersupply	Displays the power supply SPROM content for a specific Fabric Extender.
	<i>module_no</i>	Power supply module number for a specific Fabric Extender. The range is from 1 to 2.

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	4.2(1)N1(1)	This command was introduced.

Examples This example shows how to display all SPROM content for a specific Fabric Extender:

```
switch# show sprom fex 100 all
DISPLAY FEX 100 SUP sprom contents
Common block:
Block Signature : 0xabab
Block Version   : 3
Block Length    : 160
Block Checksum  : 0x18c9
EEPROM Size     : 65535
Block Count     : 3
FRU Major Type  : 0x6003
FRU Minor Type  : 0x0
OEM String      : Cisco Systems, Inc.
Product Number  : N5K-C5110T-BF-1GE
Serial Number   : JAF1237ABSE
Part Number     : 73-12009-02
Part Revision   : 00
Mfg Deviation   : 0
H/W Version     : 0.0
Mfg Bits        : 0
Engineer Use    : 0
snmpOID         : 9.12.3.1.9.72.5.0
Power Consump   : -200
RMA Code        : 0-0-0-0
CLEI Code       : 000000000000
VID             : V00
Supervisor Module specific block:
```


Send comments to nexus5k-docfeedback@cisco.com

```
Block Signature : 0x6002
Block Version   : 2
Block Length    : 103
Block Checksum  : 0x2648
Feature Bits    : 0x0
HW Changes Bits : 0x2
Card Index      : 11011
MAC Addresses   : 00-00-00-00-00-00
Number of MACs  : 0
Number of EPLD  : 0
Port Type-Num   : 2-52
Sensor #1       : 85,75
Sensor #2       : 100,90
Sensor #3       : 100,90
Sensor #4       : 100,90
Sensor #5       : 100,90
Sensor #6       : 100,90
Sensor #7       : 100,90
Sensor #8       : 100,90
Max Connector Power: 1000
Cooling Requirement: 300
Ambient Temperature: 40
```

DISPLAY FEX 100 backplane sprom contents:

Common block:

```
Block Signature : 0xabab
Block Version   : 3
Block Length    : 160
Block Checksum  : 0x195d
EEPROM Size     : 65535
Block Count     : 5
FRU Major Type  : 0x6001
FRU Minor Type  : 0x0
OEM String      : Cisco Systems, Inc.
Product Number  : N5K-C5110T-BF-1GE
Serial Number   : JAF1237ABSE
Part Number     : 73-12009-02
Part Revision   : 00
Mfg Deviation   : 0
H/W Version     : 0.0
Mfg Bits        : 0
Engineer Use    : 0
snmpOID         : 9.12.3.1.3.719.0.0
Power Consump   : -800
RMA Code        : 0-0-0-0
CLEI Code       : 00000000
VID             : V01
```

Chassis specific block:

```
Block Signature : 0x6001
Block Version   : 3
Block Length    : 39
Block Checksum  : 0x28a
Feature Bits    : 0x0
HW Changes Bits : 0x2
Stackmib OID    : 0
MAC Addresses   : 00-0d-ec-b1-13-00
Number of MACs  : 64
OEM Enterprise  : 0
OEM MIB Offset  : 0
MAX Connector Power: 0
```

WWN software-module specific block:

```
Block Signature : 0x6005
Block Version   : 1
Block Length    : 0
```

Send comments to nexus5k-docfeedback@cisco.com

```

Block Checksum : 0x66
wwn usage bits:
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00
License software-module specific block:
Block Signature : 0x6006
Block Version : 1
Block Length : 16
Block Checksum : 0x77
lic usage bits:
00 00 00 00 00 00 00 00

DISPLAY FEX 100 power-supply 1 sprom contents:
Common block:
Block Signature : 0xabab
Block Version : 3
Block Length : 124
Block Checksum : 0x15fc
EEPROM Size : 124
Block Count : 1
FRU Major Type : 0xab01
FRU Minor Type : 0x1
OEM String : Cisco Systems, Inc.
Product Number : N5K-PAC-200W
Serial Number : PAC12473L17
Part Number : 341-0335-01
Part Revision : 01
CLEI Code : COUPADSBA
VID : 00V0
snmpOID : 0.0.0.0.0.0.0.0
H/W Version : 0.1
Current : 1667
RMA Code : 0-0-0-0
switch#

```

Send comments to nexus5k-docfeedback@cisco.com

This command shows how to display the power supply SPROM contents for a specific Fabric Extender:

```
switch# show sprom fex 100 powersupply 1
DISPLAY FEX 100 power-supply 1 sprom contents:
Common block:
  Block Signature : 0xabab
  Block Version   : 3
  Block Length    : 124
  Block Checksum  : 0x15fc
  EEPROM Size     : 124
  Block Count     : 1
  FRU Major Type  : 0xab01
  FRU Minor Type  : 0x1
  OEM String      : Cisco Systems, Inc.
  Product Number  : N5K-PAC-200W
  Serial Number   : PAC12473L17
  Part Number     : 341-0335-01
  Part Revision   : 01
  CLEI Code       : COUPADSBAA
  VID             : 00V0
  snmpOID         : 0.0.0.0.0.0.0.0
  H/W Version     : 0.1
  Current         : 1667
  RMA Code        : 0-0-0-0
switch#
```

Related Commands

Command	Description
show fex	Displays all configured Fabric Extender chassis connected to the switch.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

show startup-config exclude-provision

To display the startup configuration that excludes the configuration for offline preprovisioned interfaces, use the **show startup-config exclude-provision** command.

show startup-config exclude-provision

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	5.0(2)N1(1)	This command was introduced.

Examples	<p>This example shows how to display the startup configuration without the offline preprovisioned interfaces:</p> <pre>switch# show startup-config exclude-provision</pre>
-----------------	--

Related Commands	Command	Description
	provision	Preprovisions a module in a slot.
	show provision	Displays the preprovisioned module information.
	show running-config exclude-provision	Displays the running configuration excluding the preprovisioned features.
	slot	Configures a chassis slot for a predefined module.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

show system reset-reason fex

To display the reason for the last reset of the Fabric Extender, use the **show system reset-reason fex** command.

show system reset-reason fex *chassis_ID*

Syntax Description	<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
--------------------	-------------------	--

Command Default	None
-----------------	------

Command Modes	EXEC mode
---------------	-----------

Command History	Release	Modification
	4.2(1)N1(1)	This command was introduced.

Examples This example shows how to display the last reset reason for a specific Fabric Extender:

```
switch# show system reset-reason fex 100
----- reset reason for FEX 100 ----

1) At 430815 usecs after Fri Apr 16 04:27:04 2010
   Reset Reason: Reset Requested by CLI command reload (9)
   Service (Additional Info): Reload requested by supervisor
   Image Version: 4.2(1)N1(1)

2) At 505550 usecs after Fri Apr 16 03:39:50 2010
   Reset Reason: Reset due to upgrade (88)
   Service (Additional Info): Reset due to upgrade
   Image Version: 4.2(1u)N1(1u)

3) At 607267 usecs after Fri Apr 16 02:50:10 2010
   Reset Reason: Reset due to upgrade (88)
   Service (Additional Info): Reset due to upgrade
   Image Version: 4.2(1)N1(1)

4) At 857790 usecs after Fri Apr 16 02:00:22 2010
   Reset Reason: Reset due to upgrade (88)
   Service (Additional Info): Reset due to upgrade
   Image Version: 4.2(1u)N1(1u)

switch#
```

Related Commands	Command	Description
	show fex	Displays all configured Fabric Extender chassis connected to the switch.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

show version fex

To display the software version information about a Fabric Extender, use the **show version fex** command.

show version fex *chassis_ID*

Syntax Description	<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
--------------------	-------------------	--

Command Default	None
-----------------	------

Command Modes	EXEC mode
---------------	-----------

Command History	Release	Modification
	4.2(1)N1(1)	This command was introduced.

Examples

This example shows how to display the software version of a Fabric Extender:

```
switch# show version fex 100
Software
  Bootloader version:      1.12
  System boot mode:       primary
  System image version:    4.2(1)N2(1) [build 4.2(1)N2(1)]

Hardware
  Module:                  Fabric Extender 48x1GE Module
  CPU:                     Motorola, e300c1
  Serial number:           JAF1302ABDP
  Bootflash:               locked

Kernel uptime is 0 day(s), 9 hour(s), 9 minutes(s), 16 second(s)

Last reset at Fri Jul 02 04:27:04 2010
  Reason: Reset Requested by CLI command reload
  Service: Reload requested by supervisor
switch#
```

Related Commands	Command	Description
	show fex	Displays all configured Fabric Extender chassis connected to the switch.

Send comments to nexus5k-docfeedback@cisco.com



T Commands

This chapter describes the Cisco NX-OS commands that begin with T that are used to manage a Cisco Nexus 2000 Series Fabric Extender from a Cisco Nexus 5000 Series switch.

Send comments to nexus5k-docfeedback@cisco.com

type

To set the Fabric Extender card type to a specific card, use the **type** command. To revert to the default FEX card, use the **no** form of this command.

type *fex_card_type*

no type

Syntax Description	<i>fex_card_type</i>	Fabric Extender card type. The following Fabric Extender card types are supported: <ul style="list-style-type: none">• N2148T—Fabric Extender 48x1G 4x10G SFP+ Module• N2224TP—Fabric Extender 24x1G 2x10G SFP+ Module• N2232P—Fabric Extender 32x10G SFP+ 8x10G SFP+ Module• N2232TM—Fabric Extender 32x10GBase-T 8x10G SFP+ Module• N2248T—Fabric Extender 48x1G 4x10G SFP+ Module				
Command Default	None					
Command Modes	Fabric extender configuration mode					
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>4.2(1)N1(1)</td><td>This command was introduced.</td></tr></table>	Release	Modification	4.2(1)N1(1)	This command was introduced.	
Release	Modification					
4.2(1)N1(1)	This command was introduced.					
Usage Guidelines	<p>The following Cisco Nexus 2000 Series Fabric Extenders are supported on a Cisco Nexus 5000 Series switch that runs a Cisco NX-OS release 4.2(1)N2(1):</p> <ul style="list-style-type: none">• Cisco Nexus 2148T Fabric Extender—It has four 10-Gigabit Ethernet fabric interfaces for its uplink connection to the parent Cisco Nexus 5000 Series switch and 48 1000BASE-T (1-Gigabit) Ethernet host interfaces for its downlink connection to servers or hosts.• Cisco Nexus N2224TP Fabric Extender—It has two 10-Gigabit Ethernet fabric interfaces with small form-factor pluggable (SFP+) interface adapters for its uplink connection to the parent Cisco Nexus 5000 Series switch and 24 1000BASE-T (1-Gigabit) Ethernet host interfaces for its downlink connection to servers or hosts. It does not support Fibre Channel over Ethernet (FCoE).• Cisco Nexus 2232P Fabric Extender—It has eight 10-Gigabit Ethernet fabric interfaces with small form-factor pluggable (SFP+) interface adapters for its uplink connection to the parent Cisco Nexus 5000 Series switch and 32 10-Gigabit Ethernet fabric interfaces with SFP+ interface adapters for its downlink connection to servers or hosts.• Cisco Nexus 2248T Fabric Extender—It has four 10-Gigabit Ethernet fabric interfaces with SFP+ interface adapters for its uplink connection to the parent Cisco Nexus 5000 Series switch and 48 1000BASE-T (1-Gigabit) Ethernet host interfaces for its downlink connection to servers or hosts.					

Send comments to nexus5k-docfeedback@cisco.com

The following Cisco Nexus 2000 Series Fabric Extenders are supported on a Cisco Nexus 5000 Series switch that runs a Cisco NX-OS release 5.0(3)N2(1):

- Cisco Nexus 2148T Fabric Extender—It has four 10-Gigabit Ethernet fabric interfaces for its uplink connection to the parent Cisco Nexus 5000 Series switch and 48 1000BASE-T (1-Gigabit) Ethernet host interfaces for its downlink connection to servers or hosts.
- Cisco Nexus N2224TP Fabric Extender—It has two 10-Gigabit Ethernet fabric interfaces with small form-factor pluggable (SFP+) interface adapters for its uplink connection to the parent Cisco Nexus 5000 Series switch and 24 1000BASE-T (1-Gigabit) Ethernet host interfaces for its downlink connection to servers or hosts. It does not support Fibre Channel over Ethernet (FCoE).
- Cisco Nexus 2232P Fabric Extender—It has eight 10-Gigabit Ethernet fabric interfaces with small form-factor pluggable (SFP+) interface adapters for its uplink connection to the parent Cisco Nexus 5000 Series switch and 32 10-Gigabit Ethernet fabric interfaces with SFP+ interface adapters for its downlink connection to servers or hosts.
- Cisco Nexus 2232TM Fabric Extender—It has eight 10-Gigabit Ethernet fabric interfaces with small form-factor pluggable (SFP+) interface adapters for its uplink connection to the parent Cisco Nexus 5000 Series switch and 32 10-Gigabit BASE-T Ethernet fabric interfaces for its downlink connection to servers or hosts.
- Cisco Nexus 2248T Fabric Extender—It has four 10-Gigabit Ethernet fabric interfaces with SFP+ interface adapters for its uplink connection to the parent Cisco Nexus 5000 Series switch and 48 1000BASE-T (1-Gigabit) Ethernet host interfaces for its downlink connection to servers or hosts.

Examples

This example shows how to configure the Fabric Extender card:

```
switch(config)# fex 100
switch(config-fex)# type N2148T
switch(config-fex)#
```

Related Commands

Command	Description
fex	Creates a Fabric Extender and enters fabric extender configuration mode.
show fex	Displays all configured Fabric Extender chassis connected to the switch.

■ type

Send comments to nexus5k-docfeedback@cisco.com