

*Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)*



## T Commands

---

This chapter describes the Cisco NX-OS Virtual Router Redundancy Protocol (VRRP) commands that begin with T.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## track (VRRP)

To modify the priority for a virtual router based on a tracked object, use the **track** command. To disable priority tracking for a virtual router, use the **no** form of this command.

**track** *object-number* [**decrement** *value*]

**no track** *object-number* [**decrement** *value*]

<b>Syntax Description</b>	<i>object-number</i>	Number for a configured tracked object. The range is from 1 to 500.
	<b>decrement</b> <i>value</i>	(Optional) Decrements the VRRP priority if the tracked object is down. The range is from 1 to 254.

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	VRRP configuration mode
----------------------	-------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)N1(1)	This command was introduced.

<b>Usage Guidelines</b>	Use the <b>track (VRRP)</b> command to change the priority of the virtual router based on the state of a configured tracked object. Use the track command to configure the tracked object. When the tracked object is down, the priority reverts to the priority value for the virtual router. When the tracked object is up, the priority of the virtual router is restored to the original value.
	This command does not require a license.

<b>Examples</b>	This example shows how to enable object tracking for a virtual router:
	<pre> switch# <b>configure terminal</b> switch(config)# <b>track 33 ip route 192.0.2.0/24 reachability</b> switch(config)# <b>interface ethernet 2/1</b> switch(config-if)# <b>no switchport</b> switch(config-if)# <b>vrrp 250</b> switch(config-if-vrrp)# <b>track 33 priority 2</b> switch(config-if-vrrp)# </pre>

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>feature vrrp</b>	Enables VRRP.
	<b>show vrrp</b>	Displays VRRP configuration information.

***Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)***

Command	Description
<b>track interfave (VRRP)</b>	Tracks the state of an interface and modifies the VRRP priority if that interface state goes down.
<b>vrrp</b>	Configures a VRRP group.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## track interface (VRRP)

To track the priority for a virtual router based on an interface, use the **track interface** command. To disable priority tracking for a virtual router, use the **no** form of this command.

**track interface** {*ethernet slot/port* | **port-channel** *number*[*.sub\_if\_number*]} **priority** *value*

**no track interface** {*ethernet slot/port* | **port-channel** *number*[*.sub\_if\_number*]} **priority** *value*

### Syntax Description

<b>ethernet</b> <i>slot/port</i>	Specifies the virtual router interface for which to track the priority. The slot number is from 1 to 255, and the port number is from 1 to 128.
<b>port-channel</b> <i>number</i>	Specifies the port-channel group for which to track priority. The range is from 1 to 4096
<i>sub_if-number</i>	(Optional) Subinterface number. The range is from 1 to 4093.
<b>priority</b> <i>value</i>	Specifies the interface priority for a virtual router. The range of values is from 1 to 254. If this router is the owner of the IP addresses, the value is automatically set to 254.

### Command Default

Disabled

### Command Modes

VRRP configuration mode

### Command History

Release	Modification
5.0(3)N1(1)	This command was introduced.

### Usage Guidelines

Use the **track** command to change the priority of the virtual router based on the state of another interface in the switch. When the tracked interface is down, the priority reverts to the priority value for the virtual router. When the tracked interface is up, the priority of the virtual router is restored to the interface state tracking value.



#### Note

Interface state tracking will not be operational unless you enable preemption on the interface.

This command does not require a license.

### Examples

This example shows how to enable interface state tracking for a virtual router:

```
switch# configure terminal
switch(config)# interface ethernet 2/1
switch(config-if)# no switchport
switch(config-if)# vrrp 250
switch(config-if-vrrp)# track interface ethernet 2/2 priority 2
switch(config-if-vrrp)#
```

***Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)***

Related Commands	Command	Description
	<b>feature vrrp</b>	Enables VRRP.
	<b>show vrrp</b>	Displays VRRP configuration information.
	<b>track (VRRP)</b>	Tracks an object to modify the VRRP priority.
	<b>vrrp</b>	Configures a VRRP group.

***Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)***