



## **Cisco Nexus 5500 Series NX-OS Fabric Extender Command Reference**

Cisco NX-OS Releases 7.x

First Published: January 31, 2014

### **Americas Headquarters**

Cisco Systems, Inc.  
170 West Tasman Drive  
San Jose, CA 95134-1706  
USA  
<http://www.cisco.com>  
Tel: 408 526-4000  
800 553-NETS (6387)  
Fax: 408 527-0883

Text Part Number: OL-30873-01

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: [www.cisco.com/go/trademarks](http://www.cisco.com/go/trademarks). Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

*Cisco Nexus 5500 Series NX-OS Fabric Extender Command Reference*  
© 2014 Cisco Systems, Inc. All rights reserved.



# CONTENTS

## **Preface** v

Audience v

Document Conventions v

Related Documentation vi

Documentation Feedback vii

Obtaining Documentation and Submitting a Service Request vii

## **A Commands** FEX-1

attach fex FEX-2

## **D Commands** FEX-3

description (fex) FEX-4

diagnostic bootup level FEX-5

## **F Commands** FEX-7

fcoe FEX-8

feature fex FEX-10

fex FEX-11

fex associate FEX-13

fex pinning redistribute FEX-14

fex queue-limit FEX-15

## **H Commands** FEX-17

hardware buffer-threshold FEX-18

hardware N2248PQ uplink-load-balance-mode FEX-20

hardware queue-limit FEX-21

hardware shared-buffer-size FEX-24

hardware uplink-pause-no-drop FEX-26

## **L Commands** FEX-29

locator-led fex FEX-30

logging fex FEX-31

**P Commands** FEX-33

pinning max-links FEX-34

provision FEX-36

**S Commands** FEX-39

serial FEX-40

slot FEX-42

switchport mode fex-fabric FEX-43

**Show Commands** FEX-45

show diagnostic result fex FEX-46

show environment fex FEX-48

show fex FEX-50

show fex detail FEX-53

show fex transceiver FEX-56

show fex version FEX-58

show interface fex-fabric FEX-59

show interface fex-intf FEX-60

show interface transceiver fex-fabric FEX-61

show inventory fex FEX-63

show locator-led FEX-64

show module fex FEX-65

show provision FEX-67

show queuing interface FEX-68

show running-config exclude-provision FEX-70

show running-config fex FEX-72

show sprom fex FEX-74

show startup-config exclude-provision FEX-78

show system reset-reason fex FEX-79

show version fex FEX-81

**T Commands** FEX-83

type FEX-84



## Preface

---

This preface describes the audience, organization, and conventions of the *Cisco Nexus 5500 Series NX-OS Fabric Extender Command Reference*. It also provides information on how to obtain related documentation.

This preface includes the following sections:

- [Audience, page v](#)
- [Document Conventions, page v](#)
- [Related Documentation, page vi](#)
- [Documentation Feedback, page vii](#)
- [Obtaining Documentation and Submitting a Service Request, page vii](#)

## Audience

This publication is for experienced users who configure and maintain Cisco NX-OS devices.

## Document Conventions

Command descriptions use these conventions:

Convention	Description
<b>boldface font</b>	Commands and keywords are in boldface.
<i>italic font</i>	Arguments for which you supply values are in italics.
[ ]	Elements in square brackets are optional.
{x   y   z}	Alternative keywords are grouped in braces and separated by vertical bars.
[ x   y   z ]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.

Screen examples use these conventions:

<code>screen font</code>	Terminal sessions and information that the switch displays are in screen font.
<b>boldface screen font</b>	Information you must enter is in boldface screen font.
<i>italic screen font</i>	Arguments for which you supply values are in italic screen font.
< >	Nonprinting characters, such as passwords, are in angle brackets.
[ ]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

This document uses the following conventions:



#### Note

Means reader *take note*. Notes contain helpful suggestions or references to material not covered in the manual.



#### Caution

Means reader *be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

## Related Documentation

Documentation for Cisco Nexus 5000 Series Switches and Cisco Nexus 2000 Series Fabric Extenders is available at the following URL:

[http://www.cisco.com/en/US/products/ps9670/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/ps9670/tsd_products_support_series_home.html)

The documentation set includes the following types of documents:

- Licensing Information Guide
- Release Notes
- Installation and Upgrade Guides
- Configuration Guides
- Configuration Examples and TechNotes
- Programming Guides
- Operations Guides
- Error and System Message Guides
- Field Notices
- Security Advisories, Responses and Notices
- Troubleshooting Guide
- Command References
- MIB Reference Guide

## Documentation Feedback

To provide technical feedback on this document or to report an error or omission, please send your comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com). We appreciate your feedback.

## Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as an RSS feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service. Cisco currently supports RSS Version 2.0.







# A Commands

---

This chapter describes the Cisco NX-OS commands that begin with A that are used to manage a Cisco Nexus 2000 Series Fabric Extender from a Cisco Nexus 5500 switch.

# attach fex

To access the command-line interface (CLI) of a connected Fabric Extender to run diagnostic commands, use the **attach fex** command.

**attach fex** *chassis\_ID*

## Syntax Description

<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
-------------------	--

## Command Default

None

## Command Modes

EXEC mode

## Command History

Release	Modification
5.0(2)N1(1)	This command was introduced.

## Usage Guidelines

Use the **attach fex** command to access the CLI on a connected Fabric Extender and performing diagnostic commands. We recommend that you use this command only following direction from Cisco technical support personnel.

## Examples

This example shows how to access the CLI of a connected Fabric Extender to run diagnostic commands:

```
switch# attach fex 101
```

## Related Commands

Command	Description
<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.



## D Commands

---

This chapter describes the Cisco NX-OS commands that begin with D that are used to manage a Cisco Nexus 2000 Series Fabric Extender from a Cisco Nexus 5500 switch.

# description (fex)

To specify a description for a Fabric Extender, use the **description** command. To revert to the default description, use the **no** form of this command.

**description** *description*

**no description**

<b>Syntax Description</b>	<i>description</i>	Description of a Fabric Extender. The default is the string FEXxxxx where xxxx is the chassis ID. For example, if the chassis ID is 123, the default description is FEX0123. The maximum length is 20 alphanumeric characters.
---------------------------	--------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Fabric extender configuration mode
----------------------	------------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(2)N1(1)	This command was introduced.

**Examples** This example shows how to specify a description for a Fabric Extender:

```
switch# configure terminal
switch(config)# fex 101
switch(config-fex)# description Rack16_FEX101
```

This example shows how to revert to the default description for a Fabric Extender:

```
switch# configure terminal
switch(config)# fex 101
switch(config-fex)# no description
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>fex</b>	Creates a Fabric Extender and enters Fabric Extender configuration mode.
	<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

# diagnostic bootup level

To configure the bootup diagnostic level to trigger diagnostics when the device boots, use the **diagnostic bootup level** command. To remove the bootup diagnostic level configuration, use the **no** form of this command.

**diagnostic bootup level {bypass | complete}**

**no diagnostic bootup level {bypass | complete}**

Syntax Description	bypass	Specifies that all bootup tests are skipped.
	complete	Specifies that all bootup diagnostics are performed. This is the default value.

Command Default	Complete
-----------------	----------

Command Modes	Global configuration mode
---------------	---------------------------

Command History	Release	Modification
	5.0(2)N1(1)	This command was introduced.
	5.0(2)N1(1)	Support was added to control the diagnostic level of all the Fabric Extenders connected to the switch.

**Examples**

This example shows how to configure the bootup diagnostics level to trigger the complete diagnostics:

```
switch(config)# diagnostic bootup level complete
switch(config)#
```

This example shows how to remove the bootup diagnostics level configuration:

```
switch(config)# no diagnostic bootup level complete
switch(config)#
```

Related Commands	Command	Description
	<b>show diagnostic bootup level</b>	Displays the bootup diagnostics level.
	<b>show diagnostic bootup result</b>	Displays the results of the diagnostics tests.

■ diagnostic bootup level



## F Commands

---

This chapter describes the Cisco NX-OS commands that begin with F that are used to manage a Cisco Nexus 2000 Series Fabric Extender from a Cisco Nexus 5500 switch.

# fcoe

To associate a Cisco Nexus 2000 Series Fabric Extender (FEX) to a switch for pinning Fibre Channel over Ethernet (FCoE) Initialization Protocol (FIP) and FCoE traffic, use the **fcoe** command. To remove the association, use the **no** form of this command.

**fcoe** [**vsan** *vsan-id*]

**no fcoe** [**vsan**]

Syntax Description	<b>vsan</b> <i>vsan-id</i> Specifies the VSAN status. The VSAN ID range is from 1 to 4094.	
Command Default	None	
Command Modes	FEX configuration mode VLAN configuration mode	
Command History	Release	Modification
	5.1(3)N1(1)	This command was introduced.

**Usage Guidelines**

Before you use this command, make sure that you enable the Fabric Extender (FEX) features on the switch by using the **feature fex** command.

You can use this command only on a Cisco Nexus 2232P Fabric Extender. When you bind an interface to a virtual Fibre Channel interface to enable FCoE traffic, you must use slot number 1. The port number can be from 1 to 32.

**Examples** This example shows how to configure a FEX as FCoE enabled:

```
switch# configure terminal
switch(config)# feature fex
switch(config)# fex 100
switch(config-fex)# fcoe
switch(config-fex)#
```

This example shows how to configure a pair of FEXs to carry FCoE traffic in a fabric virtual port channel (vPC) topology, with the host uplink ports in the FEXs configured to the same port channel:

```
switch# configure terminal
switch(config)# feature lacp
switch(config)# feature fex
switch(config)# feature fcoe
switch(config)# fex 100
switch(config-fex)# fcoe
switch(config-fex)# exit
switch(config)# interface vfc 1
switch(config-if)# bind interface eth101/1/1
```



```
switch(config)# interface eth101/1/1
switch(config-if)# channel-group 1
switch(config)# fex 102
switch(config-fex)# fcoe
switch(config)# interface vfc 1
switch(config-if)# bind interface eth102/1/1
switch(config)# interface eth102/1/1
switch(config-if)# channel-group 1
switch(config-if)#
```

This example shows how to configure FCoE traffic on a VLAN:

```
switch# configure terminal
switch(config)# vlan 5
switch(config-vlan)# fcoe vsan 1
switch(config-vlan)#
```

This example shows how to disable FCoE traffic on a FEX:

```
switch# configure terminal
switch(config)# fex 100
switch(config-fex)# no fcoe
switch(config-fex)#
```

#### Related Commands

Command	Description
<b>feature fcoe</b>	Enables the FCoE feature on the switch.
<b>feature fex</b>	Enables the FEX feature on the switch.
<b>feature lacp</b>	Enables the Link Aggregation Control Protocol (LACP).
<b>show fex</b>	Displays information about a specific FEX.

# feature fex

To enable Fabric Extender (FEX) features on the switch, use the **feature fex** command. To disable FEX, use the **no** form of this command.

- feature fex**
- no feature fex**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** Global configuration mode

Command History	Release	Modification
	5.0(2)N1(1)	This command was introduced.

**Examples** This example shows how to enable FEX features on the switch:

```
switch(config)# feature fex
switch(config)#
```

Related Commands	Command	Description
	<b>fex</b>	Creates a Fabric Extender and enters fabric extender configuration mode.
	<b>show feature</b>	Displays the features enabled or disabled on the switch.

# fex

To create a Fabric Extender and enter fabric extender configuration mode, use the **fex** command. To delete the Fabric Extender configuration, use the **no** form of this command.

**fex** *chassis\_ID*

**no fex** *chassis\_ID*

Syntax Description	<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
--------------------	-------------------	--

Command Default	None
-----------------	------

Command Modes	Global configuration mode
---------------	---------------------------

Command History	Release	Modification
	5.0(2)N1(1)	This command was introduced.

Usage Guidelines	You can create and configure the Fabric Extender before you connect and associate it to an interface on the parent switch. Once you associate the Fabric Extender to the switch, the configuration you created is transferred over to the Fabric Extender and applied.
------------------	--

Examples	This example shows how to enter Fabric Extender configuration mode:
----------	---

```
switch# configure terminal
switch(config)# fex 101
switch(config-fex)#
```

This example shows how to delete the Fabric Extender configuration:

```
switch(config-fex)# no fex 101
switch(config)#
```

Related Commands	Command	Description
	<b>beacon</b>	Turns on the locator beacon LED of a Fabric Extender.
	<b>description (fex)</b>	Specifies a description for a Fabric Extender.
	<b>fex associate</b>	Associates a Fabric Extender to an Ethernet or EtherChannel interface.
	<b>pinning max-links</b>	Specifies the number of statically pinned uplinks connected to a Fabric Extender.
	<b>serial</b>	Assigns a serial number to a Fabric Extender.

Command	Description
<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.
<b>type</b>	Specifies the Fabric Extender card.

# fex associate

To associate a Fabric Extender to a fabric interface, use the **fex associate** command. To disassociate the Fabric Extender, use the **no** form of this command.

**fex associate** *chassis\_ID*

**no fex associate** [*chassis\_ID*]

<b>Syntax Description</b>	<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
---------------------------	-------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Interface configuration mode
----------------------	------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(2)N1(1)	This command was introduced.

<b>Usage Guidelines</b>	Before you can associate an interface on the parent switch to the Fabric Extender, you must first make the interface into a fabric interface by entering the <b>switchport mode fex-fabric</b> command.
-------------------------	---

<b>Examples</b>	This example shows how to associate the Fabric Extender to an Ethernet interface:
-----------------	---

```
switch# configure terminal
switch(config)# interface ethernet 1/40
switch(config-if)# switchport mode fex-fabric
switch(config-if)# fex associate 101
```

This example shows how to associate the Fabric Extender to an EtherChannel interface:

```
switch# configure terminal
switch(config)# interface port-channel 4
switch(config-if)# switchport mode fex-fabric
switch(config-if)# fex associate 101
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.
	<b>switchport mode fex-fabric</b>	Sets the interface to be an uplink port.

# fex pinning redistribute

To redistribute the host interfaces on a Fabric Extender, use the **fex pinning redistribute** command.

**fex pinning redistribute** *chassis\_ID*

<b>Syntax Description</b>	<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
---------------------------	-------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(2)N1(1)	This command was introduced.

<b>Usage Guidelines</b>	When you provision the Fabric Extender using the statically pinned mode (see the <i>Cisco Nexus 2000 Series Fabric Extender Software Configuration Guide</i> ), the host interfaces on the Fabric Extender are pinned to the fabric interfaces in the order that they were initially configured. The next time that you reboot the Fabric Extender, the configured fabric interfaces are pinned to the host interfaces in an ascending order by the port number of the fabric interface.
-------------------------	--

Use the **fex pinning redistribute** command if you want to configure the same fixed distribution of host interfaces without restarting the Fabric Extender after your initial configuration.



## Caution

This command disrupts all the host interface ports of the Fabric Extender. However, the disruption is shorter than would be the case if you reboot the Fabric Extender.

<b>Examples</b>	<p>This example shows how to redistribute the host interfaces on a Fabric Extender:</p> <pre>switch# <b>fex pinning redistribute</b> 101 switch#</pre>
-----------------	--

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>pinning max-links</b>	Defines the number of uplinks on a Fabric Extender.
	<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.
	<b>show interface fex-intf</b>	Displays the Fabric Extender ports pinned to a specific switch interface.

# fex queue-limit

To limit the amount of input buffer space (in bytes) allocated to each Fabric Extender port, use the **fex queue-limit** command. To disable the drop threshold and allow a Fabric Extender port to use all available buffer space, use the **no** form of this command.

**fex queue-limit**

**no fex queue-limit**

## Syntax Description

This command has no arguments or keywords.

## Command Default

Fabric Extender queue limit is available in the default configuration and is set on.

## Command Modes

System QoS configuration mode

## Command History

Release	Modification
5.0(2)N1(1)	This command was introduced.

## Usage Guidelines

By default, the drop threshold applies to each Fabric Extender port to limit the amount of buffer being allocated for each port. To restore the default queue limit of each Fabric Extender port, use the **fex queue-limit** command.

## Examples

This example shows how to set the queue limit for the input buffer for each Fabric Extender port:

```
switch(config)# system qos
switch(config-sys-qos)# fex queue-limit
switch(config-sys-qos)#
```

This example shows how to restore the default queue limit for each Fabric Extender port:

```
switch(config)# system qos
switch(config-sys-qos)# no fex queue-limit
switch(config-sys-qos)#
```

## Related Commands

Command	Description
<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.







# H Commands

---

This chapter describes the Cisco NX-OS commands that begin with H that are used to manage a Cisco Nexus 2000 Series Fabric Extender from a Cisco Nexus 5500 switch.

# hardware buffer-threshold

To limit the amount of input hardware buffer usage for each Fabric Extender, use the **hardware buffer-threshold** command. To revert to the default and allow a Fabric Extender to use all available hardware buffer space, use the **no** form of this command.

**hardware** *fex\_card\_typ* **buffer-threshold** *buffer-limit*

**no hardware** *fex\_card\_typ* **buffer-threshold**

## Syntax Description

<i>fex_card_type</i>	Fabric Extender card type. The following Fabric Extender card types are supported: <ul style="list-style-type: none"> <li><b>N2148T</b>—Fabric Extender 48x1G 4x10G SFP+ Module</li> </ul> See the “Usage Guidelines” section for a description of this Fabric Extender.
<i>buffer-limit</i>	Buffer threshold limit in bytes. The range is from 81920 to 316160.

## Command Default

None

## Command Modes

Fabric extender configuration mode

## Command History

Release	Modification
5.0(2)N1(1)	This command was introduced.

## Usage Guidelines



### Note

This command is supported only on a Cisco Nexus 2148T Fabric Extender.

The Cisco Nexus 2148T Fabric Extender has four 10-Gigabit Ethernet fabric interfaces for its uplink connection to the parent Cisco Nexus 5500 Series switch and 48 1000BASE-T (1-Gigabit) Ethernet host interfaces for its downlink connection to servers or hosts.

The **buffer-threshold** keyword sets the consumption level of input buffers before an indication is sent to the egress queue to start observing the tail drop threshold. If the buffer usage is lower than the configured buffer threshold, the tail drop threshold is ignored.

## Examples

This example shows how to configure the hardware buffer threshold limit on a Cisco Nexus 2148T Fabric Extender:

```
switch(config)# fex 110
switch(config-fex)# hardware N2148T buffer-threshold 163840
switch(config-fex)#
```

This example shows how to remove the hardware buffer threshold configured on a Cisco Nexus 2148T Fabric Extender:

```
switch(config)# fex 110  
switch(config-fex)# no hardware N2148T buffer-threshold  
switch(config-fex)#
```

**Related Commands**

Command	Description
<b>fex</b>	Creates a Fabric Extender and enters fabric extender configuration mode.
<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.
<b>show queuing interface</b>	Displays information about interface queuing parameters, including buffer threshold and queue limits.
<b>show running-config fex</b>	Displays the running configuration for Fabric Extenders.

# hardware N2248PQ uplink-load-balance-mode

To enable the load balancing queues for the Cisco Nexus 2248PQ Fabric Extender, use the **hardware N2248PQ uplink-load-balance-mode** command. To disable load balancing queues, use the **no** form of this command.

**hardware N2248PQ uplink-load-balance-mode**

**no hardware N2248PQ uplink-load-balance-mode**

## Syntax Description

This command has no arguments or keywords.

## Command Default

None

## Command Modes

Fabric extender configuration mode

## Command History

Release	Modification
6.0(2)N1(1)	This command was introduced.

## Usage Guidelines



### Note

This command is supported only on a Cisco Nexus 2248PQ Fabric Extender.

The Cisco Nexus 2248PQ has 48 10-Gigabit Ethernet host interfaces with SFP+ interface adapters and 16 10-Gigabit Ethernet fabric interfaces corresponding to 4 QSFP interface adapters for its uplink connection to the parent switch.

## Examples

This example shows how to enable the load balancing queues for a Cisco Nexus 2248PQ Fabric Extender:

```
switch(config)# fex 100
switch(config-fex)# hardware N2248PQ uplink-load-balance-mode
switch(config-fex)#
```

This example shows how to disable the load balancing queues for a Cisco Nexus 2248PQ Fabric Extender:

```
switch(config)# fex 100
switch(config-fex)# no hardware N2248PQ uplink-load-balance-mode
switch(config-fex)#
```

# hardware queue-limit

To control the egress queue tail drop threshold level on a Fabric Extender, use the **hardware queue-limit** command. To disable the drop threshold and allow a Fabric Extender to use all available hardware buffer space, use the **no** form of this command.

**hardware** *fex\_card\_typ* **queue-limit** [*queue-limit*] [**rx** | **tx**]

**no hardware** *fex\_card\_typ* **queue-limit** [**rx** | **tx**]

## Syntax Description

<i>fex_card_type</i>	<p>Fabric Extender card type. The following Fabric Extender card types are supported:</p> <ul style="list-style-type: none"> <li>• <b>N2148T</b>—Fabric Extender 48x1G 4x10G SFP+ Module</li> <li>• <b>N224TP</b>—Fabric Extender 24x1G 2x10G SFP+ Module</li> <li>• <b>N2232P</b>—Fabric Extender 32x10G SFP+ 8x10G SFP+ Module</li> <li>• <b>N2232TM</b>—Fabric Extender 32x10GBase-T 8x10G SFP+ Module</li> <li>• <b>N2248T</b>—Fabric Extender 48x1G 4x10G SFP+ Module</li> <li>• <b>N2248TP-E</b>—Fabric Extender 48x1G 4x10G SFP+ Module</li> <li>• <b>N2248PQ</b>—Fabric Extender 48x10G SFP+ 16x10G SFP+ Module</li> </ul> <p>See the “Usage Guidelines” section for a description of these Fabric Extenders.</p>
<i>queue-limit</i>	<p>(Optional) Queue limit in bytes. The range is from 81920 to 652800 for a Cisco Nexus 2148T Fabric Extender, from 32768 to 33538048 for a on a Cisco Nexus 2248TP-E Fabric Extender, and from 5120 to 652800 for all other supported Fabric Extenders.</p>
<b>rx</b>	<p>(Optional) Specifies the default queue-limit for receiving (ingress).</p> <p><b>Note</b> This keyword is supported only on a Cisco Nexus 2248TP-E Fabric Extender.</p>
<b>tx</b>	<p>(Optional) Specifies the default queue-limit for transmission (egress).</p> <p><b>Note</b> This keyword is supported only on a Cisco Nexus 2248TP-E Fabric Extender.</p>

## Command Default

The default queue-limit for **rx** (ingress) on a Cisco Nexus 2248TP-E Fabric Extender is 1MB.  
The default queue-limit for **tx** (egress) on a Cisco Nexus 2248TP-E Fabric Extender is 4MB.

## Command Modes

Fabric extender configuration mode

## Command History

Release	Modification
5.0(2)N1(1)	This command was introduced.
5.1(3)N1(1)	The Cisco Nexus 2248TP-E Fabric Extender was introduced. The <b>rx</b> and <b>tx</b> keywords was introduced for this Fabric Extender.  The queue limit is changed to 5120 to 652800 bytes for all Cisco Nexus 2000 Series Fabric Extender, except Cisco Nexus 2148T Fabric Extender and Cisco Nexus 2248TP-E Fabric Extender.  <b>Note</b> On a Cisco Nexus 5000 Series switch that runs a Cisco NX-OS release prior to 5.1(3)N1(1), the queue limit range was from 2560 to 652800 bytes.

## Usage Guidelines

You can use a lower queue limit value on the Fabric Extender to prevent one blocked receiver from affecting traffic being sent to other noncongested receivers (head-of-line blocking); however, this will increase burst absorption on the ingress traffic. A higher queue limit value provides better burst absorption and less head-of-line blocking protection.

The following Cisco Nexus 2000 Series Fabric Extenders was introduced on a Cisco Nexus 5500 Series switch that runs a Cisco NX-OS release 5.1(3)N1(1):

- Cisco Nexus N2248TP-E Fabric Extender—It has four 10-Gigabit Ethernet fabric interfaces for its uplink connection to the parent Cisco Nexus 5500 Series switch and 48 1000BASE-T (1-Gigabit) Ethernet host interfaces with small form-factor pluggable (SFP+) interface adapters for its downlink connection to servers or hosts.
- Cisco Nexus 2248PQ Fabric Extender—It has 48 10-Gigabit Ethernet host interfaces with SFP+ interface adapters and 16 10-Gigabit Ethernet fabric interfaces corresponding to 4 QSFP interface adapters for its uplink connection to the parent switch.

## Examples

This example shows how to configure the hardware buffer queue limit on a Cisco Nexus 2248T Fabric Extender:

```
switch(config)# fex 110
switch(config-fex)# hardware N2248T queue-limit 327680
switch(config-fex)#
```

This example shows how to remove the hardware buffer queue limit configured on a Cisco Nexus 2248T Fabric Extender:

```
switch(config)# fex 110
switch(config-fex)# no hardware N2248T queue-limit
switch(config-fex)#
```

## Related Commands

Command	Description
<b>fex</b>	Creates a Fabric Extender and enters fabric extender configuration mode.
<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

Command	Description
<b>show queuing interface</b>	Displays information about interface queuing parameters, including buffer threshold and queue limits.
<b>show running-config fex</b>	Displays the running configuration for Fabric Extenders.

# hardware shared-buffer-size

To configure the shared buffer size for a Cisco Nexus 2000 Series Fabric Extender, use the **hardware shared-buffer-size** command. To revert to the default setting, use the **no** form of this command.

**hardware** *fex\_card\_type* **shared-buffer-size** [*buffer-size*]

**no hardware** *fex\_card\_type* **shared-buffer-size** [*buffer-size*]

## Syntax Description

<i>fex_card_type</i>	Fabric Extender card type. The following Fabric Extender card types are supported: <ul style="list-style-type: none"> <li>• <b>N2248TP-E</b>—Fabric Extender 48x1G 4x10G SFP+ Module</li> </ul> See the “Usage Guidelines” section for a description of this Fabric Extender.
<i>buffer-size</i>	(Optional) Shared buffer size (KB). The range is from 10800KB to 25392KB.

## Command Default

The default size of the shared buffer is 25392KB.

## Command Modes

Fabric Extender configuration mode

## Command History

Release	Modification
5.1(3)N1(1)	This command was introduced.
	The Cisco Nexus N2248TP-E Fabric Extender was introduced.

## Usage Guidelines



### Note

This command is supported only on a Cisco Nexus 2248TP-E Fabric Extender.

The Cisco Nexus N2248TP-E Fabric Extender has four 10-Gigabit Ethernet fabric interfaces for its uplink connection to the parent Cisco Nexus 5500 Series switch and 48 1000BASE-T (1-Gigabit) Ethernet host interfaces with small form-factor pluggable (SFP+) interface adapters for its downlink connection to servers or hosts.

The total available buffer is 32MB which is shared in both direction (ingress, egress).

The default size of the shared buffer is 25392KB. However, when configuring an Ethernet-based pause no-drop class, the shared buffer size changes to 10800KB. This change is required to increase the dedicated buffer that supports the pause no-drop class. The pause no-drop class does not use buffer space from the shared-pool.



## Examples

This example shows how to configure the hardware buffer size on a Cisco Nexus 2248TP-E Fabric Extender:

```
switch# configure terminal
switch(config)# fex 100
switch(config-fex)# hardware N2248TTP-E shared-buffer-size 25000
switch(config-fex)#
```

This example shows how to remove the hardware pause no-drop configuration between a Cisco Nexus 2248TTP-E Fabric Extender and a switch:

```
switch# configure terminal
switch(config)# fex 100
switch(config-fex)# no hardware N2248TTP-E shared-buffer-size 25000
switch(config-fex)#
```

## Related Commands

Command	Description
<b>fex</b>	Creates a Fabric Extender and enters fabric extender configuration mode.
<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.
<b>show running-config fex</b>	Displays the running configuration for Fabric Extenders.

# hardware uplink-pause-no-drop

To configure a pause no-drop class up to a distance of 3000 meters between the Cisco Nexus 2000 Series Fabric Extender and a Cisco Nexus 5500 switch, use the **hardware uplink-pause-no-drop** command. To revert to the default setting, use the **no** form of this command.

**hardware** *fex\_card\_type* **uplink-pause-no-drop distance** [*distance-value*]

**no hardware** *fex\_card\_type* **uplink-pause-no-drop distance** [*distance-value*]

## Syntax Description

<i>fex_card_type</i>	Fabric Extender card type. The following Fabric Extender card types are supported: <ul style="list-style-type: none"> <li>• <b>N2248TP-E</b>—Fabric Extender 48x1G 4x10G SFP+ Module</li> </ul> See the “Usage Guidelines” section for a description of this Fabric Extender.
<b>distance</b>	Specifies the distance between the Fabric Extender and switch.
<i>distance-value</i>	(Optional) Distance in meters. The range is from 300 to 3000.

## Command Default

The default distance between a Fabric Extender and the switch is 300 meters.

## Command Modes

Fabric Extender configuration mode

## Command History

Release	Modification
5.1(3)N1(1)	This command was introduced.
	The Cisco Nexus N2248TP-E Fabric Extender was introduced.

## Usage Guidelines



### Note

This command is supported only on a Cisco Nexus 2248TP-E Fabric Extender.

The Cisco Nexus N2248TP-E Fabric Extender has four 10-Gigabit Ethernet fabric interfaces for its uplink connection to the parent Cisco Nexus 5500 Series switch and 48 1000BASE-T (1-Gigabit) Ethernet host interfaces with small form-factor pluggable (SFP+) interface adapters for its downlink connection to servers or hosts.

## Examples

This example shows how to configure the hardware pause no-drop class up to a distance of 3000 meters between a Cisco Nexus 2248TTP-E Fabric Extender and a switch:

```
switch# configure terminal
switch(config)# fex 100
switch(config-fex)# hardware N2248TTP-E pause-no-drop distance 3000
switch(config-fex)#
```

This example shows how to remove the hardware pause no-drop configuration between a Cisco Nexus 2248TTP-E Fabric Extender and a switch:

```
switch# configure terminal
switch(config)# fex 100
switch(config-fex)# no hardware N2248TTP-E pause-no-drop distance 3000
switch(config-fex)#
```

**Related Commands**

Command	Description
<b>fex</b>	Creates a Fabric Extender and enters fabric extender configuration mode.
<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.
<b>show running-config fex</b>	Displays the running configuration for Fabric Extenders.

■ hardware uplink-pause-no-drop



## L Commands

---

This chapter describes the Cisco NX-OS commands that begin with L that are used to manage a Cisco Nexus 2000 Series Fabric Extender from a Cisco Nexus 5500 switch.

# locator-led fex

To turn on the locator LED of a Fabric Extender, use the **locator-led** command. To turn off the locator LED, use the **no** form of this command.

**locator-led fex** *chassis\_ID*

**no locator-led fex** *chassis\_ID*

## Syntax Description

<i>chassis_ID</i>	Fabric Extender chassis ID. The range is from 100 to 199.
-------------------	---

## Command Default

None

## Command Modes

EXEC mode

## Command History

Release	Modification
5.0(2)N1(1)	This command was introduced.

## Usage Guidelines

Use the **locator-led** command to toggle the locator LED of a Fabric Extender, which allows you to easily identify the machine in a busy data center.

## Examples

This example shows how to turn on the locator LED for a specific Fabric Extender chassis:

```
switch# locator-led fex 100
switch#
```

This example shows how to turn off the locator beacon LED for a specific Fabric Extender chassis:

```
switch# no locator-led fex 100
switch#
```

## Related Commands

Command	Description
<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.
<b>show locator-led</b>	Displays the status of the locator LED in Fabric Extender modules.

# logging fex

To set the logging alert level for Fabric Extender events, use the **logging fex** command. To reset the logging level, use the **no** form of this command.

**logging fex** [*severity-level*]

**no logging fex** [*severity-level*]

<b>Syntax Description</b>	<p><i>severity-level</i> (Optional) Number of the desired severity level at which messages should be logged. Messages at or numerically lower than the specified level are logged. Severity levels are as follows:</p> <ul style="list-style-type: none"> <li>0—emergency: System unusable</li> <li>1—alert: Immediate action needed</li> <li>2—critical: Critical condition—default level</li> <li>3—error: Error condition</li> <li>4—warning: Warning condition</li> <li>5—notification: Normal but significant condition</li> <li>6—informational: Informational message only</li> <li>7—debugging: Appears during debugging only</li> </ul>				
<b>Command Default</b>	None				
<b>Command Modes</b>	Global configuration mode				
<b>Command History</b>	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>5.0(2)N1(1)</td><td>This command was introduced.</td></tr> </table>	Release	Modification	5.0(2)N1(1)	This command was introduced.
Release	Modification				
5.0(2)N1(1)	This command was introduced.				
<b>Examples</b>	<p>This example shows how to set the logging alert level for Fabric Extender events:</p> <pre>switch(config)# logging fex 4</pre> <p>This example shows how to reset the logging level:</p> <pre>switch(config)# no logging fex</pre>				
<b>Related Commands</b>	<table> <tr> <th>Command</th><th>Description</th></tr> <tr> <td>show fex</td><td>Displays all configured Fabric Extender chassis connected to the switch.</td></tr> </table>	Command	Description	show fex	Displays all configured Fabric Extender chassis connected to the switch.
Command	Description				
show fex	Displays all configured Fabric Extender chassis connected to the switch.				







## P Commands

---

This chapter describes the Cisco NX-OS commands that begin with P that are used to manage a Cisco Nexus 2000 Series Fabric Extender from a Cisco Nexus 5500 switch.

# pinning max-links

To specify the number of statically pinned uplinks, use the **pinning max-links** command. To reset to the default, use the **no** form of this command.

**pinning max-links** *uplinks*

**no pinning max-links**

## Syntax Description

<i>uplinks</i>	Number of uplinks. The range is from 1 to 8. The default is 1.  This command is applicable only if the Fabric Extender is connected to its parent switch using one or more statically pinned fabric interfaces.
----------------	---

## Command Default

The default number of uplinks is 1.

## Command Modes

Fabric extender configuration mode

## Command History

Release	Modification
5.0(2)N1(1)	This command was introduced.

## Usage Guidelines

Use the **pinning max-links** command when you create a number of pinned fabric interface connections to enable the parent switch to determine a distribution of host interfaces. The host interfaces are divided by the number of *uplinks* and distributed accordingly.



### Caution

Changing the value of *uplinks* is disruptive. All the host interfaces on the Fabric Extender are brought down and back up as the parent switch reassigns its static pinning.

## Examples

This example shows how to specify the number of statically pinned uplinks for a Fabric Extender:

```
switch# configure terminal
switch(config)# fex 101
switch(config-fex)# pinning max-links 4
```

This example shows how to revert to the uplink count to the default for a Fabric Extender:

```
switch# configure terminal
switch(config)# fex 101
switch(config-fex)# no pinning max-links
```

**Related Commands**

Command	Description
<b>fex</b>	Creates a Fabric Extender and enters fabric extender configuration mode.
<b>fex pinning redistribute</b>	Redistributes the host interfaces on a Fabric Extender.
<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

# provision

To preprovision a module in a chassis slot, use the **provision** command. To remove a preprovisioned module from a slot, use the **no** form of this command.

**provision model** *model-name*

**no provision model** [*model-name*]

Syntax	Description
<b>model</b>	Specifies the type of module to be provisioned.
<i>model-name</i>	Module name. The supported modules are as follows: <ul style="list-style-type: none"> <li>• <b>N2K-C2148T</b>—Cisco Nexus 2000 Series Fabric Extender 48x1G 4x10G Module</li> <li>• <b>N2K-C2232P</b>—Cisco Nexus 2000 Series Fabric Extender 32x10G Module</li> <li>• <b>N2K-C2232TM</b>—Cisco Nexus 2000 Series Fabric Extender 32x10G Module</li> <li>• <b>N2K-C2248T</b>—Cisco Nexus 2000 Series Fabric Extender 48x1G 4x10G Module</li> <li>• <b>N2K-N2224TP</b>—Cisco Nexus 2000 Series Fabric Extender 24x1G 2x10G SFP+ Module</li> <li>• <b>N2248PQ</b>—Cisco Nexus 2000 Series Fabric Extender 48x10G SFP+ 16x10G SFP+ Module</li> <li>• <b>N55-M16FP</b>—Cisco 16 port Port Fiber Channel Expansion Module 16 x SFP</li> <li>• <b>N55-M16P</b>—Cisco 16x10-Gigabit Ethernet Expansion Module</li> <li>• <b>N55-M16UP</b>—Cisco 16x10-Gigabit Flexible Ethernet Expansion Module</li> <li>• <b>N55-M8P8FP</b>—Cisco 8 Port 1/2/4/8-Gigabit Fibre Channel + 8 Port 10-Gigabit Ethernet Expansion Module</li> <li>• <b>N5K-M1008</b>—Cisco 8 Port Fiber Channel Expansion Module 8 x SFP</li> <li>• <b>N5K-M1060</b>—Cisco 6 Port Fiber Channel Expansion Module 6 x SFP</li> <li>• <b>N5K-M1404</b>—Expansion Module 4 x 10GBase-T LAN, 4 x Fiber Channel</li> <li>• <b>N5K-M1600</b>—Cisco 6-port 10 Gigabit Ethernet SFP Module 6 x SFP</li> </ul>

**Command Default** None

**Command Modes** Slot configuration mode  
Switch profile configuration mode

**Command History**

Release	Modification
5.0(2)N1(1)	This command was introduced.

**Usage Guidelines**

Use this command to define the modules (line card or Cisco Nexus 2000 Series Fabric Extender) to preprovision. If the card type does not match the card in the slot or the module is not compatible with the chassis, you see the following messages:

```
ERROR: The card type does not match the card in slot
```

or

```
ERROR: This module cannot be configured for this chassis
```

You can configure features or interfaces (Ethernet, Fibre Channel) on the modules before the modules are inserted in the switch chassis. You can also use this command to manage the configuration of these features or interfaces when the module is offline due to a failure or scheduled downtime. These configurations are applied when the module comes online.

When you preprovision a module by specifying the type of module, platform manager will allow only modules of matching type to come online. If you configure the interfaces for the module without specifying the module type, the configuration is applied when the module comes online, regardless of the module type.

You can preprovision modules and interfaces in a switch profile. The modules and interfaces are preprovisioned when you apply (commit) the switch profile. Once the module is inserted and interfaces are created, the preprovisioning module passes on the configuration to the respective applications before the interfaces come up.

Mutual exclusion is a mechanism where configuration outside the switch profile is not allowed in the switch profile and vice-versa. This requirement is to ensure that configuration in the switch profile is exactly the same on both switches. Preprovisioned configuration is the same as a configuration when the module is online, so mutual exclusion checks would continue to apply normally.

When you downgrade from Cisco NX-OS release 5.0(2)N1(1), which supports preprovisioning, to an earlier release of Cisco NX-OS that does not support module preprovisioning, you will be prompted to remove preprovisioning configuration that you configured on the switch.

**Examples**

This example shows how to preprovision a module in slot 2 of the chassis:

***Need new command output***

```
switch(config)# slot 2
switch(config-slot)# provision model N5K-M1404
switch(config-slot)#
```

This example shows how to remove a preprovisioned module from a chassis slot:

```
switch(config)# slot 2
switch(config-slot)# no provision model N5K-M1404
switch(config-slot)#
```

This example shows how to remove all preprovisioned modules or line cards from a chassis slot:

```
switch(config)# slot 2
switch(config-slot)# no provision model
switch(config-slot)#
```

Related Commands	Command	Description
	<b>show module</b>	Displays module information.
	<b>show provision</b>	Displays provisioned modules.
	<b>show switch-profile</b>	Displays switch profile information.
	<b>show running-config exclude-provision</b>	Displays the running configuration excluding the preprovisioned features.
	<b>slot</b>	Enables a slot for preprovisioning a module.
	<b>switch-profile</b>	Configures a switch profile.



## S Commands

---

This chapter describes the Cisco NX-OS commands that begin with S that are used to manage a Cisco Nexus 2000 Series Fabric Extender from a Cisco Nexus 5500 switch.

# serial

To assign a serial number to a Fabric Extender, use the **serial** command. To remove the serial number, use the **no** form of this command.

```
serial serial_string

no serial
```

Syntax Description	serial_string	Serial number string for the Fabric Extender. The string is alphanumeric, case sensitive, and has a maximum length of 20 characters.
--------------------	---------------	--


Command Default	None
-----------------	------

Command Modes	Fabric extender configuration mode
---------------	------------------------------------

Command History	Release	Modification
	5.0(2)N1(1)	This command was introduced.

**Usage Guidelines**

The serial number string you define with the **serial** command must match the serial number of the Fabric Extender. If you configure a serial number and then you use the **fex associate** command to associate the corresponding chassis ID to the switch, the association will succeed only if the Fabric Extender reports a matching serial number string.

  
**Caution**

Configuring a serial number other than that of the given Fabric Extender will force the Fabric Extender offline.

**Examples**

This example shows how to specify a serial number for a Fabric Extender:

```
switch# configure terminal
switch(config)# fex 101
switch(config-fex)# serial Rack16_FEX101
```

This example shows how to remove a serial number from a Fabric Extender:

```
switch# configure terminal
switch(config)# fex 101
switch(config-fex)# no serial
```



Related Commands	Command	Description
	<b>fex</b>	Creates a Fabric Extender and enters fabric extender configuration mode.
	<b>fex associate</b>	Associates a Fabric Extender to an Ethernet or EtherChannel interface.
	<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

# slot

To enable preprovisioning on a slot in a chassis, use the **slot** command. To disable the slot for preprovisioning, use the **no** form of this command.

**slot** *slot-number*

**no slot** *slot-number*

<b>Syntax Description</b>	<i>slot-number</i> Slot number in the chassis. The range is from 2 to 199.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Global configuration mode Configuration synchronization mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(2)N1(1)	This command was introduced.
<b>Usage Guidelines</b>	Use this command to enable preprovisioning of features or interfaces of a module on a slot in a chassis. Preprovisioning allows you to configure features or interfaces (Ethernet, Fibre Channel) on modules before the modules are inserted in the switch chassis.	
<b>Examples</b>	<p>This example shows how to enable a chassis slot for preprovisioning of a module:</p> <pre>switch(config)# <b>slot 2</b> switch(config-slot)#</pre> <p>This example shows how to disable a chassis slot for preprovisioning of a module:</p> <pre>switch(config)# <b>no slot 2</b> switch(config)#</pre>	
<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>port</b>	Configures ports as Ethernet, native Fibre Channel or Fibre Channel over Ethernet (FCoE) ports.
	<b>provision</b>	Preprovisions a module in a slot.
	<b>show running-config exclude-provision</b>	Displays the running configuration excluding the preprovisioned features.

# switchport mode fex-fabric

To set the interface type to be an uplink port for a Fabric Extender, use the **switchport mode fex-fabric** command.

**switchport mode fex-fabric**

**no switchport mode fex-fabric**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Interface configuration mode
----------------------	------------------------------

Command History	Release	Modification
	5.0(2)N1(1)	This command was introduced.

<b>Examples</b>	This example shows how to set an Ethernet interface to be an uplink port for a Fabric Extender:
-----------------	---

```
switch# configure terminal
switch(config)# interface ethernet 1/40
switch(config-if)# switchport mode fex-fabric
```

This example shows how to set an EtherChannel interface to be an uplink port for a Fabric Extender:

```
switch# configure terminal
switch(config)# interface port-channel 4
switch(config-if)# switchport mode fex-fabric
```

Related Commands	Command	Description
	<b>fex associate</b>	Associates a Fabric Extender to an Ethernet or EtherChannel interface.
	<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

■ **switchport mode fex-fabric**



## Show Commands

---

This chapter describes the Cisco NX-OS **show** commands used to manage a Cisco Nexus 2000 Series Fabric Extender from a Cisco Nexus 5500 switch.

# show diagnostic result fex

To display the results from the diagnostic tests for a Fabric Extender chassis, use the **show diagnostic result fex** command.

**show diagnostic result fex** *chassis\_ID*

<b>Syntax Description</b>	<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
<b>Command Default</b>	None	
<b>Command Modes</b>	EXEC mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(2)N1(1)	This command was introduced.

## Examples

This example shows how to display the results from the diagnostic tests for a Fabric Extender:

```
switch# show diagnostic result fex 100
FEX-100: 48x1GE/Supervisor SerialNo   : JAF1237ABSE
Overall Diagnostic Result for FEX-100  : OK

Test results: (. = Pass, F = Fail, U = Untested)
TestPlatform:
0)          SPROM: -----> .
1)          MV88E6095: -----> .
2)          Fan: -----> .
3)          Power Supply: -----> .
4) Temperature Sensor: -----> .

TestForwardingPorts:
Eth   1  2  3  4  5  6  7  8  9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24
Port -----
      .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .

Eth   25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48
Port -----
      .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .

TestFabricPorts:
Fabric 1  2  3  4
Port -----
      .  .  .  .

switch#
```

## Related Commands

Command	Description
show fex	Displays all configured Fabric Extender chassis connected to the switch.

# show environment fex

To display the environmental sensor status, use the **show environment fex** command.

**show environment fex** {**all** | *chassis\_ID*} [**temperature** | **power** | **fan**]

Syntax Description		
<b>all</b>		Displays information for all Fabric Extender chassis.
<i>chassis_ID</i>		Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
<b>temperature</b>		(Optional) Displays temperature sensor information.
<b>power</b>		(Optional) Displays power capacity and power distribution information.
<b>fan</b>		(Optional) Displays fan information.

**Command Default** None

**Command Modes** EXEC mode

Command History	Release	Modification
	5.0(2)N1(1)	This command was introduced.

**Examples** This example shows how to display the environmental sensor status for a Fabric Extender:

```
switch# show environment fex 100
```

Temperature Fex 100:

Module	Sensor	MajorThresh (Celsius)	MinorThres (Celsius)	CurTemp (Celsius)	Status
1	Outlet-1	63	45	26	ok
1	Inlet-1	65	55	27	ok
1	Die-1	100	85	38	ok

Fan Fex: 100:

Fan	Model	Hw	Status
Chassis	N2K-C2248-FAN	--	ok
PS-1	N2200-PAC-400W	--	ok
PS-2	N2200-PAC-400W	--	failure

Power Supply Fex 100:

Voltage: 12 Volts

PS	Model	Power (Watts)	Power (Amp)	Status
----	-------	------------------	----------------	--------



```

1  N2200-PAC-400W      396.00    33.00    ok
2  --                  --         --      fail/shutdown

```

Mod	Model	Power Requested (Watts)	Power Requested (Amp)	Power Allocated (Watts)	Power Allocated (Amp)	Status
1	N2K-C2248TP-1GE	55.20	4.60	55.20	4.60	powered-up

Power Usage Summary:

```

-----
Power Supply redundancy mode:          redundant
Power Supply redundancy operational mode: Non-redundant

```

```

Total Power Capacity                      396.00 W

```

```

Power reserved for Supervisor(s)         55.20 W
Power currently used by Modules           0.00 W

```

```

-----
Total Power Available                     340.80 W
-----

```

switch#

## Related Commands

Command	Description
<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

# show fex

To display information about a specific Fabric Extender or all attached chassis, use the **show fex** command.

**show fex** [*chassis\_ID* [**detail**]]

<b>Syntax Description</b>	<i>chassis_ID</i>	(Optional) Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
	<b>detail</b>	(Optional) Displays a detailed listing.

**Command Default** None

**Command Modes** EXEC mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(2)N1(1)	This command was introduced.

## Examples

This example shows how to display information about all attached Fabric Extender chassis:

```
switch# show fex
FEX          FEX          FEX          FEX
Number      Description    State          Model          Serial
-----
100          FEX0100           Online        N2K-C2248PQ-10GE  FOC1616R00Q
---          -----
              Discovered    N2K-C2248TP-1GE  SSI16020453
---          -----
              Discovered    N2K-C2232P-10GE  SSI133106K6
switch#
```

This example shows how to display information about a specific Fabric Extender chassis:

```
switch# show fex 100
switch(config-slot)# show fex 100
FEX: 100 Description: FEX0100 state: Online
  FEX version: 6.0(2)N1(1) [Switch version: 6.0(2)N1(1)]
  Extender Serial: FOC1616R00Q
  Extender Model: N2K-C2248PQ-10GE, Part No: 73-14775-02
  Pinning-mode: static Max-links: 1
  Fabric port for control traffic: Eth2/3
  FCoE Admin: false
  FCoE Oper: true
  FCoE FEX AA Configured: false
  Fabric interface state:
    Po100 - Interface Up. State: Active
    Eth2/1 - Interface Up. State: Active
    Eth2/2 - Interface Up. State: Active
    Eth2/3 - Interface Up. State: Active
    Eth2/4 - Interface Up. State: Active
```

This example shows how to display the detailed information about all attached Fabric Extender chassis:

```
switch# show fex detail
show fex detail
FEX: 100 Description: FEX0100    state: Online
    FEX version: 6.0(2)N1(1) [Switch version: 6.0(2)N1(1)]
    FEX Interim version: 6.0(2)N1(1)
    Switch Interim version: 6.0(2)N1(1)
    Extender Serial: FOC1616R00Q
    Extender Model: N2K-C2248PQ-10GE, Part No: 73-14775-02
    Card Id: 207, Mac Addr: a4:18:75:37:67:42, Num Macs: 64
    Module Sw Gen: 12594 [Switch Sw Gen: 21]
    post level: complete
pinning-mode: static    Max-links: 1
    Fabric port for control traffic: Eth2/3
    FCoE Admin: false
    FCoE Oper: true
    FCoE FEX AA Configured: false
    Fabric interface state:
        Po100 - Interface Up. State: Active
        Eth2/1 - Interface Up. State: Active
        Eth2/2 - Interface Up. State: Active
        Eth2/3 - Interface Up. State: Active
        Eth2/4 - Interface Up. State: Active
    Fex Port      State Fabric Port
Eth100/1/1  Up      None
    Eth100/1/2  Up      Po100
    Eth100/1/3  Up      Po100
    Eth100/1/4  Up      Po100
    Eth100/1/5  Up      Po100
    Eth100/1/6  Up      Po100
    Eth100/1/7  Up      Po100
    Eth100/1/8  Up      Po100
    Eth100/1/9  Up      Po100
    Eth100/1/10 Up      Po100
    Eth100/1/11 Up      Po100
    Eth100/1/12 Up      Po100
    Eth100/1/13 Up      Po100
    Eth100/1/14 Up      Po100
    Eth100/1/15 Up      Po100
    Eth100/1/16 Up      Po100
    Eth100/1/17 Down    None
    Eth100/1/18 Down    None
    Eth100/1/19 Down    None
    Eth100/1/20 Down    None
    Eth100/1/21 Up      Po100
    Eth100/1/22 Up      Po100
    Eth100/1/23 Up      Po100
    Eth100/1/24 Up      Po100
    Eth100/1/25 Up      Po100
    Eth100/1/26 Up      Po100
    Eth100/1/27 Down    None
    Eth100/1/28 Down    None
    Eth100/1/29 Up      Po100
    Eth100/1/30 Up      Po100
    Eth100/1/31 Up      Po100
    Eth100/1/32 Up      Po100
    Eth100/1/33 Up      Po100
    Eth100/1/34 Up      Po100
    Eth100/1/35 Up      Po100
    Eth100/1/36 Up      Po100
    Eth100/1/37 Up      Po100
    Eth100/1/38 Up      Po100
    Eth100/1/39 Up      Po100
```

## show fex

```

Eth100/1/40 Up Po100
Eth100/1/41 Up Po100
Eth100/1/42 Up Po100
Eth100/1/43 Up Po100
Eth100/1/44 Up Po100
Eth100/1/45 Up Po100
Eth100/1/46 Up Po100
Eth100/1/47 Down None
Eth100/1/48 Down None

```

## Logs:

```

01/13/2013 03:10:36.646339: Module register received
01/13/2013 03:10:36.653063: Image Version Mismatch
01/13/2013 03:10:36.654323: Registration response sent
01/13/2013 03:10:36.654653: Requesting satellite to download image
01/13/2013 03:18:32.807440: Image preload successful.
01/13/2013 03:18:34.914876: Deleting route to FEX
01/13/2013 03:18:34.925056: Module disconnected
01/13/2013 03:18:34.926943: Module Offline
01/13/2013 03:18:34.929419: Deleting route to FEX
01/13/2013 03:18:34.936603: Module disconnected
01/13/2013 03:18:34.940691: Offlining Module
01/13/2013 03:20:05.822920: Deleting route to FEX
01/13/2013 03:20:05.829998: Module disconnected
01/13/2013 03:20:05.832442: Offlining Module
01/13/2013 03:20:23.566625: Module register received
01/13/2013 03:20:23.569473: Registration response sent
01/13/2013 03:20:23.868221: create module inserted event.
01/13/2013 03:20:23.869315: Module Online Sequence
01/13/2013 03:20:36.461303: Module Online
01/14/2013 22:21:54.969375: Deleting route to FEX
01/14/2013 22:21:54.981504: Module disconnected
01/14/2013 22:21:54.983913: Offlining Module
01/14/2013 22:21:54.984853: Module Offline Sequence
01/14/2013 22:22:01.715915: Module Offline
01/14/2013 22:22:01.757028: Deleting route to FEX
01/14/2013 22:22:01.764842: Module disconnected
01/14/2013 22:22:01.767241: Offlining Module
01/14/2013 22:23:45.341774: Module register received
01/14/2013 22:23:45.344482: Registration response sent
01/14/2013 22:23:49.813218: create module inserted event.
01/14/2013 22:23:49.814317: Module Online Sequence
01/14/2013 22:23:58.120815: Module Online

```

switch#

## Related Commands

Command	Description
<b>fex</b>	Creates a Fabric Extender and enters fabric extender configuration mode.

# show fex detail

To display detailed information about a specific Fabric Extender or all attached chassis, use the **show fex detail** command.

## show fex detail

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

Command History	Release	Modification
	5.0(2)N1(1)	This command was introduced.

<b>Examples</b>	This example shows how to display detailed information about all attached Fabric Extender chassis:
-----------------	--

```
switch# show fex detail
FEX: 100 Description: FEX0100    state: Online
  FEX version: 4.2(1)N1(1) [Switch version: 4.2(1)N1(1)]
  FEX Interim version: 4.2(1)N1(0.326)
  Switch Interim version: 4.2(1)N1(0.326)
  Extender Model: N5K-C5110T-BF-1GE,  Extender Serial: JAF1237ABSE
  Part No: 73-12009-02
  Card Id: 70, Mac Addr: 00:0d:ec:b1:13:02, Num Macs: 64
  Module Sw Gen: 12594  [Switch Sw Gen: 21]
  post level: complete
  pinning-mode: static    Max-links: 1
  Fabric port for control traffic: Eth3/4
  Fabric interface state:
    Po12 - Interface Up. State: Active
    Eth3/3 - Interface Up. State: Active
    Eth3/4 - Interface Up. State: Active
  Fex Port      State  Fabric Port  Primary Fabric
    Eth100/1/1   Up    Po12         Po12
    Eth100/1/2   Up    Po12         Po12
    Eth100/1/3   Up    Po12         Po12
    Eth100/1/4   Up    Po12         Po12
    Eth100/1/5   Up    Po12         Po12
    Eth100/1/6   Up    Po12         Po12
    Eth100/1/7   Up    Po12         Po12
    Eth100/1/8   Up    Po12         Po12
    Eth100/1/9   Up    Po12         Po12
    Eth100/1/10  Up    Po12         Po12
    Eth100/1/11  Up    Po12         Po12
    Eth100/1/12  Up    Po12         Po12
    Eth100/1/13  Up    Po12         Po12
    Eth100/1/14  Up    Po12         Po12
    Eth100/1/15  Up    Po12         Po12
    Eth100/1/16  Up    Po12         Po12
```

## show fex detail

Eth100/1/17	Up	Po12	Po12
Eth100/1/18	Up	Po12	Po12
Eth100/1/19	Up	Po12	Po12
Eth100/1/20	Up	Po12	Po12
Eth100/1/21	Up	Po12	Po12
Eth100/1/22	Up	Po12	Po12
Eth100/1/23	Up	Po12	Po12
Eth100/1/24	Up	Po12	Po12
Eth100/1/25	Up	Po12	Po12
Eth100/1/26	Up	Po12	Po12
Eth100/1/27	Up	Po12	Po12
Eth100/1/28	Up	Po12	Po12
Eth100/1/29	Up	Po12	Po12
Eth100/1/30	Up	Po12	Po12
Eth100/1/31	Up	Po12	Po12
Eth100/1/32	Up	Po12	Po12
Eth100/1/33	Down	Po12	Po12
Eth100/1/34	Down	Po12	Po12
Eth100/1/35	Down	Po12	Po12
Eth100/1/36	Down	Po12	Po12
Eth100/1/37	Down	Po12	Po12
Eth100/1/38	Down	Po12	Po12
Eth100/1/39	Down	Po12	Po12
Eth100/1/40	Up	Po12	Po12
Eth100/1/41	Up	Po12	Po12
Eth100/1/42	Up	Po12	Po12
Eth100/1/43	Up	Po12	Po12
Eth100/1/44	Up	Po12	Po12
Eth100/1/45	Up	Po12	Po12
Eth100/1/46	Up	Po12	Po12
Eth100/1/47	Up	Po12	Po12
Eth100/1/48	Up	Po12	Po12

## Logs:

```

04/16/2010 05:05:23.441707: Module register received
04/16/2010 05:05:23.442886: Registration response sent
04/16/2010 05:05:23.551846: Module Online Sequence
04/16/2010 05:05:56.520856: Module Online
04/16/2010 05:29:38.526605: Deleting route to FEX
04/16/2010 05:29:38.536055: Module disconnected
04/16/2010 05:29:38.537686: Offlining Module
04/16/2010 05:29:38.538260: Module Offline Sequence
04/16/2010 05:29:53.646254: Module Offline
04/16/2010 05:29:54.178401: Deleting route to FEX
04/16/2010 05:29:54.184092: Module disconnected
04/16/2010 05:29:54.186230: Offlining Module
04/16/2010 05:31:13.784346: Module register received
04/16/2010 05:31:13.785410: Registration response sent
04/16/2010 05:31:15.676906: Module Online Sequence
04/16/2010 05:31:50.492714: Module Online
04/16/2010 05:32:18.388033: Deleting route to FEX
04/16/2010 05:32:18.393579: Module disconnected
04/16/2010 05:32:18.394845: Offlining Module
04/16/2010 05:32:18.395412: Module Offline Sequence
04/16/2010 05:32:30.336790: Module Offline
04/16/2010 05:32:30.683558: Deleting route to FEX
04/16/2010 05:32:30.690042: Module disconnected
04/16/2010 05:32:30.692101: Offlining Module
04/16/2010 05:33:42.781911: Module register received
04/16/2010 05:33:42.783432: Registration response sent
04/16/2010 05:33:52.542824: Module Online Sequence
04/16/2010 05:34:33.483417: Module Online

```

```

<---output truncated--->
switch#

```

Related Commands	Command	Description
	<b>fex</b>	Creates a Fabric Extender and enters fabric extender configuration mode.
	<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

# show fex transceiver

To display information about the transceiver connecting a Fabric Extender to the Cisco Nexus 5500 switch, use the **show fex transceiver** command.

**show fex *chassis\_ID* transceiver [calibration | detail]**

Syntax Description	<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
	<b>calibration</b>	(Optional) Displays detailed calibration information about the transceiver.
	<b>detail</b>	(Optional) Displays detailed diagnostic information about the transceiver.

Command Default None

Command Modes EXEC mode

Command History	<b>Release</b>	<b>Modification</b>
	5.0(2)N1(1)	This command was introduced.

**Examples** This example shows how to display information about the transceiver that connects a Fabric Extender to the Cisco Nexus 5500 switch:

```
switch# show fex 101 transceiver
```

```
Fex Uplink: 1
Fabric Port: Ethernet3/5
  sfp is present
  name is CISCO-AVAGO
  part number is SFBR-7700SDZ
  revision is B4
  serial number is AGD113921ZR
  nominal bitrate is 10300 Mbits/sec
  Link length supported for 50/125mm fiber is 82 m(s)
  Link length supported for 62.5/125mm fiber is 26 m(s)
  cisco id is --
  cisco extended id number is 4
```

```
Fex Uplink: 2
Fabric Port: Ethernet3/6
  sfp is present
  name is CISCO-AVAGO
  part number is SFBR-7700SDZ
  revision is B4
  serial number is AGD113422LS
  nominal bitrate is 10300 Mbits/sec
  Link length supported for 50/125mm fiber is 82 m(s)
  Link length supported for 62.5/125mm fiber is 26 m(s)
  cisco id is --
  cisco extended id number is 4
```



```
Fex Uplink: 3
Fabric Port: --
    sfp is present
    name is CISCO-AVAGO
    part number is SFBR-7700SDZ
    revision is B4
    serial number is AGD11392258
    nominal bitrate is 10300 Mbits/sec
    Link length supported for 50/125mm fiber is 82 m(s)
    Link length supported for 62.5/125mm fiber is 26 m(s)
--More--
switch#
```

## Related Commands

Command	Description
<b>fex</b>	Creates a Fabric Extender and enters fabric extender configuration mode.

# show fex version

To display the version information about a Fabric Extender, use the **show fex version** command.

**show fex *chassis\_ID* version**

Syntax Description	<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
--------------------	-------------------	--

Command Default	None
-----------------	------

Command Modes	EXEC mode
---------------	-----------

Command History	Release	Modification
	5.0(2)N1(1)	This command was introduced.

**Examples** This example shows how to display the version information about a Fabric Extender:

```
switch# show fex 101 version
```

```
Software
  Bootloader version:      1.9
  System boot mode:       primary
  System image version:    6.0(2)N1(1) [build 6.0(2)N1(1)]

Hardware
  Module:                  Fabric Extender 48x10GE + 4x40GE Module
  CPU:                     Motorola, e500v2, core 0
  Serial number:           FOC16150CN1
  Bootflash:               unlocked
```

```
Kernel uptime is 0 day(s), 1 hour(s), 28 minutes(s), 28 second(s)
```

```
Last reset at unknown time
  Reason: Unknown
  Service:
switch#
```

Related Commands	Command	Description
	<b>fex</b>	Creates a Fabric Extender and enters fabric extender configuration mode.

# show interface fex-fabric

To display all Fabric Extender fabric interfaces, use the **show interface fex-fabric** command.

**show interface fex-fabric**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(2)N1(1)	This command was introduced.

<b>Examples</b>	This example shows how to display all Fabric Extender fabric interfaces:
-----------------	--

switch# **show interface fex-fabric**

Fex	Fabric Port	Fabric Port State	Fex Uplink	Model	FEX Serial
---	Eth1/6	Discovered	2	N2K-C2232P-10GE	SSI133106K6
---	Eth1/7	Discovered	3	N2K-C2248TP-1GE	SSI16020453
---	Eth1/10	Discovered	2	N2K-C2248TP-1GE	SSI16020453
100	Eth2/1	Active	5	N2K-C2248PQ-10GE	FOC1616R00Q
100	Eth2/2	Active	6	N2K-C2248PQ-10GE	FOC1616R00Q
100	Eth2/3	Active	7	N2K-C2248PQ-10GE	FOC1616R00Q
100	Eth2/4	Active	8	N2K-C2248PQ-10GE	FOC1616R00Qswitch#

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

# show interface fex-intf

To display the host interfaces pinned to a fabric interface, use the **show interface fex-intf** command.

**show interface** *interface* **fex-intf**

<b>Syntax Description</b>	<i>interface</i>	Ethernet or EtherChannel interface.
<b>Command Default</b>	None	
<b>Command Modes</b>	EXEC mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(2)N1(1)	This command was introduced.
<b>Examples</b>	<p>This example shows how to display the host interfaces pinned to an Ethernet fabric interface on the parent switch:</p> <pre>switch# show interface ethernet 1/1 fex-intf</pre> <p>This example shows how to display the host interfaces pinned to an EtherChannel fabric interface on the parent switch:</p> <pre>switch# show interface port-channel 1 fex-intf</pre>	
<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

# show interface transceiver fex-fabric

To display information about all transceivers connected to fabric interfaces, use the **show interface transceiver fex-fabric** command.

**show interface transceiver fex-fabric [calibration | detail]**

<b>Syntax Description</b>	<b>calibration</b>	(Optional) Displays detailed calibration information about the transceiver.
	<b>detail</b>	(Optional) Displays detailed diagnostic information about the transceiver.

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(2)N1(1)	This command was introduced.

**Examples** This example shows how to display information about all transceivers that connect to fabric interfaces:

```
switch# show interface transceiver fex-fabric
Ethernet1/5
  sfp is present
  name is CISCO-MOLEX INC
  part number is 74752-9025
  revision is A
  serial number is MOC12302468
  nominal bitrate is 12000 Mbits/sec
  Link length supported for 50/125mm fiber is 0 m(s)
  Link length supported for 62.5/125mm fiber is 0 m(s)
  cisco id is --
  cisco extended id number is 4

Ethernet1/6
  sfp is present
  name is CISCO-MOLEX INC
  part number is 74752-9025
  revision is A
  serial number is MOC12260214
  nominal bitrate is 12000 Mbits/sec
  Link length supported for 50/125mm fiber is 0 m(s)
  Link length supported for 62.5/125mm fiber is 0 m(s)
  cisco id is --
  cisco extended id number is 4

Ethernet1/7
  sfp is present
  name is CISCO-MOLEX INC
  part number is 74752-9025
  revision is A
  serial number is MOC12301888
```

**show interface transceiver fex-fabric**

```
nominal bitrate is 12000 Mbits/sec
Link length supported for 50/125mm fiber is 0 m(s)
Link length supported for 62.5/125mm fiber is 0 m(s)
cisco id is --
cisco extended id number is 4

Ethernet1/8
  sfp is present
  name is CISCO-MOLEX INC
--More--
switch#
```

**Related Commands**

Command	Description
<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

# show inventory fex

To display the physical inventory of a Fabric Extender, such as the name, description, and volume ID, use the **show inventory fex** command.

**show inventory fex** *chassis\_ID*

Syntax Description	<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
--------------------	-------------------	--

Command Default	None
-----------------	------

Command Modes	EXEC mode
---------------	-----------

Command History	Release	Modification
	5.0(2)N1(1)	This command was introduced.

**Examples** This example shows how to display the physical inventory of a specific Fabric Extender chassis:

```
switch# show inventory fex 100
NAME: "FEX 100 CHASSIS", DESCR: "N2K-C2248PQ-10GE CHASSIS"
PID: N2K-C2248PQ-10GE , VID: V00 , SN: FOC1616R00Q

NAME: "FEX 100 Module 1", DESCR: "Fabric Extender Module: 48x10GE, 16x10GE/4x40G
QSFP Supervisor"
PID: N2K-C2248PQ-10GE , VID: V00 , SN: FOC16150CN1

NAME: "FEX 100 Fan 1", DESCR: "Fabric Extender Fan module"
PID: N2K-C2248PQ-FAN , VID: N/A , SN: N/A

NAME: "FEX 100 Power Supply 1", DESCR: "Fabric Extender AC power supply"
PID: N2200-PAC-400W , VID: V03 , SN: DTN1605P3EX

NAME: "FEX 100 Power Supply 2", DESCR: "Fabric Extender AC power supply"
PID: N2200-PAC-400W , VID: V03 , SN: DTN1605P3EY
switch#
```

Related Commands	Command	Description
	<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

# show locator-led

To display the status of the locator LED in a Fabric Extender, use the **show locator-led** command.

## show locator-led status

<b>Syntax Description</b>	<b>status</b>	Displays the status of the locator LED in a Fabric Extender module.
---------------------------	---------------	---

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(2)N1(1)	This command was introduced.

<b>Usage Guidelines</b>	Use the <b>locator-led</b> command to toggle the locator LED of a Fabric Extender.
-------------------------	--

<b>Examples</b>	This example shows how to display the modules that have the locator LED set to off or on:
-----------------	---

```
switch# show locator-led status
Component          Locator LED Status
-----
FEX 100            off
FEX 101            off
FEX 102            off
FEX 103            off
FEX 105            off
switch#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>locator-led</b>	Turns on the locator LED of a Fabric Extender chassis.
	<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.



# show module fex

To display the module information for a Fabric Extender, use the **show module fex** command.

**show module fex** [**all** | *chassis\_ID*]

Syntax Description	<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
	all	Displays information about all Fabric Extender modules.

Command Default	None
-----------------	------

Command Modes	EXEC mode
---------------	-----------

Command History	Release	Modification
	5.0(2)N1(1)	This command was introduced.

## Examples

This example shows how to display the module information of Fabric Extenders:

```
switch# show module fex all
FEX Mod Ports Card Type                               Model                               Status
-----
100 1    48    Fabric Extender 48x1GE + 4x10G Module  N2K-C2248TP-1GE  present
101 1    48    Fabric Extender 48x1GE + 4x10G Module  N2K-C2248TP-1GE  present
102 1    32    Fabric Extender 32x10GE + 8x10G Module  N2K-C2232P-10GE  present

FEX Mod Sw                Hw                World-Wide-Name(s) (WWN)
-----
100 1    6.0(2u)N1(1u)  4.3              --
101 1    6.0(2u)N1(1u)  4.3              --
102 1    6.0(2u)N1(1u)  1.0              --

FEX Mod  MAC-Address(es)                               Serial-Num
-----
100 1    2c36.f836.0340 to 2c36.f836.036f  SSI15510MCP
101 1    a456.30c2.7900 to a456.30c2.792f  SSI16020453
102 1    000d.ecca.7c00 to 000d.ecca.7c1f  SSI133106K6
switch#
```

This commands shows how to display the module information for a specific Fabric Extender:

```
switch# show module fex 100
FEX Mod Ports Card Type                               Model                               Status
-----
100 1    48    Fabric Extender 48x1GE + 4x10G Module  N2K-C2248TP-1GE  present

FEX Mod Sw                Hw                World-Wide-Name(s) (WWN)
-----
100 1    6.0(2)N1(1)  4.3              --

FEX Mod  MAC-Address(es)                               Serial-Num
-----
```

```
-----  
100 1      2c36.f836.0340 to 2c36.f836.036f      SSI15510MCP  
switch#
```

Related Commands	Command	Description
	show fex	Displays all configured Fabric Extender chassis connected to the switch.

# show provision

To display information about provision, use the **show provision** command.

**show provision failed-config** *slot-number*

Syntax Description	<b>failed-config</b>	Displays the configuration that failed to be applied to the slot.
	<i>slot-number</i>	Slot number in the chassis. The range is from 2 to 199.

Command Default	None
-----------------	------

Command Modes	EXEC mode Configuration synchronization mode
---------------	---

Command History	Release	Modification
	5.0(2)N1(1)	This command was introduced.

Examples	<p>This example shows how to display the preprovisioning configuration that failed to be applied to slot 2:</p> <pre>switch# show provision failed-config 2 Config has not been applied yet for this slot.  switch#</pre>
----------	---

Related Commands	Command	Description
	<b>provision</b>	Preprovisions a module in a slot.
	<b>show running-config exclude-provision</b>	Displays the running configuration excluding the preprovisioned features.
	<b>slot</b>	Enables a slot for preprovisioning a module.

# show queuing interface

To display the queuing information of interfaces, use the **show queuing interface** command.

**show queuing interface** [**ethernet** *slot-chassis-nolport-slot-nolport-no*]

Syntax Description	ethernet	(Optional) Specifies that queuing information be displayed for an Ethernet interface or a Fabric Extender.
	<i>slot-chassis-no</i>	Slot number of the Ethernet interface or chassis ID of the Fabric Extender. The range is from 1 to 255.
	<i>port-slot-no</i>	Port number of the Ethernet interface or the remote slot ID of the Fabric Extender. The range is from 1 to 128.
	<i>port-no</i>	Port number of the Fabric Extender. The range is from 1 to 48.

**Command Default** Displays the queuing information for all interfaces.

**Command Modes** EXEC mode

Command History	Release	Modification
	5.0(2)N1(1)	This command was introduced.

**Examples** This example shows how to display the queuing information, including the buffer threshold and queue limit values, of a specified interface:

```
switch# show queuing interface ethernet 1/4
Interface Ethernet1/4 TX Queuing
qos-group  sched-type  oper-bandwidth
    0         WRR         50
    1         WRR         50
    5         priority      0

Interface Ethernet1/4 RX Queuing
qos-group 0:
  q-size: 102400, MTU: 1538
  drop-type: drop, xon: 0, xoff: 640
  Statistics:
    Pkts received over the port           : 1
    Ucast pkts sent to the cross-bar      : 0
    Mcast pkts sent to the cross-bar      : 1
    Ucast pkts received from the cross-bar : 1577841
    Pkts sent to the port                 : 1577841
    Pkts discarded on ingress              : 0
    Per-priority-pause status             : Rx (Inactive), Tx (Inactive)

qos-group 1:
  q-size: 76800, MTU: 2240
  drop-type: no-drop, xon: 128, xoff: 240
  Statistics:
```

```

Pkts received over the port          : 0
Ucast pkts sent to the cross-bar     : 0
Mcast pkts sent to the cross-bar     : 0
Ucast pkts received from the cross-bar : 0
Pkts sent to the port                : 0
Pkts discarded on ingress             : 0
Per-priority-pause status            : Rx (Inactive), Tx (Inactive)

qos-group 5:
q-size: 122880, MTU: 1538
drop-type: drop, xon: 0, xoff: 768
Statistics:
  Pkts received over the port          : 0
  Ucast pkts sent to the cross-bar     : 0
  Mcast pkts sent to the cross-bar     : 0
  Ucast pkts received from the cross-bar : 0
  Pkts sent to the port                : 1
  Pkts discarded on ingress             : 0
  Per-priority-pause status            : Rx (Inactive), Tx (Inactive)

switch#

```

Table 1 describes the significant fields shown in the display.

**Table 1** *show queuing interface Field Descriptions*

Field	Description
Ethernet ...	Ethernet interface information.
qoS-group	Information about QoS groups configured on the switch.
sched-type	Type of schedule.
WRR	Weighted round robin(WRR). Queue eight for scheduling.
Priority	Priority of the queue.
q-size	Queue size.
drop-type	Queue drop type can be either drop or no-drop.
MTU	Maximum transmit unit (MTU) for the queue.
Xon	Transmission on at this threshold.
Xoff	Transmission off at this threshold.
Buffer threshold	Buffer threshold value for the interface.
Queue limit	Queue limit value for the interface.

#### Related Commands

Command	Description
<b>hardware buffer-threshold</b>	Configures the hardware buffer threshold.
<b>hardware queue-limit</b>	Configures the hardware queue limit.
<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

# show running-config exclude-provision

To display the running configuration without the configuration for offline preprovisioned interfaces, use the **show running-config exclude-provision** command.

## show running-config exclude-provision

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(2)N1(1)	This command was introduced.

<b>Examples</b>	This example shows how to display the running configuration without the offline preprovisioned interfaces:
-----------------	--

```
switch# show running-config exclude-provision

!Command: show running-config exclude-provision
!Time: Mon Sep  6 08:10:16 2010

version 5.0(2)N1(1)
feature fcoe

feature telnet
feature tacacs+
cfs ipv4 distribute
cfs eth distribute
feature udd
feature interface-vlan
feature lacp
feature vpc
feature lldp
feature vtp
feature fex

username admin password 5 $1$wmFN7Wly$/pjqx1DfAkCCAg/KyxbUz/  role network-admin
username install password 5 !  role network-admin
username praveena password 5 !  role network-operator
no password strength-check
ip domain-lookup
ip domain-lookup
tacacs-server host 192.168.131.54 key 7 "wawy1234"
tacacs-server host 192.168.131.37
tacacs-server host 192.168.131.37 test username user1
aaa group server tacacs+ t1
    server 192.168.131.54
```

```
aaa group server tacacs+ tacacs
radius-server host 192.168.128.5 key 7 "KkwyCet" authentication accounting
aaa group server radius r1
    server 192.168.128.5
hostname BEND-2
vlan dot1Q tag native
logging event link-status default
logging event trunk-status default
no service recover-errdisable
errdisable recovery interval 600
no errdisable detect cause link-flap
errdisable recovery cause link-flap
errdisable recovery cause udd
--More--
<--output truncated-->
switch#
```

**Related Commands**

Command	Description
<b>copy running-config startup-config</b>	Copies the running configuration to the startup configuration.
<b>provision</b>	Preprovisions a module in a slot.
<b>show provision</b>	Displays the preprovisioned module information.
<b>show startup-config exclude-provision</b>	Displays the startup configuration without the preprovisioning information for offline interfaces.
<b>slot</b>	Configures a chassis slot for a predefined module.

# show running-config fex

To display the running configuration for Fabric Extenders (FEXs), use the **show running-config fex** command.

**show running-config fex [all]**

<b>Syntax Description</b>	<b>all</b> (Optional) Displays FEX information including default settings.				
<b>Command Default</b>	None				
<b>Command Modes</b>	EXEC mode				
<b>Command History</b>	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>5.0(2)N1(1)</td><td>This command was introduced.</td></tr> </table>	Release	Modification	5.0(2)N1(1)	This command was introduced.
Release	Modification				
5.0(2)N1(1)	This command was introduced.				

## Examples

This example shows how to display information on the running FEX configuration, including the buffer threshold value and queue limit:

```
switch# show running-config fex

!Command: show running-config fex
!Time: Mon Jan 14 23:54:12 2013

version 6.0(2)N1(1)
feature fex

fex 100
  pinning max-links 1
  description "FEX0100"
fex 101
  pinning max-links 1
  description "FEX0101"
fex 102
  pinning max-links 1
  description "FEX0102"

interface Ethernet1/2
  fex associate 100

interface Ethernet1/4
  fex associate 101

interface Ethernet1/25
  fex associate 102

interface Ethernet1/26
  fex associate 102

switch#
```



Related Commands	Command	Description
	<b>hardware buffer-threshold</b>	Configures the hardware buffer threshold.
	<b>hardware queue-limit</b>	Configures the hardware queue limit.
	<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

# show sprom fex

To display information about the SPROM, use the **show sprom fex** command.

**show sprom fex** {**all** | *chassis\_ID* {**all** | **backplane** | **powersupply** *module\_no*}}

Syntax Description		
	<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
	<b>all</b>	Displays all SPROM content for a specific Fabric Extender.
	<b>backplane</b>	Displays the backplane SPROM content for a specific Fabric Extender.
	<b>powersupply</b>	Displays the power supply SPROM content for a specific Fabric Extender.
	<i>module_no</i>	Power supply module number for a specific Fabric Extender. The range is from 1 to 2.

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

Command History	Release	Modification
	5.0(2)N1(1)	This command was introduced.

**Examples** This example shows how to display all SPROM content for a specific Fabric Extender:

```
switch# show sprom fex 100 all
DISPLAY FEX 100 SUP sprom contents
Common block:
Block Signature : 0xabab
Block Version   : 3
Block Length    : 160
Block Checksum  : 0x18c9
EEPROM Size     : 65535
Block Count     : 3
FRU Major Type  : 0x6003
FRU Minor Type  : 0x0
OEM String      : Cisco Systems, Inc.
Product Number  : N5K-C5110T-BF-1GE
Serial Number   : JAF1237ABSE
Part Number     : 73-12009-02
Part Revision   : 00
Mfg Deviation   : 0
H/W Version     : 0.0
Mfg Bits        : 0
Engineer Use    : 0
snmpOID         : 9.12.3.1.9.72.5.0
Power Consump   : -200
RMA Code        : 0-0-0-0
CLEI Code       : 000000000000
VID             : V00
Supervisor Module specific block:
```

```
Block Signature : 0x6002
Block Version   : 2
Block Length    : 103
Block Checksum  : 0x2648
Feature Bits    : 0x0
HW Changes Bits : 0x2
Card Index      : 11011
MAC Addresses   : 00-00-00-00-00-00
Number of MACs  : 0
Number of EPLD  : 0
Port Type-Num   : 2-52
Sensor #1      : 85,75
Sensor #2      : 100,90
Sensor #3      : 100,90
Sensor #4      : 100,90
Sensor #5      : 100,90
Sensor #6      : 100,90
Sensor #7      : 100,90
Sensor #8      : 100,90
Max Connector Power: 1000
Cooling Requirement: 300
Ambient Temperature: 40

DISPLAY FEX 100 backplane sprom contents:
Common block:
Block Signature : 0xabab
Block Version   : 3
Block Length    : 160
Block Checksum  : 0x195d
EEPROM Size     : 65535
Block Count     : 5
FRU Major Type  : 0x6001
FRU Minor Type  : 0x0
OEM String      : Cisco Systems, Inc.
Product Number  : N5K-C5110T-BF-1GE
Serial Number   : JAF1237ABSE
Part Number     : 73-12009-02
Part Revision   : 00
Mfg Deviation   : 0
H/W Version     : 0.0
Mfg Bits        : 0
Engineer Use    : 0
snmpOID         : 9.12.3.1.3.719.0.0
Power Consump   : -800
RMA Code        : 0-0-0-0
CLEI Code       : 00000000
VID             : V01
Chassis specific block:
Block Signature : 0x6001
Block Version   : 3
Block Length    : 39
Block Checksum  : 0x28a
Feature Bits    : 0x0
HW Changes Bits : 0x2
Stackmib OID    : 0
MAC Addresses   : 00-0d-ec-b1-13-00
Number of MACs  : 64
OEM Enterprise  : 0
OEM MIB Offset  : 0
MAX Connector Power: 0
WWN software-module specific block:
Block Signature : 0x6005
Block Version   : 1
Block Length    : 0
```

```

Block Checksum : 0x66
wnn usage bits:
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00
License software-module specific block:
Block Signature : 0x6006
Block Version : 1
Block Length : 16
Block Checksum : 0x77
lic usage bits:
00 00 00 00 00 00 00 00

DISPLAY FEX 100 power-supply 1 sprom contents:
Common block:
Block Signature : 0xabab
Block Version : 3
Block Length : 124
Block Checksum : 0x15fc
EEPROM Size : 124
Block Count : 1
FRU Major Type : 0xab01
FRU Minor Type : 0x1
OEM String : Cisco Systems, Inc.
Product Number : N5K-PAC-200W
Serial Number : PAC12473L17
Part Number : 341-0335-01
Part Revision : 01
CLEI Code : COUPADSBA
VID : 00V0
snmpOID : 0.0.0.0.0.0.0.0
H/W Version : 0.1
Current : 1667
RMA Code : 0-0-0-0
switch#

```

This command shows how to display the power supply SPROM contents for a specific Fabric Extender:

```
switch# show sprom fex 100 powersupply 1
DISPLAY FEX 100 power-supply 1 sprom contents:
Common block:
  Block Signature : 0xabab
  Block Version   : 3
  Block Length    : 124
  Block Checksum  : 0x15fc
  EEPROM Size     : 124
  Block Count     : 1
  FRU Major Type  : 0xab01
  FRU Minor Type  : 0x1
  OEM String      : Cisco Systems, Inc.
  Product Number  : N5K-PAC-200W
  Serial Number   : PAC12473L17
  Part Number     : 341-0335-01
  Part Revision   : 01
  CLEI Code       : COUPADSBAA
  VID             : 00V0
  snmpOID         : 0.0.0.0.0.0.0.0
  H/W Version     : 0.1
  Current         : 1667
  RMA Code        : 0-0-0-0
switch#
```

**Related Commands**

Command	Description
<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

# show startup-config exclude-provision

To display the startup configuration that excludes the configuration for offline preprovisioned interfaces, use the **show startup-config exclude-provision** command.

**show startup-config exclude-provision**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(2)N1(1)	This command was introduced.

<b>Examples</b>	<p>This example shows how to display the startup configuration without the offline preprovisioned interfaces:</p> <pre>switch# show startup-config exclude-provision</pre>
-----------------	--

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>provision</b>	Preprovisions a module in a slot.
	<b>show provision</b>	Displays the preprovisioned module information.
	<b>show running-config exclude-provision</b>	Displays the running configuration excluding the preprovisioned features.
	<b>slot</b>	Configures a chassis slot for a predefined module.

# show system reset-reason fex

To display the reason for the last reset of the Fabric Extender, use the **show system reset-reason fex** command.

**show system reset-reason fex** *chassis\_ID*

Syntax Description	<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
--------------------	-------------------	--

Command Default	None
-----------------	------

Command Modes	EXEC mode
---------------	-----------

Command History	Release	Modification
	5.0(2)N1(1)	This command was introduced.

**Examples** This example shows how to display the last reset reason for a specific Fabric Extender:

```
switch# show system reset-reason fex 100

----- reset reason for FEX 100 -----

1) At 0 usecs after Unknown time
   Reset Reason: Unknown (0)
   Service (Additional Info):
   Image Version: 6.0(2)N1(1)

2) At 492646 usecs after Sun Jan 13 03:18:29 2013
   Reset Reason: Kernel Reboot (1)
   Service (Additional Info): Reload new image
   Image Version: 6.0(2)N1(1)

3) At 278870 usecs after Sun Jan 13 02:44:14 2013
   Reset Reason: Unknown (0)
   Service (Additional Info):
   Image Version: 6.0(2)N1(1)

4) At 603531 usecs after Fri Jan 11 05:27:57 2013
   Reset Reason: Reset due to upgrade (88)
   Service (Additional Info): Reset due to upgrade
   Image Version: 6.0(2)N1(1)

switch#
```

Related Commands	Command	Description
	<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

■ show system reset-reason fex



# show version fex

To display the software version information about a Fabric Extender, use the **show version fex** command.

**show version fex** *chassis\_ID*

Syntax Description	<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
--------------------	-------------------	--

Command Default	None
-----------------	------

Command Modes	EXEC mode
---------------	-----------

Command History	Release	Modification
	5.0(2)N1(1)	This command was introduced.

## Examples

This example shows how to display the software version of a Fabric Extender:

```
switch# show version fex 100
Software
  Bootloader version:      0.2
  System boot mode:       primary
  System image version:    6.0(2)N1(1) [build 6.0(2)N1(1)]

Hardware
  Module:                  Fabric Extender 48x1GE + 4x10G Module
  CPU:                     Motorola, e300c4
  Serial number:           FOC16031XJQ
  Bootflash:               locked

Kernel uptime is 0 day(s), 22 hour(s), 20 minutes(s), 32 second(s)

Last reset at Mon Jan 14 06:41:35 2013
  Reason: Reset due to upgrade
  Service: Reset due to upgrade
switch#
```

Related Commands	Command	Description
	<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

 show version fex



## T Commands

---

This chapter describes the Cisco NX-OS commands that begin with T that are used to manage a Cisco Nexus 2000 Series Fabric Extender from a Cisco Nexus 5500 switch.

# type

To set the Fabric Extender card type to a specific card, use the **type** command. To revert to the default FEX card, use the **no** form of this command.

**type** *fex\_card\_type*

**no type**

## Syntax Description

*fex\_card\_type*

Fabric Extender card type. The following Fabric Extender card types are supported:

- **N2148T**—Fabric Extender 48x1G 4x10G SFP+ Module
- **N2224TP**—Fabric Extender 24x1G 2x10G SFP+ Module
- **N2232P**—Fabric Extender 32x10G SFP+ 8x10G SFP+ Module
- **N2232TM**—Fabric Extender 32x10GBase-T 8x10G SFP+ Module
- **N2248T**—Fabric Extender 48x1G 4x10G SFP+ Module
- **N2248PQ**—Fabric Extender 48x10G SFP+ 16x10G SFP+ Module

## Command Default

None

## Command Modes

Fabric extender configuration mode

## Command History

### Release

### Modification

4.2(1)N1(1)

This command was introduced.

## Usage Guidelines

The following Cisco Nexus 2000 Series Fabric Extenders are supported on a Cisco Nexus 5500 switch:

- Cisco Nexus 2148T Fabric Extender—It has four 10-Gigabit Ethernet fabric interfaces for its uplink connection to the parent Cisco Nexus 5500 Series switch and 48 1000BASE-T (1-Gigabit) Ethernet host interfaces for its downlink connection to servers or hosts.
- Cisco Nexus N2224TP Fabric Extender—It has two 10-Gigabit Ethernet fabric interfaces with small form-factor pluggable (SFP+) interface adapters for its uplink connection to the parent Cisco Nexus 5500 Series switch and 24 1000BASE-T (1-Gigabit) Ethernet host interfaces for its downlink connection to servers or hosts. It does not support Fibre Channel over Ethernet (FCoE).
- Cisco Nexus 2232P Fabric Extender—It has eight 10-Gigabit Ethernet fabric interfaces with small form-factor pluggable (SFP+) interface adapters for its uplink connection to the parent Cisco Nexus 5500 Series switch and 32 10-Gigabit Ethernet fabric interfaces with SFP+ interface adapters for its downlink connection to servers or hosts.

- Cisco Nexus 2232TM Fabric Extender—It has eight 10-Gigabit Ethernet fabric interfaces with small form-factor pluggable (SFP+) interface adapters for its uplink connection to the parent Cisco Nexus 5500 Series switch and 32 10-Gigabit BASE-T Ethernet fabric interfaces for its downlink connection to servers or hosts.
- Cisco Nexus 2248T Fabric Extender—It has four 10-Gigabit Ethernet fabric interfaces with SFP+ interface adapters for its uplink connection to the parent Cisco Nexus 5500 Series switch and 48 1000BASE-T (1-Gigabit) Ethernet host interfaces for its downlink connection to servers or hosts.
- Cisco Nexus 2248PQ Fabric Extender—It has 48 10-Gigabit Ethernet host interfaces with SFP+ interface adapters and 16 10-Gigabit Ethernet fabric interfaces corresponding to 4 QSFP interface adapters for its uplink connection to the parent switch.

### Examples

This example shows how to configure the Fabric Extender card:

```
switch(config)# fex 100  
switch(config-fex)# type N2148T  
switch(config-fex)#
```

### Related Commands

Command	Description
<b>fex</b>	Creates a Fabric Extender and enters fabric extender configuration mode.
<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

■ type