Show Commands

This chapter describes the Cisco NX-OS IGMP show commands.

show ip igmp event-history

To display information in the IGMP event history buffers, use the **show ip igmp event-history** command.

show ip igmp event-history {clis | debugs | errors | events | ha | igmp-internal | msgs | mtrace |
policy | statistics | vrf}

Syntax Description	clis	Displays events of type CLI.				
	debugs	Displays events of type debug.				
	errors	Displays events of type error.				
	events	Displays events of type event.				
	ha	Displays events of type HA.				
	igmp-internal	Displays events of type IGMP internal.				
	msgs	Displays events of type msg.				
	mtrace	Displays events of type mtrace.				
	policy	Displays events of type policy.				
	statistics	Displays events of type statistics.				
	vrf	Displays events of type VRF.				
Command Default	None					
Command Modes	Any commond r	nada				
	Any command n	node				
Command History	Release	Modification				
	5.2(1)N1(1)	This command was introduced.				
Usage Guidelines	This command o	does not require a license.				
Examples	This example shows how to display information in the IGMP HA event history buffer: switch(config)# show ip igmp event-history ha					
	ha events for	IGMP process				
	—	:01:32.339950 igmp [4588]: : Router-port PSS entry for vlan 20 upd				
	ated [count 0] 2008 Apr 12 04:00:05.118545 igmp [4588]: : Handling existing vlans notification					
	-	:00:04.824730 igmp [4588]: : PSS entry for global updatedswitch(config)#				

Related Commands	Command	Description
	clear ip igmp event-history	Clears the contents of the IGMP event history buffers.
	ip igmp event-history	Configures the size of IGMP event history buffers.

show ip igmp groups

To display information about IGMP-attached group membership, use the **show ip igmp groups** command.

show ip igmp groups [{source [group]} | {group [source]}] [ethernet slot/[QSFP-module/]port |
port-channel channel-number[.sub_if_number] | vlan vlan-id] [vrf {vrf-name | all}]

Syntax Description	source	Source IP address.			
	group	(Optional) Multicast IP address of the single group to display.			
	ethernet slot/[QSFP-module/]port	(Optional) Specifies the Ethernet interface and the slot number and port number. The slot number is from 1 to 255. The <i>QSFP-module</i> number is from 1 to 4. The port number is from 1 to 128.			
		Note The <i>QSFP-module</i> number applies only to the QSFP+ Generic Expansion Module (GEM).			
	port-channel number	(Optional) Specifies the EtherChannel interface and EtherChannel number. The range is from 1 to 4096.			
	sub_if_number	(Optional) Subinterface number. The range is from 1 to 4093.			
	vlan vlan-id	(Optional) Specifies the VLAN. The range is from 1 to 4094.			
	vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.			
	vrf-name	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.			
	all	Specifies all VRFs.			
Command Modes	Any command mode				
Command History		Modification			
	6.0(2)N1(2)	Support for the QSFP+ GEM was added.			
	5.2(1)N1(1)	This command was introduced.			
Usage Guidelines	The show ip igmp route command is an alternative form of this command.				
	This command does not require a license.				
Examples	This example shows how to display information about the IGMP-attached group membership:				
	switch(config) # show ip igmp groups IGMP Connected Group Membership for VRF "default" - 0 total entries Type: S - Static, D - Dynamic, L - Local, T - SSM Translated Group Address Type Interface Uptime Expires Last Reporter				

switch(config)#

Related Commands

CommandDescriptionshow ip igmp routeDisplays information about the IGMP-attached group membership.

show ip igmp interface

To display information about IGMP on interfaces, use the **show ip igmp interface** command.

show ip igmp interface [brief] [vrf {vrf-name | all}]

Syntax Description	ethernet slot/[QSFP-module/]port	Specifies the Ethernet interface and the slot number and port number. The slot number is from 1 to 255. The <i>QSFP-module</i> number is from 1 to 4. The port number is from 1 to 128.			
		Note The <i>QSFP-module</i> number applies only to the QSFP+ Generic Expansion Module (GEM).			
	port-channel number	Specifies the EtherChannel interface and EtherChannel number. The range is from 1 to 4096.			
	sub_if_number	Subinterface number. The range is from 1 to 4093.			
	vlan vlan-id	Specifies the VLAN. The range is from 1 to 4094.			
	brief	(Optional) Displays one line status per interface.			
	vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.			
	vrf-name	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.			
	all	Specifies all VRFs.			
Command Modes	Any command mode Release	Modification			
oonnana motory	6.0(2)N1(2)	Support for the QSFP+ GEM was added.			
	5.2(1)N1(1)	This command was introduced.			
Usage Guidelines	This command does not re	equire a license.			
Examples	This example shows how to display information about IGMP on an interface (if IGMP is not in vPC mode, the vPC information is not displayed):				
	switch(config)# show ig IGMP Interfaces for VRH Vlan20, Interface statu IP address: 20.1.1.3,	F "default" s: protocol-down/link-down/admin-down			

```
Membership count: 0
 Old Membership count 0
 Route-queue depth: 0
 IGMP version: 2, host version: 0
 IGMP query interval: 125 secs, configured value: 125 secs
 IGMP max response time: 10 secs, configured value: 10 secs
 IGMP startup query interval: 31 secs, configured value: 31 secs
 IGMP startup query count: 2
 IGMP last member mrt: 1 secs
 IGMP last member query count: 2
 IGMP group timeout: 260 secs, configured value: 260 secs
 IGMP querier timeout: 255 secs, configured value: 255 secs
 IGMP unsolicited report interval: 10 secs
 IGMP robustness variable: 2, configured value: 2
 IGMP reporting for link-local groups: disabled
 IGMP interface enable refcount: 1
 IGMP interface immediate leave: disabled
 IGMP Report Policy: None
 IGMP State Limit: None
 IGMP interface statistics:
   General (sent/received):
     v1-reports: 0/0
     v2-queries: 0/0, v2-reports: 0/0, v2-leaves: 0/0
     v3-queries: 0/0, v3-reports: 0/0
   Errors:
     General Queries received with invalid destination address; v2: 0, v3: 0
     Checksum errors: 0, Packet length errors: 0
     Packets with Local IP as source: 0, Source subnet check failures: 0
      Query from non-querier:0
     Report version mismatch: 0, Query version mismatch: 0
     Unknown IGMP message type: 0
     Invalid v1 reports: 0, Invalid v2 reports: 0, Invalid v3 reports: 0
   Packets dropped due to router-alert check: 0
 Interface PIM DR: No
 Interface vPC CFS statistics:
   DR queries sent: 0
   DR queries rcvd: 0
   DR queries fail: 0
   DR updates sent: 0
   DR updates rcvd: 0
   DR updates fail: 0
switch(config)#
```

This example shows how to display information about IGMP on an interface in a brief format:

switch(config)#	show ip	igmp inter	face brief		
IGMP Interfaces	for VRF	"default",	count: 1		
Interface	IP	Address	IGMP Querier	Membership Count	Version
Vlan20 switch(config)#	20	.1.1.3	0.0.0.0	0	v2

show ip igmp local-groups

To display information about IGMP local groups, use the show ip igmp local-groups command.

Syntax Description	ethernet slot/[QSFP-module/]port	Specifies the Ethernet interface and the slot number and port number. The slot number is from 1 to 255. The <i>QSFP-module</i> number is from 1 to 4. The port number is from 1 to 128.				
		Note The <i>QSFP-module</i> number applies only to the QSFP+ Generic Expansion Module (GEM).				
	port-channel number	Specifies the EtherChannel interface and EtherChannel number. The range is from 1 to 4096.				
	sub_if_number	Subinterface number. The range is from 1 to 4093.				
	vlan vlan-id	Specifies the VLAN. The range is from 1 to 4094.				
	vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.				
	vrf-name	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.				
	all	Specifies all VRFs.				
Command Modes	Any command mode					
Command History		Modification				
		Support for the QSFP+ GEM was added.				
	5.2(1)N1(1)	This command was introduced.				
Usage Guidelines	This command does not re	equire a license.				
Examples	•	to display information about IGMP local groups:				
	switch(config)# show ip) igmp iocai-groups				

show ip igmp route

To display information about the IGMP-attached group membership, use the **show ip igmp route** command.

show ip igmp route [{source [group]} | {group [source]}] [ethernet slot/[QSFP-module/]port |
port-channel channel-number[.sub_if_number] | vlan vlan-id] [vrf {vrf-name | all}]

Syntax Description	source	Source IP address.			
	group	(Optional) Multicast IP address of single group to display.			
	ethernet slot/[QSFP-module/]port	Specifies the Ethernet interface and the slot number and port number. The slot number is from 1 to 255. The <i>QSFP-module</i> number is from 1 to 4. The port number is from 1 to 128.			
		Note The <i>QSFP-module</i> number applies only to the QSFP+ Generic Expansion Module (GEM).			
	port-channel number	Specifies the EtherChannel interface and EtherChannel number. The range is from 1 to 4096.			
	sub_if_number	Subinterface number. The range is from 1 to 4093.			
	vlan vlan-id	Specifies the VLAN. The range is from 1 to 4094.			
	vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.			
	vrf-name	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.			
	all	Specifies all VRFs.			
<u></u>					
Command History		Modification			
		Support for the QSFP+ GEM was added.			
	5.2(1)N1(1)	This command was introduced.			
Usage Guidelines	The show ip igmp groups	s command is an alternative form of this command.			
	This command does not require a license.				
Examples	This example shows how to display information about the IGMP-attached group membership:				
	-	ute mbership for VRF "default" - 1 total entries ynamic, L - Local, T - SSM Translated			

Cisco Nexus 5500 Series NX-OS Multicast Routing Command Reference

230.0.0.0	S	Ethernet1/5	00:31:47	never	0.0.0.0
switch#					

 Commands
 Command
 Description

 show ip igmp groups
 Displays information about the IGMP-attached group membership.

show running-config igmp

To display information about the running-system configuration for IGMP, use the **show running-config igmp** command.

show running-config igmp [all]

Syntax Description	all (Optional) Displays configured and default information.			
Command Default	None			
Command Modes	Any command mod	le		
Command History	Release	Modification		
	5.2(1)N1(1)	This command was introduced.		
Usage Guidelines	This command requ	uires the LAN Base Services license.		
Examples	This example show	s how to display information about the IGMP running-system configuration:		
	<pre>switch(config)# show running-config igmp</pre>			
	!Command: show ru !Time: Fri May 2	unning-config igmp 2 08:05:08 2008		
	version 5.2(1)N1((1)		
	interface Etherne ip igmp static-			
	<pre>switch(config)#</pre>			

show startup-config igmp

To display information about the startup-system configuration for IGMP, use the **show startup-config igmp** command.

show startup-config igmp [all]

Syntax Description	all (Opti	onal) Displays configured and default information.
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.
Usage Guidelines	This command requires	s the LAN Base Services license.
Examples	This example shows how to display information about the IGMP startup-system configuration:	
	<pre>switch(config)# show</pre>	startup-config igmp