



# W Commands

---

This chapter describes the Cisco NX-OS quality of service (QoS) commands that begin with W.

## wrr-queue cos-map

To map assigned class of service (CoS) values to select one of the egress queues, use the **wrr-queue cos-map** command. To return the CoS map to the default setting, use the **no** form of this command.

**wrr-queue cos-map** *queue-id cos1 ... cos8*

**no wrr-queue cos-map** *queue-id cos1 ... cos8*

### Syntax Description

<i>queue-id</i>	ID of the egress queue. The range is from 0 to 3.
<i>cos1... cos8</i>	CoS values that are mapped to select a queue. Enter up to eight CoS values. Separate each value with a space. The range is from 0 to 7.

### Command Default

The defaults are as follows:

- Receive queue 0 and transmit queue 0: CoS 0 and 1.
- Receive queue 1 and transmit queue 1: CoS 2 and 3.
- Receive queue 2 and transmit queue 2: CoS 4 and 5.
- Receive queue 3 and transmit queue 3: CoS 6 and 7.

### Command Modes

Global configuration mode

### Command History

Release	Modification
5.2(1)N1(1)	This command was introduced.

### Usage Guidelines



#### Note

This command is applicable only to Layer 3 multicast traffic.

You can use this command to distribute traffic into different queues, where each queue is configured with different weighted round robin (WRR) parameters.

You can configure a maximum of four multicast queues for Layer 3 multicast traffic. We recommend that you configure at least one class of service (CoS) value for each multicast queue.

### Examples

This example shows how to map CoS values 0 and 1 to queue 1:

```
switch(config)# wrr-queue cos-map 1 0 1
switch(config)#
```

**Related Commands**

Command	Description
<b>show wrr-queue cos-map</b>	Displays the weighted round-robin (WRR) queue information.

