



Cisco Nexus 5500 Series NX-OS System Management Command Reference

Cisco NX-OS Releases 7.x

First Published: January 27, 2014

Cisco Systems, Inc.
www.cisco.com

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco website at www.cisco.com/go/offices.

Text Part Number: OL-30882-01

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

Cisco Nexus 5500 Series NX-OS System Management Command Reference
© 2014 Cisco Systems, Inc. All rights reserved.



Preface ix

Audience ix

Document Conventions ix

Related Documentation x

Documentation Feedback xi

Obtaining Documentation and Submitting a Service Request xi

xi

New and Changed Information xiii

New and Changed Information for Cisco NX-OS Releases xiii

New and Changed Information for Cisco NX-OS Release 7.0(0)N1(1) xiii

A Commands 1

abort (session) 2

aclog match-log-level 3

C Commands 5

clear logging logfile 6

clear logging nvram 7

clear logging onboard 8

clear logging session 9

clear ntp session 10

clear ntp statistics 11

commit (session) 12

D Commands 13

diagnostic bootup level 14

description (SPAN, ERSPAN) 15

destination (ERSPAN) 17

destination (SPAN session) 18

F Commands 21

feature ptp 22

filter access-group 23

I Commands 25

- [ip access-list \(session\) 26](#)
- [ip dns source-interface 27](#)
- [ip domain-list 29](#)
- [ip domain-lookup 31](#)
- [ip domain-name 32](#)
- [ip host 34](#)
- [ip name-server 35](#)
- [ip port access-group \(session\) 37](#)

L Commands 39

- [logging abort 40](#)
- [logging commit 41](#)
- [logging console 42](#)
- [logging distribute 43](#)
- [logging event 44](#)
- [logging event port 45](#)
- [logging ip access-list cache 46](#)
- [logging level 48](#)
- [logging logfile 50](#)
- [logging module 51](#)
- [logging monitor 52](#)
- [logging server 53](#)
- [logging timestamp 55](#)

M Commands 57

- [monitor erspan origin ip-address 58](#)
- [monitor session 59](#)
- [mtu 61](#)

N Commands 63

- [ntp 64](#)
- [ntp abort 65](#)
- [ntp authenticate 66](#)
- [ntp commit 67](#)
- [ntp distribute 68](#)
- [ntp sync-retry 69](#)

P Commands 71

- poweroff module 72
- ptp announce 73
- ptp delay request minimum interval 74
- ptp domain 75
- ptp priority1 76
- ptp priority2 77
- ptp source 78
- ptp sync interval 79
- ptp vlan 80

S Commands 81

- shut (ERSPAN) 82
- snmp-server community 83
- snmp-server contact 84
- snmp-server context 85
- snmp-server enable traps 87
- snmp-server enable traps link 90
- snmp-server globalEnforcePriv 92
- snmp-server host 93
- snmp-server location 95
- snmp-server mib community-map 96
- snmp-server tcp-session 97
- snmp-server user 98
- snmp trap link-status 100
- source (SPAN, ERSPAN) 102
- switchport monitor rate-limit 104
- switch-profile 105

Show Commands 107

- show diagnostic bootup level 108
- show diagnostic result 109
- show hosts 111
- show ip dns source-interface 112
- show logging console 113
- show logging info 114
- show logging last 115

show logging level	116
show logging logfile	118
show logging module	119
show logging monitor	120
show logging nvram	121
show logging onboard	122
show logging pending	127
show logging pending-diff	128
show logging session status	129
show logging server	130
show logging status	131
show logging timestamp	132
show monitor session	133
show ntp authentication-status	135
show ntp peer-status	136
show ntp peers	137
show ntp statistics	138
show ntp timestamp-status	139
show ptp brief	140
show ptp clock	141
show ptp clocks foreign-masters-record	142
show ptp corrections	143
show ptp parent	144
show ptp port interface	145
show ptp time-property	146
show running-config monitor	147
show running-config port-security	149
show snmp community	150
show snmp context	151
show snmp engineID	152
show snmp group	153
show snmp host	155
show snmp sessions	156
show snmp trap	157
show snmp user	159

[show monitor session](#) 160

V Commands 163

[verify \(session\)](#) 164

[vrf \(ERSPAN\)](#) 165

System Message Logging Facilities 1



Preface

This preface describes the audience, organization, and conventions of the *Cisco Nexus 5500 Series NX-OS System Management Command Reference*. It also provides information on how to obtain related documentation.

This preface includes the following sections:

- [Audience, page ix](#)
- [Document Conventions, page ix](#)
- [Related Documentation, page x](#)
- [Documentation Feedback, page xi](#)
- [Obtaining Documentation and Submitting a Service Request, page xi](#)

Audience

This publication is for experienced users who configure and maintain Cisco NX-OS devices.

Document Conventions

Command descriptions use these conventions:

Convention	Description
boldface font	Commands and keywords are in boldface.
italic font	Arguments for which you supply values are in italics.
[]	Elements in square brackets are optional.
{x y z}	Alternative keywords are grouped in braces and separated by vertical bars.
[x y z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.

Screen examples use these conventions:

<code>screen font</code>	Terminal sessions and information that the switch displays are in screen font.
boldface screen font	Information you must enter is in boldface screen font.
<i>italic screen font</i>	Arguments for which you supply values are in italic screen font.
< >	Nonprinting characters, such as passwords, are in angle brackets.
[]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

This document uses the following conventions:



Note

Means reader *take note*. Notes contain helpful suggestions or references to material not covered in the manual.



Caution

Means reader *be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

Related Documentation

Documentation for Cisco Nexus 5000 Series Switches and Cisco Nexus 2000 Series Fabric Extenders is available at the following URL:

http://www.cisco.com/en/US/products/ps9670/tsd_products_support_series_home.html

The documentation set includes the following types of documents:

- Licensing Information Guide
- Release Notes
- Installation and Upgrade Guides
- Configuration Guides
- Configuration Examples and TechNotes
- Programming Guides
- Operations Guides
- Error and System Message Guides
- Field Notices
- Security Advisories, Responses and Notices
- Troubleshooting Guide
- Command References
- MIB Reference Guide

Documentation Feedback

To provide technical feedback on this document or to report an error or omission, please send your comments to nexus5k-docfeedback@cisco.com. We appreciate your feedback.

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as an RSS feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service. Cisco currently supports RSS Version 2.0.



New and Changed Information

This chapter provides release-specific information for each new and changed feature in the *Cisco Nexus 5500 Series NX-OS System Management Command Reference*. The latest version of this document is available at the following Cisco website:

http://www.cisco.com/en/US/products/ps9670/prod_command_reference_list.html

To check for additional information about this Cisco NX-OS Release, see the *Cisco Nexus 6000 Series NX-OS Release Notes, Release 6.0* available at the following Cisco website:

http://www.cisco.com/en/US/products/ps9670/prod_release_notes_list.html

New and Changed Information for Cisco NX-OS Releases

This section includes the following topics:

- [New and Changed Information for Cisco NX-OS Release 7.0\(0\)N1\(1\)](#), page xiii

New and Changed Information for Cisco NX-OS Release 7.0(0)N1(1)

[Table 1](#) summarizes the new and changed features for Cisco NX-OS Release 7.0(0)N1(1) and tells you where they are documented.

Table 1 *New and Changed Information for Release 7.0(0)N1(1)*

Feature	Description	Where Documented
SPAN with ACL Filtering	This feature was introduced.	• F Commands



A Commands

This chapter describes the system management commands that begin with A.

abort (session)

To discard the current configuration session, use the **abort** command.

abort

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Session configuration mode

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples This example shows how to abort the current configuration session:

```
switch# configure session MySession1
switch(config-s)# abort
switch#
```

Related Commands	Command	Description
	commit	Commits a session.
	configure session	Creates a configuration session.
	show configuration session	Displays the contents of the session.
	verify	Verifies a session.

acllog match-log-level

To specify the minimum severity level to log ACL matches, use the **acllog match-log-level** command. To remove the acllog match log level, use the **no** form of this command.

acllog match-log-level *severity-level*

no acllog match-log-level *severity-level*

Syntax Description

severity-level Number of the desired severity level at which messages should be logged. Messages at or numerically lower than the specified level are logged. Severity levels are as follows:

- **0**—emergency: System unusable
- **1**—alert: Immediate action needed
- **2**—critical: Critical condition
- **3**—error: Error condition
- **4**—warning: Warning condition
- **5**—notification: Normal but significant condition—default level
- **6**—informational: Informational message only (default)
- **7**—debugging: Appears during debugging only

Command Default

None

Command Modes

Global configuration mode

Command History

Release	Modification
5.2(1)N1(1)	This command was introduced.

Examples

This example shows how to set the acllog match-log-level to 6, informational:

```
switch(config)# acllog match-log-level 6
switch(config)#
```

Related Commands

Command	Description
logging level	Enables logging messages from a specified facility and configures the logging severity level.
logging logfile	Configures the name of the log file used to store system messages and sets the minimum severity level to log.



C Commands

This chapter describes the system management commands that begin with C.

clear logging logfile

To clear the contents of the log file, use the **clear logging logfile** command.

clear logging logfile

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples This example shows how to clear the logging logfile:

```
switch# clear logging logfile
switch#
```

Related Commands	Command	Description
	show logging logfile	Displays the messages in the log file.

clear logging nvram

To clear the NVRAM logs, use the **clear logging nvram** command.

clear logging nvram

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples	This example shows how to clear the NVRAM logs: <pre>switch# clear logging nvram</pre>
-----------------	---

Related Commands	Command	Description
	show logging nvram	Displays the NVRAM logs.

clear logging onboard

To clear the onboard failure logging (OBFL) entries in the persistent log, use the **clear logging onboard** command.

clear logging onboard [**environmental-history**] [**exception-log**] [**obfl-log**] [**stack-trace**]

Syntax Description	environmental-history	(Optional) Clears the OBFL environmental history.
	exception-log	(Optional) Clears the OBFL exception log entries.
	obfl-log	(Optional) Clears the OBFL (boot-up/uptime/device-version/obfl-history) entries.
	stack-trace	(Optional) Clears the OBFL stack trace entries.

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples This example shows how to clear the OBFL environmental history entries:

```
switch# clear logging onboard environmental-history
```

This example shows how to clear the OBFL exception-log entries:

```
switch# clear logging onboard exception-log
```

This example shows how to clear the OBFL (boot-up/uptime/device-version/obfl-history) entries:

```
switch# clear logging onboard obfl-log
```

This example shows how to clear the OBFL stack trace entries:

```
switch# clear logging onboard stack-trace
```

Related Commands	Command	Description
	show logging onboard	Displays onboard failure logs.

clear logging session

To clear the current logging session, use the **clear logging session** command.

clear logging session

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples	This example shows how to clear the current logging session: <pre>switch# clear logging session</pre>
-----------------	--

Related Commands	Command	Description
	show logging session	Displays the logging session status.

clear ntp session

To clear the Network Time Protocol (NTP) session, use the **clear ntp session** command.

clear ntp session

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples This example shows how to discard the NTP Cisco Fabric Services (CFS) distribution session in progress:

```
switch# clear ntp session
```

Related Commands	Command	Description
	show ntp	Displays NTP information.

clear ntp statistics

To clear the Network Time Protocol (NTP) session, use the **clear ntp statistics** command.

clear ntp statistics {all-peers | io | local | memory}

Syntax Description	all-peers	Clears all peer transaction statistics.
	io	Clears I/O statistics.
	local	Clears local statistics.
	memory	Clears memory statistics.

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples	This example shows how to discard the NTP I/O statistics: <pre>switch# clear ntp statistics io</pre>
-----------------	---

Related Commands	Command	Description
	show ntp	Displays NTP information.

commit (session)

To commit the current configuration session, use the **commit** command.

commit

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Session configuration mode

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples This example shows how to commit the current session:

```
switch(config-s)# commit
switch(config-s)#
```

Related Commands	Command	Description
	configure session	Creates a configuration session.
	show configuration session	Displays the contents of the session.
	verify	Verifies a session.



D Commands

This chapter describes the system management commands that begin with D.

diagnostic bootup level

To configure the bootup diagnostic level to trigger diagnostics when the device boots, use the **diagnostic bootup level** command. To remove bootup diagnostic level configuration, use the **no** form of this command.

diagnostic bootup level {bypass | complete}

no diagnostic bootup level {bypass | complete}

Syntax Description

bypass	Specifies that all bootup tests are skipped.
complete	Specifies that all bootup diagnostics are performed. This is the default value.

Command Default

Complete

Command Modes

Global configuration mode

Command History

Release	Modification
5.2(1)N1(1)	This command was introduced.

Examples

This example shows how to configure the bootup diagnostics level to trigger the complete diagnostics:

```
switch(config)# diagnostic bootup level complete
switch(config)#
```

This example shows how to remove the bootup diagnostics level configuration:

```
switch(config)# no diagnostic bootup level complete
switch(config)#
```

Related Commands

Command	Description
show diagnostic bootup level	Displays the bootup diagnostics level.
show diagnostic bootup result	Displays the results of the diagnostics tests.

description (SPAN, ERSPAN)

To add a description to an Ethernet Switched Port Analyzer (SPAN) or an Encapsulated Remote Switched Port Analyzer (ERSPAN) session configuration, use the **description** command. To remove the description, use the **no** form of this command.

description *description*

no description

Syntax Description

<i>description</i>	String description of the SPAN session configuration. This string is limited to 80 characters.
--------------------	--

Command Default

No description is added.

Command Modes

SPAN session configuration mode
ERSPAN session configuration mode

Command History

Release	Modification
5.2(1)N1(1)	This command was introduced.

Usage Guidelines

Use the **description** command to provide a reminder in the configuration to describe what certain SPAN sessions are used for. The description appears in the output of the following commands such as **show monitor session** and **show running-config monitor**.

Examples

This example shows how to add a description for a SPAN session:

```
switch# configure terminal
switch(config)# monitor session 9 type local
switch(config-monitor)# description A Local SPAN session
switch(config-monitor)#
```

This example shows how to add a description for an ERSPAN session:

```
switch# configure terminal
switch(config)# monitor session 9 type erspan-source
switch(config-erspan-src)# description An ERSPAN session
switch(config-erspan-src)#
```

Related Commands

Command	Description
destination (SPAN session)	Configures a destination SPAN port.
monitor session	Creates a new SPAN session configuration.

Command	Description
show monitor session	Displays SPAN session configuration information.
show running-config monitor	Displays the running configuration information of a SPAN session.
source (SPAN session)	Configures a source SPAN port.

destination (ERSPAN)

To configure an Encapsulated Remote Switched Port Analyzer (ERSPAN) destination IP address, use the **destination** command. To remove the destination ERSPAN IP address, use the **no** form of this command.

destination ip *ip_address*

no destination ip *ip_address*

Syntax Description	ip	Configures the remote IP address.
	<i>ip_address</i>	IPv4 address in the format <i>A.B.C.D</i> .

Command Default	None
-----------------	------

Command Modes	ERSPAN session configuration mode
---------------	-----------------------------------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Usage Guidelines	You can configure only one destination IP address for an ERSPAN source session. This command does not require a license.
------------------	--

Examples	This example shows how to configure an ERSPAN destination IP address:
----------	---

```
switch# configure terminal
switch(config)# monitor session 1 type erspan-source
switch(config-erspan-src)# destination ip 192.0.3.1
switch(config-erspan-src)#
```

Related Commands	Command	Description
	monitor session	Creates a new SPAN session configuration.
	show monitor session	Displays SPAN session configuration information.
	show running-config monitor	Displays the running configuration information of a SPAN session.
	source (SPAN session)	Configures a source SPAN port.
	source (ERSPAN session)	Configures a source VLAN or VSAN interface.

destination (SPAN session)

To configure a Switched Port Analyzer (SPAN) destination port, use the **destination** command. To remove the destination SPAN port, use the **no** form of this command.

destination interface {**ethernet** *slot*[/*QSFP-module*]/*port*}

no source interface {**ethernet** *slot*[/*QSFP-module*]/*port*}

Syntax Description	interface	Specifies the interface type to use as the destination SPAN port.
	ethernet <i>slot</i> [/ <i>QSFP-module</i>]/ <i>port</i>	Specifies the Ethernet interface to use as the destination SPAN port. The slot number is from 1 to 255. The <i>QSFP-module</i> number is from 1 to 4. The port number is from 1 to 128.
	Note	The <i>QSFP-module</i> number applies only to the QSFP+ Generic Expansion Module (GEM).

Command Default None

Command Modes SPAN session configuration mode

Command History	Release	Modification
	6.0(2)N1(2)	Support for the QSFP+ GEM was added.
	5.2(1)N1(1)	This command was introduced.

Usage Guidelines Each local SPAN session destination session must have a destination port (also called a *monitoring port*) that receives a copy of traffic from the source port.

The destination port can be any Ethernet physical port and must reside on the same switch as the source port (for a local SPAN session). The destination port cannot be a source port, a port channel, or SAN port channel group.

A destination port receives copies of sent and received traffic for all monitored source ports. If a destination port is oversubscribed, it can become congested. This congestion can affect traffic forwarding on one or more of the source ports.

Examples This example shows how to configure an Ethernet interface SPAN destination port and activate the SPAN session:

```
switch# configure terminal
switch(config)# interface ethernet 1/5
switch(config-if)# switchport monitor
switch(config-if)# exit
switch(config)# monitor session 9 type local
switch(config-monitor)# description A Local SPAN session
switch(config-monitor)# source interface ethernet 1/1
```

```
switch(config-monitor)# destination interface ethernet 1/5
switch(config-monitor)# no shutdown
switch(config-monitor)#
```

Related Commands

Command	Description
source (SPAN session)	Configures a source SPAN port.
monitor session	Creates a new SPAN session configuration.
show monitor session	Displays SPAN session configuration information.
show running-config monitor	Displays the running configuration information of a SPAN session.

■ destination (SPAN session)



F Commands

This chapter describes the system management commands that begin with F.

feature ptp

To enable the PTP feature, use the **feature ptp** command. To unconfigure the PTP feature, use the **no** form of this command.

feature ptp

no feature ptp

Syntax Description There are no arguments or keywords for this command.

Command Default None

Command Modes Global configuration mode

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples This example shows how to enable PTP on the device:

```
switch# configure terminal
switch(config)# feature ptp
```

Related Commands	Command	Description
	feature ptp	Enables or disables PTP on the device.
	ptp source	Configures the source IP address for all PTP packets.
	ptp domain	Configures the domain number to use for this clock.
	ptp priority1	Configures the priority 1 value to use when advertising this clock.
	ptp priority2	Configures the priority 1 value to use when advertising this clock.
	show ptp brief	Displays the PTP status.
	show ptp clock	Displays the properties of the local clock.

filter access-group

To apply an access group to an Encapsulated Remote Switched Port Analyzer (ERSPAN) or Switched Port Analyzer (SPAN) source session, use the **filter access-group** command. To remove an access group, use the **no** form of this command.

filter access-group *acl-filter*

no filter access-group *acl-filter*

Syntax Description	<i>acl-filter</i>	Access control list (ACL) name. An ACL associates the access list with the SPAN session.
---------------------------	-------------------	--

Command Default	None
------------------------	------

Command Modes	SPAN session configuration mode (config-monitor) ERSPAN source session configuration mode (config-erspan-src)
----------------------	--

Command History	Release	Modification
	7.0(0)N1(1)	This command was introduced.

Usage Guidelines	ACL filtering allows you to filter SPAN and ERSPAN traffic so that you can reduce bandwidth congestion. An ACL is a list of permissions associated to any entity in the system; in the context of a monitoring session, an ACL is a list of rules which results in the spanning of traffic that matches the ACL criteria, saving bandwidth for more meaningful data. The filter applies to all sources in the session.
-------------------------	--



Note

If the ACL has rules with a log option configured, the log option is ignored but the rule is implemented.

Examples	This example shows how to enable an ACL filter for a SPAN session:
-----------------	--

```
switch# configure terminal
switch(config)# monitor session 3
switch(config-monitor)# filter access-group acl_span_ses_3
```

This example shows how to enable an ACL filter for a ERSPAN session:

```
switch# configure terminal
switch(config)# monitor session 4 type erspan-source
switch(config-erspan-src)# filter access-group acl_erspan_ses_3
```

■ filter access-group

Related Commands	Command	Description
	monitor session	Creates a new SPAN or ERSPAN session.



I Commands

This chapter describes the system management commands that begin with I.

ip access-list (session)

To create an IPv4 access control list (ACL) within a configuration session, use the **ip access-list** command. To remove an ACL from a configuration session, use the **no** form of this command.

ip access-list *ACL-name*

no ip access-list *ACL-name*

Syntax Description	<i>ACL-name</i>	Name of the IPv4 ACL. The name can be up to 64 alphanumeric characters and cannot contain a space or quotation mark.
--------------------	-----------------	--

Command Default	No IPv4 ACLs are defined by default.
-----------------	--------------------------------------

Command Modes	Global session configuration mode
---------------	-----------------------------------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples This example shows how to create an IPv4 ACL for a configuration session:

```
switch# configure session MySession1
switch(config-s)# ip access-list myACL
switch(config-s-acl)#
```

Related Commands	Command	Description
	configure session	Creates a configuration session.
	deny	Configures a deny rule in an IPv4 ACL.
	permit	Configures a permit rule in an IPv4 ACL.
	show configuration session	Displays the contents of the session.

ip dns source-interface

To configure the source interface for the Domain Name Server (DNS) domain lookup, use the **ip dns source-interface** command. To revert to the default settings, use the **no** form of this command.

ip dns source-interface { **ethernet** *slot*[/*QSFP-module*]/*port* | **loopback** *intf-num* } [**vrf** { *vrf-name* | **default** | **management** }]

no ip dns source-interface { **ethernet** *slot*[/*QSFP-module*]/*port* | **loopback** *intf-num* } [**vrf** { *vrf-name* | **default** | **management** }]

Syntax Description

ethernet <i>slot</i> [/ <i>QSFP-module</i>]/ <i>port</i>	Specifies the Ethernet interface to use as the source interface. The slot number is from 1 to 255. The <i>QSFP-module</i> number is from 1 to 4. The port number is from 1 to 128.
	Note The <i>QSFP-module</i> number applies only to the QSFP+ Generic Expansion Module (GEM).
loopback <i>intf-num</i>	Specifies the loopback interface to use as the source interface. The range of values is from 0 to 1023.
vrf <i>vrf-name</i>	(Optional) Specifies the virtual routing and forwarding (VRF) instance. (Optional) VRF name. The name is case sensitive and can be a maximum of 32 characters.
default	(Optional) Specifies the default VRF.
management	(Optional) Specifies the management VRF.

Command Default

None

Command Modes

Global configuration mode

Command History

Release	Modification
6.0(2)N1(2)	Support for the QSFP+ GEM was added.
5.2(1)N1(1)	This command was introduced.

Usage Guidelines

This command does not require a license.

Examples

This example shows how to configure an Ethernet interface as the source interface for a DNS lookup:

```
switch# configure terminal
switch(config)# ip dns source-interface ethernet 1/5
switch(config)#
```

Related Commands

Command	Description
ip domain-lookup	Enables the DNS lookup feature.
show ip dns source-interface	Displays information about the DNS source interfaces.

ip domain-list

To configure the IP domain list, use the **ip domain-list** command. To disable the IP domain list, use the **no** form of the command.

ip domain-list *domain-name* [**use-vrf** *name*]

no ip domain-list *domain-name* [**use-vrf** *name*]

Syntax Description	domain-list	Specifies the domain name for the IP domain list. The name can be any case-sensitive, alphanumeric string up to 63 characters.
	use-vrf <i>name</i>	(Optional) Specifies the virtual routing and forwarding (VRF) to use to resolve the domain domain name for the IP domain list. The name can be any case-sensitive, alphanumeric string up to 32 characters.

Command Default None

Command Modes Global configuration mode
VRF context configuration mode

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Usage Guidelines Use the **ip domain-list** command to configure additional domain names for the device. Use the **vrf context** command to enter the VRF context mode to configure additional domain names for a particular VRF.

Examples This example shows how to configure the IP domain list for the default VRF:

```
switch# config terminal
switch(config)# ip domain-list Mysite.com
```

This example shows how to configure the IP domain list for the management VRF:

```
switch# config terminal
switch(config)# vrf context management
switch(config-vrf)# ip domain-list Mysite.com
```

This example shows how to configure the IP domain list for the default VRF to use the management VRF as a backup if the domain name cannot be resolved through the default VRF:

```
switch# config terminal
switch(config)# vrf context management
switch(config-vrf)# exit
switch(config)# ip domain-name Mysite.com use-vrf management
switch(config)# ip name-server 192.0.2.1
switch(config)# ip domain-list Mysite2.com
```

Related Commands	Command	Description
	show hosts	Displays information about the IP domain name configuration.

ip domain-lookup

To enable the Domain Name Server (DNS) lookup feature, use the **ip domain-lookup** command. Use the **no** form of this command to disable this feature.

ip domain-lookup

no ip domain-lookup

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Usage Guidelines	Use the ip domain-lookup command to enable DNS.
-------------------------	--

Examples	This example shows how to configure the DNS server lookup feature:
-----------------	--

```
switch# config terminal
switch(config)# vrf context management
switch(config-vrf)# exit
switch(config)# ip domain-name Mysite.com use-vrf management
switch(config)# ip name-server 192.0.2.1
switch(config)# ip domain-lookup
switch(config)#
```

Related Commands	Command	Description
	show hosts	Displays information about the DNS.

ip domain-name

To configure a domain name, use the **ip domain-name** command. To delete a domain name, use the **no** form of the command.

ip domain-name *domain-name* [**use-vrf** *name*]

no ip domain-name *domain-name* [**use-vrf** *name*]

Syntax Description	<i>domain-name</i>	Domain name. The name can be any case-sensitive, alphanumeric string up to 63 characters.
	use-vrf <i>name</i>	(Optional) Specifies the virtual routing and forwarding (VRF) to use to resolve the domain name. The name can be any case-sensitive, alphanumeric string up to 32 characters.

Command Default None

Command Modes Global configuration mode
VRF context configuration mode

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Usage Guidelines Use the **ip domain-name** command to configure the domain name for the device. Use the **vrf context** command to enter the VRF context mode to configure the domain monastery for a particular VRF.

Examples This example shows how to configure the IP domain name for the default VRF:

```
switch# config terminal
switch(config)# ip domain-name Mysite.com
switch(config)#
```

This example shows how to configure the IP domain name for the management VRF:

```
switch# config terminal
switch(config)# vrf context management
switch(config-vrf)# ip domain-name Mysite.com
switch(config-vrf)#
```

This example shows how to configure the IP domain name for the default VRF to use the management VRF as a backup if the domain name cannot be resolved through the default VRF:

```
switch# config terminal
switch(config)# vrf context management
switch(config-vrf)# exit
switch(config)# ip domain-name Mysite.com use-vrf management
```

Related Commands

Command	Description
ip domain-list	Configures the IP domain list.
ip domain-lookup	Enables the Domain Name Server (DNS) lookup feature.
show hosts	Displays information about the IP domain name configuration.

ip host

To define static hostname-to-address mappings in the Domain Name System (DNS) hostname cache, use the **ip host** command. To remove a hostname-to-address mapping, use the **no** form of this command.

ip host *name* *address1* [*address2*... *address6*]

no ip host *name* *address1* [*address2*... *address6*]

Syntax Description	<i>name</i>	Hostname. The <i>name</i> can be any case-sensitive, alphanumeric string up to 80 characters.
	<i>address1</i>	IPv4 address in the x.x.x.x format.
	<i>address2</i> ... <i>address6</i>	(Optional) Up to five additional IPv4 addresses in the x.x.x.x format.

Command Default	None
------------------------	------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Usage Guidelines	Use the ip host command to add a static hostname to DNS.
-------------------------	---

Examples	This example shows how to configure a static hostname:
	switch(config)# ip host mycompany.com 192.0.2.1

Related Commands	Command	Description
	show hosts	Displays information about the IP domain name configuration.

ip name-server

To configure a name server, use the **ip name-server** command. To disable this feature, use the **no** form of the command.

ip name-server *ip-address* [**use-vrf** *name*]

no ip name-server *ip-address* [**use-vrf** *name*]

Syntax Description	<i>ip-address</i>	IP address for the name server.
	use-vrf <i>name</i>	(Optional) Specifies the virtual routing and forwarding (VRF) to use to reach the name-server. The name can be any case-sensitive, alphanumeric string up to 32 characters.

Command Default	None
------------------------	------

Command Modes	Global configuration mode VRF context configuration mode
----------------------	---

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Usage Guidelines	Use the ip name-server command to configure the name server for the device. Use the vrf context command to enter the VRF context mode to configure the domain names for a particular VRF.
-------------------------	---

Examples	This example shows how to configure the IP name server for the default VRF:
-----------------	---

```
switch# config terminal
switch(config)# vrf context management
switch(config-vrf)# exit
switch(config)# ip domain-name Mysite.com use-vrf management
switch(config)# ip name-server 192.0.2.1
```

This example shows how to configure the IP name server for the management VRF:

```
switch# config terminal
switch(config)# vrf context management
switch(config-vrf)# ip name-server 192.0.2.1
```

This example shows how to configure the IP name server for the default VRF to use the management VRF as a backup if the IP name server cannot be reached through the default VRF:

```
switch# config terminal
switch(config)# vrf context management
switch(config-vrf)# exit
switch(config)# ip domain-name Mysite.com use-vrf management
switch(config)# ip name-server 192.0.2.1 use-vrf management
```

Related Commands	Command	Description
	ip domain-list	Defines a list of domains.
	ip domain lookup	Enables DNS-based host name-to-address translation.
	show hosts	Displays information about the IP domain name configuration.
	vrf context	Creates a virtual routing and forwarding (VRF) instance.

ip port access-group (session)

To apply an IPv4 access control list (ACL) to an interface as a port ACL, use the **ip port access-group** command. To remove an IPv4 ACL from an interface, use the **no** form of this command.

ip port access-group *access-list-name* {**in** | **out**}

no ip port access-group *access-list-name* {**in** | **out**}

Syntax Description	<i>access-list-name</i>	Name of the IPv4 ACL. The name can be up to 64 alphanumeric, case-sensitive characters long.
	in	Specifies that the ACL applies to inbound traffic.
	out	Specifies that the ACL applies to outbound traffic.

Command Default	None
------------------------	------

Command Modes	Session interface configuration mode
----------------------	--------------------------------------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples This example shows how to apply an IPv4 ACL named ip-acl-01 to the Ethernet interface 1/2 as a port ACL:

```
switch# configure session MySession1
switch(config-s)# interface ethernet 1/2
switch(config-s-if)# ip port access-group ip-acl-01 in
switch(config-s-if)#
```

This example shows how to remove an IPv4 ACL named ip-acl-01 from Ethernet interface 1/2:

```
switch(config-s)# interface ethernet 1/2
switch(config-s-if)# no ip port access-group ip-acl-01 in
switch(config-s-if)#
```

Related Commands	Command	Description
	show access-lists	Displays all ACLs.
	show configuration session	Displays the contents of the session.



L Commands

This chapter describes the system management commands that begin with L.

logging abort

To discard the pending changes to the syslog server configuration, use the **logging abort** command.

logging abort

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Global configuration mode

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples This example shows how to discard the changes made to the syslog server configuration:

```
switch(config)# logging distribute
switch(config)# logging abort
switch(config)#
```

Related Commands	Command	Description
	logging distribute	Enables the distribution of the syslog server configuration to network switches using the CFS infrastructure.
	show logging pending	Displays the pending changes to the syslog server configuration.
	show logging status	Displays the logging status.

logging commit

To commit the pending changes to the syslog server configuration for distribution to the switches in the fabric, use the **logging commit** command.

logging commit

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples	This example shows how to commit the distribution of the syslog server configuration:
-----------------	---

<pre>switch(config)# logging distribute switch(config)# commit switch(config)#</pre>
--

Related Commands	Command	Description
	logging distribute	Enables the distribution of the syslog server configuration to network switches using the CFS infrastructure.
	show logging status	Displays the logging status.

logging console

To enable logging messages to the console session, use the **logging console** command. To disable logging messages to the console session, use the **no** form of this command.

logging console [*severity-level*]

no logging console

Syntax Description	<i>severity-level</i> (Optional) Number of the desired severity level at which messages should be logged. Messages at or numerically lower than the specified level are logged. Severity levels are as follows: • 0—emergency: System unusable • 1—alert: Immediate action needed • 2—critical: Critical condition—default level • 3—error: Error condition • 4—warning: Warning condition • 5—notification: Normal but significant condition • 6—informational: Informational message only • 7—debugging: Appears during debugging only				
Command Default	None				
Command Modes	Global configuration mode				
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>5.2(1)N1(1)</td><td>This command was introduced.</td></tr></table>	Release	Modification	5.2(1)N1(1)	This command was introduced.
Release	Modification				
5.2(1)N1(1)	This command was introduced.				
Examples	This example shows how to enable logging messages with a severity level of 4 (warning) or higher to the console session: <pre>switch# configure terminal switch(config)# logging console 4</pre>				
Related Commands	<table><tr><th>Command</th><th>Description</th></tr><tr><td>show logging console</td><td>Displays the console logging configuration.</td></tr></table>	Command	Description	show logging console	Displays the console logging configuration.
Command	Description				
show logging console	Displays the console logging configuration.				

logging distribute

To enable the distribution of the syslog server configuration to network switches using the Cisco Fabric Services (CFS) infrastructure, use the **logging distribute** command. To disable the distribution, use the **no** form of this command.

logging distribute

no logging distribute

Syntax Description This command has no arguments or keywords.

Command Default Distribution is disabled.

Command Modes Global configuration mode

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples This example shows how to enable the distribution of the syslog server configuration:

```
switch(config)# logging distribute
switch(config)#
```

This example shows how to disable the distribution of the syslog server configuration:

```
switch(config)# no logging distribute
switch(config)#
```

Related Commands	Command	Description
	logging abort	Cancels the pending changes to the syslog server configuration.
	logging commit	Commits the changes to the syslog server configuration for distribution to the switches in the fabric.
	show logging status	Displays the logging status.

logging event

To log interface events, use the **logging event** command. To disable logging of interface events, use the **no** form of this command.

logging event port {link-status | trunk-status} {default | enable}

no logging event port {link-status | trunk-status} {default | enable}

Syntax Description

link-status	Specifies to log all UP/DOWN and CHANGE messages.
trunk-status	Specifies to log all TRUNK status messages.
default	Specifies to the default logging configuration is used by interfaces not explicitly configured.
enable	Enables the logging to override the port level configuration.

Command Default

None

Command Modes

Global configuration mode

Command History

Release	Modification
5.2(1)N1(1)	This command was introduced.

Examples

This example shows how to log interface events:

```
switch# configure terminal  
switch(config)# logging event link-status default
```

Related Commands

Command	Description
show logging	Displays the logging status.

logging event port

To log events on an interface, use the **logging event port** command. To disable logging of interface events, use the **no** form of this command.

logging event port {link-status | trunk-status} [default]

no logging event port {link-status | trunk-status}

Syntax Description	link-status	Specifies to log all UP/DOWN and CHANGE messages.
	trunk-status	Specifies to log all TRUNK status messages.
	default	(Optional) Specifies the default logging configuration that is used by interfaces not explicitly configured.

Command Default	None
-----------------	------

Command Modes	Interface configuration mode
---------------	------------------------------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples	This example shows how to log interface events: <pre>switch# configure terminal switch(config)# interface ethernet 1/1 switch(config-if)# logging event port link-status default</pre>
----------	---

Related Commands	Command	Description
	show interface	Displays the interface configuration information.
	show logging	Displays the logging status.

logging ip access-list cache

To configure the Optimized ACL Logging (OAL) parameters, use the **logging ip access-list cache** command. To reset to the default settings, use the **no** form of this command.

logging ip access-list cache {{ **entries** *num_entries* } | { **interval** *seconds* } | { **threshold** *num_packets* } }

no logging ip access-list cache {{ **entries** *num_entries* } | { **interval** *seconds* } | { **threshold** *num_packets* } }

Syntax Description	entries <i>num_entries</i>	Specifies the maximum number of log entries that are cached in the software. The range is from 0 to 1048576. The default value is 8000 entries.
	interval <i>seconds</i>	Specifies the maximum time interval before an entry is sent to a syslog. The range is from 5 to 86400. The default value is 300 seconds.
	threshold <i>num_packets</i>	Specifies the number of packet matches (hits) before an entry is sent to a syslog. The range is from 0 to 1000000. The default value is 0 packets—rate limiting is off; the system log is not triggered by the number of packet matches.

Defaults None

Command Modes Global configuration

Supported User Roles network-admin

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Usage Guidelines This command does not require a license.

Examples This example shows how to specify the maximum number of log entries that are cached in the software:

```
switch# configure terminal
switch(config)# logging ip access-list cache entries 200
switch(config)#
```

This example shows how to specify the maximum time interval before an entry is sent to the system log:

```
switch# configure terminal
switch(config)# logging ip access-list cache interval 350
switch(config)#
```

This example shows how to specify the number of packet matches before an entry is sent to the system log:

```
switch# configure terminal
switch(config)# logging ip access-list cache threshold 125
switch(config)#
```

Related Commands

Command	Description
show logging ip access-list	Displays the status of IP access list logging.

logging level

To enable logging messages from a defined facility that have the specified severity level or higher, use the **logging level** command. To disable logging messages from a defined facility, use the **no** form of this command.

logging level *facility severity-level*

no logging level *facility severity-level*

Syntax Description	<i>facility</i>	Facility. The facilities are listed in Table A-1 of Appendix A, “System Message Logging Facilities.”
		To apply the same severity level to all facilities, use the all facility.
	<i>severity-level</i>	Number of the desired severity level at which messages should be logged. Messages at or numerically lower than the specified level are logged. Severity levels are as follows: • 0—emergency: System unusable • 1—alert: Immediate action needed • 2—critical: Critical condition—default level • 3—error: Error condition • 4—warning: Warning condition • 5—notification: Normal but significant condition • 6—informational: Informational message only • 7—debugging: Appears during debugging only
Command Default	None	
Command Modes	Global configuration mode	
Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.
Examples	This example shows how to enable logging messages from the AAA facility that have a severity level of 2 or higher: <pre>switch(config)# logging level aaa 2</pre>	

Related Commands	Command	Description
	show logging level	Displays the facility logging level configuration.

logging logfile

To configure the name of the log file used to store system messages and the minimum severity level to log, use the **logging logfile** command. To disable logging to the log file, use the **no** form of this command.

logging logfile *logfile-name severity-level [size bytes]*

no logging logfile [*logfile-name severity-level [size bytes]*]

Syntax Description	<i>logfile-name</i>	Name of the log file to be used to store system messages.
	<i>severity-level</i>	Number of the desired severity level at which messages should be logged. Messages at or numerically lower than the specified level are logged. Severity levels are as follows: • 0—emergency: System unusable • 1—alert: Immediate action needed • 2—critical: Critical condition—default level • 3—error: Error condition • 4—warning: Warning condition • 5—notification: Normal but significant condition • 6—informational: Informational message only • 7—debugging: Appears during debugging only
	<i>size bytes</i>	(Optional) Specifies a maximum file size. The default file size is 4194304 bytes and can be configured from 4096 to 4194304 bytes.

Command Default None

Command Modes Global configuration mode

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples This example shows how to configure a log file called logfile to store system messages and set its severity level to 4:

```
switch(config)# logging logfile logfile 4
```

Related Commands	Command	Description
	show logging logfile	Displays the log file.

logging module

To enable module log messages, use the **logging module** command. To disable module log messages, use the **no** form of this command.

logging module [*severity-level*]

no logging module

Syntax Description	<i>severity-level</i> (Optional) Number of the desired severity level at which messages should be logged. Messages at or numerically lower than the specified level are logged. Severity levels are as follows: • 0—emergency: System unusable • 1—alert: Immediate action needed • 2—critical: Critical condition • 3—error: Error condition • 4—warning: Warning condition • 5—notification: Normal but significant condition—default level • 6—informational: Informational message only • 7—debugging: Appears during debugging only				
Command Default	None				
Command Modes	Global configuration mode				
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>5.2(1)N1(1)</td><td>This command was introduced.</td></tr></table>	Release	Modification	5.2(1)N1(1)	This command was introduced.
Release	Modification				
5.2(1)N1(1)	This command was introduced.				
Usage Guidelines	Set a specified severity level or use the default.				
Examples	This example shows how to enable module log messages: <pre>switch(config)# logging module</pre>				
Related Commands	<table><tr><th>Command</th><th>Description</th></tr><tr><td>show logging module</td><td>Displays the module logging status.</td></tr></table>	Command	Description	show logging module	Displays the module logging status.
Command	Description				
show logging module	Displays the module logging status.				

logging monitor

To enable the device to log messages to the monitor (terminal line), use the **logging monitor** command. To disable monitor log messages, use the **no** form of this command.

logging monitor [*severity-level*]

no logging monitor

Syntax Description

severity-level

(Optional) Number of the desired severity level at which messages should be logged. Messages at or numerically lower than the specified level are logged. Severity levels are as follows:

- **0**—emergency: System unusable
- **1**—alert: Immediate action needed
- **2**—critical: Critical condition—default level
- **3**—error: Error condition
- **4**—warning: Warning condition
- **5**—notification: Normal but significant condition
- **6**—informational: Informational message only
- **7**—debugging: Appears during debugging only

Command Default

None

Command Modes

Global configuration mode

Command History

Release	Modification
5.2(1)N1(1)	This command was introduced.

Usage Guidelines

This configuration applies to Telnet and Secure Shell (SSH) sessions.

Examples

This example shows how to enable monitor log messages:

```
switch(config)# logging monitor
```

Related Commands

Command	Description
show logging monitor	Displays the status of monitor logging.

logging server

To configure a remote syslog server at the specified hostname or IPv4/IPv6 address, use the **logging server** command. To disable the remote syslog server, use the **no** form of this command.

logging server *host* [*severity-level*] [**facility** {**auth** | **authpriv** | **cron** | **daemon** | **ftp** | **kernel** | **local0** | **local1** | **local2** | **local3** | **local4** | **local5** | **local6** | **local7** | **lpr** | **mail** | **news** | **syslog** | **user** | **uucp**} | **use-vrf** {*vrf_name* | **management**}]

no logging server *host* [*severity-level*] [**facility** {**auth** | **authpriv** | **cron** | **daemon** | **ftp** | **kernel** | **local0** | **local1** | **local2** | **local3** | **local4** | **local5** | **local6** | **local7** | **lpr** | **mail** | **news** | **syslog** | **user** | **uucp**} | **use-vrf** {*vrf_name* | **management**}]

Syntax Description	
<i>host</i>	Hostname or IPv4/IPv6 address of the remote syslog server.
<i>severity-level</i>	(Optional) Number of the desired severity level at which messages should be logged. Messages at or numerically lower than the specified level are logged. Severity levels are as follows: • 0—emergency: System unusable • 1—alert: Immediate action needed • 2—critical: Critical condition—default level • 3—error: Error condition • 4—warning: Warning condition • 5—notification: Normal but significant condition • 6—informational: Informational message only • 7—debugging: Appears during debugging only
facility <i>facility</i>	(Optional) Specifies the outgoing <i>facility</i> . The facilities are listed in Table A-1 of Appendix A, “System Message Logging Facilities.” The default outgoing facility is local7 .
vrf <i>vrf_name</i>	(Optional) Specifies the virtual routing and forwarding (VRF) to be used in the remote server. The name can be a maximum of 32 alphanumeric characters.
management	Specifies the management VRF. This is the default VRF.

Command Default The default outgoing facility is **local7**.
The default VRF is **management**.

Command Modes Global configuration mode

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples

This example shows how to configure a remote syslog server at a specified IPv4 address, using the default outgoing facility:

```
switch(config)# logging server 192.168.2.253
```

This example shows how to configure a remote syslog server at a specified hostname with severity level 5 or higher:

```
switch(config)# logging server syslogA 5
```

Related Commands

Command	Description
show logging server	Displays the configured syslog servers.

logging timestamp

To set the logging time-stamp units, use the **logging timestamp** command. To reset the logging time-stamp units to the default, use the **no** form of this command.

logging timestamp { **microseconds** | **milliseconds** | **seconds** }

no logging timestamp { **microseconds** | **milliseconds** | **seconds** }

Syntax Description	microseconds	Specifies the units to use for logging timestamps in microseconds. The default units are seconds .
	milliseconds	Specifies the units to use for logging timestamps in milliseconds.
	seconds	Specifies the units to use for logging timestamps in seconds. The default units are seconds .
Command Default	None	
Command Modes	Global configuration mode	
Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.
Usage Guidelines	By default, the units are seconds.	
Examples	This example shows how to set the logging time-stamp units to microseconds:	
	<pre>switch(config)# logging timestamp microseconds</pre>	
Related Commands	Command	Description
	show logging timestamp	Displays the logging time-stamp configuration.

■ logging timestamp



M Commands

This chapter describes the system management commands that begin with M.

monitor erspan origin ip-address

To configure the Encapsulated Remote Switched Port Analyzer (ERSPAN) origin IP address, use the **monitor erspan origin ip-address** command. To remove the ERSPAN origin IP address configuration, use the **no** form of this command.

monitor erspan origin ip-address *ip-address* [**global**]

no monitor erspan origin ip-address *ip-address* [**global**]

Syntax Description	<i>ip-address</i>	IP address.
	global	(Optional) Specifies the default virtual device context (VDC) configuration across all VDCs.

Command Default	None
------------------------	------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Usage Guidelines	When you change the origin IP address in the default VDC, it impacts all the sessions.
	This command does not require a license.

Examples	This example shows how to configure the ERSPAN origin IP address:
	<pre>switch# configure terminal switch(config)# monitor erspan origin ip-address 10.1.1.1 global switch(config)#</pre>

This example shows how to remove the ERSPAN IP address:

```
switch# configure terminal
switch(config)# no monitor erspan origin ip-address 10.1.1.1 global
switch(config)#
```

Related Commands	Command	Description
	monitor session	Configures a SPAN or an ERSPAN session.

monitor session

To create a new Ethernet Switched Port Analyzer (SPAN) or an Encapsulated Remote Switched Port Analyzer (ERSPAN) session configuration for analyzing traffic between ports or add to an existing session configuration, use the **monitor session** command. To clear SPAN or ERSPAN sessions, use the **no** form of this command.

monitor session {*session-number* [**shut** | **type** {**local** | **erspan-source**} | **all shut**}

no monitor session {*session-number* | **all**} [**shut**]

Syntax Description

<i>session-number</i>	SPAN session to create or configure. The range is from 1 to 18.
all	Specifies to apply configuration information to all SPAN sessions.
shut	(Optional) Specifies that the selected session will be shut down for monitoring.
type	(Optional) Specifies the type of session to configure.
local	Specifies the session type to be local.
erspan-source	Creates an ERSPAN source session.

Command Default

None

Command Modes

Global configuration mode

Command History

Release	Modification
5.2(1)N1(1)	This command was introduced.

Usage Guidelines

To ensure that you are working with a completely new session, you can clear the desired session number or all SPAN sessions.



Note

The Cisco Nexus 6000 switch supports two active SPAN sessions. The Cisco Nexus 5548 Switch supports four active SPAN sessions. When you configure more than two SPAN sessions, the first two sessions are active. During startup, the order of active sessions is reversed; the last two sessions are active. For example, if you configured ten sessions 1 to 10 where 1 and 2 are active, after a reboot, sessions 9 and 10 will be active. To enable deterministic behavior, explicitly suspend the sessions 3 to 10 with the **monitor session** *session-number* **shut** command.

After you create an ERSPAN session, you can describe the session and add interfaces and VLANs as sources and destinations.

Examples

This example shows how to create a SPAN session:

```
switch# configure terminal
switch(config)# monitor session 2
switch(config)#
```

This example shows how to enter the monitor configuration mode for configuring SPAN session number 9 for analyzing traffic between ports:

```
switch(config)# monitor session 9 type local
switch(config-monitor)# description A Local SPAN session
switch(config-monitor)# source interface ethernet 1/1
switch(config-monitor)# destination interface ethernet 1/2
switch(config-monitor)# no shutdown
```

This example shows how to configure any SPAN destination interfaces as Layer 2 SPAN monitor ports before activating the SPAN session:

```
switch(config)# interface ethernet 1/2
switch(config-if)# switchport
switch(config-if)# switchport monitor
switch(config-if)# no shutdown
```

This example shows how to configure a typical SPAN destination trunk interface:

```
switch(config)# interface Ethernet1/2
switch(config-if)# switchport
switch(config-if)# switchport mode trunk
switch(config-if)# switchport monitor
switch(config-if)# switchport trunk allowed vlan 10-12
switch(config-if)# no shutdown
```

This example shows how to create an ERSPAN session:

```
switch# configure terminal
switch(config)# monitor session 1 type erspan-source
switch(config-erspan-src)#
```

Related Commands

Command	Description
description (SPAN, ERSPAN)	Adds a description to identify the SPAN session.
destination (ERSPAN)	Configures the destination IP port for an ERSPAN packet.
erspan-id (ERSPAN)	Sets the flow ID for an ERSPAN session.
ip dscp (ERSPAN)	Sets the DSCP value for an ERSPAN packet.
ip prec (ERSPAN)	Sets the IP precedence value for an ERSPAN packet.
ip ttl (ERSPAN)	Sets the time-to-live (TTL) value for an ERSPAN packet.
mtu (ERSPAN)	Sets the maximum transmission value (MTU) for ERSPAN packets.
show monitor session	Displays SPAN session configuration information.
source (SPAN, ERSPAN)	Adds a SPAN source port.

mtu

To configure the maximum transmission unit (MTU) truncation size for packets in the specified Ethernet Switched Port Analyzer (SPAN) session, use the **mtu** command. To remove the MTU truncation size configuration, use the **no** form of this command.

mtu *mtu-size*

no mtu

Syntax Description

mtu-size	MTU truncation size. The range is from 64 to 1500.
----------	--

Command Default

Disabled

Command Modes

Monitor configuration (config-monitor)

Supported User Roles

network-admin
vdc-admin

Command History

Release	Modification
5.2(1)N1(1)	This command was introduced.

Usage Guidelines

MTU truncation and the SPAN rate limit cannot be enabled for the same SPAN session. If you configure both for one session, only the rate limit is allowed on F1 Series modules, and MTU truncation is disabled until you disable the rate limit configuration.



Note

MTU turncation is supported only on F1 Series modules and F2 Series modules.

This command does not require a license.

Examples

This example shows how to configure the MTU truncation size for packets in the specified SPAN session:

```
switch# configure terminal
switch(config)# monitor session 5
switch(config-monitor)# mtu 128
switch(config-monitor)#
```

This example shows how to remove the MTU truncation size configuration for packets in the specified SPAN session:

```
switch# configure terminal
```

```
switch(config)# monitor session 5  
switch(config-monitor)# no mtu
```

Related Commands

Command	Description
monitor session	Places you in the monitor configuration mode for configuring a SPAN session.
show monitor session	Displays the status of the SPAN session.



N Commands

This chapter describes the system management commands that begin with N.

ntp

To configure the Network Time Protocol (NTP) peers and servers for the switch, use the **ntp** command. To remove configured peers and servers, use the **no** form of this command.

ntp {**peer** *hostname* | **server** *hostname*} [**prefer**] [**use-vrf** *vrf-name*]

no ntp {**peer** *hostname* | **server** *hostname*}

Syntax Description

peer <i>hostname</i>	Specifies the hostname or IP address of an NTP peer.
server <i>hostname</i>	Specifies the hostname or IP address of the NTP server.
prefer	(Optional) Specifies this peer/server as the preferred peer/server.
use-vrf <i>vrf-name</i>	(Optional) Specifies the virtual routing and forwarding (VRF) used to reach this peer/server.

Command Default

None

Command Modes

Global configuration mode

Command History

Release	Modification
5.2(1)N1(1)	This command was introduced.

Usage Guidelines

You can specify multiple peer associations.

Examples

This example shows how to form a server association with a server:

```
switch(config)# ntp server ntp.cisco.com
```

This example shows how to form a peer association with a peer:

```
switch(config)# ntp peer 192.168.10.0
```

This example shows how to delete an association with a peer:

```
switch(config)# no ntp peer 192.168.10.0
```

Related Commands

Command	Description
ntp distribute	Enables CFS distribution for NTP.
show ntp	Displays NTP information.

ntp abort

To discard the Network Time Protocol (NTP) Cisco Fabric Services (CFS) distribution session in progress, use the **ntp abort** command.

ntp abort

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples	This example shows how to discard the NTP CFS distribution session in progress: <pre>switch(config)# ntp abort</pre>
-----------------	--

Related Commands	Command	Description
	ntp distribute	Enables CFS distribution for NTP.
	show ntp	Displays NTP information.

ntp authenticate

To enable Network Time Protocol (NTP) authentication, use the `ntp authenticate` command. To disable NTP authentication, use the `no` form of this command.

ntp authenticate

no ntp authenticate

Syntax Description This command has no arguments or keywords.

Command Default Disabled

Command Modes Global configuration (config)

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Usage Guidelines This command does not require a license.

Examples This example shows how to enable NTP authentication:

```
switch(config)# ntp authenticate
```

This example shows how to disable NTP authentication:

```
switch(config)# no ntp authenticate
switch(config)#
```

Related Commands	Command	Description
	show ntp authentication-status	Displays the status of NTP authentication.

ntp commit

To apply the pending configuration pertaining to the Network Time Protocol (NTP) Cisco Fabric Services (CFS) distribution session in progress in the fabric, use the **ntp commit** command.

ntp commit

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples	This example shows how to commit changes to the active NTP configuration: <pre>switch(config)# ntp commit</pre>
-----------------	--

Related Commands	Command	Description
	ntp distribute	Enables CFS distribution for NTP.
	show ntp	Displays NTP information.

ntp distribute

To enable Cisco Fabric Services (CFS) distribution for Network Time Protocol (NTP), use the **ntp distribute** command. To disable this feature, use the **no** form of this command.

ntp distribute

no ntp distribute

Syntax Description This command has no arguments or keywords.

Command Default Disabled

Command Modes Global configuration mode

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Usage Guidelines Before distributing the Fibre Channel timer changes to the fabric, the temporary changes to the configuration must be committed to the active configuration using the **ntp commit** command.

Examples This example shows how to distribute the active NTP configuration to the fabric:

```
switch(config)# ntp distribute
```

Related Commands	Command	Description
	ntp commit	Commits the NTP configuration changes to the active configuration.
	show ntp	Displays NTP information.

ntp sync-retry

To retry synchronization with the configured Network Time Protocol (NTP) servers, use the **ntp sync-retry** command.

ntp sync-retry

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples	This example shows how to retry synchronization with the configured NTP servers: <pre>switch# ntp sync-retry</pre>
-----------------	---

Related Commands	Command	Description
	ntp distribute	Enables CFS distribution for NTP.
	show ntp	Displays NTP information.



P Commands

This chapter describes the system management commands that begin with P.

poweroff module

To power off a module, use the **poweroff module** command. To return power to the module, use the **no** form of this command.

poweroff module *module*

no poweroff module *module*

Syntax Description	<i>module</i>	Module number. The range is from 1 to 18.
--------------------	---------------	---

Defaults	None
----------	------

Command Default	Global configuration (config)
-----------------	-------------------------------

SupportedUserRoles	network-admin vdc-admin
--------------------	----------------------------

Command History	Release	Modification
	5.2(1)N1(1)	The command was introduced.

Usage Guidelines	This command does not require a license.
------------------	--

Examples	This example shows how to power off module 2: switch# poweroff module 2
----------	---

Related Commands	Command	Description
	show module	Displays information about modules.

ptp announce

To configure the interval between PTP announcement messages on an interface or the number of PTP intervals before a timeout occurs on an interface, use the **ptp announce** command. To disable this feature, use the **no** form of this command.

ptp announce {**interval** *log-seconds* | **timeout** *count*}

no ptp announce

Syntax Description

interval <i>log-seconds</i>	The number of log seconds between PTP announcement messages. The range is from 0 to 4 seconds.
timeout <i>count</i>	The number of PTP intervals before a timeout occurs on the interface. The range is from 2 to 10.

Command Default

The default interval is 1 log second.
The default timeout is 3 announce intervals.

Command Modes

Interfaces configuration mode

Command History

Release	Modification
5.2(1)N1(1)	This command was introduced.

Examples

This example shows how to set the announcement interval on interface 5/1 to 1:

```
switch# configure terminal
switch(config) # interface ethernet 5/1
switch(config-if) # ptp announce interval 1
switch(config-if)
```

Related Commands

Command	Description
feature ptp	Enables or disables PTP on the device.
ptp delay request minimum interval	Configures the minimum interval allowed between PTP delay-request messages when the port is in the master state.
ptp sync interval	Configures the interval between PTP synchronization messages on an interface.
ptp vlan	Configures the VLAN for the interface where PTP is being enabled.
show ptp brief	Displays the PTP status.
show ptp port interface ethernet	Displays the status of the PTP port on the switch.

ptp delay request minimum interval

To configure the minimum interval allowed between PTP delay request messages when the port is in the master state, use the **ptp delay request minimum interval** command. To disable this feature, use the **no** form of this command.

ptp delay request minimum interval *log-seconds*

no ptp delay request minimum interval

Syntax Description	<i>log-seconds</i>	The number of log seconds between PTP delay request messages. The range is from -1 to 6 seconds.
---------------------------	--------------------	--

Command Default	0 log seconds
------------------------	---------------

Command Modes	Interface configuration mode
----------------------	------------------------------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples This example shows how to set the minimum delay request interval to 3:

```
switch# configure terminal
switch(config) # interface ethernet 5/1
switch(config-if) # ptp delay request minimum interval 3
```

Related Commands	Command	Description
	feature ptp	Enables or disables PTP on the device.
	ptp announce	Configures the interval between PTP announce messages on an interface or the number of PTP intervals before a timeout occurs on an interface.
	ptp sync interval	Configures the interval between PTP synchronization messages on an interface.
	ptp vlan	Configures the VLAN for the interface where PTP is being enabled.
	show ptp brief	Displays the PTP status.
	show ptp port interface ethernet	Displays the status of the PTP port on the switch.

ptp domain

To configure the domain number to use for this clock, use the **ptp domain** command. PTP domains allow you to use multiple independent PTP clocking subdomains on a single network.

ptp domain *number*

no ptp domain *number*

Syntax Description

<i>number</i>	Configures the domain number to use for this clock. The range is from 0 to 128.
---------------	---

Command Default

0

Command Modes

Global configuration mode

Command History

Release	Modification
5.2(1)N1(1)	This command was introduced.

Examples

This example shows how to configure the domain number for use with a clock:

```
switch(config)# ptp domain 1
```

Related Commands

Command	Description
feature ptp	Enables or disables PTP on the device.
ptp source	Configures the source IP address for all PTP packets.
ptp priority1	Configures the priority 1 value to use when advertising this clock.
ptp priority2	Configures the priority 1 value to use when advertising this clock.
show ptp brief	Displays the PTP status.
show ptp clock	Displays the properties of the local clock.

ptp priority1

To configure the priority1 value to use when advertising this clock, use the **ptp priority1** command.

ptp priority1 *value*

no ptp priority1 *value*

Syntax Description

<i>value</i>	The configured value overrides the default criteria (clock quality, clock class, etc.) for best master clock selection. Lower values take precedence. The range is from 0 to 255.
--------------	---

Command Default

255 when advertising the clock

Command Modes

Global configuration mode

Command History

Release	Modification
5.2(1)N1(1)	This command was introduced.

Examples

This example shows how to set the priority1 value used to advertise this clock:

```
switch(config)# ptp priority1 10
```

Related Commands

Command	Description
feature ptp	Enables or disables PTP on the device.
ptp source	Configures the source IP address for all PTP packets.
ptp domain	Configures the domain number to use for this clock.
ptp priority2	Configures the priority2 value to use when advertising this clock.
show ptp brief	Displays the PTP status.
show ptp clock	Displays the properties of the local clock.

ptp priority2

To configure the priority2 value to use when advertising this clock, use the **ptp priority2** command.

ptp priority2 *value*

no ptp priority2 *value*

Syntax Description

<i>value</i>	The configured value is used to decide between two devices that are otherwise equally matched in the default criteria. For example, you can use the priority2 value to give a specific switch priority over other identical switches. The range is from 0 to 255.
--------------	---

Command Default

255 when advertising the clock

Command Modes

Global configuration mode

Command History

Release	Modification
5.2(1)N1(1)	This command was introduced.

Examples

This example shows how to set the priority2 value used to advertise this clock:

```
switch(config)# ptp priority2 20
```

Related Commands

Command	Description
feature ptp	Enables or disables PTP on the device.
ptp source	Configures the source IP address for all PTP packets.
ptp domain	Configures the domain number to use for this clock.
ptp priority1	Configures the priority1 value to use when advertising this clock.
show ptp brief	Displays the PTP status.
show ptp clock	Displays the properties of the local clock.

ptp source

To configure the source IP address for all PTP packets, use the **ptp source** command. To unconfigure the source IP address for all PTP packets, use the **no** form of this command.

ptp source *ip-address* [**vrf** *vrf*]

no ptp source *ip-address* [**vrf** *vrf*]

Syntax Description	<i>ip-address</i>	Specifies the source IP address for all PTP packets. The IP address can be in IPv4 or IPv6 format.
	vrf <i>vrf</i>	Specifies the VRF.

Command Default	None
------------------------	------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples	This example shows how to configure the source IP address for all PTP packets:
	<pre>switch(config)# ptp source 192.0.2.1</pre>

Related Commands	Command	Description
	feature ptp	Enables or disables PTP on the device.
	ptp domain	Configures the domain number to use for this clock.
	ptp priority1	Configures the priority 1 value to use when advertising this clock.
	ptp priority2	Configures the priority 1 value to use when advertising this clock.
	show ptp brief	Displays the PTP status.
	show ptp clock	Displays the properties of the local clock.

ptp sync interval

To configure the interval between PTP synchronization messages, use the **ptp sync interval** command. To disable this feature, use the **no** form of this command.

ptp sync interval *log-seconds*

no ptp sync interval

Syntax Description	<i>log-seconds</i>	The number of log seconds between PTP synchronization messages on an interface. The range is from -3 seconds to 1 second.
---------------------------	--------------------	---

Command Default	None
------------------------	------

Command Modes	Interface configuration mode
----------------------	------------------------------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples This example shows how to set the PTP synchronization interval to -3:

```
switch# configure terminal
switch(config) # interface ethernet 5/1
switch(config-if) # ptp sync interval -3
```

Related Commands	Command	Description
	feature ptp	Enables or disables PTP on the device.
	ptp announce	Configures the interval between PTP announce messages on an interface or the number of PTP intervals before a timeout occurs on an interface.
	ptp delay request minimum interval	Configures the minimum interval allowed between PTP delay-request messages when the port is in the master state.
	ptp vlan	Configures the VLAN for the interface where PTP is being enabled.
	show ptp brief	Displays the PTP status.
	show ptp port interface ethernet	Displays the status of the PTP port on the switch.

ptp vlan

To specify the VLAN for the interface where PTP is being enabled, use the **ptp vlan** command. To disable this feature, use the **no** form of this command.

ptp vlan *vlan-id*

no ptp vlan

Syntax Description	<i>vlan-id</i> The VLAN ID for the interface where PTP is being enabled. The range is from 1 to 4094.	
Command Default	1	
Command Modes	Interface configuration mode	
Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.
Usage Guidelines	PTP can only be enabled on one VLAN on an interface.	
Examples	This example shows how to specify VLAN 10 as the interface where PTP is being enabled:	
	<pre>switch# configure terminal switch(config) # interface ethernet 5/1 switch(config-if) # ptp vlan 10</pre>	
Related Commands	Command	Description
	feature ptp	Enables or disables PTP on the device.
	ptp announce	Configures the interval between PTP announce messages on an interface or the number of PTP intervals before a timeout occurs on an interface.
	ptp delay request minimum interval	Configures the minimum interval allowed between PTP delay-request messages when the port is in the master state.
	ptp sync interval	Configures the interval between PTP synchronization messages on an interface.
	show ptp brief	Displays the PTP status.
	show ptp port interface ethernet	Displays the status of the PTP port on the switch.



S Commands

This chapter describes the system management commands that begin with S.

shut (ERSPAN)

To shut down an Encapsulated Remote Switched Port Analyzer (ERSPAN) session, use the **shut** command. To enable an ERSPAN session, use the **no shut** form of this command.

shut

no shut

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes ERSPAN session configuration mode

Release	Modification
5.2(1)N1(1)	This command was introduced.

Usage Guidelines This command does not require a license.

Examples This example shows how to shut down an ERSPAN session:

```
switch# configure terminal
switch(config)# monitor session 1 type erspan-source
switch(config-erspan-src)# shut
switch(config-erspan-src)#
```

This example shows how to enable an ERSPAN session:

```
switch# configure terminal
switch(config)# monitor session 1 type erspan-source
switch(config-erspan-src)# no shut
switch(config-erspan-src)#
```

Command	Description
monitor session	Enters the monitor configuration mode.
show monitor session	Displays the virtual SPAN or ERSPAN configuration.

snmp-server community

To create Simple Network Management Protocol (SNMP) communities for SNMPv1 or SNMPv2c, use the **snmp-server community** command. To revert to the defaults, sue the **no** form of this command.

snmp-server community *com-name* [**group** *grp-name* | **ro** | **rw** | **use-acl** *acl-name*]

no snmp-server community *com-name* [**group** *grp-name* | **ro** | **rw** | **use-acl** *acl-name*]

Syntax Description	
<i>com-name</i>	SNMP community string. The name can be any alphanumeric string up to 32 characters.
group <i>grp-name</i>	(Optional) Specifies the group to which the community belongs. The name can be a maximum of 32 characters.
ro	(Optional) Specifies read-only access with this community string.
rw	(Optional) Specifies read-write access with this community string.
use-acl <i>acl-name</i>	(Optional) Specifies the access control list (ACL) to filter SNMP requests. The name can be a maximum of 32 characters.

Command Default	None
-----------------	------

Command Modes	Global configuration mode
---------------	---------------------------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Usage Guidelines	You can assign an access list (ACL) to a community to filter incoming SNMP requests. If the assigned ACL allows the incoming request packet, SNMP processes the request. If the ACL denies the request, SNMP drops the request and sends a system message. See the <i>Cisco Nexus 5000 Series NX-OS Security Configuration Guide</i> for more information on creating ACLs. The ACL applies to both IPv4 and IPv6 over UDP and TCP. After creating the ACL, assign the ACL to the SNMP community.
------------------	---

Examples	This example shows how to create an SNMP community string and assign an ACL to the community to filter SNMP requests: <pre>switch(config)# snmp-server community public use-acl my_acl_for_public switch(config)#</pre>
----------	--

Related Commands	Command	Description
	show snmp community	Displays the SNMP community strings.

snmp-server contact

To configure the Simple Network Management Protocol (SNMP) contact (sysContact) information, use the **snmp-server contact** command. To remove the contact information, use the **no** form of this command.

snmp-server contact *[text]*

no snmp-server contact *[text]*

Syntax Description

<i>text</i>	(Optional) String that describes the system contact information. The text can be any alphanumeric string up to 32 characters and cannot contain spaces.
-------------	---

Command Default

No system contact (sysContact) string is set.

Command Modes

Global configuration mode

Command History

Release	Modification
5.2(1)N1(1)	This command was introduced.

Examples

This example shows how to set an SNMP contact:

```
switch(config)# snmp-server contact DialSystemOperatorAtBeeper#1235
switch(config)#
```

This example shows how to remove an SNMP contact:

```
switch(config)# no snmp-server contact DialSystemOperatorAtBeeper#1235
switch(config)#
```

Related Commands

Command	Description
show snmp	Displays information about SNMP.
snmp-server location	Sets the system location string.

snmp-server context

To configure the Simple Network Management Protocol (SNMP) context to logical network entity mapping, use the **snmp-server context** command. To remove the context, use the **no** form of this command.

snmp-server context *context-name* [**instance** *instance-name*] [**vrf** {*vrf-name* | **default** | **management**}] [**topology** *topology-name*]

no snmp-server context *context-name* [**instance** *instance-name*] [**vrf** {*vrf-name* | **default** | **management**}] [**topology** *topology-name*]

Syntax Description

<i>context-name</i>	SNMP context. The name can be any alphanumeric string up to 32 characters.
instance <i>instance-name</i>	(Optional) Specifies a protocol instance. The name can be any alphanumeric string up to 32 characters.
vrf <i>vrf-name</i>	(Optional) Specifies the virtual routing and forwarding (VRF) instance. The name is case sensitive, and can be a maximum of 32 alphanumeric characters.
default	Specifies the default VRF.
management	Specifies the management VRF.
topology <i>topology-name</i>	(Optional) Specifies the topology. The name can be any alphanumeric string up to 32 characters.

Command Default

None

Command Modes

Global configuration mode

Command History

Release	Modification
5.2(1)N1(1)	This command was introduced.

Usage Guidelines

Use the **snmp-server context** command to map between SNMP contexts and logical network entities, such as protocol instances or VRFs.

Examples

This example shows how to map the public1 context to the default VRF:

```
switch(config)# snmp-server context public1 vrf default
switch(config)#
```

Related Commands

Command	Description
show snmp	Displays the SNMP status.
show snmp context	Displays information about SNMP contexts.

snmp-server enable traps

To enable the Simple Network Management Protocol (SNMP) notifications, use the **snmp-server enable traps** command. To disable SNMP notifications, use the **no** form of this command.

snmp-server enable traps

```
[aaa [server-state-change] |
callhome [event-notify | smtp-send-fail] |
entity {entity_fan_status_change | entity_mib_change | entity_module_inserted |
entity_module_removed | entity_module_status_change | entity_power_out_change |
entity_power_status_change | entity_unrecognised_module} |
fcdomain |
fcns |
fcs |
fctrace |
fspf |
license [notify-license-expiry | notify-license-expiry-warning | notify-licensefile-missing |
notify-no-license-for-feature] |
link |
rf [redundancy_framework] |
rmon [fallingAlarm | hcFallingAlarm | hcRisingAlarm | risingAlarm] |
rscn |
snmp [authentication] |
vsan | vtp |
zone [default-zone-behavior-change | merge-failure | merge-success | request-reject1 |
unsupp-mem]]
```

no snmp-server enable traps

```
[aaa [server-state-change] |
callhome [event-notify | smtp-send-fail] |
entity {entity_fan_status_change | entity_mib_change | entity_module_inserted |
entity_module_removed | entity_module_status_change | entity_power_out_change |
entity_power_status_change | entity_unrecognised_module} |
fcdomain |
fcns |
fcs |
fctrace |
fspf |
license [notify-license-expiry | notify-license-expiry-warning | notify-licensefile-missing |
notify-no-license-for-feature] |
link |
rf [redundancy_framework] |
rmon [fallingAlarm | hcFallingAlarm | hcRisingAlarm | risingAlarm] |
rscn |
snmp [authentication] |
vsan | vtp |
zone [default-zone-behavior-change | merge-failure | merge-success | request-reject1 |
unsupp-mem]]
```

Syntax Description

aaa	(Optional) Enables notifications for a AAA server state change.
server-state-change	(Optional) Specifies the AAA server state change.

callhome	(Optional) Enables Cisco Call Home notifications.
event-notify	(Optional) Specifies the Cisco Call Home external event notification.
smtp-send-fail	(Optional) Specifies the SMTP message send fail notification.
entity	(Optional) Enables notifications for a change in the module status, fan status, or power status.
entity_fan_status_change	(Optional) Specifies the entity fan status change.
entity_mib_change	(Optional) Specifies the entity MIB change.
entity_module_inserted	(Optional) Specifies the entity module inserted.
entity_module_removed	(Optional) Specifies the entity module removed.
entity_module_status_change	(Optional) Specifies the entity module status change.
entity_power_out_change	(Optional) Specifies the entity power out change.
entity_power_status_change	(Optional) Specifies the entity power status change.
entity_unrecognised_module	(Optional) Specifies the entity unrecognized module.
fcdomain	(Optional) Enables notifications for the Fibre Channel domain.
fcns	(Optional) Enables notifications for the name server.
fcs	(Optional) Enables notifications for the fabric configuration server.
fctrace	(Optional) Enables notifications for the route to an N port.
fspf	(Optional) Enables notifications for the Fabric Shortest Path First (FSPF).
license	(Optional) Enables notifications for the license manager.
notify-license-expiry	(Optional) Specifies the license expiry notification.
notify-license-expiry-warning	(Optional) Specifies the license expiry warning notification.
notify-licensefile-missing	(Optional) Specifies the license file missing notification.
notify-no-license-for-feature	(Optional) Specifies that a notification is sent when no license needs to be installed for the feature.
link	(Optional) Enables notifications for uplink and downlink interfaces.
rf	(Optional) Enables notifications for the redundancy framework.
redundancy_framework	(Optional) Specifies the Redundancy_Framework (RF) supervisor switchover MIB.
rmon	(Optional) Enables notifications for rising, falling, and high-capacity alarms.
fallingAlarm	(Optional) Specifies the RMON falling alarm.
hcFallingAlarm	(Optional) Specifies the high-capacity RMON falling alarm.
hcRisingAlarm	(Optional) Specifies the high-capacity RMON rising alarm.
risingAlarm	(Optional) Specifies the RMON rising alarm.
rscn	(Optional) Enables RSCN notifications.

snmp	(Optional) Enables SNMP authentication notifications.
authentication	(Optional) Specifies the SNMP authentication trap.
vsan	(Optional) Enables notifications for VSANs.
vtp	(Optional) Enables notifications for a VLAN Trunking Protocol (VTP) domain.
zone	(Optional) Enables zone notifications.
default-zone-behavior-change	(Optional) Specifies the default zone behavior change notification.
merge-failure	(Optional) Specifies the merge failure notification.
merge-success	(Optional) Specifies the merge success notification.
request-reject1	(Optional) Specifies the request reject notification.
unsupp-mem	(Optional) Specifies the unsupported member notification.

Command Default All notifications

Command Modes Global configuration mode

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Usage Guidelines The **snmp-server enable traps** command enables both traps and informs, depending on the configured notification host receivers.

Examples This example shows how to enable SNMP notifications for the server state change:

```
switch(config)# snmp-server enable traps aaa
switch(config)#
```

This example shows how to disable all SNMP notifications:

```
switch(config)# no snmp-server enable traps
switch(config)#
```

Related Commands	Command	Description
	snmp-server enable traps link	Enables the Simple Network Management Protocol (SNMP) notifications on link traps.
	show snmp trap	Displays the SNMP notifications enabled or disabled.

snmp-server enable traps link

To enable the Simple Network Management Protocol (SNMP) notifications on link traps, use the **snmp-server enable traps link** command. To disable SNMP notifications on link traps, use the **no** form of this command.

snmp-server enable traps link *[notification-type]*

no snmp-server enable traps link *[notification-type]*

Syntax Description

<i>notification-type</i>	(Optional) Type of notification to enable. If no type is specified, all notifications available on your device are sent. The notification type can be one of the following keywords: • IETF-extended-linkDown—Enables the Internet Engineering Task Force (IETF) extended link state down notification. • IETF-extended-linkUp—Enables the IETF extended link state up notification. • cisco-extended-linkDown—Enables the Cisco extended link state down notification. • cisco-extended-linkUp—Enables the Cisco extended link state up notification. • connUnitPortStatusChange—Enables the overall status of the connectivity unit Notification. • delayed-link-state-change—Enables the delayed link state change. • fcTrunkIfDownNotify—Enables the Fibre Channel Fabric Element (FCFE) link state down notification. • fcTrunkIfUpNotify—Enables the FCFE link state up notification. • fcot-inserted—Specifies that the Fibre Channel optical transmitter (FCOT) hardware has been inserted. • fcot-removed—Specifies that the FCOT has been removed. • linkDown—Enables the IETF Link state down notification. • linkUp—Enables the IETF Link state up notification.
--------------------------	--

Command Default

Disabled

Command Modes

Global configuration mode

Command History

Release	Modification
5.2(1)N1(1)	This command was introduced.

Usage Guidelines

This command is disabled by default. Most notification types are disabled.

If you enter this command with no *notification-type* arguments, the default is to enable all notification types controlled by this command

Examples

This example shows how to enable the SNMP link trap notification on the switch:

```
switch(config)# snmp-server enable traps link
switch(config)#
```

This example shows how to disable the SNMP link trap notification on the switch:

```
switch(config)# no snmp-server enable traps link
switch(config)#
```

Related Commands

Command	Description
show snmp trap	Displays the SNMP notifications enabled or disabled.

snmp-server globalEnforcePriv

To configure Simple Network Management Protocol (SNMP) message encryption for all users, use the **snmp-server globalEnforcePriv** command. To remove the encryption, use the **no** form of this command.

snmp-server globalEnforcePriv

no snmp-server globalEnforcePriv

Syntax Description

This command has no arguments or keywords.

Command Default

The SNMP agent accepts SNMPv3 messages without authentication and encryption.

Command Modes

Global configuration mode

Command History

Release	Modification
5.2(1)N1(1)	This command was introduced.

Examples

This example shows how to configure SNMP message encryption for all users:

```
switch(config)# snmp-server globalEnforcePriv
switch(config)#
```

This example shows how to remove SNMP message encryption for all users:

```
switch(config)# no snmp-server globalEnforcePriv
switch(config)#
```

Related Commands

Command	Description
snmp-server user	Configures a new user to an SNMP group.
show snmp sessions	Displays the current SNMP sessions.

snmp-server host

To specify the recipient of a Simple Network Management Protocol (SNMP) notification operation, use the **snmp-server host** command. To remove the specified host, use the **no** form of this command.

```
snmp-server host host-address { community-string
| filter-vrf { vrf-name | default | management }
| { informs | traps } { community-string | version { 1 | 2c | 3 { auth | noauth | priv } }
community-string [udp-port port]}
| version { 1 | 2c | 3 { auth | noauth | priv } } community-string [udp-port port]}
```

```
no snmp-server host host-address { community-string
| filter-vrf { vrf-name | default | management }
| { informs | traps } { community-string | version { 1 | 2c | 3 { auth | noauth | priv } }
community-string [udp-port port]}
| version { 1 | 2c | 3 { auth | noauth | priv } } community-string [udp-port port]}
```

Syntax Description

<i>host-address</i>	IPv4 or IPv6 address or DNS name of the SNMP notification host.
<i>community-string</i>	String sent with the notification operation. The string can be a maximum of 32 alphanumeric characters. We recommend that you define this string using the snmp-server community command prior to using the snmp-server host command.
filter-vrf <i>vrf-name</i>	Specifies the virtual routing and forwarding (VRF) instance. The name is case sensitive and can be a maximum of 32 alphanumeric characters.
default	Specifies the default VRF.
management	Specifies the management VRF.
informs	Sends SNMP informs to this host.
traps	Sends SNMP traps to this host.
version	Specifies the version of the SNMP used to send the traps. Version 3 is the most secure model, because it allows packet encryption with the priv keyword. If you use the version keyword, one of the following must be specified: 1—SNMPv1. 2c—SNMPv2C. 3—SNMPv3. The following three optional keywords can follow the version 3 keyword: auth—Enables Message Digest 5 (MD5) and Secure Hash Algorithm (SHA) packet authentication noauth (Default)—The noAuthNoPriv security level. This is the default if the auth, noauth, or priv keyword is not specified. priv—Enables Data Encryption Standard (DES) packet encryption (also called “privacy”)
udp-port <i>port</i>	(Optional) Specifies the UDP port of the host to use. The port range is from 0 to 65535.

Command Default Disabled

Command Modes Global configuration mode

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Usage Guidelines SNMP notifications can be sent as traps or inform requests. Traps are unreliable because the receiver does not send acknowledgments when it receives traps. The sender cannot determine if the traps were received. However, an SNMP entity that receives an inform request acknowledges the message with an SNMP response PDU. If the sender never receives the response, the inform request can be sent again. Therefore, informs are more likely to reach their intended destination.

Examples This example shows how to send the SNMP traps to the host specified by the IPv4 address 192.168.0.10. The community string is defined as my_acl_for_public.:

```
switch(config)# snmp-server community public use-acl my_acl_for_public
switch(config)# snmp-server host 192.168.0.10 my_acl_for_public
switch(config)#
```

This example shows how to send all inform requests to the host myhost.cisco.com using the community string my_acl_for_public:

```
switch(config)# snmp-server enable traps
switch(config)# snmp-server host myhost.cisco.com informs version 2c my_acl_for_public
switch(config)#
```

Related Commands	Command	Description
	show snmp host	Displays information about the SNMP host.

snmp-server location

To set the Simple Network Management Protocol (SNMP) system location string, use the **snmp-server location** command. To remove the location string, use the **no** form of this command.

snmp-server location *text*

no snmp-server location *text*

Syntax Description	<i>text</i> (Optional) String that describes the system location information.
--------------------	---

Command Default	No system location string is set.
-----------------	-----------------------------------

Command Modes	Global configuration mode
---------------	---------------------------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples	This example shows how to set a system location string: <pre>switch(config)# snmp-server location Building 3/Room 21 switch(config)#</pre> This example shows how to remove the system location string: <pre>switch(config)# no snmp-server location Building 3/Room 21 switch(config)#</pre>
----------	---

Related Commands	Command	Description
	snmp-server contact	Sets the SNMP system contact (sysContact) string.

snmp-server mib community-map

To configure a Simple Network Management Protocol (SNMP) context to map to a logical network entity, such as a protocol instance or VRF, use the **snmp-server mib community-map** command. To remove the mapping, use the **no** form of this command.

snmp-server mib community-map *community-string* **context** *context-name*

no snmp-server mib community-map *community-string* **context** *context-name*

Syntax Description

<i>community-string</i>	String sent with the notification operation. The string can be a maximum of 32 alphanumeric characters. We recommend that you define this string using the snmp-server community command prior to using the snmp-server mib community-map command.
context	Specifies the SNMP context to be mapped to the logical network entity.
<i>context-name</i>	SNMP context. The name can be any alphanumeric string up to 32 characters.

Command Default

None

Command Modes

Global configuration mode

Command History

Release	Modification
5.2(1)N1(1)	This command was introduced.

Examples

This example shows how to map an SNMPv2c community named `my_acl_for_public` to an SNMP context `public1`:

```
switch(config)# snmp-server mib community-map my_acl_for_public context public1
switch(config)#
```

This example shows how to remove the mapping of an SNMPv2c community to an SNMP context:

```
switch(config)# no snmp-server mib community-map my_acl_for_public context public1
switch(config)#
```

Related Commands

Command	Description
snmp-server community	Configures an SNMP community.
snmp-server context	Configures an SNMP context.
show snmp	Displays the SNMP status.

snmp-server tcp-session

To enable a one-time authentication for Simple Network Management Protocol (SNMP) over a TCP session, use the **snmp-server tcp-session** command. To disable the one-time authentication, use the **no** form of this command.

snmp-server tcp-session [auth]

no snmp-server tcp-session [auth]

Syntax Description	auth (Optional) Specifies that one-time authentication for SNMP be enabled over the TCP session.
--------------------	---

Command Default	Disabled
-----------------	----------

Command Modes	Global configuration mode
---------------	---------------------------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples This example shows how to enable one-time authentication for SNMP over a TCP session:

```
switch(config)# snmp-server tcp-session auth
switch(config)#
```

This example shows how to disable one-time authentication for SNMP over a TCP session:

```
switch(config)# no snmp-server tcp-session auth
switch(config)#
```

Related Commands	Command	Description
	show snmp	Displays the SNMP status.

snmp-server user

To configure a new user to a Simple Network Management Protocol (SNMP) group, use the **snmp-server user** command. To remove a user from an SNMP group, use the **no** form of this command.

```
snmp-server user username [groupname] [auth {md5 | sha} auth-password [{engineID engine-ID | localizedkey | priv {priv-password | aes-128} }]]
```

```
no snmp-server user
```

Syntax Description

<i>username</i>	Name of the user on the host that connects to the agent. The name can be a maximum of 32 alphanumeric characters.
<i>groupname</i>	(Optional) Name of the group to which the user is associated. The name can be a maximum of 32 alphanumeric characters.
auth	(Optional) Specifies that an authentication level setting will be initiated for the session.
md5	(Optional) Specifies that the HMAC-MD5-96 authentication level be used for the session.
sha	(Optional) Specifies that the HMAC-SHA-96 authentication level be used for the session.
<i>auth-password</i>	(Optional) Authentication password for the user that enables the agent to receive packets from the host. The password can be a maximum of 130 characters.
engineID <i>engine-ID</i>	(Optional) Specifies the SNMP engine ID.
localizedkey	(Optional) Specifies whether the passwords are in localized key format.
priv	(Optional) The option that initiates a privacy authentication level setting session.
<i>priv-password</i>	(Optional) Privacy password for the user that enables the host to encrypt the content of the message that it sends to the agent. The password can be a maximum of 130 characters.
aes-128	(Optional) Specifies that a 128-bit AES algorithm for privacy be used for the session.

Command Default

None

Command Modes

Global configuration mode

Command History

Release	Modification
5.2(1)N1(1)	This command was introduced.

Examples

This example shows how to configure an SNMP user named authuser with authentication and privacy parameters:

```
switch(config)# snmp-server user authuser publicsecurity auth sha shapwd priv aes-128
switch(config)#
```

This example shows how to delete an SNMP user:

```
switch(config)# no snmp-server user authuser
switch(config)#
```

Related Commands

Command	Description
<code>show snmp user</code>	Displays information about one or more SNMP users.

snmp trap link-status

To enable Simple Network Management Protocol (SNMP) link trap generation on an interface, use the **snmp trap link-status** command. To disable SNMP link traps, use the **no** form of this command.

snmp trap link-status

no snmp trap link-status

Syntax Description This command has no arguments or keywords.

Command Default Enabled

Command Modes Interface configuration mode
Virtual Ethernet interface configuration mode

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Usage Guidelines By default, SNMP link traps are sent when a Layer 2 interface goes up or down. You can disable SNMP link trap notifications on an individual interface. You can use these limit notifications on a flapping interface (an interface that transitions between up and down repeatedly).

You can use this command on the following interfaces:

- Layer 2 interface
- Layer 3 interface



Note Use the **no switchport** command to configure an interface as a Layer 3 interface.

- Virtual Ethernet interface

Examples This example shows how to disable SNMP link-state traps for a specific Layer 2 interface:

```
switch(config)# interface ethernet 1/1
switch(config-if)# no snmp trap link-status
switch(config-if)#
```

This example shows how to enable SNMP link-state traps for a specific Layer 3 interface:

```
switch(config)# interface ethernet 1/5
switch(config-if)# no switchport
switch(config-if)# snmp trap link-status
switch(config-if)#
```

This example shows how to enable SNMP link-state traps for a specific Layer 2 interface:

```
switch(config)# interface ethernet 1/1
switch(config-if)# snmp trap link-status
switch(config-if)#
```

This example shows how to enable SNMP link-state traps for a specific virtual Ethernet interface:

```
switch(config)# interface vethernet 1
switch(config-if)# snmp trap link-status
switch(config-if)#
```

Related Commands

Command	Description
interface vethernet	Configures a virtual Ethernet interface.
no switchport	Configures an interface as a Layer 3 routed interface.
show snmp trap	Displays the SNMP notifications, enabled or disabled.

source (SPAN, ERSPAN)

To add an Ethernet Switched Port Analyzer (SPAN) or an Encapsulated Remote Switched Port Analyzer (ERSPAN) source port, use the **source** command. To remove the source SPAN or ERSPAN port, use the **no** form of this command.

```
source {interface {ethernet slot[/QSFP-module/]port | port-channel channel-num | vethernet
veth-num} [{both | rx | tx}] | vlan vlan-num | vsan vsan-num}
```

```
no source {interface {ethernet slot[/QSFP-module/]port | port-channel channel-num | vethernet
veth-num} | vlan vlan-num | vsan vsan-num}
```

Syntax Description

interface	Specifies the interface type to use as the source SPAN port.
ethernet <i>slot</i> [/ <i>QSFP-module</i> /] <i>port</i>	Specifies the Ethernet interface to use as the source SPAN port. The slot number is from 1 to 255. The <i>QSFP-module</i> number is from 1 to 4. The port number is from 1 to 128. Note The <i>QSFP-module</i> number applies only to the QSFP+ Generic Expansion Module (GEM).
port-channel <i>channel-num</i>	Specifies the EtherChannel interface to use as the source SPAN port. The EtherChannel number is from 1 to 4096.
vethernet <i>veth-num</i>	Specifies the virtual Ethernet interface to use as the source SPAN or ERSPAN port. The virtual Ethernet interface number is from 1 to 1048575.
both	(Optional) Specifies both ingress and egress traffic on the source port. Note This keyword applies to the ERSPAN source port.
rx	(Optional) Specifies only ingress traffic on the source port. Note This keyword applies to the ERSPAN source port.
tx	(Optional) Specifies only egress traffic on the source port. Note This keyword applies to the ERSPAN source port.
vlan <i>vlan-num</i>	Specifies the VLAN interface to use as the source SPAN port. The range is from 1 to 3967 and 4048 to 4093.
vsan <i>vsan-num</i>	Specifies the virtual storage area network (VSAN) to use as the source SPAN port. The range is from 1 to 4093.

Command Default

None

Command Modes

SPAN session configuration mode
ERSPAN session configuration mode

Command History

Release	Modification
6.0(2)N1(2)	Support for the QSFP+ GEM was added.
5.2(1)N1(1)	This command was introduced.

Usage Guidelines

A source port (also called a *monitored port*) is a switched port that you monitor for network traffic analysis. In a single local SPAN session, you can monitor source port traffic such as received (Rx), transmitted (Tx), or bidirectional (both).

A source port can be an Ethernet port, port channel, SAN port channel, VLAN, or a VSAN port. It cannot be a destination port.

For ERSPAN, if you do not specify **both**, **rx**, or **tx**, the source traffic is analyzed for both directions.

Examples

This example shows how to configure an Ethernet SPAN source port:

```
switch# configure terminal
switch(config)# monitor session 9 type local
switch(config-monitor)# description A Local SPAN session
switch(config-monitor)# source interface ethernet 1/1
switch(config-monitor)#
```

This example shows how to configure a port channel SPAN source:

```
switch# configure terminal
switch(config)# monitor session 2
switch(config-monitor)# source interface port-channel 5
switch(config-monitor)#
```

This example shows how to configure an ERSPAN source port to receive traffic on the port:

```
switch# configure terminal
switch(config)# monitor session 1 type erspan-source
switch(config-erspan-src)# source interface ethernet 1/5 rx
switch(config-erspan-src)#
```

Related Commands

Command	Description
destination (SPAN, ERSPAN)	Configures a destination SPAN port.
monitor session	Creates a new SPAN session configuration.
show monitor session	Displays SPAN session configuration information.
show running-config monitor	Displays the running configuration information of a SPAN session.

switchport monitor rate-limit

To configure a rate limit to monitor traffic on an interface, use the **switchport monitor rate-limit** command. To remove a rate limit, use the **no** form of this command.

switchport monitor rate-limit 1G

no switchport monitor rate-limit [1G]

Syntax Description	1G (Optional) Specifies that the rate limit is 1 GB.	
Command Default	None	
Command Modes	Interface configuration mode	
Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.
Usage Guidelines	This command is applicable to the following Cisco Nexus 5000 Series switches: • Cisco Nexus 5010 Series • Cisco Nexus 5020 Series This command does not require a license.	
Examples	This example shows how to limit the bandwidth on Ethernet interface 1/2 to 1 GB: <pre>switch(config)# interface ethernet 1/2 switch(config-if)# switchport monitor rate-limit 1G switch(config-if)#</pre>	
Related Commands	Command	Description
	show interface switchport	Displays information on all interfaces configured as switch ports.
	switchport private-vlan association trunk	Associates the isolated trunk port with the primary and secondary VLANs of a private VLAN.

switch-profile

To create or configure a switch profile, use the **switch-profile** command. To delete a switch profile, use the **no** form of this command.

switch-profile *sw-profile-name*

no switch-profile *sw-profile-name* { **all-config** | **local-config** | **profile-only** }

Syntax Description	<i>sw-profile-name</i>	Name of the switch profile. The name is case sensitive, can be a maximum of 64 alphanumeric characters and can include an underscore and hyphen. The name cannot contain spaces or special characters.
	all-config	Specifies that the switch profile be deleted with all local and peer configurations.
	local-config	Specifies that the switch profile and all local configurations be deleted.
	profile-only	Specifies that the switch profile only is to be deleted and no other configurations.

Command Default	None
------------------------	------

Command Modes	Configuration synchronization mode
----------------------	------------------------------------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Usage Guidelines

Use this command to create a switch profile on each of the peer switches. You must use the same profile name on both the switches in the Cisco Fabric Services (CFS) peer configuration.

You can configure only one active switch profile on each peer switch. If you create or configure a second switch profile, you see the following error message:

```
Error: Another switch profile already exists. Cannot configure more than one switch-profile.
```

The configuration that is made locally on the switch is synchronized and made available on the peer switch only after the connectivity is established between the peer switches and the configuration is verified and committed on the local switch.

You can configure a switch profile to include the interface configuration, quality of service (QoS), and virtual port channel (vPC) commands. FCoE commands are not supported on a switch profile.

When you delete a switch profile, you can choose to delete the local switch profile with the local configurations on the switch, delete the switch profile with the local configurations and configuration information in the peer, or delete the switch profile only while saving all other configuration information. The peer becomes unreachable.

Examples

This example shows how to create a switch profile named s5010 on switch 1 of the peer:

Peer A

```
switch# configure terminal
switch(config)# cfs ipv4 distribute
switch(config)# exit
switch# config sync
Enter configuration commands, one per line. End with CNTL/Z.
switch(config-sync)# switch-profile s5010
Switch-Profile started, Profile ID is 1
switch(config-sync-sp)#
```

This example shows how to create a switch profile named s5010 on switch 2 of the peer:

Peer B

```
switch# configure terminal
switch(config)# cfs ipv4 distribute
switch(config)# exit
switch# config sync
Enter configuration commands, one per line. End with CNTL/Z.
switch(config-sync)# switch-profile s5010
Switch-Profile started, Profile ID is 1
switch(config-sync-sp)#
```

This example shows how to delete a switch profile named s5010 and its local configuration on switch 1 of the peer:

Peer A

```
switch# config sync
Enter configuration commands, one per line. End with CNTL/Z.
switch(config-sync)# no switch-profile s5010 local-config
switch(config-sync)#
```

Related Commands

Command	Description
config sync	Enters configuration synchronization mode.
show switch-profile	Displays the switch profile created on the switch and its configuration revision.
sync-peers destination	Configures the peer switch for configuration synchronization.



Show Commands

This chapter describes the system management **show** commands.

show diagnostic bootup level

To display the current bootup diagnostic level on the switch, use the **show diagnostic bootup level** command.

show diagnostic bootup level

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples This example shows how to display the current bootup diagnostic level:

```
switch# show diagnostic bootup level

Current bootup diagnostic level: complete

switch#
```

Related Commands	Command	Description
	diagnostic bootup level	Configures the bootup diagnostic level for a faster module bootup time.
	show diagnostic result	Displays the results of the diagnostics tests.

show diagnostic result

To display the results of the diagnostic tests, use the **show diagnostic result** command.

show diagnostic result module {*module-no* | **all**}

Syntax Description	module	Specifies the module for which diagnostic results are displayed.
	<i>module-no</i>	Module number. Valid values are 1 to 3.
	all	Displays the diagnostic results for all modules.

Command Default	None
-----------------	------

Command Modes	EXEC mode
---------------	-----------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples

This example shows how to display the diagnostic results for a specific module:

```
switch# show diagnostic result module 1
```

```
Current bootup diagnostic level: complete
```

```
Module 1: 48X10GE/Supervisor SerialNo : JAF1339ANGH
```

```
Overall Diagnostic Result for Module 1 : PASS
```

```
Diagnostic level at card bootup: complete
```

```
Test results: (. = Pass, F = Fail, I = Incomplete,
               U = Untested, A = Abort)
```

```

1) TestUSBFlash -----> .
2) TestSPROM -----> .
3) TestPCIE -----> .
4) TestLED -----> .
5) TestOBFL -----> .
6) TestNVRAM -----> .
7) TestPowerSupply -----> F
8) TestTemperatureSensor -----> .
9) TestFan -----> .
10) TestVoltage -----> .
11) TestGPIO -----> .
12) TestInbandPort -----> .
13) TestManagementPort -----> .
14) TestMemory -----> .
15) TestFabricEngine :
```

```

Eth      1  2  3  4  5  6  7  8  9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24
Port -----
      .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .
```

```

Eth   25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48
Port  -----
      . . . . . . . . . . . . . . . . . . . . . . . . . . . .

```

16) TestFabricPort :

```

Eth   1  2  3  4  5  6  7  8  9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24
Port  -----
      . . . . . . . . . . . . . . . . . . . . . . . . . . . .

```

```

Eth   25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48
Port  -----
      . . . . . . . . . . . . . . . . . . . . . . . . . . . .

```

17) TestForwardingEngine :

```

Eth   1  2  3  4  5  6  7  8  9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24
Port  -----
      . . . . . . . . . . . . . . . . . . . . . . . . . . . .

```

```

Eth   25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48
Port  -----
      . . . . . . . . . . . . . . . . . . . . . . . . . . . .

```

18) TestForwardingEnginePort :

```

Eth   1  2  3  4  5  6  7  8  9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24
Port  -----
      . . . . . . . . . . . . . . . . . . . . . . . . . . . .

```

```

Eth   25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48
Port  -----
      . . . . . . . . . . . . . . . . . . . . . . . . . . . .

```

19) TestFrontPort :

```

Eth   1  2  3  4  5  6  7  8  9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24
Port  -----
      . . . . . . . . . . . . . . . . . . . . . . . . . . . .

```

```

Eth   25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48
Port  -----
      . . . . . . . . . . . . . . . . . . . . . . . . . . . .

```

switch#

Related Commands

Command	Description
diagnostic bootup level	Configures the bootup diagnostic level for a faster module bootup time.
show diagnostic bootup level	Displays the bootup diagnostics level.

show hosts

To display the Domain Name Server (DNS) name servers and domain names, use the **show hosts** command.

show hosts

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples This example shows how to display the IP addresses of the DNS servers that are used to resolve host names:

```
switch# show hosts
```

```
DNS lookup enabled
```

```
Default domain for vrf:default is mysite.com
```

```
Name/address lookup uses domain service
```

```
Name servers are 255.255.255.255
```

Vrf	Use-vrf	Token	Config
default	management	domain	mysite.com
default	management	add. domain(s)	mysite2.com
Host	Address		
switch#			

Related Commands	Command	Description
	ip domain-list	Defines a list of domains.
	ip domain lookup	Enables DNS-based host name-to-address translation.
	ip domain-name	Configures a name server.

show ip dns source-interface

To display the source interfaces configured for Domain Name Server (DNS) domain lookup, use the **show ip dns source-interface** command.

show ip dns source-interface [**vrf** {*vrf-name* | **all** | **default** | **management**}]

Syntax Description	vrf	(Optional) Displays information about the virtual routing and forwarding (VRF) instance.
	<i>vrf-name</i>	(Optional) VRF name. The name is case sensitive and can be a maximum of 32 characters.
	all	(Optional) Displays all VRF instances.
	default	(Optional) Displays the default VRF information.
	management	(Optional) Displays the management VRF information.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Usage Guidelines This command does not require a license.

Examples This example shows how to display the source interfaces configured for DNS domain lookup:

```
switch# show ip dns source-interface
VRF Name      Interface
default       Ethernet1/5
switch#
```

Related Commands	Command	Description
	ip domain-lookup	Enables the DNS lookup feature.
	ip dns source-interface	Configures interfaces for DNS domain lookup.

show logging console

To display the console logging configuration, use the **show logging console** command.

show logging console

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples	This example shows how to display the console logging configuration: <pre>switch# show logging console</pre>
-----------------	---

Related Commands	Command	Description
	logging console	Configures logging to the console.

show logging info

To display the logging configuration, use the **show logging info** command.

show logging info

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples	This example shows how to display the logging configuration:
	switch# show logging info

Related Commands	Command	Description
	logging level	Enables logging messages from a defined facility.

show logging last

To display the last number of lines of the logfile, use the **show logging last** command.

show logging last *number*

Syntax Description	<i>number</i>	Enters the number of lines to display from 1 to 9999.
Command Default	None	
Command Modes	EXEC mode	
Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.
Examples	This example shows how to display the last 42 lines of the log file: <pre>switch# show logging last 42</pre>	
Related Commands	Command	Description
	logging level	Enables logging messages from a defined facility.

show logging level

To display the facility logging severity level configuration, use the **show logging level** command.

show logging level [*facility*]

Syntax Description	<i>facility</i>	(Optional) Logging facility. The facilities are listed in Table A-1 of Appendix A, “System Message Logging Facilities.”
Command Default	None	
Command Modes	EXEC mode	
Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples

This example shows how to display the EtherChannel logging severity level configuration:

```
switch# show logging level port-channel
```

This example shows how to display the Flex Links logging severity level configuration:

```
switch# show logging level flexlink
Facility          Default Severity    Current Session Severity
-----
Flexlink          2                   5

0 (emergencies)   1 (alerts)          2 (critical)
3 (errors)        4 (warnings)        5 (notifications)
6 (information)   7 (debugging)
```

switch#

This example shows how to display the FCoE NPV logging severity level configuration:

```
switch# show logging level fcoe_mgr
Facility          Default Severity    Current Session Severity
-----
fcoe_mgr          2                   3

0 (emergencies)   1 (alerts)          2 (critical)
3 (errors)        4 (warnings)        5 (notifications)
6 (information)   7 (debugging)
```

switch#

Related Commands

Command	Description
logging level	Configures the facility logging level.

show logging logfile

To display the messages in the log file that were timestamped within the span entered, use the **show logging logfile** command.

show logging logfile [**start-time** yyyy mmm dd hh:mm:ss] [**end-time** yyyy mmm dd hh:mm:ss]

Syntax Description

start-time yyyy mmm dd hh:mm:ss	(Optional) Specifies a start time in the format yyyy mmm dd hh:mm:ss. Use three characters for the month (<i>mmm</i>) field, digits for the year (yyyy) and day (<i>dd</i>) fields, and digits separated by colons for the time (<i>hh:mm:ss</i>) field.
end-time yyyy mmm dd hh:mm:ss	(Optional) Specifies an end time in the format yyyy mmm dd hh:mm:ss. Use three characters for the month (<i>mmm</i>) field, digits for the year (yyyy) and day (<i>dd</i>) fields, and digits separated by colons for the time (<i>hh:mm:ss</i>) field.

Command Default

None

Command Modes

EXEC mode

Command History

Release	Modification
5.2(1)N1(1)	This command was introduced.

Usage Guidelines

If you do not enter an end time, the current time is used.

Examples

This example shows how to display the messages in the log file that were timestamped within the span shown:

```
switch# show logging logfile start-time 2008 mar 11 12:10:00
```

Related Commands

Command	Description
logging logfile	Configures logging to a log file.

show logging module

To display the module logging configuration, use the **show logging module** command.

show logging module

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples	This example shows how to display the module logging configuration: <pre>switch# show logging module</pre>
-----------------	---

Related Commands	Command	Description
	logging module	Configures module logging.

show logging monitor

To display the monitor logging configuration, use the **show logging monitor** command.

show logging monitor

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples	This example shows how to display the monitor logging configuration: <pre>switch# show logging monitor</pre>
-----------------	---

Related Commands	Command	Description
	logging monitor	Configures logging on the monitor.

show logging nvram

To display the messages in the nonvolatile random access memory (NVRAM) log, use the **show logging nvram** command.

show logging nvram [**last** *number-lines*]

Syntax Description	last <i>number-lines</i> (Optional) Specifies the number of lines to display. The number of lines is from 1 to 100.
--------------------	--

Command Default	None
-----------------	------

Command Modes	EXEC mode
---------------	-----------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples	This example shows how to display the last 20 messages in the NVRAM log: switch# show logging nvram last 20
----------	---

Related Commands	Command	Description
	logging level	Enables logging messages from a defined facility.

show logging onboard

To display the onboard logging information based on the error type, use the **show logging onboard** command.

```
show logging onboard { boot-uptime | device-version | endtime | environmental-history |
exception-log | kernel-trace | obfl-history | obfl-logs | stack-trace | starttime | status } [> file
| | type]
```

Syntax Description	
boot-uptime	Displays the onboard failure logging (OBFL) boot and uptime information.
device-version	Displays the OBFL device version information.
endtime	Displays the OBFL logs until the specified end time in the following format: <i>mm/dd/yy-HH:MM:SS</i>
environmental-history	Displays the OBFL environmental history.
exception-log	Displays the OBFL exception log.
kernel-trace	Displays the OBFL kernel trace information.
obfl-history	Displays the OBFL history information.
obfl-logs	Displays the OBFL technical support log information.
stack-trace	Displays the OBFL kernel stack trace information.
starttime	Displays the OBFL logs from the specified start time in the following format: <i>mm/dd/yy-HH:MM:SS</i>
status	Displays the OBFL status enable or disable.
> file	(Optional) Redirects the output to a file. See the “Usage Guidelines” section for additional information.
 type	(Optional) Filters the output. See the “Usage Guidelines” section for additional information.

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Usage Guidelines

The date and time arguments for the **starttime** and **endtime** keywords are entered as the date month/day/year (*mm/dd/yy*), followed by a hyphen, and the time in 24-hour format in hours:minutes:seconds (*HH:MM:SS*). For example:

- **starttime** 03/17/08-15:01:57
- **endtime** 03/18/08-15:04:57

The valid values for *file* are as follows:

- **bootflash:**
- **ftp:**
- **scp:**
- **sftp:**
- **tftp:**
- **volatile:**

The valid values for *type* are as follows:

- **begin [-i] [-x] [word]**—Begin with the line that matches the text.
 - **-i**—Ignores the case difference when comparing the strings.
 - **-x**—Prints only the lines where the match is a whole line.
 - *word*—Specifies for the expression.
- **count [> file | | type]**—Counts number of lines.
- **egrep | grep print-match**—Egrep or Grep. Egrep searches for lines of text that match more sophisticated regular expression syntax than grep. Grep searches for lines of text that match one or many regular expressions, and outputs only the matching lines.
 - **-A num**—Prints the specifies number of lines of context after every matching line. Range: 1 to 999.
 - **-B num**—Prints the specifies number of lines of context before every matching line. Range: 1 to 999.
 - **-c**—Prints a total count of matching lines only.
 - **-i**—Ignores the case difference when comparing the strings.
 - **-n**—Prints each match preceded by its line number.
 - **-v**—Prints only the lines that contain no matches for the *word* argument.
 - **-w**—Prints only lines where the match is a complete word.
 - **-x**—Prints only the lines where the match is a whole line.
 - *word*—Specifies for the expression.
- **exclude [-i] [-x] [word]**—Excludes the lines that match.
 - **-i**—Ignores the case difference when comparing the strings.
 - **-x**—Prints only the lines where the match is a whole line.
 - *word*—Specifies for the expression.
- **head [-n num]**—Stream Editor. The optional **-n num** keyword and argument allow you to specify the number of lines to print. Range: 0 to 2147483647.
- **include [-i] [-x] [word]**—Include the lines that match.
 - **-i**—Ignores the case difference when comparing the strings.
 - **-x**—Prints only the lines where the match is a whole line.
 - *word*—Specifies for the expression.
- **last [num]**—Displays the last lines to print. The optional *num* specifies the number of lines to print. Range: 0 to 9999.
- **less [-E | -d]**—Quits at the end of the file.

- **-E**—(Optional) Quits at the end of the file.
- **-d**—(Optional) Specifies a dumb terminal.
- **no-more**—Turns-off pagination for command output.
- **sed *command***—Stream Editor
- **wc**—Counts words, lines, and characters.
 - **-c**—(Optional) Specifies the output character count.
 - **-l**—(Optional) Specifies the output line count.
 - **-w**—(Optional) Specifies the output word count.
 - **>**—Redirects it to a file.
 - **|**—Pipes command output to filter.

Use this command to view OBFL data from the system hardware. The OBFL feature is enabled by default and records operating temperatures, hardware uptime, interrupts, and other important events and messages that can assist with diagnosing problems with hardware cards or modules installed in a Cisco router or switch. Data is logged to files stored in nonvolatile memory. When the onboard hardware is started up, a first record is made for each area monitored and becomes a base value for subsequent records.

The OBFL feature provides a circular updating scheme for collecting continuous records and archiving older (historical) records, ensuring accurate data about the system. Data is recorded in one of two formats: continuous information that displays a snapshot of measurements and samples in a continuous file, and summary information that provides details about the data being collected. The message “No historical data to display” is seen when historical data is not available.

Examples

This example shows how to display the OBFL boot and uptime information:

```
switch# show logging onboard boot-uptime
```

```
-----
OBFL Data for
Module: 0
-----
```

```
Sun Dec 16 16:03:39 2012: Boot Record
```

```
-----
Boot Time.....: Sun Dec 16 16:03:39 2012
Module Number.....: 1
Serial Number.....: FOC16191MQ1
Bios Version.....:
Firmware Version...:
```

```
Sun Dec 16 16:44:08 2012: Boot Record
```

```
-----
Boot Time.....: Sun Dec 16 16:44:07 2012
Module Number.....: 0
Serial Number.....: FOC16192WJZ
Bios Version.....: v1.2.0(06/09/12)
Firmware Version...: 6.0(2)N1(1) [build 6.0(2)N1(0.365.5P)]
--More--
```

Table 1 describes the significant fields shown in the display.

Table 1 *show logging onboard boot-uptime Command Output*

Field	Description
Boot Time	Time boot occurred.
Slot Number	Slot number.
Serial Number	Serial number of the module.
Bios Version	Primary binary input and output system (BIOS) version.
Firmware Version	Firmware version.

This example shows how to display the OBFL logging device information:

```
switch# show logging onboard device-version
```

```
-----
OBFL Data for
  Module: 1
-----

Device Version Record
-----
Timestamp                Device Name      Instance Hardware Software
                        Num   Version   Version
-----
Sun Nov 3 07:07:00 2008  GATOS          2         2         0
Sun Nov 3 07:07:00 2008  GATOS          3         2         0
Sun Nov 3 07:07:00 2008  GATOS          4         2         0
Sun Nov 3 07:07:00 2008  GATOS          5         2         0
Sun Nov 3 07:07:00 2008  GATOS          6         2         0
Sun Nov 3 07:07:00 2008  GATOS          7         2         0
Sun Nov 3 07:07:00 2008  GATOS          8         2         0
Sun Nov 3 07:07:00 2008  GATOS          9         2         0
Sun Nov 3 07:07:00 2008  GATOS         10         2         0
Sun Nov 3 07:07:00 2008  GATOS         11         2         0
Sun Nov 3 07:07:00 2008  GATOS         12         2         0
Sun Nov 3 07:07:00 2008  GATOS         13         2         0
Mon Nov 4 00:15:08 2008  ALTOS          0         2         0
Mon Nov 4 00:15:08 2008  GATOS          0         2         0
Mon Nov 4 00:15:08 2008  GATOS          1         2         0
Mon Nov 4 00:15:08 2008  GATOS          2         2         0
```

Table 2 describes the significant fields shown in the display.

Table 2 *show logging onboard device-version Command Output*

Field	Description
Timestamp	Day, date, and time.
Device Name	Device name.
Instance Num	Number of instances.
Hardware Version	Hardware device version.
Software Version	Software device version.

This example shows how to display the OBFL history information:

```
switch# show logging onboard obfl-history
```

The **show logging onboard obfl-history** command displays the following information:

- Timestamp when OBFL is manually disabled.
- Timestamp when OBFL is manually enabled.
- Timestamp when OBFL data is manually cleared.

This example shows how to display the OBFL kernel stack trace information:

```
switch# show logging onboard stack-trace
```

The **show logging onboard stack-trace** command displays the following information:

- Time in seconds
- Time in microseconds
- Error description string
- Current process name and identification
- Kernel jiffies
- Stack trace

Related Commands

Command	Description
clear logging onboard	Clears the OBFL entries in the persistent log.
hw-module logging onboard	Enables or disabled OBFL entries based on the error type.

show logging pending

To display the pending changes to the syslog server configuration, use the **show logging pending** command.

show logging pending

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples	This example shows how to display the pending changes to the syslog server configuration:
	<pre>switch# show logging pending switch#</pre>

Related Commands	Command	Description
	logging abort	Cancels the pending changes to the syslog server configuration.

show logging pending-diff

To display the differences from the current syslog server configuration to the pending changes of the syslog server configuration, use the **show logging pending-diff** command.

show logging pending-diff

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples This example shows how to display the pending differences of the syslog server configuration:

```
switch# show logging pending-diff
switch#
```

Related Commands	Command	Description
	logging abort	Cancels the pending changes to the syslog server configuration.

show logging session status

To display the logging session status, use the **show logging session status** command.

show logging session status

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples	This example shows how to display the logging session status: <pre>switch# show logging session status</pre>
-----------------	---

Related Commands	Command	Description
	logging level	Enables logging messages from a defined facility.

show logging server

To display the syslog server configuration, use the **show logging server** command.

show logging server

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples This example shows how to display the syslog server configuration:

```
switch# show logging server
```

Related Commands	Command	Description
	logging server	Configures a remote syslog server.

show logging status

To display the logging status, use the **show logging status** command.

show logging status

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples	This example shows how to display the logging status:
-----------------	---

<pre>switch# show logging status Fabric Distribute : Enabled Session State : IDLE switch#</pre>
--

Related Commands	Command	Description
	logging distribute	Enables the distribution of the syslog server configuration to network switches using the Cisco Fabric Services (CFS) infrastructure.

show logging timestamp

To display the logging time-stamp configuration, use the **show logging timestamp** command.

show logging timestamp

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples	This example shows how to display the logging time-stamp configuration: <pre>switch# show logging timestamp</pre>
-----------------	--

Related Commands	Command	Description
	logging timestamp	Configures the logging time stamp granularity.

show monitor session

To display information about the Switched Port Analyzer (SPAN) or Encapsulated Remote Switched Port Analyzer (ERSPAN) sessions, use the **show monitor session** command.

show monitor session [*session* | **all** [**brief**] | **range** *range* [**brief**] | **status**]

Syntax Description

<i>session</i>	(Optional) Number of the session. The range is from 1 to 18.
all	(Optional) Displays all sessions.
brief	(Optional) Displays a brief summary of the information.
range <i>range</i>	(Optional) Displays a range of sessions. The range is from 1 to 18.
status	(Optional) Displays the operational state of all sessions.
Note This keyword applies only to SPAN sessions.	

Command Default

None

Command Modes

EXEC mode

Command History

Release	Modification
5.2(1)N1(1)	This command was introduced.

Examples

This example shows how to display information about SPAN session 1:

```
switch# show monitor session 1
session 1
-----
description      : A Local SPAN session
type             : local
state            : down (No operational src/dst)
source intf      :
    rx           : Eth1/5
    tx           : Eth1/5
    both         : Eth1/5
source VLANs     :
    rx           :
source VSANs     :
    rx           :
destination ports : Eth1/21

Legend: f = forwarding enabled, l = learning enabled

switch#
```

This example shows how to display a brief information about a SPAN session:

```
switch# show monitor session range 1 brief
session 1
-----
```

show monitor session

```

description      : A Local SPAN session
type             : local
state           : down (No operational src/dst)
source intf      :
    rx           : Eth1/5
    tx           : Eth1/5
    both         : Eth1/5
source VSANs     :
destination ports : Eth1/21

```

Legend: f = forwarding enabled, l = learning enabled

switch#

This example shows how to display the information about an ERSPAN session:

```

switch# show monitor session 1
session 1
-----
description      : ERSPAN Source configuration
type             : erspan-source
state           : down (No valid global IP Address)
flow-id         : 1
vrf-name        : default
destination-ip   : 192.0.2.1
ip-ttl          : 255
ip-dscp         : 0
origin-ip       : origin-ip not specified
source intf      :
    rx           : Eth1/5
    tx           : Eth1/5
    both         : Eth1/5
source VLANs     :
    rx           : 5
switch#

```

Related Commands

Command	Description
monitor session	Creates a new Switched Port Analyzer (SPAN) session configuration.
show running-config monitor	Displays the running configuration information about SPAN sessions.

show ntp authentication-status

To display the status of the Network Time Protocol (NTP) authentication, use the **show ntp authentication-status** command.

show ntp authentication-status

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Any command mode
----------------------	------------------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples	This example shows how to display the authentication status for NTP: <pre>switch(config)# show ntp authentication-status</pre>
-----------------	--

Related Commands	Command	Description
	[no] ntp authenticate	Displays information about NTP peers.

show ntp peer-status

To display the status of the Network Time Protocol (NTP) peers, use the **show ntp peer-status** command.

show ntp peer-status

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples This example shows how to display the peer status for NTP:

```
switch(config)# show ntp peer-status
```

Related Commands	Command	Description
	show ntp peers	Displays information about NTP peers.

show ntp peers

To display information about Network Time Protocol (NTP) peers, use the **show ntp peers** command.

show ntp peers

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples	This example shows how to display information about NTP peers: <pre>switch(config)# show ntp peers</pre>
-----------------	--

Related Commands	Command	Description
	show ntp peer-status	Displays status information about NTP peers.

show ntp statistics

To display Network Time Protocol (NTP) statistics, use the **show ntp statistics** command.

show ntp statistics { **io** | **local** | **memory** | **peer** { **ipaddr** *address* | **name** *name1* [*..nameN*] }

Syntax Description		
io		Displays the input-output statistics.
local		Displays the counters maintained by the local NTP.
memory		Displays the statistics counters related to the memory code.
peer		Displays the per-peer statistics counter of a peer.
ipaddr <i>address</i>		Displays statistics for the peer with the configured IPv4 or IPv6 address. The IPv4 address format is dotted decimal, x.x.x.x. The IPv6 address format is hexadecimal A:B::C:D.
name <i>name1</i>		Displays statistics for a named peer.
<i>..nameN</i>		(Optional) Displays statistics for one or more named peers.

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples

This example shows how to display the statistics for NTP:

```
switch(config)# show ntp statistics local
```

Related Commands	Command	Description
	clear ntp statistics	Clears NTP statistics

show ntp timestamp-status

To display the Network Time Protocol (NTP) time-stamp information, use the **show ntp timestamp-status** command.

show ntp timestamp-status

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples	This example shows how to display the NTP time-stamp status: <pre>switch(config)# show ntp timestamp-status</pre>
-----------------	---

Related Commands	Command	Description
	clear ntp statistics	Clears NTP statistics
	ntp	Configures NTP peers and servers on the switch.

show ptp brief

To display the PTP information, use the **show ptp brief** command.

show ptp brief

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Global configuration mode

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples This example shows how to display the PTP status:

```
switch(config)# show ptp brief
```

Related Commands	Command	Description
	show ptp clock	Displays the properties of the local clock.
	show ptp clocks foreign-masters-record	Displays the state of foreign masters known to the PTP process.
	show ptp corrections	Displays the last few PTP corrections.
	show ptp parent	Displays the properties of the PTP parent and grandmaster clock.
	show ptp port interface	Displays the status of the PTP port.
	show ptp time-property	Displays the PTP clock time properties.

show ptp clock

To display the properties of the local PTP clock including clock identity, use the **show ptp clock** command.

show ptp clock

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples	This example shows how to display the properties of the local clock: <pre>switch(config)# show ptp clock</pre>
-----------------	---

Related Commands	Command	Description
	show ptp brief	Displays the PTP status.
	show ptp clocks foreign-masters-record	Displays the state of foreign masters known to the PTP process.
	show ptp corrections	Displays the last few PTP corrections.
	show ptp parent	Displays the properties of the PTP parent and grandmaster clock.
	show ptp port interface	Displays the status of the PTP port.
	show ptp time-property	Displays the PTP clock time properties.

show ptp clocks foreign-masters-record

To display the state of the foreign masters known to the PTP process, use the **show ptp clocks foreign-masters-record** command.

show ptp clocks foreign-masters-record [*ethernet slot[/QSFP-module/]port*]

Syntax Description

ethernet	Specifies an Ethernet interface.
<i>slot[/QSFP-module/]port</i>	(Optional) Specifies the Ethernet interface and its slot number and port number. The slot number is from 1 to 255. The <i>QSFP-module</i> number is from 1 to 4. The port number is from 1 to 128.
Note	The <i>QSFP-module</i> number applies only to the QSFP+ Generic Expansion Module (GEM).

Command Modes

Global configuration mode

Command History

Release	Modification
6.0(2)N1(2)	Support for the QSFP+ GEM was added.
5.2(1)N1(1)	This command was introduced.

Usage Guidelines

For each foreign master, the output displays the clock identity, basic clock properties, and whether the clock is being used as a grandmaster.

Examples

This example shows how to display the foreign masters known to the PTP process:

```
switch(config)# show ptp foreign-masters-record
```

Related Commands

Command	Description
show ptp brief	Displays the PTP status.
show ptp clock	Displays the properties of the local clock.
show ptp corrections	Displays the last few PTP corrections.
show ptp port interface	Displays the status of the PTP port.
show ptp parent	Displays the properties of the PTP parent and grandmaster clock.
show ptp time-property	Displays the PTP clock time properties.

show ptp corrections

To display the last few PTP corrections, use the **show ptp corrections** command.

show ptp corrections

Syntax Description	There are no arguments or keywords for this command.
---------------------------	--

Command Default	None
------------------------	------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples	This example shows how to display the most recent PTP corrections on the switch: <pre>switch(config)# show ptp corrections</pre>
-----------------	---

Related Commands	Command	Description
	show ptp brief	Displays the PTP status.
	show ptp clock	Displays the properties of the local clock.
	show ptp clocks foreign-masters-record	Displays the state of foreign masters known to the PTP process.
	show ptp port interface	Displays the status of the PTP port.
	show ptp parent	Displays the properties of the PTP parent and grandmaster clock.
	show ptp time-property	Displays the PTP clock time properties.

show ptp parent

To display the properties of the PTP parent and grandmaster clock, use the **show ptp parent** command.

show ptp parent

Syntax Description There are no arguments or keywords for this command.

Command Default None

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples This example shows how to display the properties of the PTP parent and grandmaster clock:

```
switch(config)# show ptp parent
```

Related Commands	Command	Description
	show ptp brief	Displays the PTP status.
	show ptp clock	Displays the properties of the local clock.
	show ptp clocks foreign-masters-record	Displays the state of foreign masters known to the PTP process.
	show ptp corrections	Displays the last few PTP corrections.
	show ptp port interface	Displays the status of the PTP port.
	show ptp time-property	Displays the PTP clock time properties.

show ptp port interface

To display the status of the PTP port, use the **show ptp port interface ethernet** command.

show ptp port interface [**ethernet** *slot*[/*QSFP-module*]/*port*]

Syntax Description	ethernet	Specifies an Ethernet interface.
	<i>slot</i> [/ <i>QSFP-module</i>]/ <i>port</i>	(Optional) Specifies the Ethernet interface and its slot number and port number. The <i>slot</i> number is from 1 to 255. The <i>QSFP-module</i> number is from 1 to 4. The <i>port</i> number is from 1 to 128.
	Note	The <i>QSFP-module</i> number applies only to the QSFP+ Generic Expansion Module (GEM).

Command Default	None
------------------------	------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	6.0(2)N1(2)	Support for the QSFP+ GEM was added.
	5.2(1)N1(1)	This command was introduced.

Examples This example shows how to display the status of the PTP port on the switch:

```
switch(config)# show ptp port interface ethernet 5/1
```

Related Commands	Command	Description
	show ptp brief	Displays the PTP status.
	show ptp clock	Displays the properties of the local clock.
	show ptp clocks foreign-masters-record	Displays the state of foreign masters known to the PTP process.
	show ptp corrections	Displays the last few PTP corrections.
	show ptp port interface	Displays the status of the PTP port.
	show ptp parent	Displays the properties of the PTP parent and grandmaster clock.
	show ptp time-property	Displays the PTP clock time properties.

show ptp time-property

To display the PTP clock time properties, use the **show ptp time-property** command.

show ptp time-property

Syntax Description There are no arguments or keywords for this command.

Command Default None

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples This example shows how to display the PTP clock time properties:

```
switch(config)# show ptp time-property
```

Related Commands	Command	Description
	show ptp brief	Displays the PTP status.
	show ptp clock	Displays the properties of the local clock.
	show ptp clocks foreign-masters-record	Displays the state of foreign masters known to the PTP process.
	show ptp corrections	Displays the last few PTP corrections.
	show ptp parent	Displays the properties of the PTP parent and grandmaster clock.
	show ptp port interface	Displays the status of the PTP port.

show running-config monitor

To display the running configuration for the Switched Port Analyzer (SPAN) or Encapsulated Remote Switched Port Analyzer (ERSPAN) session, use the **show running-config monitor** command.

show running-config monitor [all]

Syntax Description	all	(Optional) Displays current SPAN configuration information including default settings.
Command Default	None	
Command Modes	EXEC mode	
Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples

This example shows how to display information on the running SPAN configuration:

```
switch# show running-config monitor

!Command: show running-config monitor
!Time: Thu Jan  1 06:48:56 2009

version 5.2(1)N1(1)
monitor session 1
  description A Local SPAN session
  source interface Ethernet1/5 both
  destination interface Ethernet1/21
  no shut

switch#
```

This example shows how to display detailed information on the running SPAN configuration:

```
switch# show running-config monitor all

!Command: show running-config monitor all
!Time: Thu Jan  1 06:51:08 2009

version 5.2(1)N1(1)
monitor session 1 type local
  description A Local SPAN session
  source interface Ethernet1/5 both
  destination interface Ethernet1/21
  no shut

switch#
```

Related Commands	Command	Description
	monitor session	Configures SPAN or ERSPAN sessions.
	show monitor session	Displays information about SPAN or ERSPAN sessions.

show running-config port-security

To display the running system configuration information about secure ports, use the **show running-config port-security** command.

show running-config port-security [all]

Syntax Description	all	(Optional) Displays detailed information about secure ports, including default settings.
---------------------------	------------	--

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Usage Guidelines	This command does not require a license.
-------------------------	--

Examples	This example shows how to display the running system configuration of all secure ports on an interface:
-----------------	---

```
switch# show running-config port-security

!Command: show running-config port-security
!Time: Tue Apr 12 10:06:56 2005

version 5.2(1)N1(1)
feature port-security

interface Ethernet1/5
  switchport port-security
  switchport port-security aging time 3
  switchport port-security maximum 10
  switchport port-security mac-address sticky

switch#
```

Related Commands	Command	Description
	clear port-security dynamic	Clears the dynamically secured addresses on a port.
	show startup-config port-security	Displays the configuration information in the startup file.

show snmp community

To display the Simple Network Management Protocol (SNMP) community strings configured on the switch, use the **show snmp community** command.

show snmp community

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples This example shows how to display the SNMP community strings:

```
switch# show snmp community
Community          Group / Access      context      acl_filter
-----
public             network-admin
switch#
```

Related Commands	Command	Description
	snmp-server community	Configures the community access string to permit access to the SNMP protocol.

show snmp context

To display the Simple Network Management Protocol (SNMP) contexts configured on the switch, use the **show snmp context** command.

show snmp context

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples	This example shows how to display the SNMP contexts: <pre>switch# show snmp context</pre>
-----------------	--

Related Commands	Command	Description
	snmp-server context	Configures an SNMP context.

show snmp engineID

To display the identification of the local Simple Network Management Protocol (SNMP) engine, use the **show snmp engineID** command.

show snmp engineID

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Usage Guidelines	An SNMP engine is a copy of SNMP that can reside on a local or remote device. SNMP passwords are localized using the SNMP engine ID of the authoritative SNMP engine.
-------------------------	---

Examples	This example shows how to display the SNMP engine ID:
-----------------	---

```
switch# show snmp engineID
Local SNMP engineID: [Hex] 8000000903000DECB230C0
                      [Dec] 128:000:000:009:003:000:013:236:178:048:192
switch#
```

Related Commands	Command	Description
	show running-config snmp	Displays the running configuration information about SNMP.

show snmp group

To display the names of the Simple Network Management Protocol (SNMP) groups configured on the switch, use the **show snmp group** command.

show snmp group

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples

This example shows how to display the SNMP groups:

```
switch# show snmp group
```

```
Role: network-admin
```

```
Description: Predefined network admin role has access to all commands
on the switch
```

Rule	Perm	Type	Scope	Entity
1	permit	read-write		

```
Role: network-operator
```

```
Description: Predefined network operator role has access to all read
commands on the switch
```

Rule	Perm	Type	Scope	Entity
1	permit	read		

```
Role: vdc-admin
```

```
Description: Predefined vdc admin role has access to all commands within
a VDC instance
```

Rule	Perm	Type	Scope	Entity
1	permit	read-write		

```
Role: vdc-operator
```

```
Description: Predefined vdc operator role has access to all read commands
within a VDC instance
```

Rule	Perm	Type	Scope	Entity
1	permit	read		

■ show snmp group

```

Role: priv-3
  Description: This is a system defined privilege role.
  vsan policy: permit (default)
  Vlan policy: permit (default)
  Interface policy: permit (default)
  Vrf policy: permit (default)

```

```

Role: priv-2
  Description: This is a system defined privilege role.
  vsan policy: permit (default)
  Vlan policy: permit (default)
  Interface policy: permit (default)
  Vrf policy: permit (default)

```

```

Role: priv-1
  Description: This is a system defined privilege role.
  vsan policy: permit (default)
  Vlan policy: permit (default)
  Interface policy: permit (default)
  Vrf policy: permit (default)

```

```

Role: priv-0
  Description: This is a system defined privilege role.
  vsan policy: permit (default)
  Vlan policy: permit (default)
  Interface policy: permit (default)
  Vrf policy: permit (default)

```

Rule	Perm	Type	Scope	Entity
10	permit	command		traceroute6 *
9	permit	command		traceroute *
8	permit	command		telnet6 *
7	permit	command		telnet *
6	permit	command		ping6 *
5	permit	command		ping *
4	permit	command		ssh6 *
3	permit	command		ssh *
2	permit	command		enable *
1	permit	read		

```

Role: priv-15
  Description: This is a system defined privilege role.
  vsan policy: permit (default)
  Vlan policy: permit (default)
  Interface policy: permit (default)
  Vrf policy: permit (default)

```

Rule	Perm	Type	Scope	Entity
1	permit	read-write		

```
switch#
```

Related Commands

Command	Description
show running-config snmp	Displays the running configuration information about SNMP.

show snmp host

To display the Simple Network Management Protocol (SNMP) host information, use the **show snmp host** command.

show snmp host

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples	This example shows how to display the SNMP host: <pre>switch# show snmp host</pre>
-----------------	---

Related Commands	Command	Description
	snmp-server host	Configures an SNMP host.

show snmp sessions

To display the current Simple Network Management Protocol (SNMP) sessions, use the **show snmp sessions** command.

show snmp sessions

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples This example shows how to display the SNMP sessions:

```
switch# show snmp sessions
```

Related Commands	Command	Description
	show running-config snmp	Displays the running configuration information about SNMP.

show snmp trap

To display the Simple Network Management Protocol (SNMP) link trap generation information, use the **show snmp trap** command.

show snmp trap

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples This example shows how to display the SNMP traps:

```
switch# show snmp trap
```

Trap type	Description	Enabled
entity	: entity_mib_change	Yes
entity	: entity_module_status_change	Yes
entity	: entity_power_status_change	Yes
entity	: entity_module_inserted	Yes
entity	: entity_module_removed	Yes
entity	: entity_unrecognised_module	Yes
entity	: entity_fan_status_change	Yes
link	: linkDown	Yes
link	: linkUp	Yes
link	: IETF-extended-linkDown	Yes
link	: IETF-extended-linkUp	Yes
link	: cisco-extended-linkDown	Yes
link	: cisco-extended-linkUp	Yes
callhome	: event-notify	No
callhome	: smtp-send-fail	No
cfs	: state-change-notif	No
cfs	: merge-failure	No
rf	: redundancy_framework	Yes
aaa	: server-state-change	No
license	: notify-license-expiry	Yes
license	: notify-no-license-for-feature	Yes
license	: notify-licensefile-missing	Yes
license	: notify-license-expiry-warning	Yes
zone	: unsupp-mem	No
upgrade	: UpgradeOpNotifyOnCompletion	Yes
upgrade	: UpgradeJobStatusNotify	Yes
feature-control	: FeatureOpStatusChange	No
sysmgr	: cseFailSwCoreNotifyExtended	No
rmon	: risingAlarm	No

■ show snmp trap

```

rmon          : fallingAlarm          No
rmon          : hcRisingAlarm         No
rmon          : hcFallingAlarm        No
config        : ccmCLIRunningConfigChanged No
snmp          : authentication        No
bridge        : topologychange        No
bridge        : newroot               No
stp           : inconsistency         No
stpx          : loop-inconsistency    No
stpx          : root-inconsistency    No
switch#

```

Related Commands

Command	Description
snmp trap link-status	Enables SNMP link trap generation.

show snmp user

To display information on each Simple Network Management Protocol (SNMP) user, use the **show snmp user** command.

show snmp user

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples This example shows how to display the SNMP users configured on the switch:

```
switch# show snmp user
```

```

      SNMP USERS
-----
User                               Auth  Priv(enforce) Groups
-----
admin                             md5   des(no)          network-admin
NOTIFICATION TARGET USERS (configured for sending V3 Inform)
-----
User                               Auth  Priv
-----
switch#
```

This example shows how to display information about a specific SNMP user:

```
switch# show snmp user admin
switch#
```

Related Commands	Command	Description
	snmp-server user	Configures a new user to an SNMP group.

show monitor session

To display information about the Switched Port Analyzer (SPAN) or Encapsulated Remote Switched Port Analyzer (ERSPAN) sessions, use the **show monitor session** command.

show monitor session [*session* | **all** [**brief**] | **range** *range* [**brief**] | **status**]

Syntax Description

<i>session</i>	(Optional) Number of the session. The range is from 1 to 18.
all	(Optional) Displays all sessions.
brief	(Optional) Displays a brief summary of the information.
range <i>range</i>	(Optional) Displays a range of sessions. The range is from 1 to 18.
status	(Optional) Displays the operational state of all sessions.
Note This keyword applies only to SPAN sessions.	

Command Default

None

Command Modes

EXEC mode

Command History

Release	Modification
5.2(1)N1(1)	This command was introduced.

Examples

This example shows how to display information about SPAN session 1:

```
switch# show monitor session 1
session 1
-----
description      : A Local SPAN session
type             : local
state            : down (No operational src/dst)
source intf      :
    rx           : Eth1/5
    tx           : Eth1/5
    both         : Eth1/5
source VLANs     :
    rx           :
source VSANs     :
    rx           :
destination ports : Eth1/21
```

Legend: f = forwarding enabled, l = learning enabled

```
switch#
```

This example shows how to display a brief information about a SPAN session:

```
switch# show monitor session range 1 brief
session 1
-----
```

```

description      : A Local SPAN session
type             : local
state            : down (No operational src/dst)
source intf      :
    rx           : Eth1/5
    tx           : Eth1/5
    both         : Eth1/5
source VSANs     :
destination ports : Eth1/21

```

Legend: f = forwarding enabled, l = learning enabled

switch#

This example shows how to display the information about an ERSPAN session:

```

switch# show monitor session 1
session 1
-----
description      : ERSPAN Source configuration
type             : erspan-source
state            : down (No valid global IP Address)
flow-id          : 1
vrf-name         : default
destination-ip    : 192.0.2.1
ip-ttl           : 255
ip-dscp          : 0
origin-ip        : origin-ip not specified
source intf      :
    rx           : Eth1/5
    tx           : Eth1/5
    both         : Eth1/5
source VLANs     :
    rx           : 5
switch#

```

Related Commands

Command	Description
monitor session	Creates a new Switched Port Analyzer (SPAN) session configuration.
show running-config monitor	Displays the running configuration information about SPAN sessions.



V Commands

This chapter describes the system management commands available that begin with V.

verify (session)

To verify the current configuration session, use the **verify** command.

verify

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Session configuration mode
----------------------	----------------------------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples	This example shows how to verify a session: <pre>switch(config-s)# verify Failed to start Verification: Session Database already locked, Verify/Commit in Progress. switch(config-s)#</pre>
-----------------	---

Related Commands	Command	Description
	commit	Commits a session.
	configure session	Creates a configuration session.
	show configuration session	Displays the contents of the session.

vrf (ERSPAN)

To configure a virtual routing and forwarding (VRF) instance for Encapsulated Remote Switched Port Analyzer (ERSPAN) traffic forwarding in the source, use the **vrf** command. To revert to the defaults, use the **no** form of this command.

```
vrf { vrf_name | default | management }
```

```
no vrf { vrf_name | default | management }
```

Syntax Description	<i>vrf_name</i>	Name of the VRF. The VRF name can be any case-sensitive, alphanumeric string up to 32 characters.
	default	Specifies the default VRF instance.
	management	Specifies the management VRF instance.

Command Default	None
------------------------	------

Command Modes	ERSPAN session configuration mode
----------------------	-----------------------------------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Usage Guidelines	This command does not require a license.
-------------------------	--

Examples	This example shows how to configure a VRF instance for the ESRSPAN source:
-----------------	--

```
switch# configure terminal
switch(config)# monitor session 1 type erspan-source
switch(config-erspan-src)# vrf default
switch(config-erspan-src)#
```

Related Commands	Command	Description
	monitor-session	Enters the monitor configuration mode for configuring an ERSPAN session for analyzing traffic between ports.
	show monitor session	Displays information about the Ethernet switched port analyzer (SPAN) or ERSPAN monitor session.



System Message Logging Facilities

This appendix contains the system message logging information. [Table A-1](#) lists the facilities that you can use in system message logging configuration.

Table A-1 **System Message Logging Facilities**

Facility	Description
aaa	Sets level for aaa syslog messages.
aclmgr	Sets level for aclmgr syslog messages.
adjmgr	Sets syslog filter level for Adjacency Manager.
afm	Sets level for afm syslog messages.
all	Sets level for all facilities.
altos	Altos syslog level.
arp	Sets syslog filter level for ARP.
ascii-cfg	Sets the logging level for ascii-cfg.
auth	Sets level for Authorization System.
authpriv	Sets level for Authorization (Private) system.
backup	Sets level for switchport backup syslog messages.
bootvar	Sets level for bootvar.
callhome	Callhome syslog level.
capability	Sets syslog level for mig utils daemon.
cdp	Sets logging level for CDP.
cert-enroll	Cert-enroll syslog level.
cfs	Sets logging level for CFS.
clis	Sets syslog filter level for CLIS.
core	Core daemon syslog level.
cron	Sets level for Cron/at facility.
daemon	Sets level for System daemons.
dcbx	Sets level for dcx syslog messages.
device-alias	Sets syslog level for Device Alias Distribution Service.
dhcp_snoop	Sets the level for DHCP snooping syslog messages.

Text Part Number:

Table A-1 System Message Logging Facilities (continued)

Facility	Description
dstats	Delta statistics syslog level.
epp	Sets level for EPP syslog messages.
ethpc	Sets level for ethpc syslog messages.
ethpm	Sets level for Ethernet Port Manager (ethpm) syslog messages.
evmc	Sets level for evmc syslog messages.
fabric_start_cfg_mgr	Sets the syslog filter level for FabricPath configuration manager.
fc2d	Sets level for fc2d syslog messages.
fcdomain	Sets level for fcdomain syslog messages.
fcns	Sets syslog filter level for name server.
fcoe_mgr	Sets the level for Fibre Channel over Ethernet (FCoE) manager syslog messages.
fcpc	Sets level for fcpc syslog messages.
fcs	Sets syslog filter level for FCS.
fdmi	Sets logging level for fdmi.
feature-mgr	Feature manager syslog level.
fex	Sets the level for Cisco Nexus 2000 Series Fabric Extender syslog messages.
flexlink	Sets level for switchport backup syslog messages.
flogi	Configure level for flogi syslog messages.
fs-daemon	FS daemon syslog level.
fspf	FSPF syslog level.
ftp	Sets level for File Transfer System.
fwm	Sets level for fwm syslog messages.
gatos	Gatos syslog level.
im	Sets level for im syslog messages.
interface-vlan	Sets level for interface VLAN syslog messages.
ip	Sets level for IP syslog messages.
ipconf	Sets level for ipconf syslog messages.
ipqos	Sets level for ipqosmgr syslog messages.
kernel	Sets level for kernel.
l3vm	Sets syslog filter level for L3VM.
lacp	Sets level for LACP syslog messages.
license	Licensing syslog level. Note This facility was deprecated and replaced with the licmgr facility in Cisco NX-OS 5.0(2)N1(1). For backwards compatibility, it will be maintained for a number of releases.
licmgr	Licensing syslog level.

Table A-1 **System Message Logging Facilities (continued)**

Facility	Description
lldp	Sets level for LLDP syslog messages.
local0	Sets level for Local use daemons.
local1	Sets level for Local use daemons.
local2	Sets level for Local use daemons.
local3	Sets level for Local use daemons.
local4	Sets level for Local use daemons.
local5	Sets level for Local use daemons.
local6	Sets level for Local use daemons.
local7	Sets level for Local use daemons.
lpr	Sets level for Line Printer System.
m2rib	Sets level for Multicast Routing Information Base (MRIB) logging messages.
mail	Sets level for Mail system.
mfdm	Sets level for multicast Forwarding Information Base (FIB) distribution (MFDm) syslog messages.
mfwd	Sets level for multicast forwarding system messages.
monitor	Sets level for ethernet Switched Port Analyzer (SPAN) syslog messages.
news	Sets level for USENET news.
nohms	Sets level for nohms syslog messages.
nqosm	Sets level for nqosm syslog messages.
ntp	Sets syslog filter level for NTP.
pfm	Sets level for pfm syslog messages.
pktmgr	Sets syslog filter level for Packet Manager.
plugin	Sets level for plugin syslog messages.
port	Sets level for port syslog messages.
port-channel	Sets level for EtherChannel syslog messages.
port-profile	Sets level for port profile syslog messages.
port-resources	Sets level for prm syslog messages.
provision	Sets level for provision syslog messages.
qd	Sets level for qd syslog messages.
radius	RADIUS syslog level.
rdl	Sets logging level for RDL.
res_mgr	Set slevel for res_mgr syslog messages.
rib	Sets level for rib.
rlir	Sets level for RLIR.
routing	Sets level for routing information.

Table A-1 System Message Logging Facilities (continued)

Facility	Description
rscn	Sets level for RSCN.
san-port-channel	Sets level for san-port-channel syslog messages.
scsi-target	SCSI target daemon syslog level.
security	Security syslog level.
session	Sets level for session-manager syslog messages. Note This facility was deprecated and replaced with the session-mgr facility in Cisco NX-OS 5.0(2)N1(1). For backward compatibility, it will be maintained for a number of releases.
session-mgr	Sets level for session-manager syslog messages.
smm	Sets logging level for Shared Memory Manager.
snmpd	Sets level for SNMP syslog messages.
sifmgr	Sets level for sifmgr syslog messages.
spanning-tree	Sets level for stp syslog messages.
stp	Sets level for stp syslog messages.
syslog	Sets level for Internal Syslog Messages.
sysmgr	System Manager syslog level.
tacacs	TACACS+ syslog level.
track	Sets level for object tracking messages.
tcpudp	Sets syslog filter level for TCPUDP.
track	Sets level for track syslog messages.
udld	Sets level for UDLD syslog messages.
ufdm	Sets level for unicast Forwarding Information Base (FIB) distribution (UFDM) syslog messages.
urib	Sets syslog filter level for Unicast Routing Information Base (URIB).
user	Sets level for User Process.
uucp	Sets level for Unix-to-Unix copy system.
vlan_mgr	Sets level for VLAN syslog messages.
vmm	Sets level for vmm syslog messages.
vpc	Sets level for vPC syslog messages.
vsan	VSAN syslog level.
vshd	Sets logging level for vshd.
vtp	Sets level for interface vlan syslog messages.
wwnm	Sets WWN Manager syslog level.
xml	XML agent syslog level.
zone	Sets syslog filter level for zone server.
zschk	Sets level for zschk syslog messages.