

# **T** Commands

This chapter describes the Cisco NX-OS Virtual Router Redundancy Protocol (VRRP) commands that begin with T.

## track (VRRP)

To modify the priority for a virtual router based on a tracked object, use the **track** command. To disable priority tracking for a virtual router, use the **no** form of this command.

track object-number [decrement value]

no track object-number [decrement value]

Syntax Description	object-number	Number for a configured tracked object. The range is from 1 to 500.	
	decrement value	(Optional) Decrements the VRRP priority if the tracked object is down. The range is from 1 to 254.	
Command Default	None		
Command Modes	VRRP configuration mode		
Command History	Release	Modification	
	5.2(1)N1(1)	This command was introduced.	
	configured tracked object. Use the track command to configure the tracked object. When the tracked object is down, the priority reverts to the priority value for the virtual router. When the tracked object is up, the priority of the virtual router is restored to the original value. This command does not require a license.		
Examples	This example shows how to enable object tracking for a virtual router: <pre>switch# configure terminal switch(config)# track 33 ip route 192.0.2.0/24 reachability switch(config)# interface ethernet 2/1 switch(config-if)# no switchport switch(config-if)# vrrp 250 switch(config-if-vrrp)# track 33 priority 2 switch(config-if-vrrp)#</pre>		
Related Commands	Command	Description	
	feature vrrp	Enables VRRP.	
	show vrrp	Displays VRRP configuration information.	

Command	<b>Description</b> Tracks the state of an interface and modifies the VRRP priority if that interface state goes down.	
track interfave (VRRP)		
vrrp	Configures a VRRP group.	

### track interface (VRRP)

To track the priority for a virtual router based on an interface, use the **track interface** command. To disable priority tracking for a virtual router, use the **no** form of this command.

track interface {ethernet slot/[QSFP-module/]port | port-channel number[.sub\_if\_number]}
priority value

**no track interface** {**ethernet** *slot/[QSFP-module/]port* | **port-channel** *number[.sub\_if\_number]*} **priority** *value* 

Syntox Description		
Syntax Description	<b>ethernet</b> slot/[QSFP-module/]port	Specifies the virtual router interface for which to track the priority. The <i>slot</i> number is from 1 to 255. The <i>QSFP-module</i> number is from 1 to 4. The <i>port</i> number is from 1 to 128.
		<b>Note</b> The <i>QSFP-module</i> number applies only to the QSFP+ Generic Expansion Module (GEM).
	port-channel number	Specifies the port-channel group for which to track priority. The range is from 1 to 4096
	sub_if-number	(Optional) Subinterface number. The range is from 1 to 4093.
	priority value	Specifies the interface priority for a virtual router. The range of values is from 1 to 254. If this router is the owner of the IP addresses, the value is automatically set to 254.
Command Default Command Modes	Disabled VRRP configuration mode	
Command History	Release	Modification
oonnana matory		Support for the QSFP+ GEM was added.
		This command was introduced.
Usage Guidelines	Use the <b>track</b> command to in the switch. When the tra	change the priority of the virtual router based on the state of another interface cked interface is down, the priority reverts to the priority value for the virtua interface is up, the priority of the virtual router is restored to the interface state

This command does not require a license.

#### Examples

This example shows how to enable interface state tracking for a virtual router:

```
switch# configure terminal
switch(config)# interface ethernet 2/1
switch(config-if)# no switchport
switch(config-if)# vrrp 250
switch(config-if-vrrp)# track interface ethernet 2/2 priority 2
switch(config-if-vrrp)#
```

#### Related Commandsl Co

Command	Description	
feature vrrp	Enables VRRP.	
show vrrp	Displays VRRP configuration information.	
track (VRRP)	Tracks an object to modify the VRRP priority.	
vrrp	Configures a VRRP group.	

