

# **E Commands**

This chapter describes the Cisco NX-OS Enhanced Interior Gateway Routing Protocol (EIGRP) commands that begin with E.

## eigrp log-neighbor-changes

To enable the logging of changes in Enhanced Interior Gateway Routing Protocol (EIGRP) neighbor adjacencies, use the **eigrp log-neighbor-changes** command. To disable the logging of changes in EIGRP neighbor adjacencies, use the **no** form of this command.

#### eigrp log-neighbor-changes

no eigrp log-neighbor-changes

Syntax Description	This command has no arg	guments or keywords.
Command Default	Adjacency changes are lo	ogged.
Command Modes	Address-family configuration mode Router configuration mode Router VRF configuration mode	
Command History	Release Mo	dification
	5.2(1)N1(1) Thi	is command was introduced.
Usage Guidelines	Use the <b>eigrp log-neighbor-changes</b> command to log neighbor adjacency changes to monitor the stability of the routing system and to detect problems. Logging is enabled by default. To disable the logging of neighbor adjacency changes, use the <b>no</b> form of this command. This command requires the LAN Base Services license.	
Examples	This example shows how to enable logging of neighbor changes for EIGRP process 209: switch(config)# router eigrp 209 switch(config-router)# eigrp log-neighbor-changes	
Related Commands	Command	Description
	log-adjacency-changes	Enables logging of EIGRP adjacency state changes.
	log-neighbor-changes	Enables logging of EIGRP neighbor changes.
	log-neighbor-warnings	Enables logging of EIGRP neighbor warnings.

## eigrp log-neighbor-warnings

To enable the logging of Enhanced Interior Gateway Routing Protocol (EIGRP) neighbor warning messages, use the **eigrp log-neighbor-warnings** command. To disable the logging of EIGRP neighbor warning messages, use the **no** form of this command.

eigrp log-neighbor-warnings [seconds]

no eigrp log-neighbor-warnings

Syntax Description	seconds	(Optional) Time interval (in seconds) between repeated neighbor warning messages. The range of seconds is from 1 to 65535.
Command Default	Neighbor warning messa	ges are logged.
Command Modes	Address-family configur Router configuration mo Router VRF configuratio	de
Command History	Release Mo	odification
	5.2(1)N1(1) Th	is command was introduced.
Usage Guidelines	the interval between repe	<b>bor-warnings</b> command to enable neighbor warning messages and to configure eated neighbor warning messages. the LAN Base Services license.
Examples	warning messages in 5-n	to log neighbor warning messages for EIGRP process 209 and to repeat the ninute (300 seconds) intervals:
	<pre>switch(config)# router switch(config-router)#</pre>	r eigrp 209 # eigrp log-neighbor-warnings 30
Related Commands	Command	Description
	log-adjacency-changes	Enables logging of EIGRP adjacency state changes.
	log-neighbor-changes	Enables logging of EIGRP neighbor changes.
	log-neighbor-warnings	Enables logging of EIGRP neighbor warnings.

## eigrp router-id

To set the router ID used by the Enhanced Interior Gateway Routing Protocol (EIGRP) when communicating with its neighbors, use the **eigrp router-id** command. To remove the configured router ID, use the **no** form of this command.

eigrp router-id *ip-address* 

no eigrp router-id ip-address

Syntax Description	ip-address	Router ID in dotted decimal notation.	
Command Default	EIGRP automatic	ally selects an IP address to use as the router ID when an EIGRP process is started.	
Command Modes	Address-family configuration mode Router configuration mode Router VRF configuration mode		
Command History	Release	Modification	
	5.2(1)N1(1)	This command was introduced.	
Usage Guidelines	<ul> <li>EIGRP automatically selects an IP address to use as the router ID when an EIGRP process is started. T highest local IP address is selected and loopback interfaces are preferred. The router ID is not chang unless the EIGRP process is removed with the <b>no router eigrp</b> command or if the router ID is manual configured with the <b>eigrp router-id</b> command.</li> <li>Use the <b>eigrp router-id</b> command to manually configure the router ID for EIGRP. The router ID is us to identify the originating router for external routes. If an external route is received with the local rout ID, the route is discarded. The router ID can be configured with any IP address with two exceptions; 0.0.0.0 and 255.255.255.255 are not legal values and cannot be entered. You should configure a uniq value for each router.</li> </ul>		
	This command re	quires the LAN Base Services license.	
Examples	This example shows how to configure 172.16.1.3 as a fixed router ID:		
		<pre>router eigrp 209 outer)# eigrp router-id 172.16.1.3</pre>	
Related Commands	Command	Description	
	show ip eigrp	Displays a summary of the EIGRP processes.	

#### eigrp stub

To configure a router as a stub using the Enhanced Interior Gateway Routing Protocol (EIGRP), use the **eigrp stub** command. To disable the EIGRP stub routing feature, use the **no** form of this command.

eigrp stub [direct | leak-map map-name | receive-only | redistributed]

**no eigrp stub** [direct | leak-map *map-name* | receive-only | redistributed]

Syntax Description	direct	(Optional) Advertises directly connected routes.	
-,p	leak-map map-name	(Optional) Allows dynamic prefixes based on the leak map.	
	receive-only	(Optional) Sets the router as a receive-only neighbor.	
	redistributed	(Optional) Advertises redistributed routes from other protocols and autonomous systems.	
Command Default	Disabled		
Command Modes	Address-family configuration mode Router configuration mode Router VRF configuration mode		
Command History	Release	Modification	
	5.2(1)N1(1)	This command was introduced.	
Usage Guidelines	Use the <b>eigrp stub</b> command to configure a router as a stub where the router directs all IP traffic to a distribution router. The <b>direct</b> keyword permits EIGRP stub routing to advertise connected routes. This option is enabled by default.		
	The <b>receive-only</b> keyword restricts the router from sharing any of its routes with any other router in that EIGRP autonomous system, and the <b>receive-only</b> keyword does not permit any other option to be specified because it prevents any type of route from being sent.		
	The <b>redistributed</b> keyword permits the EIGRP Stub Routing feature to send other routing protocols and autonomous systems. Without the configuration of this option, EIGRP does not advertise redistributed routes.		
	If you use any of these four keywords ( <b>direct</b> , <b>leak-map</b> , <b>receive-only</b> , <b>redistributed</b> ) with the <b>eigrp stub</b> command, only the route types specified by the particular keyword are advertised.		
	This command require	es the LAN Base Services license.	
Examples	This example shows how to configure the router as a receive-only neighbor:		
	switch(config)# <b>rou</b>	ter eigrp 1	

switch(config-router)# eigrp stub receive-only

Related	Commands
---------	----------

Command	Description
show ip eigrp	Displays a summary of the EIGRP processes.