

S Commands

This chapter describes the Cisco NX-OS Enhanced Interior Gateway Routing Protocol (EIGRP) commands that begin with S.

shutdown (EIGRP)

To shut down an instance of Enhanced Interior Gateway Routing Protocol (EIGRP), use the **shutdown** command. To disable this function, use the **no** form of this command.

shutdown

no shutdown

| Syntax Description | This command has no a | arguments or keywords. |
|--------------------|-----------------------|------------------------|
|--------------------|-----------------------|------------------------|

Command Default Enabled

Command Modes Address family configuration mode Router configuration mode Router VRF configuration mode

| Command History | Release | Modification |
|-----------------|-------------|------------------------------|
| | 5.2(1)N1(1) | This command was introduced. |

Usage GuidelinesUse the shutdown command to disable an instance of EIGRP without removing the configuration.This command requires the LAN Base Services license.

Examples This example shows how to disable eigrp 209:

switch(config)# router eigrp 209
switch(config-router)# shutdown
switch(config-router)#

| Related Commands | Command | Description |
|-------------------------|---------------------------------------|--|
| | copy running-config startup-config | Saves the configuration in the startup configuration file. |
| | show ip eigrp interfaces | Displays information about EIGRP interfaces. |

stub

To configure a router as a stub using the Enhanced Interior Gateway Routing Protocol (EIGRP), use the **stub** command. To disable the EIGRP stub routing feature, use the **no** form of this command.

stub [direct | leak-map map-name| receive-only | redistributed]

no stub [direct | leak-map map-name| receive-only | redistributed]]

| Syntax Description | direct | (Optional) Advertises directly connected routes. | |
|--------------------|--|---|--|
| - <i>,</i> | leak-map map-name | (Optional) Allows dynamic prefixes based on the leak map. | |
| | receive-only | (Optional) Sets the router as a receive-only neighbor. | |
| | redistributed | (Optional) Advertises redistributed routes from other protocols and autonomous systems. | |
| Command Default | Disabled | | |
| Command Modes | Address-family configu Router configuration mo Router VRF configurati | ode | |
| Command History | Release | Modification | |
| | 5.2(1)N1(1) | This command was introduced. | |
| Usage Guidelines | Use the stub command to configure a router as a stub where the router directs all IP traffic to a distribution router. The direct keyword permits EIGRP stub routing to advertise connected routes. This option is enabled by default. | | |
| | The receive-only keyword restricts the router from sharing any of its routes with any other router in that EIGRP autonomous system, and the receive-only keyword does not permit any other option to be specified because it prevents any type of route from being sent. | | |
| | The redistributed keyword permits EIGRP stub routing to send other routing protocols and autonomous systems. Without the configuration of this option, EIGRP does not advertise redistributed routes. | | |
| | If you use any of these four keywords (direct , leak-map , receive-only , redistributed) with the stub command, only the route types specified by the particular keyword(s) are advertised. | | |
| | This command requires | the LAN Base Services license. | |
| Examples | This example shows how | w to configure the router as a receive-only neighbor: | |
| | <pre>switch(config)# route switch(config-router)</pre> | | |

switch(config-router)#

Related Commands

| Command | Description |
|---------------------------------------|--|
| copy running-config startup-config | Saves the configuration changes to the startup configuration file. |
| show ip eigrp | Displays EIGRP information. |
| show ip eigrp neighbors | Displays EIGRP neighbor information. |

