



# M Commands

---

This chapter describes the basic Cisco NX-OS system commands that begin with M.

# modem in

To enable the modem connection on the console port, use the **modem in** command. To disable the modem connection, use the **no** form of this command.

**modem in**

**no modem in**

## Syntax Description

This command has no arguments or keywords.

## Command Default

Timeout is disabled.

## Command Modes

Terminal line configuration mode

## Command History

| Release     | Modification                 |
|-------------|------------------------------|
| 6.0(2)N1(1) | This command was introduced. |

## Usage Guidelines

You can configure the console port only from a session on the console port.

## Examples

This example shows how to enable a modem connection on the console port:

```
switch# configure terminal
switch(config)# line console
switch(config-console)# modem in
```

This example shows how to disable a modem connection on the console port:

```
switch# configure terminal
switch(config)# line console
switch(config-console)# no modem in
```

## Related Commands

| Command             | Description  |
|---------------------|--|
| <b>line console</b> | Enters console port configuration mode.                    |
| <b>show line</b>    | Displays information about the console port configuration. |

# modem init-string

To download the initialization string to a modem connected to the console port, use the **modem init-string** command. To revert to the default, use the **no** form of this command.

**modem init-string {default | user-input}**

**no modem init-string**

## Syntax Description

|                   |   |
|-------------------|---|
| <b>default</b>    | Downloads the default initialization string.    |
| <b>user-input</b> | Downloads the user-input initialization string. |

## Command Default

The default initialization string is ATE0Q1&D2&C1S0=1\015.

## Command Modes

Terminal line configuration mode

## Command History

| Release     | Modification                 |
|-------------|------------------------------|
| 6.0(2)N1(1) | This command was introduced. |

## Usage Guidelines

You can configure the console port only from a session on the console port.

The default initialization string ATE0Q1&D2&C1S0=1\015 is defined as follows:

- AT—Attention
- E0 (required)—No echo
- Q1—Result code on
- &D2—Normal data terminal ready (DTR) option
- &C1—Enable tracking the state of the data carrier
- S0=1—Pick up after one ring
- \015 (required)—Carriage return in octal

Use the **modem set-string** command to configure the user-input initialization string.

## Examples

This example shows how to download the default initialization string to the modem connected to the console port:

```
switch# configure terminal
switch(config)# line console
switch(config-console)# modem init-string default
```

This example shows how to download the user-input initialization string to the modem connected to the console port:

```
switch# configure terminal
```

```
switch(config)# line console
switch(config-console)# modem init-string user-input
```

This example shows how to remove the initialization string to the modem connected to the console port:

```
switch# configure terminal
switch(config)# line console
switch(config-console)# no modem init-string
```

#### Related Commands

| Command                 | Description  |
|-------------------------|--|
| <b>line console</b>     | Enters console port configuration mode.                      |
| <b>modem set-string</b> | Configures the user-input initialization string for a modem. |
| <b>show line</b>        | Displays information about the console port configuration.   |

# modem set-string user-input

To configure the user-input initialization string to download to a modem connected to the console port, use the **modem set-string user-input** command. To revert to the default, use the **no** form of this command.

**modem set-string user-input** *string*

**no modem set-string**

|                           |               |   |
|---------------------------|---------------|---|
| <b>Syntax Description</b> | <i>string</i> | User-input string. This string is alphanumeric and case sensitive, can contain special characters, and has a maximum of 100 characters. |
|---------------------------|---------------|---|

|                        |      |
|------------------------|------|
| <b>Command Default</b> | None |
|------------------------|------|

|                      |                                  |
|----------------------|----------------------------------|
| <b>Command Modes</b> | Terminal line configuration mode |
|----------------------|----------------------------------|

| <b>Command History</b> | Release     | Modification                 |
|------------------------|-------------|------------------------------|
|                        | 6.0(2)N1(1) | This command was introduced. |

|                         |   |
|-------------------------|---|
| <b>Usage Guidelines</b> | You can configure the console port only from a session on the console port. |
|-------------------------|---|

|                 |   |
|-----------------|---|
| <b>Examples</b> | This example shows how to configure the user-input initialization string for the modem connected to the console port: |
|-----------------|---|

```
switch# configure terminal
switch(config)# line console
switch(config-console)# modem set-string user-input ATE0Q1&D2&C1S0=3\015
```

This example shows how to revert to the default user-input initialization string for the modem connected to the console port:

```
switch# configure terminal
switch(config)# line console
switch(config-console)# no modem set-string
```

| <b>Related Commands</b> | Command                  | Description  |
|-------------------------|--------------------------|--|
|                         | <b>line console</b>      | Enters console port configuration mode.                    |
|                         | <b>modem init-string</b> | Downloads the user-input initialization string to a modem. |
|                         | <b>show line</b>         | Displays information about the console port configuration. |

# move

To move a file from one directory to another, use the **move** command.

```
move {[filesystem:] [/server/] [directory] source-filename} [filesystem:] [/server/] [directory]
[destination-filename]
```

## Syntax Description

|                             |  |
|-----------------------------|--|
| <i>filesystem:</i>          | (Optional) Name of the file system. Valid values are <b>bootflash</b> , <b>debug</b> , <b>modflash</b> , or <b>volatile</b> .  |
| <i>/server/</i>             | (Optional) Name of the server. Valid values are <b>///</b> , <b>//module-1/</b> , <b>//sup-1/</b> , <b>//sup-active/</b> , or <b>//sup-local/</b> . The double slash (//) is required. |
| <i>directory</i>            | (Optional) Name of a directory. The directory name is case sensitive.  |
| <i>source-filename</i>      | Name of the file to move. The filename is case sensitive.  |
| <i>destination-filename</i> | (Optional) Name of the destination file. The filename is alphanumeric, case sensitive, and has a maximum of 64 characters.   |

## Command Default

The default filename for the destination file is the same as the source file.

## Command Modes

EXEC mode

## Command History

| Release     | Modification                 |
|-------------|------------------------------|
| 6.0(2)N1(1) | This command was introduced. |

## Usage Guidelines

You can make a copy of a file by using the **copy** command.



### Tip

You can rename a file by moving it within the same directory.

## Examples

This example shows how to move a file to another directory:

```
switch# move file1 my_files/file2
```

This example shows how to move a file to another file system:

```
switch# move file1 volatile:
```

This example shows how to move a file to another supervisor module:

```
switch# move file1 bootflash://sup-1/file1.bak
```

**Related Commands**

| Command       | Description   |
|---------------|---|
| <b>cd</b>     | Changes the current working directory.              |
| <b>copy</b>   | Makes a copy of a file.                             |
| <b>delete</b> | Deletes a file or directory.                        |
| <b>dir</b>    | Displays the directory contents.                    |
| <b>pwd</b>    | Displays the name of the current working directory. |

